NOTICE FOR USE
Lubrication system prompt
Every 1200 hours Every1200h
Every 600 hours Every600h
Every 300 hours Every300h
Every 100 hours Every100h
Daily every day
Radiator
Rear wheel bearing
Cooling pump
Hydraulic
Front wheel bearing
Brake Clutch Fretting
pedal
Oil pump drive device
Crankshaft box
Distributor
Fuel injection pump
Brake fluid
Transmission shaft
Differential
Grease
Wheel bearing grease
Cooling pump grease
Engine lubricating oil
Gear oil
Hydraulic oil
Brake fluid
Torque converter oil
Clean soft water
Supply
Replace
Infinity XI