12/16/08 Carter Color Coat 505-0808-003

0700 START and ERRS on-site. Weather is to be cold, high of 22°F.

ERRS to start sweeping the remaining dry solids from the second floor.

1125 ERRS has mini-excavator delivered on-site

1200 Break for lunch.

1230 Back from lunch.

1730 ERRS finishes sweeping the solids on the second floor.

START and ERRS off-site.

Shawn Campbell
12/16/08

12/17/08 Carter Color Coat 505-0808-003

0700 START and ERRS on site. Weather is snow with 30°F. ERRS to pack the PCB ballasts for disposal, clean out wood block from the elevator shaft. and start sweeping the first floor.

195 START Campbell ~~take~~ collects a sample from the trucky ramp to take to EQ for disposal.

1030 START Campbell leaves site to drop sample off at EQ.

1200 Break for lunch.

1230 Back from lunch.

1420 mini-excavator taken off-site.

1730 START and ERRS off-site

Shawn Campbell
12/17/08

12/18/08 Carter Color Coat 505-0808-003

0700 START and EARS on-site, weather is cold, high of 26°F. EARS will load trucks with wood block, finish removing the wood block floor and sweeping the first floor.

1200 Break for lunch

1230 Back from lunch

1530 START Campbell off-site.