Spreadsheet - Calcs

excess air BP O_2 basis
BP CO_2 basis

Excess Air @ furnace (EA BP - DFA 2)

O_2 test grid E/W average dry basis > convert to wet
O_2 CR ~~dry~~ wet basis

Calc
excess air @ stack

CO on % basis

CO ppm → CO #/mbtu equation
NOx #/mbtu → NOx ppm
~~BP~~ correction ~~BP~~ CO ppm same basis as NOx ppm