Site Name:	Operational Period:	U.S. EPA Region 6
Task Order 62 CES Environmental	Date: 3-20-2015	**DAILY WORK ORDER**
Branch: Federal	Division/ Group: Response	mergency and Rapid Response Service

WORK AUTHORIZED:

Continue to pump water on site as necessary, depending on rainfall.

Continue development of profiles and disposal of sludge, liquids, and solids.

Continue removal of water, oil, sludge, and waste, from the ASTs, Frac Tanks, Totes, and Drums.

Site Cerclis:#	TXD 008950461	On-Scene Coordinator:	ERRS Response Manager
Contract Number:	EP – S6 - 07 -02	Gary Moore, USEPA	LeRoy Cassidey, CB&I Federal
Task Order:	062	Date: 3.20.2015 Time:1700	Date: 3.20.2015 Time: 1700

PERSONNEL ON-SITE:	QTY	Used	Unused
Response Manager	1	1	
Foreman	1	1	
	0	0	
Truck Driver/Equip Op	1	1	
Laborer	3	3	
Health and Safety Manager	0	0	
PERSONNEL OFF-SITE			
Subcontract Manager	1	1	
Transport and Disposal Coord	1	1	
Field Cost Accountant	1	1	

EQUIPMENT ON-SITE:	QTY	USED	Unused
Pick –up Truck	2	2	
Generator	2	2	
Trash Pumps	1	1	
Utility Trailer	0	0	
Frac Tank w Liner	1	1	
4,000 PSI Pressure Washer	1	1	
Open Top Roll Off	8	8	
Vacuum Truck Air Mover	1	1	
Carbon Vapor Unit	1	1	
Skid Steer	0	0	
Vacuum/OT Boxes	22	22	
9,000 lb Overhead Lift	1	1	
Storage Trailer	1	1	
Myers (Bean) Pump	1	1	
Air Compressor	1	1	
Acid Pump	1	1	

WORK ACCOMPLISHED / AMENDMENTS *(problem areas, general comments, summary)(Input for day's 1, 900-5Pon5):*

The RM continued processing of operational-H/Safety paperwork, invoice approvals, and Truck Log and Tank/Tote/Drum spreadsheets. Received analysis from Test America.

T&D Coordinator continued to work with CB&I and TCEQ on future waste streams with US Ecology and Clean Harbors.

The crew rinsed FT 215012 and FT 33527. Continued removal of acidic material from ST 1.

Republic Services transported and disposed cut up empty drums and totes for OT 25337. TIBC picked up load for Lonestar Ecology from FT 30335.

OSC	Date:	Time:	RM	Date: 3.23.2015	Time:0900
Gary Moore	3/23/15	1427			

Next OPERATIONAL PERIOD *(administrative, tactical / resource status changes, special instructions, H&S)(Input for next DWO):*

Continue Acid Transfer from ST 1. Remove all liquids.

Try removal of residual material from FT 1004 and rinse. Transfer material into VB 25206 and VB 25274.

Pump water from rain event.

9858499