



DAMES & MOORE

A PROFESSIONAL LIMITED PARTNERSHIP

6 COMMERCE DRIVE, CRANFORD, NEW JERSEY 07016-1101 (201) 272-8300

SDMS Document



67894

October 26, 1987

*IF sent copy
to Lisa
Vidulich
for review
11/5/87*

Ms Janet Feldstein
SCP - Carlstadt Project Officer
U.S. Environmental Protection Agency
26 Federal Plaza
New York, New York 10278

Re: Revision No.4
Project Operations Plan
SCP Site Remedial Investigation
Carlstadt, New Jersey

Dear Ms. Feldstein:

The attached revisions to the March 4, 1987 Project Operations Plan (POP) are intended to enhance the analytical Program for the resampling event. These revisions were discussed with Ms. Lisa Vidulich of EPA - Edison on October 21, 1987 and we received her verbal approval. The Revision 4 Parameter Table is attached and supercedes the Revision 3 Table of August 10, 1987.

To complete our documentation of the revisions, we request that the revisions be approved by the EPA in writing.

Very truly yours,

DAMES & MOORE

Gerard M. Coscia, P.E.
Project Manager

GMC/nam
Attachments

cc: Mr. Morris, IBM
Mr. Armstrong, GE
Mr. J. Koczan, Dames & Moore

003607

TABLE A-2

Parameter Table

Parameter	No. of Samples ⁽³⁾	Sample Matrix	Analytical Method and Reference ⁽⁴⁾	Sample Preservation	Holding Time
Volatile Organics (plus xylenes, styrene and MEK) ⁽¹⁾	16	Water	USEPA Method 624	Cool, 4°C	7 days
Extractable Organics	16	Water	USEPA Method 625	Cool, 4°C	7 days till extraction: 40 days till analysis
Metals	32 ⁽⁵⁾	Water	USEPA Method 200 series	Nitric acid to ⁽⁶⁾ pH 2 and cool, 4°C	6 months
PCB	16	Water	USEPA Method 608	Cool, 4°C	7 days till extraction: 40 days till analysis
Pesticides	16	Water	USEPA Method 608	Cool, 4°C	7 days till extraction: 40 days till analysis
Acidity	16	Water	USEPA Method 305.1	Cool, 4°C	14 days
Alkalinity	16	Water	USEPA Method 310.1	Cool, 4°C	14 days
Petroleum Hydrocarbons	16	Water	USEPA Method 418.1	Sulfuric acid to pH 2 and cool, 4°C	28 days
Total Cyanides	16	Water	USEPA Method 335.3	Sodium Hydroxide to pH 12 and cool, 4°C ⁽⁹⁾	14 days
Total Phenols	16	Water	USEPA Method 420.2	Sulfuric acid to pH 2 and cool, 4°C	28 days
Volatile Organics (plus xylenes, styrene and MEK) ⁽¹⁾	49	Soil	USEPA SW-846 (5030,8240)	Cool, 4°C	14 days
Extractable Organics	49	Soil	USEPA SW-846 (3550,8270)	Cool, 4°C	14 days till extraction: 40 days till analysis
Metals	49	Soil	USEPA SW-846 (3050,6010)	Cool, 4°C	6 months
PCB	49	Soil	USEPA SW-846 (3550,8080)	Cool, 4°C	7 days till extraction: 40 days till analysis
Pesticides	49	Soil	USEPA SW-846 (3550,8080)	Cool, 4°C	7 days till extraction: 40 days till analysis
Petroleum Hydrocarbons ⁽²⁾	49	Soil	USEPA Method 418.1	Cool, 4°C	7 days till extraction: 30 days till analysis
Total Cyanides	49	Soil	USEPA Method 335.2 ⁽⁷⁾	Cool, 4°C	14 days
Total Phenols	49	Soil	USEPA Method 420.1 ⁽⁸⁾	Cool, 4°C	28 days

Reference: Federal Register 40 CFR, Part 136, October 26, 1984.
 Field Sampling Procedures Manual, New Jersey Dept. of Environmental Protection, November, 1985.
 ECRA Sampling Plan Guide (draft), New Jersey Dept. of Environmental Protection, June, 1986.
 Methods for Chemical Analysis of Water & Wastes, USEPA - 600/4-79-020, March 1983.
 USEPA SW-846 Third Edition Methodologies (QA in Accordance with Appendix E of POP).

- Notes: (1) In the analysis of methyl ethyl ketone (MEK), styrene and xylenes from water samples, an extra spike is added for analyses using Method 624. For SW-846 analysis for soil samples, an extra spike is added and extraction procedures are followed.
- (2) The method to be used for petroleum hydrocarbons in soil is as follows: Prepare sample as per oil and grease method as found in "Procedures for Handling and Chemical Analysis of Sediment and Water Samples", EPA/CE-81-1, NTIS #AD-A103788, then follow EPA Method 418.1 starting with paragraph 7.7 (note: add 3g silica gel for every 100 ml of final extract).
- (3) Number of water samples reflects Round I water samples only. Round II water samples will be analyzed for target parameters only, following review of Round I sampling results and discussion with EPA. Number of soil samples includes eight sediment samples from Peach Island Creek.
- (4) For USEPA SW-846 Analytical Methods, the number in parenthesis for each parameter are the the Method Work-up Number and the Method Analysis Number, respectively.
- (5) Filtered and unfiltered samples will be collected.
- (6) For filtered samples, preservative will be added after filtering. For unfiltered samples, preservative will be added directly to sample jars.
- (7) As modified in the October 1986 CLP Statement of Work for Inorganics.
- (8) Combined with the procedure outlined in EPA 600/4-81-055.
- (9) After checking for the absence of sulfides with lead acetate paper.

003608