

Duty: 8/20/07

164333

Health & Safety Sign-off:

Sam Boakes

Sam Boakes

Joe Parisit

Joe Parisit

Sara Biedeman

Sara M. Biedeman

Jennifer Mueller

Jennifer Mueller

Gary Heller

Gary Heller 8/21/07

2. Wash components in warm water with a mild detergent or with a cleaner recommended by the manufacturer. A stiff bristle (not wire) brush may be used to facilitate the removal of dirt.
3. Rinse components thoroughly in clean, warm, preferably running water. Drain all components.
4. When the cleaner does not contain a disinfecting agent, respirator components should be immersed for 2 minutes in one of the following:
  - Hypochlorite solution [50 parts per million (ppm) of chlorine] made by adding approximately one milliliter of laundry bleach to 1 liter of warm water
  - Aqueous solution of iodine [50 ppm iodine made by adding approximately 0.8 milliliter of tincture of iodine (6 to 8 grams ammonium and/or potassium iodide per 100 cubic centimeters of 45 percent alcohol) to 1 liter of warm water]
  - Other commercially available cleansers of equivalent disinfectant quality when used as directed if their use is recommended or approved by the respirator manufacturer
5. Rinse components thoroughly in clean, warm, preferably running water. Drain all components. The importance of thorough rinsing cannot be over emphasized. Detergents or disinfectants that dry on facepieces may cause dermatitis. In addition, some disinfectants may cause deterioration of rubber or corrosion of metal parts if not completely removed.
6. Components should be air-dried or hand-dried with a clean, lint-free cloth.
7. Reassemble the facepiece. Replace filters, cartridges, and canisters prior to next use.
8. Test the respirator to ensure that all components work properly.
9. Place the respirator in a clean bag and seal for storage.

Depending on work conditions, respirator facial sealing surfaces may need periodic cleaning during the course of daily use. Cleaning of the facial sealing surface during work breaks can reduce the chance of facial irritation caused by sweat, natural skin oil, or irritating materials that may have deposited on the facepiece. Facial sealing surfaces can be cleaned using disinfectant wipes soaked in isopropyl alcohol or benzalkonium chloride. After use of the disinfectant wipe, the sealing surface should air dry or be dried thoroughly using paper towels or tissues.

---

**Disclaimer:** This safe work practice (SWP) is the property of Tetra Tech, Inc. (Tetra Tech), and its subsidiaries. Any reuse of the SWP without Tetra Tech's permission is at the sole risk of the user. The user will hold harmless Tetra Tech for any damages that result from unauthorized reuse of this SWP. Authorized users are responsible for obtaining proper training and qualification from their employer before performing operations described in this SWP.


Health & Safety meeting 8/21/01

issues: physical hazards, chemical hazards,  
hospital route.

<u>NAME</u>	<u>AFFILIATION</u>	<u>SIGN</u>
Joe Parisa	TEAM I	Joe Parisa
Jenny Mueller	TEAM I	Jenny Mueller
Jane Biedeman	TEAM I	Jane Biedeman
Gay Heller	EXCEL	Gay Heller
Sam Barnes	USEPA	Sam Barnes
Mike McAteer	USEPA	Mike McAteer

8/22/01 - Health & Safety sign off  
Work today - photodocumentation no cleanout, gloves  
only when handling documents.  
main hazard - heat stress

<u>Name</u>	<u>affiliation</u>
Joe Parrish	TT EMI
Jenny Mueller	TT EMI
Sara Bredeman	TT EMI
Greg Heller	Excel

<u>sign</u>

Jenny Mueller
Sara Bredeman
Greg Heller