### FUGITIVE DUST TEST REPORT

IN THE VICINITY OF

U.S.S. LEAD REFINERY, INC. EAST CHICAGO, INDIANA

SEPTEMBER 16, 1985

### Conducted By:

EMISSIONS SAMPLING SECTION AIR POLLUTION—CONTROL DIVISION INDIANA STATE BOARD OF HEALTH

EPA Region 5 Records Ctr.



308180

Reference #14

#### INTRODUCTION

On September 16, 1985, an ambient air pollution study was conducted in the vicinity of U.S.S. Lead Refinery, Inc., located at 5300 Kennedy Avenue, East Chicago, Indiana. The purpose of the study was to determine the compliance status of U.S.S. Lead in regard to Regulation 325 IAC 6-4, concerning fugitive dust emissions. A copy of this regulation can be found in Appendix I. Personnel participating in this study were Ed Surla, Vic Windle and Daniel F. Hancock of the Emissions Sampling Section, Air Pollution Control Division, Indiana State Board of Health.

#### PROCESS INFORMATION

U.S.S. Lead is a secondary lead smelter. The furnace is charged with lead plates reclaimed from used batteries. The furnace was not in operation during the fugitive dust test.

Potential sources of fugitive dust are storage piles of furnace slag, flue dust and battery casings located on plant property. Fugitive dust may also be generated by traffic within the plant boundaries.

#### SAMPLING PROCEDURES

The test consisted of simultaneous ambient sampling at two locations, one of which was upwind (background site) of the U.S.S. Lead property, and another which was downwind (primary site) of the plant property. The location of the sampling sites for the test can be found on the map included in Appendix II.

The exposed filters were removed from the samplers and transported to the laboratory. The filters were dessicated 24 hours and then weighed to the nearest milligram.

#### RESULTS

The calculations for the total suspended particulate determination are shown in Appendix III. Kurz flow controllers attached to each sampler maintain a true air flow. The true air flow rate multiplied by the total sampling time equals the total air volume sampled. The weight of the filter catch divided by the total air volume results in the total suspended particulate concentration. A summary of the test results follows:

TEST DATE: September 16, 1985 PRIMARY SITE PARTICULATE CONCENTRATION: 218 micrograms/cubic meter
BACKGROUND SITE PARTICULATE CONCENTRATION: 122 micrograms/cubic meter
CONCENTRATION INCREASE: 96 micrograms/cubic meter

#### CONCLUSION

The maximum allowable particulate concentration increase as established in the Indiana Air Pollution Control Board Rule 325 IAC 6-4, Section 2(c), is 50 micrograms per cubic meter (primary over background). The results of this study indicate a concentration increase of 96 micrograms per cubic meter. Therefore, this source is not in compliance with Rule 325 IAC 6-4, Section 2(c).

In addition, the filter samples were analyzed for lead concentration using procedures outlined in EPA Method 12. Lead analysis results are summarized in Appendix IV.

APPENDIX I REGULATION

Rule 4. Fugitive Dust Emissions - Maximum Allowable

325 IAC 6-4-1 Applicability

Authority: IC 13-1-1-4; IC 13-7-5-1

Affected: IC 13-1-1-1; IC 13-1-1-4; IC 13-7-1-1; IC 13-7-5-1;

IC 13-7-7-2

Sec 1. (a) This Rule shall apply to all sources of fugitive dust. For the purposes of this Rule, "fugitive dust" means the generation of particulate matter to the extent that some portion of the material escapes beyond the property line or boundaries of the property, right-of-way, or easement on which the source is located.

325 IAC 6-4-2 Allowable Emissions

Authority: IC 13-1-1-4; IC 13-7-5-1

Affected: IC 13-1-1-1; IC 13-1-1-4; IC 13-7-1-1; IC 13-7-5-1;

IC 13-7-7-2

- Sec. 2. (a) A source or sources generating fugitive dust shall be in violation of this Rule if any of the following criteria are violated:
  - (1) Maximum Allowable Particles A source or combination of sources which cause to exist fugitive dust concentrations greater than 67% in excess of ambient upwind concentrations as determined by the following formula:

$$P = \frac{100 (R-U)}{U}$$

- P = Percentage increase
- R = Number of particles of fugitive dust measured at downwind. receptor site
- U = Number of particles of fugitive dust measured at upwind or background site
- (2) Potential Respiratory Damage The fugitive dust is comprised of 50% or more respirable dust, then the percent increase of dust concentration in Section 2(a) shall be modified as follows:

$$P_{R} = (1.5 - R) P$$

Where N = Fraction of fugitive dust that is respirable dust;  $P_{\rm p}$  = allowable percentage increase in dust concentration above background; and P = no value greater than 67%.

Promulgated 8/27/80

- (3) Ambient Air Concentrations The ground level ambient air concentrations exceed 50 micrograms per cubic meter above background concentrations for a 60-minute period.
- (4) Visible Emissions If fugitive dust is visible crossing the boundry or property line of a source and may be refuted by factual data expressed in Section 2(a), 2(b), or 2(c).

325 IAC 6-4-3 Combined Sources

Authority: IC 13-1-1-4; IC 13-7-5-1

Affected: IC 13-1-1-1; IC 13-1-1-4; IC 13-7-1-1; IC 13-7-5-1;

IC 13-7-7-2

- Sec. 3. (a) The allowable particles shall refer to the total of all particles leaving the boundaries or crossing the property lines of any source of fugitive dust regardless of whether from a single operation or a number of operations. If the source is determined to be comprised of two or more legally separate persons, each shall be held proportionately responsible on the basis of contributions by each person as determined by microscopic analysis. In such cases, samples shall be taken downwind from the combination of sources and at the fence line of each source.
- (b) No source which is contributing to a combined downwind fugitive dust concentration in excess of the limits of this Rule shall be required to reduce emissions if the concentrations at his property line are in compliance unless all contributors are individually in compliance and a combined fugitive dust concentration still exceeds the limits of this Rule. Each source shall then be required to reduce its emissions by like percentages to achieve an acceptable combined downwind concentration.
- (c) When all contributors are individually in compliance and no nuisance to the surrounding community is created, the Board may waive the requirement for further reduction in emissions by combined contributors.

325 IAC 6-4-4 Mobile Fugitive Dust Sources

Authority: IC 13-1-1-4; IC 13-7-5-1

Affected: IC 13-1-1-1; IC 13-1-1-4; IC 13-7-1-1; IC 13-7-5-1;

IC 13-7-7-2

Sec. 4. (a) No vehicle shall be driven or moved on any public street, road, alley, highway, or other thoroughfare, unless such vehicle is so constructed as to prevent its contents from dripping, sifting, leaking, or otherwise escaping therefrom so as to create conditions which result in fugitive dust. This section applies only to the cargo any vehicle may be conveying and mud tracked by the vehicle.

325 IAC 6-4-5 Methods of Measurement

Authority: IC 13-1-1-4; IC 13-7-5-1

Affected: IC 13-1-1-1; IC 13-1-1-4; IC 13-7-1-1; IC 13-7-5-1;

IC 13-7-7-2

Sec. 5. (a) Particle Numbers and Sizes - Particle quantities and sizes will be measured by manual microscopic analysis of a dustfall sample collected on a sticky slide or by use of commercially available particle counting

devices which count and classify particles by micron size range, or other methods acceptable to the Board.

- Ambient Air Concentrations Ambient air concentrations shall be measured using the standard Hi Volume Sampling and Analysis Techniques as specified by EPA in the April 30, 1971, Federal Register.
- Visible Emissions Observations by a qualified representative of the Board of visible emissions crossing the property line of the source at or near ground level.

325 IAC 6-4-6 Exemptions

Authority: IC 13-1-1-4; IC 13-7-5-1

Affected: IC 13-1-1-1; IC 13-1-1-4; IC 13-7-1-1; IC 13-7-5-1;

IC 13-7-7-2

- Sec. 6. The following conditions will be considered as exceptions to this Rule and therefore not in violation:
- (a) Release of steam not in combination with any other gaseous or particulate pollutants unless the condensation from said steam creates nuisance or hazard in the surrounding community.
- Fugitive dust from publicly maintained unpaved thoroughfares where no nuisance or health hazard is created by its usage or where it is demonstrated to the Board that no means are available to finance the necessary road improvements immediately. A reasonable long-range schedule for necessary road improvements must be submitted to support the Board's granting such an exception.
- (c) Fugitive dust from construction or demolition where every reasonable precaution has been taken in minimizing fugitive dust emissions.
- (b) Fugitive dust generated from agricultural operations providing every reasonable precaution is taken to minimize emissions and providing "1 operations are terminated if a severe health hazard is generated because of prevailing meteorological conditions.
- Visible plumes from a stack or chimney which provide adequate dispersion and are in compliance with other applicable Rules.
- Fugitive dust from a source caused by adverse meteorological conditions.

325 IAC 6-4-7 Compliance

Authority: IC 13-1-1-4; IC 13-7-5-1

Affected: IC 13-1-1-1; IC 13-1-1-4; IC 13-7-1-1; IC 13-7-5-1;


IC 13-7-7-2

Sec. 7. (a) All sources must comply with this Rule as soon as practicable but no later than July 1, 1974.

APPENDIX 11

SAMPLING SITE LOCATIONS

A STUDY STUDY OF



APPENDIX III

Y.

CALCULATIONS

## TOTAL SUSPENDED PARTICULATE VALCULATIONS PRIMARY SITE

(1)-	Observed Air Flow (CFM) - From Flow Neter =
(2)	True Air Flow (Green Controller)
(3)	Weight of Filter Catch (grams) = Final Weight (g) - Initial Weight (g)
	$= \frac{4.145}{9} = \frac{4.111}{0.034} = \frac{4.111}{0.0$
(4)	Adjusted Total Air Volume (cubic meters)
•	= True Air Flow (cubic meters/minute) x Time (min.)  = 1.30 x 120  = 156 cubic meters
(5)	Particulate Concentration (micrograms/cubic meter)  = Keight of Filter Catch (g) x 10 <sup>6</sup> Adjusted Total Air Volume (cubic meters)
	= 218 micrograms/cubic meter ,

# TOTAL SUSPENDED PARTICULATE CALCULATIONS BACKGROUND SITE

ا رمعان	(1)	Observed Air Flow (CFM) - From Flow Neter = CFM
	(2)	True Air Flow (Kurz Flow Controller) = 1.30 m <sup>3</sup> /minute
	(3)	Weight of Filter Catch (grams) = Final Weight (g) - Initial Weight (
	(4)	= 4.061 g - 4.042 g = 0.019 grams  Adjusted Total Air Volume (cubic meters)
•		= True Air Flow (cubic meters/minute) x Time (min.)  = 1.30 x 120  = 156 cubic meters
	<b>(</b> 5)	Particulate Concentration (micrograms/cubic meter)  ** Weight of Filter Catch (g)
	<b>≫</b>	

APPENDIX IV

LEAD ANALYSIS

1 4

## STATE BOARD OF HEALTH

#### INDIANAPOLIS

### OFFICE MEMORANDUM

DATE: October 22, 1985

TO:

Vic Windle

THRU:

W. Smith 9

FROM:

Phil Zillinger

E. Surla

SUBJECT: Hi-Vol Samples From USS Lead Collected September 16, 1985

The above mentioned samples were analyzed on September 24, 1985 using the procedures outlined in Method 12. The following results were obtained:

Sample	Filter Number	 Lead Concentration (ug Pb/m³)
Background	5021364	0.375
Primary	5021359	38.187

PZ/bs

## terence 22

Federal Register / Vol. 47. No. 74 / Friday, April 16, 1982 / Rules and Regulations

-Refurence Methods

Arthod 12 Determination of Liorganic Lead caissions From Stationary Sources

1. Applicability and Principle.

1.3 Applicability. This method applies to e determination ci inorganic lead (Pb) missions from specified stationary sources . ·lv

Principle, Particulate and gaseous Pb

2.3 Precision. The within-leboratory precision, as measured by the coefficient of variation ranges from 0.2 to 9.5 percent relative to a run-mean concentration. These values were based on tests conducted at a gray iron foundly, a lead storage battery manufacturing plant, a secondary lead smelter, and a lead recovery furnace of an alkyl lead manufacturing plant. The concentrations encountered during these tests ranged from 0.81 to 123.3 mg Pb/m2.

2.4 Interferences. Semple matrix effects

3.1.1 Probe Nozzle, Probe Liner, Pitot Tube, Differential Pressure Gauge, Filter Holder, Filter Heating System, Metering System, Berometer, and Cas Density Determination Equipment. Same as Method S. Sections 2.1.1 to 2.1.6 and 2.1.8 to 2.1.10.

3.1.2 Impingers. Four impingers connected in series with leak-free ground glass fittings or any similar leak-free noncontuminating fittings. For the first, third, and fourth

erence 22

TO

SUBJECT

11

USS Lead Refinery kile Lake Co. 7\_VD04703027\_4

Documentation ON March 25, 1986, I contacted Mr. Ed Surla of the Division of Air Pollection Control regarding the fugitive dust study at the above reterenced facility. Mr. Surla explained that used for this study was have included this

reference 22. Further ouestions can be addressed Mr. Ed Surla ot ACB17/Ce33-0671.

081 A W22-SS-3 State Form No. 1352

INCHIOUMCICHS

DRY GAS METER

Figure 12-1, Inorganic lead sampling train.

RM 12 Revision

4. Francesia

4.1.1 Filter, Gelman Spectro Grade, Reeve Angel 934 AH, MSA 1106 EH, all-with lot assa; for Pb. or other high-purity glass fiber filters, without organic binder, exhibiting at lors, 9,195 percent efficiency (<0.05 percent

p. retretion) on 0.3 micron dioctyl phthelate smoke particles. Conduct the filter efficiency test using ASTM Standard Method D2228-71 (incorporater) by reference—see § 60.17) or are test data from the supplier's grafity control program. 1-27-83

4.1.3 Weter, Deionized distilled to conform to ASTM Sperification E0193-77 (incorporated by reference—see § 60.17).

Tipe 3. If high concentrations of organic matter are not expected to be present, the expected to be present. permangenate test for ordificable organic matter.



ienerse vordiers ist 3 conscratification farbon, endpolories

3.2 Sample Recovery: The following items are needed:

3.21 Probe-Uner and Probe-Nozzla Brushes, Petri Dishes, Plastic Storage Containers, and Funnel and Rubber Policeman, Same as Method 5, Sections 2.2.1, 2.2.4, 2.2.6, and 2.2.7, respectively.

3.22 Wash Bottles, Glass (2). .

3.2.3 Sample Storage Containers. Chemically resistant, borosilicate glasa bottles, for 0.1 mino acid (HNO<sub>s</sub>) impinger and probe solutions and washes, 1000-ml. Use screw-cap liners that are either subberbacked Teflon' or leak-free and resistant to chemical attack by 0.1 N HNO<sub>s</sub> (Narrow mouth glass bottles have been found to be less prone to leakage.)

1.2.4 Graduated Cylinder and/or Balance. To measure condensed water to within 2 ml or 1 g. Use a graduated cylinder that has a minimum capacity of 500 ml. and aubdivisions no greater than 5 ml. [Most luboratory balances are expable of weighing

to the nearest O.S.g. or less.)

3.25 Funnel Glass to aid in sample recovery.

33 Analysis. The following equipment is needed:

- 3.3.1 Atomic Absorption Spectrophotometer. With lead bollow cathode imp and burner for air/acctylene flame.
  - and Hairbie
  - 3.3.3 Erlenmeyer Flanks 125-ml 24/40 S.

3.3.4 Membrane Ellists/Mullipore SCWPO 4700 or equivalent.

2.3.5 Editation Apparatus, Millipore, vectom filtration unit, or equivalent, for use with the above membrane filter.

2.16 Volumetric Flacks, 100-ml, 250-ml, and 1930 ml.

4. Heagens.

4.1 Sampling. The reagents used in sampling are as follows:

4.1.1 Filter Gelman Spectro Grade. Reeve Angel 934 AH, MSA 1200 BH all with lot assay for Pb, or other high-purity gloss fiber filters, without organic binder, exhibiting at least 99.95 percent efficiency (<0.05 percent penetration) on 0.3 micron diocityl phthalatu smoke particles. Conduct the filter efficiency leat using ASTM Standard Method D 2980—71 or use lest data from the supplier's quality control program.

4.3.2. Silica Gel, Crushed Ice, and Stopcock Gresse. Same as Method 5, Section 3.1.2, 3.2.4, and 3.7.5, respectively.

- 4.1.2 Water. Deionized distilled, to conform to ASTM Specification D 1193-74, Type 3. If high concentrations of organic matter are not expected to be present, the analyst may delete the potassium permanganate test for oxidizable organic tradier.
- 4.1.4 Nitric Acid, U.3 N. Dilute 0.5 ml of concentrated HSO, to 1 liter with deionized distilled water, (it may be desirable to run blanks before field use to elimenate a high blank on test samples 3.
- 4.2 Protest Preparation, 6 N HNO, is needed. Dilute 393 oil of concentrated HNO, to 1 liter with decembed distilled water.

4.3 Sample Recovery. 0.1 N HNO. (same-as 4.1.4 above) is needed for anopie recovery.

4.4 Analysis. The following reagents are needed for analysis (use ACS reagent grade chemicals or equivalent, unless otherwise specified):

4.4.1 Water, Same as 4.1.3 above.

4.4.2 Nitric Acid. Concentrated.

4.4.3 Nitric Acid, 50 percent (V/V). Dilute 500 ml of concentrated HNO, to 1 liter with defonized distilled water.

4.4.4 Stock Lead Standard Solution, 1000 µg Pb/ml. Dissolve 0.1598 g of lead muste [Pu(NO<sub>2</sub>)<sub>3</sub>] in about 60 ml of deionized distilled water, add 2 ml concentrated HNO<sub>2</sub>, and dilute to 100 ml with deionized distilled water.

4.4.5 Working Lead Standards. Pipet 0.0, 1.0, 2.0, 3.0, 4.0, and 5.0 ml of the stock lead standard solution [4.4.4] into 250-ml volumetric flasks. Add 5 ml of concentrated HNO, to each flask and dilute to volume with deionized distilled water. These working standards contain 0.0, 4.0, 8.0, 12.0, 16.0, and 20.0 µg Pb/ml, respectively. Prepare, as needed, additional standards at other concentrations in a similar manner.

4.4.6 Air. Suitable quality for atomic absorption analysis.

4.4.7 Acetylene. Suitable quality for

atomic absorption analysis.

4.4.8 Hydrogen Peroxide, 3 percent (V/V).

Dilute 10 ml of 30 percent H<sub>1</sub>O<sub>2</sub> to 100 ml with

deionfied distilled water.

5. Procedure.

5.1 Sampling. The complexity of this method is such that, in order to obtain reliable results, lesters should be trained and experienced with the lest procedures.

5.11 Pretest Preparation. Follow the same general procedure given in Method 5. Section 4.1.1, except the filter need not be weighed.
5.1.2 Preliminary Determinations. Follow the same general procedure given in Method 5, Section 4.1.2.

5.1.1 Preparation of Collection Train.
Follow the same general procedure given in Method 5. Section 4.1.1 except place 100 ml of 0.1 HNO. in each of the first two impingers, leave the third impinger empty, and transfer approximately 200 to 300 g of preweighed silica gel from its consiner to the fourth impinger. Set up the train as shown in Figure 12-1.

5.1.4 Leek-Check Procedures Follow the general leak-check procedures given in Method 5, Sections 4.1.4.1. (Pretest Leak-Check), 4.1.4.2 (Leak-Checke During the Sample Run), and 4.1.4.1 (Post-Test Leak-Check).

5.1.5 Sumpling Train Operation. Follow the same general procedure given in Method 5, Section 4.1.5. For each run, record the data required on a data sheet such as the one shown in EPA Method 5, Figure 5-2.

\$1.6 Calculation of Percent Lokinetic Same as Method 5, Section 4.1.6.

5.2 Sample hecovery. Begin proper cleanup procedure as soon as the probe is removed from the stack at the end of the sampling period.

Allow the probe to conf. When it can be safely handled, wipe off all external particulate matter near the tip of the probe nuzzle and place a cap over it. Do not cap off the probe up tightly while the sampling train

is cooling down as this would create a vacuum in the filter holder, thus drawing liquid from the impingers into the filter.

Before moving the sampling train to the cleanup site, remove the probe from the sapling train, wipe off the silicone grease, and cap the open outlet of the probe. Be careful not to lose any condensate that might be present. Wipe off the silicone grease from the glassware inlet where the probe was fastened and cap the inlet, Remove the umbilical coril from the last impinger and cap the impinger. The tester may use ground-glass stoppers, plastic caps, or seruin caps to close these openings.

Transfer the probe and filter-impinger assembly to a cleanup area, which is clean and protected from the wind so that the chances of commitmenting or losing the sample are minimized.

Inspect the train prior to and during disassembly and note any abnormal

conditions. Treat the samples as follows: 5.2.1 Container No. 1 (Pilter). Carefully remove the filter from the filter holder and place it in its identified petri dish container. If it is necessary to fold the filter, do so such that the sample-exposed side is inside the fold. Carefully transfer to the petri dish any visible sample matter and/or filter hovers that adhere to the filter holder gasket by using a dry Nylon bristle brush and/or a shurp-edy-d blade. Seal the container.

\$2.2. Container No. 2 (Probe). Taking care that dust on the outside of the probe or other extenor surfaces does not get into the sample, quantitatively recover sample matter or eny condensate from the probe notable, probe litting, probe litting, probe litting, probe litting, and front half of the filter holder by washing these components with 0.1 N HNOs and placing the wash into a glass sample storage container. Measure and record (to the nearest 2-inf) the total amount of 0.1 N HNOs used for each rinse. Perform the 0.1 N HNOs traces as follows:

Carefully remove the probe number and rinse the inside surfaces with 0.2 N HNO? from a wash bottle while brushing with a standers steel, Nylon-bristle brush thrush antil the 0.7 N HNO, rinse shows no visible particles, then make a final rinse of the inside surface.

Brush and rinse with 0.2 N HNO, the inside parts of the Swagelok litting in a sunder way until no visible particles remain.

Rinse the probe liner with 0.1 N HNO. While rotating the probe so that all inside surfaces will be rinsed with 0.1 N 18NO., till the probe and equirt 0.1 N HNO, into its upper end. Let the 0.1 N HNO, drain from the lower end into the sample container. The tester may use a glass funnel to aid in transferring liquid washes to the container. Follow the rinse with a probe brusin field the probe in an inclined position, equal 0.1 14 HNO, into the upper end of the probe we that probe brush is being pushed with a twenting action through the probe, hold the sample container underweath the lower end of the probe and eatch any 61 NINO, and anaple matter that is brushed from the probe Ranthe brush through the probe there times or more until no visible sample matter is carried out with the 01 N HNO, and none remains on the probe liner on visual map course Visite.

Thintion of made names or operating products does not constitute enduranment by the U.S. Environmented in machine Agenty.

stainless steel or other metal probes, run the brush through in the above prescribed manner at least six times, since metal probeshave small crevices in which sample matter can be entrapped. Rinse the brush with 0.1 N HNO, and quantitatively collect these washings in the sample container. After the brushing make a final rinse of the probe as described above.

It is recommended that two people clean the probe to minimize loss of sample. Between sampling runs, keep brushes clean and protected from contamination.

After insuring that all joints are wiped clean of silicone grease, brush and rinse with 0.1 N HNO, the inside of the front half of the filter holder. Brush and rinse each suface three times or more, if needed, to remove visible sample matter. Make a final rinse of the brush and filter holder. After all 0.1 N HNO, washings and sample matter are collected in the sample container, tighten the lid on the sample container so that the fluid will not leak out when it is shipped to the luboratory. Mark the height of the fluid level to determine whether leakage occurs during transport. Label the container to clearly identify its contents.

5.23 Contoiner Na. 3 (Silica Gel). Check the color of the indicating silica gel to determine if it has been completely spent and make a notation of its condition. Transfer the silica gel from the fourth impinger to the original container and seal. The tester may use a funnel to pour the silica gel and a rubber policeman to remove the silica gel om the impinger. It is not necessary to emove the small amount of particles that may adhere to the walls and are difficult to remove. Since the gain in weight is to be used for moisture calculations, do not use any water or other liquids to transfer the silica gel. If a balance is available in the field, the tester may follow procedure for Container No. 3 under Section 5.4 (Analysis).

5.2.4 Container No. 4 (Impingers). Due to the large quantity of liquid involved, the tester may place the impinger solutions in several containers. Clean each of the first three impingers and connecting glassware in the following manners.

1. Wipe the impinger ball joints free of silicone grease and cup the joints.

2. Rotate and ay tate each impinger, so that the impinger contents might serve as a rinse solution.

3. Transfer the contents of the impingers to a 500-ml graduated cylinder. Remove the outlet ball joint cap and drain the contents through this opening. Do not separate the impinger parts (inner and outer tubes) while transferring their contents to the cylinder. Measure the liquid volume to within ±2 ml. Alternatively, determine the weight of the liquid to within ±0.5 g. Record in the log the volume or weight of the liquid present, along with a notation of any color or film observed in the impinger esten. The liquid volume or weight is needed, along with the stick gel. I data, to calculate the stack gas moisture.

ident (see Method 5, Figure 5-3).

1. Transfer the centents to Container No. 4.

5 Note, In steps 5 and 6 below, measure and record the total amount of 0.1 N HNO<sub>5</sub> used for russing Poor approximately 30 ml of 0.1 N HNO<sub>5</sub> into each of the first three

impingers and agitate the impingers. Drain, the 0.1 N HNO, through the outlet arm of each impinger into Cuntainer No. 4. Repeat this operation a second time; inspect the impingers for any abnormal conditions.

6. Wipe the ball joints of the glussware connecting the impingers free of silicone grease and rinse each piece of glassware twice with 0.1 N HNOs; transfer this rinse into Container No. 4. (Do not rinse or brush the glass-fritted filter support.) Mark the height of the fluid level to determine whether leakage occurs during transport. Label the container to clearly identify its contents.

5.2.5 Blanks. Save 200 ml of the 0.1 N HNO, used for sampling and cleanup as a blank. Take the solution directly from the bottle being used and place into a glass sample container labeled "0.1 N HNO, blank."

5.3 Sample Preparation.

5.3.1 Container No. 1 (Filter). Cut the filter into strips and transfer the strips and all loose particulate matter into a 125-ml Erlenmeyer flask. Rinse the petri dish with 10 ml of 50 percent HNO, to insure a quantitative transfer and add to the flask. (Note: If the total volume required in Section 5.3.1 is expected to exceed 80 ml, use a 250-ml Erlenmeyer flask in place of the 125-ml flask.)

5.3.2 Containers No. 2 and No. 4 (Probe and Impingers). (Check the liquid level in Containers No. 2 and/or No. 4 and confirm as to whether or not leakage occurred during transport; note observation on the analysis sheet. If a noticeable amount of leakage had occurred, either void the sample or take steps, subject to the approval of the Administrator, to adjust the final results.) Combino the contents of Containers No. 2 and No. 4 and take to dryness on a hot plate.

5.3.3 Sample Extraction for lend. Based on the approximate stack gas particulate concentration and the total volume of stack gas sampled, estimate the total weight of particulate sample collected. Then transfer the residue from Containers No. 2 and No. 4 to the 125-ml Erlenmeyer flusk that contains the filter using rubber policeman and 10 ml of 50 percent HNO, for every 100 mg of sample collected in the train or a minimum of 30 ml of 50 percent HNO, whichever is larger.

Place the Erlenmeyer flask on a hot plate and heat with periodic stirring for 30 min at a temperature just below boiling. If the sample volume falls below 15 ml, add more 50 percent HNO. Add 10 ml of 3 percent H<sub>2</sub>O<sub>3</sub> and continue heating for 10 min. Add 50 ml of hot (80°C) deionized distilled water and heat for 20 min. Remove the flask from the hot plate and allow to coel. Filter the sample through a Millipore membrane filter or equivalent and transfer the filtrate to a 250-ml volumetric flask. Dilute to volume with deionized distilled water.

5.3.4 Filter Blank, Determine a filter blank using two filters from each lot of filters used in the sampling train. Cut each filter into strips and place each filter in a separate 125-ml Erlenmeyer flask. Add 15 ml of 50 percent HNO, and treat as described in Section 5.3.3 using 10 ml of 3 percent Hi<sub>2</sub>O<sub>4</sub> and 50 ml of bot, deionized distilled water. Filter and didute to a tool volume of 100 ml using deionized distilled water.

3.3.5 0.1 N HNO, Blank. Take the entire 200 ml of 0.1 N HNO, to drynese on a steom

bath, add 15 ml of 50 percent HNO, and treat as described in Section 5.3.3 using 10 ml of 3 percent H,O, and 50 ml of hot, deconized distilled water. Dilute to a total volume of 100 ml using deconized distilled water.

5.4 Analysis,

5.4.1 Lead Determination. Cultivate the spectrophotometer us described in Section 6.2 and determine the absorbance for each source sample, the filter blank, and 0.1 N HNO, blank. Analyze each semple three times in this manner. Make appropriate dilutions, as required, to bring all sample Pb concentrations into the linear absorbance range of the spectrophotomater.

If the Pb concentration of a sample is at the low end of the calibration curve and high accuracy is required, the sample can be taken to dryness on a hot plate and the residue dissolved in the appropriate volume of water to bring it into the optimum range of the

calibration curve.

5.4.2 Mandatory Check for Matrix Effects on the Lead Results. The analysis for Pb by atomic absorption is sensitive to the chemical composition and to the physical properties (viscosity, pH) of the sample (matrix effects). Since the Pb procedure described here will be applied to many different sources, many sample matrices will be encountered. Thus, check (mandatory) at least one sample from each source using the Method of Additions to ascertain that the chemical composition and physical properties of the sample did not cause erroneous analytical results.

Three acceptable "Method of Additions" procedures are described in the Ceneral Procedure Section of the Perkin Elmer Corporation Manual (see Citation 9.1). If the results of the Method of Additions procedure on the source sample do not agree within 5 percent of the value obtained by the conventional atomic absorption analysis, then the tester must reanalyze all samples from the source using the Method of Additions procedure.

5.4.3 Container No. 3 (Sillen Gel). The tester may conduct this step in the field. Weigh the spent silica gel (or silica gel plus impinger) to the neurest 0.5 g; record this weight.

8. Calibration.

Maintain a laboratory log of all calibrations.

6.1 Sampling Train Calibration. Calibrate the sampling train components according to the indicated sections of Method 5: Probe Nozzle [Section 5.1]; Pitot Tube (Section 5.2]; Metering System (Section 5.3]; Probe hieuter (Section 5.4); Temperature Gauges (Section 5.5); Leak-Check of the Metering System (Section 5.0); and Barometer (Section 5.7).

absorbance of the standard solutions using the instrument settings recommended by the spectrophotometer manufacturer. Repeat until good agreement (±3 percent) is obtained between two consecutive readings. Plot the absorbance (y-axis) versus concentration in µg Pb/ml (x-axis). Draw or compute a straight line through the lower portion of the curve. Do not force the calibration curve through zero, but if the curve does not pass through the angent or at least he closer to the origin than ±0.000.

 rorbance units, check for incorrectly pared standards and for curvature in the pathbration curve.

To determine stability of the calibration curve, run a blank and a standard after every five samples and recalibrate, as necessary.

7. Calculations.

7.1 Dry Cas Volume. Using the data from this test, calculate  $V_{\rm mine}$ , the total volume of dry gus metered corrected to standard conditions (20°C and 760 mm Hg), by using Equation 3-1 of Method 5. If necessary, adjust  $V_{\rm mine}$  for leakages as outlined in Section 6.3 of Method 5. See the field data sheet for the average dry gas meter temperature and average orifice pressure drop.

7.2 Volume of Water Vapor and Moisture Content. Using data obtained in this test and Equations 5-2 and 5-3 of Method 5, calculate the volume of water vapor Valual) and the moisture content B<sub>m</sub> of the stack gas.

7.3 Total Lead in Source Sample. For each source sample correct the average absorbance for the contribution of the filter blank and the 0.1 N HNO, blank. Use the calibration curve and this corrected absorbance to determine the µg Pb concentration in the sample aspirated into the spectrophotometer. Calculate the total Pb content  $C^*_{\mathcal{D}_p}$  [in µg] in the original source sample; correct for all the dilutions that were made to bring the Pb concentration of the sample into the linear range of the recorrephotometer.

7.4 Lead Concentration. Calculate the stack gas Pb concentration C<sub>Pb</sub> in mg/dscm as follows:

$$C_{P_0} = K \frac{C'_{P_0}}{V_{m(n,n)}}$$

Where:

K=0 001 mg/µg for metric units.

=2.205 lb/µg for English units.

7.5 Isokinetic Variation and Acceptable Results. Same as Method 5, Sections 6.11 and 6.12, respectively. To calculate v., the average stack gas velocity, use Equation 2-9 of Method 2 and the data from this field test.

8. Alternative Test Methods for Inorganic Lead.

8.1. Simultaneous Determination of Particulate and Lead Emissions. The tester may use Method 5 to simultaneously determine Pb provided that (1) he uses acetone to remove particulate from the probe and inside of the filter holder as specified by Method 5, (2) he uses 0.1 N HNO, in the impingers, (3) he uses a glass fiber filter with a low Pb background, and (4) he treats and analyzes the entire train contents, including the impingers, for Pb as described in Section 5 of this method.

8.2 Filter Location. The tester may use a filter between the third and fourth impinger provided that he includes the filter in the analysis for Pb.

8.3 In-stack Filter. The tester may use an in-stack filter provided that (1) he uses a

glass-lined probe and at least two impingers, each containing 100 ml of 0.1 N HNO<sub>3</sub>, after the in-stack filter and (2) he recovers and analyzes the probe and impinger contents for Pb. Recover sample from the nozzle with acctone if a particulate analysis is to be a made.

9. Bibliography

9.1 Perkin Elmer Corporation, Analytical Methods for Alomic Absorption Spectrophotometry, Norwalk, Connecticut. September 1976.

9.2 American Society for Testing and Materials, Annual Book of ASTM Standurds, Part 31; Water, Atmospheric Analysis, Philadelphio, Pa. 1974, p. 40–42. 9.3 Klein, R. and C. Huch, Standard

9.3 Klein, R. and C. Huch. Stundard Additions—Uses and Limitations in Spectrophotometric Analysis. Anier. Lab. 5.21–27, 1977.

9.4 Mitchell, W.J. and M.R. Midgett.
Determining Inorganic and Alkyl Lead
Emissions from Stationary Sources. U.S.
Environmental Protection Agency. Emission
Monitoring and Support Laboratory. Research
Triangle Park, N.C. (Presented at National
APCA Meeting. Houston. June 28, 1978).

9.5 Same as Method 5, Citations 2 to 5

and 7 of Section 7.

(Secs. 111, 114, and 301(a) of the Clean Air Act as amended (42 U.S.C. 7411, 7414, and 7601(a)))

IFR Doc 82-1044 Filed 4-15-42 &43 ami

#### **ENVIRONMENTAL PROTECTION AGENCY**

40 CFR Part 60

[AD-FRL-2620-3]

15125

Standards of Performance for New Stationary Sources; Reference Methods; Revision to Method 12 for Inorganic Lead To Add a Method of **Additions Procedure** 

**AGENCY:** Environmental Protection Agency (EPA). ACTION: Final rule.

SUMMARY: The purpose of this action is to promulgate a revision to Method 12 for inorganic lead of Appendix A of 40 CFR Part 60 to include a method of additions procedure, which deals with the resolution of any possible interferences in the lead analysis. This revision is necessary because it has been determined that the method of additions procedures previously cited by Method 12 may not be readily available to the analyst, and were not suitable for incorporation by reference. This revision was proposed in the Federal Register on December 12, 1983 (48 FR 55395). No changes in the revision have been made since proposal, as no comment letters were received.

EFFECTIVE DATE: August 24, 1984.

Under section 307(b)(1) of the Clean ,, Air Act, judicial review of this revision . a is available only by the filing of a petition for review in the U.S. Court of Appeals for the District of Columbia - intelligently and effectively participate Circuit within 60 days of today's publication of this rule. Under section 307(b)(2) of the Clean Air Act, the requirements that are the subject of ... today's notice may not be challenged later in civil or criminal proceedings brought by EPA to enforce these (COA) requirements. The Annual Control of the Control of

ADDRESSES: Docket. A docket, number A-83-38, containing materials considered by EPA in development of the promulgated rulemaking, is available for public inspection between 8:00 a.m. and 4:00 p.m., Monday through Friday, at EPA's Central Docket Section (LE-131). West Tower Lobby. Gallery 1, 401 M Street, SW., Washington, D.C. 20460. A reasonable fee may be charged for

FOR FURTHER INFORMATION CONTACT: William Crimley or Roger Shigehara, Emission Measurement Branch, Emission Standards and Engineering Division (MD-19), U.S. Environmental Protection Agency, Research Triangle Park, North Carolina 27711, telephone (919) 541-2237.

**SUPPLEMENTARY INFORMATION: This** rulemaking does not impose any additional emission measurement requirements on facilities affected by this rulemaking. Rather, this rulemaking adds a supplementary analytical procedure to a test method that would apply irrespective of this rulemaking. This addition is necessary because the supplementary analytical procedure, 🤝 which was previously cited by the method, is not suitable for incorporation by reference.

#### **Public Participation**

The revision was proposed and published in the Federal Register on December 12, 1983 (48 FR 55395). The opportunity to request a public hearing was presented to provide interested persons the opportunity for oral presentation of data, views, or arguments concerning the proposed revision, but no person desired to make an oral presentation. The public comment period was from December 12. 1983, to February 27, 1984. No comment letters were received.

The docket is an organized and complete file of the information  $\Rightarrow$ considered by EPA in the development of this rulemaking. The docket is a dynamic file, since material is added throughout the rulemaking development. The docketing system is intended to allow members of the public and industries involved to identify readily and locate documents so that they can in the rulemaking process. Along with the statement of basis and purpose of ... the proposed and promulgated rule and EPA responses to significant comments. the contents of the docket will serve as The record in case of judicial review ... (Section 307(d)(7)(A)).

#### Miscellaneous ~

: Under Executive Order 12291, EPA must judge whether a regulation is "major" and therefore subject to the requirement of a regulatory impact analysis. This regulation is not major because it will not have an annual effect on the economy of \$100 million or more: it will not result in a major increase in costs or prices; and there will be no significant adverse effects on . \_ \_ competition, employment, investment. productivity innovation, or on the ability of U.S.-based enterprises to compete with foreign-based enterprises in domestic or export markets. This regulation was submitted to OMB for . review under E.O. 12291.

Pursuant to the provisions of 5 U.S.C. 605(u). I hereby certify that the attached

rule will not have a significant economic impact on small entities because no additional costs will be incurred. This rule does not contain any information collection requirements subject to OMB review under the Paperwork Reduction Act of 1980 U.S.C. 3501 et seq.

This rulemaking is issued under the authority of sections 111, 114, and 301(a) of the Clean Air Act, as amended (42 U.S.C. 7411, 7414, and 7601(a)).

#### ¿List of Subjects in 40 CFR Part 60

Air pollution control, Aluminum, Ammonium sulfate plants, Asphalt, Cement industry, Coal Copper, Electric power plants, Glass and glass products. Grains, Intergovernmental relations, Iron, Lead, Metals. Metallic Minerals, Motor vehicles, Nitric acid plants, Paper and paper products industry. Petroleum, Phosphate, Sewage disposal, Steel Suffuric acid plants. Waste treatment and disposal, Zinc. Tires. Incorporation by Reference, Can surface coating. Sulfuric acid plants, Industrial organic chemicals. Organic solvent cleaners. Fossil fuel-fired steam generators. Fiberglass Insulation, Synthetic Fibers, Line.

- Dated: August 2, 1984. Alvio L. Alm. Acting Administrator.

#### PART 60-[AMENDED]

- 40 CFR Part 60, Appendix A. Method . 12. is amended as follows:

1. By revising Section 5.4.2 to read as follows:

#### §5.4.2 Check for Matrix Effects on the Lead Results.

Since the analysis for Pb by atomic absorption is sensitive to the chemical composition and to the physical properties (viscosity, pH) of the sample (matrix effects), the analyst shall check at least one sample from each source rusing the method of additions as

Add or spike an equal volume of standard solution to an aliquot of the sample solution, then measure the absorbance of the resulting solution and the absorbance of an aliquot of unspiked sample.

Next, calculate the Pb concentration C, in µg/ml of the sample solution by using the following equation:

$$C_n = C_n \quad \frac{A_n}{A_n - A_n} \qquad \qquad \text{Eq. 12-1}$$

C.=Pb concentration of the standard solution, µg/mi.

rate tables, which are proposed amendments to the International Mail Manual (incorporated by reference in the Code of Federal Regulations, 39 CFR 10.1), and which are to become effective on the date service begins. No comments were received.

Accordingly, the Postal Service states that it intends to begin Express Mail International Service with Norway on October 23, 1984 at the rates indicated in the table below.

List of Subjects in 39 CFR Part 10

Postal service, Foreign relations. 👵 🖧

NORWAY.—EXPRESS MAIL INTERNATIONAL SERVICE

Custom designed service 1.8		On demand service * ,		
Up to and include	<b>~</b> ~ (	· · Up to and includ	ng ∵: ??	
Pounds	Pass		Rate	
		,	• • •	
T	\$26.00		250.00	
2	31.70	2	23.70	
3	35.40	3	27 40	
4	38.10 42.80	4	31.10 34.80	
6			38.50	
	50.20	7	4220	
7	33.50		4590	
	57.00		49.80	
10		10	53.30	
11	85.00	11	57.00	
12	<b>66.70</b>	12	<b>60.70</b>	
13	72.40	13	54.40	
14	76.10	14	88.70	
16			73.80	
		16	75.50	
17		17	79.20	
18		1 19	\$2.90 \$6.50	
20			80.30	
21		20	94.00	
22		72	97.70	
		23	101 40	
24	113 10	: 34	105.10	
25	116.80	25	108.80	
26		26	112.50	
27		27	116.20	
28			119.90	
29	1131.60		123.60	
30	_135.30 _139.00		127.30	
37		1 32	134.70	
33	1000	1	138.40	
34	150.10	34	142 10	
35			145.80	
56	157 50	36	749.50	
<b>37</b>	_161.20	• 37	153.20	
30		i 39.	156.90	
	- 168 60	39	160.60	
A	17230	41	164.30	
w '	178.70	0	171.70	
4	193.40		175 40	
44	187.10		179.10	
		1	;ـــــــــــــــــــــــــــــــــــــ	

Rates in the table are applicable to each prece of international Custom Designed Excess Mail shoped under a Service Agreement providing for tender by the customer at a

Pictup is available surder a Service Agreement for an adout charge of \$5.00 for each pictup stop, reperfees of the number of picces picked up. Domestic and international Express Mail picked sur together surder the same Service Assessment increases.

A transmittal letter making these changes in the pages of the International Mail Manual will be published in the Federal Register as provided in 39 CFR 10.3 and will be transmitted to subscribers automatically.

(39 U.S.C. 401, 404, 407)

W. Allen Sanders,

Associate General Counsel, Office of General Law and Administration.

[FR Disc. 94-25247 Filed 9-21-94, 8:45 am] BILLING CODE 7710-12-M

## ENVIRONMENTAL PROTECTION AGENCY

40 CFR Part 60

[AD-FRL-2620-3]

Standards of Performance for New Stationary Sources; Reference Methods; Revision To Method 12 for Inorganic Lead To Add a Method of Additions Procedure

Correction

In FR Doc. 84-21131 beginning on page 33842 in the issue of Friday, August 24, 1984, make the following correction: In column three, the equation at the bottom of the page should read:

$$C_S = C_A \frac{A_S}{A_S - A_S}$$

BILLING CODE 1905-01-8

#### DEPARTMENT OF TRANSPORTATION

Coast Guard ...

46 CFR Part 170

[CGD 79-023]

Subdivision and Stability Regulations

AGENCY: Coast Guard, DOT.
ACTION: Final rule: correction.

SUMMARY: This document corrects three incorrect definitions in the final rule issued November 4, 1983.

FOR FURTHER INFORMATION CONTACT:
Lt. Albert W. Horsmon Jr., Commandant (G-MTH-5/13), Room 1308, U.S. Coast Guard Headquarters, Washington, D.C. 20593, [202] 428-2187.

Discussion of Correction

#### # 170.170 [Amended]

In the Federal Register of November 4, 1983, page 51014, some definitions for the coefficient P in the inequality defining GM in § 170.170(a) are incorrect due to typographical errors. The second, third, and fourth definitions for P are corrected to read:

P=.055+(L/1309) metric tons/m<sup>3</sup>...for ocean service, Great Lakes winter service, or service on exposed waters. P = .0033 + (L/14.200)<sup>2</sup> tons/ft<sup>2</sup> . . . for Great Lakes summer service or service on partially protected waters.

on F

form.

tege

Con

of s

with

will

ma)

pov

of 2

lice

cha

Spi

(S:

lic

da

e٧

m.

st

is

ał

aı

F.

. ter:

P=.036+(L/1309)<sup>2</sup> metric tons/m<sup>2</sup>... for Great lakes summer service or service on partially protected waters.

Dated: September 18, 1984.

Clyde T. Lusk, Jr.,

Rear Admiral, U.S. Coast Guard, Chief, Office of Merchant Marine Safety.

[FR Doc. 84-25712 Filed 9-21-84; 8:45 em] BALLING CODE 4910-14-85 ( 17/17 f 17/17

## FEDERAL COMMUNICATIONS

47 CFR Part 1 한 한학학 하 호마

Amendment of Part 1 of the Rules (Concerning Practice and Procedure in the Private Radio Services (Concerning Practices)

AGENCY: Federal Communications 7, 11-7
Commission.

ACTION: Final rule: correction.

summary: This document corrects an error in the Appendix to an amendment of the rules of practice and procedure in the Private Radio Services.

FOR FURTHER INFORMATION CONTACT: 30: 3 Robert De Young, Private Radio Bureau, (202) 632-7175

Mary Beth Hess, Private Radio Bureau, (202) 634-2443

### SUPPLEMENTARY INFORMATION:

Erratum (17-11)

Released: September 17, 1984.

In the matter of amendment of Part 1 of the Rules concerning Practice and Procedure in the Private Radio Services.

On July 24, 1984, the Commission released an Order (FCC 84-323) (August 2, 1984, 49 FR 30943) in the above-captioned proceeding. Section 1.925(f), 33 (g) and (h) were printed incorrectly in 3.14, the Appendix. Those paragraphs should read:

§ 1.925 Application for special temporary authorization, temporary permit or temporary operating authority.

(f) An applicant for a Ship Radio station license may operate the radio station pending issuance of the ship station authorization by the Commission for a period of 90 days, under a temporary operating authority, evidenced by a properly executed certification made on FCC Form 506-A.

(g) An applicant for a Business Radio station license utilizing an already authorized facility may operate the radio station for a period of 180 days.

### Federal Register / Vol. 47, No. 74 / Friday, April 16, 1982 / Rules and Regulations

.p. .ix A—Reference Methods

Hethod 12. Determination of Liorganic Lead

1. Applicability and Principle.

1.1 Applicability. This method applies to be determination of inorganic lead (Pb) missions from specified stationary sources by.

1.7 Principle, Particulate and gassous Pb missions are withdrawn isokicetically from the source and collected on a filter and in the nitric soid. The collected samples are appeared in soid solution and analyzed by this absorption spectrometry using so air colytene flame.

2. Range, Sensitivity, Procision, and terterances.

2.3 Range. For a minimum analytical curary of ±10 percent, the lower limit of , range is 100 µg. The upper limit can be to identify extended by dilution.

2.2 Analytical Sensitivity. Typical silivities for a 1-percent change in comption (0.0044 absorbance units) are 0.2 d 0.5 µg Pb/ml for the 217.0 and 280.0 nm es, respectively.

2.3 Precision. The within-laboratory precision, as measured by the coefficient of variation ranges from 0.2 to 9.5 percent relative to a run-mean concentration. These values were based on tests conducted at a gray iron foundry, a lead storage battery manufacturing plant, a secondary lead smelter, and a lead recovery furnace of an alkyl lead manufacturing plant. The concentrations encountered during these tests ranged from 0.61 to 123.3 mg Pb/m<sup>3</sup>.

2.4 Interferences. Semple matrix effects may interfere with the analysis for Pb by flame atomic absorption. If this interference is suspected, the analyst may confirm the presence of these matrix effects and frequently eliminate the interference by using the Method of Standard Additions.


High concentrations of copper may interfere with the analysis of Ph at 217.0 nm... This interference can be avoided by analyzing the samples at 283.3 nm.

3. Apparetus.

3.1 Sampling Train. A schematic of the sampling train is shown in Figure 12-1; it is similar to the Method 5 train. The sampling train consists of the following components:

2.1.1 Probe Nozzle, Probe Liner, Pilot Tube, Differential Pressure Gauge, Filter Holder, Filter Heating System, Metering System, Barometer, and Cas Density Determination Equipment. Same as Method 5, Sections 2.1.1 to 2.1.6 and 2.1.8 to 2.7.10, respectively.

3.1.2 Impingers. Four impingers connected in series with leak-free ground glass fittings or any similar leak-free noncentaminating fittings. For the first, third, and fourth impingers, use the Greenburg-Smith design, modified by replacing the tip with a 1.3 cm (½ in.) ID glass tube extending to about 1.3 cm (½ in.) from the bottom of the flask. For the second impinger, use the Greenburg-Smith design with the standard tip. Place a thermometer, capable of measuring temperature to within 1°C (2°F) at the outlet of the fourth impinger for monitoring purposes.



20

RM 12 Perisim

4. Rengeats

4.1.3 Filter, Gelman Spectro Grada, Reeve Angel 934 AH, MSA 1106 EH, all with let essay for Pb, or other high-purity glass fiber filters, without organic binder, exhibiting at turn, 97,95 percent efficiency (<0.05 percent

por effection) on 0.3 micron diocty) phthalate amoke particles. Conclust the filter efficiency test using ASTM Standard Method D2638-71 (incorporated by reference—see § 60.17) or ere test date from the supplier's quality control program. 1-27-83

4.1.3 Water. Deigniffen distilled, to conform to ASTM Sperification Esses-77 (incorporated by reference—see § \$50.37). Type S. If high concentrations of organic motter are not expected to be present, the studyst may delete the potassium permangenate tast for critifizable organic

3.2 Sample Recovery: The following items are needed:

3.21 Probe-liner and Probe-Nozzle Brushes, Petri Dishes, Plastic Storage Containers, and Funnel and Rubber Policeman, Same as Method 5, Sections 2.2.1, 2.24, 2.26, and 2.7. respectively.

3.2.2 Wash Bottles, Glass (2). .

3.2.3 Sample Storage Containers. Chemically resistant borosilicate glass bottles, for 0.1 mix and (HNO,) impinger and probe solutions and washes, 1000-ml Use screw-cap liners that are either rubberbacked Teffon' or leak-free and resistant to chemical attack by 0.1 N HNO. (Narrow . mouth glass bottles have been lound to be less prone to leekage.)

124 Graduated Cylinder and/or Balance. To measure condensed water to within 2 ml or 1 g. Use a graduated cylinder that has a: minimum capacity of 500 ml, and subdivisions no greater than 5-mL (Most Inboratory balances are capable of weighing to the nearest 0.5 g or less)

3.25 Furnel Glass to aid in sample recovery.

3.3 Analysis. The following equipment is necded

3.3.1 Atomic Absorption . Spectrophotometer, With lead bollow cathode lamp and burner for air/scrtylene Raine

Hat Plate

3.3.3 Crleameyer, Flanka 125-ml. 24/40 S.

3.3.4 Membrage Ellers Mullipore SCWPO 4700 or equivalent.

- 3.35 Fütration Apparatus, Millipore . vectom filtration unit, or equivalent, for use with the above membrane filter.

3.16 Volumetric Flacks, 10G-ml, 250-ml, and 1000 mlu

4 Heagenia

4.1 Sampling The reagents used in sampling are as follows:

4.1.1 Filter Gelman Spectro Grade, Reeve Angel 934 AH, MSA 1106 BHL all with lot assay for Pb, or other high-purity glass fiber filters, without organic binder, exhibiting at least 99.95 percent el Diciency (<0.05 percent penetration) on 0.3 micron dioctyl phibalulu smake particles. Conduct the filter efficiency test using ASTM Standard Method D 2980-71 . or use lest data from the supplier's quality control program.

4.1.3. Silica Gel, Crushed Ice, and Stapcock Gresse, Same as Method 5, Section 3.1.2, 3.1.4, and 3.1.5, respectively.

4.1.3 Warer, Deronized danilled, to conform to ASIM Specification D 1193-74. Type 3. If high concentrations of organic matter are not expected to be present, the analyst may delete the potassium perinunganate test for andizable organic maller.

4.1.4 Nime Acid, U1 N. Difute 0.5 ml of concentrated H2O, to 1 liter with deionized distilled water. (It may be desirable to run blanks before field use to climinate a high blank on test samples }

4.2 Prefest Preparation, 6 N HNO, Is needed. Dilute 393 ml of concentrated 11NO, to I liter with desenved distilled water,

4.3 Sample Recovery, Q1 N HNO: [same as 4.1.4 above) is needed for anraple recovery.

4.4 Analysis. The following resgents are needed for analysis (use ACS rengent gradechemicals or equivalent, unless otherwise specified):

4.4.1 Water, Same as 4.1.3 above.

4.4.2 Nitric Acid. Concentrated.

4.4.3 Nitric Acid, 50 percent (V/V). Dilute 500 ml of concentrated HNO, to 1 liter with deionized distilled water.

4.4.4 Stock Lead Standard Solution, 1000 μg Pb/ml. Dissolve 0.1598 g of lead mitrate. [Pb[NO2]2] in about 60 ml of deionized distilled water, add 2 ml concentrated HNO. and dilute to 100 ml with deionized distilled water.

4.4.5 Working Load Standards. Pipet 0.0. 1.0, 2.0, 3.0, 4.0, and 5.0 ml of the stock lead standard solution (4.4.4) into 250-mì volumetric flasks. Add 5 ml of concentrated HNO, to each flack and dilute to volume with deionized distilled water. These working standards contain 0.0, 4.0, 8.0, 12.0, 16.0, and 20.0 µg Pb/ml, respectively. Prepare, as needed, additional standards at other conceptrations in a similar manner.

4.4.6 Air. Suitable quality for atomic absorption analysis.

4.4.7 Acetylene. Suitable quality for atomic absorption analysis.

4.4.8 Hydrogen Peroxide, J percent (V/V). Dilute 10 ml of 30 percent H.O. to 100 ml with deionized distilled water.

5. Procedure.

5.1 Sampling. The complexity of this method is such that, in order to obtain reliable results, testers should be trained and experienced with the test procedures.

5.1.1 Pretest Preparation. Follow the same general procedure given in Method 5. Section 4.1.1, except the Elter need not be weighed. ·· 5.1.2 Proliminary Determinations. Follow the same general procedure given in Method 5. Section 4.2.2

5.1.3 Preparation of Collection Train. Follow the same general procedure given in Method & Section 4.1.1 except place 100 ml of 0.1 HNO, in each of the first two impingers, leave the third impinger empty. and transfer approximately 200 to 200 g of preweighed sulica gel from its container to the fourth impinger Set up the train as shown in Figure 13-1

5.1.4 Leak-Check Procedures Follow tha general leak-check procedures given In Method 5, Sections 4.1.4.1. (Prefest Leak-Check), 4142 [Leak-Checks During the Sample Runj, and £1.4.3 (Post-Test Leak-Check). . . .

5.1.5 Sumpling Train Operation Follow the same general procedure given in Method 5. Section 4.3.5. For each run, second the data required on a data sheet such as the one shown in EPA Method 5, Figure 5-2

5.1.6 Culculation of Percent Lakinetic. Same as Method 5, Section 4.1.6.

5.2 Sample Recovery, Begin proper cleanup procedure as alloit at the probe to removed from the stack at the end of the sampling period.

Allow the probe to cool. When it can be safely handled, wipe off all external particulate matter near the tip of the probe norre and place a cap over it. Do not cap off the probe up tightly while the templing work

is cooling down as this would create a vacuum in the filter holder, thus drawing liquid from the impingers into the filter.

Before moving the sampling train to the cleanup ette, remove the probe from the sapling train, wipe of the silicone grease, and cap the open outlet of the probe. Be careful not to lose any condensate that might be present. Wipe off the silicone greuse from the glasaware inlet where the probe was lustened and cap the inlet. Remove the umbilical cord from the last impinger and cap the minimum. The tester may use ground-glass stoppers. plastic caps, or serum caps to close these openings.

Transfer the probe and filter-impinger assembly to a cleanup area, which is clean and protected from the wind so that the chances of communitating or losing the sample are minimized.

Inspect the train prior to and during disassembly and note any abnormal

conditions. Treat the samples as follows: 5.2.1 Container No. 1 (Filter), Carefully remove the filter from the filter holder and place it in its identified petri dish container. If it is necessary to fold the filter, do so such that the sample-exposed side is inside the fold. Carefully transfer to the petri dish any visible sample matter and/or filter libers that adhere to the filter holder gasket by using a dry Nylon bristle brush and/or a shurp-edged blade. Seaf the container.

5.2.2 Container No. 2 (Probe). Taking care that dust on the outside of the probe or other exterior surfaces does not get into the sample, quantitatively recover sample matter or eny condensate from the probe nozzle. probe fitting, probe liner, and from half of the filter holder by washing these components with 0.2 N HNO, and placing the wash into 2 glass sample storage container. Measure and record (to the pearest 2-od) the total amount ... of 0.1 N HNO, used for each mass. Perform the Q1 N HNO' mases as follows:

Carefully remove the probe number and rinse the inside surfaces with 0.1 N HNO? from a west bottle while brushing with a stainless steel, Nylon-bristle brush, Brush antil the 0.1 N HNO, rinse shows no visible particles, than make a final rinse of the inside surface.

Brush and rinsa with 0.1 N IINO, the inside parts of the Swagalok fitting by a sunder way until no visible particles remain.

Rinse the probe liner with 0.1 N HNO. While rotating the probe so that all inside surfaces will be rinsed with 0.1 N I iNO., tilt the probe and equirt 0.1 N HNO, into its upper and Let the 0.1 N HNO, drain from the lower end into the sample container. The tester may use a glass funnel to aid in transferring liquid washes to the container. Follow the rinse with a probe brush, field the probe in an inclined position, equal 0.1 % HNO, into the upper end of the profes we thus probe brush is being pushed with a temping ection through the prutie; hold the sample container underneath the lower end of the probe and catch any \$1 N HNO, and sample matter that is brushed from the probe Ranthe brush through the probe there times or more until no visible sample matter in corried out with the UI N HNO, and more remains on the probe liner on visual mapacitions With ...

<sup>\*</sup>Montion of made names or poscilic products dura not constitute endurancement by the U.S. Environmental Franction Agency.

atainless steel or other metal probes, run thebright through in the above prescribed manner at least six times, since metal probes have small crevices in which sample matter can be entrapped. Rinse the brush with 0.1 N HNO, and quantitatively collect these washings in the sample container. After the brushing make a final rinse of the probe as described above.

It is recommended that two people clean the probe to minimize loss of sample. Between sampling runs, keep brushes clean and protected from contamination.

After insuring that all joints are wiped clean of silicone grease, brush and rines with 0.1 N HNO, the inside of the front half of the litter holder. Brush and rines each sufface three times or more, if needed, to remove visible sample matter. Make a final rines of the brush and filter holder. After all 0.1 N 1000, washings and sample matter are collected in the sample container, tighten the lid on the sample container so that the fluid will not leak out when it is shipped to the laboratory. Mark the height of the fluid level to determine whether leakage occurs during transport. Libel the container to clearly identify its contents.

5.23 Contourer No. 3 (Silica Cel). Check the color of the indicating salica gel to determine if it has been completely spent and make a notation of its condition. Transfer the silica gel from the fourth impinger to the original container and seal. The tester may use a funnel to pour the silica gel and a rubber policeman to remove the silica gel om the impinger. It is not necessary to emove the small amount of particles that may adhere to the walls and are difficult to remove. Since the gain in weight is to be used for moisture calculations, do not use any water or other liquids to transfer the silica gel. If a balance is available in the field, the tester may follow procedure for Container No. 3 under Section 5.4 (Analysis).

5.2.4 Container No. 4 (Impingers). Due to the large quantity of liquid involved, the lester may place the impinger solutions in several containers. Clean each of the first three impingers and connecting glassware in the following manner.

1. Wipe the impinger ball joints free of silicone grease and cap the joints.

 Rutate and syltate each impinger, so that the impinger contents might serve as a consusolution.

3. Transfer the contents of the impingers to a 500-ml graduated cylinder. Remove the outlet ball joint cap and drain the contents through this opening. Do not separate the impinger parts (inner and outer tubes) while transferring their contents to the cylinder. Measure the liquid volume to within ±2 ml. Alternatively, determine the weight of the liquid to within ±0.5 g. Record in the log the volume or weight of the liquid present, along with a notation of any color or film observed in the impinger catch. The liquid volume or weight is needed, along with the silica gel distant to Calculate the stack gas meisture

intent (see Method 5, Figure 5-3).

1. Transfer the contents to Contamor No. 4.

5. Note, In steps 5 and 6 below, measure and record the total amount of 0.1 N HNOs word for rinsing Poor approximately 30 ml of 0.1 N HNO, into each of the first three

impingers and agitate the Impingers. Drain, the 0.1 N HNO, through the outlet arm of each impinger into Container No. 4. Repeat this operation a second time; inspect the impingers for any abnormal conditions.

6. Wipe the ball joints of the glussware connecting the impingers free of silicone grease and rinse each piece of glassware twice with 0.1 N HNO; transfer this rinse into Container No. 4, (Do not rinse or brush the glass-fritted filter support.) Mark the hight of the fluid level to determine whether leakage occurs during transport. Label the container to clearly identify its contents.

5.2.5 Blanks. Save 200 ml of the 0.1 N HNO, used for sampling and cleanup as a blank. Take the solution directly from the bottle being used and place into a glass sample container labeled "0.1 N HNO, blank."

5.3 Sample Preparation.

5.3.1 Container No. 1 (Filter). Cut the filter into strips and transfer the strips and all loose particulate matter into a 125-ml Elemmeyer flask. Rinse the peth dish with 10 ml of 50 percent HNO, to insure a quantitative transfer and add to the flask. (Note: If the total volume required in Section 5.3.) is expected to exceed 80 ml, use a 250-ml Elemmeyer flask in place of the 125-ml flask.)

5.3.2 Containers No. 2 and No. 4 (Probe and Impingers). (Check the liquid level in Containers No. 2 and/or No. 4 and confirm as to whether or not leakage occurred during transport; note observation on the analysis sheet. If a noticeable amount of leakage had occurred, either void the sample or take steps, subject to the approval of the Administrator, to adjust the final results.) Combina the contents of Containers No. 2 and No. 4 and take to dryness on a hot plate.

5.3.3 Sample Extraction for lead. Based on the approximate stack gas particulate concentration and the total volume of stack gas sampled, estimate the total weight of particulate sample collected. Then transfer the residue from Containers No. 2 and No. 4 to the 125-ml Erlenmeyer flusk that contains the filter using rubber policoman and 10 ml of 50 percent HNO, for every 100 mg of sample collected in the train or a minimum of 20 ml of 50 percent HNO, whichever is larger.

Place the Erlenmeyer flask on a hot plate and heat with periodic stirring for 30 min at a temperature just below boiling. If the sample volume falls below 15 ml, add more 50 percent HNO<sub>3</sub>. Add 10 ml of 3 percent H<sub>1</sub>O<sub>3</sub> and continue heating for 10 min. Add 50 ml of hot (80°C) dejunized distilled water and heat for 20 min. Remove the flask from the hot plate and allow to cool. Filter the sample through a Millipore membrane filter or equivalent and transfer the filtrate to a 250-ml volumetric flask. Dilute to volume with dejonized distilled water.

5.3.4 Filter Blank. Determine a filter blank using two filters from each lot of filters used in the sampling train. Out each filter into strips and place each filter in a separate 125-ml Erlenmayer flask. Add 15 ml of 50 percent HNO, and treat as described in Section 8.3.3 using 10 ml of 3 percent H<sub>2</sub>O<sub>2</sub> and 50 ml of bot demonzed distilled water. Filter and daute to a loak volume of 100 ml using demonzed distilled water.

5.3.5 0.1 N HNO, Blank. Take the entire 200 ml of 0.1 N HNO, to dry ness on a steam

bath, add 15 ml of 50 percent FINO,, and treat as described in Section 5.3.3 using 10 ml of 3 percent FI,O, and 50 ml of hot, desonized distilled water. Dilute to a total volume of 100 ml using desonized distilled water.

5.4 Analysis.

5.4.1 Lead Determination. Culibrate the spectrophotometer as described to Section 8.2 and determine the absorbance for each source sample, the filter blank, and 0.1 N HNO<sub>3</sub> blank. Analyze each sample three times in this manner. Make appropriate dilutions, as required, to bring all sample Pb concentrations into the linear absorbance range of the spectrophotometer.

If the Pb concentration of a sample is at the low end of the calibration curve and high accuracy is required, the sample can be taken to dryness on a hot plate and the residue dissolved in the appropriate volume of water to bring it into the optimum rungs of the

calibration curve.

on the Lead Results. The analysis for Pb by atomic absorption is sensitive to the chemical composition and to the physical properties (viscosity, pH) of the sample (matrix effects). Since the Pb procedure described here will be applied to many different sources, many sample matrices will be encountered. Thus, check (mandatory) at least one sample from each source using the Method of Additions to ascertain that the chemical composition and physical properties of the sample did not cause emoneous analytical results.

Three acceptable "Method of Additions" procedures are described in the Ceneral Procedure Section of the Perkin Elmer Corporation Manual (see Citation 0.1). If the results of the Method of Additions procedure on the source sample do not agree within 5 percent of the value obtained by the conventional atomic absorption analysis, then the tester must resnallyze all samples from the source using the Method of Additions procedure.

5.4.3 Container No. 3 (Silica Gel). The tester may conduct this step in the field. Weigh the spent silica gel (or silica gel plus impinger) to the neurest 0.5 g; record this weight.

6. Calibration.

Maintain a laboratory log of all calibrations.

8.1 Sampling Train Calibration. Calibrate the sampling train components according to the indicated sections of Method 5: Probe Nozzle (Section 5.1); Pitot Tube (Section 5.2); Metering System (Section 5.3); Probe Heuter (Section 5.4); Temperature Gauges (Section 5.5); Leak-Check of the Metering System (Section 5.0); and Barometer (Section 5.7).

6.2 Spectrophotometer. Measure the absorbance of the standard solutions using the instrument settings recommended by the spectrophotometer manufacturer. Repeat until good agreement (±3 percent) is obtained between two consecutive readings. Plot the absorbance (y-axis) versus concentration in µg Pb/ml (x-axis). Draw or compute a straight line through the linear portion of the curve. Do not force the calibration noisy through the argument at least the closer to the origin than ±0.003

forbance units, check for incorrectly pared standards and for curvature in the catibration curve.

To determine stability of the calibration curve, run a blank and a standard after every five samples and recalibrate, as necessary.

7. Colculations.

7.3 Dry Cas Volume. Using the data from this test, calculate Values the total volume of dry gus metered corrected to stundard conditions (20°C and 760 mm Hg), by using Equation 5-1 of Method 5. If necessary, adjust Value for leakages as outlined in Section 6.3 of Method 5. See the field data sheet for the average dry gas meter temperature and average orifice pressure drop.

7.2 Volume of Water Vapor and Moisture Content. Using data obtained in this test and Equations 5-2 and 5-3 of Method 5, colculate the volume of water vapor Value) and the muisture content B., of the stack gas.

7.3 Total Lead in Source Sample. For each source sample correct the average absorbance for the contribution of the fifter blank and the 0.1 N HNO, blank. Use the calibration curve and this corrected absorbance to determine the ug Pb concentration in the sample aspirated into the spectrophotometer. Calculate the total P5 content C'm [in µg] in the original source sample: correct for all the ditutions that were made to bring the Pb concentration of the sample into the linear range of the rnectrophotometer.

7.4 Lead Concentration. Calculate the stack gas Pb concentration Cm in mg/dscm es follows:

## Cro = K C'ro

K=0.001 mg/µg for metric units. = 2,205 lb/ug for English units.

7.5 Isokineuc Variation and Acceptable Results. Same as Method 5, Sections 6-11 and 6.12, respectively. To calculate v., the average stack gas velocity, use Equation 2-9 of Method 2 and the data from this field test,

8. Alternative Test Methods for Inorganic

Lead.

8.1. Simultaneous Determination of Particulate and Lead Emissions. The tester may use Method 5 to simultaneously determine Pb provided that (1) he uses acetone to remove particulate from the probe and inside of the filter holder as specified by Method 5, [2] he uses 0.1 N HNO, in the impingers, (3) he uses a glass fiber filter with a low Pb background, and (4) he treats and analyzes the entire train contents, including the impingers, for Pb as described in Section 5 of this method.

8.2 Filter Location. The tester may use a filter between the third and fourth impinger provided that he includes the filter in the

analysis for Pb.

8.3 In-stack Filter. The tester may use an in-stack filter provided that (1) he uses a

glass-lined probe and at least two impingers. each containing 100 ml of 0.1 N HNO., after the in-stack filter and [2] he recovers and analyzes the probe and impinger contents for Pb. Recover sample from the nuzzle with acetone if a particulate analysis is to be . made.

9. Bioliography

9.1 Perkin Elmer Corporation. Analytical Methods for Atomic Absorption Spectrophotometry, Norwalk, Connecticut, September 1976.

9.2 American Society for Testing and Materials. Annual Book of ASTM Standurds. Part 31; Water, Atmospheric Analysis,

Philadelphia, Pa. 1974. p. 40-12. 9.3 Klein, R. and C. Huch, Standard Additions-Uses and Limitations in Spectrophotometric Analysis. Amer. Lab. S.21-27, 1977.

8.4 Mitchell, W.J. and M.R. Midgett. Determining Inorganic and Alkyl Load Emissions from Stationary Sources, U.S. Environmental Protection Agency, Emission Monitoring and Support Laboratory, Research Triangle Park, N.C. (Presented at National APCA Meeting, Houston, June 20, 1978).

9.5 Same as Method 5, Citations 2 to 5 and 7 of Section 7.

(Secs. 111, 114, and 301(a) of the Clean Air Act as amended [42 U.S.C. 7411, 7414, wild 7601(2)))

IFR Doc. 62-10461 Filed 4-15-42: &43 ami

### ENVIRONMENTAL PROTECTION AGENCY

40 CFR Part 60

[AD-FRL-2620-3]

15125

Standards of Performance for New Stationary Sources; Reference Methods; Revision to Method 12 for Inorganic Lead To Add a Method of Additions Procedure

AGENCY: Environmental Protection Agency (EPA).

ACTION: Final rule.

SUMMARY: The purpose of this action is to promulgate a revision to Method 12 for inorganic lead of Appendix A of 40 CFR Part 60 to include a method of additions procedure, which deals with the resolution of any possible interferences in the lead analysis. This revision is necessary because it has been determined that the method of additions procedures previously cited by Method 12 may not be readily available to the analyst, and were not suitable for incorporation by reference. This revision was proposed in the Federal Register on December 12, 1983 (48 FR 55395). No changes in the revision bave been made since proposal, as no comment letters were received.

EFFECTIVE DATE: August 24, 1984.

Under section 307(b)(1) of the Clean Air Act, judicial review of this revision is available only by the filing of a petition for review in the U.S. Court of Appeals for the District of Columbia Circuit within 60 days of today's publication of this rule. Under section 307(b)(2) of the Clean Air Act, the requirements that are the subject of today's notice may not be challenged later in civil or criminal proceedings brought by EPA to enforce these requirements.

ADDRESSES: Docket. A docket, number A-83-38, containing materials considered by EPA in development of the promulgated rulemaking, is available for public inspection between 8:00 a.m. and 4:00 p.m., Monday through Friday, at EPA's Central Docket Section (LE-131), West Tower Lobby, Gallery 1, 401 M Street, SW., Washington, D.C. 20460. A reasonable fee may be charged for copying.

FOR FURTHER INFORMATION CONTACT: William Grimley or Roger Shigehara, Emission Measurement Branch, Emission Standards and Engineering Division (MD-19), U.S. Environmental Protection Agency, Research Triangle Park, North Carolina 27711, telephone (919) 541-2237.

supplementary information: This rulemaking does not impose any additional emission measurement requirements on facilities affected by this rulemaking. Rather, this rulemaking adds a supplementary analytical procedure to a test method that would apply irrespective of this rulemaking. This addition is necessary because the supplementary analytical procedure, which was previously cited by the method, is not suitable for incorporation by reference.

#### **Public Participation**

The revision was proposed and published in the Federal Register on December 12, 1983 (48 FR 55395). The opportunity to request a public hearing was presented to provide interested persons the opportunity for oral presentation of data, views, or arguments concerning the proposed revision, but no person desired to make an oral presentation. The public comment period was from December 12, 1983, to February 27, 1984. No comment letters were received.

#### Docket

The docket is an organized and complete file of the information 🖘 considered by EPA in the development of this rulemaking. The docket is a dynamic file, since material is added throughout the rulemaking development. The docketing system is intended to allow members of the public and industries involved to identify readily and locate documents so that they can intelligently and effectively participate in the rulemaking process. Along with the statement of basis and purpose of ... the proposed and promulgated rule and EPA responses to significant comments, the contents of the docket will serve as Like record in case of judicial review ; (Section 307(d)(7)(A)).

#### Miscellaneous ~

Under Executive Order 12291, EPA must judge whether a regulation is 'major" and therefore subject to the requirement of a regulatory impact analysis. This regulation is not major because it will not have an annual effect on the economy of \$100 million or more; it will not result in a major increase in costs or prices; and there will be no significant adverse effects on competition, employment, investment, productivity innovation, or on the ability of U.S.-based enterprises to compete with foreign-based enterprises in domestic or export markets. This regulation was submitted to OMB for ... review under E.O. 12291.

Pursuant to the provisions of 5 U.S.C. 605(o). I hereby certify that the attached

rule will not have a significant economic impact on small entities because no additional costs will be incurred. This rule does not contain any information collection requirements subject to OMB review under the Paperwork Reduction Act of 1980 U.S.C. 3501 et seq.

This rulemaking is issued under the authority of sections 111, 114, and 301(a) of the Clean Air Act, as amended (42 U.S.C. 7411, 7414, and 7601(a)).

#### List of Subjects in 40 CFR Part 60

Air pollution control, Aluminum, Ammonium sulfate plants, Asphalt, Cement industry, Coal Copper, Electric power plants, Glass and glass products. Grains, Intergovernmental relations, Iron, Lead. Metals, Metallic Minerals, Motor vehicles, Nitric acid plants, Paper and paper products industry, Petroleum, Phosphate. Sewage disposal, Steel Suffuric acid plants, Waste treatment and disposal, Zinc. Tires. Incorporation by Reference, Can surface coating, Sulfuric acid plants, Industrial organic chemicals. Organic solvent cleaners, Fossil fuel-fired steam generators. Fiberglass Insulation, Synthetic Fibers, Lime.

Dated: August 2, 1984.

Alvin L. Alm,

Acting Administrator.

#### PART 60-[AMENDED]

-- 40 CFR Part 60, Appendix A. Method 12, is amended as follows:

1. By revising Section 5.4.2 to read as follows:

#### §5.4.2 Check for Matrix Effects on the Lead Results.

Since the analysis for Pb by atomic absorption is sensitive to the chemical composition and to the physical properties (viscosity, pH) of the sample (matrix effects), the analyst shall check at least one sample from each source using the method of additions as follows:

Add or spike an equal volume of standard solution to an aliquot of the sample solution, then measure the absorbance of the resulting solution and the absorbance of an aliquot of unspiked sample.

Next, calculate the Pb concentration C, in µg/ml of the sample solution by using the following equation:

$$C_n = C_n \quad \frac{A_n}{A_n - A_n} \qquad \text{Eq. 12-1}$$

Where:
C<sub>n</sub>=Pb concentration of the standard
solution, µg/mi.

on F

fort.

tege

coo:

Con

of s

with

will

ma

pov

of 2

\_ter:

lice

chi

ιš;

lic

rac

e۲

CE

51

al

Fi V

- 5

. da

rate tables, which are proposed amendments to the International Mail Manual (incorporated by reference in the Code of Federal Regulations, 39 CFR 10.1), and which are to become effective on the date service begins. No comments were received.

Accordingly, the Postal Service states that it intends to begin Express Mail International Service with Norway on October 23, 1984 at the rates indicated in the table below.

List of Subjects in 39 CFR Part 10

Postal service, Foreign relations. 34.345

NORWAY.—EXPRESS MAIL INTERNATIONAL ... SERVICE

	,		<u> </u>
Custom designed sen	rice 1.4	On demand service	p4
Up to and moud	<b>~</b>	· · Up to and include	ng 😗 😁
Pounds	Pate	Pounds	Rate
			•••
!	\$29.00	2	320.00
3	31.70 35.40		23.70 27.40
4	31 10	3	3L10
5	42.80	5	34.80
6	46.50	i.a	30.50
7	50.20	7 -	42.20
	33.90	4	45.90
1	57.00	9	49.80
10	B1 30	10	53.30
''	82.00	11	57 00
12	72.40	12	<b>60.70</b>
14	70.10	13	64.40 66.70
-		15	73.80
16		16	75.50
17	87.20	17	79.20
18	90.90		<b>82.90</b>
19	94 50	19	86.60
20	98.30	20	90.30
21	102.00	21	94.00
z	105.70	22	97.70
24	112.10		101.40
25	116.60		108.80
26			112.50
27	24.20	26	115.20
26	. 127.90	28	119.90
	131.60	į 29	123.60
30	135.30	30	127.30
\$1 32	139 00	) 31   32	:31.00
33	145.00	171	. 134.70 138.40
34	150.10		142.10
35	153.80		145.80
<b>34</b>	157 50	36	149.50
37	161.20		153.20
36	164.90		155.90
40	168 60	39	160.60
41	176.00		164.30
Q	178.70	42	171.70
4	183 40	43	175.40
44	187.10	44	176.10
	<del></del>		

\*\* Plates in this table are applicable to each peop of international Custom Designed Express Mel shipped under a Service Agreement providing for lander by the customer at a designated Post Ofrice.

Picoup is available under a Service Agreement for an adold charge of \$5.60 for each pictup atop, regardless of the number of pecies piched up Domestic and international Europea half sicked up topieter under the same Service Agreement south one may observe others.

A transmittal letter making these changes in the pages of the International Mail Manual will be published in the Federal Register as provided in 39 CFR 10.3 and will be transmitted to subscribers automatically.

(39 U.S.C. 401, 404, 407)

W. Allen Sanders,

Associate General Counsel. Office of General Law and Administration.

[FR Doc. 84-25247 Filed 9-21-84; 8:45 am] BILLING CODE 77:10-12-86

## ENVIRONMENTAL PROTECTION AGENCY

40 CFR Part 60

[AD-FRL-2620-3]

Standards of Performance for New Stationary Sources; Reference Methods; Revision To Method 12 for Inorganic Lead To Add a Method of Additions Procedure

Correction

In FR Doc. 84-21131 beginning on page 33842 in the issue of Friday, August 24, 1984, make the following correction: In column three, the equation at the bottom of the page should read:

$$C_S = C_A \frac{A_S}{A_2 - A_S}$$

BILLING CODE 1905-01-M

DEPARTMENT OF TRANSPORTATION

Coast Guard ...

46 CFR Part 170

[CGD 79-023]

Subdivision and Stability Regulations

AGENCY: Coast Guard, DOT. ACTION: Final rule; correction.

SUMMARY: This document corrects three incorrect definitions in the final rule issued November 4, 1983.

FOR FURTHER INFORMATION CONTACT:
Lt. Albert W. Horsmon Jr., Commandant (G-MTH-5/13), Room 1308, U.S. Coast Guard Headquarters, Washington, D.C. 20593, (202) 428-2187.

Discussion of Correction

§ 170.170 [Amended] .--

In the Federal Register of November 4, 1983, page 51014, some definitions for the coefficient P in the inequality defining GM in § 170.170(a) are incorrect due to typographical errors. The second, third, and fourth definitions for P are corrected to read:

P = .055 + (L/1309) metric tons/m<sup>2</sup> . . . for occan service. Great Lakes winter service, or service on exposed waters.

P= .0033+(L/14.200)\* tons/ft\* ... for Great Lakes summer service or service on partially protected waters.

P=.036+(L/1309)<sup>2</sup> metric tons/m<sup>2</sup>... for Great lakes summer service or service on partially protected waters.

Dated: September 18, 1984.

Clyde T. Lusk, Jr.,

Rear Admiral, U.S. Coast Guard. Chief. Office of Merchant Marine Safety.

[FR Doc. 84-25312 Filed 9-21-84: 845 am]

## FEDERAL COMMUNICATIONS COMMISSION

47 CFR Part 1 = 100 विकास

Amendment of Part 1 of the Rules
Concerning Practice and Procedure in
the Private Radio Services (Concerning)

ACTION: Final rule; correction.

summary: This document corrects an error in the Appendix to an amendment of the rules of practice and procedure in the Private Radio Services.

FOR FURTHER INFORMATION CONTACT: 31 2 Robert DeYoung, Private Radio Bureau, (202) 832-7175

Mary Beth Hess, Private Radio Bureau, ... (202) 634-2443

SUPPLEMENTARY INFORMATION:

Erratum agency on the assistances (c)

Released: September 17, 1984.

In the matter of amendment of Part 1 of the Rules concerning Practice and Procedure in the Private Radio Services.

On July 24, 1984, the Commission released an Order (FCC 84-323) (August 2, 1984, 49 FR 30943) in the above-captioned proceeding. Section 1.925(f), 56 (g) and (h) were printed incorrectly in 1.54, the Appendix. Those paragraphs should read:

§ 1.925 Application for special temporary authorization, temporary permit or temporary operating authority.

(f) An applicant for a Ship Radio station license may operate the radio station pending issuance of the ship station authorization by the Commission for a period of 90 days, under a temporary operating authority, evidenced by a properly executed certification made on FCC Form 506-A.

(g) An applicant for a Business Radio station license utilizing an already Augustation license utilizing an already Augustation for a period of 180 days, the under a temporary permit, evidenced by