

SOUTH POINT PLANT SUPERFUND SITE

SOUTH POINT, OHIO

EPA Region 5 Records Ctr.



393830

Prepared for:

HONEYWELL INTERNATIONAL, INC.

Edina, Minnesota

May 8, 2007



engineering and constructing a better tomorrow

May 9, 2007

Nabil Fayoumi
Remedial Project Manager
Superfund Division
U. S. EPA - Region V
77 West Jackson Blvd.
Chicago, Illinois 60640


Re: South Point – 2006 Annual Groundwater Monitoring Report

Dear Mr. Fayoumi:

On behalf of Honeywell International Inc. (Honeywell), MACTEC Engineering and Consulting, Inc. (MACTEC) is pleased to provide you with one copy of the *2006 Annual Groundwater Monitoring Report, South Point Superfund Site, South Point, Ohio*. This submittal is the seventh annual report and presents the groundwater quality and groundwater flow evaluations for two semi-annual sampling events in 2006. Also, a compact disc containing the electronic data deliverables (EDD) in Region V format for the subject report will be forthcoming in a separate package.

If you have any questions or comments concerning the information presented in the report, please feel free to contact Steve Conn at (952) 806-0660.

Sincerely,
MACTEC Engineering and Consulting, Inc.


Steve G. Conn
Senior Project Manager
By DVG with Permission



Bruce Baker
Senior Principle Project Manager

cc: Chuck Geadelmann, Honeywell
Kevin O'Hara, Ohio EPA (1 Copy)
Craig Cox, Cox-Colvin, Inc. (1 Copy)
Joe Davis, OMI (1 Copy)

**2006 ANNUAL GROUNDWATER MONITORING REPORT
SOUTH POINT SUPERFUND SITE**

SOUTH POINT, OHIO

Prepared for:

**HONEYWELL INTERNATIONAL, INC.
7171 Ohms Lane
Branch 5242
Edina, Minnesota, 55439**

**MACTEC Engineering and Consulting, Inc.
46850 Magellan Drive, Suite 190
Novi, MI 48377**

May 8, 2007

Project 3310-05-2010

TABLE OF CONTENTS

| | | |
|-------|--|-----|
| 1.0 | INTRODUCTION | 1-1 |
| 2.0 | SITE SETTING..... | 2-1 |
| 3.0 | FIELD METHODS | 3-1 |
| 3.1 | WELL NETWORK STATUS | 3-1 |
| 3.2 | WATER-LEVEL MEASUREMENTS..... | 3-1 |
| 3.3 | GROUNDWATER SAMPLING | 3-2 |
| 4.0 | RESULTS | 4-1 |
| 4.1 | GROUNDWATER FLOW | 4-1 |
| 4.2 | GROUNDWATER QUALITY..... | 4-1 |
| 4.2.1 | Ammonia | 4-1 |
| 4.2.2 | Nitrate/Nitrite..... | 4-2 |
| 4.2.3 | Manganese | 4-3 |
| 4.2.4 | Beryllium | 4-3 |
| 4.2.5 | Cadmium | 4-4 |
| 4.2.6 | Copper | 4-4 |
| 4.3 | EXTRACTED GROUNDWATER AND CONTAMINANT MASS | 4-4 |
| 4.4 | HYDRAULIC CONTAINMENT | 4-4 |
| 5.0 | NPDES DISCHARGE TRENDS..... | 5-1 |
| 6.0 | SUMMARY AND RECOMMENDATIONS..... | 6-1 |
| 7.0 | REFERENCES | 7-1 |

TABLES

FIGURES

APPENDIX A: Water Sampling Logs

APPENDIX B: Analytical Data Sheets

LIST OF TABLES

Table

- | | |
|-----|---|
| 2-1 | Constituents of Concern and Performance Standards, South Point Plant Superfund Site, South Point, Ohio |
| 3-1 | Well Status, South Point Plant Superfund Site, South Point, Ohio |
| 3-2 | Depth to Groundwater and Calculated Groundwater Elevations, South Point Plant Superfund Site, South Point, Ohio |
| 4-1 | Analytical Results for the Year 2006 Monitoring, South Point Plant Superfund Site, South Point, Ohio |
| 4-2 | Extracted Groundwater Volume during Year 2006, South Point Plant Superfund Site, South Point, Ohio |
| 4-3 | Extracted Contaminant Mass during Year 2006, South Point Plant Superfund Site, South Point, Ohio |
| 5-1 | NPDES Discharge Data, South Point Plant Superfund Site, South Point, Ohio. |

LIST OF FIGURES

Figure

- 2-1 Site Location, South Point Plant Superfund Site, South Point, Ohio
- 3-1 Well Network, South Point Plant Superfund Site, South Point, Ohio
- 4-1 Groundwater Flow Map (April 2006), South Point Plant Superfund Site, South Point, Ohio
- 4-2 Groundwater Flow Map (October 2006), South Point Plant Superfund Site, South Point, Ohio
- 4-3 Groundwater Plume Geometry (April 2006), South Point Plant Superfund Site, South Point, Ohio
- 4-4 Groundwater Plume Geometry (October 2006), South Point Plant Superfund Site, South Point, Ohio
- 4-5 Ammonia Trends in Groundwater at the South Point Plant Superfund Site, South Point, Ohio
- 4-6 Nitrate/Nitrite Trends in Groundwater at the South Point Plant Superfund Site, South Point, Ohio
- 4-7 Manganese Trends in Groundwater at the South Point Plant Superfund Site, South Point, Ohio
- 5-1 NPDES Trends at the South Point Plant Superfund Site, South Point, Ohio.

1.0 INTRODUCTION

This document represents the annual report for the groundwater monitoring program conducted at the South Point Superfund Site (Plant) in South Point, Ohio during the year 2006. Groundwater monitoring was conducted, and this report was prepared, in accordance with the Final Design Report (FDR) for the South Point Plant Superfund Site (Parsons Engineering Science [Parsons], 2001). Groundwater quality and flow conditions are monitored semi-annually. The objective of this monitoring is to assess the flow and groundwater quality until the remedial goals for groundwater are met.

This report presents the site setting, the field methods used for groundwater monitoring, the results of the groundwater monitoring, the National Pollutant Discharge Elimination System (NPDES) permitted discharge trends, and the conclusions and recommendations for monitoring in 2007. In addition, the groundwater quality data was provided to United States Environmental Protection Agency (USEPA) in an electronic form consistent with Region V's electronic data deliverable (EDD) format.

In 2006, a 5-Year Review, as required by Section 121 of CERCLA, was conducted by the USEPA and the Ohio Environmental Protection Agency (OEPA). On April 19, 2006, USEPA and OEPA performed a 5-Year Review inspection at the site. Following their inspection, the USEPA issued the site's 5-Year Review Report on May 8, 2006. The report concluded with USEPA requesting the following actions be performed:

An Institutional Controls (IC) Plan shall be prepared within six months of the date of the Five Year Review Report is signed to address the following IC issues:

Revise deeds to show the exact locations of the Eastern Disposal Area and Northern Fly Ash Pond;
Revise groundwater IC's at the time the Records of Decision (ROD's) performance standards are met; allowing the parcel owner to petition USEPA to remove groundwater use restriction;
Incorporate an annual certification step to the O&M Plan and provide copies of the reports to the current landowners;

- Honeywell shall work with the current owners of parcels 2, 3, and 4 and the Village of South Point to place the appropriate groundwater usage restrictions on these parcels. USEPA will assist Honeywell as appropriate and necessary;
- The plan shall include IC maps (paper and GIS formats) to identify the Site and all areas subject to restrictions;

- Explore feasibility of implementing covenants under the Ohio version of the Uniform Environmental Covenants Act for as many parcels as possible.; and
 - Examine the extent to which the Lawrence Economic Development Corporation (LEDC) and Honeywell International Inc. (Honeywell) are required to notify USEPA prior to the transfer of Site parcels, and contact them about placing appropriate restrictions when transfers of land occur.
- USEPA will work with Honeywell on potential optimization strategies for the groundwater capture system as recommended in the Groundwater Evaluation and Optimization System (GEOS) Report, which was part of the 5-Year Report.
 - USEPA and Honeywell will work with LEDC on issues related to redeveloping their portion of the Northern Fly Ash Ponds for cargo container storage. USEPA's Remedial Program will communicate with the Regional Redevelopment Coordinator to discuss the potential for the LEDC portion of the Site to be nominated for a national redevelopment award.

On November 17, 2006, an IC Plan was submitted to the USEPA and OEPA, which addressed the IC issues presented in the 5-Year Review Report.

On October 2, 2006, MACTEC Engineering and Consulting, Inc. (MACTEC) submitted to USEPA a response letter to the findings listed in the GEOS report review of the South Point Superfund Site 5-Year Review Report. The letter summarized the GEOS findings and provided responses to each, which included clarifying the historic basis for some of the apparent inconsistencies noted by GEOS. Based on GEOS' recommendations and conclusions, the response letter provided the following proposed activities:

- **Target Capture Zones** – Explore existing data and other site information to attempt to refine the sites target capture zone. If additional data are needed, extra monitoring locations and procedures for obtaining this data will be proposed.
- **Hydraulic Gradient/Hydraulic Containment Areas** - Conduct sensitivity analysis in conjunction with groundwater modeling with a new, revised model with more realistic boundary conditions.
- **Required Rates of Groundwater Pumping** - Investigate, through sensitivity analysis groundwater modeling and data evaluation, the effectiveness of the pumping system, and validate existing target flow rates or propose other flow rates sufficient to protect off-site water supply sources.

- **Well Efficiency Evaluation** - Evaluate pumping well efficiency and perform any necessary maintenance to restore pumping capacity. Two piezometers will be installed, one at each pumping well, to provide data indicating present condition and any trends in loss of efficiency.
- **Monitoring Well Network** - Based on the results of the Target Capture Zone and Capture Zone analysis, propose additional wells necessary to optimize the existing monitoring well network.

As of this date, neither Honeywell nor MACTEC has received a response and/or approval from USEPA on either the proposed IC Plan or activities presented in the response letter to the GEOS report.

2.0 SITE SETTING

The Plant is located on a relatively flat part of an Ohio River terrace, within the eastern flood plain of the Ohio River (Figure 2-1). The Plant is situated on 70 to 100 feet of unconsolidated alluvium and glacial outwash sediment resting on bedrock. The glacial sediments comprise the principal aquifer of the area. Overlying the aquifer is a relatively uniform silt and fine sand unit which is generally seven to ten feet thick.

Groundwater in the unconsolidated aquifer is present under unconfined conditions. The water table (phreatic surface) occurs at an average elevation of 514 feet above mean sea level (msl) in Plant observation wells. This corresponds to an average depth-to-water of 45 feet. The average saturated thickness of the aquifer is 38 feet. Pumping test results indicate that the transmissivity of the aquifer is approximately 13,500 ft²/day and the average hydraulic conductivity is 386 ft/day. Using an effective porosity of 0.2, groundwater velocities were calculated to range from 3.9 ft/day to 19 ft/day during the Remedial Investigation (RI) (Geraghty & Miller, 1994).

During the RI, groundwater was determined to be impacted by elevated levels of waste-specific compounds (nitrate and ammonia), sulfate, iron, manganese, and other metals from on-site sources. Contaminant plumes were identified beneath the Plant and centered on the Plant's Central Well Field and Disposal Area D. Results of a borehole conductivity survey conducted during the RI indicate that, contaminant concentrations are highest, in general, near the top of the aquifer and diminish with depth. Preliminary remedial goals (PRGs) were developed for constituents of concern in both soil and groundwater based on the findings of the RI, a Baseline Risk Assessment, and an Ecological Risk Assessment. The PRGs were adopted as Performance Standards (PS) for groundwater. These standards are presented in Table 2-1.

The following remedial action objectives address groundwater and soil for protection of human health and the environment:

- prevent ingestion of contaminated groundwater (nitrates, ammonia, metals) under the Plant by future human receptors,
- restore quality of the local groundwater under the Plant,
- minimize potential ingestion and dermal contact of contaminated surface soils by current and future human receptors,

- excavate arsenic contaminated soils in the Mid-Plant Area which exceeds the arsenic PS for soils, and
- excavate coke-oven gas line drip pots and their surrounding soils which contain contaminants of concern at concentrations exceeding the soil PSs.

The selected remedy for groundwater, as proposed by Remedial Alternative RA-5A in USEPA's Proposed Plan (USEPA, 1997), consisted of:

- institutional controls,
- containment through pumping of the existing containment system,
- discharge to the Ohio River, and
- groundwater monitoring and submittal of an annual monitoring report.

The remedy for soils, completed in December 2001, consisted of:

- institutional controls,
- excavation of wastes from Disposal Area D,
- excavation of arsenic contaminated soils from the Mid-Plant Area,
- excavation of the coke-oven gas line drip pots and contaminated soils,
- consolidation of wastes within the Eastern Disposal Area,
- construction of an onsite landfill in the Eastern Disposal Area for wastes from Disposal Area D and arsenic contaminated soils from the Mid-Plant Area having concentrations less than 400 milligrams per kilogram, and
- offsite disposal of the coke-oven gas line drip pots and contaminated soils associated with the drip pots, and arsenic contaminated soils from the Mid-Plant Area having concentrations greater than 400 milligrams per kilogram.

3.0 FIELD METHODS

The field activities of the semi-annual groundwater monitoring program were conducted in April and October 2006. The locations of the wells used for containment, water-level monitoring, and groundwater quality monitoring are presented on Figure 3-1.

3.1 WELL NETWORK STATUS

The site's well network consists of:

- Thirteen inactive production wells for water level measurement only;
- Two containment wells for groundwater containment and groundwater quality monitoring;
- Fifteen monitoring wells for water level measurement and groundwater quality monitoring;
- Six monitoring wells for water level measurement only; and
- One Ohio River water level measuring point.

The status of the well network is summarized in Table 3-1.

The two containment wells, SPIS-23 and SPIS-24 are connected to a remote monitoring system and are inspected at least weekly to monitor their performance throughout the year. Both wells were offline at some point during the year for maintenance or due to equipment malfunctions. SPIS-24 was offline from January 4, 2006 to February 6, 2006 due a pump motor failure and repair. Well pressure and production rates were monitored for both wells throughout the year.

3.2 WATER-LEVEL MEASUREMENTS

Groundwater levels were measured in April and October 2006 to determine the direction of groundwater flow. Static groundwater-level measurements were collected from the monitor well network during each sampling episode. An electronic water-level indicator was used to measure the distance between the surveyed measuring point and the groundwater surface. These measurements were subtracted from surveyed elevations to determine groundwater elevations which in turn were used to generate groundwater flow maps. Table 3-2 provides the water-level measurements and elevations collected during 2006.

3.3 GROUNDWATER SAMPLING

Prior to initiation of purging and sampling activities, static water levels were measured in all monitor wells as described above. Monitor wells were purged and sampled using an electrically-operated submersible pump. Production wells were purged and sampled while operating. Water sampling logs are provided in Appendix A.

The wells used for collection of groundwater samples are indicated on Table 3-1. Samples were submitted to Severn Trent Laboratories in Pittsburgh for the April event and Columbia Analytical Services in October, for laboratory analyses of ammonia, selected total metals (arsenic, beryllium, cadmium, copper, manganese, nickel), and nitrate/nitrite.

4.0 RESULTS

This section discusses the results of the field activities and laboratory analyses obtained for the 2006 groundwater monitoring program. The discussions include: groundwater flow; groundwater quality; extracted groundwater and contaminant mass; and hydraulic containment.

4.1 GROUNDWATER FLOW

Groundwater level data collected during 2006 are provided in Table 3-2. The groundwater elevation data from the two semi-annual monitoring events were used to generate water-table maps which show the direction of groundwater flow. Figures 4-1 and 4-2 show that the groundwater flow at the site is primarily to the southwest, toward the Ohio River and a groundwater depression is formed by the containment wells SPIS-23 and SPIS-24. The hydraulic gradient of the groundwater surface was 0.00225 and 0.00278 feet/feet in April and October 2006, respectively. Based on a hydraulic conductivity of 386 ft/day and an effective porosity of 0.2 (Geraghty & Miller, 1994), groundwater flow velocity was calculated to range from 4.8 to 5.8 ft/day.

4.2 GROUNDWATER QUALITY

Analytical results for the two semi-annual sampling events are provided in Table 4-1. Analytical data sheets are provided in Appendix B. Concentrations of ammonia, nitrate/nitrite, manganese, beryllium, cadmium, and copper were reported above their respective PS in groundwater collected during both sampling events. Arsenic and nickel concentrations were below the PS. Details of the exceedance are discussed below.

4.2.1 Ammonia

Although ammonia is present in many of the groundwater samples analyzed, it was detected above the site-specific PS of 30 milligrams per liter at four locations during 2006 (Table 4-1). These locations are:

- SPIS-24 30.8 mg/l in April
- SPMW-06R 35.1 mg/l in April; 39.9 mg/l in October
- SPMW-07 48.4 mg/l in April; 131.0 mg/l in October
- SPMW-09 37.6 mg/l in April; 36.7 mg/l in October

Figures 4-3 and 4-4 depict the aerial distribution of ammonia in groundwater at the Plant. Identified on these figures are the inferred extent of the ammonia plumes that exceed the PS of 30 mg/l. The plumes are confined upgradient of the two containment wells (SPIS-23 and SPIS-24). Figure 4-5 presents a comparison of ammonia concentration trends for selected wells since the monitoring program began in 2000. The 2006 monitoring results for ammonia show a general decline in concentration in most of the wells with the exception of a marked increase in monitor well SPMW-07. The data appears to represent the end of a four year period of decreasing ammonia concentrations in this well that began at the end of 2001, coincident with excavation and construction activities at the site¹. The activities may have increased the permeability of surface soils resulting in additional recharge to the aquifer.

4.2.2 Nitrate/Nitrite

Although nitrate/nitrite is present in most of the groundwater samples analyzed, it was detected at or above the site-specific PS of 10 mg/l at six locations during 2006 (Table 4-1). These locations are:

- SPMW-02 17.8 mg/l in April
- SPIS-24 11.9 mg/l in April
- SPMW-06R 21.8 mg/l in April; 28.6 mg/l in October
- SPMW-07 24.9 mg/l in April; 38.4 mg/l in October
- SPMW-09 24.9 mg/l in October
- SPOB-12R2 14.4 mg/l in April

Figures 4-3 and 4-4 depict the aerial distribution of nitrate/nitrite in groundwater at the Plant. Identified on these figures is the inferred extent of the nitrate/nitrite plume that exceeds the 10 mg/l PS. The Mid-Plant Area plumes are confined upgradient of the two containment wells (SPIS-23 and SPIS-24). The most downgradient exceedance was at SPOB-12R2, which is in the immediate vicinity of SPIS-23. Nitrate/nitrite was detected at SPOB-12R2 at 14.4 mg/l in April and 9.17 mg/l in October. Nitrate/nitrite concentrations also exceeded the 10 mg/l standard in the October sampling event at SPMW-09, downgradient of Disposal Area D; however, the downgradient extent of this plume is expected to be limited.

¹These activities include excavation of contaminated soils and the construction of the landfill by Honeywell in 2000-2001; and the road construction and redevelopment of the site by the Lawrence Economic Development Corporation, which is ongoing.

Figure 4-6 presents a comparison of nitrate/nitrite concentration trends for selected wells since the monitoring program began in 2000. The 2006 data shows that, in general, nitrate/nitrite concentrations increased in three of the monitoring wells and for the other wells there was a decrease or little change in nitrate/nitrite concentrations during the 2006 monitoring period. The most notable decline was observed in well SPMW-02, and the most notable increase was observed in well SPMW-07.

4.2.3 Manganese

Manganese was present in all groundwater samples analyzed during year 2006. However, it was detected at or above the site-specific PS of 1.4 mg/l at only two locations (Table 4-1). These locations are:

- SPMW-06R 2.9 mg/l in April; 3.8 mg/l in October
- SPMW-09 4.5 mg/l in April; 15.2 mg/l in October

Figures 4-3 and 4-4 depict the aerial distribution of manganese in groundwater at the Plant. These occurrences are consistent with previous sampling events. Figure 4-7 presents a comparison of manganese concentration trends for selected wells since the monitoring program began in 2000. Manganese concentrations appear to be stable or on a general decline except for SPMW-09 and SPMW-06R which have increased. Manganese concentrations in SPMW-09, fluctuated considerably during 2002, 2003, and 2004 following excavation activities at Disposal Area D. The current declining trend indicates that the affects of the excavation on the groundwater system may be waning, as seen in the ammonia data (Figure 4-5).

4.2.4 Beryllium

Beryllium was detected above the site-specific PS of 0.004 mg/l only once in 2006. The detection of 0.0055 mg/l occurred in October in SPMW-09 (Table 4-1). The pH of the water in SPMW-09 has historically been low. In April the pH was 4.16, and in October the pH was 3.47. The pH for the site generally ranges from 6.5 to 7.2. The contaminants in groundwater at SPMW-09 likely represent a small and separate plume which is pH dependent. Accordingly, as the plume migrates the pH is restored to neutral and it is believed that the concentrations of dissolved metals naturally decline.

4.2.5 Cadmium

Cadmium was detected above the site-specific PS of 0.005 mg/l once in 2006. The detection of 0.011 mg/l occurred in October in SPMW-09 (Table 4-1). As stated under Section 4.2.4, the groundwater pH in the area of SPMW-09 is normally lower than the general site, and it is believed that the concentration of cadmium declines below the PS a short distance from SPMW-09 as the pH adjusts.

4.2.6 Copper

Copper was not detected above the site-specific PS of 3.8 mg/l in any of the wells sampled in 2006.

4.3 EXTRACTED GROUNDWATER AND CONTAMINANT MASS

In-line cumulative flow meter readings show that a combined total of approximately 265 million gallons of groundwater were extracted by the containment wells SPIS-23 and SPIS-24 during the year 2006. Individual totals for SPIS-23 and SPIS-24 were approximately 81 million and 184 million gallons, respectively (Table 4-2).

Using the groundwater extraction information and the groundwater quality results, the mass of contaminants removed from the groundwater beneath the Plant can be calculated. The summarized calculations are provided in Table 4-3. The extracted mass of those contaminants of concern detected above PSs during the year 2006 are as follows:

- Ammonia - 19,506 kg;
- Nitrate/Nitrite - 8,536 kg; and
- Manganese - 328 kg.

4.4 HYDRAULIC CONTAINMENT

The feasibility study for the Plant (Geraghty & Miller, 1997) included a groundwater modeling simulation that demonstrated that pumping SPIS-23 and SPIS-24 would provide a capture zone capable of capturing the present day plume. This capture zone model was based on a pumping rate of 150 gpm for each extraction well. During 2006, SPIS-23 and SPIS-24 pumped at average rates of 154 GPM and 350 GPM, respectively. These pumping rates have been effective in containing the groundwater plumes as demonstrated by the analytical results discussed in Section 4.3.

5.0 NPDES DISCHARGE TRENDS

Groundwater from extraction wells and storm water runoff are combined and then discharged through an outfall to the Ohio River. This outfall is permitted under Ohio EPA NPDES, which details effluent limitations and monitoring requirements.

The site's NPDES permit is maintained and monitored by the Lawrence Economic Development Corporation. The 5-year permit (Number 0IN00088*DD) was renewed on May 1, 2003. The permit requires daily monitoring of the flow rate, monthly sampling for ammonia and nitrate concentrations, and semi-annual sampling for pH and acute toxicity at Outfall 007. This outfall is equipped with an automated monitoring system. There are currently no permit limits for ammonia and nitrate. The permitted range for pH is 6.5 to 9.0 standard units. The permit limit for acute toxicity is 3.1 acute toxicity units.

Discharge data for ammonia and nitrate/nitrite from January 1997 through December 2006 are provided in Table 5-1 and presented graphically on Figure 5-1. The data shows a general increase in ammonia concentrations during the middle portion of the year. Nitrate concentrations appear to follow a similar, but less pronounced trend.

6.0 SUMMARY AND RECOMMENDATIONS

Groundwater flow continues to be generally to the southwest toward the Ohio River. Ammonia and/or nitrate/nitrite were detected in groundwater samples above their respective PSs in a total of six monitoring wells. Beryllium, cadmium, and manganese were detected in an isolated occurrence above their respective PSs in monitor well SPMW-09. It is believed that these concentrations are pH dependent and that they are localized around SPMW-09. The two primary contaminant plumes are being captured by containment wells SPIS-23 and SPIS-24. Capture-zone models and inspection of groundwater flow maps support this. The present scope of groundwater monitoring should be continued for the year 2007.

Two water-level sampling points (SPIS-25 and SPIS-27) continue to not respond to changes in water levels as do other wells in the immediate area, yielding spurious water levels. The lack of change can be due to iron fouling or an accumulation of sediment in the borehole and or screen. Because of this, it is recommended that these sample points be removed from the list of monitoring points used for the collection of water levels. The loss of this data would not adversely affect the monitoring program.

7.0 REFERENCES

- Geraghty & Miller, Inc., 1994. Remedial Investigation Report, South Point Plant Site, South Point, Ohio. Unpublished Consultant's Report.
- Geraghty & Miller, Inc., 1997. Final South Point Feasibility Study, South Point, Ohio. Unpublished Consultant's Report.
- Parsons Engineering Science, Inc., 1998. Remedial Design Workplan, South Point Superfund Site, South Point, Ohio. Unpublished Consultant's Report.
- Parsons Engineering Science, Inc., 2001. Final Design Report, South Point Superfund Site, South Point, Ohio. Unpublished Consultant's Report.
- United States Environmental Protection Agency, 1997. Record of Decision (ROD), Allied Signal South Point Plant Site, South Point, Ohio.

TABLES

Table 2-1
Constituents of Concern and Groundwater Performance Standards
South Point Plant Superfund Site
South Point, Ohio

| Constituents of Concern | Performance Standard (mg/l) |
|--------------------------------|------------------------------------|
| Arsenic | 0.05 |
| Beryllium | 0.004 |
| Cadmium | 0.005 |
| Copper | 3.8 |
| Manganese | 1.4 |
| Nickel | 2.0 |
| Ammonia (as Nitrogen) | 30 |
| Nitrate/Nitrite | 10 |

**Table 3-1
Well Status
South Point Plant Superfund Site
South Point, Ohio**

| Name | Well Type | Water Levels | Water Quality |
|-----------|-----------------------------|--------------|---------------|
| Cassion | River Level Measuring Point | Yes | |
| SPIS-01 | Inactive Production | Yes | |
| SPIS-02 | Inactive Production | Yes | |
| SPIS-05 | Inactive Production | Yes | |
| SPIS-06 | Inactive Production | Yes | |
| SPIS-10 | Inactive Production | Yes | |
| SPIS-15 | Inactive Production | Yes | |
| SPIS-15A | Inactive Production | Yes | |
| SPIS-18 | Inactive Production | Yes | |
| SPIS-22 | Inactive Production | Yes | |
| SPIS-23* | Containment | | Yes |
| SPIS-24* | Containment | | Yes |
| SPIS-25 | Inactive Production | Yes** | |
| SPIS-26 | Inactive Production | Yes | |
| SPIS-27 | Inactive Production | Yes** | |
| SPIS-28 | Inactive Production | Yes | |
| SPMW-01 | Monitor | Yes | Yes |
| SPMW-02 | Monitor | Yes | Yes |
| SPMW-03 | Monitor | Yes | Yes |
| SPMW-04 | Monitor | Yes | Yes |
| SPMW-05 | Monitor | Yes | Yes |
| SPMW-06R | Monitor | Yes | Yes |
| SPMW-07 | Monitor | Yes | Yes |
| SPMW-08 | Monitor | Yes | Yes |
| SPMW-09 | Monitor | Yes | Yes |
| SPMW-10R | Monitor | Yes | Yes |
| SPMW-11R | Monitor | Yes | Yes |
| SPMW-12 | Monitor | Yes | Yes |
| SPMW-13 | Monitor | Yes | Yes |
| SPOB-12R2 | Observation | Yes | Yes |
| SPOB-15R2 | Observation | Yes | |
| SPOB-17R | Observation | Yes | |
| SPOB-18R | Observation | Yes | |
| SPOB-26 | Observation | Yes | |
| SPOB-29 | Observation | Yes | |
| SPOB-34 | Observation | Yes | Yes |
| T2-B | Piezometer | Yes | |

* Active Production Well.

** Water Levels from these wells are anomalous.

Table 3-2
Depth to Groundwater and Calculated Groundwater Elevation
South Point Superfund Site
South Point, Ohio

| Name | Depth-To-Water | | Water Level Elevation | |
|-----------|----------------|------------|-----------------------|------------|
| | 4/10/2006 | 10/23/2006 | 4/10/2006 | 10/23/2006 |
| Caisson | 32.90 | 31.90 | 517.39 | 518.39 |
| SPIS-01 | 43.22 | 43.60 | 518.27 | 517.89 |
| SPIS-02 | 43.03 | 44.35 | 518.58 | 517.26 |
| SPIS-05 | 43.89 | 44.16 | 518.42 | 518.15 |
| SPIS-06 | 49.05 | 49.12 | 518.10 | 518.03 |
| SPIS-10 | 44.37 | 44.64 | 521.20 | 520.93 |
| SPIS-15 | 43.43 | 43.50 | 520.82 | 520.75 |
| SPIS-15A | 36.74 | 36.43 | 523.97 | 524.28 |
| SPIS-18 | 37.84 | 37.10 | 522.35 | 523.09 |
| SPIS-22 | 46.27 | 46.04 | 518.08 | 518.31 |
| SPIS-25* | 46.74 | 46.20 | 525.63 | 526.17 |
| SPIS-26 | 46.13 | 46.82 | 523.05 | 522.36 |
| SPIS-27* | 49.51 | 48.82 | 522.49 | 523.78 |
| SPIS-28 | 46.39 | 46.50 | 517.75 | 517.64 |
| SPMW-01 | 36.35 | 37.14 | 527.55 | 526.76 |
| SPMW-02 | 47.33 | 48.08 | 521.70 | 520.95 |
| SPMW-03 | 43.96 | 44.46 | 519.12 | 518.62 |
| SPMW-04 | 48.91 | 48.83 | 517.86 | 517.94 |
| SPMW-05 | 61.11 | 61.90 | 522.55 | 521.76 |
| SPMW-06R | 72.02 | 72.80 | 523.76 | 522.98 |
| SPMW-07 | 43.50 | 44.10 | 519.18 | 518.58 |
| SPMW-08 | 42.38 | 42.90 | 523.11 | 522.59 |
| SPMW-09 | 40.32 | 40.27 | 524.33 | 524.38 |
| SPMW-10R | 67.71 | 68.52 | 524.47 | 523.66 |
| SPMW-11R | 49.82 | 50.11 | 516.53 | 516.24 |
| SPMW-12 | 48.54 | 48.80 | 517.54 | 517.28 |
| SPMW-13 | 48.07 | 48.14 | 517.84 | 517.77 |
| SPOB-12R2 | 49.92 | 50.08 | 518.07 | 517.91 |
| SPOB-15R2 | 44.92 | 44.81 | 518.63 | 518.74 |
| SPOB-17R | 32.28 | 34.88 | 521.01 | 518.41 |
| SPOB-18R | 34.82 | 34.58 | 517.54 | 517.78 |
| SPOB-26 | 34.67 | 34.18 | 520.54 | 521.03 |
| SPOB-29 | 43.43 | 43.55 | 520.17 | 520.05 |
| SPOB-34 | 47.38 | 47.55 | 517.70 | 517.53 |
| T2-B | 17.60 | 18.05 | 525.30 | 524.85 |

* Recommended for deletion from the water level monitoring list because of spurious readings during each monitoring period.

Table 4-1
2006 Groundwater Monitoring Results
South Point Plant Superfund Site
South Point, Ohio

| Location Sample Name Sample Date Sample Type Media Laboratory Lab ID | Concentration | | Monitoring Network | Monitoring Network | Monitoring Network | Monitoring Network | Monitoring Network | Monitoring Network | Monitoring Network | Monitoring Network |
|--|---------------|-------|--|---|--|--|---|---|--|---|
| | Units | PS | SPIS-23 4/11/2006 Industrial Supply Well Ground Water Columbia Analytical Services CSD280128011 | SPIS-23 10/25/2006 Industrial Supply Well Ground Water Columbia Analytical Services CSJ200402008 | SPIS-24 4/12/2006 Industrial Supply Well Ground Water Columbia Analytical Services CSD280128012 | SPIS-24-DUPLICA 4/12/2006 Industrial Supply Well Ground Water Columbia Analytical Services CSD280128013 | SPIS-24 10/25/2006 Industrial Supply Well Ground Water Columbia Analytical Services CSJ200402009 | SPIS-24 DUPLICA 10/25/2006 Industrial Supply Well Ground Water Columbia Analytical Services CSJ200402010 | SPMW-01 4/11/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128001 | SPMW-01 10/24/2006 Monitor Well Ground Water Columbia Analytical Services CSJ190360001 |
| Arsenic | MG/L | 0.05 | J.0032 | 0.0021 | < 0.01 | < 0.01 | 0.0012 | 0.0012 | < 0.01 | < 0.001 |
| Beryllium | MG/L | 0.004 | < .005 | < .005 | J.00045 | B.00046 | < .001 | < .001 | < .005 | < 0.005 |
| Cadmium | MG/L | 0.005 | < .005 | < .001 | < .005 | < .005 | < .001 | < .001 | < .00081 | < 0.001 |
| Copper | MG/L | 3.8 | < .025 | < .001 | B.012 | J.0073 | 0.239 | 0.0175 | < .025 | < 0.001 |
| Manganese | MG/L | 1.4 | 0.257 | 0.266 | 0.338 | 0.39 | 0.371 | 0.356 | J.0137 | 0.0166 |
| Nickel | MG/L | 2 | J.0045 | 0.0088 | J.0037 | J.005 | 0.121 | 0.0111 | J.004 | 0.0071 |
| Ammonia as Nitrogen | MG/L | 30 | 0.42 | 0.57 | 30.8 | 24.8 | 24.8 | J.17 | J.17 | < 0.05 |
| Nitrate/Nitrite | MG/L | 10 | 3.6 | 3.05 | 11.9 | 10.6 | 9.66 | 9.73 | 2.1 | 1.77 |

| Location Sample Name Sample Date Sample Type Media Laboratory Lab ID | Concentration | | Monitoring Network | Monitoring Network |
|--|---------------|-------|--|---|--|---|--|---|--|---|
| | Units | PS | SPMW-02 4/11/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402007 | SPMW-02 10/24/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402004 | SPMW-03 4/11/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128010 | SPMW-03 10/25/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402007 | SPMW-04 4/12/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128019 | SPMW-04 10/25/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402015 | SPMW-05 4/11/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128002 | SPMW-05 10/24/2006 Monitor Well Ground Water Columbia Analytical Services CSJ190360002 |
| Arsenic | MG/L | 0.05 | < 0.01 | < .001 | < 0.01 | < .001 | < 0.01 | < .001 | < 0.01 | < 0.01 |
| Beryllium | MG/L | 0.004 | < .005 | < .001 | < .005 | < .001 | J.00058 | < .005 | < .005 | < .005 |
| Cadmium | MG/L | 0.005 | < .00045 | < .001 | < .005 | < .001 | < .005 | < .001 | < .005 | < .001 |
| Copper | MG/L | 3.8 | J.0012 | 0.0012 | < .00029 | < .001 | < .025 | 0.0013 | < .025 | 0.003 |
| Manganese | MG/L | 1.4 | 0.559 | 0.153 | 0.328 | 0.0581 | 0.0274 | 0.0228 | 0.017 | 0.0439 |
| Nickel | MG/L | 2 | J.0027 | 0.0048 | J.0121 | 0.0052 | J.0049 | 0.006 | J.003 | 0.0237 |
| Ammonia as Nitrogen | MG/L | 30 | J.68 | 0.05 | J.005 | 0.154 | J.06 | < 0.05 | J.06 | < 0.05 |
| Nitrate/Nitrite | MG/L | 10 | 17.8 | 3.89 | 2.5 | 3.14 | 2.7 | 3.68 | J.3 | 2.44 |

| Location Sample Name Sample Date Sample Type Media Laboratory Lab ID | Concentration | | Monitoring Network | Monitoring Network | Monitoring Network | Monitoring Network | Monitoring Network | Monitoring Network | Monitoring Network | Monitoring Network |
|--|---------------|-------|---|--|--|--|---|---|--|---|
| | Units | PS | SPMW-06R 4/12/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128004 | SPMW-06R 10/24/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402001 | SPMW-07 4/11/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128008 | SPMW-07-DUPLICA 4/11/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128009 | SPMW-07 10/25/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402005 | SPMW-07 DUPLICA 10/25/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402006 | SPMW-08 4/11/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128005 | SPMW-08 10/24/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402002 |
| Arsenic | MG/L | 0.05 | < 0.01 | 0.0044 | < 0.01 | < 0.01 | < .001 | < .001 | < 0.01 | < .001 |
| Beryllium | MG/L | 0.004 | < .005 | < .005 | < .005 | < .001 | < .001 | < .001 | < .005 | < .001 |
| Cadmium | MG/L | 0.005 | < .005 | < .001 | < .00054 | < .00056 | < .001 | < .001 | < .005 | < .001 |
| Copper | MG/L | 3.8 | J.001 | 0.004 | J.0025 | J.0024 | 0.0023 | 0.0038 | < .025 | 0.0013 |
| Manganese | MG/L | 1.4 | 2.89 | 3.84 | 0.474 | 0.463 | 0.407 | 1.34 | 1.35 | 1.35 |
| Nickel | MG/L | 2 | J.0156 | 0.0372 | J.0033 | J.0032 | 0.008 | 0.0082 | J.00055 | 0.0122 |
| Ammonia as Nitrogen | MG/L | 30 | 35.1 | 39.9 | 48.4 | 44.7 | 130 | 131 | 0.26 | 0.172 |
| Nitrate/Nitrite | MG/L | 10 | 21.8 | 28.6 | 24.9 | 23.5 | 38.4 | 38.4 | J.05 | 0.23 |

Qualifiers preceding the value are flags determined by the lab. Qualifiers following the value are designated upon in-house validation.

- < Not detected.
- Bold Concentrations** Represent values above PS.
- PS Preliminary Remedial Goals.
- B Estimated. (preceding value).
- J Estimated. (following value).

Table 4-1
2006 Groundwater Monitoring Results
South Point Plant Superfund Site
South Point, Ohio

| Location Sample Name Sample Date Sample Type Media Laboratory Lab ID | | | Monitoring Network SPMW-09 4/12/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128006 | Monitoring Network SPMW-09 10/24/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402003 | Monitoring Network SPMW-10R 4/11/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128003 | Monitoring Network SPMW-10R 10/24/2006 Monitor Well Ground Water Columbia Analytical Services CSJ190360003 | Monitoring Network SPMW-11R 4/12/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128016 | Monitoring Network SPMW-11R 10/25/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402012 | Monitoring Network SPMW-12 4/12/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128017 | Monitoring Network SPMW-12 10/25/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402013 |
|--|------------------------|------------|--|---|---|--|---|--|--|---|
| | Concentration Units | PS MG/L | | | | | | | | |
| Arsenic | MG/L | 0.05 | < 0.01 | < .001 | < 0.01 | 0.0018 | J .0018 | < .001 | < 0.01 | 0.001 |
| Beryllium | MG/L | 0.004 | J .0025 | 0.0055 | J .0011 | < .005 | J .00058 | < .005 | J .00034 | < .001 |
| Cadmium | MG/L | 0.005 | J .0033 | 0.011 | < .0017 | 0.0011 | < .005 | < .001 | < .005 | < .001 |
| Copper | MG/L | 3.8 | 0.448 | 2.52 | J .0016 | 0.0052 | < .025 | 0.0017 | < .025 | 0.0016 |
| Manganese | MG/L | 1.4 | 4.46 | 15.2 | 0.496 | 0.585 | 0.0757 | 0.0562 | 0.0323 | 0.0735 |
| Nickel | MG/L | 2 | 0.225 | 0.682 | 0.0674 | 0.0727 | J .0219 | 0.0196 | J .0109 | 0.0118 |
| Ammonia as Nitrogen | MG/L | 30 | 37.6 | 36.7 | < 0.01 | < .005 | 0.49 | 0.5 | 0.5 | 0.4 |
| Nitrate/Nitrite | MG/L | 10 | 8.8 | 24.9 | 2.4 | 2.06 | 2.5 | 2.69 | 6 | 3.58 |

| Location Sample Name Sample Date Sample Type Media Laboratory Lab ID | | | Monitoring Network SPMW-13 4/12/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128018 | Monitoring Network SPMW-13 10/25/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402014 | Monitoring Network SPOB-12R2 4/12/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128015 | Monitoring Network SPOB-12R2 10/25/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402011 | Monitoring Network SPOB-34 4/12/2006 Monitor Well Ground Water Columbia Analytical Services CSD280128014 | Monitoring Network SPOB-34 10/25/2006 Monitor Well Ground Water Columbia Analytical Services CSJ200402016 |
|--|------------------------|------------|--|---|--|---|--|---|
| | Concentration Units | PS MG/L | | | | | | |
| Arsenic | MG/L | 0.05 | < 0.01 | < .001 | < 0.01 | < .001 | 0.0116 | 0.0104 |
| Beryllium | MG/L | 0.004 | J .00058 | < .001 | J .00046 | < .001 | J .00041 | < .001 |
| Cadmium | MG/L | 0.005 | < .005 | < .001 | < .005 | < .001 | < .005 | < .001 |
| Copper | MG/L | 3.8 | J .00054 | < .001 | < .025 | 0.002 | < .025 | 0.0011 |
| Manganese | MG/L | 1.4 | 0.267 | 0.246 | 0.048 | 0.0789 | 0.389 | 0.409 |
| Nickel | MG/L | 2 | < .04 | 0.0033 | J .0131 | 0.0173 | J .0027 | 0.0107 |
| Ammonia as Nitrogen | MG/L | 30 | < 0.12 | < 0.05 | 2.4 | 1.5 | 1.4 | 0.768 |
| Nitrate/Nitrite | MG/L | 10 | 0.49 | 1.14 | 14.4 | 9.17 | < 0.1 | < 0.05 |

< Not detected.
Bold Concentrations Represent values above PS.
 PS Performance Standards.
 J Estimated results are less than the reporting limit.

Table 4-2
Extracted Groundwater Volume for 2006
South Point Superfund Site
South Point, Ohio

| Date | SPIS-23 | | | SPIS-24 | | |
|-------------------------------------|----------------|-----------------|--------------------------------|--------------------|-----------------|------------------------|
| | Pressure (PSI) | Flow Rate (GPM) | Cumulative Flow Reading (Gal.) | Pressure (PSI) | Flow Rate (GPM) | Cumulative Flow (Gal.) |
| 1/1/2006 | 10 | 204 | 176,789,000 | 0 | 0 | 902,705,000 |
| 2/2/2006 | 18 | 150 | 187,826,000 | 62 | 420 | 903,424,000 |
| 3/3/2006 | 19 | 149 | 192,477,000 | 61 | 412 | 915,885,000 |
| 4/6/2006 | 18 | 150 | 199,937,000 | 62 | 414 | 936,564,000 |
| 5/4/2006 | 15 | 120 | 205,760,000 | 62 | 416 | 952,440,000 |
| 6/1/2006 | 12 | 160 | 212,072,000 | 62 | 409 | 972,866,000 |
| 7/6/2006 | 15 | 152 | 220,048,000 | 62 | 407 | 989,871,000 |
| 8/3/2006 | 9 | 157 | 225,104,000 | 62 | 400 | 1,001,613,000 |
| 9/7/2006 | 9 | 150 | 232,842,000 | 62 | 402 | 1,021,999,000 |
| 10/5/2006 | 9 | 150 | 239,373,000 | 62 | 400 | 1,039,272,000 |
| 11/3/2006 | 9 | 155 | 245,589,000 | 63 | 404 | 1,055,623,000 |
| 12/1/2006 | 9 | 150 | 251,963,000 | 65 | 399 | 1,071,648,000 |
| 12/31/2006 | 9 | 151 | 257,560,000 | 65 | 401 | 1,086,605,000 |
| Annual Flow (Gallons) | | | 80,771,000 | 183,900,000 | | |
| Average Flow (GPM) | | | 154 | 350 | | |
| Annual System Flow (Gallons) | | | 264,671,000 | | | |

GPM = gallons per minute
 PSI = pounds per square inch


Table 4-3
 Extracted Contaminant Mass during Year 2006
 South Point Plant Superfund Site
 South Point, Ohio

| Well ID and Contaminant | Contaminant Concentrations (mg/l) | | | Extracted Groundwater Volume (gallons) | Extracted Contaminant Mass (Kg) |
|----------------------------|-----------------------------------|--------|---------|--|---------------------------------|
| | Apr-06 | Oct-06 | Average | | |
| SPIS-23 | | | | | |
| Ammonia as Nitrogen | 0.42 | 0.57 | 0.495 | 81,967,000 | 154 |
| Nitrate/Nitrite | 3.6 | 3.05 | 3.325 | 81,967,000 | 1,032 |
| Manganese | 0.257 | 0.266 | 0.2615 | 81,967,000 | 81 |
| SPIS-24 | | | | | |
| Ammonia as Nitrogen | 30.8 | 24.8 | 30.45 | 183,900,000 | 19,353 |
| Nitrate/Nitrite | 11.9 | 9.66 | 10.78 | 183,900,000 | 7,504 |
| Manganese | 0.338 | 0.371 | 0.3545 | 183,900,000 | 247 |
| TOTALS | | | | | |
| Ammonia as Nitrogen | | | | | 19,507 |
| Nitrate/Nitrite | | | | | 8,536 |
| Manganese | | | | | 328 |

1 gallon = 3.78541 liters

Concentration (mg/l) * Conversion (l/gal) * Volume (gal) * Conversion (kg/mg)

FIGURES



Taken from the Cateletsburg, Kentucky, 7.5 Series
U.S.G.S. Topographic Quadrangle Map




FIGURE 2-1
SITE LOCATION
SOUTHPOINT PLANT SUPERFUND SITE
SOUTHPOINT, OHIO

| | | |
|-------------|----|---------|
| DESIGNED BY | JK | 8/25/06 |
| DRAWN BY | DP | 8/25/06 |
| CHKD. BY | BW | 8/25/06 |

MACTEC
46850 Magellan Drive, Suite 190
Novi, MI 48377

P:\INDUSTRIAL PRODUCTS\Honeywell\WINTON\New South Point\Project Demographics\4.1 Response\Annual\06\07\08\09\10\11\12\13\14\15\16\17\18\19\20\21\22\23\24\25\26\27\28\29\30\31\32\33\34\35\36\37\38\39\40\41\42\43\44\45\46\47\48\49\50\51\52\53\54\55\56\57\58\59\60\61\62\63\64\65\66\67\68\69\70\71\72\73\74\75\76\77\78\79\80\81\82\83\84\85\86\87\88\89\90\91\92\93\94\95\96\97\98\99\100\101\102\103\104\105\106\107\108\109\110\111\112\113\114\115\116\117\118\119\120\121\122\123\124\125\126\127\128\129\130\131\132\133\134\135\136\137\138\139\140\141\142\143\144\145\146\147\148\149\150\151\152\153\154\155\156\157\158\159\160\161\162\163\164\165\166\167\168\169\170\171\172\173\174\175\176\177\178\179\180\181\182\183\184\185\186\187\188\189\190\191\192\193\194\195\196\197\198\199\200\201\202\203\204\205\206\207\208\209\210\211\212\213\214\215\216\217\218\219\220\221\222\223\224\225\226\227\228\229\230\231\232\233\234\235\236\237\238\239\240\241\242\243\244\245\246\247\248\249\250\251\252\253\254\255\256\257\258\259\260\261\262\263\264\265\266\267\268\269\270\271\272\273\274\275\276\277\278\279\280\281\282\283\284\285\286\287\288\289\290\291\292\293\294\295\296\297\298\299\300\301\302\303\304\305\306\307\308\309\310\311\312\313\314\315\316\317\318\319\320\321\322\323\324\325\326\327\328\329\330\331\332\333\334\335\336\337\338\339\340\341\342\343\344\345\346\347\348\349\350\351\352\353\354\355\356\357\358\359\360\361\362\363\364\365\366\367\368\369\370\371\372\373\374\375\376\377\378\379\380\381\382\383\384\385\386\387\388\389\390\391\392\393\394\395\396\397\398\399\400\401\402\403\404\405\406\407\408\409\410\411\412\413\414\415\416\417\418\419\420\421\422\423\424\425\426\427\428\429\430\431\432\433\434\435\436\437\438\439\440\441\442\443\444\445\446\447\448\449\450\451\452\453\454\455\456\457\458\459\460\461\462\463\464\465\466\467\468\469\470\471\472\473\474\475\476\477\478\479\480\481\482\483\484\485\486\487\488\489\490\491\492\493\494\495\496\497\498\499\500\501\502\503\504\505\506\507\508\509\510\511\512\513\514\515\516\517\518\519\520\521\522\523\524\525\526\527\528\529\530\531\532\533\534\535\536\537\538\539\540\541\542\543\544\545\546\547\548\549\550\551\552\553\554\555\556\557\558\559\560\561\562\563\564\565\566\567\568\569\570\571\572\573\574\575\576\577\578\579\580\581\582\583\584\585\586\587\588\589\590\591\592\593\594\595\596\597\598\599\600\601\602\603\604\605\606\607\608\609\610\611\612\613\614\615\616\617\618\619\620\621\622\623\624\625\626\627\628\629\630\631\632\633\634\635\636\637\638\639\640\641\642\643\644\645\646\647\648\649\650\651\652\653\654\655\656\657\658\659\660\661\662\663\664\665\666\667\668\669\670\671\672\673\674\675\676\677\678\679\680\681\682\683\684\685\686\687\688\689\690\691\692\693\694\695\696\697\698\699\700\701\702\703\704\705\706\707\708\709\710\711\712\713\714\715\716\717\718\719\720\721\722\723\724\725\726\727\728\729\730\731\732\733\734\735\736\737\738\739\740\741\742\743\744\745\746\747\748\749\750\751\752\753\754\755\756\757\758\759\760\761\762\763\764\765\766\767\768\769\770\771\772\773\774\775\776\777\778\779\780\781\782\783\784\785\786\787\788\789\790\791\792\793\794\795\796\797\798\799\800\801\802\803\804\805\806\807\808\809\810\811\812\813\814\815\816\817\818\819\820\821\822\823\824\825\826\827\828\829\830\831\832\833\834\835\836\837\838\839\840\841\842\843\844\845\846\847\848\849\850\851\852\853\854\855\856\857\858\859\860\861\862\863\864\865\866\867\868\869\870\871\872\873\874\875\876\877\878\879\880\881\882\883\884\885\886\887\888\889\890\891\892\893\894\895\896\897\898\899\900\901\902\903\904\905\906\907\908\909\910\911\912\913\914\915\916\917\918\919\920\921\922\923\924\925\926\927\928\929\930\931\932\933\934\935\936\937\938\939\940\941\942\943\944\945\946\947\948\949\950\951\952\953\954\955\956\957\958\959\960\961\962\963\964\965\966\967\968\969\970\971\972\973\974\975\976\977\978\979\980\981\982\983\984\985\986\987\988\989\990\991\992\993\994\995\996\997\998\999\1000

| CONTAINMENT WELLS | WATER LEVELS AND WATER QUALITY | WELLS USED FOR WATER LEVELS ONLY |
|-------------------|--------------------------------|----------------------------------|
| SPIS-23 | SPMW-01 | SPIS-01 |
| SPIS-24 | SPMW-02 | SPIS-02 |
| | SPMW-03 | SPIS-05 |
| | SPMW-04 | SPIS-06 |
| | SPMW-05 | SPIS-10 |
| | SPMW-06R | SPIS-15 |
| | SPMW-07 | SPIS-15A |
| | SPMW-08 | SPIS-18 |
| | SPMW-09 | SPIS-22 |
| | SPMW-10R | SPIS-25 |
| | SPMW-11R | SPIS-26 |
| | SPMW-12 | SPIS-27 |
| | SPMW-13 | SPIS-28 |
| | SPOB-12R2 | SPOB-15R2 |
| | SPOB-34 | SPOB-17R |
| | | SPOB-18R |
| | | SPOB-26 |
| | | SPOB-29 |
| | | T2-B |
| | | Caisson |

Legend



Legend

- Areas Subject to Inspection and Maintenance

Groundwater Containment System

- Containment Wells
- Wells Used for Water Levels and Water Quality
- Wells Used for Water Levels Only





FIGURE 3-1
MONITORING AND CONTAINMENT WELL LOCATIONS
SOUTH POINT PLANT SUPERFUND SITE
SOUTH POINT, OHIO


| | | |
|-------------|----|--------|
| DESIGNED BY | DP | 3/9/07 |
| DRAWN BY | DP | 3/9/07 |
| CHKD. BY | MT | 3/9/07 |

MACTEC
46850 Magellan Drive, Suite 190
Novi, MI 48377

P:\INDUSTRIAL PROJECTS\Honeywell\IRONMONTON_TAR\South Point\4.0 Project Deliverables\4.1 Reports\Annual06\Drawings\FIG 3-1.dwg Tue, 08 May 2007 11:26am dpars

| WATER QUALITY | WATER LEVEL ELEVATIONS | WELLS USED FOR WATER LEVELS ONLY | WATER LEVEL ELEVATIONS |
|---------------|------------------------|----------------------------------|------------------------|
| SPMW-01 | 527.55 | SPIS-01 | 518.27 |
| SPMW-02 | 521.70 | SPIS-02 | 518.58 |
| SPMW-03 | 519.12 | SPIS-05 | 518.42 |
| SPMW-04 | 517.86 | SPIS-06 | 518.10 |
| SPMW-05 | 522.55 | SPIS-10 | 521.20 |
| SPMW-06R | 523.76 | SPIS-15 | 520.82 |
| SPMW-07 | 519.18 | SPIS-15A | 523.97 |
| SPMW-08 | 523.11 | SPIS-18 | 522.35 |
| SPMW-09 | 524.33 | SPIS-22 | 518.08 |
| SPMW-10R | 524.47 | SPIS-25* | 525.63 |
| SPMW-11R | 516.53 | SPIS-26 | 523.05 |
| SPMW-12 | 517.54 | SPIS-27* | 522.49 |
| SPMW-13 | 517.84 | SPIS-28 | 517.75 |
| SPOB-12R2 | 518.07 | SPOB-15R2 | 518.63 |
| SPOB-34 | 517.70 | SPOB-17R | 521.01 |
| | | SPOB-18R | 517.54 |
| | | SPOB-26 | 520.54 |
| | | SPOB-29 | 520.17 |
| | | T2-B | 525.30 |
| | | Caisson | 517.39 |

* Measurement is suspect and was not used in contouring.



Legend

- Containment Wells
- Wells Used for Water Levels and Water Quality
- Wells Used for Water Levels Only

Water level data collected April 21, 2006

- Groundwater Flow Direction
- Elevation of water table (feet above msl)





FIGURE 4-1
GROUNDWATER FLOW MAP
APRIL 2006
SOUTH POINT PLANT SUPERFUND SITE
SOUTH POINT, OHIO


| | | |
|-------------|----|--------|
| DESIGNED BY | DP | 3/9/07 |
| DRAWN BY | DP | 3/9/07 |
| CHKD. BY | MT | 3/9/07 |

MACTEC
46850 Magellan Drive, Suite 190
Novi, MI 48377

P:\INDUSTRIAL PROJECTS\Honeywell\IRONTON TAP\South Point\4.0 Project Deliverables\4.1 Reports\Annual\06\07\Fig 4-1.dwg Tue, 08 May 2007 - 11:25am dpas

| WATER LEVELS AND WATER QUALITY | WATER LEVEL ELEVATIONS | WELLS USED FOR WATER LEVELS ONLY | WATER LEVEL ELEVATIONS |
|--------------------------------|------------------------|----------------------------------|------------------------|
| SPMW-01 | 526.76 | SPIS-01 | 517.89 |
| SPMW-02 | 520.95 | SPIS-02 | 517.26 |
| SPMW-03 | 518.62 | SPIS-05 | 518.15 |
| SPMW-04 | 517.94 | SPIS-06 | 518.03 |
| SPMW-05 | 521.76 | SPIS-10 | 520.93 |
| SPMW-06R | 522.98 | SPIS-15 | 520.75 |
| SPMW-07 | 518.58 | SPIS-15A | 524.28 |
| SPMW-08 | 522.59 | SPIS-18 | 523.09 |
| SPMW-09 | 524.38 | SPIS-22 | 518.31 |
| SPMW-10R | 523.66 | SPIS-25* | 526.17 |
| SPMW-11R | 516.24 | SPIS-26 | 522.36 |
| SPMW-12 | 517.28 | SPIS-27* | 523.78 |
| SPMW-13 | 517.77 | SPIS-28 | 517.64 |
| SPOB-12R2 | 517.91 | SPOB-15R2 | 518.74 |
| SPOB-34 | 517.53 | SPOB-17R | 518.41 |
| | | SPOB-18R | 517.78 |
| | | SPOB-26 | 521.03 |
| | | SPOB-29 | 520.05 |
| | | T2-B | 524.85 |
| | | Caisson | 518.39 |

* Measurement is suspect and was not used in contouring.



Legend

- Containment Wells
- Wells Used for Water Levels and Water Quality
- Wells Used for Water Levels Only

Water level data collected October 10, 2006

- Groundwater Flow Direction
- 516— Elevation of water table (feet above msl)




FIGURE 4-2
GROUNDWATER FLOW MAP
OCTOBER 2006
SOUTH POINT PLANT SUPERFUND SITE
SOUTH POINT, OHIO


| | | |
|-------------|----|--------|
| DESIGNED BY | DP | 3/9/07 |
| DRAWN BY | DP | 3/9/07 |
| CHKD. BY | MT | 3/9/07 |

MACTEC
46850 Magellan Drive, Suite 190
Novi, MI 48377

P:\INDUSTRIAL PROJECTS\Honeywell\FRONTON_TAR\South_Point\4.0_Project_Deliverables\4.1_Reports\Annual06\DriftRpt\FIG 4-2.dwg Tue, 08 May 2007 - 11:25am dpass

| WATER LEVELS AND WATER QUALITY | WATER LEVEL ELEVATIONS | WELLS USED FOR WATER LEVELS ONLY | WATER LEVEL ELEVATIONS |
|--------------------------------|------------------------|----------------------------------|------------------------|
| SPMW-01 | 527.55 | SPIS-01 | 518.27 |
| SPMW-02 | 521.70 | SPIS-02 | 518.58 |
| SPMW-03 | 519.12 | SPIS-05 | 518.42 |
| SPMW-04 | 517.86 | SPIS-06 | 518.10 |
| SPMW-05 | 522.55 | SPIS-10 | 521.20 |
| SPMW-06R | 523.76 | SPIS-15 | 520.82 |
| SPMW-07 | 519.18 | SPIS-15A | 523.97 |
| SPMW-08 | 523.11 | SPIS-18 | 522.35 |
| SPMW-09 | 524.33 | SPIS-22 | 518.08 |
| SPMW-10R | 524.47 | SPIS-25* | 525.63 |
| SPMW-11R | 516.53 | SPIS-26 | 523.05 |
| SPMW-12 | 517.54 | SPIS-27* | 522.49 |
| SPMW-13 | 517.84 | SPIS-28 | 517.75 |
| SPOB-12R2 | 518.07 | SPOB-15R2 | 518.63 |
| SPOB-34 | 517.70 | SPOB-17R | 521.01 |
| | | SPOB-18R | 517.54 |
| | | SPOB-26 | 520.54 |
| | | SPOB-29 | 520.17 |
| | | T2-B | 525.30 |
| | | Caisson | 517.39 |

* Measurement is suspect and was not used in contouring.



Legend

- Containment Wells
- Wells Used for Water Levels and Water Quality
- Wells Used for Water Levels Only

Water level data collected April 21, 2006

- 516 Elevation of water table (feet above msl)
- Ammonia Plume - 30 mg/L
- Manganese Plume - 1.4 mg/L
- Nitrate Plume - 10 mg/L

1.1 Ammonia Concentrations in mg/L
 0.23 Manganese Concentrations in mg/L
 3.2 Nitrate Concentrations in mg/L





FIGURE 4-3
GROUNDWATER PLUME GEOMETRY
APRIL 2006
SOUTH POINT PLANT SUPERFUND SITE
SOUTH POINT, OHIO

| | | | |
|-------------|----|--------|---|
| DESIGNED BY | DP | 3/9/07 | 46850 Magellan Drive, Suite 190 Novi, MI 48377 |
| DRAWN BY | DP | 3/9/07 | |
| CHKD. BY | MT | 3/9/07 | |

P:\INDUSTRIAL PROJECTS\Honeywell\IRON TON TAR\South Point\4.0 Project Deliverables\4.1 Reports\Annual06\Drawings\FIG 4-3.dwg Tue, 08 May 2007 - 11:24am dpass

| WATER LEVELS AND WATER QUALITY | WATER LEVEL ELEVATIONS | WELLS USED FOR WATER LEVELS ONLY | WATER LEVEL ELEVATIONS |
|--------------------------------|------------------------|----------------------------------|------------------------|
| SPMW-01 | 526.76 | SPIS-01 | 517.89 |
| SPMW-02 | 520.95 | SPIS-02 | 517.26 |
| SPMW-03 | 518.62 | SPIS-05 | 518.15 |
| SPMW-04 | 517.94 | SPIS-06 | 518.03 |
| SPMW-05 | 521.76 | SPIS-10 | 520.93 |
| SPMW-06R | 522.98 | SPIS-15 | 520.75 |
| SPMW-07 | 518.58 | SPIS-15A | 524.28 |
| SPMW-08 | 522.59 | SPIS-18 | 523.09 |
| SPMW-09 | 524.38 | SPIS-22 | 518.31 |
| SPMW-10R | 523.66 | SPIS-25* | 526.17 |
| SPMW-11R | 516.24 | SPIS-26 | 522.36 |
| SPMW-12 | 517.28 | SPIS-27* | 523.78 |
| SPMW-13 | 517.77 | SPOB-15R2 | 518.74 |
| SPOB-12R2 | 517.91 | SPOB-17R | 518.41 |
| SPOB-34 | 517.53 | SPOB-18R | 517.78 |
| | | SPOB-26 | 521.03 |
| | | SPOB-29 | 520.05 |
| | | T2-B | 524.85 |
| | | Caisson | 518.39 |

* Measurement is suspect and was not used in contouring.



Legend

- Containment Wells
- Wells Used for Water Levels and Water Quality
- Wells Used for Water Levels Only

Water level data collected October 23, 2006

- 523 — Elevation of water table (feet above msl)
- Ammonia Plume - 30 mg/L
- Manganese Plume - 1.4 mg/L
- Nitrate Plume - 10 mg/L

1.1 Ammonia Concentrations in mg/L
0.23 Manganese Concentrations in mg/L
3.2 Nitrate Concentrations in mg/L




FIGURE 4-4
GROUNDWATER PLUME GEOMETRY
OCTOBER 2006
SOUTH POINT PLANT SUPERFUND SITE
SOUTH POINT, OHIO

| | | |
|-------------|----|--------|
| DESIGNED BY | DP | 3/9/07 |
| DRAWN BY | DP | 3/9/07 |
| CHKD. BY | MT | 3/9/07 |

MACTEC
46850 Magellan Drive, Suite 190
Novi, MI 48377

P:\INDUSTRIAL PROJECTS\Honeywell\IRONTON_TAR\South_Point\4.0_Project_Deliverables\4.1_Reports\Annual06\DriftPl\FIG 4-4.dwg Tue, 08 May 2007 - 11:24am dpass

Figure 4-5
 Ammonia Trends in Groundwater
 South Point Superfund Site
 South Point, Ohio




Figure 4-6
 Nitrate/Nitrite Trends in Groundwater
 South Point Superfund Site
 South Point, Ohio




Figure 4-7
Manganese Trends in Groundwater
South Point Superfund Site
South Point, Ohio





Figure 5-1
NPDES Trends
South Point Plant Superfund Site
South Point, Ohio



APPENDIX A
WATER SAMPLING LOGS

SOUTH POINT WELL WATER LEVELS

DATE: 10-23-06

| WELL # | DTW | DTB | DTB-DTW | PID | TIME | LOCATION |
|---------------|-----------------|-----------------|----------|-----|-----------------|---|
| SPMW-01 | 37.14 | 62.14 | | 0.0 | 0840 | NORTH ENTRANCE OFF ROAD BY FIELD |
| SPMW-05 | 61.90 | 85.80 | | 0.0 | 0845 | ALONG SOUTH-EAST FENCE LINE IN PINES ADJACENT TO RESIDENTIAL PROPERTY |
| SPMW-10R | 63.52 | 95.18 | | 0.0 | 0915 | AT CAP AREA |
| SPMW-06R | 73.80 | 101.1 | | 0.0 | 0915 | AT CAP AREA |
| SPMW-08 | 42.90 | 66.20 | | 0.0 | 0920 | FLY-ASH PONDS |
| SPIS-18 | 37.10 | 150+ | | 0.0 | 0930 | FLY-ASH PONDS |
| IS-15 | 43.50 | 150+ | | 0.0 | 0935 | ALONG County Rd Fence line |
| SPIS-15A | 36.43 | 150+ | | 0.0 | 0950 | FLY-ASH PONDS |
| SPMW-09 | 40.27 | 60.75 | | 0.0 | 0935 | FLY-ASH PONDS |
| T2-B | 18.05 | 44.17 | | 0.0 | 0940 | FLY-ASH PONDS |
| SPIS-26 | 46.42 | 150+ | | 0.0 | 0910 | FORMER PUMPING WELL |
| SPIS-25 | 46.20 | 150+ | | 0.0 | 0905 | FORMER PUMPING WELL |
| SPIS-27 | 48.42 | 150+ | | 0.0 | 0900 | FORMER PUMPING WELLS/ACROSS FROM CALGON BLDG. |
| SPMW-02 | 48.08 | 75.50 | | 0.0 | 0855 | BY ROADWAY ON RIGHT GOING EAST TURN SOUTH |
| Dup - SPMW-07 | 44.10 | 67.11 | | 0.0 | 1000 | HOOK LEFT ON ROADWAY BESIDE RR TRACKS / can not get too |
| SPMW-03 | 44.40 | 67.2 | | 0.0 | 1010 | BOON DOCKS NORTH OF TRACKS |
| SPIS-22 | 40.0 | 66.0 | 46.0/150 | 0.0 | 1000 | FORMER PW |
| SPOB-34 | 47.55 | 82.05 | | 0.0 | 1030 | NEAR PINES |
| SPOB-12R2 | 50.08 | 67.13 | | 0.0 | 1035 | NEAR PINES |
| SPMW-11R | 50.11 | 64.62 | | 0.0 | 1045 | NEAR PINES |
| SPMW-12 | 48.80 | 65.1 | | 0.0 | 1050 | NEAR PINES |
| SPMW-13 | 48.14 | 71.2 | | 0.0 | 1055 | NEAR PINES |
| SPMW-04 | 48.83 | 66.85 | | 0.0 | 1100 | NEAR PINES |
| SPIS-06 | 49.12 | 150+ | | 0.0 | 1105 | FORMER PUMPING WELLS |
| SPIS-05 | 44.16 | 150+ | | 0.0 | 1105 | FORMER PUMPING WELLS |
| SPIS-01 | 43.60 | 150+ | | 0.0 | 1215 | INSIDE RED BRICK BLDG. |
| SPIS-28 | 46.50 | 150+ | | 0.0 | 1210 | FORMER PUMPING WELLS |
| SPIS-02 | 44.35 | 150+ | | 0.0 | 1230 | BRICK BLDG. NEXT TO TOWERS |
| SPOB-29 | 43.55 | 76.60 | | 0.0 | 1125 | GO TO PYRO CHEM |
| SPOB-15D | 44.81 | 62.58 | | 0.0 | 1250 | SOUTH OF CO. RD. 1 INSIDE AND TO THE RIGHT |
| SPOB-26 | 34.14 | 72.13 | | 0.0 | 1240 | NEAR THE DOCK |
| CAISSON | 31.90 | - | | - | 1245 | AT THE RIVER |
| SPOB-17D | 34.84 | 50.55 | | 0.0 | 110 | EAST ON THE PATH TO TREE WITH LARGE BRANCH DOWN |
| SPOB-18D | 34.58 | 52.63 | | 0.0 | 1120 | FOLLOW THE LANE PAST PUMP HOUSE |
| SPIS-10 | 44.64 | 150+ | | 0.0 | 1200 | AT SP FIRE STATION |
| SPIS-23 | - | - | - | - | - | Pumping Well |
| SPIS-24 | - | - | - | - | - | Pumping Well |

3780 Key

CHAIN OF CUSTODY/LABORATORY ANALYSIS REQUEST FORM

SR # _____
CAS Contact _____

| | | | | | | | | | | | | | | | | | |
|-------------------------------------|--|-----------------------------------|--|--|--|---|--|--------------------------------------|--|--|--|--|--|--|--|--|--|
| Project Name SOUTH POINT | | Project Number | | ANALYSIS REQUESTED (Include Method Number and Container Preservative) | | | | | | | | | | | | | |
| Project Manager Joe Davis | | Report CC | | PRESERVATIVE | | | | | | | | | | | | | |
| Company/Address OMI INC. | | NUMBER OF CONTAINERS | | <div style="display: flex; justify-content: space-between;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);"> GC/MS VOA's <input type="checkbox"/> 8260 <input type="checkbox"/> 624 <input type="checkbox"/> CLP GC/MS SVOA's <input type="checkbox"/> 8270 <input type="checkbox"/> 625 <input type="checkbox"/> CLP GC VOA's <input type="checkbox"/> 8021 <input type="checkbox"/> 601/602 PESTICIDES <input type="checkbox"/> 8081 <input type="checkbox"/> 608 <input type="checkbox"/> CLP PCB's <input type="checkbox"/> 8082 <input type="checkbox"/> 608 <input type="checkbox"/> CLP METALS, TOTAL (List in comments below) METALS, DISSOLVED (List in comments below) </div> <div style="text-align: right;"> 2 3 NH₃ NO₂/NO₃ </div> </div> | | | | | | | | | | | | | |
| 3329 S. 3 rd ST. | | | | | | | | | | | | | | | | | |
| IronTON, OH 4563 | | | | | | | | | | | | | | | | | |
| Phone # 740 532 9486 | | | | | | | | | | | | | | | | | |
| FAX# | | Sampler's Signature | | Sampler's Printed Name | | Preservative Key 0. NONE 1. HCL 2. HNO ₃ 3. H ₂ SO ₄ 4. NaOH 5. Zn. Acetate 6. MeOH 7. NaHSO ₄ 8. Other _____ | | | | | | | | | | | |
| Sampler's Signature | | Sampler's Printed Name | | | | | | | | | | | | | | | |
| CLIENT SAMPLE ID | | FOR OFFICE USE ONLY LAB ID | | SAMPLING DATE TIME | | MATRIX | | REMARKS/ALTERNATE DESCRIPTION | | | | | | | | | |
| SPMW-01 | | | | 10-24-06 10:25 | | water | | | | | | | | | | | |
| SPMW-05 | | | | 10-24-06 11:10 | | water | | | | | | | | | | | |
| SPMW-10R | | | | 10-24-06 11:55 | | water | | | | | | | | | | | |
| SPMW-02 | | | | 10-24-06 13:20 | | water | | | | | | | | | | | |
| SPMW-06R | | | | 10-24-06 14:10 | | water | | | | | | | | | | | |
| SPMW-08 | | | | 10-24-06 14:50 | | water | | | | | | | | | | | |
| SPMW-09 | | | | 10-24-06 15:40 | | water | | | | | | | | | | | |

| | | | | | | | |
|--|--|---|--|--|--|--|--|
| SPECIAL INSTRUCTIONS/COMMENTS Metals See QAPP <input type="checkbox"/> | | TURNAROUND REQUIREMENTS <input type="checkbox"/> RUSH (SURCHARGES APPLY) <input type="checkbox"/> 24 hr <input type="checkbox"/> 48 hr <input type="checkbox"/> 5 day <input checked="" type="checkbox"/> STANDARD REQUESTED FAX DATE _____ REQUESTED REPORT DATE _____ | | REPORT REQUIREMENTS <input type="checkbox"/> I. Results Only <input type="checkbox"/> II. Results + QC Summaries (LCS, DUP, MS/MSD as required) <input type="checkbox"/> III. Results + QC and Calibration Summaries <input type="checkbox"/> IV. Data Validation Report with Raw Data <input type="checkbox"/> V. Specialized Forms / Custom Report Edata <input type="checkbox"/> Yes <input type="checkbox"/> No | | INVOICE INFORMATION PO# _____ BILL TO: _____ SUBMISSION #: _____ | |
|--|--|---|--|--|--|--|--|

SAMPLE RECEIPT: CONDITION/COOLER TEMP: _____ CUSTODY SEALS: Y N

| | | | | | |
|-------------------------------------|--------------------|------------------------|--------------------|------------------------|--------------------|
| RELINQUISHED BY | RECEIVED BY | RELINQUISHED BY | RECEIVED BY | RELINQUISHED BY | RECEIVED BY |
| <i>Patricia Holmes</i> | | | | | |
| Signature | Signature | Signature | Signature | Signature | Signature |
| Printed Name | Printed Name | Printed Name | Printed Name | Printed Name | Printed Name |
| Firm OMI / Honeywell | Firm | Firm | Firm | Firm | Firm |
| Date/Time 10-24-06 / 1700 | Date/Time | Date/Time | Date/Time | Date/Time | Date/Time |



CHAIN OF CUSTODY/LABORATORY ANALYSIS REQUEST FORM

SR # _____
CAS Contact _____

One Mustard St., Suite 250 • Rochester, NY 14609-0859 • (585) 288-5380 • 800-695-7222 x11 • FAX (585) 288-8475 PAGE 2 OF 2

| Project Name SOUTH POINT | | Project Number | | ANALYSIS REQUESTED (Include Method Number and Container Preservative) | | | | | | | | | | | | | | | | | | | | |
|---|----------------------------|--|------|--|--|---|--|---|--|---|---|-----------------|----------------------------------|--|--|--|--|--|--|-----------------------------------|--|--|--|--|
| Project Manager Joe Davis | | Report CC | | PRESERVATIVE | | | | | | | | | | | | | | | | | | | | |
| Company/Address OMI / Honeywell | | SAMPLER'S INFORMATION Sampler's Signature: _____ Sampler's Printed Name: _____ | | NUMBER OF CONTAINERS | GC/MS VOA's <input type="checkbox"/> 8260 <input type="checkbox"/> 624 <input type="checkbox"/> CLP | GC/MS SVOA's <input type="checkbox"/> 8270 <input type="checkbox"/> 625 <input type="checkbox"/> CLP | GC VOA's <input type="checkbox"/> 6021 <input type="checkbox"/> 601/602 | PESTICIDES <input type="checkbox"/> 6081 <input type="checkbox"/> 608 <input type="checkbox"/> CLP | PCB's <input type="checkbox"/> 8082 <input type="checkbox"/> 608 <input type="checkbox"/> CLP | METALS, TOTAL (List in comments below) | METALS, DISSOLVED (List in comments below) | NH ₃ | NO ₂ /NO ₃ | | | | | | | | | | | |
| Company/Address 3329 S. 3rd ST. | | | | | | | | | | | | | | | | | | | | | | | | |
| Phone # (740) 532-9486 | | | | | FAX# | | | | | | | | | | | | | | | | | | | |
| CLIENT SAMPLE ID | FOR OFFICE USE ONLY LAB ID | SAMPLING DATE | TIME | MATRIX | | | | | | | | | | | | | | | | REMARKS/ ALTERNATE DESCRIPTION | | | | |
| SPI3-24 | | 10-25-06 | 1425 | water | | | | | | | | | | | | | | | | | | | | |
| SPI3-24 Dup | | 10-25-06 | 1425 | water | | | | | | | | | | | | | | | | | | | | |
| SPI3-23, ms, MSD | | 10-25-06 | 1445 | water | | | | | | | | | | | | | | | | | | | | |

| | | | |
|---|---|--|---|
| SPECIAL INSTRUCTIONS/COMMENTS Metals See QAPP <input type="checkbox"/> | TURNAROUND REQUIREMENTS RUSH (SURCHARGES APPLY) ___ 24 hr ___ 48 hr ___ 5 day <input checked="" type="checkbox"/> STANDARD | REPORT REQUIREMENTS ___ I. Results Only ___ II. Results + QC Summaries (LCS, DUP, MS/MSD as required) ___ III. Results + QC and Calibration Summaries ___ IV. Data Validation Report with Raw Data ___ V. Specialized Forms / Custom Report Edata ___ Yes ___ No | INVOICE INFORMATION PO# _____ BILL TO: _____ SUBMISSION #: _____ |
| | SAMPLE RECEIPT: CONDITION/COOLER TEMP: _____ CUSTODY SEALS: Y N | | |

| | | | | | |
|-------------------------------------|--------------|-----------------|--------------|-----------------|--------------|
| RELINQUISHED BY | RECEIVED BY | RELINQUISHED BY | RECEIVED BY | RELINQUISHED BY | RECEIVED BY |
| Signature <i>Richard Holman</i> | Signature | Signature | Signature | Signature | Signature |
| Printed Name | Printed Name | Printed Name | Printed Name | Printed Name | Printed Name |
| Firm <i>OMI / Honeywell</i> | Firm | Firm | Firm | Firm | Firm |
| Date/Time <i>10-25-06 / 1600</i> | Date/Time | Date/Time | Date/Time | Date/Time | Date/Time |

CHAIN OF CUSTODY/LABORATORY ANALYSIS REQUEST FORM

SR # _____
CAS Contact _____

| | | | | | | | | | | | | | | | |
|---|--|------------------------|--|---|--|--|--|--|--|--|--|--|--|--|--|
| Project Name SOUTH POINT | | Project Number | | ANALYSIS REQUESTED (Include Method Number and Container Preservative) | | | | | | | | | | | |
| Project Manager Joe Davis | | Report CC | | PRESERVATIVE | | | | | | | | | | | |
| Company/Address OMI / Honeywell | | NUMBER OF CONTAINERS | | GC/MS VOAs <input type="checkbox"/> 8260 <input type="checkbox"/> 624 <input type="checkbox"/> CLP GC/MS SVOAs <input type="checkbox"/> 8270 <input type="checkbox"/> 625 <input type="checkbox"/> CLP GC VOAs <input type="checkbox"/> 8021 <input type="checkbox"/> 601/802 PESTICIDES <input type="checkbox"/> 8081 <input type="checkbox"/> 608 <input type="checkbox"/> CLP PCBs <input type="checkbox"/> 8082 <input type="checkbox"/> 608 <input type="checkbox"/> CLP METALS, TOTAL (List in comments below) METALS, DISSOLVED (List in comments below) NH ₃ , NO ₂ /NO ₃ | | | | | | | | | | | |
| 3329 S. 3rd ST | | | | | | | | | | | | | | | |
| Ironton, OH 45635 | | | | | | | | | | | | | | | |
| Phone # (740) 532-9486 | | FAX# | | Preservative Key 0. NONE 1. HCL 2. HNO ₃ 3. H ₂ SO ₄ 4. NaOH 5. Zn. Acetate 6. MeOH 7. NaHSO ₄ 8. Other _____ | | | | | | | | | | | |
| Sampler's Signature | | Sampler's Printed Name | | | | | | | | | | | | | |

| CLIENT SAMPLE ID | FOR OFFICE USE ONLY LAB ID | SAMPLING | | MATRIX | ANALYSIS REQUESTED | | | | | | | | | | | | REMARKS/ ALTERNATE DESCRIPTION |
|------------------|-------------------------------|----------|------|--------|--------------------|--|--|--|--|--|--|--|--|--|--|--|-----------------------------------|
| | | DATE | TIME | | PRESERVATIVE | | | | | | | | | | | | |
| SPMW-03 | | 10-25-06 | 0955 | water | | | | | | | | | | | | | |
| SPMW-07 | | 10-25-06 | 0945 | water | | | | | | | | | | | | | |
| SPMW-07 Dup | | 10-25-06 | 0945 | water | | | | | | | | | | | | | |
| SPOB-34 | | 10-25-06 | 1035 | water | | | | | | | | | | | | | |
| SPOB-12R2 | | 10-25-06 | 1105 | water | | | | | | | | | | | | | |
| SPMW-11R2 | | 10-25-06 | 1140 | water | | | | | | | | | | | | | |
| SPMW-12 | | 10-25-06 | 1300 | water | | | | | | | | | | | | | |
| SPMW-13 | | 10-25-06 | 1335 | water | | | | | | | | | | | | | |
| SPMW-04 | | 10-25-06 | 1410 | water | | | | | | | | | | | | | |

| | | | |
|--|---|---|---|
| SPECIAL INSTRUCTIONS/COMMENTS Metals | TURNAROUND REQUIREMENTS ____ RUSH (SURCHARGES APPLY) ____ 24 hr ____ 48 hr ____ 5 day <input checked="" type="checkbox"/> STANDARD | REPORT REQUIREMENTS ____ I. Results Only ____ II. Results + QC Summaries (LCS, DUP, MS/MSD as required) ____ III. Results + QC and Calibration Summaries ____ IV. Data Validation Report with Raw Data ____ V. Specialized Forms / Custom Report Edata ____ Yes ____ No | INVOICE INFORMATION PO# _____ BILL TO: _____ SUBMISSION #: _____ |
| | REQUESTED FAX DATE _____ REQUESTED REPORT DATE _____ | | |

| | | | | | |
|--|--------------|--------------------|--------------|-----------------|--------------|
| SAMPLE RECEIPT: CONDITION/COOLER TEMP: _____ | | CUSTODY SEALS: Y N | | | |
| RELINQUISHED BY R. Todd Holme | RECEIVED BY | RELINQUISHED BY | RECEIVED BY | RELINQUISHED BY | RECEIVED BY |
| Signature | Signature | Signature | Signature | Signature | Signature |
| Printed Name | Printed Name | Printed Name | Printed Name | Printed Name | Printed Name |
| Firm OMI / Honeywell | Firm | Firm | Firm | Firm | Firm |
| Date/Time 10-25-06 / @ 1600 | Date/Time | Date/Time | Date/Time | Date/Time | Date/Time |

PROJECT Ironton **FIELD SAMPLE NUMBER** SPmw-01 **JOB NUMBER**
SITE ID SOUTH Point **SITE TYPE** **EVENT NO**
ACTIVITY START 0900 END 1030 **SAMPLE TIME** 1025 **DATE** 10-24-06
FILE TYPE

WATER LEVEL / PUMP SETTINGS **MEASUREMENT POINT**
 TOP OF WELL RISER **PROTECTIVE CASING STICKUP (FROM GROUND)** 2.5 FT **CASING / WELL DIFFERENCE** FT
 TOP OF PROTECTIVE CASING **WELL DIAMETER** 2 IN
INITIAL DEPTH TO WATER 37.14 FT **HISTORICAL WELL DEPTH (TOR)** 62.14 FT **PID AMBIENT AIR** 0.0 PPM
FINAL DEPTH TO WATER FT **PID WELL MOUTH** 0.0 PPM
SCREEN LENGTH FT **PRESSURE TO PUMP** PSI **DISCHARGE SETTING**
TOTAL VOL. PURGED 4 GAL **REFILL SETTING**
(Purge volume (meters per minute) x time duration (minutes) x 0.00026 gal/millimeter)

| PURGE DATA | | SPECIFIC | | | | | | | | PUMP | COMMENTS |
|------------|---------------------|-------------------|------------------|---------------------|------------|-----------|-----------------|--------------|-------------------|------|----------|
| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/m) | TEMP. (± deg. c) | CONDUCTANCE (ms/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (± mv) | INTAKE DEPTH (ft) | | |
| 955 | 37.14 | 500 | 11.93 | 35.2 | 6.21 | 0.00 | 9.2 | 138 | | | |
| 1000 | 37.14 | 500 | 11.75 | 34.0 | 6.11 | 0.00 | 10.7 | 139 | | | |
| 1005 | 37.14 | 500 | 11.49 | 33.3 | 6.02 | 0.00 | 9.0 | 142 | | | |
| 1010 | 37.14 | 500 | 11.18 | 33.8 | 5.98 | 0.00 | 26.6 | 146 | | | |
| 1015 | 37.14 | 500 | 11.18 | 33.4 | 5.97 | 0.00 | 26.6 | 146 | | | |
| 1020 | 37.14 | 500 | 11.14 | 32.4 | 6.0 | 0.00 | 23.9 | 147 | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |

EQUIPMENT DOCUMENTATION
TYPE OF PUMP: BLADDER PERISTALTIC OTHER 2" sub
TYPE OF TUBING: HIGH DENSITY POLYETHYLENE OTHER
TYPE OF PUMP MATERIAL: STAINLESS STEEL OTHER
TYPE OF BLADDER MATERIAL: TEFLON OTHER

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

PURGE OBSERVATIONS
 PURGE WATER CONTAINERIZED YES NO
 NOTES:
 Prepared/Date: 10-24-06
 Checked/Date: PH

Honeywell
 102 COLUMBIA RD. BOX 2105
 MORRISTOWN, NJ 07962



MACTEC

LOW FLOW GROUNDWATER DATA RECORD
 ALLIED CHEMICAL/IRONTON COKE FACILITY
 IRONTON, OHIO
 SITE NO. 35024
 3293051221/2200.3

PROJECT **IronTOn** FIELD SAMPLE NUMBER **SPMW-05** JOB NUMBER _____
 SITE ID **SOUTH POINT** SITE TYPE _____ EVENT NO _____
 ACTIVITY **START 1035 END 1115** SAMPLE TIME **1110** DATE **10-24-06**
 FILE TYPE _____

WATER LEVEL / PUMP SETTINGS

INITIAL DEPTH TO WATER **61.90** FT MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING PROTECTIVE CASING STICKUP (FROM GROUND) **3** FT CASING / WELL DIFFERENCE _____ FT

FINAL DEPTH TO WATER _____ FT HISTORICAL WELL DEPTH (TOR) **85.80** FT PID AMBIENT AIR **0.0** PPM WELL DIAMETER **2** IN

SCREEN LENGTH _____ FT PRESSURE TO PUMP _____ PSI PID WELL MOUTH **0.0** PPM WELL INTEGRITY:
 INTEGRITY YES NO N/A
 CAP _____
 CASING _____
 LOCKED _____
 COLLAR _____

TOTAL VOL. PURGED **4** GAL REFILL SETTING _____ DISCHARGE SETTING _____
 (purge volume (milliliters per minute) x time duration (minutes) x 0.00026 gal/milliliter)

| PURGE DATA | | | SPECIFIC | | | | | | PUMP | | COMMENTS |
|------------|---------------------|-------------------|------------------|---------------------|------------|-----------|-----------------|--------------|-------------------|--|----------|
| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/m) | TEMP. (± deg. c) | CONDUCTANCE (ms/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (± mv) | INTAKE DEPTH (ft) | | |
| 1040 | 61.90 | 500 | 8.87 | 45.7 | 7.27 | 2.70 | 9.9 | 94 | | | |
| 1045 | 61.90 | 500 | 8.87 | 45.7 | 7.27 | 2.70 | 9.9 | 94 | | | |
| 1050 | 61.90 | 500 | 8.86 | 45.9 | 7.32 | 2.71 | 12.1 | 93 | | | |
| 1055 | 61.90 | 500 | 9.11 | 46.9 | 7.42 | 2.97 | 24.8 | 87 | | | |
| 1100 | 61.90 | 500 | 9.79 | 46.6 | 7.52 | 2.90 | 29.6 | 81 | | | |
| 1105 | 61.90 | 500 | 10.15 | 45.9 | 7.57 | 2.59 | 23.9 | 74 | | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP
 BLADDER
 PERISTALTIC OTHER **2" Sub**

TYPE OF TUBING
 HIGH DENSITY POLYETHYLENE
 OTHER _____

TYPE OF PUMP MATERIAL
 STAINLESS STEEL
 OTHER _____

TYPE OF BLADDER MATERIAL
 TEFLON
 OTHER _____

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID / LITERS |
|----------|---------------|---------------------|-----------------|------------------|---------------------------|
| | | | | | |

PURGE OBSERVATIONS

PURGE WATER CONTAINERIZED YES NO _____

NOTES:

Prepared/Date: **10-24-06**
 Checked/Date: **PH**

Honeywell
 102 COLUMBIA RD. BOX 2105
 MORRISTOWN, NJ 07962

MACTEC

LOW FLOW GROUNDWATER DATA RECORD
 ALLIED CHEMICAL/IRONTON COKE FACILITY
 IRONTON, OHIO
 SITE NO. 35024
 3293051221/2200.3

PROJECT Ironton FIELD SAMPLE NUMBER SPmw-10R JOB NUMBER
 SITE ID SOUTH POINT SITE TYPE EVENT NO
 ACTIVITY START 1120 END 1200 SAMPLE TIME 1155 DATE 10-24-04
 FILE TYPE

WATER LEVEL / PUMP SETTINGS MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING
 PROTECTIVE CASING STICKUP (FROM GROUND) FT
 CASING / WELL DIFFERENCE FT
 INITIAL DEPTH TO WATER 68.52 FT
 HISTORICAL WELL DEPTH (TOR) 95.18 FT
 PID AMBIENT AIR 0.0 PPM
 WELL DIAMETER IN
 FINAL DEPTH TO WATER FT
 PRESSURE TO PUMP PSI
 PID WELL MOUTH 0.0 PPM
 WELL INTERGRITY:
 INTEGRITY YES NO N/A
 CAP
 CASING LOCKED
 COLLAR
 SCREEN LENGTH FT
 REFILL SETTING
 DISCHARGE SETTING
 TOTAL VOL PURGED 4 GAL
 (purge volume (meters per minute) x time duration (minutes) x 0.00026 gal/mmeter)

| PURGE DATA | | SPECIFIC | | | | | | | PUMP | | COMMENTS |
|------------|---------------------|-------------------|------------------|---------------------|------------|-----------|-----------------|----------------|-------------------|--|----------|
| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/m) | TEMP. (°/deg. c) | CONDUCTANCE (mc/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (+/- mv) | INTAKE DEPTH (ft) | | |
| 1125 | 68.52 | 500 | 9.30 | 52.2 | 4.24 | 0.00 | 100 | 37.4 | | | |
| 1130 | 68.52 | 500 | 9.99 | 51.3 | 4.14 | 0.00 | 100 | 334 | | | |
| 1135 | 68.52 | 500 | 10.36 | 51.1 | 4.12 | 0.00 | 182 | 343 | | | |
| 1140 | 68.52 | 500 | 10.40 | 51.1 | 4.11 | 0.00 | 113 | 344 | | | |
| 1145 | 68.52 | 500 | 10.45 | 51.0 | 4.12 | 0.00 | 99.3 | 345 | | | |
| 1150 | 68.52 | 500 | 10.50 | 50.9 | 4.11 | 0.00 | 110 | 349 | | | |

EQUIPMENT DOCUMENTATION
 TYPE OF PUMP: BLADDER PERISTALTIC OTHER 2" sub
 TYPE OF TUBING: HIGH DENSITY POLYETHYLENE OTHER
 TYPE OF PUMP MATERIAL: STAINLESS STEEL OTHER
 TYPE OF BLADDER MATERIAL: TEFLON OTHER

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

PURGE OBSERVATIONS
 PURGE WATER CONTAINERIZED YES NO
 NOTES:
 Prepared/Date: 10-24-06
 Checked/Date: PH

Honeywell
 102 COLUMBIA RD. BOX 2105
 MORRISTOWN, NJ 07962



LOW FLOW GROUNDWATER DATA RECORD
 ALLIED CHEMICAL/IRONTON COKE FACILITY
 IRONTON, OHIO
 SITE NO. 35024
 329305122 1/2200.3

PROJECT: Ironton FIELD SAMPLE NUMBER: SPmw-02 JOB NUMBER:
 SITE ID: South Point SITE TYPE: EVENT NO:
 ACTIVITY: START 1245 END 1325 SAMPLE TIME: 1320 DATE: 10-24-06
 FILE TYPE:

WATER LEVEL / PUMP SETTINGS

INITIAL DEPTH TO WATER: 46.08 FT
 FINAL DEPTH TO WATER: FT
 SCREEN LENGTH: FT
 TOTAL VOL. PURGED: 4 GAL
(purge volume (milliliters per minute) x time duration (minutes) x 0.00026 gal/milliliter)

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING

HISTORICAL WELL DEPTH (TOR): 75.50 FT
 PRESSURE TO PUMP: PSI
 REFILL SETTING:

PROTECTIVE CASING STICKUP (FROM GROUND): 3 FT
 PID AMBIENT AIR: 0.0 PPM
 PID WELL MOUTH: 0.0 PPM
 DISCHARGE SETTING:

CASING / WELL DIFFERENCE: FT
 WELL DIAMETER: 2 IN

WELL INTEGRITY:

| INTEGRITY | YES | NO | N/A |
|-----------|-------------------------------------|--------------------------|--------------------------|
| CAP | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| CASING | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| LOCKED | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| COLLAR | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/min) | TEMP. (°C) | SPECIFIC | | DO (mg/L) | TURBIDITY (ntu) | REDOX (+/- mv) | PUMP INTAKE DEPTH (ft) | COMMENTS |
|------|---------------------|---------------------|------------|---------------------|------------|-----------|-----------------|----------------|------------------------|----------|
| | | | | CONDUCTANCE (ms/cm) | pH (units) | | | | | |
| 1250 | 46.05 | 500 | 9.15 | 45.3 | 6.44 | 9.99 | 71.7 | 233 | | |
| 1255 | 46.05 | 500 | 9.32 | 45.2 | 6.53 | 9.12 | 63 | 226 | | |
| 1300 | 46.05 | 500 | 10.55 | 55.4 | 6.72 | 2.60 | 56.8 | 177 | | |
| 1305 | 46.05 | 500 | 10.99 | 60.8 | 6.88 | 0.00 | 48.7 | 156 | | |
| 1310 | 46.05 | 500 | 11.09 | 63.5 | 7.03 | 0.00 | 41.1 | 134 | | |
| 1315 | 46.05 | 500 | 11.17 | 64.2 | 7.07 | 0.00 | 40.3 | 127 | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP: BLADDER PERISTALTIC OTHER 2" sub

TYPE OF TUBING: HIGH DENSITY POLYETHYLENE OTHER

TYPE OF PUMP MATERIAL: STAINLESS STEEL OTHER

TYPE OF BLADDER MATERIAL: TEFLON OTHER

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

PURGE OBSERVATIONS

PURGE WATER CONTAINERIZED: YES NO

NOTES:

Prepared/Date: 10-24-06
 Checked/Date: PT

| | | |
|--|--|---|
| <h1>Honeywell</h1> <p>102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962</p> |  | <p>LOW FLOW GROUNDWATER DATA RECORD ALLIED CHEMICAL/IRONTON COKE FACILITY IRONTON, OHIO SITE NO. 35024 329305122/2200.3</p> |
|--|--|---|

PROJECT: Ironton FIELD SAMPLE NUMBER: SPMW-06R JOB NUMBER:
 SITE ID: SOUTH POINT SITE TYPE: EVENT NO:
 ACTIVITY: START 1330 END 1415 SAMPLE TIME: 1410 DATE: 10-24-06 FILE TYPE:

WATER LEVEL / PUMP SETTINGS
 INITIAL DEPTH TO WATER: 72.80 FT
 FINAL DEPTH TO WATER: FT
 SCREEN LENGTH: FT
 TOTAL VOL PURGED: 4.5 GAL
(purge volume (meters per minute) x time duration (minutes) x 0.00026 gal/meter)

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING

PROTECTIVE CASING STICKUP (FROM GROUND): 3 FT
PID AMBIENT AIR: 0.0 PPM
PID WELL MOUTH: 0.0 PPM
DISCHARGE SETTING:

CASING / WELL DIFFERENCE: FT
WELL DIAMETER: 2 IN
WELL INTEGRITY:
 INTEGRITY YES NO N/A
 CAP
 CASING
 LOCKED
 COLLAR

| PURGE DATA | | | SPECIFIC | | | | | | PUMP | | COMMENTS |
|------------|---------------------|---------------------|--------------------|---------------------|------------|-----------|-----------------|----------------|-------------------|--|----------|
| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/min) | TEMP. (+/- deg. c) | CONDUCTANCE (mc/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (+/- mv) | INTAKE DEPTH (ft) | | |
| 1340 | 72.80 | 500 | 10.88 | .168 | 6.53 | 0.00 | 274 | 109 | | | |
| 1345 | 72.80 | 500 | 10.94 | .169 | 6.52 | 0.00 | 263 | 109 | | | |
| 1350 | 72.80 | 500 | 10.96 | .170 | 6.53 | 0.00 | 263 | 109 | | | |
| 1355 | 72.80 | 500 | 11.28 | .172 | 6.53 | 0.00 | 140 | 108 | | | |
| 1400 | 72.80 | 500 | 11.30 | .171 | 6.54 | 0.00 | 135 | 107 | | | |
| 1405 | 72.80 | 500 | 11.33 | .173 | 6.54 | 0.00 | 110 | 106 | | | |

EQUIPMENT DOCUMENTATION
 TYPE OF PUMP: BLADDER PERISTALTIC OTHER 2" sub
 TYPE OF TUBING: HIGH DENSITY POLYETHYLENE OTHER _____
 TYPE OF PUMP MATERIAL: STAINLESS STEEL OTHER _____
 TYPE OF BLADDER MATERIAL: TEFLON OTHER _____

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

PURGE OBSERVATIONS
 PURGE WATER CONTAINERIZED: YES NO

NOTES: _____

Prepared/Date: 10-24-06
 Checked/Date: PH

Honeywell
 102 COLUMBIA RD. BOX 2105
 MORRISTOWN, NJ 07962


MACTEC

LOW FLOW GROUNDWATER DATA RECORD
 ALLIED CHEMICAL/IRONTON COKE FACILITY
 IRONTON, OHIO
 SITE NO. 35024
 3293051221/2200.3

PROJECT Iron ton FIELD SAMPLE NUMBER SPmw-08 JOB NUMBER
 SITE ID South Point SITE TYPE EVENT NO
 ACTIVITY START 1420 END 1455 SAMPLE TIME 1450 DATE 10-24-06
 FILE TYPE

WATER LEVEL / PUMP SETTINGS

INITIAL DEPTH TO WATER 42.90 FT
 FINAL DEPTH TO WATER FT
 SCREEN LENGTH FT
 TOTAL VOL. PURGED 4 GAL
 (purge volume (meters per minute) x time duration (minutes) x 0.00026 gal/meter)

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING

HISTORICAL WELL DEPTH (TOR) 66.20 FT
 PRESSURE TO PUMP PSI
 REFILL SETTING

PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT
 PID AMBIENT AIR 0.0 PPM
 PID WELL MOUTH 0.0 PPM
 DISCHARGE SETTING

CASING / WELL DIFFERENCE FT
 WELL DIAMETER 2 IN
 WELL INTEGRITY:
 INTEGRITY YES NO N/A
 CAP /// --- ---
 CASING /// --- ---
 LOCKED /// --- ---
 COLLAR /// --- ---

| PURGE DATA | | SPECIFIC | | | | | | | | PUMP | COMMENTS |
|------------|---------------------|-------------------|--------------------|---------------------|------------|-----------|-----------------|----------------|------------------------|------|----------|
| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/m) | TEMP. (+/- deg. c) | CONDUCTANCE (mc/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (+/- mv) | PUMP INTAKE DEPTH (ft) | | |
| 1425 | 42.90 | 500 | 10.50 | 97.2 | 6.56 | 0.00 | 22.6 | 125 | | | |
| 1430 | 42.90 | 500 | 10.75 | 86.5 | 6.51 | 0.00 | 20.3 | 126 | | | |
| 1435 | 42.90 | 500 | 10.86 | 86.9 | 6.49 | 0.00 | 17.0 | 123 | | | |
| 1440 | 42.90 | 500 | 10.87 | 87.1 | 6.49 | 0.00 | 16.3 | 125 | | | |
| 1445 | 42.90 | 500 | 10.89 | 86.5 | 6.49 | 0.00 | 16.8 | 127 | | | |
| 1450 | 42.90 | 500 | 10.86 | 86.6 | 6.49 | 0.00 | 9.7 | 129 | | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP
 BLADDER
 PERISTALTIC OTHER 2" sub.

TYPE OF TUBING
 HIGH DENSITY POLYETHYLENE
 OTHER

TYPE OF PUMP MATERIAL
 STAINLESS STEEL
 OTHER

TYPE OF BLADDER MATERIAL
 TEFLON
 OTHER

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID/LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

PURGE OBSERVATIONS

PURGE WATER CONTAINERIZED YES NO

NOTES:

Prepared/Date: 10-24-06
 Checked/Date: PH

| | | |
|--|--|---|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  | LOW FLOW GROUNDWATER DATA RECORD ALLIED CHEMICAL/IRONTON COKE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|--|--|---|

PROJECT: IronTON FIELD SAMPLE NUMBER: SPmw-09 JOB NUMBER: _____
 SITE ID: SOUTH POINT SITE TYPE: _____ EVENT NO: _____
 ACTIVITY: START 1505 END 1550 SAMPLE TIME: 1540 DATE: 10-24-06
 FILE TYPE: _____

WATER LEVEL / PUMP SETTINGS
 INITIAL DEPTH TO WATER: 40.27 FT
 FINAL DEPTH TO WATER: _____ FT
 SCREEN LENGTH: _____ FT
 TOTAL VOL. PURGED: 4 GAL
 (purge volume (militers per minute) x time duration (minutes) x 0.00026 gal/militier)

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING
 HISTORICAL WELL DEPTH (TOR): 60.25 FT
 PRESSURE TO PUMP: _____ PSI
 REFILL SETTING: _____

PROTECTIVE CASING STICKUP (FROM GROUND): 3 FT
PID AMBIENT AIR: 0.0 PPM
PID WELL MOUTH: 0.0 PPM
DISCHARGE SETTING: _____

CASING / WELL DIFFERENCE: _____ FT
WELL DIAMETER: 2 IN
WELL INTEGRITY:
 INTEGRITY: YES NO N/A
 CAP: _____
 CASING LOCKED: _____
 COLLAR: _____

| PURGE DATA | | | | SPECIFIC | | | | | PUMP | | COMMENTS |
|------------|---------------------|---------------------|--------------------|---------------------|------------|-----------|-----------------|----------------|-------------------|--|----------|
| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/min) | TEMP. (°/- deg. c) | CONDUCTANCE (ms/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (+/- mv) | INTAKE DEPTH (ft) | | |
| 1510 | 40.27 | 500 | 10.42 | .132 | 3.52 | 0.00 | 46.1 | 408 | | | |
| 1515 | 40.27 | 500 | 10.42 | .131 | 3.55 | 0.00 | 47.7 | 408 | | | |
| 1520 | 40.27 | 500 | 10.40 | .129 | 3.59 | 0.00 | 47.8 | 407 | | | |
| 1525 | 40.27 | 500 | 10.29 | .130 | 3.48 | 0.00 | 42.9 | 414 | | | |
| 1530 | 40.27 | 500 | 10.21 | .132 | 3.47 | 0.00 | 40.8 | 415 | | | |
| 1535 | 40.27 | 500 | 10.13 | .132 | 3.47 | 0.00 | 32.9 | 416 | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |

EQUIPMENT DOCUMENTATION
 TYPE OF PUMP: BLADDER PERISTALTIC OTHER 2" sub
 TYPE OF TUBING: HIGH DENSITY POLYETHYLENE OTHER _____
 TYPE OF PUMP MATERIAL: STAINLESS STEEL OTHER _____
 TYPE OF BLADDER MATERIAL: TEFLON OTHER _____

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

PURGE OBSERVATIONS
 PURGE WATER CONTAINERIZED: YES NO
 NOTES: _____

Prepared/Date: 10-24-06
 Checked/Date: PFF

| | | |
|---|---|---|
| Honeywell 102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  MACTEC | LOW FLOW GROUNDWATER DATA RECORD ALLIED CHEMICAL/IRONTON COKE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|---|---|---|

PROJECT IronTon FIELD SAMPLE NUMBER SPMW-03 JOB NUMBER
 SITE ID SOUTH POINT SITE TYPE EVENT NO
 ACTIVITY START 810 END 900 SAMPLE TIME 855 DATE 10-25-06
 FILE TYPE

WATER LEVEL / PUMP SETTINGS

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING

INITIAL DEPTH TO WATER 44.46 FT
 FINAL DEPTH TO WATER FT
 SCREEN LENGTH FT
 TOTAL VOL. PURGED 4 GAL
(purge volume (militers per minute) x time duration (minutes) x 0.00026 gal/militiliter)

PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT
 CASING / WELL DIFFERENCE FT
 HISTORICAL WELL DEPTH (TOR) 67.2 FT
 PID AMBIENT AIR 0.0 PPM
 PID WELL MOUTH 0.0 PPM
 PRESSURE TO PUMP PSI
 REFILL SETTING
 DISCHARGE SETTING

WELL DIAMETER 2 IN
 WELL INTERGRITY:
 INTEGRITY YES NO N/A
 CAP
 CASING
 LOCKED
 COLLAR

| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/min) | TEMP. (+/- deg. c) | SPECIFIC | | | | TURBIDITY (ntu) | REDOX (+/- mv) | PUMP INTAKE DEPTH (ft) | COMMENTS |
|------|---------------------|---------------------|--------------------|---------------------|------------|-----------|------|-----------------|----------------|------------------------|----------|
| | | | | CONDUCTANCE (mg/cm) | pH (units) | DO (mg/L) | | | | | |
| 825 | 44.46 | 500 | 5.63 | 51.2 | 6.25 | 0.00 | 34.8 | 184 | | | |
| 830 | 44.46 | 500 | 5.66 | 53.3 | 6.38 | 0.00 | 17.1 | 169 | | | |
| 835 | 44.46 | 500 | 5.70 | 53.7 | 6.47 | 0.00 | 9.0 | 145 | | | |
| 840 | 44.46 | 500 | 5.72 | 53.7 | 6.49 | 0.00 | 6.2 | 146 | | | |
| 845 | 44.46 | 500 | 5.72 | 53.7 | 6.51 | 0.00 | 5.0 | 146 | | | |
| 850 | 44.46 | 500 | 5.72 | 54.0 | 6.51 | 0.00 | 4.4 | 147 | | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP
 BLADDER
 PERISTALTIC
 OTHER 2" sub

TYPE OF TUBING
 HIGH DENSITY POLYETHYLENE
 OTHER

TYPE OF PUMP MATERIAL
 STAINLESS STEEL
 OTHER

TYPE OF BLADDER MATERIAL
 TEFLON
 OTHER

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

PURGE OBSERVATIONS

PURGE WATER CONTAINERIZED YES NO

NOTES:

Prepared/Date: 10-25-06
 Checked/Date: PJ

Honeywell
 102 COLUMBIA RD. BOX 2105
 MORRISTOWN, NJ 07962



LOW FLOW GROUNDWATER DATA RECORD
 ALLIED CHEMICAL/IRONTON COKE FACILITY
 IRONTON, OHIO
 SITE NO. 35024
 3293051221/2200.3

PROJECT Ironton FIELD SAMPLE NUMBER SPmw-07 JOB NUMBER
 SITE ID SOUTH POINT SITE TYPE EVENT NO
 ACTIVITY START 0905 END 0955 SAMPLE TIME 0955 DATE 10-25-06
 FILE TYPE

WATER LEVEL / PUMP SETTINGS

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING

INITIAL DEPTH TO WATER 44.10 FT
 FINAL DEPTH TO WATER FT
 SCREEN LENGTH FT
 TOTAL VOL. PURGED 4.5 GAL
(purge volume (militers per minute) x time duration (minutes) x 0.00026 gal/militers)

PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT
 CASING / WELL DIFFERENCE FT
 HISTORICAL WELL DEPTH (TOF) 67.11 FT
 PID AMBIENT AIR 0.0 PPM
 PID WELL MOUTH 0.0 PPM
 DISCHARGE SETTING

WELL DIAMETER 2 IN
 WELL INTEGRITY:
 INTEGRITY YES / NO / N/A
 CAP / - -
 CASING / - -
 LOCKED / - -
 COLLAR / - -

| PURGE DATA | | | SPECIFIC | | | | | PUMP | | COMMENTS |
|------------|---------------------|-------------------|--------------------|---------------------|------------|-----------|-----------------|----------------|-------------------|----------|
| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/m) | TEMP. (+/- deg. c) | CONDUCTANCE (ms/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (+/- mv) | INTAKE DEPTH (ft) | |
| 915 | 44.10 | 500 | 10.24 | 226 | 7.72 | 0.00 | 27.1 | 120 | | |
| 920 | 44.10 | 500 | 10.24 | 225 | 7.72 | 0.00 | 26.8 | 121 | | |
| 925 | 44.10 | 500 | 11.66 | 212 | 7.74 | 0.00 | 39.1 | 106 | | |
| 930 | 44.10 | 500 | 12.23 | 209 | 7.76 | 0.00 | 33.8 | 97 | | |
| 935 | 44.10 | 500 | 12.60 | 201 | 7.76 | 0.00 | 13.2 | 94 | | |
| 940 | 44.10 | 500 | 12.61 | 115 | 7.63 | 0.00 | 15.1 | 90 | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP
 BLADDER
 PERISTALTIC
 OTHER 2" sub

TYPE OF TUBING
 HIGH DENSITY POLYETHYLENE
 OTHER

TYPE OF PUMP MATERIAL
 STAINLESS STEEL
 OTHER

TYPE OF BLADDER MATERIAL
 TEFLON
 OTHER

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

PURGE OBSERVATIONS

PURGE WATER CONTAINERIZED (YES) YES NO

NOTES:

(Dup)

Prepared/Date: 10-25-06
 Checked/Date: PH

Honeywell
 102 COLUMBIA RD. BOX 2105
 MORRISTOWN, NJ 07962

MACTEC

LOW FLOW GROUNDWATER DATA RECORD
 ALLIED CHEMICAL/IRONTON COKE FACILITY
 IRONTON, OHIO
 SITE NO. 35024
 3293051221/2200.3

PROJECT Ironton FIELD SAMPLE NUMBER SP08-34 JOB NUMBER
 SITE ID SOUTH Point SITE TYPE EVENT NO
 ACTIVITY START 1000 END 1040 SAMPLE TIME 1035 DATE 10-25-06
 FILE TYPE

WATER LEVEL / PUMP SETTINGS
 INITIAL DEPTH TO WATER 47.55 FT
 FINAL DEPTH TO WATER FT
 SCREEN LENGTH FT
 TOTAL VOL PURGED 4.5 GAL
 (purge volume (milliliters per minute) x time duration (minutes) x 0.00026 gal/milliliter)

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING

PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT

HISTORICAL WELL DEPTH (TOR) 82.05 FT

PID AMBIENT AIR 0.0 PPM

PID WELL MOUTH 0.0 PPM

CASING / WELL DIFFERENCE FT

WELL DIAMETER 2 IN

WELL INTEGRITY:

| INTEGRITY | YES | NO | N/A |
|---------------|-------------------------------------|--------------------------|--------------------------|
| CAP | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| CASING LOCKED | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| COLLAR | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/m) | TEMP. (+/- deg. c) | SPECIFIC CONDUCTANCE (mc/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (+/- mv) | PUMP INTAKE DEPTH (ft) | COMMENTS |
|------|---------------------|-------------------|--------------------|------------------------------|------------|-----------|-----------------|----------------|------------------------|----------|
| | | | | | | | | | | |
| 1005 | 47.55 | 500 | 12.99 | 96.7 | 7.76 | 0.00 | 11.0 | -241 | | |
| 1010 | 47.55 | 500 | 12.95 | 96.9 | 7.76 | 0.00 | 11.4 | -240 | | |
| 1015 | 47.55 | 500 | 12.99 | 96.0 | 7.76 | 0.00 | 11.5 | -239 | | |
| 1020 | 47.55 | 500 | 12.72 | 97.4 | 7.78 | 0.00 | 13.8 | -237 | | |
| 1025 | 47.55 | 500 | 12.15 | 98.9 | 7.79 | 0.00 | 21.0 | -235 | | |
| 1030 | 47.55 | 500 | 11.75 | 99.9 | 7.79 | 0.00 | 30.7 | -234 | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP
 BLADDER
 PERISTALTIC OTHER 2" sub

TYPE OF TUBING
 HIGH DENSITY POLYETHYLENE
 OTHER

TYPE OF PUMP MATERIAL
 STAINLESS STEEL
 OTHER

TYPE OF BLADDER MATERIAL
 TEFLON
 OTHER

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID/LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

PURGE OBSERVATIONS

PURGE WATER CONTAINERIZED YES NO

NOTES: _____

Prepared/Date: 10-25-06
 Checked/Date: PJT

| | | |
|--|--|---|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  | LOW FLOW GROUNDWATER DATA RECORD ALLIED CHEMICAL/IRONTON COKE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|--|--|---|

PROJECT Ironton FIELD SAMPLE NUMBER SPI5-24 JOB NUMBER
 SITE ID South Point SITE TYPE EVENT NO
 ACTIVITY START 1420 END 1430 SAMPLE TIME 1425 DATE 10-25-06
 FILE TYPE

WATER LEVEL / PUMP SETTINGS

INITIAL DEPTH TO WATER FT

FINAL DEPTH TO WATER FT

SCREEN LENGTH FT

TOTAL VOL PURGED GAL

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING

HISTORICAL WELL DEPTH (TOR) FT

PRESSURE TO PUMP PSI

REFILL SETTING

PROTECTIVE CASING STICKUP (FROM GROUND) FT

PID AMBIENT AIR PPM

PID WELL MOUTH PPM

DISCHARGE SETTING

CASING / WELL DIFFERENCE FT

WELL DIAMETER IN

WELL INTEGRITY:
 INTEGRITY YES NO N/A
 CAP _____
 CASING _____
 LOCKED _____
 COLLAR _____

PURGE DATA

| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/min) | TEMP. (°C deg. C) | SPECIFIC CONDUCTANCE (mc/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (+/- mv) | PUMP INTAKE DEPTH (ft) | COMMENTS |
|------|---------------------|---------------------|-------------------|------------------------------|------------|-----------|-----------------|----------------|------------------------|----------|
| 1425 | — | — | 13.3 | .101 | 6.54 | 0.00 | 9.6 | 101 | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP
 BLADDER
 PERISTALTIC OTHER _____

TYPE OF TUBING
 HIGH DENSITY POLYETHYLENE
 OTHER _____

TYPE OF PUMP MATERIAL
 STAINLESS STEEL
 OTHER _____

TYPE OF BLADDER MATERIAL
 TEFLON
 OTHER _____

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

PURGE OBSERVATIONS

PURGE WATER CONTAINERIZED YES NO _____

NOTES:
Pumping well (Dup)

Prepared/Date: 10-25-06
 Checked/Date: PH

| | | |
|---|---|--|
| Honeywell 102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  MACTEC | LOW FLOW GROUNDWATER DATA RECORD ALLIED CHEMICAL/IRONTON COKE FACILITY IRONTON, OHIO SITE NO. 35024 329305-1221/2200.3 |
|---|---|--|

PROJECT Ironton FIELD SAMPLE NUMBER SPIS-23 JOB NUMBER []
 SITE ID SOUTH POINT SITE TYPE [] EVENT NO []
 ACTIVITY START 1440 END 1450 SAMPLE TIME 1445 DATE 10-25-06
 FILE TYPE []

WATER LEVEL / PUMP SETTINGS

INITIAL DEPTH TO WATER [] FT
 FINAL DEPTH TO WATER [] FT
 SCREEN LENGTH [] FT
 TOTAL VOL PURGED [] GAL
(purge volume (milliliters per minute) x time duration (minutes) x 0.00026 gal/milliliter)

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING

HISTORICAL WELL DEPTH (TOR) [] FT
 PRESSURE TO PUMP [] PSI
 REFILL SETTING []

PROTECTIVE CASING STICKUP (FROM GROUND) [] FT
 P10 AMBIENT AIR [] PPM
 P10 WELL MOUTH [] PPM
 DISCHARGE SETTING []

CASING / WELL DIFFERENCE [] FT
 WELL DIAMETER [] IN
 WELL INTEGRITY:
 INTEGRITY YES NO N/A
 CAP [] [] []
 LOCKED [] [] []
 COLLAR [] [] []

| PURGE DATA | | DEPTH TO WATER (ft) | PURGE RATE (min) | TEMP. (°F-deg. C) | SPECIFIC CONDUCTANCE (mc/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (-/+ mv) | PUMP INTAKE DEPTH (ft) | COMMENTS |
|------------|---|---------------------|------------------|-------------------|------------------------------|------------|-----------|-----------------|----------------|------------------------|----------|
| 1445 | - | - | - | 13.2 | 102 | 7.01 | 0.00 | 9.6 | 91 | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP: BLADDER PERISTALTIC OTHER _____

TYPE OF TUBING: HIGH DENSITY POLYETHYLENE OTHER _____

TYPE OF PUMP MATERIAL: STAINLESS STEEL OTHER _____

TYPE OF BLADDER MATERIAL: TEFLON OTHER _____

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID/LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

PURGE OBSERVATIONS
 PURGE WATER CONTAINERIZED YES NO _____

NOTES:
Pumping well (MS, MSD)

Prepared/Date: 10-25-06
 Checked/Date: PH

Honeywell
 102 COLUMBIA RD. BOX 2105
 MORRISTOWN, NJ 07962

MACTEC

LOW FLOW GROUNDWATER DATA RECORD
 ALLIED CHEMICAL/IRONTON COKE FACILITY
 IRONTON, OHIO
 SITE NO. 35024
 3293051221/2200.3

PROJECT Ironton FIELD SAMPLE NUMBER SPOB-12R2 JOB NUMBER
 SITE ID SOUTH POINT SITE TYPE EVENT NO
 ACTIVITY START 1040 END 1110 SAMPLE TIME 1105 DATE 10-25-06
 FILE TYPE

WATER LEVEL / PUMP SETTINGS

INITIAL DEPTH TO WATER 50.08 FT
 FINAL DEPTH TO WATER FT
 SCREEN LENGTH FT
 TOTAL VOL PURGED 4 GAL
(purge volume (militers per minute) x time duration (minutes) x 0.00026 gal/militers)

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING

HISTORICAL WELL DEPTH (TOR) 67.13 FT
 PRESSURE TO PUMP PSI
 REFILL SETTING

PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT
 PID AMBIENT AIR 0.0 PPM
 PID WELL MOUTH 0.0 PPM
 DISCHARGE SETTING

CASING / WELL DIFFERENCE FT
 WELL DIAMETER 2 IN
 WELL INTEGRITY:
 INTEGRITY YES NO N/A
 CAP
 CASING LOCKED
 COLLAR

| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/m) | TEMP. (°/ deg. c) | SPECIFIC | | | | TURBIDITY (ntu) | REDOX (+/- mv) | PUMP INTAKE DEPTH (ft) | COMMENTS |
|------|---------------------|-------------------|-------------------|---------------------|------------|-----------|------|-----------------|----------------|------------------------|----------|
| | | | | CONDUCTANCE (mS/cm) | pH (units) | DO (mg/L) | | | | | |
| 1045 | 50.08 | 500 | 10.86 | .096 | 6.49 | 0.00 | 21.0 | 9 | | | |
| 1048 | 50.08 | 500 | 10.91 | .091 | 6.37 | 0.00 | 25.2 | 13 | | | |
| 1051 | 50.08 | 500 | 11.48 | .101 | 6.30 | 0.00 | 14.2 | 26 | | | |
| 1054 | 50.08 | 500 | 11.48 | .101 | 6.31 | 0.00 | 14.8 | 26 | | | |
| 1057 | 50.08 | 500 | 11.51 | .101 | 6.32 | 0.00 | 20.1 | 28 | | | |
| 1100 | 50.08 | 500 | 11.51 | .100 | 6.31 | 0.00 | 24.0 | 29 | | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP: BLADDER PERISTALTIC OTHER 2" sub

TYPE OF TUBING: HIGH DENSITY POLYETHYLENE OTHER

TYPE OF PUMP MATERIAL: STAINLESS STEEL OTHER

TYPE OF BLADDER MATERIAL: TEFLON OTHER

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID/LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

PURGE OBSERVATIONS

PURGE WATER CONTAINERIZED YES NO

NOTES:

Prepared/Date: 10-25-06
 Checked/Date: PH

Honeywell
 102 COLUMBIA RD. BOX 2105
 MORRISTOWN, NJ 07962

MACTEC

LOW FLOW GROUNDWATER DATA RECORD
 ALLIED CHEMICAL/IRONTON COKE FACILITY
 IRONTON, OHIO
 SITE NO. 35024
 3293051221/2200.3

PROJECT Ironton FIELD SAMPLE NUMBER SPmw-11R JOB NUMBER
 SITE ID SOUTH POINT SITE TYPE EVENT NO
 ACTIVITY START 1115 END 1143 SAMPLE TIME 1140 DATE 10-25-06
 FILE TYPE

WATER LEVEL / PUMP SETTINGS

INITIAL DEPTH TO WATER 50.11 FT
 FINAL DEPTH TO WATER FT
 SCREEN LENGTH FT
 TOTAL VOL PURGED 4 GAL
(purge volume (milliliters per minute) x time duration (minutes) x 0.00026 gal/milliliter)

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING

HISTORICAL WELL DEPTH (TOR) 64.62 FT
 PRESSURE TO PUMP PSI
 REFILL SETTING

PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT
 PID AMBIENT AIR 0.0 PPM
 PID WELL MOUTH 0.0 PPM
 DISCHARGE SETTING

CASING / WELL DIFFERENCE FT
 WELL DIAMETER 2 IN
 WELL INTEGRITY:
 INTEGRITY YES NO N/A
 CAP
 CASING LOCKED
 COLLAR

| PURGE DATA | | | SPECIFIC | | | | | | PUMP | | COMMENTS |
|------------|---------------------|---------------------|-------------------|---------------------|------------|-----------|-----------------|----------------|-------------------|--|----------|
| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/min) | TEMP. (°F deg. C) | CONDUCTANCE (mc/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (°F. mv) | INTAKE DEPTH (ft) | | |
| 1118 | 50.11 | 500 | 12.05 | 28.4 | 5.75 | 0.00 | 88.7 | 85 | | | |
| 1121 | 50.13 | 500 | 12.07 | 28.6 | 5.69 | 0.00 | 89.5 | 86 | | | |
| 1124 | 50.12 | 500 | 12.14 | 28.6 | 5.63 | 0.00 | 48.2 | 91 | | | |
| 1127 | 50.12 | 500 | 12.15 | 28.6 | 5.58 | 0.00 | 28.5 | 95 | | | |
| 1130 | 50.11 | 500 | 12.13 | 28.5 | 5.56 | 0.00 | 22.3 | 99 | | | |
| 1133 | 50.11 | 500 | 12.11 | 28.5 | 5.55 | 0.00 | 19.5 | 100 | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP
 BLADDER
 PERISTALTIC
 OTHER 2" SW

TYPE OF TUBING
 HIGH DENSITY POLYETHYLENE
 OTHER

TYPE OF PUMP MATERIAL
 STAINLESS STEEL
 OTHER

TYPE OF BLADDER MATERIAL
 TEFLON
 OTHER

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

PURGE OBSERVATIONS

PURGE WATER CONTAINERIZED YES NO

NOTES:

Prepared/Date: 10-25-06
 Checked/Date: PA

| | | |
|--|--|---|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  | LOW FLOW GROUNDWATER DATA RECORD ALLIED CHEMICAL/IRONTON COKE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|--|--|---|

PROJECT: Ironton FIELD SAMPLE NUMBER: SPmw-12 JOB NUMBER:

 SITE ID: SOUTH POINT SITE TYPE: EVENT NO:

 ACTIVITY: START 1230 END 1305 SAMPLE TIME: 1300 DATE: 10-25-06

 FILE TYPE:

WATER LEVEL / PUMP SETTINGS MEASUREMENT POINT

 TOP OF WELL RISER PROTECTIVE CASING STICKUP (FROM GROUND): 3 FT CASING / WELL DIFFERENCE: FT

 TOP OF PROTECTIVE CASING INITIAL DEPTH TO WATER: 48.80 FT

 HISTORICAL WELL DEPTH (TOR): 65.1 FT PID AMBIENT AIR: 0.0 PPM WELL DIAMETER: 2 IN

 SCREEN LENGTH: FT PRESSURE TO PUMP: PSI PID WELL MOUTH: 0.0 PPM WELL INTEGRITY:

 TOTAL VOL. PURGED: 4 GAL REFILL SETTING: DISCHARGE SETTING: INTEGRITY YES NO N/A

 (purge volume (milliliters per minute) x time duration (minutes) x 0.00026 (gallons/milliliter))

 CAP

 CASING LOCKED

 COLLAR

| PURGE DATA | | | SPECIFIC | | | | | PUMP | | COMMENTS |
|------------|---------------------|---------------------|-------------------|---------------------|------------|-----------|-----------------|----------------|-------------------|----------|
| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/min) | TEMP. (°/ deg. c) | CONDUCTANCE (ms/cm) | pH (units) | DO (mg/L) | TURBIDITY (ntu) | REDOX (+/- mv) | INTAKE DEPTH (ft) | |
| 1240 | 48.80 | 500 | 12.41 | 67.8 | 7.03 | 0.00 | 42.4 | 48 | | |
| 1243 | 48.82 | 500 | 12.83 | 66.6 | 7.04 | 0.00 | 41.8 | 49 | | |
| 1246 | 48.82 | 500 | 11.82 | 64.4 | 6.91 | 0.00 | 51.2 | 73 | | |
| 1249 | 48.82 | 500 | 11.82 | 64.5 | 6.90 | 0.00 | 51.9 | 73 | | |
| 1252 | 48.82 | 500 | 11.82 | 64.5 | 6.91 | 0.00 | 53.2 | 73 | | |
| 1255 | 48.82 | 500 | 11.80 | 64.3 | 6.89 | 0.00 | 52.2 | 77 | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |

EQUIPMENT DOCUMENTATION

 TYPE OF PUMP: BLADDER PERISTALTIC OTHER 2" sub

 TYPE OF TUBING: HIGH DENSITY POLYETHYLENE OTHER

 TYPE OF PUMP MATERIAL: STAINLESS STEEL OTHER

 TYPE OF BLADDER MATERIAL: TEFLON OTHER

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID/LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

PURGE OBSERVATIONS

 PURGE WATER CONTAINERIZED: YES NO

 NOTES:

Prepared/Date: 10-25-06

 Checked/Date: NH

Honeywell

 102 COLUMBIA RD. BOX 2105

 MORRISTOWN, NJ 07962



LOW FLOW GROUNDWATER DATA RECORD

 ALLIED CHEMICAL/IRONTON COKE FACILITY

 IRONTON, OHIO

 SITE NO. 35024

 3293051221/2200.3

PROJECT: Ironton FIELD SAMPLE NUMBER: SPmw-13 JOB NUMBER: _____
 SITE ID: SOUTH POINT SITE TYPE: _____ EVENT NO: _____
 ACTIVITY: START 1310 END 1340 SAMPLE TIME: 1335 DATE: 10-25-06
 FILE TYPE: _____

WATER LEVEL / PUMP SETTINGS

INITIAL DEPTH TO WATER: 48.14 FT
 FINAL DEPTH TO WATER: _____ FT
 SCREEN LENGTH: _____ FT
 TOTAL VOL PURGED: 4 GAL
(purge volume (milliliters per minute) x time duration (minutes) x 0.00026 gal/milliliter)

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING

HISTORICAL WELL DEPTH (TOR): 71.2 FT

PRESSURE TO PUMP: _____ (PSI)
 REFILL SETTING: _____

PROTECTIVE CASING STICKUP (FROM GROUND): 3 FT

PID AMBIENT AIR: 0.0 PPM
 PID WELL MOUTH: 0.0 PPM
 DISCHARGE SETTING: _____

CASING / WELL DIFFERENCE: _____ FT

WELL DIAMETER: 2 IN

WELL INTEGRITY:

| | | | |
|---------------|-------------------------------------|--------------------------|--------------------------|
| INTEGRITY | YES | NO | N/A |
| CAP | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| CASING LOCKED | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| COLLAR | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/m) | TEMP. (°F deg. C) | SPECIFIC | | | | TURBIDITY (ntu) | REDOX (± mv) | PUMP INTAKE DEPTH (ft) | COMMENTS |
|------|---------------------|-------------------|-------------------|---------------------|------------|-----------|---|-----------------|--------------|------------------------|----------|
| | | | | CONDUCTANCE (ms/cm) | pH (units) | DO (mg/L) | | | | | |
| 1318 | 48.14 | 500 | 11.27 | 54.7 | 7.77 | 0.00 | 0 | 31 | | | |
| 1321 | 48.14 | 500 | 11.16 | 54.9 | 7.81 | 0.00 | 0 | 26 | | | |
| 1324 | 48.14 | 500 | 11.19 | 55.0 | 7.82 | 0.00 | 0 | 24 | | | |
| 1327 | 48.14 | 500 | 11.15 | 55.0 | 7.82 | 0.00 | 0 | 22 | | | |
| 1330 | 48.14 | 500 | 11.08 | 55.1 | 7.82 | 0.00 | 0 | 21 | | | |
| 1333 | 48.14 | 500 | 11.03 | 55.1 | 7.83 | 0.00 | 0 | 19 | | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP: BLADDER PERISTALTIC OTHER 2" sub

TYPE OF TUBING: HIGH DENSITY POLYETHYLENE OTHER _____

TYPE OF PUMP MATERIAL: STAINLESS STEEL OTHER _____

TYPE OF BLADDER MATERIAL: TEFLON OTHER _____

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID/LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

PURGE OBSERVATIONS

PURGE WATER CONTAINERIZED: YES NO

NOTES:

Prepared/Date: 10-25-06
 Checked/Date: PH

| | | |
|---|--|--|
| Honeywell 102 COLUMBIA RD. BOX 2105 <small>IRONTON, OHIO 45329</small> |  | LOW FLOW GROUNDWATER DATA RECORD ALLIED CHEMICAL/IRONTON COKE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|---|--|--|

PROJECT IRONTON FIELD SAMPLE NUMBER SPmw-04 JOB NUMBER
 SITE ID SOUTH POINT SITE TYPE EVENT NO
 ACTIVITY START 1345 END 1415 SAMPLE TIME 1410 DATE 10-25-06
 FILE TYPE

WATER LEVEL / PUMP SETTINGS
 INITIAL DEPTH TO WATER 48.83 FT
 FINAL DEPTH TO WATER FT
 SCREEN LENGTH FT
 TOTAL VOL PURGED 4.5 GAL
(purge volume (milliliters per minute) x time duration (minutes) x 0.00026 gal/milliliter)

MEASUREMENT POINT
 TOP OF WELL RISER
 TOP OF PROTECTIVE CASING
 HISTORICAL WELL DEPTH (TOR) 66.85 FT
 PRESSURE TO PUMP PSI
 REFILL SETTING

PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT
 PID AMBIENT AIR 0.0 PPM
 PID WELL MOUTH 0.0 PPM
 DISCHARGE SETTING

CASING / WELL DIFFERENCE FT
 WELL DIAMETER 2 IN
 WELL INTEGRITY:
 INTEGRITY YES NO N/A
 CAP
 CASING
 LOCKED
 COLLAR

| TIME | DEPTH TO WATER (ft) | PURGE RATE (ml/min) | TEMP. (+/- deg. c) | SPECIFIC | | | TURBIDITY (ntu) | REDOX (+/- mv) | PUMP INTAKE DEPTH (ft) | COMMENTS |
|------|---------------------|---------------------|--------------------|---------------------|------------|-----------|-----------------|----------------|------------------------|----------|
| | | | | CONDUCTANCE (ms/cm) | pH (units) | DO (mg/L) | | | | |
| 1348 | 48.83 | 500 | 12.13 | 34.8 | 6.35 | 0.00 | 7.2 | 101 | | |
| 1351 | 48.84 | 500 | 12.18 | 34.6 | 6.32 | 0.00 | 4.6 | 105 | | |
| 1354 | 48.84 | 500 | 12.15 | 34.5 | 6.32 | 0.00 | 4.0 | 108 | | |
| 1357 | 48.83 | 500 | 12.12 | 34.3 | 6.31 | 0.00 | 3.5 | 110 | | |
| 1400 | 48.83 | 500 | 12.10 | 34.3 | 6.31 | 0.00 | 4.0 | 113 | | |
| 1405 | 48.83 | 500 | 12.34 | 35.5 | 6.33 | 0.00 | 3.0 | 104 | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |

EQUIPMENT DOCUMENTATION

TYPE OF PUMP
 BLADDER
 PERISTALTIC
 OTHER 2" sub

TYPE OF TUBING
 HIGH DENSITY POLYETHYLENE
 OTHER

TYPE OF PUMP MATERIAL
 STAINLESS STEEL
 OTHER

TYPE OF BLADDER MATERIAL
 TEFLON
 OTHER

ANALYTICAL PARAMETERS

| ANALYSIS | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|----------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

PURGE OBSERVATIONS
 PURGE WATER CONTAINERIZED YES NO
 NOTES:

Prepared/Date: 10-25-06
 Checked/Date: PH

Honeywell
 102 COLUMBIA RD. BOX 2105
 MORRISTOWN, NJ 07962



LOW FLOW GROUNDWATER DATA RECORD
 ALLIED CHEMICAL/IRONTON COKE FACILITY
 IRONTON, OHIO
 SITE NO. 35024
 3293051221/2200.3

SOUTH POINT WELL WATER LEVELS

DATE: 4/10/06

| WELL # | DTW | DTB | DTB-DTW | PID | TIME | LOCATION |
|-----------|--------|-------|---------|------|------|---|
| SPMW-01 | -36.35 | 62.15 | 25.8 | 0.00 | 728 | NORTH ENTRANCE OFF ROAD BY FIELD |
| SPMW-05 | -61.11 | 85.83 | 24.72 | 0.00 | 740 | ALONG SOUTH-EAST FENCE LINE IN PINES ADJACENT TO RESIDENTIAL PROPERTY |
| SPMW-10R | -67.71 | 95.9 | 28.19 | 0.00 | 755 | AT CAP AREA |
| SPMW-06R | -72.02 | 101.6 | 29.58 | 0.00 | 800 | AT CAP AREA |
| SPMW-08 | -42.38 | 66.22 | 23.84 | 0.00 | 805 | FLY-ASH PONDS |
| SPIS-18 | -37.84 | 150 | 112.16 | 0.00 | 810 | FLY-ASH PONDS |
| IS-15 | -43.43 | 150 | 106.57 | 0.00 | 1140 | |
| SPIS-15A | -36.74 | 150 | 113.26 | 0.00 | 815 | FLY-ASH PONDS |
| SPMW-09 | -40.32 | 60.3 | 19.98 | 0.00 | 823 | FLY-ASH PONDS |
| T2-B | -17.6 | 44.2 | 26.6 | 0.00 | 830 | FLY-ASH PONDS |
| SPIS-26 | -46.13 | 150 | 103.87 | 0.00 | 840 | FORMER PUMPING WELL |
| SPIS-25 | -46.74 | 150 | 103.26 | 0.00 | 850 | FORMER PUMPING WELL |
| SPIS-27 | -49.51 | 150 | 100.49 | 0.00 | 900 | FORMER PUMPING WELLS/ACROSS FROM CALGON BLDG. |
| SPMW-02 | -47.33 | 75.2 | 27.87 | 0.00 | 905 | BY ROADWAY ON RIGHT GOING EAST TURN SOUTH |
| SPMW-07 | -43.5 | 67.21 | 23.71 | 0.00 | 928 | HOOK LEFT ON ROADWAY BESIDE RR TRACKS |
| SPMW-03 | -43.96 | 67 | 23.04 | 0.00 | 918 | BOON DOCKS NORTH OF TRACKS |
| SPIS-22 | -46.27 | 150 | 103.73 | 0.00 | 940 | FORMER PW |
| SPOB-34 | -47.38 | 81.9 | 34.52 | 0.00 | 943 | NEAR PINES |
| SPOB-12R2 | -49.92 | 67.04 | 17.12 | 0.00 | 945 | NEAR PINES |
| SPMW-11R | -49.82 | 64.5 | 14.68 | 0.00 | 950 | NEAR PINES |
| SPMW-12 | -48.54 | 64.9 | 16.36 | 0.00 | 955 | NEAR PINES |
| SPMW-13 | -48.07 | 71.03 | 22.96 | 0.00 | 1000 | NEAR PINES |
| SPMW-04 | -48.91 | 66.75 | 17.84 | 0.00 | 1005 | NEAR PINES |
| SPIS-06 | -49.05 | 150 | 100.95 | 0.00 | 1010 | FORMER PUMPING WELLS |
| SPIS-05 | -43.89 | 150 | 106.11 | 0.00 | 1015 | FORMER PUMPING WELLS |
| SPIS-01 | -43.22 | 150 | 106.78 | 0.00 | 1020 | INSIDE RED BRICK BLDG. |
| SPIS-28 | -46.39 | 150 | 103.61 | 0.00 | 1025 | FORMER PUMPING WELLS |
| SPIS-02 | -43.03 | 150 | 106.97 | 0.00 | 1030 | Former BRICK BLDG. NEXT TO Former TOWERS |
| SPOB-29 | -43.43 | 76.62 | 33.19 | 0.00 | 1038 | GO TO PYRO CHEM |
| SPOB-15D | -44.92 | 62.51 | 17.59 | 0.00 | 1130 | SOUTH OF CO. RD. 1 INSIDE AND TO THE RIGHT |
| SPOB-26 | -34.67 | 72.02 | 37.35 | 0.00 | 1113 | NEAR THE DOCK |
| CAISSON | 32.9 | | 32.9 | 0.00 | 1120 | AT THE RIVER |
| SPOB-17D | -35.28 | 50.56 | 15.28 | 0.00 | 1045 | EAST ON THE PATH TO TREE WITH LARGE BRANCH DOWN |
| SPOB-18D | -34.82 | 52.63 | 17.81 | 0.00 | 1055 | FOLLOW THE LANE PAST PUMP HOUSE |
| SPIS-10 | -44.37 | 150 | 105.63 | 0.00 | 1129 | AT SP FIRE STATION |
| SPIS-23 | | | | | | Pumping Well |
| SPIS-24 | | | | | | Pumping Well |

PROJECT Ironton FIELD SAMPLE ID SPMW01 STUDY AREA / AOC _____
 SITE ID 00201 South Point SITE TYPE _____ DATE 4-11-06
 ACTIVITY START 08:00 END 09:20 JOB NUMBER _____ FILE TYPE _____
 SAMPLE TIME 09:10 WEATHER SUNNY 47°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 62.15 FT (TOR) HISTORICAL WELL DEPTH _____ FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT PROTECTIVE CASING / WELL DIFFERENCE 8 FT
 DEPTH TO WATER 36.35 FT (TOR) SCREEN LENGTH _____ FT WELL DIAMETER 2 IN WELL MATERIAL 2" PVC
 HEIGHT OF WATER COLUMN 25.8 FT PURGE VOLUME _____ GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP / /
 CASING COLLAR / /
 LOCKED / /
 PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED 4.5 GAL

PURGE DATA

| TIME | 08:40 | 08:45 | 08:50 | 08:55 | 09:00 | 09:05 |
|-------------------------|-------|-------|-------|-------|-------|-------|
| PURGE VOLUME (gallons) | 1 | 1.5 | 2.0 | 2.5 | 3.0 | 3.5 |
| PURGE RATE (gal/min) | 500ml | 500ml | 500ml | 500ml | 500ml | 500ml |
| WATER LEVEL (feet) | 36.35 | 36.35 | 36.35 | 36.35 | 36.35 | 36.35 |
| TEMPERATURE (degreesC) | 13.72 | 13.40 | 12.77 | 14.07 | 14.22 | 13.96 |
| pH (units) | 6.46 | 6.83 | 6.79 | 7.04 | 7.0 | 7.01 |
| DISSOLVED OXYGEN (mg/L) | 1.40 | 3.57 | 1.00 | .99 | .97 | 1.02 |
| SPEC. COND. (ms/cm) | 442 | 414 | 447 | 490 | 521 | 0.505 |
| TURBIDITY (ntu) | 26.3 | 0.0 | 1.3 | .7 | .6 | 0.0 |
| REDOX POTENTIAL (mv) | 176 | 164 | 160 | 142 | 139 | 140 |

SAMPLE OBSERVATIONS

CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes) _____
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED _____
 COMBINED WITH _____

EQUIPMENT DOCUMENTATION

PURGING SAMPLING SUBMERSIBLE PUMP POLAND SPRING
 DISTILLED WATER OTHER _____
 DEDICATED HDPE TUBING OTHER _____

NUMBER OF FILTERS USED _____
 WATER LEVEL EQUIPMENT USED ELECTRIC COND. PROBE
 OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

C. Miller
P. Holmes

Prepared/Date: 4-11-06
 Checked/Date: _____

| | | |
|--|--|--|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRON TON CORE FACILITY IRONTON, OHIO SITE NO. 35024 3283051221/2200.3 |
|--|--|--|

PROJECT Ironton - South Point FIELD SAMPLE ID SPmw 10R STUDY AREA / AOC
 SITE ID South Point SITE TYPE DATE 4-11-06
 ACTIVITY START 09:25 END 10:40 JOB NUMBER FILE TYPE
 SAMPLE TIME 10:30 WEATHER Sunny 52°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 95.9 FT (TOR) HISTORICAL WELL DEPTH FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT PROTECTIVE CASING / WELL DIFFERENCE FT
 DEPTH TO WATER 66.69 FT (TOR) SCREEN LENGTH FT WELL DIAMETER 2 IN WELL MATERIAL 2 PVC
 HEIGHT OF WATER COLUMN 28.19 FT PURGE VOLUME GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP
 CASING
 COLLAR
 LOCKED
 PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED 96 GAL

PURGE DATA

| TIME | 10:00 | 10:05 | 10:10 | 10:15 | 10:20 | 10:25 |
|--------------------------|-------|-------|-------|-------|-------|-------|
| PURGE VOLUME (gallons) | 5 | 5.5 | 6.0 | 6.5 | 7.0 | 7.5 |
| PURGE RATE (gal/min) | 500ml | 500ml | 500ml | 500ml | 500ml | 500ml |
| WATER LEVEL (feet) | 66.69 | 66.69 | 66.69 | 66.69 | 66.69 | 66.69 |
| TEMPERATURE (degrees C) | 14.04 | 14.43 | 15.22 | 15.47 | 16.12 | 15.84 |
| pH (units) | 4.83 | 4.61 | 4.78 | 4.76 | 4.81 | 4.89 |
| DISSOLVED OXYGEN (mg/L) | 2.08 | 2.10 | 2.94 | 2.65 | 2.46 | 2.39 |
| SPEC. COND. (mc/cm) | 390 | 407 | 0.409 | 0.411 | 0.412 | 0.413 |
| TURBIDITY (ntu) | 126 | 98 | 119.0 | 94.4 | 80.0 | 67.7 |
| REDOX POTENTIAL (+/- mv) | 347 | 358 | 348 | 347 | 341 | 329 |

SAMPLE OBSERVATIONS

CLEAR
 COLORED Brownish
 TURBID
 ODOR
 OTHER (see notes)
 PURGE WATER CONTAINERIZED?
 YES NO
 NO. OF DRUMS USED
 COMBINED WITH

EQUIPMENT DOCUMENTATION

PURGING SAMPLING
 SUBMERSIBLE PUMP POLAR SPRING
 DEDICATED HOPE TUBING DISTILLED WATER
 OTHER OTHER
 NUMBER OF FILTERS USED
 WATER LEVEL EQUIPMENT USED
 ELECTRIC COND. PROBE
 OTHER

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

Water Brownish in Color.

P Holmes
 C Miller

Prepared/Date: 4-11-06
 Checked/Date:

Honeywell
 102 COLUMBIA RD. BOX 2105
 MORRISTOWN, NJ 07962

MACTEC

GROUNDWATER SAMPLING DATA RECORD
 ALLIED CHEMICAL/IRONTON COKE FACILITY
 IRONTON, OHIO
 SITE NO. 35024
 3283051221/2200.3

PROJECT: Ironton - South Point FIELD SAMPLE ID: SPMW 05 STUDY AREA / AOC:
 SITE ID: South Point SITE TYPE: DATE: 4-11-06
 ACTIVITY: START 10:53 END 1145 JOB NUMBER: FILE TYPE:
 SAMPLE TIME: 1135 WEATHER: SUNNY 55°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH: 85.83 FT (TOR) HISTORICAL WELL DEPTH: FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND): 3 FT PROTECTIVE CASING / WELL DIFFERENCE: FT
 DEPTH TO WATER: 61.11 FT (TOR) SCREEN LENGTH: FT WELL DIAMETER: 2 IN WELL MATERIAL: PVC
 HEIGHT OF WATER COLUMN: 28.19 FT PURGE VOLUME: GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP: COLLAR: LOCKED:
 PID AMBIENT AIR: 0.0 PPM PID WELL MOUTH: 0.0 PPM TOTAL VOLUME PURGED: 6.0 GAL

PURGE DATA

| TIME | 1105 | 1110 | 1115 | 1120 | 1125 | 1130 |
|--------------------------|-------|-------|-------|-------|-------|-------|
| PURGE VOLUME (gallons) | 3 | 3.5 | 4.0 | 4.5 | 5.0 | 5.5 |
| PURGE RATE (gal/min) | 500ml | 500ml | 500ml | 500ml | 500ml | 500ml |
| WATER LEVEL (feet) | 61.11 | 61.11 | 61.11 | 61.12 | 61.11 | 61.11 |
| TEMPERATURE (degrees C) | 14.32 | 14.27 | 14.07 | 14.06 | 14.22 | 14.37 |
| pH (units) | 6.89 | 7.13 | 7.32 | 7.43 | 7.66 | 7.93 |
| DISSOLVED OXYGEN (mg/L) | 5.11 | 4.88 | 4.66 | 4.57 | 4.26 | 4.19 |
| SPEC. COND. (mc/cm) | 1143 | 1453 | 1459 | 1461 | 1465 | 1466 |
| TURBIDITY (ntu) | 149.0 | 147.0 | 121.0 | 111.0 | 110.0 | 106.0 |
| REDOX POTENTIAL (+/- mv) | 219 | 183 | 165 | 155 | 136 | 123 |

SAMPLE OBSERVATIONS

CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes) _____
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED: _____
 COMBINED WITH: _____

EQUIPMENT DOCUMENTATION

PURGING: SAMPLING:
 SUBMERSIBLE PUMP POLAND SPRING
 DEDICATED HDPE TUBING DISTILLED WATER
 OTHER _____ OTHER _____

NUMBER OF FILTERS USED: _____
 WATER LEVEL EQUIPMENT USED: ELECTRIC COND. PROBE
 OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

*P Holmes
C Miller*

Prepared/Date: 4-11-06
 Checked/Date:

| | | |
|--|--|---|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRONTON CORE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|--|--|---|

PROJECT: Ironton - South Point FIELD SAMPLE ID: SPMW03 STUDY AREA / AOC:
 SITE ID: SITE TYPE: DATE: 4-11-06
 ACTIVITY: START 12:15 END 12:55 JOB NUMBER: FILE TYPE:
 SAMPLE TIME: 1245 WEATHER: SUNNY 65°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH: 67.00 FT (TOR) HISTORICAL WELL DEPTH: FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND): 3 FT PROTECTIVE CASING / WELL DIFFERENCE: FT
 DEPTH TO WATER: 43.96 FT (TOR) SCREEN LENGTH: FT WELL DIAMETER: 2 IN WELL MATERIAL: PVC
 HEIGHT OF WATER COLUMN: 23.04 FT PURGE VOLUME: GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP: CASING: COLLAR: LOCKED:
 PID AMBIENT AIR: 0.0 PPM PID WELL MOUTH: 0.0 PPM TOTAL VOLUME PURGED: 5.0 GAL

PURGE DATA

| TIME | 1225 | 1228 | 1231 | 1234 | 1237 | 1240 |
|--------------------------|--------|--------|--------|--------|--------|--------|
| PURGE VOLUME (gallons) | 1.5 | 2 | 2.5 | 3 | 3.5 | 4.0 |
| PURGE RATE (gal/min) | 500 mL |
| WATER LEVEL (feet) | 43.96 | 43.96 | 43.96 | 43.96 | 43.96 | 43.96 |
| TEMPERATURE (degrees C) | 15.12 | 15.04 | 15.54 | 15.06 | 15.45 | 14.90 |
| pH (units) | 7.47 | 7.14 | 6.93 | 6.89 | 6.91 | 7.14 |
| DISSOLVED OXYGEN (mg/L) | 6.00 | 0.00 | 6.00 | 0.00 | 0.00 | 0.00 |
| EPEC. COND. (mS/cm) | .533 | .576 | .576 | .587 | .615 | .622 |
| TURBIDITY (ntu) | 175.0 | 177.0 | 175 | 169 | 181 | 176 |
| REDOX POTENTIAL (+/- mv) | 223 | 211 | 193 | 166 | 174 | 155 |

SAMPLE OBSERVATIONS

CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes) _____
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED _____
 COMBINED WITH _____

EQUIPMENT DOCUMENTATION

PURGING: SAMPLING:
 SUBMERSIBLE PUMP POLAND SPRING
 DEDICATED HDPE TUBING DISTILLED WATER
 OTHER _____ OTHER _____
 NUMBER OF FILTERS USED: _____
 WATER LEVEL EQUIPMENT USED: ELECTRIC COND. PROBE
 OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

*P. Hoimes
C. Miller*

Prepared/Date: 4-11-06
 Checked/Date:

| | | |
|--|--|---|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRONTON COKE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|--|--|---|

PROJECT Ironton - South Point FIELD SAMPLE ID SPMW-07 STUDY AREA / AOC _____
 SITE ID _____ SITE TYPE _____ DATE 4-11-06
 ACTIVITY START 13:00 END 13:35 JOB NUMBER _____ FILE TYPE _____
 SAMPLE TIME 1325 WEATHER Sunny 75°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 67.21 FT (TOR) HISTORICAL WELL DEPTH _____ FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT PROTECTIVE CASING / WELL DIFFERENCE _____ FT
 DEPTH TO WATER 43.5 FT (TOR) SCREEN LENGTH _____ FT WELL DIAMETER 2 IN WELL MATERIAL PVC
 HEIGHT OF WATER COLUMN 23.71 FT PURGE VOLUME _____ GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP _____
 PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED 4.5 GAL COLLAR _____
 LOCKED _____

PURGE DATA

| TIME | 13:06 | 13:09 | 13:12 | 13:15 | 13:18 | 13:21 |
|--------------------------|----------------|--------|--------|--------|--------|--------|
| PURGE VOLUME (gallons) | 5.0 | 1.5 | 2 | 2.5 | 3 | 3.5 |
| PURGE RATE (gal/min) | 500 mL | 500 mL | 500 mL | 500 mL | 600 mL | 500 mL |
| WATER LEVEL (feet) | 43.5 | 43.5 | 43.5 | 43.5 | 43.5 | 43.5 |
| TEMPERATURE (degrees C) | 15.62 | 15.63 | 15.60 | 15.59 | 15.63 | 15.55 |
| pH (units) | 4.01 | 7.99 | 7.94 | 7.92 | 7.93 | 7.96 |
| DISSOLVED OXYGEN (mg/L) | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 |
| SPEC. COND. (mS/cm) | 1.78 | 1.77 | 1.69 | 1.69 | 1.65 | 1.66 |
| TURBIDITY (ntu) | 159 | 155 | 162 | 100.0 | 115 | 139 |
| REDOX POTENTIAL (+/- mv) | 191 | 190 | 184 | 173 | 164 | 168 |

SAMPLE OBSERVATIONS:
 CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes)
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED _____
 COMBINED WITH: _____

EQUIPMENT DOCUMENTATION

PURGING SAMPLING SUBMERSIBLE PUMP POLAND SPRING
 DEDICATED HOPE TUBING DISTILLED WATER OTHER _____
 NUMBER OF FILTERS USED _____ WATER LEVEL EQUIPMENT USED ELECTRIC COND. PROBE
 OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

*P. Holms
C. Miller*

Prepared/Date: 4-11-06
 Checked/Date: _____

| | | |
|--|--|--|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07862 |  | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRONTON CORE FACILITY IRONTON, OHIO SITE NO. 35024 329305122/2200.3 |
|--|--|--|

PROJECT Ironton - South Point FIELD SAMPLE ID D.NW-02 STUDY AREA / AOC
 SITE ID SITE TYPE DATE 4-11-02
 ACTIVITY START 13:40 END 14:20 JOB NUMBER FILE TYPE
 SAMPLE TIME 1410 WEATHER SUNNY 75°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 75.2 FT (TOR) HISTORICAL WELL DEPTH FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT PROTECTIVE CASING / WELL DIFFERENCE FT
 DEPTH TO WATER 47.33 FT (TOR) SCREEN LENGTH FT WELL DIAMETER 2 IN WELL MATERIAL PVC
 HEIGHT OF WATER COLUMN 27.87 FT PURGE VOLUME GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP
 PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED GAL CASING COLLAR LOCKED

PURGE DATA

| TIME | 1350 | 1353 | 1356 | 1359 | 1402 | 1405 |
|--------------------------|-------|-------|-------|-------|-------|-------|
| PURGE VOLUME (gallons) | 1 | 1.5 | 2.1 | 2.7 | 3 | 3.5 |
| PURGE RATE (gal/min) | 500ml | 500ml | 500ml | 500ml | 500ml | 500ml |
| WATER LEVEL (feet) | 47.33 | 47.33 | 47.33 | 47.33 | 47.33 | 47.33 |
| TEMPERATURE (degrees C) | 14.64 | 14.50 | 14.45 | 14.42 | 14.43 | 14.43 |
| pH (units) | 7.37 | 7.15 | 7.08 | 7.30 | 7.51 | 7.63 |
| DISSOLVED OXYGEN (mg/L) | 4.39 | 3.68 | 0.00 | 0.00 | 0.00 | 0.00 |
| SPEC. COND. (mc/cm) | 162 | 709 | 91 | 91 | 92 | 92 |
| TURBIDITY (ntu) | 151 | 143 | 166 | 171 | 175 | 172 |
| REDOX POTENTIAL (+/- mv) | 203 | 204 | 191 | 189 | 74 | 165 |

SAMPLE OBSERVATIONS

CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes) _____
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED _____
 COMBINED WITH _____

EQUIPMENT DOCUMENTATION

PURGING SAMPLING SUBMERSIBLE PUMP POLAND SPRING
 DEDICATED HDPE TUBING DISTILLED WATER OTHER _____
 NUMBER OF FILTERS USED _____ WATER LEVEL EQUIPMENT USED ELECTRIC COND. PROBE
 OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

*P Holmes
C. Miller*

Prepared/Date: 4-11-02
 Checked/Date: _____

| | | |
|--|--|--|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07862 |  | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRON TON CORE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|--|--|--|

PROJECT Ironton / South Point FIELD SAMPLE ID SP15 23 STUDY AREA / AOC
 SITE ID SITE TYPE DATE 4-11-06
 ACTIVITY START 14:30 END 14:45 JOB NUMBER FILE TYPE
 SAMPLE TIME 14:35 WEATHER SUNNY 76°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH FT (TOR) HISTORICAL WELL DEPTH FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND) FT PROTECTIVE CASING / WELL DIFFERENCE FT
 DEPTH TO WATER FT (TOR) SCREEN LENGTH FT WELL DIAMETER IN WELL MATERIAL
 HEIGHT OF WATER COLUMN FT PURGE VOLUME GAL/VOL WELL INTEGRITY: YES NO N/A
 PID AMBIENT AIR PPM PID WELL MOUTH PPM TOTAL VOLUME PURGED GAL CAP CASING COLLAR LOCKED

PURGE DATA

| | | | | | |
|--------------------------|--------------|--|--|--|--|
| TIME | <u>1435</u> | | | | |
| PURGE VOLUME (gallons) | | | | | |
| PURGE RATE (gal/min) | | | | | |
| WATER LEVEL (feet) | | | | | |
| TEMPERATURE (degreesC) | <u>15.13</u> | | | | |
| pH (units) | <u>7.63</u> | | | | |
| DISSOLVED OXYGEN (mg/L) | <u>—</u> | | | | |
| SPEC. COND. (ms/cm) | <u>—</u> | | | | |
| TURBIDITY (ntu) | <u>0.3</u> | | | | |
| REDOX POTENTIAL (+/- mv) | <u>—</u> | | | | |

SAMPLE OBSERVATIONS

CLEAR
 COLORED
 TURBID
 ODOR
 OTHER (see notes)
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED COMBINED WITH:

EQUIPMENT DOCUMENTATION

PURGING SAMPLING SUBMERSIBLE PUMP DEDICATED HDPE TUBING
DECON FLUIDS USED POLAND SPRING DISTILLED WATER OTHER
NUMBER OF FILTERS USED **WATER LEVEL EQUIPMENT USED** ELECTRIC COND. PROBE OTHER

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

NOTES

Matrix SPIKE
matrix spike Dup
Pumping well.
P Holmes
C Miller

Prepared/Date: 4-11-06
 Checked/Date:

| | | |
|--|--|---|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRONTON CORE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|--|--|---|

PROJECT Ironton South Point FIELD SAMPLE ID SPMw-06R STUDY AREA / AOC _____
 SITE ID _____ SITE TYPE _____ DATE 4-12-06
 ACTIVITY START 07:30 END 08:55 JOB NUMBER _____ FILE TYPE _____
 SAMPLE TIME 08:45 WEATHER Cloudy 62° F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 101.6 FT (TOR) HISTORICAL WELL DEPTH _____ FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT PROTECTIVE CASING / WELL DIFFERENCE _____ FT
 DEPTH TO WATER 72.02 FT (TOR) SCREEN LENGTH _____ FT WELL DIAMETER 2 IN WELL MATERIAL PVC
 HEIGHT OF WATER COLUMN 29.58 FT PURGE VOLUME _____ GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP / /
 CASING / /
 COLLAR / /
 LOCKED / /
 PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED 5.5 GAL

PURGE DATA

| TIME | 08:10 | 08:13 | 08:16 | 08:19 | 08:22 | 08:25 |
|--------------------------|-------|-------|-------|-------|-------|-------|
| PURGE VOLUME (gallons) | 2 | 2.5 | 3.0 | 3.5 | 4.0 | 4.5 |
| PURGE RATE (gal/min) | 500ml | 500ml | 500ml | 500ml | 500ml | 500ml |
| WATER LEVEL (feet) | 72.02 | 72.02 | 72.02 | 72.02 | 72.02 | 72.02 |
| TEMPERATURE (degreesC) | 14.84 | 14.88 | 14.90 | 14.89 | 14.87 | 14.93 |
| pH (units) | 6.76 | 6.80 | 7.06 | 7.03 | 7.16 | 7.05 |
| DISSOLVED OXYGEN (mg/L) | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| SPEC. COND. (ms/cm) | 1.49 | 1.42 | 1.49 | 1.50 | 1.47 | 1.51 |
| TURBIDITY (ntu) | 388 | 263 | 52.8 | 46.9 | 69.1 | 74.6 |
| REDOX POTENTIAL (+/- mv) | 207 | 168 | 93 | 93 | 92 | 93 |

SAMPLE OBSERVATIONS

CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes) _____
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED _____
 COMBINED WITH: _____

EQUIPMENT DOCUMENTATION

PURGING SAMPLING
 SUBMERSIBLE PUMP
 DEDICATED HDPE TUBING
 DECON FLUIDS USED POLAND SPRING
 DISTILLED WATER
 OTHER _____
 NUMBER OF FILTERS USED _____
 WATER LEVEL EQUIPMENT USED ELECTRIC COND. PROBE
 OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

*PHolmes
cmll*

Prepared/Date: 4-12-06
 Checked/Date: _____

| | | |
|--|---|---|
| Honeywell 102 COLUMBIARD. BOX 2105 MORRISTOWN, NJ 07962 |  MACTEC | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRONTON CORE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|--|---|---|

PROJECT Ironton - South Point FIELD SAMPLE ID SPMW-08 STUDY AREA / AOC _____
 SITE ID _____ SITE TYPE _____ DATE 4-12-06
 ACTIVITY START 09:00 END 09:40 JOB NUMBER _____ FILE TYPE _____
 SAMPLE TIME 09:30 WEATHER Cloudy 64°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 66.22 FT (TOR) HISTORICAL WELL DEPTH _____ FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT PROTECTIVE CASING / WELL DIFFERENCE _____ FT
 DEPTH TO WATER 42.38 FT (TOR) SCREEN LENGTH _____ FT WELL DIAMETER 2 IN WELL MATERIAL PVC
 HEIGHT OF WATER COLUMN 23.84 FT PURGE VOLUME _____ GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP CASING COLLAR LOCKED
 PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED 5 GAL

PURGE DATA

| TIME | 09:10 | 09:13 | 09:16 | 09:19 | 09:22 | 09:25 |
|--------------------------|-------|-------|-------|-------|-------|-------|
| PURGE VOLUME (gallons) | 1.5 | 2.0 | 2.5 | 3.0 | 3.5 | 4.0 |
| PURGE RATE (gal/min) | 300ml | 500ml | 500ml | 500ml | 500ml | 500ml |
| WATER LEVEL (feet) | 42.38 | 42.38 | 42.38 | 42.38 | 42.38 | 42.38 |
| TEMPERATURE (degreesC) | 14.46 | 14.34 | 14.37 | 14.34 | 14.39 | 14.38 |
| pH (units) | 7.05 | 6.82 | 6.88 | 6.82 | 6.95 | 6.89 |
| DISSOLVED OXYGEN (mg/L) | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| SPEC. COND. (mc/cm) | .744 | .944 | .913 | .900 | 1.29 | .999 |
| TURBIDITY (ntu) | 39.3 | 29.5 | 21.2 | 21.2 | 19.4 | 18.7 |
| REDOX POTENTIAL (+/- mv) | 153 | 149 | 140 | 144 | 143 | 138 |

SAMPLE OBSERVATIONS

CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes) _____
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED _____
 COMBINED WITH _____

EQUIPMENT DOCUMENTATION

PURGING SAMPLING
 SUBMERSIBLE PUMP POLAND SPRING
 DEDICATED HDPE TUBING DISTILLED WATER
 OTHER _____ OTHER _____
 NUMBER OF FILTERS USED _____
 WATER LEVEL EQUIPMENT USED ELECTRIC COND. PROBE
 OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

*P Holmes
C Miller*

Prepared/Date: 4-12-06
 Checked/Date: _____

| | | |
|---|---|---|
| Honeywell 102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  MACTEC | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRONTON CORE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|---|---|---|

PROJECT Ironton - South Point FIELD SAMPLE ID SPmw-09 STUDY AREA / AOC
 SITE ID SITE TYPE DATE 4-12-06
 ACTIVITY START 09:45 END 10:30 JOB NUMBER FILE TYPE
 SAMPLE TIME 10:20 WEATHER Partly Cloudy 66°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 60.03 FT (TOR) HISTORICAL WELL DEPTH FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND) FT PROTECTIVE CASING / WELL DIFFERENCE FT
 DEPTH TO WATER 40.32 FT (TOR) SCREEN LENGTH FT WELL DIAMETER 2 IN WELL MATERIAL PVC
 HEIGHT OF WATER COLUMN 19.98 FT PURGE VOLUME GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP
 CASING
 COLLAR
 LOCKED
 PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED 5.5 GAL

PURGE DATA

| TIME | 10:00 | 10:03 | 10:06 | 10:09 | 10:12 | 10:15 |
|--------------------------|-------|-------|-------|-------|-------|-------|
| PURGE VOLUME (gallons) | 2 | 2.5 | 3.0 | 3.5 | 4.0 | 4.5 |
| PURGE RATE (gal/min) | 500ml | 500ml | 500ml | 500ml | 500ml | 500ml |
| WATER LEVEL (feet) | 40.32 | 40.32 | 40.32 | 40.32 | 40.32 | 40.32 |
| TEMPERATURE (degreesC) | 13.54 | 13.62 | 13.66 | 13.76 | 13.76 | 13.80 |
| pH (units) | 4.22 | 4.11 | 4.10 | 4.12 | 4.12 | 4.16 |
| DISSOLVED OXYGEN (mg/L) | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| SPEC. COND. (ms/cm) | .655 | .689 | .686 | .683 | .671 | .677 |
| TURBIDITY (ntu) | 91.1 | 50.3 | 48.5 | 43.6 | 45.5 | 37.9 |
| REDOX POTENTIAL (+/- mv) | 366 | 377 | 374 | 375 | 375 | 374 |

SAMPLE OBSERVATIONS:
 CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes) _____
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED _____
 COMBINED WITH _____

EQUIPMENT DOCUMENTATION

PURGING SAMPLING
 SUBMERSIBLE PUMP POLAND SPRING
 DEDICATED HDPE TUBING DISTILLED WATER
 OTHER _____ OTHER _____

NUMBER OF FILTERS USED _____
 WATER LEVEL EQUIPMENT USED ELECTRIC COND. PROBE
 OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

*P. Holmes
C. Miller*

Prepared/Date: 4-12-06
 Checked/Date:

| | | |
|--|--|--|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRONTON CORE FACILITY IRONTON, OHIO SITE NO. 35024 32930512.21/2200.3 |
|--|--|--|

PROJECT Ironton - South Point FIELD SAMPLE ID SP0B-34 STUDY AREA / AOC
 SITE ID SITE TYPE DATE 4-12-06
 ACTIVITY START 10:50 END 11:30 JOB NUMBER FILE TYPE
 SAMPLE TIME 11:30 WEATHER SUNNY 70°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 81.90 FT (TOR) HISTORICAL WELL DEPTH FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT PROTECTIVE CASING / WELL DIFFERENCE FT
 DEPTH TO WATER 47.38 FT (TOR) SCREEN LENGTH FT WELL DIAMETER 2 IN WELL MATERIAL PVC
 HEIGHT OF WATER COLUMN 34.12 FT PURGE VOLUME GAL/VOL WELL INTEGRITY: YES NO N/A
 PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED 5 GAL
 CAP YES NO N/A
 COLLAR YES NO N/A
 LOCKED YES NO N/A

PURGE DATA

| TIME | 11:00 | 11:03 | 11:06 | 11:09 | 11:12 | 11:15 |
|-------------------------|-------|-------|-------|-------|-------|-------|
| PURGE VOLUME (gallons) | 1.5 | 2.0 | 2.5 | 3.0 | 3.5 | 4 |
| PURGE RATE (gal/min) | 500ml | 500ml | 500ml | 500ml | 500ml | 500ml |
| WATER LEVEL (feet) | 47.38 | 47.38 | 47.38 | 47.38 | 47.38 | 47.40 |
| TEMPERATURE (degrees C) | 15.97 | 15.94 | 15.92 | 15.97 | 15.94 | 15.78 |
| pH (units) | 7.34 | 7.37 | 7.44 | 7.54 | 7.76 | 7.82 |
| DISSOLVED OXYGEN (mg/L) | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 |
| SPEC. COND. (mc/cm) | 0.445 | .416 | .460 | .90 | .90 | .90 |
| TURBIDITY (ntu) | 115 | 110 | 95.8 | 90.7 | 81.6 | 78.5 |
| REDOX POTENTIAL (mv) | -113 | -126 | -134 | -144 | -159 | -166 |

SAMPLE OBSERVATIONS

CLEAR
 COLORED
 TURBID
 ODOR
 OTHER (see notes)

PURGE WATER CONTAINERIZED?
 YES NO

NO. OF DRUMS USED
 COMBINED WITH

EQUIPMENT DOCUMENTATION

PURGING SAMPLING
 SUBMERSIBLE PUMP POLAND SPRING
 DEDICATED HDPE TUBING DISTILLED WATER
 OTHER OTHER

NUMBER OF FILTERS USED
 WATER LEVEL EQUIPMENT USED
 ELECTRIC COND. PROBE
 OTHER

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID/LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

*P Holmes
C Miller*

Prepared/Date: 4-12-06
 Checked/Date:

| | | |
|--|----------------------|--|
| <p>Honeywell 102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07862</p> | <p>MACTEC</p> | <p>GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRONTON CORE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3</p> |
|--|----------------------|--|

PROJECT Ironton - South Point FIELD SAMPLE ID 5006 12R2 STUDY AREA / AOC
 SITE ID SITE TYPE DATE 4-12-06
 ACTIVITY START 12:10 END 12:55 JOB NUMBER FILE TYPE
 SAMPLE TIME 1245 WEATHER SUNNY 77° F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 67.04 FT (TOR) HISTORICAL WELL DEPTH FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT PROTECTIVE CASING / WELL DIFFERENCE FT
 DEPTH TO WATER 49.92 FT (TOR) SCREEN LENGTH FT WELL DIAMETER 2 IN WELL MATERIAL PVC
 HEIGHT OF WATER COLUMN 17.12 FT PURGE VOLUME GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP ✓
 COLLAR ✓
 LOCKED ✓
 PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED 5 GAL

PURGE DATA

| TIME | 1223 | 1226 | 1229 | 1232 | 1235 | 1238 |
|--------------------------|-------|-------|-------|-------|-------|-------|
| PURGE VOLUME (gallons) | 1.5 | 2 | 2.5 | 3 | 3.5 | 4.0 |
| PURGE RATE (gal/min) | 500ml | 500ml | 500ml | 500ml | 500ml | 500ml |
| WATER LEVEL (feet) | 49.92 | 49.92 | 49.92 | 49.92 | 49.92 | 49.92 |
| TEMPERATURE (degreesC) | 15.36 | 15.37 | 15.31 | 15.32 | 15.33 | 15.33 |
| pH (units) | 6.53 | 6.56 | 6.74 | 6.80 | 6.82 | 6.83 |
| DISSOLVED OXYGEN (mg/L) | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 |
| SPEC. COND. (mc/cm) | .932 | .945 | .946 | .955 | 0.961 | 0.956 |
| TURBIDITY (ntu) | 235.0 | 177.0 | 162 | 155 | 143.0 | 150.0 |
| REDOX POTENTIAL (+/- mv) | 159 | 148 | 137 | 134 | 132 | 132 |

SAMPLE OBSERVATIONS

CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes)
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED _____
 COMBINED WITH _____

EQUIPMENT DOCUMENTATION

PURGING SAMPLING DECON FLUIDS USED: POLAND SPRING, DISTILLED WATER, OTHER _____
 SUBMERSIBLE PUMP DEDICATED HDPE TUBING NUMBER OF FILTERS USED _____
 WATER LEVEL EQUIPMENT USED: ELECTRIC COND. PROBE, OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID/LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

Re Stenciled well

PHolmes
C Miller

Prepared/Date: 4-12-06
 Checked/Date:

| | | |
|--|--|---|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07862 |  | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRONTON CORE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|--|--|---|

PROJECT Ironton - South Point FIELD SAMPLE ID SPMw 11R STUDY AREA / AOC _____
 SITE ID _____ SITE TYPE _____ DATE 4-12-06
 ACTIVITY START 13:05 END 13:50 JOB NUMBER _____ FILE TYPE _____
 SAMPLE TIME 1340 WEATHER SUNNY 76°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 64.5 FT (TOR) HISTORICAL WELL DEPTH _____ FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT PROTECTIVE CASING / WELL DIFFERENCE _____ FT

DEPTH TO WATER 49.82 FT (TOR) SCREEN LENGTH _____ FT WELL DIAMETER 2 IN WELL MATERIAL PVC

HEIGHT OF WATER COLUMN 14.68 FT PURGE VOLUME _____ GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP _____
 CASING _____
 COLLAR _____
 LOCKED _____

PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED 5 GAL

PURGE DATA

| TIME | 1320 | 1323 | 1326 | 1329 | 1332 | 1335 |
|--------------------------|--------|--------|--------|--------|--------|--------|
| PURGE VOLUME (gallons) | 1.5 | 2 | 2.5 | 3 | 3.5 | 4.0 |
| PURGE RATE (gal/min) | 500 ML |
| WATER LEVEL (feet) | 49.82 | 49.82 | 49.82 | 49.82 | 49.82 | 49.62 |
| TEMPERATURE (degrees C) | 14.87 | 14.41 | 14.40 | 14.40 | 14.57 | 14.57 |
| pH (units) | 5.58 | 5.51 | 5.60 | 5.60 | 6.19 | 6.18 |
| DISSOLVED OXYGEN (mg/L) | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 |
| SPEC. COND. (ms/cm) | .334 | .337 | .334 | .334 | .389 | .398 |
| TURBIDITY (ntu) | 335 | 257 | 163 | 160 | 116 | 116 |
| REDOX POTENTIAL (+/- mv) | 240 | 246 | 246 | 247 | 224 | 224 |

SAMPLE OBSERVATIONS:
 CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes)
 PURGE WATER CONTAINERIZED? YES _____ NO
 NO. OF DRUMS USED _____
 COMBINED WITH _____

EQUIPMENT DOCUMENTATION

PURGING SAMPLING
 SUBMERSIBLE PUMP DEDICATED HDPE TUBING

DECON FLUIDS USED POLAND SPRING DISTILLED WATER OTHER _____

NUMBER OF FILTERS USED _____
 WATER LEVEL EQUIPMENT USED ELECTRIC COND. PROBE OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

*P Holmes
C Miller*

Prepared/Date: 4-12-06
 Checked/Date: _____

| | | |
|--|--|--|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRONTON CORE FACILITY IRONTON, OHIO SITE NO. 35024 329305122 1/2200.3 |
|--|--|--|

PROJECT Ironton - South Point FIELD SAMPLE ID SPMW 12 STUDY AREA / AOC
 SITE ID SITE TYPE DATE 4.12.06
 ACTIVITY START 13:54 END 14:25 JOB NUMBER FILE TYPE
 SAMPLE TIME 1420 WEATHER SUNNY 80°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 64.90 FT (TOR) HISTORICAL WELL DEPTH FT (TOR)
 PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT PROTECTIVE CASING / WELL DIFFERENCE FT
 DEPTH TO WATER 48.54 FT (TOR) SCREEN LENGTH FT WELL DIAMETER 2 IN WELL MATERIAL PVC
 HEIGHT OF WATER COLUMN 16.36 FT PURGE VOLUME GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP CASING
 COLLAR LOCKED
 PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED 5 GAL

PURGE DATA

| TIME | 1403 | 1406 | 1409 | 1412 | 1415 | 1418 |
|--------------------------|--------|--------|--------|--------|--------|--------|
| PURGE VOLUME (gallons) | 1.25 | 2 | 2.5 | 3 | 3.5 | 4 |
| PURGE RATE (gal/min) | 500 mL |
| WATER LEVEL (feet) | 48.54 | 48.54 | 48.54 | 48.54 | 48.54 | 48.54 |
| TEMPERATURE (degrees C) | 14.82 | 14.97 | 14.96 | 14.81 | 14.57 | 14.52 |
| pH (units) | 7.27 | 7.17 | 7.16 | 7.12 | 7.13 | 7.09 |
| DISSOLVED OXYGEN (mg/L) | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 |
| SPEC. COND. (mc/cm) | .766 | .817 | .957 | .958 | .999 | .948 |
| TURBIDITY (ntu) | 103 | 93.9 | 81.1 | 72.7 | 67.0 | 67.1 |
| REDOX POTENTIAL (+/- mv) | 165 | 179 | 171 | 165 | 159 | 156 |

SAMPLE OBSERVATIONS

CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes) _____
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED _____
 COMBINED WITH _____

EQUIPMENT DOCUMENTATION

PURGING SAMPLING
 SUBMERSIBLE PUMP DEDICATED HDPE TUBING
DECON FLUIDS USED POLAND SPRING DISTILLED WATER OTHER _____
NUMBER OF FILTERS USED _____
 WATER LEVEL EQUIPMENT USED ELECTRIC COND. PROBE OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

*P Holmes
C Miller*

Prepared/Date: 4-12-06
 Checked/Date:

| | | |
|---|---|--|
| Honeywell 102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  MACTEC | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRON TON CONE FACILITY IRONTON, OHIO SITE NO. 35024 3283051221/2200.3 |
|---|---|--|

PROJECT Ironton - South Point FIELD SAMPLE ID SPMW 13 STUDY AREA / AOC
 SITE ID SITE TYPE DATE 4-12-06
 ACTIVITY START 14:30 END 15:20 JOB NUMBER FILE TYPE
 SAMPLE TIME 1455 WEATHER Sunny 81°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH 71.03 FT (TOR) HISTORICAL WELL DEPTH FT (TOR)
 PROTECTIVE CASING STICKUP (FROM GROUND) 3 FT PROTECTIVE CASING / WELL DIFFERENCE FT
 DEPTH TO WATER 48.07 FT (TOR) SCREEN LENGTH FT WELL DIAMETER 2 IN WELL MATERIAL PVC
 HEIGHT OF WATER COLUMN 22.96 FT PURGE VOLUME GAL/VOL WELL INTEGRITY: YES NO N/A
 CAP
 CASING
 COLLAR
 LOCKED
 PID AMBIENT AIR 0.0 PPM PID WELL MOUTH 0.0 PPM TOTAL VOLUME PURGED 5 GAL

PURGE DATA

| TIME | 14:39 | 14:42 | 14:45 | 14:46 | 14:51 | 14:54 |
|--------------------------|-------|-------|-------|-------|-------|-------|
| PURGE VOLUME (gallons) | 1.5 | 2.0 | 2.5 | 3 | 3.5 | 4 |
| PURGE RATE (gal/min) | 500ml | 500ml | 500ml | 500ml | 500ml | 500ml |
| WATER LEVEL (feet) | 48.07 | 48.07 | 48.07 | 46.07 | 46.07 | 46.07 |
| TEMPERATURE (degrees C) | 14.49 | 14.53 | 14.50 | 14.52 | 14.57 | 14.57 |
| pH (units) | 7.91 | 7.89 | 7.91 | 7.96 | 7.99 | 8.02 |
| DISSOLVED OXYGEN (mg/L) | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 |
| SPEC. COND. (mM/cm) | .825 | .792 | .794 | .783 | .764 | .755 |
| TURBIDITY (ntu) | 62.4 | 50.6 | 47.1 | 45.1 | 41.4 | 39.2 |
| REDOX POTENTIAL (+/- mv) | 188 | 181 | 175 | 167 | 162 | 150 |

SAMPLE OBSERVATIONS:
 CLEAR
 COLORED _____
 TURBID _____
 ODOR _____
 OTHER (see notes) _____
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED _____
 COMBINED WITH: _____

EQUIPMENT DOCUMENTATION

PURGING SAMPLING
 SUBMERSIBLE PUMP POLAND SPRING
 DEDICATED HDPE TUBING DISTILLED WATER
 OTHER _____
 NUMBER OF FILTERS USED _____
 WATER LEVEL EQUIPMENT USED
 ELECTRIC COND. PROBE
 OTHER _____

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

*PHOENIX
C Miller*

Prepared/Date: 4-12-06
 Checked/Date: _____

| | | |
|--|--|---|
|  102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07962 |  | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRONTON CORE FACILITY IRONTON, OHIO SITE NO. 35024 3293051221/2200.3 |
|--|--|---|

PROJECT: Ironton - South Point FIELD SAMPLE ID: SP MW 04 STUDY AREA / AOC:
 SITE ID: SITE TYPE: DATE: 4-12-06
 ACTIVITY: START 15:05 END 1545 JOB NUMBER: FILE TYPE:
 SAMPLE TIME: 1535 WEATHER: SUNNY 87°F

WATER LEVEL / WELL DATA

MEASURED WELL DEPTH: 66.75 FT (TOR) HISTORICAL WELL DEPTH: FT (TOR) PROTECTIVE CASING STICKUP (FROM GROUND): 3 FT PROTECTIVE CASING / WELL DIFFERENCE: FT
 DEPTH TO WATER: 48.91 FT (TOR) SCREEN LENGTH: FT WELL DIAMETER: 2 IN WELL MATERIAL: PVC
 HEIGHT OF WATER COLUMN: 17.84 FT PURGE VOLUME: GAL/VOL WELL INTEGRITY: YES NO N/A
 PID AMBIENT AIR: 0.0 PPM PID WELL MOUTH: 0.0 PPM TOTAL VOLUME PURGED: 4.5 GAL CAP CASING COLLAR LOCKED

PURGE DATA

| TIME | 1513 | 1516 | 1519 | 1522 | 1525 | 1528 |
|--------------------------|--------|--------|--------|--------|--------|--------|
| PURGE VOLUME (gallons) | 1 | 1.5 | 2 | 2.5 | 3 | 3.5 |
| PURGE RATE (gal/min) | 500 ML |
| WATER LEVEL (feet) | 48.91 | 48.91 | 48.91 | 48.91 | 48.91 | 48.91 |
| TEMPERATURE (degrees C) | 14.79 | 14.76 | 14.76 | 14.71 | 14.70 | 14.71 |
| pH (units) | 7.30 | 6.75 | 6.64 | 6.63 | 6.63 | 6.62 |
| DISSOLVED OXYGEN (mg/L) | 0.21 | 0.04 | 0.02 | 0.02 | 0.00 | 0.00 |
| SPEC. COND. (mc/cm) | 899 | 863 | 837 | 835 | 834 | 835 |
| TURBIDITY (ntu) | 70.8 | 60.3 | 68.6 | 49.9 | 49.1 | 49.7 |
| REDOX POTENTIAL (+/- mv) | 72 | 105 | 106 | 107 | 108 | 110 |

SAMPLE OBSERVATIONS:
 CLEAR
 COLORED
 TURBID
 ODOR
 OTHER (see notes)
 PURGE WATER CONTAINERIZED? YES NO
 NO. OF DRUMS USED:
 COMBINED WITH:

EQUIPMENT DOCUMENTATION

PURGING: SAMPLING:
 SUBMERSIBLE PUMP DEDICATED HDPE TUBING
 DECON FLUIDS USED: POLAND SPRING DISTILLED WATER OTHER
 NUMBER OF FILTERS USED:
 WATER LEVEL EQUIPMENT USED: ELECTRIC COND. PROBE OTHER

ANALYTICAL PARAMETERS

| ANALYTE | METHOD NUMBER | PRESERVATION METHOD | VOLUME REQUIRED | SAMPLE COLLECTED | SAMPLE BOTTLE ID LETTERS |
|---------|---------------|---------------------|-----------------|------------------|--------------------------|
| | | | | | |

NOTES

p Holm →
Cmiller

Prepared/Date: 4-12-06
 Checked/Date:

| | | |
|---|---------------|--|
| Honeywell 102 COLUMBIA RD. BOX 2105 MORRISTOWN, NJ 07862 | MACTEC | GROUNDWATER SAMPLING DATA RECORD ALLIED CHEMICAL/IRON TON CORE FACILITY IRONTON, OHIO SITE NO. 35024 3283051221/2200.3 |
|---|---------------|--|

APPENDIX B
ANALYTICAL DATA SHEETS



A FULL SERVICE ENVIRONMENTAL LABORATORY

November 28, 2006

Mr. Patrick Holmes
OMI/Ironton
3329 South Third Street
Ironton, OH 45638

PROJECT: IRONTON - SOUTH POINT - OCTOBER 2006
Submission #: R2634493


Dear Mr. Holmes

Enclosed are the analytical results of the analyses requested. All data has been reviewed prior to report submission. Should you have any questions please contact me at (585) 288-5380.

Thank you for letting us provide this service.

Sincerely,

COLUMBIA ANALYTICAL SERVICES



Carlton Beechler
Project Chemist

Enc.



1 Mustard ST.
Suite 250
Rochester, NY 14609
(585) 288-5380

THIS IS AN ANALYTICAL TEST REPORT FOR:

Client : OMI/Ironton
Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006
Lab Submission # : R2634493
Project Manager : Carlton Beechler
Reported : 11/28/06

Report Contains a total of 1146 pages

The results reported herein relate only to the samples received by the laboratory. This report may not be reproduced except in full, without the approval of Columbia Analytical Services.

This package has been reviewed by Columbia Analytical Services' QA Department/Laboratory Director to comply with NELAC standards prior to report submittal. *Michael E. Perry*

SDG NARRATIVE

COLUMBIA ANALYTICAL SERVICES, INC.

Client: OMI/Ironton
Project: Ironton - Southpoint - October 2006
Sample Matrix: Water

Service Request No.: R2634493
Date Received: 10/25-26/06

CASE NARRATIVE

All analyses were performed consistent with the quality assurance program of Columbia Analytical Services, Inc. (CAS). This report contains analytical results for samples designated for Tier IV, CLP deliverables. When appropriate to the method, method blank results have been reported with each analytical test.

Sample Receipt

Nineteen water samples were received for analysis at Columbia Analytical Services on 10/25-26/06. The samples were received in good condition and consistent with the accompanying chain of custody form. The samples were stored in a refrigerator between 1°C and 6°C upon receipt at the laboratory.


General Chemistry Parameters

No analytical or quality control problems were encountered during analysis.

Total Metals

No analytical or quality control problems were encountered during analysis.

Approved by



Date

12/1/06

SDG #: 950030
 SUBMISSION R2634493
 CLIENT: OMI/Ironton
 CLIENT REP: Carlton Beechler
 PROJECT: Ironton - South Point - OC
 BATCH COMPLETE: yes
 DISKETTE REQUESTED: Y_X_N
 DATE: 10/26/06
 CUSTODY SEAL: PRESENT/ABSENT:
 CHAIN OF CUSTODY: PRESENT/ABSENT:
 DATE REVISED:
 DATE DUE: 11/20/06
 PROTOCOL: SW846
 SHIPPING No.:

| CAS JOB # | CLIENT/EPA ID | MATRIX | REQUESTED PARAMETERS | DATE SAMPLED | DATE RECEIVED | pH (SOLIDS) | % SOLIDS | REMARKS | SAMPLE CONDITION |
|-----------|---------------|--------|--------------------------------------|--------------|---------------|-------------|----------|---------|------------------|
| 950030 | SPMW-01 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/24/2006 | 10/25/2006 | | | | |
| 950031 | SPMW-05 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/24/2006 | 10/25/2006 | | | | |
| 950032 | SPMW-10R | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/24/2006 | 10/25/2006 | | | | |
| 950033 | SPMW-02 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/24/2006 | 10/25/2006 | | | | |
| 950034 | SPMW-06R | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/24/2006 | 10/25/2006 | | | | |
| 950035 | SPMW-08 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/24/2006 | 10/25/2006 | | | | |
| 950036 | SPMW-09 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/24/2006 | 10/25/2006 | | | | |
| 950466 | SPMW-03 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| 950467 | SPMW-07 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| 950468 | SPMW-07 DUP | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| 950469 | SPOB-34 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| 950470 | SPOB-12R2 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| 950471 | SPMW-11R2 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| 950472 | SPMW-12 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| 950473 | SPMW-13 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| 950474 | SPMW-04 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| 950475 | SPIS-24 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| 950476 | SPIS-24 DUP | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| 950477 | SPIS-23 | WATER | As, Be, Cd, Cu, Mn, Ni, NH3, NO3/NO2 | 10/25/2006 | 10/26/2006 | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |



INORGANIC QUALIFIERS

C (Concentration) qualifier –

- B - if the reported value was obtained from a reading that was less than the Contract Required Detection Limit (CRDL) but was greater than or equal to the Instrument Detection Limit (IDL). This qualifier may also be used to indicate that there was contamination above the reporting limit in the associated blank. See Narrative for details.
- U - if the analyte was analyzed for, but not detected

Q qualifier - Specified entries and their meanings are as follows:

- D - Spike was diluted out
- E - The reported value is estimated because the serial dilution did not meet criteria.
- J - Estimated Value
- M - Duplicate injection precision not met.
- N - Spiked sample recovery not within control limits.
- S - The reported value was determined by the Method of Standard Additions (MSA).
- W - Post-digestion spike for Furnace AA Analysis is out of control limits (85-115), while sample absorbance is less than 50% of spike absorbance.
- * - Duplicate analysis not within control limits.
- + - Correlation coefficient for the MSA is less than 0.995.

M (Method) qualifier:

- "P" for ICP
- "A" for Flame AA
- "F" for Furnace AA
- "PM" for ICP when Microwave Digestion is used
- "AM" for Flame AA when Microwave Digestion is used
- "FM" for Furnace M when Microwave Digestion is used
- "CV" for Manual Cold Vapor AA
- "AV" for Automated Cold Vapor AA
- "AF" for Automated Cold Vapor Atomic Fluorescence Spectrometry
- "CA" for Midi-Distillation Spectrophotometric
- "AS" for Semi-Automated Spectrophotometric
- "C" for Manual Spectrophotometric
- "T" for Titrimetric
- " " where no data has been entered
- "NR" if the analyte is not required to be analyzed.

CAS/Rochester Lab ID # for State Certifications

NELAP Accredited
Delaware Accredited
Connecticut ID # PH0556
Florida ID # E87674
Illinois ID #200047
Maine ID #NY0032
Massachusetts ID # M-NY032
Navy Facilities Engineering Service Center Approved

Nebraska Accredited
New Jersey ID # NY004
New York ID # 10145
New Hampshire ID # 294100 A/B
Pennsylvania ID # 68-786
Rhode Island ID # 158
West Virginia ID # 292

CHAINS OF CUSTODY

INTERNAL CHAINS



CHAIN OF CUSTODY/LABORATORY ANALYSIS REQUEST FORM

One Mustard St., Suite 250 • Rochester, NY 14609-0859 • (585) 288-5380 • 800-695-7222 X11 • FAX (585) 288-8475

PAGE 1 OF 1

SR # _____
CAS Contact _____

| Project Name SOUTH POINT | | | Project Number | | | | | | |
|--|-------------------------------|----------------|---|--------|---|--|---|--|-----------------------------------|
| Project Manager Joe Davis | | | Report CC | | | | | | |
| Company/Address OMI INC. 3329 S. 3RD ST. Ironton, OH 4563 | | | ANALYSIS REQUESTED (Include Method Number and Container Preservative) | | | | | | |
| Phone # 740 532 9486 | | | FAX# | | | | | | |
| Sampler's Signature | | | Sampler's Printed Name | | | | | | |
| CLIENT SAMPLE ID | FOR OFFICE USE ONLY LAB ID | SAMPLING DATE | SAMPLING TIME | MATRIX | PRESERVATIVE | NUMBER OF CONTAINERS | ANALYSIS REQUESTED | | REMARKS/ ALTERNATE DESCRIPTION |
| | | | | | | | GCMS VOAS <input type="checkbox"/> CLP | GCMS SVOAS <input type="checkbox"/> CLP | |
| SPMW-01 | 950030 | 10-24-06 10:25 | | water | <input type="checkbox"/> 8260 <input type="checkbox"/> 624 <input type="checkbox"/> CLP | | <input type="checkbox"/> 8270 <input type="checkbox"/> 625 <input type="checkbox"/> CLP | | |
| SPMW-05 | 950031 | 10-24-06 11:10 | | water | <input type="checkbox"/> 8021 <input type="checkbox"/> 601/602 | | <input type="checkbox"/> 8082 <input type="checkbox"/> 608 <input type="checkbox"/> CLP | | |
| SPMW-10R | 950032 | 10-24-06 11:55 | | water | <input type="checkbox"/> 8081 <input type="checkbox"/> 608 <input type="checkbox"/> CLP | | <input type="checkbox"/> 8082 <input type="checkbox"/> 608 <input type="checkbox"/> CLP | | |
| SPMW-02 | 950033 | 10-24-06 13:20 | | water | <input type="checkbox"/> 8260 <input type="checkbox"/> 624 <input type="checkbox"/> CLP | | <input type="checkbox"/> 8270 <input type="checkbox"/> 625 <input type="checkbox"/> CLP | | |
| SPMW-06R | 950034 | 10-24-06 14:10 | | water | <input type="checkbox"/> 8021 <input type="checkbox"/> 601/602 | | <input type="checkbox"/> 8081 <input type="checkbox"/> 608 <input type="checkbox"/> CLP | | |
| SPMW-08 | 950035 | 10-24-06 14:50 | | water | <input type="checkbox"/> 8260 <input type="checkbox"/> 624 <input type="checkbox"/> CLP | | <input type="checkbox"/> 8270 <input type="checkbox"/> 625 <input type="checkbox"/> CLP | | |
| SPMW-09 | 950036 | 10-24-06 15:40 | | water | <input type="checkbox"/> 8021 <input type="checkbox"/> 601/602 | | <input type="checkbox"/> 8081 <input type="checkbox"/> 608 <input type="checkbox"/> CLP | | |
| | | | | | | | | | |
| SPECIAL INSTRUCTIONS/COMMENTS Metals | | | | | | TURNAROUND REQUIREMENTS <input type="checkbox"/> RUSH (SURCHARGES APPLY) 24 hr _____ 48 hr _____ 5 day _____ | | REPORT REQUIREMENTS <input type="checkbox"/> I. Results Only <input type="checkbox"/> II. Results + QC Summaries (LCS, DUP, MSMSD as required) <input type="checkbox"/> III. Results + QC and Calibration Summaries <input type="checkbox"/> IV. Data Validation Report with Raw Data <input type="checkbox"/> V. Specialized Forms / Custom Report | |
| See QAPP <input type="checkbox"/> | | | | | | REQUESTED FAX DATE | | INVOICE INFORMATION | |
| SAMPLE RECEIPT: CONDITION/COOLER TEMP: _____ | | | | | | REQUESTED REPORT DATE | | TO# | |
| RELINQUISHED BY <i>Rachel Adams</i> | | | | | | RELINQUISHED BY | | BILL TO: | |
| Signature | | | | | | Signature | | SUBMISSION #: 22634493 | |
| Printed Name | | | | | | Printed Name | | RECEIVED BY | |
| Firm | | | | | | Firm | | RECEIVED BY | |
| Date/Time | | | | | | Date/Time | | RECEIVED BY | |
| Date/Time | | | | | | Date/Time | | RECEIVED BY | |

Cooler Receipt And Preservation Check Form

Project/Client OMI Submission Number R2-34493

Cooler received on 10-25-06 by: ME COURIER: CAS UPS FEDEX VELOCITY CLIENT

1. Were custody seals on outside of cooler? YES NO
2. Were custody papers properly filled out (ink, signed, etc.)? YES NO
3. Did all bottles arrive in good condition (unbroken)? YES NO
4. Did any VOA vials have significant air bubbles? YES NO N/A
5. Were Ice or Ice packs present? YES NO
6. Where did the bottles originate? CAS/ROC, CLIENT
7. Temperature of cooler(s) upon receipt: 2⁹

Is the temperature within 0° - 6° C?: Yes Yes Yes Yes Yes
 If No, Explain Below No No No No No

Date/Time Temperatures Taken: 10-25-06 @ 9:42

Thermometer ID: 161 or IR GUN Reading From: Temp Blank or Sample Bottle

If out of Temperature, Client Approval to Run Samples _____
 PC Secondary Review: 9/25/06

Cooler Breakdown: Date: 10/25/06 by: RJ

1. Were all bottle labels complete (i.e. analysis, preservation, etc.)? YES NO
2. Did all bottle labels and tags agree with custody papers? YES NO
3. Were correct containers used for the tests indicated? YES NO
4. Air Samples: Cassettes / Tubes Intact Canisters Pressurized Tedlar® Bags Inflated N/A

Explain any discrepancies: _____

| | | YES | NO | Sample I.D. | Reagent | Vol. Added | Final pH |
|-------------------------|--------------------------------|-----|----|-------------|---------|------------|----------|
| pH | Reagent | | | | | | |
| ≥12 | NaOH | | | | | | |
| ∅ | HNO ₃ | ✓ | | | | | |
| ∅ | H ₂ SO ₄ | ✓ | | | | | |
| Residual Chlorine (+/-) | for TCN & Phenol | | | | | | |

YES = All samples OK NO = Samples were preserved at lab as listed PC OK to adjust pH _____

| | | |
|--|--|--|
| VOC Vial pH Verification (Tested after Analysis) Following Samples Exhibited pH > 2 | | |
| | | |
| | | |
| | | |

Other Comments:

PC Secondary Review: 9/11/06

BODY/LABORATORY ANALYSIS REQUEST FORM

SR # _____
CAS Contact _____

, NY 14609-0859 • (585) 288-5380 • 800-695-7222 x11 • FAX (585) 288-8475 PAGE 1 OF 2

| PRESERVATIVE | | ANALYSIS REQUESTED (Include Method Number and Container Preservative) | | PRESERVATIVE KEY | |
|--|--|--|---|--|--|
| NUMBER OF CONTAINERS | PREPRESERVATIVE | METALS, TOTAL (List in comments below) | METALS, DISSOLVED (List in comments below) | METALS, TOTAL 8082 <input type="checkbox"/> 608 <input type="checkbox"/> CLP | REMARKS/ ALTERNATE DESCRIPTION |
| GC/MS VOAS <input type="checkbox"/> CLP | GC/MS SVOAS <input type="checkbox"/> CLP | PCBs <input type="checkbox"/> 8081 <input type="checkbox"/> 608 <input type="checkbox"/> CLP | PESTICIDES <input type="checkbox"/> 8021 <input type="checkbox"/> 601/602 | GC VOAS <input type="checkbox"/> 8270 <input type="checkbox"/> 625 <input type="checkbox"/> CLP | Preservative Key 0. NONE 1. HCL 2. HNO ₃ 3. H ₂ SO ₄ 4. NaOH 5. Zn. Acetate 6. MeOH 7. NaHSO ₄ 8. Other _____ |
| SPMw-03 | 950466 | 10-25-06 0855 | water | X | |
| SPMw-07 | 950467 | 10-25-06 0945 | water | X | |
| SPMw-07 Dup | 950468 | 10-25-06 0945 | water | X | |
| SPOB-34 | 950469 | 10-25-06 1035 | water | X | |
| SPOB-12R2 | 950470 | 10-25-06 1105 | water | X | |
| SPMw-11R2 | 950471 | 10-25-06 1140 | water | X | |
| SPMw-12 | 950472 | 10-25-06 1300 | water | X | |
| SPMw-13 | 950473 | 10-25-06 1335 | water | X | |
| SPMw-04 | 990474 | 10-25-06 1410 | water | X | |
| SPECIAL INSTRUCTIONS/COMMENTS Metals | | TURNAROUND REQUIREMENTS RUSH (SURCHARGES APPLY) 24 hr _____ 48 hr _____ 5 day _____ <input checked="" type="checkbox"/> STANDARD REQUESTED FAX DATE _____ REQUESTED REPORT DATE _____ | | REPORT REQUIREMENTS I. Results Only _____ II. Results + OC Summaries (LCS, DUP, MS/MSD as required) _____ III. Results + OC and Calibration Summaries _____ IV. Data Validation Report with Raw Data _____ V. Specialized Forms / Custom Report _____ Edata Yes _____ No _____ | |
| CUSTODY SEALS: Y N | | RECEIVED BY | | RECEIVED BY | |
| RELINQUISHED BY | | RELINQUISHED BY | | RELINQUISHED BY | |
| Signature: <i>Richard Hobbs</i> | | Signature: _____ | | Signature: _____ | |
| Printed Name: <i>Richard Hobbs</i> | | Printed Name: _____ | | Printed Name: _____ | |
| Firm: <i>CAS</i> | | Firm: _____ | | Firm: _____ | |
| Date/Time: <i>10-25-06 0920</i> | | Date/Time: _____ | | Date/Time: _____ | |



CHAIN OF CUSTODY/LABORATORY ANALYSIS REQUEST FORM

SR #

2 OF 2

PAGE

One Mustard St., Suite 250 • Rochester, NY 14609-0859 • (585) 288-5380 • 800-695-7222 x11 • FAX (585) 288-8475

CAS Contact

| PROJECT INFORMATION | | ANALYSIS REQUESTED (Include Method Number and Container Preservative) | | | | | REMARKS/ ALTERNATE DESCRIPTION | | | | | | |
|-------------------------------|----------------|---|--------------|---|----------------|---|--------------------------------|--|------|--------------------------------------|-------------------|------------------------|--|
| Project Name | Project Number | Report CC | PRESERVATIVE | NUMBER OF CONTAINERS | GC/MS VOAs CLP | GC/MS SVOAs CLP | GC VOAs | PESTICIDES | PCBs | METALS, TOTAL | METALS, DISSOLVED | OTHER | |
| South Point | | Joe Davis | | 0-1F / Honeywell | | 3329 S. 3rd ST., | | FRONTON, OH 45638 | | FAX# | | Sampler's Printed Name | |
| (740) 532-9486 | | Sampler's Signature | | LAB ID | | DATE | | SAMPLING TIME | | MATRIX | | PRESERVATIVE KEY | |
| FOR OFFICE USE ONLY | | DATE | | TIME | | MATRIX | | | | | | | |
| CLIENT SAMPLE ID | | 950475 | | 10-25-04 | | 1405 | | water | | | | | |
| SPLS-24 Dup | | 950476 | | 10-25-04 | | 1425 | | water | | | | | |
| SPLS-23, m.s., m.s.O | | 950477 | | 10-25-04 | | 1445 | | water | | | | | |
| SPECIAL INSTRUCTIONS/COMMENTS | | Metals | | | | | | | | | | | |
| TURNAROUND REQUIREMENTS | | RUSH (SURCHARGES APPLY) | | 24 hr 48 hr 5 day | | STANDARD | | | | | | | |
| REPORT REQUIREMENTS | | I. Results Only | | II. Results + QC Summaries (LCS, DUP, MS/MSD as required) | | III. Results + QC and Calibration Summaries | | IV. Data Validation Report with Raw Data | | V. Specialized Forms / Custom Report | | SUBMISSION #: 2763493 | |
| INVOICE INFORMATION | | PO# | | BILL TO: | | | | | | | | RECEIVED BY | |
| RECEIVED BY | | Signature | | Printed Name | | Firm | | Date/Time | | | | | |
| RECEIVED BY | | Signature | | Printed Name | | Firm | | Date/Time | | | | | |
| RECEIVED BY | | Signature | | Printed Name | | Firm | | Date/Time | | | | | |
| RECEIVED BY | | Signature | | Printed Name | | Firm | | Date/Time | | | | | |
| RECEIVED BY | | Signature | | Printed Name | | Firm | | Date/Time | | | | | |

Cooler Receipt And Preservation Check Form

Project/Client OMI Submission Number RQ-34493

Cooler received on 10/26/06 by: FEDEX COURIER: CAS UPS FEDEX VELOCITY CLIENT

1. Were custody seals on outside of cooler? YES NO
2. Were custody papers properly filled out (ink, signed, etc.)? YES NO
3. Did all bottles arrive in good condition (unbroken)? YES NO
4. Did any VOA vials have significant air bubbles? YES NO N/A
5. Were Ice or Ice packs present? YES NO
6. Where did the bottles originate? CAS/ROC, CLIENT
7. Temperature of cooler(s) upon receipt: 3°

Is the temperature within 0° - 6° C?: Yes Yes Yes Yes Yes
 If No, Explain Below No No No No No

Date/Time Temperatures Taken: 10/26/06 @ 0940
 Thermometer ID: 161 or IR GUN Reading From: Temp Blank or Sample Bottle

If out of Temperature, Client Approval to Run Samples _____
 PC Secondary Review: C 10/25/06

Cooler Breakdown: Date: 10-27-06 by: HE

1. Were all bottle labels complete (i.e. analysis, preservation, etc.)? YES NO
 2. Did all bottle labels and tags agree with custody papers? YES NO
 3. Were correct containers used for the tests indicated? YES NO
 4. Air Samples: Cassettes / Tubes Intact Canisters Pressurized Tedlar® Bags Inflated N/A
- Explain any discrepancies: _____

| | | YES | NO | Sample I.D. | Reagent | Vol. Added | Final pH |
|-------------------------|--------------------------------|-----|----|-------------|---------|------------|----------|
| pH | Reagent | | | | | | |
| ≥12 | NaOH | | | | | | |
| ≤2 | HNO ₃ | ✓ | | | | | |
| ≤2 | H ₂ SO ₄ | ✓ | | | | | |
| Residual Chlorine (+/-) | for TCN & Phenol | | | | | | |

YES = All samples OK NO = Samples were preserved at lab as listed PC OK to adjust pH _____

| | | |
|--|--|--|
| VOC Vial pH Verification (Tested after Analysis) Following Samples Exhibited pH > 2 | | |
| | | |
| | | |
| | | |

Other Comments: _____

PC Secondary Review: C 11/1/06

Chain of Custody

Submission: R2634493 **Client:** OMI/Ironton

Lab ID: 950030 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/25/2006

Container: 9500301

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|--------|-------------------|------------------|---------|--------------------------|
| 10/25/06 15:26 | rjones | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |

Container: 9500302

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/25/06 15:25 | rjones | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:50 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/22/06 7:40 | gesmeria | Wet Chemistry | LTS | Storage | <input type="checkbox"/> |

Lab ID: 950031 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/25/2006

Container: 9500311

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|--------|-------------------|------------------|---------|--------------------------|
| 10/25/06 15:26 | rjones | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |

Container: 9500312

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/25/06 15:25 | rjones | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:50 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/22/06 7:40 | gesmeria | Wet Chemistry | LTS | Storage | <input type="checkbox"/> |

Chain of Custody

Submission: R2634493 **Client:** OMI/Ironton

Lab ID: 950032 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/25/2006

Container: 9500321

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|--------|-------------------|------------------|---------|--------------------------|
| 10/25/06 15:26 | rjones | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |

Container: 9500322

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/25/06 15:25 | rjones | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:50 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/22/06 7:40 | gesmeria | Wet Chemistry | LTS | Storage | <input type="checkbox"/> |

Lab ID: 950033 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/25/2006

Container: 9500331

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|--------|-------------------|------------------|---------|--------------------------|
| 10/25/06 15:26 | rjones | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |

Container: 9500332

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/25/06 15:25 | rjones | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:50 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/22/06 7:40 | gesmeria | Wet Chemistry | LTS | Storage | <input type="checkbox"/> |

Chain of Custody

Submission: R2634493 **Client:** OMI/Ironton

Lab ID: 950034 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/25/2006

Container: 9500341

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|--------|-------------------|------------------|---------|--------------------------|
| 10/25/06 15:26 | rjones | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |

Container: 9500342

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/25/06 15:25 | rjones | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:50 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/22/06 7:40 | gesmeria | Wet Chemistry | LTS | Storage | <input type="checkbox"/> |

Lab ID: 950035 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/25/2006

Container: 9500351

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|--------|-------------------|------------------|---------|--------------------------|
| 10/25/06 15:26 | rjones | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |

Container: 9500352

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/25/06 15:26 | rjones | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:50 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/22/06 7:40 | gesmeria | Wet Chemistry | LTS | Storage | <input type="checkbox"/> |

Chain of Custody

Submission: R2634493 **Client:** OMI/Ironton

Lab ID: 950036 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/25/2006

Container: 9500361

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|--------|-------------------|------------------|---------|--------------------------|
| 10/25/06 15:26 | rjones | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |

Container: 9500362

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/25/06 15:26 | rjones | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:50 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/22/06 7:40 | gesmeria | Wet Chemistry | LTS | Storage | <input type="checkbox"/> |

Lab ID: 950466 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504661

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:50 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504662

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:16 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

Chain of Custody

Submission: R2634493 **Client:** OMI/Ironton

Lab ID: 950467 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504671

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:50 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504672

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:16 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

Lab ID: 950468 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504681

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:51 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504682

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:16 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

Chain of Custody

Submission: R2634493 **Client:** OMI/Ironton

Lab ID: 950469 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504691

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:51 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504692

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:23 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

Lab ID: 950470 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504701

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:51 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504702

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:23 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

Chain of Custody

Submission: R2634493 **Client:** OMI/Ironton

Lab ID: 950471 **Matrix** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504711

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:51 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504712

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:23 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

Lab ID: 950472 **Matrix** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504721

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:51 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504722

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:23 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

Chain of Custody

Submission: R2634493 **Client:** OMI/Ironton

Lab ID: 950473 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504731

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:51 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504732

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:23 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

Lab ID: 950474 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504741

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:51 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504742

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:23 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

Chain of Custody

Submission: R2634493 **Client:** OMI/Ironton

Lab ID: 950475 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504751

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:51 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:15 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504752

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:23 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

Lab ID: 950476 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504761

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:51 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:16 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504762

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:23 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

Chain of Custody

Submission: R2634493 **Client:** OMI/Ironton

Lab ID: 950477 **Matrix:** WATER

Received into CAS-Rochester Custody: 10/26/2006

Container: 9504771

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/01/06 8:48 | nmead | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/01/06 13:30 | nmead | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |
| 11/07/06 8:51 | splace | Wet Chemistry | Cooler 2 | Analysis | <input type="checkbox"/> |
| 11/07/06 10:16 | splace | Wet Chemistry | Cooler 2 | Storage | <input type="checkbox"/> |

Container: 9504772

| Date of Custody | User | Dept | Storage Location | Purpose | Empty |
|-----------------|----------|-------------------|------------------|----------|--------------------------|
| 10/27/06 15:52 | gesmeria | Sample Management | Ambient 1 | Storage | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Analysis | <input type="checkbox"/> |
| 10/31/06 13:12 | cwoods | Metals | Ambient 1 | Storage | <input type="checkbox"/> |
| 11/22/06 13:23 | cwoods | Metals | LTS | Storage | <input type="checkbox"/> |

METALS DATA


METALS
COVER PAGE - INORGANIC ANALYSIS DATA PACKAGE

Contract: r2634493 SDG No.: 950030
Lab Code: _____ Case No.: _____ SAS No.: _____
SOW No.: SW846 CLP-M

| <u>Sample ID.</u> | <u>Lab Sample No.</u> |
|-------------------|-----------------------|
| SPMW-01 | 950030 |
| SPMW-05 | 950031 |
| SPMW-10R | 950032 |
| SPMW-02 | 950033 |
| SPMW-06R | 950034 |
| SPMW-08 | 950035 |
| SPMW-09 | 950036 |
| SPMW-03 | 950466 |
| SPMW-07 | 950467 |
| SPMW-07 DUP | 950468 |
| SPOB-34 | 950469 |
| SPOB-12R2 | 950470 |
| SPMW-11R2 | 950471 |
| SPMW-12 | 950472 |
| SPMW-13 | 950473 |
| SPMW-04 | 950474 |
| SPIS-24 | 950475 |
| SPIS-24 DUP | 950476 |
| SPIS-23 | 950477 |
| SPIS-23D | 950477D |
| SPIS-23S | 950477S |

Were ICP interelement corrections applied? Yes/No YES
Were ICP background corrections applied? Yes/No YES
If yes-were raw data generated before Yes/No NO
application of background corrections?

Comments: See Attached Case Narrative

Signature:  Name: Michael Perry

Date: 12/1/06 Title: Laboratory Director

METALS

-1-

INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPIS-23

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950477

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 2.1 | | | MS |
| 7440-41-7 | Beryllium | 5.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 1.0 | U | | MS |
| 7439-96-5 | Manganese | 266 | | | MS |
| 7440-02-0 | Nickel | 8.8 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPIS-24

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950475

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.2 | | | MS |
| 7440-41-7 | Beryllium | 1.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 23.9 | | | MS |
| 7439-96-5 | Manganese | 371 | | | MS |
| 7440-02-0 | Nickel | 12.1 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPIS-24 DUP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950476

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.2 | | | MS |
| 7440-41-7 | Beryllium | 1.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 17.5 | | | MS |
| 7439-96-5 | Manganese | 356 | | | MS |
| 7440-02-0 | Nickel | 11.1 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-01

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950030

Level (low/med): LOW Date Received: 10/25/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | U | | MS |
| 7440-41-7 | Beryllium | 5.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 1.0 | U | | MS |
| 7439-96-5 | Manganese | 16.6 | | | MS |
| 7440-02-0 | Nickel | 7.1 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-02

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950033

Level (low/med): LOW Date Received: 10/25/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | U | | MS |
| 7440-41-7 | Beryllium | 1.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 1.2 | | | MS |
| 7439-96-5 | Manganese | 153 | | | MS |
| 7440-02-0 | Nickel | 4.8 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-03

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950466

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | U | | MS |
| 7440-41-7 | Beryllium | 1.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 1.0 | U | | MS |
| 7439-96-5 | Manganese | 58.1 | | | MS |
| 7440-02-0 | Nickel | 5.2 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS

-1-

INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-04

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950474

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | U | | MS |
| 7440-41-7 | Beryllium | 5.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 1.3 | | | MS |
| 7439-96-5 | Manganese | 22.8 | | | MS |
| 7440-02-0 | Nickel | 6.0 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-05

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950031

Level (low/med): LOW Date Received: 10/25/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | | | MS |
| 7440-41-7 | Beryllium | 5.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 3.0 | | | MS |
| 7439-96-5 | Manganese | 43.9 | | | MS |
| 7440-02-0 | Nickel | 23.7 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-06R

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950034

Level (low/med): LOW Date Received: 10/25/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 4.4 | | | MS |
| 7440-41-7 | Beryllium | 5.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 4.0 | | | MS |
| 7439-96-5 | Manganese | 3840 | | | MS |
| 7440-02-0 | Nickel | 37.2 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-07

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950467

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | U | | MS |
| 7440-41-7 | Beryllium | 1.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 2.3 | | | MS |
| 7439-96-5 | Manganese | 407 | | | MS |
| 7440-02-0 | Nickel | 8.0 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-07 DUP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950468

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | U | | MS |
| 7440-41-7 | Beryllium | 1.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 3.8 | | | MS |
| 7439-96-5 | Manganese | 391 | | | MS |
| 7440-02-0 | Nickel | 8.2 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS

-1-

INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-08

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950035

Level (low/med): LOW Date Received: 10/25/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | U | | MS |
| 7440-41-7 | Beryllium | 1.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 1.3 | | | MS |
| 7439-96-5 | Manganese | 1350 | | | MS |
| 7440-02-0 | Nickel | 12.2 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-09

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950036

Level (low/med): LOW Date Received: 10/25/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | U | | MS |
| 7440-41-7 | Beryllium | 5.5 | | | MS |
| 7440-43-9 | Cadmium | 11.0 | | | MS |
| 7440-50-8 | Copper | 2520 | | | MS |
| 7439-96-5 | Manganese | 15200 | | | MS |
| 7440-02-0 | Nickel | 682 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-10R

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950032

Level (low/med): LOW Date Received: 10/25/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.8 | | | MS |
| 7440-41-7 | Beryllium | 5.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.1 | | | MS |
| 7440-50-8 | Copper | 5.2 | | | MS |
| 7439-96-5 | Manganese | 585 | | | MS |
| 7440-02-0 | Nickel | 72.7 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-11R2

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950471

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | U | | MS |
| 7440-41-7 | Beryllium | 5.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 1.7 | | | MS |
| 7439-96-5 | Manganese | 56.2 | | | MS |
| 7440-02-0 | Nickel | 19.6 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-12

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950472

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | | | MS |
| 7440-41-7 | Beryllium | 1.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 1.6 | | | MS |
| 7439-96-5 | Manganese | 73.5 | | | MS |
| 7440-02-0 | Nickel | 11.8 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPMW-13

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950473

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | U | | MS |
| 7440-41-7 | Beryllium | 1.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 1.0 | U | | MS |
| 7439-96-5 | Manganese | 246 | | | MS |
| 7440-02-0 | Nickel | 3.3 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPOB-12R2

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950470

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 1.0 | U | | MS |
| 7440-41-7 | Beryllium | 1.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 2.0 | | | MS |
| 7439-96-5 | Manganese | 78.9 | | | MS |
| 7440-02-0 | Nickel | 17.3 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS
-1-
INORGANIC ANALYSIS DATA SHEET

SAMPLE NO.

SPOB-34

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Lab Sample ID: 950469

Level (low/med): LOW Date Received: 10/26/06

Concentration Units (ug/L or mg/kg dry weight): UG/L

| CAS No. | Analyte | Concentration | C | Q | M |
|-----------|-----------|---------------|---|---|----|
| 7440-38-2 | Arsenic | 10.4 | | | MS |
| 7440-41-7 | Beryllium | 1.0 | U | | MS |
| 7440-43-9 | Cadmium | 1.0 | U | | MS |
| 7440-50-8 | Copper | 1.1 | | | MS |
| 7439-96-5 | Manganese | 409 | | | MS |
| 7440-02-0 | Nickel | 10.7 | | | MS |

Color Before: YELLOW Clarity Before: CLEAR Texture: _____

Color After: COLORLESS Clarity After: CLEAR Artifacts: _____

Comments: _____

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|---------|---------------------|-------|-------|------------------------|-------|-------|-------|-----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Arsenic | 50 | 50 | 100 | 50 | 50 | 100 | 50 | 100 | MS |
| Cadmium | 50 | 49 | 98 | 50 | 53 | 106 | 53 | 106 | MS |
| Nickel | 50 | 50 | 100 | 50 | 51 | 102 | 51 | 102 | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|---------|---------------------|-------|-------|------------------------|-------|-------|-------|-----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Arsenic | | | | 50 | 49 | 98 | 49 | 98 | MS |
| Cadmium | | | | 50 | 52 | 104 | 51 | 102 | MS |
| Nickel | | | | 50 | 50 | 100 | 49 | 98 | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|---------|---------------------|-------|-------|------------------------|-------|-------|-------|-----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Arsenic | | | | 50 | 50 | 100 | 48 | 96 | MS |
| Cadmium | | | | 50 | 52 | 104 | 52 | 104 | MS |
| Nickel | | | | 50 | 53 | 106 | 53 | 106 | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|---------|---------------------|-------|-------|------------------------|-------|-------|-------|---|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Arsenic | | | | 50 | 50 | 100 | | | MS |
| Cadmium | | | | 50 | 50 | 100 | | | MS |
| Nickel | | | | 50 | 53 | 106 | | | MS |

Comments:

METALS
-2A-
INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Beryllium | 50 | 46 | 92 | 50 | 49 | 98 | 49 | 98 | MS |
| Cadmium | 50 | 49 | 98 | 50 | 50 | 100 | 49 | 98 | MS |
| Copper | 50 | 50 | 100 | 50 | 51 | 102 | 48 | 96 | MS |
| Manganese | 50 | 49 | 98 | 50 | 48 | 96 | 49 | 98 | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|-----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Beryllium | | | | 50 | 51 | 102 | 50 | 100 | MS |
| Cadmium | | | | 50 | 51 | 102 | 52 | 104 | MS |
| Copper | | | | 50 | 49 | 98 | 50 | 100 | MS |
| Manganese | | | | 50 | 49 | 98 | 50 | 100 | MS |

Comments:

METALS
-2A-
INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|---|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Beryllium | | | | 50 | 50 | 100 | | | MS |
| Cadmium | | | | 50 | 52 | 104 | | | MS |
| Copper | | | | 50 | 50 | 100 | | | MS |
| Manganese | | | | 50 | 50 | 100 | | | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|-----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Beryllium | 50 | 49 | 98 | 50 | 47 | 94 | 51 | 102 | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Beryllium | | | | 50 | 52 | 104 | 49 | 98 | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|-----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Arsenic | 50 | 50 | 100 | 50 | 53 | 106 | 53 | 106 | MS |
| Beryllium | 50 | 49 | 98 | 50 | 52 | 104 | 52 | 104 | MS |
| Cadmium | 50 | 50 | 100 | 50 | 51 | 102 | 52 | 104 | MS |
| Manganese | 50 | 53 | 106 | 50 | 54 | 108 | 54 | 108 | MS |
| Nickel | 50 | 52 | 104 | 50 | 53 | 106 | 53 | 106 | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|-----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Arsenic | | | | 50 | 52 | 104 | 50 | 100 | MS |
| Beryllium | | | | 50 | 51 | 102 | 50 | 100 | MS |
| Cadmium | | | | 50 | 51 | 102 | 50 | 100 | MS |
| Manganese | | | | 50 | 52 | 104 | 52 | 104 | MS |
| Nickel | | | | 50 | 51 | 102 | 50 | 100 | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|-----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Arsenic | | | | 50 | 53 | 106 | 53 | 106 | MS |
| Beryllium | | | | 50 | 53 | 106 | 53 | 106 | MS |
| Cadmium | | | | 50 | 52 | 104 | 52 | 104 | MS |
| Manganese | | | | 50 | 54 | 108 | 54 | 108 | MS |
| Nickel | | | | 50 | 54 | 108 | 55 | 110 | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|---|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Arsenic | | | | 50 | 52 | 104 | | | MS |
| Beryllium | | | | 50 | 52 | 104 | | | MS |
| Cadmium | | | | 50 | 53 | 106 | | | MS |
| Manganese | | | | 50 | 55 | 110 | | | MS |
| Nickel | | | | 50 | 54 | 108 | | | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|-----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Copper | 50 | 54 | 108 | 50 | 52 | 104 | 52 | 104 | MS |
| Manganese | 50 | 53 | 106 | 50 | 53 | 106 | 52 | 104 | MS |

Comments:

METALS
-2A-
INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|-----|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Copper | | | | 50 | 51 | 102 | 51 | 102 | MS |
| Manganese | | | | 50 | 53 | 106 | 52 | 104 | MS |

Comments:

METALS

-2A-

INITIAL AND CONTINUING CALIBRATION VERIFICATION

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Initial Calibration Source: ACCUSTANDARD

Continuing Calibration Source: ACCUSTANDARD

Concentration Units: ug/L

| Analyte | Initial Calibration | | | Continuing Calibration | | | | M | |
|-----------|---------------------|-------|-------|------------------------|-------|-------|-------|---|-------|
| | True | Found | %R(1) | True | Found | %R(1) | Found | | %R(1) |
| Copper | | | | 50 | 51 | 102 | | | MS |
| Manganese | | | | 50 | 51 | 102 | | | MS |

Comments:

METALS
-2B-
CRDL STANDARD FOR AA AND ICP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

AA CRDL Standard Source: _____

ICP CRDL Standard Source: INORGANIC VENTURES

Concentration Units: ug/L

| Analyte | CRDL Standard for AA | | | CRDL Standard for ICP | | | | |
|---------|----------------------|-------|----|-----------------------|-------|-----|-------|-----|
| | True | Found | %R | Initial | | | Final | |
| | | | | True | Found | %R | Found | %R |
| Arsenic | | | | 1.0 | 1.02 | 102 | 1.01 | 101 |
| Cadmium | | | | 1.0 | 1.02 | 102 | 1.04 | 104 |
| Nickel | | | | 1.0 | 1.09 | 109 | 1.07 | 107 |

Comments:

METALS
-2B-
CRDL STANDARD FOR AA AND ICP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

AA CRDL Standard Source: _____

ICP CRDL Standard Source: INORGANIC VENTURES

Concentration Units: ug/L

| Analyte | CRDL Standard for AA | | | CRDL Standard for ICP | | | | |
|---------|----------------------|-------|----|-----------------------|-------|----|-------|-----|
| | True | Found | %R | Initial | | | Final | |
| | | | | True | Found | %R | Found | %R |
| Arsenic | | | | 1.0 | | | 1.01 | 101 |
| Cadmium | | | | 1.0 | | | 1.06 | 106 |
| Nickel | | | | 1.0 | | | 1.08 | 108 |

Comments:

METALS
-2B-
CRDL STANDARD FOR AA AND ICP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

AA CRDL Standard Source: _____

ICP CRDL Standard Source: INORGANIC VENTURES

Concentration Units: ug/L

| Analyte | CRDL Standard for AA | | | CRDL Standard for ICP | | | | |
|---------|----------------------|-------|----|-----------------------|-------|----|-------|-----|
| | True | Found | %R | Initial | | | Final | |
| | | | | True | Found | %R | Found | %R |
| Arsenic | | | | 1.0 | | | 1.00 | 100 |
| Cadmium | | | | 1.0 | | | 1.00 | 100 |
| Nickel | | | | 1.0 | | | 1.13 | 113 |

Comments:

METALS
-2B-
CRDL STANDARD FOR AA AND ICP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

AA CRDL Standard Source: _____

ICP CRDL Standard Source: INORGANIC VENTURES

Concentration Units: ug/L

| Analyte | CRDL Standard for AA | | | CRDL Standard for ICP | | | | |
|-----------|----------------------|-------|----|-----------------------|-------|-----|-------|-----|
| | True | Found | %R | Initial | | | Final | |
| | | | | True | Found | %R | Found | %R |
| Beryllium | | | | 1.0 | 0.99 | 99 | 1.01 | 101 |
| Cadmium | | | | 1.0 | 0.98 | 98 | 1.06 | 106 |
| Copper | | | | 1.0 | 1.03 | 103 | 1.03 | 103 |
| Manganese | | | | 1.0 | 1.01 | 101 | 1.06 | 106 |

Comments:

METALS
-2B-
CRDL STANDARD FOR AA AND ICP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

AA CRDL Standard Source: _____

ICP CRDL Standard Source: INORGANIC VENTURES

Concentration Units: ug/L

| Analyte | CRDL Standard for AA | | | CRDL Standard for ICP | | | | |
|-----------|----------------------|-------|----|-----------------------|-------|-----|-------|-----|
| | True | Found | %R | Initial | | | Final | |
| | | | | True | Found | %R | Found | %R |
| Beryllium | | | | 1.0 | 1.05 | 105 | 1.10 | 110 |

Comments:

METALS
-2B-
CRDL STANDARD FOR AA AND ICP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

AA CRDL Standard Source: _____

ICP CRDL Standard Source: INORGANIC VENTURES

Concentration Units: ug/L

| Analyte | CRDL Standard for AA | | | CRDL Standard for ICP | | | | |
|-----------|----------------------|-------|----|-----------------------|-------|-----|-------|-----|
| | True | Found | %R | Initial | | | Final | |
| | | | | True | Found | %R | Found | %R |
| Arsenic | | | | 1.0 | 1.08 | 108 | 1.05 | 105 |
| Beryllium | | | | 1.0 | 1.02 | 102 | 1.04 | 104 |
| Cadmium | | | | 1.0 | 1.01 | 101 | 0.99 | 99 |
| Manganese | | | | 1.0 | 1.15 | 115 | 1.12 | 112 |
| Nickel | | | | 1.0 | 0.98 | 98 | 0.91 | 91 |

Comments:

METALS
-2B-
CRDL STANDARD FOR AA AND ICP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

AA CRDL Standard Source: _____

ICP CRDL Standard Source: INORGANIC VENTURES

Concentration Units: ug/L

| Analyte | CRDL Standard for AA | | | CRDL Standard for ICP | | | | |
|-----------|----------------------|-------|----|-----------------------|-------|----|-------|-----|
| | True | Found | %R | Initial | | | Final | |
| | | | | True | Found | %R | Found | %R |
| Arsenic | | | | 1.0 | | | 1.06 | 106 |
| Beryllium | | | | 1.0 | | | 1.05 | 105 |
| Cadmium | | | | 1.0 | | | 1.02 | 102 |
| Manganese | | | | 1.0 | | | 1.10 | 110 |
| Nickel | | | | 1.0 | | | 0.93 | 93 |

Comments:

METALS
-2B-
CRDL STANDARD FOR AA AND ICP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

AA CRDL Standard Source: _____

ICP CRDL Standard Source: INORGANIC VENTURES

Concentration Units: ug/L

| Analyte | CRDL Standard for AA | | | CRDL Standard for ICP | | | | |
|-----------|----------------------|-------|----|-----------------------|-------|----|-------|-----|
| | True | Found | %R | Initial | | | Final | |
| | | | | True | Found | %R | Found | %R |
| Arsenic | | | | 1.0 | | | 1.04 | 104 |
| Beryllium | | | | 1.0 | | | 1.01 | 101 |
| Cadmium | | | | 1.0 | | | 1.02 | 102 |
| Manganese | | | | 1.0 | | | 1.10 | 110 |
| Nickel | | | | 1.0 | | | 0.95 | 95 |

Comments:

METALS
-2B-
CRDL STANDARD FOR AA AND ICP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

AA CRDL Standard Source: _____

ICP CRDL Standard Source: INORGANIC VENTURES

Concentration Units: ug/L

| Analyte | CRDL Standard for AA | | | CRDL Standard for ICP | | | | |
|-----------|----------------------|-------|----|-----------------------|-------|-----|-------|-----|
| | True | Found | %R | Initial | | | Final | |
| | | | | True | Found | %R | Found | %R |
| Copper | | | | 1.0 | 1.03 | 103 | 1.05 | 105 |
| Manganese | | | | 1.0 | 1.11 | 111 | 1.07 | 107 |

Comments:

METALS
-2B-
CRDL STANDARD FOR AA AND ICP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

AA CRDL Standard Source: _____

ICP CRDL Standard Source: INORGANIC VENTURES

Concentration Units: ug/L

| Analyte | CRDL Standard for AA | | | CRDL Standard for ICP | | | | |
|-----------|----------------------|-------|----|-----------------------|-------|----|-------|-----|
| | True | Found | %R | Initial | | | Final | |
| | | | | True | Found | %R | Found | %R |
| Copper | | | | 1.0 | | | 1.00 | 100 |
| Manganese | | | | 1.0 | | | 1.08 | 108 |

Comments:

METALS
-2B-
CRDL STANDARD FOR AA AND ICP

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

AA CRDL Standard Source: _____

ICP CRDL Standard Source: INORGANIC VENTURES

Concentration Units: ug/L

| Analyte | CRDL Standard for AA | | | CRDL Standard for ICP | | | | |
|-----------|----------------------|-------|----|-----------------------|-------|----|-------|-----|
| | True | Found | %R | Initial | | | Final | |
| | | | | True | Found | %R | Found | %R |
| Copper | | | | 1.0 | | | 1.01 | 101 |
| Manganese | | | | 1.0 | | | 1.07 | 107 |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | | M |
|---------|-----------------------------|---|-------------------------------------|---|-------|---|-------|---|-------------------|---|----|
| | 1 | C | 1 | C | 2 | C | 3 | C | 1 | C | |
| Arsenic | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |
| Cadmium | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |
| Nickel | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | C | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | C | M |
|---------|-----------------------------|---|-------------------------------------|---|-------|---|-------|---|-------------------|---|----|
| | | | 1 | C | 2 | C | 3 | C | | | |
| Arsenic | | | 1.000 | U | 1.000 | U | 1.000 | U | | | MS |
| Cadmium | | | 1.000 | U | 1.000 | U | 1.000 | U | | | MS |
| Nickel | | | 1.000 | U | 1.000 | U | 1.000 | U | | | MS |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | C | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | C | M |
|---------|-----------------------------|---|-------------------------------------|---|---|---|---|---|-------------------|---|----|
| | | | 1 | C | 2 | C | 3 | C | | | |
| Arsenic | | | 1.000 | U | | | | | | | MS |
| Cadmium | | | 1.000 | U | | | | | | | MS |
| Nickel | | | 1.000 | U | | | | | | | MS |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | C | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | C | M |
|-----------|-----------------------------|---|-------------------------------------|---|-------|---|-------|---|-------------------|---|----|
| | | | 1 | C | 2 | C | 3 | C | | | |
| Beryllium | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |
| Cadmium | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |
| Copper | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |
| Manganese | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | C | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | C | M |
|-----------|-----------------------------|---|-------------------------------------|---|-------|---|---|---|-------------------|---|----|
| | | | 1 | C | 2 | C | 3 | C | | | |
| Beryllium | | | 1.000 | U | 1.000 | U | | | | | MS |
| Cadmium | | | 1.000 | U | 1.000 | U | | | | | MS |
| Copper | | | 1.000 | U | 1.000 | U | | | | | MS |
| Manganese | | | 1.000 | U | 1.000 | U | | | | | MS |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | C | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | C | M |
|-----------|-----------------------------|---|-------------------------------------|---|-------|---|-------|---|-------------------|---|----|
| | | | 1 | C | 2 | C | 3 | C | | | |
| Beryllium | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | | | MS |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | C | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | C | M |
|-----------|-----------------------------|---|-------------------------------------|---|---|---|---|---|-------------------|---|----|
| | | | 1 | C | 2 | C | 3 | C | | | |
| Beryllium | | | 1.000 | U | | | | | | | MS |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | C | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | C | M |
|-----------|--------------------------------------|---|--|---|-------|---|-------|---|----------------------|---|----|
| | | | 1 | C | 2 | C | 3 | C | | | |
| Arsenic | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |
| Beryllium | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |
| Cadmium | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |
| Manganese | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |
| Nickel | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | C | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | C | M |
|-----------|-----------------------------|---|-------------------------------------|---|-------|---|-------|---|-------------------|---|----|
| | | | 1 | C | 2 | C | 3 | C | | | |
| Arsenic | | | 1.000 | U | 1.000 | U | 1.000 | U | | | MS |
| Beryllium | | | 1.000 | U | 1.000 | U | 1.000 | U | | | MS |
| Cadmium | | | 1.000 | U | 1.000 | U | 1.000 | U | | | MS |
| Manganese | | | 1.000 | U | 1.000 | U | 1.000 | U | | | MS |
| Nickel | | | 1.000 | U | 1.000 | U | 1.000 | U | | | MS |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | C | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | C | M |
|-----------|-----------------------------|---|-------------------------------------|---|---|---|---|---|-------------------|---|----|
| | | | 1 | C | 2 | C | 3 | C | | | |
| Arsenic | | | 1.000 | U | | | | | | | MS |
| Beryllium | | | 1.000 | U | | | | | | | MS |
| Cadmium | | | 1.000 | U | | | | | | | MS |
| Manganese | | | 1.000 | U | | | | | | | MS |
| Nickel | | | 1.000 | U | | | | | | | MS |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | C | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | C | M |
|-----------|-----------------------------|---|-------------------------------------|---|-------|---|-------|---|-------------------|---|----|
| | | | 1 | C | 2 | C | 3 | C | | | |
| Copper | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | MS |
| Manganese | 1.000 | U | 1.000 | U | 1.000 | U | 1.000 | U | | | MS |

Comments:

METALS

-3-

BLANKS

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Preparation Blank Matrix (soil/water): WATER

Preparation Blank Concentration Units (ug/L or mg/kg): UG/L

| Analyte | Initial Calib. Blank (ug/L) | C | Continuing Calibration Blank (ug/L) | | | | | | Preparation Blank | C | M |
|-----------|-----------------------------|---|-------------------------------------|---|-------|---|---|---|-------------------|---|----|
| | | | 1 | C | 2 | C | 3 | C | | | |
| Copper | | | 1.000 | U | 1.000 | U | | | | | MS |
| Manganese | | | 1.000 | U | 1.000 | U | | | | | MS |

Comments:

METALS

-4-

ICP INTERFERENCE CHECK SAMPLE

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

ICP ID Number: PE ICPMS ICS Source: INORGANIC VENTURES

Concentration Units): ug/L

| Analyte | True | | Initial Found | | | Final Found | | |
|---------|-------|--------|---------------|--------|----|-------------|--------|----|
| | Sol.A | Sol.AB | Sol.A | Sol.AB | %R | Sol.A | Sol.AB | %R |
| Arsenic | 0.00 | 20.00 | 0.60 | 19.19 | 96 | | | |
| Cadmium | 0.00 | 20.00 | 0.03 | 19.78 | 99 | | | |
| Nickel | 0.00 | 20.00 | 0.55 | 18.49 | 92 | | | |

METALS

-4-

ICP INTERFERENCE CHECK SAMPLE

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

ICP ID Number: PE ICPMS ICS Source: INORGANIC VENTURES

Concentration Units): ug/L

| Analyte | True | | Initial Found | | | Final Found | | |
|-----------|-------|--------|---------------|--------|-----|-------------|--------|----|
| | Sol.A | Sol.AB | Sol.A | Sol.AB | %R | Sol.A | Sol.AB | %R |
| Beryllium | 0.00 | | -0.01 | -0.01 | | | | |
| Cadmium | 0.00 | 20.00 | 0.02 | 20.03 | 100 | | | |
| Copper | 0.00 | 20.00 | 1.21 | 18.52 | 93 | | | |
| Manganese | 0.54 | 20.00 | 0.32 | 18.86 | 94 | | | |

METALS

-4-

ICP INTERFERENCE CHECK SAMPLE

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

ICP ID Number: PE ICPMS ICS Source: INORGANIC VENTURES

Concentration Units): ug/L

| Analyte | True | | Initial Found | | | Final Found | | |
|-----------|-------|--------|---------------|--------|----|-------------|--------|----|
| | Sol.A | Sol.AB | Sol.A | Sol.AB | %R | Sol.A | Sol.AB | %R |
| Beryllium | 0.00 | | 0.02 | 0.08 | | | | |

METALS

-4-

ICP INTERFERENCE CHECK SAMPLE

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

ICP ID Number: PE ICPMS ICS Source: INORGANIC VENTURES

Concentration Units): ug/L

| Analyte | True | | Initial Found | | | Final Found | | |
|-----------|-------|--------|---------------|--------|-----|-------------|--------|----|
| | Sol.A | Sol.AB | Sol.A | Sol.AB | %R | Sol.A | Sol.AB | %R |
| Arsenic | 0.00 | 20.00 | 0.77 | 20.95 | 105 | | | |
| Beryllium | 0.00 | | 0.01 | 0.08 | | | | |
| Cadmium | 0.00 | 20.00 | 0.04 | 20.27 | 101 | | | |
| Manganese | 0.54 | 20.00 | 0.32 | 20.88 | 104 | | | |
| Nickel | 0.00 | 20.00 | 0.49 | 20.28 | 101 | | | |

METALS

-4-

ICP INTERFERENCE CHECK SAMPLE

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

ICP ID Number: PE ICPMS ICS Source: INORGANIC VENTURES

Concentration Units): ug/L

| Analyte | True | | Initial Found | | | Final Found | | |
|-----------|-------|--------|---------------|--------|----|-------------|--------|----|
| | Sol.A | Sol.AB | Sol.A | Sol.AB | %R | Sol.A | Sol.AB | %R |
| Copper | 0.00 | 20.00 | 1.09 | 18.49 | 92 | | | |
| Manganese | 0.54 | 20.00 | 0.26 | 19.71 | 99 | | | |

METALS

-5A-

SPIKE SAMPLE RECOVERY

SAMPLE NO.

SPIS-23S

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Level (low/med): LOW

Solids for Sample: 0.0

Concentration Units (ug/L or mg/kg dry weight): UG/L

| Analyte | Control Limit %R | Spiked Sample Result (SSR) C | Sample Result (SR) C | Spike Added (SA) | %R | Q | M |
|-----------|------------------|------------------------------|----------------------|------------------|-----|---|----|
| Arsenic | 75 - 125 | 22.40 | 2.14 | 20.0 | 101 | | MS |
| Beryllium | 75 - 125 | 19.30 | 5.00 U | 20.0 | 96 | | MS |
| Cadmium | 75 - 125 | 19.40 | 1.00 U | 20.0 | 97 | | MS |
| Copper | 75 - 125 | 19.80 | 1.00 U | 20.0 | 99 | | MS |
| Manganese | | 286.00 | 266.00 | 20.0 | 100 | | MS |
| Nickel | 75 - 125 | 30.70 | 8.82 | 20.0 | 109 | | MS |

Comments: _____

METALS
-5B-

POST DIGEST SPIKE SAMPLE RECOVERY

SAMPLE NO.

SPIS-23A

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS _____ SDG NO.: 950030

Matrix (soil/water): WATER Level (low/med): LOW

Concentration Units: ug/L

| Analyte | Control Limit %R | Spiked Sample Result (SSR) C | Sample Result (SR) C | Spike Added (SA) | %R | Q | M |
|-----------|------------------|------------------------------|----------------------|------------------|-----|---|----|
| Arsenic | | 20.6 | 2.1 | 20 | 92 | | MS |
| Beryllium | | 19.0 | 1.0 U | 20 | 95 | | MS |
| Cadmium | | 19.4 | 1.0 U | 20 | 97 | | MS |
| Copper | | 21.0 | 1.0 U | 20 | 105 | | MS |
| Manganese | | 45.5 | 26.6 | 20 | 94 | | MS |
| Nickel | | 28.9 | 8.8 | 20 | 100 | | MS |

Comments: _____

METALS
-6-
DUPLICATES

SAMPLE NO.

SPIS-23D

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Level (low/med): LOW

% Solids for Sample: 0.0 % Solids for Duplicate: 0.0

Concentration Units (ug/L or mg/kg dry weight): UG/L

| Analyte | Control Limit | Sample (S) | C | Duplicate (D) | C | RPD | Q | M |
|-----------|---------------|------------|---|---------------|---|-----|---|----|
| Arsenic | 1.0 | 2.14 | | 2.26 | | 5 | | MS |
| Beryllium | | 5.00 | U | 5.00 | U | | | MS |
| Cadmium | | 1.00 | U | 1.00 | U | | | MS |
| Copper | | 1.00 | U | 1.00 | U | | | MS |
| Manganese | | 266.00 | | 269.00 | | 1 | | MS |
| Nickel | | 8.82 | | 9.35 | | 6 | | MS |

Comments: _____

METALS

-7-

LABORATORY CONTROL SAMPLE

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Solid LCS Source: _____

Aqueous LCS Source: ACCUSTANDARD

| Analyte | Aqueous (ug/L) | | | Solid (mg/kg) | | | | |
|---------|----------------|-------|-----|---------------|-------|---|--------|----|
| | True | Found | %R | True | Found | C | Limits | %R |
| Arsenic | 20 | 19.50 | 98 | | | | | |
| Cadmium | 20 | 21.20 | 106 | | | | | |
| Nickel | 20 | 23.10 | 116 | | | | | |

Comments: _____

METALS

-7-

LABORATORY CONTROL SAMPLE

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Solid LCS Source: _____

Aqueous LCS Source: ACCUSTANDARD

| Analyte | Aqueous (ug/L) | | | Solid (mg/kg) | | | | |
|-----------|----------------|-------|-----|---------------|-------|---|--------|----|
| | True | Found | %R | True | Found | C | Limits | %R |
| Beryllium | 20 | 17.30 | 86 | | | | | |
| Cadmium | 20 | 18.60 | 93 | | | | | |
| Copper | 20 | 21.40 | 107 | | | | | |
| Manganese | 20 | 20.30 | 102 | | | | | |

Comments: _____

METALS

-7-

LABORATORY CONTROL SAMPLE

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Solid LCS Source: _____

Aqueous LCS Source: ACCUSTANDARD

| Analyte | Aqueous (ug/L) | | | Solid (mg/kg) | | | | |
|-----------|----------------|-------|-----|---------------|-------|---|--------|----|
| | True | Found | %R | True | Found | C | Limits | %R |
| Arsenic | 20 | 19.70 | 98 | | | | | |
| Beryllium | 20 | 19.30 | 96 | | | | | |
| Cadmium | 20 | 20.30 | 102 | | | | | |
| Copper | 20 | 21.30 | 106 | | | | | |
| Manganese | 20 | 23.30 | 116 | | | | | |
| Nickel | 20 | 22.60 | 113 | | | | | |

Comments: _____

METALS

-9-

ICP SERIAL DILUTIONS

SAMPLE NO.

SPMW-01L

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Level (low/med): LOW

Concentration Units: ug/L

| Analyte | Initial Sample Result (I) | | Serial Dilution Result (S) | | % Difference | Q | M |
|-----------|---------------------------|---|----------------------------|---|--------------|---|----|
| | | C | | C | | | |
| Arsenic | 1.00 | U | 5.00 | U | | | MS |
| Beryllium | 1.00 | U | 5.00 | U | | | MS |
| Cadmium | 1.00 | U | 5.00 | U | | | MS |
| Copper | 1.00 | U | 5.00 | U | | | MS |
| Manganese | 16.57 | | 17.07 | | 3 | | MS |
| Nickel | 7.11 | | 6.60 | | 7 | | MS |

Comments: _____

METALS

-9-

ICP SERIAL DILUTIONS

SAMPLE NO.

SPIS-23L

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Matrix (soil/water): WATER Level (low/med): LOW

Concentration Units: ug/L

| Analyte | Initial Sample Result (I) C | Serial Dilution Result (S) C | % Difference | Q | M |
|-----------|--------------------------------|---------------------------------|--------------|---|----|
| Arsenic | 2.14 | 5.00 U | 100.0 | | MS |
| Beryllium | 1.00 U | 5.00 U | | | MS |
| Cadmium | 1.00 U | 5.00 U | | | MS |
| Copper | 1.00 U | 5.00 U | | | MS |
| Manganese | 26.65 | 28.08 | 5 | | MS |
| Nickel | 8.82 | 8.31 | 6 | | MS |

Comments: _____

METALS

-10-

INSTRUMENT DETECTION LIMITS (QUARTERLY)

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

ICP ID Number: PE ICPMS Date: 1/2/03

Flame AA ID Number: _____

Turnace AA ID Number: _____

| Analyte | Isotope | Back-ground | PQL (ug/L) | IDL (ug/L) | M |
|-----------|---------|-------------|------------|------------|----|
| Arsenic | 75 | | 1.00 | 1.00 | MS |
| Beryllium | 9 | | 1.00 | 1.00 | MS |
| Cadmium | 111 | | 1.00 | 1.00 | MS |
| Copper | 63 | | 1.00 | 1.00 | MS |
| Manganese | 55 | | 1.00 | 1.00 | MS |
| Nickel | 60 | | 1.00 | 1.00 | MS |

Comments: _____

METALS
-12-
ICP LINEAR RANGES (QUARTERLY)

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

ICP ID Number: PE ICPMS Date: 8/28/06

| Analyte | Integ. Time (Sec.) | Concentration (ug/L) | M |
|-----------|--------------------|----------------------|----|
| Arsenic | 0.100 | 200 | MS |
| Beryllium | 0.100 | 200 | MS |
| Cadmium | 0.100 | 200 | MS |
| Copper | 0.100 | 200 | MS |
| Manganese | 0.100 | 200 | MS |
| Nickel | 0.100 | 200 | MS |

Comments: _____

METALS

-13-

PREPARATION LOG

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Method: MS

| Sample ID | Preparation Date | Initial Volume | Final Volume (mL) |
|-------------|------------------|----------------|-------------------|
| SPMW-03 | 10/31/06 | 50.0 | 50.0 |
| SPMW-07 | 10/31/06 | 50.0 | 50.0 |
| SPMW-07 DUP | 10/31/06 | 50.0 | 50.0 |
| SPOB-34 | 10/31/06 | 50.0 | 50.0 |
| SPOB-12R2 | 10/31/06 | 50.0 | 50.0 |
| SPMW-11R2 | 10/31/06 | 50.0 | 50.0 |
| SPMW-12 | 10/31/06 | 50.0 | 50.0 |
| SPMW-13 | 10/31/06 | 50.0 | 50.0 |
| SPMW-04 | 10/31/06 | 50.0 | 50.0 |
| SPIS-24 | 10/31/06 | 50.0 | 50.0 |
| SPIS-24 DUP | 10/31/06 | 50.0 | 50.0 |
| SPIS-23 | 10/31/06 | 50.0 | 50.0 |
| SPIS-23D | 10/31/06 | 50.0 | 50.0 |
| SPIS-23S | 10/31/06 | 50.0 | 50.0 |
| LCSW | 10/31/06 | 50.0 | 50.0 |
| PBW | 10/31/06 | 50.0 | 50.0 |

Comments:

METALS

-13-

PREPARATION LOG

Contract: r2634493Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030Method: MS

| Sample ID | Preparation Date | Initial Volume | Final Volume (mL) |
|-------------|------------------|----------------|-------------------|
| SPMW-03 | 11/15/06 | 50.0 | 50.0 |
| SPMW-07 | 11/15/06 | 50.0 | 50.0 |
| SPMW-07 DUP | 11/15/06 | 50.0 | 50.0 |
| SPOB-34 | 11/15/06 | 50.0 | 50.0 |
| SPOB-12R2 | 11/15/06 | 50.0 | 50.0 |
| SPMW-11R2 | 11/15/06 | 50.0 | 50.0 |
| SPMW-12 | 11/15/06 | 50.0 | 50.0 |
| SPMW-13 | 11/15/06 | 50.0 | 50.0 |
| SPMW-04 | 11/15/06 | 50.0 | 50.0 |
| SPIS-24 | 11/15/06 | 50.0 | 50.0 |
| SPIS-24 DUP | 11/15/06 | 50.0 | 50.0 |
| SPIS-23 | 11/15/06 | 50.0 | 50.0 |
| SPIS-23D | 11/15/06 | 50.0 | 50.0 |
| SPIS-23S | 11/15/06 | 50.0 | 50.0 |
| LCSW | 11/15/06 | 50.0 | 50.0 |
| PBW | 11/15/06 | 50.0 | 50.0 |

Comments:

METALS

-13-

PREPARATION LOG

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG NO.: 950030

Method: MS

| Sample ID | Preparation Date | Initial Volume | Final Volume (mL) |
|-----------|------------------|----------------|-------------------|
| SPMW-01 | 11/15/06 | 50.0 | 50.0 |
| SPMW-05 | 11/15/06 | 50.0 | 50.0 |
| SPMW-10R | 11/15/06 | 50.0 | 50.0 |
| SPMW-02 | 11/15/06 | 50.0 | 50.0 |
| SPMW-06R | 11/15/06 | 50.0 | 50.0 |
| SPMW-08 | 11/15/06 | 50.0 | 50.0 |
| SPMW-09 | 11/15/06 | 50.0 | 50.0 |
| LCSW | 11/15/06 | 50.0 | 50.0 |
| PBW | 11/15/06 | 50.0 | 50.0 |

Comments:

Instrument Tuning Report

File Name: epa.tun
File Path: c:\elandata\Tuning

| Analyte | Exact Mass | Meas. Mass | Mass DAC | Res. DAC | Meas. Pk. Width | Custom Res. |
|---------|------------|------------|----------|----------|-----------------|-------------|
| He | 3.016 | 3.025 | 580 | 2090 | 0.691 | |
| Be | 9.012 | 9.028 | 2037 | 2070 | 0.708 | |
| Mg | 23.985 | 23.978 | 5673 | 2080 | 0.740 | |
| Co | 58.933 | 58.929 | 14164 | 2100 | 0.701 | |
| Rh | 102.905 | 102.929 | 24878 | 2130 | 0.711 | |
| In | 114.904 | 114.878 | 27783 | 2150 | 0.697 | |
| Ba | 137.905 | 137.929 | 33394 | 2170 | 0.670 | |
| Ce | 139.905 | 139.879 | 33870 | 2160 | 0.696 | |
| Pb | 207.977 | 207.979 | 50438 | 2220 | 0.693 | |
| U | 238.050 | 237.975 | 57736 | 2250 | 0.695 | |

Instrument Tuning Report

File Name: epa.tun
File Path: c:\elandata\Tuning

| Analyte | Exact Mass | Meas. Mass | Mass DAC | Res. DAC | Meas. Pk. Width | Custom Res. |
|---------|------------|------------|----------|----------|-----------------|-------------|
| He | 3.016 | 3.027 | 580 | 2090 | 0.709 | |
| Be | 9.012 | 9.028 | 2032 | 2070 | 0.720 | |
| Mg | 23.985 | 23.979 | 5661 | 2080 | 0.733 | |
| Co | 58.933 | 58.928 | 14165 | 2100 | 0.703 | |
| Rh | 102.905 | 102.929 | 24872 | 2130 | 0.713 | |
| In | 114.904 | 114.928 | 27801 | 2150 | 0.708 | |
| Ba | 137.905 | 137.879 | 33388 | 2170 | 0.708 | |
| Ce | 139.905 | 139.929 | 33864 | 2160 | 0.710 | |
| Pb | 207.977 | 207.978 | 50426 | 2220 | 0.693 | |
| U | 238.050 | 238.026 | 57747 | 2250 | 0.692 | |

Instrument Tuning Report

File Name: epa.tun
File Path: c:\elandata\Tuning

| Analyte | Exact Mass | Meas. Mass | Mass DAC | Res. DAC | Meas. Pk. Width | Custom Res. |
|---------|------------|------------|----------|----------|-----------------|-------------|
| He | 3.016 | 3.027 | 582 | 2090 | 0.707 | |
| Be | 9.012 | 9.028 | 2035 | 2070 | 0.714 | |
| Mg | 23.985 | 24.029 | 5671 | 2080 | 0.729 | |
| Co | 58.933 | 58.929 | 14163 | 2100 | 0.707 | |
| Rh | 102.905 | 102.879 | 24865 | 2130 | 0.719 | |
| In | 114.904 | 114.878 | 27794 | 2150 | 0.711 | |
| Ba | 137.905 | 137.929 | 33393 | 2170 | 0.693 | |
| Ce | 139.905 | 139.879 | 33857 | 2160 | 0.710 | |
| Pb | 207.977 | 207.979 | 50426 | 2220 | 0.698 | |
| U | 238.050 | 238.076 | 57753 | 2250 | 0.705 | |

Instrument Tuning Report

File Name: epa.tun
File Path: c:\elandata\Tuning

| Analyte | Exact Mass | Meas. Mass | Mass DAC | Res. DAC | Meas. Pk. Width | Custom Res. |
|---------|------------|------------|----------|----------|-----------------|-------------|
| He | 3.016 | 3.025 | 579 | 2090 | 0.701 | |
| Be | 9.012 | 8.978 | 2036 | 2070 | 0.704 | |
| Mg | 23.985 | 23.978 | 5663 | 2080 | 0.725 | |
| Co | 58.933 | 58.928 | 14167 | 2100 | 0.700 | |
| Rh | 102.905 | 102.929 | 24873 | 2130 | 0.720 | |
| In | 114.904 | 114.928 | 27790 | 2150 | 0.702 | |
| Ba | 137.905 | 137.929 | 33401 | 2170 | 0.693 | |
| Ce | 139.905 | 139.928 | 33877 | 2160 | 0.710 | |
| Pb | 207.977 | 207.928 | 50426 | 2220 | 0.701 | |
| U | 238.050 | 238.076 | 57741 | 2250 | 0.703 | |

METALS

-14-

ANALYSIS RUN LOG

Contract: r2634493

Lab Code: Case No.: SAS No.: SDG No.: 950030

Instrument ID Number: PE ICPMS Method: MS

Start Date: 11/13/06 End Date: 11/13/06

| Sample ID. | D/F | Time | % R | Analytes | | | | | | | | | | | | | | | | | | | | | | |
|------------|------|-------|-----|----------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| | | | | A L | S B | A S | B A | B E | C D | C A | C R | C O | C U | F E | P B | M G | M N | H G | N I | K E | S G | A A | N L | T A | V L | Z N |
| Blank | 1.00 | 13:39 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| Standard 1 | 1.00 | 13:44 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| Standard 2 | 1.00 | 13:50 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| Standard 3 | 1.00 | 13:56 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| ICV1 | 1.00 | 14:02 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| ICB1 | 1.00 | 14:08 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| CRDL1 | 1.00 | 14:14 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| ICS-A1 | 1.00 | 14:20 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| ICS-AB1 | 1.00 | 14:26 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| CCV1 | 1.00 | 14:32 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| CCB1 | 1.00 | 14:38 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| QC Std 8 | 1.00 | 14:44 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| ZZZZZZ | 1.00 | 14:50 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 14:58 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 15:04 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 15:10 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 5.00 | 15:16 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 15:22 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 15:28 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 15:34 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 15:40 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 15:46 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 15:52 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 15:58 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 16:04 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 16:10 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 16:16 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 16:22 | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 16:28 | | | | | | | | | | | | | | | | | | | | | | | | |
| CRDL2 | 1.00 | 16:34 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| HLCCV2 | 1.00 | 16:40 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| CCV3 | 1.00 | 16:46 | | | X | | | X | | | | | | | | | | X | | | | | | | | |
| CCB3 | 1.00 | 16:52 | | | X | | | X | | | | | | | | | | X | | | | | | | | |

104

* - Denotes additional elements (other than the standard CLP elements) are represented on another Form 14

METALS

-14-

ANALYSIS RUN LOG

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

Instrument ID Number: PE ICPMS Method: MS

Start Date: 11/13/06 End Date: 11/13/06

| Sample ID. | D/F | Time | % R | Analytes | | | | | | | | | | | | | | | | | | | | | |
|------------|--------|-------|-----|----------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|---|--------|--------|--------|--------|---|--------|
| | | | | A L | S B | A S | B A | B E | C D | C A | C R | C O | F U | P B | M G | M N | H G | N I | K | S E | A G | N A | T L | V | Z N |
| PBW | 1.00 | 16:58 | | | | X | | | X | | | | | | | | | X | | | | | | | |
| LCSW | 1.00 | 17:03 | | | | X | | | X | | | | | | | | | X | | | | | | | |
| ZZZZZZ | 1.00 | 17:12 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 17:18 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 17:24 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 17:30 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 17:35 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 17:41 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 17:47 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 17:53 | | | | | | | | | | | | | | | | | | | | | | | |
| CCV4 | 1.00 | 17:59 | | | | X | | | X | | | | | | | | | X | | | | | | | |
| CCB4 | 1.00 | 18:05 | | | | X | | | X | | | | | | | | | X | | | | | | | |
| ZZZZZZ | 10.00 | 18:11 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 18:17 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 18:23 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 18:29 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 18:35 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 18:41 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 18:47 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 18:53 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 18:59 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 19:05 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 19:11 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 19:17 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 19:23 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 19:29 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 19:35 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 19:41 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 19:47 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 19:53 | | | | | | | | | | | | | | | | | | | | | | | |
| CRDL3 | 1.00 | 19:59 | | | | X | | | X | | | | | | | | | X | | | | | | | |
| CCV6 | 1.00 | 20:05 | | | | X | | | X | | | | | | | | | X | | | | | | | |
| CCB6 | 1.00 | 20:11 | | | | X | | | X | | | | | | | | | X | | | | | | | |

* - Denotes additional elements (other than the standard CLP elements) are represented on another Form 14-105

METALS

-14-

ANALYSIS RUN LOG

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

Instrument ID Number: PE ICPMS Method: MS

Start Date: 11/13/06 End Date: 11/13/06

| Sample ID. | D/F | Time | % R | Analytes | | | | | | | | | | | | | | | | | | | | | |
|-------------|-------|-------|-----|----------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| | | | | A L | S B | A S | B A | B E | C D | C A | C R | C O | C U | F E | P B | M G | M N | H G | N I | K E | S G | A A | N L | T V | Z N |
| SPMW-03 | 1.00 | 20:17 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| SPMW-07 | 1.00 | 20:23 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| SPMW-07 DUP | 1.00 | 20:29 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| SPOB-34 | 1.00 | 20:35 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| SPOB-12R2 | 1.00 | 20:41 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| SPMW-11R2 | 1.00 | 20:47 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| SPMW-12 | 1.00 | 20:53 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| SPMW-13 | 1.00 | 20:59 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| SPMW-04 | 1.00 | 21:05 | | | | X | | | | | | | | | | | | X | | | | | | | |
| CCV7 | 1.00 | 21:10 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| CCB7 | 1.00 | 21:16 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| SPIS-24 | 1.00 | 21:22 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| SPIS-24 DUP | 1.00 | 21:28 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| SPIS-23 | 1.00 | 21:34 | | | | X | | | | | | | | | | | | X | | | | | | | |
| SPIS-23D | 1.00 | 21:40 | | | | X | | | | | | | | | | | | X | | | | | | | |
| SPIS-23S | 1.00 | 21:46 | | | | X | | | | | | | | | | | | X | | | | | | | |
| SPIS-23A | 1.00 | 21:52 | | | | X | | | | | | | | | | | | X | | | | | | | |
| SPIS-23L | 5.00 | 21:58 | | | | X | | | | | | | | | | | | X | | | | | | | |
| ZZZZZZ | 10.00 | 22:04 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 22:10 | | | | | | | | | | | | | | | | | | | | | | | |
| CCV8 | 1.00 | 22:16 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| CCB8 | 1.00 | 22:22 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| ZZZZZZ | 10.00 | 22:28 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 22:34 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 22:40 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 22:46 | | | | | | | | | | | | | | | | | | | | | | | |
| CRDL4 | 1.00 | 22:52 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| CCV9 | 1.00 | 22:58 | | | | X | | X | | | | | | | | | | X | | | | | | | |
| CCB9 | 1.00 | 23:04 | | | | X | | X | | | | | | | | | | X | | | | | | | |

* - Denotes additional elements (other than the standard CLP elements) are represented on another Form 106

METALS

-14-

ANALYSIS RUN LOG

Contract: r2634493
 Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030
 Instrument ID Number: PE ICPMS Method: MS
 Start Date: 11/17/06 End Date: 11/17/06

| Sample ID. | D/F | Time | % R | Analytes | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------|-------|-------|-----|----------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--|--|--|--|
| | | | | A L | S B | A S | B A | B E | C D | C A | C R | C O | C U | F E | P B | M G | M N | H G | N I | K E | S E | A G | N A | T L | V L | Z N | C N | | | | |
| Blank | 1.00 | 15:28 | | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | |
| Standard 1 | 1.00 | 15:34 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| Standard 2 | 1.00 | 15:40 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| Standard 3 | 1.00 | 15:46 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| ICV2 | 1.00 | 15:51 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| ICB2 | 1.00 | 15:57 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| CRDL1 | 1.00 | 16:03 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| ICS-A1 | 1.00 | 16:09 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| ICS-AB1 | 1.00 | 16:15 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| CCV1 | 1.00 | 16:21 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| CCB1 | 1.00 | 16:27 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| QC Std 8 | 1.00 | 16:33 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| PBW | 1.00 | 16:39 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| LCSW | 1.00 | 16:45 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| SPMW-03 | 1.00 | 16:51 | | | | | X | | | | X | | | X | | | | | | | | | | | | | | | | | |
| SPMW-07 | 10.00 | 16:57 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-07 | 1.00 | 17:03 | | | | | X | | | | X | | | | | | | | | | | | | | | | | | | | |
| SPMW-07 DUP | 10.00 | 17:09 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-07 DUP | 1.00 | 17:15 | | | | | X | | | | X | | | | | | | | | | | | | | | | | | | | |
| SPOB-34 | 10.00 | 17:21 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPOB-34 | 1.00 | 17:27 | | | | | X | | | | X | | | | | | | | | | | | | | | | | | | | |
| CCV2 | 1.00 | 17:33 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| CCB2 | 1.00 | 17:39 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| SPOB-12R2 | 1.00 | 17:45 | | | | | | | | | X | | | X | | | | | | | | | | | | | | | | | |
| SPMW-11R2 | 1.00 | 17:51 | | | | | | | | | X | | | X | | | | | | | | | | | | | | | | | |
| SPMW-12 | 1.00 | 17:57 | | | | | | | | | X | | | X | | | | | | | | | | | | | | | | | |
| SPMW-13 | 10.00 | 18:03 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-13 | 1.00 | 18:09 | | | | | | | | | X | | | | | | | | | | | | | | | | | | | | |
| SPMW-04 | 1.00 | 18:15 | | | | | | X | | | X | | | X | | | | | | | | | | | | | | | | | |
| SPIS-24 | 10.00 | 18:21 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPIS-24 | 1.00 | 18:26 | | | | | | | | | X | | | | | | | | | | | | | | | | | | | | |
| SPIS-24 DUP | 10.00 | 18:32 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CCV3 | 1.00 | 18:38 | | | | | X | X | | | X | | | X | | | | | | | | | | | | | | | | | |

* - Denotes additional elements (other than the standard CLP elements) are represented on another Form 107

METALS

-14-

ANALYSIS RUN LOG

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

Instrument ID Number: PE ICPMS Method: MS

Start Date: 11/17/06 End Date: 11/17/06

| Sample ID. | D/F | Time | % R | Analytes | | | | | | | | | | | | | | | | | | | | | |
|-------------|--------|-------|-----|----------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| | | | | A L | S B | A S | B A | B E | C D | C A | C R | C O | F U | P B | M G | M N | H G | N I | K E | S E | A G | N A | T L | V L | Z N |
| CCB3 | 1.00 | 18:44 | | | | | X | X | | | X | | | X | | | | | | | | | | | |
| SPIS-24 DUP | 1.00 | 18:50 | | | | | | | | | X | | | | | | | | | | | | | | |
| SPIS-23 | 10.00 | 18:56 | | | | | | | | | | | | X | | | | | | | | | | | |
| SPIS-23D | 10.00 | 19:02 | | | | | | | | | | | | X | | | | | | | | | | | |
| SPIS-23S | 10.00 | 19:08 | | | | | | | | | | | | X | | | | | | | | | | | |
| SPIS-23A | 10.00 | 19:14 | | | | | | | | | | | | X | | | | | | | | | | | |
| SPIS-23L | 10.00 | 19:20 | | | | | | | | | | | | X | | | | | | | | | | | |
| SPIS-23 | 1.00 | 19:26 | | | | | | X | | | X | | | | | | | | | | | | | | |
| SPIS-23D | 1.00 | 19:32 | | | | | | X | | | X | | | | | | | | | | | | | | |
| SPIS-23S | 1.00 | 19:38 | | | | | | X | | | X | | | | | | | | | | | | | | |
| CCV4 | 1.00 | 19:44 | | | | | X | X | | | X | | | X | | | | | | | | | | | |
| CCB4 | 1.00 | 19:50 | | | | | X | X | | | X | | | X | | | | | | | | | | | |
| SPIS-23A | 1.00 | 19:56 | | | | | | X | | | X | | | | | | | | | | | | | | |
| SPIS-23L | 5.00 | 20:02 | | | | | | X | | | X | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 20:08 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 20:14 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 20:20 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 20:26 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 20:32 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 100.00 | 20:38 | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 20:44 | | | | | | | | | | | | | | | | | | | | | | | |
| CRDL2 | 1.00 | 20:50 | | | | | X | X | | | X | | | X | | | | | | | | | | | |
| HLCCV2 | 1.00 | 20:56 | | | | | X | X | | | X | | | X | | | | | | | | | | | |
| CCV5 | 1.00 | 21:02 | | | | | X | X | | | X | | | X | | | | | | | | | | | |
| CCB5 | 1.00 | 21:08 | | | | | X | X | | | X | | | X | | | | | | | | | | | |

* - Denotes additional elements (other than the standard CLP elements) are represented on another Form **108**

METALS

-14-

ANALYSIS RUN LOG

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

Instrument ID Number: PE ICPMS Method: MS

Start Date: 11/20/06 End Date: 11/20/06

| Sample ID. | D/F | Time | % R | Analytes | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------|-------|-------|-----|----------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--|--|
| | | | | A L | S B | A S | B A | B E | C D | C A | C R | C O | C U | F E | P B | M G | M N | H G | N I | K E | S E | A G | N A | T L | V L | Z N | C N | | |
| Blank | 1.00 | 09:28 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| Standard 1 | 1.00 | 09:34 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| Standard 2 | 1.00 | 09:40 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| Standard 3 | 1.00 | 09:46 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| ICV3 | 1.00 | 09:52 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| ICB3 | 1.00 | 09:58 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| CRDL1 | 1.00 | 10:04 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| ICS-A1 | 1.00 | 10:10 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| ICS-AB1 | 1.00 | 10:16 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| CCV1 | 1.00 | 10:22 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| CCB1 | 1.00 | 10:28 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| QC Std 8 | 1.00 | 10:34 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 10:40 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 10:46 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPOB-12R2 | 1.00 | 10:52 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 10:58 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-12 | 1.00 | 11:04 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| SPMW-13 | 1.00 | 11:10 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:16 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPIS-24 | 1.00 | 11:22 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| SPIS-24 DUP | 1.00 | 11:28 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| CCV2 | 1.00 | 11:34 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| CCB2 | 1.00 | 11:40 | | | | | | X | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:45 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:51 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:57 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 12:03 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 5.00 | 12:09 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 12:15 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 12:23 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 12:29 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 12:35 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 10.00 | 12:41 | | | | | | | | | | | | | | | | | | | | | | | | | | | |

* - Denotes additional elements (other than the standard CLP elements) are represented on another Form 14

METALS

-14-

ANALYSIS RUN LOG

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

Instrument ID Number: PE ICPMS Method: MS

Start Date: 11/20/06 End Date: 11/20/06

| Sample ID. | D/F | Time | % R | Analytes | | | | | | | | | | | | | | | | | | | | | | | |
|------------|-------|-------|-----|----------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| | | | | A L | S B | A S | B A | B E | C D | C A | C R | C O | C U | F E | P B | M G | M N | H G | N I | K E | S E | A G | N A | T L | V L | Z N | C N |
| ZZZZZZ | 10.00 | 12:47 | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-11R2 | 5.00 | 12:53 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| SPMW-04 | 5.00 | 12:59 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| SPIS-23 | 5.00 | 13:05 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| SPIS-23D | 5.00 | 13:11 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| CCV3 | 1.00 | 13:17 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| CCB3 | 1.00 | 13:23 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| SPIS-23S | 5.00 | 13:29 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| SPIS-23A | 5.00 | 13:35 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| SPIS-23L | 5.00 | 13:40 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| CRDL2 | 1.00 | 13:46 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| HLCCV2 | 1.00 | 13:52 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| CCV4 | 1.00 | 13:58 | | | | | | X | | | | | | | | | | | | | | | | | | | |
| CCB4 | 1.00 | 14:04 | | | | | | X | | | | | | | | | | | | | | | | | | | |

* - Denotes additional elements (other than the standard CLP elements) are represented on another Form 1110

METALS

-14-

ANALYSIS RUN LOG

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

Instrument ID Number: PE ICPMS Method: MS

Start Date: 11/21/06 End Date: 11/21/06

| Sample ID. | D/F | Time | % R | Analytes | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------|------|-------|-----|----------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|---|--------|--------|--------|--------|---|--------|--------|--|--|--|--|
| | | | | A L | S B | A S | B A | B E | C D | C A | C R | C O | C U | F E | P B | M G | M N | H G | N I | K | S E | A G | N A | T L | V | Z N | C N | | | | |
| Blank | 1.00 | 09:33 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| Standard 1 | 1.00 | 09:38 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| Standard 2 | 1.00 | 09:44 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| Standard 3 | 1.00 | 09:50 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| ICV4 | 1.00 | 09:56 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| ICB4 | 1.00 | 10:02 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| CRDL1 | 1.00 | 10:08 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| ICS-A1 | 1.00 | 10:14 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| ICS-AB1 | 1.00 | 10:20 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| CCV1 | 1.00 | 10:26 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| CCB1 | 1.00 | 10:32 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| QC Std 8 | 1.00 | 10:38 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| PBW | 1.00 | 10:44 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| LCSW | 1.00 | 10:50 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| ZZZZZZ | 2.00 | 10:56 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-01 | 1.00 | 11:02 | | | X | | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:08 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:14 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:20 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-01L | 5.00 | 11:26 | | | X | | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| SPMW-05 | 1.00 | 11:32 | | | X | | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| CCV2 | 1.00 | 11:38 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| CCB2 | 1.00 | 11:44 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| SPMW-10R | 1.00 | 11:50 | | | X | | X | | | | | | | | | | | | | | | | | | | X | | | | | |
| SPMW-02 | 1.00 | 11:56 | | | X | X | X | | | | | | | | | | | | | | | | | | | | X | | | | |
| SPMW-06R | 1.00 | 12:02 | | | X | | X | | | | | | | | | | | | | | | | | | | | X | | | | |
| SPMW-08 | 1.00 | 12:08 | | | X | X | X | | | | | | | | | | | | | | | | | | | | X | | | | |
| SPMW-09 | 1.00 | 12:14 | | | X | | X | | | | | | | | | | | | | | | | | | | | | | | | |
| CRDL2 | 1.00 | 12:19 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 12:25 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CCV3 | 1.00 | 12:31 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| CCB3 | 1.00 | 12:37 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | | | |
| SPMW-01 | 5.00 | 12:49 | | | | X | | | | | | | | | | | | | | | | | | | | | | | | | |

* - Denotes additional elements (other than the standard CLP elements) are represented on another Form 111

METALS

-14-

ANALYSIS RUN LOG

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

Instrument ID Number: PE ICPMS Method: MS

Start Date: 11/21/06 End Date: 11/21/06

| Sample ID. | D/F | Time | % R | Analytes | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------|--------|-------|-----|----------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--|--|
| | | | | A L | S B | A S | B A | B E | C D | C A | C R | C O | C U | F E | P B | M G | M N | H G | N I | K E | S E | A G | N A | T L | V L | Z N | C N | | |
| ZZZZZZ | 5.00 | 12:55 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 5.00 | 13:01 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CCV4 | 1.00 | 13:07 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | |
| CCB4 | 1.00 | 13:13 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | |
| ZZZZZZ | 5.00 | 13:18 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-01L | 5.00 | 13:24 | | | | | X | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-05 | 5.00 | 13:30 | | | | | X | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-10R | 5.00 | 13:36 | | | | | X | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-06R | 100.00 | 13:42 | | | | | | | | | | | | | X | | | | | | | | | | | | | | |
| SPMW-06R | 5.00 | 13:48 | | | | | X | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-08 | 20.00 | 13:54 | | | | | | | | | | | | | X | | | | | | | | | | | | | | |
| SPMW-09 | 500.00 | 14:00 | | | | | | | | | | | | | X | | | | | | | | | | | | | | |
| SPMW-09 | 100.00 | 14:06 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CCV5 | 1.00 | 14:12 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | |
| CCB5 | 1.00 | 14:18 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | |
| SPMW-09 | 5.00 | 14:24 | | | | | X | | | | | | | | | | | | X | | | | | | | | | | |
| CRDL3 | 1.00 | 14:30 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | |
| HLCCV2 | 1.00 | 14:36 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | |
| CCV6 | 1.00 | 14:42 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | |
| CCB6 | 1.00 | 14:48 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | |
| SPMW-10R | 10.00 | 15:04 | | | | | | | | | | | | | X | | | | | | | | | | | | | | |
| CRDL4 | 1.00 | 15:10 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | |
| CCV7 | 1.00 | 15:15 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | |
| CCB7 | 1.00 | 15:21 | | | X | X | X | | | | | | | | X | X | | | | | | | | | | | | | |

* - Denotes additional elements (other than the standard CLP elements) are represented on another Form **112**

METALS

-14-

ANALYSIS RUN LOG

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

Instrument ID Number: PE ICPMS Method: MS

Start Date: 11/22/06 End Date: 11/22/06

| Sample ID. | D/F | Time | % R | Analytes | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------|--------|-------|-----|----------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|---|--------|--------|--------|--------|---|--------|--------|--|--|
| | | | | A L | S B | A S | B A | B E | C D | C A | C R | C O | C U | F E | P B | M G | M N | H G | N I | K | S E | A G | N A | T L | V | Z N | C N | | |
| Blank | 1.00 | 09:48 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| Standard 1 | 1.00 | 09:54 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| Standard 2 | 1.00 | 10:00 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| Standard 3 | 1.00 | 10:06 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| ICV5 | 1.00 | 10:12 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| ICB5 | 1.00 | 10:18 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| CRDL1 | 1.00 | 10:24 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| ICS-A1 | 1.00 | 10:30 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| ICS-AB1 | 1.00 | 10:36 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| CCV1 | 1.00 | 10:42 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| CCB1 | 1.00 | 10:48 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| QC Std 8 | 1.00 | 10:54 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| PBW | 1.00 | 11:00 | | | | | | | | | | X | | | | | | | | | | | | | | | | | |
| LCSW | 1.00 | 11:06 | | | | | | | | | | X | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:12 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:18 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:24 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:30 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 5.00 | 11:36 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:42 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 11:48 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CCV2 | 1.00 | 11:54 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| CCB2 | 1.00 | 11:59 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| SPMW-02 | 5.00 | 12:05 | | | | | | | | | | | | | | X | | | | | | | | | | | | | |
| SPMW-02 | 1.00 | 12:11 | | | | | | | | | | X | | | | | | | | | | | | | | | | | |
| SPMW-06R | 1.00 | 12:17 | | | | | | | | | | X | | | | | | | | | | | | | | | | | |
| SPMW-08 | 1.00 | 12:23 | | | | | | | | | | X | | | | | | | | | | | | | | | | | |
| SPMW-09 | 100.00 | 12:29 | | | | | | | | | | X | | | | | | | | | | | | | | | | | |
| CRDL2 | 1.00 | 12:35 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| HLCCV2 | 1.00 | 12:41 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| CRDL3 | 1.00 | 12:47 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| CCV3 | 1.00 | 12:53 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |
| CCB3 | 1.00 | 12:59 | | | | | | | | | | X | | | | X | | | | | | | | | | | | | |

113

* - Denotes additional elements (other than the standard CLP elements) are represented on another Form 14

METALS

-14-

ANALYSIS RUN LOG

Contract: r2634493

Lab Code: _____ Case No.: _____ SAS No.: _____ SDG No.: 950030

Instrument ID Number: PE ICPMS Method: MS

Start Date: 11/22/06 End Date: 11/22/06

| Sample ID. | D/F | Time | % R | Analytes | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------|------|-------|-----|----------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--|--|--|--|
| | | | | A L | S B | A S | B A | B E | C D | C A | C R | C O | C U | F E | P B | M G | M N | H G | N I | K E | S E | A G | N A | T A | V L | Z N | C N | | | | |
| ZZZZZZ | 1.00 | 13:29 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 13:35 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 13:41 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CCV4 | 1.00 | 13:47 | | | | | | | | | | X | | | | | | | | | | | | | | | | | | | |
| CCB4 | 1.00 | 13:53 | | | | | | | | | | X | | | | | | | | | | | | | | | | | | | |
| SPMW-01 | 1.00 | 14:04 | | | | | | | | | | X | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 14:10 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 14:16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ZZZZZZ | 1.00 | 14:22 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPMW-01L | 5.00 | 14:28 | | | | | | | | | | X | | | | | | | | | | | | | | | | | | | |
| SPMW-05 | 1.00 | 14:34 | | | | | | | | | | X | | | | | | | | | | | | | | | | | | | |
| SPMW-10R | 1.00 | 14:40 | | | | | | | | | | X | | | | | | | | | | | | | | | | | | | |
| CRDL4 | 1.00 | 14:46 | | | | | | | | | | X | | | | | | | | | | | | | | | | | | | |
| CCV5 | 1.00 | 14:52 | | | | | | | | | | X | | | | | | | | | | | | | | | | | | | |
| CCB5 | 1.00 | 14:58 | | | | | | | | | | X | | | | | | | | | | | | | | | | | | | |

* - Denotes additional elements (other than the standard CLP elements) are represented on another Form 14

METALS

15-IN

ICP-MS INTERNAL STANDARDS RELATIVE INTENSITY SUMMARY

Lab Name: Columbia Analytical Services Contract: r2634493
 Lab Code: _____ Case No.: _____ NRAS No. _____ SDG NO.: 950030
 CP-MS Instrument ID: PE ICPMS Start Date: 11/13/2006 End Date: 11/13/2006

| Sample No. | Client ID | Time | Internal Standards %RI For: | | | | | | | | | | | |
|-------------|-------------|-------|-----------------------------|---|---------------|---|---------------|---|---------------|---|---------------|---|---------|---|
| | | | Element Tb | Q | Element Ge | Q | Element Sc | Q | Element In | Q | Element Ho | Q | Element | Q |
| Blank | Blank | 13:39 | 100 | | 100 | | 100 | | 100 | | 100 | | | |
| Standard 1 | Standard 1 | 13:44 | 99 | | 98 | | 98 | | 101 | | 99 | | | |
| Standard 2 | Standard 2 | 13:50 | 96 | | 96 | | 97 | | 100 | | 96 | | | |
| Standard 3 | Standard 3 | 13:56 | 94 | | 98 | | 97 | | 100 | | 97 | | | |
| ICV1 | ICV1 | 14:02 | 93 | | 95 | | 97 | | 98 | | 96 | | | |
| ICB1 | ICB1 | 14:08 | 94 | | 97 | | 98 | | 98 | | 95 | | | |
| CRDL1 | CRDL1 | 14:14 | 95 | | 95 | | 96 | | 99 | | 95 | | | |
| ICS-A1 | ICS-A1 | 14:20 | 91 | | 104 | | 94 | | 92 | | 91 | | | |
| ICS-AB1 | ICS-AB1 | 14:26 | 89 | | 102 | | 93 | | 93 | | 92 | | | |
| CCV1 | CCV1 | 14:32 | 93 | | 96 | | 91 | | 95 | | 93 | | | |
| CCB1 | CCB1 | 14:38 | 92 | | 98 | | 94 | | 96 | | 96 | | | |
| QC Std 8 | QC Std 8 | 14:44 | 94 | | 99 | | 95 | | 99 | | 95 | | | |
| CRDL2 | CRDL2 | 16:34 | 98 | | 99 | | 94 | | 99 | | 99 | | | |
| HLCCV2 | HLCCV2 | 16:40 | 95 | | 96 | | 91 | | 96 | | 94 | | | |
| CCV3 | CCV3 | 16:46 | 97 | | 96 | | 93 | | 97 | | 95 | | | |
| CCB3 | CCB3 | 16:52 | 97 | | 98 | | 95 | | 99 | | 98 | | | |
| PBW-M399013 | PBW | 16:58 | 101 | | 100 | | 100 | | 102 | | 99 | | | |
| LCSW-M39901 | LCSW | 17:03 | 105 | | 109 | | 109 | | 109 | | 108 | | | |
| CCV4 | CCV4 | 17:59 | 97 | | 99 | | 97 | | 98 | | 97 | | | |
| CCB4 | CCB4 | 18:05 | 98 | | 99 | | 96 | | 99 | | 97 | | | |
| CRDL3 | CRDL3 | 19:59 | 100 | | 101 | | 98 | | 103 | | 101 | | | |
| CCV6 | CCV6 | 20:05 | 97 | | 101 | | 99 | | 102 | | 99 | | | |
| CCB6 | CCB6 | 20:11 | 100 | | 100 | | 97 | | 102 | | 99 | | | |
| 950466 | SPMW-03 | 20:17 | 102 | | 106 | | 124 | | 103 | | 102 | | | |
| 950467 | SPMW-07 | 20:23 | 100 | | 109 | | 114 | | 102 | | 99 | | | |
| 950468 | SPMW-07 DUP | 20:29 | 103 | | 111 | | 117 | | 106 | | 104 | | | |
| 950469 | SPOB-34 | 20:35 | 107 | | 110 | | 122 | | 110 | | 107 | | | |
| 950470 | SPOB-12R2 | 20:41 | 108 | | 109 | | 129 * | | 112 | | 108 | | | |
| 950471 | SPMW-11R2 | 20:47 | 109 | | 110 | | 133 * | | 116 | | 112 | | | |
| 950472 | SPMW-12 | 20:53 | 112 | | 114 | | 134 * | | 118 | | 116 | | | |
| 950473 | SPMW-13 | 20:59 | 120 | | 116 | | 133 * | | 120 | | 118 | | | |
| 950474 | SPMW-04 | 21:05 | 117 | | 114 | | 138 * | | 121 | | 118 | | | |
| CCV7 | CCV7 | 21:10 | 108 | | 99 | | 105 | | 107 | | 106 | | | |
| CCB7 | CCB7 | 21:16 | 109 | | 100 | | 104 | | 108 | | 107 | | | |
| 950475 | SPIS-24 | 21:22 | 115 | | 111 | | 135 * | | 115 | | 112 | | | |
| 950476 | SPIS-24 DUP | 21:28 | 113 | | 111 | | 131 * | | 113 | | 114 | | | |
| 950477 | SPIS-23 | 21:34 | 119 | | 114 | | 143 * | | 124 | | 120 | | | |
| 950477D | SPIS-23D | 21:40 | 121 | | 110 | | 138 * | | 121 | | 118 | | | |
| 950477S | SPIS-23S | 21:46 | 116 | | 109 | | 137 * | | 119 | | 119 | | | |
| 950477A | SPIS-23A | 21:52 | 116 | | 109 | | 139 * | | 118 | | 118 | | | |
| 950477L | SPIS-23L | 21:58 | 116 | | 103 | | 120 | | 116 | | 119 | | | |
| CCV8 | CCV8 | 22:16 | 112 | | 95 | | 108 | | 107 | | 110 | | | |
| CCB8 | CCB8 | 22:22 | 111 | | 96 | | 111 | | 111 | | 113 | | | |
| CRDL4 | CRDL4 | 22:52 | 111 | | 96 | | 111 | | 111 | | 113 | | | |
| CCV9 | CCV9 | 22:58 | 108 | | 93 | | 107 | | 109 | | 109 | | | |

METALS

15-IN

ICP-MS INTERNAL STANDARDS RELATIVE INTENSITY SUMMARY

Lab Name: Columbia Analytical Services Contract: r2634493
 Lab Code: _____ Case No.: _____ NRAS No. _____ SDG NO.: 950030
 ICP-MS Instrument ID: PE ICPMS Start Date: 11/13/2006 End Date: 11/13/2006

| Sample No. | Client ID | Time | Internal Standards %RI For: | | | | | | | | | | | |
|------------|-----------|-------|-----------------------------|---|---------------|---|---------------|---|---------------|---|---------------|---|---------|---|
| | | | Element Tb | Q | Element Ge | Q | Element Sc | Q | Element In | Q | Element Ho | Q | Element | Q |
| CCB9 | CCB9 | 23:04 | 110 | | 95 | | 110 | | 107 | | 110 | | | |

METALS

15-IN

ICP-MS INTERNAL STANDARDS RELATIVE INTENSITY SUMMARY

Lab Name: Columbia Analytical Services Contract: r2634493

Lab Code: _____ Case No.: _____ NRAS No. _____ SDG NO.: 950030

ICP-MS Instrument ID: PE ICPMS Start Date: 11/17/2006 End Date: 11/17/2006

| Sample No. | Client ID | Time | Internal Standards %RI For: | | | | | | | | | | | |
|-------------|-------------|-------|-----------------------------|---|---------------|---|---------------|---|---------------|---|---------------|---|---------|---|
| | | | Element Tb | Q | Element Ge | Q | Element Sc | Q | Element In | Q | Element Ho | Q | Element | Q |
| Blank | Blank | 15:28 | 100 | | 100 | | 100 | | 100 | | 100 | | | |
| Standard 1 | Standard 1 | 15:34 | 101 | | 103 | | 103 | | 101 | | 101 | | | |
| Standard 2 | Standard 2 | 15:40 | 99 | | 99 | | 98 | | 100 | | 98 | | | |
| Standard 3 | Standard 3 | 15:46 | 96 | | 100 | | 98 | | 98 | | 96 | | | |
| ICV2 | ICV2 | 15:51 | 99 | | 98 | | 100 | | 98 | | 95 | | | |
| ICB2 | ICB2 | 15:57 | 96 | | 97 | | 96 | | 97 | | 94 | | | |
| CRDL1 | CRDL1 | 16:03 | 96 | | 98 | | 98 | | 100 | | 97 | | | |
| ICS-A1 | ICS-A1 | 16:09 | 96 | | 109 | | 99 | | 98 | | 95 | | | |
| ICS-AB1 | ICS-AB1 | 16:15 | 96 | | 109 | | 100 | | 99 | | 93 | | | |
| CCV1 | CCV1 | 16:21 | 95 | | 103 | | 98 | | 99 | | 95 | | | |
| CCB1 | CCB1 | 16:27 | 97 | | 100 | | 99 | | 96 | | 93 | | | |
| QC Std 8 | QC Std 8 | 16:33 | 94 | | 101 | | 96 | | 97 | | 94 | | | |
| PBW-M399014 | PBW | 16:39 | 94 | | 101 | | 97 | | 98 | | 96 | | | |
| LCSW-M39901 | LCSW | 16:45 | 98 | | 107 | | 109 | | 104 | | 98 | | | |
| 950466 | SPMW-03 | 16:51 | 96 | | 107 | | 119 | | 101 | | 95 | | | |
| 950467 | SPMW-07 | 16:57 | 95 | | 106 | | 101 | | 98 | | 94 | | | |
| 950467 | SPMW-07 | 17:03 | 97 | | 113 | | 116 | | 101 | | 96 | | | |
| 950468 | SPMW-07 DUP | 17:09 | 95 | | 110 | | 102 | | 102 | | 96 | | | |
| 950468 | SPMW-07 DUP | 17:15 | 98 | | 116 | | 119 | | 105 | | 97 | | | |
| 950469 | SPOB-34 | 17:21 | 98 | | 109 | | 106 | | 103 | | 97 | | | |
| 950469 | SPOB-34 | 17:27 | 98 | | 115 | | 118 | | 103 | | 97 | | | |
| CCV2 | CCV2 | 17:33 | 98 | | 106 | | 105 | | 104 | | 97 | | | |
| CCB2 | CCB2 | 17:39 | 96 | | 104 | | 102 | | 102 | | 97 | | | |
| 950470 | SPOB-12R2 | 17:45 | 99 | | 110 | | 128 | * | 103 | | 98 | | | |
| 950471 | SPMW-11R2 | 17:51 | 100 | | 111 | | 128 | * | 104 | | 97 | | | |
| 950472 | SPMW-12 | 17:57 | 100 | | 112 | | 127 | * | 105 | | 100 | | | |
| 950473 | SPMW-13 | 18:03 | 100 | | 107 | | 105 | | 104 | | 100 | | | |
| 950473 | SPMW-13 | 18:09 | 103 | | 113 | | 122 | | 108 | | 101 | | | |
| 950474 | SPMW-04 | 18:15 | 103 | | 111 | | 131 | * | 108 | | 100 | | | |
| 950475 | SPIS-24 | 18:21 | 100 | | 104 | | 104 | | 103 | | 100 | | | |
| 950475 | SPIS-24 | 18:26 | 99 | | 107 | | 123 | | 104 | | 100 | | | |
| 950476 | SPIS-24 DUP | 18:32 | 102 | | 105 | | 109 | | 105 | | 101 | | | |
| CCV3 | CCV3 | 18:38 | 101 | | 103 | | 104 | | 103 | | 100 | | | |
| CCB3 | CCB3 | 18:44 | 99 | | 101 | | 103 | | 104 | | 100 | | | |
| 950476 | SPIS-24 DUP | 18:50 | 103 | | 107 | | 122 | | 105 | | 102 | | | |
| 950477 | SPIS-23 | 18:56 | 100 | | 104 | | 107 | | 106 | | 102 | | | |
| 950477D | SPIS-23D | 19:02 | 102 | | 101 | | 104 | | 104 | | 100 | | | |
| 950477S | SPIS-23S | 19:08 | 102 | | 100 | | 104 | | 105 | | 101 | | | |
| 950477A | SPIS-23A | 19:14 | 99 | | 102 | | 104 | | 105 | | 100 | | | |
| 950477L | SPIS-23L | 19:20 | 100 | | 99 | | 101 | | 101 | | 99 | | | |
| 950477 | SPIS-23 | 19:26 | 105 | | 111 | | 123 | | 110 | | 103 | | | |
| 950477D | SPIS-23D | 19:32 | 103 | | 109 | | 128 | * | 112 | | 105 | | | |
| 950477S | SPIS-23S | 19:38 | 106 | | 108 | | 125 | | 109 | | 104 | | | |
| ICV4 | CCV4 | 19:44 | 103 | | 100 | | 105 | | 105 | | 101 | | | |
| ICB4 | CCB4 | 19:50 | 100 | | 98 | | 103 | | 106 | | 103 | | | |

METALS

15-IN

ICP-MS INTERNAL STANDARDS RELATIVE INTENSITY SUMMARY

Lab Name: Columbia Analytical Services Contract: r2634493
 Lab Code: _____ Case No.: _____ NRAS No. _____ SDG NO.: 950030
 ICP-MS Instrument ID: PE ICPMS Start Date: 11/17/2006 End Date: 11/17/2006

| Sample No. | Client ID | Time | Internal Standards %RI For: | | | | | | | | | | | |
|------------|-----------|-------|-----------------------------|---|---------------|---|---------------|---|---------------|---|---------------|---|---------|---|
| | | | Element Tb | Q | Element Ge | Q | Element Sc | Q | Element In | Q | Element Ho | Q | Element | Q |
| 950477A | SPIS-23A | 19:56 | 100 | | 105 | | 122 | | 108 | | 102 | | | |
| 950477L | SPIS-23L | 20:02 | 106 | | 102 | | 108 | | 106 | | 104 | | | |
| CRDL2 | CRDL2 | 20:50 | 104 | | 93 | | 101 | | 104 | | 103 | | | |
| HLCCV2 | HLCCV2 | 20:56 | 95 | | 90 | | 96 | | 99 | | 96 | | | |
| CCV5 | CCV5 | 21:02 | 101 | | 92 | | 98 | | 98 | | 99 | | | |
| CCB5 | CCB5 | 21:08 | 100 | | 92 | | 101 | | 99 | | 100 | | | |

METALS

15-IN

ICP-MS INTERNAL STANDARDS RELATIVE INTENSITY SUMMARY

Lab Name: Columbia Analytical Services Contract: r2634493
 Lab Code: _____ Case No.: _____ NRAS No. _____ SDG NO.: 950030
 CP-MS Instrument ID: PE ICPMS Start Date: 11/20/2006 End Date: 11/20/2006

| Sample No. | Client ID | Time | Internal Standards %RI For: | | | | | | | | | | | |
|------------|-------------|-------|-----------------------------|---|---------------|---|---------------|---|---------------|---|---------------|---|---------|---|
| | | | Element Tb | Q | Element Ge | Q | Element Sc | Q | Element In | Q | Element Ho | Q | Element | Q |
| Blank | Blank | 09:28 | 100 | | 100 | | 100 | | 100 | | 100 | | | |
| Standard 1 | Standard 1 | 09:34 | 94 | | 98 | | 101 | | 99 | | 100 | | | |
| Standard 2 | Standard 2 | 09:40 | 97 | | 97 | | 97 | | 97 | | 98 | | | |
| Standard 3 | Standard 3 | 09:46 | 95 | | 96 | | 97 | | 95 | | 97 | | | |
| ICV3 | ICV3 | 09:52 | 93 | | 94 | | 96 | | 93 | | 94 | | | |
| ICB3 | ICB3 | 09:58 | 93 | | 94 | | 95 | | 97 | | 95 | | | |
| CRDL1 | CRDL1 | 10:04 | 95 | | 95 | | 96 | | 95 | | 96 | | | |
| ICS-A1 | ICS-A1 | 10:10 | 90 | | 103 | | 98 | | 95 | | 91 | | | |
| ICS-AB1 | ICS-AB1 | 10:16 | 88 | | 102 | | 98 | | 94 | | 91 | | | |
| CCV1 | CCV1 | 10:22 | 91 | | 97 | | 96 | | 94 | | 91 | | | |
| CCB1 | CCB1 | 10:28 | 90 | | 99 | | 97 | | 97 | | 94 | | | |
| QC Std 8 | QC Std 8 | 10:34 | 90 | | 94 | | 93 | | 91 | | 89 | | | |
| 950470 | SPOB-12R2 | 10:52 | 93 | | 102 | | 118 | | 97 | | 92 | | | |
| 950472 | SPMW-12 | 11:04 | 94 | | 107 | | 120 | | 99 | | 95 | | | |
| 950473 | SPMW-13 | 11:10 | 98 | | 112 | | 119 | | 106 | | 98 | | | |
| 950475 | SPIS-24 | 11:22 | 96 | | 108 | | 119 | | 103 | | 99 | | | |
| 950476 | SPIS-24 DUP | 11:28 | 97 | | 108 | | 120 | | 106 | | 100 | | | |
| CCV2 | CCV2 | 11:34 | 96 | | 100 | | 101 | | 99 | | 96 | | | |
| CCB2 | CCB2 | 11:40 | 97 | | 98 | | 99 | | 100 | | 97 | | | |
| 950471 | SPMW-11R2 | 12:53 | 96 | | 94 | | 100 | | 99 | | 98 | | | |
| 950474 | SPMW-04 | 12:59 | 98 | | 95 | | 100 | | 100 | | 97 | | | |
| 950477 | SPIS-23 | 13:05 | 95 | | 94 | | 102 | | 99 | | 97 | | | |
| 950477D | SPIS-23D | 13:11 | 95 | | 95 | | 99 | | 102 | | 98 | | | |
| CCV3 | CCV3 | 13:17 | 94 | | 93 | | 95 | | 99 | | 95 | | | |
| CCB3 | CCB3 | 13:23 | 94 | | 94 | | 95 | | 97 | | 96 | | | |
| 950477S | SPIS-23S | 13:29 | 96 | | 91 | | 99 | | 98 | | 96 | | | |
| 950477A | SPIS-23A | 13:35 | 94 | | 94 | | 100 | | 98 | | 98 | | | |
| 950477L | SPIS-23L | 13:40 | 93 | | 93 | | 96 | | 99 | | 97 | | | |
| CRDL2 | CRDL2 | 13:46 | 95 | | 90 | | 96 | | 98 | | 95 | | | |
| HLCCV2 | HLCCV2 | 13:52 | 96 | | 94 | | 98 | | 98 | | 99 | | | |
| CCV4 | CCV4 | 13:58 | 91 | | 90 | | 95 | | 95 | | 95 | | | |
| CCB4 | CCB4 | 14:04 | 91 | | 88 | | 92 | | 96 | | 94 | | | |

METALS

15-IN

ICP-MS INTERNAL STANDARDS RELATIVE INTENSITY SUMMARY

Lab Name: Columbia Analytical Services Contract: r2634493
 Lab Code: _____ Case No.: _____ NRAS No. _____ SDG NO.: 950030
 CP-MS Instrument ID: PE ICPMS Start Date: 11/21/2006 End Date: 11/21/2006

| Sample No. | Client ID | Time | Internal Standards %RI For: | | | | | | | | | | | |
|-------------|------------|-------|-----------------------------|---|---------------|---|---------------|---|---------------|---|---------------|---|---------|---|
| | | | Element Tb | Q | Element Ge | Q | Element Sc | Q | Element In | Q | Element Ho | Q | Element | Q |
| Blank | Blank | 09:33 | 100 | | 100 | | 100 | | 100 | | 100 | | | |
| Standard 1 | Standard 1 | 09:38 | 96 | | 98 | | 95 | | 101 | | 99 | | | |
| Standard 2 | Standard 2 | 09:44 | 99 | | 97 | | 98 | | 95 | | 97 | | | |
| Standard 3 | Standard 3 | 09:50 | 98 | | 100 | | 99 | | 96 | | 97 | | | |
| ICV4 | ICV4 | 09:56 | 93 | | 96 | | 97 | | 93 | | 95 | | | |
| ICB4 | ICB4 | 10:02 | 99 | | 98 | | 99 | | 96 | | 97 | | | |
| CRDL1 | CRDL1 | 10:08 | 102 | | 98 | | 99 | | 99 | | 96 | | | |
| ICS-A1 | ICS-A1 | 10:14 | 92 | | 108 | | 100 | | 94 | | 93 | | | |
| ICS-AB1 | ICS-AB1 | 10:20 | 94 | | 112 | | 104 | | 99 | | 95 | | | |
| CCV1 | CCV1 | 10:26 | 94 | | 102 | | 99 | | 100 | | 95 | | | |
| CCB1 | CCB1 | 10:32 | 97 | | 104 | | 99 | | 98 | | 95 | | | |
| QC Std 8 | QC Std 8 | 10:38 | 95 | | 99 | | 98 | | 95 | | 93 | | | |
| PBW-M399014 | PBW | 10:44 | 96 | | 100 | | 101 | | 98 | | 95 | | | |
| LCSW-M39901 | LCSW | 10:50 | 98 | | 105 | | 103 | | 102 | | 97 | | | |
| 950030 | SPMW-01 | 11:02 | 102 | | 107 | | 122 | | 104 | | 103 | | | |
| 950030L | SPMW-01L | 11:26 | 101 | | 108 | | 106 | | 99 | | 98 | | | |
| 950031 | SPMW-05 | 11:32 | 104 | | 112 | | 126 * | | 104 | | 100 | | | |
| CCV2 | CCV2 | 11:38 | 96 | | 102 | | 100 | | 99 | | 96 | | | |
| CCB2 | CCB2 | 11:44 | 98 | | 104 | | 100 | | 97 | | 99 | | | |
| 950032 | SPMW-10R | 11:50 | 102 | | 111 | | 127 * | | 103 | | 103 | | | |
| 950033 | SPMW-02 | 11:56 | 102 | | 106 | | 116 | | 104 | | 100 | | | |
| 950034 | SPMW-06R | 12:02 | 101 | | 109 | | 123 | | 101 | | 100 | | | |
| 950035 | SPMW-08 | 12:08 | 103 | | 113 | | 118 | | 107 | | 102 | | | |
| 950036 | SPMW-09 | 12:14 | 109 | | 116 | | 137 * | | 106 | | 112 | | | |
| CRDL2 | CRDL2 | 12:19 | 101 | | 111 | | 106 | | 106 | | 104 | | | |
| CCV3 | CCV3 | 12:31 | 99 | | 106 | | 102 | | 100 | | 101 | | | |
| CCB3 | CCB3 | 12:37 | 101 | | 102 | | 99 | | 99 | | 98 | | | |
| 950030 | SPMW-01 | 12:49 | 99 | | 103 | | 105 | | 103 | | 99 | | | |
| CCV4 | CCV4 | 13:07 | 96 | | 105 | | 102 | | 99 | | 97 | | | |
| CCB4 | CCB4 | 13:13 | 100 | | 100 | | 98 | | 98 | | 96 | | | |
| 950030L | SPMW-01L | 13:24 | 95 | | 101 | | 96 | | 98 | | 95 | | | |
| 950031 | SPMW-05 | 13:30 | 99 | | 102 | | 100 | | 99 | | 97 | | | |
| 950032 | SPMW-10R | 13:36 | 98 | | 101 | | 103 | | 99 | | 96 | | | |
| 950034 | SPMW-06R | 13:42 | 95 | | 99 | | 96 | | 98 | | 97 | | | |
| 950034 | SPMW-06R | 13:48 | 101 | | 104 | | 101 | | 99 | | 98 | | | |
| 950035 | SPMW-08 | 13:54 | 98 | | 99 | | 100 | | 97 | | 97 | | | |
| 950036 | SPMW-09 | 14:00 | 95 | | 100 | | 97 | | 97 | | 97 | | | |
| 950036 | SPMW-09 | 14:06 | 95 | | 100 | | 97 | | 97 | | 97 | | | |
| CCV5 | CCV5 | 14:12 | 95 | | 98 | | 97 | | 95 | | 95 | | | |
| CCB5 | CCB5 | 14:18 | 96 | | 98 | | 98 | | 99 | | 98 | | | |
| 950036 | SPMW-09 | 14:24 | 99 | | 102 | | 111 | | 101 | | 99 | | | |
| CRDL3 | CRDL3 | 14:30 | 99 | | 105 | | 103 | | 102 | | 100 | | | |
| HLCCV2 | HLCCV2 | 14:36 | 92 | | 96 | | 95 | | 94 | | 91 | | | |
| CCV6 | CCV6 | 14:42 | 93 | | 96 | | 94 | | 96 | | 92 | | | |
| CCB6 | CCB6 | 14:48 | 95 | | 100 | | 99 | | 97 | | 97 | | | |

METALS

15-IN

ICP-MS INTERNAL STANDARDS RELATIVE INTENSITY SUMMARY

Lab Name: Columbia Analytical Services Contract: r2634493
 Lab Code: _____ Case No.: _____ NRAS No. _____ SDG NO.: 950030
 ICP-MS Instrument ID: PE ICPMS Start Date: 11/21/2006 End Date: 11/21/2006

| Sample No. | Client ID | Time | Internal Standards %RI For: | | | | | | | | | | | |
|------------|-----------|-------|-----------------------------|---|---------------|---|---------------|---|---------------|---|---------------|---|---------|---|
| | | | Element Tb | Q | Element Ge | Q | Element Sc | Q | Element In | Q | Element Ho | Q | Element | Q |
| 950032 | SPMW-10R | 15:04 | 95 | | 98 | | 98 | | 94 | | 94 | | | |
| CRDL4 | CRDL4 | 15:10 | 99 | | 98 | | 97 | | 96 | | 97 | | | |
| CCV7 | CCV7 | 15:15 | 95 | | 96 | | 94 | | 93 | | 94 | | | |
| CCB7 | CCB7 | 15:21 | 94 | | 94 | | 94 | | 96 | | 94 | | | |

METALS

15-IN

ICP-MS INTERNAL STANDARDS RELATIVE INTENSITY SUMMARY

lab Name: Columbia Analytical Services Contract: r2634493lab Code: _____ Case No.: _____ NRAS No. _____ SDG NO.: 950030CP-MS Instrument ID: PE ICPMS Start Date: 11/22/2006 End Date: 11/22/2006

| Sample No. | Client ID | Time | Internal Standards %RI For: | | | | | | | | | | | |
|-------------|------------|-------|-----------------------------|---|---------------|---|---------------|---|---------------|---|---------------|---|---------|---|
| | | | Element Tb | Q | Element Ge | Q | Element Sc | Q | Element In | Q | Element Ho | Q | Element | Q |
| Blank | Blank | 09:48 | 100 | | 100 | | 100 | | 100 | | 100 | | | |
| Standard 1 | Standard 1 | 09:54 | 96 | | 98 | | 98 | | 100 | | 99 | | | |
| Standard 2 | Standard 2 | 10:00 | 94 | | 99 | | 98 | | 101 | | 99 | | | |
| Standard 3 | Standard 3 | 10:06 | 95 | | 96 | | 98 | | 98 | | 95 | | | |
| ICV5 | ICV5 | 10:12 | 93 | | 92 | | 95 | | 96 | | 93 | | | |
| ICB5 | ICB5 | 10:18 | 93 | | 97 | | 100 | | 100 | | 97 | | | |
| CRDL1 | CRDL1 | 10:24 | 96 | | 96 | | 97 | | 97 | | 96 | | | |
| ICS-A1 | ICS-A1 | 10:30 | 95 | | 108 | | 103 | | 97 | | 93 | | | |
| ICS-AB1 | ICS-AB1 | 10:36 | 95 | | 113 | | 110 | | 101 | | 94 | | | |
| CCV1 | CCV1 | 10:42 | 93 | | 104 | | 107 | | 102 | | 95 | | | |
| CCB1 | CCB1 | 10:48 | 96 | | 108 | | 107 | | 102 | | 96 | | | |
| QC Std 8 | QC Std 8 | 10:54 | 94 | | 100 | | 100 | | 98 | | 93 | | | |
| PBW-M399014 | PBW | 11:00 | 96 | | 101 | | 101 | | 99 | | 93 | | | |
| LCSW-M39901 | LCSW | 11:06 | 98 | | 111 | | 113 | | 106 | | 100 | | | |
| CCV2 | CCV2 | 11:54 | 97 | | 106 | | 106 | | 103 | | 95 | | | |
| CCB2 | CCB2 | 11:59 | 99 | | 110 | | 107 | | 104 | | 99 | | | |
| 950033 | SPMW-02 | 12:05 | 97 | | 110 | | 110 | | 104 | | 99 | | | |
| 950033 | SPMW-02 | 12:11 | 98 | | 112 | | 121 | | 109 | | 98 | | | |
| 950034 | SPMW-06R | 12:17 | 99 | | 114 | | 130 * | | 106 | | 98 | | | |
| 950035 | SPMW-08 | 12:23 | 100 | | 119 | | 126 * | | 109 | | 97 | | | |
| 950036 | SPMW-09 | 12:29 | 99 | | 114 | | 112 | | 108 | | 99 | | | |
| CRDL2 | CRDL2 | 12:35 | 98 | | 108 | | 107 | | 106 | | 97 | | | |
| HLCCV2 | HLCCV2 | 12:41 | 95 | | 106 | | 109 | | 104 | | 95 | | | |
| CRDL3 | CRDL3 | 12:47 | 96 | | 108 | | 109 | | 107 | | 98 | | | |
| CCV3 | CCV3 | 12:53 | 96 | | 104 | | 105 | | 104 | | 94 | | | |
| CCB3 | CCB3 | 12:59 | 96 | | 104 | | 107 | | 109 | | 98 | | | |
| CCV4 | CCV4 | 13:47 | 95 | | 101 | | 101 | | 99 | | 94 | | | |
| CCB4 | CCB4 | 13:53 | 94 | | 104 | | 105 | | 104 | | 97 | | | |
| 950030 | SPMW-01 | 14:04 | 98 | | 114 | | 133 * | | 115 | | 99 | | | |
| 950030L | SPMW-01L | 14:28 | 98 | | 109 | | 111 | | 106 | | 95 | | | |
| 950031 | SPMW-05 | 14:34 | 96 | | 117 | | 135 * | | 107 | | 96 | | | |
| 950032 | SPMW-10R | 14:40 | 99 | | 121 | | 140 * | | 111 | | 100 | | | |
| CRDL4 | CRDL4 | 14:46 | 99 | | 111 | | 109 | | 105 | | 99 | | | |
| CCV5 | CCV5 | 14:52 | 97 | | 107 | | 105 | | 103 | | 96 | | | |
| CCB5 | CCB5 | 14:58 | 97 | | 108 | | 109 | | 106 | | 99 | | | |

Metals Cover Page

Analyst: SJewto

Date: 11/13/06

Instrument: ELAN

Data File: 111306A

Reviewed By: SD 11/14/06

Entered By: SD 11/14/06

Approval: DCB 11/15/06

| Starlims Run # | Analytes Used | Batch ID | Method | Failed Analytes | Comments/ Problems |
|----------------|---------------|----------|--------|-----------------|--------------------|
| 137370 | As Mn | M3990125 | 6020 | | |
| | | | | | |
| | | | | | |
| 137371 | As Cd Cu Ni | M3990131 | 6020 | Mn Cu | 950474,477 Cd |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

Package Data:

| Client Sub# | Package | Analytes Used | Failed Metals | Batch ID | Stds Attached? | Transferred To LIMS | Raw Data Copied? |
|-------------|---------|---------------|---------------|----------|----------------|---------------------|------------------|
| 34171 | 5/ASP | As Mn | | M3990125 | Yes / No | MARRS / Run above | Yes / No |
| | 5/ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| 34493 | 5/ASP | As Cd Cu Ni | | M3990131 | Yes / No | MARRS / Run above | Yes / No |
| | 5/ASP | 950474,477 Cd | | | Yes / No | MARRS / Run above | Yes / No |
| | 5/ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5/ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5/ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5/ASP | | | | Yes / No | MARRS / Run above | Yes / No |

Daily Performance Report

Sample ID: Sample

Sample Date/Time: Monday, November 13, 2006 09:22:26

Sample Description:

Method File: c:\elandata\Method\EPA DAILY.mth

Dataset File: c:\elandata\Dataset\Daily2006\Sample.235

Tuning File: c:\elandata\Tuning\lepa.tun

Optimization File: c:\elandata\Optimize\lepa2.dac

Dual Detector Mode: Dual

Acq. Dead Time(ns): 60

Current Dead Time (ns): 60

Summary

| Analyte | Mass | Meas. Intens. | Mean | Net Intens. | Mean | Net Intens. SD | Net Intens. RSD |
|---------|-------|---------------|----------|-------------|----------|----------------|-----------------|
| Mg | 24.0 | | 47098.0 | 47098.019 | 303.127 | 0.6 | |
| Rh | 102.9 | | 376577.7 | 376577.691 | 2223.957 | 0.6 | |
| In | 114.9 | | 379778.7 | 379778.676 | 2284.919 | 0.6 | |
| Pb | 208.0 | | 147664.9 | 147664.944 | 1469.767 | 1.0 | |
| U | 238.1 | | 291073.4 | 291073.416 | 3106.844 | 1.1 | |
| [> Ba | 137.9 | | 291192.9 | 291192.915 | 2385.007 | 0.8 | |
| [Ba++ | 69.0 | | 9308.3 | 0.032 | 0.001 | 2.1 | |
| [> Ce | 139.9 | | 405606.0 | 405606.020 | 3555.242 | 0.9 | |
| [CeO | 155.9 | | 7711.3 | 0.019 | 0.001 | 2.9 | |
| Bkgd | 220.0 | | 40.8 | 40.804 | 11.146 | 27.3 | |

Current Optimization File Data

| Current Value | Description |
|---------------|-------------------------|
| 1.01 | Nebulizer Gas Flow |
| 8.00 | Lens Voltage |
| 1500.00 | ICP RF Power |
| -1832.50 | Analog Stage Voltage |
| 1017.50 | Pulse Stage Voltage |
| 70.00 | Discriminator Threshold |
| -2.50 | AC Rod Offset |

Current Autolens Data

| Analyte | Mass | Num of Pts | DAC Value | Maximum Intensity |
|---------|------|------------|-----------|-------------------|
| Be | 9 | 29 | 6.0 | 11347.2 |
| Co | 59 | 29 | 7.8 | 163395.3 |
| In | 115 | 29 | 8.0 | 266809.4 |

Elan 9000 Method 6020 - Summary Report

Sample ID: Blank

Sample Date/Time: Monday, November 13, 2006 13:39:03

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\Blank.001

Send to 111306

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 63.001 | 6.9 | | | | | ug/L |
| Al | 27 | 2334.350 | 3.1 | | | | | ug/L |
| > Sc | 45 | 381869.082 | 0.6 | | | | | ug/L |
| V | 51 | 4488.603 | 4.4 | | | | | ug/L |
| Cr | 52 | 15368.650 | 2.1 | | | | | ug/L |
| Cr | 53 | 814.381 | 3.3 | | | | | ug/L |
| Mn | 55 | 494.020 | 6.9 | | | | | ug/L |
| Co | 59 | 188.671 | 15.8 | | | | | ug/L |
| Ni | 60 | 136.669 | 7.9 | | | | | ug/L |
| Ni | 62 | 143.669 | 5.3 | | | | | ug/L |
| Cu | 63 | 212.338 | 4.4 | | | | | ug/L |
| Cu | 65 | 189.671 | 5.0 | | | | | ug/L |
| Zn | 66 | 1515.486 | 0.5 | | | | | ug/L |
| Zn | 67 | 342.344 | 10.8 | | | | | ug/L |
| Zn | 68 | 1170.427 | 2.6 | | | | | ug/L |
| > Ge | 72 | 244883.968 | 1.0 | | | | | ug/L |
| As | 75 | 124.002 | 9.5 | | | | | ug/L |
| Se | 77 | 216.736 | 0.5 | | | | | ug/L |
| Se | 78 | 16119.238 | 0.7 | | | | | mg/L |
| Se | 82 | 1872.010 | 0.4 | | | | | ug/L |
| Kr | 83 | 1902.236 | 0.9 | | | | | mg/L |
| Y | 89 | 408188.389 | 3.0 | | | | | ug/L |
| Mo | 95 | 112.002 | 7.1 | | | | | ug/L |
| Mo | 97 | 64.001 | 10.9 | | | | | ug/L |
| Mo | 98 | 98.282 | 4.3 | | | | | ug/L |
| Rh | 103 | 340052.119 | 0.9 | | | | | ug/L |
| Ag | 107 | 91.335 | 8.8 | | | | | ug/L |
| Ag | 109 | 75.668 | 14.5 | | | | | ug/L |
| Cd | 111 | 218.275 | 11.2 | | | | | ug/L |
| Cd | 114 | 58.957 | 7.1 | | | | | ug/L |
| > In | 115 | 358352.924 | 2.5 | | | | | ug/L |
| Sb | 121 | 107.668 | 2.8 | | | | | ug/L |
| Sb | 123 | 79.665 | 26.4 | | | | | ug/L |
| Ba | 135 | 46.667 | 2.5 | | | | | ug/L |
| Ba | 137 | 47.001 | 16.6 | | | | | ug/L |
| > Tb | 159 | 411268.087 | 2.5 | | | | | ug/L |
| > Ho | 165 | 390096.908 | 0.3 | | | | | ug/L |
| Tl | 203 | 60.001 | 1.7 | | | | | ug/L |
| Tl | 205 | 78.001 | 5.9 | | | | | ug/L |
| Pb | 208 | 320.672 | 3.2 | | | | | ug/L |

Sample ID: Blank

Report Date/Time: Monday, November 13, 2006 13:42:04

Page 1

| | | | | | |
|---|----|-----|--------|------|------|
| | Pb | 206 | 87.335 | 12.7 | ug/L |
| L | Pb | 207 | 77.001 | 6.5 | ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 1

Sample Date/Time: Monday, November 13, 2006 13:44:59

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\Standard 1.002

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 11136.549 | 1.8 | 63.001 | 10.00000 | 0.222 | 2.2 | ug/L |
| Al | 27 | 74017.759 | 2.1 | 2334.350 | 10.00000 | 0.227 | 2.3 | ug/L |
| Sc | 45 | 372969.477 | 1.0 | 381869.082 | | | | ug/L |
| V | 51 | 174855.607 | 2.0 | 4488.603 | 10.00000 | 0.225 | 2.3 | ug/L |
| Cr | 52 | 166634.834 | 3.0 | 15368.650 | 10.00000 | 0.250 | 2.5 | ug/L |
| Cr | 53 | 18652.713 | 2.4 | 814.381 | 10.00000 | 0.172 | 1.7 | ug/L |
| Mn | 55 | 219199.293 | 3.5 | 494.020 | 10.00000 | 0.299 | 3.0 | ug/L |
| Co | 59 | 181792.108 | 1.0 | 188.671 | 10.00000 | 0.073 | 0.7 | ug/L |
| Ni | 60 | 40661.709 | 1.2 | 136.669 | 10.00000 | 0.050 | 0.5 | ug/L |
| Ni | 62 | 6138.321 | 1.2 | 143.669 | 10.00000 | 0.154 | 1.5 | ug/L |
| Cu | 63 | 93967.149 | 1.3 | 212.338 | 10.00000 | 0.195 | 2.0 | ug/L |
| Cu | 65 | 45692.076 | 1.9 | 189.671 | 10.00000 | 0.116 | 1.2 | ug/L |
| Zn | 66 | 28441.409 | 1.4 | 1515.486 | 10.00000 | 0.173 | 1.7 | ug/L |
| Zn | 67 | 5005.554 | 3.4 | 342.344 | 10.00000 | 0.475 | 4.8 | ug/L |
| Zn | 68 | 21587.149 | 2.2 | 1170.427 | 10.00000 | 0.131 | 1.3 | ug/L |
| Ge | 72 | 240060.900 | 1.0 | 244883.968 | | | | ug/L |
| As | 75 | 32227.883 | 2.7 | 124.002 | 10.00000 | 0.321 | 3.2 | ug/L |
| Se | 77 | 2570.063 | 0.8 | 216.736 | 10.00000 | 0.029 | 0.3 | ug/L |
| Se | 78 | 23730.867 | 1.3 | 16119.238 | 10.00000 | 0.644 | 6.4 | mg/L |
| Se | 82 | 4928.257 | 2.3 | 1872.010 | 10.00000 | 0.217 | 2.2 | ug/L |
| Kr | 83 | 1803.547 | 3.4 | 1902.236 | | | | mg/L |
| Y | 89 | 398766.292 | 1.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 55065.994 | 3.0 | 112.002 | 10.00000 | 0.054 | 0.5 | ug/L |
| Mo | 97 | 34578.945 | 1.2 | 64.001 | 10.00000 | 0.177 | 1.8 | ug/L |
| Mo | 98 | 85150.785 | 0.6 | 98.282 | 10.00000 | 0.256 | 2.6 | ug/L |
| Rh | 103 | 338294.321 | 0.9 | 340052.119 | | | | ug/L |
| Ag | 107 | 145541.901 | 1.5 | 91.335 | 10.00000 | 0.238 | 2.4 | ug/L |
| Ag | 109 | 134469.641 | 1.0 | 75.668 | 10.00000 | 0.189 | 1.9 | ug/L |
| Cd | 111 | 32340.252 | 1.5 | 218.275 | 10.00000 | 0.433 | 4.3 | ug/L |
| Cd | 114 | 71391.933 | 1.1 | 58.957 | 10.00000 | 0.394 | 3.9 | ug/L |
| In | 115 | 363168.405 | 2.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 100482.186 | 0.7 | 107.668 | 10.00000 | 0.246 | 2.5 | ug/L |
| Sb | 123 | 76744.832 | 1.5 | 79.665 | 10.00000 | 0.225 | 2.3 | ug/L |
| Ba | 135 | 24371.511 | 2.5 | 46.667 | 10.00000 | 0.294 | 2.9 | ug/L |
| Ba | 137 | 41965.500 | 1.4 | 47.001 | 10.00000 | 0.207 | 2.1 | ug/L |
| Tb | 159 | 405842.826 | 1.4 | 411268.087 | | | | ug/L |
| Ho | 165 | 384614.072 | 1.8 | 390096.908 | | | | ug/L |
| Tl | 203 | 84282.944 | 1.1 | 60.001 | 10.00000 | 0.242 | 2.4 | ug/L |
| Tl | 205 | 193943.228 | 1.7 | 78.001 | 10.00000 | 0.049 | 0.5 | ug/L |
| Pb | 208 | 264733.642 | 0.5 | 320.672 | 10.00000 | 0.149 | 1.5 | ug/L |

Sample ID: Standard 1

Report Date/Time: Monday, November 13, 2006 13:48:00

Page 1

| | | | | | | | | |
|--|----|-----|-----------|-----|--------|----------|-------|----------|
| | Pb | 206 | 67526.181 | 1.2 | 87.335 | 10.00000 | 0.219 | 2.2 ug/L |
| | Pb | 207 | 57422.066 | 0.4 | 77.001 | 10.00000 | 0.157 | 1.6 ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 2

Sample Date/Time: Monday, November 13, 2006 13:50:57

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\Standard 2.003

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 22225.488 | 0.6 | 63.001 | 20.03161 | 0.274 | 1.4 | ug/L |
| Al | 27 | 260757.907 | 1.4 | 2334.350 | 21.97293 | 0.154 | 0.7 | ug/L |
| Sc | 45 | 370258.282 | 0.7 | 381869.082 | | | | ug/L |
| V | 51 | 344298.910 | 2.3 | 4488.603 | 20.01731 | 0.469 | 2.3 | ug/L |
| Cr | 52 | 306922.988 | 2.0 | 15368.650 | 19.87783 | 0.467 | 2.4 | ug/L |
| Cr | 53 | 36597.902 | 1.7 | 814.381 | 20.04027 | 0.472 | 2.4 | ug/L |
| Mn | 55 | 422007.115 | 2.3 | 494.020 | 19.92897 | 0.620 | 3.1 | ug/L |
| Co | 59 | 360553.716 | 0.9 | 188.671 | 20.04519 | 0.377 | 1.9 | ug/L |
| Ni | 60 | 80161.347 | 2.6 | 136.669 | 20.02687 | 0.827 | 4.1 | ug/L |
| Ni | 62 | 11675.958 | 0.9 | 143.669 | 19.92195 | 0.720 | 3.6 | ug/L |
| Cu | 63 | 183625.770 | 2.1 | 212.338 | 19.98993 | 0.919 | 4.6 | ug/L |
| Cu | 65 | 88155.181 | 2.2 | 189.671 | 19.94231 | 0.840 | 4.2 | ug/L |
| Zn | 66 | 53273.951 | 0.9 | 1515.486 | 19.91878 | 0.718 | 3.6 | ug/L |
| Zn | 67 | 9491.163 | 0.5 | 342.344 | 19.99923 | 0.557 | 2.8 | ug/L |
| Zn | 68 | 40055.436 | 0.5 | 1170.427 | 19.88159 | 0.636 | 3.2 | ug/L |
| Ge | 72 | 235572.815 | 2.7 | 244883.968 | | | | ug/L |
| As | 75 | 63373.386 | 1.4 | 124.002 | 20.01578 | 0.285 | 1.4 | ug/L |
| Se | 77 | 4897.772 | 1.1 | 216.736 | 20.05455 | 0.407 | 2.0 | ug/L |
| Se | 78 | 31481.363 | 0.5 | 16119.238 | 20.10579 | 0.957 | 4.8 | mg/L |
| Se | 82 | 7982.688 | 0.3 | 1872.010 | 20.07508 | 0.641 | 3.2 | ug/L |
| Kr | 83 | 1778.541 | 3.3 | 1902.236 | | | | mg/L |
| Y | 89 | 395527.008 | 2.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 110613.739 | 0.7 | 112.002 | 20.06667 | 0.162 | 0.8 | ug/L |
| Mo | 97 | 67391.588 | 3.2 | 64.001 | 19.94426 | 0.713 | 3.6 | ug/L |
| Mo | 98 | 168807.694 | 1.5 | 98.282 | 20.01031 | 0.237 | 1.2 | ug/L |
| Rh | 103 | 330210.868 | 1.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 283494.706 | 1.2 | 91.335 | 19.93895 | 0.199 | 1.0 | ug/L |
| Ag | 109 | 264736.889 | 1.8 | 75.668 | 19.98196 | 0.380 | 1.9 | ug/L |
| Cd | 111 | 62522.479 | 1.5 | 218.275 | 19.91910 | 0.241 | 1.2 | ug/L |
| Cd | 114 | 138908.564 | 0.7 | 58.957 | 19.93360 | 0.193 | 1.0 | ug/L |
| In | 115 | 359085.230 | 0.4 | 358352.924 | | | | ug/L |
| Sb | 121 | 193836.022 | 1.5 | 107.668 | 19.90023 | 0.243 | 1.2 | ug/L |
| Sb | 123 | 148896.739 | 0.6 | 79.665 | 19.92399 | 0.189 | 0.9 | ug/L |
| Ba | 135 | 47648.646 | 0.5 | 46.667 | 20.03427 | 0.270 | 1.3 | ug/L |
| Ba | 137 | 80952.449 | 0.7 | 47.001 | 19.97935 | 0.423 | 2.1 | ug/L |
| Tb | 159 | 393702.630 | 1.5 | 411268.087 | | | | ug/L |
| Ho | 165 | 372730.456 | 0.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 161832.962 | 0.9 | 60.001 | 19.96288 | 0.260 | 1.3 | ug/L |
| Tl | 205 | 375365.373 | 2.4 | 78.001 | 19.99511 | 0.497 | 2.5 | ug/L |
| Pb | 208 | 514624.588 | 1.1 | 320.672 | 20.01365 | 0.298 | 1.5 | ug/L |

Sample ID: Standard 2

Report Date/Time: Monday, November 13, 2006 13:53:58

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 133312.165 | 2.1 | 87.335 | 20.07518 | 0.491 | 2.4 ug/L |
| | Pb | 207 | 111603.566 | 1.5 | 77.001 | 20.01319 | 0.391 | 2.0 ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 3

Sample Date/Time: Monday, November 13, 2006 13:56:55

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\Standard 3.004

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 109618.767 | 1.3 | 63.001 | 99.95484 | 0.568 | 0.6 | ug/L |
| Al | 27 | 642093.954 | 3.0 | 2334.350 | 96.16474 | 3.008 | 3.1 | ug/L |
| > Sc | 45 | 370056.253 | 0.7 | 381869.082 | | | | ug/L |
| V | 51 | 1588651.424 | 3.5 | 4488.603 | 99.66122 | 3.426 | 3.4 | ug/L |
| Cr | 52 | 1398378.989 | 2.3 | 15368.650 | 99.70894 | 2.532 | 2.5 | ug/L |
| Cr | 53 | 175263.604 | 1.7 | 814.381 | 99.88771 | 1.973 | 2.0 | ug/L |
| Mn | 55 | 1964969.113 | 0.6 | 494.020 | 99.56566 | 1.673 | 1.7 | ug/L |
| Co | 59 | 1714365.648 | 1.8 | 188.671 | 99.69997 | 2.594 | 2.6 | ug/L |
| Ni | 60 | 385139.216 | 1.7 | 136.669 | 99.75006 | 1.444 | 1.4 | ug/L |
| Ni | 62 | 57497.923 | 0.6 | 143.669 | 99.88604 | 1.607 | 1.6 | ug/L |
| Cu | 63 | 880047.175 | 0.8 | 212.338 | 99.72562 | 1.482 | 1.5 | ug/L |
| Cu | 65 | 426600.065 | 1.6 | 189.671 | 99.76651 | 2.277 | 2.3 | ug/L |
| Zn | 66 | 251300.924 | 2.6 | 1515.486 | 99.73438 | 3.196 | 3.2 | ug/L |
| Zn | 67 | 43698.043 | 0.5 | 342.344 | 99.66206 | 1.072 | 1.1 | ug/L |
| Zn | 68 | 184426.306 | 2.8 | 1170.427 | 99.60410 | 2.409 | 2.4 | ug/L |
| > Ge | 72 | 238767.887 | 1.0 | 244883.968 | | | | ug/L |
| As | 75 | 309930.171 | 1.6 | 124.002 | 99.83830 | 2.302 | 2.3 | ug/L |
| Se | 77 | 23348.865 | 0.3 | 216.736 | 99.88297 | 0.706 | 0.7 | ug/L |
| Se | 78 | 90847.915 | 1.7 | 16119.238 | 99.65551 | 3.048 | 3.1 | mg/L |
| Se | 82 | 32903.769 | 1.0 | 1872.010 | 99.97700 | 0.779 | 0.8 | ug/L |
| Kr | 83 | 1800.879 | 3.1 | 1902.236 | | | | mg/L |
| Y | 89 | 392801.376 | 0.5 | 408188.389 | | | | ug/L |
| Mo | 95 | 539382.967 | 2.2 | 112.002 | 99.90377 | 2.157 | 2.2 | ug/L |
| Mo | 97 | 327895.722 | 3.2 | 64.001 | 99.86266 | 3.199 | 3.2 | ug/L |
| Mo | 98 | 827314.455 | 1.3 | 98.282 | 99.91304 | 1.211 | 1.2 | ug/L |
| Rh | 103 | 319844.560 | 2.3 | 340052.119 | | | | ug/L |
| Ag | 107 | 1324580.155 | 3.2 | 91.335 | 99.65769 | 3.325 | 3.3 | ug/L |
| Ag | 109 | 1245200.434 | 1.3 | 75.668 | 99.70190 | 1.387 | 1.4 | ug/L |
| Cd | 111 | 303341.095 | 1.4 | 218.275 | 99.85299 | 1.392 | 1.4 | ug/L |
| Cd | 114 | 674877.724 | 2.0 | 58.957 | 99.85106 | 1.862 | 1.9 | ug/L |
| > In | 115 | 358760.423 | 0.1 | 358352.924 | | | | ug/L |
| Sb | 121 | 931128.880 | 1.2 | 107.668 | 99.78783 | 1.239 | 1.2 | ug/L |
| Sb | 123 | 716761.676 | 0.5 | 79.665 | 99.80382 | 0.373 | 0.4 | ug/L |
| Ba | 135 | 233025.276 | 1.0 | 46.667 | 99.98588 | 2.795 | 2.8 | ug/L |
| Ba | 137 | 397781.529 | 1.2 | 47.001 | 99.99238 | 0.786 | 0.8 | ug/L |
| > Tb | 159 | 387261.841 | 1.9 | 411268.087 | | | | ug/L |
| > Ho | 165 | 378931.947 | 0.4 | 390096.908 | | | | ug/L |
| Tl | 203 | 768498.765 | 3.3 | 60.001 | 99.65722 | 2.944 | 3.0 | ug/L |
| Tl | 205 | 1693678.779 | 1.5 | 78.001 | 99.40012 | 1.141 | 1.1 | ug/L |
| Pb | 208 | 2444831.352 | 0.9 | 320.672 | 99.67341 | 0.528 | 0.5 | ug/L |

Sample ID: Standard 3

Report Date/Time: Monday, November 13, 2006 13:59:57

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 643727.575 | 0.8 | 87.335 | 99.77048 | 0.428 | 0.4 ug/L |
| | Pb | 207 | 537503.292 | 2.2 | 77.001 | 99.74206 | 1.844 | 1.8 ug/L |

Quantitative Analysis Calibration Report

File Name: 111306A.cal
File Path: C:\elandata\System
Calibration Type: External Calibration

| Analyte | Mass | Curve Type | Slope | Intercept | Corr. Coeff. |
|---------|---------|------------------|-------|-----------|--------------|
| Be | 9.012 | Linear Thru Zero | 0.00 | 0.00 | 0.999998 |
| Al | 26.982 | Linear Thru Zero | 0.02 | 0.00 | 0.982849 |
| Sc | 44.956 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| V | 50.944 | Linear Thru Zero | 0.04 | 0.00 | 0.999885 |
| Cr | 51.941 | Linear Thru Zero | 0.04 | 0.00 | 0.999911 |
| Cr | 52.941 | Linear Thru Zero | 0.00 | 0.00 | 0.999987 |
| Mn | 54.938 | Linear Thru Zero | 0.08 | 0.00 | 0.999810 |
| Co | 58.933 | Linear Thru Zero | 0.07 | 0.00 | 0.999909 |
| Ni | 59.933 | Linear Thru Zero | 0.02 | 0.00 | 0.999937 |
| Ni | 61.928 | Linear Thru Zero | 0.00 | 0.00 | 0.999985 |
| Cu | 62.930 | Linear Thru Zero | 0.04 | 0.00 | 0.999925 |
| Cu | 64.928 | Linear Thru Zero | 0.02 | 0.00 | 0.999945 |
| Zn | 65.926 | Linear Thru Zero | 0.01 | 0.00 | 0.999928 |
| Zn | 66.927 | Linear Thru Zero | 0.00 | 0.00 | 0.999886 |
| Zn | 67.925 | Linear Thru Zero | 0.01 | 0.00 | 0.999839 |
| Ge | 71.922 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| As | 74.922 | Linear Thru Zero | 0.01 | 0.00 | 0.999974 |
| Se | 76.920 | Linear Thru Zero | 0.00 | 0.00 | 0.999986 |
| Se | 77.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999878 |
| Se | 81.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999998 |
| Kr | 82.914 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Y | 88.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Mo | 94.906 | Linear Thru Zero | 0.02 | 0.00 | 0.999990 |
| Mo | 96.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999980 |
| Mo | 97.906 | Linear Thru Zero | 0.02 | 0.00 | 0.999992 |
| Rh | 102.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ag | 106.905 | Linear Thru Zero | 0.04 | 0.00 | 0.999882 |
| Ag | 108.905 | Linear Thru Zero | 0.03 | 0.00 | 0.999911 |
| Cd | 110.904 | Linear Thru Zero | 0.01 | 0.00 | 0.999977 |
| Cd | 113.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999977 |
| In | 114.904 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Sb | 120.904 | Linear Thru Zero | 0.03 | 0.00 | 0.999952 |
| Sb | 122.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999960 |
| Ba | 134.906 | Linear Thru Zero | 0.01 | 0.00 | 1.000000 |
| Ba | 136.905 | Linear Thru Zero | 0.01 | 0.00 | 1.000000 |
| Tb | 158.925 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ho | 164.930 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Tl | 202.972 | Linear Thru Zero | 0.02 | 0.00 | 0.999882 |
| Tl | 204.975 | Linear Thru Zero | 0.04 | 0.00 | 0.999640 |
| Pb | 207.977 | Linear Thru Zero | 0.06 | 0.00 | 0.999893 |

| | | | | | |
|----|---------|------------------|------|------|----------|
| Pb | 205.975 | Linear Thru Zero | 0.02 | 0.00 | 0.999946 |
| Pb | 206.976 | Linear Thru Zero | 0.01 | 0.00 | 0.999933 |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 1

Sample Date/Time: Monday, November 13, 2006 14:02:54

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 1.005

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 52704.693 | 1.5 | 63.001 | 48.09880 | 0.369 | 0.8 | ug/L |
| Al | 27 | 322132.694 | 1.0 | 2334.350 | 48.14396 | 0.209 | 0.4 | ug/L |
| Sc | 45 | 369518.508 | 0.8 | 381869.082 | | | | ug/L |
| V | 51 | 803554.742 | 2.4 | 4488.603 | 50.34545 | 0.957 | 1.9 | ug/L |
| Cr | 52 | 694369.112 | 1.4 | 15368.650 | 49.04572 | 1.027 | 2.1 | ug/L |
| Cr | 53 | 85857.240 | 1.0 | 814.381 | 48.77165 | 0.458 | 0.9 | ug/L |
| Mn | 55 | 1014139.529 | 0.9 | 494.020 | 52.94084 | 1.074 | 2.0 | ug/L |
| Co | 59 | 854490.378 | 1.4 | 188.671 | 51.19173 | 0.198 | 0.4 | ug/L |
| Ni | 60 | 187862.545 | 2.8 | 136.669 | 50.11160 | 0.768 | 1.5 | ug/L |
| Ni | 62 | 28544.114 | 2.9 | 143.669 | 50.99124 | 2.212 | 4.3 | ug/L |
| Cu | 63 | 452382.951 | 0.1 | 212.338 | 52.81421 | 0.826 | 1.6 | ug/L |
| Cu | 65 | 213810.548 | 1.9 | 189.671 | 51.51101 | 1.662 | 3.2 | ug/L |
| Zn | 66 | 131661.271 | 2.3 | 1515.486 | 53.58057 | 2.016 | 3.8 | ug/L |
| Zn | 67 | 22197.079 | 0.4 | 342.344 | 51.80244 | 0.797 | 1.5 | ug/L |
| Zn | 68 | 95770.262 | 2.0 | 1170.427 | 53.00659 | 0.269 | 0.5 | ug/L |
| Ge | 72 | 231722.941 | 1.5 | 244883.968 | | | | ug/L |
| As | 75 | 149467.192 | 2.5 | 124.002 | 49.58109 | 0.515 | 1.0 | ug/L |
| Se | 77 | 12082.086 | 0.5 | 216.736 | 52.83436 | 0.659 | 1.2 | ug/L |
| Se | 78 | 52990.422 | 0.6 | 16119.238 | 51.58130 | 1.430 | 2.8 | mg/L |
| Se | 82 | 17771.797 | 0.6 | 1872.010 | 53.04044 | 0.479 | 0.9 | ug/L |
| Kr | 83 | 1763.871 | 1.3 | 1902.236 | | | | mg/L |
| Y | 89 | 393798.821 | 1.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 262602.484 | 0.7 | 112.002 | 49.70327 | 0.494 | 1.0 | ug/L |
| Mo | 97 | 159811.089 | 1.9 | 64.001 | 49.74918 | 1.684 | 3.4 | ug/L |
| Mo | 98 | 413941.198 | 1.4 | 98.282 | 51.09806 | 1.358 | 2.7 | ug/L |
| Rh | 103 | 320181.987 | 1.1 | 340052.119 | | | | ug/L |
| Ag | 107 | 651480.053 | 0.7 | 91.335 | 50.09628 | 0.752 | 1.5 | ug/L |
| Ag | 109 | 615419.219 | 2.5 | 75.668 | 50.36402 | 1.436 | 2.9 | ug/L |
| Cd | 111 | 146258.040 | 1.8 | 218.275 | 49.18008 | 1.411 | 2.9 | ug/L |
| Cd | 114 | 337216.136 | 0.8 | 58.957 | 50.99896 | 1.173 | 2.3 | ug/L |
| In | 115 | 351036.349 | 1.5 | 358352.924 | | | | ug/L |
| Sb | 121 | 453247.756 | 1.6 | 107.668 | 49.64536 | 1.158 | 2.3 | ug/L |
| Sb | 123 | 344207.801 | 1.9 | 79.665 | 48.97573 | 0.186 | 0.4 | ug/L |
| Ba | 135 | 117584.931 | 0.2 | 46.667 | 50.89770 | 0.965 | 1.9 | ug/L |
| Ba | 137 | 194612.882 | 1.7 | 47.001 | 49.35764 | 0.138 | 0.3 | ug/L |
| Tb | 159 | 383764.339 | 1.9 | 411268.087 | | | | ug/L |
| Ho | 165 | 372512.962 | 1.6 | 390096.908 | | | | ug/L |
| Tl | 203 | 373378.679 | 2.1 | 60.001 | 49.25381 | 0.801 | 1.6 | ug/L |
| Tl | 205 | 861510.330 | 0.3 | 78.001 | 51.43909 | 0.691 | 1.3 | ug/L |
| Pb | 208 | 1214518.019 | 0.4 | 320.672 | 50.37248 | 0.955 | 1.9 | ug/L |

Sample ID: QC Std 1

Report Date/Time: Monday, November 13, 2006 14:05:56

Page 1

135

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 315606.287 | 1.1 | 87.335 | 49.76579 | 1.298 | 2.6 ug/L |
| | Pb | 207 | 255465.853 | 0.3 | 77.001 | 48.22701 | 0.885 | 1.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 96.198 | | | | |
| Al | 27 | 96.288 | | | | |
| > Sc | 45 | | 96.766 | | | |
| V | 51 | 100.691 | | | | |
| Cr | 52 | 98.091 | | | | |
| Cr | 53 | 97.543 | | | | |
| Mn | 55 | 105.882 | | | | |
| Co | 59 | 102.383 | | | | |
| Ni | 60 | 100.223 | | | | |
| Ni | 62 | 101.982 | | | | |
| Cu | 63 | 105.628 | | | | |
| Cu | 65 | 103.022 | | | | |
| Zn | 66 | 107.161 | | | | |
| Zn | 67 | 103.605 | | | | |
| Zn | 68 | 106.013 | | | | |
| > Ge | 72 | | 94.626 | | | |
| As | 75 | 99.162 | | | | |
| Se | 77 | 105.669 | | | | |
| Se | 78 | 103.163 | | | | |
| Se | 82 | 106.081 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 99.407 | | | | |
| Mo | 97 | 99.498 | | | | |
| Mo | 98 | 102.196 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 100.193 | | | | |
| Ag | 109 | 100.728 | | | | |
| Cd | 111 | 98.360 | | | | |
| Cd | 114 | 101.998 | | | | |
| > In | 115 | | 97.958 | | | |
| Sb | 121 | 99.291 | | | | |
| Sb | 123 | 97.951 | | | | |
| Ba | 135 | 101.795 | | | | |
| Ba | 137 | 98.715 | | | | |
| > Tb | 159 | | 93.312 | | | |
| > Ho | 165 | | 95.492 | | | |
| Tl | 203 | 98.508 | | | | |
| Tl | 205 | 102.878 | | | | |
| Pb | 208 | 100.745 | | | | |
| Pb | 206 | 99.532 | | | | |
| Pb | 207 | 96.454 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 2

Sample Date/Time: Monday, November 13, 2006 14:08:51

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 2.006

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 61.668 | 15.3 | 63.001 | -0.00001 | 0.008 | 58999.9 | ug/L |
| Al | 27 | 2505.402 | 0.4 | 2334.350 | 0.03279 | 0.002 | 6.4 | ug/L |
| Sc | 45 | 373805.020 | 0.5 | 381869.082 | | | | ug/L |
| V | 51 | 4315.375 | 3.2 | 4488.603 | -0.00488 | 0.009 | 176.1 | ug/L |
| Cr | 52 | 14501.086 | 1.3 | 15368.650 | -0.03870 | 0.017 | 42.8 | ug/L |
| Cr | 53 | 733.706 | 4.6 | 814.381 | -0.03591 | 0.021 | 59.2 | ug/L |
| Mn | 55 | 500.020 | 3.6 | 494.020 | 0.00116 | 0.001 | 66.5 | ug/L |
| Co | 59 | 186.337 | 4.1 | 188.671 | 0.00024 | 0.000 | 154.0 | ug/L |
| Ni | 60 | 158.336 | 25.8 | 136.669 | 0.00693 | 0.011 | 158.3 | ug/L |
| Ni | 62 | 131.002 | 7.0 | 143.669 | -0.01362 | 0.018 | 130.4 | ug/L |
| Cu | 63 | 237.339 | 12.3 | 212.338 | 0.00367 | 0.003 | 86.9 | ug/L |
| Cu | 65 | 201.671 | 5.9 | 189.671 | 0.00434 | 0.003 | 60.1 | ug/L |
| Zn | 66 | 1498.150 | 4.4 | 1515.486 | 0.01376 | 0.028 | 205.0 | ug/L |
| Zn | 67 | 307.675 | 2.3 | 342.344 | -0.05351 | 0.015 | 27.7 | ug/L |
| Zn | 68 | 1139.756 | 5.2 | 1170.427 | 0.00481 | 0.028 | 592.1 | ug/L |
| Ge | 72 | 236586.500 | 0.7 | 244883.968 | | | | ug/L |
| As | 75 | 219.005 | 5.7 | 124.002 | 0.03225 | 0.004 | 12.0 | ug/L |
| Se | 77 | 228.270 | 2.9 | 216.736 | 0.08233 | 0.032 | 39.4 | ug/L |
| Se | 78 | 15622.491 | 2.3 | 16119.238 | 0.06867 | 0.605 | 880.6 | mg/L |
| Se | 82 | 1804.662 | 1.3 | 1872.010 | -0.01216 | 0.117 | 959.7 | ug/L |
| Kr | 83 | 1818.884 | 5.4 | 1902.236 | | | | mg/L |
| Y | 89 | 390408.873 | 1.3 | 408188.389 | | | | ug/L |
| Mo | 95 | 864.721 | 15.3 | 112.002 | 0.14309 | 0.023 | 16.3 | ug/L |
| Mo | 97 | 504.687 | 17.8 | 64.001 | 0.13770 | 0.026 | 19.1 | ug/L |
| Mo | 98 | 1245.236 | 11.4 | 98.282 | 0.14200 | 0.016 | 11.3 | ug/L |
| Rh | 103 | 323445.551 | 1.1 | 340052.119 | | | | ug/L |
| Ag | 107 | 167.003 | 3.0 | 91.335 | 0.00599 | 0.001 | 8.4 | ug/L |
| Ag | 109 | 156.670 | 8.7 | 75.668 | 0.00679 | 0.001 | 18.4 | ug/L |
| Cd | 111 | 203.496 | 6.3 | 218.275 | -0.00332 | 0.005 | 152.0 | ug/L |
| Cd | 114 | 60.502 | 15.2 | 58.957 | 0.00042 | 0.001 | 304.0 | ug/L |
| In | 115 | 350409.590 | 1.1 | 358352.924 | | | | ug/L |
| Sb | 121 | 1461.478 | 13.2 | 107.668 | 0.14870 | 0.020 | 13.2 | ug/L |
| Sb | 123 | 1142.270 | 15.9 | 79.665 | 0.15158 | 0.024 | 15.8 | ug/L |
| Ba | 135 | 55.334 | 15.2 | 46.667 | 0.00503 | 0.004 | 70.8 | ug/L |
| Ba | 137 | 46.334 | 19.6 | 47.001 | 0.00059 | 0.002 | 387.8 | ug/L |
| Tb | 159 | 384930.504 | 0.5 | 411268.087 | | | | ug/L |
| Ho | 165 | 372252.869 | 1.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 81.668 | 10.6 | 60.001 | 0.00323 | 0.001 | 37.4 | ug/L |
| Tl | 205 | 151.336 | 8.5 | 78.001 | 0.00460 | 0.001 | 18.0 | ug/L |
| Pb | 208 | 430.675 | 3.8 | 320.672 | 0.00517 | 0.001 | 11.2 | ug/L |

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|-----------|
| | Pb | 206 | 118.669 | 9.1 | 87.335 | 0.00557 | 0.002 | 27.2 ug/L |
| | Pb | 207 | 97.668 | 4.1 | 77.001 | 0.00457 | 0.001 | 12.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 97.888 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 96.612 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 97.783 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 93.596 | | | |
| > Ho | 165 | | 95.426 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Monday, November 13, 2006 14:14:47

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 3.007

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1141.423 | 1.7 | 63.001 | 1.00008 | 0.002 | 0.2 | ug/L |
| Al | 27 | 71627.448 | 3.3 | 2334.350 | 10.57334 | 0.293 | 2.8 | ug/L |
| > Sc | 45 | 365011.421 | 1.5 | 381869.082 | | | | ug/L |
| V | 51 | 21573.522 | 0.4 | 4488.603 | 1.10242 | 0.019 | 1.7 | ug/L |
| Cr | 52 | 30787.420 | 1.8 | 15368.650 | 1.17613 | 0.024 | 2.0 | ug/L |
| Cr | 53 | 2691.462 | 3.1 | 814.381 | 1.11102 | 0.072 | 6.5 | ug/L |
| Mn | 55 | 21946.417 | 1.5 | 494.020 | 1.12164 | 0.014 | 1.3 | ug/L |
| Co | 59 | 18418.526 | 2.7 | 188.671 | 1.09278 | 0.007 | 0.7 | ug/L |
| Ni | 60 | 4196.766 | 3.9 | 136.669 | 1.08664 | 0.065 | 6.0 | ug/L |
| Ni | 62 | 722.372 | 2.4 | 143.669 | 1.05257 | 0.046 | 4.4 | ug/L |
| Cu | 63 | 9410.072 | 1.8 | 212.338 | 1.07549 | 0.015 | 1.4 | ug/L |
| Cu | 65 | 4702.040 | 1.8 | 189.671 | 1.09038 | 0.030 | 2.7 | ug/L |
| Zn | 66 | 16689.198 | 1.6 | 1515.486 | 6.27729 | 0.249 | 4.0 | ug/L |
| Zn | 67 | 2712.135 | 1.6 | 342.344 | 5.65767 | 0.223 | 3.9 | ug/L |
| Zn | 68 | 12169.001 | 1.1 | 1170.427 | 6.19594 | 0.176 | 2.8 | ug/L |
| > Ge | 72 | 231740.911 | 2.1 | 244883.968 | | | | ug/L |
| As | 75 | 3202.648 | 2.5 | 124.002 | 1.02425 | 0.011 | 1.0 | ug/L |
| Se | 77 | 453.946 | 0.8 | 216.736 | 1.10750 | 0.055 | 4.9 | ug/L |
| Se | 78 | 16816.661 | 0.6 | 16119.238 | 2.13987 | 0.346 | 16.2 | mg/L |
| Se | 82 | 2081.793 | 1.4 | 1872.010 | 1.02925 | 0.091 | 8.8 | ug/L |
| Kr | 83 | 1758.537 | 2.4 | 1902.236 | | | | mg/L |
| Y | 89 | 385142.011 | 1.7 | 408188.389 | | | | ug/L |
| Mo | 95 | 5993.214 | 1.0 | 112.002 | 1.09950 | 0.009 | 0.8 | ug/L |
| Mo | 97 | 3467.757 | 3.2 | 64.001 | 1.04629 | 0.033 | 3.1 | ug/L |
| Mo | 98 | 8931.007 | 1.3 | 98.282 | 1.07654 | 0.011 | 1.1 | ug/L |
| Rh | 103 | 327204.872 | 1.2 | 340052.119 | | | | ug/L |
| Ag | 107 | 14255.994 | 1.5 | 91.335 | 1.07541 | 0.015 | 1.4 | ug/L |
| Ag | 109 | 13304.078 | 0.7 | 75.668 | 1.06883 | 0.008 | 0.8 | ug/L |
| Cd | 111 | 3278.298 | 1.1 | 218.275 | 1.01767 | 0.013 | 1.3 | ug/L |
| Cd | 114 | 6927.756 | 2.3 | 58.957 | 1.02563 | 0.026 | 2.5 | ug/L |
| > In | 115 | 355557.742 | 0.2 | 358352.924 | | | | ug/L |
| Sb | 121 | 10282.110 | 1.6 | 107.668 | 1.10040 | 0.016 | 1.5 | ug/L |
| Sb | 123 | 7875.054 | 1.4 | 79.665 | 1.09543 | 0.013 | 1.2 | ug/L |
| Ba | 135 | 2462.055 | 3.3 | 46.667 | 1.02397 | 0.038 | 3.7 | ug/L |
| Ba | 137 | 4315.827 | 1.7 | 47.001 | 1.05999 | 0.025 | 2.4 | ug/L |
| > Tb | 159 | 392289.102 | 0.9 | 411268.087 | | | | ug/L |
| > Ho | 165 | 371676.265 | 0.6 | 390096.908 | | | | ug/L |
| Tl | 203 | 8129.044 | 1.0 | 60.001 | 1.06734 | 0.012 | 1.1 | ug/L |
| Tl | 205 | 18772.316 | 2.4 | 78.001 | 1.11886 | 0.025 | 2.2 | ug/L |
| Pb | 208 | 26622.470 | 1.2 | 320.672 | 1.09401 | 0.011 | 1.0 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Monday, November 13, 2006 14:17:48

Page 1

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 6873.236 | 1.0 | 87.335 | 1.07309 | 0.013 | 1.2 ug/L |
| | Pb | 207 | 5782.064 | 1.9 | 77.001 | 1.08021 | 0.020 | 1.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 100.008 | | | | |
| Al | 27 | 105.733 | | | | |
| > Sc | 45 | | 95.585 | | | |
| V | 51 | 110.242 | | | | |
| Cr | 52 | 117.613 | | | | |
| Cr | 53 | 111.102 | | | | |
| Mn | 55 | 112.164 | | | | |
| Co | 59 | 109.278 | | | | |
| Ni | 60 | 108.664 | | | | |
| Ni | 62 | 105.257 | | | | |
| Cu | 63 | 107.549 | | | | |
| Cu | 65 | 109.038 | | | | |
| Zn | 66 | 125.546 | | | | |
| Zn | 67 | 113.153 | | | | |
| Zn | 68 | 123.919 | | | | |
| > Ge | 72 | | 94.633 | | | |
| As | 75 | 102.425 | | | | |
| Se | 77 | 110.750 | | | | |
| Se | 78 | 213.987 | | | | |
| Se | 82 | 102.925 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 109.950 | | | | |
| Mo | 97 | 104.629 | | | | |
| Mo | 98 | 107.654 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 107.541 | | | | |
| Ag | 109 | 106.883 | | | | |
| Cd | 111 | 101.767 | | | | |
| Cd | 114 | 102.563 | | | | |
| > In | 115 | | 99.220 | | | |
| Sb | 121 | 110.040 | | | | |
| Sb | 123 | 109.543 | | | | |
| Ba | 135 | 102.397 | | | | |
| Ba | 137 | 105.999 | | | | |
| > Tb | 159 | | 95.385 | | | |
| > Ho | 165 | | 95.278 | | | |
| Tl | 203 | 106.734 | | | | |
| Tl | 205 | 111.886 | | | | |
| Pb | 208 | 109.401 | | | | |
| Pb | 206 | 107.309 | | | | |
| Pb | 207 | 108.021 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 4

Sample Date/Time: Monday, November 13, 2006 14:20:44

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 4.008

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| Be | 9 | 54.001 | 17.0 | 63.001 | -0.00472 | 0.010 | 217.4 | ug/L |
| Al | 27 | 126847492.833 | 2.2 | 2334.350 | 19661.79322 | 1038.151 | 5.3 | ug/L |
| > Sc | 45 | 359221.813 | 3.4 | 381869.082 | | | | ug/L |
| V | 51 | 2931.424 | 16.2 | 4488.603 | -0.08385 | 0.029 | 34.3 | ug/L |
| Cr | 52 | 26897.286 | 2.1 | 15368.650 | 0.92584 | 0.103 | 11.2 | ug/L |
| Cr | 53 | 7566.178 | 3.3 | 814.381 | 4.01703 | 0.297 | 7.4 | ug/L |
| Mn | 55 | 14959.900 | 1.2 | 494.020 | 0.68609 | 0.020 | 3.0 | ug/L |
| Co | 59 | 1081.414 | 3.0 | 188.671 | 0.04824 | 0.002 | 4.9 | ug/L |
| Ni | 60 | 2400.703 | 0.7 | 136.669 | 0.54834 | 0.013 | 2.4 | ug/L |
| Ni | 62 | 2055.941 | 2.7 | 143.669 | 3.11071 | 0.107 | 3.4 | ug/L |
| Cu | 63 | 6647.050 | 1.2 | 212.338 | 0.68239 | 0.008 | 1.2 | ug/L |
| Cu | 65 | 2668.454 | 2.8 | 189.671 | 0.54187 | 0.026 | 4.8 | ug/L |
| Zn | 66 | 5552.572 | 1.4 | 1515.486 | 1.48727 | 0.059 | 3.9 | ug/L |
| Zn | 67 | 2232.988 | 4.2 | 342.344 | 4.03926 | 0.119 | 2.9 | ug/L |
| Zn | 68 | 2737.144 | 4.1 | 1170.427 | 0.77432 | 0.081 | 10.4 | ug/L |
| > Ge | 72 | 254855.622 | 1.7 | 244883.968 | | | | ug/L |
| As | 75 | 2120.958 | 1.9 | 124.002 | 0.60130 | 0.001 | 0.2 | ug/L |
| Se | 77 | 885.780 | 1.7 | 216.736 | 2.67112 | 0.105 | 3.9 | ug/L |
| Se | 78 | 16008.793 | 0.1 | 16119.238 | -0.94908 | 0.322 | 34.0 | mg/L |
| Se | 82 | 1878.278 | 1.4 | 1872.010 | -0.21048 | 0.054 | 25.5 | ug/L |
| Kr | 83 | 1887.899 | 2.1 | 1902.236 | | | | mg/L |
| Y | 89 | 392097.019 | 0.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 2157236.414 | 6.8 | 112.002 | 433.03370 | 25.513 | 5.9 | ug/L |
| Mo | 97 | 1280028.191 | 1.7 | 64.001 | 422.70086 | 10.095 | 2.4 | ug/L |
| Mo | 98 | 3538861.921 | 1.1 | 98.282 | 463.34086 | 4.062 | 0.9 | ug/L |
| Rh | 103 | 305099.742 | 1.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 382.679 | 2.5 | 91.335 | 0.02434 | 0.001 | 3.9 | ug/L |
| Ag | 109 | 351.011 | 0.9 | 75.668 | 0.02440 | 0.000 | 0.8 | ug/L |
| Cd | 111 | 288.782 | 48.1 | 218.275 | 0.03098 | 0.049 | 157.6 | ug/L |
| Cd | 114 | 4523.819 | 3.9 | 58.957 | 0.71706 | 0.034 | 4.7 | ug/L |
| > In | 115 | 330957.215 | 1.0 | 358352.924 | | | | ug/L |
| Sb | 121 | 3401.395 | 3.9 | 107.668 | 0.38361 | 0.014 | 3.6 | ug/L |
| Sb | 123 | 2534.506 | 1.0 | 79.665 | 0.37154 | 0.008 | 2.0 | ug/L |
| Ba | 135 | 139.669 | 7.3 | 46.667 | 0.04332 | 0.004 | 9.4 | ug/L |
| Ba | 137 | 187.004 | 6.2 | 47.001 | 0.03766 | 0.003 | 7.5 | ug/L |
| > Tb | 159 | 373124.959 | 1.7 | 411268.087 | | | | ug/L |
| > Ho | 165 | 354680.072 | 2.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 2246.993 | 7.1 | 60.001 | 0.30360 | 0.016 | 5.2 | ug/L |
| Tl | 205 | 5346.108 | 7.9 | 78.001 | 0.33055 | 0.020 | 5.9 | ug/L |
| Pb | 208 | 1530.403 | 0.3 | 320.672 | 0.05399 | 0.002 | 2.9 | ug/L |

Sample ID: QC Std 4

Report Date/Time: Monday, November 13, 2006 14:23:44

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 405.014 | 2.6 | 87.335 | 0.05397 | 0.003 | 5.7 ug/L |
| | Pb | 207 | 327.343 | 3.4 | 77.001 | 0.05109 | 0.004 | 7.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | 98.309 | | | | |
| Sc | 45 | | 94.069 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| Ge | 72 | | 104.072 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 108.258 | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| In | 115 | | 92.355 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| Tb | 159 | | 90.725 | | | |
| Ho | 165 | | 90.921 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 5

Sample Date/Time: Monday, November 13, 2006 14:26:40

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 5.009

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| Be | 9 | 57.334 | 3.6 | 63.001 | -0.00092 | 0.002 | 236.2 | ug/L |
| Al | 27 | 121960409.003 | 1.1 | 2334.350 | 19196.08521 | 440.464 | 2.3 | ug/L |
| Sc | 45 | 353444.064 | 2.0 | 381869.082 | | | | ug/L |
| V | 51 | -3674.038 | 75.2 | 4488.603 | -0.51324 | 0.178 | 34.6 | ug/L |
| Cr | 52 | 311060.109 | 1.6 | 15368.650 | 22.40629 | 0.729 | 3.3 | ug/L |
| Cr | 53 | 42703.231 | 0.7 | 814.381 | 25.14840 | 0.347 | 1.4 | ug/L |
| Mn | 55 | 422157.750 | 1.1 | 494.020 | 20.38278 | 0.090 | 0.4 | ug/L |
| Co | 59 | 346472.254 | 2.3 | 188.671 | 19.20772 | 0.310 | 1.6 | ug/L |
| Ni | 60 | 74970.159 | 1.0 | 136.669 | 18.49375 | 0.154 | 0.8 | ug/L |
| Ni | 62 | 13364.516 | 3.2 | 143.669 | 21.95419 | 0.684 | 3.1 | ug/L |
| Cu | 63 | 177190.287 | 2.2 | 212.338 | 19.13489 | 0.523 | 2.7 | ug/L |
| Cu | 65 | 83501.803 | 1.2 | 189.671 | 18.59164 | 0.305 | 1.6 | ug/L |
| Zn | 66 | 53226.336 | 1.7 | 1515.486 | 19.67867 | 0.461 | 2.3 | ug/L |
| Zn | 67 | 9494.502 | 2.3 | 342.344 | 20.04740 | 0.515 | 2.6 | ug/L |
| Zn | 68 | 35813.493 | 1.5 | 1170.427 | 17.94712 | 0.362 | 2.0 | ug/L |
| Ge | 72 | 250304.757 | 0.6 | 244883.968 | | | | ug/L |
| As | 75 | 62563.597 | 0.1 | 124.002 | 19.19144 | 0.134 | 0.7 | ug/L |
| Se | 77 | 831.508 | 2.3 | 216.736 | 2.51204 | 0.096 | 3.8 | ug/L |
| Se | 78 | 15636.449 | 1.7 | 16119.238 | -1.06086 | 0.415 | 39.2 | mg/L |
| Se | 82 | 1828.534 | 1.9 | 1872.010 | -0.26053 | 0.107 | 40.9 | ug/L |
| Kr | 83 | 1864.894 | 1.2 | 1902.236 | | | | mg/L |
| Y | 89 | 380011.838 | 1.6 | 408188.389 | | | | ug/L |
| Mo | 95 | 2068789.291 | 7.8 | 112.002 | 413.83205 | 27.180 | 6.6 | ug/L |
| Mo | 97 | 1241754.075 | 0.8 | 64.001 | 408.70458 | 7.612 | 1.9 | ug/L |
| Mo | 98 | 3509694.965 | 1.3 | 98.282 | 458.06140 | 10.409 | 2.3 | ug/L |
| Rh | 103 | 299347.430 | 0.7 | 340052.119 | | | | ug/L |
| Ag | 107 | 249753.058 | 1.0 | 91.335 | 20.29639 | 0.178 | 0.9 | ug/L |
| Ag | 109 | 239373.421 | 1.4 | 75.668 | 20.70237 | 0.139 | 0.7 | ug/L |
| Cd | 111 | 55771.400 | 1.7 | 218.275 | 19.77666 | 0.179 | 0.9 | ug/L |
| Cd | 114 | 131839.663 | 0.5 | 58.957 | 21.07101 | 0.363 | 1.7 | ug/L |
| In | 115 | 332068.064 | 1.4 | 358352.924 | | | | ug/L |
| Sb | 121 | 3227.324 | 1.0 | 107.668 | 0.36224 | 0.009 | 2.4 | ug/L |
| Sb | 123 | 2373.187 | 3.5 | 79.665 | 0.34591 | 0.009 | 2.7 | ug/L |
| Ba | 135 | 158.670 | 8.7 | 46.667 | 0.05355 | 0.007 | 12.3 | ug/L |
| Ba | 137 | 221.005 | 4.1 | 47.001 | 0.04795 | 0.002 | 5.2 | ug/L |
| Tb | 159 | 364182.220 | 0.4 | 411268.087 | | | | ug/L |
| Ho | 165 | 358911.433 | 0.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 2107.621 | 4.6 | 60.001 | 0.28099 | 0.012 | 4.2 | ug/L |
| Tl | 205 | 4948.520 | 3.8 | 78.001 | 0.30216 | 0.010 | 3.3 | ug/L |
| Pb | 208 | 1775.091 | 2.1 | 320.672 | 0.06371 | 0.001 | 1.9 | ug/L |

Sample ID: QC Std 5

Report Date/Time: Monday, November 13, 2006 14:29:42

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 462.684 | 2.2 | 87.335 | 0.06257 | 0.002 | 2.5 ug/L |
| | Pb | 207 | 384.013 | 5.6 | 77.001 | 0.06135 | 0.004 | 6.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | 95.980 | | | | |
| > Sc | 45 | | 92.556 | | | |
| V | 51 | | | | | |
| Cr | 52 | 112.031 | | | | |
| Cr | 53 | 125.742 | | | | |
| Mn | 55 | 101.914 | | | | |
| Co | 59 | 96.039 | | | | |
| Ni | 60 | 92.469 | | | | |
| Ni | 62 | 109.771 | | | | |
| Cu | 63 | 95.674 | | | | |
| Cu | 65 | 92.958 | | | | |
| Zn | 66 | 98.393 | | | | |
| Zn | 67 | 100.237 | | | | |
| Zn | 68 | 89.736 | | | | |
| > Ge | 72 | | 102.214 | | | |
| As | 75 | 95.957 | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 103.458 | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 101.482 | | | | |
| Ag | 109 | 103.512 | | | | |
| Cd | 111 | 98.883 | | | | |
| Cd | 114 | 105.355 | | | | |
| > In | 115 | | 92.665 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 88.551 | | | |
| > Ho | 165 | | 92.006 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 13, 2006 14:32:39

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 6.010

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 49077.606 | 1.6 | 63.001 | 47.75773 | 0.641 | 1.3 | ug/L |
| Al | 27 | 311945.704 | 0.9 | 2334.350 | 49.72384 | 0.540 | 1.1 | ug/L |
| > Sc | 45 | 346549.091 | 0.3 | 381869.082 | | | | ug/L |
| V | 51 | 799869.719 | 0.6 | 4488.603 | 53.45679 | 0.477 | 0.9 | ug/L |
| Cr | 52 | 707291.404 | 1.7 | 15368.650 | 53.35777 | 0.992 | 1.9 | ug/L |
| Cr | 53 | 82654.206 | 2.5 | 814.381 | 50.07585 | 1.283 | 2.6 | ug/L |
| Mn | 55 | 1001914.865 | 2.0 | 494.020 | 51.79186 | 0.269 | 0.5 | ug/L |
| Co | 59 | 821249.208 | 1.0 | 188.671 | 48.73943 | 1.005 | 2.1 | ug/L |
| Ni | 60 | 192236.681 | 0.8 | 136.669 | 50.80297 | 0.798 | 1.6 | ug/L |
| Ni | 62 | 28513.326 | 1.8 | 143.669 | 50.42559 | 0.092 | 0.2 | ug/L |
| Cu | 63 | 445320.570 | 0.9 | 212.338 | 51.49860 | 1.246 | 2.4 | ug/L |
| Cu | 65 | 224682.002 | 1.6 | 189.671 | 53.60315 | 0.734 | 1.4 | ug/L |
| Zn | 66 | 129942.364 | 1.5 | 1515.486 | 52.34627 | 0.277 | 0.5 | ug/L |
| Zn | 67 | 22455.774 | 0.8 | 342.344 | 51.91125 | 1.082 | 2.1 | ug/L |
| Zn | 68 | 99141.690 | 1.7 | 1170.427 | 54.36766 | 0.342 | 0.6 | ug/L |
| > Ge | 72 | 233955.185 | 1.6 | 244883.968 | | | | ug/L |
| As | 75 | 153048.923 | 1.0 | 124.002 | 50.30452 | 1.304 | 2.6 | ug/L |
| Se | 77 | 12287.053 | 1.3 | 216.736 | 53.22125 | 0.359 | 0.7 | ug/L |
| Se | 78 | 54288.006 | 2.8 | 16119.238 | 52.66339 | 3.066 | 5.8 | mg/L |
| Se | 82 | 17655.150 | 0.7 | 1872.010 | 52.10476 | 1.300 | 2.5 | ug/L |
| Kr | 83 | 1791.544 | 3.3 | 1902.236 | | | | mg/L |
| Y | 89 | 385351.254 | 1.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 257356.107 | 0.5 | 112.002 | 50.51305 | 0.159 | 0.3 | ug/L |
| Mo | 97 | 165355.799 | 0.7 | 64.001 | 53.36904 | 0.512 | 1.0 | ug/L |
| Mo | 98 | 402329.477 | 1.1 | 98.282 | 51.49544 | 0.599 | 1.2 | ug/L |
| Rh | 103 | 324787.462 | 1.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 650201.336 | 2.8 | 91.335 | 51.84951 | 1.589 | 3.1 | ug/L |
| Ag | 109 | 601355.302 | 1.5 | 75.668 | 51.03052 | 0.591 | 1.2 | ug/L |
| Cd | 111 | 152033.703 | 1.8 | 218.275 | 53.01046 | 0.901 | 1.7 | ug/L |
| Cd | 114 | 333803.840 | 4.3 | 58.957 | 52.34147 | 2.129 | 4.1 | ug/L |
| > In | 115 | 338477.686 | 0.3 | 358352.924 | | | | ug/L |
| Sb | 121 | 441757.296 | 1.0 | 107.668 | 50.17418 | 0.547 | 1.1 | ug/L |
| Sb | 123 | 339206.972 | 0.6 | 79.665 | 50.05772 | 0.413 | 0.8 | ug/L |
| Ba | 135 | 112157.752 | 2.3 | 46.667 | 48.50293 | 0.328 | 0.7 | ug/L |
| Ba | 137 | 193676.005 | 1.5 | 47.001 | 49.10555 | 1.558 | 3.2 | ug/L |
| > Tb | 159 | 384005.104 | 1.7 | 411268.087 | | | | ug/L |
| > Ho | 165 | 362824.114 | 1.9 | 390096.908 | | | | ug/L |
| Tl | 203 | 378703.379 | 2.2 | 60.001 | 51.29722 | 1.281 | 2.5 | ug/L |
| Tl | 205 | 880016.889 | 1.6 | 78.001 | 53.94420 | 0.688 | 1.3 | ug/L |
| Pb | 208 | 1232071.871 | 1.2 | 320.672 | 52.46352 | 0.889 | 1.7 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Monday, November 13, 2006 14:35:41

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 315422.477 | 1.1 | 87.335 | 51.06294 | 1.091 | 2.1 ug/L |
| | Pb | 207 | 262161.448 | 0.2 | 77.001 | 50.81590 | 1.024 | 2.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 95.515 | | | | |
| Al | 27 | 99.448 | | | | |
| > Sc | 45 | | 90.751 | | | |
| V | 51 | 106.914 | | | | |
| Cr | 52 | 106.716 | | | | |
| Cr | 53 | 100.152 | | | | |
| Mn | 55 | 103.584 | | | | |
| Co | 59 | 97.479 | | | | |
| Ni | 60 | 101.606 | | | | |
| Ni | 62 | 100.851 | | | | |
| Cu | 63 | 102.997 | | | | |
| Cu | 65 | 107.206 | | | | |
| Zn | 66 | 104.693 | | | | |
| Zn | 67 | 103.823 | | | | |
| Zn | 68 | 108.735 | | | | |
| > Ge | 72 | | 95.537 | | | |
| As | 75 | 100.609 | | | | |
| Se | 77 | 106.442 | | | | |
| Se | 78 | 105.327 | | | | |
| Se | 82 | 104.210 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 101.026 | | | | |
| Mo | 97 | 106.738 | | | | |
| Mo | 98 | 102.991 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 103.699 | | | | |
| Ag | 109 | 102.061 | | | | |
| Cd | 111 | 106.021 | | | | |
| Cd | 114 | 104.683 | | | | |
| > In | 115 | | 94.454 | | | |
| Sb | 121 | 100.348 | | | | |
| Sb | 123 | 100.115 | | | | |
| Ba | 135 | 97.006 | | | | |
| Ba | 137 | 98.211 | | | | |
| > Tb | 159 | | 93.371 | | | |
| > Ho | 165 | | 93.009 | | | |
| Tl | 203 | 102.594 | | | | |
| Tl | 205 | 107.888 | | | | |
| Pb | 208 | 104.927 | | | | |
| Pb | 206 | 102.126 | | | | |
| Pb | 207 | 101.632 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 13, 2006 14:38:37

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 7.011

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 56.667 | 10.3 | 63.001 | -0.00243 | 0.005 | 204.8 | ug/L |
| Al | 27 | 2674.789 | 0.9 | 2334.350 | 0.07459 | 0.008 | 10.7 | ug/L |
| > Sc | 45 | 358890.334 | 1.4 | 381869.082 | | | | ug/L |
| V | 51 | 4370.113 | 4.7 | 4488.603 | 0.00983 | 0.013 | 131.4 | ug/L |
| Cr | 52 | 14611.616 | 2.2 | 15368.650 | 0.01245 | 0.017 | 138.3 | ug/L |
| Cr | 53 | 1378.461 | 3.8 | 814.381 | 0.36223 | 0.040 | 11.2 | ug/L |
| Mn | 55 | 526.355 | 5.3 | 494.020 | 0.00205 | 0.001 | 66.7 | ug/L |
| Co | 59 | 181.004 | 7.6 | 188.671 | -0.00025 | 0.001 | 330.7 | ug/L |
| Ni | 60 | 172.004 | 9.0 | 136.669 | 0.00968 | 0.004 | 39.5 | ug/L |
| Ni | 62 | 145.336 | 3.8 | 143.669 | 0.00712 | 0.009 | 124.8 | ug/L |
| Cu | 63 | 262.340 | 9.0 | 212.338 | 0.00602 | 0.002 | 40.9 | ug/L |
| Cu | 65 | 226.005 | 13.4 | 189.671 | 0.00915 | 0.007 | 72.5 | ug/L |
| Zn | 66 | 1475.479 | 4.1 | 1515.486 | -0.00564 | 0.020 | 350.8 | ug/L |
| Zn | 67 | 378.346 | 6.5 | 342.344 | 0.09561 | 0.059 | 61.6 | ug/L |
| Zn | 68 | 1122.087 | 2.5 | 1170.427 | -0.01525 | 0.014 | 90.9 | ug/L |
| > Ge | 72 | 240685.807 | 0.8 | 244883.968 | | | | ug/L |
| As | 75 | 228.339 | 13.4 | 124.002 | 0.03407 | 0.010 | 30.2 | ug/L |
| Se | 77 | 254.537 | 4.0 | 216.736 | 0.17781 | 0.044 | 24.9 | ug/L |
| Se | 78 | 15628.412 | 2.1 | 16119.238 | -0.28039 | 0.515 | 183.5 | mg/L |
| Se | 82 | 1799.861 | 1.5 | 1872.010 | -0.12731 | 0.119 | 93.6 | ug/L |
| Kr | 83 | 1799.879 | 2.5 | 1902.236 | | | | mg/L |
| Y | 89 | 394852.075 | 1.0 | 408188.389 | | | | ug/L |
| Mo | 95 | 1061.079 | 11.3 | 112.002 | 0.18332 | 0.023 | 12.7 | ug/L |
| Mo | 97 | 651.032 | 2.8 | 64.001 | 0.18639 | 0.006 | 3.4 | ug/L |
| Mo | 98 | 1690.951 | 13.8 | 98.282 | 0.20017 | 0.029 | 14.6 | ug/L |
| Rh | 103 | 320446.509 | 0.5 | 340052.119 | | | | ug/L |
| Ag | 107 | 165.337 | 2.1 | 91.335 | 0.00604 | 0.000 | 4.9 | ug/L |
| Ag | 109 | 141.336 | 3.5 | 75.668 | 0.00568 | 0.000 | 7.8 | ug/L |
| Cd | 111 | 190.705 | 17.1 | 218.275 | -0.00679 | 0.011 | 159.8 | ug/L |
| Cd | 114 | 53.401 | 5.6 | 58.957 | -0.00053 | 0.000 | 81.4 | ug/L |
| > In | 115 | 345551.182 | 0.5 | 358352.924 | | | | ug/L |
| Sb | 121 | 1247.107 | 13.9 | 107.668 | 0.12722 | 0.019 | 15.1 | ug/L |
| Sb | 123 | 905.183 | 10.2 | 79.665 | 0.11975 | 0.013 | 11.0 | ug/L |
| Ba | 135 | 45.001 | 8.0 | 46.667 | 0.00089 | 0.002 | 215.4 | ug/L |
| Ba | 137 | 50.001 | 17.1 | 47.001 | 0.00176 | 0.003 | 145.7 | ug/L |
| > Tb | 159 | 379142.947 | 2.8 | 411268.087 | | | | ug/L |
| > Ho | 165 | 373265.552 | 0.9 | 390096.908 | | | | ug/L |
| Tl | 203 | 178.337 | 10.4 | 60.001 | 0.01592 | 0.002 | 15.5 | ug/L |
| Tl | 205 | 368.345 | 11.9 | 78.001 | 0.01751 | 0.003 | 15.5 | ug/L |
| Pb | 208 | 417.675 | 1.4 | 320.672 | 0.00459 | 0.000 | 6.3 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Monday, November 13, 2006 14:41:37

Page 1

| | | | | | | | | |
|---|----|-----|---------|-----|--------|---------|-------|-----------|
| I | Pb | 206 | 107.002 | 9.2 | 87.335 | 0.00369 | 0.002 | 41.9 ug/L |
| L | Pb | 207 | 101.002 | 4.5 | 77.001 | 0.00515 | 0.001 | 14.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 93.983 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 98.286 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 96.428 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 92.189 | | | |
| > Ho | 165 | | 95.685 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 8

Sample Date/Time: Monday, November 13, 2006 14:44:34

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 8.012

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 102982.796 | 0.7 | 63.001 | 96.30540 | 0.825 | 0.9 | ug/L |
| Al | 27 | 616148.382 | 0.9 | 2334.350 | 94.63353 | 1.429 | 1.5 | ug/L |
| > Sc | 45 | 360838.432 | 0.6 | 381869.082 | | | | ug/L |
| V | 51 | 1566013.920 | 2.4 | 4488.603 | 100.75484 | 2.327 | 2.3 | ug/L |
| Cr | 52 | 1399081.291 | 0.1 | 15368.650 | 102.33316 | 0.613 | 0.6 | ug/L |
| Cr | 53 | 176711.470 | 0.9 | 814.381 | 103.29908 | 1.201 | 1.2 | ug/L |
| Mn | 55 | 1939030.393 | 0.6 | 494.020 | 97.28142 | 1.264 | 1.3 | ug/L |
| Co | 59 | 1707567.497 | 0.3 | 188.671 | 98.32886 | 1.886 | 1.9 | ug/L |
| Ni | 60 | 384901.424 | 0.8 | 136.669 | 98.72850 | 2.430 | 2.5 | ug/L |
| Ni | 62 | 57760.755 | 1.4 | 143.669 | 99.36672 | 2.745 | 2.8 | ug/L |
| Cu | 63 | 885069.266 | 2.0 | 212.338 | 99.32801 | 3.339 | 3.4 | ug/L |
| Cu | 65 | 428418.178 | 2.3 | 189.671 | 99.22151 | 3.450 | 3.5 | ug/L |
| Zn | 66 | 251880.434 | 0.0 | 1515.486 | 98.97587 | 1.706 | 1.7 | ug/L |
| Zn | 67 | 44180.598 | 1.5 | 342.344 | 99.79263 | 3.015 | 3.0 | ug/L |
| Zn | 68 | 187194.410 | 3.2 | 1170.427 | 100.15735 | 4.786 | 4.8 | ug/L |
| > Ge | 72 | 241153.240 | 1.7 | 244883.968 | | | | ug/L |
| As | 75 | 314326.818 | 1.0 | 124.002 | 100.26663 | 2.431 | 2.4 | ug/L |
| Se | 77 | 23334.625 | 0.3 | 216.736 | 98.84116 | 1.827 | 1.8 | ug/L |
| Se | 78 | 89065.580 | 1.6 | 16119.238 | 96.14555 | 3.703 | 3.9 | mg/L |
| Se | 82 | 32565.708 | 0.4 | 1872.010 | 97.87591 | 2.134 | 2.2 | ug/L |
| Kr | 83 | 1752.535 | 2.4 | 1902.236 | | | | mg/L |
| Y | 89 | 388754.452 | 1.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 537363.458 | 0.4 | 112.002 | 101.16550 | 1.036 | 1.0 | ug/L |
| Mo | 97 | 326578.280 | 0.7 | 64.001 | 101.09901 | 1.604 | 1.6 | ug/L |
| Mo | 98 | 801594.611 | 1.8 | 98.282 | 98.39907 | 2.014 | 2.0 | ug/L |
| Rh | 103 | 321597.104 | 3.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 1329941.904 | 3.3 | 91.335 | 101.70410 | 3.526 | 3.5 | ug/L |
| Ag | 109 | 1247819.325 | 1.3 | 75.668 | 101.54971 | 1.292 | 1.3 | ug/L |
| Cd | 111 | 296808.705 | 1.0 | 218.275 | 99.31371 | 1.933 | 1.9 | ug/L |
| Cd | 114 | 662417.009 | 1.3 | 58.957 | 99.61176 | 0.359 | 0.4 | ug/L |
| > In | 115 | 352980.480 | 0.9 | 358352.924 | | | | ug/L |
| Sb | 121 | 930090.032 | 1.1 | 107.668 | 101.30910 | 0.705 | 0.7 | ug/L |
| Sb | 123 | 718826.554 | 0.7 | 79.665 | 101.74031 | 1.571 | 1.5 | ug/L |
| Ba | 135 | 229776.402 | 2.3 | 46.667 | 99.02230 | 1.161 | 1.2 | ug/L |
| Ba | 137 | 397862.707 | 2.2 | 47.001 | 100.47265 | 0.553 | 0.6 | ug/L |
| > Tb | 159 | 385427.788 | 1.7 | 411268.087 | | | | ug/L |
| > Ho | 165 | 370439.849 | 0.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 763149.205 | 2.0 | 60.001 | 101.24195 | 2.268 | 2.2 | ug/L |
| Tl | 205 | 1707021.825 | 0.1 | 78.001 | 102.48307 | 0.189 | 0.2 | ug/L |
| Pb | 208 | 2463862.427 | 0.9 | 320.672 | 102.75582 | 1.216 | 1.2 | ug/L |

| | | | | | | | | |
|--|----|-----|------------|-----|--------|-----------|-------|----------|
| | Pb | 206 | 653983.408 | 1.6 | 87.335 | 103.68848 | 1.892 | 1.8 ug/L |
| | Pb | 207 | 539625.766 | 1.7 | 77.001 | 102.43980 | 2.017 | 2.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 96.305 | | | | |
| Al | 27 | 94.634 | | | | |
| > Sc | 45 | | 94.493 | | | |
| V | 51 | 100.755 | | | | |
| Cr | 52 | 102.333 | | | | |
| Cr | 53 | 103.299 | | | | |
| Mn | 55 | 97.281 | | | | |
| Co | 59 | 98.329 | | | | |
| Ni | 60 | 98.729 | | | | |
| Ni | 62 | 99.367 | | | | |
| Cu | 63 | 99.328 | | | | |
| Cu | 65 | 99.222 | | | | |
| Zn | 66 | 98.976 | | | | |
| Zn | 67 | 99.793 | | | | |
| Zn | 68 | 100.157 | | | | |
| > Ge | 72 | | 98.477 | | | |
| As | 75 | 100.267 | | | | |
| Se | 77 | 98.841 | | | | |
| Se | 78 | | | | | |
| Se | 82 | 97.876 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 101.165 | | | | |
| Mo | 97 | 101.099 | | | | |
| Mo | 98 | 98.399 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 101.704 | | | | |
| Ag | 109 | 101.550 | | | | |
| Cd | 111 | 99.314 | | | | |
| Cd | 114 | 99.612 | | | | |
| > In | 115 | | 98.501 | | | |
| Sb | 121 | 101.309 | | | | |
| Sb | 123 | 101.740 | | | | |
| Ba | 135 | 99.022 | | | | |
| Ba | 137 | 100.473 | | | | |
| > Tb | 159 | | 93.717 | | | |
| > Ho | 165 | | 94.961 | | | |
| Tl | 203 | 101.242 | | | | |
| Tl | 205 | 102.483 | | | | |
| Pb | 208 | 102.756 | | | | |
| Pb | 206 | 103.688 | | | | |
| Pb | 207 | 102.440 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 945866

Sample Date/Time: Monday, November 13, 2006 14:50:32

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\945866.013

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 69.668 | 15.9 | 63.001 | -0.00038 | 0.009 | 2446.6 | ug/L |
| Al | 27 | 30577.646 | 1.7 | 2334.350 | 3.65530 | 0.165 | 4.5 | ug/L |
| Sc | 45 | 426050.531 | 3.7 | 381869.082 | | | | ug/L |
| V | 51 | 4913.721 | 8.8 | 4488.603 | -0.00486 | 0.026 | 535.0 | ug/L |
| Cr | 52 | 26521.418 | 2.4 | 15368.650 | 0.58858 | 0.082 | 14.0 | ug/L |
| Cr | 53 | 3784.566 | 6.2 | 814.381 | 1.43378 | 0.175 | 12.2 | ug/L |
| Mn | 55 | 6134269.326 | 1.8 | 494.020 | 292.06429 | 6.622 | 2.3 | ug/L |
| Co | 59 | 11756.406 | 1.7 | 188.671 | 0.63159 | 0.004 | 0.6 | ug/L |
| Ni | 60 | 22965.848 | 2.8 | 136.669 | 5.55526 | 0.124 | 2.2 | ug/L |
| Ni | 62 | 2824.507 | 3.1 | 143.669 | 4.37675 | 0.132 | 3.0 | ug/L |
| Cu | 63 | 10286.784 | 2.4 | 212.338 | 1.07217 | 0.040 | 3.7 | ug/L |
| Cu | 65 | 1665.516 | 1.2 | 189.671 | 0.32280 | 0.003 | 1.0 | ug/L |
| Zn | 66 | 14665.376 | 2.0 | 1515.486 | 4.90951 | 0.048 | 1.0 | ug/L |
| Zn | 67 | 3637.831 | 3.1 | 342.344 | 7.08926 | 0.313 | 4.4 | ug/L |
| Zn | 68 | 16464.088 | 2.9 | 1170.427 | 7.78531 | 0.181 | 2.3 | ug/L |
| Ge | 72 | 254146.821 | 1.3 | 244883.968 | | | | ug/L |
| As | 75 | 8175.423 | 0.7 | 124.002 | 2.43606 | 0.023 | 0.9 | ug/L |
| Se | 77 | 487.814 | 1.1 | 216.736 | 1.06620 | 0.019 | 1.8 | ug/L |
| Se | 78 | 17830.322 | 2.6 | 16119.238 | 1.37504 | 0.663 | 48.2 | mg/L |
| Se | 82 | 2048.718 | 0.3 | 1872.010 | 0.32077 | 0.086 | 26.7 | ug/L |
| Kr | 83 | 1993.258 | 0.8 | 1902.236 | | | | mg/L |
| Y | 89 | 421436.300 | 1.3 | 408188.389 | | | | ug/L |
| Mo | 95 | 13678.034 | 4.5 | 112.002 | 2.57528 | 0.159 | 6.2 | ug/L |
| Mo | 97 | 8782.725 | 6.1 | 64.001 | 2.72191 | 0.214 | 7.9 | ug/L |
| Mo | 98 | 21846.222 | 8.8 | 98.282 | 2.69300 | 0.287 | 10.7 | ug/L |
| Rh | 103 | 336457.539 | 1.6 | 340052.119 | | | | ug/L |
| Ag | 107 | 1179.095 | 1.8 | 91.335 | 0.08395 | 0.001 | 0.7 | ug/L |
| Ag | 109 | 1135.422 | 5.3 | 75.668 | 0.08709 | 0.006 | 7.3 | ug/L |
| Cd | 111 | 74.174 | 55.4 | 218.275 | -0.04696 | 0.014 | 29.6 | ug/L |
| Cd | 114 | 146.441 | 20.0 | 58.957 | 0.01351 | 0.005 | 35.9 | ug/L |
| In | 115 | 350417.050 | 1.9 | 358352.924 | | | | ug/L |
| Sb | 121 | 2366.390 | 37.0 | 107.668 | 0.24932 | 0.101 | 40.6 | ug/L |
| Sb | 123 | 1734.764 | 37.3 | 79.665 | 0.23740 | 0.097 | 40.9 | ug/L |
| Ba | 135 | 128996.155 | 1.5 | 46.667 | 52.11465 | 0.914 | 1.8 | ug/L |
| Ba | 137 | 215277.802 | 0.9 | 47.001 | 50.96959 | 0.687 | 1.3 | ug/L |
| Tb | 159 | 411100.410 | 0.7 | 411268.087 | | | | ug/L |
| Ho | 165 | 388108.035 | 1.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 751.375 | 6.2 | 60.001 | 0.08763 | 0.007 | 7.7 | ug/L |
| Tl | 205 | 1678.186 | 3.3 | 78.001 | 0.09174 | 0.004 | 4.1 | ug/L |
| Pb | 208 | 2617.185 | 2.9 | 320.672 | 0.09151 | 0.004 | 4.1 | ug/L |

| | | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|-----|------|
| | Pb | 206 | 695.703 | 5.7 | 87.335 | 0.09214 | 0.006 | 6.5 | ug/L |
| | Pb | 207 | 560.024 | 5.0 | 77.001 | 0.08762 | 0.006 | 6.3 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 111.570 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 103.783 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 97.785 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.959 | | | |
| > Ho | 165 | | 99.490 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 945866D

Sample Date/Time: Monday, November 13, 2006 14:58:47

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\945866D.014

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 63.001 | 10.4 | 63.001 | -0.00579 | 0.006 | 101.5 | ug/L |
| Al | 27 | 25987.105 | 4.5 | 2334.350 | 3.04861 | 0.170 | 5.6 | ug/L |
| Sc | 45 | 426623.385 | 1.4 | 381869.082 | | | | ug/L |
| V | 51 | 4890.831 | 6.0 | 4488.603 | -0.00673 | 0.016 | 239.7 | ug/L |
| Cr | 52 | 25748.977 | 0.6 | 15368.650 | 0.53650 | 0.023 | 4.3 | ug/L |
| Cr | 53 | 3938.971 | 3.6 | 814.381 | 1.50444 | 0.076 | 5.1 | ug/L |
| Mn | 55 | 5845936.429 | 0.8 | 494.020 | 277.85767 | 5.177 | 1.9 | ug/L |
| Co | 59 | 11565.137 | 1.7 | 188.671 | 0.62024 | 0.020 | 3.3 | ug/L |
| Ni | 60 | 22472.822 | 1.3 | 136.669 | 5.42659 | 0.103 | 1.9 | ug/L |
| Ni | 62 | 2703.466 | 2.4 | 143.669 | 4.17063 | 0.064 | 1.5 | ug/L |
| Cu | 63 | 9753.140 | 3.6 | 212.338 | 1.01318 | 0.033 | 3.3 | ug/L |
| Cu | 65 | 1503.151 | 3.6 | 189.671 | 0.28652 | 0.011 | 3.8 | ug/L |
| Zn | 66 | 14565.867 | 1.7 | 1515.486 | 4.86314 | 0.082 | 1.7 | ug/L |
| Zn | 67 | 3693.857 | 5.3 | 342.344 | 7.19109 | 0.311 | 4.3 | ug/L |
| Zn | 68 | 15690.916 | 1.0 | 1170.427 | 7.37781 | 0.109 | 1.5 | ug/L |
| Ge | 72 | 254596.721 | 1.5 | 244883.968 | | | | ug/L |
| As | 75 | 7890.814 | 1.8 | 124.002 | 2.34561 | 0.036 | 1.5 | ug/L |
| Se | 77 | 465.613 | 2.7 | 216.736 | 0.97274 | 0.042 | 4.4 | ug/L |
| Se | 78 | 17536.364 | 2.8 | 16119.238 | 0.97101 | 0.707 | 72.8 | mg/L |
| Se | 82 | 1955.563 | 1.7 | 1872.010 | 0.02983 | 0.182 | 610.7 | ug/L |
| Kr | 83 | 1971.253 | 5.3 | 1902.236 | | | | mg/L |
| Y | 89 | 418402.013 | 2.1 | 408188.389 | | | | ug/L |
| Mo | 95 | 12251.456 | 1.3 | 112.002 | 2.20863 | 0.069 | 3.1 | ug/L |
| Mo | 97 | 7469.759 | 4.6 | 64.001 | 2.21559 | 0.123 | 5.5 | ug/L |
| Mo | 98 | 19172.104 | 0.5 | 98.282 | 2.26231 | 0.038 | 1.7 | ug/L |
| Rh | 103 | 328054.892 | 1.9 | 340052.119 | | | | ug/L |
| Ag | 107 | 978.067 | 6.0 | 91.335 | 0.06540 | 0.005 | 7.2 | ug/L |
| Ag | 109 | 896.391 | 1.8 | 75.668 | 0.06442 | 0.002 | 2.6 | ug/L |
| Cd | 111 | 121.726 | 19.8 | 218.275 | -0.03267 | 0.007 | 22.5 | ug/L |
| Cd | 114 | 132.092 | 78.9 | 58.957 | 0.01060 | 0.015 | 145.3 | ug/L |
| In | 115 | 365376.444 | 1.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 916.726 | 4.7 | 107.668 | 0.08498 | 0.006 | 6.9 | ug/L |
| Sb | 123 | 696.961 | 10.5 | 79.665 | 0.08431 | 0.011 | 13.5 | ug/L |
| Ba | 135 | 125831.254 | 1.4 | 46.667 | 51.56239 | 0.621 | 1.2 | ug/L |
| Ba | 137 | 218204.006 | 1.3 | 47.001 | 52.40922 | 1.303 | 2.5 | ug/L |
| Tb | 159 | 405304.156 | 1.2 | 411268.087 | | | | ug/L |
| Ho | 165 | 387425.020 | 1.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 772.377 | 4.6 | 60.001 | 0.09039 | 0.003 | 3.3 | ug/L |
| Tl | 205 | 1658.183 | 10.3 | 78.001 | 0.09067 | 0.009 | 9.4 | ug/L |
| Pb | 208 | 2365.821 | 2.5 | 320.672 | 0.08164 | 0.001 | 1.1 | ug/L |

Sample ID: 945866D

Report Date/Time: Monday, November 13, 2006 15:01:49

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 605.695 | 3.5 | 87.335 | 0.07867 | 0.003 | 3.4 ug/L |
| | Pb | 207 | 515.354 | 1.1 | 77.001 | 0.07969 | 0.002 | 2.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 111.720 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 103.966 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 101.960 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.550 | | | |
| > Ho | 165 | | 99.315 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 945866S

Sample Date/Time: Monday, November 13, 2006 15:04:45

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\945866S.015

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 21812.744 | 2.9 | 63.001 | 17.28365 | 0.609 | 3.5 | ug/L |
| Al | 27 | 181201.038 | 0.7 | 2334.350 | 23.38622 | 0.454 | 1.9 | ug/L |
| > Sc | 45 | 424877.991 | 2.4 | 381869.082 | | | | ug/L |
| V | 51 | 397404.841 | 1.0 | 4488.603 | 21.50858 | 0.583 | 2.7 | ug/L |
| Cr | 52 | 362902.589 | 1.6 | 15368.650 | 21.71894 | 0.866 | 4.0 | ug/L |
| Cr | 53 | 43431.988 | 0.5 | 814.381 | 21.21382 | 0.626 | 3.0 | ug/L |
| Mn | 55 | 6549190.794 | 1.1 | 494.020 | 307.47535 | 7.124 | 2.3 | ug/L |
| Co | 59 | 428858.529 | 1.6 | 188.671 | 23.09342 | 0.440 | 1.9 | ug/L |
| Ni | 60 | 110356.378 | 1.0 | 136.669 | 26.45610 | 0.634 | 2.4 | ug/L |
| Ni | 62 | 16376.578 | 2.2 | 143.669 | 26.17482 | 0.720 | 2.7 | ug/L |
| Cu | 63 | 220060.257 | 1.4 | 212.338 | 23.07943 | 0.088 | 0.4 | ug/L |
| Cu | 65 | 105918.620 | 0.8 | 189.671 | 22.91072 | 0.181 | 0.8 | ug/L |
| Zn | 66 | 66279.253 | 1.9 | 1515.486 | 23.91805 | 0.436 | 1.8 | ug/L |
| Zn | 67 | 12495.487 | 1.4 | 342.344 | 25.83982 | 0.740 | 2.9 | ug/L |
| Zn | 68 | 55348.430 | 1.0 | 1170.427 | 27.24391 | 0.151 | 0.6 | ug/L |
| > Ge | 72 | 257764.980 | 1.5 | 244883.968 | | | | ug/L |
| As | 75 | 73731.178 | 1.3 | 124.002 | 21.97358 | 0.610 | 2.8 | ug/L |
| Se | 77 | 4814.657 | 0.8 | 216.736 | 18.34109 | 0.162 | 0.9 | ug/L |
| Se | 78 | 30706.473 | 1.1 | 16119.238 | 16.88548 | 0.843 | 5.0 | mg/L |
| Se | 82 | 7722.844 | 1.0 | 1872.010 | 17.14215 | 0.148 | 0.9 | ug/L |
| Kr | 83 | 1932.243 | 3.2 | 1902.236 | | | | mg/L |
| Y | 89 | 431249.957 | 0.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 138909.905 | 0.3 | 112.002 | 25.58586 | 0.108 | 0.4 | ug/L |
| Mo | 97 | 87846.849 | 1.2 | 64.001 | 26.60752 | 0.368 | 1.4 | ug/L |
| Mo | 98 | 221087.538 | 1.0 | 98.282 | 26.55909 | 0.196 | 0.7 | ug/L |
| Rh | 103 | 332016.737 | 1.5 | 340052.119 | | | | ug/L |
| Ag | 107 | 289400.015 | 1.6 | 91.335 | 21.66086 | 0.425 | 2.0 | ug/L |
| Ag | 109 | 268508.393 | 1.8 | 75.668 | 21.38774 | 0.384 | 1.8 | ug/L |
| Cd | 111 | 64262.344 | 1.0 | 218.275 | 20.99227 | 0.239 | 1.1 | ug/L |
| Cd | 114 | 146118.318 | 0.7 | 58.957 | 21.50506 | 0.098 | 0.5 | ug/L |
| > In | 115 | 360550.956 | 0.6 | 358352.924 | | | | ug/L |
| Sb | 121 | 210822.728 | 1.0 | 107.668 | 22.47214 | 0.135 | 0.6 | ug/L |
| Sb | 123 | 158947.755 | 1.1 | 79.665 | 22.01539 | 0.387 | 1.8 | ug/L |
| Ba | 135 | 181042.704 | 3.0 | 46.667 | 72.39579 | 2.462 | 3.4 | ug/L |
| Ba | 137 | 300247.324 | 0.7 | 47.001 | 70.36998 | 1.964 | 2.8 | ug/L |
| > Tb | 159 | 415458.863 | 2.2 | 411268.087 | | | | ug/L |
| > Ho | 165 | 392185.554 | 1.1 | 390096.908 | | | | ug/L |
| Tl | 203 | 175907.626 | 0.1 | 60.001 | 22.03756 | 0.246 | 1.1 | ug/L |
| Tl | 205 | 417753.241 | 0.5 | 78.001 | 23.68719 | 0.143 | 0.6 | ug/L |
| Pb | 208 | 569044.869 | 0.4 | 320.672 | 22.40706 | 0.185 | 0.8 | ug/L |

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 146290.683 | 0.4 | 87.335 | 21.89869 | 0.240 | 1.1 ug/L |
| | Pb | 207 | 120123.823 | 0.9 | 77.001 | 21.53051 | 0.415 | 1.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 111.263 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 105.260 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 100.613 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 101.019 | | | |
| > Ho | 165 | | 100.535 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 945866A

Sample Date/Time: Monday, November 13, 2006 15:10:42

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\945866A.016

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 20847.588 | 0.9 | 63.001 | 16.82822 | 0.304 | 1.8 | ug/L |
| Al | 27 | 164370.322 | 1.1 | 2334.350 | 21.59276 | 0.683 | 3.2 | ug/L |
| > Sc | 45 | 417026.768 | 2.7 | 381869.082 | | | | ug/L |
| V | 51 | 370442.605 | 3.7 | 4488.603 | 20.42858 | 1.325 | 6.5 | ug/L |
| Cr | 52 | 330685.780 | 1.6 | 15368.650 | 20.09002 | 0.891 | 4.4 | ug/L |
| Cr | 53 | 41794.343 | 2.7 | 814.381 | 20.78149 | 0.315 | 1.5 | ug/L |
| Mn | 55 | 6251185.079 | 0.7 | 494.020 | 303.47080 | 3.633 | 1.2 | ug/L |
| Co | 59 | 398793.440 | 0.8 | 188.671 | 22.20601 | 0.097 | 0.4 | ug/L |
| Ni | 60 | 107522.080 | 1.7 | 136.669 | 26.65689 | 0.738 | 2.8 | ug/L |
| Ni | 62 | 14885.433 | 1.2 | 143.669 | 24.58580 | 0.100 | 0.4 | ug/L |
| Cu | 63 | 205889.444 | 0.3 | 212.338 | 22.33133 | 0.163 | 0.7 | ug/L |
| Cu | 65 | 97303.964 | 2.4 | 189.671 | 21.76783 | 0.731 | 3.4 | ug/L |
| Zn | 66 | 60924.847 | 0.7 | 1515.486 | 22.70723 | 0.079 | 0.3 | ug/L |
| Zn | 67 | 12157.652 | 1.7 | 342.344 | 25.99710 | 0.251 | 1.0 | ug/L |
| Zn | 68 | 51034.335 | 1.8 | 1170.427 | 25.95155 | 0.597 | 2.3 | ug/L |
| > Ge | 72 | 249244.845 | 1.1 | 244883.968 | | | | ug/L |
| As | 75 | 69813.308 | 1.8 | 124.002 | 21.51483 | 0.627 | 2.9 | ug/L |
| Se | 77 | 4497.947 | 1.6 | 216.736 | 17.68756 | 0.178 | 1.0 | ug/L |
| Se | 78 | 30485.674 | 1.6 | 16119.238 | 17.89398 | 1.029 | 5.8 | mg/L |
| Se | 82 | 7301.131 | 0.9 | 1872.010 | 16.62806 | 0.038 | 0.2 | ug/L |
| Kr | 83 | 1953.915 | 3.1 | 1902.236 | | | | mg/L |
| Y | 89 | 411719.163 | 3.0 | 408188.389 | | | | ug/L |
| Mo | 95 | 134035.647 | 2.1 | 112.002 | 24.91752 | 0.879 | 3.5 | ug/L |
| Mo | 97 | 81038.381 | 2.1 | 64.001 | 24.77094 | 0.809 | 3.3 | ug/L |
| Mo | 98 | 202081.809 | 1.7 | 98.282 | 24.49517 | 0.411 | 1.7 | ug/L |
| Rh | 103 | 321093.743 | 1.1 | 340052.119 | | | | ug/L |
| Ag | 107 | 278036.998 | 1.2 | 91.335 | 21.00085 | 0.518 | 2.5 | ug/L |
| Ag | 109 | 263686.655 | 0.9 | 75.668 | 21.19681 | 0.479 | 2.3 | ug/L |
| Cd | 111 | 59328.422 | 2.9 | 218.275 | 19.54828 | 0.408 | 2.1 | ug/L |
| Cd | 114 | 134082.258 | 0.1 | 58.957 | 19.91327 | 0.294 | 1.5 | ug/L |
| > In | 115 | 357335.185 | 1.4 | 358352.924 | | | | ug/L |
| Sb | 121 | 195461.385 | 0.6 | 107.668 | 21.02341 | 0.179 | 0.9 | ug/L |
| Sb | 123 | 150756.622 | 0.6 | 79.665 | 21.07038 | 0.390 | 1.9 | ug/L |
| Ba | 135 | 176924.407 | 2.2 | 46.667 | 75.61875 | 2.769 | 3.7 | ug/L |
| Ba | 137 | 299188.527 | 0.6 | 47.001 | 74.92425 | 1.490 | 2.0 | ug/L |
| > Tb | 159 | 388755.687 | 1.6 | 411268.087 | | | | ug/L |
| > Ho | 165 | 377262.541 | 1.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 162854.666 | 1.2 | 60.001 | 21.20791 | 0.150 | 0.7 | ug/L |
| Tl | 205 | 382739.528 | 0.3 | 78.001 | 22.56157 | 0.289 | 1.3 | ug/L |
| Pb | 208 | 531590.443 | 1.3 | 320.672 | 21.75994 | 0.298 | 1.4 | ug/L |

Sample ID: 945866A

Report Date/Time: Monday, November 13, 2006 15:13:43

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 137486.000 | 1.2 | 87.335 | 21.39589 | 0.418 | 2.0 ug/L |
| | Pb | 207 | 113079.553 | 1.0 | 77.001 | 21.07059 | 0.477 | 2.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 109.207 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 101.781 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 99.716 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 94.526 | | | |
| > Ho | 165 | | 96.710 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 945866L

Sample Date/Time: Monday, November 13, 2006 15:16:39

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\945866L.017

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 64.334 | 17.9 | 63.001 | 0.00055 | 0.010 | 1900.5 | ug/L |
| Al | 27 | 16514.192 | 3.5 | 2334.350 | 2.03695 | 0.096 | 4.7 | ug/L |
| Sc | 45 | 386474.267 | 1.0 | 381869.082 | | | | ug/L |
| V | 51 | 4497.793 | 9.8 | 4488.603 | -0.00283 | 0.024 | 857.1 | ug/L |
| Cr | 52 | 17675.571 | 1.3 | 15368.650 | 0.14641 | 0.012 | 8.1 | ug/L |
| Cr | 53 | 1839.555 | 2.0 | 814.381 | 0.55656 | 0.016 | 2.9 | ug/L |
| Mn | 55 | 1155957.031 | 3.2 | 494.020 | 56.21364 | 1.117 | 2.0 | ug/L |
| Co | 59 | 2386.366 | 3.6 | 188.671 | 0.12250 | 0.001 | 0.8 | ug/L |
| Ni | 60 | 4468.912 | 5.8 | 136.669 | 1.07899 | 0.101 | 9.4 | ug/L |
| Ni | 62 | 650.032 | 3.0 | 143.669 | 0.84302 | 0.037 | 4.4 | ug/L |
| Cu | 63 | 2571.089 | 1.6 | 212.338 | 0.25651 | 0.013 | 5.1 | ug/L |
| Cu | 65 | 762.376 | 2.8 | 189.671 | 0.12799 | 0.005 | 3.7 | ug/L |
| Zn | 66 | 4874.808 | 1.2 | 1515.486 | 1.27964 | 0.081 | 6.3 | ug/L |
| Zn | 67 | 1122.087 | 2.0 | 342.344 | 1.70902 | 0.051 | 3.0 | ug/L |
| Zn | 68 | 4498.926 | 0.5 | 1170.427 | 1.72820 | 0.071 | 4.1 | ug/L |
| Ge | 72 | 248755.252 | 3.3 | 244883.968 | | | | ug/L |
| As | 75 | 1716.527 | 2.6 | 124.002 | 0.49218 | 0.016 | 3.3 | ug/L |
| Se | 77 | 274.071 | 3.9 | 216.736 | 0.22347 | 0.029 | 12.8 | ug/L |
| Se | 78 | 16024.266 | 1.6 | 16119.238 | -0.42718 | 0.860 | 201.4 | mg/L |
| Se | 82 | 1819.865 | 1.5 | 1872.010 | -0.24997 | 0.109 | 43.7 | ug/L |
| Kr | 83 | 1829.552 | 0.9 | 1902.236 | | | | mg/L |
| Y | 89 | 410055.334 | 1.7 | 408188.389 | | | | ug/L |
| Mo | 95 | 2508.403 | 1.8 | 112.002 | 0.44679 | 0.005 | 1.2 | ug/L |
| Mo | 97 | 1510.819 | 3.7 | 64.001 | 0.44365 | 0.020 | 4.6 | ug/L |
| Mo | 98 | 3825.267 | 1.4 | 98.282 | 0.45300 | 0.004 | 1.0 | ug/L |
| Rh | 103 | 333714.226 | 0.7 | 340052.119 | | | | ug/L |
| Ag | 107 | 304.675 | 5.2 | 91.335 | 0.01619 | 0.001 | 7.2 | ug/L |
| Ag | 109 | 279.674 | 7.8 | 75.668 | 0.01648 | 0.002 | 11.8 | ug/L |
| Cd | 111 | 169.695 | 18.3 | 218.275 | -0.01579 | 0.010 | 62.7 | ug/L |
| Cd | 114 | 21.513 | 185.4 | 58.957 | -0.00551 | 0.006 | 107.7 | ug/L |
| In | 115 | 356550.372 | 0.9 | 358352.924 | | | | ug/L |
| Sb | 121 | 549.690 | 10.6 | 107.668 | 0.04769 | 0.006 | 12.1 | ug/L |
| Sb | 123 | 404.707 | 11.4 | 79.665 | 0.04558 | 0.006 | 13.6 | ug/L |
| Ba | 135 | 26232.157 | 1.5 | 46.667 | 10.68736 | 0.071 | 0.7 | ug/L |
| Ba | 137 | 44138.370 | 1.3 | 47.001 | 10.54567 | 0.197 | 1.9 | ug/L |
| Tb | 159 | 407058.704 | 1.0 | 411268.087 | | | | ug/L |
| Ho | 165 | 387412.501 | 1.9 | 390096.908 | | | | ug/L |
| Tl | 203 | 262.673 | 4.2 | 60.001 | 0.02578 | 0.002 | 6.5 | ug/L |
| Tl | 205 | 580.026 | 3.7 | 78.001 | 0.02887 | 0.002 | 5.8 | ug/L |
| Pb | 208 | 944.697 | 1.9 | 320.672 | 0.02498 | 0.001 | 2.1 | ug/L |

Sample ID: 945866L

Report Date/Time: Monday, November 13, 2006 15:19:41

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 242.006 | 5.4 | 87.335 | 0.02353 | 0.001 | 5.9 ug/L |
| | Pb | 207 | 210.338 | 3.4 | 77.001 | 0.02430 | 0.001 | 2.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 101.206 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 101.581 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 99.497 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.976 | | | |
| > [Ho | 165 | | 99.312 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 945867

Sample Date/Time: Monday, November 13, 2006 15:22:37

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\945867.018

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 65.668 | 4.9 | 63.001 | -0.00683 | 0.002 | 23.8 | ug/L |
| Al | 27 | 49953.788 | 1.2 | 2334.350 | 5.78698 | 0.044 | 0.8 | ug/L |
| > Sc | 45 | 453472.089 | 1.6 | 381869.082 | | | | ug/L |
| V | 51 | 4850.286 | 4.7 | 4488.603 | -0.02470 | 0.009 | 36.1 | ug/L |
| Cr | 52 | 27879.169 | 0.2 | 15368.650 | 0.56657 | 0.028 | 5.0 | ug/L |
| Cr | 53 | 4304.822 | 2.5 | 814.381 | 1.55916 | 0.028 | 1.8 | ug/L |
| Mn | 55 | 5779565.580 | 0.9 | 494.020 | 260.26784 | 3.984 | 1.5 | ug/L |
| Co | 59 | 11535.428 | 1.3 | 188.671 | 0.58547 | 0.012 | 2.0 | ug/L |
| Ni | 60 | 22725.171 | 0.4 | 136.669 | 5.19816 | 0.094 | 1.8 | ug/L |
| Ni | 62 | 2730.142 | 4.1 | 143.669 | 3.98259 | 0.234 | 5.9 | ug/L |
| Cu | 63 | 12444.080 | 2.9 | 212.338 | 1.23003 | 0.044 | 3.6 | ug/L |
| Cu | 65 | 2302.008 | 2.6 | 189.671 | 0.43525 | 0.009 | 2.0 | ug/L |
| Zn | 66 | 20990.620 | 2.1 | 1515.486 | 6.85487 | 0.045 | 0.7 | ug/L |
| Zn | 67 | 4990.544 | 0.4 | 342.344 | 9.42566 | 0.177 | 1.9 | ug/L |
| Zn | 68 | 21285.365 | 1.2 | 1170.427 | 9.66086 | 0.242 | 2.5 | ug/L |
| > Ge | 72 | 268704.651 | 1.5 | 244883.968 | | | | ug/L |
| As | 75 | 8522.775 | 0.7 | 124.002 | 2.40166 | 0.043 | 1.8 | ug/L |
| Se | 77 | 491.615 | 2.2 | 216.736 | 0.97339 | 0.017 | 1.7 | ug/L |
| Se | 78 | 17619.070 | 1.9 | 16119.238 | -0.07363 | 0.696 | 945.2 | mg/L |
| Se | 82 | 2011.843 | 2.6 | 1872.010 | -0.12057 | 0.139 | 115.5 | ug/L |
| Kr | 83 | 1975.587 | 3.1 | 1902.236 | | | | mg/L |
| Y | 89 | 441900.211 | 0.7 | 408188.389 | | | | ug/L |
| Mo | 95 | 12776.916 | 0.8 | 112.002 | 2.20674 | 0.015 | 0.7 | ug/L |
| Mo | 97 | 7562.839 | 1.0 | 64.001 | 2.14851 | 0.027 | 1.2 | ug/L |
| Mo | 98 | 19644.358 | 1.8 | 98.282 | 2.22080 | 0.011 | 0.5 | ug/L |
| Rh | 103 | 343308.688 | 0.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 833.717 | 1.3 | 91.335 | 0.05216 | 0.002 | 3.0 | ug/L |
| Ag | 109 | 763.376 | 3.7 | 75.668 | 0.05148 | 0.003 | 5.4 | ug/L |
| Cd | 111 | 65.424 | 67.1 | 218.275 | -0.05167 | 0.014 | 26.3 | ug/L |
| Cd | 114 | 93.287 | 97.6 | 58.957 | 0.00437 | 0.013 | 294.8 | ug/L |
| > In | 115 | 381247.167 | 1.3 | 358352.924 | | | | ug/L |
| Sb | 121 | 529.356 | 7.8 | 107.668 | 0.04181 | 0.004 | 8.8 | ug/L |
| Sb | 123 | 391.593 | 11.1 | 79.665 | 0.04019 | 0.005 | 13.3 | ug/L |
| Ba | 135 | 162098.915 | 1.6 | 46.667 | 64.97957 | 1.916 | 2.9 | ug/L |
| Ba | 137 | 276304.727 | 1.9 | 47.001 | 64.91119 | 2.161 | 3.3 | ug/L |
| > Tb | 159 | 414449.076 | 1.6 | 411268.087 | | | | ug/L |
| > Ho | 165 | 409576.111 | 0.8 | 390096.908 | | | | ug/L |
| Tl | 203 | 740.707 | 7.9 | 60.001 | 0.08131 | 0.007 | 8.4 | ug/L |
| Tl | 205 | 1778.543 | 12.6 | 78.001 | 0.09212 | 0.012 | 13.1 | ug/L |
| Pb | 208 | 2672.195 | 2.5 | 320.672 | 0.08812 | 0.003 | 3.5 | ug/L |

Sample ID: 945867

Report Date/Time: Monday, November 13, 2006 15:25:38

Page 1

174

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 726.372 | 3.5 | 87.335 | 0.09104 | 0.004 | 4.8 ug/L |
| | Pb | 207 | 539.356 | 3.5 | 77.001 | 0.07875 | 0.004 | 4.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 118.751 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 109.727 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 106.389 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.773 | | | |
| > Ho | 165 | | 104.993 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 946569

Sample Date/Time: Monday, November 13, 2006 15:28:34

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\946569.019

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 172.670 | 0.3 | 63.001 | 0.07961 | 0.002 | 2.3 | ug/L |
| Al | 27 | 189695.364 | 0.7 | 2334.350 | 24.14746 | 0.325 | 1.3 | ug/L |
| Sc | 45 | 430876.163 | 1.1 | 381869.082 | | | | ug/L |
| V | 51 | 5379.862 | 10.8 | 4488.603 | 0.01694 | 0.030 | 175.5 | ug/L |
| Cr | 52 | 34225.513 | 2.6 | 15368.650 | 1.04496 | 0.044 | 4.2 | ug/L |
| Cr | 53 | 3382.054 | 2.2 | 814.381 | 1.21142 | 0.053 | 4.4 | ug/L |
| Mn | 55 | 18983031.444 | 1.4 | 494.020 | 831.62209 | 18.658 | 2.2 | ug/L |
| Co | 59 | 46786.472 | 2.0 | 188.671 | 2.34154 | 0.070 | 3.0 | ug/L |
| Ni | 60 | 24829.522 | 1.4 | 136.669 | 5.52769 | 0.180 | 3.3 | ug/L |
| Ni | 62 | 4567.632 | 4.1 | 143.669 | 6.63285 | 0.340 | 5.1 | ug/L |
| Cu | 63 | 10279.106 | 1.7 | 212.338 | 0.98385 | 0.035 | 3.6 | ug/L |
| Cu | 65 | 4364.522 | 5.1 | 189.671 | 0.83968 | 0.054 | 6.5 | ug/L |
| Zn | 66 | 67553.755 | 1.6 | 1515.486 | 22.71855 | 0.354 | 1.6 | ug/L |
| Zn | 67 | 10865.522 | 1.3 | 342.344 | 20.82339 | 0.697 | 3.3 | ug/L |
| Zn | 68 | 50372.982 | 1.6 | 1170.427 | 23.04353 | 0.390 | 1.7 | ug/L |
| Ge | 72 | 276259.372 | 2.0 | 244883.968 | | | | ug/L |
| As | 75 | 3145.625 | 1.1 | 124.002 | 0.83734 | 0.023 | 2.8 | ug/L |
| Se | 77 | 290.338 | 3.4 | 216.736 | 0.17158 | 0.053 | 31.0 | ug/L |
| Se | 78 | 17879.234 | 2.2 | 16119.238 | -0.33988 | 0.810 | 238.3 | mg/L |
| Se | 82 | 1407.119 | 8.9 | 1872.010 | -1.96299 | 0.273 | 13.9 | ug/L |
| Kr | 83 | 1374.461 | 6.4 | 1902.236 | | | | mg/L |
| Y | 89 | 457134.315 | 2.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 1102.417 | 5.6 | 112.002 | 0.16969 | 0.011 | 6.4 | ug/L |
| Mo | 97 | 611.695 | 1.9 | 64.001 | 0.15425 | 0.003 | 2.1 | ug/L |
| Mo | 98 | 1456.976 | 2.5 | 98.282 | 0.15223 | 0.004 | 2.7 | ug/L |
| Rh | 103 | 351263.419 | 0.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 334.677 | 2.5 | 91.335 | 0.01660 | 0.001 | 3.6 | ug/L |
| Ag | 109 | 329.343 | 5.2 | 75.668 | 0.01853 | 0.001 | 7.1 | ug/L |
| Cd | 111 | 446.333 | 2.3 | 218.275 | 0.06513 | 0.003 | 5.3 | ug/L |
| Cd | 114 | 648.405 | 21.9 | 58.957 | 0.08073 | 0.019 | 24.1 | ug/L |
| In | 115 | 384702.001 | 0.2 | 358352.924 | | | | ug/L |
| Sb | 121 | 907.725 | 2.7 | 107.668 | 0.07918 | 0.002 | 2.9 | ug/L |
| Sb | 123 | 710.374 | 2.3 | 79.665 | 0.08115 | 0.002 | 2.8 | ug/L |
| Ba | 135 | 63933.288 | 0.6 | 46.667 | 25.03666 | 0.324 | 1.3 | ug/L |
| Ba | 137 | 107067.149 | 0.4 | 47.001 | 24.57489 | 0.229 | 0.9 | ug/L |
| Tb | 159 | 423969.344 | 1.3 | 411268.087 | | | | ug/L |
| Ho | 165 | 412689.801 | 0.6 | 390096.908 | | | | ug/L |
| Tl | 203 | 178.337 | 5.7 | 60.001 | 0.01368 | 0.001 | 9.7 | ug/L |
| Tl | 205 | 339.010 | 5.7 | 78.001 | 0.01383 | 0.001 | 8.3 | ug/L |
| Pb | 208 | 21682.249 | 0.3 | 320.672 | 0.79908 | 0.003 | 0.4 | ug/L |

Sample ID: 946569

Report Date/Time: Monday, November 13, 2006 15:31:35

Page 1

177

| | | | | | | | | | |
|---|----|-----|----------|-----|--------|---------|-------|-----|------|
| | Pb | 206 | 5787.067 | 1.4 | 87.335 | 0.81050 | 0.007 | 0.8 | ug/L |
| L | Pb | 207 | 4472.578 | 1.9 | 77.001 | 0.74829 | 0.010 | 1.4 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 112.833 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 112.812 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 107.353 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 103.088 | | | |
| > [Ho | 165 | | 105.792 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 946572

Sample Date/Time: Monday, November 13, 2006 15:34:32

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\946572.020

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 93.001 | 10.3 | 63.001 | 0.01753 | 0.008 | 43.2 | ug/L |
| Al | 27 | 182898.000 | 3.5 | 2334.350 | 23.38504 | 0.858 | 3.7 | ug/L |
| > Sc | 45 | 428769.473 | 0.2 | 381869.082 | | | | ug/L |
| V | 51 | 6231.456 | 8.7 | 4488.603 | 0.06472 | 0.030 | 45.9 | ug/L |
| Cr | 52 | 36762.660 | 3.0 | 15368.650 | 1.21328 | 0.069 | 5.7 | ug/L |
| Cr | 53 | 3686.852 | 0.9 | 814.381 | 1.36982 | 0.015 | 1.1 | ug/L |
| Mn | 55 | 81255923.121 | 0.7 | 494.020 | 3702.52431 | 33.199 | 0.9 | ug/L |
| Co | 59 | 399121.217 | 1.5 | 188.671 | 20.86138 | 0.523 | 2.5 | ug/L |
| Ni | 60 | 166864.306 | 2.3 | 136.669 | 38.83147 | 0.383 | 1.0 | ug/L |
| Ni | 62 | 27732.371 | 2.9 | 143.669 | 43.19127 | 1.911 | 4.4 | ug/L |
| Cu | 63 | 44118.957 | 2.2 | 212.338 | 4.47321 | 0.139 | 3.1 | ug/L |
| Cu | 65 | 19396.408 | 0.6 | 189.671 | 4.03687 | 0.055 | 1.4 | ug/L |
| Zn | 66 | 212166.188 | 1.0 | 1515.486 | 75.56845 | 1.758 | 2.3 | ug/L |
| Zn | 67 | 34490.611 | 2.8 | 342.344 | 70.49676 | 1.721 | 2.4 | ug/L |
| Zn | 68 | 162205.390 | 0.5 | 1170.427 | 78.64548 | 1.101 | 1.4 | ug/L |
| > Ge | 72 | 265570.917 | 1.6 | 244883.968 | | | | ug/L |
| As | 75 | 5088.271 | 2.9 | 124.002 | 1.43496 | 0.026 | 1.8 | ug/L |
| Se | 77 | 362.675 | 0.6 | 216.736 | 0.49565 | 0.030 | 6.1 | ug/L |
| Se | 78 | 18507.413 | 1.4 | 16119.238 | 1.22440 | 0.093 | 7.6 | mg/L |
| Se | 82 | 1667.167 | 0.7 | 1872.010 | -1.04894 | 0.089 | 8.5 | ug/L |
| Kr | 83 | 1523.488 | 3.5 | 1902.236 | | | | mg/L |
| Y | 89 | 432695.889 | 0.8 | 408188.389 | | | | ug/L |
| Mo | 95 | 1250.106 | 3.9 | 112.002 | 0.20265 | 0.008 | 4.0 | ug/L |
| Mo | 97 | 427.349 | 3.6 | 64.001 | 0.10611 | 0.006 | 5.4 | ug/L |
| Mo | 98 | 984.123 | 2.2 | 98.282 | 0.10280 | 0.003 | 2.5 | ug/L |
| Rh | 103 | 340620.475 | 1.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 227.672 | 2.5 | 91.335 | 0.00965 | 0.001 | 5.6 | ug/L |
| Ag | 109 | 171.670 | 10.0 | 75.668 | 0.00719 | 0.001 | 16.9 | ug/L |
| Cd | 111 | 1295.866 | 1.2 | 218.275 | 0.33988 | 0.006 | 1.8 | ug/L |
| Cd | 114 | 2770.531 | 6.6 | 58.957 | 0.38678 | 0.026 | 6.7 | ug/L |
| > In | 115 | 371864.000 | 1.1 | 358352.924 | | | | ug/L |
| Sb | 121 | 2251.994 | 3.9 | 107.668 | 0.22127 | 0.007 | 3.1 | ug/L |
| Sb | 123 | 1696.708 | 1.0 | 79.665 | 0.21688 | 0.005 | 2.2 | ug/L |
| Ba | 135 | 166759.186 | 1.4 | 46.667 | 66.98364 | 0.557 | 0.8 | ug/L |
| Ba | 137 | 279188.600 | 1.6 | 47.001 | 65.71692 | 0.507 | 0.8 | ug/L |
| > Tb | 159 | 413485.398 | 0.9 | 411268.087 | | | | ug/L |
| > Ho | 165 | 394080.141 | 1.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 486.352 | 3.2 | 60.001 | 0.05309 | 0.002 | 2.9 | ug/L |
| Tl | 205 | 1091.416 | 7.8 | 78.001 | 0.05720 | 0.006 | 9.6 | ug/L |
| Pb | 208 | 116402.509 | 1.1 | 320.672 | 4.55130 | 0.022 | 0.5 | ug/L |

Sample ID: 946572

Report Date/Time: Monday, November 13, 2006 15:37:33

Page 1

| | | | | | | | | |
|--|----|-----|-----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 30557.913 | 2.1 | 87.335 | 4.54153 | 0.065 | 1.4 ug/L |
| | Pb | 207 | 24550.356 | 0.6 | 77.001 | 4.36839 | 0.092 | 2.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 112.282 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 108.448 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 103.770 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 100.539 | | | |
| > [Ho | 165 | | 101.021 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 946573

Sample Date/Time: Monday, November 13, 2006 15:40:30

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\946573.021

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 472.018 | 4.2 | 63.001 | 0.31885 | 0.012 | 3.8 | ug/L |
| Al | 27 | 1597539.911 | 0.8 | 2334.350 | 208.54781 | 3.994 | 1.9 | ug/L |
| > Sc | 45 | 425411.444 | 1.3 | 381869.082 | | | | ug/L |
| V | 51 | 3947.168 | 23.7 | 4488.603 | -0.05787 | 0.049 | 85.3 | ug/L |
| Cr | 52 | 162248.124 | 1.6 | 15368.650 | 9.10013 | 0.278 | 3.1 | ug/L |
| Cr | 53 | 19074.998 | 0.8 | 814.381 | 9.04801 | 0.111 | 1.2 | ug/L |
| Mn | 55 | 15635391.396 | 0.8 | 494.020 | 691.05135 | 17.029 | 2.5 | ug/L |
| Co | 59 | 428274.907 | 1.8 | 188.671 | 21.70906 | 0.520 | 2.4 | ug/L |
| Ni | 60 | 62037.222 | 3.7 | 136.669 | 13.99105 | 0.823 | 5.9 | ug/L |
| Ni | 62 | 10385.906 | 1.3 | 143.669 | 15.52637 | 0.219 | 1.4 | ug/L |
| Cu | 63 | 57480.144 | 1.0 | 212.338 | 5.65883 | 0.169 | 3.0 | ug/L |
| Cu | 65 | 27715.959 | 0.8 | 189.671 | 5.61190 | 0.146 | 2.6 | ug/L |
| Zn | 66 | 267248.946 | 1.0 | 1515.486 | 92.45225 | 2.500 | 2.7 | ug/L |
| Zn | 67 | 43005.116 | 0.9 | 342.344 | 85.44091 | 2.708 | 3.2 | ug/L |
| Zn | 68 | 194205.211 | 0.8 | 1170.427 | 91.43872 | 2.648 | 2.9 | ug/L |
| > Ge | 72 | 273855.536 | 2.2 | 244883.968 | | | | ug/L |
| As | 75 | 6079.611 | 1.8 | 124.002 | 1.66920 | 0.021 | 1.3 | ug/L |
| Se | 77 | 400.143 | 5.5 | 216.736 | 0.59497 | 0.104 | 17.5 | ug/L |
| Se | 78 | 18121.537 | 3.0 | 16119.238 | 0.12657 | 1.097 | 866.7 | mg/L |
| Se | 82 | 1839.203 | 2.4 | 1872.010 | -0.71321 | 0.039 | 5.5 | ug/L |
| Kr | 83 | 1754.869 | 4.7 | 1902.236 | | | | mg/L |
| Y | 89 | 726495.629 | 1.0 | 408188.389 | | | | ug/L |
| Mo | 95 | 6565.653 | 3.4 | 112.002 | 1.13611 | 0.046 | 4.1 | ug/L |
| Mo | 97 | 3926.631 | 1.0 | 64.001 | 1.11797 | 0.012 | 1.1 | ug/L |
| Mo | 98 | 9994.708 | 1.8 | 98.282 | 1.13623 | 0.026 | 2.3 | ug/L |
| Rh | 103 | 344236.084 | 1.2 | 340052.119 | | | | ug/L |
| Ag | 107 | 603.695 | 1.6 | 91.335 | 0.03631 | 0.000 | 1.3 | ug/L |
| Ag | 109 | 615.029 | 3.9 | 75.668 | 0.04076 | 0.002 | 4.2 | ug/L |
| Cd | 111 | 998.936 | 0.3 | 218.275 | 0.24096 | 0.002 | 1.0 | ug/L |
| Cd | 114 | 1491.863 | 4.8 | 58.957 | 0.20116 | 0.009 | 4.4 | ug/L |
| > In | 115 | 377252.455 | 0.6 | 358352.924 | | | | ug/L |
| Sb | 121 | 1552.494 | 2.5 | 107.668 | 0.14670 | 0.005 | 3.1 | ug/L |
| Sb | 123 | 1173.400 | 2.9 | 79.665 | 0.14428 | 0.004 | 2.9 | ug/L |
| Ba | 135 | 137122.345 | 0.7 | 46.667 | 53.64426 | 0.913 | 1.7 | ug/L |
| Ba | 137 | 228538.501 | 0.9 | 47.001 | 52.39249 | 0.587 | 1.1 | ug/L |
| > Tb | 159 | 424570.761 | 1.0 | 411268.087 | | | | ug/L |
| > Ho | 165 | 413499.999 | 1.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 442.349 | 1.5 | 60.001 | 0.04502 | 0.001 | 1.9 | ug/L |
| Tl | 205 | 959.398 | 7.4 | 78.001 | 0.04719 | 0.004 | 9.2 | ug/L |
| Pb | 208 | 154548.033 | 0.2 | 320.672 | 5.76290 | 0.079 | 1.4 | ug/L |

| | | | | | | | | |
|--|----|-----|-----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 41527.645 | 1.5 | 87.335 | 5.88591 | 0.004 | 0.1 ug/L |
| | Pb | 207 | 31897.601 | 2.1 | 77.001 | 5.41245 | 0.157 | 2.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 111.402 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 111.831 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 105.274 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 103.235 | | | |
| > [Ho | 165 | | 105.999 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 13, 2006 15:46:28

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 6.022

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 51825.843 | 0.6 | 63.001 | 48.83578 | 0.398 | 0.8 | ug/L |
| Al | 27 | 306964.195 | 2.2 | 2334.350 | 47.37141 | 1.598 | 3.4 | ug/L |
| Sc | 45 | 357920.274 | 1.4 | 381869.082 | | | | ug/L |
| V | 51 | 803021.070 | 0.7 | 4488.603 | 51.95772 | 0.413 | 0.8 | ug/L |
| Cr | 52 | 691166.691 | 1.7 | 15368.650 | 50.43300 | 1.125 | 2.2 | ug/L |
| Cr | 53 | 85996.724 | 1.7 | 814.381 | 50.45148 | 0.833 | 1.7 | ug/L |
| Mn | 55 | 1005972.631 | 0.8 | 494.020 | 51.14918 | 1.314 | 2.6 | ug/L |
| Co | 59 | 853591.020 | 0.5 | 188.671 | 49.81951 | 1.382 | 2.8 | ug/L |
| Ni | 60 | 189301.453 | 2.1 | 136.669 | 49.20674 | 1.992 | 4.0 | ug/L |
| Ni | 62 | 28448.435 | 1.6 | 143.669 | 49.48513 | 1.666 | 3.4 | ug/L |
| Cu | 63 | 460925.558 | 1.4 | 212.338 | 52.42412 | 1.939 | 3.7 | ug/L |
| Cu | 65 | 221564.827 | 2.5 | 189.671 | 52.00384 | 2.464 | 4.7 | ug/L |
| Zn | 66 | 134142.177 | 1.5 | 1515.486 | 53.14510 | 0.477 | 0.9 | ug/L |
| Zn | 67 | 22973.191 | 1.7 | 342.344 | 52.24058 | 2.104 | 4.0 | ug/L |
| Zn | 68 | 96828.933 | 0.3 | 1170.427 | 52.20010 | 1.137 | 2.2 | ug/L |
| Ge | 72 | 237948.078 | 2.2 | 244883.968 | | | | ug/L |
| As | 75 | 154741.878 | 1.4 | 124.002 | 50.01699 | 1.702 | 3.4 | ug/L |
| Se | 77 | 12246.860 | 1.3 | 216.736 | 52.14425 | 0.604 | 1.2 | ug/L |
| Se | 78 | 53457.838 | 1.3 | 16119.238 | 50.32488 | 2.168 | 4.3 | mg/L |
| Se | 82 | 17741.333 | 0.8 | 1872.010 | 51.41704 | 1.472 | 2.9 | ug/L |
| Kr | 83 | 1672.852 | 4.8 | 1902.236 | | | | mg/L |
| Y | 89 | 391182.817 | 0.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 259832.339 | 0.9 | 112.002 | 48.40121 | 0.232 | 0.5 | ug/L |
| Mo | 97 | 160900.492 | 2.0 | 64.001 | 49.28155 | 0.686 | 1.4 | ug/L |
| Mo | 98 | 415273.227 | 0.4 | 98.282 | 50.44594 | 0.334 | 0.7 | ug/L |
| Rh | 103 | 320678.216 | 0.6 | 340052.119 | | | | ug/L |
| Ag | 107 | 664594.740 | 0.7 | 91.335 | 50.29667 | 0.490 | 1.0 | ug/L |
| Ag | 109 | 640747.631 | 0.5 | 75.668 | 51.60750 | 0.466 | 0.9 | ug/L |
| Cd | 111 | 152952.570 | 3.1 | 218.275 | 50.60723 | 1.253 | 2.5 | ug/L |
| Cd | 114 | 341574.693 | 1.7 | 58.957 | 50.84282 | 1.368 | 2.7 | ug/L |
| In | 115 | 356645.935 | 1.0 | 358352.924 | | | | ug/L |
| Sb | 121 | 456047.801 | 0.9 | 107.668 | 49.16410 | 0.927 | 1.9 | ug/L |
| Sb | 123 | 349192.902 | 0.4 | 79.665 | 48.90999 | 0.689 | 1.4 | ug/L |
| Ba | 135 | 119411.757 | 1.4 | 46.667 | 51.39645 | 0.760 | 1.5 | ug/L |
| Ba | 137 | 198327.224 | 2.1 | 47.001 | 50.02306 | 0.854 | 1.7 | ug/L |
| Tb | 159 | 385870.248 | 1.0 | 411268.087 | | | | ug/L |
| Ho | 165 | 377624.973 | 1.8 | 390096.908 | | | | ug/L |
| Tl | 203 | 389898.783 | 1.8 | 60.001 | 50.73603 | 0.268 | 0.5 | ug/L |
| Tl | 205 | 890712.194 | 1.7 | 78.001 | 52.45742 | 0.446 | 0.8 | ug/L |
| Pb | 208 | 1263965.204 | 0.5 | 320.672 | 51.71227 | 0.723 | 1.4 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Monday, November 13, 2006 15:49:30

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 328374.460 | 2.5 | 87.335 | 51.06179 | 0.530 | 1.0 ug/L |
| | Pb | 207 | 267082.272 | 1.4 | 77.001 | 49.73411 | 0.742 | 1.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 97.672 | | | | |
| Al | 27 | 94.743 | | | | |
| > Sc | 45 | | 93.729 | | | |
| V | 51 | 103.915 | | | | |
| Cr | 52 | 100.866 | | | | |
| Cr | 53 | 100.903 | | | | |
| Mn | 55 | 102.298 | | | | |
| Co | 59 | 99.639 | | | | |
| Ni | 60 | 98.413 | | | | |
| Ni | 62 | 98.970 | | | | |
| Cu | 63 | 104.848 | | | | |
| Cu | 65 | 104.008 | | | | |
| Zn | 66 | 106.290 | | | | |
| Zn | 67 | 104.481 | | | | |
| Zn | 68 | 104.400 | | | | |
| > Ge | 72 | | 97.168 | | | |
| As | 75 | 100.034 | | | | |
| Se | 77 | 104.288 | | | | |
| Se | 78 | 100.650 | | | | |
| Se | 82 | 102.834 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 96.802 | | | | |
| Mo | 97 | 98.563 | | | | |
| Mo | 98 | 100.892 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 100.593 | | | | |
| Ag | 109 | 103.215 | | | | |
| Cd | 111 | 101.214 | | | | |
| Cd | 114 | 101.686 | | | | |
| > In | 115 | | 99.524 | | | |
| Sb | 121 | 98.328 | | | | |
| Sb | 123 | 97.820 | | | | |
| Ba | 135 | 102.793 | | | | |
| Ba | 137 | 100.046 | | | | |
| > Tb | 159 | | 93.825 | | | |
| > Ho | 165 | | 96.803 | | | |
| Tl | 203 | 101.472 | | | | |
| Tl | 205 | 104.915 | | | | |
| Pb | 208 | 103.425 | | | | |
| Pb | 206 | 102.124 | | | | |
| Pb | 207 | 99.468 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 13, 2006 15:52:26

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 7.023

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54.001 | 15.8 | 63.001 | -0.00526 | 0.008 | 155.1 | ug/L |
| Al | 27 | 2497.399 | 3.7 | 2334.350 | 0.04421 | 0.017 | 39.5 | ug/L |
| > Sc | 45 | 361619.683 | 0.8 | 381869.082 | | | | ug/L |
| V | 51 | 4235.573 | 4.1 | 4488.603 | -0.00097 | 0.011 | 1130.3 | ug/L |
| Cr | 52 | 14172.521 | 2.4 | 15368.650 | -0.02813 | 0.023 | 82.3 | ug/L |
| Cr | 53 | 953.064 | 2.5 | 814.381 | 0.10654 | 0.013 | 12.3 | ug/L |
| Mn | 55 | 607.695 | 2.0 | 494.020 | 0.00617 | 0.001 | 21.3 | ug/L |
| Co | 59 | 142.336 | 4.1 | 188.671 | -0.00249 | 0.000 | 8.6 | ug/L |
| Ni | 60 | 144.336 | 14.8 | 136.669 | 0.00267 | 0.006 | 238.8 | ug/L |
| Ni | 62 | 144.003 | 11.5 | 143.669 | 0.00478 | 0.026 | 549.9 | ug/L |
| Cu | 63 | 309.009 | 2.1 | 212.338 | 0.01130 | 0.001 | 11.7 | ug/L |
| Cu | 65 | 217.005 | 7.2 | 189.671 | 0.00711 | 0.004 | 50.1 | ug/L |
| Zn | 66 | 1483.480 | 1.8 | 1515.486 | -0.00207 | 0.016 | 793.0 | ug/L |
| Zn | 67 | 327.010 | 8.0 | 342.344 | -0.02093 | 0.066 | 317.7 | ug/L |
| Zn | 68 | 1173.428 | 3.5 | 1170.427 | 0.01306 | 0.035 | 267.0 | ug/L |
| > Ge | 72 | 240637.494 | 2.3 | 244883.968 | | | | ug/L |
| As | 75 | 200.338 | 6.6 | 124.002 | 0.02517 | 0.005 | 21.7 | ug/L |
| Se | 77 | 240.003 | 2.5 | 216.736 | 0.11580 | 0.015 | 13.3 | ug/L |
| Se | 78 | 15590.908 | 0.6 | 16119.238 | -0.32041 | 0.472 | 147.5 | mg/L |
| Se | 82 | 1777.190 | 3.3 | 1872.010 | -0.19522 | 0.284 | 145.5 | ug/L |
| Kr | 83 | 1759.203 | 3.5 | 1902.236 | | | | mg/L |
| Y | 89 | 396084.438 | 3.0 | 408188.389 | | | | ug/L |
| Mo | 95 | 736.040 | 12.3 | 112.002 | 0.11692 | 0.016 | 14.1 | ug/L |
| Mo | 97 | 478.019 | 12.0 | 64.001 | 0.12748 | 0.017 | 13.1 | ug/L |
| Mo | 98 | 1119.883 | 17.5 | 98.282 | 0.12470 | 0.024 | 18.9 | ug/L |
| Rh | 103 | 322207.526 | 0.5 | 340052.119 | | | | ug/L |
| Ag | 107 | 166.337 | 17.6 | 91.335 | 0.00577 | 0.002 | 39.5 | ug/L |
| Ag | 109 | 139.669 | 13.5 | 75.668 | 0.00524 | 0.002 | 30.1 | ug/L |
| Cd | 111 | 194.307 | 1.9 | 218.275 | -0.00734 | 0.001 | 10.1 | ug/L |
| Cd | 114 | 58.963 | 12.5 | 58.957 | 0.00007 | 0.001 | 1410.1 | ug/L |
| > In | 115 | 355202.942 | 0.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 1255.108 | 13.9 | 107.668 | 0.12429 | 0.019 | 14.9 | ug/L |
| Sb | 123 | 958.942 | 17.5 | 79.665 | 0.12372 | 0.023 | 18.6 | ug/L |
| Ba | 135 | 48.001 | 14.6 | 46.667 | 0.00148 | 0.003 | 210.0 | ug/L |
| Ba | 137 | 54.667 | 11.8 | 47.001 | 0.00242 | 0.001 | 61.8 | ug/L |
| > Tb | 159 | 392628.496 | 1.4 | 411268.087 | | | | ug/L |
| > Ho | 165 | 383614.172 | 0.9 | 390096.908 | | | | ug/L |
| Tl | 203 | 82.001 | 21.4 | 60.001 | 0.00295 | 0.002 | 75.7 | ug/L |
| Tl | 205 | 153.670 | 8.9 | 78.001 | 0.00447 | 0.001 | 18.8 | ug/L |
| Pb | 208 | 451.676 | 2.4 | 320.672 | 0.00549 | 0.000 | 6.0 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Monday, November 13, 2006 15:55:26

Page 1

| | | | | | | | | |
|--|----|-----|---------|------|--------|---------|-------|-----------|
| | Pb | 206 | 115.669 | 11.5 | 87.335 | 0.00457 | 0.002 | 47.6 ug/L |
| | Pb | 207 | 119.335 | 12.8 | 77.001 | 0.00799 | 0.003 | 33.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 94.697 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 98.266 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 99.121 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 95.468 | | | |
| > [Ho | 165 | | 98.338 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 946577

Sample Date/Time: Monday, November 13, 2006 15:58:23

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\946577.024

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 61.668 | 13.1 | 63.001 | -0.00889 | 0.006 | 69.3 | ug/L |
| Al | 27 | 149969.292 | 0.8 | 2334.350 | 18.41223 | 0.231 | 1.3 | ug/L |
| Sc | 45 | 444822.078 | 1.2 | 381869.082 | | | | ug/L |
| V | 51 | 8290.241 | 7.5 | 4488.603 | 0.16007 | 0.029 | 18.0 | ug/L |
| Cr | 52 | 38139.459 | 0.4 | 15368.650 | 1.21359 | 0.036 | 2.9 | ug/L |
| Cr | 53 | 3404.730 | 4.1 | 814.381 | 1.17001 | 0.075 | 6.4 | ug/L |
| Mn | 55 | 151180.321 | 1.3 | 494.020 | 6.93235 | 0.107 | 1.5 | ug/L |
| Co | 59 | 2155.634 | 3.4 | 188.671 | 0.10312 | 0.004 | 3.4 | ug/L |
| Ni | 60 | 10053.832 | 3.2 | 136.669 | 2.33113 | 0.095 | 4.1 | ug/L |
| Ni | 62 | 1688.522 | 6.2 | 143.669 | 2.42657 | 0.185 | 7.6 | ug/L |
| Cu | 63 | 39390.336 | 3.3 | 212.338 | 4.02964 | 0.105 | 2.6 | ug/L |
| Cu | 65 | 18478.321 | 2.0 | 189.671 | 3.88243 | 0.112 | 2.9 | ug/L |
| Zn | 66 | 157683.238 | 1.2 | 1515.486 | 56.55964 | 0.472 | 0.8 | ug/L |
| Zn | 67 | 24203.341 | 0.9 | 342.344 | 49.73731 | 0.191 | 0.4 | ug/L |
| Zn | 68 | 114946.667 | 1.9 | 1170.427 | 56.10801 | 1.477 | 2.6 | ug/L |
| Ge | 72 | 262962.643 | 0.9 | 244883.968 | | | | ug/L |
| As | 75 | 1920.907 | 0.4 | 124.002 | 0.52306 | 0.003 | 0.5 | ug/L |
| Se | 77 | 370.208 | 4.2 | 216.736 | 0.53855 | 0.047 | 8.8 | ug/L |
| Se | 78 | 17764.462 | 0.8 | 16119.238 | 0.54862 | 0.150 | 27.3 | mg/L |
| Se | 82 | 2151.412 | 7.0 | 1872.010 | 0.41439 | 0.476 | 114.9 | ug/L |
| Kr | 83 | 2027.601 | 8.6 | 1902.236 | | | | mg/L |
| Y | 89 | 433509.644 | 1.1 | 408188.389 | | | | ug/L |
| Mo | 95 | 1975.590 | 13.4 | 112.002 | 0.33506 | 0.048 | 14.4 | ug/L |
| Mo | 97 | 1215.435 | 11.0 | 64.001 | 0.34047 | 0.041 | 12.0 | ug/L |
| Mo | 98 | 3080.625 | 11.1 | 98.282 | 0.34989 | 0.041 | 11.7 | ug/L |
| Rh | 103 | 342718.204 | 0.6 | 340052.119 | | | | ug/L |
| Ag | 107 | 2499.400 | 1.7 | 91.335 | 0.17592 | 0.003 | 1.4 | ug/L |
| Ag | 109 | 2355.023 | 2.5 | 75.668 | 0.17724 | 0.004 | 2.5 | ug/L |
| Cd | 111 | 298.613 | 17.6 | 218.275 | 0.02367 | 0.017 | 72.3 | ug/L |
| Cd | 114 | 284.815 | 23.0 | 58.957 | 0.03229 | 0.010 | 30.3 | ug/L |
| In | 115 | 369074.870 | 1.0 | 358352.924 | | | | ug/L |
| Sb | 121 | 1338.456 | 16.2 | 107.668 | 0.12797 | 0.023 | 18.1 | ug/L |
| Sb | 123 | 975.844 | 13.0 | 79.665 | 0.12099 | 0.017 | 14.2 | ug/L |
| Ba | 135 | 26742.441 | 0.3 | 46.667 | 10.69255 | 0.209 | 2.0 | ug/L |
| Ba | 137 | 44968.846 | 2.7 | 47.001 | 10.54024 | 0.196 | 1.9 | ug/L |
| Tb | 159 | 414891.118 | 2.0 | 411268.087 | | | | ug/L |
| Ho | 165 | 399987.099 | 1.7 | 390096.908 | | | | ug/L |
| Tl | 203 | 138.003 | 11.3 | 60.001 | 0.00939 | 0.002 | 19.9 | ug/L |
| Tl | 205 | 285.674 | 5.4 | 78.001 | 0.01145 | 0.001 | 9.3 | ug/L |
| Pb | 208 | 59465.721 | 0.5 | 320.672 | 2.28482 | 0.042 | 1.8 | ug/L |

Sample ID: 946577

Report Date/Time: Monday, November 13, 2006 16:01:25

Page 1

| | | | | | | | | |
|--|----|-----|-----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 15512.917 | 1.9 | 87.335 | 2.26489 | 0.004 | 0.2 ug/L |
| | Pb | 207 | 12175.011 | 1.6 | 77.001 | 2.12749 | 0.063 | 3.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 116.485 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 107.383 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.992 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.881 | | | |
| > Ho | 165 | | 102.535 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 946582

Sample Date/Time: Monday, November 13, 2006 16:04:22

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\946582.025

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 66.001 | 17.5 | 63.001 | -0.00452 | 0.010 | 220.0 | ug/L |
| Al | 27 | 200943.560 | 1.6 | 2334.350 | 25.27040 | 0.832 | 3.3 | ug/L |
| > Sc | 45 | 436552.364 | 2.0 | 381869.082 | | | | ug/L |
| V | 51 | 5607.973 | 5.2 | 4488.603 | 0.02570 | 0.021 | 83.5 | ug/L |
| Cr | 52 | 35584.511 | 1.3 | 15368.650 | 1.10150 | 0.072 | 6.5 | ug/L |
| Cr | 53 | 3469.090 | 0.6 | 814.381 | 1.23226 | 0.043 | 3.5 | ug/L |
| Mn | 55 | 58718764.192 | 1.7 | 494.020 | 2534.60597 | 29.826 | 1.2 | ug/L |
| Co | 59 | 32124.813 | 2.5 | 188.671 | 1.58085 | 0.050 | 3.2 | ug/L |
| Ni | 60 | 21880.604 | 4.0 | 136.669 | 4.79774 | 0.293 | 6.1 | ug/L |
| Ni | 62 | 3459.086 | 1.1 | 143.669 | 4.88703 | 0.083 | 1.7 | ug/L |
| Cu | 63 | 66130.083 | 2.0 | 212.338 | 6.36268 | 0.227 | 3.6 | ug/L |
| Cu | 65 | 32695.678 | 0.9 | 189.671 | 6.47247 | 0.096 | 1.5 | ug/L |
| Zn | 66 | 347413.955 | 2.3 | 1515.486 | 117.51660 | 0.304 | 0.3 | ug/L |
| Zn | 67 | 53830.847 | 0.6 | 342.344 | 104.63106 | 2.565 | 2.5 | ug/L |
| Zn | 68 | 259932.448 | 1.0 | 1170.427 | 119.72739 | 2.703 | 2.3 | ug/L |
| > Ge | 72 | 280347.620 | 2.3 | 244883.968 | | | | ug/L |
| As | 75 | 197895.754 | 1.3 | 124.002 | 54.29725 | 1.910 | 3.5 | ug/L |
| Se | 77 | 286.805 | 4.0 | 216.736 | 0.14202 | 0.025 | 17.5 | ug/L |
| Se | 78 | 18136.566 | 2.0 | 16119.238 | -0.34712 | 0.785 | 226.3 | mg/L |
| Se | 82 | 1814.664 | 1.3 | 1872.010 | -0.89903 | 0.063 | 7.0 | ug/L |
| Kr | 83 | 1820.551 | 3.9 | 1902.236 | | | | mg/L |
| Y | 89 | 434066.967 | 2.7 | 408188.389 | | | | ug/L |
| Mo | 95 | 11702.663 | 1.5 | 112.002 | 2.05210 | 0.022 | 1.1 | ug/L |
| Mo | 97 | 7022.363 | 3.0 | 64.001 | 2.02565 | 0.054 | 2.7 | ug/L |
| Mo | 98 | 17629.573 | 1.0 | 98.282 | 2.02413 | 0.023 | 1.1 | ug/L |
| Rh | 103 | 347979.950 | 1.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 469.351 | 0.8 | 91.335 | 0.02689 | 0.000 | 1.7 | ug/L |
| Ag | 109 | 381.679 | 3.5 | 75.668 | 0.02316 | 0.001 | 4.6 | ug/L |
| Cd | 111 | 347.159 | 3.4 | 218.275 | 0.03735 | 0.003 | 8.4 | ug/L |
| Cd | 114 | 394.124 | 21.2 | 58.957 | 0.04701 | 0.012 | 24.9 | ug/L |
| > In | 115 | 375215.859 | 0.6 | 358352.924 | | | | ug/L |
| Sb | 121 | 768.710 | 2.5 | 107.668 | 0.06723 | 0.002 | 3.2 | ug/L |
| Sb | 123 | 605.027 | 2.4 | 79.665 | 0.06946 | 0.002 | 3.5 | ug/L |
| Ba | 135 | 100228.185 | 1.1 | 46.667 | 38.90198 | 0.829 | 2.1 | ug/L |
| Ba | 137 | 173494.100 | 2.3 | 47.001 | 39.47147 | 1.434 | 3.6 | ug/L |
| > Tb | 159 | 427907.355 | 1.4 | 411268.087 | | | | ug/L |
| > Ho | 165 | 397260.965 | 0.6 | 390096.908 | | | | ug/L |
| Tl | 203 | 122.669 | 11.5 | 60.001 | 0.00761 | 0.002 | 21.7 | ug/L |
| Tl | 205 | 269.007 | 7.1 | 78.001 | 0.01062 | 0.001 | 10.6 | ug/L |
| Pb | 208 | 241108.766 | 1.5 | 320.672 | 9.36543 | 0.181 | 1.9 | ug/L |

| | | | | | | | | |
|--|----|-----|-----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 63514.117 | 1.3 | 87.335 | 9.37772 | 0.070 | 0.8 ug/L |
| | Pb | 207 | 50268.365 | 2.0 | 77.001 | 8.88616 | 0.217 | 2.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 114.320 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 114.482 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.706 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 104.046 | | | |
| > Ho | 165 | | 101.836 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948169

Sample Date/Time: Monday, November 13, 2006 16:10:21

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948169.026

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59.334 | 21.2 | 63.001 | -0.00662 | 0.011 | 166.4 | ug/L |
| Al | 27 | 18920.321 | 2.8 | 2334.350 | 2.23353 | 0.055 | 2.5 | ug/L |
| Sc | 45 | 408890.164 | 1.8 | 381869.082 | | | | ug/L |
| V | 51 | 5543.361 | 4.0 | 4488.603 | 0.04188 | 0.007 | 17.6 | ug/L |
| Cr | 52 | 24884.016 | 1.2 | 15368.650 | 0.54994 | 0.027 | 5.0 | ug/L |
| Cr | 53 | 1804.213 | 0.3 | 814.381 | 0.48319 | 0.018 | 3.6 | ug/L |
| Mn | 55 | 8474.393 | 2.3 | 494.020 | 0.37190 | 0.014 | 3.8 | ug/L |
| Co | 59 | 433.016 | 6.6 | 188.671 | 0.01254 | 0.002 | 13.3 | ug/L |
| Ni | 60 | 775.044 | 6.5 | 136.669 | 0.15084 | 0.014 | 9.5 | ug/L |
| Ni | 62 | 262.340 | 0.2 | 143.669 | 0.17755 | 0.006 | 3.2 | ug/L |
| Cu | 63 | 3071.265 | 6.0 | 212.338 | 0.29761 | 0.018 | 6.0 | ug/L |
| Cu | 65 | 1495.483 | 4.3 | 189.671 | 0.27941 | 0.010 | 3.6 | ug/L |
| Zn | 66 | 5461.845 | 2.7 | 1515.486 | 1.42126 | 0.031 | 2.2 | ug/L |
| Zn | 67 | 945.730 | 3.4 | 342.344 | 1.23821 | 0.074 | 6.0 | ug/L |
| Zn | 68 | 3964.983 | 2.8 | 1170.427 | 1.36792 | 0.061 | 4.5 | ug/L |
| Ge | 72 | 258814.599 | 1.3 | 244883.968 | | | | ug/L |
| As | 75 | 256.673 | 2.7 | 124.002 | 0.03735 | 0.002 | 5.9 | ug/L |
| Se | 77 | 247.537 | 7.2 | 216.736 | 0.07397 | 0.078 | 105.4 | ug/L |
| Se | 78 | 17297.395 | 3.2 | 16119.238 | 0.31658 | 0.436 | 137.7 | mg/L |
| Se | 82 | 1814.264 | 0.7 | 1872.010 | -0.48654 | 0.104 | 21.4 | ug/L |
| Kr | 83 | 1811.215 | 1.9 | 1902.236 | | | | mg/L |
| Y | 89 | 429657.031 | 2.3 | 408188.389 | | | | ug/L |
| Mo | 95 | 472.351 | 5.3 | 112.002 | 0.06122 | 0.003 | 5.3 | ug/L |
| Mo | 97 | 253.673 | 15.8 | 64.001 | 0.05287 | 0.011 | 20.5 | ug/L |
| Mo | 98 | 641.345 | 12.2 | 98.282 | 0.06066 | 0.008 | 12.9 | ug/L |
| Rh | 103 | 348336.787 | 1.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 87.335 | 22.6 | 91.335 | -0.00071 | 0.001 | 203.9 | ug/L |
| Ag | 109 | 71.334 | 15.1 | 75.668 | -0.00072 | 0.001 | 103.0 | ug/L |
| Cd | 111 | 261.736 | 11.6 | 218.275 | 0.00885 | 0.009 | 107.3 | ug/L |
| Cd | 114 | -12.839 | 728.4 | 58.957 | -0.01038 | 0.013 | 124.3 | ug/L |
| In | 115 | 382727.647 | 1.6 | 358352.924 | | | | ug/L |
| Sb | 121 | 277.007 | 2.9 | 107.668 | 0.01629 | 0.001 | 7.5 | ug/L |
| Sb | 123 | 188.753 | 5.5 | 79.665 | 0.01354 | 0.002 | 11.1 | ug/L |
| Ba | 135 | 735.373 | 3.1 | 46.667 | 0.27314 | 0.012 | 4.6 | ug/L |
| Ba | 137 | 1227.103 | 3.1 | 47.001 | 0.27424 | 0.005 | 1.8 | ug/L |
| Tb | 159 | 418551.126 | 1.3 | 411268.087 | | | | ug/L |
| Ho | 165 | 407324.408 | 0.9 | 390096.908 | | | | ug/L |
| Tl | 203 | 51.001 | 7.8 | 60.001 | -0.00141 | 0.000 | 34.8 | ug/L |
| Tl | 205 | 53.001 | 16.1 | 78.001 | -0.00156 | 0.000 | 28.7 | ug/L |
| Pb | 208 | 1767.091 | 1.0 | 320.672 | 0.05433 | 0.001 | 1.5 | ug/L |

Sample ID: 948169

Report Date/Time: Monday, November 13, 2006 16:13:23

Page 1

198

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 457.684 | 4.8 | 87.335 | 0.05286 | 0.003 | 6.3 ug/L |
| | Pb | 207 | 381.679 | 2.9 | 77.001 | 0.05202 | 0.002 | 3.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 107.076 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 105.689 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 106.802 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 101.771 | | | |
| > Ho | 165 | | 104.416 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: FBlank 1013

Sample Date/Time: Monday, November 13, 2006 16:16:19

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\FBlank.027

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 66.001 | 16.9 | 63.001 | -0.00162 | 0.010 | 629.7 | ug/L |
| Al | 27 | 48365.434 | 0.7 | 2334.350 | 6.17369 | 0.212 | 3.4 | ug/L |
| > Sc | 45 | 413196.385 | 2.6 | 381869.082 | | | | ug/L |
| V | 51 | 5832.024 | 4.6 | 4488.603 | 0.05501 | 0.015 | 27.0 | ug/L |
| Cr | 52 | 28734.417 | 1.7 | 15368.650 | 0.78218 | 0.060 | 7.7 | ug/L |
| Cr | 53 | 2201.646 | 1.6 | 814.381 | 0.67736 | 0.026 | 3.8 | ug/L |
| Mn | 55 | 47553.983 | 4.9 | 494.020 | 2.17006 | 0.166 | 7.6 | ug/L |
| Co | 59 | 767.043 | 2.8 | 188.671 | 0.02990 | 0.002 | 7.0 | ug/L |
| Ni | 60 | 1775.874 | 1.5 | 136.669 | 0.38420 | 0.017 | 4.5 | ug/L |
| Ni | 62 | 432.349 | 7.3 | 143.669 | 0.44159 | 0.064 | 14.4 | ug/L |
| Cu | 63 | 9394.720 | 1.1 | 212.338 | 0.94519 | 0.023 | 2.4 | ug/L |
| Cu | 65 | 4251.127 | 0.6 | 189.671 | 0.86156 | 0.025 | 2.9 | ug/L |
| Zn | 66 | 100252.777 | 0.6 | 1515.486 | 35.82329 | 1.216 | 3.4 | ug/L |
| Zn | 67 | 15098.484 | 0.9 | 342.344 | 30.79969 | 0.734 | 2.4 | ug/L |
| Zn | 68 | 69436.208 | 2.3 | 1170.427 | 33.72553 | 1.670 | 5.0 | ug/L |
| > Ge | 72 | 262555.464 | 2.7 | 244883.968 | | | | ug/L |
| As | 75 | 218.672 | 6.2 | 124.002 | 0.02508 | 0.002 | 9.0 | ug/L |
| Se | 77 | 252.337 | 0.9 | 216.736 | 0.07895 | 0.034 | 42.6 | ug/L |
| Se | 78 | 17594.137 | 1.1 | 16119.238 | 0.38216 | 0.350 | 91.7 | mg/L |
| Se | 82 | 1854.673 | 1.0 | 1872.010 | -0.44310 | 0.166 | 37.6 | ug/L |
| Kr | 83 | 1752.202 | 1.2 | 1902.236 | | | | mg/L |
| Y | 89 | 443692.046 | 1.1 | 408188.389 | | | | ug/L |
| Mo | 95 | 435.349 | 10.3 | 112.002 | 0.05323 | 0.007 | 12.6 | ug/L |
| Mo | 97 | 255.006 | 9.2 | 64.001 | 0.05181 | 0.007 | 12.9 | ug/L |
| Mo | 98 | 575.748 | 5.4 | 98.282 | 0.05196 | 0.003 | 5.7 | ug/L |
| Rh | 103 | 359035.539 | 0.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 7004.346 | 1.5 | 91.335 | 0.47703 | 0.002 | 0.4 | ug/L |
| Ag | 109 | 6638.377 | 2.1 | 75.668 | 0.48220 | 0.018 | 3.8 | ug/L |
| Cd | 111 | 290.889 | 5.8 | 218.275 | 0.01599 | 0.005 | 28.3 | ug/L |
| Cd | 114 | 282.513 | 32.8 | 58.957 | 0.02977 | 0.013 | 44.2 | ug/L |
| > In | 115 | 390721.397 | 1.6 | 358352.924 | | | | ug/L |
| Sb | 121 | 412.348 | 3.4 | 107.668 | 0.02904 | 0.002 | 6.5 | ug/L |
| Sb | 123 | 329.705 | 7.6 | 79.665 | 0.03103 | 0.003 | 8.9 | ug/L |
| Ba | 135 | 6914.604 | 1.7 | 46.667 | 2.68637 | 0.011 | 0.4 | ug/L |
| Ba | 137 | 11732.037 | 0.2 | 47.001 | 2.67884 | 0.041 | 1.5 | ug/L |
| > Tb | 159 | 424637.588 | 1.4 | 411268.087 | | | | ug/L |
| > Ho | 165 | 409258.721 | 1.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 56.001 | 5.4 | 60.001 | -0.00083 | 0.000 | 40.0 | ug/L |
| Tl | 205 | 94.335 | 12.6 | 78.001 | 0.00068 | 0.001 | 86.2 | ug/L |
| Pb | 208 | 9384.501 | 0.9 | 320.672 | 0.34166 | 0.007 | 2.2 | ug/L |

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 2457.387 | 3.6 | 87.335 | 0.33967 | 0.017 | 4.9 ug/L |
| | Pb | 207 | 1960.250 | 3.7 | 77.001 | 0.32293 | 0.009 | 2.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 108.204 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 107.216 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 109.033 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 103.251 | | | |
| > [Ho | 165 | | 104.912 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: FBlank

Sample Date/Time: Monday, November 13, 2006 16:22:17

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\FBlank.028

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 58.334 | 11.2 | 63.001 | -0.00640 | 0.006 | 87.7 | ug/L |
| Al | 27 | 38342.775 | 3.0 | 2334.350 | 4.99726 | 0.160 | 3.2 | ug/L |
| Sc | 45 | 399553.336 | 0.4 | 381869.082 | | | | ug/L |
| V | 51 | 5844.737 | 5.9 | 4488.603 | 0.06687 | 0.019 | 28.7 | ug/L |
| Cr | 52 | 27082.881 | 1.5 | 15368.650 | 0.73438 | 0.025 | 3.4 | ug/L |
| Cr | 53 | 1959.250 | 1.2 | 814.381 | 0.58708 | 0.017 | 3.0 | ug/L |
| Mn | 55 | 7059.729 | 3.6 | 494.020 | 0.31090 | 0.013 | 4.3 | ug/L |
| Co | 59 | 407.681 | 23.7 | 188.671 | 0.01150 | 0.005 | 44.5 | ug/L |
| Ni | 60 | 942.063 | 5.5 | 136.669 | 0.19425 | 0.014 | 7.1 | ug/L |
| Ni | 62 | 282.674 | 11.6 | 143.669 | 0.21752 | 0.055 | 25.4 | ug/L |
| Cu | 63 | 9776.497 | 1.7 | 212.338 | 1.01487 | 0.010 | 1.0 | ug/L |
| Cu | 65 | 4605.652 | 1.4 | 189.671 | 0.96644 | 0.011 | 1.1 | ug/L |
| Zn | 66 | 7339.972 | 1.5 | 1515.486 | 2.15577 | 0.024 | 1.1 | ug/L |
| Zn | 67 | 1272.443 | 1.0 | 342.344 | 1.97352 | 0.046 | 2.3 | ug/L |
| Zn | 68 | 5629.958 | 1.9 | 1170.427 | 2.24747 | 0.073 | 3.2 | ug/L |
| Ge | 72 | 254782.155 | 0.7 | 244883.968 | | | | ug/L |
| As | 75 | 181.337 | 4.3 | 124.002 | 0.01580 | 0.002 | 14.1 | ug/L |
| Se | 77 | 243.670 | 0.6 | 216.736 | 0.07352 | 0.001 | 1.9 | ug/L |
| Se | 78 | 17675.499 | 1.0 | 16119.238 | 1.12603 | 0.362 | 32.2 | mg/L |
| Se | 82 | 1844.537 | 0.8 | 1872.010 | -0.31063 | 0.072 | 23.2 | ug/L |
| Kr | 83 | 1877.564 | 1.4 | 1902.236 | | | | mg/L |
| Y | 89 | 433930.854 | 2.7 | 408188.389 | | | | ug/L |
| Mo | 95 | 339.677 | 5.8 | 112.002 | 0.03880 | 0.003 | 7.9 | ug/L |
| Mo | 97 | 216.338 | 7.4 | 64.001 | 0.04292 | 0.005 | 12.1 | ug/L |
| Mo | 98 | 460.221 | 5.4 | 98.282 | 0.04077 | 0.003 | 7.6 | ug/L |
| Rh | 103 | 354107.200 | 0.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 1865.894 | 1.4 | 91.335 | 0.12607 | 0.001 | 1.1 | ug/L |
| Ag | 109 | 1731.197 | 3.7 | 75.668 | 0.12518 | 0.003 | 2.8 | ug/L |
| Cd | 111 | 219.586 | 6.6 | 218.275 | -0.00346 | 0.005 | 145.5 | ug/L |
| Cd | 114 | -62.215 | 146.5 | 58.957 | -0.01741 | 0.013 | 73.6 | ug/L |
| In | 115 | 378849.552 | 1.1 | 358352.924 | | | | ug/L |
| Sb | 121 | 241.673 | 3.6 | 107.668 | 0.01298 | 0.001 | 8.2 | ug/L |
| Sb | 123 | 182.383 | 9.0 | 79.665 | 0.01293 | 0.002 | 15.3 | ug/L |
| Ba | 135 | 4944.850 | 2.1 | 46.667 | 1.91254 | 0.056 | 2.9 | ug/L |
| Ba | 137 | 8439.357 | 2.1 | 47.001 | 1.92028 | 0.052 | 2.7 | ug/L |
| Tb | 159 | 425422.063 | 0.9 | 411268.087 | | | | ug/L |
| Ho | 165 | 399456.957 | 0.9 | 390096.908 | | | | ug/L |
| Tl | 203 | 49.334 | 6.5 | 60.001 | -0.00149 | 0.000 | 23.5 | ug/L |
| Tl | 205 | 58.667 | 3.5 | 78.001 | -0.00118 | 0.000 | 12.5 | ug/L |
| Pb | 208 | 8440.095 | 1.3 | 320.672 | 0.31375 | 0.002 | 0.6 | ug/L |

Sample ID: FBlank

Report Date/Time: Monday, November 13, 2006 16:25:18

Page 1

204

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 2173.972 | 4.8 | 87.335 | 0.30651 | 0.014 | 4.7 ug/L |
| | Pb | 207 | 1792.211 | 1.1 | 77.001 | 0.30168 | 0.004 | 1.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 104.631 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 104.042 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 105.720 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 103.442 | | | |
| > Ho | 165 | | 102.399 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: FBlank

Sample Date/Time: Monday, November 13, 2006 16:28:15

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990125

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\FBlank.029

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 64.668 | 7.9 | 63.001 | -0.00038 | 0.004 | 1074.1 | ug/L |
| Al | 27 | 70295.616 | 0.5 | 2334.350 | 9.56911 | 0.100 | 1.0 | ug/L |
| > Sc | 45 | 394562.565 | 0.7 | 381869.082 | | | | ug/L |
| V | 51 | 5209.681 | 12.7 | 4488.603 | 0.03391 | 0.041 | 120.3 | ug/L |
| Cr | 52 | 24770.681 | 1.7 | 15368.650 | 0.60111 | 0.037 | 6.2 | ug/L |
| Cr | 53 | 1714.860 | 0.5 | 814.381 | 0.46900 | 0.011 | 2.3 | ug/L |
| Mn | 55 | 6375.836 | 1.8 | 494.020 | 0.27752 | 0.003 | 1.1 | ug/L |
| Co | 59 | 399.680 | 4.6 | 188.671 | 0.01102 | 0.001 | 8.3 | ug/L |
| Ni | 60 | 1093.416 | 2.9 | 136.669 | 0.23024 | 0.009 | 3.7 | ug/L |
| Ni | 62 | 291.341 | 5.6 | 143.669 | 0.23012 | 0.025 | 10.9 | ug/L |
| Cu | 63 | 19305.536 | 2.2 | 212.338 | 2.02133 | 0.047 | 2.3 | ug/L |
| Cu | 65 | 9378.703 | 1.5 | 189.671 | 2.00716 | 0.034 | 1.7 | ug/L |
| Zn | 66 | 6332.135 | 1.7 | 1515.486 | 1.77208 | 0.023 | 1.3 | ug/L |
| Zn | 67 | 1087.415 | 4.0 | 342.344 | 1.56851 | 0.102 | 6.5 | ug/L |
| Zn | 68 | 4669.355 | 0.4 | 1170.427 | 1.75127 | 0.010 | 0.6 | ug/L |
| > Ge | 72 | 255500.369 | 0.8 | 244883.968 | | | | ug/L |
| As | 75 | 157.336 | 4.9 | 124.002 | 0.00841 | 0.002 | 23.2 | ug/L |
| Se | 77 | 255.471 | 1.5 | 216.736 | 0.11847 | 0.023 | 19.7 | ug/L |
| Se | 78 | 17443.077 | 2.5 | 16119.238 | 0.77501 | 0.533 | 68.8 | mg/L |
| Se | 82 | 1831.268 | 1.4 | 1872.010 | -0.36663 | 0.036 | 9.8 | ug/L |
| Kr | 83 | 1842.556 | 3.2 | 1902.236 | | | | mg/L |
| Y | 89 | 429070.559 | 1.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 306.009 | 9.2 | 112.002 | 0.03434 | 0.005 | 15.2 | ug/L |
| Mo | 97 | 179.670 | 6.7 | 64.001 | 0.03368 | 0.003 | 10.1 | ug/L |
| Mo | 98 | 391.365 | 5.1 | 98.282 | 0.03407 | 0.002 | 6.9 | ug/L |
| Rh | 103 | 341193.218 | 2.6 | 340052.119 | | | | ug/L |
| Ag | 107 | 127.002 | 3.9 | 91.335 | 0.00241 | 0.000 | 16.7 | ug/L |
| Ag | 109 | 112.002 | 13.9 | 75.668 | 0.00265 | 0.001 | 46.8 | ug/L |
| Cd | 111 | 250.735 | 11.0 | 218.275 | 0.00829 | 0.009 | 104.3 | ug/L |
| Cd | 114 | 40.585 | 119.8 | 58.957 | -0.00291 | 0.007 | 238.9 | ug/L |
| > In | 115 | 369068.619 | 0.4 | 358352.924 | | | | ug/L |
| Sb | 121 | 186.337 | 10.4 | 107.668 | 0.00786 | 0.002 | 24.9 | ug/L |
| Sb | 123 | 140.690 | 8.9 | 79.665 | 0.00794 | 0.002 | 22.3 | ug/L |
| Ba | 135 | 544.690 | 9.0 | 46.667 | 0.20073 | 0.022 | 11.0 | ug/L |
| Ba | 137 | 874.388 | 1.0 | 47.001 | 0.19527 | 0.000 | 0.1 | ug/L |
| > Tb | 159 | 412412.371 | 1.1 | 411268.087 | | | | ug/L |
| > Ho | 165 | 393207.992 | 2.6 | 390096.908 | | | | ug/L |
| Tl | 203 | 41.334 | 21.8 | 60.001 | -0.00238 | 0.001 | 51.8 | ug/L |
| Tl | 205 | 61.334 | 18.5 | 78.001 | -0.00097 | 0.001 | 75.7 | ug/L |
| Pb | 208 | 6079.264 | 2.0 | 320.672 | 0.22623 | 0.005 | 2.0 | ug/L |

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 1570.497 | 5.6 | 87.335 | 0.22138 | 0.009 | 4.2 ug/L |
| | Pb | 207 | 1291.113 | 5.2 | 77.001 | 0.21720 | 0.015 | 6.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 103.324 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 104.335 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 102.990 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 100.278 | | | |
| > [Ho | 165 | | 100.798 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Monday, November 13, 2006 16:34:11

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 3.030

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1085.082 | 6.5 | 63.001 | 0.96434 | 0.054 | 5.6 | ug/L |
| Al | 27 | 69967.230 | 1.4 | 2334.350 | 10.49908 | 0.023 | 0.2 | ug/L |
| Sc | 45 | 359005.232 | 1.2 | 381869.082 | | | | ug/L |
| V | 51 | 21933.099 | 1.9 | 4488.603 | 1.14888 | 0.042 | 3.7 | ug/L |
| Cr | 52 | 31720.583 | 1.6 | 15368.650 | 1.28355 | 0.063 | 4.9 | ug/L |
| Cr | 53 | 2780.492 | 2.7 | 814.381 | 1.18935 | 0.059 | 5.0 | ug/L |
| Mn | 55 | 22433.058 | 2.6 | 494.020 | 1.09223 | 0.041 | 3.8 | ug/L |
| Co | 59 | 18656.048 | 1.3 | 188.671 | 1.05466 | 0.009 | 0.9 | ug/L |
| Ni | 60 | 4352.514 | 2.1 | 136.669 | 1.07336 | 0.047 | 4.4 | ug/L |
| Ni | 62 | 746.041 | 1.9 | 143.669 | 1.03228 | 0.049 | 4.8 | ug/L |
| Cu | 63 | 9868.606 | 1.3 | 212.338 | 1.07513 | 0.032 | 2.9 | ug/L |
| Cu | 65 | 4992.212 | 1.8 | 189.671 | 1.10387 | 0.036 | 3.3 | ug/L |
| Zn | 66 | 17270.720 | 1.6 | 1515.486 | 6.17982 | 0.085 | 1.4 | ug/L |
| Zn | 67 | 2802.833 | 1.8 | 342.344 | 5.55764 | 0.028 | 0.5 | ug/L |
| Zn | 68 | 12470.117 | 2.1 | 1170.427 | 6.03763 | 0.270 | 4.5 | ug/L |
| Ge | 72 | 243178.633 | 2.2 | 244883.968 | | | | ug/L |
| As | 75 | 3317.027 | 2.7 | 124.002 | 1.01106 | 0.047 | 4.6 | ug/L |
| Se | 77 | 448.012 | 1.9 | 216.736 | 0.98762 | 0.071 | 7.2 | ug/L |
| Se | 78 | 16682.441 | 0.4 | 16119.238 | 0.88777 | 0.560 | 63.1 | mg/L |
| Se | 82 | 2047.718 | 1.3 | 1872.010 | 0.59849 | 0.179 | 29.9 | ug/L |
| Kr | 83 | 1745.867 | 0.7 | 1902.236 | | | | mg/L |
| Y | 89 | 400563.088 | 0.4 | 408188.389 | | | | ug/L |
| Mo | 95 | 5583.926 | 1.0 | 112.002 | 1.02136 | 0.009 | 0.9 | ug/L |
| Mo | 97 | 3486.431 | 3.5 | 64.001 | 1.05073 | 0.050 | 4.8 | ug/L |
| Mo | 98 | 8732.128 | 1.7 | 98.282 | 1.05070 | 0.023 | 2.2 | ug/L |
| Rh | 103 | 329004.960 | 1.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 14792.933 | 0.3 | 91.335 | 1.11446 | 0.013 | 1.2 | ug/L |
| Ag | 109 | 13542.799 | 1.6 | 75.668 | 1.08631 | 0.006 | 0.5 | ug/L |
| Cd | 111 | 3343.512 | 0.8 | 218.275 | 1.03761 | 0.011 | 1.1 | ug/L |
| Cd | 114 | 7228.355 | 1.5 | 58.957 | 1.06902 | 0.032 | 3.0 | ug/L |
| In | 115 | 356142.804 | 1.5 | 358352.924 | | | | ug/L |
| Sb | 121 | 9953.710 | 2.8 | 107.668 | 1.06301 | 0.016 | 1.5 | ug/L |
| Sb | 123 | 7794.773 | 2.3 | 79.665 | 1.08231 | 0.015 | 1.4 | ug/L |
| Ba | 135 | 2474.393 | 5.1 | 46.667 | 0.99997 | 0.071 | 7.1 | ug/L |
| Ba | 137 | 4312.159 | 2.0 | 47.001 | 1.02879 | 0.038 | 3.7 | ug/L |
| Tb | 159 | 403874.086 | 2.4 | 411268.087 | | | | ug/L |
| Ho | 165 | 385669.081 | 1.9 | 390096.908 | | | | ug/L |
| Tl | 203 | 8482.734 | 1.0 | 60.001 | 1.07372 | 0.027 | 2.5 | ug/L |
| Tl | 205 | 19737.883 | 1.7 | 78.001 | 1.13417 | 0.035 | 3.1 | ug/L |
| Pb | 208 | 27772.877 | 1.7 | 320.672 | 1.10036 | 0.036 | 3.2 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Monday, November 13, 2006 16:37:12

Page 1

210

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 7180.498 | 1.0 | 87.335 | 1.08081 | 0.029 | 2.7 ug/L |
| | Pb | 207 | 6085.949 | 1.5 | 77.001 | 1.09635 | 0.035 | 3.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 96.434 | | | | |
| Al | 27 | 104.991 | | | | |
| > Sc | 45 | | 94.013 | | | |
| V | 51 | 114.888 | | | | |
| Cr | 52 | 128.355 | | | | |
| Cr | 53 | 118.935 | | | | |
| Mn | 55 | 109.223 | | | | |
| Co | 59 | 105.466 | | | | |
| Ni | 60 | 107.336 | | | | |
| Ni | 62 | 103.228 | | | | |
| Cu | 63 | 107.513 | | | | |
| Cu | 65 | 110.387 | | | | |
| Zn | 66 | 123.596 | | | | |
| Zn | 67 | 111.153 | | | | |
| Zn | 68 | 120.753 | | | | |
| > Ge | 72 | | 99.304 | | | |
| As | 75 | 101.106 | | | | |
| Se | 77 | 98.762 | | | | |
| Se | 78 | 88.777 | | | | |
| Se | 82 | 59.849 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 102.136 | | | | |
| Mo | 97 | 105.073 | | | | |
| Mo | 98 | 105.070 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 111.446 | | | | |
| Ag | 109 | 108.631 | | | | |
| Cd | 111 | 103.761 | | | | |
| Cd | 114 | 106.902 | | | | |
| > In | 115 | | 99.383 | | | |
| Sb | 121 | 106.301 | | | | |
| Sb | 123 | 108.231 | | | | |
| Ba | 135 | 99.997 | | | | |
| Ba | 137 | 102.879 | | | | |
| > Tb | 159 | | 98.202 | | | |
| > Ho | 165 | | 98.865 | | | |
| Tl | 203 | 107.372 | | | | |
| Tl | 205 | 113.417 | | | | |
| Pb | 208 | 110.036 | | | | |
| Pb | 206 | 108.081 | | | | |
| Pb | 207 | 109.635 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: HLCCV2

Sample Date/Time: Monday, November 13, 2006 16:40:08

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\HLCCV2.031

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 210816.489 | 2.1 | 63.001 | 204.00363 | 6.095 | 3.0 | ug/L |
| Al | 27 | 1248587.131 | 2.5 | 2334.350 | 198.75012 | 6.799 | 3.4 | ug/L |
| Sc | 45 | 348872.904 | 1.0 | 381869.082 | | | | ug/L |
| V | 51 | 3478695.276 | 1.2 | 4488.603 | 231.87066 | 4.582 | 2.0 | ug/L |
| Cr | 52 | 3020556.059 | 1.1 | 15368.650 | 229.83224 | 1.911 | 0.8 | ug/L |
| Cr | 53 | 343524.053 | 2.7 | 814.381 | 208.19671 | 7.503 | 3.6 | ug/L |
| Mn | 55 | 4222346.373 | 1.0 | 494.020 | 216.79637 | 1.330 | 0.6 | ug/L |
| Co | 59 | 3605802.124 | 1.3 | 188.671 | 212.48694 | 4.224 | 2.0 | ug/L |
| Ni | 60 | 781410.335 | 0.5 | 136.669 | 205.13655 | 3.898 | 1.9 | ug/L |
| Ni | 62 | 114560.622 | 2.8 | 143.669 | 201.90375 | 6.257 | 3.1 | ug/L |
| Cu | 63 | 1719300.258 | 1.9 | 212.338 | 197.47517 | 6.356 | 3.2 | ug/L |
| Cu | 65 | 859958.116 | 1.0 | 189.671 | 203.80910 | 1.141 | 0.6 | ug/L |
| Zn | 66 | 503249.286 | 0.8 | 1515.486 | 202.96447 | 1.780 | 0.9 | ug/L |
| Zn | 67 | 88140.364 | 2.2 | 342.344 | 204.54517 | 7.474 | 3.7 | ug/L |
| Zn | 68 | 380201.660 | 2.7 | 1170.427 | 208.72263 | 3.170 | 1.5 | ug/L |
| Ge | 72 | 235645.036 | 1.4 | 244883.968 | | | | ug/L |
| As | 75 | 622230.100 | 1.3 | 124.002 | 203.14629 | 4.485 | 2.2 | ug/L |
| Se | 77 | 46549.653 | 0.5 | 216.736 | 202.72945 | 3.917 | 1.9 | ug/L |
| Se | 78 | 167899.631 | 1.6 | 16119.238 | 204.81609 | 5.691 | 2.8 | mg/L |
| Se | 82 | 64022.744 | 1.0 | 1872.010 | 202.83950 | 3.741 | 1.8 | ug/L |
| Kr | 83 | 1725.529 | 1.6 | 1902.236 | | | | mg/L |
| Y | 89 | 385797.756 | 1.1 | 408188.389 | | | | ug/L |
| Mo | 95 | 1047427.073 | 0.6 | 112.002 | 202.61717 | 5.356 | 2.6 | ug/L |
| Mo | 97 | 657027.482 | 2.6 | 64.001 | 208.96691 | 6.923 | 3.3 | ug/L |
| Mo | 98 | 1588022.216 | 1.1 | 98.282 | 200.28843 | 5.470 | 2.7 | ug/L |
| Rh | 103 | 324988.040 | 1.3 | 340052.119 | | | | ug/L |
| Ag | 107 | 2922230.850 | 1.1 | 91.335 | 229.62804 | 7.682 | 3.3 | ug/L |
| Ag | 109 | 2703009.564 | 1.1 | 75.668 | 226.03747 | 7.252 | 3.2 | ug/L |
| Cd | 111 | 608606.795 | 1.4 | 218.275 | 209.24123 | 2.431 | 1.2 | ug/L |
| Cd | 114 | 1319330.069 | 3.8 | 58.957 | 203.74065 | 3.730 | 1.8 | ug/L |
| In | 115 | 343694.123 | 2.5 | 358352.924 | | | | ug/L |
| Sb | 121 | 1807743.226 | 0.3 | 107.668 | 202.31290 | 4.447 | 2.2 | ug/L |
| Sb | 123 | 1401571.442 | 1.3 | 79.665 | 203.80749 | 5.484 | 2.7 | ug/L |
| Ba | 135 | 462862.180 | 1.8 | 46.667 | 196.78034 | 3.659 | 1.9 | ug/L |
| Ba | 137 | 788761.619 | 0.5 | 47.001 | 196.49907 | 1.724 | 0.9 | ug/L |
| Tb | 159 | 390755.148 | 0.5 | 411268.087 | | | | ug/L |
| Ho | 165 | 367403.283 | 2.1 | 390096.908 | | | | ug/L |
| Tl | 203 | 1505036.264 | 1.4 | 60.001 | 201.33498 | 1.536 | 0.8 | ug/L |
| Tl | 205 | 3877360.825 | 0.2 | 78.001 | 234.77781 | 4.761 | 2.0 | ug/L |
| Pb | 208 | 5166762.719 | 0.2 | 320.672 | 217.33320 | 4.418 | 2.0 | ug/L |

Sample ID: HLCCV2

Report Date/Time: Monday, November 13, 2006 16:43:09

Page 1

213

| | | | | | | | | |
|--|----|-----|-------------|-----|--------|-----------|-------|----------|
| | Pb | 206 | 1247406.085 | 0.7 | 87.335 | 199.46236 | 3.455 | 1.7 ug/L |
| | Pb | 207 | 1070152.519 | 0.7 | 77.001 | 204.88550 | 3.496 | 1.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 91.359 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 96.227 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 95.909 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 95.012 | | | |
| > Ho | 165 | | 94.183 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 13, 2006 16:46:06

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 6.032

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 50888.457 | 2.1 | 63.001 | 48.55040 | 2.759 | 5.7 | ug/L |
| Al | 27 | 323115.510 | 2.0 | 2334.350 | 50.45422 | 1.226 | 2.4 | ug/L |
| > Sc | 45 | 353979.205 | 3.8 | 381869.082 | | | | ug/L |
| V | 51 | 814624.911 | 1.3 | 4488.603 | 53.33319 | 1.414 | 2.7 | ug/L |
| Cr | 52 | 708235.971 | 3.1 | 15368.650 | 52.32533 | 2.257 | 4.3 | ug/L |
| Cr | 53 | 82246.141 | 2.1 | 814.381 | 48.79165 | 0.847 | 1.7 | ug/L |
| Mn | 55 | 1022617.625 | 1.7 | 494.020 | 52.48707 | 0.120 | 0.2 | ug/L |
| Co | 59 | 836914.260 | 1.3 | 188.671 | 49.31672 | 1.198 | 2.4 | ug/L |
| Ni | 60 | 192816.493 | 0.7 | 136.669 | 50.59193 | 0.703 | 1.4 | ug/L |
| Ni | 62 | 28929.419 | 0.8 | 143.669 | 50.81354 | 1.293 | 2.5 | ug/L |
| Cu | 63 | 450832.248 | 1.2 | 212.338 | 51.75380 | 0.360 | 0.7 | ug/L |
| Cu | 65 | 222327.635 | 0.5 | 189.671 | 52.67148 | 1.158 | 2.2 | ug/L |
| Zn | 66 | 132264.621 | 2.0 | 1515.486 | 52.91130 | 1.056 | 2.0 | ug/L |
| Zn | 67 | 22842.501 | 2.0 | 342.344 | 52.44114 | 1.723 | 3.3 | ug/L |
| Zn | 68 | 97959.689 | 2.9 | 1170.427 | 53.32110 | 1.058 | 2.0 | ug/L |
| > Ge | 72 | 235641.891 | 1.8 | 244883.968 | | | | ug/L |
| As | 75 | 154047.933 | 1.7 | 124.002 | 50.27691 | 1.737 | 3.5 | ug/L |
| Se | 77 | 12272.163 | 0.6 | 216.736 | 52.77948 | 1.150 | 2.2 | ug/L |
| Se | 78 | 54467.087 | 2.9 | 16119.238 | 52.37298 | 2.866 | 5.5 | mg/L |
| Se | 82 | 17696.705 | 0.8 | 1872.010 | 51.82732 | 1.361 | 2.6 | ug/L |
| Kr | 83 | 1739.532 | 2.1 | 1902.236 | | | | mg/L |
| Y | 89 | 386430.083 | 1.7 | 408188.389 | | | | ug/L |
| Mo | 95 | 259383.632 | 1.4 | 112.002 | 49.46097 | 0.731 | 1.5 | ug/L |
| Mo | 97 | 164329.747 | 0.4 | 64.001 | 51.52762 | 0.604 | 1.2 | ug/L |
| Mo | 98 | 406104.370 | 1.0 | 98.282 | 50.50078 | 0.894 | 1.8 | ug/L |
| Rh | 103 | 325369.381 | 1.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 663498.722 | 1.8 | 91.335 | 51.40686 | 1.427 | 2.8 | ug/L |
| Ag | 109 | 623369.874 | 0.7 | 75.668 | 51.39544 | 0.726 | 1.4 | ug/L |
| Cd | 111 | 155944.365 | 0.3 | 218.275 | 52.82669 | 0.454 | 0.9 | ug/L |
| Cd | 114 | 342716.230 | 0.5 | 58.957 | 52.21186 | 0.526 | 1.0 | ug/L |
| > In | 115 | 348415.185 | 1.0 | 358352.924 | | | | ug/L |
| Sb | 121 | 458506.986 | 0.8 | 107.668 | 50.59307 | 0.487 | 1.0 | ug/L |
| Sb | 123 | 345897.168 | 1.4 | 79.665 | 49.59294 | 0.937 | 1.9 | ug/L |
| Ba | 135 | 117898.839 | 1.8 | 46.667 | 49.37091 | 1.890 | 3.8 | ug/L |
| Ba | 137 | 202364.866 | 1.9 | 47.001 | 49.66681 | 2.092 | 4.2 | ug/L |
| > Tb | 159 | 396806.487 | 2.3 | 411268.087 | | | | ug/L |
| > Ho | 165 | 371772.815 | 0.7 | 390096.908 | | | | ug/L |
| Tl | 203 | 383878.343 | 0.7 | 60.001 | 50.74105 | 0.639 | 1.3 | ug/L |
| Tl | 205 | 890025.432 | 1.4 | 78.001 | 53.24452 | 1.074 | 2.0 | ug/L |
| Pb | 208 | 1249324.961 | 1.3 | 320.672 | 51.91299 | 0.977 | 1.9 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Monday, November 13, 2006 16:49:09

Page 1

216

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 322159.133 | 0.7 | 87.335 | 50.88938 | 0.673 | 1.3 ug/L |
| | Pb | 207 | 268445.092 | 0.9 | 77.001 | 50.77079 | 0.639 | 1.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 97.101 | | | | |
| Al | 27 | 100.908 | | | | |
| > Sc | 45 | | 92.696 | | | |
| V | 51 | 106.666 | | | | |
| Cr | 52 | 104.651 | | | | |
| Cr | 53 | 97.583 | | | | |
| Mn | 55 | 104.974 | | | | |
| Co | 59 | 98.633 | | | | |
| Ni | 60 | 101.184 | | | | |
| Ni | 62 | 101.627 | | | | |
| Cu | 63 | 103.508 | | | | |
| Cu | 65 | 105.343 | | | | |
| Zn | 66 | 105.823 | | | | |
| Zn | 67 | 104.882 | | | | |
| Zn | 68 | 106.642 | | | | |
| > Ge | 72 | | 96.226 | | | |
| As | 75 | 100.554 | | | | |
| Se | 77 | 105.559 | | | | |
| Se | 78 | 104.746 | | | | |
| Se | 82 | 103.655 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 98.922 | | | | |
| Mo | 97 | 103.055 | | | | |
| Mo | 98 | 101.002 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 102.814 | | | | |
| Ag | 109 | 102.791 | | | | |
| Cd | 111 | 105.653 | | | | |
| Cd | 114 | 104.424 | | | | |
| > In | 115 | | 97.227 | | | |
| Sb | 121 | 101.186 | | | | |
| Sb | 123 | 99.186 | | | | |
| Ba | 135 | 98.742 | | | | |
| Ba | 137 | 99.334 | | | | |
| > Tb | 159 | | 96.484 | | | |
| > Ho | 165 | | 95.303 | | | |
| Tl | 203 | 101.482 | | | | |
| Tl | 205 | 106.489 | | | | |
| Pb | 208 | 103.826 | | | | |
| Pb | 206 | 101.779 | | | | |
| Pb | 207 | 101.542 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 13, 2006 16:52:04

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 7.033

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 60.001 | 15.3 | 63.001 | 0.00031 | 0.009 | 3094.8 | ug/L |
| Al | 27 | 2489.730 | 2.3 | 2334.350 | 0.04218 | 0.009 | 21.5 | ug/L |
| > Sc | 45 | 362371.841 | 1.7 | 381869.082 | | | | ug/L |
| V | 51 | 4396.054 | 4.8 | 4488.603 | 0.00888 | 0.016 | 178.8 | ug/L |
| Cr | 52 | 14799.289 | 3.7 | 15368.650 | 0.01605 | 0.044 | 276.9 | ug/L |
| Cr | 53 | 782.711 | 1.0 | 814.381 | 0.00585 | 0.006 | 101.8 | ug/L |
| Mn | 55 | 543.023 | 4.0 | 494.020 | 0.00287 | 0.001 | 46.2 | ug/L |
| Co | 59 | 149.003 | 8.4 | 188.671 | -0.00211 | 0.001 | 31.7 | ug/L |
| Ni | 60 | 134.336 | 4.1 | 136.669 | -0.00002 | 0.002 | 7809.8 | ug/L |
| Ni | 62 | 136.669 | 10.3 | 143.669 | -0.00835 | 0.020 | 242.6 | ug/L |
| Cu | 63 | 246.006 | 9.9 | 212.338 | 0.00418 | 0.003 | 71.4 | ug/L |
| Cu | 65 | 211.338 | 6.8 | 189.671 | 0.00573 | 0.003 | 58.3 | ug/L |
| Zn | 66 | 1531.489 | 3.4 | 1515.486 | 0.01603 | 0.024 | 151.6 | ug/L |
| Zn | 67 | 303.675 | 1.1 | 342.344 | -0.07554 | 0.009 | 11.9 | ug/L |
| Zn | 68 | 1201.432 | 3.4 | 1170.427 | 0.02668 | 0.015 | 56.1 | ug/L |
| > Ge | 72 | 240979.270 | 1.7 | 244883.968 | | | | ug/L |
| As | 75 | 227.672 | 8.2 | 124.002 | 0.03368 | 0.005 | 14.5 | ug/L |
| Se | 77 | 239.670 | 1.0 | 216.736 | 0.11305 | 0.019 | 17.1 | ug/L |
| Se | 78 | 15727.514 | 0.4 | 16119.238 | -0.17409 | 0.259 | 148.9 | mg/L |
| Se | 82 | 1769.521 | 0.9 | 1872.010 | -0.22993 | 0.143 | 62.2 | ug/L |
| Kr | 83 | 1714.860 | 3.0 | 1902.236 | | | | mg/L |
| Y | 89 | 396042.457 | 0.3 | 408188.389 | | | | ug/L |
| Mo | 95 | 965.067 | 19.2 | 112.002 | 0.16021 | 0.029 | 18.3 | ug/L |
| Mo | 97 | 605.695 | 22.1 | 64.001 | 0.16712 | 0.035 | 21.1 | ug/L |
| Mo | 98 | 1497.838 | 21.1 | 98.282 | 0.17117 | 0.033 | 19.0 | ug/L |
| Rh | 103 | 327774.525 | 2.9 | 340052.119 | | | | ug/L |
| Ag | 107 | 185.671 | 6.0 | 91.335 | 0.00730 | 0.000 | 6.0 | ug/L |
| Ag | 109 | 169.003 | 8.8 | 75.668 | 0.00766 | 0.001 | 11.5 | ug/L |
| Cd | 111 | 217.464 | 4.3 | 218.275 | 0.00088 | 0.005 | 608.9 | ug/L |
| Cd | 114 | 59.726 | 18.3 | 58.957 | 0.00021 | 0.001 | 635.5 | ug/L |
| > In | 115 | 353249.405 | 3.2 | 358352.924 | | | | ug/L |
| Sb | 121 | 1804.882 | 11.6 | 107.668 | 0.18461 | 0.018 | 9.6 | ug/L |
| Sb | 123 | 1372.598 | 11.1 | 79.665 | 0.18271 | 0.016 | 8.6 | ug/L |
| Ba | 135 | 44.667 | 12.3 | 46.667 | -0.00024 | 0.002 | 990.4 | ug/L |
| Ba | 137 | 53.667 | 17.6 | 47.001 | 0.00196 | 0.002 | 113.9 | ug/L |
| > Tb | 159 | 398987.961 | 0.6 | 411268.087 | | | | ug/L |
| > Ho | 165 | 381847.292 | 0.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 88.001 | 9.9 | 60.001 | 0.00376 | 0.001 | 28.8 | ug/L |
| Tl | 205 | 173.337 | 19.0 | 78.001 | 0.00565 | 0.002 | 33.7 | ug/L |
| Pb | 208 | 482.010 | 2.9 | 320.672 | 0.00680 | 0.000 | 7.3 | ug/L |

| | | | | | | | | |
|--|----|-----|---------|------|--------|---------|-------|-----------|
| | Pb | 206 | 130.002 | 10.3 | 87.335 | 0.00685 | 0.002 | 30.0 ug/L |
| | Pb | 207 | 112.669 | 9.0 | 77.001 | 0.00687 | 0.002 | 26.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 94.894 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 98.405 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.576 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.014 | | | |
| > Ho | 165 | | 97.885 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: PBW-M3990131

Sample Date/Time: Monday, November 13, 2006 16:58:01

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\PBW-M3990131.034

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 57.001 | 21.3 | 63.001 | -0.00528 | 0.011 | 213.3 | ug/L |
| Al | 27 | 301247.454 | 0.7 | 2334.350 | 43.47218 | 0.812 | 1.9 | ug/L |
| > Sc | 45 | 382487.546 | 1.7 | 381869.082 | | | | ug/L |
| V | 51 | 5324.170 | 1.3 | 4488.603 | 0.05047 | 0.007 | 13.1 | ug/L |
| Cr | 52 | 21449.117 | 0.7 | 15368.650 | 0.42244 | 0.021 | 4.9 | ug/L |
| Cr | 53 | 1287.779 | 5.2 | 814.381 | 0.26192 | 0.047 | 17.9 | ug/L |
| Mn | 55 | 1679.519 | 2.0 | 494.020 | 0.05879 | 0.003 | 4.7 | ug/L |
| Co | 59 | 231.006 | 11.2 | 188.671 | 0.00240 | 0.001 | 44.6 | ug/L |
| Ni | 60 | 423.348 | 2.6 | 136.669 | 0.07277 | 0.006 | 8.8 | ug/L |
| Ni | 62 | 172.003 | 2.1 | 143.669 | 0.04886 | 0.010 | 20.8 | ug/L |
| Cu | 63 | 1793.211 | 1.4 | 212.338 | 0.17524 | 0.008 | 4.4 | ug/L |
| Cu | 65 | 991.736 | 1.7 | 189.671 | 0.18363 | 0.011 | 6.1 | ug/L |
| Zn | 66 | 3149.627 | 1.8 | 1515.486 | 0.63931 | 0.048 | 7.5 | ug/L |
| Zn | 67 | 579.359 | 3.9 | 342.344 | 0.53561 | 0.092 | 17.2 | ug/L |
| Zn | 68 | 2470.391 | 2.8 | 1170.427 | 0.69290 | 0.075 | 10.8 | ug/L |
| > Ge | 72 | 244413.872 | 3.4 | 244883.968 | | | | ug/L |
| As | 75 | 233.339 | 13.7 | 124.002 | 0.03432 | 0.008 | 22.1 | ug/L |
| Se | 77 | 246.337 | 1.6 | 216.736 | 0.12725 | 0.034 | 26.5 | ug/L |
| Se | 78 | 16878.549 | 1.0 | 16119.238 | 1.04403 | 0.906 | 86.7 | mg/L |
| Se | 82 | 1792.926 | 1.5 | 1872.010 | -0.23467 | 0.118 | 50.3 | ug/L |
| Kr | 83 | 1821.217 | 3.0 | 1902.236 | | | | mg/L |
| Y | 89 | 408801.730 | 3.3 | 408188.389 | | | | ug/L |
| Mo | 95 | 1019.075 | 23.6 | 112.002 | 0.16439 | 0.039 | 23.9 | ug/L |
| Mo | 97 | 663.369 | 37.4 | 64.001 | 0.17826 | 0.069 | 38.7 | ug/L |
| Mo | 98 | 1474.617 | 34.4 | 98.282 | 0.16253 | 0.056 | 34.3 | ug/L |
| Rh | 103 | 341025.016 | 0.3 | 340052.119 | | | | ug/L |
| Ag | 107 | 107.002 | 5.8 | 91.335 | 0.00104 | 0.001 | 49.1 | ug/L |
| Ag | 109 | 88.668 | 6.5 | 75.668 | 0.00092 | 0.000 | 47.1 | ug/L |
| Cd | 111 | 216.886 | 5.7 | 218.275 | -0.00162 | 0.005 | 321.7 | ug/L |
| Cd | 114 | -114.357 | 306.5 | 58.957 | -0.02572 | 0.051 | 199.3 | ug/L |
| > In | 115 | 364616.729 | 2.3 | 358352.924 | | | | ug/L |
| Sb | 121 | 1104.085 | 14.1 | 107.668 | 0.10469 | 0.014 | 13.2 | ug/L |
| Sb | 123 | 852.698 | 17.3 | 79.665 | 0.10547 | 0.018 | 16.6 | ug/L |
| Ba | 135 | 195.004 | 5.1 | 46.667 | 0.05935 | 0.003 | 5.3 | ug/L |
| Ba | 137 | 255.340 | 4.7 | 47.001 | 0.04890 | 0.003 | 6.5 | ug/L |
| > Tb | 159 | 414190.948 | 1.4 | 411268.087 | | | | ug/L |
| > Ho | 165 | 386652.280 | 1.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 53.334 | 15.7 | 60.001 | -0.00078 | 0.001 | 140.6 | ug/L |
| Tl | 205 | 92.001 | 6.1 | 78.001 | 0.00084 | 0.000 | 31.8 | ug/L |
| Pb | 208 | 861.692 | 7.5 | 320.672 | 0.02174 | 0.003 | 12.3 | ug/L |

Sample ID: PBW-M3990131

Report Date/Time: Monday, November 13, 2006 17:01:02

Page 1

222

| | | | | | | | | |
|--|----|-----|---------|------|--------|---------|-------|-----------|
| | Pb | 206 | 228.672 | 10.1 | 87.335 | 0.02159 | 0.004 | 16.2 ug/L |
| | Pb | 207 | 190.671 | 5.0 | 77.001 | 0.02081 | 0.002 | 9.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 100.162 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 99.808 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 101.748 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.711 | | | |
| > Ho | 165 | | 99.117 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: LCSW-M3990131

Sample Date/Time: Monday, November 13, 2006 17:03:59

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\LCSW-M3990131.035

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|----------------|----------|-----------|-------|
| Be | 9 | 23592.587 | 0.9 | 63.001 | 19.05554 | 0.629 | 3.3 | ug/L |
| Al | 27 | 236591.350 | 3.2 | 2334.350 | 31.24702 | 1.914 | 6.1 | ug/L |
| > Sc | 45 | 417050.325 | 2.8 | 381869.082 | | | | ug/L |
| V | 51 | 431690.995 | 2.0 | 4488.603 | 23.84147 | 1.080 | 4.5 | ug/L |
| Cr | 52 | 386051.608 | 2.4 | 15368.650 | 23.63767 | 1.295 | 5.5 | ug/L |
| Cr | 53 | 46194.191 | 2.4 | 814.381 | 23.01526 | 0.105 | 0.5 | ug/L |
| Mn | 55 | 537753.322 | 2.0 | 494.020 | 22.2% 24.32145 | 0.813 | 3.3 | ug/L |
| Co | 59 | 456532.039 | 2.8 | 188.671 | 23.70313 | 0.750 | 3.2 | ug/L |
| Ni | 60 | 99984.139 | 2.5 | 136.669 | 23.10949 | 0.932 | 4.0 | ug/L |
| Ni | 62 | 14491.402 | 1.1 | 143.669 | 22.29761 | 0.597 | 2.7 | ug/L |
| Cu | 63 | 241378.894 | 1.6 | 212.338 | 22.2% 24.41627 | 0.776 | 3.2 | ug/L |
| Cu | 65 | 116440.453 | 1.4 | 189.671 | 24.29080 | 0.685 | 2.8 | ug/L |
| Zn | 66 | 58401.548 | 1.6 | 1515.486 | 20.23067 | 0.313 | 1.5 | ug/L |
| Zn | 67 | 10588.497 | 1.9 | 342.344 | 20.96394 | 0.079 | 0.4 | ug/L |
| Zn | 68 | 43489.962 | 1.0 | 1170.427 | 20.48891 | 0.121 | 0.6 | ug/L |
| > Ge | 72 | 267352.903 | 1.6 | 244883.968 | | | | ug/L |
| As | 75 | 67785.280 | 1.3 | 124.002 | 19.46886 | 0.257 | 1.3 | ug/L |
| Se | 77 | 4694.522 | 0.5 | 216.736 | 17.18899 | 0.305 | 1.8 | ug/L |
| Se | 78 | 31667.502 | 2.4 | 16119.238 | 16.67215 | 1.208 | 7.2 | mg/L |
| Se | 82 | 7670.796 | 0.8 | 1872.010 | 16.17074 | 0.479 | 3.0 | ug/L |
| Kr | 83 | 1830.886 | 4.7 | 1902.236 | | | | mg/L |
| Y | 89 | 434866.793 | 2.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 137389.360 | 0.7 | 112.002 | 23.30100 | 0.104 | 0.4 | ug/L |
| Mo | 97 | 83876.849 | 0.6 | 64.001 | 23.39181 | 0.087 | 0.4 | ug/L |
| Mo | 98 | 215929.352 | 0.7 | 98.282 | 23.88559 | 0.057 | 0.2 | ug/L |
| Rh | 103 | 363724.015 | 2.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 327611.424 | 1.5 | 91.335 | 22.58143 | 0.484 | 2.1 | ug/L |
| Ag | 109 | 304229.850 | 1.1 | 75.668 | 22.31716 | 0.402 | 1.8 | ug/L |
| Cd | 111 | 70595.128 | 1.9 | 218.275 | 21.23890 | 0.547 | 2.6 | ug/L |
| Cd | 114 | 154729.857 | 1.1 | 58.957 | 20.96952 | 0.076 | 0.4 | ug/L |
| > In | 115 | 391538.860 | 0.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 224650.660 | 1.3 | 107.668 | 22.05043 | 0.107 | 0.5 | ug/L |
| Sb | 123 | 168345.645 | 2.0 | 79.665 | 21.47209 | 0.545 | 2.5 | ug/L |
| Ba | 135 | 57408.330 | 1.4 | 46.667 | 22.07599 | 0.276 | 1.3 | ug/L |
| Ba | 137 | 98465.301 | 0.6 | 47.001 | 22.19513 | 0.189 | 0.9 | ug/L |
| > Tb | 159 | 431671.781 | 0.8 | 411268.087 | | | | ug/L |
| > Ho | 165 | 419739.852 | 1.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 193819.369 | 2.3 | 60.001 | 22.69408 | 0.833 | 3.7 | ug/L |
| Tl | 205 | 446696.825 | 1.4 | 78.001 | 23.66510 | 0.079 | 0.3 | ug/L |
| Pb | 208 | 628971.760 | 0.1 | 320.672 | 23.14335 | 0.321 | 1.4 | ug/L |

Sample ID: LCSW-M3990131

Report Date/Time: Monday, November 13, 2006 17:07:00

Page 1

225

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 163310.242 | 1.6 | 87.335 | 22.84062 | 0.152 | 0.7 ug/L |
| | Pb | 207 | 134240.329 | 1.0 | 77.001 | 22.48328 | 0.492 | 2.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 109.213 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 109.175 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 109.261 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 104.961 | | | |
| > Ho | 165 | | 107.599 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: LCSW-M3990131

Sample Date/Time: Monday, November 13, 2006 17:12:07

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\LCSW-M3990131.036

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 23920.528 | 1.7 | 63.001 | 19.41674 | 0.679 | 3.5 | ug/L |
| Al | 27 | 284547.935 | 2.5 | 2334.350 | 37.79692 | 0.276 | 0.7 | ug/L |
| Sc | 45 | 414997.160 | 2.8 | 381869.082 | | | | ug/L |
| V | 51 | 436321.994 | 3.7 | 4488.603 | 24.23120 | 1.614 | 6.7 | ug/L |
| Cr | 52 | 388460.372 | 0.8 | 15368.650 | 23.90752 | 0.910 | 3.8 | ug/L |
| Cr | 53 | 45704.817 | 2.1 | 814.381 | 22.90002 | 1.102 | 4.8 | ug/L |
| Mn | 55 | 545878.915 | 2.4 | 494.020 | 25.45414 | 0.848 | 3.3 | ug/L |
| Co | 59 | 441574.595 | 1.5 | 188.671 | 23.63431 | 0.126 | 0.5 | ug/L |
| Ni | 60 | 100338.991 | 2.2 | 136.669 | 23.90773 | 0.738 | 3.1 | ug/L |
| Ni | 62 | 14999.304 | 1.1 | 143.669 | 23.80696 | 0.287 | 1.2 | ug/L |
| Cu | 63 | 240605.515 | 0.7 | 212.338 | 25.08933 | 0.417 | 1.7 | ug/L |
| Cu | 65 | 116309.520 | 2.4 | 189.671 | 25.01700 | 0.845 | 3.4 | ug/L |
| Zn | 66 | 57778.532 | 1.0 | 1515.486 | 20.64898 | 0.353 | 1.7 | ug/L |
| Zn | 67 | 10759.383 | 1.6 | 342.344 | 22.00398 | 0.513 | 2.3 | ug/L |
| Zn | 68 | 44076.078 | 2.5 | 1170.427 | 21.44104 | 0.745 | 3.5 | ug/L |
| Ge | 72 | 259297.099 | 1.0 | 244883.968 | | | | ug/L |
| As | 75 | 67959.003 | 0.8 | 124.002 | 20.12636 | 0.283 | 1.4 | ug/L |
| Se | 77 | 4709.798 | 2.1 | 216.736 | 17.81262 | 0.579 | 3.3 | ug/L |
| Se | 78 | 32268.576 | 1.5 | 16119.238 | 18.56796 | 0.906 | 4.9 | mg/L |
| Se | 82 | 7767.685 | 1.1 | 1872.010 | 17.13915 | 0.339 | 2.0 | ug/L |
| Kr | 83 | 1827.219 | 1.6 | 1902.236 | | | | mg/L |
| Y | 89 | 444567.809 | 1.8 | 408188.389 | | | | ug/L |
| Mo | 95 | 137486.931 | 0.5 | 112.002 | 23.21404 | 0.464 | 2.0 | ug/L |
| Mo | 97 | 83388.662 | 0.9 | 64.001 | 23.15356 | 0.582 | 2.5 | ug/L |
| Mo | 98 | 213903.984 | 1.4 | 98.282 | 23.55549 | 0.487 | 2.1 | ug/L |
| Rh | 103 | 362813.136 | 2.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 330178.404 | 0.6 | 91.335 | 22.65387 | 0.319 | 1.4 | ug/L |
| Ag | 109 | 304391.077 | 0.8 | 75.668 | 22.22550 | 0.199 | 0.9 | ug/L |
| Cd | 111 | 71250.225 | 0.1 | 218.275 | 21.33824 | 0.367 | 1.7 | ug/L |
| Cd | 114 | 157319.483 | 1.5 | 58.957 | 21.22965 | 0.688 | 3.2 | ug/L |
| In | 115 | 393365.534 | 1.7 | 358352.924 | | | | ug/L |
| Sb | 121 | 224009.212 | 1.5 | 107.668 | 21.89266 | 0.651 | 3.0 | ug/L |
| Sb | 123 | 173334.746 | 0.1 | 79.665 | 22.00768 | 0.346 | 1.6 | ug/L |
| Ba | 135 | 57550.281 | 0.4 | 46.667 | 21.76894 | 0.490 | 2.3 | ug/L |
| Ba | 137 | 98890.327 | 1.1 | 47.001 | 21.93032 | 0.753 | 3.4 | ug/L |
| Tb | 159 | 438993.591 | 2.4 | 411268.087 | | | | ug/L |
| Ho | 165 | 416442.652 | 1.7 | 390096.908 | | | | ug/L |
| Tl | 203 | 193674.316 | 0.1 | 60.001 | 22.85239 | 0.349 | 1.5 | ug/L |
| Tl | 205 | 448713.185 | 0.9 | 78.001 | 23.96281 | 0.333 | 1.4 | ug/L |
| Pb | 208 | 633816.412 | 1.3 | 320.672 | 23.50550 | 0.342 | 1.5 | ug/L |

Sample ID: LCSW-M3990131

Report Date/Time: Monday, November 13, 2006 17:15:08

Page 1

228

| | | | | | | | | |
|---|----|-----|------------|-----|--------|----------|-------|----------|
| I | Pb | 206 | 161512.940 | 1.3 | 87.335 | 22.77137 | 0.428 | 1.9 ug/L |
| L | Pb | 207 | 135668.674 | 1.7 | 77.001 | 22.90357 | 0.625 | 2.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 108.675 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 105.886 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 109.770 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 106.741 | | | |
| > [Ho | 165 | | 106.754 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950466 D.10

Sample Date/Time: Monday, November 13, 2006 17:18:04

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950466 D.10.037

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 58.667 | 18.2 | 63.001 | -0.00269 | 0.008 | 306.7 | ug/L |
| Al | 27 | 53575.876 | 0.6 | 2334.350 | 7.65927 | 0.231 | 3.0 | ug/L |
| > Sc | 45 | 372687.619 | 2.7 | 381869.082 | | | | ug/L |
| V | 51 | 4932.672 | 1.8 | 4488.603 | 0.03472 | 0.014 | 39.3 | ug/L |
| Cr | 52 | 17854.290 | 2.2 | 15368.650 | 0.20542 | 0.061 | 29.9 | ug/L |
| Cr | 53 | 1170.427 | 4.1 | 814.381 | 0.21336 | 0.010 | 4.7 | ug/L |
| Mn | 55 | 118923.194 | 1.5 | 494.020 | 5.83671 | 0.124 | 2.1 | ug/L |
| Co | 59 | 601.028 | 1.9 | 188.671 | 0.02329 | 0.001 | 2.3 | ug/L |
| Ni | 60 | 2014.597 | 2.9 | 136.669 | 0.47303 | 0.013 | 2.8 | ug/L |
| Ni | 62 | 354.344 | 6.0 | 143.669 | 0.35624 | 0.039 | 11.0 | ug/L |
| Cu | 63 | 1662.182 | 2.3 | 212.338 | 0.15975 | 0.005 | 3.3 | ug/L |
| Cu | 65 | 879.722 | 7.1 | 189.671 | 0.15690 | 0.015 | 9.6 | ug/L |
| Zn | 66 | 1423.803 | 2.4 | 1515.486 | -0.03714 | 0.013 | 35.8 | ug/L |
| Zn | 67 | 357.011 | 2.0 | 342.344 | 0.03080 | 0.018 | 58.8 | ug/L |
| Zn | 68 | 1340.455 | 1.2 | 1170.427 | 0.08823 | 0.008 | 9.6 | ug/L |
| > Ge | 72 | 245532.517 | 0.7 | 244883.968 | | | | ug/L |
| As | 75 | 261.007 | 5.9 | 124.002 | 0.04281 | 0.004 | 10.0 | ug/L |
| Se | 77 | 239.870 | 4.8 | 216.736 | 0.09481 | 0.052 | 54.7 | ug/L |
| Se | 78 | 16096.776 | 1.7 | 16119.238 | -0.08453 | 0.276 | 326.2 | mg/L |
| Se | 82 | 1770.921 | 1.1 | 1872.010 | -0.33153 | 0.076 | 23.0 | ug/L |
| Kr | 83 | 1773.540 | 1.5 | 1902.236 | | | | mg/L |
| Y | 89 | 395113.708 | 0.6 | 408188.389 | | | | ug/L |
| Mo | 95 | 454.350 | 2.1 | 112.002 | 0.06219 | 0.001 | 2.3 | ug/L |
| Mo | 97 | 264.007 | 9.3 | 64.001 | 0.05978 | 0.008 | 12.8 | ug/L |
| Mo | 98 | 603.345 | 2.4 | 98.282 | 0.05995 | 0.002 | 2.6 | ug/L |
| Rh | 103 | 328813.172 | 0.3 | 340052.119 | | | | ug/L |
| Ag | 107 | 92.668 | 14.1 | 91.335 | -0.00001 | 0.001 | 9342.0 | ug/L |
| Ag | 109 | 74.001 | 3.6 | 75.668 | -0.00023 | 0.000 | 86.7 | ug/L |
| Cd | 111 | 220.840 | 1.7 | 218.275 | -0.00028 | 0.001 | 369.5 | ug/L |
| Cd | 114 | 75.674 | 18.6 | 58.957 | 0.00231 | 0.002 | 90.2 | ug/L |
| > In | 115 | 363965.005 | 0.5 | 358352.924 | | | | ug/L |
| Sb | 121 | 261.007 | 5.3 | 107.668 | 0.01603 | 0.002 | 9.8 | ug/L |
| Sb | 123 | 212.390 | 5.3 | 79.665 | 0.01804 | 0.001 | 8.0 | ug/L |
| Ba | 135 | 4078.038 | 1.3 | 46.667 | 1.67020 | 0.030 | 1.8 | ug/L |
| Ba | 137 | 7019.360 | 2.4 | 47.001 | 1.69217 | 0.030 | 1.8 | ug/L |
| > Tb | 159 | 401150.908 | 0.7 | 411268.087 | | | | ug/L |
| > Ho | 165 | 386267.118 | 3.1 | 390096.908 | | | | ug/L |
| Tl | 203 | 91.335 | 4.4 | 60.001 | 0.00406 | 0.000 | 7.8 | ug/L |
| Tl | 205 | 155.336 | 6.6 | 78.001 | 0.00451 | 0.001 | 18.7 | ug/L |
| Pb | 208 | 732.020 | 1.7 | 320.672 | 0.01659 | 0.000 | 2.8 | ug/L |

Sample ID: 950466 D.10

Report Date/Time: Monday, November 13, 2006 17:21:06

Page 1

231

| | | | | | | | | |
|--|----|-----|---------|------|--------|---------|-------|-----------|
| | Pb | 206 | 196.671 | 7.3 | 87.335 | 0.01682 | 0.003 | 18.2 ug/L |
| | Pb | 207 | 165.003 | 10.0 | 77.001 | 0.01615 | 0.003 | 17.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 97.596 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 100.265 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 101.566 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.540 | | | |
| > Ho | 165 | | 99.018 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950467 D.10

Sample Date/Time: Monday, November 13, 2006 17:24:02

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950467 D.10.038

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 67.334 | 5.2 | 63.001 | 0.00649 | 0.004 | 63.6 | ug/L |
| Al | 27 | 14099.059 | 1.2 | 2334.350 | 1.80391 | 0.038 | 2.1 | ug/L |
| > Sc | 45 | 365802.694 | 1.5 | 381869.082 | | | | ug/L |
| V | 51 | 5347.486 | 4.0 | 4488.603 | 0.06686 | 0.018 | 27.6 | ug/L |
| Cr | 52 | 21778.649 | 2.3 | 15368.650 | 0.51505 | 0.059 | 11.4 | ug/L |
| Cr | 53 | 1412.134 | 1.5 | 814.381 | 0.36608 | 0.012 | 3.3 | ug/L |
| Mn | 55 | 867508.854 | 1.3 | 494.020 | 43.33349 | 0.932 | 2.2 | ug/L |
| Co | 59 | 2426.711 | 4.4 | 188.671 | 0.12845 | 0.006 | 4.3 | ug/L |
| Ni | 60 | 2981.898 | 6.5 | 136.669 | 0.72726 | 0.048 | 6.5 | ug/L |
| Ni | 62 | 384.346 | 5.8 | 143.669 | 0.41596 | 0.036 | 8.6 | ug/L |
| Cu | 63 | 3059.926 | 3.1 | 212.338 | 0.31850 | 0.009 | 2.9 | ug/L |
| Cu | 65 | 1656.181 | 1.9 | 189.671 | 0.33885 | 0.010 | 2.9 | ug/L |
| Zn | 66 | 28517.004 | 1.7 | 1515.486 | 10.63626 | 0.263 | 2.5 | ug/L |
| Zn | 67 | 4491.589 | 2.8 | 342.344 | 9.41070 | 0.194 | 2.1 | ug/L |
| Zn | 68 | 20916.426 | 0.2 | 1170.427 | 10.58979 | 0.098 | 0.9 | ug/L |
| > Ge | 72 | 242128.433 | 0.9 | 244883.968 | | | | ug/L |
| As | 75 | 356.011 | 5.9 | 124.002 | 0.07421 | 0.008 | 10.3 | ug/L |
| Se | 77 | 241.070 | 4.0 | 216.736 | 0.11402 | 0.042 | 36.9 | ug/L |
| Se | 78 | 15998.818 | 1.2 | 16119.238 | 0.08159 | 0.385 | 472.4 | mg/L |
| Se | 82 | 1837.869 | 0.6 | 1872.010 | -0.04097 | 0.087 | 211.7 | ug/L |
| Kr | 83 | 1765.871 | 1.8 | 1902.236 | | | | mg/L |
| Y | 89 | 395968.421 | 0.8 | 408188.389 | | | | ug/L |
| Mo | 95 | 1228.103 | 1.4 | 112.002 | 0.20986 | 0.005 | 2.4 | ug/L |
| Mo | 97 | 762.042 | 1.3 | 64.001 | 0.21578 | 0.004 | 2.0 | ug/L |
| Mo | 98 | 1857.359 | 3.2 | 98.282 | 0.21552 | 0.008 | 3.7 | ug/L |
| Rh | 103 | 326227.577 | 0.6 | 340052.119 | | | | ug/L |
| Ag | 107 | 87.668 | 9.7 | 91.335 | -0.00019 | 0.001 | 341.4 | ug/L |
| Ag | 109 | 70.001 | 19.2 | 75.668 | -0.00038 | 0.001 | 292.3 | ug/L |
| Cd | 111 | 210.785 | 10.4 | 218.275 | -0.00161 | 0.007 | 447.9 | ug/L |
| Cd | 114 | 102.037 | 29.6 | 58.957 | 0.00655 | 0.004 | 67.0 | ug/L |
| > In | 115 | 353953.991 | 0.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 369.679 | 7.0 | 107.668 | 0.02860 | 0.003 | 8.8 | ug/L |
| Sb | 123 | 262.307 | 9.8 | 79.665 | 0.02591 | 0.004 | 13.6 | ug/L |
| Ba | 135 | 17151.152 | 3.7 | 46.667 | 7.09450 | 0.146 | 2.1 | ug/L |
| Ba | 137 | 29333.497 | 0.4 | 47.001 | 7.12016 | 0.097 | 1.4 | ug/L |
| > Tb | 159 | 400492.449 | 1.7 | 411268.087 | | | | ug/L |
| > Ho | 165 | 380744.650 | 1.7 | 390096.908 | | | | ug/L |
| Tl | 203 | 272.674 | 4.2 | 60.001 | 0.02765 | 0.002 | 6.6 | ug/L |
| Tl | 205 | 572.692 | 6.8 | 78.001 | 0.02903 | 0.003 | 9.3 | ug/L |
| Pb | 208 | 699.352 | 5.3 | 320.672 | 0.01567 | 0.001 | 6.6 | ug/L |

Sample ID: 950467 D.10

Report Date/Time: Monday, November 13, 2006 17:27:04

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|-----------|
| | Pb | 206 | 187.337 | 7.1 | 87.335 | 0.01573 | 0.002 | 10.4 ug/L |
| | Pb | 207 | 149.670 | 1.7 | 77.001 | 0.01376 | 0.000 | 0.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 95.793 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 98.875 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.772 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.380 | | | |
| > Ho | 165 | | 97.603 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950468 D.10

Sample Date/Time: Monday, November 13, 2006 17:30:00

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\1111306A\950468 D.10.039

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 64.001 | 18.9 | 63.001 | 0.00280 | 0.011 | 388.1 | ug/L |
| Al | 27 | 10530.088 | 0.7 | 2334.350 | 1.24604 | 0.016 | 1.3 | ug/L |
| > Sc | 45 | 369283.699 | 1.3 | 381869.082 | | | | ug/L |
| V | 51 | 5260.467 | 2.6 | 4488.603 | 0.05798 | 0.007 | 12.5 | ug/L |
| Cr | 52 | 20540.827 | 1.5 | 15368.650 | 0.41013 | 0.015 | 3.7 | ug/L |
| Cr | 53 | 1313.783 | 3.7 | 814.381 | 0.30174 | 0.018 | 6.1 | ug/L |
| Mn | 55 | 872660.198 | 0.2 | 494.020 | 42.70553 | 0.957 | 2.2 | ug/L |
| Co | 59 | 2699.131 | 1.5 | 188.671 | 0.14099 | 0.005 | 3.8 | ug/L |
| Ni | 60 | 2993.235 | 4.9 | 136.669 | 0.71510 | 0.048 | 6.7 | ug/L |
| Ni | 62 | 399.014 | 4.9 | 143.669 | 0.42786 | 0.047 | 11.0 | ug/L |
| Cu | 63 | 4182.091 | 0.9 | 212.338 | 0.43444 | 0.006 | 1.4 | ug/L |
| Cu | 65 | 2159.302 | 4.4 | 189.671 | 0.44511 | 0.031 | 7.1 | ug/L |
| Zn | 66 | 9322.640 | 2.4 | 1515.486 | 3.00460 | 0.043 | 1.4 | ug/L |
| Zn | 67 | 1690.855 | 1.6 | 342.344 | 2.98818 | 0.137 | 4.6 | ug/L |
| Zn | 68 | 7184.170 | 3.5 | 1170.427 | 3.15176 | 0.141 | 4.5 | ug/L |
| > Ge | 72 | 247194.253 | 2.2 | 244883.968 | | | | ug/L |
| As | 75 | 363.012 | 8.4 | 124.002 | 0.07395 | 0.008 | 10.6 | ug/L |
| Se | 77 | 235.137 | 3.6 | 216.736 | 0.06799 | 0.014 | 20.7 | ug/L |
| Se | 78 | 15873.342 | 0.7 | 16119.238 | -0.50332 | 0.467 | 92.7 | mg/L |
| Se | 82 | 1837.536 | 0.6 | 1872.010 | -0.15977 | 0.155 | 97.0 | ug/L |
| Kr | 83 | 1773.540 | 2.2 | 1902.236 | | | | mg/L |
| Y | 89 | 401276.386 | 1.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 1203.432 | 2.8 | 112.002 | 0.19726 | 0.005 | 2.4 | ug/L |
| Mo | 97 | 746.041 | 0.7 | 64.001 | 0.20275 | 0.002 | 0.8 | ug/L |
| Mo | 98 | 1794.859 | 4.7 | 98.282 | 0.20026 | 0.013 | 6.5 | ug/L |
| Rh | 103 | 320911.546 | 1.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 80.335 | 19.8 | 91.335 | -0.00096 | 0.001 | 124.5 | ug/L |
| Ag | 109 | 70.001 | 22.2 | 75.668 | -0.00057 | 0.001 | 226.8 | ug/L |
| Cd | 111 | 225.351 | 6.4 | 218.275 | 0.00060 | 0.004 | 681.7 | ug/L |
| Cd | 114 | 94.806 | 17.4 | 58.957 | 0.00501 | 0.003 | 51.8 | ug/L |
| > In | 115 | 366833.338 | 1.5 | 358352.924 | | | | ug/L |
| Sb | 121 | 302.009 | 11.5 | 107.668 | 0.02014 | 0.004 | 20.5 | ug/L |
| Sb | 123 | 243.973 | 3.8 | 79.665 | 0.02212 | 0.001 | 4.8 | ug/L |
| Ba | 135 | 17035.904 | 2.1 | 46.667 | 7.25035 | 0.154 | 2.1 | ug/L |
| Ba | 137 | 29468.642 | 0.7 | 47.001 | 7.35677 | 0.051 | 0.7 | ug/L |
| > Tb | 159 | 389357.113 | 0.2 | 411268.087 | | | | ug/L |
| > Ho | 165 | 380647.583 | 1.8 | 390096.908 | | | | ug/L |
| Tl | 203 | 292.341 | 5.4 | 60.001 | 0.03022 | 0.003 | 9.0 | ug/L |
| Tl | 205 | 616.029 | 4.9 | 78.001 | 0.03154 | 0.001 | 3.9 | ug/L |
| Pb | 208 | 861.026 | 0.2 | 320.672 | 0.02226 | 0.001 | 2.8 | ug/L |

Sample ID: 950468 D.10

Report Date/Time: Monday, November 13, 2006 17:33:02

Page 1

237

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|-----------|
| | Pb | 206 | 226.339 | 7.4 | 87.335 | 0.02180 | 0.003 | 13.7 ug/L |
| | Pb | 207 | 197.004 | 4.7 | 77.001 | 0.02251 | 0.001 | 5.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 96.704 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 100.943 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.366 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 94.672 | | | |
| > Ho | 165 | | 97.578 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950469 D.10

Sample Date/Time: Monday, November 13, 2006 17:35:59

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950469 D.10.040

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 56.001 | 11.7 | 63.001 | -0.00499 | 0.006 | 114.6 | ug/L |
| Al | 27 | 13639.625 | 1.8 | 2334.350 | 1.69501 | 0.030 | 1.8 | ug/L |
| > Sc | 45 | 372778.910 | 1.3 | 381869.082 | | | | ug/L |
| V | 51 | 4620.477 | 5.3 | 4488.603 | 0.01498 | 0.017 | 112.3 | ug/L |
| Cr | 52 | 30857.350 | 2.1 | 15368.650 | 1.13474 | 0.068 | 6.0 | ug/L |
| Cr | 53 | 2578.092 | 4.3 | 814.381 | 1.01311 | 0.051 | 5.0 | ug/L |
| Mn | 55 | 889820.832 | 1.5 | 494.020 | 42.83842 | 0.484 | 1.1 | ug/L |
| Co | 59 | 1072.413 | 2.2 | 188.671 | 0.04860 | 0.002 | 4.4 | ug/L |
| Ni | 60 | 3970.319 | 2.4 | 136.669 | 0.94351 | 0.036 | 3.8 | ug/L |
| Ni | 62 | 479.685 | 3.8 | 143.669 | 0.55012 | 0.033 | 6.0 | ug/L |
| Cu | 63 | 1456.809 | 1.0 | 212.338 | 0.13352 | 0.005 | 3.4 | ug/L |
| Cu | 65 | 847.718 | 1.9 | 189.671 | 0.14522 | 0.000 | 0.2 | ug/L |
| Zn | 66 | 115154.995 | 0.3 | 1515.486 | 43.10957 | 0.928 | 2.2 | ug/L |
| Zn | 67 | 17531.935 | 1.9 | 342.344 | 37.53049 | 0.628 | 1.7 | ug/L |
| Zn | 68 | 83335.568 | 2.1 | 1170.427 | 42.42683 | 0.622 | 1.5 | ug/L |
| > Ge | 72 | 251218.870 | 2.0 | 244883.968 | | | | ug/L |
| As | 75 | 3679.182 | 2.5 | 124.002 | 1.08805 | 0.035 | 3.2 | ug/L |
| Se | 77 | 217.203 | 2.0 | 216.736 | -0.02088 | 0.024 | 113.3 | ug/L |
| Se | 78 | 15583.563 | 1.0 | 16119.238 | -1.19526 | 0.457 | 38.2 | mg/L |
| Se | 82 | 1759.052 | 1.0 | 1872.010 | -0.49132 | 0.159 | 32.4 | ug/L |
| Kr | 83 | 1835.887 | 2.7 | 1902.236 | | | | mg/L |
| Y | 89 | 402568.641 | 1.5 | 408188.389 | | | | ug/L |
| Mo | 95 | 1296.447 | 1.5 | 112.002 | 0.22062 | 0.001 | 0.4 | ug/L |
| Mo | 97 | 789.045 | 6.3 | 64.001 | 0.22227 | 0.019 | 8.7 | ug/L |
| Mo | 98 | 2014.283 | 1.8 | 98.282 | 0.23264 | 0.001 | 0.2 | ug/L |
| Rh | 103 | 330161.066 | 2.3 | 340052.119 | | | | ug/L |
| Ag | 107 | 74.668 | 19.0 | 91.335 | -0.00122 | 0.001 | 97.3 | ug/L |
| Ag | 109 | 47.334 | 5.3 | 75.668 | -0.00226 | 0.000 | 9.7 | ug/L |
| Cd | 111 | 248.291 | 4.8 | 218.275 | 0.01023 | 0.004 | 37.7 | ug/L |
| Cd | 114 | 127.703 | 28.9 | 58.957 | 0.01021 | 0.005 | 51.5 | ug/L |
| > In | 115 | 356960.297 | 1.9 | 358352.924 | | | | ug/L |
| Sb | 121 | 151.003 | 11.6 | 107.668 | 0.00471 | 0.002 | 39.6 | ug/L |
| Sb | 123 | 113.938 | 7.0 | 79.665 | 0.00483 | 0.001 | 17.7 | ug/L |
| Ba | 135 | 37254.142 | 1.8 | 46.667 | 15.31603 | 0.325 | 2.1 | ug/L |
| Ba | 137 | 62365.136 | 1.1 | 47.001 | 15.03077 | 0.221 | 1.5 | ug/L |
| > Tb | 159 | 403632.016 | 0.4 | 411268.087 | | | | ug/L |
| > Ho | 165 | 389079.471 | 1.8 | 390096.908 | | | | ug/L |
| Tl | 203 | 154.003 | 19.8 | 60.001 | 0.01185 | 0.004 | 29.9 | ug/L |
| Tl | 205 | 318.676 | 2.6 | 78.001 | 0.01377 | 0.000 | 2.6 | ug/L |
| Pb | 208 | 1056.370 | 2.9 | 320.672 | 0.02927 | 0.002 | 6.6 | ug/L |

Sample ID: 950469 D.10

Report Date/Time: Monday, November 13, 2006 17:39:00

Page 1

240

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|-----------|
| | Pb | 206 | 276.674 | 8.1 | 87.335 | 0.02862 | 0.003 | 11.4 ug/L |
| | Pb | 207 | 232.339 | 5.3 | 77.001 | 0.02815 | 0.003 | 10.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 97.620 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 102.587 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 99.611 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.143 | | | |
| > Ho | 165 | | 99.739 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950470 D.10

Sample Date/Time: Monday, November 13, 2006 17:41:57

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950470 D.10.041

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55.001 | 6.3 | 63.001 | -0.00650 | 0.003 | 46.3 | ug/L |
| Al | 27 | 32214.805 | 0.7 | 2334.350 | 4.40749 | 0.034 | 0.8 | ug/L |
| > Sc | 45 | 377397.271 | 0.4 | 381869.082 | | | | ug/L |
| V | 51 | 5081.967 | 4.5 | 4488.603 | 0.03988 | 0.015 | 38.2 | ug/L |
| Cr | 52 | 22225.489 | 0.8 | 15368.650 | 0.49730 | 0.018 | 3.5 | ug/L |
| Cr | 53 | 1499.817 | 3.3 | 814.381 | 0.39008 | 0.026 | 6.6 | ug/L |
| Mn | 55 | 175515.711 | 2.7 | 494.020 | 8.48899 | 0.388 | 4.6 | ug/L |
| Co | 59 | 1858.226 | 3.5 | 188.671 | 0.09268 | 0.003 | 3.7 | ug/L |
| Ni | 60 | 6815.188 | 1.6 | 136.669 | 1.65537 | 0.062 | 3.7 | ug/L |
| Ni | 62 | 1007.738 | 7.3 | 143.669 | 1.43661 | 0.153 | 10.7 | ug/L |
| Cu | 63 | 2910.538 | 4.1 | 212.338 | 0.29205 | 0.010 | 3.4 | ug/L |
| Cu | 65 | 1501.150 | 1.9 | 189.671 | 0.29274 | 0.009 | 3.0 | ug/L |
| Zn | 66 | 119940.614 | 1.4 | 1515.486 | 45.22842 | 1.571 | 3.5 | ug/L |
| Zn | 67 | 17875.669 | 2.0 | 342.344 | 38.54073 | 1.157 | 3.0 | ug/L |
| Zn | 68 | 83935.859 | 1.8 | 1170.427 | 43.02952 | 1.337 | 3.1 | ug/L |
| > Ge | 72 | 249608.312 | 2.1 | 244883.968 | | | | ug/L |
| As | 75 | 288.675 | 8.9 | 124.002 | 0.05016 | 0.010 | 19.4 | ug/L |
| Se | 77 | 216.269 | 7.1 | 216.736 | -0.01946 | 0.055 | 281.9 | ug/L |
| Se | 78 | 15906.889 | 1.3 | 16119.238 | -0.65426 | 0.677 | 103.5 | mg/L |
| Se | 82 | 1782.591 | 2.7 | 1872.010 | -0.38612 | 0.109 | 28.3 | ug/L |
| Kr | 83 | 1713.860 | 0.7 | 1902.236 | | | | mg/L |
| Y | 89 | 403622.495 | 2.0 | 408188.389 | | | | ug/L |
| Mo | 95 | 251.673 | 7.2 | 112.002 | 0.02551 | 0.004 | 14.2 | ug/L |
| Mo | 97 | 141.669 | 7.0 | 64.001 | 0.02329 | 0.003 | 11.4 | ug/L |
| Mo | 98 | 306.989 | 3.1 | 98.282 | 0.02492 | 0.001 | 5.6 | ug/L |
| Rh | 103 | 326617.777 | 1.1 | 340052.119 | | | | ug/L |
| Ag | 107 | 81.335 | 16.7 | 91.335 | -0.00080 | 0.001 | 129.1 | ug/L |
| Ag | 109 | 60.334 | 16.8 | 75.668 | -0.00127 | 0.001 | 64.8 | ug/L |
| Cd | 111 | 279.987 | 8.4 | 218.275 | 0.01958 | 0.008 | 42.4 | ug/L |
| Cd | 114 | 198.869 | 5.8 | 58.957 | 0.02046 | 0.001 | 7.2 | ug/L |
| > In | 115 | 361533.714 | 0.7 | 358352.924 | | | | ug/L |
| Sb | 121 | 170.003 | 15.6 | 107.668 | 0.00653 | 0.003 | 43.8 | ug/L |
| Sb | 123 | 127.938 | 5.7 | 79.665 | 0.00657 | 0.001 | 15.8 | ug/L |
| Ba | 135 | 10094.879 | 1.4 | 46.667 | 4.15428 | 0.070 | 1.7 | ug/L |
| Ba | 137 | 16704.229 | 1.9 | 47.001 | 4.03542 | 0.104 | 2.6 | ug/L |
| > Tb | 159 | 401910.365 | 0.8 | 411268.087 | | | | ug/L |
| > Ho | 165 | 384687.584 | 1.6 | 390096.908 | | | | ug/L |
| Tl | 203 | 128.002 | 11.3 | 60.001 | 0.00878 | 0.002 | 18.8 | ug/L |
| Tl | 205 | 241.339 | 2.7 | 78.001 | 0.00950 | 0.000 | 1.7 | ug/L |
| Pb | 208 | 1221.713 | 1.1 | 320.672 | 0.03638 | 0.001 | 3.4 | ug/L |

Sample ID: 950470 D.10

Report Date/Time: Monday, November 13, 2006 17:44:59

Page 1

243

| | | | | | | | | |
|---|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 313.342 | 3.4 | 87.335 | 0.03472 | 0.002 | 6.9 ug/L |
| L | Pb | 207 | 282.008 | 7.3 | 77.001 | 0.03765 | 0.003 | 8.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 98.829 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 101.929 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 100.888 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.725 | | | |
| > Ho | 165 | | 98.613 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950471 D.10

Sample Date/Time: Monday, November 13, 2006 17:47:57

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950471 D.10.042

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 62.001 | 10.6 | 63.001 | -0.00032 | 0.006 | 1866.7 | ug/L |
| Al | 27 | 173490.771 | 2.5 | 2334.350 | 25.17746 | 0.442 | 1.8 | ug/L |
| > Sc | 45 | 378122.950 | 1.5 | 381869.082 | | | | ug/L |
| V | 51 | 5434.511 | 8.7 | 4488.603 | 0.06126 | 0.034 | 55.4 | ug/L |
| Cr | 52 | 27727.336 | 1.5 | 15368.650 | 0.88291 | 0.060 | 6.8 | ug/L |
| Cr | 53 | 2187.976 | 1.7 | 814.381 | 0.77436 | 0.034 | 4.4 | ug/L |
| Mn | 55 | 105362.565 | 4.7 | 494.020 | 5.05626 | 0.248 | 4.9 | ug/L |
| Co | 59 | 2216.650 | 2.3 | 188.671 | 0.11196 | 0.003 | 2.7 | ug/L |
| Ni | 60 | 7819.080 | 3.0 | 136.669 | 1.89335 | 0.073 | 3.9 | ug/L |
| Ni | 62 | 1296.114 | 2.6 | 143.669 | 1.90382 | 0.074 | 3.9 | ug/L |
| Cu | 63 | 1996.259 | 2.4 | 212.338 | 0.19184 | 0.007 | 3.7 | ug/L |
| Cu | 65 | 1054.411 | 0.9 | 189.671 | 0.19145 | 0.003 | 1.7 | ug/L |
| Zn | 66 | 149800.620 | 0.7 | 1515.486 | 56.30248 | 0.106 | 0.2 | ug/L |
| Zn | 67 | 22785.690 | 3.1 | 342.344 | 49.06099 | 1.766 | 3.6 | ug/L |
| Zn | 68 | 105803.230 | 1.4 | 1170.427 | 54.09111 | 0.927 | 1.7 | ug/L |
| > Ge | 72 | 250948.779 | 0.8 | 244883.968 | | | | ug/L |
| As | 75 | 365.012 | 8.2 | 124.002 | 0.07291 | 0.008 | 11.4 | ug/L |
| Se | 77 | 229.803 | 2.7 | 216.736 | 0.03158 | 0.022 | 68.4 | ug/L |
| Se | 78 | 15989.711 | 0.9 | 16119.238 | -0.66570 | 0.306 | 46.0 | mg/L |
| Se | 82 | 1768.054 | 0.7 | 1872.010 | -0.45981 | 0.062 | 13.5 | ug/L |
| Kr | 83 | 1746.867 | 1.2 | 1902.236 | | | | mg/L |
| Y | 89 | 410884.111 | 1.8 | 408188.389 | | | | ug/L |
| Mo | 95 | 217.338 | 3.7 | 112.002 | 0.01850 | 0.001 | 4.8 | ug/L |
| Mo | 97 | 130.002 | 2.3 | 64.001 | 0.01911 | 0.001 | 2.6 | ug/L |
| Mo | 98 | 259.694 | 7.5 | 98.282 | 0.01874 | 0.003 | 13.8 | ug/L |
| Rh | 103 | 331667.207 | 1.9 | 340052.119 | | | | ug/L |
| Ag | 107 | 65.668 | 26.2 | 91.335 | -0.00204 | 0.001 | 66.9 | ug/L |
| Ag | 109 | 50.667 | 3.0 | 75.668 | -0.00211 | 0.000 | 7.4 | ug/L |
| Cd | 111 | 256.185 | 5.9 | 218.275 | 0.01037 | 0.005 | 49.3 | ug/L |
| Cd | 114 | 201.347 | 3.3 | 58.957 | 0.02034 | 0.001 | 5.6 | ug/L |
| > In | 115 | 367754.849 | 1.9 | 358352.924 | | | | ug/L |
| Sb | 121 | 140.003 | 10.0 | 107.668 | 0.00309 | 0.001 | 47.1 | ug/L |
| Sb | 123 | 122.181 | 10.5 | 79.665 | 0.00547 | 0.001 | 26.4 | ug/L |
| Ba | 135 | 3805.241 | 3.2 | 46.667 | 1.57082 | 0.050 | 3.2 | ug/L |
| Ba | 137 | 6258.412 | 1.1 | 47.001 | 1.52083 | 0.004 | 0.3 | ug/L |
| > Tb | 159 | 397694.726 | 1.1 | 411268.087 | | | | ug/L |
| > Ho | 165 | 389600.665 | 0.6 | 390096.908 | | | | ug/L |
| Tl | 203 | 75.334 | 10.7 | 60.001 | 0.00194 | 0.001 | 49.6 | ug/L |
| Tl | 205 | 150.670 | 4.4 | 78.001 | 0.00416 | 0.000 | 10.0 | ug/L |
| Pb | 208 | 2456.164 | 2.9 | 320.672 | 0.08472 | 0.003 | 4.0 | ug/L |

Sample ID: 950471 D.10

Report Date/Time: Monday, November 13, 2006 17:50:59

Page 1

246

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 656.032 | 2.8 | 87.335 | 0.08577 | 0.003 | 3.7 ug/L |
| | Pb | 207 | 532.022 | 3.1 | 77.001 | 0.08216 | 0.003 | 3.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 99.019 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 102.477 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.624 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 96.700 | | | |
| > Ho | 165 | | 99.873 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950472 D.10

Sample Date/Time: Monday, November 13, 2006 17:53:56

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950472 D.10.043

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 56.667 | 14.2 | 63.001 | -0.00490 | 0.007 | 139.9 | ug/L |
| Al | 27 | 59586.887 | 1.1 | 2334.350 | 8.46347 | 0.147 | 1.7 | ug/L |
| > Sc | 45 | 376533.222 | 2.3 | 381869.082 | | | | ug/L |
| V | 51 | 5515.794 | 1.8 | 4488.603 | 0.06749 | 0.009 | 13.9 | ug/L |
| Cr | 52 | 17912.414 | 1.8 | 15368.650 | 0.19578 | 0.034 | 17.4 | ug/L |
| Cr | 53 | 961.398 | 1.0 | 814.381 | 0.08939 | 0.018 | 20.1 | ug/L |
| Mn | 55 | 141827.568 | 1.2 | 494.020 | 7.01962 | 0.106 | 1.5 | ug/L |
| Co | 59 | 1672.518 | 1.5 | 188.671 | 0.08463 | 0.002 | 2.3 | ug/L |
| Ni | 60 | 4853.129 | 3.0 | 136.669 | 1.19774 | 0.037 | 3.1 | ug/L |
| Ni | 62 | 702.703 | 3.2 | 143.669 | 0.95512 | 0.033 | 3.4 | ug/L |
| Cu | 63 | 1862.227 | 2.4 | 212.338 | 0.18336 | 0.004 | 2.2 | ug/L |
| Cu | 65 | 1060.745 | 1.9 | 189.671 | 0.19991 | 0.003 | 1.6 | ug/L |
| Zn | 66 | 102753.645 | 0.4 | 1515.486 | 39.60596 | 0.119 | 0.3 | ug/L |
| Zn | 67 | 15700.601 | 0.7 | 342.344 | 34.59420 | 0.303 | 0.9 | ug/L |
| Zn | 68 | 73961.508 | 0.4 | 1170.427 | 38.77288 | 0.378 | 1.0 | ug/L |
| > Ge | 72 | 243637.046 | 0.6 | 244883.968 | | | | ug/L |
| As | 75 | 517.688 | 3.1 | 124.002 | 0.12451 | 0.005 | 3.7 | ug/L |
| Se | 77 | 250.804 | 3.1 | 216.736 | 0.14888 | 0.037 | 24.6 | ug/L |
| Se | 78 | 16074.350 | 0.7 | 16119.238 | 0.04939 | 0.262 | 531.4 | mg/L |
| Se | 82 | 1813.464 | 1.3 | 1872.010 | -0.15465 | 0.047 | 30.5 | ug/L |
| Kr | 83 | 1829.886 | 2.4 | 1902.236 | | | | mg/L |
| Y | 89 | 407146.463 | 1.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 464.018 | 3.5 | 112.002 | 0.06413 | 0.004 | 5.7 | ug/L |
| Mo | 97 | 270.340 | 6.7 | 64.001 | 0.06183 | 0.006 | 9.9 | ug/L |
| Mo | 98 | 617.380 | 2.9 | 98.282 | 0.06174 | 0.002 | 2.9 | ug/L |
| Rh | 103 | 339803.269 | 2.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 67.668 | 6.0 | 91.335 | -0.00185 | 0.000 | 15.3 | ug/L |
| Ag | 109 | 48.334 | 11.8 | 75.668 | -0.00225 | 0.000 | 19.0 | ug/L |
| Cd | 111 | 225.015 | 3.7 | 218.275 | 0.00122 | 0.003 | 273.5 | ug/L |
| Cd | 114 | 144.150 | 10.2 | 58.957 | 0.01233 | 0.002 | 17.6 | ug/L |
| > In | 115 | 363344.574 | 0.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 160.003 | 5.7 | 107.668 | 0.00538 | 0.001 | 17.1 | ug/L |
| Sb | 123 | 128.387 | 6.3 | 79.665 | 0.00655 | 0.001 | 19.3 | ug/L |
| Ba | 135 | 3473.092 | 0.2 | 46.667 | 1.40299 | 0.028 | 2.0 | ug/L |
| Ba | 137 | 5807.415 | 2.6 | 47.001 | 1.38243 | 0.063 | 4.5 | ug/L |
| > Tb | 159 | 405921.885 | 1.9 | 411268.087 | | | | ug/L |
| > Ho | 165 | 383304.531 | 1.1 | 390096.908 | | | | ug/L |
| Tl | 203 | 106.668 | 16.0 | 60.001 | 0.00611 | 0.002 | 34.6 | ug/L |
| Tl | 205 | 212.338 | 5.7 | 78.001 | 0.00787 | 0.001 | 7.3 | ug/L |
| Pb | 208 | 1827.096 | 1.4 | 320.672 | 0.06096 | 0.002 | 2.9 | ug/L |

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 475.685 | 4.0 | 87.335 | 0.05975 | 0.003 | 5.0 ug/L |
| | Pb | 207 | 397.013 | 5.0 | 77.001 | 0.05896 | 0.003 | 5.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 98.603 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 99.491 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 101.393 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.700 | | | |
| > Ho | 165 | | 98.259 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 13, 2006 17:59:54

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 6.044

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 53000.552 | 1.2 | 63.001 | 48.30052 | 1.559 | 3.2 | ug/L |
| Al | 27 | 340304.526 | 0.5 | 2334.350 | 50.81143 | 1.845 | 3.6 | ug/L |
| > Sc | 45 | 370303.590 | 3.3 | 381869.082 | | | | ug/L |
| V | 51 | 818699.229 | 0.5 | 4488.603 | 51.22761 | 1.577 | 3.1 | ug/L |
| Cr | 52 | 721451.414 | 0.6 | 15368.650 | 50.92929 | 2.011 | 3.9 | ug/L |
| Cr | 53 | 87513.852 | 2.5 | 814.381 | 49.62371 | 0.484 | 1.0 | ug/L |
| Mn | 55 | 1028136.525 | 0.9 | 494.020 | 51.39882 | 1.478 | 2.9 | ug/L |
| Co | 59 | 865161.308 | 1.5 | 188.671 | 49.65019 | 1.790 | 3.6 | ug/L |
| Ni | 60 | 195597.577 | 0.8 | 136.669 | 49.99710 | 2.125 | 4.3 | ug/L |
| Ni | 62 | 29959.396 | 1.4 | 143.669 | 51.24159 | 1.501 | 2.9 | ug/L |
| Cu | 63 | 464943.296 | 2.9 | 212.338 | 51.97664 | 1.767 | 3.4 | ug/L |
| Cu | 65 | 225371.987 | 1.7 | 189.671 | 51.98319 | 1.161 | 2.2 | ug/L |
| Zn | 66 | 137789.418 | 2.8 | 1515.486 | 53.66648 | 0.392 | 0.7 | ug/L |
| Zn | 67 | 23407.400 | 1.5 | 342.344 | 52.33349 | 2.057 | 3.9 | ug/L |
| Zn | 68 | 101596.237 | 0.3 | 1170.427 | 53.88615 | 2.104 | 3.9 | ug/L |
| > Ge | 72 | 242080.956 | 3.5 | 244883.968 | | | | ug/L |
| As | 75 | 154064.454 | 1.3 | 124.002 | 48.94916 | 1.101 | 2.2 | ug/L |
| Se | 77 | 12571.008 | 0.6 | 216.736 | 52.65209 | 1.821 | 3.5 | ug/L |
| Se | 78 | 55304.611 | 1.8 | 16119.238 | 51.55870 | 2.989 | 5.8 | mg/L |
| Se | 82 | 18236.868 | 1.1 | 1872.010 | 52.02556 | 1.520 | 2.9 | ug/L |
| Kr | 83 | 1736.865 | 2.3 | 1902.236 | | | | mg/L |
| Y | 89 | 402663.821 | 1.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 263827.031 | 1.5 | 112.002 | 50.02172 | 1.283 | 2.6 | ug/L |
| Mo | 97 | 166689.274 | 0.3 | 64.001 | 51.96543 | 0.906 | 1.7 | ug/L |
| Mo | 98 | 415359.342 | 1.5 | 98.282 | 51.34310 | 0.202 | 0.4 | ug/L |
| Rh | 103 | 330093.789 | 0.6 | 340052.119 | | | | ug/L |
| Ag | 107 | 672863.021 | 1.3 | 91.335 | 51.82647 | 1.177 | 2.3 | ug/L |
| Ag | 109 | 629014.362 | 2.1 | 75.668 | 51.54866 | 0.380 | 0.7 | ug/L |
| Cd | 111 | 154630.126 | 2.1 | 218.275 | 52.07302 | 1.063 | 2.0 | ug/L |
| Cd | 114 | 350777.903 | 1.8 | 58.957 | 53.12290 | 0.541 | 1.0 | ug/L |
| > In | 115 | 350472.217 | 1.4 | 358352.924 | | | | ug/L |
| Sb | 121 | 469026.664 | 1.7 | 107.668 | 51.45249 | 0.950 | 1.8 | ug/L |
| Sb | 123 | 350249.710 | 1.4 | 79.665 | 49.91795 | 0.058 | 0.1 | ug/L |
| Ba | 135 | 119600.087 | 1.3 | 46.667 | 49.79849 | 0.470 | 0.9 | ug/L |
| Ba | 137 | 201601.973 | 1.8 | 47.001 | 49.19380 | 0.794 | 1.6 | ug/L |
| > Tb | 159 | 398867.737 | 1.2 | 411268.087 | | | | ug/L |
| > Ho | 165 | 378307.100 | 2.1 | 390096.908 | | | | ug/L |
| Tl | 203 | 393160.296 | 0.2 | 60.001 | 51.08144 | 0.992 | 1.9 | ug/L |
| Tl | 205 | 914903.906 | 1.0 | 78.001 | 53.79120 | 0.612 | 1.1 | ug/L |
| Pb | 208 | 1272161.777 | 0.8 | 320.672 | 51.95423 | 0.666 | 1.3 | ug/L |

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 328086.023 | 1.0 | 87.335 | 50.93640 | 0.676 | 1.3 ug/L |
| | Pb | 207 | 270572.773 | 0.4 | 77.001 | 50.29959 | 0.897 | 1.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 96.601 | | | | |
| Al | 27 | 101.623 | | | | |
| > Sc | 45 | | 96.971 | | | |
| V | 51 | 102.455 | | | | |
| Cr | 52 | 101.859 | | | | |
| Cr | 53 | 99.247 | | | | |
| Mn | 55 | 102.798 | | | | |
| Co | 59 | 99.300 | | | | |
| Ni | 60 | 99.994 | | | | |
| Ni | 62 | 102.483 | | | | |
| Cu | 63 | 103.953 | | | | |
| Cu | 65 | 103.966 | | | | |
| Zn | 66 | 107.333 | | | | |
| Zn | 67 | 104.667 | | | | |
| Zn | 68 | 107.772 | | | | |
| > Ge | 72 | | 98.855 | | | |
| As | 75 | 97.898 | | | | |
| Se | 77 | 105.304 | | | | |
| Se | 78 | 103.117 | | | | |
| Se | 82 | 104.051 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 100.043 | | | | |
| Mo | 97 | 103.931 | | | | |
| Mo | 98 | 102.686 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 103.653 | | | | |
| Ag | 109 | 103.097 | | | | |
| Cd | 111 | 104.146 | | | | |
| Cd | 114 | 106.246 | | | | |
| > In | 115 | | 97.801 | | | |
| Sb | 121 | 102.905 | | | | |
| Sb | 123 | 99.836 | | | | |
| Ba | 135 | 99.597 | | | | |
| Ba | 137 | 98.388 | | | | |
| > Tb | 159 | | 96.985 | | | |
| > Ho | 165 | | 96.978 | | | |
| Tl | 203 | 102.163 | | | | |
| Tl | 205 | 107.582 | | | | |
| Pb | 208 | 103.908 | | | | |
| Pb | 206 | 101.873 | | | | |
| Pb | 207 | 100.599 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 13, 2006 18:05:52

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 7.045

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 57.334 | 17.1 | 63.001 | -0.00292 | 0.009 | 292.6 | ug/L |
| Al | 27 | 2505.402 | 2.8 | 2334.350 | 0.04048 | 0.014 | 35.3 | ug/L |
| > Sc | 45 | 366353.047 | 1.5 | 381869.082 | | | | ug/L |
| V | 51 | 4837.695 | 3.1 | 4488.603 | 0.03372 | 0.005 | 14.5 | ug/L |
| Cr | 52 | 16033.577 | 2.6 | 15368.650 | 0.09374 | 0.013 | 14.3 | ug/L |
| Cr | 53 | 732.039 | 2.8 | 814.381 | -0.02853 | 0.005 | 19.0 | ug/L |
| Mn | 55 | 491.353 | 5.6 | 494.020 | 0.00005 | 0.001 | 1876.2 | ug/L |
| Co | 59 | 135.336 | 4.5 | 188.671 | -0.00296 | 0.000 | 11.9 | ug/L |
| Ni | 60 | 143.336 | 21.4 | 136.669 | 0.00201 | 0.008 | 401.5 | ug/L |
| Ni | 62 | 132.002 | 10.7 | 143.669 | -0.01767 | 0.029 | 162.0 | ug/L |
| Cu | 63 | 230.339 | 2.1 | 212.338 | 0.00219 | 0.001 | 31.9 | ug/L |
| Cu | 65 | 200.004 | 5.6 | 189.671 | 0.00272 | 0.003 | 96.3 | ug/L |
| Zn | 66 | 1557.161 | 3.1 | 1515.486 | 0.02089 | 0.006 | 29.3 | ug/L |
| Zn | 67 | 333.343 | 1.8 | 342.344 | -0.01420 | 0.013 | 94.9 | ug/L |
| Zn | 68 | 1222.102 | 3.2 | 1170.427 | 0.03274 | 0.028 | 85.5 | ug/L |
| > Ge | 72 | 242979.831 | 2.1 | 244883.968 | | | | ug/L |
| As | 75 | 173.670 | 1.8 | 124.002 | 0.01605 | 0.002 | 9.7 | ug/L |
| Se | 77 | 223.803 | 3.0 | 216.736 | 0.03711 | 0.019 | 51.3 | ug/L |
| Se | 78 | 15806.256 | 1.2 | 16119.238 | -0.23554 | 0.657 | 278.8 | mg/L |
| Se | 82 | 1770.055 | 2.0 | 1872.010 | -0.27619 | 0.022 | 8.0 | ug/L |
| Kr | 83 | 1761.204 | 2.0 | 1902.236 | | | | mg/L |
| Y | 89 | 400994.369 | 3.5 | 408188.389 | | | | ug/L |
| Mo | 95 | 779.378 | 19.0 | 112.002 | 0.12517 | 0.027 | 21.6 | ug/L |
| Mo | 97 | 498.020 | 20.2 | 64.001 | 0.13382 | 0.030 | 22.7 | ug/L |
| Mo | 98 | 1133.444 | 21.7 | 98.282 | 0.12648 | 0.029 | 23.3 | ug/L |
| Rh | 103 | 334663.192 | 0.7 | 340052.119 | | | | ug/L |
| Ag | 107 | 151.670 | 4.9 | 91.335 | 0.00466 | 0.001 | 11.9 | ug/L |
| Ag | 109 | 140.336 | 7.3 | 75.668 | 0.00530 | 0.001 | 15.1 | ug/L |
| Cd | 111 | 209.017 | 6.0 | 218.275 | -0.00235 | 0.004 | 180.0 | ug/L |
| Cd | 114 | 57.701 | 13.3 | 58.957 | -0.00010 | 0.001 | 1173.3 | ug/L |
| > In | 115 | 354763.272 | 0.4 | 358352.924 | | | | ug/L |
| Sb | 121 | 1263.777 | 15.3 | 107.668 | 0.12538 | 0.020 | 16.3 | ug/L |
| Sb | 123 | 1006.081 | 15.0 | 79.665 | 0.13053 | 0.021 | 15.9 | ug/L |
| Ba | 135 | 43.001 | 19.0 | 46.667 | -0.00118 | 0.003 | 272.1 | ug/L |
| Ba | 137 | 49.001 | 20.1 | 47.001 | 0.00067 | 0.002 | 335.6 | ug/L |
| > Tb | 159 | 403863.208 | 1.1 | 411268.087 | | | | ug/L |
| > Ho | 165 | 379820.399 | 2.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 85.668 | 11.0 | 60.001 | 0.00354 | 0.001 | 39.7 | ug/L |
| Tl | 205 | 140.003 | 16.1 | 78.001 | 0.00375 | 0.001 | 33.8 | ug/L |
| Pb | 208 | 438.675 | 3.7 | 320.672 | 0.00515 | 0.001 | 11.9 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Monday, November 13, 2006 18:08:52

Page 1

| | | | | | | | | | |
|--|----|-----|---------|------|--------|---------|-------|------|------|
| | Pb | 206 | 103.668 | 6.4 | 87.335 | 0.00287 | 0.001 | 25.4 | ug/L |
| | Pb | 207 | 110.669 | 10.9 | 77.001 | 0.00662 | 0.002 | 34.6 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 95.937 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 99.222 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 98.998 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.200 | | | |
| > [Ho | 165 | | 97.366 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950473 D.10

Sample Date/Time: Monday, November 13, 2006 18:11:49

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950473 D.10.046

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 61.001 | | 63.001 | -0.00117 | 0.001 | 76.1 | ug/L |
| Al | 27 | 9943.696 | 1.2 | 2334.350 | 1.12440 | 0.039 | 3.5 | ug/L |
| > Sc | 45 | 377766.144 | 1.7 | 381869.082 | | | | ug/L |
| V | 51 | 4978.140 | 2.9 | 4488.603 | 0.03329 | 0.014 | 41.3 | ug/L |
| Cr | 52 | 16865.224 | 2.4 | 15368.650 | 0.11774 | 0.044 | 37.6 | ug/L |
| Cr | 53 | 907.059 | 4.8 | 814.381 | 0.05681 | 0.020 | 35.9 | ug/L |
| Mn | 55 | 528239.445 | 1.7 | 494.020 | 25.66698 | 1.245 | 4.9 | ug/L |
| Co | 59 | 811.714 | 1.5 | 188.671 | 0.03460 | 0.002 | 6.1 | ug/L |
| Ni | 60 | 1329.120 | 8.1 | 136.669 | 0.29634 | 0.037 | 12.4 | ug/L |
| Ni | 62 | 192.671 | 6.7 | 143.669 | 0.07749 | 0.011 | 14.1 | ug/L |
| Cu | 63 | 1115.753 | 0.5 | 212.338 | 0.09785 | 0.003 | 3.5 | ug/L |
| Cu | 65 | 623.030 | 3.7 | 189.671 | 0.09664 | 0.009 | 8.9 | ug/L |
| Zn | 66 | 27911.958 | 2.0 | 1515.486 | 10.10191 | 0.497 | 4.9 | ug/L |
| Zn | 67 | 4400.539 | 1.0 | 342.344 | 8.93759 | 0.416 | 4.7 | ug/L |
| Zn | 68 | 20333.650 | 1.3 | 1170.427 | 9.98485 | 0.484 | 4.8 | ug/L |
| > Ge | 72 | 249046.712 | 3.3 | 244883.968 | | | | ug/L |
| As | 75 | 273.341 | 1.3 | 124.002 | 0.04555 | 0.003 | 7.6 | ug/L |
| Se | 77 | 245.804 | 1.7 | 216.736 | 0.10613 | 0.049 | 46.6 | ug/L |
| Se | 78 | 16266.733 | 1.4 | 16119.238 | -0.13984 | 0.959 | 685.6 | mg/L |
| Se | 82 | 1814.398 | 1.0 | 1872.010 | -0.27197 | 0.182 | 66.9 | ug/L |
| Kr | 83 | 1785.876 | 2.6 | 1902.236 | | | | mg/L |
| Y | 89 | 401410.698 | 1.5 | 408188.389 | | | | ug/L |
| Mo | 95 | 892.391 | 12.3 | 112.002 | 0.14024 | 0.019 | 13.9 | ug/L |
| Mo | 97 | 550.024 | 10.8 | 64.001 | 0.14367 | 0.017 | 12.1 | ug/L |
| Mo | 98 | 1398.595 | 9.8 | 98.282 | 0.15266 | 0.016 | 10.4 | ug/L |
| Rh | 103 | 332172.790 | 0.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 84.335 | 17.6 | 91.335 | -0.00070 | 0.001 | 157.8 | ug/L |
| Ag | 109 | 69.668 | 8.2 | 75.668 | -0.00063 | 0.000 | 68.7 | ug/L |
| Cd | 111 | 235.304 | 2.8 | 218.275 | 0.00353 | 0.002 | 60.7 | ug/L |
| Cd | 114 | 71.436 | 33.2 | 58.957 | 0.00157 | 0.003 | 218.3 | ug/L |
| > In | 115 | 368282.882 | 0.3 | 358352.924 | | | | ug/L |
| Sb | 121 | 582.026 | 8.9 | 107.668 | 0.04921 | 0.005 | 10.7 | ug/L |
| Sb | 123 | 458.984 | 4.8 | 79.665 | 0.05115 | 0.003 | 5.5 | ug/L |
| Ba | 135 | 5253.708 | 1.5 | 46.667 | 2.14800 | 0.020 | 0.9 | ug/L |
| Ba | 137 | 8997.278 | 1.3 | 47.001 | 2.16330 | 0.016 | 0.7 | ug/L |
| > Tb | 159 | 402813.914 | 1.2 | 411268.087 | | | | ug/L |
| > Ho | 165 | 390223.681 | 0.4 | 390096.908 | | | | ug/L |
| Tl | 203 | 112.335 | 5.7 | 60.001 | 0.00659 | 0.001 | 11.4 | ug/L |
| Tl | 205 | 222.005 | 15.9 | 78.001 | 0.00821 | 0.002 | 25.2 | ug/L |
| Pb | 208 | 596.681 | 2.7 | 320.672 | 0.01093 | 0.001 | 6.3 | ug/L |

Sample ID: 950473 D.10

Report Date/Time: Monday, November 13, 2006 18:14:50

Page 1

258

| | | | | | | | | |
|--|----|-----|---------|------|--------|---------|-------|-----------|
| | Pb | 206 | 164.003 | 10.4 | 87.335 | 0.01154 | 0.003 | 22.7 ug/L |
| | Pb | 207 | 130.336 | 9.7 | 77.001 | 0.00961 | 0.002 | 24.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 98.926 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 101.700 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 102.771 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 97.944 | | | |
| > [Ho | 165 | | 100.032 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950474 D.10

Sample Date/Time: Monday, November 13, 2006 18:17:47

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950474 D.10.047

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59.667 | 22.8 | 63.001 | -0.00406 | 0.012 | 306.9 | ug/L |
| Al | 27 | 29715.276 | 5.2 | 2334.350 | 3.88886 | 0.267 | 6.9 | ug/L |
| > Sc | 45 | 391006.486 | 1.6 | 381869.082 | | | | ug/L |
| V | 51 | 5081.904 | 0.7 | 4488.603 | 0.02900 | 0.007 | 23.7 | ug/L |
| Cr | 52 | 18971.762 | 1.1 | 15368.650 | 0.22075 | 0.009 | 4.3 | ug/L |
| Cr | 53 | 1148.424 | 2.2 | 814.381 | 0.17043 | 0.010 | 5.9 | ug/L |
| Mn | 55 | 47353.970 | 0.4 | 494.020 | 2.23680 | 0.017 | 0.7 | ug/L |
| Co | 59 | 592.360 | 5.4 | 188.671 | 0.02175 | 0.001 | 6.7 | ug/L |
| Ni | 60 | 2417.708 | 2.3 | 136.669 | 0.55578 | 0.018 | 3.3 | ug/L |
| Ni | 62 | 443.683 | 4.6 | 143.669 | 0.48428 | 0.040 | 8.3 | ug/L |
| Cu | 63 | 1504.151 | 1.4 | 212.338 | 0.13718 | 0.004 | 2.6 | ug/L |
| Cu | 65 | 764.376 | 2.3 | 189.671 | 0.12521 | 0.002 | 1.9 | ug/L |
| Zn | 66 | 103431.658 | 0.9 | 1515.486 | 38.31502 | 0.702 | 1.8 | ug/L |
| Zn | 67 | 15570.690 | 1.2 | 342.344 | 32.94949 | 0.380 | 1.2 | ug/L |
| Zn | 68 | 74731.139 | 2.5 | 1170.427 | 37.64379 | 0.683 | 1.8 | ug/L |
| > Ge | 72 | 253408.660 | 1.0 | 244883.968 | | | | ug/L |
| As | 75 | 258.007 | 1.3 | 124.002 | 0.03937 | 0.000 | 0.8 | ug/L |
| Se | 77 | 227.870 | 4.7 | 216.736 | 0.01486 | 0.051 | 340.8 | ug/L |
| Se | 78 | 15940.485 | 1.2 | 16119.238 | -0.92466 | 0.103 | 11.2 | mg/L |
| Se | 82 | 1764.053 | 2.1 | 1872.010 | -0.52406 | 0.144 | 27.5 | ug/L |
| Kr | 83 | 1751.202 | 3.9 | 1902.236 | | | | mg/L |
| Y | 89 | 411978.442 | 0.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 434.349 | 7.8 | 112.002 | 0.05857 | 0.006 | 10.1 | ug/L |
| Mo | 97 | 272.007 | 2.9 | 64.001 | 0.06219 | 0.002 | 3.6 | ug/L |
| Mo | 98 | 605.082 | 4.9 | 98.282 | 0.06017 | 0.003 | 4.9 | ug/L |
| Rh | 103 | 339899.214 | 1.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 82.001 | 15.0 | 91.335 | -0.00079 | 0.001 | 120.6 | ug/L |
| Ag | 109 | 58.001 | 3.4 | 75.668 | -0.00149 | 0.000 | 11.7 | ug/L |
| Cd | 111 | 253.153 | 2.2 | 218.275 | 0.01026 | 0.002 | 22.1 | ug/L |
| Cd | 114 | 118.102 | 4.9 | 58.957 | 0.00850 | 0.001 | 9.9 | ug/L |
| > In | 115 | 363791.190 | 0.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 332.677 | 7.0 | 107.668 | 0.02362 | 0.003 | 11.0 | ug/L |
| Sb | 123 | 236.221 | 5.6 | 79.665 | 0.02134 | 0.002 | 8.9 | ug/L |
| Ba | 135 | 5722.022 | 2.1 | 46.667 | 2.28818 | 0.067 | 2.9 | ug/L |
| Ba | 137 | 9770.824 | 2.0 | 47.001 | 2.29692 | 0.046 | 2.0 | ug/L |
| > Tb | 159 | 412128.272 | 0.9 | 411268.087 | | | | ug/L |
| > Ho | 165 | 391456.462 | 0.8 | 390096.908 | | | | ug/L |
| Tl | 203 | 102.668 | 6.9 | 60.001 | 0.00534 | 0.001 | 18.4 | ug/L |
| Tl | 205 | 179.004 | 3.9 | 78.001 | 0.00573 | 0.000 | 8.3 | ug/L |
| Pb | 208 | 1143.375 | 1.2 | 320.672 | 0.03243 | 0.000 | 1.1 | ug/L |

Sample ID: 950474 D.10

Report Date/Time: Monday, November 13, 2006 18:20:49

Page 1

261

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 293.675 | 1.2 | 87.335 | 0.03092 | 0.001 | 1.8 ug/L |
| | Pb | 207 | 251.006 | 6.3 | 77.001 | 0.03120 | 0.003 | 8.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 102.393 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 103.481 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 101.518 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.209 | | | |
| > Ho | 165 | | 100.349 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950475 D.10

Sample Date/Time: Monday, November 13, 2006 18:23:45

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950475 D.10.048

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 52.667 | 10.5 | 63.001 | -0.00862 | 0.005 | 56.4 | ug/L |
| Al | 27 | 78291.825 | 3.6 | 2334.350 | 11.19139 | 0.435 | 3.9 | ug/L |
| > Sc | 45 | 377618.573 | 0.2 | 381869.082 | | | | ug/L |
| V | 51 | 5406.744 | 3.3 | 4488.603 | 0.05969 | 0.011 | 18.7 | ug/L |
| Cr | 52 | 17656.538 | 2.8 | 15368.650 | 0.17363 | 0.033 | 19.2 | ug/L |
| Cr | 53 | 924.061 | 4.1 | 814.381 | 0.06659 | 0.021 | 30.9 | ug/L |
| Mn | 55 | 799543.466 | 1.1 | 494.020 | 38.82888 | 0.849 | 2.2 | ug/L |
| Co | 59 | 2347.688 | 3.3 | 188.671 | 0.12026 | 0.007 | 5.4 | ug/L |
| Ni | 60 | 4754.071 | 3.0 | 136.669 | 1.14686 | 0.053 | 4.6 | ug/L |
| Ni | 62 | 630.364 | 4.2 | 143.669 | 0.80821 | 0.034 | 4.2 | ug/L |
| Cu | 63 | 22451.774 | 2.4 | 212.338 | 2.41711 | 0.099 | 4.1 | ug/L |
| Cu | 65 | 11269.062 | 1.6 | 189.671 | 2.48504 | 0.083 | 3.3 | ug/L |
| Zn | 66 | 190870.105 | 2.8 | 1515.486 | 72.45529 | 1.835 | 2.5 | ug/L |
| Zn | 67 | 28646.121 | 2.3 | 342.344 | 62.36653 | 2.198 | 3.5 | ug/L |
| Zn | 68 | 136950.184 | 0.4 | 1170.427 | 70.74592 | 1.200 | 1.7 | ug/L |
| > Ge | 72 | 249051.911 | 1.6 | 244883.968 | | | | ug/L |
| As | 75 | 572.692 | 1.6 | 124.002 | 0.13796 | 0.002 | 1.7 | ug/L |
| Se | 77 | 252.270 | 5.4 | 216.736 | 0.13260 | 0.074 | 55.7 | ug/L |
| Se | 78 | 16075.663 | 1.4 | 16119.238 | -0.39977 | 0.496 | 123.9 | mg/L |
| Se | 82 | 1818.932 | 0.9 | 1872.010 | -0.26129 | 0.072 | 27.6 | ug/L |
| Kr | 83 | 1775.874 | 3.5 | 1902.236 | | | | mg/L |
| Y | 89 | 415229.404 | 1.4 | 408188.389 | | | | ug/L |
| Mo | 95 | 921.727 | 2.5 | 112.002 | 0.15051 | 0.005 | 3.2 | ug/L |
| Mo | 97 | 589.027 | 4.2 | 64.001 | 0.16045 | 0.008 | 4.8 | ug/L |
| Mo | 98 | 1375.031 | 1.6 | 98.282 | 0.15470 | 0.002 | 1.5 | ug/L |
| Rh | 103 | 340761.216 | 0.3 | 340052.119 | | | | ug/L |
| Ag | 107 | 87.335 | 0.7 | 91.335 | -0.00029 | 0.000 | 20.1 | ug/L |
| Ag | 109 | 71.001 | 6.1 | 75.668 | -0.00036 | 0.000 | 90.6 | ug/L |
| Cd | 111 | 286.828 | 3.6 | 218.275 | 0.02280 | 0.004 | 16.7 | ug/L |
| Cd | 114 | 223.027 | 3.0 | 58.957 | 0.02437 | 0.001 | 4.0 | ug/L |
| > In | 115 | 357679.456 | 0.5 | 358352.924 | | | | ug/L |
| Sb | 121 | 5620.284 | 1.6 | 107.668 | 0.59263 | 0.007 | 1.2 | ug/L |
| Sb | 123 | 4161.970 | 0.2 | 79.665 | 0.57024 | 0.002 | 0.3 | ug/L |
| Ba | 135 | 12304.535 | 1.3 | 46.667 | 4.93788 | 0.050 | 1.0 | ug/L |
| Ba | 137 | 21295.059 | 1.8 | 47.001 | 5.01598 | 0.118 | 2.3 | ug/L |
| > Tb | 159 | 412481.561 | 2.3 | 411268.087 | | | | ug/L |
| > Ho | 165 | 383764.260 | 1.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 219.672 | 11.2 | 60.001 | 0.02057 | 0.003 | 14.8 | ug/L |
| Tl | 205 | 457.684 | 7.9 | 78.001 | 0.02207 | 0.002 | 8.4 | ug/L |
| Pb | 208 | 6095.605 | 2.7 | 320.672 | 0.23271 | 0.006 | 2.4 | ug/L |

Sample ID: 950475 D.10

Report Date/Time: Monday, November 13, 2006 18:26:47

Page 1

264

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 1544.825 | 4.3 | 87.335 | 0.22325 | 0.008 | 3.5 ug/L |
| | Pb | 207 | 1310.116 | 4.4 | 77.001 | 0.22627 | 0.012 | 5.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 98.887 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 101.702 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 99.812 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.295 | | | |
| > Ho | 165 | | 98.377 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950476 D.10

Sample Date/Time: Monday, November 13, 2006 18:29:43

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950476 D.10.049

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 61.001 | 17.1 | 63.001 | -0.00031 | 0.010 | 3297.8 | ug/L |
| Al | 27 | 39510.217 | 2.8 | 2334.350 | 5.56041 | 0.156 | 2.8 | ug/L |
| > Sc | 45 | 372434.923 | 1.4 | 381869.082 | | | | ug/L |
| V | 51 | 5124.638 | 2.6 | 4488.603 | 0.04668 | 0.007 | 14.5 | ug/L |
| Cr | 52 | 17091.017 | 2.0 | 15368.650 | 0.15081 | 0.037 | 24.2 | ug/L |
| Cr | 53 | 883.722 | 4.4 | 814.381 | 0.05099 | 0.024 | 48.0 | ug/L |
| Mn | 55 | 772710.421 | 1.0 | 494.020 | 37.60824 | 0.286 | 0.8 | ug/L |
| Co | 59 | 2431.046 | 2.0 | 188.671 | 0.12516 | 0.002 | 2.0 | ug/L |
| Ni | 60 | 4503.597 | 4.9 | 136.669 | 1.08677 | 0.053 | 4.9 | ug/L |
| Ni | 62 | 613.029 | 0.9 | 143.669 | 0.78195 | 0.009 | 1.1 | ug/L |
| Cu | 63 | 17367.923 | 1.6 | 212.338 | 1.86821 | 0.026 | 1.4 | ug/L |
| Cu | 65 | 8465.049 | 1.8 | 189.671 | 1.85985 | 0.031 | 1.7 | ug/L |
| Zn | 66 | 181593.289 | 2.1 | 1515.486 | 69.07117 | 1.468 | 2.1 | ug/L |
| Zn | 67 | 28799.991 | 2.6 | 342.344 | 62.83774 | 1.518 | 2.4 | ug/L |
| Zn | 68 | 134744.653 | 2.2 | 1170.427 | 69.75533 | 1.563 | 2.2 | ug/L |
| > Ge | 72 | 248445.926 | 0.3 | 244883.968 | | | | ug/L |
| As | 75 | 538.689 | 5.4 | 124.002 | 0.12786 | 0.009 | 7.1 | ug/L |
| Se | 77 | 253.271 | 6.1 | 216.736 | 0.13857 | 0.066 | 47.8 | ug/L |
| Se | 78 | 16064.183 | 0.4 | 16119.238 | -0.36901 | 0.038 | 10.4 | mg/L |
| Se | 82 | 1817.798 | 0.3 | 1872.010 | -0.25172 | 0.030 | 12.1 | ug/L |
| Kr | 83 | 1790.877 | 2.9 | 1902.236 | | | | mg/L |
| Y | 89 | 403636.052 | 1.4 | 408188.389 | | | | ug/L |
| Mo | 95 | 865.054 | 2.1 | 112.002 | 0.13688 | 0.002 | 1.4 | ug/L |
| Mo | 97 | 531.689 | 4.3 | 64.001 | 0.13998 | 0.011 | 7.8 | ug/L |
| Mo | 98 | 1198.674 | 0.9 | 98.282 | 0.13061 | 0.005 | 3.8 | ug/L |
| Rh | 103 | 331391.230 | 1.2 | 340052.119 | | | | ug/L |
| Ag | 107 | 80.335 | 5.2 | 91.335 | -0.00094 | 0.000 | 14.0 | ug/L |
| Ag | 109 | 58.667 | 6.5 | 75.668 | -0.00144 | 0.000 | 26.5 | ug/L |
| Cd | 111 | 269.676 | 4.9 | 218.275 | 0.01536 | 0.002 | 10.3 | ug/L |
| Cd | 114 | 176.569 | 20.9 | 58.957 | 0.01688 | 0.005 | 27.3 | ug/L |
| > In | 115 | 364775.544 | 3.1 | 358352.924 | | | | ug/L |
| Sb | 121 | 3292.017 | 2.5 | 107.668 | 0.33556 | 0.008 | 2.3 | ug/L |
| Sb | 123 | 2561.896 | 1.3 | 79.665 | 0.33998 | 0.011 | 3.2 | ug/L |
| Ba | 135 | 12256.129 | 1.1 | 46.667 | 5.05644 | 0.121 | 2.4 | ug/L |
| Ba | 137 | 20988.609 | 0.8 | 47.001 | 5.08111 | 0.072 | 1.4 | ug/L |
| > Tb | 159 | 401300.317 | 1.7 | 411268.087 | | | | ug/L |
| > Ho | 165 | 391619.063 | 1.8 | 390096.908 | | | | ug/L |
| Tl | 203 | 243.006 | 6.5 | 60.001 | 0.02297 | 0.003 | 11.1 | ug/L |
| Tl | 205 | 453.017 | 1.2 | 78.001 | 0.02129 | 0.001 | 2.5 | ug/L |
| Pb | 208 | 4157.780 | 1.4 | 320.672 | 0.15135 | 0.001 | 0.6 | ug/L |

Sample ID: 950476 D.10

Report Date/Time: Monday, November 13, 2006 18:32:45

Page 1

267

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 1072.746 | 1.0 | 87.335 | 0.14777 | 0.002 | 1.4 ug/L |
| | Pb | 207 | 897.057 | 0.7 | 77.001 | 0.14724 | 0.002 | 1.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 97.529 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 101.455 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 101.792 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.576 | | | |
| > Ho | 165 | | 100.390 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477 D.10

Sample Date/Time: Monday, November 13, 2006 18:35:41

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950477 D.10.050

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 50.667 | 18.3 | 63.001 | -0.01113 | 0.007 | 65.6 | ug/L |
| Al | 27 | 23318.481 | 0.9 | 2334.350 | 3.04870 | 0.107 | 3.5 | ug/L |
| > Sc | 45 | 382889.096 | 2.2 | 381869.082 | | | | ug/L |
| V | 51 | 5012.408 | 1.2 | 4488.603 | 0.03124 | 0.009 | 29.4 | ug/L |
| Cr | 52 | 16907.304 | 0.8 | 15368.650 | 0.10459 | 0.020 | 19.4 | ug/L |
| Cr | 53 | 895.724 | 1.4 | 814.381 | 0.04389 | 0.008 | 18.3 | ug/L |
| Mn | 55 | 583269.048 | 1.2 | 494.020 | 27.72082 | 0.579 | 2.1 | ug/L |
| Co | 59 | 1219.768 | 2.1 | 188.671 | 0.05587 | 0.001 | 1.8 | ug/L |
| Ni | 60 | 3306.023 | 4.7 | 136.669 | 0.76940 | 0.038 | 5.0 | ug/L |
| Ni | 62 | 424.015 | 5.3 | 143.669 | 0.44931 | 0.043 | 9.7 | ug/L |
| Cu | 63 | 1165.427 | 2.4 | 212.338 | 0.10051 | 0.003 | 3.2 | ug/L |
| Cu | 65 | 631.364 | 5.4 | 189.671 | 0.09532 | 0.006 | 6.4 | ug/L |
| Zn | 66 | 161373.996 | 1.5 | 1515.486 | 59.87328 | 1.376 | 2.3 | ug/L |
| Zn | 67 | 24542.007 | 2.0 | 342.344 | 52.17118 | 1.247 | 2.4 | ug/L |
| Zn | 68 | 111816.705 | 1.3 | 1170.427 | 56.41761 | 1.037 | 1.8 | ug/L |
| > Ge | 72 | 254403.646 | 1.0 | 244883.968 | | | | ug/L |
| As | 75 | 884.723 | 8.5 | 124.002 | 0.22847 | 0.020 | 8.8 | ug/L |
| Se | 77 | 230.537 | 4.5 | 216.736 | 0.02198 | 0.047 | 213.5 | ug/L |
| Se | 78 | 16031.842 | 0.7 | 16119.238 | -0.88823 | 0.094 | 10.6 | mg/L |
| Se | 82 | 1794.126 | 1.5 | 1872.010 | -0.45489 | 0.056 | 12.3 | ug/L |
| Kr | 83 | 1756.203 | 1.4 | 1902.236 | | | | mg/L |
| Y | 89 | 411213.948 | 0.4 | 408188.389 | | | | ug/L |
| Mo | 95 | 959.065 | 3.8 | 112.002 | 0.15235 | 0.006 | 4.2 | ug/L |
| Mo | 97 | 586.026 | 1.9 | 64.001 | 0.15446 | 0.005 | 3.5 | ug/L |
| Mo | 98 | 1406.523 | 3.2 | 98.282 | 0.15368 | 0.006 | 4.1 | ug/L |
| Rh | 103 | 331783.362 | 1.5 | 340052.119 | | | | ug/L |
| Ag | 107 | 71.001 | 12.7 | 91.335 | -0.00168 | 0.001 | 35.0 | ug/L |
| Ag | 109 | 47.667 | 5.3 | 75.668 | -0.00235 | 0.000 | 9.2 | ug/L |
| Cd | 111 | 265.159 | 1.3 | 218.275 | 0.01314 | 0.002 | 16.7 | ug/L |
| Cd | 114 | 145.873 | 8.8 | 58.957 | 0.01232 | 0.002 | 18.0 | ug/L |
| > In | 115 | 368219.930 | 1.9 | 358352.924 | | | | ug/L |
| Sb | 121 | 219.005 | 5.7 | 107.668 | 0.01131 | 0.001 | 8.8 | ug/L |
| Sb | 123 | 152.939 | 8.9 | 79.665 | 0.00964 | 0.002 | 18.8 | ug/L |
| Ba | 135 | 15239.408 | 0.7 | 46.667 | 6.35787 | 0.050 | 0.8 | ug/L |
| Ba | 137 | 25127.419 | 1.9 | 47.001 | 6.14964 | 0.110 | 1.8 | ug/L |
| > Tb | 159 | 397057.893 | 0.9 | 411268.087 | | | | ug/L |
| > Ho | 165 | 400424.717 | 0.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 144.669 | 6.9 | 60.001 | 0.01020 | 0.001 | 12.3 | ug/L |
| Tl | 205 | 287.008 | 3.6 | 78.001 | 0.01149 | 0.001 | 5.2 | ug/L |
| Pb | 208 | 2056.786 | 3.9 | 320.672 | 0.06666 | 0.003 | 4.2 | ug/L |

Sample ID: 950477 D.10

Report Date/Time: Monday, November 13, 2006 18:38:43

Page 1

270

| | | | | | | | | |
|---|----|-----|---------|-----|--------|---------|-------|-----------|
| | Pb | 206 | 547.024 | 9.7 | 87.335 | 0.06708 | 0.008 | 11.3 ug/L |
| L | Pb | 207 | 431.349 | 5.4 | 77.001 | 0.06188 | 0.004 | 6.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 100.267 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 103.887 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.753 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 96.545 | | | |
| > Ho | 165 | | 102.647 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477D D.10

Sample Date/Time: Monday, November 13, 2006 18:41:39

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950477D D.10.051

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 51.667 | 9.1 | 63.001 | -0.01063 | 0.004 | 36.1 | ug/L |
| Al | 27 | 20729.961 | 1.1 | 2334.350 | 2.64026 | 0.076 | 2.9 | ug/L |
| > Sc | 45 | 386955.293 | 1.5 | 381869.082 | | | | ug/L |
| V | 51 | 5163.149 | 2.1 | 4488.603 | 0.03698 | 0.004 | 10.3 | ug/L |
| Cr | 52 | 17284.079 | 0.5 | 15368.650 | 0.11812 | 0.022 | 18.6 | ug/L |
| Cr | 53 | 876.722 | 8.3 | 814.381 | 0.02828 | 0.040 | 143.2 | ug/L |
| Mn | 55 | 598687.512 | 2.2 | 494.020 | 28.17508 | 0.529 | 1.9 | ug/L |
| Co | 59 | 1203.099 | 4.9 | 188.671 | 0.05434 | 0.003 | 6.2 | ug/L |
| Ni | 60 | 3374.050 | 3.1 | 136.669 | 0.77808 | 0.028 | 3.7 | ug/L |
| Ni | 62 | 462.017 | 7.8 | 143.669 | 0.50402 | 0.062 | 12.2 | ug/L |
| Cu | 63 | 1454.142 | 4.2 | 212.338 | 0.12973 | 0.007 | 5.1 | ug/L |
| Cu | 65 | 829.383 | 3.4 | 189.671 | 0.13706 | 0.005 | 3.8 | ug/L |
| Zn | 66 | 134220.994 | 0.8 | 1515.486 | 49.21030 | 0.628 | 1.3 | ug/L |
| Zn | 67 | 20300.569 | 1.3 | 342.344 | 42.59936 | 0.806 | 1.9 | ug/L |
| Zn | 68 | 94975.118 | 0.8 | 1170.427 | 47.35506 | 0.169 | 0.4 | ug/L |
| > Ge | 72 | 256880.092 | 0.6 | 244883.968 | | | | ug/L |
| As | 75 | 881.722 | 6.7 | 124.002 | 0.22512 | 0.018 | 7.9 | ug/L |
| Se | 77 | 232.203 | 4.4 | 216.736 | 0.01935 | 0.036 | 188.6 | ug/L |
| Se | 78 | 16043.622 | 0.5 | 16119.238 | -1.06642 | 0.063 | 6.0 | mg/L |
| Se | 82 | 1801.128 | 0.8 | 1872.010 | -0.48585 | 0.075 | 15.5 | ug/L |
| Kr | 83 | 1753.202 | 1.3 | 1902.236 | | | | mg/L |
| Y | 89 | 416038.841 | 1.5 | 408188.389 | | | | ug/L |
| Mo | 95 | 898.391 | 2.1 | 112.002 | 0.14245 | 0.008 | 5.7 | ug/L |
| Mo | 97 | 567.025 | 4.4 | 64.001 | 0.14982 | 0.009 | 6.3 | ug/L |
| Mo | 98 | 1403.004 | 2.0 | 98.282 | 0.15419 | 0.003 | 1.8 | ug/L |
| Rh | 103 | 336302.258 | 2.3 | 340052.119 | | | | ug/L |
| Ag | 107 | 57.667 | 5.3 | 91.335 | -0.00262 | 0.000 | 13.2 | ug/L |
| Ag | 109 | 52.667 | 11.6 | 75.668 | -0.00192 | 0.001 | 31.0 | ug/L |
| Cd | 111 | 270.593 | 5.2 | 218.275 | 0.01546 | 0.006 | 41.8 | ug/L |
| Cd | 114 | 198.075 | 8.7 | 58.957 | 0.01996 | 0.002 | 9.2 | ug/L |
| > In | 115 | 366162.869 | 3.0 | 358352.924 | | | | ug/L |
| Sb | 121 | 196.004 | 8.4 | 107.668 | 0.00904 | 0.002 | 19.3 | ug/L |
| Sb | 123 | 142.023 | 6.1 | 79.665 | 0.00827 | 0.001 | 11.7 | ug/L |
| Ba | 135 | 15522.270 | 2.3 | 46.667 | 6.25833 | 0.142 | 2.3 | ug/L |
| Ba | 137 | 25926.531 | 1.1 | 47.001 | 6.13237 | 0.066 | 1.1 | ug/L |
| > Tb | 159 | 410829.306 | 0.3 | 411268.087 | | | | ug/L |
| > Ho | 165 | 395045.428 | 2.2 | 390096.908 | | | | ug/L |
| Tl | 203 | 128.002 | 16.1 | 60.001 | 0.00839 | 0.003 | 33.5 | ug/L |
| Tl | 205 | 253.673 | 4.8 | 78.001 | 0.00984 | 0.001 | 6.8 | ug/L |
| Pb | 208 | 2215.805 | 1.6 | 320.672 | 0.07398 | 0.002 | 2.4 | ug/L |

Sample ID: 950477D D.10

Report Date/Time: Monday, November 13, 2006 18:44:41

Page 1

273

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 566.692 | 3.2 | 87.335 | 0.07117 | 0.005 | 6.3 ug/L |
| | Pb | 207 | 473.018 | 2.4 | 77.001 | 0.07033 | 0.001 | 1.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 101.332 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 104.899 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.179 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.893 | | | |
| > Ho | 165 | | 101.269 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477S D.10

Sample Date/Time: Monday, November 13, 2006 18:47:37

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950477S D.10.052

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 2600.098 | 0.9 | 63.001 | 2.27137 | 0.024 | 1.1 | ug/L |
| Al | 27 | 35389.736 | 3.5 | 2334.350 | 4.88007 | 0.273 | 5.6 | ug/L |
| > Sc | 45 | 377291.101 | 1.9 | 381869.082 | | | | ug/L |
| V | 51 | 45158.834 | 0.5 | 4488.603 | 2.51347 | 0.065 | 2.6 | ug/L |
| Cr | 52 | 50062.504 | 2.8 | 15368.650 | 2.46701 | 0.153 | 6.2 | ug/L |
| Cr | 53 | 4893.819 | 0.6 | 814.381 | 2.29683 | 0.061 | 2.6 | ug/L |
| Mn | 55 | 625249.459 | 2.4 | 494.020 | 29.92967 | 0.653 | 2.2 | ug/L |
| Co | 59 | 43428.309 | 1.1 | 188.671 | 2.37686 | 0.028 | 1.2 | ug/L |
| Ni | 60 | 12457.433 | 2.6 | 136.669 | 3.01746 | 0.115 | 3.8 | ug/L |
| Ni | 62 | 1717.194 | 1.6 | 143.669 | 2.58269 | 0.025 | 0.9 | ug/L |
| Cu | 63 | 23439.834 | 2.5 | 212.338 | 2.48763 | 0.037 | 1.5 | ug/L |
| Cu | 65 | 11248.366 | 0.9 | 189.671 | 2.44472 | 0.052 | 2.1 | ug/L |
| Zn | 66 | 140327.216 | 1.6 | 1515.486 | 52.36371 | 0.822 | 1.6 | ug/L |
| Zn | 67 | 21871.224 | 2.2 | 342.344 | 46.74484 | 0.571 | 1.2 | ug/L |
| Zn | 68 | 100579.058 | 1.3 | 1170.427 | 51.06162 | 1.231 | 2.4 | ug/L |
| > Ge | 72 | 252578.551 | 1.4 | 244883.968 | | | | ug/L |
| As | 75 | 8313.562 | 0.9 | 124.002 | 2.49365 | 0.042 | 1.7 | ug/L |
| Se | 77 | 752.834 | 3.6 | 216.736 | 2.15979 | 0.097 | 4.5 | ug/L |
| Se | 78 | 17718.034 | 0.2 | 16119.238 | 1.37250 | 0.346 | 25.2 | mg/L |
| Se | 82 | 2503.309 | 0.6 | 1872.010 | 1.74194 | 0.125 | 7.2 | ug/L |
| Kr | 83 | 1775.207 | 3.5 | 1902.236 | | | | mg/L |
| Y | 89 | 406625.703 | 1.5 | 408188.389 | | | | ug/L |
| Mo | 95 | 13795.882 | 1.1 | 112.002 | 2.45331 | 0.024 | 1.0 | ug/L |
| Mo | 97 | 8314.896 | 1.1 | 64.001 | 2.43236 | 0.027 | 1.1 | ug/L |
| Mo | 98 | 21281.055 | 2.5 | 98.282 | 2.47654 | 0.072 | 2.9 | ug/L |
| Rh | 103 | 329825.845 | 3.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 30906.189 | 1.5 | 91.335 | 2.24405 | 0.009 | 0.4 | ug/L |
| Ag | 109 | 29123.429 | 1.0 | 75.668 | 2.25146 | 0.029 | 1.3 | ug/L |
| Cd | 111 | 7330.758 | 1.4 | 218.275 | 2.26569 | 0.032 | 1.4 | ug/L |
| Cd | 114 | 16084.787 | 2.2 | 58.957 | 2.29568 | 0.074 | 3.2 | ug/L |
| > In | 115 | 370648.693 | 1.9 | 358352.924 | | | | ug/L |
| Sb | 121 | 22565.072 | 1.3 | 107.668 | 2.32980 | 0.041 | 1.7 | ug/L |
| Sb | 123 | 17575.004 | 3.0 | 79.665 | 2.35762 | 0.034 | 1.5 | ug/L |
| Ba | 135 | 20673.486 | 0.8 | 46.667 | 8.42296 | 0.042 | 0.5 | ug/L |
| Ba | 137 | 35010.742 | 0.6 | 47.001 | 8.36632 | 0.105 | 1.3 | ug/L |
| > Tb | 159 | 406866.550 | 0.9 | 411268.087 | | | | ug/L |
| > Ho | 165 | 392030.833 | 1.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 18829.775 | 1.7 | 60.001 | 2.35330 | 0.055 | 2.3 | ug/L |
| Tl | 205 | 43707.099 | 1.2 | 78.001 | 2.47522 | 0.019 | 0.8 | ug/L |
| Pb | 208 | 62951.507 | 1.0 | 320.672 | 2.46865 | 0.041 | 1.7 | ug/L |

Sample ID: 950477S D.10

Report Date/Time: Monday, November 13, 2006 18:50:39

Page 1

276

| | | | | | | | | |
|--|----|-----|-----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 16184.532 | 1.5 | 87.335 | 2.41185 | 0.027 | 1.1 ug/L |
| | Pb | 207 | 13370.521 | 2.1 | 77.001 | 2.38531 | 0.075 | 3.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 98.801 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 103.142 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 103.431 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.930 | | | |
| > [Ho | 165 | | 100.496 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477A D.10

Sample Date/Time: Monday, November 13, 2006 18:53:36

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950477A D.10.053

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 22896.310 | 1.3 | 63.001 | 20.33737 | 0.487 | 2.4 | ug/L |
| Al | 27 | 185066.496 | 2.1 | 2334.350 | 26.81309 | 0.822 | 3.1 | ug/L |
| > Sc | 45 | 379290.622 | 3.6 | 381869.082 | | | | ug/L |
| V | 51 | 360353.825 | 2.8 | 4488.603 | 21.84905 | 0.375 | 1.7 | ug/L |
| Cr | 52 | 326516.342 | 1.5 | 15368.650 | 21.90196 | 0.775 | 3.5 | ug/L |
| Cr | 53 | 37851.515 | 2.4 | 814.381 | 20.69814 | 0.458 | 2.2 | ug/L |
| Mn | 55 | 1020822.990 | 1.1 | 494.020 | 49.35609 | 1.250 | 2.5 | ug/L |
| Co | 59 | 367784.056 | 3.1 | 188.671 | 20.39519 | 0.138 | 0.7 | ug/L |
| Ni | 60 | 84148.696 | 2.2 | 136.669 | 20.77801 | 0.752 | 3.6 | ug/L |
| Ni | 62 | 12806.964 | 2.0 | 143.669 | 21.03884 | 0.425 | 2.0 | ug/L |
| Cu | 63 | 194445.838 | 3.6 | 212.338 | 21.00055 | 0.217 | 1.0 | ug/L |
| Cu | 65 | 94755.631 | 0.7 | 189.671 | 21.11874 | 0.654 | 3.1 | ug/L |
| Zn | 66 | 191120.135 | 2.4 | 1515.486 | 72.22176 | 2.032 | 2.8 | ug/L |
| Zn | 67 | 29899.843 | 0.5 | 342.344 | 64.84266 | 2.510 | 3.9 | ug/L |
| Zn | 68 | 137383.991 | 1.1 | 1170.427 | 70.68216 | 3.224 | 4.6 | ug/L |
| > Ge | 72 | 250293.568 | 3.7 | 244883.968 | | | | ug/L |
| As | 75 | 65149.681 | 1.1 | 124.002 | 20.00093 | 0.610 | 3.1 | ug/L |
| Se | 77 | 4983.023 | 0.9 | 216.736 | 19.62576 | 0.771 | 3.9 | ug/L |
| Se | 78 | 31024.563 | 1.2 | 16119.238 | 18.43826 | 1.396 | 7.6 | mg/L |
| Se | 82 | 8085.121 | 1.1 | 1872.010 | 18.96529 | 1.075 | 5.7 | ug/L |
| Kr | 83 | 1748.534 | 2.2 | 1902.236 | | | | mg/L |
| Y | 89 | 412962.694 | 1.3 | 408188.389 | | | | ug/L |
| Mo | 95 | 113960.402 | 0.4 | 112.002 | 21.33702 | 0.124 | 0.6 | ug/L |
| Mo | 97 | 71576.809 | 0.9 | 64.001 | 22.03708 | 0.123 | 0.6 | ug/L |
| Mo | 98 | 182324.780 | 1.4 | 98.282 | 22.26499 | 0.099 | 0.4 | ug/L |
| Rh | 103 | 333709.814 | 1.5 | 340052.119 | | | | ug/L |
| Ag | 107 | 281931.764 | 0.8 | 91.335 | 21.45266 | 0.153 | 0.7 | ug/L |
| Ag | 109 | 268482.405 | 1.9 | 75.668 | 21.74117 | 0.318 | 1.5 | ug/L |
| Cd | 111 | 62730.095 | 0.8 | 218.275 | 20.83446 | 0.370 | 1.8 | ug/L |
| Cd | 114 | 144720.291 | 3.1 | 58.957 | 21.65240 | 0.551 | 2.5 | ug/L |
| > In | 115 | 354643.765 | 1.0 | 358352.924 | | | | ug/L |
| Sb | 121 | 203072.665 | 0.9 | 107.668 | 22.00672 | 0.046 | 0.2 | ug/L |
| Sb | 123 | 150148.829 | 0.9 | 79.665 | 21.14132 | 0.069 | 0.3 | ug/L |
| Ba | 135 | 66156.241 | 1.1 | 46.667 | 26.75067 | 0.230 | 0.9 | ug/L |
| Ba | 137 | 108914.258 | 1.1 | 47.001 | 25.81201 | 0.095 | 0.4 | ug/L |
| > Tb | 159 | 410582.175 | 0.8 | 411268.087 | | | | ug/L |
| > Ho | 165 | 390551.543 | 1.2 | 390096.908 | | | | ug/L |
| Tl | 203 | 163140.078 | 2.0 | 60.001 | 20.52636 | 0.636 | 3.1 | ug/L |
| Tl | 205 | 392324.360 | 0.5 | 78.001 | 22.33983 | 0.348 | 1.6 | ug/L |
| Pb | 208 | 537479.255 | 0.4 | 320.672 | 21.25211 | 0.166 | 0.8 | ug/L |

Sample ID: 950477A D.10

Report Date/Time: Monday, November 13, 2006 18:56:37

Page 1

279

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 137323.332 | 1.1 | 87.335 | 20.64028 | 0.066 | 0.3 ug/L |
| | Pb | 207 | 113275.018 | 2.1 | 77.001 | 20.38893 | 0.633 | 3.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 99.325 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 102.209 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.965 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.833 | | | |
| > Ho | 165 | | 100.117 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477L D.10

Sample Date/Time: Monday, November 13, 2006 18:59:34

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950477L D.10.054

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 61.001 | 16.1 | 63.001 | -0.00076 | 0.010 | 1291.6 | ug/L |
| Al | 27 | 24025.520 | 3.6 | 2334.350 | 3.21987 | 0.167 | 5.2 | ug/L |
| > Sc | 45 | 375499.541 | 1.6 | 381869.082 | | | | ug/L |
| V | 51 | 4958.869 | 3.9 | 4488.603 | 0.03397 | 0.017 | 49.6 | ug/L |
| Cr | 52 | 16250.348 | 4.7 | 15368.650 | 0.08145 | 0.069 | 85.1 | ug/L |
| Cr | 53 | 754.708 | 3.3 | 814.381 | -0.02589 | 0.017 | 65.9 | ug/L |
| Mn | 55 | 122818.012 | 0.6 | 494.020 | 5.96534 | 0.035 | 0.6 | ug/L |
| Co | 59 | 378.679 | 6.3 | 188.671 | 0.01050 | 0.002 | 14.5 | ug/L |
| Ni | 60 | 862.053 | 5.2 | 136.669 | 0.18044 | 0.012 | 6.6 | ug/L |
| Ni | 62 | 199.004 | 4.5 | 143.669 | 0.08946 | 0.011 | 12.2 | ug/L |
| Cu | 63 | 515.688 | 1.0 | 212.338 | 0.03279 | 0.001 | 2.9 | ug/L |
| Cu | 65 | 368.679 | 6.7 | 189.671 | 0.03979 | 0.007 | 16.4 | ug/L |
| Zn | 66 | 153354.469 | 1.0 | 1515.486 | 58.32087 | 0.817 | 1.4 | ug/L |
| Zn | 67 | 22842.164 | 1.7 | 342.344 | 49.75934 | 1.421 | 2.9 | ug/L |
| Zn | 68 | 110885.521 | 2.2 | 1170.427 | 57.38281 | 1.804 | 3.1 | ug/L |
| > Ge | 72 | 248118.019 | 1.2 | 244883.968 | | | | ug/L |
| As | 75 | 283.341 | 3.6 | 124.002 | 0.04892 | 0.004 | 8.0 | ug/L |
| Se | 77 | 216.469 | 1.2 | 216.736 | -0.01288 | 0.018 | 137.2 | ug/L |
| Se | 78 | 15711.854 | 1.7 | 16119.238 | -0.78696 | 0.581 | 73.8 | mg/L |
| Se | 82 | 1757.119 | 1.0 | 1872.010 | -0.43193 | 0.057 | 13.2 | ug/L |
| Kr | 83 | 1779.541 | 0.4 | 1902.236 | | | | mg/L |
| Y | 89 | 411776.163 | 2.0 | 408188.389 | | | | ug/L |
| Mo | 95 | 299.675 | 5.0 | 112.002 | 0.03429 | 0.003 | 9.5 | ug/L |
| Mo | 97 | 191.337 | 3.2 | 64.001 | 0.03829 | 0.002 | 6.3 | ug/L |
| Mo | 98 | 429.813 | 1.0 | 98.282 | 0.03959 | 0.001 | 2.3 | ug/L |
| Rh | 103 | 337977.523 | 0.9 | 340052.119 | | | | ug/L |
| Ag | 107 | 90.335 | 1.7 | 91.335 | -0.00014 | 0.000 | 129.5 | ug/L |
| Ag | 109 | 74.334 | 11.4 | 75.668 | -0.00017 | 0.001 | 384.5 | ug/L |
| Cd | 111 | 256.464 | 7.6 | 218.275 | 0.01183 | 0.007 | 60.3 | ug/L |
| Cd | 114 | 132.952 | 5.2 | 58.957 | 0.01077 | 0.001 | 9.4 | ug/L |
| > In | 115 | 361842.671 | 1.0 | 358352.924 | | | | ug/L |
| Sb | 121 | 498.353 | 11.9 | 107.668 | 0.04145 | 0.007 | 16.5 | ug/L |
| Sb | 123 | 382.567 | 9.3 | 79.665 | 0.04175 | 0.005 | 13.1 | ug/L |
| Ba | 135 | 3060.593 | 1.8 | 46.667 | 1.23488 | 0.012 | 1.0 | ug/L |
| Ba | 137 | 5097.276 | 1.7 | 47.001 | 1.21246 | 0.021 | 1.7 | ug/L |
| > Tb | 159 | 405553.065 | 0.9 | 411268.087 | | | | ug/L |
| > Ho | 165 | 389847.555 | 2.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 93.668 | 17.4 | 60.001 | 0.00424 | 0.002 | 46.8 | ug/L |
| Tl | 205 | 155.670 | 3.5 | 78.001 | 0.00444 | 0.000 | 8.6 | ug/L |
| Pb | 208 | 1440.730 | 3.3 | 320.672 | 0.04443 | 0.003 | 5.7 | ug/L |

Sample ID: 950477L D.10

Report Date/Time: Monday, November 13, 2006 19:02:36

Page 1

| | | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|------|------|
| | Pb | 206 | 363.678 | 5.6 | 87.335 | 0.04171 | 0.004 | 10.1 | ug/L |
| | Pb | 207 | 313.676 | 8.5 | 77.001 | 0.04273 | 0.005 | 12.0 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 98.332 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 101.321 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 100.974 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.610 | | | |
| > Ho | 165 | | 99.936 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 13, 2006 19:05:33

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 6.055

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55893.389 | 1.1 | 63.001 | 51.45804 | 0.217 | 0.4 | ug/L |
| Al | 27 | 347009.346 | 1.7 | 2334.350 | 52.34093 | 0.539 | 1.0 | ug/L |
| > Sc | 45 | 366341.922 | 1.3 | 381869.082 | | | | ug/L |
| V | 51 | 818876.681 | 2.5 | 4488.603 | 51.77688 | 1.930 | 3.7 | ug/L |
| Cr | 52 | 731795.682 | 1.7 | 15368.650 | 52.20846 | 1.292 | 2.5 | ug/L |
| Cr | 53 | 86091.975 | 3.5 | 814.381 | 49.33228 | 1.573 | 3.2 | ug/L |
| Mn | 55 | 1050489.263 | 1.6 | 494.020 | 51.95118 | 0.882 | 1.7 | ug/L |
| Co | 59 | 850468.188 | 3.9 | 188.671 | 48.26294 | 1.258 | 2.6 | ug/L |
| Ni | 60 | 193426.571 | 2.5 | 136.669 | 48.88355 | 0.366 | 0.7 | ug/L |
| Ni | 62 | 30111.949 | 1.7 | 143.669 | 50.94326 | 0.157 | 0.3 | ug/L |
| Cu | 63 | 459989.202 | 2.7 | 212.338 | 50.86462 | 0.445 | 0.9 | ug/L |
| Cu | 65 | 227607.730 | 1.9 | 189.671 | 51.93832 | 0.590 | 1.1 | ug/L |
| Zn | 66 | 137999.755 | 1.3 | 1515.486 | 53.18821 | 0.447 | 0.8 | ug/L |
| Zn | 67 | 23676.495 | 1.5 | 342.344 | 52.35429 | 0.574 | 1.1 | ug/L |
| Zn | 68 | 102922.527 | 1.9 | 1170.427 | 54.00026 | 1.684 | 3.1 | ug/L |
| > Ge | 72 | 244583.167 | 1.8 | 244883.968 | | | | ug/L |
| As | 75 | 153856.398 | 1.6 | 124.002 | 48.35872 | 0.122 | 0.3 | ug/L |
| Se | 77 | 12716.095 | 1.0 | 216.736 | 52.68315 | 0.877 | 1.7 | ug/L |
| Se | 78 | 55226.047 | 2.8 | 16119.238 | 50.67550 | 2.643 | 5.2 | mg/L |
| Se | 82 | 18512.072 | 0.2 | 1872.010 | 52.27405 | 0.904 | 1.7 | ug/L |
| Kr | 83 | 1740.199 | 1.2 | 1902.236 | | | | mg/L |
| Y | 89 | 406913.863 | 2.6 | 408188.389 | | | | ug/L |
| Mo | 95 | 265433.072 | 0.6 | 112.002 | 49.41771 | 0.993 | 2.0 | ug/L |
| Mo | 97 | 165315.870 | 2.3 | 64.001 | 50.61534 | 1.809 | 3.6 | ug/L |
| Mo | 98 | 427467.292 | 0.5 | 98.282 | 51.89247 | 0.496 | 1.0 | ug/L |
| Rh | 103 | 336774.386 | 1.7 | 340052.119 | | | | ug/L |
| Ag | 107 | 675518.226 | 1.6 | 91.335 | 51.08798 | 0.852 | 1.7 | ug/L |
| Ag | 109 | 641825.967 | 1.1 | 75.668 | 51.65925 | 0.757 | 1.5 | ug/L |
| Cd | 111 | 155418.961 | 2.8 | 218.275 | 51.39346 | 1.358 | 2.6 | ug/L |
| Cd | 114 | 358937.089 | 2.7 | 58.957 | 53.38278 | 1.420 | 2.7 | ug/L |
| > In | 115 | 356901.369 | 1.4 | 358352.924 | | | | ug/L |
| Sb | 121 | 475502.429 | 0.6 | 107.668 | 51.22778 | 1.003 | 2.0 | ug/L |
| Sb | 123 | 354845.219 | 0.4 | 79.665 | 49.66732 | 0.663 | 1.3 | ug/L |
| Ba | 135 | 122685.418 | 0.7 | 46.667 | 50.34227 | 0.284 | 0.6 | ug/L |
| Ba | 137 | 204249.069 | 2.4 | 47.001 | 49.11336 | 0.962 | 2.0 | ug/L |
| > Tb | 159 | 404736.317 | 0.8 | 411268.087 | | | | ug/L |
| > Ho | 165 | 385446.056 | 2.8 | 390096.908 | | | | ug/L |
| Tl | 203 | 389895.032 | 1.1 | 60.001 | 49.73107 | 1.484 | 3.0 | ug/L |
| Tl | 205 | 922505.040 | 2.3 | 78.001 | 53.23417 | 0.815 | 1.5 | ug/L |
| Pb | 208 | 1285515.438 | 1.6 | 320.672 | 51.52953 | 0.626 | 1.2 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Monday, November 13, 2006 19:08:35

Page 1

285

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 329503.936 | 3.5 | 87.335 | 50.19387 | 0.362 | 0.7 ug/L |
| | Pb | 207 | 272682.267 | 0.5 | 77.001 | 49.76555 | 1.365 | 2.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 102.916 | | | | |
| Al | 27 | 104.682 | | | | |
| > Sc | 45 | | 95.934 | | | |
| V | 51 | 103.554 | | | | |
| Cr | 52 | 104.417 | | | | |
| Cr | 53 | 98.665 | | | | |
| Mn | 55 | 103.902 | | | | |
| Co | 59 | 96.526 | | | | |
| Ni | 60 | 97.767 | | | | |
| Ni | 62 | 101.887 | | | | |
| Cu | 63 | 101.729 | | | | |
| Cu | 65 | 103.877 | | | | |
| Zn | 66 | 106.376 | | | | |
| Zn | 67 | 104.709 | | | | |
| Zn | 68 | 108.001 | | | | |
| > Ge | 72 | | 99.877 | | | |
| As | 75 | 96.717 | | | | |
| Se | 77 | 105.366 | | | | |
| Se | 78 | 101.351 | | | | |
| Se | 82 | 104.548 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 98.835 | | | | |
| Mo | 97 | 101.231 | | | | |
| Mo | 98 | 103.785 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 102.176 | | | | |
| Ag | 109 | 103.318 | | | | |
| Cd | 111 | 102.787 | | | | |
| Cd | 114 | 106.766 | | | | |
| > In | 115 | | 99.595 | | | |
| Sb | 121 | 102.456 | | | | |
| Sb | 123 | 99.335 | | | | |
| Ba | 135 | 100.685 | | | | |
| Ba | 137 | 98.227 | | | | |
| > Tb | 159 | | 98.412 | | | |
| > Ho | 165 | | 98.808 | | | |
| Tl | 203 | 99.462 | | | | |
| Tl | 205 | 106.468 | | | | |
| Pb | 208 | 103.059 | | | | |
| Pb | 206 | 100.388 | | | | |
| Pb | 207 | 99.531 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 13, 2006 19:11:31

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 7.056

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54.667 | 12.2 | 63.001 | -0.00600 | 0.007 | 111.7 | ug/L |
| Al | 27 | 2565.421 | 2.3 | 2334.350 | 0.04366 | 0.004 | 8.6 | ug/L |
| > Sc | 45 | 371907.367 | 2.1 | 381869.082 | | | | ug/L |
| V | 51 | 4808.979 | 2.1 | 4488.603 | 0.02745 | 0.008 | 28.6 | ug/L |
| Cr | 52 | 15803.462 | 0.5 | 15368.650 | 0.06033 | 0.029 | 47.8 | ug/L |
| Cr | 53 | 704.370 | 3.0 | 814.381 | -0.05061 | 0.004 | 7.1 | ug/L |
| Mn | 55 | 480.352 | 4.6 | 494.020 | -0.00075 | 0.001 | 91.1 | ug/L |
| Co | 59 | 153.336 | 10.4 | 188.671 | -0.00202 | 0.001 | 50.1 | ug/L |
| Ni | 60 | 129.336 | 18.6 | 136.669 | -0.00192 | 0.006 | 320.3 | ug/L |
| Ni | 62 | 128.002 | 1.6 | 143.669 | -0.02710 | 0.007 | 25.1 | ug/L |
| Cu | 63 | 242.339 | 11.5 | 212.338 | 0.00322 | 0.003 | 84.4 | ug/L |
| Cu | 65 | 185.004 | 12.9 | 189.671 | -0.00109 | 0.006 | 578.3 | ug/L |
| Zn | 66 | 1574.498 | 3.5 | 1515.486 | 0.02139 | 0.021 | 97.1 | ug/L |
| Zn | 67 | 298.008 | 2.9 | 342.344 | -0.10069 | 0.033 | 32.6 | ug/L |
| Zn | 68 | 1237.438 | 2.6 | 1170.427 | 0.03416 | 0.031 | 89.5 | ug/L |
| > Ge | 72 | 245544.752 | 2.1 | 244883.968 | | | | ug/L |
| As | 75 | 185.671 | 6.3 | 124.002 | 0.01920 | 0.003 | 16.0 | ug/L |
| Se | 77 | 222.870 | 0.7 | 216.736 | 0.02347 | 0.013 | 56.7 | ug/L |
| Se | 78 | 16071.412 | 1.4 | 16119.238 | -0.10798 | 0.710 | 657.7 | mg/L |
| Se | 82 | 1793.926 | 1.1 | 1872.010 | -0.25779 | 0.169 | 65.4 | ug/L |
| Kr | 83 | 1783.875 | 0.6 | 1902.236 | | | | mg/L |
| Y | 89 | 406661.988 | 2.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 814.716 | 20.3 | 112.002 | 0.12636 | 0.031 | 24.7 | ug/L |
| Mo | 97 | 503.021 | 17.8 | 64.001 | 0.12979 | 0.028 | 21.3 | ug/L |
| Mo | 98 | 1195.856 | 14.9 | 98.282 | 0.12886 | 0.022 | 17.2 | ug/L |
| Rh | 103 | 334752.249 | 1.1 | 340052.119 | | | | ug/L |
| Ag | 107 | 179.337 | 6.0 | 91.335 | 0.00625 | 0.001 | 11.7 | ug/L |
| Ag | 109 | 144.336 | 9.2 | 75.668 | 0.00518 | 0.001 | 19.0 | ug/L |
| Cd | 111 | 214.525 | 7.7 | 218.275 | -0.00315 | 0.006 | 191.2 | ug/L |
| Cd | 114 | 58.413 | 9.1 | 58.957 | -0.00032 | 0.001 | 240.1 | ug/L |
| > In | 115 | 368544.452 | 1.1 | 358352.924 | | | | ug/L |
| Sb | 121 | 1437.140 | 15.5 | 107.668 | 0.13852 | 0.024 | 17.6 | ug/L |
| Sb | 123 | 1075.981 | 11.8 | 79.665 | 0.13487 | 0.018 | 13.7 | ug/L |
| Ba | 135 | 48.667 | 10.1 | 46.667 | 0.00102 | 0.002 | 189.9 | ug/L |
| Ba | 137 | 60.001 | 17.6 | 47.001 | 0.00324 | 0.003 | 80.1 | ug/L |
| > Tb | 159 | 406695.774 | 0.4 | 411268.087 | | | | ug/L |
| > Ho | 165 | 391327.828 | 1.2 | 390096.908 | | | | ug/L |
| Tl | 203 | 72.334 | 20.1 | 60.001 | 0.00154 | 0.002 | 125.6 | ug/L |
| Tl | 205 | 145.003 | 11.4 | 78.001 | 0.00380 | 0.001 | 26.9 | ug/L |
| Pb | 208 | 434.009 | 6.8 | 320.672 | 0.00444 | 0.001 | 30.3 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Monday, November 13, 2006 19:14:31

Page 1

| | | | | | | | | | |
|---|----|-----|---------|-----|--------|---------|-------|------|------|
| | Pb | 206 | 118.669 | 6.1 | 87.335 | 0.00467 | 0.001 | 27.8 | ug/L |
| L | Pb | 207 | 103.002 | 3.9 | 77.001 | 0.00463 | 0.001 | 19.1 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 97.391 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 100.270 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.844 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.888 | | | |
| > Ho | 165 | | 100.316 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956 D.100

Sample Date/Time: Monday, November 13, 2006 19:17:28

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948956 D.100.057

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54.667 | 26.7 | 63.001 | -0.00699 | 0.013 | 188.2 | ug/L |
| Al | 27 | 23498.003 | 2.9 | 2334.350 | 3.10817 | 0.115 | 3.7 | ug/L |
| Sc | 45 | 379049.329 | 0.7 | 381869.082 | | | | ug/L |
| V | 51 | 4752.167 | 2.6 | 4488.603 | 0.01822 | 0.007 | 39.5 | ug/L |
| Cr | 52 | 16040.589 | 2.4 | 15368.650 | 0.05520 | 0.021 | 38.9 | ug/L |
| Cr | 53 | 744.374 | 7.2 | 814.381 | -0.03582 | 0.029 | 80.6 | ug/L |
| Mn | 55 | 1487241.469 | 1.9 | 494.020 | 71.24398 | 0.537 | 0.8 | ug/L |
| Co | 59 | 3035.250 | 2.4 | 188.671 | 0.15621 | 0.003 | 2.0 | ug/L |
| Ni | 60 | 751.375 | 1.2 | 136.669 | 0.14960 | 0.004 | 3.0 | ug/L |
| Ni | 62 | 223.005 | 8.2 | 143.669 | 0.12311 | 0.026 | 21.4 | ug/L |
| Cu | 63 | 578.026 | 2.4 | 212.338 | 0.03850 | 0.002 | 5.6 | ug/L |
| Cu | 65 | 325.676 | 4.9 | 189.671 | 0.02877 | 0.003 | 9.7 | ug/L |
| Zn | 66 | 151781.941 | 1.9 | 1515.486 | 56.70531 | 1.068 | 1.9 | ug/L |
| Zn | 67 | 22635.934 | 1.8 | 342.344 | 48.42897 | 1.000 | 2.1 | ug/L |
| Zn | 68 | 106923.569 | 2.4 | 1170.427 | 54.35014 | 2.159 | 4.0 | ug/L |
| Ge | 72 | 252498.632 | 1.5 | 244883.968 | | | | ug/L |
| As | 75 | 7350.981 | 0.4 | 124.002 | 2.20124 | 0.040 | 1.8 | ug/L |
| Se | 77 | 209.403 | 3.2 | 216.736 | -0.05715 | 0.037 | 64.5 | ug/L |
| Se | 78 | 15848.624 | 1.1 | 16119.238 | -0.96268 | 0.518 | 53.8 | mg/L |
| Se | 82 | 1766.721 | 0.6 | 1872.010 | -0.49684 | 0.051 | 10.3 | ug/L |
| Kr | 83 | 1817.550 | 0.8 | 1902.236 | | | | mg/L |
| Y | 89 | 418153.781 | 1.0 | 408188.389 | | | | ug/L |
| Mo | 95 | 1884.232 | 1.3 | 112.002 | 0.31970 | 0.004 | 1.1 | ug/L |
| Mo | 97 | 1128.754 | 3.8 | 64.001 | 0.31581 | 0.011 | 3.4 | ug/L |
| Mo | 98 | 2894.959 | 1.0 | 98.282 | 0.32917 | 0.002 | 0.6 | ug/L |
| Rh | 103 | 339019.795 | 0.7 | 340052.119 | | | | ug/L |
| Ag | 107 | 76.001 | 17.4 | 91.335 | -0.00129 | 0.001 | 82.4 | ug/L |
| Ag | 109 | 62.001 | 4.8 | 75.668 | -0.00122 | 0.000 | 20.3 | ug/L |
| Cd | 111 | 266.476 | 5.9 | 218.275 | 0.01364 | 0.005 | 37.2 | ug/L |
| Cd | 114 | 145.805 | 14.6 | 58.957 | 0.01230 | 0.003 | 24.1 | ug/L |
| In | 115 | 367839.403 | 1.5 | 358352.924 | | | | ug/L |
| Sb | 121 | 495.020 | 4.6 | 107.668 | 0.04019 | 0.002 | 4.8 | ug/L |
| Sb | 123 | 372.778 | 4.9 | 79.665 | 0.03951 | 0.002 | 4.4 | ug/L |
| Ba | 135 | 666.700 | 1.9 | 46.667 | 0.25100 | 0.008 | 3.0 | ug/L |
| Ba | 137 | 1072.080 | 4.1 | 47.001 | 0.24305 | 0.009 | 3.5 | ug/L |
| Tb | 159 | 410542.209 | 1.0 | 411268.087 | | | | ug/L |
| Ho | 165 | 388858.516 | 2.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 91.668 | 10.3 | 60.001 | 0.00404 | 0.001 | 32.1 | ug/L |
| Tl | 205 | 154.336 | 2.9 | 78.001 | 0.00438 | 0.000 | 6.5 | ug/L |
| Pb | 208 | 1141.375 | 5.4 | 320.672 | 0.03268 | 0.003 | 9.5 | ug/L |

Sample ID: 948956 D.100

Report Date/Time: Monday, November 13, 2006 19:20:30

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|-----------|
| | Pb | 206 | 291.675 | 1.7 | 87.335 | 0.03092 | 0.001 | 3.7 ug/L |
| | Pb | 207 | 252.340 | 8.4 | 77.001 | 0.03182 | 0.005 | 15.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 99.262 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 103.109 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.647 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.824 | | | |
| > Ho | 165 | | 99.683 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956D D.100

Sample Date/Time: Monday, November 13, 2006 19:23:27

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948956D D.100.058

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54.667 | 13.7 | 63.001 | -0.00704 | 0.007 | 104.5 | ug/L |
| Al | 27 | 22846.174 | 1.5 | 2334.350 | 3.00784 | 0.166 | 5.5 | ug/L |
| > Sc | 45 | 379979.514 | 3.6 | 381869.082 | | | | ug/L |
| V | 51 | 4840.415 | 3.9 | 4488.603 | 0.02297 | 0.008 | 35.4 | ug/L |
| Cr | 52 | 16274.376 | 2.0 | 15368.650 | 0.06988 | 0.047 | 67.3 | ug/L |
| Cr | 53 | 726.706 | 1.6 | 814.381 | -0.04626 | 0.017 | 36.9 | ug/L |
| Mn | 55 | 1491950.841 | 0.7 | 494.020 | 71.47860 | 0.674 | 0.9 | ug/L |
| Co | 59 | 2957.554 | 1.3 | 188.671 | 0.15196 | 0.003 | 1.9 | ug/L |
| Ni | 60 | 770.710 | 1.9 | 136.669 | 0.15433 | 0.005 | 3.2 | ug/L |
| Ni | 62 | 216.338 | 9.5 | 143.669 | 0.11243 | 0.035 | 31.4 | ug/L |
| Cu | 63 | 546.023 | 0.5 | 212.338 | 0.03506 | 0.000 | 0.7 | ug/L |
| Cu | 65 | 295.342 | 9.4 | 189.671 | 0.02205 | 0.006 | 25.7 | ug/L |
| Zn | 66 | 151613.849 | 2.5 | 1515.486 | 56.64512 | 1.616 | 2.9 | ug/L |
| Zn | 67 | 22670.384 | 3.8 | 342.344 | 48.49603 | 1.564 | 3.2 | ug/L |
| Zn | 68 | 108357.033 | 0.8 | 1170.427 | 55.07208 | 0.777 | 1.4 | ug/L |
| > Ge | 72 | 252481.349 | 0.7 | 244883.968 | | | | ug/L |
| As | 75 | 7292.597 | 2.2 | 124.002 | 2.18322 | 0.048 | 2.2 | ug/L |
| Se | 77 | 209.469 | 0.9 | 216.736 | -0.05709 | 0.009 | 16.4 | ug/L |
| Se | 78 | 15829.475 | 1.6 | 16119.238 | -0.98938 | 0.397 | 40.1 | mg/L |
| Se | 82 | 1779.923 | 0.7 | 1872.010 | -0.45673 | 0.040 | 8.7 | ug/L |
| Kr | 83 | 1744.534 | 4.2 | 1902.236 | | | | mg/L |
| Y | 89 | 413995.637 | 1.0 | 408188.389 | | | | ug/L |
| Mo | 95 | 1802.213 | 2.1 | 112.002 | 0.30472 | 0.010 | 3.2 | ug/L |
| Mo | 97 | 1130.755 | 2.4 | 64.001 | 0.31622 | 0.007 | 2.3 | ug/L |
| Mo | 98 | 2777.957 | 2.3 | 98.282 | 0.31523 | 0.011 | 3.3 | ug/L |
| Rh | 103 | 342286.190 | 0.3 | 340052.119 | | | | ug/L |
| Ag | 107 | 75.334 | 3.3 | 91.335 | -0.00135 | 0.000 | 17.4 | ug/L |
| Ag | 109 | 54.667 | 4.6 | 75.668 | -0.00180 | 0.000 | 12.1 | ug/L |
| Cd | 111 | 242.841 | 1.4 | 218.275 | 0.00599 | 0.001 | 22.8 | ug/L |
| Cd | 114 | 137.034 | 4.6 | 58.957 | 0.01103 | 0.001 | 7.8 | ug/L |
| > In | 115 | 368061.031 | 0.9 | 358352.924 | | | | ug/L |
| Sb | 121 | 320.676 | 9.8 | 107.668 | 0.02193 | 0.003 | 13.8 | ug/L |
| Sb | 123 | 243.530 | 0.3 | 79.665 | 0.02195 | 0.000 | 0.9 | ug/L |
| Ba | 135 | 674.701 | 6.0 | 46.667 | 0.25351 | 0.017 | 6.5 | ug/L |
| Ba | 137 | 1066.412 | 1.3 | 47.001 | 0.24111 | 0.003 | 1.1 | ug/L |
| > Tb | 159 | 411575.812 | 0.3 | 411268.087 | | | | ug/L |
| > Ho | 165 | 393441.732 | 1.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 90.001 | 16.4 | 60.001 | 0.00367 | 0.002 | 47.2 | ug/L |
| Tl | 205 | 159.003 | 12.8 | 78.001 | 0.00453 | 0.001 | 23.2 | ug/L |
| Pb | 208 | 1115.374 | 1.8 | 320.672 | 0.03110 | 0.001 | 1.8 | ug/L |

Sample ID: 948956D D.100

Report Date/Time: Monday, November 13, 2006 19:26:29

Page 1

| | | | | | | | | |
|---|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 288.008 | 3.9 | 87.335 | 0.02986 | 0.002 | 7.1 ug/L |
| L | Pb | 207 | 236.672 | 5.8 | 77.001 | 0.02844 | 0.003 | 9.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 99.505 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 103.102 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.709 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.075 | | | |
| > Ho | 165 | | 100.857 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956S D.100

Sample Date/Time: Monday, November 13, 2006 19:29:26

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948956S D.100.059

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 322.343 | 11.8 | 63.001 | 0.24195 | 0.039 | 16.1 | ug/L |
| Al | 27 | 23157.715 | 3.0 | 2334.350 | 3.17981 | 0.142 | 4.5 | ug/L |
| > Sc | 45 | 366032.213 | 1.4 | 381869.082 | | | | ug/L |
| V | 51 | 8651.106 | 3.3 | 4488.603 | 0.27647 | 0.011 | 4.0 | ug/L |
| Cr | 52 | 19581.525 | 3.4 | 15368.650 | 0.35327 | 0.037 | 10.6 | ug/L |
| Cr | 53 | 1138.756 | 0.7 | 814.381 | 0.20733 | 0.005 | 2.5 | ug/L |
| Mn | 55 | 1483845.938 | 1.2 | 494.020 | 73.22090 | 2.794 | 3.8 | ug/L |
| Co | 59 | 7205.520 | 1.9 | 188.671 | 0.39730 | 0.010 | 2.5 | ug/L |
| Ni | 60 | 1678.186 | 1.3 | 136.669 | 0.38908 | 0.020 | 5.1 | ug/L |
| Ni | 62 | 341.344 | 3.2 | 143.669 | 0.33527 | 0.035 | 10.3 | ug/L |
| Cu | 63 | 2712.469 | 1.3 | 212.338 | 0.27589 | 0.008 | 2.8 | ug/L |
| Cu | 65 | 1400.132 | 1.7 | 189.671 | 0.27588 | 0.016 | 5.8 | ug/L |
| Zn | 66 | 151512.612 | 1.3 | 1515.486 | 58.29795 | 1.265 | 2.2 | ug/L |
| Zn | 67 | 22563.737 | 1.6 | 342.344 | 49.73089 | 1.584 | 3.2 | ug/L |
| Zn | 68 | 109661.318 | 1.3 | 1170.427 | 57.41360 | 1.498 | 2.6 | ug/L |
| > Ge | 72 | 245329.465 | 3.3 | 244883.968 | | | | ug/L |
| As | 75 | 7983.238 | 3.4 | 124.002 | 2.46832 | 0.169 | 6.8 | ug/L |
| Se | 77 | 265.404 | 0.9 | 216.736 | 0.20373 | 0.042 | 20.6 | ug/L |
| Se | 78 | 16290.585 | 0.6 | 16119.238 | 0.19861 | 0.697 | 350.8 | mg/L |
| Se | 82 | 1852.473 | 2.1 | 1872.010 | -0.06866 | 0.178 | 258.7 | ug/L |
| Kr | 83 | 1792.211 | 3.3 | 1902.236 | | | | mg/L |
| Y | 89 | 413917.707 | 1.1 | 408188.389 | | | | ug/L |
| Mo | 95 | 2985.231 | 0.4 | 112.002 | 0.52584 | 0.002 | 0.4 | ug/L |
| Mo | 97 | 1895.234 | 2.0 | 64.001 | 0.55108 | 0.011 | 2.0 | ug/L |
| Mo | 98 | 4667.855 | 0.9 | 98.282 | 0.54536 | 0.005 | 0.9 | ug/L |
| Rh | 103 | 340635.659 | 1.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 3256.002 | 1.0 | 91.335 | 0.23526 | 0.002 | 0.9 | ug/L |
| Ag | 109 | 2996.902 | 3.2 | 75.668 | 0.23112 | 0.008 | 3.3 | ug/L |
| Cd | 111 | 982.435 | 0.8 | 218.275 | 0.24789 | 0.003 | 1.2 | ug/L |
| Cd | 114 | 1827.005 | 2.2 | 58.957 | 0.25847 | 0.006 | 2.5 | ug/L |
| > In | 115 | 362977.595 | 0.2 | 358352.924 | | | | ug/L |
| Sb | 121 | 2560.086 | 4.8 | 107.668 | 0.25966 | 0.013 | 5.1 | ug/L |
| Sb | 123 | 1939.382 | 1.0 | 79.665 | 0.25583 | 0.002 | 0.9 | ug/L |
| Ba | 135 | 1200.765 | 2.6 | 46.667 | 0.46880 | 0.018 | 3.9 | ug/L |
| Ba | 137 | 2026.934 | 4.6 | 47.001 | 0.47129 | 0.028 | 5.9 | ug/L |
| > Tb | 159 | 409212.878 | 1.3 | 411268.087 | | | | ug/L |
| > Ho | 165 | 392011.280 | 2.6 | 390096.908 | | | | ug/L |
| Tl | 203 | 1950.248 | 1.2 | 60.001 | 0.23701 | 0.005 | 2.0 | ug/L |
| Tl | 205 | 4646.676 | 3.0 | 78.001 | 0.25927 | 0.009 | 3.5 | ug/L |
| Pb | 208 | 7203.631 | 0.9 | 320.672 | 0.27131 | 0.005 | 1.8 | ug/L |

Sample ID: 948956S D.100

Report Date/Time: Monday, November 13, 2006 19:32:28

Page 1

297

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 1834.220 | 2.9 | 87.335 | 0.26168 | 0.001 | 0.2 ug/L |
| | Pb | 207 | 1534.823 | 2.2 | 77.001 | 0.26169 | 0.013 | 4.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 95.853 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 100.182 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 101.291 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.500 | | | |
| > Ho | 165 | | 100.491 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956A D.100

Sample Date/Time: Monday, November 13, 2006 19:35:25

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948956A D.100.060

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 22623.570 | 2.2 | 63.001 | 20.53015 | 0.659 | 3.2 | ug/L |
| Al | 27 | 270978.107 | 0.8 | 2334.350 | 40.27339 | 0.758 | 1.9 | ug/L |
| Sc | 45 | 371183.618 | 2.3 | 381869.082 | | | | ug/L |
| V | 51 | 360732.007 | 0.7 | 4488.603 | 22.35964 | 0.657 | 2.9 | ug/L |
| Cr | 52 | 318993.195 | 1.3 | 15368.650 | 21.84962 | 0.248 | 1.1 | ug/L |
| Cr | 53 | 36260.422 | 1.3 | 814.381 | 20.25472 | 0.741 | 3.7 | ug/L |
| Mn | 55 | 1864721.802 | 1.7 | 494.020 | 93.28116 | 2.323 | 2.5 | ug/L |
| Co | 59 | 365367.050 | 1.8 | 188.671 | 20.96881 | 0.577 | 2.8 | ug/L |
| Ni | 60 | 82886.002 | 0.7 | 136.669 | 21.16706 | 0.253 | 1.2 | ug/L |
| Ni | 62 | 12201.720 | 2.9 | 143.669 | 20.72769 | 0.327 | 1.6 | ug/L |
| Cu | 63 | 193326.110 | 0.7 | 212.338 | 21.60993 | 0.377 | 1.7 | ug/L |
| Cu | 65 | 96030.463 | 1.0 | 189.671 | 22.13619 | 0.280 | 1.3 | ug/L |
| Zn | 66 | 202384.661 | 1.9 | 1515.486 | 79.15880 | 0.896 | 1.1 | ug/L |
| Zn | 67 | 31779.144 | 1.9 | 342.344 | 71.34467 | 1.996 | 2.8 | ug/L |
| Zn | 68 | 149550.486 | 0.4 | 1170.427 | 79.62120 | 0.821 | 1.0 | ug/L |
| Ge | 72 | 241865.246 | 1.5 | 244883.968 | | | | ug/L |
| As | 75 | 72395.251 | 2.1 | 124.002 | 22.99683 | 0.809 | 3.5 | ug/L |
| Se | 77 | 5138.851 | 1.0 | 216.736 | 20.99031 | 0.431 | 2.1 | ug/L |
| Se | 78 | 32456.557 | 1.1 | 16119.238 | 21.65934 | 1.098 | 5.1 | mg/L |
| Se | 82 | 8283.715 | 0.2 | 1872.010 | 20.43782 | 0.324 | 1.6 | ug/L |
| Kr | 83 | 1807.881 | 2.2 | 1902.236 | | | | mg/L |
| Y | 89 | 403089.749 | 2.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 113663.617 | 2.2 | 112.002 | 20.87364 | 0.192 | 0.9 | ug/L |
| Mo | 97 | 72272.468 | 1.3 | 64.001 | 21.83238 | 0.580 | 2.7 | ug/L |
| Mo | 98 | 178709.310 | 0.4 | 98.282 | 21.41092 | 0.323 | 1.5 | ug/L |
| Rh | 103 | 335094.105 | 2.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 292104.411 | 1.7 | 91.335 | 21.80257 | 0.095 | 0.4 | ug/L |
| Ag | 109 | 266588.673 | 0.2 | 75.668 | 21.18003 | 0.319 | 1.5 | ug/L |
| Cd | 111 | 65398.125 | 0.6 | 218.275 | 21.30809 | 0.227 | 1.1 | ug/L |
| Cd | 114 | 145903.775 | 0.5 | 58.957 | 21.41825 | 0.328 | 1.5 | ug/L |
| In | 115 | 361538.985 | 1.7 | 358352.924 | | | | ug/L |
| Sb | 121 | 200123.760 | 1.4 | 107.668 | 21.27984 | 0.634 | 3.0 | ug/L |
| Sb | 123 | 152407.616 | 0.7 | 79.665 | 21.05263 | 0.265 | 1.3 | ug/L |
| Ba | 135 | 50348.184 | 2.1 | 46.667 | 20.48425 | 0.387 | 1.9 | ug/L |
| Ba | 137 | 86942.458 | 1.6 | 47.001 | 20.73485 | 0.284 | 1.4 | ug/L |
| Tb | 159 | 407964.895 | 0.3 | 411268.087 | | | | ug/L |
| Ho | 165 | 380038.130 | 1.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 165526.178 | 1.0 | 60.001 | 21.40028 | 0.309 | 1.4 | ug/L |
| Tl | 205 | 389151.765 | 1.5 | 78.001 | 22.76974 | 0.107 | 0.5 | ug/L |
| Pb | 208 | 539559.526 | 0.8 | 320.672 | 21.92516 | 0.159 | 0.7 | ug/L |

Sample ID: 948956A D.100

Report Date/Time: Monday, November 13, 2006 19:38:26

Page 1

300

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 137273.444 | 0.4 | 87.335 | 21.20709 | 0.348 | 1.6 ug/L |
| | Pb | 207 | 115809.011 | 0.9 | 77.001 | 21.42024 | 0.324 | 1.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 97.202 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 98.767 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 100.889 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 99.197 | | | |
| > [Ho | 165 | | 97.421 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956L D.100

Sample Date/Time: Monday, November 13, 2006 19:41:23

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948956L D.100.061

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 66.334 | 3.5 | 63.001 | 0.00392 | 0.002 | 42.2 | ug/L |
| Al | 27 | 59817.541 | 1.3 | 2334.350 | 8.51944 | 0.219 | 2.6 | ug/L |
| > Sc | 45 | 375590.812 | 1.3 | 381869.082 | | | | ug/L |
| V | 51 | 4704.546 | 2.5 | 4488.603 | 0.01798 | 0.007 | 41.6 | ug/L |
| Cr | 52 | 15503.566 | 1.6 | 15368.650 | 0.02751 | 0.008 | 29.2 | ug/L |
| Cr | 53 | 715.705 | 2.1 | 814.381 | -0.04804 | 0.011 | 23.2 | ug/L |
| Mn | 55 | 296656.908 | 3.5 | 494.020 | 14.64994 | 0.844 | 5.8 | ug/L |
| Co | 59 | 733.373 | 0.4 | 188.671 | 0.03091 | 0.001 | 3.6 | ug/L |
| Ni | 60 | 333.677 | 6.0 | 136.669 | 0.04989 | 0.007 | 13.8 | ug/L |
| Ni | 62 | 168.670 | 3.4 | 143.669 | 0.04259 | 0.011 | 25.2 | ug/L |
| Cu | 63 | 451.683 | 4.9 | 212.338 | 0.02645 | 0.002 | 5.8 | ug/L |
| Cu | 65 | 288.008 | 2.1 | 189.671 | 0.02246 | 0.001 | 6.6 | ug/L |
| Zn | 66 | 149382.772 | 1.8 | 1515.486 | 57.59310 | 2.144 | 3.7 | ug/L |
| Zn | 67 | 23090.517 | 1.8 | 342.344 | 50.99079 | 0.631 | 1.2 | ug/L |
| Zn | 68 | 108433.995 | 0.2 | 1170.427 | 56.87306 | 1.432 | 2.5 | ug/L |
| > Ge | 72 | 244827.394 | 2.4 | 244883.968 | | | | ug/L |
| As | 75 | 1575.498 | 2.7 | 124.002 | 0.45614 | 0.008 | 1.7 | ug/L |
| Se | 77 | 213.069 | 4.7 | 216.736 | -0.01423 | 0.064 | 451.6 | ug/L |
| Se | 78 | 16212.608 | 2.0 | 16119.238 | 0.12957 | 0.426 | 328.4 | mg/L |
| Se | 82 | 1781.124 | 2.5 | 1872.010 | -0.27945 | 0.274 | 98.1 | ug/L |
| Kr | 83 | 1786.543 | 1.4 | 1902.236 | | | | mg/L |
| Y | 89 | 402361.179 | 1.4 | 408188.389 | | | | ug/L |
| Mo | 95 | 691.369 | 8.0 | 112.002 | 0.10416 | 0.010 | 9.7 | ug/L |
| Mo | 97 | 418.348 | 9.1 | 64.001 | 0.10481 | 0.012 | 11.2 | ug/L |
| Mo | 98 | 987.235 | 5.8 | 98.282 | 0.10444 | 0.007 | 7.0 | ug/L |
| Rh | 103 | 335318.663 | 0.5 | 340052.119 | | | | ug/L |
| Ag | 107 | 97.335 | 21.1 | 91.335 | 0.00027 | 0.002 | 577.2 | ug/L |
| Ag | 109 | 74.668 | 7.7 | 75.668 | -0.00023 | 0.000 | 211.9 | ug/L |
| Cd | 111 | 252.374 | 9.1 | 218.275 | 0.00908 | 0.007 | 77.2 | ug/L |
| Cd | 114 | 143.319 | 5.0 | 58.957 | 0.01195 | 0.001 | 9.0 | ug/L |
| > In | 115 | 367830.766 | 0.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 617.696 | 12.9 | 107.668 | 0.05304 | 0.009 | 16.1 | ug/L |
| Sb | 123 | 506.508 | 12.0 | 79.665 | 0.05770 | 0.008 | 14.5 | ug/L |
| Ba | 135 | 177.004 | 8.8 | 46.667 | 0.05352 | 0.007 | 12.4 | ug/L |
| Ba | 137 | 277.341 | 5.6 | 47.001 | 0.05530 | 0.004 | 6.7 | ug/L |
| > Tb | 159 | 406452.090 | 1.0 | 411268.087 | | | | ug/L |
| > Ho | 165 | 384316.180 | 1.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 68.334 | 8.1 | 60.001 | 0.00119 | 0.001 | 68.0 | ug/L |
| Tl | 205 | 130.669 | 12.6 | 78.001 | 0.00312 | 0.001 | 32.2 | ug/L |
| Pb | 208 | 1121.707 | 1.2 | 320.672 | 0.03240 | 0.001 | 3.4 | ug/L |

Sample ID: 948956L D.100

Report Date/Time: Monday, November 13, 2006 19:44:25

Page 1

303

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 286.341 | 4.8 | 87.335 | 0.03063 | 0.003 | 8.4 ug/L |
| | Pb | 207 | 254.006 | 3.8 | 77.001 | 0.03261 | 0.002 | 6.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 98.356 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 99.977 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 102.645 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.829 | | | |
| > [Ho | 165 | | 98.518 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948957 D.100

Sample Date/Time: Monday, November 13, 2006 19:47:22

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948957 D.100.062

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59.001 | 15.5 | 63.001 | -0.00269 | 0.008 | 296.3 | ug/L |
| Al | 27 | 24100.039 | 0.2 | 2334.350 | 3.22857 | 0.072 | 2.2 | ug/L |
| > Sc | 45 | 375709.417 | 2.1 | 381869.082 | | | | ug/L |
| V | 51 | 4597.466 | 1.6 | 4488.603 | 0.01125 | 0.002 | 16.6 | ug/L |
| Cr | 52 | 15408.387 | 1.0 | 15368.650 | 0.02059 | 0.013 | 61.1 | ug/L |
| Cr | 53 | 747.708 | 1.0 | 814.381 | -0.03000 | 0.013 | 44.0 | ug/L |
| Mn | 55 | 1389733.879 | 0.7 | 494.020 | 67.94327 | 1.361 | 2.0 | ug/L |
| Co | 59 | 3006.906 | 1.0 | 188.671 | 0.15803 | 0.001 | 0.9 | ug/L |
| Ni | 60 | 750.041 | 3.4 | 136.669 | 0.15298 | 0.006 | 3.7 | ug/L |
| Ni | 62 | 219.338 | 3.0 | 143.669 | 0.12467 | 0.013 | 10.5 | ug/L |
| Cu | 63 | 524.022 | 4.7 | 212.338 | 0.03385 | 0.003 | 8.3 | ug/L |
| Cu | 65 | 268.007 | 2.0 | 189.671 | 0.01726 | 0.002 | 12.7 | ug/L |
| Zn | 66 | 154871.994 | 1.7 | 1515.486 | 59.05946 | 0.612 | 1.0 | ug/L |
| Zn | 67 | 23847.648 | 1.2 | 342.344 | 52.13054 | 1.582 | 3.0 | ug/L |
| Zn | 68 | 109322.638 | 1.7 | 1170.427 | 56.72888 | 2.039 | 3.6 | ug/L |
| > Ge | 72 | 247465.842 | 1.8 | 244883.968 | | | | ug/L |
| As | 75 | 7346.310 | 0.5 | 124.002 | 2.24559 | 0.053 | 2.4 | ug/L |
| Se | 77 | 215.336 | 4.1 | 216.736 | -0.01504 | 0.043 | 288.9 | ug/L |
| Se | 78 | 16152.919 | 2.0 | 16119.238 | -0.16633 | 0.721 | 433.5 | mg/L |
| Se | 82 | 1762.853 | 0.7 | 1872.010 | -0.39923 | 0.069 | 17.2 | ug/L |
| Kr | 83 | 1750.535 | 1.8 | 1902.236 | | | | mg/L |
| Y | 89 | 403477.559 | 0.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 1778.541 | 3.2 | 112.002 | 0.29629 | 0.015 | 5.1 | ug/L |
| Mo | 97 | 1081.748 | 1.1 | 64.001 | 0.29744 | 0.002 | 0.8 | ug/L |
| Mo | 98 | 2710.785 | 1.5 | 98.282 | 0.30305 | 0.003 | 1.1 | ug/L |
| Rh | 103 | 337259.601 | 0.2 | 340052.119 | | | | ug/L |
| Ag | 107 | 71.334 | 5.3 | 91.335 | -0.00171 | 0.000 | 19.4 | ug/L |
| Ag | 109 | 53.667 | 5.4 | 75.668 | -0.00193 | 0.000 | 10.2 | ug/L |
| Cd | 111 | 245.681 | 11.5 | 218.275 | 0.00582 | 0.008 | 143.2 | ug/L |
| Cd | 114 | 133.788 | 7.6 | 58.957 | 0.01031 | 0.002 | 14.7 | ug/L |
| > In | 115 | 372996.657 | 1.7 | 358352.924 | | | | ug/L |
| Sb | 121 | 337.677 | 4.9 | 107.668 | 0.02326 | 0.002 | 7.0 | ug/L |
| Sb | 123 | 262.259 | 9.4 | 79.665 | 0.02399 | 0.003 | 11.7 | ug/L |
| Ba | 135 | 652.032 | 5.1 | 46.667 | 0.24877 | 0.011 | 4.6 | ug/L |
| Ba | 137 | 1138.089 | 1.1 | 47.001 | 0.26266 | 0.003 | 1.3 | ug/L |
| > Tb | 159 | 404694.059 | 1.1 | 411268.087 | | | | ug/L |
| > Ho | 165 | 394223.176 | 0.4 | 390096.908 | | | | ug/L |
| Tl | 203 | 91.668 | 12.6 | 60.001 | 0.00387 | 0.001 | 38.3 | ug/L |
| Tl | 205 | 149.670 | 5.7 | 78.001 | 0.00400 | 0.001 | 12.5 | ug/L |
| Pb | 208 | 1158.710 | 0.7 | 320.672 | 0.03271 | 0.000 | 0.9 | ug/L |

Sample ID: 948957 D.100

Report Date/Time: Monday, November 13, 2006 19:50:23

Page 1

306

| | | | | | | | | |
|---|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 297.008 | 1.8 | 87.335 | 0.03111 | 0.001 | 3.0 ug/L |
| L | Pb | 207 | 255.006 | 6.9 | 77.001 | 0.03161 | 0.003 | 9.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 98.387 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 101.054 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.086 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.402 | | | |
| > Ho | 165 | | 101.058 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948958

Sample Date/Time: Monday, November 13, 2006 19:53:20

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948958.063

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 57.667 | 23.7 | 63.001 | -0.01116 | 0.011 | 94.3 | ug/L |
| Al | 27 | 30200.261 | 0.8 | 2334.350 | 3.50128 | 0.048 | 1.4 | ug/L |
| > Sc | 45 | 437334.376 | 2.0 | 381869.082 | | | | ug/L |
| V | 51 | 6589.483 | 2.2 | 4488.603 | 0.07720 | 0.009 | 12.2 | ug/L |
| Cr | 52 | 29541.901 | 0.8 | 15368.650 | 0.72857 | 0.032 | 4.4 | ug/L |
| Cr | 53 | 1831.553 | 1.9 | 814.381 | 0.43545 | 0.003 | 0.8 | ug/L |
| Mn | 55 | 336282.594 | 2.3 | 494.020 | 14.92675 | 0.225 | 1.5 | ug/L |
| Co | 59 | 1138.090 | 9.0 | 188.671 | 0.04741 | 0.006 | 12.2 | ug/L |
| Ni | 60 | 1987.590 | 0.3 | 136.669 | 0.41733 | 0.006 | 1.5 | ug/L |
| Ni | 62 | 436.349 | 3.9 | 143.669 | 0.42258 | 0.018 | 4.3 | ug/L |
| Cu | 63 | 5803.412 | 1.7 | 212.338 | 0.55360 | 0.005 | 0.9 | ug/L |
| Cu | 65 | 2840.846 | 3.4 | 189.671 | 0.53974 | 0.014 | 2.6 | ug/L |
| Zn | 66 | 12637.370 | 1.8 | 1515.486 | 3.83624 | 0.086 | 2.2 | ug/L |
| Zn | 67 | 1955.582 | 1.2 | 342.344 | 3.17597 | 0.001 | 0.0 | ug/L |
| Zn | 68 | 8903.511 | 2.1 | 1170.427 | 3.62489 | 0.041 | 1.1 | ug/L |
| > Ge | 72 | 272137.906 | 1.2 | 244883.968 | | | | ug/L |
| As | 75 | 2299.007 | 2.1 | 124.002 | 0.61095 | 0.008 | 1.4 | ug/L |
| Se | 77 | 255.004 | 3.9 | 216.736 | 0.05342 | 0.029 | 53.9 | ug/L |
| Se | 78 | 18318.689 | 1.7 | 16119.238 | 0.47586 | 0.569 | 119.6 | mg/L |
| Se | 82 | 1931.024 | 2.2 | 1872.010 | -0.42114 | 0.123 | 29.2 | ug/L |
| Kr | 83 | 1961.250 | 2.3 | 1902.236 | | | | mg/L |
| Y | 89 | 468553.755 | 4.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 971.733 | 8.6 | 112.002 | 0.14252 | 0.016 | 11.5 | ug/L |
| Mo | 97 | 551.691 | 11.2 | 64.001 | 0.13294 | 0.019 | 14.4 | ug/L |
| Mo | 98 | 1386.702 | 10.8 | 98.282 | 0.14008 | 0.019 | 13.5 | ug/L |
| Rh | 103 | 371327.351 | 0.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 422.015 | 3.2 | 91.335 | 0.02191 | 0.001 | 5.8 | ug/L |
| Ag | 109 | 420.015 | 5.1 | 75.668 | 0.02440 | 0.001 | 5.1 | ug/L |
| Cd | 111 | 270.391 | 6.6 | 218.275 | 0.00869 | 0.004 | 47.0 | ug/L |
| Cd | 114 | 115.931 | 52.4 | 58.957 | 0.00673 | 0.008 | 118.2 | ug/L |
| > In | 115 | 395901.021 | 1.6 | 358352.924 | | | | ug/L |
| Sb | 121 | 519.021 | 9.8 | 107.668 | 0.03891 | 0.006 | 14.4 | ug/L |
| Sb | 123 | 402.495 | 3.3 | 79.665 | 0.03971 | 0.002 | 6.3 | ug/L |
| Ba | 135 | 1704.525 | 1.3 | 46.667 | 0.62940 | 0.010 | 1.6 | ug/L |
| Ba | 137 | 2806.167 | 2.3 | 47.001 | 0.61423 | 0.016 | 2.7 | ug/L |
| > Tb | 159 | 436862.138 | 0.4 | 411268.087 | | | | ug/L |
| > Ho | 165 | 428751.615 | 0.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 47.001 | 14.7 | 60.001 | -0.00217 | 0.001 | 35.8 | ug/L |
| Tl | 205 | 64.668 | 9.8 | 78.001 | -0.00109 | 0.000 | 30.6 | ug/L |
| Pb | 208 | 2569.845 | 3.8 | 320.672 | 0.07991 | 0.003 | 4.4 | ug/L |

309

Sample ID: 948958

Report Date/Time: Monday, November 13, 2006 19:56:22

Page 1

308 *11/13/06*

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 678.368 | 3.8 | 87.335 | 0.07979 | 0.003 | 4.4 ug/L |
| | Pb | 207 | 560.691 | 5.0 | 77.001 | 0.07809 | 0.005 | 5.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 114.525 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 111.129 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 110.478 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 106.223 | | | |
| > Ho | 165 | | 109.909 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Monday, November 13, 2006 19:59:17

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 3.064

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1233.104 | 0.4 | 63.001 | 1.05661 | 0.011 | 1.0 | ug/L |
| Al | 27 | 76900.346 | 1.6 | 2334.350 | 11.08743 | 0.262 | 2.4 | ug/L |
| > Sc | 45 | 374311.176 | 0.8 | 381869.082 | | | | ug/L |
| V | 51 | 22171.553 | 1.8 | 4488.603 | 1.10518 | 0.015 | 1.4 | ug/L |
| Cr | 52 | 32108.395 | 0.9 | 15368.650 | 1.21436 | 0.012 | 1.0 | ug/L |
| Cr | 53 | 2703.466 | 1.3 | 814.381 | 1.07825 | 0.010 | 0.9 | ug/L |
| Mn | 55 | 22882.610 | 2.0 | 494.020 | 1.09459 | 0.034 | 3.1 | ug/L |
| Co | 59 | 19004.171 | 1.5 | 188.671 | 1.05557 | 0.018 | 1.7 | ug/L |
| Ni | 60 | 4439.227 | 1.4 | 136.669 | 1.07521 | 0.023 | 2.2 | ug/L |
| Ni | 62 | 765.710 | 3.1 | 143.669 | 1.04279 | 0.055 | 5.2 | ug/L |
| Cu | 63 | 9830.226 | 0.8 | 212.338 | 1.05149 | 0.018 | 1.7 | ug/L |
| Cu | 65 | 4858.799 | 2.7 | 189.671 | 1.05342 | 0.032 | 3.0 | ug/L |
| Zn | 66 | 17743.715 | 0.6 | 1515.486 | 6.24395 | 0.114 | 1.8 | ug/L |
| Zn | 67 | 2855.184 | 1.5 | 342.344 | 5.56300 | 0.041 | 0.7 | ug/L |
| Zn | 68 | 13037.989 | 1.1 | 1170.427 | 6.21578 | 0.049 | 0.8 | ug/L |
| > Ge | 72 | 247491.061 | 1.1 | 244883.968 | | | | ug/L |
| As | 75 | 3381.720 | 0.4 | 124.002 | 1.01239 | 0.015 | 1.5 | ug/L |
| Se | 77 | 445.879 | 1.5 | 216.736 | 0.94476 | 0.030 | 3.2 | ug/L |
| Se | 78 | 17196.810 | 1.1 | 16119.238 | 1.16065 | 0.326 | 28.1 | mg/L |
| Se | 82 | 2099.798 | 0.9 | 1872.010 | 0.64527 | 0.049 | 7.6 | ug/L |
| Kr | 83 | 1823.218 | 2.6 | 1902.236 | | | | mg/L |
| Y | 89 | 410328.826 | 0.3 | 408188.389 | | | | ug/L |
| Mo | 95 | 5814.420 | 2.2 | 112.002 | 1.02248 | 0.025 | 2.4 | ug/L |
| Mo | 97 | 3565.465 | 1.6 | 64.001 | 1.03237 | 0.018 | 1.8 | ug/L |
| Mo | 98 | 9064.926 | 1.1 | 98.282 | 1.04850 | 0.009 | 0.8 | ug/L |
| Rh | 103 | 341472.298 | 1.7 | 340052.119 | | | | ug/L |
| Ag | 107 | 15053.735 | 0.4 | 91.335 | 1.09011 | 0.008 | 0.8 | ug/L |
| Ag | 109 | 13948.470 | 0.6 | 75.668 | 1.07564 | 0.005 | 0.4 | ug/L |
| Cd | 111 | 3558.818 | 2.7 | 218.275 | 1.06347 | 0.034 | 3.2 | ug/L |
| Cd | 114 | 7382.686 | 2.1 | 58.957 | 1.04932 | 0.025 | 2.4 | ug/L |
| > In | 115 | 370431.373 | 0.4 | 358352.924 | | | | ug/L |
| Sb | 121 | 10306.807 | 1.6 | 107.668 | 1.05835 | 0.018 | 1.7 | ug/L |
| Sb | 123 | 7911.799 | 1.5 | 79.665 | 1.05597 | 0.016 | 1.5 | ug/L |
| Ba | 135 | 2541.413 | 0.9 | 46.667 | 1.00488 | 0.016 | 1.6 | ug/L |
| Ba | 137 | 4540.616 | 1.7 | 47.001 | 1.06050 | 0.012 | 1.2 | ug/L |
| > Tb | 159 | 412474.631 | 1.0 | 411268.087 | | | | ug/L |
| > Ho | 165 | 393479.867 | 1.1 | 390096.908 | | | | ug/L |
| Tl | 203 | 8676.602 | 0.6 | 60.001 | 1.07621 | 0.011 | 1.0 | ug/L |
| Tl | 205 | 19980.124 | 0.7 | 78.001 | 1.12501 | 0.017 | 1.6 | ug/L |
| Pb | 208 | 28267.624 | 1.1 | 320.672 | 1.09728 | 0.001 | 0.1 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Monday, November 13, 2006 20:02:17

Page 1

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 7231.876 | 1.3 | 87.335 | 1.06649 | 0.017 | 1.6 ug/L |
| | Pb | 207 | 6165.342 | 2.1 | 77.001 | 1.08805 | 0.016 | 1.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 105.661 | | | | |
| Al | 27 | 110.874 | | | | |
| > Sc | 45 | | 98.021 | | | |
| V | 51 | 110.518 | | | | |
| Cr | 52 | 121.436 | | | | |
| Cr | 53 | 107.825 | | | | |
| Mn | 55 | 109.459 | | | | |
| Co | 59 | 105.557 | | | | |
| Ni | 60 | 107.521 | | | | |
| Ni | 62 | 104.279 | | | | |
| Cu | 63 | 105.149 | | | | |
| Cu | 65 | 105.342 | | | | |
| Zn | 66 | 124.879 | | | | |
| Zn | 67 | 111.260 | | | | |
| Zn | 68 | 124.316 | | | | |
| > Ge | 72 | | 101.065 | | | |
| As | 75 | 101.239 | | | | |
| Se | 77 | 94.476 | | | | |
| Se | 78 | 116.065 | | | | |
| Se | 82 | 64.527 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 102.248 | | | | |
| Mo | 97 | 103.237 | | | | |
| Mo | 98 | 104.850 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 109.011 | | | | |
| Ag | 109 | 107.564 | | | | |
| Cd | 111 | 106.347 | | | | |
| Cd | 114 | 104.932 | | | | |
| > In | 115 | | 103.371 | | | |
| Sb | 121 | 105.835 | | | | |
| Sb | 123 | 105.597 | | | | |
| Ba | 135 | 100.488 | | | | |
| Ba | 137 | 106.050 | | | | |
| > Tb | 159 | | 100.293 | | | |
| > Ho | 165 | | 100.867 | | | |
| Tl | 203 | 107.621 | | | | |
| Tl | 205 | 112.501 | | | | |
| Pb | 208 | 109.728 | | | | |
| Pb | 206 | 106.649 | | | | |
| Pb | 207 | 108.805 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 13, 2006 20:05:15

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 6.065

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 56421.937 | 1.0 | 63.001 | 50.59481 | 1.512 | 3.0 | ug/L |
| Al | 27 | 342213.484 | 2.1 | 2334.350 | 50.26551 | 1.774 | 3.5 | ug/L |
| > Sc | 45 | 376247.983 | 2.0 | 381869.082 | | | | ug/L |
| V | 51 | 837645.946 | 1.9 | 4488.603 | 51.57138 | 1.712 | 3.3 | ug/L |
| Cr | 52 | 723203.313 | 1.0 | 15368.650 | 50.20485 | 1.327 | 2.6 | ug/L |
| Cr | 53 | 88733.822 | 0.8 | 814.381 | 49.52732 | 1.313 | 2.7 | ug/L |
| Mn | 55 | 1036280.076 | 2.2 | 494.020 | 50.96021 | 1.568 | 3.1 | ug/L |
| Co | 59 | 890628.817 | 1.9 | 188.671 | 50.26013 | 0.527 | 1.0 | ug/L |
| Ni | 60 | 194597.510 | 3.1 | 136.669 | 48.91405 | 1.887 | 3.9 | ug/L |
| Ni | 62 | 29476.336 | 0.9 | 143.669 | 49.57821 | 0.455 | 0.9 | ug/L |
| Cu | 63 | 468707.704 | 2.3 | 212.338 | 51.53546 | 0.714 | 1.4 | ug/L |
| Cu | 65 | 222912.667 | 2.0 | 189.671 | 50.58411 | 1.476 | 2.9 | ug/L |
| Zn | 66 | 137508.293 | 0.7 | 1515.486 | 52.68928 | 0.298 | 0.6 | ug/L |
| Zn | 67 | 24049.561 | 0.9 | 342.344 | 52.88531 | 0.883 | 1.7 | ug/L |
| Zn | 68 | 100456.755 | 2.4 | 1170.427 | 52.37974 | 1.580 | 3.0 | ug/L |
| > Ge | 72 | 245988.254 | 1.2 | 244883.968 | | | | ug/L |
| As | 75 | 155181.329 | 1.6 | 124.002 | 48.49924 | 0.917 | 1.9 | ug/L |
| Se | 77 | 12679.974 | 1.3 | 216.736 | 52.21843 | 0.537 | 1.0 | ug/L |
| Se | 78 | 55747.169 | 2.2 | 16119.238 | 50.92723 | 1.982 | 3.9 | mg/L |
| Se | 82 | 18420.670 | 0.3 | 1872.010 | 51.65272 | 0.849 | 1.6 | ug/L |
| Kr | 83 | 1750.201 | 3.8 | 1902.236 | | | | mg/L |
| Y | 89 | 409827.276 | 1.4 | 408188.389 | | | | ug/L |
| Mo | 95 | 272174.434 | 0.6 | 112.002 | 49.33982 | 0.839 | 1.7 | ug/L |
| Mo | 97 | 164613.284 | 2.6 | 64.001 | 49.06607 | 1.382 | 2.8 | ug/L |
| Mo | 98 | 433288.127 | 1.7 | 98.282 | 51.22865 | 1.647 | 3.2 | ug/L |
| Rh | 103 | 329815.926 | 0.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 682383.129 | 2.3 | 91.335 | 50.24169 | 0.041 | 0.1 | ug/L |
| Ag | 109 | 658655.950 | 0.7 | 75.668 | 51.62278 | 0.791 | 1.5 | ug/L |
| Cd | 111 | 158875.878 | 1.1 | 218.275 | 51.15853 | 0.662 | 1.3 | ug/L |
| Cd | 114 | 350413.864 | 0.5 | 58.957 | 50.75359 | 1.113 | 2.2 | ug/L |
| > In | 115 | 366569.582 | 2.3 | 358352.924 | | | | ug/L |
| Sb | 121 | 474584.581 | 0.9 | 107.668 | 49.79366 | 1.509 | 3.0 | ug/L |
| Sb | 123 | 360253.751 | 0.8 | 79.665 | 49.10637 | 1.241 | 2.5 | ug/L |
| Ba | 135 | 123085.599 | 0.8 | 46.667 | 51.33723 | 0.461 | 0.9 | ug/L |
| Ba | 137 | 206782.468 | 2.5 | 47.001 | 50.53808 | 0.857 | 1.7 | ug/L |
| > Tb | 159 | 398197.008 | 0.9 | 411268.087 | | | | ug/L |
| > Ho | 165 | 387827.064 | 1.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 395270.162 | 1.6 | 60.001 | 50.07998 | 0.204 | 0.4 | ug/L |
| Tl | 205 | 909618.260 | 0.9 | 78.001 | 52.16730 | 1.011 | 1.9 | ug/L |
| Pb | 208 | 1278838.814 | 1.3 | 320.672 | 50.93641 | 0.353 | 0.7 | ug/L |

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 333675.780 | 1.7 | 87.335 | 50.52211 | 0.308 | 0.6 ug/L |
| | Pb | 207 | 270282.135 | 3.3 | 77.001 | 48.99200 | 1.001 | 2.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 101.190 | | | | |
| Al | 27 | 100.531 | | | | |
| > Sc | 45 | | 98.528 | | | |
| V | 51 | 103.143 | | | | |
| Cr | 52 | 100.410 | | | | |
| Cr | 53 | 99.055 | | | | |
| Mn | 55 | 101.920 | | | | |
| Co | 59 | 100.520 | | | | |
| Ni | 60 | 97.828 | | | | |
| Ni | 62 | 99.156 | | | | |
| Cu | 63 | 103.071 | | | | |
| Cu | 65 | 101.168 | | | | |
| Zn | 66 | 105.379 | | | | |
| Zn | 67 | 105.771 | | | | |
| Zn | 68 | 104.759 | | | | |
| > Ge | 72 | | 100.451 | | | |
| As | 75 | 96.998 | | | | |
| Se | 77 | 104.437 | | | | |
| Se | 78 | 101.854 | | | | |
| Se | 82 | 103.305 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 98.680 | | | | |
| Mo | 97 | 98.132 | | | | |
| Mo | 98 | 102.457 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 100.483 | | | | |
| Ag | 109 | 103.246 | | | | |
| Cd | 111 | 102.317 | | | | |
| Cd | 114 | 101.507 | | | | |
| > In | 115 | | 102.293 | | | |
| Sb | 121 | 99.587 | | | | |
| Sb | 123 | 98.213 | | | | |
| Ba | 135 | 102.674 | | | | |
| Ba | 137 | 101.076 | | | | |
| > Tb | 159 | | 96.822 | | | |
| > Ho | 165 | | 99.418 | | | |
| Tl | 203 | 100.160 | | | | |
| Tl | 205 | 104.335 | | | | |
| Pb | 208 | 101.873 | | | | |
| Pb | 206 | 101.044 | | | | |
| Pb | 207 | 97.984 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 13, 2006 20:11:13

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 7.066

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 61.668 | 4.1 | 63.001 | 0.00062 | 0.001 | 149.5 | ug/L |
| Al | 27 | 2560.752 | 1.0 | 2334.350 | 0.04550 | 0.008 | 18.2 | ug/L |
| > Sc | 45 | 369584.386 | 2.6 | 381869.082 | | | | ug/L |
| V | 51 | 4764.278 | 4.3 | 4488.603 | 0.02679 | 0.020 | 75.8 | ug/L |
| Cr | 52 | 15893.312 | 3.4 | 15368.650 | 0.07426 | 0.057 | 76.4 | ug/L |
| Cr | 53 | 689.369 | 5.4 | 814.381 | -0.05614 | 0.031 | 54.4 | ug/L |
| Mn | 55 | 496.020 | 2.4 | 494.020 | 0.00015 | 0.000 | 131.4 | ug/L |
| Co | 59 | 139.336 | 18.1 | 188.671 | -0.00279 | 0.001 | 46.4 | ug/L |
| Ni | 60 | 140.336 | 9.5 | 136.669 | 0.00100 | 0.003 | 331.4 | ug/L |
| Ni | 62 | 133.336 | 9.6 | 143.669 | -0.01679 | 0.025 | 150.8 | ug/L |
| Cu | 63 | 219.672 | 3.1 | 212.338 | 0.00088 | 0.001 | 130.2 | ug/L |
| Cu | 65 | 176.670 | 10.7 | 189.671 | -0.00282 | 0.005 | 174.7 | ug/L |
| Zn | 66 | 1522.488 | 1.2 | 1515.486 | 0.00420 | 0.015 | 365.9 | ug/L |
| Zn | 67 | 305.009 | 2.9 | 342.344 | -0.08219 | 0.013 | 15.4 | ug/L |
| Zn | 68 | 1217.434 | 1.9 | 1170.427 | 0.02658 | 0.022 | 83.7 | ug/L |
| > Ge | 72 | 244339.365 | 1.6 | 244883.968 | | | | ug/L |
| As | 75 | 172.670 | 4.2 | 124.002 | 0.01540 | 0.002 | 9.9 | ug/L |
| Se | 77 | 227.136 | 5.2 | 216.736 | 0.04611 | 0.053 | 115.8 | ug/L |
| Se | 78 | 16181.180 | 1.1 | 16119.238 | 0.13059 | 0.430 | 328.9 | mg/L |
| Se | 82 | 1814.798 | 1.0 | 1872.010 | -0.16522 | 0.144 | 87.1 | ug/L |
| Kr | 83 | 1787.543 | 2.4 | 1902.236 | | | | mg/L |
| Y | 89 | 402323.243 | 1.1 | 408188.389 | | | | ug/L |
| Mo | 95 | 844.719 | 19.1 | 112.002 | 0.13366 | 0.031 | 23.4 | ug/L |
| Mo | 97 | 496.687 | 23.7 | 64.001 | 0.12986 | 0.037 | 28.8 | ug/L |
| Mo | 98 | 1221.676 | 18.1 | 98.282 | 0.13372 | 0.028 | 21.0 | ug/L |
| Rh | 103 | 339132.009 | 3.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 179.004 | 8.4 | 91.335 | 0.00641 | 0.001 | 20.8 | ug/L |
| Ag | 109 | 150.670 | 9.7 | 75.668 | 0.00583 | 0.001 | 21.9 | ug/L |
| Cd | 111 | 204.829 | 6.4 | 218.275 | -0.00544 | 0.005 | 97.4 | ug/L |
| Cd | 114 | 47.918 | 20.2 | 58.957 | -0.00173 | 0.002 | 87.9 | ug/L |
| > In | 115 | 364058.474 | 1.6 | 358352.924 | | | | ug/L |
| Sb | 121 | 1417.470 | 15.7 | 107.668 | 0.13830 | 0.025 | 18.0 | ug/L |
| Sb | 123 | 1063.010 | 13.4 | 79.665 | 0.13486 | 0.020 | 15.2 | ug/L |
| Ba | 135 | 49.334 | 15.5 | 46.667 | 0.00109 | 0.003 | 261.5 | ug/L |
| Ba | 137 | 50.334 | 16.1 | 47.001 | 0.00080 | 0.002 | 229.9 | ug/L |
| > Tb | 159 | 410514.100 | 1.7 | 411268.087 | | | | ug/L |
| > Ho | 165 | 385764.807 | 0.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 83.001 | 6.3 | 60.001 | 0.00301 | 0.001 | 21.5 | ug/L |
| Tl | 205 | 150.670 | 8.8 | 78.001 | 0.00424 | 0.001 | 18.2 | ug/L |
| Pb | 208 | 446.676 | 4.8 | 320.672 | 0.00519 | 0.001 | 15.2 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Monday, November 13, 2006 20:14:13

Page 1

| | | | | | | | | |
|---|----|-----|---------|-----|--------|---------|-------|-----------|
| I | Pb | 206 | 120.335 | 7.1 | 87.335 | 0.00518 | 0.001 | 26.1 ug/L |
| L | Pb | 207 | 107.668 | 2.7 | 77.001 | 0.00575 | 0.001 | 10.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 96.783 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 99.778 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 101.592 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.817 | | | |
| > Ho | 165 | | 98.889 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950466

Sample Date/Time: Monday, November 13, 2006 20:17:10

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950466.067

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 78.668 | 10.2 | 63.001 | 0.00064 | 0.006 | 984.2 | ug/L |
| Al | 27 | 600599.928 | 1.6 | 2334.350 | 70.47625 | 1.796 | 2.5 | ug/L |
| > Sc | 45 | 471762.269 | 0.9 | 381869.082 | | | | ug/L |
| V | 51 | 11104.477 | 2.6 | 4488.603 | 0.27431 | 0.013 | 4.6 | ug/L |
| Cr | 52 | 47936.709 | 3.0 | 15368.650 | 1.63672 | 0.085 | 5.2 | ug/L |
| Cr | 53 | 4287.813 | 2.3 | 814.381 | 1.47395 | 0.056 | 3.8 | ug/L |
| Mn | 55 | 1305413.404 | 1.9 | 494.020 | 60.87653 | 1.301 | 2.1 | ug/L |
| Co | 59 | 5296.737 | 3.2 | 188.671 | 0.27287 | 0.010 | 3.6 | ug/L |
| Ni | 60 | 22096.479 | 1.0 | 136.669 | 5.23547 | 0.040 | 0.8 | ug/L |
| Ni | 62 | 2321.680 | 2.4 | 143.669 | 3.47746 | 0.080 | 2.3 | ug/L |
| Cu | 63 | 14813.303 | 1.0 | 212.338 | 1.52207 | 0.020 | 1.3 | ug/L |
| Cu | 65 | 7441.397 | 2.7 | 189.671 | 1.55920 | 0.039 | 2.5 | ug/L |
| Zn | 66 | 9803.528 | 0.5 | 1515.486 | 3.01253 | 0.023 | 0.8 | ug/L |
| Zn | 67 | 1964.585 | 4.2 | 342.344 | 3.38882 | 0.165 | 4.9 | ug/L |
| Zn | 68 | 9507.850 | 1.8 | 1170.427 | 4.13657 | 0.094 | 2.3 | ug/L |
| > Ge | 72 | 259372.495 | 0.2 | 244883.968 | | | | ug/L |
| As | 75 | 1130.755 | 1.4 | 124.002 | 0.29645 | 0.006 | 1.9 | ug/L |
| Se | 77 | 364.475 | 1.4 | 216.736 | 0.53615 | 0.022 | 4.2 | ug/L |
| Se | 78 | 18188.415 | 0.4 | 16119.238 | 1.36183 | 0.088 | 6.5 | mg/L |
| Se | 82 | 1997.239 | 0.9 | 1872.010 | 0.04296 | 0.066 | 153.3 | ug/L |
| Kr | 83 | 1894.901 | 1.8 | 1902.236 | | | | mg/L |
| Y | 89 | 449765.691 | 2.1 | 408188.389 | | | | ug/L |
| Mo | 95 | 3130.954 | 6.1 | 112.002 | 0.54298 | 0.026 | 4.8 | ug/L |
| Mo | 97 | 2016.265 | 6.6 | 64.001 | 0.57740 | 0.031 | 5.3 | ug/L |
| Mo | 98 | 4829.953 | 7.6 | 98.282 | 0.55508 | 0.036 | 6.5 | ug/L |
| Rh | 103 | 343915.383 | 1.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 109.002 | 7.3 | 91.335 | 0.00109 | 0.000 | 42.3 | ug/L |
| Ag | 109 | 95.668 | 11.2 | 75.668 | 0.00139 | 0.001 | 66.7 | ug/L |
| Cd | 111 | 385.781 | 5.4 | 218.275 | 0.05159 | 0.007 | 12.7 | ug/L |
| Cd | 114 | 274.272 | 26.4 | 58.957 | 0.03065 | 0.010 | 32.2 | ug/L |
| > In | 115 | 368956.891 | 1.5 | 358352.924 | | | | ug/L |
| Sb | 121 | 1454.477 | 14.3 | 107.668 | 0.13985 | 0.019 | 13.8 | ug/L |
| Sb | 123 | 1077.017 | 10.4 | 79.665 | 0.13462 | 0.013 | 9.8 | ug/L |
| Ba | 135 | 41055.963 | 0.1 | 46.667 | 16.22356 | 0.202 | 1.2 | ug/L |
| Ba | 137 | 70974.058 | 1.7 | 47.001 | 16.44346 | 0.466 | 2.8 | ug/L |
| > Tb | 159 | 419987.198 | 1.2 | 411268.087 | | | | ug/L |
| > Ho | 165 | 396341.437 | 2.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 283.674 | 4.0 | 60.001 | 0.02761 | 0.001 | 2.8 | ug/L |
| Tl | 205 | 626.697 | 1.9 | 78.001 | 0.03073 | 0.001 | 3.7 | ug/L |
| Pb | 208 | 3737.366 | 0.7 | 320.672 | 0.13304 | 0.003 | 2.5 | ug/L |

Sample ID: 950466

Report Date/Time: Monday, November 13, 2006 20:20:12

Page 1

321

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 959.398 | 1.7 | 87.335 | 0.12910 | 0.005 | 4.0 ug/L |
| | Pb | 207 | 800.380 | 1.3 | 77.001 | 0.12815 | 0.001 | 0.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 123.540 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 105.916 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.959 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 102.120 | | | |
| > Ho | 165 | | 101.601 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950467

Sample Date/Time: Monday, November 13, 2006 20:23:08

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950467.068

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 81.668 | 5.1 | 63.001 | 0.00758 | 0.004 | 47.9 | ug/L |
| Al | 27 | 127679.988 | 0.6 | 2334.350 | 15.95663 | 0.378 | 2.4 | ug/L |
| > Sc | 45 | 435907.768 | 2.5 | 381869.082 | | | | ug/L |
| V | 51 | 11002.250 | 4.7 | 4488.603 | 0.31379 | 0.017 | 5.5 | ug/L |
| Cr | 52 | 76336.497 | 1.1 | 15368.650 | 3.59810 | 0.066 | 1.8 | ug/L |
| Cr | 53 | 7693.961 | 1.5 | 814.381 | 3.28877 | 0.096 | 2.9 | ug/L |
| Mn | 55 | 9398338.886 | 2.0 | 494.020 | 427.10051 | 9.429 | 2.2 | ug/L |
| Co | 59 | 25694.828 | 2.7 | 188.671 | 1.32921 | 0.031 | 2.4 | ug/L |
| Ni | 60 | 34575.277 | 2.1 | 136.669 | 7.99910 | 0.195 | 2.4 | ug/L |
| Ni | 62 | 3041.253 | 4.2 | 143.669 | 4.50554 | 0.214 | 4.7 | ug/L |
| Cu | 63 | 28706.991 | 1.8 | 212.338 | 2.89418 | 0.050 | 1.7 | ug/L |
| Cu | 65 | 15402.728 | 4.5 | 189.671 | 3.18773 | 0.133 | 4.2 | ug/L |
| Zn | 66 | 8987.936 | 2.4 | 1515.486 | 2.62744 | 0.075 | 2.9 | ug/L |
| Zn | 67 | 3044.587 | 3.6 | 342.344 | 5.50701 | 0.210 | 3.8 | ug/L |
| Zn | 68 | 12026.793 | 0.4 | 1170.427 | 5.24117 | 0.026 | 0.5 | ug/L |
| > Ge | 72 | 266253.221 | 0.4 | 244883.968 | | | | ug/L |
| As | 75 | 2336.351 | 4.0 | 124.002 | 0.63608 | 0.025 | 3.9 | ug/L |
| Se | 77 | 450.412 | 3.0 | 216.736 | 0.83128 | 0.047 | 5.7 | ug/L |
| Se | 78 | 18606.450 | 0.3 | 16119.238 | 1.28522 | 0.072 | 5.6 | mg/L |
| Se | 82 | 2954.324 | 0.9 | 1872.010 | 2.65101 | 0.078 | 3.0 | ug/L |
| Kr | 83 | 1946.247 | 3.1 | 1902.236 | | | | mg/L |
| Y | 89 | 451074.797 | 0.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 12096.562 | 1.1 | 112.002 | 2.17154 | 0.013 | 0.6 | ug/L |
| Mo | 97 | 7581.523 | 1.5 | 64.001 | 2.24009 | 0.053 | 2.4 | ug/L |
| Mo | 98 | 18245.803 | 2.9 | 98.282 | 2.14417 | 0.065 | 3.0 | ug/L |
| Rh | 103 | 335656.548 | 1.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 126.336 | 18.8 | 91.335 | 0.00241 | 0.002 | 70.4 | ug/L |
| Ag | 109 | 90.668 | 13.3 | 75.668 | 0.00103 | 0.001 | 82.1 | ug/L |
| Cd | 111 | 353.478 | 5.5 | 218.275 | 0.04190 | 0.005 | 12.5 | ug/L |
| Cd | 114 | 317.921 | 12.4 | 58.957 | 0.03724 | 0.005 | 13.9 | ug/L |
| > In | 115 | 366742.209 | 1.6 | 358352.924 | | | | ug/L |
| Sb | 121 | 2036.269 | 4.1 | 107.668 | 0.20194 | 0.008 | 4.0 | ug/L |
| Sb | 123 | 1558.140 | 2.2 | 79.665 | 0.20122 | 0.007 | 3.5 | ug/L |
| Ba | 135 | 174560.811 | 0.8 | 46.667 | 70.89487 | 1.476 | 2.1 | ug/L |
| Ba | 137 | 297996.002 | 1.6 | 47.001 | 70.92794 | 2.040 | 2.9 | ug/L |
| > Tb | 159 | 409036.917 | 1.3 | 411268.087 | | | | ug/L |
| > Ho | 165 | 386717.333 | 0.8 | 390096.908 | | | | ug/L |
| Tl | 203 | 1678.853 | 4.4 | 60.001 | 0.20585 | 0.011 | 5.3 | ug/L |
| Tl | 205 | 3839.256 | 1.2 | 78.001 | 0.21636 | 0.003 | 1.2 | ug/L |
| Pb | 208 | 2777.206 | 2.4 | 320.672 | 0.09826 | 0.003 | 2.6 | ug/L |

Sample ID: 950467

Report Date/Time: Monday, November 13, 2006 20:26:10

Page 1

324

| | | | | | | | | |
|--|----|-----|---------|------|--------|---------|-------|-----------|
| | Pb | 206 | 734.373 | 10.9 | 87.335 | 0.09837 | 0.012 | 12.0 ug/L |
| | Pb | 207 | 612.695 | 2.3 | 77.001 | 0.09754 | 0.002 | 2.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 114.151 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 108.726 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.341 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.457 | | | |
| > Ho | 165 | | 99.134 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| L Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950468

Sample Date/Time: Monday, November 13, 2006 20:29:07

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950468.069

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 88.001 | 9.7 | 63.001 | 0.01053 | 0.006 | 52.5 | ug/L |
| Al | 27 | 87421.930 | 2.8 | 2334.350 | 10.50690 | 0.300 | 2.9 | ug/L |
| Sc | 45 | 448277.494 | 1.4 | 381869.082 | | | | ug/L |
| V | 51 | 12416.717 | 5.6 | 4488.603 | 0.37101 | 0.030 | 8.0 | ug/L |
| Cr | 52 | 69794.424 | 0.5 | 15368.650 | 3.07925 | 0.037 | 1.2 | ug/L |
| Cr | 53 | 7064.064 | 2.1 | 814.381 | 2.88692 | 0.079 | 2.7 | ug/L |
| Mn | 55 | 10146697.195 | 1.2 | 494.020 | 451.93124 | 7.977 | 1.8 | ug/L |
| Co | 59 | 28675.563 | 2.7 | 188.671 | 1.45481 | 0.033 | 2.3 | ug/L |
| Ni | 60 | 36200.175 | 2.1 | 136.669 | 8.20835 | 0.160 | 1.9 | ug/L |
| Ni | 62 | 3113.946 | 1.9 | 143.669 | 4.52183 | 0.102 | 2.3 | ug/L |
| Cu | 63 | 40589.028 | 1.5 | 212.338 | 4.01942 | 0.036 | 0.9 | ug/L |
| Cu | 65 | 21094.548 | 1.7 | 189.671 | 4.29390 | 0.072 | 1.7 | ug/L |
| Zn | 66 | 10744.033 | 3.0 | 1515.486 | 3.17996 | 0.138 | 4.3 | ug/L |
| Zn | 67 | 3279.345 | 2.2 | 342.344 | 5.85619 | 0.117 | 2.0 | ug/L |
| Zn | 68 | 13207.262 | 3.0 | 1170.427 | 5.68765 | 0.158 | 2.8 | ug/L |
| Ge | 72 | 271671.084 | 0.7 | 244883.968 | | | | ug/L |
| As | 75 | 2423.377 | 3.9 | 124.002 | 0.64724 | 0.023 | 3.6 | ug/L |
| Se | 77 | 446.679 | 2.1 | 216.736 | 0.78240 | 0.031 | 3.9 | ug/L |
| Se | 78 | 19528.363 | 0.9 | 16119.238 | 1.91819 | 0.093 | 4.8 | mg/L |
| Se | 82 | 2984.068 | 1.2 | 1872.010 | 2.56497 | 0.057 | 2.2 | ug/L |
| Kr | 83 | 2029.934 | 1.5 | 1902.236 | | | | mg/L |
| Y | 89 | 461381.471 | 3.0 | 408188.389 | | | | ug/L |
| Mo | 95 | 12183.023 | 2.1 | 112.002 | 2.10470 | 0.026 | 1.2 | ug/L |
| Mo | 97 | 7528.141 | 1.1 | 64.001 | 2.14022 | 0.024 | 1.1 | ug/L |
| Mo | 98 | 18437.037 | 2.2 | 98.282 | 2.08518 | 0.022 | 1.0 | ug/L |
| Rh | 103 | 352685.086 | 1.3 | 340052.119 | | | | ug/L |
| Ag | 107 | 127.669 | 9.5 | 91.335 | 0.00216 | 0.001 | 32.4 | ug/L |
| Ag | 109 | 107.002 | 8.4 | 75.668 | 0.00201 | 0.001 | 41.3 | ug/L |
| Cd | 111 | 363.627 | 10.4 | 218.275 | 0.04070 | 0.010 | 24.1 | ug/L |
| Cd | 114 | 354.647 | 21.7 | 58.957 | 0.04083 | 0.012 | 28.7 | ug/L |
| In | 115 | 380968.738 | 1.9 | 358352.924 | | | | ug/L |
| Sb | 121 | 1966.585 | 2.9 | 107.668 | 0.18704 | 0.009 | 4.8 | ug/L |
| Sb | 123 | 1461.461 | 1.8 | 79.665 | 0.18056 | 0.003 | 1.5 | ug/L |
| Ba | 135 | 179566.835 | 0.5 | 46.667 | 70.48841 | 1.047 | 1.5 | ug/L |
| Ba | 137 | 308401.768 | 1.0 | 47.001 | 70.94593 | 1.348 | 1.9 | ug/L |
| Tb | 159 | 423161.071 | 1.0 | 411268.087 | | | | ug/L |
| Ho | 165 | 403794.532 | 0.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 1681.186 | 1.8 | 60.001 | 0.19706 | 0.004 | 1.9 | ug/L |
| Tl | 205 | 3918.961 | 2.3 | 78.001 | 0.21141 | 0.005 | 2.3 | ug/L |
| Pb | 208 | 3828.714 | 0.6 | 320.672 | 0.13380 | 0.001 | 0.7 | ug/L |

Sample ID: 950468

Report Date/Time: Monday, November 13, 2006 20:32:08

Page 1

327

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 1019.739 | 3.2 | 87.335 | 0.13519 | 0.005 | 3.5 ug/L |
| | Pb | 207 | 804.714 | 5.5 | 77.001 | 0.12628 | 0.008 | 6.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 117.390 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 110.939 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 106.311 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 102.892 | | | |
| > Ho | 165 | | 103.511 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950469

Sample Date/Time: Monday, November 13, 2006 20:35:05

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950469.070

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 87.335 | 16.1 | 63.001 | 0.00792 | 0.011 | 142.7 | ug/L |
| Al | 27 | 28502.950 | 1.0 | 2334.350 | 3.07446 | 0.082 | 2.7 | ug/L |
| Sc | 45 | 464389.721 | 1.7 | 381869.082 | | | | ug/L |
| V | 51 | 2593.116 | 72.6 | 4488.603 | -0.14383 | 0.093 | 64.8 | ug/L |
| Cr | 52 | 179375.124 | 0.6 | 15368.650 | 9.22907 | 0.111 | 1.2 | ug/L |
| Cr | 53 | 20074.018 | 1.0 | 814.381 | 8.70825 | 0.235 | 2.7 | ug/L |
| Mn | 55 | 10012645.108 | 3.3 | 494.020 | 452.10623 | 20.528 | 4.5 | ug/L |
| Co | 59 | 10840.825 | 2.5 | 188.671 | 0.55101 | 0.021 | 3.9 | ug/L |
| Ni | 60 | 46602.775 | 1.9 | 136.669 | 10.71951 | 0.082 | 0.8 | ug/L |
| Ni | 62 | 3979.323 | 1.0 | 143.669 | 5.92812 | 0.038 | 0.6 | ug/L |
| Cu | 63 | 12880.078 | 2.1 | 212.338 | 1.27724 | 0.048 | 3.8 | ug/L |
| Cu | 65 | 6618.694 | 1.4 | 189.671 | 1.33606 | 0.027 | 2.1 | ug/L |
| Zn | 66 | 9844.243 | 0.2 | 1515.486 | 2.91074 | 0.061 | 2.1 | ug/L |
| Zn | 67 | 5375.454 | 1.7 | 342.344 | 10.23637 | 0.141 | 1.4 | ug/L |
| Zn | 68 | 21169.739 | 1.7 | 1170.427 | 9.62865 | 0.227 | 2.4 | ug/L |
| Ge | 72 | 268070.102 | 1.6 | 244883.968 | | | | ug/L |
| As | 75 | 36313.318 | 1.3 | 124.002 | 10.38315 | 0.042 | 0.4 | ug/L |
| Se | 77 | 333.940 | 2.2 | 216.736 | 0.37201 | 0.038 | 10.1 | ug/L |
| Se | 78 | 18869.702 | 0.7 | 16119.238 | 1.44913 | 0.325 | 22.4 | mg/L |
| Se | 82 | 2088.928 | 0.4 | 1872.010 | 0.11450 | 0.080 | 69.6 | ug/L |
| Kr | 83 | 2056.274 | 2.6 | 1902.236 | | | | mg/L |
| Y | 89 | 479649.399 | 2.8 | 408188.389 | | | | ug/L |
| Mo | 95 | 14073.350 | 1.9 | 112.002 | 2.35966 | 0.045 | 1.9 | ug/L |
| Mo | 97 | 8852.121 | 0.9 | 64.001 | 2.44246 | 0.023 | 0.9 | ug/L |
| Mo | 98 | 21568.803 | 1.4 | 98.282 | 2.36703 | 0.057 | 2.4 | ug/L |
| Rh | 103 | 361477.409 | 0.1 | 340052.119 | | | | ug/L |
| Ag | 107 | 87.668 | 12.6 | 91.335 | -0.00086 | 0.001 | 80.4 | ug/L |
| Ag | 109 | 63.668 | 12.8 | 75.668 | -0.00141 | 0.001 | 45.5 | ug/L |
| Cd | 111 | 266.861 | 18.0 | 218.275 | 0.00820 | 0.014 | 168.7 | ug/L |
| Cd | 114 | 23.408 | 351.8 | 58.957 | -0.00557 | 0.011 | 200.2 | ug/L |
| In | 115 | 392945.786 | 1.0 | 358352.924 | | | | ug/L |
| Sb | 121 | 324.343 | 4.9 | 107.668 | 0.02018 | 0.001 | 6.1 | ug/L |
| Sb | 123 | 243.869 | 6.6 | 79.665 | 0.01989 | 0.002 | 8.8 | ug/L |
| Ba | 135 | 401896.540 | 1.0 | 46.667 | 151.35696 | 0.969 | 0.6 | ug/L |
| Ba | 137 | 672738.193 | 1.8 | 47.001 | 148.47706 | 3.494 | 2.4 | ug/L |
| Tb | 159 | 441097.786 | 1.0 | 411268.087 | | | | ug/L |
| Ho | 165 | 416340.932 | 1.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 188.337 | 21.6 | 60.001 | 0.01465 | 0.005 | 31.3 | ug/L |
| Tl | 205 | 419.015 | 11.4 | 78.001 | 0.01792 | 0.002 | 13.2 | ug/L |
| Pb | 208 | 2490.170 | 2.2 | 320.672 | 0.07973 | 0.003 | 3.4 | ug/L |

Sample ID: 950469

Report Date/Time: Monday, November 13, 2006 20:38:07

Page 1

330

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 644.031 | 2.2 | 87.335 | 0.07773 | 0.003 | 3.6 ug/L |
| | Pb | 207 | 538.689 | 1.7 | 77.001 | 0.07713 | 0.002 | 3.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 121.610 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 109.468 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 109.653 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 107.253 | | | |
| > Ho | 165 | | 106.728 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| L Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950470

Sample Date/Time: Monday, November 13, 2006 20:41:04

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950470.071

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 100.002 | 8.2 | 63.001 | 0.01301 | 0.005 | 40.6 | ug/L |
| Al | 27 | 302099.680 | 3.9 | 2334.350 | 33.85874 | 1.199 | 3.5 | ug/L |
| Sc | 45 | 491257.313 | 0.9 | 381869.082 | | | | ug/L |
| V | 51 | 9100.228 | 4.1 | 4488.603 | 0.15756 | 0.016 | 10.2 | ug/L |
| Cr | 52 | 88776.062 | 2.2 | 15368.650 | 3.74687 | 0.142 | 3.8 | ug/L |
| Cr | 53 | 9451.453 | 1.9 | 814.381 | 3.62384 | 0.050 | 1.4 | ug/L |
| Mn | 55 | 1811421.238 | 2.0 | 494.020 | 82.47318 | 2.416 | 2.9 | ug/L |
| Co | 59 | 18409.164 | 1.3 | 188.671 | 0.95121 | 0.002 | 0.3 | ug/L |
| Ni | 60 | 74544.702 | 1.2 | 136.669 | 17.32137 | 0.359 | 2.1 | ug/L |
| Ni | 62 | 9091.716 | 2.5 | 143.669 | 13.98454 | 0.513 | 3.7 | ug/L |
| Cu | 63 | 27150.766 | 1.1 | 212.338 | 2.74176 | 0.054 | 2.0 | ug/L |
| Cu | 65 | 13497.396 | 2.8 | 189.671 | 2.79367 | 0.061 | 2.2 | ug/L |
| Zn | 66 | 12863.051 | 2.1 | 1515.486 | 4.02319 | 0.038 | 0.9 | ug/L |
| Zn | 67 | 2980.229 | 2.0 | 342.344 | 5.38798 | 0.179 | 3.3 | ug/L |
| Zn | 68 | 13265.694 | 3.9 | 1170.427 | 5.85950 | 0.309 | 5.3 | ug/L |
| Ge | 72 | 265737.224 | 1.3 | 244883.968 | | | | ug/L |
| As | 75 | 1902.570 | 2.2 | 124.002 | 0.51203 | 0.019 | 3.7 | ug/L |
| Se | 77 | 359.674 | 0.8 | 216.736 | 0.48299 | 0.023 | 4.7 | ug/L |
| Se | 78 | 18598.378 | 0.9 | 16119.238 | 1.32231 | 0.459 | 34.7 | mg/L |
| Se | 82 | 2114.668 | 1.1 | 1872.010 | 0.24138 | 0.109 | 45.2 | ug/L |
| Kr | 83 | 1991.925 | 1.8 | 1902.236 | | | | mg/L |
| Y | 89 | 500951.147 | 1.1 | 408188.389 | | | | ug/L |
| Mo | 95 | 1281.445 | 1.5 | 112.002 | 0.19259 | 0.008 | 4.2 | ug/L |
| Mo | 97 | 784.045 | 5.1 | 64.001 | 0.19520 | 0.015 | 7.5 | ug/L |
| Mo | 98 | 1840.578 | 2.8 | 98.282 | 0.18784 | 0.005 | 2.9 | ug/L |
| Rh | 103 | 354020.051 | 1.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 152.336 | 3.6 | 91.335 | 0.00342 | 0.000 | 8.5 | ug/L |
| Ag | 109 | 119.335 | 3.4 | 75.668 | 0.00252 | 0.000 | 17.2 | ug/L |
| Cd | 111 | 639.989 | 6.5 | 218.275 | 0.11728 | 0.009 | 7.4 | ug/L |
| Cd | 114 | 934.959 | 2.1 | 58.957 | 0.11554 | 0.001 | 0.7 | ug/L |
| In | 115 | 399398.703 | 2.3 | 358352.924 | | | | ug/L |
| Sb | 121 | 586.360 | 1.8 | 107.668 | 0.04491 | 0.001 | 2.8 | ug/L |
| Sb | 123 | 436.260 | 4.4 | 79.665 | 0.04349 | 0.003 | 6.9 | ug/L |
| Ba | 135 | 109261.506 | 1.7 | 46.667 | 40.95198 | 1.041 | 2.5 | ug/L |
| Ba | 137 | 188689.609 | 0.8 | 47.001 | 41.44536 | 0.646 | 1.6 | ug/L |
| Tb | 159 | 443121.437 | 0.8 | 411268.087 | | | | ug/L |
| Ho | 165 | 422125.187 | 2.1 | 390096.908 | | | | ug/L |
| Tl | 203 | 464.018 | 2.6 | 60.001 | 0.04647 | 0.001 | 2.2 | ug/L |
| Tl | 205 | 1104.751 | 0.9 | 78.001 | 0.05378 | 0.002 | 2.9 | ug/L |
| Pb | 208 | 3953.072 | 1.6 | 320.672 | 0.13205 | 0.005 | 3.7 | ug/L |

Sample ID: 950470

Report Date/Time: Monday, November 13, 2006 20:44:06

Page 1

333

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 1030.407 | 3.5 | 87.335 | 0.13029 | 0.006 | 5.0 ug/L |
| | Pb | 207 | 840.384 | 2.5 | 77.001 | 0.12621 | 0.006 | 4.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 128.645 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 108.516 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 111.454 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 107.745 | | | |
| > Ho | 165 | | 108.210 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950471

Sample Date/Time: Monday, November 13, 2006 20:47:03

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950471.072

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 98.668 | 1.5 | 63.001 | 0.00985 | 0.002 | 21.6 | ug/L |
| Al | 27 | 2173398.779 | 7.5 | 2334.350 | 237.39090 | 17.009 | 7.2 | ug/L |
| Sc | 45 | 508502.492 | 2.9 | 381869.082 | | | | ug/L |
| V | 51 | 16029.836 | 4.3 | 4488.603 | 0.46066 | 0.040 | 8.7 | ug/L |
| Cr | 52 | 152723.231 | 1.8 | 15368.650 | 6.94189 | 0.313 | 4.5 | ug/L |
| Cr | 53 | 17147.131 | 1.7 | 814.381 | 6.69525 | 0.206 | 3.1 | ug/L |
| Mn | 55 | 1186031.099 | 0.4 | 494.020 | 53.23158 | 0.708 | 1.3 | ug/L |
| Co | 59 | 23439.152 | 0.6 | 188.671 | 1.19701 | 0.011 | 0.9 | ug/L |
| Ni | 60 | 85547.144 | 1.9 | 136.669 | 19.60620 | 0.573 | 2.9 | ug/L |
| Ni | 62 | 13043.333 | 1.9 | 143.669 | 19.88253 | 0.599 | 3.0 | ug/L |
| Cu | 63 | 17930.121 | 2.3 | 212.338 | 1.77733 | 0.058 | 3.3 | ug/L |
| Cu | 65 | 8428.679 | 1.4 | 189.671 | 1.70373 | 0.019 | 1.1 | ug/L |
| Zn | 66 | 17865.979 | 1.5 | 1515.486 | 5.72840 | 0.065 | 1.1 | ug/L |
| Zn | 67 | 3257.002 | 0.7 | 342.344 | 5.86463 | 0.040 | 0.7 | ug/L |
| Zn | 68 | 14726.822 | 2.8 | 1170.427 | 6.47100 | 0.204 | 3.1 | ug/L |
| Ge | 72 | 269495.623 | 1.1 | 244883.968 | | | | ug/L |
| As | 75 | 2578.425 | 1.7 | 124.002 | 0.69721 | 0.017 | 2.4 | ug/L |
| Se | 77 | 345.607 | 3.8 | 216.736 | 0.40979 | 0.057 | 13.9 | ug/L |
| Se | 78 | 18709.224 | 0.6 | 16119.238 | 1.14071 | 0.184 | 16.2 | mg/L |
| Se | 82 | 2057.454 | 0.6 | 1872.010 | -0.00741 | 0.049 | 666.4 | ug/L |
| Kr | 83 | 1983.256 | 2.5 | 1902.236 | | | | mg/L |
| Y | 89 | 501866.953 | 2.0 | 408188.389 | | | | ug/L |
| Mo | 95 | 1298.781 | 3.3 | 112.002 | 0.18683 | 0.005 | 2.9 | ug/L |
| Mo | 97 | 778.044 | 1.8 | 64.001 | 0.18503 | 0.005 | 2.9 | ug/L |
| Mo | 98 | 1937.598 | 1.8 | 98.282 | 0.19006 | 0.003 | 1.7 | ug/L |
| Rh | 103 | 370061.094 | 2.5 | 340052.119 | | | | ug/L |
| Ag | 107 | 96.335 | 1.6 | 91.335 | -0.00062 | 0.000 | 22.3 | ug/L |
| Ag | 109 | 63.334 | 20.0 | 75.668 | -0.00169 | 0.001 | 51.7 | ug/L |
| Cd | 111 | 608.397 | 7.0 | 218.275 | 0.10090 | 0.011 | 10.8 | ug/L |
| Cd | 114 | 926.368 | 4.7 | 58.957 | 0.10958 | 0.006 | 5.7 | ug/L |
| In | 115 | 415758.109 | 0.9 | 358352.924 | | | | ug/L |
| Sb | 121 | 455.350 | 4.1 | 107.668 | 0.03057 | 0.002 | 6.2 | ug/L |
| Sb | 123 | 347.243 | 4.1 | 79.665 | 0.03061 | 0.001 | 4.4 | ug/L |
| Ba | 135 | 43019.854 | 0.5 | 46.667 | 15.87688 | 0.104 | 0.7 | ug/L |
| Ba | 137 | 71279.941 | 0.8 | 47.001 | 15.42131 | 0.086 | 0.6 | ug/L |
| Tb | 159 | 449643.548 | 0.7 | 411268.087 | | | | ug/L |
| Ho | 165 | 435818.398 | 0.7 | 390096.908 | | | | ug/L |
| Tl | 203 | 197.671 | 6.4 | 60.001 | 0.01473 | 0.001 | 9.5 | ug/L |
| Tl | 205 | 380.012 | 2.1 | 78.001 | 0.01495 | 0.000 | 2.8 | ug/L |
| Pb | 208 | 18458.221 | 1.2 | 320.672 | 0.64167 | 0.004 | 0.6 | ug/L |

Sample ID: 950471

Report Date/Time: Monday, November 13, 2006 20:50:05

Page 1

336

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 4893.486 | 2.1 | 87.335 | 0.64643 | 0.016 | 2.5 ug/L |
| | Pb | 207 | 3780.895 | 0.5 | 77.001 | 0.59626 | 0.001 | 0.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 133.161 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 110.050 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 116.019 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 109.331 | | | |
| > Ho | 165 | | 111.721 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950472

Sample Date/Time: Monday, November 13, 2006 20:53:02

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950472.073

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 81.335 | 18.1 | 63.001 | -0.00180 | 0.010 | 536.6 | ug/L |
| Al | 27 | 615868.203 | 1.3 | 2334.350 | 66.88702 | 0.964 | 1.4 | ug/L |
| > Sc | 45 | 509632.146 | 2.7 | 381869.082 | | | | ug/L |
| V | 51 | 14659.817 | 2.9 | 4488.603 | 0.39606 | 0.014 | 3.4 | ug/L |
| Cr | 52 | 41335.717 | 2.4 | 15368.650 | 1.09010 | 0.038 | 3.5 | ug/L |
| Cr | 53 | 3724.870 | 2.2 | 814.381 | 1.09716 | 0.046 | 4.2 | ug/L |
| Mn | 55 | 1563652.061 | 1.6 | 494.020 | 67.95447 | 0.278 | 0.4 | ug/L |
| Co | 59 | 18007.616 | 0.7 | 188.671 | 0.88780 | 0.014 | 1.6 | ug/L |
| Ni | 60 | 53038.875 | 2.9 | 136.669 | 11.75604 | 0.398 | 3.4 | ug/L |
| Ni | 62 | 6479.583 | 1.0 | 143.669 | 9.43698 | 0.196 | 2.1 | ug/L |
| Cu | 63 | 16216.266 | 2.8 | 212.338 | 1.55348 | 0.052 | 3.3 | ug/L |
| Cu | 65 | 8600.189 | 2.0 | 189.671 | 1.68324 | 0.056 | 3.3 | ug/L |
| Zn | 66 | 11783.778 | 1.5 | 1515.486 | 3.44612 | 0.098 | 2.8 | ug/L |
| Zn | 67 | 2136.962 | 5.0 | 342.344 | 3.44611 | 0.208 | 6.0 | ug/L |
| Zn | 68 | 9852.931 | 5.3 | 1170.427 | 3.97198 | 0.183 | 4.6 | ug/L |
| > Ge | 72 | 278318.616 | 1.4 | 244883.968 | | | | ug/L |
| As | 75 | 3901.619 | 2.5 | 124.002 | 1.03945 | 0.013 | 1.2 | ug/L |
| Se | 77 | 627.290 | 1.4 | 216.736 | 1.41114 | 0.048 | 3.4 | ug/L |
| Se | 78 | 19871.219 | 2.5 | 16119.238 | 1.77114 | 0.805 | 45.5 | mg/L |
| Se | 82 | 2439.290 | 0.7 | 1872.010 | 0.86120 | 0.120 | 13.9 | ug/L |
| Kr | 83 | 1995.926 | 3.1 | 1902.236 | | | | mg/L |
| Y | 89 | 503394.988 | 1.3 | 408188.389 | | | | ug/L |
| Mo | 95 | 3986.994 | 1.6 | 112.002 | 0.60690 | 0.011 | 1.8 | ug/L |
| Mo | 97 | 2432.713 | 2.7 | 64.001 | 0.61015 | 0.014 | 2.3 | ug/L |
| Mo | 98 | 6044.312 | 1.6 | 98.282 | 0.60849 | 0.009 | 1.5 | ug/L |
| Rh | 103 | 373491.182 | 0.7 | 340052.119 | | | | ug/L |
| Ag | 107 | 135.669 | 7.9 | 91.335 | 0.00179 | 0.001 | 36.5 | ug/L |
| Ag | 109 | 86.001 | 6.2 | 75.668 | -0.00021 | 0.000 | 154.6 | ug/L |
| Cd | 111 | 517.329 | 2.0 | 218.275 | 0.07284 | 0.003 | 4.7 | ug/L |
| Cd | 114 | 597.483 | 4.8 | 58.957 | 0.06638 | 0.003 | 5.0 | ug/L |
| > In | 115 | 422180.828 | 0.5 | 358352.924 | | | | ug/L |
| Sb | 121 | 587.027 | 3.7 | 107.668 | 0.04192 | 0.002 | 5.1 | ug/L |
| Sb | 123 | 426.612 | 2.1 | 79.665 | 0.03938 | 0.001 | 2.7 | ug/L |
| Ba | 135 | 38494.437 | 1.6 | 46.667 | 13.85001 | 0.210 | 1.5 | ug/L |
| Ba | 137 | 65104.007 | 1.5 | 47.001 | 13.73306 | 0.206 | 1.5 | ug/L |
| > Tb | 159 | 461132.054 | 0.5 | 411268.087 | | | | ug/L |
| > Ho | 165 | 451200.501 | 1.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 317.009 | 6.3 | 60.001 | 0.02698 | 0.002 | 8.7 | ug/L |
| Tl | 205 | 684.035 | 2.1 | 78.001 | 0.02928 | 0.001 | 3.4 | ug/L |
| Pb | 208 | 10884.884 | 1.4 | 320.672 | 0.36003 | 0.001 | 0.4 | ug/L |

Sample ID: 950472

Report Date/Time: Monday, November 13, 2006 20:56:04

Page 1

339

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 2912.872 | 1.1 | 87.335 | 0.36606 | 0.002 | 0.5 ug/L |
| | Pb | 207 | 2256.661 | 1.8 | 77.001 | 0.33793 | 0.010 | 2.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 133.457 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 113.653 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 117.811 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 112.124 | | | |
| > [Ho | 165 | | 115.664 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950473

Sample Date/Time: Monday, November 13, 2006 20:59:01

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950473.074

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 66.001 | 25.8 | 63.001 | -0.01175 | 0.012 | 104.1 | ug/L |
| Al | 27 | 65478.434 | 3.5 | 2334.350 | 6.81197 | 0.091 | 1.3 | ug/L |
| Sc | 45 | 509094.702 | 2.3 | 381869.082 | | | | ug/L |
| V | 51 | 9497.928 | 4.2 | 4488.603 | 0.16085 | 0.021 | 13.2 | ug/L |
| Cr | 52 | 31356.196 | 0.4 | 15368.650 | 0.56996 | 0.044 | 7.8 | ug/L |
| Cr | 53 | 2866.522 | 1.2 | 814.381 | 0.74161 | 0.038 | 5.2 | ug/L |
| Mn | 55 | 6281972.873 | 1.6 | 494.020 | 267.99282 | 10.849 | 4.0 | ug/L |
| Co | 59 | 7958.211 | 0.7 | 188.671 | 0.37881 | 0.009 | 2.5 | ug/L |
| Ni | 60 | 15232.770 | 6.7 | 136.669 | 3.29125 | 0.314 | 9.5 | ug/L |
| Ni | 62 | 714.371 | 0.9 | 143.669 | 0.80301 | 0.025 | 3.2 | ug/L |
| Cu | 63 | 9036.656 | 2.7 | 212.338 | 0.83881 | 0.041 | 4.9 | ug/L |
| Cu | 65 | 4571.299 | 1.2 | 189.671 | 0.85667 | 0.013 | 1.6 | ug/L |
| Zn | 66 | 7623.562 | 1.0 | 1515.486 | 1.97108 | 0.044 | 2.3 | ug/L |
| Zn | 67 | 1689.521 | 0.6 | 342.344 | 2.50136 | 0.109 | 4.3 | ug/L |
| Zn | 68 | 8124.042 | 3.2 | 1170.427 | 3.09547 | 0.134 | 4.3 | ug/L |
| Ge | 72 | 283805.053 | 2.6 | 244883.968 | | | | ug/L |
| As | 75 | 1403.132 | 4.5 | 124.002 | 0.34129 | 0.008 | 2.3 | ug/L |
| Se | 77 | 556.419 | 2.6 | 216.736 | 1.10973 | 0.084 | 7.6 | ug/L |
| Se | 78 | 19865.705 | 1.5 | 16119.238 | 1.33775 | 0.921 | 68.8 | mg/L |
| Se | 82 | 2320.190 | 1.1 | 1872.010 | 0.41025 | 0.159 | 38.7 | ug/L |
| Kr | 83 | 2001.260 | 1.6 | 1902.236 | | | | mg/L |
| Y | 89 | 501859.402 | 2.1 | 408188.389 | | | | ug/L |
| Mo | 95 | 5419.483 | 1.7 | 112.002 | 0.82005 | 0.029 | 3.5 | ug/L |
| Mo | 97 | 3458.419 | 3.7 | 64.001 | 0.86276 | 0.042 | 4.9 | ug/L |
| Mo | 98 | 8508.787 | 1.1 | 98.282 | 0.84864 | 0.019 | 2.2 | ug/L |
| Rh | 103 | 392142.860 | 1.5 | 340052.119 | | | | ug/L |
| Ag | 107 | 119.002 | 15.4 | 91.335 | 0.00062 | 0.001 | 191.1 | ug/L |
| Ag | 109 | 93.335 | 7.9 | 75.668 | 0.00019 | 0.000 | 237.9 | ug/L |
| Cd | 111 | 418.859 | 2.6 | 218.275 | 0.04351 | 0.001 | 2.1 | ug/L |
| Cd | 114 | 348.428 | 43.4 | 58.957 | 0.03426 | 0.018 | 52.6 | ug/L |
| In | 115 | 428570.983 | 2.0 | 358352.924 | | | | ug/L |
| Sb | 121 | 1462.143 | 3.5 | 107.668 | 0.11961 | 0.003 | 2.2 | ug/L |
| Sb | 123 | 1072.344 | 2.7 | 79.665 | 0.11394 | 0.005 | 4.1 | ug/L |
| Ba | 135 | 60649.518 | 0.9 | 46.667 | 20.43035 | 0.142 | 0.7 | ug/L |
| Ba | 137 | 103303.075 | 0.9 | 47.001 | 20.39820 | 0.167 | 0.8 | ug/L |
| Tb | 159 | 492743.612 | 0.6 | 411268.087 | | | | ug/L |
| Ho | 165 | 460780.095 | 1.6 | 390096.908 | | | | ug/L |
| Tl | 203 | 329.343 | 4.1 | 60.001 | 0.02756 | 0.001 | 4.1 | ug/L |
| Tl | 205 | 714.705 | 5.9 | 78.001 | 0.03004 | 0.002 | 5.7 | ug/L |
| Pb | 208 | 2210.468 | 3.6 | 320.672 | 0.06145 | 0.004 | 5.8 | ug/L |

Sample ID: 950473

Report Date/Time: Monday, November 13, 2006 21:02:03

Page 1

342

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 584.360 | 4.1 | 87.335 | 0.06138 | 0.004 | 6.9 ug/L |
| | Pb | 207 | 484.686 | 3.7 | 77.001 | 0.06014 | 0.004 | 6.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 133.317 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 115.894 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 119.595 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 119.811 | | | |
| > Ho | 165 | | 118.119 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950474

Sample Date/Time: Monday, November 13, 2006 21:05:00

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950474.075

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 75.668 | 2.0 | 63.001 | -0.00736 | 0.001 | 15.2 | ug/L |
| Al | 27 | 243194.821 | 2.8 | 2334.350 | 25.25800 | 0.892 | 3.5 | ug/L |
| > Sc | 45 | 528466.594 | 0.7 | 381869.082 | | | | ug/L |
| V | 51 | 10407.816 | 5.0 | 4488.603 | 0.18495 | 0.026 | 14.0 | ug/L |
| Cr | 52 | 58357.667 | 3.1 | 15368.650 | 1.87215 | 0.108 | 5.8 | ug/L |
| Cr | 53 | 5907.819 | 0.9 | 814.381 | 1.91653 | 0.019 | 1.0 | ug/L |
| Mn | 55 | 522231.635 | 0.7 | 494.020 | 22.65941 | 0.396 | 1.7 | ug/L |
| Co | 59 | 5365.781 | 2.4 | 188.671 | 0.25678 | 0.009 | 3.5 | ug/L |
| Ni | 60 | 27276.195 | 2.8 | 136.669 | 6.02236 | 0.180 | 3.0 | ug/L |
| Ni | 62 | 3298.686 | 3.0 | 143.669 | 4.67811 | 0.101 | 2.1 | ug/L |
| Cu | 63 | 13582.533 | 2.4 | 212.338 | 1.29585 | 0.031 | 2.4 | ug/L |
| Cu | 65 | 6392.515 | 1.4 | 189.671 | 1.23837 | 0.012 | 0.9 | ug/L |
| Zn | 66 | 9082.373 | 2.6 | 1515.486 | 2.51777 | 0.105 | 4.2 | ug/L |
| Zn | 67 | 2082.615 | 4.6 | 342.344 | 3.33370 | 0.149 | 4.5 | ug/L |
| Zn | 68 | 9895.973 | 2.0 | 1170.427 | 3.98978 | 0.137 | 3.4 | ug/L |
| > Ge | 72 | 278601.957 | 1.0 | 244883.968 | | | | ug/L |
| As | 75 | 1423.136 | 3.4 | 124.002 | 0.35399 | 0.011 | 3.0 | ug/L |
| Se | 77 | 421.211 | 3.1 | 216.736 | 0.64606 | 0.046 | 7.0 | ug/L |
| Se | 78 | 19244.313 | 1.7 | 16119.238 | 1.03308 | 0.575 | 55.7 | mg/L |
| Se | 82 | 2152.411 | 0.8 | 1872.010 | 0.06311 | 0.102 | 162.2 | ug/L |
| Kr | 83 | 1965.918 | 2.0 | 1902.236 | | | | mg/L |
| Y | 89 | 508337.292 | 0.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 2343.686 | 2.9 | 112.002 | 0.33865 | 0.016 | 4.7 | ug/L |
| Mo | 97 | 1505.818 | 1.4 | 64.001 | 0.36022 | 0.015 | 4.2 | ug/L |
| Mo | 98 | 3636.668 | 1.7 | 98.282 | 0.35157 | 0.004 | 1.1 | ug/L |
| Rh | 103 | 389745.155 | 1.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 85.335 | 1.8 | 91.335 | -0.00156 | 0.000 | 13.7 | ug/L |
| Ag | 109 | 64.334 | 7.7 | 75.668 | -0.00181 | 0.000 | 11.5 | ug/L |
| Cd | 111 | 363.246 | 0.7 | 218.275 | 0.02706 | 0.003 | 11.8 | ug/L |
| Cd | 114 | 225.640 | 12.3 | 58.957 | 0.01885 | 0.003 | 14.5 | ug/L |
| > In | 115 | 433664.548 | 2.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 677.701 | 1.6 | 107.668 | 0.04855 | 0.001 | 1.5 | ug/L |
| Sb | 123 | 485.579 | 7.3 | 79.665 | 0.04486 | 0.004 | 9.6 | ug/L |
| Ba | 135 | 66066.588 | 2.1 | 46.667 | 22.87781 | 0.640 | 2.8 | ug/L |
| Ba | 137 | 113956.697 | 0.7 | 47.001 | 23.13074 | 0.480 | 2.1 | ug/L |
| > Tb | 159 | 479552.495 | 2.7 | 411268.087 | | | | ug/L |
| > Ho | 165 | 461862.897 | 2.2 | 390096.908 | | | | ug/L |
| Tl | 203 | 339.010 | 3.4 | 60.001 | 0.02852 | 0.001 | 4.4 | ug/L |
| Tl | 205 | 749.041 | 3.7 | 78.001 | 0.03163 | 0.001 | 4.1 | ug/L |
| Pb | 208 | 6875.837 | 1.4 | 320.672 | 0.21738 | 0.005 | 2.4 | ug/L |

Sample ID: 950474

Report Date/Time: Monday, November 13, 2006 21:08:02

Page 1

345

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 1807.881 | 4.2 | 87.335 | 0.21683 | 0.010 | 4.8 ug/L |
| | Pb | 207 | 1473.812 | 1.6 | 77.001 | 0.21062 | 0.007 | 3.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 138.389 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 113.769 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 121.016 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 116.603 | | | |
| > Ho | 165 | | 118.397 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 13, 2006 21:10:59

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 6.076

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59198.473 | 1.4 | 63.001 | 49.89607 | 0.452 | 0.9 | ug/L |
| Al | 27 | 400907.895 | 2.7 | 2334.350 | 55.38093 | 1.098 | 2.0 | ug/L |
| > Sc | 45 | 400120.786 | 0.7 | 381869.082 | | | | ug/L |
| V | 51 | 879404.190 | 0.9 | 4488.603 | 50.88906 | 0.087 | 0.2 | ug/L |
| Cr | 52 | 753430.784 | 3.4 | 15368.650 | 49.14069 | 1.463 | 3.0 | ug/L |
| Cr | 53 | 89975.733 | 1.1 | 814.381 | 47.18597 | 0.219 | 0.5 | ug/L |
| Mn | 55 | 1081857.109 | 2.3 | 494.020 | 54.22372 | 0.704 | 1.3 | ug/L |
| Co | 59 | 896088.696 | 0.9 | 188.671 | 51.56514 | 1.184 | 2.3 | ug/L |
| Ni | 60 | 204952.606 | 1.8 | 136.669 | 52.50849 | 0.438 | 0.8 | ug/L |
| Ni | 62 | 29968.430 | 1.4 | 143.669 | 51.39608 | 0.726 | 1.4 | ug/L |
| Cu | 63 | 488938.339 | 0.7 | 212.338 | 54.82019 | 1.072 | 2.0 | ug/L |
| Cu | 65 | 236632.024 | 3.3 | 189.671 | 54.72499 | 1.094 | 2.0 | ug/L |
| Zn | 66 | 135237.626 | 3.3 | 1515.486 | 52.81774 | 1.050 | 2.0 | ug/L |
| Zn | 67 | 24244.794 | 0.7 | 342.344 | 54.37619 | 1.042 | 1.9 | ug/L |
| Zn | 68 | 102229.634 | 3.1 | 1170.427 | 54.34906 | 1.072 | 2.0 | ug/L |
| > Ge | 72 | 241295.428 | 1.5 | 244883.968 | | | | ug/L |
| As | 75 | 158122.379 | 0.9 | 124.002 | 50.37988 | 0.320 | 0.6 | ug/L |
| Se | 77 | 12822.391 | 0.9 | 216.736 | 53.86862 | 1.107 | 2.1 | ug/L |
| Se | 78 | 57771.490 | 3.0 | 16119.238 | 54.96030 | 1.432 | 2.6 | mg/L |
| Se | 82 | 18806.999 | 0.5 | 1872.010 | 54.00546 | 1.156 | 2.1 | ug/L |
| Kr | 83 | 1832.553 | 4.7 | 1902.236 | | | | mg/L |
| Y | 89 | 421934.243 | 1.1 | 408188.389 | | | | ug/L |
| Mo | 95 | 283194.229 | 1.7 | 112.002 | 49.19359 | 0.658 | 1.3 | ug/L |
| Mo | 97 | 175075.004 | 1.6 | 64.001 | 50.01554 | 1.262 | 2.5 | ug/L |
| Mo | 98 | 437319.322 | 0.6 | 98.282 | 49.54218 | 0.700 | 1.4 | ug/L |
| Rh | 103 | 349596.342 | 2.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 736867.060 | 1.4 | 91.335 | 52.00489 | 0.870 | 1.7 | ug/L |
| Ag | 109 | 675792.283 | 0.3 | 75.668 | 50.75815 | 0.435 | 0.9 | ug/L |
| Cd | 111 | 169022.019 | 0.8 | 218.275 | 52.16424 | 0.929 | 1.8 | ug/L |
| Cd | 114 | 366304.312 | 0.8 | 58.957 | 50.84287 | 0.942 | 1.9 | ug/L |
| > In | 115 | 382449.099 | 1.1 | 358352.924 | | | | ug/L |
| Sb | 121 | 490748.663 | 1.3 | 107.668 | 49.33680 | 1.088 | 2.2 | ug/L |
| Sb | 123 | 383380.368 | 1.2 | 79.665 | 50.07146 | 0.302 | 0.6 | ug/L |
| Ba | 135 | 131147.144 | 2.0 | 46.667 | 49.23969 | 0.149 | 0.3 | ug/L |
| Ba | 137 | 225225.799 | 1.1 | 47.001 | 49.56657 | 0.862 | 1.7 | ug/L |
| > Tb | 159 | 442345.424 | 2.2 | 411268.087 | | | | ug/L |
| > Ho | 165 | 414103.908 | 1.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 419889.919 | 1.7 | 60.001 | 49.83498 | 1.366 | 2.7 | ug/L |
| Tl | 205 | 952152.727 | 2.3 | 78.001 | 51.13967 | 1.357 | 2.7 | ug/L |
| Pb | 208 | 1327567.604 | 1.4 | 320.672 | 49.52152 | 0.392 | 0.8 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Monday, November 13, 2006 21:14:01

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 339750.895 | 1.8 | 87.335 | 48.17691 | 0.339 | 0.7 ug/L |
| | Pb | 207 | 285119.653 | 2.0 | 77.001 | 48.41675 | 1.277 | 2.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 99.792 | | | | |
| Al | 27 | 110.762 | | | | |
| > Sc | 45 | | 104.780 | | | |
| V | 51 | 101.778 | | | | |
| Cr | 52 | 98.281 | | | | |
| Cr | 53 | 94.372 | | | | |
| Mn | 55 | 108.447 | | | | |
| Co | 59 | 103.130 | | | | |
| Ni | 60 | 105.017 | | | | |
| Ni | 62 | 102.792 | | | | |
| Cu | 63 | 109.640 | | | | |
| Cu | 65 | 109.450 | | | | |
| Zn | 66 | 105.635 | | | | |
| Zn | 67 | 108.752 | | | | |
| Zn | 68 | 108.698 | | | | |
| > Ge | 72 | | 98.535 | | | |
| As | 75 | 100.760 | | | | |
| Se | 77 | 107.737 | | | | |
| Se | 78 | 109.921 | | | | |
| Se | 82 | 108.011 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 98.387 | | | | |
| Mo | 97 | 100.031 | | | | |
| Mo | 98 | 99.084 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 104.010 | | | | |
| Ag | 109 | 101.516 | | | | |
| Cd | 111 | 104.328 | | | | |
| Cd | 114 | 101.686 | | | | |
| > In | 115 | | 106.724 | | | |
| Sb | 121 | 98.674 | | | | |
| Sb | 123 | 100.143 | | | | |
| Ba | 135 | 98.479 | | | | |
| Ba | 137 | 99.133 | | | | |
| > Tb | 159 | | 107.556 | | | |
| > Ho | 165 | | 106.154 | | | |
| Tl | 203 | 99.670 | | | | |
| Tl | 205 | 102.279 | | | | |
| Pb | 208 | 99.043 | | | | |
| Pb | 206 | 96.354 | | | | |
| Pb | 207 | 96.834 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 13, 2006 21:16:57

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 7.077

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 61.334 | 14.1 | 63.001 | -0.00372 | 0.006 | 164.0 | ug/L |
| Al | 27 | 3007.906 | 1.7 | 2334.350 | 0.08110 | 0.017 | 20.7 | ug/L |
| > Sc | 45 | 397626.560 | 3.6 | 381869.082 | | | | ug/L |
| V | 51 | 4934.896 | 0.6 | 4488.603 | 0.01549 | 0.009 | 56.1 | ug/L |
| Cr | 52 | 16669.158 | 1.7 | 15368.650 | 0.04548 | 0.038 | 82.5 | ug/L |
| Cr | 53 | 823.382 | 4.4 | 814.381 | -0.01313 | 0.009 | 68.0 | ug/L |
| Mn | 55 | 548.690 | 5.5 | 494.020 | 0.00272 | 0.001 | 33.0 | ug/L |
| Co | 59 | 145.669 | 4.0 | 188.671 | -0.00243 | 0.000 | 11.2 | ug/L |
| Ni | 60 | 136.669 | 12.1 | 136.669 | 0.00001 | 0.004 | 67747.5 | ug/L |
| Ni | 62 | 145.003 | 12.9 | 143.669 | 0.00258 | 0.032 | 1224.1 | ug/L |
| Cu | 63 | 264.674 | 7.6 | 212.338 | 0.00580 | 0.002 | 27.3 | ug/L |
| Cu | 65 | 236.672 | 5.7 | 189.671 | 0.01085 | 0.004 | 38.9 | ug/L |
| Zn | 66 | 1554.827 | 1.0 | 1515.486 | 0.01639 | 0.019 | 113.3 | ug/L |
| Zn | 67 | 339.344 | 1.4 | 342.344 | -0.00552 | 0.016 | 285.4 | ug/L |
| Zn | 68 | 1237.771 | 2.6 | 1170.427 | 0.03688 | 0.027 | 72.0 | ug/L |
| > Ge | 72 | 244555.376 | 2.2 | 244883.968 | | | | ug/L |
| As | 75 | 184.337 | 9.6 | 124.002 | 0.01897 | 0.004 | 22.5 | ug/L |
| Se | 77 | 247.337 | 1.8 | 216.736 | 0.13035 | 0.018 | 13.6 | ug/L |
| Se | 78 | 16945.279 | 0.5 | 16119.238 | 1.10477 | 0.508 | 45.9 | mg/L |
| Se | 82 | 1848.538 | 1.6 | 1872.010 | -0.06388 | 0.164 | 256.7 | ug/L |
| Kr | 83 | 1834.554 | 3.3 | 1902.236 | | | | mg/L |
| Y | 89 | 417326.168 | 1.4 | 408188.389 | | | | ug/L |
| Mo | 95 | 861.054 | 17.7 | 112.002 | 0.12703 | 0.027 | 21.4 | ug/L |
| Mo | 97 | 519.022 | 16.5 | 64.001 | 0.12701 | 0.026 | 20.2 | ug/L |
| Mo | 98 | 1255.347 | 25.3 | 98.282 | 0.12881 | 0.037 | 28.8 | ug/L |
| Rh | 103 | 360538.280 | 0.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 192.337 | 2.3 | 91.335 | 0.00652 | 0.001 | 10.2 | ug/L |
| Ag | 109 | 159.003 | 11.8 | 75.668 | 0.00573 | 0.001 | 25.9 | ug/L |
| Cd | 111 | 227.257 | 5.3 | 218.275 | -0.00269 | 0.004 | 143.1 | ug/L |
| Cd | 114 | 54.583 | 20.6 | 58.957 | -0.00124 | 0.002 | 130.5 | ug/L |
| > In | 115 | 387712.701 | 2.6 | 358352.924 | | | | ug/L |
| Sb | 121 | 1448.808 | 12.1 | 107.668 | 0.13240 | 0.020 | 14.9 | ug/L |
| Sb | 123 | 1144.380 | 13.6 | 79.665 | 0.13655 | 0.022 | 15.8 | ug/L |
| Ba | 135 | 53.667 | 9.6 | 46.667 | 0.00105 | 0.002 | 214.3 | ug/L |
| Ba | 137 | 52.667 | 6.7 | 47.001 | 0.00030 | 0.001 | 241.8 | ug/L |
| > Tb | 159 | 448703.982 | 1.8 | 411268.087 | | | | ug/L |
| > Ho | 165 | 416668.242 | 0.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 85.335 | 8.0 | 60.001 | 0.00251 | 0.001 | 31.9 | ug/L |
| Tl | 205 | 155.670 | 10.6 | 78.001 | 0.00386 | 0.001 | 22.6 | ug/L |
| Pb | 208 | 464.676 | 2.0 | 320.672 | 0.00453 | 0.000 | 8.8 | ug/L |

| | | | | | | | | |
|--|----|-----|---------|------|--------|---------|-------|-----------|
| | Pb | 206 | 129.669 | 12.5 | 87.335 | 0.00513 | 0.002 | 45.5 ug/L |
| | Pb | 207 | 113.669 | 8.0 | 77.001 | 0.00531 | 0.002 | 29.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 104.126 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 99.866 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 108.193 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 109.103 | | | |
| > Ho | 165 | | 106.811 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950475

Sample Date/Time: Monday, November 13, 2006 21:22:54

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950475.078

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 86.001 | 9.2 | 63.001 | 0.00046 | 0.005 | 1163.7 | ug/L |
| Al | 27 | 649353.734 | 4.5 | 2334.350 | 69.51457 | 3.638 | 5.2 | ug/L |
| > Sc | 45 | 517125.564 | 0.8 | 381869.082 | | | | ug/L |
| V | 51 | 12188.562 | 3.4 | 4488.603 | 0.27513 | 0.022 | 7.9 | ug/L |
| Cr | 52 | 35730.147 | 2.1 | 15368.650 | 0.76933 | 0.034 | 4.4 | ug/L |
| Cr | 53 | 3096.606 | 2.3 | 814.381 | 0.81680 | 0.029 | 3.5 | ug/L |
| Mn | 55 | 9313926.459 | 1.4 | 494.020 | 414.12551 | 5.435 | 1.3 | ug/L |
| Co | 59 | 27177.852 | 0.6 | 188.671 | 1.37616 | 0.021 | 1.5 | ug/L |
| Ni | 60 | 53237.450 | 2.6 | 136.669 | 12.06682 | 0.232 | 1.9 | ug/L |
| Ni | 62 | 5810.083 | 1.6 | 143.669 | 8.63353 | 0.181 | 2.1 | ug/L |
| Cu | 63 | 233768.346 | 1.0 | 212.338 | 23.22576 | 0.446 | 1.9 | ug/L |
| Cu | 65 | 114237.040 | 2.1 | 189.671 | 23.40808 | 0.640 | 2.7 | ug/L |
| Zn | 66 | 480493.903 | 2.2 | 1515.486 | 167.71181 | 4.622 | 2.8 | ug/L |
| Zn | 67 | 71327.726 | 1.7 | 342.344 | 143.07954 | 3.678 | 2.6 | ug/L |
| Zn | 68 | 341980.973 | 0.8 | 1170.427 | 162.46073 | 2.271 | 1.4 | ug/L |
| > Ge | 72 | 272126.741 | 1.0 | 244883.968 | | | | ug/L |
| As | 75 | 4525.607 | 1.5 | 124.002 | 1.24071 | 0.032 | 2.6 | ug/L |
| Se | 77 | 642.158 | 2.5 | 216.736 | 1.51976 | 0.039 | 2.6 | ug/L |
| Se | 78 | 19747.083 | 2.0 | 16119.238 | 2.13629 | 0.518 | 24.3 | mg/L |
| Se | 82 | 2485.904 | 0.5 | 1872.010 | 1.14542 | 0.086 | 7.5 | ug/L |
| Kr | 83 | 2078.280 | 3.9 | 1902.236 | | | | mg/L |
| Y | 89 | 499128.075 | 3.4 | 408188.389 | | | | ug/L |
| Mo | 95 | 9394.725 | 3.9 | 112.002 | 1.49482 | 0.033 | 2.2 | ug/L |
| Mo | 97 | 5861.787 | 2.1 | 64.001 | 1.53571 | 0.013 | 0.8 | ug/L |
| Mo | 98 | 14844.013 | 0.5 | 98.282 | 1.55018 | 0.035 | 2.2 | ug/L |
| Rh | 103 | 376167.159 | 1.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 336.677 | 6.9 | 91.335 | 0.01517 | 0.001 | 7.5 | ug/L |
| Ag | 109 | 285.674 | 7.4 | 75.668 | 0.01386 | 0.002 | 11.0 | ug/L |
| Cd | 111 | 587.501 | 1.4 | 218.275 | 0.09660 | 0.002 | 2.2 | ug/L |
| Cd | 114 | 877.223 | 10.8 | 58.957 | 0.10442 | 0.014 | 13.0 | ug/L |
| > In | 115 | 411886.623 | 1.7 | 358352.924 | | | | ug/L |
| Sb | 121 | 58281.351 | 0.9 | 107.668 | 5.43018 | 0.079 | 1.5 | ug/L |
| Sb | 123 | 43799.822 | 0.8 | 79.665 | 5.30272 | 0.102 | 1.9 | ug/L |
| Ba | 135 | 141033.289 | 1.4 | 46.667 | 49.46095 | 0.776 | 1.6 | ug/L |
| Ba | 137 | 237066.857 | 0.7 | 47.001 | 48.72493 | 0.638 | 1.3 | ug/L |
| > Tb | 159 | 473565.938 | 0.8 | 411268.087 | | | | ug/L |
| > Ho | 165 | 438276.807 | 2.7 | 390096.908 | | | | ug/L |
| Tl | 203 | 770.710 | 9.5 | 60.001 | 0.07876 | 0.006 | 7.4 | ug/L |
| Tl | 205 | 1832.553 | 5.1 | 78.001 | 0.08851 | 0.002 | 2.5 | ug/L |
| Pb | 208 | 51615.385 | 0.1 | 320.672 | 1.80788 | 0.052 | 2.9 | ug/L |

Sample ID: 950475

Report Date/Time: Monday, November 13, 2006 21:25:56

Page 1

354

| | | | | | | | | |
|--|----|-----|-----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 13156.509 | 0.9 | 87.335 | 1.75078 | 0.039 | 2.2 ug/L |
| | Pb | 207 | 10964.318 | 0.8 | 77.001 | 1.74670 | 0.063 | 3.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 135.420 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 111.125 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 114.939 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 115.148 | | | |
| > [Ho | 165 | | 112.351 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950476

Sample Date/Time: Monday, November 13, 2006 21:28:53

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950476.079

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 83.001 | 10.7 | 63.001 | 0.00031 | 0.007 | 2093.2 | ug/L |
| Al | 27 | 311458.793 | 3.2 | 2334.350 | 34.25826 | 1.172 | 3.4 | ug/L |
| Sc | 45 | 500729.362 | 1.5 | 381869.082 | | | | ug/L |
| V | 51 | 10993.543 | 3.2 | 4488.603 | 0.23771 | 0.024 | 10.1 | ug/L |
| Cr | 52 | 31826.994 | 1.9 | 15368.650 | 0.62237 | 0.057 | 9.2 | ug/L |
| Cr | 53 | 2825.841 | 2.1 | 814.381 | 0.74371 | 0.010 | 1.3 | ug/L |
| Mn | 55 | 9100719.325 | 2.7 | 494.020 | 406.10563 | 14.150 | 3.5 | ug/L |
| Co | 59 | 26250.554 | 2.0 | 188.671 | 1.33354 | 0.038 | 2.8 | ug/L |
| Ni | 60 | 49024.648 | 2.1 | 136.669 | 11.14789 | 0.171 | 1.5 | ug/L |
| Ni | 62 | 5178.995 | 2.5 | 143.669 | 7.69597 | 0.190 | 2.5 | ug/L |
| Cu | 63 | 178878.529 | 1.5 | 212.338 | 17.82800 | 0.395 | 2.2 | ug/L |
| Cu | 65 | 87633.112 | 2.6 | 189.671 | 18.00521 | 0.363 | 2.0 | ug/L |
| Zn | 66 | 417680.086 | 0.9 | 1515.486 | 146.21373 | 2.561 | 1.8 | ug/L |
| Zn | 67 | 62684.521 | 1.1 | 342.344 | 126.06441 | 0.303 | 0.2 | ug/L |
| Zn | 68 | 297418.127 | 3.2 | 1170.427 | 141.67261 | 3.452 | 2.4 | ug/L |
| Ge | 72 | 271189.521 | 0.9 | 244883.968 | | | | ug/L |
| As | 75 | 4218.777 | 1.2 | 124.002 | 1.15786 | 0.004 | 0.4 | ug/L |
| Se | 77 | 626.957 | 3.7 | 216.736 | 1.47065 | 0.088 | 6.0 | ug/L |
| Se | 78 | 19432.785 | 0.5 | 16119.238 | 1.84832 | 0.225 | 12.2 | mg/L |
| Se | 82 | 2485.971 | 1.8 | 1872.010 | 1.16902 | 0.066 | 5.6 | ug/L |
| Kr | 83 | 2008.596 | 2.3 | 1902.236 | | | | mg/L |
| Y | 89 | 490023.519 | 1.8 | 408188.389 | | | | ug/L |
| Mo | 95 | 8629.887 | 1.6 | 112.002 | 1.39628 | 0.025 | 1.8 | ug/L |
| Mo | 97 | 5339.432 | 3.6 | 64.001 | 1.42221 | 0.057 | 4.0 | ug/L |
| Mo | 98 | 13929.468 | 0.7 | 98.282 | 1.47931 | 0.003 | 0.2 | ug/L |
| Rh | 103 | 371730.990 | 4.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 184.004 | 9.0 | 91.335 | 0.00539 | 0.001 | 18.8 | ug/L |
| Ag | 109 | 162.337 | 8.9 | 75.668 | 0.00546 | 0.001 | 20.6 | ug/L |
| Cd | 111 | 617.098 | 1.4 | 218.275 | 0.10819 | 0.003 | 2.4 | ug/L |
| Cd | 114 | 880.313 | 4.1 | 58.957 | 0.10675 | 0.006 | 5.3 | ug/L |
| In | 115 | 404774.885 | 0.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 35486.426 | 1.3 | 107.668 | 3.35956 | 0.039 | 1.1 | ug/L |
| Sb | 123 | 26241.128 | 0.5 | 79.665 | 3.22799 | 0.041 | 1.3 | ug/L |
| Ba | 135 | 142114.979 | 0.4 | 46.667 | 50.81024 | 1.141 | 2.2 | ug/L |
| Ba | 137 | 237399.346 | 1.7 | 47.001 | 49.73170 | 0.708 | 1.4 | ug/L |
| Tb | 159 | 464639.681 | 1.9 | 411268.087 | | | | ug/L |
| Ho | 165 | 445672.890 | 1.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 763.376 | 3.8 | 60.001 | 0.07662 | 0.003 | 4.0 | ug/L |
| Tl | 205 | 1778.208 | 4.7 | 78.001 | 0.08431 | 0.005 | 5.6 | ug/L |
| Pb | 208 | 33688.585 | 0.5 | 320.672 | 1.15530 | 0.011 | 1.0 | ug/L |

Sample ID: 950476

Report Date/Time: Monday, November 13, 2006 21:31:55

Page 1

357

| | | | | | | | | | |
|---|----|-----|----------|-----|--------|---------|-------|-----|------|
| I | Pb | 206 | 8500.420 | 2.1 | 87.335 | 1.10719 | 0.022 | 2.0 | ug/L |
| L | Pb | 207 | 7140.129 | 1.0 | 77.001 | 1.11300 | 0.021 | 1.9 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 131.126 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 110.742 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 112.954 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 112.977 | | | |
| > Ho | 165 | | 114.247 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477

Sample Date/Time: Monday, November 13, 2006 21:34:52

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950477.080

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 77.001 | 7.2 | 63.001 | -0.00792 | 0.004 | 48.1 | ug/L |
| Al | 27 | 70448.253 | 1.2 | 2334.350 | 6.85801 | 0.131 | 1.9 | ug/L |
| Sc | 45 | 544389.955 | 1.2 | 381869.082 | | | | ug/L |
| V | 51 | 10194.684 | 2.5 | 4488.603 | 0.16241 | 0.015 | 9.3 | ug/L |
| Cr | 52 | 31568.999 | 0.5 | 15368.650 | 0.47341 | 0.025 | 5.4 | ug/L |
| Cr | 53 | 2646.447 | 2.9 | 814.381 | 0.57802 | 0.024 | 4.2 | ug/L |
| Mn | 55 | 6419237.627 | 1.6 | 494.020 | 279.54300 | 4.724 | 1.7 | ug/L |
| Co | 59 | 12470.783 | 1.3 | 188.671 | 0.61271 | 0.019 | 3.2 | ug/L |
| Ni | 60 | 39742.611 | 0.9 | 136.669 | 8.81659 | 0.259 | 2.9 | ug/L |
| Ni | 62 | 3313.692 | 3.1 | 143.669 | 4.71665 | 0.224 | 4.8 | ug/L |
| Cu | 63 | 8708.302 | 0.8 | 212.338 | 0.82505 | 0.030 | 3.6 | ug/L |
| Cu | 65 | 4539.615 | 1.5 | 189.671 | 0.86949 | 0.021 | 2.4 | ug/L |
| Zn | 66 | 44597.521 | 2.7 | 1515.486 | 14.70508 | 0.104 | 0.7 | ug/L |
| Zn | 67 | 8466.050 | 1.6 | 342.344 | 15.96004 | 0.653 | 4.1 | ug/L |
| Zn | 68 | 36529.606 | 1.9 | 1170.427 | 16.45293 | 0.856 | 5.2 | ug/L |
| Ge | 72 | 277926.555 | 3.1 | 244883.968 | | | | ug/L |
| As | 75 | 7854.445 | 1.1 | 124.002 | 2.13721 | 0.092 | 4.3 | ug/L |
| Se | 77 | 464.680 | 0.4 | 216.736 | 0.81226 | 0.058 | 7.2 | ug/L |
| Se | 78 | 19401.966 | 1.2 | 16119.238 | 1.28240 | 0.972 | 75.8 | mg/L |
| Se | 82 | 2272.710 | 0.3 | 1872.010 | 0.41336 | 0.194 | 46.9 | ug/L |
| Kr | 83 | 2022.266 | 2.2 | 1902.236 | | | | mg/L |
| Y | 89 | 514222.056 | 1.8 | 408188.389 | | | | ug/L |
| Mo | 95 | 10242.061 | 2.1 | 112.002 | 1.51749 | 0.042 | 2.8 | ug/L |
| Mo | 97 | 6064.934 | 0.8 | 64.001 | 1.47814 | 0.020 | 1.3 | ug/L |
| Mo | 98 | 15671.295 | 2.7 | 98.282 | 1.52240 | 0.035 | 2.3 | ug/L |
| Rh | 103 | 383120.827 | 1.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 106.335 | 5.3 | 91.335 | -0.00039 | 0.000 | 86.6 | ug/L |
| Ag | 109 | 78.001 | 3.4 | 75.668 | -0.00100 | 0.000 | 15.1 | ug/L |
| Cd | 111 | 489.718 | 7.3 | 218.275 | 0.05883 | 0.010 | 17.6 | ug/L |
| Cd | 114 | 543.699 | 23.7 | 58.957 | 0.05643 | 0.015 | 26.8 | ug/L |
| In | 115 | 442574.841 | 0.7 | 358352.924 | | | | ug/L |
| Sb | 121 | 830.383 | 3.8 | 107.668 | 0.06059 | 0.002 | 4.0 | ug/L |
| Sb | 123 | 622.960 | 1.5 | 79.665 | 0.05922 | 0.001 | 1.6 | ug/L |
| Ba | 135 | 178150.867 | 1.6 | 46.667 | 60.70898 | 1.113 | 1.8 | ug/L |
| Ba | 137 | 296535.246 | 2.2 | 47.001 | 59.21921 | 1.433 | 2.4 | ug/L |
| Tb | 159 | 487396.142 | 0.3 | 411268.087 | | | | ug/L |
| Ho | 165 | 467358.073 | 2.4 | 390096.908 | | | | ug/L |
| Tl | 203 | 329.343 | 4.0 | 60.001 | 0.02710 | 0.002 | 7.6 | ug/L |
| Tl | 205 | 759.042 | 4.6 | 78.001 | 0.03171 | 0.003 | 7.9 | ug/L |
| Pb | 208 | 10380.959 | 0.8 | 320.672 | 0.33061 | 0.008 | 2.4 | ug/L |

Sample ID: 950477

Report Date/Time: Monday, November 13, 2006 21:37:54

Page 1

360

| | | | | | | | | |
|---|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 2773.823 | 1.0 | 87.335 | 0.33563 | 0.011 | 3.1 ug/L |
| L | Pb | 207 | 2159.301 | 1.2 | 77.001 | 0.31124 | 0.011 | 3.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 142.559 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 113.493 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 123.503 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 118.511 | | | |
| > Ho | 165 | | 119.806 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477D

Sample Date/Time: Monday, November 13, 2006 21:40:51

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950477D.081

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 82.668 | 9.2 | 63.001 | -0.00277 | 0.005 | 174.1 | ug/L |
| Al | 27 | 43231.292 | 1.4 | 2334.350 | 4.22061 | 0.070 | 1.7 | ug/L |
| > Sc | 45 | 527215.504 | 0.3 | 381869.082 | | | | ug/L |
| V | 51 | 10734.766 | 4.3 | 4488.603 | 0.20040 | 0.022 | 10.8 | ug/L |
| Cr | 52 | 32863.674 | 1.1 | 15368.650 | 0.58910 | 0.021 | 3.6 | ug/L |
| Cr | 53 | 2682.459 | 1.1 | 814.381 | 0.62607 | 0.009 | 1.4 | ug/L |
| Mn | 55 | 6719120.298 | 0.3 | 494.020 | 300.85496 | 5.742 | 1.9 | ug/L |
| Co | 59 | 12727.510 | 2.4 | 188.671 | 0.64313 | 0.006 | 0.9 | ug/L |
| Ni | 60 | 40994.997 | 0.3 | 136.669 | 9.35090 | 0.199 | 2.1 | ug/L |
| Ni | 62 | 3273.342 | 2.5 | 143.669 | 4.79150 | 0.094 | 2.0 | ug/L |
| Cu | 63 | 12146.636 | 2.0 | 212.338 | 1.19298 | 0.034 | 2.8 | ug/L |
| Cu | 65 | 6519.615 | 0.5 | 189.671 | 1.30446 | 0.028 | 2.2 | ug/L |
| Zn | 66 | 12239.106 | 2.2 | 1515.486 | 3.72678 | 0.109 | 2.9 | ug/L |
| Zn | 67 | 3523.447 | 2.4 | 342.344 | 6.38590 | 0.064 | 1.0 | ug/L |
| Zn | 68 | 14795.273 | 1.7 | 1170.427 | 6.48640 | 0.264 | 4.1 | ug/L |
| > Ge | 72 | 270280.597 | 2.0 | 244883.968 | | | | ug/L |
| As | 75 | 8089.672 | 0.6 | 124.002 | 2.26443 | 0.052 | 2.3 | ug/L |
| Se | 77 | 472.947 | 2.5 | 216.736 | 0.89211 | 0.071 | 7.9 | ug/L |
| Se | 78 | 19781.288 | 1.4 | 16119.238 | 2.33595 | 0.431 | 18.5 | mg/L |
| Se | 82 | 2276.511 | 0.8 | 1872.010 | 0.59889 | 0.086 | 14.3 | ug/L |
| Kr | 83 | 2139.963 | 1.6 | 1902.236 | | | | mg/L |
| Y | 89 | 525171.551 | 1.4 | 408188.389 | | | | ug/L |
| Mo | 95 | 10350.867 | 3.8 | 112.002 | 1.56988 | 0.053 | 3.4 | ug/L |
| Mo | 97 | 6272.756 | 0.7 | 64.001 | 1.56573 | 0.020 | 1.3 | ug/L |
| Mo | 98 | 15841.313 | 1.3 | 98.282 | 1.57545 | 0.017 | 1.1 | ug/L |
| Rh | 103 | 390467.855 | 1.5 | 340052.119 | | | | ug/L |
| Ag | 107 | 82.668 | 6.9 | 91.335 | -0.00172 | 0.000 | 20.9 | ug/L |
| Ag | 109 | 58.667 | 3.5 | 75.668 | -0.00217 | 0.000 | 7.3 | ug/L |
| Cd | 111 | 522.826 | 3.6 | 218.275 | 0.07091 | 0.006 | 7.8 | ug/L |
| Cd | 114 | 530.348 | 5.4 | 58.957 | 0.05638 | 0.004 | 6.5 | ug/L |
| > In | 115 | 432446.881 | 0.5 | 358352.924 | | | | ug/L |
| Sb | 121 | 750.708 | 3.0 | 107.668 | 0.05520 | 0.002 | 3.5 | ug/L |
| Sb | 123 | 580.162 | 4.6 | 79.665 | 0.05593 | 0.003 | 5.9 | ug/L |
| Ba | 135 | 178718.910 | 0.6 | 46.667 | 59.89537 | 1.075 | 1.8 | ug/L |
| Ba | 137 | 301846.892 | 0.7 | 47.001 | 59.27924 | 0.728 | 1.2 | ug/L |
| > Tb | 159 | 495659.127 | 1.5 | 411268.087 | | | | ug/L |
| > Ho | 165 | 460628.014 | 0.5 | 390096.908 | | | | ug/L |
| Tl | 203 | 319.009 | 2.2 | 60.001 | 0.02648 | 0.001 | 3.0 | ug/L |
| Tl | 205 | 715.705 | 5.9 | 78.001 | 0.03011 | 0.002 | 7.2 | ug/L |
| Pb | 208 | 12017.818 | 1.1 | 320.672 | 0.39042 | 0.004 | 1.1 | ug/L |

Sample ID: 950477D

Report Date/Time: Monday, November 13, 2006 21:43:52

Page 1

363

| | | | | | | | | |
|---|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 3132.287 | 1.2 | 87.335 | 0.38626 | 0.003 | 0.7 ug/L |
| L | Pb | 207 | 2598.431 | 3.0 | 77.001 | 0.38284 | 0.011 | 2.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 138.062 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 110.371 | | | |
| > [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 120.676 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 120.520 | | | |
| > [Ho | 165 | | 118.080 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477S

Sample Date/Time: Monday, November 13, 2006 21:46:49

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950477S.082

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 26035.202 | 0.9 | 63.001 | 16.78469 | 0.231 | 1.4 | ug/L |
| Al | 27 | 241731.377 | 1.8 | 2334.350 | 25.41420 | 0.331 | 1.3 | ug/L |
| Sc | 45 | 522005.257 | 0.8 | 381869.082 | | | | ug/L |
| V | 51 | 456070.730 | 1.6 | 4488.603 | 20.06689 | 0.454 | 2.3 | ug/L |
| Cr | 52 | 395761.349 | 2.2 | 15368.650 | 19.14545 | 0.376 | 2.0 | ug/L |
| Cr | 53 | 47075.400 | 0.8 | 814.381 | 18.65474 | 0.302 | 1.6 | ug/L |
| Mn | 55 | 6933552.361 | 2.4 | 494.020 | 315.27529 | 3.917 | 1.2 | ug/L |
| Co | 59 | 470698.250 | 1.7 | 188.671 | 24.55832 | 0.622 | 2.5 | ug/L |
| Ni | 60 | 132214.287 | 0.9 | 136.669 | 30.70760 | 0.202 | 0.7 | ug/L |
| Ni | 62 | 17695.280 | 1.5 | 143.669 | 27.40795 | 0.252 | 0.9 | ug/L |
| Cu | 63 | 235982.029 | 1.4 | 212.338 | 23.97981 | 0.366 | 1.5 | ug/L |
| Cu | 65 | 109821.437 | 1.5 | 189.671 | 23.01930 | 0.697 | 3.0 | ug/L |
| Zn | 66 | 62998.964 | 2.5 | 1515.486 | 21.97466 | 0.244 | 1.1 | ug/L |
| Zn | 67 | 12454.425 | 1.2 | 342.344 | 24.92386 | 0.624 | 2.5 | ug/L |
| Zn | 68 | 50825.034 | 0.9 | 1170.427 | 24.17305 | 0.581 | 2.4 | ug/L |
| Ge | 72 | 266066.716 | 1.6 | 244883.968 | | | | ug/L |
| As | 75 | 77618.607 | 1.1 | 124.002 | 22.41149 | 0.619 | 2.8 | ug/L |
| Se | 77 | 5221.035 | 1.1 | 216.736 | 19.31429 | 0.136 | 0.7 | ug/L |
| Se | 78 | 34332.597 | 0.6 | 16119.238 | 20.02575 | 0.892 | 4.5 | mg/L |
| Se | 82 | 8709.416 | 1.4 | 1872.010 | 19.27247 | 0.291 | 1.5 | ug/L |
| Kr | 83 | 1999.593 | 1.2 | 1902.236 | | | | mg/L |
| Y | 89 | 513089.581 | 1.3 | 408188.389 | | | | ug/L |
| Mo | 95 | 161762.076 | 1.4 | 112.002 | 25.30505 | 0.193 | 0.8 | ug/L |
| Mo | 97 | 97983.660 | 0.4 | 64.001 | 25.20676 | 0.292 | 1.2 | ug/L |
| Mo | 98 | 256799.463 | 1.4 | 98.282 | 26.20104 | 0.180 | 0.7 | ug/L |
| Rh | 103 | 378238.078 | 0.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 332237.828 | 1.0 | 91.335 | 21.12161 | 0.382 | 1.8 | ug/L |
| Ag | 109 | 315400.356 | 1.5 | 75.668 | 21.33860 | 0.343 | 1.6 | ug/L |
| Cd | 111 | 75331.308 | 2.3 | 218.275 | 20.90140 | 0.523 | 2.5 | ug/L |
| Cd | 114 | 171597.052 | 1.0 | 58.957 | 21.45115 | 0.285 | 1.3 | ug/L |
| In | 115 | 424503.291 | 0.9 | 358352.924 | | | | ug/L |
| Sb | 121 | 247641.245 | 1.8 | 107.668 | 22.42006 | 0.338 | 1.5 | ug/L |
| Sb | 123 | 188727.673 | 1.0 | 79.665 | 22.20122 | 0.226 | 1.0 | ug/L |
| Ba | 135 | 237841.341 | 3.3 | 46.667 | 82.61913 | 2.575 | 3.1 | ug/L |
| Ba | 137 | 396609.807 | 0.8 | 47.001 | 80.74553 | 1.542 | 1.9 | ug/L |
| Tb | 159 | 478170.009 | 1.2 | 411268.087 | | | | ug/L |
| Ho | 165 | 464771.687 | 0.9 | 390096.908 | | | | ug/L |
| Tl | 203 | 196880.806 | 2.9 | 60.001 | 20.80880 | 0.449 | 2.2 | ug/L |
| Tl | 205 | 454189.628 | 1.1 | 78.001 | 21.72990 | 0.139 | 0.6 | ug/L |
| Pb | 208 | 636946.461 | 0.4 | 320.672 | 21.16262 | 0.119 | 0.6 | ug/L |

Sample ID: 950477S

Report Date/Time: Monday, November 13, 2006 21:49:51

Page 1

366

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 166310.331 | 1.4 | 87.335 | 21.00578 | 0.266 | 1.3 ug/L |
| | Pb | 207 | 133598.830 | 1.2 | 77.001 | 20.20203 | 0.071 | 0.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 136.697 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 108.650 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 118.460 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 116.267 | | | |
| > Ho | 165 | | 119.143 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477A

Sample Date/Time: Monday, November 13, 2006 21:52:48

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950477A.083

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 23883.085 | 1.4 | 63.001 | 15.18198 | 0.539 | 3.5 | ug/L |
| Al | 27 | 249555.459 | 0.7 | 2334.350 | 25.88143 | 0.507 | 2.0 | ug/L |
| Sc | 45 | 529463.685 | 2.3 | 381869.082 | | | | ug/L |
| V | 51 | 423239.011 | 1.3 | 4488.603 | 18.34363 | 0.616 | 3.4 | ug/L |
| Cr | 52 | 374960.515 | 2.9 | 15368.650 | 17.81345 | 0.339 | 1.9 | ug/L |
| Cr | 53 | 44704.044 | 1.2 | 814.381 | 17.43888 | 0.289 | 1.7 | ug/L |
| Mn | 55 | 6861408.207 | 1.7 | 494.020 | 311.31675 | 4.734 | 1.5 | ug/L |
| Co | 59 | 432832.293 | 3.2 | 188.671 | 22.52893 | 0.812 | 3.6 | ug/L |
| Ni | 60 | 124803.165 | 2.3 | 136.669 | 28.92060 | 0.822 | 2.8 | ug/L |
| Ni | 62 | 16607.030 | 0.2 | 143.669 | 25.64908 | 0.165 | 0.6 | ug/L |
| Cu | 63 | 214079.551 | 2.9 | 212.338 | 21.70083 | 0.593 | 2.7 | ug/L |
| Cu | 65 | 101268.441 | 2.0 | 189.671 | 21.16789 | 0.302 | 1.4 | ug/L |
| Zn | 66 | 91229.918 | 0.8 | 1515.486 | 32.01719 | 0.345 | 1.1 | ug/L |
| Zn | 67 | 16067.646 | 3.1 | 342.344 | 32.29392 | 0.928 | 2.9 | ug/L |
| Zn | 68 | 69907.369 | 0.7 | 1170.427 | 33.39908 | 0.425 | 1.3 | ug/L |
| Ge | 72 | 266663.135 | 0.7 | 244883.968 | | | | ug/L |
| As | 75 | 71583.955 | 2.2 | 124.002 | 20.61255 | 0.346 | 1.7 | ug/L |
| Se | 77 | 4816.592 | 1.0 | 216.736 | 17.70460 | 0.129 | 0.7 | ug/L |
| Se | 78 | 33151.351 | 3.7 | 16119.238 | 18.51655 | 1.179 | 6.4 | mg/L |
| Se | 82 | 8242.675 | 0.6 | 1872.010 | 17.87063 | 0.153 | 0.9 | ug/L |
| Kr | 83 | 2027.600 | 3.8 | 1902.236 | | | | mg/L |
| Y | 89 | 510651.876 | 0.4 | 408188.389 | | | | ug/L |
| Mo | 95 | 150390.824 | 2.2 | 112.002 | 23.62033 | 0.099 | 0.4 | ug/L |
| Mo | 97 | 93796.524 | 0.6 | 64.001 | 24.23286 | 0.587 | 2.4 | ug/L |
| Mo | 98 | 245066.492 | 2.2 | 98.282 | 25.10470 | 0.060 | 0.2 | ug/L |
| Rh | 103 | 378469.294 | 3.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 311580.624 | 1.2 | 91.335 | 19.89265 | 0.528 | 2.7 | ug/L |
| Ag | 109 | 302262.804 | 1.0 | 75.668 | 20.53472 | 0.259 | 1.3 | ug/L |
| Cd | 111 | 70228.669 | 1.1 | 218.275 | 19.56257 | 0.341 | 1.7 | ug/L |
| Cd | 114 | 160715.526 | 1.6 | 58.957 | 20.18058 | 0.730 | 3.6 | ug/L |
| In | 115 | 422788.396 | 2.0 | 358352.924 | | | | ug/L |
| Sb | 121 | 234410.801 | 1.2 | 107.668 | 21.31700 | 0.683 | 3.2 | ug/L |
| Sb | 123 | 174332.251 | 0.9 | 79.665 | 20.59367 | 0.343 | 1.7 | ug/L |
| Ba | 135 | 235595.737 | 0.9 | 46.667 | 81.78901 | 0.557 | 0.7 | ug/L |
| Ba | 137 | 391492.910 | 0.9 | 47.001 | 79.65504 | 1.692 | 2.1 | ug/L |
| Tb | 159 | 478474.975 | 1.3 | 411268.087 | | | | ug/L |
| Ho | 165 | 461617.978 | 0.9 | 390096.908 | | | | ug/L |
| Tl | 203 | 180585.881 | 2.4 | 60.001 | 19.21713 | 0.339 | 1.8 | ug/L |
| Tl | 205 | 424275.898 | 1.4 | 78.001 | 20.43896 | 0.404 | 2.0 | ug/L |
| Pb | 208 | 590454.592 | 0.8 | 320.672 | 19.75054 | 0.028 | 0.1 | ug/L |

Sample ID: 950477A

Report Date/Time: Monday, November 13, 2006 21:55:49

Page 1

369

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 152038.778 | 1.5 | 87.335 | 19.33361 | 0.300 | 1.6 ug/L |
| | Pb | 207 | 122255.531 | 1.0 | 77.001 | 18.61209 | 0.031 | 0.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 138.651 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 108.894 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 117.981 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 116.341 | | | |
| > Ho | 165 | | 118.334 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477L

Sample Date/Time: Monday, November 13, 2006 21:58:46

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\950477L.084

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59.001 | 6.1 | 63.001 | -0.01231 | 0.003 | 25.9 | ug/L |
| Al | 27 | 57303.679 | 2.7 | 2334.350 | 6.60323 | 0.365 | 5.5 | ug/L |
| > Sc | 45 | 459431.962 | 2.6 | 381869.082 | | | | ug/L |
| V | 51 | 6028.955 | 1.5 | 4488.603 | 0.03193 | 0.006 | 17.8 | ug/L |
| Cr | 52 | 19760.265 | 0.7 | 15368.650 | 0.07426 | 0.032 | 43.1 | ug/L |
| Cr | 53 | 1329.119 | 4.2 | 814.381 | 0.16174 | 0.040 | 24.7 | ug/L |
| Mn | 55 | 1182239.115 | 1.0 | 494.020 | 56.81786 | 0.296 | 0.5 | ug/L |
| Co | 59 | 2483.062 | 3.0 | 188.671 | 0.12630 | 0.004 | 3.1 | ug/L |
| Ni | 60 | 6904.264 | 3.6 | 136.669 | 1.66291 | 0.071 | 4.3 | ug/L |
| Ni | 62 | 692.702 | 2.3 | 143.669 | 0.90055 | 0.030 | 3.4 | ug/L |
| Cu | 63 | 2454.720 | 2.5 | 212.338 | 0.24051 | 0.007 | 3.0 | ug/L |
| Cu | 65 | 1455.808 | 3.2 | 189.671 | 0.27991 | 0.012 | 4.4 | ug/L |
| Zn | 66 | 122753.491 | 1.4 | 1515.486 | 45.89753 | 0.464 | 1.0 | ug/L |
| Zn | 67 | 19485.952 | 1.1 | 342.344 | 41.72140 | 0.611 | 1.5 | ug/L |
| Zn | 68 | 89341.932 | 0.6 | 1170.427 | 45.44829 | 0.555 | 1.2 | ug/L |
| > Ge | 72 | 251660.018 | 0.6 | 244883.968 | | | | ug/L |
| As | 75 | 1643.845 | 3.2 | 124.002 | 0.46358 | 0.016 | 3.4 | ug/L |
| Se | 77 | 276.138 | 2.6 | 216.736 | 0.21864 | 0.023 | 10.5 | ug/L |
| Se | 78 | 16999.315 | 2.5 | 16119.238 | 0.54848 | 0.651 | 118.7 | mg/L |
| Se | 82 | 1878.012 | 0.8 | 1872.010 | -0.13978 | 0.029 | 20.6 | ug/L |
| Kr | 83 | 1848.223 | 2.1 | 1902.236 | | | | mg/L |
| Y | 89 | 447464.887 | 3.5 | 408188.389 | | | | ug/L |
| Mo | 95 | 1897.569 | 4.8 | 112.002 | 0.28212 | 0.015 | 5.4 | ug/L |
| Mo | 97 | 1179.762 | 2.4 | 64.001 | 0.29011 | 0.008 | 2.8 | ug/L |
| Mo | 98 | 2953.574 | 3.5 | 98.282 | 0.29545 | 0.010 | 3.3 | ug/L |
| Rh | 103 | 366304.970 | 2.3 | 340052.119 | | | | ug/L |
| Ag | 107 | 138.336 | 5.9 | 91.335 | 0.00209 | 0.001 | 25.4 | ug/L |
| Ag | 109 | 134.002 | 6.6 | 75.668 | 0.00318 | 0.001 | 17.5 | ug/L |
| Cd | 111 | 323.667 | 4.1 | 218.275 | 0.01986 | 0.003 | 16.6 | ug/L |
| Cd | 114 | 211.759 | 3.4 | 58.957 | 0.01826 | 0.001 | 5.2 | ug/L |
| > In | 115 | 416426.340 | 0.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 560.025 | 12.5 | 107.668 | 0.04014 | 0.006 | 15.6 | ug/L |
| Sb | 123 | 403.848 | 11.3 | 79.665 | 0.03733 | 0.005 | 14.0 | ug/L |
| Ba | 135 | 34730.570 | 0.4 | 46.667 | 12.06047 | 0.153 | 1.3 | ug/L |
| Ba | 137 | 58140.377 | 1.2 | 47.001 | 11.83706 | 0.140 | 1.2 | ug/L |
| > Tb | 159 | 477722.909 | 1.1 | 411268.087 | | | | ug/L |
| > Ho | 165 | 462503.946 | 1.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 159.670 | 12.7 | 60.001 | 0.00940 | 0.002 | 22.1 | ug/L |
| Tl | 205 | 314.676 | 7.6 | 78.001 | 0.01069 | 0.001 | 10.9 | ug/L |
| Pb | 208 | 3005.910 | 1.2 | 320.672 | 0.08772 | 0.000 | 0.3 | ug/L |

Sample ID: 950477L

Report Date/Time: Monday, November 13, 2006 22:01:48

Page 1

372

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 772.044 | 3.0 | 87.335 | 0.08493 | 0.004 | 4.8 ug/L |
| | Pb | 207 | 632.697 | 0.8 | 77.001 | 0.08233 | 0.001 | 1.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 120.311 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 102.767 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 116.206 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 116.159 | | | |
| > Ho | 165 | | 118.561 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956 D.10

Sample Date/Time: Monday, November 13, 2006 22:04:45

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948956 D.10.085

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54.001 | 15.8 | 63.001 | -0.01887 | 0.006 | 34.0 | ug/L |
| Al | 27 | 79523.466 | 1.2 | 2334.350 | 8.57805 | 0.102 | 1.2 | ug/L |
| > Sc | 45 | 495989.419 | 1.8 | 381869.082 | | | | ug/L |
| V | 51 | 5251.903 | 1.3 | 4488.603 | -0.02705 | 0.007 | 27.2 | ug/L |
| Cr | 52 | 17772.110 | 1.2 | 15368.650 | -0.11747 | 0.024 | 20.1 | ug/L |
| Cr | 53 | 1175.428 | 3.5 | 814.381 | 0.05019 | 0.011 | 21.8 | ug/L |
| Mn | 55 | 17346666.685 | 1.2 | 494.020 | 751.04428 | 15.271 | 2.0 | ug/L |
| Co | 59 | 33136.087 | 1.3 | 188.671 | 1.63602 | 0.054 | 3.3 | ug/L |
| Ni | 60 | 6932.620 | 2.8 | 136.669 | 1.50077 | 0.076 | 5.0 | ug/L |
| Ni | 62 | 925.727 | 2.0 | 143.669 | 1.13302 | 0.013 | 1.1 | ug/L |
| Cu | 63 | 2996.235 | 0.8 | 212.338 | 0.26665 | 0.004 | 1.5 | ug/L |
| Cu | 65 | 1073.413 | 3.6 | 189.671 | 0.17138 | 0.012 | 6.9 | ug/L |
| Zn | 66 | 134504.534 | 2.4 | 1515.486 | 45.26879 | 0.268 | 0.6 | ug/L |
| Zn | 67 | 20332.980 | 0.8 | 342.344 | 39.15654 | 0.768 | 2.0 | ug/L |
| Zn | 68 | 96745.016 | 1.2 | 1170.427 | 44.30121 | 0.944 | 2.1 | ug/L |
| > Ge | 72 | 279528.611 | 2.1 | 244883.968 | | | | ug/L |
| As | 75 | 78492.448 | 1.7 | 124.002 | 21.57608 | 0.819 | 3.8 | ug/L |
| Se | 77 | 243.937 | 4.1 | 216.736 | -0.01262 | 0.037 | 292.9 | ug/L |
| Se | 78 | 17150.246 | 2.0 | 16119.238 | -1.40394 | 0.804 | 57.2 | mg/L |
| Se | 82 | 1843.604 | 0.9 | 1872.010 | -0.80408 | 0.128 | 15.9 | ug/L |
| Kr | 83 | 1882.565 | 4.7 | 1902.236 | | | | mg/L |
| Y | 89 | 489738.960 | 2.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 19495.313 | 2.3 | 112.002 | 2.87919 | 0.047 | 1.6 | ug/L |
| Mo | 97 | 11944.341 | 1.5 | 64.001 | 2.90254 | 0.071 | 2.4 | ug/L |
| Mo | 98 | 30432.250 | 0.4 | 98.282 | 2.94038 | 0.073 | 2.5 | ug/L |
| Rh | 103 | 413131.569 | 1.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 82.001 | 7.4 | 91.335 | -0.00192 | 0.000 | 24.2 | ug/L |
| Ag | 109 | 54.334 | 5.6 | 75.668 | -0.00257 | 0.000 | 10.2 | ug/L |
| Cd | 111 | 274.308 | 3.8 | 218.275 | 0.00055 | 0.001 | 230.7 | ug/L |
| Cd | 114 | 235.897 | 26.8 | 58.957 | 0.01920 | 0.007 | 35.7 | ug/L |
| > In | 115 | 446825.369 | 2.1 | 358352.924 | | | | ug/L |
| Sb | 121 | 788.379 | 1.7 | 107.668 | 0.05630 | 0.001 | 1.1 | ug/L |
| Sb | 123 | 639.248 | 6.2 | 79.665 | 0.06043 | 0.006 | 9.2 | ug/L |
| Ba | 135 | 7615.555 | 2.0 | 46.667 | 2.34779 | 0.059 | 2.5 | ug/L |
| Ba | 137 | 13095.416 | 2.4 | 47.001 | 2.37312 | 0.046 | 2.0 | ug/L |
| > Tb | 159 | 534666.675 | 0.9 | 411268.087 | | | | ug/L |
| > Ho | 165 | 496276.289 | 1.9 | 390096.908 | | | | ug/L |
| Tl | 203 | 203.671 | 0.8 | 60.001 | 0.01261 | 0.000 | 2.8 | ug/L |
| Tl | 205 | 413.681 | 3.4 | 78.001 | 0.01409 | 0.000 | 2.9 | ug/L |
| Pb | 208 | 1424.062 | 2.2 | 320.672 | 0.03165 | 0.002 | 5.2 | ug/L |

Sample ID: 948956 D.10

Report Date/Time: Monday, November 13, 2006 22:07:47

Page 1

375

| | | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|------|------|
| | Pb | 206 | 361.345 | 5.9 | 87.335 | 0.02966 | 0.003 | 10.9 | ug/L |
| | Pb | 207 | 311.009 | 2.7 | 77.001 | 0.03021 | 0.002 | 5.9 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 129.885 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 114.147 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 124.689 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 130.004 | | | |
| > [Ho | 165 | | 127.219 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956D D.10

Sample Date/Time: Monday, November 13, 2006 22:10:44

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948956D D.10.086

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 58.334 | 15.6 | 63.001 | -0.01055 | 0.008 | 73.2 | ug/L |
| Al | 27 | 79476.657 | 0.5 | 2334.350 | 9.77605 | 0.183 | 1.9 | ug/L |
| Sc | 45 | 437049.373 | 1.9 | 381869.082 | | | | ug/L |
| V | 51 | 5133.841 | 2.7 | 4488.603 | -0.00005 | 0.012 | 23006.0 | ug/L |
| Cr | 52 | 17188.222 | 2.8 | 15368.650 | -0.02389 | 0.048 | 201.8 | ug/L |
| Cr | 53 | 1135.089 | 3.4 | 814.381 | 0.09856 | 0.022 | 22.4 | ug/L |
| Mn | 55 | 14796761.896 | 2.8 | 494.020 | 734.07386 | 32.621 | 4.4 | ug/L |
| Co | 59 | 30083.505 | 0.6 | 188.671 | 1.70141 | 0.025 | 1.5 | ug/L |
| Ni | 60 | 6191.029 | 2.7 | 136.669 | 1.53584 | 0.072 | 4.7 | ug/L |
| Ni | 62 | 827.716 | 1.9 | 143.669 | 1.16696 | 0.051 | 4.4 | ug/L |
| Cu | 63 | 2583.760 | 1.3 | 212.338 | 0.26311 | 0.004 | 1.6 | ug/L |
| Cu | 65 | 841.051 | 3.3 | 189.671 | 0.14934 | 0.009 | 5.7 | ug/L |
| Zn | 66 | 133503.445 | 1.8 | 1515.486 | 51.55710 | 0.775 | 1.5 | ug/L |
| Zn | 67 | 20665.137 | 1.9 | 342.344 | 45.71090 | 1.117 | 2.4 | ug/L |
| Zn | 68 | 97303.945 | 2.3 | 1170.427 | 51.13004 | 1.251 | 2.4 | ug/L |
| Ge | 72 | 244024.714 | 2.1 | 244883.968 | | | | ug/L |
| As | 75 | 70400.159 | 0.5 | 124.002 | 22.16289 | 0.478 | 2.2 | ug/L |
| Se | 77 | 250.670 | 3.7 | 216.736 | 0.14725 | 0.058 | 39.3 | ug/L |
| Se | 78 | 17395.260 | 1.0 | 16119.238 | 1.73686 | 0.594 | 34.2 | mg/L |
| Se | 82 | 1853.139 | 1.0 | 1872.010 | -0.03634 | 0.174 | 480.0 | ug/L |
| Kr | 83 | 1876.897 | 4.0 | 1902.236 | | | | mg/L |
| Y | 89 | 432755.417 | 0.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 17607.100 | 2.8 | 112.002 | 2.83019 | 0.099 | 3.5 | ug/L |
| Mo | 97 | 10685.955 | 1.7 | 64.001 | 2.82521 | 0.053 | 1.9 | ug/L |
| Mo | 98 | 27309.222 | 2.6 | 98.282 | 2.87077 | 0.076 | 2.6 | ug/L |
| Rh | 103 | 366397.392 | 2.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 125.336 | 7.4 | 91.335 | 0.00136 | 0.001 | 41.7 | ug/L |
| Ag | 109 | 102.668 | 9.8 | 75.668 | 0.00112 | 0.001 | 64.2 | ug/L |
| Cd | 111 | 246.779 | 3.7 | 218.275 | -0.00096 | 0.002 | 206.1 | ug/L |
| Cd | 114 | 190.865 | 5.3 | 58.957 | 0.01596 | 0.002 | 9.6 | ug/L |
| In | 115 | 410531.035 | 1.0 | 358352.924 | | | | ug/L |
| Sb | 121 | 645.698 | 7.0 | 107.668 | 0.04896 | 0.005 | 9.7 | ug/L |
| Sb | 123 | 484.635 | 4.2 | 79.665 | 0.04788 | 0.003 | 5.7 | ug/L |
| Ba | 135 | 6651.721 | 2.6 | 46.667 | 2.31257 | 0.054 | 2.4 | ug/L |
| Ba | 137 | 11688.976 | 0.8 | 47.001 | 2.38999 | 0.056 | 2.3 | ug/L |
| Tb | 159 | 474077.128 | 2.4 | 411268.087 | | | | ug/L |
| Ho | 165 | 441567.137 | 1.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 184.337 | 5.0 | 60.001 | 0.01297 | 0.001 | 10.1 | ug/L |
| Tl | 205 | 394.013 | 11.4 | 78.001 | 0.01539 | 0.002 | 14.2 | ug/L |
| Pb | 208 | 1361.390 | 1.8 | 320.672 | 0.03494 | 0.001 | 2.4 | ug/L |

| | | | | | | | | |
|---|----|-----|---------|-----|--------|---------|-------|----------|
| I | Pb | 206 | 361.345 | 6.6 | 87.335 | 0.03489 | 0.003 | 7.4 ug/L |
| L | Pb | 207 | 296.675 | 3.7 | 77.001 | 0.03339 | 0.002 | 7.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 114.450 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 99.649 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 114.561 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 115.272 | | | |
| > [Ho | 165 | | 113.194 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 13, 2006 22:16:43

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 6.087

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 58351.172 | 0.9 | 63.001 | 47.84660 | 1.449 | 3.0 | ug/L |
| Al | 27 | 453410.164 | 1.3 | 2334.350 | 60.98621 | 2.430 | 4.0 | ug/L |
| Sc | 45 | 411501.319 | 2.8 | 381869.082 | | | | ug/L |
| V | 51 | 862287.818 | 2.9 | 4488.603 | 48.52088 | 1.518 | 3.1 | ug/L |
| Cr | 52 | 752468.617 | 0.9 | 15368.650 | 47.72715 | 1.783 | 3.7 | ug/L |
| Cr | 53 | 87901.819 | 1.9 | 814.381 | 44.82339 | 1.423 | 3.2 | ug/L |
| Mn | 55 | 1060302.087 | 1.2 | 494.020 | 55.09154 | 1.231 | 2.2 | ug/L |
| Co | 59 | 867202.754 | 0.9 | 188.671 | 51.72359 | 1.440 | 2.8 | ug/L |
| Ni | 60 | 200082.825 | 0.4 | 136.669 | 53.14309 | 1.364 | 2.6 | ug/L |
| Ni | 62 | 29897.186 | 2.3 | 143.669 | 53.14288 | 0.784 | 1.5 | ug/L |
| Cu | 63 | 462627.601 | 0.4 | 212.338 | 53.76027 | 1.190 | 2.2 | ug/L |
| Cu | 65 | 228564.098 | 0.7 | 189.671 | 54.80906 | 1.498 | 2.7 | ug/L |
| Zn | 66 | 135608.617 | 2.5 | 1515.486 | 54.91547 | 0.403 | 0.7 | ug/L |
| Zn | 67 | 22598.168 | 2.2 | 342.344 | 52.51247 | 1.976 | 3.8 | ug/L |
| Zn | 68 | 98963.860 | 1.1 | 1170.427 | 54.54440 | 1.020 | 1.9 | ug/L |
| Ge | 72 | 232840.339 | 2.2 | 244883.968 | | | | ug/L |
| As | 75 | 146600.752 | 0.7 | 124.002 | 48.41301 | 0.883 | 1.8 | ug/L |
| Se | 77 | 12107.990 | 0.5 | 216.736 | 52.70333 | 1.283 | 2.4 | ug/L |
| Se | 78 | 53944.256 | 1.1 | 16119.238 | 52.54798 | 2.209 | 4.2 | mg/L |
| Se | 82 | 17919.580 | 0.9 | 1872.010 | 53.25218 | 0.813 | 1.5 | ug/L |
| Kr | 83 | 1784.209 | 1.7 | 1902.236 | | | | mg/L |
| Y | 89 | 418389.120 | 2.8 | 408188.389 | | | | ug/L |
| Mo | 95 | 275592.263 | 1.0 | 112.002 | 47.93209 | 1.260 | 2.6 | ug/L |
| Mo | 97 | 175126.611 | 1.3 | 64.001 | 50.09056 | 1.676 | 3.3 | ug/L |
| Mo | 98 | 432041.351 | 2.5 | 98.282 | 48.98559 | 0.832 | 1.7 | ug/L |
| Rh | 103 | 352035.664 | 1.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 714560.732 | 1.3 | 91.335 | 50.47865 | 0.480 | 1.0 | ug/L |
| Ag | 109 | 678090.721 | 1.2 | 75.668 | 50.99002 | 1.318 | 2.6 | ug/L |
| Cd | 111 | 167172.933 | 1.3 | 218.275 | 51.65477 | 1.631 | 3.2 | ug/L |
| Cd | 114 | 385895.224 | 1.8 | 58.957 | 53.61113 | 0.910 | 1.7 | ug/L |
| In | 115 | 382108.639 | 2.2 | 358352.924 | | | | ug/L |
| Sb | 121 | 502060.313 | 0.4 | 107.668 | 50.52520 | 0.929 | 1.8 | ug/L |
| Sb | 123 | 376036.028 | 1.2 | 79.665 | 49.16889 | 1.069 | 2.2 | ug/L |
| Ba | 135 | 132781.089 | 3.0 | 46.667 | 47.87288 | 1.713 | 3.6 | ug/L |
| Ba | 137 | 224030.451 | 0.8 | 47.001 | 47.33022 | 0.430 | 0.9 | ug/L |
| Tb | 159 | 460708.454 | 1.3 | 411268.087 | | | | ug/L |
| Ho | 165 | 428470.773 | 1.1 | 390096.908 | | | | ug/L |
| Tl | 203 | 419622.437 | 0.9 | 60.001 | 48.12925 | 0.887 | 1.8 | ug/L |
| Tl | 205 | 963860.318 | 2.0 | 78.001 | 50.02503 | 0.639 | 1.3 | ug/L |
| Pb | 208 | 1339666.820 | 0.3 | 320.672 | 48.29899 | 0.395 | 0.8 | ug/L |

| | | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|-----|------|
| | Pb | 206 | 340964.550 | 0.8 | 87.335 | 46.73038 | 0.264 | 0.6 | ug/L |
| | Pb | 207 | 286683.973 | 0.9 | 77.001 | 47.04932 | 0.948 | 2.0 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 95.693 | | | | |
| Al | 27 | 121.972 | | | | |
| > Sc | 45 | | 107.760 | | | |
| V | 51 | 97.042 | | | | |
| Cr | 52 | 95.454 | | | | |
| Cr | 53 | 89.647 | | | | |
| Mn | 55 | 110.183 | | | | |
| Co | 59 | 103.447 | | | | |
| Ni | 60 | 106.286 | | | | |
| Ni | 62 | 106.286 | | | | |
| Cu | 63 | 107.521 | | | | |
| Cu | 65 | 109.618 | | | | |
| Zn | 66 | 109.831 | | | | |
| Zn | 67 | 105.025 | | | | |
| Zn | 68 | 109.089 | | | | |
| > Ge | 72 | | 95.082 | | | |
| As | 75 | 96.826 | | | | |
| Se | 77 | 105.407 | | | | |
| Se | 78 | 105.096 | | | | |
| Se | 82 | 106.504 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 95.864 | | | | |
| Mo | 97 | 100.181 | | | | |
| Mo | 98 | 97.971 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 100.957 | | | | |
| Ag | 109 | 101.980 | | | | |
| Cd | 111 | 103.310 | | | | |
| Cd | 114 | 107.222 | | | | |
| > In | 115 | | 106.629 | | | |
| Sb | 121 | 101.050 | | | | |
| Sb | 123 | 98.338 | | | | |
| Ba | 135 | 95.746 | | | | |
| Ba | 137 | 94.660 | | | | |
| > Tb | 159 | | 112.021 | | | |
| > Ho | 165 | | 109.837 | | | |
| Tl | 203 | 96.258 | | | | |
| Tl | 205 | 100.050 | | | | |
| Pb | 208 | 96.598 | | | | |
| Pb | 206 | 93.461 | | | | |
| Pb | 207 | 94.099 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 13, 2006 22:22:41

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 7.088

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 58.001 | 17.0 | 63.001 | -0.00970 | 0.007 | 75.5 | ug/L |
| Al | 27 | 3347.039 | 2.7 | 2334.350 | 0.09780 | 0.014 | 14.4 | ug/L |
| > Sc | 45 | 425292.184 | 1.4 | 381869.082 | | | | ug/L |
| V | 51 | 4850.499 | 6.5 | 4488.603 | -0.00798 | 0.020 | 248.5 | ug/L |
| Cr | 52 | 16047.603 | 2.4 | 15368.650 | -0.06669 | 0.037 | 55.3 | ug/L |
| Cr | 53 | 821.382 | 2.4 | 814.381 | -0.04252 | 0.015 | 34.1 | ug/L |
| Mn | 55 | 572.359 | 5.7 | 494.020 | 0.00521 | 0.001 | 26.6 | ug/L |
| Co | 59 | 146.336 | 4.4 | 188.671 | -0.00200 | 0.000 | 24.3 | ug/L |
| Ni | 60 | 130.336 | 12.7 | 136.669 | -0.00006 | 0.004 | 6224.0 | ug/L |
| Ni | 62 | 139.336 | 18.2 | 143.669 | 0.00424 | 0.048 | 1129.2 | ug/L |
| Cu | 63 | 257.007 | 13.9 | 212.338 | 0.00628 | 0.004 | 63.5 | ug/L |
| Cu | 65 | 215.005 | 14.1 | 189.671 | 0.00807 | 0.007 | 82.8 | ug/L |
| Zn | 66 | 1565.496 | 0.8 | 1515.486 | 0.04855 | 0.007 | 15.1 | ug/L |
| Zn | 67 | 319.676 | 11.1 | 342.344 | -0.01667 | 0.083 | 495.6 | ug/L |
| Zn | 68 | 1162.426 | 1.6 | 1170.427 | 0.02524 | 0.016 | 65.2 | ug/L |
| > Ge | 72 | 233744.164 | 1.3 | 244883.968 | | | | ug/L |
| As | 75 | 199.004 | 0.9 | 124.002 | 0.02655 | 0.001 | 5.2 | ug/L |
| Se | 77 | 244.404 | 2.8 | 216.736 | 0.16540 | 0.022 | 13.3 | ug/L |
| Se | 78 | 16211.021 | 1.4 | 16119.238 | 1.12173 | 0.538 | 47.9 | mg/L |
| Se | 82 | 1760.919 | 1.5 | 1872.010 | -0.08520 | 0.044 | 51.5 | ug/L |
| Kr | 83 | 1750.868 | 1.3 | 1902.236 | | | | mg/L |
| Y | 89 | 419542.644 | 2.0 | 408188.389 | | | | ug/L |
| Mo | 95 | 914.727 | 16.0 | 112.002 | 0.13256 | 0.022 | 16.7 | ug/L |
| Mo | 97 | 537.357 | 21.9 | 64.001 | 0.12850 | 0.030 | 23.5 | ug/L |
| Mo | 98 | 1346.886 | 17.4 | 98.282 | 0.13529 | 0.023 | 17.3 | ug/L |
| Rh | 103 | 351259.579 | 2.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 192.671 | 6.0 | 91.335 | 0.00628 | 0.001 | 18.5 | ug/L |
| Ag | 109 | 179.337 | 5.3 | 75.668 | 0.00696 | 0.001 | 11.9 | ug/L |
| Cd | 111 | 224.033 | 8.4 | 218.275 | -0.00498 | 0.008 | 151.8 | ug/L |
| Cd | 114 | 54.516 | 14.0 | 58.957 | -0.00140 | 0.001 | 87.3 | ug/L |
| > In | 115 | 395918.429 | 2.7 | 358352.924 | | | | ug/L |
| Sb | 121 | 1575.167 | 15.8 | 107.668 | 0.14127 | 0.022 | 15.7 | ug/L |
| Sb | 123 | 1178.063 | 15.1 | 79.665 | 0.13733 | 0.020 | 14.5 | ug/L |
| Ba | 135 | 57.001 | 12.7 | 46.667 | 0.00193 | 0.003 | 149.4 | ug/L |
| Ba | 137 | 61.334 | 8.4 | 47.001 | 0.00198 | 0.001 | 66.8 | ug/L |
| > Tb | 159 | 456110.395 | 1.8 | 411268.087 | | | | ug/L |
| > Ho | 165 | 439031.166 | 1.1 | 390096.908 | | | | ug/L |
| Tl | 203 | 92.001 | 11.3 | 60.001 | 0.00273 | 0.001 | 39.9 | ug/L |
| Tl | 205 | 151.336 | 4.0 | 78.001 | 0.00322 | 0.000 | 7.0 | ug/L |
| Pb | 208 | 494.344 | 5.2 | 320.672 | 0.00469 | 0.001 | 15.4 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Monday, November 13, 2006 22:25:41

Page 1

384

| | | | | | | | | |
|--|----|-----|---------|------|--------|---------|-------|-----------|
| | Pb | 206 | 132.669 | 15.0 | 87.335 | 0.00458 | 0.003 | 54.6 ug/L |
| | Pb | 207 | 117.002 | 3.7 | 77.001 | 0.00486 | 0.001 | 10.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 111.371 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 95.451 | | | |
| > As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 110.483 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 110.903 | | | |
| > Ho | 165 | | 112.544 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956S D.10

Sample Date/Time: Monday, November 13, 2006 22:28:39

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948956S D.10.089

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 2736.143 | 1.8 | 63.001 | 2.03982 | 0.039 | 1.9 | ug/L |
| Al | 27 | 94142.158 | 1.8 | 2334.350 | 11.53638 | 0.169 | 1.5 | ug/L |
| Sc | 45 | 440849.848 | 0.4 | 381869.082 | | | | ug/L |
| V | 51 | 45952.481 | 3.2 | 4488.603 | 2.15279 | 0.074 | 3.4 | ug/L |
| Cr | 52 | 52151.549 | 1.3 | 15368.650 | 2.08149 | 0.027 | 1.3 | ug/L |
| Cr | 53 | 5238.365 | 1.6 | 814.381 | 2.06542 | 0.031 | 1.5 | ug/L |
| Mn | 55 | 14678187.583 | 1.7 | 494.020 | 728.74264 | 14.295 | 2.0 | ug/L |
| Co | 59 | 73674.314 | 0.5 | 188.671 | 4.18669 | 0.025 | 0.6 | ug/L |
| Ni | 60 | 15171.954 | 2.1 | 136.669 | 3.81611 | 0.051 | 1.3 | ug/L |
| Ni | 62 | 2137.962 | 1.0 | 143.669 | 3.40353 | 0.068 | 2.0 | ug/L |
| Cu | 63 | 24968.615 | 2.5 | 212.338 | 2.74854 | 0.044 | 1.6 | ug/L |
| Cu | 65 | 11389.225 | 1.2 | 189.671 | 2.56691 | 0.019 | 0.7 | ug/L |
| Zn | 66 | 141302.315 | 0.3 | 1515.486 | 54.66989 | 0.704 | 1.3 | ug/L |
| Zn | 67 | 21505.262 | 0.6 | 342.344 | 47.65355 | 0.715 | 1.5 | ug/L |
| Zn | 68 | 97999.190 | 0.7 | 1170.427 | 51.56068 | 0.881 | 1.7 | ug/L |
| Ge | 72 | 243725.751 | 1.0 | 244883.968 | | | | ug/L |
| As | 75 | 73959.186 | 1.3 | 124.002 | 23.30913 | 0.412 | 1.8 | ug/L |
| Se | 77 | 763.368 | 1.7 | 216.736 | 2.31656 | 0.085 | 3.7 | ug/L |
| Se | 78 | 18557.579 | 1.7 | 16119.238 | 3.26819 | 0.448 | 13.7 | mg/L |
| Se | 82 | 2513.112 | 0.3 | 1872.010 | 2.04904 | 0.109 | 5.3 | ug/L |
| Kr | 83 | 1817.883 | 3.6 | 1902.236 | | | | mg/L |
| Y | 89 | 433417.516 | 0.9 | 408188.389 | | | | ug/L |
| Mo | 95 | 30730.873 | 1.4 | 112.002 | 5.02276 | 0.111 | 2.2 | ug/L |
| Mo | 97 | 18921.651 | 1.8 | 64.001 | 5.08848 | 0.211 | 4.1 | ug/L |
| Mo | 98 | 48757.995 | 1.4 | 98.282 | 5.20652 | 0.177 | 3.4 | ug/L |
| Rh | 103 | 356364.676 | 1.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 32813.492 | 2.2 | 91.335 | 2.17986 | 0.025 | 1.2 | ug/L |
| Ag | 109 | 31404.392 | 2.0 | 75.668 | 2.22134 | 0.036 | 1.6 | ug/L |
| Cd | 111 | 7842.475 | 2.2 | 218.275 | 2.21706 | 0.081 | 3.7 | ug/L |
| Cd | 114 | 17825.166 | 1.8 | 58.957 | 2.32898 | 0.104 | 4.5 | ug/L |
| In | 115 | 405105.352 | 2.7 | 358352.924 | | | | ug/L |
| Sb | 121 | 25731.592 | 1.0 | 107.668 | 2.43231 | 0.081 | 3.3 | ug/L |
| Sb | 123 | 19309.322 | 1.2 | 79.665 | 2.37091 | 0.036 | 1.5 | ug/L |
| Ba | 135 | 12868.058 | 1.9 | 46.667 | 4.58987 | 0.058 | 1.3 | ug/L |
| Ba | 137 | 21748.565 | 1.6 | 47.001 | 4.55357 | 0.095 | 2.1 | ug/L |
| Tb | 159 | 463853.187 | 0.6 | 411268.087 | | | | ug/L |
| Ho | 165 | 443971.628 | 2.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 19715.496 | 1.6 | 60.001 | 2.17551 | 0.061 | 2.8 | ug/L |
| Tl | 205 | 46945.017 | 1.6 | 78.001 | 2.34825 | 0.079 | 3.4 | ug/L |
| Pb | 208 | 64781.630 | 0.2 | 320.672 | 2.24236 | 0.043 | 1.9 | ug/L |

Sample ID: 948956S D.10

Report Date/Time: Monday, November 13, 2006 22:31:41

Page 1

| | | | | | | | | |
|---|----|-----|-----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 16506.499 | 1.6 | 87.335 | 2.17091 | 0.028 | 1.3 ug/L |
| L | Pb | 207 | 13641.627 | 0.9 | 77.001 | 2.14780 | 0.057 | 2.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 115.445 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 99.527 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 113.046 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 112.786 | | | |
| > Ho | 165 | | 113.811 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956A D.10

Sample Date/Time: Monday, November 13, 2006 22:34:38

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948956A D.10.090

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 24011.118 | 1.0 | 63.001 | 18.80798 | 0.213 | 1.1 | ug/L |
| Al | 27 | 262736.721 | 1.0 | 2334.350 | 33.66098 | 0.269 | 0.8 | ug/L |
| > Sc | 45 | 429796.310 | 1.5 | 381869.082 | | | | ug/L |
| V | 51 | 369170.432 | 1.6 | 4488.603 | 19.72735 | 0.599 | 3.0 | ug/L |
| Cr | 52 | 321467.306 | 0.2 | 15368.650 | 18.87660 | 0.271 | 1.4 | ug/L |
| Cr | 53 | 36957.483 | 1.4 | 814.381 | 17.76591 | 0.232 | 1.3 | ug/L |
| Mn | 55 | 15428840.654 | 1.2 | 494.020 | 787.12085 | 11.577 | 1.5 | ug/L |
| Co | 59 | 403561.364 | 1.1 | 188.671 | 23.61811 | 0.543 | 2.3 | ug/L |
| Ni | 60 | 90008.378 | 3.2 | 136.669 | 23.44188 | 0.783 | 3.3 | ug/L |
| Ni | 62 | 13014.285 | 1.2 | 143.669 | 22.56873 | 0.209 | 0.9 | ug/L |
| Cu | 63 | 199347.818 | 2.1 | 212.338 | 22.72597 | 0.744 | 3.3 | ug/L |
| Cu | 65 | 97311.600 | 1.6 | 189.671 | 22.87320 | 0.254 | 1.1 | ug/L |
| Zn | 66 | 179136.177 | 1.1 | 1515.486 | 71.39508 | 1.028 | 1.4 | ug/L |
| Zn | 67 | 28780.568 | 0.4 | 342.344 | 65.82158 | 0.992 | 1.5 | ug/L |
| Zn | 68 | 130345.114 | 2.3 | 1170.427 | 70.68482 | 1.091 | 1.5 | ug/L |
| > Ge | 72 | 237189.830 | 1.2 | 244883.968 | | | | ug/L |
| As | 75 | 130225.974 | 0.8 | 124.002 | 42.20253 | 0.191 | 0.5 | ug/L |
| Se | 77 | 4707.863 | 1.1 | 216.736 | 19.54575 | 0.100 | 0.5 | ug/L |
| Se | 78 | 31850.260 | 0.8 | 16119.238 | 21.68358 | 0.834 | 3.8 | mg/L |
| Se | 82 | 7934.309 | 0.1 | 1872.010 | 19.82409 | 0.291 | 1.5 | ug/L |
| Kr | 83 | 1850.224 | 2.7 | 1902.236 | | | | mg/L |
| Y | 89 | 415123.474 | 0.3 | 408188.389 | | | | ug/L |
| Mo | 95 | 136682.156 | 3.0 | 112.002 | 23.33280 | 0.614 | 2.6 | ug/L |
| Mo | 97 | 86374.852 | 3.4 | 64.001 | 24.26100 | 1.242 | 5.1 | ug/L |
| Mo | 98 | 212870.828 | 1.5 | 98.282 | 23.70393 | 0.431 | 1.8 | ug/L |
| Rh | 103 | 356360.885 | 0.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 306854.381 | 1.6 | 91.335 | 21.28693 | 0.133 | 0.6 | ug/L |
| Ag | 109 | 280092.679 | 2.8 | 75.668 | 20.67551 | 0.126 | 0.6 | ug/L |
| Cd | 111 | 67842.251 | 2.4 | 218.275 | 20.54945 | 0.882 | 4.3 | ug/L |
| Cd | 114 | 150348.283 | 1.4 | 58.957 | 20.51666 | 0.663 | 3.2 | ug/L |
| > In | 115 | 389018.977 | 2.1 | 358352.924 | | | | ug/L |
| Sb | 121 | 210863.359 | 1.7 | 107.668 | 20.84235 | 0.790 | 3.8 | ug/L |
| Sb | 123 | 161654.366 | 0.7 | 79.665 | 20.75389 | 0.295 | 1.4 | ug/L |
| Ba | 135 | 61750.913 | 1.1 | 46.667 | 22.20960 | 0.032 | 0.1 | ug/L |
| Ba | 137 | 106119.479 | 0.7 | 47.001 | 22.37519 | 0.404 | 1.8 | ug/L |
| > Tb | 159 | 461536.486 | 1.2 | 411268.087 | | | | ug/L |
| > Ho | 165 | 430303.616 | 1.0 | 390096.908 | | | | ug/L |
| Tl | 203 | 173438.363 | 0.7 | 60.001 | 19.80241 | 0.233 | 1.2 | ug/L |
| Tl | 205 | 400697.990 | 2.5 | 78.001 | 20.70950 | 0.659 | 3.2 | ug/L |
| Pb | 208 | 545386.140 | 1.5 | 320.672 | 19.57312 | 0.456 | 2.3 | ug/L |

| | | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|-----|------|
| | Pb | 206 | 140088.763 | 0.6 | 87.335 | 19.11155 | 0.297 | 1.6 | ug/L |
| | Pb | 207 | 118253.666 | 0.8 | 77.001 | 19.31595 | 0.342 | 1.8 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 112.551 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 96.858 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 108.558 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 112.223 | | | |
| > [Ho | 165 | | 110.307 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956L D.10

Sample Date/Time: Monday, November 13, 2006 22:40:38

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948956L D.10.091

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 58.667 | 6.0 | 63.001 | -0.00738 | 0.003 | 34.9 | ug/L |
| Al | 27 | 80203.972 | 1.6 | 2334.350 | 10.54538 | 0.247 | 2.3 | ug/L |
| > Sc | 45 | 409830.821 | 0.7 | 381869.082 | | | | ug/L |
| V | 51 | 4735.327 | 6.2 | 4488.603 | -0.00457 | 0.019 | 407.4 | ug/L |
| Cr | 52 | 16336.502 | 2.8 | 15368.650 | -0.01007 | 0.037 | 370.9 | ug/L |
| Cr | 53 | 870.054 | 4.6 | 814.381 | -0.00204 | 0.021 | 1013.9 | ug/L |
| Mn | 55 | 1022.740 | 5.2 | 494.020 | 0.03055 | 0.003 | 9.8 | ug/L |
| Co | 59 | 154.003 | 8.7 | 188.671 | -0.00120 | 0.001 | 66.1 | ug/L |
| Ni | 60 | 211.671 | 8.1 | 136.669 | 0.02361 | 0.004 | 18.5 | ug/L |
| Ni | 62 | 160.003 | 5.1 | 143.669 | 0.05156 | 0.017 | 32.6 | ug/L |
| Cu | 63 | 366.678 | 2.5 | 212.338 | 0.02060 | 0.001 | 6.0 | ug/L |
| Cu | 65 | 293.341 | 2.6 | 189.671 | 0.02951 | 0.002 | 7.3 | ug/L |
| Zn | 66 | 144841.958 | 2.7 | 1515.486 | 60.71127 | 1.514 | 2.5 | ug/L |
| Zn | 67 | 22224.152 | 0.9 | 342.344 | 53.39125 | 0.830 | 1.6 | ug/L |
| Zn | 68 | 102594.391 | 0.9 | 1170.427 | 58.49983 | 0.460 | 0.8 | ug/L |
| > Ge | 72 | 225181.818 | 0.6 | 244883.968 | | | | ug/L |
| As | 75 | 161.003 | 15.1 | 124.002 | 0.01602 | 0.008 | 49.7 | ug/L |
| Se | 77 | 231.803 | 3.7 | 216.736 | 0.14879 | 0.039 | 26.1 | ug/L |
| Se | 78 | 16403.747 | 0.5 | 16119.238 | 2.22387 | 0.044 | 2.0 | mg/L |
| Se | 82 | 1799.994 | 1.7 | 1872.010 | 0.26832 | 0.115 | 42.9 | ug/L |
| Kr | 83 | 1805.214 | 1.7 | 1902.236 | | | | mg/L |
| Y | 89 | 406441.899 | 1.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 376.012 | 8.2 | 112.002 | 0.04419 | 0.005 | 12.3 | ug/L |
| Mo | 97 | 223.339 | 16.3 | 64.001 | 0.04393 | 0.010 | 23.7 | ug/L |
| Mo | 98 | 478.850 | 12.3 | 98.282 | 0.04206 | 0.007 | 15.8 | ug/L |
| Rh | 103 | 350434.416 | 1.0 | 340052.119 | | | | ug/L |
| Ag | 107 | 83.668 | 12.0 | 91.335 | -0.00101 | 0.001 | 68.6 | ug/L |
| Ag | 109 | 77.668 | 2.7 | 75.668 | -0.00027 | 0.000 | 55.7 | ug/L |
| Cd | 111 | 272.303 | 15.7 | 218.275 | 0.01166 | 0.013 | 112.3 | ug/L |
| Cd | 114 | 146.891 | 10.1 | 58.957 | 0.01154 | 0.002 | 18.0 | ug/L |
| > In | 115 | 384706.664 | 0.2 | 358352.924 | | | | ug/L |
| Sb | 121 | 629.030 | 11.5 | 107.668 | 0.05133 | 0.007 | 14.2 | ug/L |
| Sb | 123 | 499.738 | 10.3 | 79.665 | 0.05380 | 0.007 | 12.6 | ug/L |
| Ba | 135 | 64.001 | 12.2 | 46.667 | 0.00458 | 0.003 | 56.6 | ug/L |
| Ba | 137 | 92.001 | 9.3 | 47.001 | 0.00865 | 0.002 | 25.2 | ug/L |
| > Tb | 159 | 453432.958 | 1.7 | 411268.087 | | | | ug/L |
| > Ho | 165 | 427423.696 | 1.1 | 390096.908 | | | | ug/L |
| Tl | 203 | 75.668 | 5.0 | 60.001 | 0.00114 | 0.000 | 30.3 | ug/L |
| Tl | 205 | 126.002 | 13.1 | 78.001 | 0.00211 | 0.001 | 43.0 | ug/L |
| Pb | 208 | 1188.711 | 1.7 | 320.672 | 0.03027 | 0.001 | 2.8 | ug/L |

Sample ID: 948956L D.10

Report Date/Time: Monday, November 13, 2006 22:43:40

Page 1

393

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|-----------|
| | Pb | 206 | 303.342 | 5.9 | 87.335 | 0.02852 | 0.002 | 7.2 ug/L |
| | Pb | 207 | 287.008 | 9.8 | 77.001 | 0.03337 | 0.005 | 15.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 107.322 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 91.954 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 107.354 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 110.252 | | | |
| > Ho | 165 | | 109.569 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948957 D.10

Sample Date/Time: Monday, November 13, 2006 22:46:37

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990131

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\948957 D.10.092

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55.334 | 23.5 | 63.001 | -0.01367 | 0.009 | 68.3 | ug/L |
| Al | 27 | 79234.025 | 0.4 | 2334.350 | 9.59934 | 0.198 | 2.1 | ug/L |
| > Sc | 45 | 443470.996 | 1.9 | 381869.082 | | | | ug/L |
| V | 51 | 4936.337 | 3.5 | 4488.603 | -0.01455 | 0.005 | 34.1 | ug/L |
| Cr | 52 | 17625.465 | 1.3 | 15368.650 | -0.01328 | 0.010 | 72.6 | ug/L |
| Cr | 53 | 1127.754 | 2.8 | 814.381 | 0.08725 | 0.025 | 28.9 | ug/L |
| Mn | 55 | 14454041.555 | 3.8 | 494.020 | 711.29884 | 18.601 | 2.6 | ug/L |
| Co | 59 | 29651.635 | 1.9 | 188.671 | 1.66450 | 0.048 | 2.9 | ug/L |
| Ni | 60 | 8303.230 | 6.6 | 136.669 | 2.05576 | 0.153 | 7.5 | ug/L |
| Ni | 62 | 1192.431 | 5.6 | 143.669 | 1.77294 | 0.115 | 6.5 | ug/L |
| Cu | 63 | 2715.470 | 2.5 | 212.338 | 0.27553 | 0.010 | 3.7 | ug/L |
| Cu | 65 | 917.726 | 3.9 | 189.671 | 0.16525 | 0.007 | 4.3 | ug/L |
| Zn | 66 | 148391.345 | 0.1 | 1515.486 | 56.94731 | 0.648 | 1.1 | ug/L |
| Zn | 67 | 22468.476 | 1.0 | 342.344 | 49.39389 | 1.035 | 2.1 | ug/L |
| Zn | 68 | 102016.723 | 1.2 | 1170.427 | 53.23093 | 0.329 | 0.6 | ug/L |
| > Ge | 72 | 245821.733 | 1.2 | 244883.968 | | | | ug/L |
| As | 75 | 66810.081 | 0.4 | 124.002 | 20.87211 | 0.209 | 1.0 | ug/L |
| Se | 77 | 240.537 | 5.2 | 216.736 | 0.09655 | 0.058 | 60.2 | ug/L |
| Se | 78 | 16828.490 | 1.8 | 16119.238 | 0.83798 | 0.587 | 70.1 | mg/L |
| Se | 82 | 1896.549 | 1.1 | 1872.010 | 0.05511 | 0.119 | 215.9 | ug/L |
| Kr | 83 | 1918.573 | 2.0 | 1902.236 | | | | mg/L |
| Y | 89 | 430519.541 | 4.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 17225.290 | 0.8 | 112.002 | 2.79171 | 0.077 | 2.8 | ug/L |
| Mo | 97 | 10139.934 | 0.7 | 64.001 | 2.70257 | 0.062 | 2.3 | ug/L |
| Mo | 98 | 26983.125 | 2.3 | 98.282 | 2.86078 | 0.109 | 3.8 | ug/L |
| Rh | 103 | 365118.635 | 0.6 | 340052.119 | | | | ug/L |
| Ag | 107 | 111.669 | 2.1 | 91.335 | 0.00052 | 0.000 | 28.2 | ug/L |
| Ag | 109 | 95.335 | 4.2 | 75.668 | 0.00066 | 0.000 | 25.6 | ug/L |
| Cd | 111 | 246.834 | 3.5 | 218.275 | -0.00029 | 0.004 | 1448.1 | ug/L |
| Cd | 114 | 161.513 | 11.1 | 58.957 | 0.01229 | 0.002 | 15.2 | ug/L |
| > In | 115 | 407228.536 | 2.4 | 358352.924 | | | | ug/L |
| Sb | 121 | 835.384 | 2.4 | 107.668 | 0.06738 | 0.003 | 5.1 | ug/L |
| Sb | 123 | 636.017 | 7.4 | 79.665 | 0.06690 | 0.005 | 7.3 | ug/L |
| Ba | 135 | 6709.435 | 2.3 | 46.667 | 2.38395 | 0.058 | 2.4 | ug/L |
| Ba | 137 | 10993.690 | 0.4 | 47.001 | 2.29582 | 0.013 | 0.6 | ug/L |
| > Tb | 159 | 463918.813 | 0.4 | 411268.087 | | | | ug/L |
| > Ho | 165 | 446629.063 | 0.4 | 390096.908 | | | | ug/L |
| Tl | 203 | 266.674 | 14.1 | 60.001 | 0.02178 | 0.004 | 18.9 | ug/L |
| Tl | 205 | 550.024 | 7.3 | 78.001 | 0.02294 | 0.002 | 8.6 | ug/L |
| Pb | 208 | 1292.718 | 3.1 | 320.672 | 0.03202 | 0.001 | 4.3 | ug/L |

| | | | | | | | | |
|--|----|-----|---------|-----|--------|---------|-------|----------|
| | Pb | 206 | 332.343 | 3.5 | 87.335 | 0.03056 | 0.002 | 5.0 ug/L |
| | Pb | 207 | 292.341 | 2.6 | 77.001 | 0.03215 | 0.001 | 3.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 116.132 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 100.383 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 113.639 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 112.802 | | | |
| > Ho | 165 | | 114.492 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Monday, November 13, 2006 22:52:35

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 3.093

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1253.774 | 1.7 | 63.001 | 0.94437 | 0.046 | 4.9 | ug/L |
| Al | 27 | 95426.557 | 0.6 | 2334.350 | 12.19611 | 0.460 | 3.8 | ug/L |
| > Sc | 45 | 423683.384 | 3.1 | 381869.082 | | | | ug/L |
| V | 51 | 23254.023 | 0.8 | 4488.603 | 1.00490 | 0.043 | 4.3 | ug/L |
| Cr | 52 | 32963.400 | 1.0 | 15368.650 | 1.00252 | 0.045 | 4.5 | ug/L |
| Cr | 53 | 2853.517 | 1.4 | 814.381 | 0.97552 | 0.024 | 2.5 | ug/L |
| Mn | 55 | 23388.348 | 1.6 | 494.020 | 1.18436 | 0.035 | 3.0 | ug/L |
| Co | 59 | 19070.989 | 0.8 | 188.671 | 1.12013 | 0.010 | 0.9 | ug/L |
| Ni | 60 | 4393.536 | 2.7 | 136.669 | 1.12612 | 0.031 | 2.7 | ug/L |
| Ni | 62 | 770.043 | 4.8 | 143.669 | 1.12395 | 0.085 | 7.6 | ug/L |
| Cu | 63 | 9864.267 | 0.8 | 212.338 | 1.11657 | 0.021 | 1.9 | ug/L |
| Cu | 65 | 4801.764 | 0.5 | 189.671 | 1.10215 | 0.012 | 1.1 | ug/L |
| Zn | 66 | 17201.577 | 1.8 | 1515.486 | 6.41261 | 0.211 | 3.3 | ug/L |
| Zn | 67 | 2666.453 | 1.8 | 342.344 | 5.48105 | 0.110 | 2.0 | ug/L |
| Zn | 68 | 11861.221 | 0.7 | 1170.427 | 5.95313 | 0.121 | 2.0 | ug/L |
| > Ge | 72 | 234182.949 | 1.4 | 244883.968 | | | | ug/L |
| As | 75 | 3165.300 | 2.7 | 124.002 | 1.00086 | 0.020 | 2.0 | ug/L |
| Se | 77 | 457.479 | 3.7 | 216.736 | 1.10098 | 0.057 | 5.1 | ug/L |
| Se | 78 | 17349.650 | 0.4 | 16119.238 | 2.61926 | 0.353 | 13.5 | mg/L |
| Se | 82 | 2119.403 | 1.4 | 1872.010 | 1.07971 | 0.027 | 2.5 | ug/L |
| Kr | 83 | 1849.890 | 1.3 | 1902.236 | | | | mg/L |
| Y | 89 | 413036.369 | 1.2 | 408188.389 | | | | ug/L |
| Mo | 95 | 6153.000 | 3.0 | 112.002 | 1.00679 | 0.045 | 4.4 | ug/L |
| Mo | 97 | 3666.510 | 1.2 | 64.001 | 0.98713 | 0.025 | 2.5 | ug/L |
| Mo | 98 | 9715.485 | 1.6 | 98.282 | 1.04565 | 0.019 | 1.8 | ug/L |
| Rh | 103 | 351662.517 | 2.1 | 340052.119 | | | | ug/L |
| Ag | 107 | 15742.014 | 1.6 | 91.335 | 1.06043 | 0.006 | 0.6 | ug/L |
| Ag | 109 | 14749.194 | 2.6 | 75.668 | 1.05818 | 0.024 | 2.3 | ug/L |
| Cd | 111 | 3604.693 | 3.0 | 218.275 | 0.99812 | 0.033 | 3.3 | ug/L |
| Cd | 114 | 7889.691 | 1.7 | 58.957 | 1.04356 | 0.032 | 3.1 | ug/L |
| > In | 115 | 398124.143 | 1.3 | 358352.924 | | | | ug/L |
| Sb | 121 | 10898.233 | 2.3 | 107.668 | 1.04111 | 0.025 | 2.4 | ug/L |
| Sb | 123 | 8405.170 | 0.9 | 79.665 | 1.04384 | 0.022 | 2.1 | ug/L |
| Ba | 135 | 2878.193 | 3.2 | 46.667 | 1.02745 | 0.026 | 2.5 | ug/L |
| Ba | 137 | 4822.444 | 2.7 | 47.001 | 1.01631 | 0.031 | 3.1 | ug/L |
| > Tb | 159 | 456981.543 | 1.3 | 411268.087 | | | | ug/L |
| > Ho | 165 | 439087.980 | 2.1 | 390096.908 | | | | ug/L |
| Tl | 203 | 8777.041 | 1.4 | 60.001 | 0.97529 | 0.034 | 3.4 | ug/L |
| Tl | 205 | 20545.175 | 2.2 | 78.001 | 1.03621 | 0.009 | 0.9 | ug/L |
| Pb | 208 | 28968.545 | 0.6 | 320.672 | 1.00687 | 0.015 | 1.5 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Monday, November 13, 2006 22:55:35

Page 1

| | | | | | | | | |
|--|----|-----|----------|-----|--------|---------|-------|----------|
| | Pb | 206 | 7679.948 | 1.7 | 87.335 | 1.01428 | 0.005 | 0.5 ug/L |
| | Pb | 207 | 6108.966 | 1.2 | 77.001 | 0.96479 | 0.017 | 1.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 94.437 | | | | |
| Al | 27 | 121.961 | | | | |
| > Sc | 45 | | 110.950 | | | |
| V | 51 | 100.490 | | | | |
| Cr | 52 | 100.252 | | | | |
| Cr | 53 | 97.552 | | | | |
| Mn | 55 | 118.436 | | | | |
| Co | 59 | 112.013 | | | | |
| Ni | 60 | 112.612 | | | | |
| Ni | 62 | 112.395 | | | | |
| Cu | 63 | 111.657 | | | | |
| Cu | 65 | 110.215 | | | | |
| Zn | 66 | 128.252 | | | | |
| Zn | 67 | 109.621 | | | | |
| Zn | 68 | 119.063 | | | | |
| > Ge | 72 | | 95.630 | | | |
| As | 75 | 100.086 | | | | |
| Se | 77 | 110.098 | | | | |
| Se | 78 | 261.926 | | | | |
| Se | 82 | 107.971 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 100.679 | | | | |
| Mo | 97 | 98.713 | | | | |
| Mo | 98 | 104.565 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 106.043 | | | | |
| Ag | 109 | 105.818 | | | | |
| Cd | 111 | 99.812 | | | | |
| Cd | 114 | 104.356 | | | | |
| > In | 115 | | 111.098 | | | |
| Sb | 121 | 104.111 | | | | |
| Sb | 123 | 104.384 | | | | |
| Ba | 135 | 102.745 | | | | |
| Ba | 137 | 101.631 | | | | |
| > Tb | 159 | | 111.115 | | | |
| > Ho | 165 | | 112.559 | | | |
| Tl | 203 | 97.529 | | | | |
| Tl | 205 | 103.621 | | | | |
| Pb | 208 | 100.687 | | | | |
| Pb | 206 | 101.428 | | | | |
| Pb | 207 | 96.479 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 13, 2006 22:58:32

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 6.094

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 57978.243 | 0.8 | 63.001 | 47.92357 | 1.194 | 2.5 | ug/L |
| Al | 27 | 436339.640 | 2.6 | 2334.350 | 59.14623 | 2.278 | 3.9 | ug/L |
| > Sc | 45 | 408106.300 | 1.7 | 381869.082 | | | | ug/L |
| V | 51 | 851628.213 | 0.7 | 4488.603 | 48.31665 | 1.127 | 2.3 | ug/L |
| Cr | 52 | 730405.454 | 2.1 | 15368.650 | 46.67781 | 1.808 | 3.9 | ug/L |
| Cr | 53 | 89603.815 | 1.8 | 814.381 | 46.07817 | 1.532 | 3.3 | ug/L |
| Mn | 55 | 1012991.431 | 0.4 | 494.020 | 53.56319 | 0.976 | 1.8 | ug/L |
| Co | 59 | 875681.502 | 2.4 | 188.671 | 53.13434 | 0.753 | 1.4 | ug/L |
| Ni | 60 | 194174.913 | 2.4 | 136.669 | 52.46682 | 0.525 | 1.0 | ug/L |
| Ni | 62 | 29134.814 | 2.1 | 143.669 | 52.70196 | 0.560 | 1.1 | ug/L |
| Cu | 63 | 463470.024 | 0.9 | 212.338 | 54.80600 | 0.861 | 1.6 | ug/L |
| Cu | 65 | 219062.280 | 1.0 | 189.671 | 53.44812 | 0.734 | 1.4 | ug/L |
| Zn | 66 | 130148.218 | 1.5 | 1515.486 | 53.64554 | 1.616 | 3.0 | ug/L |
| Zn | 67 | 22695.430 | 1.9 | 342.344 | 53.66812 | 0.624 | 1.2 | ug/L |
| Zn | 68 | 94787.796 | 2.1 | 1170.427 | 53.14039 | 0.323 | 0.6 | ug/L |
| > Ge | 72 | 228773.780 | 1.5 | 244883.968 | | | | ug/L |
| As | 75 | 148491.268 | 3.1 | 124.002 | 49.89523 | 1.241 | 2.5 | ug/L |
| Se | 77 | 11873.119 | 0.9 | 216.736 | 52.58559 | 0.736 | 1.4 | ug/L |
| Se | 78 | 54009.574 | 1.0 | 16119.238 | 53.93048 | 1.843 | 3.4 | mg/L |
| Se | 82 | 17593.085 | 0.3 | 1872.010 | 53.20508 | 0.992 | 1.9 | ug/L |
| Kr | 83 | 1798.546 | 3.8 | 1902.236 | | | | mg/L |
| Y | 89 | 405854.069 | 0.7 | 408188.389 | | | | ug/L |
| Mo | 95 | 277048.959 | 0.8 | 112.002 | 47.30808 | 0.749 | 1.6 | ug/L |
| Mo | 97 | 170518.312 | 1.8 | 64.001 | 47.87647 | 0.986 | 2.1 | ug/L |
| Mo | 98 | 432428.777 | 1.8 | 98.282 | 48.15069 | 1.053 | 2.2 | ug/L |
| Rh | 103 | 340106.010 | 1.4 | 340052.119 | | | | ug/L |
| Ag | 107 | 708535.689 | 2.4 | 91.335 | 49.15475 | 1.462 | 3.0 | ug/L |
| Ag | 109 | 674859.453 | 1.0 | 75.668 | 49.82421 | 0.843 | 1.7 | ug/L |
| Cd | 111 | 165504.093 | 2.9 | 218.275 | 50.20697 | 1.831 | 3.6 | ug/L |
| Cd | 114 | 371929.149 | 0.4 | 58.957 | 50.73724 | 0.262 | 0.5 | ug/L |
| > In | 115 | 389087.769 | 0.8 | 358352.924 | | | | ug/L |
| Sb | 121 | 490056.469 | 1.6 | 107.668 | 48.41857 | 0.613 | 1.3 | ug/L |
| Sb | 123 | 374963.218 | 0.8 | 79.665 | 48.13600 | 0.136 | 0.3 | ug/L |
| Ba | 135 | 131167.251 | 0.9 | 46.667 | 49.17803 | 0.852 | 1.7 | ug/L |
| Ba | 137 | 223577.145 | 0.7 | 47.001 | 49.12155 | 0.351 | 0.7 | ug/L |
| > Tb | 159 | 443015.323 | 1.4 | 411268.087 | | | | ug/L |
| > Ho | 165 | 426716.348 | 1.6 | 390096.908 | | | | ug/L |
| Tl | 203 | 410292.879 | 3.5 | 60.001 | 47.24671 | 1.455 | 3.1 | ug/L |
| Tl | 205 | 924488.381 | 1.4 | 78.001 | 48.18463 | 0.707 | 1.5 | ug/L |
| Pb | 208 | 1322892.097 | 0.6 | 320.672 | 47.89349 | 0.607 | 1.3 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Monday, November 13, 2006 23:01:34

Page 1

402

| | | | | | | | | |
|--|----|-----|------------|-----|--------|----------|-------|----------|
| | Pb | 206 | 346276.869 | 1.0 | 87.335 | 47.66450 | 1.158 | 2.4 ug/L |
| | Pb | 207 | 280420.658 | 1.3 | 77.001 | 46.20593 | 0.325 | 0.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 95.847 | | | | |
| Al | 27 | 118.292 | | | | |
| > Sc | 45 | | 106.871 | | | |
| V | 51 | 96.633 | | | | |
| Cr | 52 | 93.356 | | | | |
| Cr | 53 | 92.156 | | | | |
| Mn | 55 | 107.126 | | | | |
| Co | 59 | 106.269 | | | | |
| Ni | 60 | 104.934 | | | | |
| Ni | 62 | 105.404 | | | | |
| Cu | 63 | 109.612 | | | | |
| Cu | 65 | 106.896 | | | | |
| Zn | 66 | 107.291 | | | | |
| Zn | 67 | 107.336 | | | | |
| Zn | 68 | 106.281 | | | | |
| > Ge | 72 | | 93.421 | | | |
| As | 75 | 99.790 | | | | |
| Se | 77 | 105.171 | | | | |
| Se | 78 | 107.861 | | | | |
| Se | 82 | 106.410 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 94.616 | | | | |
| Mo | 97 | 95.753 | | | | |
| Mo | 98 | 96.301 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 98.310 | | | | |
| Ag | 109 | 99.648 | | | | |
| Cd | 111 | 100.414 | | | | |
| Cd | 114 | 101.474 | | | | |
| > In | 115 | | 108.577 | | | |
| Sb | 121 | 96.837 | | | | |
| Sb | 123 | 96.272 | | | | |
| Ba | 135 | 98.356 | | | | |
| Ba | 137 | 98.243 | | | | |
| > Tb | 159 | | 107.719 | | | |
| > Ho | 165 | | 109.387 | | | |
| Tl | 203 | 94.493 | | | | |
| Tl | 205 | 96.369 | | | | |
| Pb | 208 | 95.787 | | | | |
| Pb | 206 | 95.329 | | | | |
| Pb | 207 | 92.412 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 13, 2006 23:04:30

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111306A\QC Std 7.095

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 57.667 | 7.8 | 63.001 | -0.00911 | 0.004 | 48.0 | ug/L |
| Al | 27 | 3393.058 | 1.5 | 2334.350 | 0.11137 | 0.014 | 12.8 | ug/L |
| Sc | 45 | 418248.116 | 1.6 | 381869.082 | | | | ug/L |
| V | 51 | 5003.300 | 2.9 | 4488.603 | 0.00492 | 0.010 | 209.1 | ug/L |
| Cr | 52 | 16499.817 | 0.6 | 15368.650 | -0.02101 | 0.020 | 97.2 | ug/L |
| Cr | 53 | 780.044 | 0.9 | 814.381 | -0.05658 | 0.010 | 18.1 | ug/L |
| Mn | 55 | 590.694 | 4.0 | 494.020 | 0.00648 | 0.001 | 23.1 | ug/L |
| Co | 59 | 143.336 | 4.9 | 188.671 | -0.00209 | 0.001 | 24.0 | ug/L |
| Ni | 60 | 134.336 | 12.4 | 136.669 | 0.00140 | 0.005 | 326.5 | ug/L |
| Ni | 62 | 146.336 | 6.8 | 143.669 | 0.01889 | 0.016 | 82.2 | ug/L |
| Cu | 63 | 219.005 | 9.2 | 212.338 | 0.00214 | 0.002 | 104.9 | ug/L |
| Cu | 65 | 196.338 | 11.8 | 189.671 | 0.00412 | 0.006 | 133.6 | ug/L |
| Zn | 66 | 1547.493 | 3.8 | 1515.486 | 0.04747 | 0.022 | 46.9 | ug/L |
| Zn | 67 | 310.342 | 6.1 | 342.344 | -0.03091 | 0.052 | 168.3 | ug/L |
| Zn | 68 | 1154.425 | 7.0 | 1170.427 | 0.02704 | 0.043 | 159.5 | ug/L |
| Ge | 72 | 231418.741 | 1.0 | 244883.968 | | | | ug/L |
| As | 75 | 192.337 | 3.8 | 124.002 | 0.02500 | 0.003 | 11.9 | ug/L |
| Se | 77 | 237.203 | 0.9 | 216.736 | 0.14432 | 0.016 | 11.1 | ug/L |
| Se | 78 | 15956.974 | 0.2 | 16119.238 | 0.99180 | 0.169 | 17.0 | mg/L |
| Se | 82 | 1825.200 | 2.0 | 1872.010 | 0.18739 | 0.177 | 94.3 | ug/L |
| Kr | 83 | 1801.880 | 3.4 | 1902.236 | | | | mg/L |
| Y | 89 | 416463.600 | 0.3 | 408188.389 | | | | ug/L |
| Mo | 95 | 873.056 | 18.8 | 112.002 | 0.13025 | 0.027 | 20.4 | ug/L |
| Mo | 97 | 530.356 | 15.9 | 64.001 | 0.13135 | 0.022 | 16.8 | ug/L |
| Mo | 98 | 1339.994 | 20.3 | 98.282 | 0.13920 | 0.029 | 20.6 | ug/L |
| Rh | 103 | 354693.926 | 1.8 | 340052.119 | | | | ug/L |
| Ag | 107 | 189.337 | 8.8 | 91.335 | 0.00643 | 0.001 | 15.8 | ug/L |
| Ag | 109 | 169.670 | 4.0 | 75.668 | 0.00664 | 0.001 | 9.3 | ug/L |
| Cd | 111 | 230.997 | 3.5 | 218.275 | -0.00083 | 0.002 | 267.8 | ug/L |
| Cd | 114 | 56.751 | 15.7 | 58.957 | -0.00089 | 0.001 | 127.7 | ug/L |
| In | 115 | 383677.927 | 1.4 | 358352.924 | | | | ug/L |
| Sb | 121 | 1568.833 | 16.1 | 107.668 | 0.14548 | 0.023 | 16.1 | ug/L |
| Sb | 123 | 1142.512 | 12.2 | 79.665 | 0.13752 | 0.016 | 11.7 | ug/L |
| Ba | 135 | 52.334 | 6.7 | 46.667 | 0.00038 | 0.001 | 326.8 | ug/L |
| Ba | 137 | 57.001 | 17.8 | 47.001 | 0.00112 | 0.002 | 172.2 | ug/L |
| Tb | 159 | 452050.831 | 2.3 | 411268.087 | | | | ug/L |
| Ho | 165 | 428245.939 | 0.3 | 390096.908 | | | | ug/L |
| Tl | 203 | 83.668 | 14.2 | 60.001 | 0.00204 | 0.001 | 67.3 | ug/L |
| Tl | 205 | 153.336 | 6.4 | 78.001 | 0.00352 | 0.001 | 14.9 | ug/L |
| Pb | 208 | 495.344 | 4.9 | 320.672 | 0.00517 | 0.001 | 17.2 | ug/L |

| | | | | | | | | |
|--|----|-----|---------|------|--------|---------|-------|-----------|
| | Pb | 206 | 136.002 | 12.7 | 87.335 | 0.00551 | 0.002 | 43.7 ug/L |
| | Pb | 207 | 116.002 | 13.9 | 77.001 | 0.00517 | 0.003 | 51.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 109.527 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 94.501 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 107.067 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 109.916 | | | |
| > [Ho | 165 | | 109.779 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Metals Cover Page

Analyst: SDevto

Date: 11/17/06

Instrument: ELAN

Data File: 111706

Reviewed By: SD 11/19/06

Entered By: SD 11/20/06

Manager Approval: 11/21/06 DCB

| Starlims Run # | Analytes Used | Batch ID | Method | Failed Analytes | Comments/ Problems |
|----------------|---------------|----------|--------|-----------------|-------------------------|
| 137710 | Be | M3990143 | 6020 | | 9524106-469 only 469 |
| 137711 | Mn Cu As Cd | M3990143 | 6020 | | 948936, 51 As |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

Package Data:

| Client Sub# | Package | Analytes Used | Failed Metals | Batch ID | Stds Attached? | Transferred To LIMS | Raw Data Copied? |
|-------------|---------|------------------|---------------|----------|----------------|---------------------|------------------|
| 34493 | 5 / ASP | Be Mn Cu Cd | | M3990143 | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | 9524106-469 only | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| 34382 | 5 / ASP | As Mn | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |

Daily Performance Report

Sample ID: Sample

Sample Date/Time: Friday, November 17, 2006 15:24:16

Sample Description:

Method File: c:\elandata\Method\EPA DAILY.mth

Dataset File: c:\elandata\Dataset\Daily2006\Sample.239

Tuning File: c:\elandata\Tuning\epa.tun

Optimization File: c:\elandata\Optimize\epa2.dac

Dual Detector Mode: Dual

Acq. Dead Time(ns): 60

Current Dead Time (ns): 60

Summary

| Analyte | Mass | Meas. Intens. Mean | Net Intens. Mean | Net Intens. SD | Net Intens. RSD |
|---------|-------|--------------------|------------------|----------------|-----------------|
| Mg | 24.0 | 63293.2 | 63293.189 | 808.999 | 1.3 |
| Rh | 102.9 | 400982.4 | 400982.440 | 7504.076 | 1.9 |
| In | 114.9 | 369301.8 | 369301.758 | 5562.578 | 1.5 |
| Pb | 208.0 | 150464.0 | 150464.005 | 1325.017 | 0.9 |
| U | 238.1 | 267428.0 | 267428.045 | 3045.769 | 1.1 |
| [> Ba | 137.9 | 315898.4 | 315898.399 | 4364.675 | 1.4 |
| [Ba++ | 69.0 | 8721.4 | 0.028 | 0.001 | 2.1 |
| [> Ce | 139.9 | 433947.2 | 433947.243 | 4864.959 | 1.1 |
| [CeO | 155.9 | 8941.7 | 0.021 | 0.000 | 2.4 |
| Bkgd | 220.0 | 36.4 | 36.404 | 7.058 | 19.4 |

Current Optimization File Data

| Current Value | Description |
|---------------|-------------------------|
| 1.01 | Nebulizer Gas Flow |
| 8.00 | Lens Voltage |
| 1500.00 | ICP RF Power |
| -1832.50 | Analog Stage Voltage |
| 1017.50 | Pulse Stage Voltage |
| 70.00 | Discriminator Threshold |
| -2.50 | AC Rod Offset |

Current Autolens Data

| Analyte | Mass | Num of Pts | DAC Value | Maximum Intensity |
|---------|------|------------|-----------|-------------------|
| Be | 9 | 29 | 6.0 | 11347.2 |
| Co | 59 | 29 | 7.8 | 163395.3 |
| In | 115 | 29 | 8.0 | 266809.4 |

Elan 9000 Method 6020 - Summary Report

Sample ID: Blank

Sample Date/Time: Friday, November 17, 2006 15:28:08

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\Blank.001

Skelto
11/17/06

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 84.001 | 29.8 | | | | | ug/L |
| Al | 27 | 6946.222 | 55.4 | | | | | ug/L |
| > Sc | 45 | 426236.083 | 1.8 | | | | | ug/L |
| V | 51 | 5344.504 | 3.8 | | | | | ug/L |
| Cr | 52 | 18378.762 | 0.9 | | | | | ug/L |
| Cr | 53 | 1484.814 | 1.2 | | | | | ug/L |
| Mn | 55 | 742.040 | 1.2 | | | | | ug/L |
| Co | 59 | 848.388 | 29.6 | | | | | ug/L |
| Ni | 60 | 167.670 | 2.3 | | | | | ug/L |
| Ni | 62 | 209.338 | 4.5 | | | | | ug/L |
| Cu | 63 | 570.693 | 33.9 | | | | | ug/L |
| Cu | 65 | 318.010 | 26.6 | | | | | ug/L |
| Zn | 66 | 2186.325 | 29.7 | | | | | ug/L |
| Zn | 67 | 469.352 | 24.2 | | | | | ug/L |
| Zn | 68 | 1708.532 | 22.9 | | | | | ug/L |
| > Ge | 72 | 235019.833 | 1.0 | | | | | ug/L |
| As | 75 | 174.004 | 3.6 | | | | | ug/L |
| Se | 77 | 271.738 | 4.3 | | | | | ug/L |
| Se | 78 | 18294.754 | 1.6 | | | | | mg/L |
| Se | 82 | 514.483 | 0.9 | | | | | ug/L |
| Kr | 83 | 509.687 | 1.1 | | | | | mg/L |
| Y | 89 | 424645.807 | 0.2 | | | | | ug/L |
| Mo | 95 | 130.336 | 2.5 | | | | | ug/L |
| Mo | 97 | 59.667 | 5.4 | | | | | ug/L |
| Mo | 98 | 73.129 | 15.8 | | | | | ug/L |
| Rh | 103 | 377819.614 | 3.6 | | | | | ug/L |
| Ag | 107 | 60.668 | 20.9 | | | | | ug/L |
| Ag | 109 | 49.001 | 4.1 | | | | | ug/L |
| Cd | 111 | 302.744 | 26.7 | | | | | ug/L |
| Cd | 114 | 257.978 | 38.4 | | | | | ug/L |
| > In | 115 | 368464.817 | 0.9 | | | | | ug/L |
| Sb | 121 | 54.001 | 18.5 | | | | | ug/L |
| Sb | 123 | 50.513 | 9.6 | | | | | ug/L |
| Ba | 135 | 123.002 | 29.7 | | | | | ug/L |
| Ba | 137 | 192.338 | 44.8 | | | | | ug/L |
| > Tb | 159 | 460537.107 | 1.8 | | | | | ug/L |
| > Ho | 165 | 440378.521 | 1.7 | | | | | ug/L |
| Tl | 203 | 83.668 | 7.8 | | | | | ug/L |
| Tl | 205 | 163.337 | 7.7 | | | | | ug/L |
| Pb | 208 | 1492.737 | 33.9 | | | | | ug/L |

Sample ID: Blank

Report Date/Time: Friday, November 17, 2006 15:31:08

Page 1

410

| | | | | | |
|--|----|-----|---------|------|------|
| | Pb | 206 | 397.348 | 37.9 | ug/L |
| | Pb | 207 | 320.010 | 29.8 | ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 1

Sample Date/Time: Friday, November 17, 2006 15:34:05

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\Standard 1.002

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 11939.334 | 1.2 | 84.001 | 10.00000 | 0.334 | 3.3 | ug/L |
| Al | 27 | 96625.808 | 2.4 | 6946.222 | 10.00000 | 0.572 | 5.7 | ug/L |
| Sc | 45 | 438863.584 | 2.8 | 426236.083 | | | | ug/L |
| V | 51 | 187747.150 | 2.4 | 5344.504 | 10.00000 | 0.203 | 2.0 | ug/L |
| Cr | 52 | 179337.094 | 1.1 | 18378.762 | 10.00000 | 0.404 | 4.0 | ug/L |
| Cr | 53 | 20248.105 | 0.2 | 1484.814 | 10.00000 | 0.303 | 3.0 | ug/L |
| Mn | 55 | 223334.531 | 1.0 | 742.040 | 10.00000 | 0.150 | 1.5 | ug/L |
| Co | 59 | 191740.616 | 3.7 | 848.388 | 10.00000 | 0.191 | 1.9 | ug/L |
| Ni | 60 | 41682.736 | 0.2 | 167.670 | 10.00000 | 0.246 | 2.5 | ug/L |
| Ni | 62 | 6634.373 | 0.5 | 209.338 | 10.00000 | 0.182 | 1.8 | ug/L |
| Cu | 63 | 97062.387 | 5.4 | 570.693 | 10.00000 | 0.372 | 3.7 | ug/L |
| Cu | 65 | 45070.060 | 2.7 | 318.010 | 10.00000 | 0.198 | 2.0 | ug/L |
| Zn | 66 | 28726.389 | 1.6 | 2186.325 | 10.00000 | 0.200 | 2.0 | ug/L |
| Zn | 67 | 4889.818 | 4.4 | 469.352 | 10.00000 | 0.240 | 2.4 | ug/L |
| Zn | 68 | 20811.850 | 3.4 | 1708.532 | 10.00000 | 0.169 | 1.7 | ug/L |
| Ge | 72 | 243086.367 | 2.3 | 235019.833 | | | | ug/L |
| As | 75 | 30680.692 | 1.8 | 174.004 | 10.00000 | 0.227 | 2.3 | ug/L |
| Se | 77 | 2610.142 | 2.1 | 271.738 | 10.00000 | 0.218 | 2.2 | ug/L |
| Se | 78 | 25289.719 | 1.1 | 18294.754 | 10.00000 | 1.063 | 10.6 | mg/L |
| Se | 82 | 3698.220 | 0.5 | 514.483 | 10.00000 | 0.219 | 2.2 | ug/L |
| Kr | 83 | 511.021 | 4.1 | 509.687 | | | | mg/L |
| Y | 89 | 443885.886 | 0.5 | 424645.807 | | | | ug/L |
| Mo | 95 | 59986.743 | 1.0 | 130.336 | 10.00000 | 0.227 | 2.3 | ug/L |
| Mo | 97 | 37465.752 | 1.5 | 59.667 | 10.00000 | 0.284 | 2.8 | ug/L |
| Mo | 98 | 97995.500 | 1.4 | 73.129 | 10.00000 | 0.053 | 0.5 | ug/L |
| Rh | 103 | 374151.647 | 1.8 | 377819.614 | | | | ug/L |
| Ag | 107 | 151818.643 | 2.8 | 60.668 | 10.00000 | 0.136 | 1.4 | ug/L |
| Ag | 109 | 144931.268 | 0.8 | 49.001 | 10.00000 | 0.071 | 0.7 | ug/L |
| Cd | 111 | 32205.199 | 1.4 | 302.744 | 10.00000 | 0.092 | 0.9 | ug/L |
| Cd | 114 | 71941.229 | 0.8 | 257.978 | 10.00000 | 0.223 | 2.2 | ug/L |
| In | 115 | 371314.557 | 1.5 | 368464.817 | | | | ug/L |
| Sb | 121 | 99863.182 | 1.2 | 54.001 | 10.00000 | 0.159 | 1.6 | ug/L |
| Sb | 123 | 74308.195 | 2.3 | 50.513 | 10.00000 | 0.145 | 1.4 | ug/L |
| Ba | 135 | 27278.854 | 1.5 | 123.002 | 10.00000 | 0.224 | 2.2 | ug/L |
| Ba | 137 | 47393.878 | 1.4 | 192.338 | 10.00000 | 0.226 | 2.3 | ug/L |
| Tb | 159 | 466155.796 | 0.9 | 460537.107 | | | | ug/L |
| Ho | 165 | 446548.227 | 1.0 | 440378.521 | | | | ug/L |
| Tl | 203 | 86035.726 | 0.9 | 83.668 | 10.00000 | 0.066 | 0.7 | ug/L |
| Tl | 205 | 204640.595 | 0.6 | 163.337 | 10.00000 | 0.086 | 0.9 | ug/L |
| Pb | 208 | 275852.354 | 1.2 | 1492.737 | 10.00000 | 0.031 | 0.3 | ug/L |

Sample ID: Standard 1

Report Date/Time: Friday, November 17, 2006 15:37:06

Page 1

412

| | | | | | | | | | |
|--|----|-----|-----------|-----|---------|----------|-------|-----|------|
| | Pb | 206 | 71149.324 | 2.9 | 397.348 | 10.00000 | 0.197 | 2.0 | ug/L |
| | Pb | 207 | 59157.164 | 0.9 | 320.010 | 10.00000 | 0.120 | 1.2 | ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 2

Sample Date/Time: Friday, November 17, 2006 15:40:02

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\Standard 2.003

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 23774.109 | 1.8 | 84.001 | 20.18407 | 0.667 | 3.3 | ug/L |
| Al | 27 | 190187.046 | 2.3 | 6946.222 | 20.27723 | 0.257 | 1.3 | ug/L |
| > Sc | 45 | 418493.044 | 1.5 | 426236.083 | | | | ug/L |
| V | 51 | 366537.961 | 2.2 | 5344.504 | 20.15360 | 0.732 | 3.6 | ug/L |
| Cr | 52 | 333938.887 | 0.6 | 18378.762 | 20.12442 | 0.218 | 1.1 | ug/L |
| Cr | 53 | 37643.207 | 0.6 | 1484.814 | 20.05215 | 0.380 | 1.9 | ug/L |
| Mn | 55 | 434402.700 | 0.3 | 742.040 | 20.06176 | 0.339 | 1.7 | ug/L |
| Co | 59 | 376330.338 | 1.2 | 848.388 | 20.10162 | 0.523 | 2.6 | ug/L |
| Ni | 60 | 84926.780 | 1.2 | 167.670 | 20.24423 | 0.421 | 2.1 | ug/L |
| Ni | 62 | 12601.315 | 1.9 | 209.338 | 20.02525 | 0.224 | 1.1 | ug/L |
| Cu | 63 | 189407.913 | 0.5 | 570.693 | 20.08228 | 0.389 | 1.9 | ug/L |
| Cu | 65 | 92390.168 | 2.7 | 318.010 | 20.27535 | 0.644 | 3.2 | ug/L |
| Zn | 66 | 54285.787 | 0.5 | 2186.325 | 20.10365 | 0.350 | 1.7 | ug/L |
| Zn | 67 | 9273.585 | 2.5 | 469.352 | 20.16590 | 0.537 | 2.7 | ug/L |
| Zn | 68 | 40585.383 | 2.9 | 1708.532 | 20.24571 | 0.505 | 2.5 | ug/L |
| > Ge | 72 | 233170.583 | 1.6 | 235019.833 | | | | ug/L |
| As | 75 | 62074.676 | 1.9 | 174.004 | 20.22038 | 0.061 | 0.3 | ug/L |
| Se | 77 | 4813.523 | 1.7 | 271.738 | 20.06632 | 0.186 | 0.9 | ug/L |
| Se | 78 | 33076.967 | 1.5 | 18294.754 | 20.75101 | 1.276 | 6.1 | mg/L |
| Se | 82 | 6822.659 | 1.1 | 514.483 | 20.15170 | 0.448 | 2.2 | ug/L |
| Kr | 83 | 501.687 | 5.5 | 509.687 | | | | mg/L |
| Y | 89 | 428167.375 | 1.7 | 424645.807 | | | | ug/L |
| Mo | 95 | 121986.987 | 1.2 | 130.336 | 20.08823 | 0.272 | 1.4 | ug/L |
| Mo | 97 | 75364.908 | 3.2 | 59.667 | 20.04364 | 0.638 | 3.2 | ug/L |
| Mo | 98 | 189370.290 | 1.3 | 73.129 | 19.88144 | 0.242 | 1.2 | ug/L |
| Rh | 103 | 374011.140 | 1.9 | 377819.614 | | | | ug/L |
| Ag | 107 | 305676.845 | 1.5 | 60.668 | 20.04643 | 0.290 | 1.4 | ug/L |
| Ag | 109 | 277547.522 | 2.0 | 49.001 | 19.84356 | 0.426 | 2.1 | ug/L |
| Cd | 111 | 65357.138 | 2.2 | 302.744 | 20.09563 | 0.476 | 2.4 | ug/L |
| Cd | 114 | 139849.109 | 0.6 | 257.978 | 19.91046 | 0.144 | 0.7 | ug/L |
| > In | 115 | 369597.060 | 0.2 | 368464.817 | | | | ug/L |
| Sb | 121 | 191377.938 | 1.0 | 54.001 | 19.84662 | 0.159 | 0.8 | ug/L |
| Sb | 123 | 150199.169 | 1.6 | 50.513 | 20.06217 | 0.332 | 1.7 | ug/L |
| Ba | 135 | 53292.451 | 2.3 | 123.002 | 20.00840 | 0.473 | 2.4 | ug/L |
| Ba | 137 | 94258.366 | 0.7 | 192.338 | 20.07869 | 0.271 | 1.3 | ug/L |
| > Tb | 159 | 455410.344 | 1.3 | 460537.107 | | | | ug/L |
| > Ho | 165 | 432371.508 | 1.5 | 440378.521 | | | | ug/L |
| Tl | 203 | 171551.139 | 2.4 | 83.668 | 20.11833 | 0.543 | 2.7 | ug/L |
| Tl | 205 | 394251.143 | 1.9 | 163.337 | 19.98103 | 0.356 | 1.8 | ug/L |
| Pb | 208 | 541403.922 | 2.0 | 1492.737 | 20.06481 | 0.371 | 1.8 | ug/L |

| | | | | | | | | |
|---|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 140436.211 | 0.7 | 397.348 | 20.08844 | 0.324 | 1.6 ug/L |
| L | Pb | 207 | 119943.539 | 2.4 | 320.010 | 20.19215 | 0.370 | 1.8 ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 3

Sample Date/Time: Friday, November 17, 2006 15:46:00

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\Standard 3.004

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 120451.471 | 0.4 | 84.001 | 100.10640 | 1.462 | 1.5 | ug/L |
| Al | 27 | 853080.189 | 1.5 | 6946.222 | 99.66319 | 2.101 | 2.1 | ug/L |
| Sc | 45 | 419491.265 | 1.3 | 426236.083 | | | | ug/L |
| V | 51 | 1678162.643 | 2.6 | 5344.504 | 99.64779 | 3.707 | 3.7 | ug/L |
| Cr | 52 | 1471911.724 | 3.8 | 18378.762 | 99.61131 | 5.096 | 5.1 | ug/L |
| Cr | 53 | 183701.300 | 1.0 | 1484.814 | 100.03520 | 1.936 | 1.9 | ug/L |
| Mn | 55 | 2198122.006 | 8.7 | 742.040 | 100.04044 | 9.680 | 9.7 | ug/L |
| Co | 59 | 1773631.070 | 0.9 | 848.388 | 99.70254 | 1.881 | 1.9 | ug/L |
| Ni | 60 | 401949.806 | 2.8 | 167.670 | 99.75910 | 3.849 | 3.9 | ug/L |
| Ni | 62 | 59253.575 | 2.3 | 209.338 | 99.73040 | 3.172 | 3.2 | ug/L |
| Cu | 63 | 933542.667 | 1.4 | 570.693 | 99.92203 | 2.361 | 2.4 | ug/L |
| Cu | 65 | 449212.801 | 0.7 | 318.010 | 99.90396 | 1.556 | 1.6 | ug/L |
| Zn | 66 | 259347.283 | 2.7 | 2186.325 | 99.92083 | 2.957 | 3.0 | ug/L |
| Zn | 67 | 45523.863 | 2.9 | 469.352 | 100.10748 | 3.693 | 3.7 | ug/L |
| Zn | 68 | 187131.826 | 1.2 | 1708.532 | 99.78854 | 2.177 | 2.2 | ug/L |
| Ge | 72 | 235126.153 | 1.1 | 235019.833 | | | | ug/L |
| As | 75 | 299174.231 | 2.2 | 174.004 | 99.84623 | 2.493 | 2.5 | ug/L |
| Se | 77 | 22568.853 | 0.2 | 271.738 | 99.88566 | 1.102 | 1.1 | ug/L |
| Se | 78 | 89112.419 | 0.8 | 18294.754 | 99.88162 | 1.091 | 1.1 | mg/L |
| Se | 82 | 31281.204 | 0.9 | 514.483 | 99.87248 | 0.847 | 0.8 | ug/L |
| Kr | 83 | 500.353 | 3.1 | 509.687 | | | | mg/L |
| Y | 89 | 420864.047 | 0.4 | 424645.807 | | | | ug/L |
| Mo | 95 | 592358.576 | 2.6 | 130.336 | 99.99711 | 2.055 | 2.1 | ug/L |
| Mo | 97 | 357224.947 | 1.3 | 59.667 | 99.86921 | 1.209 | 1.2 | ug/L |
| Mo | 98 | 927080.341 | 1.4 | 73.129 | 99.98460 | 1.630 | 1.6 | ug/L |
| Rh | 103 | 362075.946 | 2.6 | 377819.614 | | | | ug/L |
| Ag | 107 | 1411748.063 | 2.7 | 60.668 | 99.73889 | 2.074 | 2.1 | ug/L |
| Ag | 109 | 1311516.313 | 1.8 | 49.001 | 99.80208 | 1.300 | 1.3 | ug/L |
| Cd | 111 | 312660.529 | 2.7 | 302.744 | 99.94083 | 2.103 | 2.1 | ug/L |
| Cd | 114 | 652338.482 | 0.7 | 257.978 | 99.76139 | 0.183 | 0.2 | ug/L |
| In | 115 | 361026.126 | 0.6 | 368464.817 | | | | ug/L |
| Sb | 121 | 925877.878 | 2.1 | 54.001 | 99.91868 | 1.969 | 2.0 | ug/L |
| Sb | 123 | 706299.848 | 0.6 | 50.513 | 99.83297 | 0.167 | 0.2 | ug/L |
| Ba | 135 | 259371.528 | 1.3 | 123.002 | 100.00550 | 1.468 | 1.5 | ug/L |
| Ba | 137 | 445378.929 | 3.0 | 192.338 | 99.87763 | 1.627 | 1.6 | ug/L |
| Tb | 159 | 443781.875 | 1.4 | 460537.107 | | | | ug/L |
| Ho | 165 | 424257.661 | 0.6 | 440378.521 | | | | ug/L |
| Tl | 203 | 795064.824 | 2.0 | 83.668 | 99.75215 | 1.453 | 1.5 | ug/L |
| Tl | 205 | 1767915.863 | 0.2 | 163.337 | 99.55047 | 0.455 | 0.5 | ug/L |
| Pb | 208 | 2524404.140 | 1.3 | 1492.737 | 99.77836 | 1.017 | 1.0 | ug/L |

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 667766.773 | 0.9 | 397.348 | 99.88050 | 0.989 | 1.0 ug/L |
| | Pb | 207 | 558675.494 | 2.1 | 320.010 | 99.80432 | 1.649 | 1.7 ug/L |

Quantitative Analysis Calibration Report

File Name: 111706.cal
File Path: C:\elandata\System
Calibration Type: External Calibration

| Analyte | Mass | Curve Type | Slope | Intercept | Corr. Coeff. |
|---------|---------|------------------|-------|-----------|--------------|
| Be | 9.012 | Linear Thru Zero | 0.00 | 0.00 | 0.999981 |
| Al | 26.982 | Linear Thru Zero | 0.02 | 0.00 | 0.999866 |
| Sc | 44.956 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| V | 50.944 | Linear Thru Zero | 0.04 | 0.00 | 0.999870 |
| Cr | 51.941 | Linear Thru Zero | 0.03 | 0.00 | 0.999845 |
| Cr | 52.941 | Linear Thru Zero | 0.00 | 0.00 | 0.999998 |
| Mn | 54.938 | Linear Thru Zero | 0.09 | 0.00 | 0.999997 |
| Co | 58.933 | Linear Thru Zero | 0.08 | 0.00 | 0.999909 |
| Ni | 59.933 | Linear Thru Zero | 0.02 | 0.00 | 0.999926 |
| Ni | 61.928 | Linear Thru Zero | 0.00 | 0.00 | 0.999927 |
| Cu | 62.930 | Linear Thru Zero | 0.04 | 0.00 | 0.999992 |
| Cu | 64.928 | Linear Thru Zero | 0.02 | 0.00 | 0.999972 |
| Zn | 65.926 | Linear Thru Zero | 0.01 | 0.00 | 0.999991 |
| Zn | 66.927 | Linear Thru Zero | 0.00 | 0.00 | 0.999982 |
| Zn | 67.925 | Linear Thru Zero | 0.01 | 0.00 | 0.999940 |
| Ge | 71.922 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| As | 74.922 | Linear Thru Zero | 0.01 | 0.00 | 0.999964 |
| Se | 76.920 | Linear Thru Zero | 0.00 | 0.00 | 0.999986 |
| Se | 77.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999845 |
| Se | 81.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999978 |
| Kr | 82.914 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Y | 88.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Mo | 94.906 | Linear Thru Zero | 0.02 | 0.00 | 0.999998 |
| Mo | 96.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999982 |
| Mo | 97.906 | Linear Thru Zero | 0.03 | 0.00 | 0.999996 |
| Rh | 102.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ag | 106.905 | Linear Thru Zero | 0.04 | 0.00 | 0.999931 |
| Ag | 108.905 | Linear Thru Zero | 0.04 | 0.00 | 0.999955 |
| Cd | 110.904 | Linear Thru Zero | 0.01 | 0.00 | 0.999994 |
| Cd | 113.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999941 |
| In | 114.904 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Sb | 120.904 | Linear Thru Zero | 0.03 | 0.00 | 0.999988 |
| Sb | 122.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999971 |
| Ba | 134.906 | Linear Thru Zero | 0.01 | 0.00 | 1.000000 |
| Ba | 136.905 | Linear Thru Zero | 0.01 | 0.00 | 0.999983 |
| Tb | 158.925 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ho | 164.930 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Tl | 202.972 | Linear Thru Zero | 0.02 | 0.00 | 0.999935 |
| Tl | 204.975 | Linear Thru Zero | 0.04 | 0.00 | 0.999798 |
| Pb | 207.977 | Linear Thru Zero | 0.06 | 0.00 | 0.999950 |

| | | | | | |
|----|---------|------------------|------|------|----------|
| Pb | 205.975 | Linear Thru Zero | 0.02 | 0.00 | 0.999984 |
| Pb | 206.976 | Linear Thru Zero | 0.01 | 0.00 | 0.999952 |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 1

Sample Date/Time: Friday, November 17, 2006 15:51:59

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 1.005

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 56511.865 | 0.2 | 84.001 | 46.42722 | 1.239 | 2.7 | ug/L |
| Al | 27 | 448984.968 | 3.8 | 6946.222 | 51.49137 | 1.882 | 3.7 | ug/L |
| Sc | 45 | 424164.208 | 2.5 | 426236.083 | | | | ug/L |
| V | 51 | 865248.852 | 1.8 | 5344.504 | 50.66471 | 1.559 | 3.1 | ug/L |
| Cr | 52 | 753709.026 | 0.7 | 18378.762 | 49.83415 | 1.367 | 2.7 | ug/L |
| Cr | 53 | 90495.406 | 2.0 | 1484.814 | 48.33748 | 1.504 | 3.1 | ug/L |
| Mn | 55 | 1059542.682 | 1.6 | 742.040 | 49.06845 | 0.333 | 0.7 | ug/L |
| Co | 59 | 894809.658 | 1.4 | 848.388 | 51.21720 | 1.345 | 2.6 | ug/L |
| Ni | 60 | 200103.989 | 1.5 | 167.670 | 50.55613 | 0.832 | 1.6 | ug/L |
| Ni | 62 | 30402.671 | 1.6 | 209.338 | 51.94876 | 1.023 | 2.0 | ug/L |
| Cu | 63 | 460872.934 | 0.8 | 570.693 | 50.21273 | 0.587 | 1.2 | ug/L |
| Cu | 65 | 227893.789 | 0.7 | 318.010 | 51.59831 | 1.263 | 2.4 | ug/L |
| Zn | 66 | 128559.724 | 0.9 | 2186.325 | 50.03895 | 1.212 | 2.4 | ug/L |
| Zn | 67 | 21486.921 | 4.7 | 469.352 | 47.56392 | 1.714 | 3.6 | ug/L |
| Zn | 68 | 93130.254 | 2.2 | 1708.532 | 50.12261 | 0.655 | 1.3 | ug/L |
| Ge | 72 | 230842.142 | 1.7 | 235019.833 | | | | ug/L |
| As | 75 | 143689.085 | 1.2 | 174.004 | 48.81391 | 0.304 | 0.6 | ug/L |
| Se | 77 | 11430.501 | 0.7 | 271.738 | 50.94032 | 0.511 | 1.0 | ug/L |
| Se | 78 | 52998.706 | 1.4 | 18294.754 | 50.35153 | 2.348 | 4.7 | mg/L |
| Se | 82 | 15820.537 | 0.4 | 514.483 | 50.64605 | 0.887 | 1.8 | ug/L |
| Kr | 83 | 501.353 | 5.6 | 509.687 | | | | mg/L |
| Y | 89 | 434406.583 | 1.4 | 424645.807 | | | | ug/L |
| Mo | 95 | 292633.265 | 1.4 | 130.336 | 49.49398 | 1.550 | 3.1 | ug/L |
| Mo | 97 | 178258.511 | 0.4 | 59.667 | 49.92121 | 0.853 | 1.7 | ug/L |
| Mo | 98 | 461399.418 | 0.3 | 73.129 | 49.85410 | 1.194 | 2.4 | ug/L |
| Rh | 103 | 363423.394 | 0.2 | 377819.614 | | | | ug/L |
| Ag | 107 | 694105.226 | 0.8 | 60.668 | 49.12960 | 0.643 | 1.3 | ug/L |
| Ag | 109 | 651712.098 | 3.5 | 49.001 | 49.67621 | 1.459 | 2.9 | ug/L |
| Cd | 111 | 152845.790 | 1.8 | 302.744 | 48.90539 | 1.272 | 2.6 | ug/L |
| Cd | 114 | 333177.822 | 1.6 | 257.978 | 51.03852 | 1.667 | 3.3 | ug/L |
| In | 115 | 360433.234 | 2.1 | 368464.817 | | | | ug/L |
| Sb | 121 | 457966.200 | 1.6 | 54.001 | 49.51218 | 1.103 | 2.2 | ug/L |
| Sb | 123 | 344565.876 | 2.7 | 50.513 | 48.80557 | 2.128 | 4.4 | ug/L |
| Ba | 135 | 130017.597 | 1.8 | 123.002 | 49.03501 | 0.253 | 0.5 | ug/L |
| Ba | 137 | 222845.328 | 1.0 | 192.338 | 48.89931 | 0.396 | 0.8 | ug/L |
| Tb | 159 | 453439.152 | 1.6 | 460537.107 | | | | ug/L |
| Ho | 165 | 419853.918 | 1.6 | 440378.521 | | | | ug/L |
| Tl | 203 | 398533.476 | 1.3 | 83.668 | 50.52767 | 0.600 | 1.2 | ug/L |
| Tl | 205 | 933784.907 | 0.2 | 163.337 | 53.13586 | 0.791 | 1.5 | ug/L |
| Pb | 208 | 1272251.624 | 0.8 | 1492.737 | 50.79337 | 0.755 | 1.5 | ug/L |

Sample ID: QC Std 1

Report Date/Time: Friday, November 17, 2006 15:55:01

Page 1

420

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 328445.905 | 1.4 | 397.348 | 49.61476 | 0.450 | 0.9 ug/L |
| | Pb | 207 | 270021.048 | 0.7 | 320.010 | 48.72967 | 1.103 | 2.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 92.854 | | | | |
| Al | 27 | 102.983 | | | | |
| > Sc | 45 | | 99.514 | | | |
| V | 51 | 101.329 | | | | |
| Cr | 52 | 99.668 | | | | |
| Cr | 53 | 96.675 | | | | |
| Mn | 55 | 98.137 | | | | |
| Co | 59 | 102.434 | | | | |
| Ni | 60 | 101.112 | | | | |
| Ni | 62 | 103.898 | | | | |
| Cu | 63 | 100.425 | | | | |
| Cu | 65 | 103.197 | | | | |
| Zn | 66 | 100.078 | | | | |
| Zn | 67 | 95.128 | | | | |
| Zn | 68 | 100.245 | | | | |
| > Ge | 72 | | 98.222 | | | |
| As | 75 | 97.628 | | | | |
| Se | 77 | 101.881 | | | | |
| Se | 78 | 100.703 | | | | |
| Se | 82 | 101.292 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 98.988 | | | | |
| Mo | 97 | 99.842 | | | | |
| Mo | 98 | 99.708 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 98.259 | | | | |
| Ag | 109 | 99.352 | | | | |
| Cd | 111 | 97.811 | | | | |
| Cd | 114 | 102.077 | | | | |
| > In | 115 | | 97.820 | | | |
| Sb | 121 | 99.024 | | | | |
| Sb | 123 | 97.611 | | | | |
| Ba | 135 | 98.070 | | | | |
| Ba | 137 | 97.799 | | | | |
| > Tb | 159 | | 98.459 | | | |
| > Ho | 165 | | 95.339 | | | |
| Tl | 203 | 101.055 | | | | |
| Tl | 205 | 106.272 | | | | |
| Pb | 208 | 101.587 | | | | |
| Pb | 206 | 99.230 | | | | |
| Pb | 207 | 97.459 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 2

Sample Date/Time: Friday, November 17, 2006 15:57:56

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 2.006

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59.667 | 5.1 | 84.001 | -0.01800 | 0.004 | 21.3 | ug/L |
| Al | 27 | 3740.877 | 1.9 | 6946.222 | -0.35473 | 0.018 | 5.1 | ug/L |
| > Sc | 45 | 410660.495 | 2.7 | 426236.083 | | | | ug/L |
| V | 51 | 4987.886 | 1.9 | 5344.504 | -0.00956 | 0.014 | 144.8 | ug/L |
| Cr | 52 | 17302.787 | 1.6 | 18378.762 | -0.02736 | 0.052 | 188.9 | ug/L |
| Cr | 53 | 1285.112 | 3.2 | 1484.814 | -0.08090 | 0.039 | 48.8 | ug/L |
| Mn | 55 | 633.364 | 4.8 | 742.040 | -0.00409 | 0.002 | 40.8 | ug/L |
| Co | 59 | 394.347 | 4.7 | 848.388 | -0.02489 | 0.001 | 3.6 | ug/L |
| Ni | 60 | 141.336 | 7.6 | 167.670 | -0.00552 | 0.002 | 45.1 | ug/L |
| Ni | 62 | 239.339 | 3.8 | 209.338 | 0.06254 | 0.013 | 20.2 | ug/L |
| Cu | 63 | 300.008 | 5.9 | 570.693 | -0.02804 | 0.002 | 7.9 | ug/L |
| Cu | 65 | 174.004 | 7.2 | 318.010 | -0.03093 | 0.003 | 8.5 | ug/L |
| Zn | 66 | 1428.803 | 1.4 | 2186.325 | -0.27810 | 0.004 | 1.4 | ug/L |
| Zn | 67 | 323.343 | 6.3 | 469.352 | -0.30306 | 0.052 | 17.2 | ug/L |
| Zn | 68 | 1173.428 | 2.5 | 1708.532 | -0.26949 | 0.012 | 4.4 | ug/L |
| > Ge | 72 | 228290.103 | 0.8 | 235019.833 | | | | ug/L |
| As | 75 | 198.338 | 10.0 | 174.004 | 0.01005 | 0.006 | 63.0 | ug/L |
| Se | 77 | 269.671 | 6.1 | 271.738 | 0.02602 | 0.067 | 256.5 | ug/L |
| Se | 78 | 17361.678 | 0.6 | 18294.754 | -0.59418 | 0.061 | 10.2 | mg/L |
| Se | 82 | 517.149 | 3.5 | 514.483 | 0.05793 | 0.047 | 81.3 | ug/L |
| Kr | 83 | 501.020 | 3.8 | 509.687 | | | | mg/L |
| Y | 89 | 410991.155 | 2.1 | 424645.807 | | | | ug/L |
| Mo | 95 | 952.399 | 19.3 | 130.336 | 0.14186 | 0.035 | 24.5 | ug/L |
| Mo | 97 | 573.026 | 21.4 | 59.667 | 0.14653 | 0.038 | 26.0 | ug/L |
| Mo | 98 | 1412.305 | 24.3 | 73.129 | 0.14717 | 0.041 | 27.6 | ug/L |
| Rh | 103 | 361274.411 | 1.8 | 377819.614 | | | | ug/L |
| Ag | 107 | 164.337 | 12.1 | 60.668 | 0.00757 | 0.001 | 19.8 | ug/L |
| Ag | 109 | 136.336 | 17.4 | 49.001 | 0.00688 | 0.002 | 28.8 | ug/L |
| Cd | 111 | 222.707 | 1.3 | 302.744 | -0.02268 | 0.002 | 9.2 | ug/L |
| Cd | 114 | 78.124 | 14.1 | 257.978 | -0.02657 | 0.002 | 6.1 | ug/L |
| > In | 115 | 356292.877 | 2.1 | 368464.817 | | | | ug/L |
| Sb | 121 | 1241.440 | 14.9 | 54.001 | 0.13036 | 0.023 | 17.6 | ug/L |
| Sb | 123 | 952.255 | 11.5 | 50.513 | 0.12965 | 0.018 | 14.2 | ug/L |
| Ba | 135 | 52.334 | 9.4 | 123.002 | -0.02547 | 0.002 | 8.6 | ug/L |
| Ba | 137 | 62.668 | 7.2 | 192.338 | -0.02749 | 0.001 | 4.2 | ug/L |
| > Tb | 159 | 442838.349 | 1.3 | 460537.107 | | | | ug/L |
| > Ho | 165 | 413178.743 | 0.5 | 440378.521 | | | | ug/L |
| Tl | 203 | 103.335 | 2.0 | 83.668 | 0.00320 | 0.000 | 10.2 | ug/L |
| Tl | 205 | 196.671 | 3.9 | 163.337 | 0.00251 | 0.000 | 18.8 | ug/L |
| Pb | 208 | 580.347 | 6.5 | 1492.737 | -0.03331 | 0.001 | 4.3 | ug/L |

Sample ID: QC Std 2

Report Date/Time: Friday, November 17, 2006 16:00:57

Page 1

423

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|-----------|
| | Pb | 206 | 144.669 | 7.3 | 397.348 | -0.03506 | 0.002 | 4.3 ug/L |
| | Pb | 207 | 142.669 | 12.6 | 320.010 | -0.02893 | 0.003 | 11.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 96.346 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 97.137 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 96.697 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 96.157 | | | |
| > Ho | 165 | | 93.824 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Friday, November 17, 2006 16:03:52

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 3.007

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1258.108 | 2.7 | 84.001 | 0.98647 | 0.008 | 0.9 | ug/L |
| Al | 27 | 94962.967 | 0.5 | 6946.222 | 10.47999 | 0.363 | 3.5 | ug/L |
| > Sc | 45 | 415925.946 | 2.8 | 426236.083 | | | | ug/L |
| V | 51 | 23342.549 | 1.2 | 5344.504 | 1.08925 | 0.033 | 3.0 | ug/L |
| Cr | 52 | 33355.628 | 1.2 | 18378.762 | 1.06671 | 0.083 | 7.8 | ug/L |
| Cr | 53 | 3129.952 | 2.2 | 1484.814 | 0.93191 | 0.078 | 8.4 | ug/L |
| Mn | 55 | 22468.812 | 1.5 | 742.040 | 1.01184 | 0.007 | 0.7 | ug/L |
| Co | 59 | 19463.568 | 1.4 | 848.388 | 1.07176 | 0.001 | 0.1 | ug/L |
| Ni | 60 | 4362.186 | 2.7 | 167.670 | 1.06632 | 0.046 | 4.3 | ug/L |
| Ni | 62 | 825.716 | 5.7 | 209.338 | 1.07316 | 0.094 | 8.7 | ug/L |
| Cu | 63 | 9985.746 | 0.5 | 570.693 | 1.03277 | 0.020 | 1.9 | ug/L |
| Cu | 65 | 4702.040 | 0.8 | 318.010 | 0.99964 | 0.021 | 2.1 | ug/L |
| Zn | 66 | 15657.854 | 1.2 | 2186.325 | 5.37272 | 0.022 | 0.4 | ug/L |
| Zn | 67 | 2595.097 | 1.6 | 469.352 | 4.85527 | 0.186 | 3.8 | ug/L |
| Zn | 68 | 11237.017 | 0.5 | 1708.532 | 5.26551 | 0.074 | 1.4 | ug/L |
| > Ge | 72 | 229877.869 | 1.5 | 235019.833 | | | | ug/L |
| As | 75 | 3236.327 | 1.2 | 174.004 | 1.04747 | 0.029 | 2.8 | ug/L |
| Se | 77 | 489.281 | 1.9 | 271.738 | 1.02468 | 0.075 | 7.3 | ug/L |
| Se | 78 | 18084.396 | 2.0 | 18294.754 | 0.28293 | 0.918 | 324.6 | mg/L |
| Se | 82 | 812.906 | 1.2 | 514.483 | 1.02829 | 0.020 | 2.0 | ug/L |
| Kr | 83 | 517.355 | 5.7 | 509.687 | | | | mg/L |
| Y | 89 | 416197.904 | 2.4 | 424645.807 | | | | ug/L |
| Mo | 95 | 6320.126 | 1.8 | 130.336 | 1.02752 | 0.022 | 2.1 | ug/L |
| Mo | 97 | 3854.931 | 3.6 | 59.667 | 1.04313 | 0.035 | 3.4 | ug/L |
| Mo | 98 | 9907.044 | 2.0 | 73.129 | 1.04262 | 0.024 | 2.3 | ug/L |
| Rh | 103 | 364921.661 | 1.3 | 377819.614 | | | | ug/L |
| Ag | 107 | 15542.636 | 0.5 | 60.668 | 1.07531 | 0.003 | 0.3 | ug/L |
| Ag | 109 | 14189.880 | 1.0 | 49.001 | 1.05787 | 0.013 | 1.2 | ug/L |
| Cd | 111 | 3416.504 | 4.5 | 302.744 | 0.97973 | 0.051 | 5.2 | ug/L |
| Cd | 114 | 6831.707 | 1.7 | 257.978 | 0.98874 | 0.020 | 2.0 | ug/L |
| > In | 115 | 367281.262 | 0.3 | 368464.817 | | | | ug/L |
| Sb | 121 | 10001.098 | 0.9 | 54.001 | 1.05527 | 0.009 | 0.9 | ug/L |
| Sb | 123 | 7702.824 | 1.6 | 50.513 | 1.06329 | 0.016 | 1.5 | ug/L |
| Ba | 135 | 2851.183 | 2.4 | 123.002 | 1.05959 | 0.030 | 2.8 | ug/L |
| Ba | 137 | 4928.506 | 1.4 | 192.338 | 1.06978 | 0.011 | 1.0 | ug/L |
| > Tb | 159 | 441601.388 | 1.5 | 460537.107 | | | | ug/L |
| > Ho | 165 | 424851.855 | 2.7 | 440378.521 | | | | ug/L |
| Tl | 203 | 8488.741 | 2.1 | 83.668 | 1.05450 | 0.051 | 4.8 | ug/L |
| Tl | 205 | 20113.111 | 0.4 | 163.337 | 1.12268 | 0.027 | 2.4 | ug/L |
| Pb | 208 | 27818.542 | 0.3 | 1492.737 | 1.04231 | 0.030 | 2.9 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Friday, November 17, 2006 16:06:52

Page 1

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 7225.538 | 2.2 | 397.348 | 1.02331 | 0.047 | 4.6 ug/L |
| | Pb | 207 | 6125.645 | 1.2 | 320.010 | 1.03905 | 0.041 | 3.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 98.647 | | | | |
| Al | 27 | 104.800 | | | | |
| > Sc | 45 | | 97.581 | | | |
| V | 51 | 108.925 | | | | |
| Cr | 52 | 106.671 | | | | |
| Cr | 53 | 93.191 | | | | |
| Mn | 55 | 101.184 | | | | |
| Co | 59 | 107.176 | | | | |
| Ni | 60 | 106.632 | | | | |
| Ni | 62 | 107.316 | | | | |
| Cu | 63 | 103.277 | | | | |
| Cu | 65 | 99.964 | | | | |
| Zn | 66 | 107.454 | | | | |
| Zn | 67 | 97.105 | | | | |
| Zn | 68 | 105.310 | | | | |
| > Ge | 72 | | 97.812 | | | |
| As | 75 | 104.747 | | | | |
| Se | 77 | 102.468 | | | | |
| Se | 78 | 28.293 | | | | |
| Se | 82 | 102.829 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 102.752 | | | | |
| Mo | 97 | 104.313 | | | | |
| Mo | 98 | 104.262 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 107.531 | | | | |
| Ag | 109 | 105.787 | | | | |
| Cd | 111 | 97.973 | | | | |
| Cd | 114 | 98.874 | | | | |
| > In | 115 | | 99.679 | | | |
| Sb | 121 | 105.527 | | | | |
| Sb | 123 | 106.329 | | | | |
| Ba | 135 | 105.959 | | | | |
| Ba | 137 | 106.978 | | | | |
| > Tb | 159 | | 95.888 | | | |
| > Ho | 165 | | 96.474 | | | |
| Tl | 203 | 105.450 | | | | |
| Tl | 205 | 112.268 | | | | |
| Pb | 208 | 104.231 | | | | |
| Pb | 206 | 102.331 | | | | |
| Pb | 207 | 103.905 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 4

Sample Date/Time: Friday, November 17, 2006 16:09:48

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 4.008

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| Be | 9 | 70.334 | 9.0 | 84.001 | -0.01070 | 0.005 | 45.7 | ug/L |
| Al | 27 | 196112963.328 | 1.7 | 6946.222 | 22928.93061 | 595.044 | 2.6 | ug/L |
| > Sc | 45 | 422553.870 | 0.9 | 426236.083 | | | | ug/L |
| V | 51 | 4667.797 | 4.8 | 5344.504 | -0.03729 | 0.012 | 33.0 | ug/L |
| Cr | 52 | 33045.056 | 1.0 | 18378.762 | 1.00819 | 0.039 | 3.8 | ug/L |
| Cr | 53 | 8856.486 | 9.3 | 1484.814 | 4.02549 | 0.476 | 11.8 | ug/L |
| Mn | 55 | 8503.423 | 2.1 | 742.040 | 0.32211 | 0.008 | 2.4 | ug/L |
| Co | 59 | 1345.789 | 6.8 | 848.388 | 0.02186 | 0.004 | 18.5 | ug/L |
| Ni | 60 | 3244.333 | 8.0 | 167.670 | 0.69880 | 0.053 | 7.5 | ug/L |
| Ni | 62 | 2673.457 | 8.3 | 209.338 | 3.79883 | 0.335 | 8.8 | ug/L |
| Cu | 63 | 12880.419 | 4.0 | 570.693 | 1.20739 | 0.041 | 3.4 | ug/L |
| Cu | 65 | 5383.460 | 2.7 | 318.010 | 1.03104 | 0.019 | 1.8 | ug/L |
| Zn | 66 | 7125.117 | 1.9 | 2186.325 | 1.69651 | 0.033 | 2.0 | ug/L |
| Zn | 67 | 2893.198 | 4.5 | 469.352 | 4.86872 | 0.251 | 5.1 | ug/L |
| Zn | 68 | 3801.238 | 2.4 | 1708.532 | 0.96213 | 0.064 | 6.7 | ug/L |
| > Ge | 72 | 255613.871 | 1.0 | 235019.833 | | | | ug/L |
| As | 75 | 2636.778 | 5.4 | 174.004 | 0.75155 | 0.037 | 5.0 | ug/L |
| Se | 77 | 1061.734 | 3.6 | 271.738 | 3.15621 | 0.115 | 3.6 | ug/L |
| Se | 78 | 18392.848 | 1.4 | 18294.754 | -1.95249 | 0.239 | 12.3 | mg/L |
| Se | 82 | 591.488 | 1.4 | 514.483 | 0.09527 | 0.007 | 7.1 | ug/L |
| Kr | 83 | 634.364 | 3.4 | 509.687 | | | | mg/L |
| Y | 89 | 436252.235 | 2.4 | 424645.807 | | | | ug/L |
| Mo | 95 | 2774121.010 | 2.8 | 130.336 | 467.81973 | 8.669 | 1.9 | ug/L |
| Mo | 97 | 1467595.847 | 1.1 | 59.667 | 409.98528 | 12.053 | 2.9 | ug/L |
| Mo | 98 | 4338628.926 | 2.2 | 73.129 | 467.47394 | 14.403 | 3.1 | ug/L |
| Rh | 103 | 369740.711 | 2.3 | 377819.614 | | | | ug/L |
| Ag | 107 | 443.683 | 1.6 | 60.668 | 0.02713 | 0.001 | 4.9 | ug/L |
| Ag | 109 | 391.346 | 3.7 | 49.001 | 0.02611 | 0.002 | 6.4 | ug/L |
| Cd | 111 | 354.165 | 46.5 | 302.744 | 0.01734 | 0.049 | 280.8 | ug/L |
| Cd | 114 | 4402.994 | 0.8 | 257.978 | 0.63426 | 0.014 | 2.2 | ug/L |
| > In | 115 | 361527.087 | 2.8 | 368464.817 | | | | ug/L |
| Sb | 121 | 3470.424 | 2.1 | 54.001 | 0.36865 | 0.018 | 4.9 | ug/L |
| Sb | 123 | 2531.236 | 0.4 | 50.513 | 0.35052 | 0.011 | 3.1 | ug/L |
| Ba | 135 | 142.669 | 7.4 | 123.002 | 0.00965 | 0.004 | 45.1 | ug/L |
| Ba | 137 | 221.005 | 10.7 | 192.338 | 0.00830 | 0.005 | 63.8 | ug/L |
| > Tb | 159 | 441138.546 | 0.4 | 460537.107 | | | | ug/L |
| > Ho | 165 | 416006.118 | 1.2 | 440378.521 | | | | ug/L |
| Tl | 203 | 855.386 | 14.7 | 83.668 | 0.09946 | 0.017 | 17.2 | ug/L |
| Tl | 205 | 2012.269 | 19.9 | 163.337 | 0.10683 | 0.024 | 22.3 | ug/L |
| Pb | 208 | 6572.408 | 1.9 | 1492.737 | 0.20827 | 0.008 | 3.8 | ug/L |

Sample ID: QC Std 4

Report Date/Time: Friday, November 17, 2006 16:12:49

Page 1

429

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 1659.182 | 1.0 | 397.348 | 0.19599 | 0.005 | 2.7 ug/L |
| | Pb | 207 | 1458.809 | 4.8 | 320.010 | 0.21091 | 0.015 | 7.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | 114.645 | | | | |
| > Sc | 45 | | 99.136 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 108.763 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 116.955 | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.117 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 95.788 | | | |
| > Ho | 165 | | 94.466 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 5

Sample Date/Time: Friday, November 17, 2006 16:15:45

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 5.009

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| Be | 9 | 65.668 | 13.0 | 84.001 | -0.01480 | 0.006 | 41.5 | ug/L |
| Al | 27 | 195180081.793 | 0.8 | 6946.222 | 22735.62825 | 560.056 | 2.5 | ug/L |
| Sc | 45 | 424236.013 | 2.7 | 426236.083 | | | | ug/L |
| V | 51 | -2484.067 | 66.1 | 5344.504 | -0.45922 | 0.096 | 21.0 | ug/L |
| Cr | 52 | 352870.284 | 0.2 | 18378.762 | 22.66935 | 0.609 | 2.7 | ug/L |
| Cr | 53 | 48250.107 | 1.1 | 1484.814 | 25.39133 | 0.439 | 1.7 | ug/L |
| Mn | 55 | 453327.270 | 2.1 | 742.040 | 18.85894 | 0.278 | 1.5 | ug/L |
| Co | 59 | 383522.530 | 3.1 | 848.388 | 19.71568 | 0.879 | 4.5 | ug/L |
| Ni | 60 | 86000.686 | 0.5 | 167.670 | 19.51543 | 0.295 | 1.5 | ug/L |
| Ni | 62 | 15013.337 | 3.0 | 209.338 | 22.86715 | 0.396 | 1.7 | ug/L |
| Cu | 63 | 189381.028 | 0.8 | 570.693 | 18.51640 | 0.130 | 0.7 | ug/L |
| Cu | 65 | 90176.859 | 0.5 | 318.010 | 18.31256 | 0.152 | 0.8 | ug/L |
| Zn | 66 | 55226.676 | 2.3 | 2186.325 | 18.80847 | 0.578 | 3.1 | ug/L |
| Zn | 67 | 10228.044 | 2.2 | 469.352 | 19.77636 | 0.721 | 3.6 | ug/L |
| Zn | 68 | 37527.018 | 0.8 | 1708.532 | 17.58037 | 0.354 | 2.0 | ug/L |
| Ge | 72 | 256682.171 | 1.3 | 235019.833 | | | | ug/L |
| As | 75 | 66369.604 | 1.3 | 174.004 | 20.24684 | 0.535 | 2.6 | ug/L |
| Se | 77 | 1148.346 | 2.4 | 271.738 | 3.49578 | 0.179 | 5.1 | ug/L |
| Se | 78 | 18410.568 | 1.9 | 18294.754 | -2.02984 | 0.203 | 10.0 | mg/L |
| Se | 82 | 588.221 | 1.3 | 514.483 | 0.07858 | 0.041 | 52.5 | ug/L |
| Kr | 83 | 612.029 | 4.9 | 509.687 | | | | mg/L |
| Y | 89 | 443796.264 | 1.3 | 424645.807 | | | | ug/L |
| Mo | 95 | 2868471.396 | 2.2 | 130.336 | 480.35339 | 13.976 | 2.9 | ug/L |
| Mo | 97 | 1465490.172 | 0.6 | 59.667 | 406.33307 | 3.777 | 0.9 | ug/L |
| Mo | 98 | 4456108.481 | 0.5 | 73.129 | 476.57689 | 3.344 | 0.7 | ug/L |
| Rh | 103 | 372651.296 | 0.9 | 377819.614 | | | | ug/L |
| Ag | 107 | 290946.743 | 2.1 | 60.668 | 20.38502 | 0.632 | 3.1 | ug/L |
| Ag | 109 | 264996.920 | 1.4 | 49.001 | 19.99683 | 0.466 | 2.3 | ug/L |
| Cd | 111 | 63419.679 | 1.6 | 302.744 | 20.03097 | 0.528 | 2.6 | ug/L |
| Cd | 114 | 135851.362 | 2.0 | 257.978 | 20.56894 | 0.217 | 1.1 | ug/L |
| In | 115 | 364087.745 | 1.0 | 368464.817 | | | | ug/L |
| Sb | 121 | 3188.642 | 2.7 | 54.001 | 0.33558 | 0.011 | 3.3 | ug/L |
| Sb | 123 | 2426.259 | 1.2 | 50.513 | 0.33311 | 0.005 | 1.5 | ug/L |
| Ba | 135 | 145.669 | 1.4 | 123.002 | 0.01088 | 0.002 | 15.2 | ug/L |
| Ba | 137 | 217.672 | 2.5 | 192.338 | 0.00762 | 0.002 | 26.9 | ug/L |
| Tb | 159 | 440698.470 | 2.2 | 460537.107 | | | | ug/L |
| Ho | 165 | 409817.067 | 1.0 | 440378.521 | | | | ug/L |
| Tl | 203 | 685.368 | 4.4 | 83.668 | 0.07890 | 0.003 | 3.9 | ug/L |
| Tl | 205 | 1599.170 | 7.7 | 163.337 | 0.08433 | 0.006 | 7.4 | ug/L |
| Pb | 208 | 1787.758 | 1.1 | 1492.737 | 0.01632 | 0.001 | 3.5 | ug/L |

Sample ID: QC Std 5

Report Date/Time: Friday, November 17, 2006 16:18:46

Page 1

432

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|-----------|
| | Pb | 206 | 472.018 | 7.4 | 397.348 | 0.01588 | 0.006 | 38.5 ug/L |
| | Pb | 207 | 401.014 | 3.5 | 320.010 | 0.01910 | 0.003 | 13.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | 113.678 | | | | |
| > Sc | 45 | | 99.531 | | | |
| V | 51 | | | | | |
| Cr | 52 | 113.347 | | | | |
| Cr | 53 | 126.957 | | | | |
| Mn | 55 | 94.295 | | | | |
| Co | 59 | 98.578 | | | | |
| Ni | 60 | 97.577 | | | | |
| Ni | 62 | 114.336 | | | | |
| Cu | 63 | 92.582 | | | | |
| Cu | 65 | 91.563 | | | | |
| Zn | 66 | 94.042 | | | | |
| Zn | 67 | 98.882 | | | | |
| Zn | 68 | 87.902 | | | | |
| > Ge | 72 | | 109.217 | | | |
| As | 75 | 101.234 | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 120.088 | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 101.925 | | | | |
| Ag | 109 | 99.984 | | | | |
| Cd | 111 | 100.155 | | | | |
| Cd | 114 | 102.845 | | | | |
| > In | 115 | | 98.812 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 95.692 | | | |
| > Ho | 165 | | 93.060 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Friday, November 17, 2006 16:21:43

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 6.010

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 58367.287 | 1.0 | 84.001 | 48.50948 | 0.616 | 1.3 | ug/L |
| Al | 27 | 439442.754 | 4.0 | 6946.222 | 50.96898 | 1.279 | 2.5 | ug/L |
| > Sc | 45 | 419201.213 | 2.2 | 426236.083 | | | | ug/L |
| V | 51 | 891941.812 | 3.5 | 5344.504 | 52.83093 | 1.028 | 1.9 | ug/L |
| Cr | 52 | 763571.305 | 3.2 | 18378.762 | 51.09060 | 1.097 | 2.1 | ug/L |
| Cr | 53 | 94233.178 | 1.8 | 1484.814 | 50.97988 | 1.952 | 3.8 | ug/L |
| Mn | 55 | 1074292.302 | 1.4 | 742.040 | 47.63077 | 0.214 | 0.5 | ug/L |
| Co | 59 | 931419.973 | 1.6 | 848.388 | 51.03262 | 0.812 | 1.6 | ug/L |
| Ni | 60 | 204717.757 | 3.2 | 167.670 | 49.52927 | 2.118 | 4.3 | ug/L |
| Ni | 62 | 30506.711 | 0.8 | 209.338 | 49.89121 | 0.711 | 1.4 | ug/L |
| Cu | 63 | 484253.875 | 1.9 | 570.693 | 50.51949 | 1.475 | 2.9 | ug/L |
| Cu | 65 | 238101.240 | 3.7 | 318.010 | 51.61457 | 2.332 | 4.5 | ug/L |
| Zn | 66 | 130308.392 | 1.7 | 2186.325 | 48.53288 | 1.355 | 2.8 | ug/L |
| Zn | 67 | 23195.135 | 0.6 | 469.352 | 49.21208 | 0.751 | 1.5 | ug/L |
| Zn | 68 | 96387.693 | 2.2 | 1708.532 | 49.67147 | 1.630 | 3.3 | ug/L |
| > Ge | 72 | 241103.077 | 1.1 | 235019.833 | | | | ug/L |
| As | 75 | 153541.112 | 0.3 | 174.004 | 49.94439 | 0.700 | 1.4 | ug/L |
| Se | 77 | 12011.450 | 0.5 | 271.738 | 51.25540 | 0.373 | 0.7 | ug/L |
| Se | 78 | 56177.196 | 0.8 | 18294.754 | 51.46198 | 0.924 | 1.8 | mg/L |
| Se | 82 | 16609.204 | 1.3 | 514.483 | 50.91295 | 1.064 | 2.1 | ug/L |
| Kr | 83 | 509.687 | 5.7 | 509.687 | | | | mg/L |
| Y | 89 | 440702.006 | 1.4 | 424645.807 | | | | ug/L |
| Mo | 95 | 304747.667 | 1.5 | 130.336 | 50.79518 | 0.964 | 1.9 | ug/L |
| Mo | 97 | 188388.041 | 2.0 | 59.667 | 51.99470 | 0.648 | 1.2 | ug/L |
| Mo | 98 | 480315.899 | 2.4 | 73.129 | 51.14310 | 1.027 | 2.0 | ug/L |
| Rh | 103 | 362641.310 | 1.6 | 377819.614 | | | | ug/L |
| Ag | 107 | 722736.231 | 0.9 | 60.668 | 50.42821 | 1.009 | 2.0 | ug/L |
| Ag | 109 | 677190.618 | 0.6 | 49.001 | 50.89121 | 0.912 | 1.8 | ug/L |
| Cd | 111 | 159422.798 | 2.2 | 302.744 | 50.27576 | 1.013 | 2.0 | ug/L |
| Cd | 114 | 338808.418 | 0.8 | 257.978 | 51.14950 | 0.907 | 1.8 | ug/L |
| > In | 115 | 365628.772 | 1.2 | 368464.817 | | | | ug/L |
| Sb | 121 | 458486.203 | 2.0 | 54.001 | 48.86508 | 1.541 | 3.2 | ug/L |
| Sb | 123 | 358126.243 | 1.0 | 50.513 | 49.98451 | 0.826 | 1.7 | ug/L |
| Ba | 135 | 131757.593 | 1.7 | 123.002 | 51.77595 | 1.360 | 2.6 | ug/L |
| Ba | 137 | 235195.710 | 1.6 | 192.338 | 53.75960 | 0.340 | 0.6 | ug/L |
| > Tb | 159 | 435290.615 | 1.2 | 460537.107 | | | | ug/L |
| > Ho | 165 | 420270.554 | 1.5 | 440378.521 | | | | ug/L |
| Tl | 203 | 402983.658 | 0.1 | 83.668 | 51.04461 | 0.709 | 1.4 | ug/L |
| Tl | 205 | 911051.208 | 1.6 | 163.337 | 51.78244 | 0.275 | 0.5 | ug/L |
| Pb | 208 | 1258695.525 | 0.2 | 1492.737 | 50.20144 | 0.672 | 1.3 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Friday, November 17, 2006 16:24:45

Page 1

435

| | | | | | | | | |
|---|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 326032.133 | 0.6 | 397.348 | 49.20745 | 0.929 | 1.9 ug/L |
| L | Pb | 207 | 273347.718 | 1.4 | 320.010 | 49.27093 | 0.360 | 0.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 97.019 | | | | |
| Al | 27 | 101.938 | | | | |
| > Sc | 45 | | 98.350 | | | |
| V | 51 | 105.662 | | | | |
| Cr | 52 | 102.181 | | | | |
| Cr | 53 | 101.960 | | | | |
| Mn | 55 | 95.262 | | | | |
| Co | 59 | 102.065 | | | | |
| Ni | 60 | 99.059 | | | | |
| Ni | 62 | 99.782 | | | | |
| Cu | 63 | 101.039 | | | | |
| Cu | 65 | 103.229 | | | | |
| Zn | 66 | 97.066 | | | | |
| Zn | 67 | 98.424 | | | | |
| Zn | 68 | 99.343 | | | | |
| > Ge | 72 | | 102.588 | | | |
| As | 75 | 99.889 | | | | |
| Se | 77 | 102.511 | | | | |
| Se | 78 | 102.924 | | | | |
| Se | 82 | 101.826 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 101.590 | | | | |
| Mo | 97 | 103.989 | | | | |
| Mo | 98 | 102.286 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 100.856 | | | | |
| Ag | 109 | 101.782 | | | | |
| Cd | 111 | 100.552 | | | | |
| Cd | 114 | 102.299 | | | | |
| > In | 115 | | 99.230 | | | |
| Sb | 121 | 97.730 | | | | |
| Sb | 123 | 99.969 | | | | |
| Ba | 135 | 103.552 | | | | |
| Ba | 137 | 107.519 | | | | |
| > Tb | 159 | | 94.518 | | | |
| > Ho | 165 | | 95.434 | | | |
| Tl | 203 | 102.089 | | | | |
| Tl | 205 | 103.565 | | | | |
| Pb | 208 | 100.403 | | | | |
| Pb | 206 | 98.415 | | | | |
| Pb | 207 | 98.542 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Friday, November 17, 2006 16:27:41

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 7.011

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 67.334 | 7.6 | 84.001 | -0.01304 | 0.004 | 32.4 | ug/L |
| Al | 27 | 4065.365 | 0.8 | 6946.222 | -0.32873 | 0.009 | 2.8 | ug/L |
| > Sc | 45 | 421742.247 | 2.2 | 426236.083 | | | | ug/L |
| V | 51 | 5143.035 | 2.8 | 5344.504 | -0.00840 | 0.014 | 169.3 | ug/L |
| Cr | 52 | 18086.458 | 1.9 | 18378.762 | -0.00606 | 0.047 | 773.9 | ug/L |
| Cr | 53 | 2012.597 | 2.5 | 1484.814 | 0.29720 | 0.044 | 14.7 | ug/L |
| Mn | 55 | 636.031 | 3.1 | 742.040 | -0.00480 | 0.001 | 18.0 | ug/L |
| Co | 59 | 336.677 | 1.9 | 848.388 | -0.02877 | 0.000 | 0.2 | ug/L |
| Ni | 60 | 156.336 | 7.7 | 167.670 | -0.00273 | 0.004 | 134.8 | ug/L |
| Ni | 62 | 210.005 | 2.2 | 209.338 | 0.00151 | 0.009 | 593.6 | ug/L |
| Cu | 63 | 275.341 | 12.0 | 570.693 | -0.03165 | 0.003 | 9.7 | ug/L |
| Cu | 65 | 176.004 | 4.7 | 318.010 | -0.03159 | 0.001 | 3.8 | ug/L |
| Zn | 66 | 1521.821 | 2.9 | 2186.325 | -0.25751 | 0.024 | 9.4 | ug/L |
| Zn | 67 | 408.681 | 6.9 | 469.352 | -0.13455 | 0.046 | 34.5 | ug/L |
| Zn | 68 | 1174.428 | 1.2 | 1708.532 | -0.28688 | 0.008 | 2.6 | ug/L |
| > Ge | 72 | 234819.175 | 2.3 | 235019.833 | | | | ug/L |
| As | 75 | 269.007 | 7.8 | 174.004 | 0.03183 | 0.007 | 22.1 | ug/L |
| Se | 77 | 306.472 | 1.8 | 271.738 | 0.15715 | 0.031 | 19.7 | ug/L |
| Se | 78 | 18094.028 | 0.1 | 18294.754 | -0.25251 | 0.591 | 234.0 | mg/L |
| Se | 82 | 535.351 | 1.6 | 514.483 | 0.06966 | 0.038 | 54.3 | ug/L |
| Kr | 83 | 519.021 | 3.8 | 509.687 | | | | mg/L |
| Y | 89 | 438518.179 | 3.5 | 424645.807 | | | | ug/L |
| Mo | 95 | 1473.148 | 20.1 | 130.336 | 0.23422 | 0.055 | 23.3 | ug/L |
| Mo | 97 | 908.394 | 22.3 | 59.667 | 0.24490 | 0.062 | 25.1 | ug/L |
| Mo | 98 | 2254.350 | 17.6 | 73.129 | 0.24224 | 0.047 | 19.4 | ug/L |
| Rh | 103 | 373679.619 | 2.2 | 377819.614 | | | | ug/L |
| Ag | 107 | 142.336 | 16.5 | 60.668 | 0.00611 | 0.002 | 25.8 | ug/L |
| Ag | 109 | 121.335 | 2.4 | 49.001 | 0.00582 | 0.000 | 2.6 | ug/L |
| Cd | 111 | 214.987 | 5.6 | 302.744 | -0.02426 | 0.005 | 19.9 | ug/L |
| Cd | 114 | 74.104 | 10.2 | 257.978 | -0.02702 | 0.001 | 4.9 | ug/L |
| > In | 115 | 351704.112 | 1.3 | 368464.817 | | | | ug/L |
| Sb | 121 | 1029.075 | 17.1 | 54.001 | 0.10847 | 0.021 | 19.2 | ug/L |
| Sb | 123 | 764.047 | 17.7 | 50.513 | 0.10405 | 0.021 | 20.2 | ug/L |
| Ba | 135 | 53.334 | 22.2 | 123.002 | -0.02535 | 0.004 | 17.0 | ug/L |
| Ba | 137 | 60.667 | 17.5 | 192.338 | -0.02811 | 0.002 | 7.8 | ug/L |
| > Tb | 159 | 447571.410 | 1.3 | 460537.107 | | | | ug/L |
| > Ho | 165 | 411482.197 | 0.6 | 440378.521 | | | | ug/L |
| Tl | 203 | 156.336 | 1.0 | 83.668 | 0.01011 | 0.000 | 1.2 | ug/L |
| Tl | 205 | 332.677 | 6.7 | 163.337 | 0.01046 | 0.001 | 12.8 | ug/L |
| Pb | 208 | 499.010 | 4.3 | 1492.737 | -0.03653 | 0.001 | 2.3 | ug/L |

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|----------|
| | Pb | 206 | 144.003 | 6.3 | 397.348 | -0.03506 | 0.002 | 4.3 ug/L |
| | Pb | 207 | 116.335 | 11.7 | 320.010 | -0.03367 | 0.002 | 7.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 98.946 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 99.915 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 95.451 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.185 | | | |
| > Ho | 165 | | 93.438 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 8

Sample Date/Time: Friday, November 17, 2006 16:33:38

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 8.012

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 120415.645 | 0.7 | 84.001 | 102.38298 | 2.036 | 2.0 | ug/L |
| Al | 27 | 838154.174 | 1.7 | 6946.222 | 100.18195 | 2.781 | 2.8 | ug/L |
| > Sc | 45 | 410081.294 | 1.6 | 426236.083 | | | | ug/L |
| V | 51 | 1686553.863 | 2.2 | 5344.504 | 102.46226 | 3.787 | 3.7 | ug/L |
| Cr | 52 | 1475734.434 | 4.5 | 18378.762 | 102.21034 | 6.059 | 5.9 | ug/L |
| Cr | 53 | 185568.933 | 0.5 | 1484.814 | 103.40519 | 2.119 | 2.0 | ug/L |
| Mn | 55 | 2381303.588 | 0.8 | 742.040 | 107.68151 | 1.555 | 1.4 | ug/L |
| Co | 59 | 1775523.110 | 1.2 | 848.388 | 99.22728 | 2.399 | 2.4 | ug/L |
| Ni | 60 | 402379.315 | 1.6 | 167.670 | 99.25235 | 1.266 | 1.3 | ug/L |
| Ni | 62 | 59670.475 | 0.8 | 209.338 | 99.82765 | 1.067 | 1.1 | ug/L |
| Cu | 63 | 931935.138 | 1.2 | 570.693 | 99.16371 | 2.223 | 2.2 | ug/L |
| Cu | 65 | 458331.505 | 1.3 | 318.010 | 101.32284 | 0.557 | 0.5 | ug/L |
| Zn | 66 | 261767.929 | 3.1 | 2186.325 | 100.24098 | 2.054 | 2.0 | ug/L |
| Zn | 67 | 46439.188 | 1.6 | 469.352 | 101.52073 | 1.834 | 1.8 | ug/L |
| Zn | 68 | 192581.787 | 3.4 | 1708.532 | 102.11899 | 4.233 | 4.1 | ug/L |
| > Ge | 72 | 236527.316 | 1.6 | 235019.833 | | | | ug/L |
| As | 75 | 311669.759 | 0.4 | 174.004 | 103.41774 | 2.169 | 2.1 | ug/L |
| Se | 77 | 23390.118 | 1.4 | 271.738 | 102.94251 | 1.144 | 1.1 | ug/L |
| Se | 78 | 93109.892 | 3.8 | 18294.754 | 104.74337 | 4.756 | 4.5 | mg/L |
| Se | 82 | 32162.752 | 1.1 | 514.483 | 102.12388 | 1.442 | 1.4 | ug/L |
| Kr | 83 | 513.688 | 5.1 | 509.687 | | | | mg/L |
| Y | 89 | 431690.767 | 0.4 | 424645.807 | | | | ug/L |
| Mo | 95 | 593530.065 | 2.3 | 130.336 | 100.91175 | 2.465 | 2.4 | ug/L |
| Mo | 97 | 362415.189 | 0.8 | 59.667 | 102.03508 | 0.849 | 0.8 | ug/L |
| Mo | 98 | 921411.226 | 1.5 | 73.129 | 100.06810 | 1.269 | 1.3 | ug/L |
| Rh | 103 | 356524.638 | 4.7 | 377819.614 | | | | ug/L |
| Ag | 107 | 1416632.599 | 2.1 | 60.668 | 100.80015 | 2.252 | 2.2 | ug/L |
| Ag | 109 | 1309265.486 | 1.5 | 49.001 | 100.34112 | 1.824 | 1.8 | ug/L |
| Cd | 111 | 314486.368 | 0.1 | 302.744 | 101.24374 | 0.381 | 0.4 | ug/L |
| Cd | 114 | 651155.386 | 1.1 | 257.978 | 100.28542 | 1.363 | 1.4 | ug/L |
| > In | 115 | 358498.758 | 0.3 | 368464.817 | | | | ug/L |
| Sb | 121 | 920720.193 | 0.4 | 54.001 | 100.06370 | 0.629 | 0.6 | ug/L |
| Sb | 123 | 717484.433 | 1.3 | 50.513 | 102.13154 | 1.585 | 1.6 | ug/L |
| Ba | 135 | 255020.848 | 1.6 | 123.002 | 100.65786 | 3.214 | 3.2 | ug/L |
| Ba | 137 | 444036.494 | 0.7 | 192.338 | 101.93905 | 1.363 | 1.3 | ug/L |
| > Tb | 159 | 433632.083 | 1.9 | 460537.107 | | | | ug/L |
| > Ho | 165 | 413272.825 | 0.8 | 440378.521 | | | | ug/L |
| Tl | 203 | 779389.970 | 1.8 | 83.668 | 100.39285 | 1.846 | 1.8 | ug/L |
| Tl | 205 | 1713550.803 | 2.1 | 163.337 | 99.06022 | 2.517 | 2.5 | ug/L |
| Pb | 208 | 2445609.009 | 0.8 | 1492.737 | 99.23509 | 0.555 | 0.6 | ug/L |

Sample ID: QC Std 8

Report Date/Time: Friday, November 17, 2006 16:36:40

Page 1

441

| | | | | | | | | |
|--|----|-----|------------|-----|---------|-----------|-------|----------|
| | Pb | 206 | 655188.856 | 0.8 | 397.348 | 100.60642 | 1.128 | 1.1 ug/L |
| | Pb | 207 | 547389.667 | 2.1 | 320.010 | 100.38638 | 1.368 | 1.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 102.383 | | | | |
| Al | 27 | 100.182 | | | | |
| > Sc | 45 | | 96.210 | | | |
| V | 51 | 102.462 | | | | |
| Cr | 52 | 102.210 | | | | |
| Cr | 53 | 103.405 | | | | |
| Mn | 55 | 107.682 | | | | |
| Co | 59 | 99.227 | | | | |
| Ni | 60 | 99.252 | | | | |
| Ni | 62 | 99.828 | | | | |
| Cu | 63 | 99.164 | | | | |
| Cu | 65 | 101.323 | | | | |
| Zn | 66 | 100.241 | | | | |
| Zn | 67 | 101.521 | | | | |
| Zn | 68 | 102.119 | | | | |
| > Ge | 72 | | 100.641 | | | |
| As | 75 | 103.418 | | | | |
| Se | 77 | 102.943 | | | | |
| Se | 78 | | | | | |
| Se | 82 | 102.124 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 100.912 | | | | |
| Mo | 97 | 102.035 | | | | |
| Mo | 98 | 100.068 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 100.800 | | | | |
| Ag | 109 | 100.341 | | | | |
| Cd | 111 | 101.244 | | | | |
| Cd | 114 | 100.285 | | | | |
| > In | 115 | | 97.295 | | | |
| Sb | 121 | 100.064 | | | | |
| Sb | 123 | 102.132 | | | | |
| Ba | 135 | 100.658 | | | | |
| Ba | 137 | 101.939 | | | | |
| > Tb | 159 | | 94.158 | | | |
| > Ho | 165 | | 93.845 | | | |
| Tl | 203 | 100.393 | | | | |
| Tl | 205 | 99.060 | | | | |
| Pb | 208 | 99.235 | | | | |
| Pb | 206 | 100.606 | | | | |
| Pb | 207 | 100.386 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: PBW-M3990143

Sample Date/Time: Friday, November 17, 2006 16:39:36

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\PBW-M3990143.013

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 58.334 | 14.6 | 84.001 | -0.01915 | 0.009 | 47.6 | ug/L |
| Al | 27 | 6289.437 | 3.2 | 6946.222 | -0.05062 | 0.035 | 69.3 | ug/L |
| > Sc | 45 | 412189.320 | 3.8 | 426236.083 | | | | ug/L |
| V | 51 | 5300.293 | 5.0 | 5344.504 | 0.00870 | 0.028 | 325.6 | ug/L |
| Cr | 52 | 18199.373 | 2.2 | 18378.762 | 0.03146 | 0.071 | 226.4 | ug/L |
| Cr | 53 | 1674.852 | 2.0 | 1484.814 | 0.13482 | 0.054 | 39.9 | ug/L |
| Mn | 55 | 871.388 | 4.5 | 742.040 | 0.00561 | 0.003 | 45.9 | ug/L |
| Co | 59 | 273.341 | 3.7 | 848.388 | -0.03246 | 0.001 | 2.6 | ug/L |
| Ni | 60 | 220.005 | 4.1 | 167.670 | 0.01257 | 0.002 | 19.2 | ug/L |
| Ni | 62 | 222.339 | 3.8 | 209.338 | 0.01917 | 0.020 | 102.7 | ug/L |
| Cu | 63 | 389.346 | 10.0 | 570.693 | -0.01969 | 0.005 | 25.4 | ug/L |
| Cu | 65 | 228.339 | 9.1 | 318.010 | -0.02032 | 0.005 | 25.9 | ug/L |
| Zn | 66 | 1583.833 | 4.1 | 2186.325 | -0.23908 | 0.023 | 9.7 | ug/L |
| Zn | 67 | 380.012 | 5.7 | 469.352 | -0.20577 | 0.029 | 13.9 | ug/L |
| Zn | 68 | 1216.768 | 4.2 | 1708.532 | -0.26980 | 0.030 | 11.3 | ug/L |
| > Ge | 72 | 236924.236 | 2.3 | 235019.833 | | | | ug/L |
| As | 75 | 248.006 | 3.6 | 174.004 | 0.02408 | 0.003 | 13.5 | ug/L |
| Se | 77 | 290.072 | 0.7 | 271.738 | 0.07207 | 0.024 | 33.3 | ug/L |
| Se | 78 | 17909.577 | 0.4 | 18294.754 | -0.73651 | 0.670 | 91.0 | mg/L |
| Se | 82 | 543.684 | 1.3 | 514.483 | 0.08140 | 0.054 | 66.7 | ug/L |
| Kr | 83 | 520.688 | 4.2 | 509.687 | | | | mg/L |
| Y | 89 | 430302.997 | 3.0 | 424645.807 | | | | ug/L |
| Mo | 95 | 2179.998 | 35.8 | 130.336 | 0.34851 | 0.134 | 38.3 | ug/L |
| Mo | 97 | 1257.448 | 33.6 | 59.667 | 0.33706 | 0.120 | 35.5 | ug/L |
| Mo | 98 | 3289.045 | 33.4 | 73.129 | 0.34902 | 0.121 | 34.6 | ug/L |
| Rh | 103 | 358373.495 | 2.0 | 377819.614 | | | | ug/L |
| Ag | 107 | 189.671 | 5.6 | 60.668 | 0.00926 | 0.001 | 8.9 | ug/L |
| Ag | 109 | 156.003 | 2.6 | 49.001 | 0.00827 | 0.000 | 4.8 | ug/L |
| Cd | 111 | 226.409 | 1.8 | 302.744 | -0.02216 | 0.001 | 5.6 | ug/L |
| Cd | 114 | 79.084 | 26.4 | 257.978 | -0.02650 | 0.003 | 12.4 | ug/L |
| > In | 115 | 359493.040 | 1.3 | 368464.817 | | | | ug/L |
| Sb | 121 | 1367.128 | 16.7 | 54.001 | 0.14265 | 0.026 | 18.2 | ug/L |
| Sb | 123 | 1059.756 | 18.6 | 50.513 | 0.14358 | 0.029 | 20.0 | ug/L |
| Ba | 135 | 74.001 | 3.6 | 123.002 | -0.01658 | 0.001 | 5.4 | ug/L |
| Ba | 137 | 98.668 | 5.0 | 192.338 | -0.01898 | 0.001 | 6.2 | ug/L |
| > Tb | 159 | 434732.902 | 0.7 | 460537.107 | | | | ug/L |
| > Ho | 165 | 422724.932 | 1.8 | 440378.521 | | | | ug/L |
| Tl | 203 | 100.668 | 13.6 | 83.668 | 0.00258 | 0.002 | 73.4 | ug/L |
| Tl | 205 | 180.337 | 15.0 | 163.337 | 0.00134 | 0.002 | 117.0 | ug/L |
| Pb | 208 | 564.013 | 5.2 | 1492.737 | -0.03448 | 0.001 | 3.9 | ug/L |

Sample ID: PBW-M3990143

Report Date/Time: Friday, November 17, 2006 16:42:37

Page 1

444

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|-----------|
| | Pb | 206 | 158.003 | 10.6 | 397.348 | -0.03353 | 0.003 | 8.4 ug/L |
| | Pb | 207 | 135.669 | 14.3 | 320.010 | -0.03077 | 0.003 | 11.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 96.704 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 100.810 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 97.565 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 94.397 | | | |
| > Ho | 165 | | 95.991 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: LCSW-M3990143

Sample Date/Time: Friday, November 17, 2006 16:45:33

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\LCSW-M3990143.014

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 23056.100 | 3.0 | 84.001 | 17.26195 | 0.751 | 4.3 | ug/L |
| Al | 27 | 207003.017 | 4.1 | 6946.222 | 21.21433 | 0.572 | 2.7 | ug/L |
| > Sc | 45 | 464270.837 | 1.7 | 426236.083 | | | | ug/L |
| V | 51 | 398968.122 | 1.6 | 5344.504 | 21.15456 | 0.252 | 1.2 | ug/L |
| Cr | 52 | 351652.222 | 0.7 | 18378.762 | 20.52635 | 0.393 | 1.9 | ug/L |
| Cr | 53 | 42020.799 | 2.2 | 1484.814 | 20.04219 | 0.673 | 3.4 | ug/L |
| Mn | 55 | 475106.918 | 1.6 | 742.040 | 20.28934 | 0.682 | 3.4 | ug/L |
| Co | 59 | 415796.526 | 2.1 | 848.388 | 21.92605 | 0.130 | 0.6 | ug/L |
| Ni | 60 | 90116.988 | 3.7 | 167.670 | 20.98742 | 0.942 | 4.5 | ug/L |
| Ni | 62 | 13565.840 | 2.5 | 209.338 | 21.18652 | 0.879 | 4.1 | ug/L |
| Cu | 63 | 213020.738 | 1.9 | 570.693 | 21.37699 | 0.170 | 0.8 | ug/L |
| Cu | 65 | 98358.161 | 1.8 | 318.010 | 20.50487 | 0.574 | 2.8 | ug/L |
| Zn | 66 | 51634.346 | 1.6 | 2186.325 | 18.01277 | 0.683 | 3.8 | ug/L |
| Zn | 67 | 9190.825 | 1.4 | 469.352 | 18.15141 | 0.554 | 3.1 | ug/L |
| Zn | 68 | 37934.861 | 0.6 | 1708.532 | 18.26932 | 0.445 | 2.4 | ug/L |
| > Ge | 72 | 250195.567 | 2.2 | 235019.833 | | | | ug/L |
| As | 75 | 57839.696 | 2.6 | 174.004 | 18.09449 | 0.471 | 2.6 | ug/L |
| Se | 77 | 4185.251 | 1.2 | 271.738 | 16.40666 | 0.469 | 2.9 | ug/L |
| Se | 78 | 31965.567 | 2.2 | 18294.754 | 16.56444 | 1.124 | 6.8 | mg/L |
| Se | 82 | 5794.481 | 0.9 | 514.483 | 16.00932 | 0.301 | 1.9 | ug/L |
| Kr | 83 | 548.024 | 0.9 | 509.687 | | | | mg/L |
| Y | 89 | 459368.423 | 1.5 | 424645.807 | | | | ug/L |
| Mo | 95 | 134701.970 | 5.8 | 130.336 | 21.32312 | 0.839 | 3.9 | ug/L |
| Mo | 97 | 80491.257 | 3.2 | 59.667 | 21.11106 | 0.370 | 1.8 | ug/L |
| Mo | 98 | 209284.993 | 2.0 | 73.129 | 21.18984 | 0.637 | 3.0 | ug/L |
| Rh | 103 | 381544.697 | 0.6 | 377819.614 | | | | ug/L |
| Ag | 107 | 309202.580 | 1.7 | 60.668 | 20.50971 | 0.357 | 1.7 | ug/L |
| Ag | 109 | 290987.680 | 1.7 | 49.001 | 20.78779 | 0.184 | 0.9 | ug/L |
| Cd | 111 | 62175.672 | 1.3 | 302.744 | 18.58695 | 0.397 | 2.1 | ug/L |
| Cd | 114 | 133603.639 | 1.3 | 257.978 | 19.16100 | 0.721 | 3.8 | ug/L |
| > In | 115 | 384586.366 | 2.5 | 368464.817 | | | | ug/L |
| Sb | 121 | 189811.900 | 1.5 | 54.001 | 19.23507 | 0.675 | 3.5 | ug/L |
| Sb | 123 | 147564.153 | 2.5 | 50.513 | 19.57459 | 0.088 | 0.5 | ug/L |
| Ba | 135 | 55999.817 | 2.3 | 123.002 | 21.20243 | 0.513 | 2.4 | ug/L |
| Ba | 137 | 98441.155 | 2.0 | 192.338 | 21.68670 | 0.448 | 2.1 | ug/L |
| > Tb | 159 | 451141.566 | 0.6 | 460537.107 | | | | ug/L |
| > Ho | 165 | 432392.145 | 0.5 | 440378.521 | | | | ug/L |
| Tl | 203 | 166479.819 | 0.4 | 83.668 | 20.48745 | 0.036 | 0.2 | ug/L |
| Tl | 205 | 393247.848 | 1.5 | 163.337 | 21.71903 | 0.226 | 1.0 | ug/L |
| Pb | 208 | 536402.122 | 0.6 | 1492.737 | 20.75819 | 0.158 | 0.8 | ug/L |

Sample ID: LCSW-M3990143

Report Date/Time: Friday, November 17, 2006 16:48:35

Page 1

447

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 139042.420 | 0.2 | 397.348 | 20.36032 | 0.139 | 0.7 ug/L |
| | Pb | 207 | 114185.141 | 0.8 | 320.010 | 19.97221 | 0.232 | 1.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 108.923 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 106.457 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 104.375 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 97.960 | | | |
| > [Ho | 165 | | 98.186 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950466

Sample Date/Time: Friday, November 17, 2006 16:51:31

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950466.015

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 86.335 | 12.3 | 84.001 | -0.00904 | 0.008 | 88.7 | ug/L |
| Al | 27 | 1246220.354 | 0.7 | 6946.222 | 121.11723 | 2.301 | 1.9 | ug/L |
| Sc | 45 | 504993.767 | 1.2 | 426236.083 | | | | ug/L |
| V | 51 | 12712.198 | 4.7 | 5344.504 | 0.31589 | 0.037 | 11.6 | ug/L |
| Cr | 52 | 53327.976 | 1.4 | 18378.762 | 1.79567 | 0.074 | 4.1 | ug/L |
| Cr | 53 | 5727.025 | 2.8 | 1484.814 | 1.80871 | 0.043 | 2.4 | ug/L |
| Mn | 55 | 1371463.962 | 1.1 | 742.040 | 58.14834 | 0.750 | 1.3 | ug/L |
| Co | 59 | 6572.657 | 2.1 | 848.388 | 0.29689 | 0.007 | 2.4 | ug/L |
| Ni | 60 | 23124.940 | 0.6 | 167.670 | 5.31068 | 0.045 | 0.9 | ug/L |
| Ni | 62 | 2586.761 | 1.8 | 209.338 | 3.71961 | 0.081 | 2.2 | ug/L |
| Cu | 63 | 9803.195 | 1.9 | 570.693 | 0.91768 | 0.018 | 1.9 | ug/L |
| Cu | 65 | 4989.210 | 2.8 | 318.010 | 0.96444 | 0.029 | 3.0 | ug/L |
| Zn | 66 | 8941.552 | 2.1 | 2186.325 | 2.38953 | 0.073 | 3.1 | ug/L |
| Zn | 67 | 1824.885 | 1.0 | 469.352 | 2.73687 | 0.037 | 1.4 | ug/L |
| Zn | 68 | 8973.254 | 2.9 | 1708.532 | 3.58222 | 0.122 | 3.4 | ug/L |
| Ge | 72 | 252165.545 | 0.2 | 235019.833 | | | | ug/L |
| As | 75 | 1243.439 | 5.0 | 174.004 | 0.32904 | 0.020 | 6.2 | ug/L |
| Se | 77 | 402.943 | 2.4 | 271.738 | 0.46527 | 0.044 | 9.4 | ug/L |
| Se | 78 | 19524.075 | 1.7 | 18294.754 | -0.13790 | 0.485 | 351.9 | mg/L |
| Se | 82 | 703.030 | 0.6 | 514.483 | 0.45707 | 0.013 | 2.9 | ug/L |
| Kr | 83 | 569.358 | 1.0 | 509.687 | | | | mg/L |
| Y | 89 | 485964.855 | 1.5 | 424645.807 | | | | ug/L |
| Mo | 95 | 3339.369 | 2.7 | 130.336 | 0.52787 | 0.012 | 2.2 | ug/L |
| Mo | 97 | 2044.605 | 1.8 | 59.667 | 0.54070 | 0.005 | 0.9 | ug/L |
| Mo | 98 | 5163.304 | 4.5 | 73.129 | 0.53506 | 0.028 | 5.3 | ug/L |
| Rh | 103 | 371432.117 | 2.7 | 377819.614 | | | | ug/L |
| Ag | 107 | 113.335 | 14.3 | 60.668 | 0.00360 | 0.001 | 29.2 | ug/L |
| Ag | 109 | 84.335 | 12.1 | 49.001 | 0.00261 | 0.001 | 33.3 | ug/L |
| Cd | 111 | 415.700 | 6.1 | 302.744 | 0.03463 | 0.006 | 17.3 | ug/L |
| Cd | 114 | 363.877 | 32.2 | 257.978 | 0.01541 | 0.017 | 108.8 | ug/L |
| In | 115 | 370522.221 | 1.6 | 368464.817 | | | | ug/L |
| Sb | 121 | 1047.076 | 4.8 | 54.001 | 0.10444 | 0.006 | 5.9 | ug/L |
| Sb | 123 | 789.631 | 8.3 | 50.513 | 0.10181 | 0.010 | 9.4 | ug/L |
| Ba | 135 | 47180.351 | 1.9 | 123.002 | 18.13927 | 0.456 | 2.5 | ug/L |
| Ba | 137 | 79979.435 | 0.3 | 192.338 | 17.88985 | 0.106 | 0.6 | ug/L |
| Tb | 159 | 444149.761 | 0.9 | 460537.107 | | | | ug/L |
| Ho | 165 | 418970.086 | 1.5 | 440378.521 | | | | ug/L |
| Tl | 203 | 339.344 | 8.1 | 83.668 | 0.03298 | 0.003 | 8.9 | ug/L |
| Tl | 205 | 771.043 | 3.0 | 163.337 | 0.03511 | 0.001 | 4.2 | ug/L |
| Pb | 208 | 4340.151 | 1.2 | 1492.737 | 0.11695 | 0.002 | 1.4 | ug/L |

Sample ID: 950466

Report Date/Time: Friday, November 17, 2006 16:54:32

Page 1

450

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 1148.757 | 2.0 | 397.348 | 0.11679 | 0.001 | 0.8 ug/L |
| | Pb | 207 | 911.726 | 2.3 | 320.010 | 0.10997 | 0.006 | 5.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 118.477 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 107.295 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 100.558 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 96.442 | | | |
| > Ho | 165 | | 95.139 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950467 D.10

Sample Date/Time: Friday, November 17, 2006 16:57:29

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950467 D.10.016

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 62.001 | 12.6 | 84.001 | -0.01863 | 0.006 | 31.3 | ug/L |
| Al | 27 | 16832.823 | 2.1 | 6946.222 | 1.12386 | 0.076 | 6.8 | ug/L |
| > Sc | 45 | 431291.486 | 1.9 | 426236.083 | | | | ug/L |
| V | 51 | 6264.145 | 7.7 | 5344.504 | 0.04943 | 0.024 | 48.1 | ug/L |
| Cr | 52 | 26334.161 | 2.8 | 18378.762 | 0.51570 | 0.052 | 10.1 | ug/L |
| Cr | 53 | 2291.672 | 4.0 | 1484.814 | 0.42140 | 0.047 | 11.1 | ug/L |
| Mn | 55 | 943934.724 | 1.1 | 742.040 | 40.65288 | 0.411 | 1.0 | ug/L |
| Co | 59 | 2968.892 | 2.5 | 848.388 | 0.11044 | 0.004 | 3.7 | ug/L |
| Ni | 60 | 3650.836 | 1.4 | 167.670 | 0.81690 | 0.012 | 1.4 | ug/L |
| Ni | 62 | 462.017 | 0.6 | 209.338 | 0.38550 | 0.005 | 1.2 | ug/L |
| Cu | 63 | 3584.140 | 2.9 | 570.693 | 0.30248 | 0.011 | 3.5 | ug/L |
| Cu | 65 | 1846.223 | 1.1 | 318.010 | 0.31843 | 0.004 | 1.2 | ug/L |
| Zn | 66 | 8086.336 | 1.6 | 2186.325 | 2.12660 | 0.044 | 2.1 | ug/L |
| Zn | 67 | 1450.474 | 1.8 | 469.352 | 2.00952 | 0.052 | 2.6 | ug/L |
| Zn | 68 | 6232.726 | 0.7 | 1708.532 | 2.25757 | 0.024 | 1.1 | ug/L |
| > Ge | 72 | 248182.907 | 0.1 | 235019.833 | | | | ug/L |
| As | 75 | 380.012 | 5.6 | 174.004 | 0.06209 | 0.007 | 10.9 | ug/L |
| Se | 77 | 287.205 | 2.0 | 271.738 | 0.00106 | 0.025 | 2389.2 | ug/L |
| Se | 78 | 18054.516 | 1.1 | 18294.754 | -1.69014 | 0.282 | 16.7 | mg/L |
| Se | 82 | 667.427 | 1.5 | 514.483 | 0.38172 | 0.030 | 7.9 | ug/L |
| Kr | 83 | 555.024 | 2.7 | 509.687 | | | | mg/L |
| Y | 89 | 458098.012 | 1.5 | 424645.807 | | | | ug/L |
| Mo | 95 | 1546.159 | 4.8 | 130.336 | 0.23950 | 0.006 | 2.6 | ug/L |
| Mo | 97 | 945.730 | 2.6 | 59.667 | 0.24838 | 0.013 | 5.3 | ug/L |
| Mo | 98 | 2322.179 | 1.1 | 73.129 | 0.24286 | 0.004 | 1.7 | ug/L |
| Rh | 103 | 368488.815 | 0.4 | 377819.614 | | | | ug/L |
| Ag | 107 | 81.668 | 4.9 | 60.668 | 0.00157 | 0.000 | 21.0 | ug/L |
| Ag | 109 | 79.001 | 14.1 | 49.001 | 0.00238 | 0.001 | 42.1 | ug/L |
| Cd | 111 | 238.575 | 5.2 | 302.744 | -0.01859 | 0.002 | 11.1 | ug/L |
| Cd | 114 | 94.386 | 24.0 | 257.978 | -0.02417 | 0.004 | 15.5 | ug/L |
| > In | 115 | 360917.843 | 2.5 | 368464.817 | | | | ug/L |
| Sb | 121 | 382.679 | 5.1 | 54.001 | 0.03558 | 0.001 | 3.1 | ug/L |
| Sb | 123 | 287.580 | 1.1 | 50.513 | 0.03368 | 0.001 | 2.8 | ug/L |
| Ba | 135 | 19499.317 | 1.1 | 123.002 | 7.57281 | 0.095 | 1.3 | ug/L |
| Ba | 137 | 33747.566 | 2.7 | 192.338 | 7.62988 | 0.267 | 3.5 | ug/L |
| > Tb | 159 | 438124.007 | 0.9 | 460537.107 | | | | ug/L |
| > Ho | 165 | 415242.503 | 1.8 | 440378.521 | | | | ug/L |
| Tl | 203 | 295.342 | 9.7 | 83.668 | 0.02779 | 0.004 | 14.9 | ug/L |
| Tl | 205 | 641.364 | 5.3 | 163.337 | 0.02807 | 0.003 | 9.2 | ug/L |
| Pb | 208 | 912.029 | 2.7 | 1492.737 | -0.02000 | 0.002 | 7.9 | ug/L |

Sample ID: 950467 D.10

Report Date/Time: Friday, November 17, 2006 17:00:30

Page 1

453

| | | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|------|------|
| | Pb | 206 | 238.339 | 5.6 | 397.348 | -0.02082 | 0.003 | 12.1 | ug/L |
| | Pb | 207 | 197.671 | 9.1 | 320.010 | -0.01901 | 0.003 | 17.0 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 101.186 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 105.601 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 97.952 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 95.133 | | | |
| > Ho | 165 | | 94.292 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| L Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950467

Sample Date/Time: Friday, November 17, 2006 17:03:26

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950467.017

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 84.001 | 7.2 | 84.001 | -0.00923 | 0.004 | 38.9 | ug/L |
| Al | 27 | 141812.543 | 2.1 | 6946.222 | 13.43197 | 0.395 | 2.9 | ug/L |
| > Sc | 45 | 492136.440 | 1.5 | 426236.083 | | | | ug/L |
| V | 51 | 12063.274 | 7.7 | 5344.504 | 0.29940 | 0.052 | 17.4 | ug/L |
| Cr | 52 | 95538.216 | 1.4 | 18378.762 | 4.34002 | 0.155 | 3.6 | ug/L |
| Cr | 53 | 10476.022 | 2.9 | 1484.814 | 4.10100 | 0.214 | 5.2 | ug/L |
| Mn | 55 | 11213117.036 | 1.0 | 742.040 | 449.98945 | 4.754 | 1.1 | ug/L |
| Co | 59 | 29815.883 | 1.5 | 848.388 | 1.43141 | 0.034 | 2.4 | ug/L |
| Ni | 60 | 40405.969 | 5.2 | 167.670 | 8.80257 | 0.363 | 4.1 | ug/L |
| Ni | 62 | 3624.825 | 2.1 | 209.338 | 5.04675 | 0.155 | 3.1 | ug/L |
| Cu | 63 | 25184.594 | 2.0 | 570.693 | 2.31794 | 0.058 | 2.5 | ug/L |
| Cu | 65 | 13349.484 | 0.8 | 318.010 | 2.54964 | 0.010 | 0.4 | ug/L |
| Zn | 66 | 9486.829 | 3.3 | 2186.325 | 2.40148 | 0.107 | 4.4 | ug/L |
| Zn | 67 | 3205.649 | 1.1 | 469.352 | 5.23916 | 0.120 | 2.3 | ug/L |
| Zn | 68 | 12551.237 | 0.4 | 1708.532 | 5.03786 | 0.048 | 1.0 | ug/L |
| > Ge | 72 | 266560.114 | 1.1 | 235019.833 | | | | ug/L |
| As | 75 | 2443.049 | 0.4 | 174.004 | 0.66148 | 0.008 | 1.2 | ug/L |
| Se | 77 | 525.417 | 2.9 | 271.738 | 0.85798 | 0.039 | 4.5 | ug/L |
| Se | 78 | 20947.058 | 0.8 | 18294.754 | 0.24895 | 0.499 | 200.3 | mg/L |
| Se | 82 | 2142.942 | 2.5 | 514.483 | 4.46437 | 0.085 | 1.9 | ug/L |
| Kr | 83 | 629.030 | 3.0 | 509.687 | | | | mg/L |
| Y | 89 | 511201.936 | 1.2 | 424645.807 | | | | ug/L |
| Mo | 95 | 14056.988 | 1.6 | 130.336 | 2.28076 | 0.045 | 2.0 | ug/L |
| Mo | 97 | 8784.052 | 3.3 | 59.667 | 2.36579 | 0.075 | 3.2 | ug/L |
| Mo | 98 | 22289.563 | 3.2 | 73.129 | 2.32421 | 0.087 | 3.7 | ug/L |
| Rh | 103 | 379321.336 | 1.1 | 377819.614 | | | | ug/L |
| Ag | 107 | 166.337 | 5.5 | 60.668 | 0.00720 | 0.001 | 9.6 | ug/L |
| Ag | 109 | 144.669 | 15.3 | 49.001 | 0.00703 | 0.002 | 24.6 | ug/L |
| Cd | 111 | 379.729 | 8.4 | 302.744 | 0.02297 | 0.011 | 46.2 | ug/L |
| Cd | 114 | 396.225 | 15.8 | 257.978 | 0.02017 | 0.010 | 48.6 | ug/L |
| > In | 115 | 372237.528 | 0.9 | 368464.817 | | | | ug/L |
| Sb | 121 | 1920.574 | 2.8 | 54.001 | 0.19536 | 0.007 | 3.6 | ug/L |
| Sb | 123 | 1472.875 | 1.3 | 50.513 | 0.19495 | 0.004 | 1.9 | ug/L |
| Ba | 135 | 201462.111 | 1.4 | 123.002 | 77.04900 | 1.197 | 1.6 | ug/L |
| Ba | 137 | 344996.050 | 1.4 | 192.338 | 76.75873 | 1.104 | 1.4 | ug/L |
| > Tb | 159 | 447308.738 | 0.3 | 460537.107 | | | | ug/L |
| > Ho | 165 | 423370.955 | 1.6 | 440378.521 | | | | ug/L |
| Tl | 203 | 1875.230 | 3.0 | 83.668 | 0.22579 | 0.011 | 4.7 | ug/L |
| Tl | 205 | 4523.940 | 0.4 | 163.337 | 0.24648 | 0.005 | 1.8 | ug/L |
| Pb | 208 | 2226.137 | 0.7 | 1492.737 | 0.03137 | 0.002 | 6.1 | ug/L |

Sample ID: 950467

Report Date/Time: Friday, November 17, 2006 17:06:27

Page 1

456

| | | | | | | | | |
|---|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 588.027 | 1.8 | 397.348 | 0.03091 | 0.002 | 5.4 ug/L |
| L | Pb | 207 | 478.018 | 1.7 | 320.010 | 0.03052 | 0.001 | 1.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 115.461 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 113.420 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 101.024 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.128 | | | |
| > Ho | 165 | | 96.138 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950468 D.10

Sample Date/Time: Friday, November 17, 2006 17:09:23

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950468 D.10.018

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 70.001 | 4.3 | 84.001 | -0.01259 | 0.003 | 22.6 | ug/L |
| Al | 27 | 21598.844 | 2.0 | 6946.222 | 1.64847 | 0.063 | 3.8 | ug/L |
| Sc | 45 | 434920.133 | 1.1 | 426236.083 | | | | ug/L |
| V | 51 | 6427.039 | 6.6 | 5344.504 | 0.05586 | 0.023 | 40.9 | ug/L |
| Cr | 52 | 24411.649 | 3.9 | 18378.762 | 0.37370 | 0.056 | 15.1 | ug/L |
| Cr | 53 | 1956.583 | 1.4 | 1484.814 | 0.23382 | 0.019 | 8.1 | ug/L |
| Mn | 55 | 945236.998 | 0.8 | 742.040 | 39.14639 | 0.322 | 0.8 | ug/L |
| Co | 59 | 3171.969 | 1.1 | 848.388 | 0.11480 | 0.004 | 3.2 | ug/L |
| Ni | 60 | 3672.513 | 1.8 | 167.670 | 0.78884 | 0.012 | 1.5 | ug/L |
| Ni | 62 | 439.349 | 5.8 | 209.338 | 0.32251 | 0.045 | 13.9 | ug/L |
| Cu | 63 | 4461.906 | 3.5 | 570.693 | 0.37416 | 0.015 | 4.1 | ug/L |
| Cu | 65 | 2366.693 | 1.4 | 318.010 | 0.40901 | 0.006 | 1.5 | ug/L |
| Zn | 66 | 1796.879 | 4.0 | 2186.325 | -0.21369 | 0.029 | 13.5 | ug/L |
| Zn | 67 | 517.688 | 7.9 | 469.352 | 0.00529 | 0.095 | 1799.2 | ug/L |
| Zn | 68 | 1785.876 | 1.6 | 1708.532 | -0.04434 | 0.004 | 9.3 | ug/L |
| Ge | 72 | 258095.066 | 1.2 | 235019.833 | | | | ug/L |
| As | 75 | 358.011 | 6.6 | 174.004 | 0.05074 | 0.006 | 11.9 | ug/L |
| Se | 77 | 284.338 | 0.9 | 271.738 | -0.05727 | 0.024 | 41.2 | ug/L |
| Se | 78 | 18171.014 | 0.9 | 18294.754 | -2.46398 | 0.435 | 17.7 | mg/L |
| Se | 82 | 686.228 | 2.2 | 514.483 | 0.35878 | 0.056 | 15.6 | ug/L |
| Kr | 83 | 525.022 | 7.1 | 509.687 | | | | mg/L |
| Y | 89 | 465767.559 | 0.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 1417.135 | 4.0 | 130.336 | 0.20790 | 0.007 | 3.5 | ug/L |
| Mo | 97 | 876.388 | 4.4 | 59.667 | 0.21875 | 0.013 | 5.8 | ug/L |
| Mo | 98 | 2140.720 | 1.6 | 73.129 | 0.21374 | 0.006 | 2.6 | ug/L |
| Rh | 103 | 369412.656 | 1.4 | 377819.614 | | | | ug/L |
| Ag | 107 | 83.001 | 9.6 | 60.668 | 0.00142 | 0.001 | 36.5 | ug/L |
| Ag | 109 | 64.668 | 6.2 | 49.001 | 0.00107 | 0.000 | 28.3 | ug/L |
| Cd | 111 | 246.764 | 3.7 | 302.744 | -0.01920 | 0.002 | 11.9 | ug/L |
| Cd | 114 | 79.931 | 28.5 | 257.978 | -0.02692 | 0.003 | 12.8 | ug/L |
| In | 115 | 376438.862 | 1.0 | 368464.817 | | | | ug/L |
| Sb | 121 | 307.009 | 2.3 | 54.001 | 0.02606 | 0.000 | 1.7 | ug/L |
| Sb | 123 | 248.985 | 12.8 | 50.513 | 0.02678 | 0.005 | 16.9 | ug/L |
| Ba | 135 | 19067.982 | 0.7 | 123.002 | 7.41558 | 0.068 | 0.9 | ug/L |
| Ba | 137 | 32600.310 | 1.4 | 192.338 | 7.37953 | 0.139 | 1.9 | ug/L |
| Tb | 159 | 437452.711 | 0.6 | 460537.107 | | | | ug/L |
| Ho | 165 | 423662.142 | 1.0 | 440378.521 | | | | ug/L |
| Tl | 203 | 337.344 | 3.2 | 83.668 | 0.03228 | 0.002 | 4.7 | ug/L |
| Tl | 205 | 722.372 | 1.8 | 163.337 | 0.03187 | 0.001 | 1.6 | ug/L |
| Pb | 208 | 625.682 | 4.1 | 1492.737 | -0.03209 | 0.001 | 3.6 | ug/L |

Sample ID: 950468 D.10

Report Date/Time: Friday, November 17, 2006 17:12:25

Page 1

459

| | | | | | | | | |
|---|----|-----|---------|-----|---------|----------|-------|----------|
| | Pb | 206 | 172.670 | 5.4 | 397.348 | -0.03141 | 0.001 | 4.2 ug/L |
| L | Pb | 207 | 145.669 | 3.2 | 320.010 | -0.02903 | 0.001 | 3.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 102.037 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 109.818 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 102.164 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 94.988 | | | |
| > [Ho | 165 | | 96.204 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950468

Sample Date/Time: Friday, November 17, 2006 17:15:21

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950468.019

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 97.335 | 17.5 | 84.001 | -0.00203 | 0.012 | 592.1 | ug/L |
| Al | 27 | 185131.489 | 1.1 | 6946.222 | 17.16115 | 0.415 | 2.4 | ug/L |
| Sc | 45 | 509127.877 | 1.6 | 426236.083 | | | | ug/L |
| V | 51 | 12133.218 | 4.8 | 5344.504 | 0.28198 | 0.023 | 8.1 | ug/L |
| Cr | 52 | 70297.137 | 3.0 | 18378.762 | 2.72837 | 0.121 | 4.4 | ug/L |
| Cr | 53 | 7548.493 | 1.4 | 1484.814 | 2.61251 | 0.099 | 3.8 | ug/L |
| Mn | 55 | 10794082.736 | 0.5 | 742.040 | 425.03843 | 6.508 | 1.5 | ug/L |
| Co | 59 | 31390.677 | 2.2 | 848.388 | 1.47980 | 0.004 | 0.2 | ug/L |
| Ni | 60 | 38006.875 | 1.9 | 167.670 | 8.12680 | 0.320 | 3.9 | ug/L |
| Ni | 62 | 3286.682 | 4.1 | 209.338 | 4.45319 | 0.288 | 6.5 | ug/L |
| Cu | 63 | 42213.784 | 2.6 | 570.693 | 3.85077 | 0.068 | 1.8 | ug/L |
| Cu | 65 | 20709.608 | 4.4 | 318.010 | 3.91839 | 0.194 | 5.0 | ug/L |
| Zn | 66 | 9232.205 | 1.8 | 2186.325 | 2.25534 | 0.098 | 4.3 | ug/L |
| Zn | 67 | 3124.951 | 3.9 | 469.352 | 4.96309 | 0.135 | 2.7 | ug/L |
| Zn | 68 | 12181.019 | 1.3 | 1708.532 | 4.75291 | 0.043 | 0.9 | ug/L |
| Ge | 72 | 271704.527 | 2.0 | 235019.833 | | | | ug/L |
| As | 75 | 2406.372 | 3.7 | 174.004 | 0.63768 | 0.038 | 5.9 | ug/L |
| Se | 77 | 525.017 | 3.1 | 271.738 | 0.81740 | 0.048 | 5.9 | ug/L |
| Se | 78 | 21194.779 | 1.3 | 18294.754 | 0.06501 | 0.821 | 1262.3 | mg/L |
| Se | 82 | 2076.725 | 1.6 | 514.483 | 4.16372 | 0.104 | 2.5 | ug/L |
| Kr | 83 | 626.030 | 5.1 | 509.687 | | | | mg/L |
| Y | 89 | 523805.180 | 3.4 | 424645.807 | | | | ug/L |
| Mo | 95 | 13236.640 | 2.4 | 130.336 | 2.06915 | 0.017 | 0.8 | ug/L |
| Mo | 97 | 8335.584 | 0.7 | 59.667 | 2.16424 | 0.028 | 1.3 | ug/L |
| Mo | 98 | 20873.438 | 2.1 | 73.129 | 2.09876 | 0.065 | 3.1 | ug/L |
| Rh | 103 | 386764.348 | 1.7 | 377819.614 | | | | ug/L |
| Ag | 107 | 244.339 | 6.0 | 60.668 | 0.01195 | 0.001 | 7.3 | ug/L |
| Ag | 109 | 211.338 | 7.5 | 49.001 | 0.01141 | 0.001 | 11.9 | ug/L |
| Cd | 111 | 377.737 | 0.5 | 302.744 | 0.01817 | 0.002 | 12.6 | ug/L |
| Cd | 114 | 339.446 | 24.1 | 257.978 | 0.01005 | 0.013 | 125.6 | ug/L |
| In | 115 | 385939.810 | 1.7 | 368464.817 | | | | ug/L |
| Sb | 121 | 1783.542 | 2.8 | 54.001 | 0.17444 | 0.008 | 4.6 | ug/L |
| Sb | 123 | 1335.644 | 0.6 | 50.513 | 0.16965 | 0.003 | 1.6 | ug/L |
| Ba | 135 | 188216.791 | 1.0 | 123.002 | 71.33553 | 1.969 | 2.8 | ug/L |
| Ba | 137 | 336203.257 | 1.8 | 192.338 | 74.13798 | 2.623 | 3.5 | ug/L |
| Tb | 159 | 451494.153 | 1.8 | 460537.107 | | | | ug/L |
| Ho | 165 | 426968.203 | 1.1 | 440378.521 | | | | ug/L |
| Tl | 203 | 1905.570 | 0.7 | 83.668 | 0.22749 | 0.001 | 0.5 | ug/L |
| Tl | 205 | 4549.621 | 2.3 | 163.337 | 0.24578 | 0.009 | 3.5 | ug/L |
| Pb | 208 | 3327.623 | 0.7 | 1492.737 | 0.07391 | 0.002 | 3.1 | ug/L |

Sample ID: 950468

Report Date/Time: Friday, November 17, 2006 17:18:22

Page 1

462

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 864.720 | 1.0 | 397.348 | 0.07132 | 0.003 | 3.9 ug/L |
| | Pb | 207 | 738.040 | 1.1 | 320.010 | 0.07599 | 0.001 | 1.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 119.447 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 115.609 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 104.743 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.036 | | | |
| > [Ho | 165 | | 96.955 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950469 D.10

Sample Date/Time: Friday, November 17, 2006 17:21:19

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950469 D.10.020

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 66.334 | 16.6 | 84.001 | -0.01730 | 0.009 | 51.6 | ug/L |
| Al | 27 | 7876.466 | 1.0 | 6946.222 | 0.05935 | 0.010 | 16.8 | ug/L |
| > Sc | 45 | 450146.385 | 0.8 | 426236.083 | | | | ug/L |
| V | 51 | 5558.988 | 2.2 | 5344.504 | -0.00470 | 0.008 | 176.6 | ug/L |
| Cr | 52 | 35074.007 | 0.5 | 18378.762 | 0.99982 | 0.015 | 1.5 | ug/L |
| Cr | 53 | 3241.663 | 3.9 | 1484.814 | 0.85631 | 0.076 | 8.8 | ug/L |
| Mn | 55 | 977129.052 | 1.7 | 742.040 | 40.86445 | 1.074 | 2.6 | ug/L |
| Co | 59 | 1382.462 | 2.7 | 848.388 | 0.02378 | 0.002 | 7.6 | ug/L |
| Ni | 60 | 4737.061 | 2.5 | 167.670 | 1.03979 | 0.016 | 1.5 | ug/L |
| Ni | 62 | 547.690 | 3.2 | 209.338 | 0.49695 | 0.020 | 4.1 | ug/L |
| Cu | 63 | 1596.502 | 3.3 | 570.693 | 0.09608 | 0.004 | 3.7 | ug/L |
| Cu | 65 | 953.397 | 3.6 | 318.010 | 0.12433 | 0.006 | 4.6 | ug/L |
| Zn | 66 | 1655.514 | 3.3 | 2186.325 | -0.25812 | 0.022 | 8.7 | ug/L |
| Zn | 67 | 739.707 | 2.4 | 469.352 | 0.46824 | 0.027 | 5.7 | ug/L |
| Zn | 68 | 2472.725 | 1.6 | 1708.532 | 0.30404 | 0.008 | 2.6 | ug/L |
| > Ge | 72 | 255627.991 | 1.1 | 235019.833 | | | | ug/L |
| As | 75 | 3754.883 | 1.2 | 174.004 | 1.09512 | 0.010 | 0.9 | ug/L |
| Se | 77 | 271.471 | 1.9 | 271.738 | -0.09909 | 0.031 | 30.8 | ug/L |
| Se | 78 | 18121.278 | 0.3 | 18294.754 | -2.30407 | 0.312 | 13.5 | mg/L |
| Se | 82 | 558.352 | 1.4 | 514.483 | -0.00375 | 0.006 | 153.8 | ug/L |
| Kr | 83 | 534.689 | 1.2 | 509.687 | | | | mg/L |
| Y | 89 | 469440.162 | 1.9 | 424645.807 | | | | ug/L |
| Mo | 95 | 1556.161 | 2.1 | 130.336 | 0.22798 | 0.007 | 3.3 | ug/L |
| Mo | 97 | 967.733 | 2.9 | 59.667 | 0.24063 | 0.010 | 4.0 | ug/L |
| Mo | 98 | 2350.630 | 1.7 | 73.129 | 0.23300 | 0.005 | 2.0 | ug/L |
| Rh | 103 | 379799.909 | 1.2 | 377819.614 | | | | ug/L |
| Ag | 107 | 60.667 | 9.4 | 60.668 | -0.00013 | 0.000 | 314.5 | ug/L |
| Ag | 109 | 42.001 | 20.8 | 49.001 | -0.00062 | 0.001 | 96.6 | ug/L |
| Cd | 111 | 248.874 | 4.3 | 302.744 | -0.01927 | 0.004 | 21.7 | ug/L |
| Cd | 114 | 28.672 | 24.4 | 257.978 | -0.03450 | 0.001 | 3.0 | ug/L |
| > In | 115 | 380246.973 | 1.2 | 368464.817 | | | | ug/L |
| Sb | 121 | 117.669 | 5.1 | 54.001 | 0.00634 | 0.001 | 8.2 | ug/L |
| Sb | 123 | 92.737 | 11.8 | 50.513 | 0.00546 | 0.002 | 29.4 | ug/L |
| Ba | 135 | 41716.246 | 1.2 | 123.002 | 15.72664 | 0.256 | 1.6 | ug/L |
| Ba | 137 | 71420.842 | 1.5 | 192.338 | 15.66722 | 0.317 | 2.0 | ug/L |
| > Tb | 159 | 452757.541 | 0.7 | 460537.107 | | | | ug/L |
| > Ho | 165 | 428317.631 | 1.5 | 440378.521 | | | | ug/L |
| Tl | 203 | 166.337 | 8.8 | 83.668 | 0.01058 | 0.002 | 19.9 | ug/L |
| Tl | 205 | 361.678 | 1.0 | 163.337 | 0.01132 | 0.000 | 4.4 | ug/L |
| Pb | 208 | 393.341 | 4.8 | 1492.737 | -0.04146 | 0.001 | 2.3 | ug/L |

Sample ID: 950469 D.10

Report Date/Time: Friday, November 17, 2006 17:24:20

Page 1

465

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|----------|
| | Pb | 206 | 105.335 | 7.9 | 397.348 | -0.04166 | 0.001 | 3.5 ug/L |
| | Pb | 207 | 100.335 | 7.5 | 320.010 | -0.03734 | 0.001 | 3.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 105.610 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 108.769 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 103.198 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.311 | | | |
| > [Ho | 165 | | 97.261 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950469

Sample Date/Time: Friday, November 17, 2006 17:27:17

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950469.021

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 86.001 | 17.6 | 84.001 | -0.00917 | 0.010 | 112.1 | ug/L |
| Al | 27 | 47063.423 | 3.3 | 6946.222 | 3.81886 | 0.358 | 9.4 | ug/L |
| > Sc | 45 | 503901.436 | 4.3 | 426236.083 | | | | ug/L |
| V | 51 | 5842.774 | 24.5 | 5344.504 | -0.02527 | 0.060 | 237.5 | ug/L |
| Cr | 52 | 185047.849 | 0.4 | 18378.762 | 9.32440 | 0.441 | 4.7 | ug/L |
| Cr | 53 | 21029.378 | 0.6 | 1484.814 | 8.81694 | 0.369 | 4.2 | ug/L |
| Mn | 55 | 11179779.906 | 1.5 | 742.040 | 444.23687 | 12.495 | 2.8 | ug/L |
| Co | 59 | 12068.861 | 3.6 | 848.388 | 0.54529 | 0.033 | 6.0 | ug/L |
| Ni | 60 | 49223.338 | 4.9 | 167.670 | 10.63788 | 0.769 | 7.2 | ug/L |
| Ni | 62 | 4120.727 | 1.8 | 209.338 | 5.72296 | 0.083 | 1.4 | ug/L |
| Cu | 63 | 12787.933 | 1.2 | 570.693 | 1.13469 | 0.013 | 1.2 | ug/L |
| Cu | 65 | 6545.636 | 2.2 | 318.010 | 1.20185 | 0.057 | 4.8 | ug/L |
| Zn | 66 | 7257.232 | 1.4 | 2186.325 | 1.61289 | 0.066 | 4.1 | ug/L |
| Zn | 67 | 4899.156 | 3.4 | 469.352 | 8.45930 | 0.232 | 2.7 | ug/L |
| Zn | 68 | 18869.212 | 3.5 | 1708.532 | 7.94931 | 0.406 | 5.1 | ug/L |
| > Ge | 72 | 269293.347 | 2.3 | 235019.833 | | | | ug/L |
| As | 75 | 35751.555 | 1.1 | 174.004 | 10.36896 | 0.286 | 2.8 | ug/L |
| Se | 77 | 377.275 | 1.9 | 271.738 | 0.25786 | 0.008 | 3.1 | ug/L |
| Se | 78 | 19837.864 | 1.5 | 18294.754 | -1.38080 | 0.398 | 28.8 | mg/L |
| Se | 82 | 687.895 | 2.5 | 514.483 | 0.28024 | 0.093 | 33.2 | ug/L |
| Kr | 83 | 611.695 | 1.9 | 509.687 | | | | mg/L |
| Y | 89 | 513712.659 | 0.9 | 424645.807 | | | | ug/L |
| Mo | 95 | 15230.728 | 1.9 | 130.336 | 2.43507 | 0.070 | 2.9 | ug/L |
| Mo | 97 | 9565.583 | 1.6 | 59.667 | 2.53844 | 0.064 | 2.5 | ug/L |
| Mo | 98 | 24666.684 | 2.1 | 73.129 | 2.53284 | 0.030 | 1.2 | ug/L |
| Rh | 103 | 388824.831 | 1.4 | 377819.614 | | | | ug/L |
| Ag | 107 | 93.668 | 8.7 | 60.668 | 0.00212 | 0.001 | 25.0 | ug/L |
| Ag | 109 | 52.334 | 10.5 | 49.001 | 0.00015 | 0.000 | 274.4 | ug/L |
| Cd | 111 | 324.377 | 3.7 | 302.744 | 0.00422 | 0.004 | 90.9 | ug/L |
| Cd | 114 | 24.779 | 253.1 | 257.978 | -0.03504 | 0.009 | 26.0 | ug/L |
| > In | 115 | 378027.580 | 1.0 | 368464.817 | | | | ug/L |
| Sb | 121 | 219.005 | 2.8 | 54.001 | 0.01686 | 0.001 | 3.0 | ug/L |
| Sb | 123 | 161.866 | 7.6 | 50.513 | 0.01487 | 0.002 | 12.6 | ug/L |
| Ba | 135 | 416375.193 | 0.9 | 123.002 | 157.32272 | 1.792 | 1.1 | ug/L |
| Ba | 137 | 708543.926 | 0.6 | 192.338 | 155.74105 | 1.394 | 0.9 | ug/L |
| > Tb | 159 | 452908.286 | 0.6 | 460537.107 | | | | ug/L |
| > Ho | 165 | 428321.984 | 0.2 | 440378.521 | | | | ug/L |
| Tl | 203 | 264.007 | 13.1 | 83.668 | 0.02270 | 0.004 | 18.9 | ug/L |
| Tl | 205 | 578.693 | 19.3 | 163.337 | 0.02341 | 0.006 | 26.5 | ug/L |
| Pb | 208 | 999.700 | 2.3 | 1492.737 | -0.01771 | 0.001 | 5.4 | ug/L |

Sample ID: 950469

Report Date/Time: Friday, November 17, 2006 17:30:19

Page 1

468

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|-----------|
| | Pb | 206 | 270.340 | 1.3 | 397.348 | -0.01721 | 0.001 | 3.4 ug/L |
| | Pb | 207 | 212.005 | 5.9 | 320.010 | -0.01757 | 0.002 | 12.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 118.221 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 114.583 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.595 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.343 | | | |
| > Ho | 165 | | 97.262 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| L Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Friday, November 17, 2006 17:33:16

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 6.022

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 62669.478 | 2.4 | 84.001 | 49.04515 | 1.779 | 3.6 | ug/L |
| Al | 27 | 476016.581 | 1.5 | 6946.222 | 52.04091 | 2.356 | 4.5 | ug/L |
| > Sc | 45 | 445423.350 | 3.7 | 426236.083 | | | | ug/L |
| V | 51 | 908663.599 | 2.9 | 5344.504 | 50.65697 | 0.490 | 1.0 | ug/L |
| Cr | 52 | 798297.087 | 1.8 | 18378.762 | 50.27854 | 1.175 | 2.3 | ug/L |
| Cr | 53 | 94925.582 | 4.5 | 1484.814 | 48.26565 | 1.359 | 2.8 | ug/L |
| Mn | 55 | 1148319.181 | 1.4 | 742.040 | 49.21971 | 0.957 | 1.9 | ug/L |
| Co | 59 | 932287.456 | 1.8 | 848.388 | 49.37795 | 1.247 | 2.5 | ug/L |
| Ni | 60 | 204494.016 | 0.2 | 167.670 | 47.82619 | 1.589 | 3.3 | ug/L |
| Ni | 62 | 31822.298 | 1.0 | 209.338 | 50.31369 | 1.224 | 2.4 | ug/L |
| Cu | 63 | 470708.704 | 0.6 | 570.693 | 47.46552 | 1.271 | 2.7 | ug/L |
| Cu | 65 | 228485.335 | 0.7 | 318.010 | 47.86964 | 1.228 | 2.6 | ug/L |
| Zn | 66 | 136189.277 | 1.1 | 2186.325 | 49.03578 | 1.087 | 2.2 | ug/L |
| Zn | 67 | 23354.594 | 2.5 | 469.352 | 47.85570 | 0.366 | 0.8 | ug/L |
| Zn | 68 | 98290.957 | 1.1 | 1708.532 | 48.94375 | 1.075 | 2.2 | ug/L |
| > Ge | 72 | 249508.744 | 3.2 | 235019.833 | | | | ug/L |
| As | 75 | 152299.567 | 3.2 | 174.004 | 47.87354 | 1.153 | 2.4 | ug/L |
| Se | 77 | 12464.917 | 1.8 | 271.738 | 51.41913 | 1.065 | 2.1 | ug/L |
| Se | 78 | 55348.625 | 0.5 | 18294.754 | 47.79683 | 2.102 | 4.4 | mg/L |
| Se | 82 | 17162.591 | 1.6 | 514.483 | 50.85716 | 1.549 | 3.0 | ug/L |
| Kr | 83 | 522.022 | 4.8 | 509.687 | | | | mg/L |
| Y | 89 | 475994.370 | 3.9 | 424645.807 | | | | ug/L |
| Mo | 95 | 308948.225 | 2.0 | 130.336 | 49.10869 | 0.203 | 0.4 | ug/L |
| Mo | 97 | 191096.679 | 1.2 | 59.667 | 50.32331 | 1.480 | 2.9 | ug/L |
| Mo | 98 | 489015.615 | 0.6 | 73.129 | 49.67458 | 1.007 | 2.0 | ug/L |
| Rh | 103 | 382306.622 | 0.8 | 377819.614 | | | | ug/L |
| Ag | 107 | 742082.133 | 1.8 | 60.668 | 49.37898 | 0.537 | 1.1 | ug/L |
| Ag | 109 | 685141.453 | 3.5 | 49.001 | 49.09434 | 1.074 | 2.2 | ug/L |
| Cd | 111 | 162816.260 | 0.6 | 302.744 | 48.97604 | 0.584 | 1.2 | ug/L |
| Cd | 114 | 356686.110 | 0.9 | 257.978 | 51.36769 | 1.294 | 2.5 | ug/L |
| > In | 115 | 383344.217 | 1.7 | 368464.817 | | | | ug/L |
| Sb | 121 | 480580.808 | 1.7 | 54.001 | 48.84680 | 0.919 | 1.9 | ug/L |
| Sb | 123 | 360198.900 | 0.9 | 50.513 | 47.95323 | 0.841 | 1.8 | ug/L |
| Ba | 135 | 136767.273 | 2.3 | 123.002 | 51.95640 | 0.955 | 1.8 | ug/L |
| Ba | 137 | 231158.786 | 1.8 | 192.338 | 51.09135 | 0.906 | 1.8 | ug/L |
| > Tb | 159 | 450162.752 | 0.7 | 460537.107 | | | | ug/L |
| > Ho | 165 | 426642.017 | 2.9 | 440378.521 | | | | ug/L |
| Tl | 203 | 404138.030 | 2.1 | 83.668 | 50.42976 | 0.771 | 1.5 | ug/L |
| Tl | 205 | 961184.397 | 0.9 | 163.337 | 53.84358 | 1.494 | 2.8 | ug/L |
| Pb | 208 | 1319054.273 | 1.1 | 1492.737 | 51.83661 | 0.963 | 1.9 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Friday, November 17, 2006 17:36:18

Page 1

471

| | | | | | | | | |
|---|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 340149.766 | 2.1 | 397.348 | 50.57371 | 0.636 | 1.3 ug/L |
| L | Pb | 207 | 281786.814 | 0.3 | 320.010 | 50.06319 | 1.558 | 3.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 98.090 | | | | |
| Al | 27 | 104.082 | | | | |
| Sc | 45 | | 104.502 | | | |
| V | 51 | 101.314 | | | | |
| Cr | 52 | 100.557 | | | | |
| Cr | 53 | 96.531 | | | | |
| Mn | 55 | 98.439 | | | | |
| Co | 59 | 98.756 | | | | |
| Ni | 60 | 95.652 | | | | |
| Ni | 62 | 100.627 | | | | |
| Cu | 63 | 94.931 | | | | |
| Cu | 65 | 95.739 | | | | |
| Zn | 66 | 98.072 | | | | |
| Zn | 67 | 95.711 | | | | |
| Zn | 68 | 97.887 | | | | |
| Ge | 72 | | 106.165 | | | |
| As | 75 | 95.747 | | | | |
| Se | 77 | 102.838 | | | | |
| Se | 78 | 95.594 | | | | |
| Se | 82 | 101.714 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 98.217 | | | | |
| Mo | 97 | 100.647 | | | | |
| Mo | 98 | 99.349 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 98.758 | | | | |
| Ag | 109 | 98.189 | | | | |
| Cd | 111 | 97.952 | | | | |
| Cd | 114 | 102.735 | | | | |
| In | 115 | | 104.038 | | | |
| Sb | 121 | 97.694 | | | | |
| Sb | 123 | 95.906 | | | | |
| Ba | 135 | 103.913 | | | | |
| Ba | 137 | 102.183 | | | | |
| Tb | 159 | | 97.747 | | | |
| Ho | 165 | | 96.881 | | | |
| Tl | 203 | 100.860 | | | | |
| Tl | 205 | 107.687 | | | | |
| Pb | 208 | 103.673 | | | | |
| Pb | 206 | 101.147 | | | | |
| Pb | 207 | 100.126 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Friday, November 17, 2006 17:39:13

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 7.023

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55.001 | 26.9 | 84.001 | -0.02430 | 0.013 | 52.5 | ug/L |
| Al | 27 | 3718.534 | 3.4 | 6946.222 | -0.38126 | 0.005 | 1.4 | ug/L |
| > Sc | 45 | 433432.303 | 2.7 | 426236.083 | | | | ug/L |
| V | 51 | 5316.016 | 1.7 | 5344.504 | -0.00675 | 0.007 | 97.2 | ug/L |
| Cr | 52 | 18083.117 | 1.8 | 18378.762 | -0.03992 | 0.017 | 42.5 | ug/L |
| Cr | 53 | 1164.093 | 0.4 | 1484.814 | -0.18337 | 0.017 | 9.4 | ug/L |
| Mn | 55 | 608.362 | 4.9 | 742.040 | -0.00718 | 0.001 | 19.1 | ug/L |
| Co | 59 | 269.340 | 5.6 | 848.388 | -0.03318 | 0.001 | 2.6 | ug/L |
| Ni | 60 | 155.336 | 7.7 | 167.670 | -0.00460 | 0.003 | 62.5 | ug/L |
| Ni | 62 | 149.336 | 4.1 | 209.338 | -0.11140 | 0.010 | 9.0 | ug/L |
| Cu | 63 | 244.339 | 9.5 | 570.693 | -0.03600 | 0.002 | 6.8 | ug/L |
| Cu | 65 | 241.006 | 11.2 | 318.010 | -0.01926 | 0.006 | 30.6 | ug/L |
| Zn | 66 | 1557.828 | 0.6 | 2186.325 | -0.26836 | 0.005 | 1.9 | ug/L |
| Zn | 67 | 323.676 | 3.4 | 469.352 | -0.35234 | 0.024 | 6.8 | ug/L |
| Zn | 68 | 1153.758 | 2.7 | 1708.532 | -0.32337 | 0.015 | 4.5 | ug/L |
| > Ge | 72 | 244748.873 | 0.3 | 235019.833 | | | | ug/L |
| As | 75 | 161.670 | 4.6 | 174.004 | -0.00627 | 0.002 | 35.1 | ug/L |
| Se | 77 | 264.938 | 3.5 | 271.738 | -0.07758 | 0.044 | 56.3 | ug/L |
| Se | 78 | 17682.868 | 0.7 | 18294.754 | -1.85491 | 0.241 | 13.0 | mg/L |
| Se | 82 | 542.084 | 3.1 | 514.483 | 0.01975 | 0.057 | 286.7 | ug/L |
| Kr | 83 | 539.023 | 3.4 | 509.687 | | | | mg/L |
| Y | 89 | 454551.978 | 1.1 | 424645.807 | | | | ug/L |
| Mo | 95 | 830.385 | 27.1 | 130.336 | 0.11249 | 0.036 | 31.8 | ug/L |
| Mo | 97 | 523.356 | 23.1 | 59.667 | 0.12364 | 0.032 | 25.9 | ug/L |
| Mo | 98 | 1201.789 | 27.1 | 73.129 | 0.11622 | 0.033 | 28.6 | ug/L |
| Rh | 103 | 373013.028 | 0.5 | 377819.614 | | | | ug/L |
| Ag | 107 | 130.002 | 6.3 | 60.668 | 0.00459 | 0.000 | 9.8 | ug/L |
| Ag | 109 | 119.002 | 15.3 | 49.001 | 0.00501 | 0.001 | 24.5 | ug/L |
| Cd | 111 | 237.096 | 4.9 | 302.744 | -0.02231 | 0.003 | 15.4 | ug/L |
| Cd | 114 | 67.791 | 12.8 | 257.978 | -0.02874 | 0.001 | 4.7 | ug/L |
| > In | 115 | 377215.711 | 1.2 | 368464.817 | | | | ug/L |
| Sb | 121 | 1097.751 | 11.9 | 54.001 | 0.10763 | 0.013 | 12.0 | ug/L |
| Sb | 123 | 811.567 | 19.7 | 50.513 | 0.10275 | 0.021 | 20.8 | ug/L |
| Ba | 135 | 52.334 | 10.9 | 123.002 | -0.02550 | 0.002 | 8.3 | ug/L |
| Ba | 137 | 60.001 | 7.3 | 192.338 | -0.02810 | 0.001 | 3.4 | ug/L |
| > Tb | 159 | 442984.731 | 0.8 | 460537.107 | | | | ug/L |
| > Ho | 165 | 428340.213 | 0.2 | 440378.521 | | | | ug/L |
| Tl | 203 | 75.668 | 9.6 | 83.668 | -0.00071 | 0.001 | 128.4 | ug/L |
| Tl | 205 | 167.670 | 5.3 | 163.337 | 0.00049 | 0.001 | 102.2 | ug/L |
| Pb | 208 | 491.010 | 0.5 | 1492.737 | -0.03764 | 0.000 | 0.2 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Friday, November 17, 2006 17:42:14

Page 1

474

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|----------|
| | Pb | 206 | 137.669 | 6.6 | 397.348 | -0.03688 | 0.001 | 3.7 ug/L |
| | Pb | 207 | 112.002 | 6.2 | 320.010 | -0.03528 | 0.001 | 3.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 101.688 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 104.140 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.375 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 96.189 | | | |
| > Ho | 165 | | 97.266 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950470

Sample Date/Time: Friday, November 17, 2006 17:45:11

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950470.024

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 102.002 | 3.5 | 84.001 | -0.00327 | 0.002 | 54.2 | ug/L |
| Al | 27 | 317940.369 | 5.8 | 6946.222 | 28.11403 | 2.015 | 7.2 | ug/L |
| > Sc | 45 | 543375.810 | 1.2 | 426236.083 | | | | ug/L |
| V | 51 | 14184.462 | 50.2 | 5344.504 | 0.33713 | 0.320 | 94.9 | ug/L |
| Cr | 52 | 106891.617 | 16.8 | 18378.762 | 4.40841 | 0.898 | 20.4 | ug/L |
| Cr | 53 | 10746.701 | 1.8 | 1484.814 | 3.75240 | 0.132 | 3.5 | ug/L |
| Mn | 55 | 1913531.375 | 2.0 | 742.040 | 78.92123 | 1.644 | 2.1 | ug/L |
| Co | 59 | 20034.936 | 3.0 | 848.388 | 0.97400 | 0.031 | 3.2 | ug/L |
| Ni | 60 | 77806.986 | 3.7 | 167.670 | 17.47323 | 0.639 | 3.7 | ug/L |
| Ni | 62 | 9816.545 | 2.3 | 209.338 | 14.68012 | 0.326 | 2.2 | ug/L |
| Cu | 63 | 21075.508 | 2.8 | 570.693 | 1.98555 | 0.057 | 2.9 | ug/L |
| Cu | 65 | 10014.785 | 3.2 | 318.010 | 1.95033 | 0.067 | 3.4 | ug/L |
| Zn | 66 | 12090.553 | 1.0 | 2186.325 | 3.41027 | 0.044 | 1.3 | ug/L |
| Zn | 67 | 2739.811 | 1.6 | 469.352 | 4.47656 | 0.084 | 1.9 | ug/L |
| Zn | 68 | 12372.636 | 1.3 | 1708.532 | 5.11798 | 0.082 | 1.6 | ug/L |
| > Ge | 72 | 259266.595 | 0.1 | 235019.833 | | | | ug/L |
| As | 75 | 1839.221 | 1.6 | 174.004 | 0.49881 | 0.009 | 1.7 | ug/L |
| Se | 77 | 402.543 | 4.6 | 271.738 | 0.41755 | 0.078 | 18.6 | ug/L |
| Se | 78 | 19338.805 | 0.2 | 18294.754 | -1.07880 | 0.062 | 5.8 | mg/L |
| Se | 82 | 775.903 | 2.7 | 514.483 | 0.61336 | 0.063 | 10.3 | ug/L |
| Kr | 83 | 607.695 | 3.6 | 509.687 | | | | mg/L |
| Y | 89 | 548732.272 | 1.0 | 424645.807 | | | | ug/L |
| Mo | 95 | 1658.850 | 11.5 | 130.336 | 0.24399 | 0.026 | 10.7 | ug/L |
| Mo | 97 | 1018.740 | 15.3 | 59.667 | 0.25360 | 0.037 | 14.6 | ug/L |
| Mo | 98 | 2534.663 | 14.9 | 73.129 | 0.25134 | 0.034 | 13.6 | ug/L |
| Rh | 103 | 383614.672 | 1.5 | 377819.614 | | | | ug/L |
| Ag | 107 | 102.002 | 15.6 | 60.668 | 0.00264 | 0.001 | 41.7 | ug/L |
| Ag | 109 | 83.001 | 24.1 | 49.001 | 0.00235 | 0.001 | 63.6 | ug/L |
| Cd | 111 | 610.810 | 1.4 | 302.744 | 0.09057 | 0.001 | 0.8 | ug/L |
| Cd | 114 | 1005.765 | 2.0 | 257.978 | 0.10741 | 0.005 | 4.8 | ug/L |
| > In | 115 | 380417.791 | 1.6 | 368464.817 | | | | ug/L |
| Sb | 121 | 884.056 | 10.8 | 54.001 | 0.08475 | 0.008 | 10.0 | ug/L |
| Sb | 123 | 692.602 | 16.9 | 50.513 | 0.08577 | 0.014 | 16.6 | ug/L |
| Ba | 135 | 113885.467 | 1.3 | 123.002 | 42.82469 | 0.717 | 1.7 | ug/L |
| Ba | 137 | 193369.063 | 0.6 | 192.338 | 42.30112 | 0.175 | 0.4 | ug/L |
| > Tb | 159 | 454738.316 | 0.5 | 460537.107 | | | | ug/L |
| > Ho | 165 | 430068.968 | 0.7 | 440378.521 | | | | ug/L |
| Tl | 203 | 542.690 | 6.6 | 83.668 | 0.05706 | 0.004 | 7.7 | ug/L |
| Tl | 205 | 1309.450 | 6.7 | 163.337 | 0.06390 | 0.005 | 8.3 | ug/L |
| Pb | 208 | 3490.985 | 1.9 | 1492.737 | 0.07932 | 0.002 | 2.7 | ug/L |

Sample ID: 950470

Report Date/Time: Friday, November 17, 2006 17:48:13

Page 1

477

| | | | | | | | | | |
|---|----|-----|---------|-----|---------|---------|-------|-----|------|
| | Pb | 206 | 898.057 | 3.1 | 397.348 | 0.07528 | 0.003 | 4.4 | ug/L |
| L | Pb | 207 | 766.376 | 1.5 | 320.010 | 0.08003 | 0.002 | 2.1 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 127.482 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 110.317 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 103.244 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.741 | | | |
| > Ho | 165 | | 97.659 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950471

Sample Date/Time: Friday, November 17, 2006 17:51:10

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950471.025

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 124.002 | 7.3 | 84.001 | 0.01075 | 0.008 | 77.5 | ug/L |
| Al | 27 | 3168516.054 | 4.4 | 6946.222 | 286.44528 | 16.815 | 5.9 | ug/L |
| Sc | 45 | 545356.871 | 3.2 | 426236.083 | | | | ug/L |
| V | 51 | 16737.618 | 5.3 | 5344.504 | 0.45311 | 0.018 | 3.9 | ug/L |
| Cr | 52 | 150321.391 | 2.5 | 18378.762 | 6.68225 | 0.144 | 2.2 | ug/L |
| Cr | 53 | 16867.586 | 5.2 | 1484.814 | 6.32430 | 0.437 | 6.9 | ug/L |
| Mn | 55 | 1368682.183 | 1.6 | 742.040 | 56.17075 | 1.886 | 3.4 | ug/L |
| Co | 59 | 27042.756 | 2.0 | 848.388 | 1.32503 | 0.057 | 4.3 | ug/L |
| Ni | 60 | 89097.365 | 1.2 | 167.670 | 19.91363 | 0.197 | 1.0 | ug/L |
| Ni | 62 | 13075.730 | 4.8 | 209.338 | 19.57086 | 0.943 | 4.8 | ug/L |
| Cu | 63 | 18472.305 | 1.5 | 570.693 | 1.72434 | 0.064 | 3.7 | ug/L |
| Cu | 65 | 9568.253 | 0.9 | 318.010 | 1.85097 | 0.058 | 3.1 | ug/L |
| Zn | 66 | 14641.342 | 3.6 | 2186.325 | 4.28639 | 0.295 | 6.9 | ug/L |
| Zn | 67 | 2745.147 | 3.7 | 469.352 | 4.46318 | 0.321 | 7.2 | ug/L |
| Zn | 68 | 13425.609 | 1.6 | 1708.532 | 5.60013 | 0.196 | 3.5 | ug/L |
| Ge | 72 | 260621.433 | 2.2 | 235019.833 | | | | ug/L |
| As | 75 | 2662.119 | 1.7 | 174.004 | 0.74394 | 0.014 | 1.9 | ug/L |
| Se | 77 | 382.609 | 1.2 | 271.738 | 0.32919 | 0.053 | 16.1 | ug/L |
| Se | 78 | 20111.838 | 1.5 | 18294.754 | -0.21967 | 0.389 | 176.9 | mg/L |
| Se | 82 | 689.229 | 1.3 | 514.483 | 0.34858 | 0.069 | 19.7 | ug/L |
| Kr | 83 | 590.360 | 4.9 | 509.687 | | | | mg/L |
| Y | 89 | 540271.387 | 3.0 | 424645.807 | | | | ug/L |
| Mo | 95 | 1402.132 | 4.3 | 130.336 | 0.20112 | 0.010 | 4.9 | ug/L |
| Mo | 97 | 879.722 | 1.5 | 59.667 | 0.21499 | 0.003 | 1.3 | ug/L |
| Mo | 98 | 2064.623 | 1.3 | 73.129 | 0.20169 | 0.002 | 1.2 | ug/L |
| Rh | 103 | 395185.303 | 1.9 | 377819.614 | | | | ug/L |
| Ag | 107 | 99.002 | 13.9 | 60.668 | 0.00238 | 0.001 | 37.5 | ug/L |
| Ag | 109 | 69.001 | 10.1 | 49.001 | 0.00129 | 0.001 | 40.2 | ug/L |
| Cd | 111 | 626.350 | 9.7 | 302.744 | 0.09355 | 0.018 | 19.3 | ug/L |
| Cd | 114 | 850.298 | 4.5 | 257.978 | 0.08366 | 0.005 | 6.1 | ug/L |
| In | 115 | 383875.423 | 0.3 | 368464.817 | | | | ug/L |
| Sb | 121 | 558.358 | 7.6 | 54.001 | 0.05096 | 0.004 | 8.2 | ug/L |
| Sb | 123 | 413.920 | 5.1 | 50.513 | 0.04803 | 0.003 | 5.6 | ug/L |
| Ba | 135 | 42977.311 | 1.2 | 123.002 | 15.97478 | 0.255 | 1.6 | ug/L |
| Ba | 137 | 75247.964 | 0.5 | 192.338 | 16.27548 | 0.128 | 0.8 | ug/L |
| Tb | 159 | 459217.132 | 0.8 | 460537.107 | | | | ug/L |
| Ho | 165 | 426167.154 | 1.4 | 440378.521 | | | | ug/L |
| Tl | 203 | 235.339 | 9.3 | 83.668 | 0.01931 | 0.003 | 16.0 | ug/L |
| Tl | 205 | 578.026 | 1.5 | 163.337 | 0.02354 | 0.000 | 0.7 | ug/L |
| Pb | 208 | 15707.254 | 2.0 | 1492.737 | 0.56152 | 0.008 | 1.4 | ug/L |

Sample ID: 950471

Report Date/Time: Friday, November 17, 2006 17:54:12

Page 1

480

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 4085.709 | 2.2 | 397.348 | 0.55149 | 0.015 | 2.7 ug/L |
| | Pb | 207 | 3379.052 | 1.0 | 320.010 | 0.54622 | 0.005 | 0.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 127.947 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 110.893 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 104.182 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 99.713 | | | |
| > [Ho | 165 | | 96.773 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950472

Sample Date/Time: Friday, November 17, 2006 17:57:09

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950472.026

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 98.335 | 19.8 | 84.001 | -0.00512 | 0.015 | 283.5 | ug/L |
| Al | 27 | 1252555.659 | 7.7 | 6946.222 | 113.28425 | 5.439 | 4.8 | ug/L |
| > Sc | 45 | 541924.180 | 3.6 | 426236.083 | | | | ug/L |
| V | 51 | 16483.241 | 2.6 | 5344.504 | 0.44770 | 0.047 | 10.4 | ug/L |
| Cr | 52 | 44384.702 | 2.3 | 18378.762 | 1.11709 | 0.124 | 11.1 | ug/L |
| Cr | 53 | 4664.021 | 5.4 | 1484.814 | 1.18046 | 0.111 | 9.4 | ug/L |
| Mn | 55 | 1804227.427 | 1.4 | 742.040 | 73.45548 | 0.468 | 0.6 | ug/L |
| Co | 59 | 23573.216 | 2.9 | 848.388 | 1.13889 | 0.023 | 2.1 | ug/L |
| Ni | 60 | 56435.738 | 2.1 | 167.670 | 12.50198 | 0.361 | 2.9 | ug/L |
| Ni | 62 | 6775.490 | 3.8 | 209.338 | 9.89303 | 0.477 | 4.8 | ug/L |
| Cu | 63 | 17328.173 | 1.4 | 570.693 | 1.60031 | 0.037 | 2.3 | ug/L |
| Cu | 65 | 9113.406 | 1.8 | 318.010 | 1.74474 | 0.014 | 0.8 | ug/L |
| Zn | 66 | 9888.970 | 4.2 | 2186.325 | 2.58941 | 0.121 | 4.7 | ug/L |
| Zn | 67 | 1883.565 | 4.7 | 469.352 | 2.70344 | 0.188 | 7.0 | ug/L |
| Zn | 68 | 8916.190 | 0.1 | 1708.532 | 3.37583 | 0.049 | 1.4 | ug/L |
| > Ge | 72 | 262631.180 | 1.0 | 235019.833 | | | | ug/L |
| As | 75 | 4064.031 | 1.0 | 174.004 | 1.15678 | 0.006 | 0.5 | ug/L |
| Se | 77 | 660.960 | 2.3 | 271.738 | 1.43299 | 0.062 | 4.3 | ug/L |
| Se | 78 | 20613.571 | 0.9 | 18294.754 | 0.21435 | 0.109 | 50.8 | mg/L |
| Se | 82 | 1081.270 | 0.8 | 514.483 | 1.47187 | 0.057 | 3.9 | ug/L |
| Kr | 83 | 584.693 | 4.4 | 509.687 | | | | mg/L |
| Y | 89 | 520922.454 | 1.6 | 424645.807 | | | | ug/L |
| Mo | 95 | 4690.702 | 4.4 | 130.336 | 0.71897 | 0.028 | 3.9 | ug/L |
| Mo | 97 | 2940.549 | 3.5 | 59.667 | 0.75277 | 0.037 | 4.9 | ug/L |
| Mo | 98 | 7693.019 | 0.7 | 73.129 | 0.76815 | 0.008 | 1.1 | ug/L |
| Rh | 103 | 390092.243 | 2.1 | 377819.614 | | | | ug/L |
| Ag | 107 | 131.669 | 3.4 | 60.668 | 0.00450 | 0.000 | 8.9 | ug/L |
| Ag | 109 | 111.335 | 10.8 | 49.001 | 0.00426 | 0.001 | 17.3 | ug/L |
| Cd | 111 | 535.349 | 3.1 | 302.744 | 0.06531 | 0.007 | 10.4 | ug/L |
| Cd | 114 | 550.310 | 4.8 | 257.978 | 0.04004 | 0.003 | 8.0 | ug/L |
| > In | 115 | 386117.103 | 1.6 | 368464.817 | | | | ug/L |
| Sb | 121 | 646.365 | 11.7 | 54.001 | 0.05945 | 0.007 | 11.5 | ug/L |
| Sb | 123 | 479.966 | 2.2 | 50.513 | 0.05644 | 0.000 | 0.7 | ug/L |
| Ba | 135 | 40162.618 | 0.4 | 123.002 | 14.94812 | 0.207 | 1.4 | ug/L |
| Ba | 137 | 69277.478 | 1.0 | 192.338 | 15.00345 | 0.214 | 1.4 | ug/L |
| > Tb | 159 | 458543.105 | 1.0 | 460537.107 | | | | ug/L |
| > Ho | 165 | 439310.717 | 0.5 | 440378.521 | | | | ug/L |
| Tl | 203 | 451.350 | 0.6 | 83.668 | 0.04458 | 0.001 | 1.2 | ug/L |
| Tl | 205 | 1063.412 | 3.5 | 163.337 | 0.04898 | 0.002 | 4.6 | ug/L |
| Pb | 208 | 12682.877 | 1.3 | 1492.737 | 0.42751 | 0.004 | 0.9 | ug/L |

Sample ID: 950472

Report Date/Time: Friday, November 17, 2006 18:00:11

Page 1

483

| | | | | | | | | |
|---|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 3292.350 | 1.0 | 397.348 | 0.41855 | 0.003 | 0.7 ug/L |
| L | Pb | 207 | 2748.147 | 2.0 | 320.010 | 0.41928 | 0.008 | 1.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 127.142 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 111.749 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.791 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.567 | | | |
| > Ho | 165 | | 99.758 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950473 D.10

Sample Date/Time: Friday, November 17, 2006 18:03:08

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950473 D.10.027

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 57.334 | 11.2 | 84.001 | -0.02398 | 0.006 | 24.8 | ug/L |
| Al | 27 | 6849.219 | 4.6 | 6946.222 | -0.04945 | 0.018 | 37.3 | ug/L |
| > Sc | 45 | 447640.994 | 2.3 | 426236.083 | | | | ug/L |
| V | 51 | 5750.234 | 2.8 | 5344.504 | 0.00768 | 0.006 | 81.8 | ug/L |
| Cr | 52 | 19273.468 | 3.0 | 18378.762 | -0.00194 | 0.009 | 480.8 | ug/L |
| Cr | 53 | 1337.787 | 2.7 | 1484.814 | -0.11352 | 0.032 | 28.3 | ug/L |
| Mn | 55 | 575116.466 | 1.9 | 742.040 | 24.56403 | 0.918 | 3.7 | ug/L |
| Co | 59 | 965.399 | 4.7 | 848.388 | 0.00327 | 0.002 | 58.7 | ug/L |
| Ni | 60 | 1559.828 | 4.2 | 167.670 | 0.32231 | 0.018 | 5.7 | ug/L |
| Ni | 62 | 174.337 | 8.2 | 209.338 | -0.07686 | 0.025 | 32.7 | ug/L |
| Cu | 63 | 1163.093 | 3.7 | 570.693 | 0.05587 | 0.003 | 4.8 | ug/L |
| Cu | 65 | 705.704 | 3.8 | 318.010 | 0.07677 | 0.005 | 6.8 | ug/L |
| Zn | 66 | 1231.103 | 5.3 | 2186.325 | -0.39999 | 0.032 | 8.0 | ug/L |
| Zn | 67 | 348.011 | 2.7 | 469.352 | -0.31626 | 0.034 | 10.9 | ug/L |
| Zn | 68 | 1133.422 | 2.7 | 1708.532 | -0.34670 | 0.011 | 3.1 | ug/L |
| > Ge | 72 | 250237.650 | 2.0 | 235019.833 | | | | ug/L |
| As | 75 | 263.007 | 6.9 | 174.004 | 0.02448 | 0.007 | 29.6 | ug/L |
| Se | 77 | 283.872 | 3.2 | 271.738 | -0.02269 | 0.045 | 196.4 | ug/L |
| Se | 78 | 18056.086 | 1.1 | 18294.754 | -1.87806 | 0.648 | 34.5 | mg/L |
| Se | 82 | 572.753 | 2.5 | 514.483 | 0.07612 | 0.025 | 33.0 | ug/L |
| Kr | 83 | 536.356 | 3.6 | 509.687 | | | | mg/L |
| Y | 89 | 471547.697 | 0.3 | 424645.807 | | | | ug/L |
| Mo | 95 | 690.369 | 4.3 | 130.336 | 0.08884 | 0.006 | 6.2 | ug/L |
| Mo | 97 | 410.348 | 4.0 | 59.667 | 0.09227 | 0.003 | 3.6 | ug/L |
| Mo | 98 | 1055.941 | 1.5 | 73.129 | 0.10012 | 0.003 | 2.5 | ug/L |
| Rh | 103 | 381510.105 | 1.2 | 377819.614 | | | | ug/L |
| Ag | 107 | 61.668 | 12.4 | 60.668 | -0.00007 | 0.001 | 729.6 | ug/L |
| Ag | 109 | 47.334 | 10.6 | 49.001 | -0.00024 | 0.000 | 159.4 | ug/L |
| Cd | 111 | 244.071 | 2.7 | 302.744 | -0.02098 | 0.002 | 7.4 | ug/L |
| Cd | 114 | 57.474 | 12.1 | 257.978 | -0.03035 | 0.001 | 3.2 | ug/L |
| > In | 115 | 381299.833 | 0.9 | 368464.817 | | | | ug/L |
| Sb | 121 | 267.340 | 7.3 | 54.001 | 0.02161 | 0.002 | 8.9 | ug/L |
| Sb | 123 | 202.152 | 5.9 | 50.513 | 0.02007 | 0.002 | 9.2 | ug/L |
| Ba | 135 | 6057.262 | 2.7 | 123.002 | 2.20914 | 0.065 | 2.9 | ug/L |
| Ba | 137 | 10296.794 | 1.2 | 192.338 | 2.18819 | 0.033 | 1.5 | ug/L |
| > Tb | 159 | 459842.761 | 0.6 | 460537.107 | | | | ug/L |
| > Ho | 165 | 440691.219 | 1.6 | 440378.521 | | | | ug/L |
| Tl | 203 | 94.668 | 12.2 | 83.668 | 0.00131 | 0.001 | 97.3 | ug/L |
| Tl | 205 | 192.671 | 4.5 | 163.337 | 0.00158 | 0.000 | 21.0 | ug/L |
| Pb | 208 | 516.678 | 4.5 | 1492.737 | -0.03719 | 0.001 | 3.1 | ug/L |

Sample ID: 950473 D.10

Report Date/Time: Friday, November 17, 2006 18:06:09

Page 1

486

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|-----------|
| | Pb | 206 | 142.003 | 9.0 | 397.348 | -0.03683 | 0.002 | 5.0 ug/L |
| | Pb | 207 | 119.335 | 15.7 | 320.010 | -0.03454 | 0.004 | 10.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 105.022 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 106.475 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 103.483 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.849 | | | |
| > Ho | 165 | | 100.071 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950473

Sample Date/Time: Friday, November 17, 2006 18:09:05

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950473.028

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 73.001 | 13.2 | 84.001 | -0.01985 | 0.007 | 33.6 | ug/L |
| Al | 27 | 39063.077 | 1.5 | 6946.222 | 2.89832 | 0.059 | 2.1 | ug/L |
| Sc | 45 | 521084.655 | 1.2 | 426236.083 | | | | ug/L |
| V | 51 | 9631.320 | 3.1 | 5344.504 | 0.14846 | 0.011 | 7.7 | ug/L |
| Cr | 52 | 29832.608 | 1.3 | 18378.762 | 0.40610 | 0.022 | 5.4 | ug/L |
| Cr | 53 | 2905.536 | 4.3 | 1484.814 | 0.48189 | 0.058 | 12.0 | ug/L |
| Mn | 55 | 6543737.973 | 0.3 | 742.040 | 264.78200 | 4.790 | 1.8 | ug/L |
| Co | 59 | 8760.026 | 3.1 | 848.388 | 0.39057 | 0.021 | 5.3 | ug/L |
| Ni | 60 | 16812.469 | 4.8 | 167.670 | 3.67051 | 0.195 | 5.3 | ug/L |
| Ni | 62 | 662.700 | 4.1 | 209.338 | 0.64150 | 0.034 | 5.4 | ug/L |
| Cu | 63 | 8921.863 | 1.5 | 570.693 | 0.78864 | 0.019 | 2.4 | ug/L |
| Cu | 65 | 4224.780 | 3.5 | 318.010 | 0.76513 | 0.017 | 2.3 | ug/L |
| Zn | 66 | 4763.742 | 1.7 | 2186.325 | 0.79650 | 0.044 | 5.5 | ug/L |
| Zn | 67 | 1386.796 | 3.6 | 469.352 | 1.69606 | 0.057 | 3.4 | ug/L |
| Zn | 68 | 6007.892 | 2.0 | 1708.532 | 1.95536 | 0.052 | 2.7 | ug/L |
| Ge | 72 | 264399.058 | 1.8 | 235019.833 | | | | ug/L |
| As | 75 | 1427.803 | 3.5 | 174.004 | 0.36578 | 0.009 | 2.6 | ug/L |
| Se | 77 | 581.087 | 1.1 | 271.738 | 1.09763 | 0.058 | 5.3 | ug/L |
| Se | 78 | 20853.897 | 0.9 | 18294.754 | 0.34446 | 0.268 | 77.8 | mg/L |
| Se | 82 | 909.316 | 2.0 | 514.483 | 0.95529 | 0.099 | 10.4 | ug/L |
| Kr | 83 | 604.695 | 3.4 | 509.687 | | | | mg/L |
| Y | 89 | 511243.969 | 1.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 6091.954 | 2.1 | 130.336 | 0.90919 | 0.020 | 2.2 | ug/L |
| Mo | 97 | 3666.510 | 2.8 | 59.667 | 0.91143 | 0.034 | 3.8 | ug/L |
| Mo | 98 | 9225.073 | 2.4 | 73.129 | 0.89263 | 0.029 | 3.3 | ug/L |
| Rh | 103 | 401527.994 | 1.4 | 377819.614 | | | | ug/L |
| Ag | 107 | 71.334 | 9.1 | 60.668 | 0.00036 | 0.000 | 125.6 | ug/L |
| Ag | 109 | 47.334 | 13.7 | 49.001 | -0.00039 | 0.000 | 122.1 | ug/L |
| Cd | 111 | 420.361 | 4.3 | 302.744 | 0.02682 | 0.006 | 23.8 | ug/L |
| Cd | 114 | 317.514 | 12.0 | 257.978 | 0.00525 | 0.005 | 93.4 | ug/L |
| In | 115 | 399030.465 | 1.0 | 368464.817 | | | | ug/L |
| Sb | 121 | 1323.785 | 4.0 | 54.001 | 0.12358 | 0.006 | 4.9 | ug/L |
| Sb | 123 | 1013.729 | 1.0 | 50.513 | 0.12267 | 0.003 | 2.1 | ug/L |
| Ba | 135 | 61759.314 | 1.3 | 123.002 | 22.32635 | 0.473 | 2.1 | ug/L |
| Ba | 137 | 108814.599 | 0.7 | 192.338 | 22.88882 | 0.424 | 1.9 | ug/L |
| Tb | 159 | 472606.846 | 1.4 | 460537.107 | | | | ug/L |
| Ho | 165 | 446016.861 | 1.0 | 440378.521 | | | | ug/L |
| Tl | 203 | 471.351 | 1.3 | 83.668 | 0.04615 | 0.001 | 1.1 | ug/L |
| Tl | 205 | 1046.743 | 6.1 | 163.337 | 0.04721 | 0.003 | 7.3 | ug/L |
| Pb | 208 | 1013.700 | 5.2 | 1492.737 | -0.01875 | 0.002 | 9.3 | ug/L |

Sample ID: 950473

Report Date/Time: Friday, November 17, 2006 18:12:07

Page 1

| | | | | | | | | |
|---|----|-----|---------|-----|---------|----------|-------|-----------|
| | Pb | 206 | 270.007 | 8.3 | 397.348 | -0.01887 | 0.003 | 15.3 ug/L |
| L | Pb | 207 | 224.005 | 2.7 | 320.010 | -0.01702 | 0.001 | 4.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 122.253 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 112.501 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 108.295 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 102.621 | | | |
| > Ho | 165 | | 101.280 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950474

Sample Date/Time: Friday, November 17, 2006 18:15:03

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950474.029

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 69.001 | 6.3 | 84.001 | -0.02562 | 0.002 | 8.3 | ug/L |
| Al | 27 | 539079.634 | 8.7 | 6946.222 | 46.89313 | 3.500 | 7.5 | ug/L |
| > Sc | 45 | 557890.282 | 1.6 | 426236.083 | | | | ug/L |
| V | 51 | 10950.095 | 11.9 | 5344.504 | 0.17658 | 0.052 | 29.3 | ug/L |
| Cr | 52 | 93074.346 | 4.0 | 18378.762 | 3.55337 | 0.131 | 3.7 | ug/L |
| Cr | 53 | 10250.763 | 8.0 | 1484.814 | 3.43209 | 0.399 | 11.6 | ug/L |
| Mn | 55 | 555355.203 | 1.0 | 742.040 | 22.79196 | 0.763 | 3.3 | ug/L |
| Co | 59 | 6418.202 | 1.2 | 848.388 | 0.27829 | 0.010 | 3.5 | ug/L |
| Ni | 60 | 31607.486 | 1.5 | 167.670 | 7.04647 | 0.269 | 3.8 | ug/L |
| Ni | 62 | 4018.677 | 4.2 | 209.338 | 5.78008 | 0.397 | 6.9 | ug/L |
| Cu | 63 | 13684.698 | 1.0 | 570.693 | 1.26250 | 0.035 | 2.8 | ug/L |
| Cu | 65 | 6823.861 | 1.1 | 318.010 | 1.30106 | 0.048 | 3.7 | ug/L |
| Zn | 66 | 27768.484 | 2.5 | 2186.325 | 8.89130 | 0.051 | 0.6 | ug/L |
| Zn | 67 | 4812.437 | 1.1 | 469.352 | 8.61552 | 0.361 | 4.2 | ug/L |
| Zn | 68 | 23438.484 | 0.8 | 1708.532 | 10.47206 | 0.293 | 2.8 | ug/L |
| > Ge | 72 | 260439.299 | 3.0 | 235019.833 | | | | ug/L |
| As | 75 | 1438.138 | 0.7 | 174.004 | 0.37567 | 0.014 | 3.7 | ug/L |
| Se | 77 | 453.412 | 2.3 | 271.738 | 0.61623 | 0.030 | 4.9 | ug/L |
| Se | 78 | 20330.221 | 1.6 | 18294.754 | 0.09526 | 1.164 | 1222.3 | mg/L |
| Se | 82 | 740.833 | 0.4 | 514.483 | 0.50159 | 0.068 | 13.5 | ug/L |
| Kr | 83 | 573.359 | 4.9 | 509.687 | | | | mg/L |
| Y | 89 | 527309.302 | 2.7 | 424645.807 | | | | ug/L |
| Mo | 95 | 2631.775 | 2.3 | 130.336 | 0.38069 | 0.006 | 1.5 | ug/L |
| Mo | 97 | 1668.517 | 0.5 | 59.667 | 0.40600 | 0.002 | 0.6 | ug/L |
| Mo | 98 | 4188.556 | 1.9 | 73.129 | 0.40118 | 0.004 | 1.0 | ug/L |
| Rh | 103 | 409016.617 | 3.0 | 377819.614 | | | | ug/L |
| Ag | 107 | 75.001 | 9.3 | 60.668 | 0.00060 | 0.000 | 77.0 | ug/L |
| Ag | 109 | 58.334 | 25.1 | 49.001 | 0.00037 | 0.001 | 282.2 | ug/L |
| Cd | 111 | 341.889 | 14.6 | 302.744 | 0.00408 | 0.014 | 345.1 | ug/L |
| Cd | 114 | 236.157 | 5.6 | 257.978 | -0.00595 | 0.002 | 36.0 | ug/L |
| > In | 115 | 398823.033 | 1.0 | 368464.817 | | | | ug/L |
| Sb | 121 | 591.694 | 5.9 | 54.001 | 0.05208 | 0.003 | 5.4 | ug/L |
| Sb | 123 | 459.208 | 2.6 | 50.513 | 0.05176 | 0.001 | 2.6 | ug/L |
| Ba | 135 | 68708.470 | 1.3 | 123.002 | 24.74286 | 0.397 | 1.6 | ug/L |
| Ba | 137 | 118664.473 | 1.0 | 192.338 | 24.86219 | 0.227 | 0.9 | ug/L |
| > Tb | 159 | 474468.837 | 0.5 | 460537.107 | | | | ug/L |
| > Ho | 165 | 440701.688 | 1.7 | 440378.521 | | | | ug/L |
| Tl | 203 | 409.347 | 5.0 | 83.668 | 0.03932 | 0.002 | 4.5 | ug/L |
| Tl | 205 | 932.061 | 1.3 | 163.337 | 0.04168 | 0.001 | 2.2 | ug/L |
| Pb | 208 | 3163.267 | 2.4 | 1492.737 | 0.06360 | 0.004 | 7.0 | ug/L |

Sample ID: 950474

Report Date/Time: Friday, November 17, 2006 18:18:04

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 791.379 | 2.3 | 397.348 | 0.05678 | 0.005 | 8.0 ug/L |
| | Pb | 207 | 698.036 | 2.0 | 320.010 | 0.06504 | 0.003 | 5.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 130.888 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 110.816 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 108.239 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 103.025 | | | |
| > Ho | 165 | | 100.073 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950475 D.10

Sample Date/Time: Friday, November 17, 2006 18:21:01

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950475 D.10.030

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 60.001 | 7.6 | 84.001 | -0.02164 | 0.003 | 12.8 | ug/L |
| Al | 27 | 72587.892 | 1.8 | 6946.222 | 7.27056 | 0.169 | 2.3 | ug/L |
| > Sc | 45 | 444227.505 | 3.6 | 426236.083 | | | | ug/L |
| V | 51 | 6026.694 | 1.7 | 5344.504 | 0.02587 | 0.009 | 33.3 | ug/L |
| Cr | 52 | 19376.362 | 0.9 | 18378.762 | 0.01526 | 0.039 | 254.2 | ug/L |
| Cr | 53 | 1385.129 | 1.2 | 1484.814 | -0.08334 | 0.034 | 40.7 | ug/L |
| Mn | 55 | 850325.930 | 1.7 | 742.040 | 37.06860 | 1.217 | 3.3 | ug/L |
| Co | 59 | 2675.790 | 0.8 | 848.388 | 0.09656 | 0.004 | 3.7 | ug/L |
| Ni | 60 | 5016.894 | 1.9 | 167.670 | 1.15238 | 0.026 | 2.2 | ug/L |
| Ni | 62 | 702.370 | 4.3 | 209.338 | 0.78329 | 0.039 | 5.0 | ug/L |
| Cu | 63 | 22829.496 | 4.4 | 570.693 | 2.28187 | 0.065 | 2.9 | ug/L |
| Cu | 65 | 11505.053 | 1.9 | 318.010 | 2.38371 | 0.026 | 1.1 | ug/L |
| Zn | 66 | 52982.909 | 3.7 | 2186.325 | 18.89711 | 1.072 | 5.7 | ug/L |
| Zn | 67 | 8035.620 | 0.8 | 469.352 | 16.07318 | 0.280 | 1.7 | ug/L |
| Zn | 68 | 38821.961 | 1.9 | 1708.532 | 19.11467 | 0.708 | 3.7 | ug/L |
| > Ge | 72 | 245276.532 | 2.2 | 235019.833 | | | | ug/L |
| As | 75 | 544.023 | 2.3 | 174.004 | 0.11607 | 0.006 | 5.0 | ug/L |
| Se | 77 | 296.605 | 1.2 | 271.738 | 0.05631 | 0.033 | 59.4 | ug/L |
| Se | 78 | 17823.801 | 1.9 | 18294.754 | -1.71510 | 0.107 | 6.3 | mg/L |
| Se | 82 | 589.554 | 1.9 | 514.483 | 0.16406 | 0.036 | 22.2 | ug/L |
| Kr | 83 | 518.355 | 1.9 | 509.687 | | | | mg/L |
| Y | 89 | 466190.307 | 1.4 | 424645.807 | | | | ug/L |
| Mo | 95 | 1049.410 | 1.8 | 130.336 | 0.14784 | 0.004 | 2.8 | ug/L |
| Mo | 97 | 633.364 | 3.1 | 59.667 | 0.15295 | 0.006 | 3.8 | ug/L |
| Mo | 98 | 1597.110 | 3.6 | 73.129 | 0.15691 | 0.005 | 3.2 | ug/L |
| Rh | 103 | 378945.120 | 0.8 | 377819.614 | | | | ug/L |
| Ag | 107 | 94.668 | 5.8 | 60.668 | 0.00219 | 0.000 | 17.7 | ug/L |
| Ag | 109 | 76.668 | 9.2 | 49.001 | 0.00192 | 0.001 | 27.6 | ug/L |
| Cd | 111 | 247.572 | 6.5 | 302.744 | -0.01916 | 0.006 | 28.9 | ug/L |
| Cd | 114 | 124.080 | 2.0 | 257.978 | -0.02052 | 0.000 | 1.9 | ug/L |
| > In | 115 | 377690.282 | 0.9 | 368464.817 | | | | ug/L |
| Sb | 121 | 5766.719 | 0.9 | 54.001 | 0.58920 | 0.003 | 0.5 | ug/L |
| Sb | 123 | 4283.330 | 0.9 | 50.513 | 0.57179 | 0.007 | 1.2 | ug/L |
| Ba | 135 | 14184.206 | 2.0 | 123.002 | 5.22926 | 0.091 | 1.7 | ug/L |
| Ba | 137 | 24304.973 | 1.3 | 192.338 | 5.21664 | 0.059 | 1.1 | ug/L |
| > Tb | 159 | 460258.267 | 0.3 | 460537.107 | | | | ug/L |
| > Ho | 165 | 438796.531 | 1.4 | 440378.521 | | | | ug/L |
| Tl | 203 | 139.669 | 8.5 | 83.668 | 0.00684 | 0.002 | 24.3 | ug/L |
| Tl | 205 | 315.342 | 9.4 | 163.337 | 0.00833 | 0.002 | 22.4 | ug/L |
| Pb | 208 | 5513.440 | 1.0 | 1492.737 | 0.15397 | 0.003 | 1.8 | ug/L |

Sample ID: 950475 D.10

Report Date/Time: Friday, November 17, 2006 18:24:02

Page 1

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 1371.127 | 4.8 | 397.348 | 0.14110 | 0.009 | 6.3 ug/L |
| | Pb | 207 | 1203.099 | 3.3 | 320.010 | 0.15279 | 0.004 | 2.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 104.221 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 104.364 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 102.504 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tl | 159 | | 99.939 | | | |
| > [Ho | 165 | | 99.641 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950475

Sample Date/Time: Friday, November 17, 2006 18:26:59

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950475.031

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 92.668 | 5.4 | 84.001 | -0.00696 | 0.006 | 81.6 | ug/L |
| Al | 27 | 702455.050 | 3.0 | 6946.222 | 65.39645 | 1.948 | 3.0 | ug/L |
| > Sc | 45 | 524392.036 | 3.7 | 426236.083 | | | | ug/L |
| V | 51 | 11935.093 | 2.5 | 5344.504 | 0.25593 | 0.028 | 10.8 | ug/L |
| Cr | 52 | 33367.706 | 2.8 | 18378.762 | 0.59110 | 0.087 | 14.7 | ug/L |
| Cr | 53 | 3235.327 | 1.8 | 1484.814 | 0.61923 | 0.034 | 5.5 | ug/L |
| Mn | 55 | 9432435.713 | 2.1 | 742.040 | 399.97012 | 13.274 | 3.3 | ug/L |
| Co | 59 | 27504.592 | 0.8 | 848.388 | 1.39372 | 0.026 | 1.9 | ug/L |
| Ni | 60 | 54709.213 | 0.5 | 167.670 | 12.61410 | 0.165 | 1.3 | ug/L |
| Ni | 62 | 5768.721 | 1.4 | 209.338 | 8.72466 | 0.128 | 1.5 | ug/L |
| Cu | 63 | 239689.051 | 0.9 | 570.693 | 23.85921 | 0.416 | 1.7 | ug/L |
| Cu | 65 | 111601.891 | 1.6 | 318.010 | 23.07144 | 0.212 | 0.9 | ug/L |
| Zn | 66 | 483288.254 | 0.7 | 2186.325 | 174.12936 | 0.951 | 0.5 | ug/L |
| Zn | 67 | 73906.706 | 0.9 | 469.352 | 151.96412 | 2.337 | 1.5 | ug/L |
| Zn | 68 | 339836.652 | 3.5 | 1708.532 | 169.46777 | 5.070 | 3.0 | ug/L |
| > Ge | 72 | 252322.515 | 1.2 | 235019.833 | | | | ug/L |
| As | 75 | 4325.499 | 2.6 | 174.004 | 1.28766 | 0.025 | 1.9 | ug/L |
| Se | 77 | 667.360 | 1.3 | 271.738 | 1.56794 | 0.026 | 1.6 | ug/L |
| Se | 78 | 20546.544 | 2.0 | 18294.754 | 1.18776 | 0.227 | 19.1 | mg/L |
| Se | 82 | 1104.473 | 0.9 | 514.483 | 1.67015 | 0.024 | 1.4 | ug/L |
| Kr | 83 | 558.358 | 0.6 | 509.687 | | | | mg/L |
| Y | 89 | 516331.394 | 2.2 | 424645.807 | | | | ug/L |
| Mo | 95 | 10083.868 | 2.6 | 130.336 | 1.58754 | 0.037 | 2.3 | ug/L |
| Mo | 97 | 6209.710 | 3.7 | 59.667 | 1.62427 | 0.049 | 3.0 | ug/L |
| Mo | 98 | 16237.997 | 0.7 | 73.129 | 1.64762 | 0.039 | 2.4 | ug/L |
| Rh | 103 | 379920.336 | 2.5 | 377819.614 | | | | ug/L |
| Ag | 107 | 409.014 | 3.2 | 60.668 | 0.02311 | 0.001 | 2.3 | ug/L |
| Ag | 109 | 349.344 | 3.9 | 49.001 | 0.02146 | 0.001 | 2.6 | ug/L |
| Cd | 111 | 606.690 | 1.2 | 302.744 | 0.08854 | 0.001 | 1.6 | ug/L |
| Cd | 114 | 828.046 | 4.6 | 257.978 | 0.08108 | 0.007 | 8.1 | ug/L |
| > In | 115 | 382060.278 | 1.8 | 368464.817 | | | | ug/L |
| Sb | 121 | 56481.704 | 1.8 | 54.001 | 5.75664 | 0.197 | 3.4 | ug/L |
| Sb | 123 | 42807.767 | 1.0 | 50.513 | 5.71149 | 0.043 | 0.7 | ug/L |
| Ba | 135 | 147047.259 | 1.1 | 123.002 | 54.96157 | 0.932 | 1.7 | ug/L |
| Ba | 137 | 246617.184 | 0.6 | 192.338 | 53.63172 | 1.266 | 2.4 | ug/L |
| > Tb | 159 | 457663.139 | 1.9 | 460537.107 | | | | ug/L |
| > Ho | 165 | 441526.471 | 0.6 | 440378.521 | | | | ug/L |
| Tl | 203 | 892.057 | 3.4 | 83.668 | 0.09745 | 0.004 | 4.0 | ug/L |
| Tl | 205 | 2101.286 | 4.0 | 163.337 | 0.10486 | 0.005 | 4.9 | ug/L |
| Pb | 208 | 52087.639 | 0.5 | 1492.737 | 1.92255 | 0.004 | 0.2 | ug/L |

Sample ID: 950475

Report Date/Time: Friday, November 17, 2006 18:30:00

Page 1

498

| | | | | | | | | |
|--|----|-----|-----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 13141.825 | 3.0 | 397.348 | 1.83237 | 0.044 | 2.4 ug/L |
| | Pb | 207 | 11139.553 | 1.3 | 320.010 | 1.85817 | 0.013 | 0.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 123.029 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 107.362 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 103.690 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.376 | | | |
| > Ho | 165 | | 100.261 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| L Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950476 D.10

Sample Date/Time: Friday, November 17, 2006 18:32:57

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950476 D.10.032

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55.001 | 16.2 | 84.001 | -0.02731 | 0.006 | 23.1 | ug/L |
| Al | 27 | 41135.023 | 0.8 | 6946.222 | 3.58957 | 0.139 | 3.9 | ug/L |
| > Sc | 45 | 462633.967 | 2.6 | 426236.083 | | | | ug/L |
| V | 51 | 6033.472 | 1.9 | 5344.504 | 0.01272 | 0.011 | 87.2 | ug/L |
| Cr | 52 | 19813.060 | 1.5 | 18378.762 | -0.00749 | 0.051 | 684.8 | ug/L |
| Cr | 53 | 1336.121 | 6.3 | 1484.814 | -0.13725 | 0.034 | 24.9 | ug/L |
| Mn | 55 | 822425.171 | 0.6 | 742.040 | 35.60970 | 0.448 | 1.3 | ug/L |
| Co | 59 | 2643.446 | 3.8 | 848.388 | 0.09385 | 0.005 | 4.9 | ug/L |
| Ni | 60 | 4748.067 | 2.1 | 167.670 | 1.08113 | 0.031 | 2.9 | ug/L |
| Ni | 62 | 630.364 | 9.4 | 209.338 | 0.65990 | 0.089 | 13.5 | ug/L |
| Cu | 63 | 17432.412 | 4.4 | 570.693 | 1.71668 | 0.067 | 3.9 | ug/L |
| Cu | 65 | 8658.252 | 3.3 | 318.010 | 1.76473 | 0.071 | 4.0 | ug/L |
| Zn | 66 | 45527.511 | 1.9 | 2186.325 | 15.99895 | 0.307 | 1.9 | ug/L |
| Zn | 67 | 7022.363 | 3.1 | 469.352 | 13.81467 | 0.358 | 2.6 | ug/L |
| Zn | 68 | 32558.810 | 1.0 | 1708.532 | 15.76902 | 0.256 | 1.6 | ug/L |
| > Ge | 72 | 246845.479 | 0.7 | 235019.833 | | | | ug/L |
| As | 75 | 513.688 | 5.3 | 174.004 | 0.10529 | 0.010 | 9.0 | ug/L |
| Se | 77 | 296.205 | 1.1 | 271.738 | 0.04607 | 0.012 | 26.6 | ug/L |
| Se | 78 | 17524.528 | 2.0 | 18294.754 | -2.27004 | 0.562 | 24.7 | mg/L |
| Se | 82 | 576.953 | 1.6 | 514.483 | 0.11304 | 0.017 | 15.1 | ug/L |
| Kr | 83 | 517.355 | 4.6 | 509.687 | | | | mg/L |
| Y | 89 | 470357.191 | 1.2 | 424645.807 | | | | ug/L |
| Mo | 95 | 950.730 | 2.6 | 130.336 | 0.12890 | 0.005 | 3.7 | ug/L |
| Mo | 97 | 599.361 | 3.8 | 59.667 | 0.14074 | 0.007 | 4.8 | ug/L |
| Mo | 98 | 1409.408 | 5.6 | 73.129 | 0.13471 | 0.007 | 5.4 | ug/L |
| Rh | 103 | 381294.973 | 0.6 | 377819.614 | | | | ug/L |
| Ag | 107 | 70.001 | 15.1 | 60.668 | 0.00044 | 0.001 | 165.5 | ug/L |
| Ag | 109 | 56.334 | 28.3 | 49.001 | 0.00037 | 0.001 | 314.2 | ug/L |
| Cd | 111 | 267.570 | 7.4 | 302.744 | -0.01470 | 0.006 | 38.1 | ug/L |
| Cd | 114 | 123.589 | 13.8 | 257.978 | -0.02094 | 0.003 | 12.1 | ug/L |
| > In | 115 | 385237.996 | 0.6 | 368464.817 | | | | ug/L |
| Sb | 121 | 3450.749 | 3.2 | 54.001 | 0.34335 | 0.013 | 3.8 | ug/L |
| Sb | 123 | 2521.089 | 3.1 | 50.513 | 0.32698 | 0.010 | 3.1 | ug/L |
| Ba | 135 | 14192.552 | 1.5 | 123.002 | 5.12864 | 0.120 | 2.3 | ug/L |
| Ba | 137 | 24047.892 | 1.3 | 192.338 | 5.05907 | 0.136 | 2.7 | ug/L |
| > Tb | 159 | 469581.734 | 1.4 | 460537.107 | | | | ug/L |
| > Ho | 165 | 445863.568 | 0.7 | 440378.521 | | | | ug/L |
| Tl | 203 | 131.002 | 8.7 | 83.668 | 0.00552 | 0.001 | 23.6 | ug/L |
| Tl | 205 | 302.675 | 2.5 | 163.337 | 0.00736 | 0.000 | 5.5 | ug/L |
| Pb | 208 | 3654.016 | 0.9 | 1492.737 | 0.08063 | 0.000 | 0.5 | ug/L |

Sample ID: 950476 D.10

Report Date/Time: Friday, November 17, 2006 18:35:58

Page 1

501

| | | | | | | | | |
|---|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 903.725 | 0.5 | 397.348 | 0.07141 | 0.001 | 1.0 ug/L |
| L | Pb | 207 | 822.716 | 2.7 | 320.010 | 0.08482 | 0.003 | 3.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 108.539 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 105.032 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.552 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 101.964 | | | |
| > Ho | 165 | | 101.246 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Friday, November 17, 2006 18:38:55

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 6.033

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 63966.220 | 1.1 | 84.001 | 50.51420 | 0.114 | 0.2 | ug/L |
| Al | 27 | 506643.569 | 0.3 | 6946.222 | 55.93351 | 0.628 | 1.1 | ug/L |
| > Sc | 45 | 441129.877 | 1.1 | 426236.083 | | | | ug/L |
| V | 51 | 897141.179 | 0.9 | 5344.504 | 50.49376 | 0.690 | 1.4 | ug/L |
| Cr | 52 | 788866.982 | 2.2 | 18378.762 | 50.14211 | 1.197 | 2.4 | ug/L |
| Cr | 53 | 91408.697 | 2.4 | 1484.814 | 46.90132 | 0.610 | 1.3 | ug/L |
| Mn | 55 | 1109460.938 | 2.0 | 742.040 | 49.08761 | 1.298 | 2.6 | ug/L |
| Co | 59 | 902119.702 | 1.3 | 848.388 | 49.32896 | 1.643 | 3.3 | ug/L |
| Ni | 60 | 205928.430 | 2.9 | 167.670 | 49.72586 | 2.587 | 5.2 | ug/L |
| Ni | 62 | 30285.248 | 1.9 | 209.338 | 49.41665 | 1.317 | 2.7 | ug/L |
| Cu | 63 | 466785.300 | 3.2 | 570.693 | 48.56317 | 0.740 | 1.5 | ug/L |
| Cu | 65 | 226022.424 | 1.9 | 318.010 | 48.88519 | 1.759 | 3.6 | ug/L |
| Zn | 66 | 131553.660 | 2.5 | 2186.325 | 48.87970 | 0.993 | 2.0 | ug/L |
| Zn | 67 | 22184.379 | 0.9 | 469.352 | 46.94762 | 2.367 | 5.0 | ug/L |
| Zn | 68 | 97746.020 | 1.9 | 1708.532 | 50.26400 | 1.347 | 2.7 | ug/L |
| > Ge | 72 | 241805.996 | 4.5 | 235019.833 | | | | ug/L |
| As | 75 | 149286.244 | 2.3 | 174.004 | 48.44632 | 1.159 | 2.4 | ug/L |
| Se | 77 | 12082.820 | 0.8 | 271.738 | 51.47245 | 2.041 | 4.0 | ug/L |
| Se | 78 | 54736.869 | 1.1 | 18294.754 | 49.38159 | 4.158 | 8.4 | mg/L |
| Se | 82 | 16669.657 | 1.0 | 514.483 | 51.01651 | 2.457 | 4.8 | ug/L |
| Kr | 83 | 513.354 | 5.2 | 509.687 | | | | mg/L |
| Y | 89 | 461080.162 | 1.9 | 424645.807 | | | | ug/L |
| Mo | 95 | 305579.548 | 0.3 | 130.336 | 48.99646 | 1.375 | 2.8 | ug/L |
| Mo | 97 | 195520.309 | 2.0 | 59.667 | 51.93172 | 2.294 | 4.4 | ug/L |
| Mo | 98 | 492115.507 | 2.5 | 73.129 | 50.39750 | 1.170 | 2.3 | ug/L |
| Rh | 103 | 388549.925 | 2.5 | 377819.614 | | | | ug/L |
| Ag | 107 | 749101.672 | 0.7 | 60.668 | 50.27974 | 1.573 | 3.1 | ug/L |
| Ag | 109 | 685641.869 | 0.7 | 49.001 | 49.55665 | 0.937 | 1.9 | ug/L |
| Cd | 111 | 167699.475 | 0.2 | 302.744 | 50.87896 | 1.376 | 2.7 | ug/L |
| Cd | 114 | 366637.974 | 3.4 | 257.978 | 53.22242 | 1.344 | 2.5 | ug/L |
| > In | 115 | 380229.172 | 2.6 | 368464.817 | | | | ug/L |
| Sb | 121 | 484114.369 | 0.5 | 54.001 | 49.62081 | 1.020 | 2.1 | ug/L |
| Sb | 123 | 367783.565 | 1.3 | 50.513 | 49.38453 | 1.746 | 3.5 | ug/L |
| Ba | 135 | 137486.137 | 1.8 | 123.002 | 50.44371 | 1.088 | 2.2 | ug/L |
| Ba | 137 | 237025.442 | 2.6 | 192.338 | 50.58855 | 1.144 | 2.3 | ug/L |
| > Tb | 159 | 466137.757 | 0.5 | 460537.107 | | | | ug/L |
| > Ho | 165 | 441159.265 | 1.9 | 440378.521 | | | | ug/L |
| Tl | 203 | 421705.858 | 1.2 | 83.668 | 50.88742 | 0.804 | 1.6 | ug/L |
| Tl | 205 | 976575.078 | 2.5 | 163.337 | 52.87518 | 0.490 | 0.9 | ug/L |
| Pb | 208 | 1329443.491 | 1.3 | 1492.737 | 50.51049 | 0.506 | 1.0 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Friday, November 17, 2006 18:41:57

Page 1

504

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 339511.306 | 2.6 | 397.348 | 48.80349 | 0.642 | 1.3 ug/L |
| | Pb | 207 | 289952.274 | 0.2 | 320.010 | 49.80052 | 0.976 | 2.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 101.028 | | | | |
| Al | 27 | 111.867 | | | | |
| > Sc | 45 | | 103.494 | | | |
| V | 51 | 100.988 | | | | |
| Cr | 52 | 100.284 | | | | |
| Cr | 53 | 93.803 | | | | |
| Mn | 55 | 98.175 | | | | |
| Co | 59 | 98.658 | | | | |
| Ni | 60 | 99.452 | | | | |
| Ni | 62 | 98.833 | | | | |
| Cu | 63 | 97.126 | | | | |
| Cu | 65 | 97.770 | | | | |
| Zn | 66 | 97.759 | | | | |
| Zn | 67 | 93.895 | | | | |
| Zn | 68 | 100.528 | | | | |
| > Ge | 72 | | 102.887 | | | |
| As | 75 | 96.893 | | | | |
| Se | 77 | 102.945 | | | | |
| Se | 78 | 98.763 | | | | |
| Se | 82 | 102.033 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 97.993 | | | | |
| Mo | 97 | 103.863 | | | | |
| Mo | 98 | 100.795 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 100.559 | | | | |
| Ag | 109 | 99.113 | | | | |
| Cd | 111 | 101.758 | | | | |
| Cd | 114 | 106.445 | | | | |
| > In | 115 | | 103.193 | | | |
| Sb | 121 | 99.242 | | | | |
| Sb | 123 | 98.769 | | | | |
| Ba | 135 | 100.887 | | | | |
| Ba | 137 | 101.177 | | | | |
| > Tb | 159 | | 101.216 | | | |
| > Ho | 165 | | 100.177 | | | |
| Tl | 203 | 101.775 | | | | |
| Tl | 205 | 105.750 | | | | |
| Pb | 208 | 101.021 | | | | |
| Pb | 206 | 97.607 | | | | |
| Pb | 207 | 99.601 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Friday, November 17, 2006 18:44:53

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 7.034

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59.001 | 13.5 | 84.001 | -0.02171 | 0.005 | 25.1 | ug/L |
| Al | 27 | 3845.259 | 1.2 | 6946.222 | -0.37008 | 0.014 | 3.8 | ug/L |
| > Sc | 45 | 436913.593 | 2.1 | 426236.083 | | | | ug/L |
| V | 51 | 5327.616 | 1.1 | 5344.504 | -0.00850 | 0.009 | 108.1 | ug/L |
| Cr | 52 | 17889.694 | 0.5 | 18378.762 | -0.06208 | 0.026 | 42.2 | ug/L |
| Cr | 53 | 1062.412 | 1.6 | 1484.814 | -0.24195 | 0.019 | 7.7 | ug/L |
| Mn | 55 | 610.695 | 5.6 | 742.040 | -0.00627 | 0.002 | 30.2 | ug/L |
| Co | 59 | 270.007 | 5.7 | 848.388 | -0.03270 | 0.001 | 3.1 | ug/L |
| Ni | 60 | 141.336 | 7.1 | 167.670 | -0.00690 | 0.003 | 42.6 | ug/L |
| Ni | 62 | 135.669 | 9.1 | 209.338 | -0.12711 | 0.019 | 14.6 | ug/L |
| Cu | 63 | 238.672 | 0.5 | 570.693 | -0.03585 | 0.000 | 1.3 | ug/L |
| Cu | 65 | 206.005 | 3.0 | 318.010 | -0.02543 | 0.002 | 7.2 | ug/L |
| Zn | 66 | 1500.150 | 2.5 | 2186.325 | -0.27322 | 0.008 | 3.0 | ug/L |
| Zn | 67 | 317.676 | 9.1 | 469.352 | -0.34516 | 0.058 | 16.9 | ug/L |
| Zn | 68 | 1124.754 | 3.4 | 1708.532 | -0.32107 | 0.013 | 3.9 | ug/L |
| > Ge | 72 | 237651.106 | 1.3 | 235019.833 | | | | ug/L |
| As | 75 | 156.336 | 6.8 | 174.004 | -0.00646 | 0.004 | 60.2 | ug/L |
| Se | 77 | 253.471 | 2.1 | 271.738 | -0.09417 | 0.036 | 38.2 | ug/L |
| Se | 78 | 17032.037 | 1.4 | 18294.754 | -2.04213 | 0.660 | 32.3 | mg/L |
| Se | 82 | 523.416 | 2.1 | 514.483 | 0.01054 | 0.049 | 469.8 | ug/L |
| Kr | 83 | 499.687 | 3.4 | 509.687 | | | | mg/L |
| Y | 89 | 450841.120 | 1.6 | 424645.807 | | | | ug/L |
| Mo | 95 | 883.725 | 29.4 | 130.336 | 0.11869 | 0.039 | 33.2 | ug/L |
| Mo | 97 | 493.354 | 28.7 | 59.667 | 0.11325 | 0.035 | 31.1 | ug/L |
| Mo | 98 | 1273.241 | 29.8 | 73.129 | 0.12135 | 0.037 | 30.3 | ug/L |
| Rh | 103 | 381804.647 | 2.1 | 377819.614 | | | | ug/L |
| Ag | 107 | 138.669 | 2.9 | 60.668 | 0.00503 | 0.000 | 2.6 | ug/L |
| Ag | 109 | 118.335 | 12.0 | 49.001 | 0.00483 | 0.001 | 20.5 | ug/L |
| Cd | 111 | 255.421 | 5.4 | 302.744 | -0.01789 | 0.005 | 28.8 | ug/L |
| Cd | 114 | 75.410 | 8.6 | 257.978 | -0.02779 | 0.001 | 3.9 | ug/L |
| > In | 115 | 383294.238 | 1.5 | 368464.817 | | | | ug/L |
| Sb | 121 | 1097.418 | 14.5 | 54.001 | 0.10579 | 0.015 | 14.6 | ug/L |
| Sb | 123 | 870.870 | 17.5 | 50.513 | 0.10882 | 0.019 | 17.4 | ug/L |
| Ba | 135 | 45.001 | 19.4 | 123.002 | -0.02885 | 0.003 | 10.9 | ug/L |
| Ba | 137 | 70.001 | 11.3 | 192.338 | -0.02631 | 0.002 | 6.9 | ug/L |
| > Tb | 159 | 456388.845 | 0.7 | 460537.107 | | | | ug/L |
| > Ho | 165 | 438926.133 | 2.8 | 440378.521 | | | | ug/L |
| Tl | 203 | 72.668 | 5.2 | 83.668 | -0.00130 | 0.000 | 29.1 | ug/L |
| Tl | 205 | 138.003 | 19.2 | 163.337 | -0.00132 | 0.002 | 123.9 | ug/L |
| Pb | 208 | 450.009 | 5.7 | 1492.737 | -0.03968 | 0.001 | 1.5 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Friday, November 17, 2006 18:47:53

Page 1

507

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|----------|
| | Pb | 206 | 122.002 | 12.3 | 397.348 | -0.03967 | 0.002 | 4.5 ug/L |
| | Pb | 207 | 103.002 | 4.2 | 320.010 | -0.03732 | 0.000 | 0.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 102.505 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 101.120 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.025 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.099 | | | |
| > Ho | 165 | | 99.670 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950476

Sample Date/Time: Friday, November 17, 2006 18:50:50

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950476.035

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 86.668 | 1.8 | 84.001 | -0.01050 | 0.001 | 11.8 | ug/L |
| Al | 27 | 395027.406 | 0.6 | 6946.222 | 36.78704 | 0.133 | 0.4 | ug/L |
| Sc | 45 | 519084.099 | 0.4 | 426236.083 | | | | ug/L |
| V | 51 | 10961.201 | 1.8 | 5344.504 | 0.21429 | 0.011 | 5.1 | ug/L |
| Cr | 52 | 30616.451 | 1.4 | 18378.762 | 0.45570 | 0.017 | 3.7 | ug/L |
| Cr | 53 | 2816.504 | 1.7 | 1484.814 | 0.44716 | 0.017 | 3.9 | ug/L |
| Mn | 55 | 9074675.641 | 0.7 | 742.040 | 387.16869 | 7.275 | 1.9 | ug/L |
| Co | 59 | 26430.780 | 0.4 | 848.388 | 1.34607 | 0.016 | 1.2 | ug/L |
| Ni | 60 | 50192.280 | 2.8 | 167.670 | 11.64400 | 0.442 | 3.8 | ug/L |
| Ni | 62 | 5107.283 | 3.2 | 209.338 | 7.73651 | 0.351 | 4.5 | ug/L |
| Cu | 63 | 175390.877 | 2.3 | 570.693 | 17.54842 | 0.196 | 1.1 | ug/L |
| Cu | 65 | 86495.431 | 0.1 | 318.010 | 17.97937 | 0.194 | 1.1 | ug/L |
| Zn | 66 | 399973.769 | 0.8 | 2186.325 | 144.87678 | 1.716 | 1.2 | ug/L |
| Zn | 67 | 59755.503 | 2.6 | 469.352 | 123.46473 | 4.581 | 3.7 | ug/L |
| Zn | 68 | 287156.700 | 2.6 | 1708.532 | 144.00954 | 5.397 | 3.7 | ug/L |
| Ge | 72 | 250751.141 | 1.2 | 235019.833 | | | | ug/L |
| As | 75 | 3988.661 | 1.1 | 174.004 | 1.19086 | 0.022 | 1.9 | ug/L |
| Se | 77 | 642.091 | 0.8 | 271.738 | 1.47933 | 0.021 | 1.4 | ug/L |
| Se | 78 | 20029.771 | 0.7 | 18294.754 | 0.67840 | 0.436 | 64.3 | mg/L |
| Se | 82 | 1081.537 | 1.0 | 514.483 | 1.62126 | 0.020 | 1.2 | ug/L |
| Kr | 83 | 564.025 | 5.3 | 509.687 | | | | mg/L |
| Y | 89 | 517127.628 | 2.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 9199.836 | 2.2 | 130.336 | 1.42229 | 0.042 | 2.9 | ug/L |
| Mo | 97 | 5732.697 | 3.4 | 59.667 | 1.47367 | 0.065 | 4.4 | ug/L |
| Mo | 98 | 15024.204 | 3.9 | 73.129 | 1.49832 | 0.066 | 4.4 | ug/L |
| Rh | 103 | 395371.391 | 0.4 | 377819.614 | | | | ug/L |
| Ag | 107 | 241.006 | 3.7 | 60.668 | 0.01163 | 0.001 | 6.5 | ug/L |
| Ag | 109 | 206.671 | 5.3 | 49.001 | 0.01096 | 0.001 | 5.3 | ug/L |
| Cd | 111 | 562.904 | 1.6 | 302.744 | 0.07249 | 0.004 | 5.5 | ug/L |
| Cd | 114 | 789.312 | 4.6 | 257.978 | 0.07357 | 0.006 | 7.9 | ug/L |
| In | 115 | 388504.837 | 1.3 | 368464.817 | | | | ug/L |
| Sb | 121 | 32874.396 | 2.1 | 54.001 | 3.29173 | 0.087 | 2.6 | ug/L |
| Sb | 123 | 24551.854 | 1.2 | 50.513 | 3.21874 | 0.078 | 2.4 | ug/L |
| Ba | 135 | 138241.291 | 0.8 | 123.002 | 50.06394 | 0.193 | 0.4 | ug/L |
| Ba | 137 | 234220.919 | 1.2 | 192.338 | 49.34623 | 0.319 | 0.6 | ug/L |
| Tb | 159 | 472232.250 | 1.0 | 460537.107 | | | | ug/L |
| Ho | 165 | 447884.544 | 1.6 | 440378.521 | | | | ug/L |
| Tl | 203 | 864.053 | 1.9 | 83.668 | 0.09262 | 0.003 | 3.4 | ug/L |
| Tl | 205 | 2008.596 | 3.5 | 163.337 | 0.09832 | 0.005 | 5.0 | ug/L |
| Pb | 208 | 33445.327 | 0.7 | 1492.737 | 1.19621 | 0.017 | 1.4 | ug/L |

Sample ID: 950476

Report Date/Time: Friday, November 17, 2006 18:53:51

Page 1

510

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 8501.420 | 1.4 | 397.348 | 1.14819 | 0.032 | 2.8 ug/L |
| | Pb | 207 | 7194.177 | 1.7 | 320.010 | 1.16326 | 0.030 | 2.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 121.783 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 106.694 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 105.439 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 102.539 | | | |
| > Ho | 165 | | 101.704 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477 D.10

Sample Date/Time: Friday, November 17, 2006 18:56:48

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950477 D.10.036

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59.334 | 19.7 | 84.001 | -0.02322 | 0.009 | 40.6 | ug/L |
| Al | 27 | 6686.749 | 0.8 | 6946.222 | -0.07926 | 0.011 | 13.4 | ug/L |
| > Sc | 45 | 455172.661 | 1.4 | 426236.083 | | | | ug/L |
| V | 51 | 5574.145 | 0.9 | 5344.504 | -0.00729 | 0.002 | 33.4 | ug/L |
| Cr | 52 | 18669.413 | 1.6 | 18378.762 | -0.06028 | 0.023 | 38.9 | ug/L |
| Cr | 53 | 1248.773 | 5.8 | 1484.814 | -0.17042 | 0.035 | 20.4 | ug/L |
| Mn | 55 | 609588.772 | 0.7 | 742.040 | 26.64740 | 0.380 | 1.4 | ug/L |
| Co | 59 | 1376.461 | 0.8 | 848.388 | 0.02673 | 0.001 | 4.1 | ug/L |
| Ni | 60 | 3672.846 | 2.0 | 167.670 | 0.83570 | 0.034 | 4.0 | ug/L |
| Ni | 62 | 426.015 | 3.8 | 209.338 | 0.33883 | 0.040 | 11.7 | ug/L |
| Cu | 63 | 1086.082 | 0.8 | 570.693 | 0.05076 | 0.003 | 5.1 | ug/L |
| Cu | 65 | 711.704 | 1.1 | 318.010 | 0.08155 | 0.001 | 1.7 | ug/L |
| Zn | 66 | 3718.867 | 1.9 | 2186.325 | 0.54033 | 0.041 | 7.5 | ug/L |
| Zn | 67 | 796.713 | 2.9 | 469.352 | 0.65942 | 0.048 | 7.3 | ug/L |
| Zn | 68 | 3158.964 | 1.8 | 1708.532 | 0.71556 | 0.040 | 5.5 | ug/L |
| > Ge | 72 | 244452.927 | 2.0 | 235019.833 | | | | ug/L |
| As | 75 | 843.051 | 1.7 | 174.004 | 0.21268 | 0.006 | 2.7 | ug/L |
| Se | 77 | 262.537 | 2.6 | 271.738 | -0.08603 | 0.049 | 57.4 | ug/L |
| Se | 78 | 17366.722 | 1.7 | 18294.754 | -2.24734 | 0.710 | 31.6 | mg/L |
| Se | 82 | 547.551 | 2.2 | 514.483 | 0.03875 | 0.012 | 30.9 | ug/L |
| Kr | 83 | 500.020 | 4.1 | 509.687 | | | | mg/L |
| Y | 89 | 454163.872 | 1.6 | 424645.807 | | | | ug/L |
| Mo | 95 | 1158.092 | 6.3 | 130.336 | 0.15893 | 0.011 | 7.0 | ug/L |
| Mo | 97 | 652.365 | 3.0 | 59.667 | 0.15199 | 0.003 | 2.0 | ug/L |
| Mo | 98 | 1707.210 | 2.9 | 73.129 | 0.16222 | 0.004 | 2.6 | ug/L |
| Rh | 103 | 375858.678 | 2.1 | 377819.614 | | | | ug/L |
| Ag | 107 | 60.667 | 12.6 | 60.668 | -0.00024 | 0.001 | 229.3 | ug/L |
| Ag | 109 | 53.334 | 3.9 | 49.001 | 0.00009 | 0.000 | 171.9 | ug/L |
| Cd | 111 | 249.629 | 4.4 | 302.744 | -0.02121 | 0.002 | 11.5 | ug/L |
| Cd | 114 | 89.185 | 18.3 | 257.978 | -0.02606 | 0.002 | 9.4 | ug/L |
| > In | 115 | 391152.414 | 1.2 | 368464.817 | | | | ug/L |
| Sb | 121 | 247.006 | 9.4 | 54.001 | 0.01891 | 0.003 | 13.6 | ug/L |
| Sb | 123 | 190.273 | 7.8 | 50.513 | 0.01783 | 0.002 | 10.8 | ug/L |
| Ba | 135 | 17614.442 | 1.6 | 123.002 | 6.50102 | 0.050 | 0.8 | ug/L |
| Ba | 137 | 29722.224 | 2.2 | 192.338 | 6.38595 | 0.190 | 3.0 | ug/L |
| > Tb | 159 | 460544.965 | 1.3 | 460537.107 | | | | ug/L |
| > Ho | 165 | 447105.900 | 0.7 | 440378.521 | | | | ug/L |
| Tl | 203 | 99.335 | 5.1 | 83.668 | 0.00171 | 0.001 | 34.8 | ug/L |
| Tl | 205 | 210.338 | 9.0 | 163.337 | 0.00237 | 0.001 | 39.7 | ug/L |
| Pb | 208 | 1271.383 | 1.7 | 1492.737 | -0.00916 | 0.000 | 5.4 | ug/L |

Sample ID: 950477 D.10

Report Date/Time: Friday, November 17, 2006 18:59:49

Page 1

513

| | | | | | | | | |
|---|----|-----|---------|-----|---------|----------|-------|-----------|
| | Pb | 206 | 332.343 | 4.1 | 397.348 | -0.01008 | 0.002 | 21.9 ug/L |
| L | Pb | 207 | 286.008 | 8.9 | 320.010 | -0.00661 | 0.004 | 61.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 106.789 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 104.014 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 106.157 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.002 | | | |
| > Ho | 165 | | 101.528 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477D D.10

Sample Date/Time: Friday, November 17, 2006 19:02:46

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950477D D.10.037

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 61.668 | 12.6 | 84.001 | -0.02022 | 0.005 | 26.0 | ug/L |
| Al | 27 | 6769.484 | 2.4 | 6946.222 | -0.04970 | 0.007 | 13.8 | ug/L |
| Sc | 45 | 442709.789 | 2.0 | 426236.083 | | | | ug/L |
| V | 51 | 5936.257 | 2.0 | 5344.504 | 0.02179 | 0.008 | 34.8 | ug/L |
| Cr | 52 | 19267.111 | 1.7 | 18378.762 | 0.01172 | 0.022 | 186.2 | ug/L |
| Cr | 53 | 1135.089 | 3.5 | 1484.814 | -0.21155 | 0.024 | 11.4 | ug/L |
| Mn | 55 | 596658.938 | 1.0 | 742.040 | 26.87212 | 0.589 | 2.2 | ug/L |
| Co | 59 | 1322.785 | 2.4 | 848.388 | 0.02598 | 0.001 | 5.6 | ug/L |
| Ni | 60 | 3729.872 | 2.5 | 167.670 | 0.87611 | 0.034 | 3.8 | ug/L |
| Ni | 62 | 422.682 | 1.4 | 209.338 | 0.35376 | 0.014 | 4.0 | ug/L |
| Cu | 63 | 1044.076 | 3.5 | 570.693 | 0.04968 | 0.005 | 9.2 | ug/L |
| Cu | 65 | 655.032 | 2.2 | 318.010 | 0.07366 | 0.003 | 4.7 | ug/L |
| Zn | 66 | 2504.068 | 2.1 | 2186.325 | 0.11450 | 0.030 | 26.4 | ug/L |
| Zn | 67 | 607.028 | 2.7 | 469.352 | 0.29304 | 0.020 | 6.9 | ug/L |
| Zn | 68 | 2355.356 | 1.1 | 1708.532 | 0.33625 | 0.013 | 3.8 | ug/L |
| Ge | 72 | 237268.371 | 1.2 | 235019.833 | | | | ug/L |
| As | 75 | 842.051 | 4.9 | 174.004 | 0.22042 | 0.011 | 4.8 | ug/L |
| Se | 77 | 264.271 | 1.7 | 271.738 | -0.04441 | 0.034 | 76.6 | ug/L |
| Se | 78 | 17190.728 | 1.4 | 18294.754 | -1.78392 | 0.546 | 30.6 | mg/L |
| Se | 82 | 537.617 | 3.8 | 514.483 | 0.05840 | 0.055 | 93.8 | ug/L |
| Kr | 83 | 498.687 | 7.1 | 509.687 | | | | mg/L |
| Y | 89 | 465450.185 | 1.5 | 424645.807 | | | | ug/L |
| Mo | 95 | 1120.420 | 3.1 | 130.336 | 0.15595 | 0.004 | 2.3 | ug/L |
| Mo | 97 | 648.365 | 4.3 | 59.667 | 0.15375 | 0.006 | 4.0 | ug/L |
| Mo | 98 | 1649.050 | 1.0 | 73.129 | 0.15920 | 0.003 | 2.1 | ug/L |
| Rh | 103 | 383038.253 | 1.2 | 377819.614 | | | | ug/L |
| Ag | 107 | 59.001 | 8.5 | 60.668 | -0.00029 | 0.000 | 111.6 | ug/L |
| Ag | 109 | 47.334 | 12.7 | 49.001 | -0.00028 | 0.000 | 143.1 | ug/L |
| Cd | 111 | 249.035 | 3.7 | 302.744 | -0.02011 | 0.004 | 17.6 | ug/L |
| Cd | 114 | 79.037 | 22.6 | 257.978 | -0.02732 | 0.003 | 9.6 | ug/L |
| In | 115 | 384726.148 | 1.1 | 368464.817 | | | | ug/L |
| Sb | 121 | 203.671 | 5.7 | 54.001 | 0.01492 | 0.001 | 8.3 | ug/L |
| Sb | 123 | 165.479 | 3.0 | 50.513 | 0.01495 | 0.000 | 3.0 | ug/L |
| Ba | 135 | 16834.159 | 2.1 | 123.002 | 6.06687 | 0.135 | 2.2 | ug/L |
| Ba | 137 | 29444.555 | 0.2 | 192.338 | 6.17832 | 0.094 | 1.5 | ug/L |
| Tb | 159 | 471442.559 | 1.3 | 460537.107 | | | | ug/L |
| Ho | 165 | 440051.083 | 1.2 | 440378.521 | | | | ug/L |
| Tl | 203 | 97.668 | 4.1 | 83.668 | 0.00170 | 0.001 | 33.6 | ug/L |
| Tl | 205 | 206.005 | 7.6 | 163.337 | 0.00232 | 0.001 | 33.5 | ug/L |
| Pb | 208 | 1232.714 | 3.5 | 1492.737 | -0.00987 | 0.002 | 17.8 | ug/L |

Sample ID: 950477D D.10

Report Date/Time: Friday, November 17, 2006 19:05:47

Page 1

516

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|-----------|
| | Pb | 206 | 331.677 | 4.4 | 397.348 | -0.00944 | 0.002 | 20.5 ug/L |
| | Pb | 207 | 276.674 | 8.0 | 320.010 | -0.00745 | 0.003 | 44.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 103.865 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 100.957 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 104.413 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 102.368 | | | |
| > [Ho | 165 | | 99.926 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477S D.10

Sample Date/Time: Friday, November 17, 2006 19:08:44

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950477S D.10.038

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 2660.785 | 1.7 | 84.001 | 2.02266 | 0.056 | 2.8 | ug/L |
| Al | 27 | 26902.007 | 4.2 | 6946.222 | 2.18982 | 0.157 | 7.1 | ug/L |
| > Sc | 45 | 443987.121 | 2.8 | 426236.083 | | | | ug/L |
| V | 51 | 43103.787 | 1.1 | 5344.504 | 2.11340 | 0.082 | 3.9 | ug/L |
| Cr | 52 | 50079.899 | 1.9 | 18378.762 | 2.00338 | 0.103 | 5.1 | ug/L |
| Cr | 53 | 4836.452 | 2.6 | 1484.814 | 1.70694 | 0.082 | 4.8 | ug/L |
| Mn | 55 | 630516.428 | 2.2 | 742.040 | 28.57500 | 1.148 | 4.0 | ug/L |
| Co | 59 | 38586.180 | 0.4 | 848.388 | 2.11563 | 0.039 | 1.9 | ug/L |
| Ni | 60 | 12043.155 | 2.9 | 167.670 | 2.93934 | 0.121 | 4.1 | ug/L |
| Ni | 62 | 1643.179 | 3.4 | 209.338 | 2.41179 | 0.043 | 1.8 | ug/L |
| Cu | 63 | 20364.391 | 1.2 | 570.693 | 2.11341 | 0.067 | 3.2 | ug/L |
| Cu | 65 | 9753.135 | 0.5 | 318.010 | 2.09330 | 0.053 | 2.5 | ug/L |
| Zn | 66 | 6785.163 | 1.9 | 2186.325 | 1.77800 | 0.021 | 1.2 | ug/L |
| Zn | 67 | 1388.129 | 0.8 | 469.352 | 2.03153 | 0.070 | 3.5 | ug/L |
| Zn | 68 | 5652.976 | 4.4 | 1708.532 | 2.11478 | 0.193 | 9.1 | ug/L |
| > Ge | 72 | 235882.643 | 1.9 | 235019.833 | | | | ug/L |
| As | 75 | 6888.917 | 2.9 | 174.004 | 2.23509 | 0.069 | 3.1 | ug/L |
| Se | 77 | 708.697 | 2.1 | 271.738 | 1.94705 | 0.069 | 3.5 | ug/L |
| Se | 78 | 18747.953 | 1.4 | 18294.754 | 0.55146 | 0.744 | 134.9 | mg/L |
| Se | 82 | 1178.083 | 2.3 | 514.483 | 2.14247 | 0.137 | 6.4 | ug/L |
| Kr | 83 | 547.357 | 2.8 | 509.687 | | | | mg/L |
| Y | 89 | 451688.064 | 2.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 14335.799 | 1.4 | 130.336 | 2.24416 | 0.038 | 1.7 | ug/L |
| Mo | 97 | 8724.993 | 5.0 | 59.667 | 2.26759 | 0.131 | 5.8 | ug/L |
| Mo | 98 | 22318.986 | 0.4 | 73.129 | 2.24592 | 0.068 | 3.0 | ug/L |
| Rh | 103 | 375086.857 | 3.9 | 377819.614 | | | | ug/L |
| Ag | 107 | 31766.080 | 0.2 | 60.668 | 2.09704 | 0.056 | 2.7 | ug/L |
| Ag | 109 | 29218.443 | 2.3 | 49.001 | 2.07770 | 0.060 | 2.9 | ug/L |
| Cd | 111 | 7162.516 | 1.5 | 302.744 | 2.05028 | 0.046 | 2.2 | ug/L |
| Cd | 114 | 14518.934 | 0.8 | 257.978 | 2.04080 | 0.060 | 2.9 | ug/L |
| > In | 115 | 385840.640 | 2.8 | 368464.817 | | | | ug/L |
| Sb | 121 | 20096.406 | 1.2 | 54.001 | 2.02509 | 0.077 | 3.8 | ug/L |
| Sb | 123 | 15393.556 | 0.9 | 50.513 | 2.03043 | 0.074 | 3.7 | ug/L |
| Ba | 135 | 22601.179 | 2.5 | 123.002 | 8.21942 | 0.208 | 2.5 | ug/L |
| Ba | 137 | 39383.571 | 0.3 | 192.338 | 8.33675 | 0.039 | 0.5 | ug/L |
| > Tb | 159 | 468071.989 | 0.2 | 460537.107 | | | | ug/L |
| > Ho | 165 | 443365.468 | 0.3 | 440378.521 | | | | ug/L |
| Tl | 203 | 17645.841 | 1.3 | 83.668 | 2.10877 | 0.033 | 1.6 | ug/L |
| Tl | 205 | 41193.314 | 1.1 | 163.337 | 2.21088 | 0.019 | 0.9 | ug/L |
| Pb | 208 | 56393.411 | 0.4 | 1492.737 | 2.07727 | 0.004 | 0.2 | ug/L |

Sample ID: 950477S D.10

Report Date/Time: Friday, November 17, 2006 19:11:46

Page 1

519

| | | | | | | | | |
|--|----|-----|-----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 14332.127 | 1.8 | 397.348 | 1.99524 | 0.042 | 2.1 ug/L |
| | Pb | 207 | 12265.142 | 0.5 | 320.010 | 2.04280 | 0.004 | 0.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 104.165 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 100.367 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 104.716 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 101.636 | | | |
| > [Ho | 165 | | 100.678 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477A D.10

Sample Date/Time: Friday, November 17, 2006 19:14:43

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950477A D.10.039

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 26188.370 | 2.9 | 84.001 | 20.58403 | 0.415 | 2.0 | ug/L |
| Al | 27 | 204880.374 | 2.9 | 6946.222 | 22.07502 | 0.460 | 2.1 | ug/L |
| Sc | 45 | 442318.651 | 1.8 | 426236.083 | | | | ug/L |
| V | 51 | 375020.251 | 2.2 | 5344.504 | 20.86666 | 0.305 | 1.5 | ug/L |
| Cr | 52 | 323305.919 | 1.4 | 18378.762 | 19.76276 | 0.236 | 1.2 | ug/L |
| Cr | 53 | 38851.485 | 3.5 | 1484.814 | 19.43276 | 1.055 | 5.4 | ug/L |
| Mn | 55 | 1016494.530 | 0.1 | 742.040 | 45.46280 | 0.357 | 0.8 | ug/L |
| Co | 59 | 374155.306 | 1.7 | 848.388 | 20.65006 | 0.345 | 1.7 | ug/L |
| Ni | 60 | 85832.039 | 3.8 | 167.670 | 20.91665 | 0.765 | 3.7 | ug/L |
| Ni | 62 | 12242.109 | 1.4 | 209.338 | 19.98503 | 0.382 | 1.9 | ug/L |
| Cu | 63 | 195653.951 | 2.4 | 570.693 | 20.54757 | 0.343 | 1.7 | ug/L |
| Cu | 65 | 92060.703 | 1.5 | 318.010 | 20.08246 | 0.278 | 1.4 | ug/L |
| Zn | 66 | 54473.016 | 1.1 | 2186.325 | 19.97157 | 0.372 | 1.9 | ug/L |
| Zn | 67 | 9792.850 | 1.7 | 469.352 | 20.35647 | 0.208 | 1.0 | ug/L |
| Zn | 68 | 39874.620 | 2.8 | 1708.532 | 20.18659 | 0.541 | 2.7 | ug/L |
| Ge | 72 | 239016.421 | 0.8 | 235019.833 | | | | ug/L |
| As | 75 | 62403.786 | 1.8 | 174.004 | 20.43942 | 0.294 | 1.4 | ug/L |
| Se | 77 | 4788.242 | 0.9 | 271.738 | 19.88277 | 0.271 | 1.4 | ug/L |
| Se | 78 | 32100.059 | 1.8 | 18294.754 | 18.72131 | 0.457 | 2.4 | mg/L |
| Se | 82 | 6790.099 | 1.0 | 514.483 | 20.01153 | 0.174 | 0.9 | ug/L |
| Kr | 83 | 504.687 | 2.6 | 509.687 | | | | mg/L |
| Y | 89 | 451200.560 | 2.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 133131.104 | 1.3 | 130.336 | 21.06266 | 0.578 | 2.7 | ug/L |
| Mo | 97 | 80366.579 | 2.1 | 59.667 | 21.05248 | 0.078 | 0.4 | ug/L |
| Mo | 98 | 209205.574 | 1.5 | 73.129 | 21.15133 | 0.418 | 2.0 | ug/L |
| Rh | 103 | 370954.516 | 0.6 | 377819.614 | | | | ug/L |
| Ag | 107 | 307612.204 | 1.8 | 60.668 | 20.38411 | 0.757 | 3.7 | ug/L |
| Ag | 109 | 289772.287 | 0.6 | 49.001 | 20.67612 | 0.286 | 1.4 | ug/L |
| Cd | 111 | 67080.962 | 0.6 | 302.744 | 20.03432 | 0.367 | 1.8 | ug/L |
| Cd | 114 | 143705.612 | 1.2 | 257.978 | 20.57987 | 0.482 | 2.3 | ug/L |
| In | 115 | 385061.619 | 2.0 | 368464.817 | | | | ug/L |
| Sb | 121 | 199637.445 | 0.9 | 54.001 | 20.19884 | 0.319 | 1.6 | ug/L |
| Sb | 123 | 152631.217 | 1.3 | 50.513 | 20.22440 | 0.272 | 1.3 | ug/L |
| Ba | 135 | 73004.467 | 1.0 | 123.002 | 27.46380 | 0.429 | 1.6 | ug/L |
| Ba | 137 | 127089.004 | 3.2 | 192.338 | 27.81030 | 0.583 | 2.1 | ug/L |
| Tb | 159 | 454311.219 | 1.5 | 460537.107 | | | | ug/L |
| Ho | 165 | 439923.533 | 0.6 | 440378.521 | | | | ug/L |
| Tl | 203 | 171896.716 | 1.3 | 83.668 | 20.79226 | 0.281 | 1.4 | ug/L |
| Tl | 205 | 402034.389 | 0.7 | 163.337 | 21.82522 | 0.184 | 0.8 | ug/L |
| Pb | 208 | 547332.030 | 0.5 | 1492.737 | 20.81919 | 0.215 | 1.0 | ug/L |

Sample ID: 950477A D.10

Report Date/Time: Friday, November 17, 2006 19:17:45

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 142693.455 | 0.9 | 397.348 | 20.53834 | 0.287 | 1.4 ug/L |
| | Pb | 207 | 117192.591 | 1.6 | 320.010 | 20.14885 | 0.432 | 2.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 103.773 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 101.701 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.504 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.648 | | | |
| > Ho | 165 | | 99.897 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477L D.10

Sample Date/Time: Friday, November 17, 2006 19:20:42

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950477L D.10.040

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 50.001 | 10.0 | 84.001 | -0.02801 | 0.004 | 15.8 | ug/L |
| Al | 27 | 6229.727 | 4.7 | 6946.222 | -0.08693 | 0.025 | 28.8 | ug/L |
| > Sc | 45 | 428431.491 | 1.3 | 426236.083 | | | | ug/L |
| V | 51 | 5617.171 | 0.8 | 5344.504 | 0.01434 | 0.006 | 38.6 | ug/L |
| Cr | 52 | 18262.171 | 0.2 | 18378.762 | -0.01405 | 0.013 | 94.8 | ug/L |
| Cr | 53 | 992.069 | 5.5 | 1484.814 | -0.26889 | 0.029 | 10.8 | ug/L |
| Mn | 55 | 122237.703 | 1.7 | 742.040 | 5.61683 | 0.074 | 1.3 | ug/L |
| Co | 59 | 429.682 | 2.6 | 848.388 | -0.02318 | 0.001 | 3.1 | ug/L |
| Ni | 60 | 859.720 | 2.6 | 167.670 | 0.17518 | 0.005 | 2.8 | ug/L |
| Ni | 62 | 219.005 | 4.0 | 209.338 | 0.02211 | 0.015 | 68.8 | ug/L |
| Cu | 63 | 596.694 | 1.6 | 570.693 | 0.00379 | 0.001 | 32.2 | ug/L |
| Cu | 65 | 395.680 | 9.0 | 318.010 | 0.01867 | 0.008 | 43.1 | ug/L |
| Zn | 66 | 1708.192 | 4.1 | 2186.325 | -0.17550 | 0.027 | 15.4 | ug/L |
| Zn | 67 | 390.346 | 2.3 | 469.352 | -0.16201 | 0.023 | 14.2 | ug/L |
| Zn | 68 | 1363.792 | 3.9 | 1708.532 | -0.17420 | 0.026 | 15.0 | ug/L |
| > Ge | 72 | 231410.025 | 0.4 | 235019.833 | | | | ug/L |
| As | 75 | 281.674 | 1.7 | 174.004 | 0.03743 | 0.001 | 3.3 | ug/L |
| Se | 77 | 240.137 | 1.9 | 271.738 | -0.12486 | 0.018 | 14.2 | ug/L |
| Se | 78 | 17083.423 | 1.1 | 18294.754 | -1.33276 | 0.312 | 23.4 | mg/L |
| Se | 82 | 512.749 | 2.4 | 514.483 | 0.02029 | 0.036 | 176.0 | ug/L |
| Kr | 83 | 512.354 | 5.8 | 509.687 | | | | mg/L |
| Y | 89 | 440982.748 | 4.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 339.344 | 1.5 | 130.336 | 0.03389 | 0.001 | 2.5 | ug/L |
| Mo | 97 | 215.005 | 11.8 | 59.667 | 0.04183 | 0.007 | 16.5 | ug/L |
| Mo | 98 | 432.921 | 9.9 | 73.129 | 0.03746 | 0.005 | 12.1 | ug/L |
| Rh | 103 | 387526.498 | 0.6 | 377819.614 | | | | ug/L |
| Ag | 107 | 83.668 | 11.1 | 60.668 | 0.00152 | 0.001 | 42.1 | ug/L |
| Ag | 109 | 64.001 | 0.0 | 49.001 | 0.00106 | 0.000 | 0.4 | ug/L |
| Cd | 111 | 218.652 | 4.6 | 302.744 | -0.02721 | 0.003 | 11.4 | ug/L |
| Cd | 114 | 51.341 | 56.2 | 257.978 | -0.03107 | 0.004 | 13.8 | ug/L |
| > In | 115 | 373078.525 | 0.1 | 368464.817 | | | | ug/L |
| Sb | 121 | 509.354 | 11.2 | 54.001 | 0.04749 | 0.006 | 12.6 | ug/L |
| Sb | 123 | 389.622 | 14.2 | 50.513 | 0.04630 | 0.008 | 16.4 | ug/L |
| Ba | 135 | 3501.771 | 3.8 | 123.002 | 1.25903 | 0.037 | 3.0 | ug/L |
| Ba | 137 | 6086.617 | 2.4 | 192.338 | 1.27805 | 0.038 | 2.9 | ug/L |
| > Tb | 159 | 459364.009 | 1.8 | 460537.107 | | | | ug/L |
| > Ho | 165 | 437911.517 | 1.1 | 440378.521 | | | | ug/L |
| Tl | 203 | 72.334 | 17.6 | 83.668 | -0.00133 | 0.001 | 108.2 | ug/L |
| Tl | 205 | 140.669 | 14.6 | 163.337 | -0.00119 | 0.001 | 88.7 | ug/L |
| Pb | 208 | 562.346 | 3.0 | 1492.737 | -0.03533 | 0.000 | 1.2 | ug/L |

Sample ID: 950477L D.10

Report Date/Time: Friday, November 17, 2006 19:23:45

Page 1

525

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|----------|
| | Pb | 206 | 156.670 | 4.3 | 397.348 | -0.03457 | 0.001 | 2.7 ug/L |
| | Pb | 207 | 128.002 | 7.2 | 320.010 | -0.03295 | 0.001 | 4.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 100.515 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 98.464 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 101.252 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.745 | | | |
| > Ho | 165 | | 99.440 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477

Sample Date/Time: Friday, November 17, 2006 19:26:41

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950477.041

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 66.668 | 6.2 | 84.001 | -0.02427 | 0.003 | 13.9 | ug/L |
| Al | 27 | 34933.765 | 1.7 | 6946.222 | 2.49425 | 0.101 | 4.0 | ug/L |
| > Sc | 45 | 523187.664 | 1.4 | 426236.083 | | | | ug/L |
| V | 51 | 9991.110 | 4.1 | 5344.504 | 0.16389 | 0.021 | 12.9 | ug/L |
| Cr | 52 | 28320.736 | 4.9 | 18378.762 | 0.31649 | 0.077 | 24.3 | ug/L |
| Cr | 53 | 2363.359 | 2.7 | 1484.814 | 0.23837 | 0.042 | 17.8 | ug/L |
| Mn | 55 | 6978187.371 | 0.9 | 742.040 | 287.34335 | 0.630 | 0.2 | ug/L |
| Co | 59 | 12908.124 | 2.8 | 848.388 | 0.60923 | 0.013 | 2.2 | ug/L |
| Ni | 60 | 39965.502 | 5.1 | 167.670 | 8.94137 | 0.545 | 6.1 | ug/L |
| Ni | 62 | 3201.647 | 1.6 | 209.338 | 4.54082 | 0.111 | 2.4 | ug/L |
| Cu | 63 | 7857.116 | 2.8 | 570.693 | 0.70061 | 0.029 | 4.1 | ug/L |
| Cu | 65 | 4287.146 | 3.1 | 318.010 | 0.79296 | 0.035 | 4.4 | ug/L |
| Zn | 66 | 27134.069 | 3.1 | 2186.325 | 8.69151 | 0.222 | 2.6 | ug/L |
| Zn | 67 | 5626.622 | 1.2 | 469.352 | 10.27222 | 0.237 | 2.3 | ug/L |
| Zn | 68 | 25623.256 | 0.4 | 1708.532 | 11.56066 | 0.076 | 0.7 | ug/L |
| > Ge | 72 | 259763.645 | 1.0 | 235019.833 | | | | ug/L |
| As | 75 | 7525.139 | 1.6 | 174.004 | 2.21663 | 0.058 | 2.6 | ug/L |
| Se | 77 | 469.947 | 1.2 | 271.738 | 0.68793 | 0.041 | 6.0 | ug/L |
| Se | 78 | 19601.474 | 0.2 | 18294.754 | -0.78904 | 0.270 | 34.2 | mg/L |
| Se | 82 | 818.507 | 1.0 | 514.483 | 0.73418 | 0.021 | 2.9 | ug/L |
| Kr | 83 | 584.026 | 5.3 | 509.687 | | | | mg/L |
| Y | 89 | 526189.062 | 1.1 | 424645.807 | | | | ug/L |
| Mo | 95 | 10583.161 | 3.5 | 130.336 | 1.57572 | 0.048 | 3.1 | ug/L |
| Mo | 97 | 6576.327 | 1.8 | 59.667 | 1.62728 | 0.020 | 1.2 | ug/L |
| Mo | 98 | 17085.251 | 1.4 | 73.129 | 1.63936 | 0.012 | 0.7 | ug/L |
| Rh | 103 | 404058.098 | 1.2 | 377819.614 | | | | ug/L |
| Ag | 107 | 87.335 | 11.5 | 60.668 | 0.00132 | 0.001 | 50.2 | ug/L |
| Ag | 109 | 54.334 | 19.7 | 49.001 | 0.00004 | 0.001 | 1805.6 | ug/L |
| Cd | 111 | 515.285 | 2.3 | 302.744 | 0.05251 | 0.005 | 10.3 | ug/L |
| Cd | 114 | 577.645 | 14.8 | 257.978 | 0.04041 | 0.013 | 31.3 | ug/L |
| > In | 115 | 403911.613 | 1.5 | 368464.817 | | | | ug/L |
| Sb | 121 | 858.386 | 7.7 | 54.001 | 0.07717 | 0.008 | 9.9 | ug/L |
| Sb | 123 | 634.936 | 9.8 | 50.513 | 0.07331 | 0.009 | 12.3 | ug/L |
| Ba | 135 | 174810.445 | 1.4 | 123.002 | 61.61438 | 1.185 | 1.9 | ug/L |
| Ba | 137 | 300109.855 | 2.1 | 192.338 | 61.53721 | 1.499 | 2.4 | ug/L |
| > Tb | 159 | 485317.791 | 0.6 | 460537.107 | | | | ug/L |
| > Ho | 165 | 453013.868 | 0.9 | 440378.521 | | | | ug/L |
| Tl | 203 | 430.682 | 5.2 | 83.668 | 0.04050 | 0.003 | 6.4 | ug/L |
| Tl | 205 | 995.403 | 1.1 | 163.337 | 0.04364 | 0.001 | 1.3 | ug/L |
| Pb | 208 | 9589.918 | 1.0 | 1492.737 | 0.29832 | 0.002 | 0.7 | ug/L |

Sample ID: 950477

Report Date/Time: Friday, November 17, 2006 19:29:43

Page 1

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 2423.377 | 1.5 | 397.348 | 0.28235 | 0.002 | 0.8 ug/L |
| | Pb | 207 | 2104.954 | 2.3 | 320.010 | 0.29728 | 0.008 | 2.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 122.746 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 110.528 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 109.620 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 105.381 | | | |
| > Ho | 165 | | 102.869 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477D

Sample Date/Time: Friday, November 17, 2006 19:32:39

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950477D.042

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 72.668 | 10.0 | 84.001 | -0.02216 | 0.005 | 23.2 | ug/L |
| Al | 27 | 35642.094 | 1.6 | 6946.222 | 2.42838 | 0.038 | 1.6 | ug/L |
| > Sc | 45 | 544516.263 | 1.1 | 426236.083 | | | | ug/L |
| V | 51 | 9709.900 | 5.2 | 5344.504 | 0.13243 | 0.028 | 21.4 | ug/L |
| Cr | 52 | 27864.146 | 3.0 | 18378.762 | 0.23181 | 0.060 | 25.9 | ug/L |
| Cr | 53 | 2403.704 | 2.2 | 1484.814 | 0.21436 | 0.023 | 10.7 | ug/L |
| Mn | 55 | 6716374.419 | 0.3 | 742.040 | 280.20696 | 2.854 | 1.0 | ug/L |
| Co | 59 | 12978.898 | 1.8 | 848.388 | 0.62162 | 0.015 | 2.4 | ug/L |
| Ni | 60 | 40361.307 | 3.2 | 167.670 | 9.14582 | 0.282 | 3.1 | ug/L |
| Ni | 62 | 3177.638 | 1.9 | 209.338 | 4.56754 | 0.099 | 2.2 | ug/L |
| Cu | 63 | 7936.857 | 1.1 | 570.693 | 0.71832 | 0.013 | 1.8 | ug/L |
| Cu | 65 | 4204.102 | 1.9 | 318.010 | 0.78715 | 0.015 | 2.0 | ug/L |
| Zn | 66 | 16958.079 | 2.2 | 2186.325 | 5.19262 | 0.151 | 2.9 | ug/L |
| Zn | 67 | 4257.797 | 2.0 | 469.352 | 7.63119 | 0.189 | 2.5 | ug/L |
| Zn | 68 | 18105.832 | 1.6 | 1708.532 | 8.01439 | 0.094 | 1.2 | ug/L |
| > Ge | 72 | 256394.167 | 0.7 | 235019.833 | | | | ug/L |
| As | 75 | 7643.581 | 1.9 | 174.004 | 2.28269 | 0.061 | 2.7 | ug/L |
| Se | 77 | 461.946 | 5.0 | 271.738 | 0.67963 | 0.089 | 13.0 | ug/L |
| Se | 78 | 19765.413 | 2.0 | 18294.754 | -0.24781 | 0.621 | 250.7 | mg/L |
| Se | 82 | 816.040 | 1.8 | 514.483 | 0.75856 | 0.054 | 7.1 | ug/L |
| Kr | 83 | 599.028 | 4.8 | 509.687 | | | | mg/L |
| Y | 89 | 515998.897 | 1.7 | 424645.807 | | | | ug/L |
| Mo | 95 | 10909.581 | 2.0 | 130.336 | 1.58664 | 0.036 | 2.2 | ug/L |
| Mo | 97 | 6514.611 | 1.2 | 59.667 | 1.57392 | 0.031 | 1.9 | ug/L |
| Mo | 98 | 16590.890 | 1.1 | 73.129 | 1.55464 | 0.043 | 2.8 | ug/L |
| Rh | 103 | 402754.681 | 1.8 | 377819.614 | | | | ug/L |
| Ag | 107 | 72.001 | 12.1 | 60.668 | 0.00024 | 0.000 | 196.4 | ug/L |
| Ag | 109 | 56.001 | 18.6 | 49.001 | 0.00006 | 0.001 | 1095.1 | ug/L |
| Cd | 111 | 494.576 | 7.6 | 302.744 | 0.04334 | 0.012 | 28.3 | ug/L |
| Cd | 114 | 608.972 | 2.0 | 257.978 | 0.04270 | 0.004 | 8.8 | ug/L |
| > In | 115 | 413663.830 | 2.6 | 368464.817 | | | | ug/L |
| Sb | 121 | 664.366 | 2.2 | 54.001 | 0.05691 | 0.003 | 4.8 | ug/L |
| Sb | 123 | 539.595 | 0.6 | 50.513 | 0.05961 | 0.002 | 3.3 | ug/L |
| Ba | 135 | 173926.803 | 3.1 | 123.002 | 62.51108 | 2.176 | 3.5 | ug/L |
| Ba | 137 | 306640.224 | 0.6 | 192.338 | 64.11284 | 0.551 | 0.9 | ug/L |
| > Tb | 159 | 475954.847 | 0.6 | 460537.107 | | | | ug/L |
| > Ho | 165 | 460005.926 | 0.8 | 440378.521 | | | | ug/L |
| Tl | 203 | 405.347 | 2.0 | 83.668 | 0.03679 | 0.001 | 1.7 | ug/L |
| Tl | 205 | 998.070 | 3.5 | 163.337 | 0.04299 | 0.002 | 5.2 | ug/L |
| Pb | 208 | 9469.528 | 0.2 | 1492.737 | 0.28854 | 0.002 | 0.8 | ug/L |

Sample ID: 950477D

Report Date/Time: Friday, November 17, 2006 19:35:41

Page 1

531

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 2418.042 | 2.4 | 397.348 | 0.27645 | 0.007 | 2.4 ug/L |
| | Pb | 207 | 2061.609 | 2.4 | 320.010 | 0.28474 | 0.005 | 1.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 127.750 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 109.095 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 112.267 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 103.348 | | | |
| > [Ho | 165 | | 104.457 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477S

Sample Date/Time: Friday, November 17, 2006 19:38:37

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950477S.043

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 23783.463 | 0.7 | 84.001 | 15.52633 | 0.232 | 1.5 | ug/L |
| Al | 27 | 247064.111 | 1.3 | 6946.222 | 22.13591 | 0.427 | 1.9 | ug/L |
| Sc | 45 | 532046.770 | 1.1 | 426236.083 | | | | ug/L |
| V | 51 | 395709.338 | 1.6 | 5344.504 | 18.26755 | 0.379 | 2.1 | ug/L |
| Cr | 52 | 355254.030 | 1.1 | 18378.762 | 17.94721 | 0.390 | 2.2 | ug/L |
| Cr | 53 | 40856.006 | 1.9 | 1484.814 | 16.87871 | 0.355 | 2.1 | ug/L |
| Mn | 55 | 7419663.776 | 3.0 | 742.040 | 312.92481 | 11.913 | 3.8 | ug/L |
| Co | 59 | 406650.561 | 1.8 | 848.388 | 21.14877 | 0.419 | 2.0 | ug/L |
| Ni | 60 | 124455.746 | 2.5 | 167.670 | 28.60509 | 1.231 | 4.3 | ug/L |
| Ni | 62 | 15985.478 | 0.7 | 209.338 | 24.67021 | 0.376 | 1.5 | ug/L |
| Cu | 63 | 200405.493 | 0.7 | 570.693 | 19.83250 | 0.357 | 1.8 | ug/L |
| Cu | 65 | 99764.332 | 1.2 | 318.010 | 20.51064 | 0.497 | 2.4 | ug/L |
| Zn | 66 | 57243.843 | 0.2 | 2186.325 | 19.76770 | 0.374 | 1.9 | ug/L |
| Zn | 67 | 11102.841 | 3.1 | 469.352 | 21.83042 | 1.124 | 5.1 | ug/L |
| Zn | 68 | 48311.456 | 0.8 | 1708.532 | 23.18114 | 0.617 | 2.7 | ug/L |
| Ge | 72 | 253697.666 | 2.0 | 235019.833 | | | | ug/L |
| As | 75 | 68034.614 | 0.7 | 174.004 | 21.00019 | 0.323 | 1.5 | ug/L |
| Se | 77 | 4661.237 | 1.4 | 271.738 | 18.13946 | 0.527 | 2.9 | ug/L |
| Se | 78 | 32887.284 | 1.5 | 18294.754 | 17.19495 | 1.480 | 8.6 | mg/L |
| Se | 82 | 6620.963 | 1.2 | 514.483 | 18.25005 | 0.174 | 1.0 | ug/L |
| Kr | 83 | 576.359 | 3.8 | 509.687 | | | | mg/L |
| Y | 89 | 524533.659 | 3.2 | 424645.807 | | | | ug/L |
| Mo | 95 | 153155.272 | 1.4 | 130.336 | 23.18373 | 0.174 | 0.7 | ug/L |
| Mo | 97 | 97319.321 | 1.2 | 59.667 | 24.40324 | 0.466 | 1.9 | ug/L |
| Mo | 98 | 249887.654 | 3.6 | 73.129 | 24.18042 | 1.040 | 4.3 | ug/L |
| Rh | 103 | 406934.284 | 1.3 | 377819.614 | | | | ug/L |
| Ag | 107 | 311453.170 | 2.1 | 60.668 | 19.74315 | 0.443 | 2.2 | ug/L |
| Ag | 109 | 289259.665 | 1.3 | 49.001 | 19.74911 | 0.202 | 1.0 | ug/L |
| Cd | 111 | 67859.794 | 0.8 | 302.744 | 19.38901 | 0.120 | 0.6 | ug/L |
| Cd | 114 | 145300.047 | 1.5 | 257.978 | 19.90927 | 0.398 | 2.0 | ug/L |
| In | 115 | 402344.062 | 0.7 | 368464.817 | | | | ug/L |
| Sb | 121 | 202509.987 | 1.9 | 54.001 | 19.60711 | 0.464 | 2.4 | ug/L |
| Sb | 123 | 152703.140 | 2.2 | 50.513 | 19.36275 | 0.467 | 2.4 | ug/L |
| Ba | 135 | 226372.962 | 1.1 | 123.002 | 79.29709 | 0.495 | 0.6 | ug/L |
| Ba | 137 | 390249.358 | 1.0 | 192.338 | 79.52734 | 0.234 | 0.3 | ug/L |
| Tb | 159 | 488365.599 | 0.8 | 460537.107 | | | | ug/L |
| Ho | 165 | 456187.182 | 0.9 | 440378.521 | | | | ug/L |
| Tl | 203 | 174787.756 | 0.2 | 83.668 | 20.38906 | 0.211 | 1.0 | ug/L |
| Tl | 205 | 423675.689 | 1.3 | 163.337 | 22.18061 | 0.306 | 1.4 | ug/L |
| Pb | 208 | 558677.856 | 0.8 | 1492.737 | 20.49193 | 0.143 | 0.7 | ug/L |

Sample ID: 950477S

Report Date/Time: Friday, November 17, 2006 19:41:39

Page 1

534

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 141779.467 | 1.4 | 397.348 | 19.67554 | 0.146 | 0.7 ug/L |
| | Pb | 207 | 119643.328 | 1.0 | 320.010 | 19.83521 | 0.235 | 1.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 124.824 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 107.947 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 109.195 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 106.043 | | | |
| > Ho | 165 | | 103.590 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Friday, November 17, 2006 19:44:36

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 6.044

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 63741.163 | 0.9 | 84.001 | 49.56389 | 0.633 | 1.3 | ug/L |
| Al | 27 | 527199.020 | 0.8 | 6946.222 | 57.32647 | 0.705 | 1.2 | ug/L |
| Sc | 45 | 448060.201 | 1.9 | 426236.083 | | | | ug/L |
| V | 51 | 891228.825 | 1.5 | 5344.504 | 49.39578 | 1.680 | 3.4 | ug/L |
| Cr | 52 | 775745.883 | 1.0 | 18378.762 | 48.51607 | 1.157 | 2.4 | ug/L |
| Cr | 53 | 91048.640 | 1.2 | 1484.814 | 45.98840 | 0.524 | 1.1 | ug/L |
| Mn | 55 | 1091762.641 | 3.3 | 742.040 | 49.82514 | 1.989 | 4.0 | ug/L |
| Co | 59 | 884153.928 | 1.3 | 848.388 | 49.85765 | 1.250 | 2.5 | ug/L |
| Ni | 60 | 201682.048 | 0.4 | 167.670 | 50.20468 | 0.826 | 1.6 | ug/L |
| Ni | 62 | 29917.602 | 2.9 | 209.338 | 50.34698 | 1.243 | 2.5 | ug/L |
| Cu | 63 | 465237.528 | 2.6 | 570.693 | 49.93952 | 1.453 | 2.9 | ug/L |
| Cu | 65 | 231499.228 | 1.5 | 318.010 | 51.63791 | 1.328 | 2.6 | ug/L |
| Zn | 66 | 131841.095 | 2.4 | 2186.325 | 50.56509 | 1.616 | 3.2 | ug/L |
| Zn | 67 | 22173.348 | 0.3 | 469.352 | 48.39392 | 0.590 | 1.2 | ug/L |
| Zn | 68 | 97450.123 | 0.5 | 1708.532 | 51.70767 | 0.598 | 1.2 | ug/L |
| Ge | 72 | 234295.648 | 1.3 | 235019.833 | | | | ug/L |
| As | 75 | 145410.851 | 0.8 | 174.004 | 48.67597 | 1.001 | 2.1 | ug/L |
| Se | 77 | 11702.144 | 0.6 | 271.738 | 51.39320 | 0.798 | 1.6 | ug/L |
| Se | 78 | 53933.095 | 1.9 | 18294.754 | 50.52473 | 0.965 | 1.9 | mg/L |
| Se | 82 | 16380.550 | 0.3 | 514.483 | 51.69625 | 0.811 | 1.6 | ug/L |
| Kr | 83 | 499.353 | 7.0 | 509.687 | | | | mg/L |
| Y | 89 | 461175.003 | 4.9 | 424645.807 | | | | ug/L |
| Mo | 95 | 312467.376 | 2.3 | 130.336 | 49.34571 | 1.159 | 2.3 | ug/L |
| Mo | 97 | 200242.411 | 1.1 | 59.667 | 52.37558 | 1.057 | 2.0 | ug/L |
| Mo | 98 | 491387.374 | 2.4 | 73.129 | 49.58621 | 1.615 | 3.3 | ug/L |
| Rh | 103 | 401522.942 | 2.2 | 377819.614 | | | | ug/L |
| Ag | 107 | 765593.721 | 2.3 | 60.668 | 50.60125 | 0.398 | 0.8 | ug/L |
| Ag | 109 | 691002.111 | 1.5 | 49.001 | 49.19651 | 0.460 | 0.9 | ug/L |
| Cd | 111 | 174796.390 | 1.1 | 302.744 | 52.24010 | 1.013 | 1.9 | ug/L |
| Cd | 114 | 369268.716 | 1.9 | 257.978 | 52.81268 | 0.160 | 0.3 | ug/L |
| In | 115 | 385898.588 | 1.6 | 368464.817 | | | | ug/L |
| Sb | 121 | 490779.776 | 1.4 | 54.001 | 49.55078 | 0.611 | 1.2 | ug/L |
| Sb | 123 | 373019.866 | 1.7 | 50.513 | 49.32261 | 0.044 | 0.1 | ug/L |
| Ba | 135 | 137650.945 | 2.2 | 123.002 | 49.41235 | 0.985 | 2.0 | ug/L |
| Ba | 137 | 236564.777 | 1.2 | 192.338 | 49.40382 | 0.365 | 0.7 | ug/L |
| Tb | 159 | 476397.237 | 0.7 | 460537.107 | | | | ug/L |
| Ho | 165 | 445414.920 | 1.0 | 440378.521 | | | | ug/L |
| Tl | 203 | 426548.731 | 0.7 | 83.668 | 50.97339 | 0.153 | 0.3 | ug/L |
| Tl | 205 | 1007754.550 | 1.7 | 163.337 | 54.04342 | 0.431 | 0.8 | ug/L |
| Pb | 208 | 1360828.469 | 1.9 | 1492.737 | 51.20341 | 0.656 | 1.3 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Friday, November 17, 2006 19:47:38

Page 1

537

| | | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|-----|------|
| | Pb | 206 | 348102.720 | 1.4 | 397.348 | 49.56288 | 0.177 | 0.4 | ug/L |
| | Pb | 207 | 295970.197 | 1.1 | 320.010 | 50.33945 | 0.673 | 1.3 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 99.128 | | | | |
| Al | 27 | 114.653 | | | | |
| > Sc | 45 | | 105.120 | | | |
| V | 51 | 98.792 | | | | |
| Cr | 52 | 97.032 | | | | |
| Cr | 53 | 91.977 | | | | |
| Mn | 55 | 99.650 | | | | |
| Co | 59 | 99.715 | | | | |
| Ni | 60 | 100.409 | | | | |
| Ni | 62 | 100.694 | | | | |
| Cu | 63 | 99.879 | | | | |
| Cu | 65 | 103.276 | | | | |
| Zn | 66 | 101.130 | | | | |
| Zn | 67 | 96.788 | | | | |
| Zn | 68 | 103.415 | | | | |
| > Ge | 72 | | 99.692 | | | |
| As | 75 | 97.352 | | | | |
| Se | 77 | 102.786 | | | | |
| Se | 78 | 101.049 | | | | |
| Se | 82 | 103.393 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 98.691 | | | | |
| Mo | 97 | 104.751 | | | | |
| Mo | 98 | 99.172 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 101.202 | | | | |
| Ag | 109 | 98.393 | | | | |
| Cd | 111 | 104.480 | | | | |
| Cd | 114 | 105.625 | | | | |
| > In | 115 | | 104.731 | | | |
| Sb | 121 | 99.102 | | | | |
| Sb | 123 | 98.645 | | | | |
| Ba | 135 | 98.825 | | | | |
| Ba | 137 | 98.808 | | | | |
| > Tb | 159 | | 103.444 | | | |
| > Ho | 165 | | 101.144 | | | |
| Tl | 203 | 101.947 | | | | |
| Tl | 205 | 108.087 | | | | |
| Pb | 208 | 102.407 | | | | |
| Pb | 206 | 99.126 | | | | |
| Pb | 207 | 100.679 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Friday, November 17, 2006 19:50:34

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 7.045

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 52.001 | 11.7 | 84.001 | -0.02752 | 0.005 | 16.8 | ug/L |
| Al | 27 | 4093.380 | 2.2 | 6946.222 | -0.34520 | 0.017 | 4.8 | ug/L |
| > Sc | 45 | 439942.925 | 2.3 | 426236.083 | | | | ug/L |
| V | 51 | 5282.029 | 1.9 | 5344.504 | -0.01320 | 0.009 | 70.1 | ug/L |
| Cr | 52 | 17656.863 | 0.6 | 18378.762 | -0.08532 | 0.028 | 33.4 | ug/L |
| Cr | 53 | 949.397 | 1.4 | 1484.814 | -0.30512 | 0.004 | 1.4 | ug/L |
| Mn | 55 | 563.692 | 13.5 | 742.040 | -0.00753 | 0.004 | 47.3 | ug/L |
| Co | 59 | 246.339 | 8.2 | 848.388 | -0.03355 | 0.001 | 3.4 | ug/L |
| Ni | 60 | 149.336 | 10.3 | 167.670 | -0.00370 | 0.004 | 105.6 | ug/L |
| Ni | 62 | 157.670 | 9.1 | 209.338 | -0.08116 | 0.025 | 30.9 | ug/L |
| Cu | 63 | 248.340 | 6.3 | 570.693 | -0.03392 | 0.002 | 5.0 | ug/L |
| Cu | 65 | 213.338 | 3.5 | 318.010 | -0.02221 | 0.002 | 7.4 | ug/L |
| Zn | 66 | 1442.473 | 2.9 | 2186.325 | -0.27626 | 0.017 | 6.0 | ug/L |
| Zn | 67 | 304.342 | 5.5 | 469.352 | -0.35120 | 0.038 | 10.8 | ug/L |
| Zn | 68 | 1086.748 | 1.0 | 1708.532 | -0.32128 | 0.007 | 2.1 | ug/L |
| > Ge | 72 | 229742.780 | 0.1 | 235019.833 | | | | ug/L |
| As | 75 | 147.003 | 8.2 | 174.004 | -0.00789 | 0.004 | 52.7 | ug/L |
| Se | 77 | 248.204 | 2.3 | 271.738 | -0.07991 | 0.026 | 32.8 | ug/L |
| Se | 78 | 17052.773 | 2.6 | 18294.754 | -1.19933 | 0.670 | 55.9 | mg/L |
| Se | 82 | 517.416 | 3.9 | 514.483 | 0.04818 | 0.068 | 141.9 | ug/L |
| Kr | 83 | 488.019 | 3.6 | 509.687 | | | | mg/L |
| Y | 89 | 437192.289 | 1.2 | 424645.807 | | | | ug/L |
| Mo | 95 | 858.388 | 27.2 | 130.336 | 0.11293 | 0.039 | 34.1 | ug/L |
| Mo | 97 | 529.690 | 27.0 | 59.667 | 0.12110 | 0.039 | 32.4 | ug/L |
| Mo | 98 | 1290.872 | 26.0 | 73.129 | 0.12146 | 0.035 | 29.2 | ug/L |
| Rh | 103 | 378768.292 | 1.9 | 377819.614 | | | | ug/L |
| Ag | 107 | 163.337 | 8.2 | 60.668 | 0.00648 | 0.001 | 12.3 | ug/L |
| Ag | 109 | 137.336 | 12.5 | 49.001 | 0.00601 | 0.001 | 18.1 | ug/L |
| Cd | 111 | 247.841 | 3.1 | 302.744 | -0.02151 | 0.001 | 5.8 | ug/L |
| Cd | 114 | 69.267 | 22.5 | 257.978 | -0.02888 | 0.002 | 7.3 | ug/L |
| > In | 115 | 390006.317 | 1.6 | 368464.817 | | | | ug/L |
| Sb | 121 | 1169.762 | 15.7 | 54.001 | 0.11132 | 0.020 | 17.9 | ug/L |
| Sb | 123 | 910.541 | 15.3 | 50.513 | 0.11232 | 0.020 | 17.7 | ug/L |
| Ba | 135 | 47.667 | 8.7 | 123.002 | -0.02806 | 0.002 | 5.8 | ug/L |
| Ba | 137 | 66.001 | 9.9 | 192.338 | -0.02738 | 0.001 | 4.4 | ug/L |
| > Tb | 159 | 462290.831 | 1.4 | 460537.107 | | | | ug/L |
| > Ho | 165 | 453027.511 | 1.3 | 440378.521 | | | | ug/L |
| Tl | 203 | 78.668 | 8.7 | 83.668 | -0.00086 | 0.001 | 105.6 | ug/L |
| Tl | 205 | 159.670 | 10.3 | 163.337 | -0.00043 | 0.001 | 222.4 | ug/L |
| Pb | 208 | 461.343 | 4.4 | 1492.737 | -0.03978 | 0.001 | 2.3 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Friday, November 17, 2006 19:53:34

Page 1

540

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|----------|
| | Pb | 206 | 125.336 | 2.8 | 397.348 | -0.03972 | 0.001 | 1.4 ug/L |
| | Pb | 207 | 107.335 | 1.9 | 320.010 | -0.03714 | 0.000 | 1.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 103.216 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 97.755 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 105.846 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.381 | | | |
| > Ho | 165 | | 102.872 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477A

Sample Date/Time: Friday, November 17, 2006 19:56:31

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950477A.046

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 24596.163 | 1.6 | 84.001 | 16.47481 | 0.176 | 1.1 | ug/L |
| Al | 27 | 240006.195 | 1.8 | 6946.222 | 22.06006 | 0.679 | 3.1 | ug/L |
| Sc | 45 | 518692.686 | 2.3 | 426236.083 | | | | ug/L |
| V | 51 | 406398.920 | 1.3 | 5344.504 | 19.26174 | 0.190 | 1.0 | ug/L |
| Cr | 52 | 348360.856 | 1.8 | 18378.762 | 18.05836 | 0.180 | 1.0 | ug/L |
| Cr | 53 | 41071.712 | 0.8 | 1484.814 | 17.43324 | 0.324 | 1.9 | ug/L |
| Mn | 55 | 7176083.056 | 1.1 | 742.040 | 310.17205 | 4.071 | 1.3 | ug/L |
| Co | 59 | 421655.209 | 0.8 | 848.388 | 22.48300 | 0.466 | 2.1 | ug/L |
| Ni | 60 | 122350.183 | 3.4 | 167.670 | 28.81541 | 1.078 | 3.7 | ug/L |
| Ni | 62 | 15689.580 | 0.8 | 209.338 | 24.82211 | 0.462 | 1.9 | ug/L |
| Cu | 63 | 207355.309 | 1.1 | 570.693 | 21.03580 | 0.287 | 1.4 | ug/L |
| Cu | 65 | 97135.208 | 1.4 | 318.010 | 20.46552 | 0.179 | 0.9 | ug/L |
| Zn | 66 | 74671.290 | 2.7 | 2186.325 | 26.70932 | 0.362 | 1.4 | ug/L |
| Zn | 67 | 14052.980 | 0.5 | 469.352 | 28.62079 | 0.548 | 1.9 | ug/L |
| Zn | 68 | 58091.727 | 1.7 | 1708.532 | 28.77641 | 0.110 | 0.4 | ug/L |
| Ge | 72 | 247489.158 | 1.4 | 235019.833 | | | | ug/L |
| As | 75 | 67528.562 | 1.7 | 174.004 | 21.36307 | 0.076 | 0.4 | ug/L |
| Se | 77 | 4605.673 | 2.2 | 271.738 | 18.38229 | 0.324 | 1.8 | ug/L |
| Se | 78 | 32585.794 | 1.2 | 18294.754 | 17.86009 | 1.135 | 6.4 | mg/L |
| Se | 82 | 6683.546 | 0.5 | 514.483 | 18.94331 | 0.323 | 1.7 | ug/L |
| Kr | 83 | 564.358 | 7.0 | 509.687 | | | | mg/L |
| Y | 89 | 509996.014 | 1.7 | 424645.807 | | | | ug/L |
| Mo | 95 | 161524.682 | 2.6 | 130.336 | 24.72542 | 0.429 | 1.7 | ug/L |
| Mo | 97 | 96990.507 | 1.1 | 59.667 | 24.59363 | 0.347 | 1.4 | ug/L |
| Mo | 98 | 255467.479 | 2.2 | 73.129 | 25.00025 | 0.849 | 3.4 | ug/L |
| Rh | 103 | 384322.599 | 0.2 | 377819.614 | | | | ug/L |
| Ag | 107 | 313969.476 | 1.1 | 60.668 | 20.12923 | 0.460 | 2.3 | ug/L |
| Ag | 109 | 294230.827 | 0.5 | 49.001 | 20.31693 | 0.337 | 1.7 | ug/L |
| Cd | 111 | 67064.475 | 2.6 | 302.744 | 19.37716 | 0.480 | 2.5 | ug/L |
| Cd | 114 | 144577.391 | 1.6 | 257.978 | 20.03925 | 0.719 | 3.6 | ug/L |
| In | 115 | 397917.166 | 2.1 | 368464.817 | | | | ug/L |
| Sb | 121 | 207260.315 | 1.0 | 54.001 | 20.29757 | 0.628 | 3.1 | ug/L |
| Sb | 123 | 156523.004 | 1.1 | 50.513 | 20.07137 | 0.346 | 1.7 | ug/L |
| Ba | 135 | 229247.446 | 1.4 | 123.002 | 85.59202 | 0.750 | 0.9 | ug/L |
| Ba | 137 | 394536.642 | 0.6 | 192.338 | 85.70131 | 1.005 | 1.2 | ug/L |
| Tb | 159 | 458211.390 | 0.8 | 460537.107 | | | | ug/L |
| Ho | 165 | 448485.540 | 0.3 | 440378.521 | | | | ug/L |
| Tl | 203 | 174496.850 | 1.9 | 83.668 | 20.70293 | 0.345 | 1.7 | ug/L |
| Tl | 205 | 410388.181 | 1.0 | 163.337 | 21.85292 | 0.179 | 0.8 | ug/L |
| Pb | 208 | 561375.079 | 0.6 | 1492.737 | 20.94525 | 0.120 | 0.6 | ug/L |

Sample ID: 950477A

Report Date/Time: Friday, November 17, 2006 19:59:32

Page 1

543

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 145928.158 | 1.1 | 397.348 | 20.60247 | 0.271 | 1.3 ug/L |
| | Pb | 207 | 119722.761 | 0.7 | 320.010 | 20.18947 | 0.151 | 0.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 121.691 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 105.306 | | | |
| > [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 107.993 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 99.495 | | | |
| > [Ho | 165 | | 101.841 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477L

Sample Date/Time: Friday, November 17, 2006 20:02:29

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\950477L.047

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 64.334 | 10.1 | 84.001 | -0.01998 | 0.005 | 24.7 | ug/L |
| Al | 27 | 96863.055 | 1.3 | 6946.222 | 9.59701 | 0.323 | 3.4 | ug/L |
| > Sc | 45 | 460161.258 | 1.8 | 426236.083 | | | | ug/L |
| V | 51 | 6057.508 | 1.1 | 5344.504 | 0.01570 | 0.008 | 49.2 | ug/L |
| Cr | 52 | 19719.837 | 1.2 | 18378.762 | -0.00736 | 0.025 | 339.6 | ug/L |
| Cr | 53 | 1315.117 | 2.3 | 1484.814 | -0.14372 | 0.027 | 18.5 | ug/L |
| Mn | 55 | 1180253.313 | 0.3 | 742.040 | 52.82038 | 1.947 | 3.7 | ug/L |
| Co | 59 | 2514.071 | 1.7 | 848.388 | 0.09139 | 0.004 | 4.6 | ug/L |
| Ni | 60 | 7363.993 | 2.0 | 167.670 | 1.75690 | 0.046 | 2.6 | ug/L |
| Ni | 62 | 737.373 | 4.5 | 209.338 | 0.87069 | 0.018 | 2.1 | ug/L |
| Cu | 63 | 1719.195 | 2.6 | 570.693 | 0.12011 | 0.009 | 7.9 | ug/L |
| Cu | 65 | 1108.752 | 2.4 | 318.010 | 0.17215 | 0.014 | 7.9 | ug/L |
| Zn | 66 | 6455.899 | 2.7 | 2186.325 | 1.61751 | 0.034 | 2.1 | ug/L |
| Zn | 67 | 1311.783 | 1.0 | 469.352 | 1.82533 | 0.115 | 6.3 | ug/L |
| Zn | 68 | 5774.391 | 1.2 | 1708.532 | 2.13862 | 0.120 | 5.6 | ug/L |
| > Ge | 72 | 239101.131 | 3.8 | 235019.833 | | | | ug/L |
| As | 75 | 1543.492 | 1.9 | 174.004 | 0.44935 | 0.027 | 6.0 | ug/L |
| Se | 77 | 281.271 | 3.1 | 271.738 | 0.02331 | 0.084 | 360.7 | ug/L |
| Se | 78 | 17382.772 | 0.9 | 18294.754 | -1.68743 | 0.732 | 43.4 | mg/L |
| Se | 82 | 567.153 | 3.8 | 514.483 | 0.13960 | 0.007 | 5.2 | ug/L |
| Kr | 83 | 510.354 | 4.6 | 509.687 | | | | mg/L |
| Y | 89 | 461769.298 | 3.9 | 424645.807 | | | | ug/L |
| Mo | 95 | 2132.961 | 4.1 | 130.336 | 0.31216 | 0.012 | 3.7 | ug/L |
| Mo | 97 | 1343.455 | 3.7 | 59.667 | 0.33172 | 0.011 | 3.2 | ug/L |
| Mo | 98 | 3326.859 | 2.8 | 73.129 | 0.32475 | 0.007 | 2.3 | ug/L |
| Rh | 103 | 393847.770 | 2.2 | 377819.614 | | | | ug/L |
| Ag | 107 | 74.334 | 6.1 | 60.668 | 0.00067 | 0.000 | 49.6 | ug/L |
| Ag | 109 | 58.667 | 15.8 | 49.001 | 0.00049 | 0.001 | 139.5 | ug/L |
| Cd | 111 | 273.999 | 3.6 | 302.744 | -0.01365 | 0.004 | 25.7 | ug/L |
| Cd | 114 | 165.658 | 20.3 | 257.978 | -0.01521 | 0.005 | 30.2 | ug/L |
| > In | 115 | 389582.498 | 0.8 | 368464.817 | | | | ug/L |
| Sb | 121 | 533.356 | 7.6 | 54.001 | 0.04762 | 0.004 | 7.7 | ug/L |
| Sb | 123 | 419.993 | 9.5 | 50.513 | 0.04800 | 0.005 | 10.1 | ug/L |
| Ba | 135 | 34552.172 | 1.5 | 123.002 | 12.09585 | 0.160 | 1.3 | ug/L |
| Ba | 137 | 59427.417 | 1.0 | 192.338 | 12.10714 | 0.181 | 1.5 | ug/L |
| > Tb | 159 | 487118.373 | 0.8 | 460537.107 | | | | ug/L |
| > Ho | 165 | 456127.576 | 1.7 | 440378.521 | | | | ug/L |
| Tl | 203 | 140.336 | 3.2 | 83.668 | 0.00627 | 0.001 | 12.8 | ug/L |
| Tl | 205 | 286.008 | 10.9 | 163.337 | 0.00612 | 0.002 | 27.2 | ug/L |
| Pb | 208 | 2206.468 | 1.4 | 1492.737 | 0.02431 | 0.002 | 8.0 | ug/L |

Sample ID: 950477L

Report Date/Time: Friday, November 17, 2006 20:05:31

Page 1

546

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|-----------|
| | Pb | 206 | 585.693 | 3.0 | 397.348 | 0.02428 | 0.004 | 15.5 ug/L |
| | Pb | 207 | 475.685 | 5.5 | 320.010 | 0.02402 | 0.005 | 21.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 107.959 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 101.737 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 105.731 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 105.772 | | | |
| > Ho | 165 | | 103.576 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956 D.100

Sample Date/Time: Friday, November 17, 2006 20:08:27

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948956 D.100.048

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 47.334 | 11.6 | 84.001 | -0.03146 | 0.005 | 14.9 | ug/L |
| Al | 27 | 5181.996 | 1.2 | 6946.222 | -0.22721 | 0.018 | 8.1 | ug/L |
| > Sc | 45 | 443196.168 | 1.9 | 426236.083 | | | | ug/L |
| V | 51 | 5223.602 | 3.6 | 5344.504 | -0.01859 | 0.016 | 88.7 | ug/L |
| Cr | 52 | 17981.226 | 0.8 | 18378.762 | -0.07276 | 0.032 | 44.5 | ug/L |
| Cr | 53 | 966.066 | 5.2 | 1484.814 | -0.30038 | 0.017 | 5.6 | ug/L |
| Mn | 55 | 1368415.022 | 1.8 | 742.040 | 61.55263 | 2.127 | 3.5 | ug/L |
| Co | 59 | 2889.864 | 3.1 | 848.388 | 0.11294 | 0.003 | 2.6 | ug/L |
| Ni | 60 | 646.365 | 3.0 | 167.670 | 0.11711 | 0.008 | 6.8 | ug/L |
| Ni | 62 | 200.671 | 6.6 | 209.338 | -0.01863 | 0.021 | 111.1 | ug/L |
| Cu | 63 | 547.357 | 3.6 | 570.693 | -0.00314 | 0.003 | 101.0 | ug/L |
| Cu | 65 | 356.345 | 2.1 | 318.010 | 0.00764 | 0.003 | 35.1 | ug/L |
| Zn | 66 | 1118.420 | 6.0 | 2186.325 | -0.41969 | 0.034 | 8.2 | ug/L |
| Zn | 67 | 256.673 | 4.9 | 469.352 | -0.47895 | 0.036 | 7.5 | ug/L |
| Zn | 68 | 866.054 | 2.9 | 1708.532 | -0.45902 | 0.006 | 1.2 | ug/L |
| > Ge | 72 | 237798.153 | 2.1 | 235019.833 | | | | ug/L |
| As | 75 | 7411.703 | 1.8 | 174.004 | 2.38916 | 0.037 | 1.5 | ug/L |
| Se | 77 | 232.803 | 3.1 | 271.738 | -0.18680 | 0.013 | 7.0 | ug/L |
| Se | 78 | 16829.279 | 1.4 | 18294.754 | -2.33720 | 0.659 | 28.2 | mg/L |
| Se | 82 | 513.082 | 4.1 | 514.483 | -0.02258 | 0.101 | 447.9 | ug/L |
| Kr | 83 | 511.021 | 2.2 | 509.687 | | | | mg/L |
| Y | 89 | 453323.557 | 0.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 1907.904 | 2.6 | 130.336 | 0.27155 | 0.006 | 2.1 | ug/L |
| Mo | 97 | 1162.759 | 1.9 | 59.667 | 0.27951 | 0.007 | 2.5 | ug/L |
| Mo | 98 | 2942.157 | 2.8 | 73.129 | 0.28101 | 0.008 | 2.9 | ug/L |
| Rh | 103 | 386807.751 | 1.6 | 377819.614 | | | | ug/L |
| Ag | 107 | 63.668 | 14.6 | 60.668 | -0.00010 | 0.001 | 625.7 | ug/L |
| Ag | 109 | 55.667 | 25.6 | 49.001 | 0.00020 | 0.001 | 485.7 | ug/L |
| Cd | 111 | 234.835 | 5.9 | 302.744 | -0.02656 | 0.004 | 13.7 | ug/L |
| Cd | 114 | 48.105 | 26.7 | 257.978 | -0.03198 | 0.002 | 5.5 | ug/L |
| > In | 115 | 396782.771 | 1.0 | 368464.817 | | | | ug/L |
| Sb | 121 | 248.340 | 3.3 | 54.001 | 0.01868 | 0.001 | 4.5 | ug/L |
| Sb | 123 | 206.305 | 3.7 | 50.513 | 0.01955 | 0.001 | 6.3 | ug/L |
| Ba | 135 | 700.370 | 4.7 | 123.002 | 0.20636 | 0.013 | 6.1 | ug/L |
| Ba | 137 | 1227.103 | 1.5 | 192.338 | 0.21531 | 0.004 | 2.0 | ug/L |
| > Tb | 159 | 475640.083 | 0.3 | 460537.107 | | | | ug/L |
| > Ho | 165 | 456865.534 | 1.5 | 440378.521 | | | | ug/L |
| Tl | 203 | 71.001 | 9.8 | 83.668 | -0.00184 | 0.001 | 47.0 | ug/L |
| Tl | 205 | 130.336 | 5.8 | 163.337 | -0.00205 | 0.000 | 16.7 | ug/L |
| Pb | 208 | 693.351 | 3.4 | 1492.737 | -0.03140 | 0.001 | 4.0 | ug/L |

Sample ID: 948956 D.100

Report Date/Time: Friday, November 17, 2006 20:11:29

Page 1

549

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|----------|
| | Pb | 206 | 182.004 | 4.1 | 397.348 | -0.03198 | 0.001 | 4.3 ug/L |
| | Pb | 207 | 152.336 | 4.4 | 320.010 | -0.02981 | 0.001 | 5.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 103.979 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 101.182 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 107.685 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 103.279 | | | |
| > Ho | 165 | | 103.744 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| L Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956D D.100

Sample Date/Time: Friday, November 17, 2006 20:14:25

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948956D D.100.049

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 51.334 | 12.5 | 84.001 | -0.02756 | 0.005 | 18.6 | ug/L |
| Al | 27 | 5206.345 | 2.2 | 6946.222 | -0.21321 | 0.023 | 10.6 | ug/L |
| > Sc | 45 | 434767.092 | 1.9 | 426236.083 | | | | ug/L |
| V | 51 | 5201.409 | 4.3 | 5344.504 | -0.01420 | 0.017 | 119.7 | ug/L |
| Cr | 52 | 17578.029 | 0.8 | 18378.762 | -0.07684 | 0.030 | 39.3 | ug/L |
| Cr | 53 | 917.726 | 2.3 | 1484.814 | -0.31607 | 0.002 | 0.7 | ug/L |
| Mn | 55 | 1409099.803 | 0.8 | 742.040 | 64.84985 | 2.026 | 3.1 | ug/L |
| Co | 59 | 2977.228 | 3.0 | 848.388 | 0.12188 | 0.012 | 9.5 | ug/L |
| Ni | 60 | 688.035 | 2.2 | 167.670 | 0.13115 | 0.003 | 2.4 | ug/L |
| Ni | 62 | 198.004 | 7.6 | 209.338 | -0.01547 | 0.024 | 153.7 | ug/L |
| Cu | 63 | 569.692 | 2.4 | 570.693 | 0.00064 | 0.004 | 550.4 | ug/L |
| Cu | 65 | 319.676 | 5.2 | 318.010 | 0.00113 | 0.002 | 167.2 | ug/L |
| Zn | 66 | 1133.422 | 4.4 | 2186.325 | -0.40365 | 0.035 | 8.7 | ug/L |
| Zn | 67 | 241.673 | 4.2 | 469.352 | -0.49912 | 0.043 | 8.5 | ug/L |
| Zn | 68 | 896.391 | 6.2 | 1708.532 | -0.43137 | 0.038 | 8.8 | ug/L |
| > Ge | 72 | 232512.613 | 3.9 | 235019.833 | | | | ug/L |
| As | 75 | 7707.976 | 3.3 | 174.004 | 2.54888 | 0.176 | 6.9 | ug/L |
| Se | 77 | 232.737 | 2.0 | 271.738 | -0.16217 | 0.055 | 33.7 | ug/L |
| Se | 78 | 16668.054 | 0.5 | 18294.754 | -2.01499 | 1.025 | 50.9 | mg/L |
| Se | 82 | 501.348 | 1.6 | 514.483 | -0.02310 | 0.079 | 341.1 | ug/L |
| Kr | 83 | 496.686 | 2.7 | 509.687 | | | | mg/L |
| Y | 89 | 437850.527 | 0.6 | 424645.807 | | | | ug/L |
| Mo | 95 | 1933.244 | 3.9 | 130.336 | 0.28506 | 0.011 | 3.9 | ug/L |
| Mo | 97 | 1231.770 | 3.0 | 59.667 | 0.30721 | 0.011 | 3.5 | ug/L |
| Mo | 98 | 2982.060 | 3.2 | 73.129 | 0.29443 | 0.011 | 3.9 | ug/L |
| Rh | 103 | 394926.591 | 2.7 | 377819.614 | | | | ug/L |
| Ag | 107 | 54.334 | 12.9 | 60.668 | -0.00060 | 0.000 | 74.1 | ug/L |
| Ag | 109 | 51.001 | 7.1 | 49.001 | -0.00001 | 0.000 | 4215.9 | ug/L |
| Cd | 111 | 212.255 | 9.9 | 302.744 | -0.03114 | 0.006 | 19.2 | ug/L |
| Cd | 114 | 51.302 | 37.3 | 257.978 | -0.03130 | 0.003 | 8.8 | ug/L |
| > In | 115 | 384346.738 | 0.7 | 368464.817 | | | | ug/L |
| Sb | 121 | 213.338 | 0.7 | 54.001 | 0.01592 | 0.000 | 0.9 | ug/L |
| Sb | 123 | 171.733 | 5.5 | 50.513 | 0.01581 | 0.001 | 8.2 | ug/L |
| Ba | 135 | 731.373 | 2.5 | 123.002 | 0.21624 | 0.006 | 2.6 | ug/L |
| Ba | 137 | 1287.112 | 1.8 | 192.338 | 0.22662 | 0.005 | 2.4 | ug/L |
| > Tb | 159 | 477874.754 | 0.4 | 460537.107 | | | | ug/L |
| > Ho | 165 | 446549.201 | 1.4 | 440378.521 | | | | ug/L |
| Tl | 203 | 66.001 | 37.0 | 83.668 | -0.00227 | 0.003 | 123.8 | ug/L |
| Tl | 205 | 152.670 | 11.3 | 163.337 | -0.00070 | 0.001 | 118.1 | ug/L |
| Pb | 208 | 388.341 | 3.1 | 1492.737 | -0.04228 | 0.001 | 1.3 | ug/L |

Sample ID: 948956D D.100

Report Date/Time: Friday, November 17, 2006 20:17:27

Page 1

552

| | | | | | | | | |
|---|----|-----|---------|------|---------|----------|-------|----------|
| | Pb | 206 | 100.002 | 6.1 | 397.348 | -0.04306 | 0.001 | 2.4 ug/L |
| L | Pb | 207 | 95.335 | 10.2 | 320.010 | -0.03893 | 0.001 | 3.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 102.001 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 98.933 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.310 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 103.765 | | | |
| > Ho | 165 | | 101.401 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956S D.100

Sample Date/Time: Friday, November 17, 2006 20:20:23

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948956S D.100.050

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 296.342 | 4.8 | 84.001 | 0.17133 | 0.014 | 8.2 | ug/L |
| Al | 27 | 6472.578 | 0.9 | 6946.222 | -0.06272 | 0.011 | 17.3 | ug/L |
| > Sc | 45 | 430770.194 | 1.2 | 426236.083 | | | | ug/L |
| V | 51 | 8724.867 | 1.5 | 5344.504 | 0.19273 | 0.003 | 1.7 | ug/L |
| Cr | 52 | 20108.772 | 1.9 | 18378.762 | 0.10228 | 0.010 | 9.5 | ug/L |
| Cr | 53 | 1256.774 | 2.4 | 1484.814 | -0.13036 | 0.011 | 8.4 | ug/L |
| Mn | 55 | 1344429.740 | 0.9 | 742.040 | 64.20908 | 0.504 | 0.8 | ug/L |
| Co | 59 | 6655.391 | 2.9 | 848.388 | 0.34535 | 0.012 | 3.4 | ug/L |
| Ni | 60 | 1450.141 | 3.8 | 167.670 | 0.33641 | 0.014 | 4.2 | ug/L |
| Ni | 62 | 327.343 | 8.2 | 209.338 | 0.22691 | 0.047 | 20.9 | ug/L |
| Cu | 63 | 2472.391 | 1.6 | 570.693 | 0.21692 | 0.004 | 1.9 | ug/L |
| Cu | 65 | 1210.767 | 4.7 | 318.010 | 0.21218 | 0.013 | 6.2 | ug/L |
| Zn | 66 | 3671.179 | 1.8 | 2186.325 | 0.64823 | 0.026 | 4.0 | ug/L |
| Zn | 67 | 651.365 | 3.0 | 469.352 | 0.47661 | 0.046 | 9.6 | ug/L |
| Zn | 68 | 2725.806 | 1.7 | 1708.532 | 0.62073 | 0.028 | 4.5 | ug/L |
| > Ge | 72 | 223869.748 | 0.1 | 235019.833 | | | | ug/L |
| As | 75 | 8146.395 | 1.8 | 174.004 | 2.79879 | 0.052 | 1.8 | ug/L |
| Se | 77 | 270.471 | 0.3 | 271.738 | 0.05470 | 0.005 | 9.1 | ug/L |
| Se | 78 | 17141.363 | 1.0 | 18294.754 | -0.42285 | 0.240 | 56.8 | mg/L |
| Se | 82 | 570.953 | 1.1 | 514.483 | 0.27575 | 0.022 | 8.0 | ug/L |
| Kr | 83 | 485.352 | 4.9 | 509.687 | | | | mg/L |
| Y | 89 | 438674.450 | 2.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 3162.298 | 2.5 | 130.336 | 0.47247 | 0.011 | 2.4 | ug/L |
| Mo | 97 | 1911.572 | 4.3 | 59.667 | 0.47824 | 0.023 | 4.8 | ug/L |
| Mo | 98 | 4875.306 | 1.3 | 73.129 | 0.47875 | 0.004 | 0.9 | ug/L |
| Rh | 103 | 377987.898 | 3.7 | 377819.614 | | | | ug/L |
| Ag | 107 | 3356.044 | 4.7 | 60.668 | 0.21523 | 0.011 | 5.3 | ug/L |
| Ag | 109 | 3094.939 | 2.3 | 49.001 | 0.21428 | 0.006 | 2.6 | ug/L |
| Cd | 111 | 937.484 | 5.0 | 302.744 | 0.18260 | 0.013 | 7.0 | ug/L |
| Cd | 114 | 1523.155 | 2.6 | 257.978 | 0.17694 | 0.006 | 3.5 | ug/L |
| > In | 115 | 390207.343 | 0.5 | 368464.817 | | | | ug/L |
| Sb | 121 | 2170.304 | 0.3 | 54.001 | 0.21100 | 0.001 | 0.6 | ug/L |
| Sb | 123 | 1694.089 | 2.9 | 50.513 | 0.21459 | 0.008 | 3.5 | ug/L |
| Ba | 135 | 1317.784 | 3.4 | 123.002 | 0.42812 | 0.012 | 2.9 | ug/L |
| Ba | 137 | 2340.686 | 3.6 | 192.338 | 0.44795 | 0.009 | 2.1 | ug/L |
| > Tb | 159 | 476096.727 | 2.9 | 460537.107 | | | | ug/L |
| > Ho | 165 | 451366.333 | 0.2 | 440378.521 | | | | ug/L |
| Tl | 203 | 1932.243 | 3.1 | 83.668 | 0.21778 | 0.007 | 3.0 | ug/L |
| Tl | 205 | 4484.585 | 1.5 | 163.337 | 0.22852 | 0.004 | 1.7 | ug/L |
| Pb | 208 | 6143.619 | 1.2 | 1492.737 | 0.17150 | 0.003 | 1.5 | ug/L |

Sample ID: 948956S D.100

Report Date/Time: Friday, November 17, 2006 20:23:25

Page 1

555

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 1544.492 | 0.8 | 397.348 | 0.15997 | 0.001 | 0.9 ug/L |
| | Pb | 207 | 1329.453 | 3.4 | 320.010 | 0.16825 | 0.007 | 4.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 101.064 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 95.256 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 105.901 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 103.379 | | | |
| > Ho | 165 | | 102.495 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956A D.100

Sample Date/Time: Friday, November 17, 2006 20:26:22

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948956A D.100.051

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 25703.171 | 1.1 | 84.001 | 20.34016 | 0.143 | 0.7 | ug/L |
| Al | 27 | 207375.611 | 1.4 | 6946.222 | 22.51803 | 0.692 | 3.1 | ug/L |
| > Sc | 45 | 439361.632 | 1.7 | 426236.083 | | | | ug/L |
| V | 51 | 360958.600 | 1.6 | 5344.504 | 20.21269 | 0.424 | 2.1 | ug/L |
| Cr | 52 | 321037.708 | 1.1 | 18378.762 | 19.75959 | 0.525 | 2.7 | ug/L |
| Cr | 53 | 37826.393 | 2.2 | 1484.814 | 19.02040 | 0.318 | 1.7 | ug/L |
| Mn | 55 | 1703015.247 | 1.1 | 742.040 | 79.52835 | 2.119 | 2.7 | ug/L |
| Co | 59 | 366397.254 | 0.9 | 848.388 | 21.10865 | 0.522 | 2.5 | ug/L |
| Ni | 60 | 80498.422 | 1.0 | 167.670 | 20.47240 | 0.208 | 1.0 | ug/L |
| Ni | 62 | 12044.152 | 1.4 | 209.338 | 20.52716 | 0.236 | 1.1 | ug/L |
| Cu | 63 | 189713.977 | 3.0 | 570.693 | 20.79457 | 0.582 | 2.8 | ug/L |
| Cu | 65 | 89972.708 | 1.2 | 318.010 | 20.48838 | 0.554 | 2.7 | ug/L |
| Zn | 66 | 51797.012 | 1.3 | 2186.325 | 19.81258 | 0.428 | 2.2 | ug/L |
| Zn | 67 | 8678.279 | 5.5 | 469.352 | 18.75145 | 1.142 | 6.1 | ug/L |
| Zn | 68 | 37094.421 | 1.2 | 1708.532 | 19.57602 | 0.535 | 2.7 | ug/L |
| > Ge | 72 | 229048.366 | 1.8 | 235019.833 | | | | ug/L |
| As | 75 | 64540.290 | 1.0 | 174.004 | 22.06808 | 0.391 | 1.8 | ug/L |
| Se | 77 | 4752.355 | 1.3 | 271.738 | 20.64232 | 0.637 | 3.1 | ug/L |
| Se | 78 | 30785.411 | 0.9 | 18294.754 | 18.77315 | 1.221 | 6.5 | mg/L |
| Se | 82 | 6757.539 | 1.6 | 514.483 | 20.84836 | 0.298 | 1.4 | ug/L |
| Kr | 83 | 483.019 | 3.6 | 509.687 | | | | mg/L |
| Y | 89 | 439186.364 | 0.4 | 424645.807 | | | | ug/L |
| Mo | 95 | 127237.343 | 1.1 | 130.336 | 20.19602 | 0.048 | 0.2 | ug/L |
| Mo | 97 | 79675.327 | 2.2 | 59.667 | 20.95066 | 0.602 | 2.9 | ug/L |
| Mo | 98 | 207182.295 | 0.7 | 73.129 | 21.02228 | 0.415 | 2.0 | ug/L |
| Rh | 103 | 369196.227 | 1.0 | 377819.614 | | | | ug/L |
| Ag | 107 | 307480.466 | 1.8 | 60.668 | 20.43857 | 0.114 | 0.6 | ug/L |
| Ag | 109 | 288776.230 | 3.0 | 49.001 | 20.67337 | 0.374 | 1.8 | ug/L |
| Cd | 111 | 67407.193 | 2.3 | 302.744 | 20.20137 | 0.425 | 2.1 | ug/L |
| Cd | 114 | 149547.695 | 2.6 | 257.978 | 21.49480 | 0.732 | 3.4 | ug/L |
| > In | 115 | 383671.935 | 1.3 | 368464.817 | | | | ug/L |
| Sb | 121 | 203066.776 | 2.6 | 54.001 | 20.62171 | 0.727 | 3.5 | ug/L |
| Sb | 123 | 150338.006 | 0.7 | 50.513 | 19.99101 | 0.137 | 0.7 | ug/L |
| Ba | 135 | 56838.857 | 2.9 | 123.002 | 20.96997 | 0.423 | 2.0 | ug/L |
| Ba | 137 | 96431.861 | 2.1 | 192.338 | 20.70080 | 0.248 | 1.2 | ug/L |
| > Tb | 159 | 462894.741 | 0.9 | 460537.107 | | | | ug/L |
| > Ho | 165 | 443341.035 | 2.8 | 440378.521 | | | | ug/L |
| Tl | 203 | 172691.248 | 1.4 | 83.668 | 20.73326 | 0.347 | 1.7 | ug/L |
| Tl | 205 | 414240.096 | 0.3 | 163.337 | 22.32608 | 0.623 | 2.8 | ug/L |
| Pb | 208 | 560956.091 | 1.4 | 1492.737 | 21.18731 | 0.787 | 3.7 | ug/L |

Sample ID: 948956A D.100

Report Date/Time: Friday, November 17, 2006 20:29:23

Page 1

558

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 145633.892 | 1.7 | 397.348 | 20.81138 | 0.713 | 3.4 ug/L |
| | Pb | 207 | 119585.823 | 0.8 | 320.010 | 20.41073 | 0.541 | 2.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 103.079 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 97.459 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.127 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.512 | | | |
| > Ho | 165 | | 100.673 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956L D.100

Sample Date/Time: Friday, November 17, 2006 20:32:20

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948956L D.100.052

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 52.001 | 8.8 | 84.001 | -0.02618 | 0.004 | 13.5 | ug/L |
| Al | 27 | 4509.932 | 2.0 | 6946.222 | -0.28212 | 0.004 | 1.5 | ug/L |
| > Sc | 45 | 426038.485 | 1.5 | 426236.083 | | | | ug/L |
| V | 51 | 4808.427 | 4.1 | 5344.504 | -0.03136 | 0.008 | 24.1 | ug/L |
| Cr | 52 | 16437.695 | 1.2 | 18378.762 | -0.13025 | 0.012 | 9.0 | ug/L |
| Cr | 53 | 873.054 | 2.8 | 1484.814 | -0.33008 | 0.018 | 5.5 | ug/L |
| Mn | 55 | 264029.628 | 1.8 | 742.040 | 12.51038 | 0.161 | 1.3 | ug/L |
| Co | 59 | 720.705 | 4.0 | 848.388 | -0.00540 | 0.002 | 36.7 | ug/L |
| Ni | 60 | 241.339 | 4.6 | 167.670 | 0.02094 | 0.003 | 16.3 | ug/L |
| Ni | 62 | 160.670 | 7.8 | 209.338 | -0.07036 | 0.021 | 30.5 | ug/L |
| Cu | 63 | 516.688 | 5.7 | 570.693 | -0.00337 | 0.003 | 85.7 | ug/L |
| Cu | 65 | 320.676 | 2.1 | 318.010 | 0.00373 | 0.002 | 51.6 | ug/L |
| Zn | 66 | 790.712 | 2.4 | 2186.325 | -0.52897 | 0.010 | 1.8 | ug/L |
| Zn | 67 | 215.338 | 3.5 | 469.352 | -0.54346 | 0.022 | 4.0 | ug/L |
| Zn | 68 | 634.697 | 3.3 | 1708.532 | -0.56303 | 0.015 | 2.6 | ug/L |
| > Ge | 72 | 225154.831 | 0.8 | 235019.833 | | | | ug/L |
| As | 75 | 1520.487 | 4.6 | 174.004 | 0.47198 | 0.021 | 4.5 | ug/L |
| Se | 77 | 229.070 | 5.5 | 271.738 | -0.14626 | 0.058 | 39.6 | ug/L |
| Se | 78 | 16447.737 | 0.4 | 18294.754 | -1.58854 | 0.191 | 12.0 | mg/L |
| Se | 82 | 493.815 | 3.1 | 514.483 | 0.00320 | 0.053 | 1647.9 | ug/L |
| Kr | 83 | 481.685 | 4.0 | 509.687 | | | | mg/L |
| Y | 89 | 430276.562 | 1.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 779.711 | 14.0 | 130.336 | 0.10070 | 0.018 | 17.5 | ug/L |
| Mo | 97 | 435.349 | 12.2 | 59.667 | 0.09669 | 0.014 | 14.8 | ug/L |
| Mo | 98 | 1118.176 | 8.4 | 73.129 | 0.10426 | 0.010 | 9.6 | ug/L |
| Rh | 103 | 367064.312 | 1.7 | 377819.614 | | | | ug/L |
| Ag | 107 | 75.001 | 23.1 | 60.668 | 0.00072 | 0.001 | 155.7 | ug/L |
| Ag | 109 | 69.668 | 13.3 | 49.001 | 0.00127 | 0.001 | 49.7 | ug/L |
| Cd | 111 | 247.574 | 17.2 | 302.744 | -0.02138 | 0.013 | 59.4 | ug/L |
| Cd | 114 | 37.895 | 9.7 | 257.978 | -0.03328 | 0.001 | 1.8 | ug/L |
| > In | 115 | 388933.939 | 1.6 | 368464.817 | | | | ug/L |
| Sb | 121 | 554.691 | 11.6 | 54.001 | 0.04985 | 0.006 | 12.8 | ug/L |
| Sb | 123 | 416.496 | 10.9 | 50.513 | 0.04764 | 0.006 | 12.1 | ug/L |
| Ba | 135 | 164.003 | 3.4 | 123.002 | 0.01526 | 0.002 | 12.2 | ug/L |
| Ba | 137 | 285.674 | 6.4 | 192.338 | 0.02023 | 0.004 | 21.4 | ug/L |
| > Tb | 159 | 460339.453 | 0.9 | 460537.107 | | | | ug/L |
| > Ho | 165 | 449664.650 | 1.0 | 440378.521 | | | | ug/L |
| Tl | 203 | 78.668 | 2.9 | 83.668 | -0.00080 | 0.000 | 38.1 | ug/L |
| Tl | 205 | 116.002 | 6.0 | 163.337 | -0.00270 | 0.000 | 14.7 | ug/L |
| Pb | 208 | 407.341 | 3.0 | 1492.737 | -0.04168 | 0.000 | 0.8 | ug/L |

Sample ID: 948956L D.100

Report Date/Time: Friday, November 17, 2006 20:35:22

Page 1

561

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|----------|
| | Pb | 206 | 107.002 | 5.2 | 397.348 | -0.04218 | 0.001 | 2.1 ug/L |
| | Pb | 207 | 90.335 | 16.0 | 320.010 | -0.03988 | 0.002 | 5.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 99.954 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 95.802 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 105.555 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.957 | | | |
| > Ho | 165 | | 102.109 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948957 D.100

Sample Date/Time: Friday, November 17, 2006 20:38:19

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948957 D.100.053

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 49.001 | 5.4 | 84.001 | -0.02971 | 0.002 | 6.7 | ug/L |
| Al | 27 | 3908.622 | 1.4 | 6946.222 | -0.36390 | 0.011 | 2.9 | ug/L |
| > Sc | 45 | 437861.657 | 2.7 | 426236.083 | | | | ug/L |
| V | 51 | 4757.848 | 2.0 | 5344.504 | -0.04175 | 0.003 | 7.0 | ug/L |
| Cr | 52 | 16241.644 | 1.7 | 18378.762 | -0.17292 | 0.011 | 6.4 | ug/L |
| Cr | 53 | 853.386 | 1.3 | 1484.814 | -0.35309 | 0.014 | 3.8 | ug/L |
| Mn | 55 | 1409798.352 | 0.7 | 742.040 | 66.90499 | 1.059 | 1.6 | ug/L |
| Co | 59 | 3081.267 | 3.2 | 848.388 | 0.13313 | 0.008 | 5.8 | ug/L |
| Ni | 60 | 688.702 | 4.9 | 167.670 | 0.13671 | 0.007 | 5.1 | ug/L |
| Ni | 62 | 210.671 | 8.8 | 209.338 | 0.01748 | 0.031 | 177.0 | ug/L |
| Cu | 63 | 1054.411 | 1.7 | 570.693 | 0.05669 | 0.002 | 3.6 | ug/L |
| Cu | 65 | 535.023 | 2.6 | 318.010 | 0.05343 | 0.002 | 3.6 | ug/L |
| Zn | 66 | 837.717 | 6.1 | 2186.325 | -0.51020 | 0.020 | 3.9 | ug/L |
| Zn | 67 | 228.339 | 3.4 | 469.352 | -0.51379 | 0.018 | 3.5 | ug/L |
| Zn | 68 | 697.036 | 3.0 | 1708.532 | -0.52826 | 0.016 | 3.0 | ug/L |
| > Ge | 72 | 225325.444 | 1.1 | 235019.833 | | | | ug/L |
| As | 75 | 6669.736 | 2.2 | 174.004 | 2.26630 | 0.074 | 3.2 | ug/L |
| Se | 77 | 223.403 | 1.2 | 271.738 | -0.17345 | 0.018 | 10.2 | ug/L |
| Se | 78 | 16357.923 | 0.8 | 18294.754 | -1.73712 | 0.422 | 24.3 | mg/L |
| Se | 82 | 481.614 | 1.4 | 514.483 | -0.03943 | 0.018 | 46.6 | ug/L |
| Kr | 83 | 480.685 | 0.7 | 509.687 | | | | mg/L |
| Y | 89 | 430237.533 | 1.7 | 424645.807 | | | | ug/L |
| Mo | 95 | 2006.595 | 0.6 | 130.336 | 0.29665 | 0.000 | 0.0 | ug/L |
| Mo | 97 | 1192.431 | 0.8 | 59.667 | 0.29680 | 0.004 | 1.4 | ug/L |
| Mo | 98 | 3196.515 | 4.1 | 73.129 | 0.31610 | 0.015 | 4.8 | ug/L |
| Rh | 103 | 371339.379 | 1.3 | 377819.614 | | | | ug/L |
| Ag | 107 | 65.001 | 15.4 | 60.668 | 0.00012 | 0.001 | 594.8 | ug/L |
| Ag | 109 | 49.001 | 19.5 | 49.001 | -0.00015 | 0.001 | 468.0 | ug/L |
| Cd | 111 | 223.088 | 2.9 | 302.744 | -0.02787 | 0.002 | 7.5 | ug/L |
| Cd | 114 | 56.704 | 11.0 | 257.978 | -0.03052 | 0.001 | 3.0 | ug/L |
| > In | 115 | 384425.736 | 0.6 | 368464.817 | | | | ug/L |
| Sb | 121 | 279.341 | 4.8 | 54.001 | 0.02261 | 0.001 | 6.6 | ug/L |
| Sb | 123 | 210.735 | 5.5 | 50.513 | 0.02097 | 0.001 | 6.5 | ug/L |
| Ba | 135 | 754.709 | 7.1 | 123.002 | 0.23203 | 0.019 | 8.3 | ug/L |
| Ba | 137 | 1218.768 | 1.4 | 192.338 | 0.21935 | 0.004 | 1.8 | ug/L |
| > Tb | 159 | 465093.322 | 0.4 | 460537.107 | | | | ug/L |
| > Ho | 165 | 448484.388 | 0.6 | 440378.521 | | | | ug/L |
| Tl | 203 | 73.668 | 14.6 | 83.668 | -0.00137 | 0.001 | 89.3 | ug/L |
| Tl | 205 | 155.670 | 3.8 | 163.337 | -0.00057 | 0.000 | 49.4 | ug/L |
| Pb | 208 | 321.339 | 0.8 | 1492.737 | -0.04485 | 0.000 | 0.4 | ug/L |

Sample ID: 948957 D.100

Report Date/Time: Friday, November 17, 2006 20:41:21

Page 1

| | | | | | | | | |
|--|----|-----|--------|------|---------|----------|-------|----------|
| | Pb | 206 | 84.001 | 13.7 | 397.348 | -0.04540 | 0.002 | 3.6 ug/L |
| | Pb | 207 | 77.668 | 7.3 | 320.010 | -0.04198 | 0.001 | 2.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 102.727 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 95.875 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.332 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.989 | | | |
| > Ho | 165 | | 101.841 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948958

Sample Date/Time: Friday, November 17, 2006 20:44:18

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948958.054

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 47.334 | 12.4 | 84.001 | -0.03427 | 0.004 | 11.6 | ug/L |
| Al | 27 | 28161.800 | 2.1 | 6946.222 | 2.10149 | 0.042 | 2.0 | ug/L |
| Sc | 45 | 478607.641 | 1.1 | 426236.083 | | | | ug/L |
| V | 51 | 6093.576 | 6.5 | 5344.504 | 0.00496 | 0.023 | 468.3 | ug/L |
| Cr | 52 | 26714.693 | 1.6 | 18378.762 | 0.36515 | 0.043 | 11.7 | ug/L |
| Cr | 53 | 1667.850 | 1.8 | 1484.814 | 0.00032 | 0.014 | 4525.3 | ug/L |
| Mn | 55 | 25394.898 | 1.9 | 742.040 | 1.07667 | 0.025 | 2.3 | ug/L |
| Co | 59 | 631.697 | 10.4 | 848.388 | -0.01360 | 0.003 | 24.9 | ug/L |
| Ni | 60 | 1403.799 | 0.6 | 167.670 | 0.29326 | 0.004 | 1.3 | ug/L |
| Ni | 62 | 324.676 | 8.3 | 209.338 | 0.17337 | 0.045 | 26.1 | ug/L |
| Cu | 63 | 5780.063 | 2.6 | 570.693 | 0.53369 | 0.014 | 2.7 | ug/L |
| Cu | 65 | 2742.145 | 1.3 | 318.010 | 0.51565 | 0.007 | 1.3 | ug/L |
| Zn | 66 | 8841.444 | 1.5 | 2186.325 | 2.45179 | 0.073 | 3.0 | ug/L |
| Zn | 67 | 1508.485 | 3.3 | 469.352 | 2.17684 | 0.074 | 3.4 | ug/L |
| Zn | 68 | 6508.606 | 1.7 | 1708.532 | 2.44600 | 0.048 | 2.0 | ug/L |
| Ge | 72 | 244661.584 | 1.0 | 235019.833 | | | | ug/L |
| As | 75 | 806.047 | 2.2 | 174.004 | 0.20058 | 0.008 | 4.1 | ug/L |
| Se | 77 | 268.871 | 1.7 | 271.738 | -0.06035 | 0.014 | 23.1 | ug/L |
| Se | 78 | 18767.088 | 2.8 | 18294.754 | -0.37736 | 0.646 | 171.2 | mg/L |
| Se | 82 | 517.549 | 2.3 | 514.483 | -0.05639 | 0.023 | 40.1 | ug/L |
| Kr | 83 | 522.688 | 3.8 | 509.687 | | | | mg/L |
| Y | 89 | 492780.336 | 3.4 | 424645.807 | | | | ug/L |
| Mo | 95 | 472.352 | 11.6 | 130.336 | 0.04690 | 0.010 | 20.5 | ug/L |
| Mo | 97 | 267.340 | 13.3 | 59.667 | 0.04780 | 0.010 | 20.2 | ug/L |
| Mo | 98 | 640.605 | 18.4 | 73.129 | 0.05165 | 0.012 | 24.2 | ug/L |
| Rh | 103 | 418211.734 | 1.3 | 377819.614 | | | | ug/L |
| Ag | 107 | 353.344 | 6.6 | 60.668 | 0.01717 | 0.001 | 5.1 | ug/L |
| Ag | 109 | 315.342 | 4.0 | 49.001 | 0.01691 | 0.001 | 6.4 | ug/L |
| Cd | 111 | 311.632 | 10.5 | 302.744 | -0.00963 | 0.007 | 68.7 | ug/L |
| Cd | 114 | 58.443 | 67.5 | 257.978 | -0.03109 | 0.005 | 15.9 | ug/L |
| In | 115 | 421512.295 | 2.8 | 368464.817 | | | | ug/L |
| Sb | 121 | 364.012 | 7.9 | 54.001 | 0.02800 | 0.004 | 12.8 | ug/L |
| Sb | 123 | 267.118 | 16.0 | 50.513 | 0.02535 | 0.005 | 20.0 | ug/L |
| Ba | 135 | 1674.852 | 3.5 | 123.002 | 0.53759 | 0.030 | 5.6 | ug/L |
| Ba | 137 | 2997.236 | 1.3 | 192.338 | 0.56545 | 0.015 | 2.6 | ug/L |
| Tb | 159 | 491771.349 | 1.8 | 460537.107 | | | | ug/L |
| Ho | 165 | 479061.303 | 2.3 | 440378.521 | | | | ug/L |
| Tl | 203 | 48.667 | 16.7 | 83.668 | -0.00471 | 0.001 | 18.8 | ug/L |
| Tl | 205 | 60.001 | 18.6 | 163.337 | -0.00587 | 0.001 | 9.2 | ug/L |
| Pb | 208 | 2553.843 | 3.7 | 1492.737 | 0.03255 | 0.001 | 4.2 | ug/L |

Sample ID: 948958

Report Date/Time: Friday, November 17, 2006 20:47:20

Page 1

567

| | | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|------|------|
| | Pb | 206 | 678.368 | 3.6 | 397.348 | 0.03260 | 0.001 | 3.8 | ug/L |
| | Pb | 207 | 558.358 | 4.3 | 320.010 | 0.03329 | 0.004 | 11.2 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 112.287 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 104.103 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 114.397 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 106.782 | | | |
| > Ho | 165 | | 108.784 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Friday, November 17, 2006 20:50:16

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 3.055

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1328.119 | 2.2 | 84.001 | 1.00763 | 0.014 | 1.3 | ug/L |
| Al | 27 | 108756.851 | 0.7 | 6946.222 | 11.67934 | 0.239 | 2.0 | ug/L |
| > Sc | 45 | 430408.188 | 1.6 | 426236.083 | | | | ug/L |
| V | 51 | 22932.457 | 1.3 | 5344.504 | 1.01809 | 0.036 | 3.5 | ug/L |
| Cr | 52 | 32427.301 | 1.4 | 18378.762 | 0.92618 | 0.051 | 5.5 | ug/L |
| Cr | 53 | 2718.137 | 1.4 | 1484.814 | 0.65231 | 0.038 | 5.9 | ug/L |
| Mn | 55 | 22353.501 | 1.4 | 742.040 | 1.05896 | 0.016 | 1.5 | ug/L |
| Co | 59 | 18692.463 | 1.2 | 848.388 | 1.08179 | 0.025 | 2.3 | ug/L |
| Ni | 60 | 4218.777 | 2.8 | 167.670 | 1.08375 | 0.042 | 3.9 | ug/L |
| Ni | 62 | 747.041 | 1.8 | 209.338 | 1.00201 | 0.039 | 3.9 | ug/L |
| Cu | 63 | 9443.444 | 2.6 | 570.693 | 1.02532 | 0.025 | 2.4 | ug/L |
| Cu | 65 | 4747.733 | 2.0 | 318.010 | 1.06430 | 0.015 | 1.4 | ug/L |
| Zn | 66 | 15276.479 | 1.8 | 2186.325 | 5.52678 | 0.059 | 1.1 | ug/L |
| Zn | 67 | 2475.059 | 3.1 | 469.352 | 4.86506 | 0.207 | 4.3 | ug/L |
| Zn | 68 | 11157.577 | 1.6 | 1708.532 | 5.53156 | 0.151 | 2.7 | ug/L |
| > Ge | 72 | 218842.642 | 1.0 | 235019.833 | | | | ug/L |
| As | 75 | 3065.928 | 1.6 | 174.004 | 1.04190 | 0.024 | 2.3 | ug/L |
| Se | 77 | 433.078 | 2.7 | 271.738 | 0.86646 | 0.049 | 5.7 | ug/L |
| Se | 78 | 16937.336 | 0.6 | 18294.754 | -0.14734 | 0.249 | 168.8 | mg/L |
| Se | 82 | 781.970 | 1.1 | 514.483 | 1.05653 | 0.037 | 3.5 | ug/L |
| Kr | 83 | 505.354 | 0.8 | 509.687 | | | | mg/L |
| Y | 89 | 421327.462 | 1.9 | 424645.807 | | | | ug/L |
| Mo | 95 | 6094.622 | 1.0 | 130.336 | 0.95039 | 0.023 | 2.5 | ug/L |
| Mo | 97 | 3897.617 | 3.0 | 59.667 | 1.01304 | 0.042 | 4.1 | ug/L |
| Mo | 98 | 9821.832 | 3.0 | 73.129 | 0.99246 | 0.023 | 2.3 | ug/L |
| Rh | 103 | 387572.407 | 3.1 | 377819.614 | | | | ug/L |
| Ag | 107 | 16404.294 | 0.3 | 60.668 | 1.09062 | 0.031 | 2.9 | ug/L |
| Ag | 109 | 14878.086 | 0.8 | 49.001 | 1.06573 | 0.027 | 2.5 | ug/L |
| Cd | 111 | 3822.540 | 0.9 | 302.744 | 1.06048 | 0.039 | 3.7 | ug/L |
| Cd | 114 | 7618.229 | 3.3 | 257.978 | 1.06257 | 0.060 | 5.6 | ug/L |
| > In | 115 | 382408.277 | 2.5 | 368464.817 | | | | ug/L |
| Sb | 121 | 10375.228 | 2.4 | 54.001 | 1.05202 | 0.043 | 4.1 | ug/L |
| Sb | 123 | 7558.012 | 1.4 | 50.513 | 1.00185 | 0.014 | 1.4 | ug/L |
| Ba | 135 | 2913.872 | 0.9 | 123.002 | 0.99590 | 0.016 | 1.6 | ug/L |
| Ba | 137 | 5136.968 | 2.1 | 192.338 | 1.02660 | 0.023 | 2.2 | ug/L |
| > Tb | 159 | 478909.621 | 1.6 | 460537.107 | | | | ug/L |
| > Ho | 165 | 451569.434 | 0.9 | 440378.521 | | | | ug/L |
| Tl | 203 | 9169.801 | 0.4 | 83.668 | 1.07099 | 0.007 | 0.7 | ug/L |
| Tl | 205 | 21917.359 | 3.4 | 163.337 | 1.15074 | 0.039 | 3.4 | ug/L |
| Pb | 208 | 29742.012 | 1.0 | 1492.737 | 1.04833 | 0.018 | 1.8 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Friday, November 17, 2006 20:53:16

Page 1

570

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 7592.867 | 0.8 | 397.348 | 1.01040 | 0.017 | 1.6 ug/L |
| | Pb | 207 | 6462.237 | 1.9 | 320.010 | 1.03029 | 0.027 | 2.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 100.763 | | | | |
| Al | 27 | 116.793 | | | | |
| > Sc | 45 | | 100.979 | | | |
| V | 51 | 101.809 | | | | |
| Cr | 52 | 92.618 | | | | |
| Cr | 53 | 65.231 | | | | |
| Mn | 55 | 105.896 | | | | |
| Co | 59 | 108.179 | | | | |
| Ni | 60 | 108.375 | | | | |
| Ni | 62 | 100.201 | | | | |
| Cu | 63 | 102.532 | | | | |
| Cu | 65 | 106.430 | | | | |
| Zn | 66 | 110.536 | | | | |
| Zn | 67 | 97.301 | | | | |
| Zn | 68 | 110.631 | | | | |
| > Ge | 72 | | 93.117 | | | |
| As | 75 | 104.190 | | | | |
| Se | 77 | 86.646 | | | | |
| Se | 78 | -14.734 | | | | |
| Se | 82 | 105.653 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 95.039 | | | | |
| Mo | 97 | 101.304 | | | | |
| Mo | 98 | 99.246 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 109.062 | | | | |
| Ag | 109 | 106.573 | | | | |
| Cd | 111 | 106.048 | | | | |
| Cd | 114 | 106.257 | | | | |
| > In | 115 | | 103.784 | | | |
| Sb | 121 | 105.202 | | | | |
| Sb | 123 | 100.185 | | | | |
| Ba | 135 | 99.590 | | | | |
| Ba | 137 | 102.660 | | | | |
| > Tb | 159 | | 103.989 | | | |
| > Ho | 165 | | 102.541 | | | |
| Tl | 203 | 107.099 | | | | |
| Tl | 205 | 115.074 | | | | |
| Pb | 208 | 104.833 | | | | |
| Pb | 206 | 101.040 | | | | |
| Pb | 207 | 103.029 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: HLCCV2

Sample Date/Time: Friday, November 17, 2006 20:56:13

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\HLCCV2.056

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 249696.127 | 1.2 | 84.001 | 212.88160 | 5.461 | 2.6 | ug/L |
| Al | 27 | 1801782.314 | 1.6 | 6946.222 | 216.79099 | 5.933 | 2.7 | ug/L |
| Sc | 45 | 409126.348 | 1.4 | 426236.083 | | | | ug/L |
| V | 51 | 3898350.703 | 0.6 | 5344.504 | 237.75074 | 4.513 | 1.9 | ug/L |
| Cr | 52 | 3190629.652 | 2.4 | 18378.762 | 222.79883 | 2.581 | 1.2 | ug/L |
| Cr | 53 | 345157.453 | 1.0 | 1484.814 | 193.44519 | 1.622 | 0.8 | ug/L |
| Mn | 55 | 4390524.039 | 1.0 | 742.040 | 223.02985 | 2.925 | 1.3 | ug/L |
| Co | 59 | 3871807.364 | 1.2 | 848.388 | 243.06582 | 1.765 | 0.7 | ug/L |
| Ni | 60 | 745603.115 | 4.1 | 167.670 | 206.65478 | 9.471 | 4.6 | ug/L |
| Ni | 62 | 109724.414 | 0.6 | 209.338 | 206.55963 | 1.770 | 0.9 | ug/L |
| Cu | 63 | 1651501.057 | 1.2 | 570.693 | 197.42727 | 3.398 | 1.7 | ug/L |
| Cu | 65 | 797793.341 | 2.1 | 318.010 | 198.16793 | 3.832 | 1.9 | ug/L |
| Zn | 66 | 469169.533 | 2.1 | 2186.325 | 202.68362 | 3.203 | 1.6 | ug/L |
| Zn | 67 | 83291.469 | 2.2 | 469.352 | 205.58347 | 5.256 | 2.6 | ug/L |
| Zn | 68 | 334894.067 | 1.3 | 1708.532 | 200.30730 | 3.010 | 1.5 | ug/L |
| Ge | 72 | 210565.894 | 0.6 | 235019.833 | | | | ug/L |
| As | 75 | 549083.931 | 3.3 | 174.004 | 204.68712 | 7.351 | 3.6 | ug/L |
| Se | 77 | 42816.203 | 1.8 | 271.738 | 212.96502 | 5.142 | 2.4 | ug/L |
| Se | 78 | 150906.338 | 2.0 | 18294.754 | 211.86915 | 5.113 | 2.4 | mg/L |
| Se | 82 | 59400.383 | 1.5 | 514.483 | 213.65108 | 4.355 | 2.0 | ug/L |
| Kr | 83 | 477.685 | 1.2 | 509.687 | | | | mg/L |
| Y | 89 | 399519.436 | 2.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 1150910.247 | 0.6 | 130.336 | 192.51866 | 4.694 | 2.4 | ug/L |
| Mo | 97 | 708759.993 | 1.6 | 59.667 | 196.28827 | 3.049 | 1.6 | ug/L |
| Mo | 98 | 1819789.621 | 0.9 | 73.129 | 194.48027 | 6.840 | 3.5 | ug/L |
| Rh | 103 | 353536.755 | 1.9 | 377819.614 | | | | ug/L |
| Ag | 107 | 3378577.749 | 0.6 | 60.668 | 236.56397 | 8.657 | 3.7 | ug/L |
| Ag | 109 | 3174044.748 | 2.0 | 49.001 | 239.42736 | 11.930 | 5.0 | ug/L |
| Cd | 111 | 631345.862 | 2.8 | 302.744 | 199.97410 | 2.833 | 1.4 | ug/L |
| Cd | 114 | 1317846.772 | 0.8 | 257.978 | 199.70498 | 4.883 | 2.4 | ug/L |
| In | 115 | 364585.728 | 3.0 | 368464.817 | | | | ug/L |
| Sb | 121 | 1808118.526 | 0.1 | 54.001 | 193.35198 | 6.122 | 3.2 | ug/L |
| Sb | 123 | 1413208.005 | 0.2 | 50.513 | 197.92613 | 5.852 | 3.0 | ug/L |
| Ba | 135 | 513499.032 | 0.2 | 123.002 | 200.04953 | 3.194 | 1.6 | ug/L |
| Ba | 137 | 878358.895 | 2.1 | 192.338 | 199.03156 | 2.556 | 1.3 | ug/L |
| Tb | 159 | 439344.228 | 1.5 | 460537.107 | | | | ug/L |
| Ho | 165 | 423554.171 | 2.8 | 440378.521 | | | | ug/L |
| Tl | 203 | 1542827.339 | 2.7 | 83.668 | 193.92199 | 2.267 | 1.2 | ug/L |
| Tl | 205 | 4570134.895 | 1.0 | 163.337 | 257.88363 | 5.935 | 2.3 | ug/L |
| Pb | 208 | 5745415.970 | 0.7 | 1492.737 | 227.64228 | 5.451 | 2.4 | ug/L |

Sample ID: HLCCV2

Report Date/Time: Friday, November 17, 2006 20:59:15

Page 1

573

| | | | | | | | | |
|--|----|-----|-------------|-----|---------|-----------|-------|----------|
| | Pb | 206 | 1331036.195 | 1.8 | 397.348 | 199.51328 | 2.629 | 1.3 ug/L |
| | Pb | 207 | 1122950.155 | 1.9 | 320.010 | 201.04257 | 1.911 | 1.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 95.986 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 89.595 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 98.947 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 95.398 | | | |
| > [Ho | 165 | | 96.180 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Friday, November 17, 2006 21:02:12

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 6.057

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59523.756 | 0.3 | 84.001 | 49.53091 | 0.483 | 1.0 | ug/L |
| Al | 27 | 498549.244 | 1.4 | 6946.222 | 58.02549 | 1.187 | 2.0 | ug/L |
| > Sc | 45 | 418653.862 | 0.9 | 426236.083 | | | | ug/L |
| V | 51 | 830044.507 | 1.1 | 5344.504 | 49.21456 | 0.452 | 0.9 | ug/L |
| Cr | 52 | 726335.941 | 1.1 | 18378.762 | 48.60781 | 0.635 | 1.3 | ug/L |
| Cr | 53 | 84602.581 | 2.1 | 1484.814 | 45.72144 | 0.591 | 1.3 | ug/L |
| Mn | 55 | 1007089.571 | 1.5 | 742.040 | 49.82483 | 0.837 | 1.7 | ug/L |
| Co | 59 | 829192.528 | 0.5 | 848.388 | 50.70243 | 1.422 | 2.8 | ug/L |
| Ni | 60 | 187577.549 | 0.7 | 167.670 | 50.64132 | 1.727 | 3.4 | ug/L |
| Ni | 62 | 28290.330 | 5.8 | 209.338 | 51.59713 | 2.014 | 3.9 | ug/L |
| Cu | 63 | 431832.286 | 0.6 | 570.693 | 50.27348 | 1.648 | 3.3 | ug/L |
| Cu | 65 | 213098.808 | 0.8 | 318.010 | 51.54770 | 1.724 | 3.3 | ug/L |
| Zn | 66 | 119552.060 | 2.7 | 2186.325 | 49.68134 | 0.500 | 1.0 | ug/L |
| Zn | 67 | 20617.347 | 0.8 | 469.352 | 48.81450 | 1.786 | 3.7 | ug/L |
| Zn | 68 | 87939.491 | 1.3 | 1708.532 | 50.58414 | 1.644 | 3.2 | ug/L |
| > Ge | 72 | 216140.335 | 2.8 | 235019.833 | | | | ug/L |
| As | 75 | 133136.013 | 2.0 | 174.004 | 48.33636 | 2.009 | 4.2 | ug/L |
| Se | 77 | 10694.793 | 1.8 | 271.738 | 50.90658 | 0.521 | 1.0 | ug/L |
| Se | 78 | 50547.917 | 1.1 | 18294.754 | 51.77288 | 1.682 | 3.2 | mg/L |
| Se | 82 | 14943.053 | 0.4 | 514.483 | 51.12037 | 1.328 | 2.6 | ug/L |
| Kr | 83 | 488.019 | 1.2 | 509.687 | | | | mg/L |
| Y | 89 | 419344.902 | 2.5 | 424645.807 | | | | ug/L |
| Mo | 95 | 284807.010 | 1.2 | 130.336 | 47.92113 | 1.417 | 3.0 | ug/L |
| Mo | 97 | 187757.275 | 1.9 | 59.667 | 52.31403 | 1.436 | 2.7 | ug/L |
| Mo | 98 | 461606.533 | 4.4 | 73.129 | 49.61736 | 2.382 | 4.8 | ug/L |
| Rh | 103 | 370505.962 | 1.4 | 377819.614 | | | | ug/L |
| Ag | 107 | 716554.212 | 3.4 | 60.668 | 50.46878 | 2.193 | 4.3 | ug/L |
| Ag | 109 | 664953.075 | 0.7 | 49.001 | 50.44073 | 1.260 | 2.5 | ug/L |
| Cd | 111 | 161796.769 | 1.4 | 302.744 | 51.51238 | 1.436 | 2.8 | ug/L |
| Cd | 114 | 345509.058 | 2.1 | 257.978 | 52.64722 | 1.388 | 2.6 | ug/L |
| > In | 115 | 362281.318 | 1.8 | 368464.817 | | | | ug/L |
| Sb | 121 | 472120.069 | 1.4 | 54.001 | 50.78061 | 1.103 | 2.2 | ug/L |
| Sb | 123 | 354899.756 | 0.7 | 50.513 | 49.99758 | 1.007 | 2.0 | ug/L |
| Ba | 135 | 131202.099 | 0.6 | 123.002 | 48.37895 | 0.224 | 0.5 | ug/L |
| Ba | 137 | 226622.440 | 1.4 | 192.338 | 48.61625 | 0.726 | 1.5 | ug/L |
| > Tb | 159 | 463778.951 | 0.7 | 460537.107 | | | | ug/L |
| > Ho | 165 | 434039.265 | 0.5 | 440378.521 | | | | ug/L |
| Tl | 203 | 409408.875 | 1.7 | 83.668 | 50.20445 | 0.599 | 1.2 | ug/L |
| Tl | 205 | 949365.542 | 2.9 | 163.337 | 52.25394 | 1.754 | 3.4 | ug/L |
| Pb | 208 | 1310954.193 | 1.6 | 1492.737 | 50.62442 | 1.056 | 2.1 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Friday, November 17, 2006 21:05:14

Page 1

576

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 336595.088 | 1.5 | 397.348 | 49.18444 | 0.966 | 2.0 ug/L |
| | Pb | 207 | 287230.280 | 0.9 | 320.010 | 50.13081 | 0.412 | 0.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 99.062 | | | | |
| Al | 27 | 116.051 | | | | |
| > Sc | 45 | | 98.221 | | | |
| V | 51 | 98.429 | | | | |
| Cr | 52 | 97.216 | | | | |
| Cr | 53 | 91.443 | | | | |
| Mn | 55 | 99.650 | | | | |
| Co | 59 | 101.405 | | | | |
| Ni | 60 | 101.283 | | | | |
| Ni | 62 | 103.194 | | | | |
| Cu | 63 | 100.547 | | | | |
| Cu | 65 | 103.095 | | | | |
| Zn | 66 | 99.363 | | | | |
| Zn | 67 | 97.629 | | | | |
| Zn | 68 | 101.168 | | | | |
| > Ge | 72 | | 91.967 | | | |
| As | 75 | 96.673 | | | | |
| Se | 77 | 101.813 | | | | |
| Se | 78 | 103.546 | | | | |
| Se | 82 | 102.241 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 95.842 | | | | |
| Mo | 97 | 104.628 | | | | |
| Mo | 98 | 99.235 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 100.938 | | | | |
| Ag | 109 | 100.881 | | | | |
| Cd | 111 | 103.025 | | | | |
| Cd | 114 | 105.294 | | | | |
| > In | 115 | | 98.322 | | | |
| Sb | 121 | 101.561 | | | | |
| Sb | 123 | 99.995 | | | | |
| Ba | 135 | 96.758 | | | | |
| Ba | 137 | 97.233 | | | | |
| > Tb | 159 | | 100.704 | | | |
| > Ho | 165 | | 98.560 | | | |
| Tl | 203 | 100.409 | | | | |
| Tl | 205 | 104.508 | | | | |
| Pb | 208 | 101.249 | | | | |
| Pb | 206 | 98.369 | | | | |
| Pb | 207 | 100.262 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Friday, November 17, 2006 21:08:10

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 7.058

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 53.001 | 13.6 | 84.001 | -0.02593 | 0.005 | 19.6 | ug/L |
| Al | 27 | 3947.308 | 2.5 | 6946.222 | -0.35281 | 0.004 | 1.0 | ug/L |
| Sc | 45 | 431164.956 | 1.9 | 426236.083 | | | | ug/L |
| V | 51 | 4916.277 | 2.9 | 5344.504 | -0.02828 | 0.011 | 40.6 | ug/L |
| Cr | 52 | 16394.282 | 2.7 | 18378.762 | -0.14602 | 0.041 | 28.2 | ug/L |
| Cr | 53 | 804.380 | 4.4 | 1484.814 | -0.37264 | 0.011 | 2.9 | ug/L |
| Mn | 55 | 511.354 | 2.3 | 742.040 | -0.00847 | 0.000 | 4.6 | ug/L |
| Co | 59 | 268.340 | 7.5 | 848.388 | -0.03133 | 0.001 | 3.2 | ug/L |
| Ni | 60 | 138.669 | 6.0 | 167.670 | -0.00419 | 0.002 | 59.0 | ug/L |
| Ni | 62 | 141.003 | 3.9 | 209.338 | -0.09463 | 0.012 | 12.4 | ug/L |
| Cu | 63 | 241.673 | 2.4 | 570.693 | -0.03299 | 0.001 | 2.2 | ug/L |
| Cu | 65 | 188.004 | 4.8 | 318.010 | -0.02528 | 0.003 | 10.0 | ug/L |
| Zn | 66 | 1411.134 | 4.7 | 2186.325 | -0.25361 | 0.023 | 9.1 | ug/L |
| Zn | 67 | 293.675 | 5.4 | 469.352 | -0.33339 | 0.042 | 12.5 | ug/L |
| Zn | 68 | 1040.075 | 3.7 | 1708.532 | -0.31085 | 0.028 | 9.1 | ug/L |
| Ge | 72 | 216176.867 | 1.4 | 235019.833 | | | | ug/L |
| As | 75 | 160.003 | 6.9 | 174.004 | -0.00005 | 0.003 | 6706.1 | ug/L |
| Se | 77 | 234.870 | 1.9 | 271.738 | -0.07332 | 0.027 | 36.9 | ug/L |
| Se | 78 | 16011.631 | 1.0 | 18294.754 | -1.24857 | 0.469 | 37.5 | mg/L |
| Se | 82 | 497.215 | 1.9 | 514.483 | 0.08472 | 0.028 | 33.3 | ug/L |
| Kr | 83 | 490.019 | 2.7 | 509.687 | | | | mg/L |
| Y | 89 | 418742.204 | 1.9 | 424645.807 | | | | ug/L |
| Mo | 95 | 1280.781 | 21.0 | 130.336 | 0.19264 | 0.044 | 22.8 | ug/L |
| Mo | 97 | 740.708 | 16.2 | 59.667 | 0.18880 | 0.032 | 17.2 | ug/L |
| Mo | 98 | 1903.928 | 24.5 | 73.129 | 0.19565 | 0.049 | 25.0 | ug/L |
| Rh | 103 | 367701.149 | 0.4 | 377819.614 | | | | ug/L |
| Ag | 107 | 186.671 | 13.4 | 60.668 | 0.00886 | 0.002 | 19.1 | ug/L |
| Ag | 109 | 150.003 | 15.8 | 49.001 | 0.00766 | 0.002 | 23.4 | ug/L |
| Cd | 111 | 260.397 | 3.1 | 302.744 | -0.01233 | 0.004 | 32.7 | ug/L |
| Cd | 114 | 71.229 | 21.4 | 257.978 | -0.02787 | 0.002 | 8.2 | ug/L |
| In | 115 | 364433.280 | 1.8 | 368464.817 | | | | ug/L |
| Sb | 121 | 1662.519 | 18.2 | 54.001 | 0.17205 | 0.032 | 18.6 | ug/L |
| Sb | 123 | 1198.793 | 14.8 | 50.513 | 0.16088 | 0.024 | 15.2 | ug/L |
| Ba | 135 | 47.001 | 2.1 | 123.002 | -0.02823 | 0.000 | 1.6 | ug/L |
| Ba | 137 | 63.001 | 11.1 | 192.338 | -0.02794 | 0.002 | 5.6 | ug/L |
| Tb | 159 | 459981.643 | 0.4 | 460537.107 | | | | ug/L |
| Ho | 165 | 441184.474 | 1.4 | 440378.521 | | | | ug/L |
| Tl | 203 | 84.335 | 7.5 | 83.668 | 0.00007 | 0.001 | 1257.5 | ug/L |
| Tl | 205 | 175.337 | 16.0 | 163.337 | 0.00062 | 0.001 | 226.2 | ug/L |
| Pb | 208 | 499.677 | 7.5 | 1492.737 | -0.03788 | 0.001 | 3.1 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Friday, November 17, 2006 21:11:10

Page 1

579

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|----------|
| | Pb | 206 | 135.002 | 8.5 | 397.348 | -0.03787 | 0.001 | 3.8 ug/L |
| | Pb | 207 | 115.002 | 5.4 | 320.010 | -0.03534 | 0.001 | 2.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 101.156 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 91.982 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.906 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.879 | | | |
| > Ho | 165 | | 100.183 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956

Sample Date/Time: Friday, November 17, 2006 21:14:07

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948956.059

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 72.001 | 16.9 | 84.001 | -0.02150 | 0.008 | 35.9 | ug/L |
| Al | 27 | 21426.743 | 3.2 | 6946.222 | 1.18784 | 0.079 | 6.6 | ug/L |
| > Sc | 45 | 531239.051 | 1.2 | 426236.083 | | | | ug/L |
| V | 51 | 8049.874 | 3.5 | 5344.504 | 0.06544 | 0.017 | 26.5 | ug/L |
| Cr | 52 | 25633.310 | 3.0 | 18378.762 | 0.14786 | 0.055 | 37.4 | ug/L |
| Cr | 53 | 2845.220 | 34.7 | 1484.814 | 0.43254 | 0.436 | 100.7 | ug/L |
| Mn | 55 | 142189328.102 | 0.7 | 742.040 | 6589.19903 | 162.228 | 2.5 | ug/L |
| Co | 59 | 254822.688 | 0.7 | 848.388 | 14.54690 | 0.305 | 2.1 | ug/L |
| Ni | 60 | 52141.812 | 0.9 | 167.670 | 13.14011 | 0.250 | 1.9 | ug/L |
| Ni | 62 | 12440.515 | 13.5 | 209.338 | 21.05217 | 3.001 | 14.3 | ug/L |
| Cu | 63 | 21677.978 | 12.0 | 570.693 | 2.30369 | 0.293 | 12.7 | ug/L |
| Cu | 65 | 1907.904 | 3.7 | 318.010 | 0.36168 | 0.020 | 5.4 | ug/L |
| Zn | 66 | 5944.513 | 1.5 | 2186.325 | 1.50332 | 0.096 | 6.4 | ug/L |
| Zn | 67 | 1574.831 | 1.4 | 469.352 | 2.51989 | 0.075 | 3.0 | ug/L |
| Zn | 68 | 7920.844 | 2.7 | 1708.532 | 3.41970 | 0.043 | 1.3 | ug/L |
| > Ge | 72 | 230936.836 | 2.6 | 235019.833 | | | | ug/L |
| As | 75 | 654381.358 | 0.6 | 174.004 | 222.53057 | 7.084 | 3.2 | ug/L |
| Se | 77 | 349.674 | 1.0 | 271.738 | 0.37776 | 0.048 | 12.8 | ug/L |
| Se | 78 | 17552.289 | 1.3 | 18294.754 | -0.60398 | 0.345 | 57.0 | mg/L |
| Se | 82 | 589.821 | 0.3 | 514.483 | 0.27932 | 0.046 | 16.5 | ug/L |
| Kr | 83 | 538.023 | 2.7 | 509.687 | | | | mg/L |
| Y | 89 | 433803.369 | 2.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 178924.631 | 0.8 | 130.336 | 28.88566 | 0.001 | 0.0 | ug/L |
| Mo | 97 | 109106.735 | 0.9 | 59.667 | 29.17528 | 0.481 | 1.6 | ug/L |
| Mo | 98 | 277163.170 | 2.9 | 73.129 | 28.59250 | 0.756 | 2.6 | ug/L |
| Rh | 103 | 367672.074 | 2.4 | 377819.614 | | | | ug/L |
| Ag | 107 | 111.002 | 19.1 | 60.668 | 0.00331 | 0.001 | 43.8 | ug/L |
| Ag | 109 | 102.335 | 1.1 | 49.001 | 0.00380 | 0.000 | 1.7 | ug/L |
| Cd | 111 | 65.364 | 65.5 | 302.744 | -0.07494 | 0.013 | 17.5 | ug/L |
| Cd | 114 | 391.435 | 34.7 | 257.978 | 0.01858 | 0.020 | 105.9 | ug/L |
| > In | 115 | 377337.180 | 0.8 | 368464.817 | | | | ug/L |
| Sb | 121 | 5378.793 | 5.5 | 54.001 | 0.54970 | 0.030 | 5.5 | ug/L |
| Sb | 123 | 4083.775 | 1.2 | 50.513 | 0.54531 | 0.004 | 0.7 | ug/L |
| Ba | 135 | 65156.128 | 2.3 | 123.002 | 24.59078 | 0.893 | 3.6 | ug/L |
| Ba | 137 | 115211.456 | 0.7 | 192.338 | 25.29529 | 0.398 | 1.6 | ug/L |
| > Tb | 159 | 452882.232 | 2.1 | 460537.107 | | | | ug/L |
| > Ho | 165 | 434637.431 | 0.2 | 440378.521 | | | | ug/L |
| Tl | 203 | 251.006 | 22.2 | 83.668 | 0.02063 | 0.007 | 33.1 | ug/L |
| Tl | 205 | 518.022 | 32.4 | 163.337 | 0.01961 | 0.009 | 47.0 | ug/L |
| Pb | 208 | 1562.071 | 1.2 | 1492.737 | 0.00343 | 0.001 | 21.6 | ug/L |

582

Sample ID: 948956

Report Date/Time: Friday, November 17, 2006 21:17:09

Page 1

581 *AW*
12/1/06

| | | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|------|------|
| | Pb | 206 | 422.348 | 1.3 | 397.348 | 0.00441 | 0.001 | 16.6 | ug/L |
| | Pb | 207 | 351.678 | 7.1 | 320.010 | 0.00626 | 0.004 | 70.9 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 124.635 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 98.263 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.408 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.338 | | | |
| > Ho | 165 | | 98.696 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956D

Sample Date/Time: Friday, November 17, 2006 21:20:06

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948956D.060

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 64.668 | 22.3 | 84.001 | -0.02694 | 0.010 | 35.9 | ug/L |
| Al | 27 | 33695.691 | 2.8 | 6946.222 | 2.27632 | 0.129 | 5.7 | ug/L |
| > Sc | 45 | 540397.492 | 1.4 | 426236.083 | | | | ug/L |
| V | 51 | 7991.813 | 2.6 | 5344.504 | 0.05631 | 0.014 | 24.3 | ug/L |
| Cr | 52 | 26033.533 | 1.4 | 18378.762 | 0.14558 | 0.037 | 25.1 | ug/L |
| Cr | 53 | 2412.373 | 1.6 | 1484.814 | 0.22603 | 0.030 | 13.4 | ug/L |
| Mn | 55 | 148248709.107 | 1.8 | 742.040 | 6704.90520 | 243.838 | 3.6 | ug/L |
| Co | 59 | 264171.292 | 3.1 | 848.388 | 14.71131 | 0.230 | 1.6 | ug/L |
| Ni | 60 | 52692.601 | 1.0 | 167.670 | 12.95862 | 0.334 | 2.6 | ug/L |
| Ni | 62 | 10120.913 | 2.7 | 209.338 | 16.63815 | 0.745 | 4.5 | ug/L |
| Cu | 63 | 18839.130 | 1.7 | 570.693 | 1.94428 | 0.071 | 3.7 | ug/L |
| Cu | 65 | 1983.256 | 2.1 | 318.010 | 0.36795 | 0.018 | 4.8 | ug/L |
| Zn | 66 | 7058.392 | 1.7 | 2186.325 | 1.87517 | 0.010 | 0.5 | ug/L |
| Zn | 67 | 1709.859 | 2.0 | 469.352 | 2.73160 | 0.078 | 2.9 | ug/L |
| Zn | 68 | 8747.343 | 1.5 | 1708.532 | 3.75928 | 0.165 | 4.4 | ug/L |
| > Ge | 72 | 236635.268 | 2.0 | 235019.833 | | | | ug/L |
| As | 75 | 651818.942 | 1.9 | 174.004 | 216.31297 | 8.412 | 3.9 | ug/L |
| Se | 77 | 354.074 | 1.8 | 271.738 | 0.35863 | 0.045 | 12.6 | ug/L |
| Se | 78 | 17055.476 | 1.3 | 18294.754 | -1.90255 | 0.792 | 41.6 | mg/L |
| Se | 82 | 603.689 | 1.0 | 514.483 | 0.27690 | 0.047 | 17.1 | ug/L |
| Kr | 83 | 530.689 | 4.8 | 509.687 | | | | mg/L |
| Y | 89 | 420199.403 | 2.1 | 424645.807 | | | | ug/L |
| Mo | 95 | 180491.378 | 1.4 | 130.336 | 29.72445 | 0.615 | 2.1 | ug/L |
| Mo | 97 | 109845.782 | 1.7 | 59.667 | 29.95605 | 0.217 | 0.7 | ug/L |
| Mo | 98 | 294644.662 | 1.0 | 73.129 | 31.01507 | 1.011 | 3.3 | ug/L |
| Rh | 103 | 359388.396 | 1.6 | 377819.614 | | | | ug/L |
| Ag | 107 | 103.002 | 15.3 | 60.668 | 0.00290 | 0.001 | 37.6 | ug/L |
| Ag | 109 | 87.001 | 23.1 | 49.001 | 0.00283 | 0.002 | 57.3 | ug/L |
| Cd | 111 | -60.855 | 54.9 | 302.744 | -0.11380 | 0.010 | 8.9 | ug/L |
| Cd | 114 | 456.086 | 9.9 | 257.978 | 0.02952 | 0.008 | 27.2 | ug/L |
| > In | 115 | 370002.560 | 2.3 | 368464.817 | | | | ug/L |
| Sb | 121 | 5067.258 | 1.6 | 54.001 | 0.52796 | 0.004 | 0.8 | ug/L |
| Sb | 123 | 3791.209 | 0.8 | 50.513 | 0.51611 | 0.014 | 2.7 | ug/L |
| Ba | 135 | 68731.975 | 0.7 | 123.002 | 26.14615 | 0.499 | 1.9 | ug/L |
| Ba | 137 | 117682.751 | 1.5 | 192.338 | 26.04641 | 0.608 | 2.3 | ug/L |
| > Tb | 159 | 449252.598 | 1.2 | 460537.107 | | | | ug/L |
| > Ho | 165 | 437733.136 | 1.1 | 440378.521 | | | | ug/L |
| Tl | 203 | 202.338 | 5.2 | 83.668 | 0.01449 | 0.001 | 7.1 | ug/L |
| Tl | 205 | 430.349 | 6.2 | 163.337 | 0.01462 | 0.001 | 8.5 | ug/L |
| Pb | 208 | 9090.703 | 0.8 | 1492.737 | 0.29162 | 0.006 | 2.0 | ug/L |

Sample ID: 948956D

Report Date/Time: Friday, November 17, 2006 21:23:07

Page 1

585

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 2334.350 | 3.1 | 397.348 | 0.28126 | 0.007 | 2.7 ug/L |
| | Pb | 207 | 1938.912 | 0.1 | 320.010 | 0.28083 | 0.004 | 1.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 126.784 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 100.687 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 100.417 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.550 | | | |
| > Ho | 165 | | 99.399 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956S

Sample Date/Time: Friday, November 17, 2006 21:26:04

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948956S.061

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 20604.982 | 0.5 | 84.001 | 13.44969 | 0.098 | 0.7 | ug/L |
| Al | 27 | 208230.626 | 2.5 | 6946.222 | 18.54261 | 0.597 | 3.2 | ug/L |
| > Sc | 45 | 531725.911 | 1.1 | 426236.083 | | | | ug/L |
| V | 51 | 357135.600 | 1.5 | 5344.504 | 16.46467 | 0.151 | 0.9 | ug/L |
| Cr | 52 | 315842.286 | 2.0 | 18378.762 | 15.82720 | 0.321 | 2.0 | ug/L |
| Cr | 53 | 37135.994 | 3.4 | 1484.814 | 15.27626 | 0.444 | 2.9 | ug/L |
| Mn | 55 | 137747753.814 | 2.3 | 742.040 | 6378.03878 | 195.424 | 3.1 | ug/L |
| Co | 59 | 601171.833 | 2.1 | 848.388 | 34.34812 | 0.357 | 1.0 | ug/L |
| Ni | 60 | 122112.031 | 2.3 | 167.670 | 30.79982 | 0.582 | 1.9 | ug/L |
| Ni | 62 | 19949.403 | 3.6 | 209.338 | 33.93327 | 1.454 | 4.3 | ug/L |
| Cu | 63 | 190267.701 | 1.3 | 570.693 | 20.67035 | 0.132 | 0.6 | ug/L |
| Cu | 65 | 82915.033 | 1.8 | 318.010 | 18.70589 | 0.440 | 2.4 | ug/L |
| Zn | 66 | 47148.487 | 1.3 | 2186.325 | 17.78960 | 0.151 | 0.8 | ug/L |
| Zn | 67 | 8607.533 | 3.6 | 469.352 | 18.41294 | 0.646 | 3.5 | ug/L |
| Zn | 68 | 37731.272 | 0.7 | 1708.532 | 19.74083 | 0.307 | 1.6 | ug/L |
| > Ge | 72 | 231076.821 | 1.1 | 235019.833 | | | | ug/L |
| As | 75 | 659924.472 | 2.2 | 174.004 | 224.14174 | 2.874 | 1.3 | ug/L |
| Se | 77 | 3747.309 | 0.9 | 271.738 | 15.86265 | 0.130 | 0.8 | ug/L |
| Se | 78 | 27708.523 | 1.3 | 18294.754 | 13.95092 | 0.179 | 1.3 | mg/L |
| Se | 82 | 5297.617 | 1.5 | 514.483 | 15.82643 | 0.119 | 0.7 | ug/L |
| Kr | 83 | 518.688 | 5.4 | 509.687 | | | | mg/L |
| Y | 89 | 421704.654 | 1.1 | 424645.807 | | | | ug/L |
| Mo | 95 | 292401.690 | 2.5 | 130.336 | 47.92827 | 1.143 | 2.4 | ug/L |
| Mo | 97 | 181908.561 | 3.3 | 59.667 | 49.37547 | 1.388 | 2.8 | ug/L |
| Mo | 98 | 482510.620 | 1.4 | 73.129 | 50.54366 | 1.559 | 3.1 | ug/L |
| Rh | 103 | 356799.523 | 2.9 | 377819.614 | | | | ug/L |
| Ag | 107 | 291783.427 | 3.6 | 60.668 | 20.03005 | 1.128 | 5.6 | ug/L |
| Ag | 109 | 270861.546 | 1.5 | 49.001 | 20.02165 | 0.708 | 3.5 | ug/L |
| Cd | 111 | 59575.801 | 0.9 | 302.744 | 18.42052 | 0.412 | 2.2 | ug/L |
| Cd | 114 | 136011.920 | 1.5 | 257.978 | 20.16819 | 0.160 | 0.8 | ug/L |
| > In | 115 | 371800.884 | 2.0 | 368464.817 | | | | ug/L |
| Sb | 121 | 194260.497 | 0.8 | 54.001 | 20.35634 | 0.355 | 1.7 | ug/L |
| Sb | 123 | 144527.800 | 1.1 | 50.513 | 19.83711 | 0.517 | 2.6 | ug/L |
| Ba | 135 | 120139.789 | 1.4 | 123.002 | 45.90076 | 1.232 | 2.7 | ug/L |
| Ba | 137 | 205845.676 | 2.0 | 192.338 | 45.75495 | 1.424 | 3.1 | ug/L |
| > Tb | 159 | 447681.638 | 1.4 | 460537.107 | | | | ug/L |
| > Ho | 165 | 437724.308 | 1.2 | 440378.521 | | | | ug/L |
| Tl | 203 | 162398.916 | 1.3 | 83.668 | 19.74132 | 0.059 | 0.3 | ug/L |
| Tl | 205 | 385213.542 | 1.8 | 163.337 | 21.02065 | 0.591 | 2.8 | ug/L |
| Pb | 208 | 517306.602 | 0.8 | 1492.737 | 19.77335 | 0.154 | 0.8 | ug/L |

Sample ID: 948956S

Report Date/Time: Friday, November 17, 2006 21:29:06

Page 1

| | | | | | | | | |
|---|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 133450.362 | 2.1 | 397.348 | 19.29860 | 0.180 | 0.9 ug/L |
| L | Pb | 207 | 110424.357 | 1.6 | 320.010 | 19.07651 | 0.256 | 1.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 124.749 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 98.322 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 100.905 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.209 | | | |
| > Ho | 165 | | 99.397 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956A

Sample Date/Time: Friday, November 17, 2006 21:32:03

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948956A.062

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 21121.278 | 0.7 | 84.001 | 14.24349 | 0.515 | 3.6 | ug/L |
| Al | 27 | 225573.282 | 1.6 | 6946.222 | 20.84462 | 0.988 | 4.7 | ug/L |
| > Sc | 45 | 515165.618 | 3.0 | 426236.083 | | | | ug/L |
| V | 51 | 360367.483 | 1.7 | 5344.504 | 17.16632 | 0.308 | 1.8 | ug/L |
| Cr | 52 | 320650.456 | 1.9 | 18378.762 | 16.64904 | 0.354 | 2.1 | ug/L |
| Cr | 53 | 37131.587 | 1.3 | 1484.814 | 15.79871 | 0.312 | 2.0 | ug/L |
| Mn | 55 | 142868782.614 | 2.2 | 742.040 | 6874.19579 | 109.400 | 1.6 | ug/L |
| Co | 59 | 599465.357 | 4.1 | 848.388 | 35.59974 | 1.229 | 3.5 | ug/L |
| Ni | 60 | 129343.225 | 1.9 | 167.670 | 33.91887 | 0.888 | 2.6 | ug/L |
| Ni | 62 | 18777.661 | 2.4 | 209.338 | 33.18824 | 0.983 | 3.0 | ug/L |
| Cu | 63 | 188402.868 | 1.7 | 570.693 | 21.27659 | 0.357 | 1.7 | ug/L |
| Cu | 65 | 87031.364 | 1.4 | 318.010 | 20.41319 | 0.313 | 1.5 | ug/L |
| Zn | 66 | 46886.354 | 1.6 | 2186.325 | 18.41547 | 0.151 | 0.8 | ug/L |
| Zn | 67 | 8836.439 | 2.5 | 469.352 | 19.72133 | 0.679 | 3.4 | ug/L |
| Zn | 68 | 38393.635 | 1.4 | 1708.532 | 20.93046 | 0.309 | 1.5 | ug/L |
| > Ge | 72 | 222316.099 | 0.9 | 235019.833 | | | | ug/L |
| As | 75 | 663227.557 | 0.6 | 174.004 | 234.16717 | 2.061 | 0.9 | ug/L |
| Se | 77 | 3745.108 | 0.3 | 271.738 | 16.52536 | 0.095 | 0.6 | ug/L |
| Se | 78 | 27738.523 | 1.5 | 18294.754 | 15.56838 | 0.952 | 6.1 | mg/L |
| Se | 82 | 5309.691 | 0.7 | 514.483 | 16.55879 | 0.219 | 1.3 | ug/L |
| Kr | 83 | 533.022 | 9.4 | 509.687 | | | | mg/L |
| Y | 89 | 414229.357 | 3.5 | 424645.807 | | | | ug/L |
| Mo | 95 | 291868.970 | 0.7 | 130.336 | 49.02438 | 0.323 | 0.7 | ug/L |
| Mo | 97 | 189875.417 | 0.8 | 59.667 | 52.81842 | 0.444 | 0.8 | ug/L |
| Mo | 98 | 486650.926 | 2.3 | 73.129 | 52.22377 | 1.159 | 2.2 | ug/L |
| Rh | 103 | 362662.691 | 0.9 | 377819.614 | | | | ug/L |
| Ag | 107 | 286921.032 | 0.4 | 60.668 | 20.17080 | 0.090 | 0.4 | ug/L |
| Ag | 109 | 264452.790 | 1.0 | 49.001 | 20.02440 | 0.213 | 1.1 | ug/L |
| Cd | 111 | 61962.959 | 3.0 | 302.744 | 19.63586 | 0.594 | 3.0 | ug/L |
| Cd | 114 | 135025.857 | 3.7 | 257.978 | 20.51819 | 0.746 | 3.6 | ug/L |
| > In | 115 | 362785.777 | 0.1 | 368464.817 | | | | ug/L |
| Sb | 121 | 197719.034 | 2.1 | 54.001 | 21.22917 | 0.433 | 2.0 | ug/L |
| Sb | 123 | 147150.097 | 0.5 | 50.513 | 20.69260 | 0.093 | 0.4 | ug/L |
| Ba | 135 | 118084.128 | 2.0 | 123.002 | 45.07702 | 0.705 | 1.6 | ug/L |
| Ba | 137 | 203061.381 | 0.9 | 192.338 | 45.10241 | 0.744 | 1.7 | ug/L |
| > Tb | 159 | 447939.136 | 0.9 | 460537.107 | | | | ug/L |
| > Ho | 165 | 420677.259 | 2.4 | 440378.521 | | | | ug/L |
| Tl | 203 | 163423.902 | 0.8 | 83.668 | 20.68160 | 0.640 | 3.1 | ug/L |
| Tl | 205 | 389534.830 | 2.2 | 163.337 | 22.11469 | 0.101 | 0.5 | ug/L |
| Pb | 208 | 522475.660 | 1.6 | 1492.737 | 20.78625 | 0.350 | 1.7 | ug/L |

Sample ID: 948956A

Report Date/Time: Friday, November 17, 2006 21:35:04

Page 1

591

| | | | | | | | | |
|---|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 132818.610 | 1.8 | 397.348 | 19.99112 | 0.137 | 0.7 ug/L |
| L | Pb | 207 | 111339.679 | 1.0 | 320.010 | 20.02144 | 0.345 | 1.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 120.864 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 94.595 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 98.459 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 97.265 | | | |
| > [Ho | 165 | | 95.526 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956L

Sample Date/Time: Friday, November 17, 2006 21:38:01

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948956L.063

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 51.334 | 16.6 | 84.001 | -0.02807 | 0.007 | 23.3 | ug/L |
| Al | 27 | 11910.627 | 2.2 | 6946.222 | 0.53225 | 0.033 | 6.3 | ug/L |
| > Sc | 45 | 439997.360 | 0.7 | 426236.083 | | | | ug/L |
| V | 51 | 5363.389 | 3.0 | 5344.504 | -0.00874 | 0.008 | 91.0 | ug/L |
| Cr | 52 | 17883.683 | 1.3 | 18378.762 | -0.07108 | 0.013 | 17.7 | ug/L |
| Cr | 53 | 1364.459 | 3.2 | 1484.814 | -0.08795 | 0.027 | 30.9 | ug/L |
| Mn | 55 | 27618590.148 | 2.9 | 742.040 | 1311.74733 | 55.021 | 4.2 | ug/L |
| Co | 59 | 52571.894 | 2.4 | 848.388 | 3.03780 | 0.088 | 2.9 | ug/L |
| Ni | 60 | 10359.541 | 2.2 | 167.670 | 2.64236 | 0.078 | 3.0 | ug/L |
| Ni | 62 | 2294.006 | 4.1 | 209.338 | 3.68927 | 0.162 | 4.4 | ug/L |
| Cu | 63 | 4236.453 | 2.2 | 570.693 | 0.41225 | 0.005 | 1.2 | ug/L |
| Cu | 65 | 893.057 | 2.3 | 318.010 | 0.13661 | 0.005 | 3.8 | ug/L |
| Zn | 66 | 2243.658 | 1.9 | 2186.325 | 0.06003 | 0.024 | 40.6 | ug/L |
| Zn | 67 | 535.356 | 2.9 | 469.352 | 0.19841 | 0.051 | 25.8 | ug/L |
| Zn | 68 | 2305.676 | 3.6 | 1708.532 | 0.37546 | 0.062 | 16.4 | ug/L |
| > Ge | 72 | 225306.691 | 1.3 | 235019.833 | | | | ug/L |
| As | 75 | 137130.220 | 1.3 | 174.004 | 47.72629 | 0.163 | 0.3 | ug/L |
| Se | 77 | 259.404 | 3.1 | 271.738 | -0.00512 | 0.036 | 700.9 | ug/L |
| Se | 78 | 16277.655 | 1.2 | 18294.754 | -1.85569 | 0.160 | 8.6 | mg/L |
| Se | 82 | 509.016 | 1.4 | 514.483 | 0.05354 | 0.017 | 32.1 | ug/L |
| Kr | 83 | 484.352 | 3.8 | 509.687 | | | | mg/L |
| Y | 89 | 414642.765 | 1.1 | 424645.807 | | | | ug/L |
| Mo | 95 | 34301.468 | 1.3 | 130.336 | 5.50524 | 0.093 | 1.7 | ug/L |
| Mo | 97 | 20506.408 | 1.5 | 59.667 | 5.45471 | 0.085 | 1.6 | ug/L |
| Mo | 98 | 54836.461 | 0.7 | 73.129 | 5.63535 | 0.025 | 0.4 | ug/L |
| Rh | 103 | 371176.157 | 1.6 | 377819.614 | | | | ug/L |
| Ag | 107 | 89.668 | 10.1 | 60.668 | 0.00184 | 0.001 | 32.1 | ug/L |
| Ag | 109 | 64.668 | 12.6 | 49.001 | 0.00104 | 0.001 | 56.5 | ug/L |
| Cd | 111 | 207.977 | 7.6 | 302.744 | -0.03143 | 0.005 | 14.8 | ug/L |
| Cd | 114 | 128.466 | 25.5 | 257.978 | -0.01992 | 0.005 | 24.0 | ug/L |
| > In | 115 | 378375.915 | 0.5 | 368464.817 | | | | ug/L |
| Sb | 121 | 1385.462 | 2.2 | 54.001 | 0.13697 | 0.004 | 2.8 | ug/L |
| Sb | 123 | 1007.003 | 7.1 | 50.513 | 0.12879 | 0.009 | 7.0 | ug/L |
| Ba | 135 | 13550.143 | 0.5 | 123.002 | 4.98101 | 0.090 | 1.8 | ug/L |
| Ba | 137 | 23450.855 | 1.3 | 192.338 | 5.01922 | 0.108 | 2.2 | ug/L |
| > Tb | 159 | 461493.493 | 1.5 | 460537.107 | | | | ug/L |
| > Ho | 165 | 449279.712 | 0.4 | 440378.521 | | | | ug/L |
| Tl | 203 | 108.002 | 10.5 | 83.668 | 0.00268 | 0.001 | 48.8 | ug/L |
| Tl | 205 | 229.005 | 8.2 | 163.337 | 0.00331 | 0.001 | 28.7 | ug/L |
| Pb | 208 | 640.682 | 4.0 | 1492.737 | -0.03294 | 0.001 | 3.2 | ug/L |

Sample ID: 948956L

Report Date/Time: Friday, November 17, 2006 21:41:03

Page 1

594

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|----------|
| | Pb | 206 | 169.670 | 6.4 | 397.348 | -0.03331 | 0.002 | 4.9 ug/L |
| | Pb | 207 | 147.003 | 10.7 | 320.010 | -0.03030 | 0.003 | 8.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 103.229 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 95.867 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.690 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.208 | | | |
| > Ho | 165 | | 102.021 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948957

Sample Date/Time: Friday, November 17, 2006 21:44:00

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\948957.064

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 68.001 | 7.6 | 84.001 | -0.02315 | 0.004 | 15.8 | ug/L |
| Al | 27 | 28079.698 | 38.3 | 6946.222 | 1.85830 | 1.008 | 54.3 | ug/L |
| > Sc | 45 | 520324.433 | 0.8 | 426236.083 | | | | ug/L |
| V | 51 | 7844.822 | 3.0 | 5344.504 | 0.06337 | 0.009 | 14.2 | ug/L |
| Cr | 52 | 25768.037 | 0.9 | 18378.762 | 0.18404 | 0.015 | 8.0 | ug/L |
| Cr | 53 | 2459.388 | 2.2 | 1484.814 | 0.28626 | 0.026 | 9.1 | ug/L |
| Mn | 55 | 152474130.156 | 2.7 | 742.040 | 7172.29119 | 268.404 | 3.7 | ug/L |
| Co | 59 | 261650.259 | 1.4 | 848.388 | 15.16342 | 0.376 | 2.5 | ug/L |
| Ni | 60 | 54653.997 | 3.5 | 167.670 | 13.98545 | 0.632 | 4.5 | ug/L |
| Ni | 62 | 7453.742 | 2.8 | 209.338 | 12.66183 | 0.544 | 4.3 | ug/L |
| Cu | 63 | 14152.486 | 2.2 | 570.693 | 1.50544 | 0.037 | 2.4 | ug/L |
| Cu | 65 | 1770.206 | 1.1 | 318.010 | 0.33643 | 0.008 | 2.3 | ug/L |
| Zn | 66 | 8550.136 | 0.7 | 2186.325 | 2.58401 | 0.025 | 1.0 | ug/L |
| Zn | 67 | 1926.909 | 2.1 | 469.352 | 3.38244 | 0.139 | 4.1 | ug/L |
| Zn | 68 | 10169.637 | 0.7 | 1708.532 | 4.73684 | 0.057 | 1.2 | ug/L |
| > Ge | 72 | 227479.313 | 1.4 | 235019.833 | | | | ug/L |
| As | 75 | 569770.967 | 1.7 | 174.004 | 196.63878 | 5.796 | 2.9 | ug/L |
| Se | 77 | 359.208 | 2.1 | 271.738 | 0.44526 | 0.014 | 3.2 | ug/L |
| Se | 78 | 16741.592 | 0.8 | 18294.754 | -1.40658 | 0.266 | 18.9 | mg/L |
| Se | 82 | 592.088 | 1.5 | 514.483 | 0.31591 | 0.031 | 9.8 | ug/L |
| Kr | 83 | 538.689 | 3.0 | 509.687 | | | | mg/L |
| Y | 89 | 412827.857 | 0.8 | 424645.807 | | | | ug/L |
| Mo | 95 | 181728.815 | 2.0 | 130.336 | 30.25565 | 0.647 | 2.1 | ug/L |
| Mo | 97 | 113784.015 | 0.5 | 59.667 | 31.37451 | 0.181 | 0.6 | ug/L |
| Mo | 98 | 288567.083 | 1.6 | 73.129 | 30.70323 | 0.764 | 2.5 | ug/L |
| Rh | 103 | 359372.610 | 3.1 | 377819.614 | | | | ug/L |
| Ag | 107 | 87.335 | 6.9 | 60.668 | 0.00189 | 0.000 | 20.5 | ug/L |
| Ag | 109 | 63.668 | 14.3 | 49.001 | 0.00113 | 0.001 | 63.5 | ug/L |
| Cd | 111 | 23.080 | 247.0 | 302.744 | -0.08756 | 0.018 | 20.7 | ug/L |
| Cd | 114 | 493.428 | 8.6 | 257.978 | 0.03582 | 0.007 | 18.6 | ug/L |
| > In | 115 | 365926.477 | 1.0 | 368464.817 | | | | ug/L |
| Sb | 121 | 4906.160 | 0.8 | 54.001 | 0.51674 | 0.009 | 1.7 | ug/L |
| Sb | 123 | 3719.456 | 2.3 | 50.513 | 0.51184 | 0.017 | 3.3 | ug/L |
| Ba | 135 | 64303.968 | 3.3 | 123.002 | 24.35000 | 0.982 | 4.0 | ug/L |
| Ba | 137 | 111856.866 | 0.9 | 192.338 | 24.63987 | 0.055 | 0.2 | ug/L |
| > Tb | 159 | 451283.563 | 1.1 | 460537.107 | | | | ug/L |
| > Ho | 165 | 429550.174 | 0.1 | 440378.521 | | | | ug/L |
| Tl | 203 | 179.337 | 4.2 | 83.668 | 0.01211 | 0.001 | 8.0 | ug/L |
| Tl | 205 | 391.346 | 8.1 | 163.337 | 0.01291 | 0.002 | 13.7 | ug/L |
| Pb | 208 | 809.690 | 3.4 | 1492.737 | -0.02525 | 0.001 | 4.3 | ug/L |

Sample ID: 948957

Report Date/Time: Friday, November 17, 2006 21:47:01

Page 1

597

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|-----------|
| | Pb | 206 | 211.338 | 8.1 | 397.348 | -0.02605 | 0.003 | 9.7 ug/L |
| | Pb | 207 | 187.004 | 8.8 | 320.010 | -0.02209 | 0.003 | 13.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 122.074 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 96.792 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 99.311 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 97.991 | | | |
| > [Ho | 165 | | 97.541 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Friday, November 17, 2006 21:49:56

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 3.065

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1155.092 | 2.6 | 84.001 | 0.92375 | 0.035 | 3.8 | ug/L |
| Al | 27 | 99073.101 | 0.1 | 6946.222 | 11.25234 | 0.424 | 3.8 | ug/L |
| > Sc | 45 | 406212.911 | 3.4 | 426236.083 | | | | ug/L |
| V | 51 | 22027.621 | 0.6 | 5344.504 | 1.04232 | 0.043 | 4.1 | ug/L |
| Cr | 52 | 31778.469 | 1.4 | 18378.762 | 1.01007 | 0.063 | 6.2 | ug/L |
| Cr | 53 | 2770.155 | 0.3 | 1484.814 | 0.76937 | 0.059 | 7.7 | ug/L |
| Mn | 55 | 21720.494 | 1.9 | 742.040 | 1.06950 | 0.013 | 1.2 | ug/L |
| Co | 59 | 17410.678 | 1.2 | 848.388 | 1.04542 | 0.015 | 1.5 | ug/L |
| Ni | 60 | 3951.310 | 1.9 | 167.670 | 1.05355 | 0.028 | 2.6 | ug/L |
| Ni | 62 | 1831.887 | 6.5 | 209.338 | 3.09921 | 0.195 | 6.3 | ug/L |
| Cu | 63 | 9703.410 | 1.1 | 570.693 | 1.09902 | 0.014 | 1.3 | ug/L |
| Cu | 65 | 4503.929 | 0.7 | 318.010 | 1.04831 | 0.016 | 1.5 | ug/L |
| Zn | 66 | 14285.383 | 2.7 | 2186.325 | 5.34671 | 0.147 | 2.7 | ug/L |
| Zn | 67 | 2264.997 | 2.7 | 469.352 | 4.57529 | 0.177 | 3.9 | ug/L |
| Zn | 68 | 10444.981 | 1.6 | 1708.532 | 5.35503 | 0.048 | 0.9 | ug/L |
| > Ge | 72 | 210593.983 | 0.8 | 235019.833 | | | | ug/L |
| As | 75 | 2977.562 | 2.0 | 174.004 | 1.05195 | 0.022 | 2.1 | ug/L |
| Se | 77 | 436.078 | 1.0 | 271.738 | 0.96336 | 0.039 | 4.0 | ug/L |
| Se | 78 | 16034.244 | 0.8 | 18294.754 | -0.56505 | 0.194 | 34.3 | mg/L |
| Se | 82 | 753.434 | 1.9 | 514.483 | 1.05963 | 0.028 | 2.6 | ug/L |
| Kr | 83 | 449.350 | 2.1 | 509.687 | | | | mg/L |
| Y | 89 | 397175.093 | 1.7 | 424645.807 | | | | ug/L |
| Mo | 95 | 5978.204 | 1.3 | 130.336 | 0.97797 | 0.008 | 0.9 | ug/L |
| Mo | 97 | 3809.242 | 2.0 | 59.667 | 1.03827 | 0.018 | 1.8 | ug/L |
| Mo | 98 | 9610.585 | 1.2 | 73.129 | 1.01869 | 0.019 | 1.9 | ug/L |
| Rh | 103 | 366107.031 | 2.3 | 377819.614 | | | | ug/L |
| Ag | 107 | 15444.119 | 0.5 | 60.668 | 1.07636 | 0.011 | 1.0 | ug/L |
| Ag | 109 | 14065.005 | 2.4 | 49.001 | 1.05629 | 0.030 | 2.8 | ug/L |
| Cd | 111 | 3567.415 | 2.0 | 302.744 | 1.03545 | 0.029 | 2.8 | ug/L |
| Cd | 114 | 7141.360 | 1.8 | 257.978 | 1.04323 | 0.026 | 2.5 | ug/L |
| > In | 115 | 364615.328 | 0.7 | 368464.817 | | | | ug/L |
| Sb | 121 | 9783.504 | 0.3 | 54.001 | 1.03981 | 0.010 | 0.9 | ug/L |
| Sb | 123 | 7515.699 | 2.0 | 50.513 | 1.04490 | 0.016 | 1.5 | ug/L |
| Ba | 135 | 2813.170 | 3.6 | 123.002 | 1.00051 | 0.048 | 4.8 | ug/L |
| Ba | 137 | 4830.115 | 2.8 | 192.338 | 1.00324 | 0.036 | 3.6 | ug/L |
| > Tb | 159 | 460440.454 | 1.8 | 460537.107 | | | | ug/L |
| > Ho | 165 | 444123.926 | 0.7 | 440378.521 | | | | ug/L |
| Tl | 203 | 8703.965 | 2.3 | 83.668 | 1.03329 | 0.027 | 2.6 | ug/L |
| Tl | 205 | 20819.516 | 0.3 | 163.337 | 1.11114 | 0.007 | 0.6 | ug/L |
| Pb | 208 | 27761.340 | 0.9 | 1492.737 | 0.99194 | 0.009 | 0.9 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Friday, November 17, 2006 21:52:57

Page 1

600

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 7064.398 | 1.9 | 397.348 | 0.95260 | 0.013 | 1.4 ug/L |
| | Pb | 207 | 6038.914 | 0.8 | 320.010 | 0.97607 | 0.006 | 0.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 92.375 | | | | |
| Al | 27 | 112.523 | | | | |
| > Sc | 45 | | 95.302 | | | |
| V | 51 | 104.232 | | | | |
| Cr | 52 | 101.007 | | | | |
| Cr | 53 | 76.937 | | | | |
| Mn | 55 | 106.950 | | | | |
| Co | 59 | 104.542 | | | | |
| Ni | 60 | 105.355 | | | | |
| Ni | 62 | 309.921 | | | | |
| Cu | 63 | 109.902 | | | | |
| Cu | 65 | 104.831 | | | | |
| Zn | 66 | 106.934 | | | | |
| Zn | 67 | 91.506 | | | | |
| Zn | 68 | 107.101 | | | | |
| > Ge | 72 | | 89.607 | | | |
| As | 75 | 105.195 | | | | |
| Se | 77 | 96.336 | | | | |
| Se | 78 | -56.505 | | | | |
| Se | 82 | 105.963 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 97.797 | | | | |
| Mo | 97 | 103.827 | | | | |
| Mo | 98 | 101.869 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 107.636 | | | | |
| Ag | 109 | 105.629 | | | | |
| Cd | 111 | 103.545 | | | | |
| Cd | 114 | 104.323 | | | | |
| > In | 115 | | 98.955 | | | |
| Sb | 121 | 103.981 | | | | |
| Sb | 123 | 104.490 | | | | |
| Ba | 135 | 100.051 | | | | |
| Ba | 137 | 100.324 | | | | |
| > Tb | 159 | | 99.979 | | | |
| > Ho | 165 | | 100.850 | | | |
| Tl | 203 | 103.329 | | | | |
| Tl | 205 | 111.114 | | | | |
| Pb | 208 | 99.194 | | | | |
| Pb | 206 | 95.260 | | | | |
| Pb | 207 | 97.607 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Friday, November 17, 2006 21:55:54

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 6.066

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55214.873 | 0.7 | 84.001 | 47.63101 | 0.929 | 2.0 | ug/L |
| Al | 27 | 466738.006 | 3.4 | 6946.222 | 56.28011 | 1.671 | 3.0 | ug/L |
| > Sc | 45 | 403869.817 | 1.5 | 426236.083 | | | | ug/L |
| V | 51 | 830958.715 | 0.3 | 5344.504 | 51.09256 | 0.912 | 1.8 | ug/L |
| Cr | 52 | 697317.569 | 3.1 | 18378.762 | 48.35866 | 0.820 | 1.7 | ug/L |
| Cr | 53 | 84644.035 | 2.3 | 1484.814 | 47.45151 | 0.903 | 1.9 | ug/L |
| Mn | 55 | 943532.807 | 0.5 | 742.040 | 48.97052 | 0.127 | 0.3 | ug/L |
| Co | 59 | 802062.215 | 1.4 | 848.388 | 51.43972 | 0.751 | 1.5 | ug/L |
| Ni | 60 | 184429.662 | 2.7 | 167.670 | 52.21588 | 1.285 | 2.5 | ug/L |
| Ni | 62 | 27795.254 | 3.3 | 209.338 | 53.22633 | 1.585 | 3.0 | ug/L |
| Cu | 63 | 426222.114 | 1.7 | 570.693 | 52.03953 | 0.713 | 1.4 | ug/L |
| Cu | 65 | 204459.072 | 2.8 | 318.010 | 51.86592 | 1.290 | 2.5 | ug/L |
| Zn | 66 | 113146.685 | 2.3 | 2186.325 | 49.33484 | 1.275 | 2.6 | ug/L |
| Zn | 67 | 20189.296 | 0.8 | 469.352 | 50.15657 | 0.538 | 1.1 | ug/L |
| Zn | 68 | 85161.802 | 0.7 | 1708.532 | 51.39167 | 0.365 | 0.7 | ug/L |
| > Ge | 72 | 205970.404 | 0.3 | 235019.833 | | | | ug/L |
| As | 75 | 131785.413 | 1.9 | 174.004 | 50.17460 | 0.909 | 1.8 | ug/L |
| Se | 77 | 10092.108 | 1.4 | 271.738 | 50.38806 | 0.703 | 1.4 | ug/L |
| Se | 78 | 47258.165 | 1.3 | 18294.754 | 50.27512 | 0.809 | 1.6 | mg/L |
| Se | 82 | 14151.139 | 0.9 | 514.483 | 50.76599 | 0.349 | 0.7 | ug/L |
| Kr | 83 | 471.351 | 7.4 | 509.687 | | | | mg/L |
| Y | 89 | 390912.604 | 1.4 | 424645.807 | | | | ug/L |
| Mo | 95 | 285341.459 | 2.3 | 130.336 | 48.17156 | 1.166 | 2.4 | ug/L |
| Mo | 97 | 175628.729 | 2.2 | 59.667 | 49.14170 | 2.669 | 5.4 | ug/L |
| Mo | 98 | 440092.708 | 1.6 | 73.129 | 47.50020 | 2.327 | 4.9 | ug/L |
| Rh | 103 | 360087.670 | 2.3 | 377819.614 | | | | ug/L |
| Ag | 107 | 727503.568 | 1.9 | 60.668 | 51.43747 | 2.302 | 4.5 | ug/L |
| Ag | 109 | 660302.611 | 1.4 | 49.001 | 50.26281 | 1.168 | 2.3 | ug/L |
| Cd | 111 | 160111.854 | 0.3 | 302.744 | 51.16852 | 1.818 | 3.6 | ug/L |
| Cd | 114 | 335295.517 | 2.7 | 257.978 | 51.31190 | 2.959 | 5.8 | ug/L |
| > In | 115 | 361077.582 | 3.2 | 368464.817 | | | | ug/L |
| Sb | 121 | 458342.187 | 1.8 | 54.001 | 49.50258 | 2.372 | 4.8 | ug/L |
| Sb | 123 | 351828.776 | 1.4 | 50.513 | 49.74935 | 1.577 | 3.2 | ug/L |
| Ba | 135 | 129370.347 | 2.0 | 123.002 | 48.70498 | 1.292 | 2.7 | ug/L |
| Ba | 137 | 225444.665 | 1.2 | 192.338 | 49.38754 | 1.550 | 3.1 | ug/L |
| > Tb | 159 | 454343.618 | 1.9 | 460537.107 | | | | ug/L |
| > Ho | 165 | 429376.864 | 1.4 | 440378.521 | | | | ug/L |
| Tl | 203 | 407733.493 | 1.9 | 83.668 | 50.55141 | 1.255 | 2.5 | ug/L |
| Tl | 205 | 924294.072 | 0.5 | 163.337 | 51.42575 | 0.585 | 1.1 | ug/L |
| Pb | 208 | 1276229.067 | 1.5 | 1492.737 | 49.82186 | 1.111 | 2.2 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Friday, November 17, 2006 21:58:56

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 328411.822 | 0.4 | 397.348 | 48.51335 | 0.830 | 1.7 ug/L |
| | Pb | 207 | 279012.393 | 1.9 | 320.010 | 49.22916 | 1.057 | 2.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 95.262 | | | | |
| Al | 27 | 112.560 | | | | |
| > Sc | 45 | | 94.753 | | | |
| V | 51 | 102.185 | | | | |
| Cr | 52 | 96.717 | | | | |
| Cr | 53 | 94.903 | | | | |
| Mn | 55 | 97.941 | | | | |
| Co | 59 | 102.879 | | | | |
| Ni | 60 | 104.432 | | | | |
| Ni | 62 | 106.453 | | | | |
| Cu | 63 | 104.079 | | | | |
| Cu | 65 | 103.732 | | | | |
| Zn | 66 | 98.670 | | | | |
| Zn | 67 | 100.313 | | | | |
| Zn | 68 | 102.783 | | | | |
| > Ge | 72 | | 87.640 | | | |
| As | 75 | 100.349 | | | | |
| Se | 77 | 100.776 | | | | |
| Se | 78 | 100.550 | | | | |
| Se | 82 | 101.532 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 96.343 | | | | |
| Mo | 97 | 98.283 | | | | |
| Mo | 98 | 95.000 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 102.875 | | | | |
| Ag | 109 | 100.526 | | | | |
| Cd | 111 | 102.337 | | | | |
| Cd | 114 | 102.624 | | | | |
| > In | 115 | | 97.995 | | | |
| Sb | 121 | 99.005 | | | | |
| Sb | 123 | 99.499 | | | | |
| Ba | 135 | 97.410 | | | | |
| Ba | 137 | 98.775 | | | | |
| > Tb | 159 | | 98.655 | | | |
| > Ho | 165 | | 97.502 | | | |
| Tl | 203 | 101.103 | | | | |
| Tl | 205 | 102.851 | | | | |
| Pb | 208 | 99.644 | | | | |
| Pb | 206 | 97.027 | | | | |
| Pb | 207 | 98.458 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Friday, November 17, 2006 22:01:52

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\111706\QC Std 7.067

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 63.001 | 12.0 | 84.001 | -0.01316 | 0.008 | 57.0 | ug/L |
| Al | 27 | 3918.627 | 1.4 | 6946.222 | -0.31603 | 0.004 | 1.4 | ug/L |
| > Sc | 45 | 395881.287 | 1.7 | 426236.083 | | | | ug/L |
| V | 51 | 4992.952 | 4.4 | 5344.504 | 0.00184 | 0.013 | 714.8 | ug/L |
| Cr | 52 | 16534.901 | 3.7 | 18378.762 | -0.03882 | 0.039 | 101.1 | ug/L |
| Cr | 53 | 932.061 | 0.9 | 1484.814 | -0.25990 | 0.007 | 2.7 | ug/L |
| Mn | 55 | 758.709 | 16.5 | 742.040 | 0.00555 | 0.007 | 127.7 | ug/L |
| Co | 59 | 241.006 | 14.4 | 848.388 | -0.03227 | 0.003 | 8.0 | ug/L |
| Ni | 60 | 127.336 | 7.7 | 167.670 | -0.00570 | 0.003 | 45.3 | ug/L |
| Ni | 62 | 752.708 | 5.4 | 209.338 | 1.09294 | 0.100 | 9.1 | ug/L |
| Cu | 63 | 673.701 | 3.3 | 570.693 | 0.02097 | 0.005 | 22.3 | ug/L |
| Cu | 65 | 189.004 | 6.4 | 318.010 | -0.02299 | 0.002 | 10.7 | ug/L |
| Zn | 66 | 1265.109 | 1.2 | 2186.325 | -0.29055 | 0.020 | 6.9 | ug/L |
| Zn | 67 | 292.341 | 9.7 | 469.352 | -0.30323 | 0.089 | 29.2 | ug/L |
| Zn | 68 | 1042.742 | 1.5 | 1708.532 | -0.28155 | 0.012 | 4.3 | ug/L |
| > Ge | 72 | 206771.726 | 2.7 | 235019.833 | | | | ug/L |
| As | 75 | 175.004 | 7.0 | 174.004 | 0.00843 | 0.006 | 74.7 | ug/L |
| Se | 77 | 229.536 | 0.8 | 271.738 | -0.04818 | 0.024 | 48.8 | ug/L |
| Se | 78 | 15544.047 | 0.4 | 18294.754 | -0.87168 | 0.749 | 85.9 | mg/L |
| Se | 82 | 479.680 | 1.4 | 514.483 | 0.10084 | 0.063 | 62.2 | ug/L |
| Kr | 83 | 458.017 | 1.2 | 509.687 | | | | mg/L |
| Y | 89 | 384842.100 | 0.2 | 424645.807 | | | | ug/L |
| Mo | 95 | 853.387 | 20.1 | 130.336 | 0.12257 | 0.031 | 25.3 | ug/L |
| Mo | 97 | 530.356 | 26.5 | 59.667 | 0.13205 | 0.042 | 31.5 | ug/L |
| Mo | 98 | 1235.421 | 25.9 | 73.129 | 0.12563 | 0.037 | 29.2 | ug/L |
| Rh | 103 | 358179.049 | 0.8 | 377819.614 | | | | ug/L |
| Ag | 107 | 162.670 | 5.9 | 60.668 | 0.00729 | 0.001 | 12.8 | ug/L |
| Ag | 109 | 145.669 | 2.1 | 49.001 | 0.00742 | 0.000 | 5.3 | ug/L |
| Cd | 111 | 217.836 | 10.1 | 302.744 | -0.02535 | 0.007 | 26.3 | ug/L |
| Cd | 114 | 67.198 | 12.9 | 257.978 | -0.02841 | 0.001 | 4.4 | ug/L |
| > In | 115 | 361628.837 | 2.2 | 368464.817 | | | | ug/L |
| Sb | 121 | 1169.428 | 12.5 | 54.001 | 0.12046 | 0.018 | 14.7 | ug/L |
| Sb | 123 | 920.839 | 16.0 | 50.513 | 0.12316 | 0.023 | 18.4 | ug/L |
| Ba | 135 | 52.001 | 20.4 | 123.002 | -0.02583 | 0.004 | 15.2 | ug/L |
| Ba | 137 | 62.334 | 1.9 | 192.338 | -0.02771 | 0.001 | 2.0 | ug/L |
| > Tb | 159 | 447459.663 | 2.6 | 460537.107 | | | | ug/L |
| > Ho | 165 | 427232.949 | 0.9 | 440378.521 | | | | ug/L |
| Tl | 203 | 72.001 | 9.7 | 83.668 | -0.00114 | 0.001 | 83.1 | ug/L |
| Tl | 205 | 151.003 | 20.8 | 163.337 | -0.00041 | 0.002 | 447.2 | ug/L |
| Pb | 208 | 462.343 | 3.9 | 1492.737 | -0.03871 | 0.001 | 2.2 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Friday, November 17, 2006 22:04:52

Page 1

606

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|----------|
| | Pb | 206 | 124.336 | 13.7 | 397.348 | -0.03880 | 0.003 | 6.9 ug/L |
| | Pb | 207 | 115.002 | 4.8 | 320.010 | -0.03470 | 0.001 | 2.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 92.878 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 87.981 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.145 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.160 | | | |
| > Ho | 165 | | 97.015 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Metals Cover Page

Analyst: SDevito

Date: 11/20/06

Instrument: ELAN

Data File: 112006

Reviewed By: SD 11/21/06

Entered By: SD 11/21/06

Manager Approval: 11/22/06 DCB

| Starlims Run # | Analytes Used | Batch ID | Method | Failed Analytes | Comments/ Problems |
|----------------|---------------|-----------|--------|-----------------|--------------------|
| 137755 | Be As | 113990143 | 6020 | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

Package Data:

| Client Sub# | Package | Analytes Used | Failed Metals | Batch ID | Stds Attached? | Transferred To LIMS | Raw Data Copied? |
|-------------|---------|---------------|---------------|-----------|----------------|---------------------|------------------|
| ✓ 34493 | 5 / ASP | Be | | 113990143 | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| ✓ 3432 | 5 / ASP | As | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |

609

Daily Performance Report

Sample ID: Sample

Sample Date/Time: Monday, November 20, 2006 09:10:13

Sample Description:

Method File: c:\elandata\Method\EPA DAILY.mth

Dataset File: c:\elandata\Dataset\Daily2006\Sample.240

Tuning File: c:\elandata\Tuning\epa.tun

Optimization File: c:\elandata\Optimize\epa2.dac

Dual Detector Mode: Dual

Acq. Dead Time(ns): 60

Current Dead Time (ns): 60

Summary

| Analyte | Mass | Meas. Intens. | Mean | Net Intens. | Mean | Net Intens. | SD | Net Intens. | RSD |
|---------|-------|---------------|----------|-------------|------------|-------------|----------|-------------|------|
| Mg | 24.0 | | 66326.1 | | 66326.123 | | 534.130 | | 0.8 |
| Rh | 102.9 | | 399277.0 | | 399277.029 | | 3951.207 | | 1.0 |
| In | 114.9 | | 393385.8 | | 393385.819 | | 3500.274 | | 0.9 |
| Pb | 208.0 | | 154126.3 | | 154126.281 | | 1933.854 | | 1.3 |
| U | 238.1 | | 257610.8 | | 257610.828 | | 3191.300 | | 1.2 |
| [> Ba | 137.9 | | 313139.0 | | 313138.969 | | 4124.598 | | 1.3 |
| [Ba++ | 69.0 | | 8109.0 | | 0.026 | | 0.000 | | 0.7 |
| [> Ce | 139.9 | | 434724.4 | | 434724.424 | | 4195.323 | | 1.0 |
| [CeO | 155.9 | | 8719.0 | | 0.020 | | 0.000 | | 1.1 |
| Bkgd | 220.0 | | 38.0 | | 38.004 | | 7.281 | | 19.2 |

Current Optimization File Data

| Current Value | Description |
|---------------|-------------------------|
| 1.01 | Nebulizer Gas Flow |
| 8.00 | Lens Voltage |
| 1500.00 | ICP RF Power |
| -1832.50 | Analog Stage Voltage |
| 1017.50 | Pulse Stage Voltage |
| 70.00 | Discriminator Threshold |
| -2.50 | AC Rod Offset |

Current Autolens Data

| Analyte | Mass | Num of Pts | DAC Value | Maximum Intensity |
|---------|------|------------|-----------|-------------------|
| Be | 9 | 29 | 6.0 | 11347.2 |
| Co | 59 | 29 | 7.8 | 163395.3 |
| In | 115 | 29 | 8.0 | 266809.4 |

Elan 9000 Method 6020 - Summary Report

Sample ID: Blank

Sample Date/Time: Monday, November 20, 2006 09:28:55

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\Blank.001

*Substo
11/20/06*

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 51.334 | 4.9 | | | | | ug/L |
| Al | 27 | 4379.197 | 6.3 | | | | | ug/L |
| > Sc | 45 | 424656.486 | 0.9 | | | | | ug/L |
| V | 51 | 5557.188 | 2.0 | | | | | ug/L |
| Cr | 52 | 18419.857 | 1.8 | | | | | ug/L |
| Cr | 53 | 945.730 | 3.9 | | | | | ug/L |
| Mn | 55 | 692.369 | 2.5 | | | | | ug/L |
| Co | 59 | 265.007 | 8.0 | | | | | ug/L |
| Ni | 60 | 177.337 | 8.0 | | | | | ug/L |
| Ni | 62 | 902.391 | 4.3 | | | | | ug/L |
| Cu | 63 | 876.388 | 2.9 | | | | | ug/L |
| Cu | 65 | 254.340 | 2.6 | | | | | ug/L |
| Zn | 66 | 2747.481 | 3.2 | | | | | ug/L |
| Zn | 67 | 502.020 | 5.7 | | | | | ug/L |
| Zn | 68 | 1975.921 | 5.0 | | | | | ug/L |
| > Ge | 72 | 227398.462 | 1.9 | | | | | ug/L |
| As | 75 | 127.002 | 5.7 | | | | | ug/L |
| Se | 77 | 226.870 | 4.8 | | | | | ug/L |
| Se | 78 | 16063.843 | 1.1 | | | | | mg/L |
| Se | 82 | 661.626 | 1.8 | | | | | ug/L |
| Kr | 83 | 694.703 | 7.1 | | | | | mg/L |
| Y | 89 | 420425.593 | 3.2 | | | | | ug/L |
| Mo | 95 | 127.336 | 14.6 | | | | | ug/L |
| Mo | 97 | 61.668 | 10.8 | | | | | ug/L |
| Mo | 98 | 69.388 | 3.6 | | | | | ug/L |
| Rh | 103 | 381957.031 | 2.0 | | | | | ug/L |
| Ag | 107 | 56.667 | 7.3 | | | | | ug/L |
| Ag | 109 | 52.667 | 15.5 | | | | | ug/L |
| Cd | 111 | 249.856 | 6.9 | | | | | ug/L |
| Cd | 114 | 64.386 | 13.6 | | | | | ug/L |
| > In | 115 | 396447.935 | 1.8 | | | | | ug/L |
| Sb | 121 | 62.334 | 5.6 | | | | | ug/L |
| Sb | 123 | 53.222 | 14.5 | | | | | ug/L |
| Ba | 135 | 56.334 | 11.8 | | | | | ug/L |
| Ba | 137 | 65.001 | 43.9 | | | | | ug/L |
| > Tb | 159 | 486746.910 | 1.2 | | | | | ug/L |
| > Ho | 165 | 457509.069 | 2.4 | | | | | ug/L |
| Tl | 203 | 48.667 | 34.5 | | | | | ug/L |
| Tl | 205 | 63.334 | 16.9 | | | | | ug/L |
| Pb | 208 | 537.345 | 9.2 | | | | | ug/L |

Sample ID: Blank

Report Date/Time: Monday, November 20, 2006 09:31:55

Page 1

611

| | | | | | |
|--|----|-----|---------|------|------|
| | Pb | 206 | 135.336 | 14.1 | ug/L |
| | Pb | 207 | 124.336 | 10.8 | ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 1

Sample Date/Time: Monday, November 20, 2006 09:34:51

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\Standard 1.002

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 12326.568 | 1.5 | 51.334 | 10.00000 | 0.398 | 4.0 | ug/L |
| Al | 27 | 97243.445 | 1.3 | 4379.197 | 10.00000 | 0.351 | 3.5 | ug/L |
| > Sc | 45 | 427166.615 | 2.5 | 424656.486 | | | | ug/L |
| V | 51 | 185329.913 | 0.7 | 5557.188 | 10.00000 | 0.242 | 2.4 | ug/L |
| Cr | 52 | 169769.343 | 1.1 | 18419.857 | 10.00000 | 0.324 | 3.2 | ug/L |
| Cr | 53 | 19162.202 | 1.7 | 945.730 | 10.00000 | 0.104 | 1.0 | ug/L |
| Mn | 55 | 206393.757 | 1.6 | 692.369 | 10.00000 | 0.231 | 2.3 | ug/L |
| Co | 59 | 187160.434 | 1.2 | 265.007 | 10.00000 | 0.205 | 2.0 | ug/L |
| Ni | 60 | 40075.239 | 2.6 | 177.337 | 10.00000 | 0.345 | 3.5 | ug/L |
| Ni | 62 | 6630.703 | 1.1 | 902.391 | 10.00000 | 0.031 | 0.3 | ug/L |
| Cu | 63 | 93099.168 | 1.6 | 876.388 | 10.00000 | 0.191 | 1.9 | ug/L |
| Cu | 65 | 43587.502 | 2.3 | 254.340 | 10.00000 | 0.297 | 3.0 | ug/L |
| Zn | 66 | 27190.235 | 1.9 | 2747.481 | 10.00000 | 0.121 | 1.2 | ug/L |
| Zn | 67 | 4776.751 | 3.1 | 502.020 | 10.00000 | 0.413 | 4.1 | ug/L |
| Zn | 68 | 19607.909 | 1.9 | 1975.921 | 10.00000 | 0.296 | 3.0 | ug/L |
| > Ge | 72 | 221797.899 | 0.9 | 227398.462 | | | | ug/L |
| As | 75 | 29036.123 | 0.7 | 127.002 | 10.00000 | 0.030 | 0.3 | ug/L |
| Se | 77 | 2326.458 | 0.8 | 226.870 | 10.00000 | 0.174 | 1.7 | ug/L |
| Se | 78 | 22397.263 | 2.9 | 16063.843 | 10.00000 | 1.228 | 12.3 | mg/L |
| Se | 82 | 3560.360 | 0.5 | 661.626 | 10.00000 | 0.064 | 0.6 | ug/L |
| Kr | 83 | 714.371 | 2.5 | 694.703 | | | | mg/L |
| Y | 89 | 412374.984 | 3.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 61576.612 | 0.3 | 127.336 | 10.00000 | 0.072 | 0.7 | ug/L |
| Mo | 97 | 37814.998 | 1.7 | 51.668 | 10.00000 | 0.143 | 1.4 | ug/L |
| Mo | 98 | 96879.423 | 2.0 | 69.388 | 10.00000 | 0.184 | 1.8 | ug/L |
| Rh | 103 | 360584.485 | 0.7 | 381957.031 | | | | ug/L |
| Ag | 107 | 159265.738 | 1.7 | 56.667 | 10.00000 | 0.162 | 1.6 | ug/L |
| Ag | 109 | 146354.513 | 0.9 | 52.667 | 10.00000 | 0.121 | 1.2 | ug/L |
| Cd | 111 | 34295.315 | 2.8 | 249.856 | 10.00000 | 0.246 | 2.5 | ug/L |
| Cd | 114 | 75659.600 | 0.6 | 64.386 | 10.00000 | 0.080 | 0.8 | ug/L |
| > In | 115 | 391995.817 | 0.4 | 396447.935 | | | | ug/L |
| Sb | 121 | 103659.177 | 1.4 | 62.334 | 10.00000 | 0.182 | 1.8 | ug/L |
| Sb | 123 | 79929.429 | 0.5 | 53.222 | 10.00000 | 0.086 | 0.9 | ug/L |
| Ba | 135 | 26788.604 | 2.2 | 56.334 | 10.00000 | 0.234 | 2.3 | ug/L |
| Ba | 137 | 45975.939 | 0.5 | 65.001 | 10.00000 | 0.171 | 1.7 | ug/L |
| > Tb | 159 | 459528.710 | 1.4 | 486746.910 | | | | ug/L |
| > Ho | 165 | 456269.472 | 0.6 | 457509.069 | | | | ug/L |
| Tl | 203 | 89670.788 | 0.9 | 48.667 | 10.00000 | 0.083 | 0.8 | ug/L |
| Tl | 205 | 209945.065 | 2.4 | 63.334 | 10.00000 | 0.280 | 2.8 | ug/L |
| Pb | 208 | 286226.658 | 1.4 | 537.345 | 10.00000 | 0.133 | 1.3 | ug/L |

Sample ID: Standard 1

Report Date/Time: Monday, November 20, 2006 09:37:52

Page 1

| | | | | | | | | |
|--|----|-----|-----------|-----|---------|----------|-------|----------|
| | Pb | 206 | 74588.443 | 1.5 | 135.336 | 10.00000 | 0.148 | 1.5 ug/L |
| | Pb | 207 | 62628.451 | 1.5 | 124.336 | 10.00000 | 0.101 | 1.0 ug/L |

Sample ID: Standard 1

Report Date/Time: Monday, November 20, 2006 09:37:52

Page 2

614

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 2

Sample Date/Time: Monday, November 20, 2006 09:40:48

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\Standard 2.003

| | Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| [| Be | 9 | 24263.527 | 2.3 | 51.334 | 20.08519 | 0.255 | 1.3 | ug/L |
| [| Al | 27 | 192349.230 | 1.7 | 4379.197 | 20.19157 | 0.595 | 2.9 | ug/L |
| > | Sc | 45 | 412106.689 | 1.8 | 424656.486 | | | | ug/L |
| | V | 51 | 346707.861 | 0.5 | 5557.188 | 19.93494 | 0.263 | 1.3 | ug/L |
| | Cr | 52 | 312384.877 | 2.0 | 18419.857 | 20.03538 | 0.517 | 2.6 | ug/L |
| [| Cr | 53 | 36055.206 | 1.8 | 945.730 | 19.99938 | 0.044 | 0.2 | ug/L |
| [| Mn | 55 | 412588.379 | 1.9 | 692.369 | 20.03801 | 0.138 | 0.7 | ug/L |
| | Co | 59 | 352924.032 | 0.7 | 265.007 | 19.79816 | 0.212 | 1.1 | ug/L |
| | Ni | 60 | 79680.392 | 2.4 | 177.337 | 20.01812 | 0.242 | 1.2 | ug/L |
| | Ni | 62 | 12571.942 | 3.3 | 902.391 | 20.10153 | 0.597 | 3.0 | ug/L |
| | Cu | 63 | 176140.639 | 1.2 | 876.388 | 19.82759 | 0.336 | 1.7 | ug/L |
| | Cu | 65 | 86136.820 | 1.6 | 254.340 | 19.99692 | 0.124 | 0.6 | ug/L |
| | Zn | 66 | 51434.437 | 1.2 | 2747.481 | 20.01456 | 0.172 | 0.9 | ug/L |
| | Zn | 67 | 8894.500 | 1.1 | 502.020 | 19.95629 | 0.504 | 2.5 | ug/L |
| | Zn | 68 | 37696.148 | 2.6 | 1975.921 | 20.08035 | 0.363 | 1.8 | ug/L |
| > | Ge | 72 | 219915.494 | 1.4 | 227398.462 | | | | ug/L |
| | As | 75 | 57547.972 | 1.8 | 127.002 | 20.00738 | 0.615 | 3.1 | ug/L |
| | Se | 77 | 4402.429 | 0.6 | 226.870 | 20.00820 | 0.326 | 1.6 | ug/L |
| | Se | 78 | 28726.535 | 0.9 | 16063.843 | 19.95243 | 0.776 | 3.9 | mg/L |
| | Se | 82 | 6488.458 | 0.2 | 661.626 | 20.04704 | 0.311 | 1.6 | ug/L |
| | Kr | 83 | 741.707 | 3.2 | 694.703 | | | | mg/L |
| [| Y | 89 | 399246.420 | 0.8 | 420425.593 | | | | ug/L |
| [| Mo | 95 | 117523.764 | 2.6 | 127.336 | 19.87786 | 0.682 | 3.4 | ug/L |
| | Mo | 97 | 73982.039 | 1.0 | 61.668 | 19.97804 | 0.653 | 3.3 | ug/L |
| | Mo | 98 | 187389.076 | 1.2 | 69.388 | 19.92967 | 0.525 | 2.6 | ug/L |
| | Rh | 103 | 365362.993 | 0.6 | 381957.031 | | | | ug/L |
| | Ag | 107 | 304905.478 | 2.2 | 56.667 | 19.88620 | 0.334 | 1.7 | ug/L |
| | Ag | 109 | 283102.135 | 0.8 | 52.667 | 19.92985 | 0.690 | 3.5 | ug/L |
| | Cd | 111 | 68612.220 | 1.0 | 249.856 | 20.07840 | 0.600 | 3.0 | ug/L |
| | Cd | 114 | 150971.981 | 0.8 | 64.386 | 20.05561 | 0.753 | 3.8 | ug/L |
| > | In | 115 | 386126.181 | 3.0 | 396447.935 | | | | ug/L |
| | Sb | 121 | 198687.480 | 1.0 | 62.334 | 19.89355 | 0.779 | 3.9 | ug/L |
| [| Sb | 123 | 154225.661 | 1.1 | 53.222 | 19.91936 | 0.470 | 2.4 | ug/L |
| [| Ba | 135 | 51789.296 | 1.3 | 56.334 | 19.74722 | 0.247 | 1.3 | ug/L |
| | Ba | 137 | 90847.226 | 2.1 | 65.001 | 19.83537 | 0.204 | 1.0 | ug/L |
| > | Tb | 159 | 473043.277 | 1.1 | 486746.910 | | | | ug/L |
| > | Ho | 165 | 448888.318 | 1.3 | 457509.069 | | | | ug/L |
| | Tl | 203 | 174290.897 | 0.7 | 48.667 | 19.95209 | 0.162 | 0.8 | ug/L |
| | Tl | 205 | 415018.587 | 2.3 | 63.334 | 20.01843 | 0.209 | 1.0 | ug/L |
| | Pb | 208 | 553131.013 | 1.0 | 537.345 | 19.93131 | 0.089 | 0.4 | ug/L |

Sample ID: Standard 2

Report Date/Time: Monday, November 20, 2006 09:43:50

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 142556.141 | 0.9 | 135.336 | 19.88683 | 0.397 | 2.0 ug/L |
| | Pb | 207 | 122512.936 | 1.0 | 124.336 | 19.98095 | 0.229 | 1.1 ug/L |

Sample ID: Standard 2

Report Date/Time: Monday, November 20, 2006 09:43:50

Page 2

616

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 3

Sample Date/Time: Monday, November 20, 2006 09:46:46

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\Standard 3.004

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 116963.264 | 2.5 | 51.334 | 99.85325 | 1.851 | 1.9 | ug/L |
| Al | 27 | 885750.375 | 1.0 | 4379.197 | 99.73051 | 0.842 | 0.8 | ug/L |
| > Sc | 45 | 411970.651 | 0.8 | 424656.486 | | | | ug/L |
| V | 51 | 1639024.506 | 2.2 | 5557.188 | 99.77227 | 1.640 | 1.6 | ug/L |
| Cr | 52 | 1407568.772 | 1.1 | 18419.857 | 99.72650 | 0.629 | 0.6 | ug/L |
| Cr | 53 | 174240.467 | 1.7 | 945.730 | 99.93630 | 0.895 | 0.9 | ug/L |
| Mn | 55 | 1909771.440 | 1.2 | 692.369 | 99.66429 | 2.756 | 2.8 | ug/L |
| Co | 59 | 1687375.823 | 1.4 | 265.007 | 99.76213 | 2.746 | 2.8 | ug/L |
| Ni | 60 | 368976.325 | 2.4 | 177.337 | 99.66340 | 3.288 | 3.3 | ug/L |
| Ni | 62 | 56832.746 | 1.8 | 902.391 | 99.83803 | 3.333 | 3.3 | ug/L |
| Cu | 63 | 864096.279 | 3.0 | 876.388 | 99.91117 | 3.477 | 3.5 | ug/L |
| Cu | 65 | 416575.209 | 1.2 | 254.340 | 99.87602 | 1.890 | 1.9 | ug/L |
| Zn | 66 | 243344.582 | 1.7 | 2747.481 | 99.96591 | 1.175 | 1.2 | ug/L |
| Zn | 67 | 41849.249 | 1.4 | 502.020 | 99.93673 | 2.270 | 2.3 | ug/L |
| Zn | 68 | 175525.371 | 0.4 | 1975.921 | 99.90131 | 1.721 | 1.7 | ug/L |
| > Ge | 72 | 218756.715 | 1.6 | 227398.462 | | | | ug/L |
| As | 75 | 273016.224 | 1.9 | 127.002 | 99.78070 | 3.269 | 3.3 | ug/L |
| Se | 77 | 20658.375 | 0.6 | 226.870 | 99.91757 | 2.204 | 2.2 | ug/L |
| Se | 78 | 79641.036 | 1.9 | 16063.843 | 99.88273 | 3.200 | 3.2 | mg/L |
| Se | 82 | 28822.090 | 0.1 | 661.626 | 99.85938 | 1.774 | 1.8 | ug/L |
| Kr | 83 | 782.045 | 1.0 | 694.703 | | | | mg/L |
| Y | 89 | 405021.557 | 1.9 | 420425.593 | | | | ug/L |
| Mo | 95 | 577067.749 | 4.2 | 127.336 | 100.01923 | 3.278 | 3.3 | ug/L |
| Mo | 97 | 352063.186 | 2.4 | 61.668 | 99.89178 | 1.724 | 1.7 | ug/L |
| Mo | 98 | 937600.330 | 3.5 | 69.388 | 100.11750 | 2.736 | 2.7 | ug/L |
| Rh | 103 | 357502.237 | 2.3 | 381957.031 | | | | ug/L |
| Ag | 107 | 1400004.577 | 2.7 | 56.667 | 99.69169 | 2.428 | 2.4 | ug/L |
| Ag | 109 | 1346921.753 | 2.1 | 52.667 | 99.87757 | 3.163 | 3.2 | ug/L |
| Cd | 111 | 315159.035 | 1.9 | 249.856 | 99.75348 | 1.561 | 1.6 | ug/L |
| Cd | 114 | 711035.416 | 2.7 | 64.386 | 99.85945 | 3.657 | 3.7 | ug/L |
| > In | 115 | 375476.884 | 2.2 | 396447.935 | | | | ug/L |
| Sb | 121 | 973656.757 | 1.5 | 62.334 | 100.01062 | 2.263 | 2.3 | ug/L |
| Sb | 123 | 734655.444 | 1.8 | 53.222 | 99.88322 | 3.446 | 3.5 | ug/L |
| Ba | 135 | 255887.493 | 1.2 | 56.334 | 100.01490 | 0.991 | 1.0 | ug/L |
| Ba | 137 | 434911.243 | 1.9 | 65.001 | 99.88367 | 1.894 | 1.9 | ug/L |
| > Tb | 159 | 460471.643 | 0.4 | 486746.910 | | | | ug/L |
| > Ho | 165 | 442235.476 | 2.4 | 457509.069 | | | | ug/L |
| Tl | 203 | 806044.301 | 2.5 | 48.667 | 99.67945 | 0.245 | 0.2 | ug/L |
| Tl | 205 | 1829793.189 | 1.4 | 63.334 | 99.45182 | 1.606 | 1.6 | ug/L |
| Pb | 208 | 2582570.086 | 2.1 | 537.345 | 99.72530 | 0.377 | 0.4 | ug/L |

Sample ID: Standard 3

Report Date/Time: Monday, November 20, 2006 09:49:48

Page 1

617

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 678474.785 | 2.5 | 135.336 | 99.80860 | 0.956 | 1.0 ug/L |
| | Pb | 207 | 569615.036 | 2.0 | 124.336 | 99.71684 | 0.666 | 0.7 ug/L |

Quantitative Analysis Calibration Report

File Name: 112006.cal
File Path: C:\elandata\System
Calibration Type: External Calibration

| Analyte | Mass | Curve Type | Slope | Intercept | Corr. Coeff. |
|---------|---------|------------------|-------|-----------|--------------|
| Be | 9.012 | Linear Thru Zero | 0.00 | 0.00 | 0.999977 |
| Al | 26.982 | Linear Thru Zero | 0.02 | 0.00 | 0.999918 |
| Sc | 44.956 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| V | 50.944 | Linear Thru Zero | 0.04 | 0.00 | 0.999947 |
| Cr | 51.941 | Linear Thru Zero | 0.03 | 0.00 | 0.999925 |
| Cr | 52.941 | Linear Thru Zero | 0.00 | 0.00 | 0.999996 |
| Mn | 54.938 | Linear Thru Zero | 0.09 | 0.00 | 0.999887 |
| Co | 58.933 | Linear Thru Zero | 0.08 | 0.00 | 0.999933 |
| Ni | 59.933 | Linear Thru Zero | 0.02 | 0.00 | 0.999887 |
| Ni | 61.928 | Linear Thru Zero | 0.00 | 0.00 | 0.999971 |
| Cu | 62.930 | Linear Thru Zero | 0.04 | 0.00 | 0.999985 |
| Cu | 64.928 | Linear Thru Zero | 0.02 | 0.00 | 0.999985 |
| Zn | 65.926 | Linear Thru Zero | 0.01 | 0.00 | 0.999999 |
| Zn | 66.927 | Linear Thru Zero | 0.00 | 0.00 | 0.999996 |
| Zn | 67.925 | Linear Thru Zero | 0.01 | 0.00 | 0.999989 |
| Ge | 71.922 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| As | 74.922 | Linear Thru Zero | 0.01 | 0.00 | 0.999952 |
| Se | 76.920 | Linear Thru Zero | 0.00 | 0.00 | 0.999993 |
| Se | 77.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999986 |
| Se | 81.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999980 |
| Kr | 82.914 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Y | 88.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Mo | 94.906 | Linear Thru Zero | 0.02 | 0.00 | 0.999996 |
| Mo | 96.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999988 |
| Mo | 97.906 | Linear Thru Zero | 0.02 | 0.00 | 0.999985 |
| Rh | 102.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ag | 106.905 | Linear Thru Zero | 0.04 | 0.00 | 0.999901 |
| Ag | 108.905 | Linear Thru Zero | 0.04 | 0.00 | 0.999984 |
| Cd | 110.904 | Linear Thru Zero | 0.01 | 0.00 | 0.999938 |
| Cd | 113.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999979 |
| In | 114.904 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Sb | 120.904 | Linear Thru Zero | 0.03 | 0.00 | 0.999997 |
| Sb | 122.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999985 |
| Ba | 134.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999985 |
| Ba | 136.905 | Linear Thru Zero | 0.01 | 0.00 | 0.999980 |
| Tb | 158.925 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ho | 164.930 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Tl | 202.972 | Linear Thru Zero | 0.02 | 0.00 | 0.999897 |
| Tl | 204.975 | Linear Thru Zero | 0.04 | 0.00 | 0.999700 |
| Pb | 207.977 | Linear Thru Zero | 0.06 | 0.00 | 0.999923 |

| | | | | | |
|----|---------|------------------|------|------|----------|
| Pb | 205.975 | Linear Thru Zero | 0.02 | 0.00 | 0.999960 |
| Pb | 206.976 | Linear Thru Zero | 0.01 | 0.00 | 0.999920 |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 1

Sample Date/Time: Monday, November 20, 2006 09:52:45

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 1.005

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 56363.204 | 0.8 | 51.334 | 48.56301 | 0.794 | 1.6 | ug/L |
| Al | 27 | 461766.711 | 1.6 | 4379.197 | 52.27935 | 1.916 | 3.7 | ug/L |
| > Sc | 45 | 408128.977 | 2.1 | 424656.486 | | | | ug/L |
| V | 51 | 839940.342 | 0.9 | 5557.188 | 51.47403 | 1.419 | 2.8 | ug/L |
| Cr | 52 | 726109.869 | 0.5 | 18419.857 | 51.33193 | 1.232 | 2.4 | ug/L |
| Cr | 53 | 85797.304 | 1.2 | 945.730 | 49.41709 | 0.695 | 1.4 | ug/L |
| Mn | 55 | 1001609.294 | 1.3 | 692.369 | 53.76342 | 0.963 | 1.8 | ug/L |
| Co | 59 | 834724.001 | 2.2 | 265.007 | 50.76270 | 0.740 | 1.5 | ug/L |
| Ni | 60 | 188360.899 | 1.6 | 177.337 | 52.32071 | 0.329 | 0.6 | ug/L |
| Ni | 62 | 30099.573 | 1.8 | 902.391 | 53.68771 | 0.449 | 0.8 | ug/L |
| Cu | 63 | 438416.023 | 1.4 | 876.388 | 52.11123 | 0.600 | 1.2 | ug/L |
| Cu | 65 | 209076.892 | 1.8 | 254.340 | 51.55763 | 1.375 | 2.7 | ug/L |
| Zn | 66 | 119701.080 | 2.4 | 2747.481 | 50.06361 | 1.351 | 2.7 | ug/L |
| Zn | 67 | 20144.522 | 1.1 | 502.020 | 48.90719 | 0.384 | 0.8 | ug/L |
| Zn | 68 | 86475.958 | 1.4 | 1975.921 | 50.10783 | 1.094 | 2.2 | ug/L |
| > Ge | 72 | 212572.695 | 1.0 | 227398.462 | | | | ug/L |
| As | 75 | 133716.756 | 1.5 | 127.002 | 50.25290 | 0.520 | 1.0 | ug/L |
| Se | 77 | 10387.938 | 1.0 | 226.870 | 51.17749 | 0.071 | 0.1 | ug/L |
| Se | 78 | 46598.795 | 1.3 | 16063.843 | 50.56247 | 0.517 | 1.0 | mg/L |
| Se | 82 | 14800.466 | 0.9 | 661.626 | 51.70271 | 0.887 | 1.7 | ug/L |
| Kr | 83 | 779.378 | 2.2 | 694.703 | | | | mg/L |
| Y | 89 | 402262.609 | 1.0 | 420425.593 | | | | ug/L |
| Mo | 95 | 282530.326 | 3.6 | 127.336 | 50.08732 | 1.127 | 2.3 | ug/L |
| Mo | 97 | 181015.449 | 1.0 | 51.668 | 52.54408 | 0.652 | 1.2 | ug/L |
| Mo | 98 | 458820.570 | 2.8 | 69.388 | 50.12179 | 0.968 | 1.9 | ug/L |
| Rh | 103 | 353102.234 | 1.0 | 381957.031 | | | | ug/L |
| Ag | 107 | 702246.697 | 0.4 | 56.667 | 51.16927 | 1.164 | 2.3 | ug/L |
| Ag | 109 | 659590.099 | 1.8 | 52.667 | 50.02685 | 0.697 | 1.4 | ug/L |
| Cd | 111 | 158756.342 | 0.9 | 249.856 | 51.37618 | 0.589 | 1.1 | ug/L |
| Cd | 114 | 360114.553 | 1.1 | 64.386 | 51.72795 | 0.437 | 0.8 | ug/L |
| > In | 115 | 366984.799 | 1.9 | 396447.935 | | | | ug/L |
| Sb | 121 | 483091.306 | 1.8 | 62.334 | 50.75504 | 0.364 | 0.7 | ug/L |
| Sb | 123 | 359024.820 | 2.1 | 53.222 | 49.91496 | 0.173 | 0.3 | ug/L |
| Ba | 135 | 128269.466 | 1.8 | 56.334 | 50.75250 | 0.757 | 1.5 | ug/L |
| Ba | 137 | 219866.969 | 2.0 | 65.001 | 51.12321 | 1.086 | 2.1 | ug/L |
| > Tb | 159 | 454770.262 | 0.8 | 486746.910 | | | | ug/L |
| > Ho | 165 | 430182.703 | 1.9 | 457509.069 | | | | ug/L |
| Tl | 203 | 406497.251 | 0.7 | 48.667 | 51.69189 | 1.292 | 2.5 | ug/L |
| Tl | 205 | 963469.304 | 1.3 | 63.334 | 53.82398 | 0.322 | 0.6 | ug/L |
| Pb | 208 | 1299312.046 | 1.0 | 537.345 | 51.57235 | 0.518 | 1.0 | ug/L |

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 338290.557 | 2.2 | 135.336 | 51.14803 | 0.363 | 0.7 ug/L |
| | Pb | 207 | 274415.157 | 0.6 | 124.336 | 49.38459 | 1.126 | 2.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 97.126 | | | | |
| Al | 27 | 104.559 | | | | |
| > Sc | 45 | | 96.108 | | | |
| V | 51 | 102.948 | | | | |
| Cr | 52 | 102.664 | | | | |
| Cr | 53 | 98.834 | | | | |
| Mn | 55 | 107.527 | | | | |
| Co | 59 | 101.525 | | | | |
| Ni | 60 | 104.641 | | | | |
| Ni | 62 | 107.375 | | | | |
| Cu | 63 | 104.222 | | | | |
| Cu | 65 | 103.115 | | | | |
| Zn | 66 | 100.127 | | | | |
| Zn | 67 | 97.814 | | | | |
| Zn | 68 | 100.216 | | | | |
| > Ge | 72 | | 93.480 | | | |
| As | 75 | 100.506 | | | | |
| Se | 77 | 102.355 | | | | |
| Se | 78 | 101.125 | | | | |
| Se | 82 | 103.405 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 100.175 | | | | |
| Mo | 97 | 105.088 | | | | |
| Mo | 98 | 100.244 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 102.339 | | | | |
| Ag | 109 | 100.054 | | | | |
| Cd | 111 | 102.752 | | | | |
| Cd | 114 | 103.456 | | | | |
| > In | 115 | | 92.568 | | | |
| Sb | 121 | 101.510 | | | | |
| Sb | 123 | 99.830 | | | | |
| Ba | 135 | 101.505 | | | | |
| Ba | 137 | 102.246 | | | | |
| > Tb | 159 | | 93.431 | | | |
| > Ho | 165 | | 94.027 | | | |
| Tl | 203 | 103.384 | | | | |
| Tl | 205 | 107.648 | | | | |
| Pb | 208 | 103.145 | | | | |
| Pb | 206 | 102.296 | | | | |
| Pb | 207 | 98.769 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 2

Sample Date/Time: Monday, November 20, 2006 09:58:43

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 2.006

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59.334 | 20.9 | 51.334 | 0.00949 | 0.011 | 113.9 | ug/L |
| Al | 27 | 3263.673 | 4.7 | 4379.197 | -0.10147 | 0.019 | 18.3 | ug/L |
| > Sc | 45 | 401208.002 | 0.3 | 424656.486 | | | | ug/L |
| V | 51 | 5229.328 | 2.4 | 5557.188 | -0.00131 | 0.008 | 642.8 | ug/L |
| Cr | 52 | 17302.116 | 0.3 | 18419.857 | -0.00741 | 0.005 | 71.7 | ug/L |
| Cr | 53 | 873.388 | 2.4 | 945.730 | -0.01190 | 0.013 | 111.1 | ug/L |
| Mn | 55 | 609.695 | 2.9 | 692.369 | -0.00223 | 0.001 | 55.1 | ug/L |
| Co | 59 | 256.007 | 7.9 | 265.007 | 0.00040 | 0.001 | 323.1 | ug/L |
| Ni | 60 | 142.669 | 8.1 | 177.337 | -0.00671 | 0.003 | 40.4 | ug/L |
| Ni | 62 | 1412.467 | 2.0 | 902.391 | 1.02699 | 0.064 | 6.2 | ug/L |
| Cu | 63 | 1190.764 | 3.2 | 876.388 | 0.04332 | 0.005 | 12.5 | ug/L |
| Cu | 65 | 222.339 | 5.6 | 254.340 | -0.00418 | 0.003 | 70.9 | ug/L |
| Zn | 66 | 2346.688 | 4.0 | 2747.481 | -0.10130 | 0.044 | 43.5 | ug/L |
| Zn | 67 | 431.349 | 4.3 | 502.020 | -0.10160 | 0.040 | 39.5 | ug/L |
| Zn | 68 | 1707.859 | 2.7 | 1975.921 | -0.08904 | 0.033 | 37.0 | ug/L |
| > Ge | 72 | 214007.517 | 1.3 | 227398.462 | | | | ug/L |
| As | 75 | 162.670 | 19.6 | 127.002 | 0.01617 | 0.012 | 76.5 | ug/L |
| Se | 77 | 235.270 | 2.5 | 226.870 | 0.10878 | 0.030 | 28.0 | ug/L |
| Se | 78 | 15243.719 | 1.2 | 16063.843 | 0.20487 | 0.576 | 281.1 | mg/L |
| Se | 82 | 790.104 | 2.1 | 661.626 | 0.60656 | 0.070 | 11.6 | ug/L |
| Kr | 83 | 779.378 | 3.7 | 694.703 | | | | mg/L |
| Y | 89 | 396631.717 | 2.0 | 420425.593 | | | | ug/L |
| Mo | 95 | 591.694 | 15.8 | 127.336 | 0.07968 | 0.015 | 19.1 | ug/L |
| Mo | 97 | 353.678 | 14.1 | 61.668 | 0.08183 | 0.013 | 16.0 | ug/L |
| Mo | 98 | 839.955 | 15.2 | 69.388 | 0.08091 | 0.013 | 15.5 | ug/L |
| Rh | 103 | 346734.828 | 1.4 | 381957.031 | | | | ug/L |
| Ag | 107 | 123.002 | 7.5 | 56.667 | 0.00477 | 0.001 | 13.6 | ug/L |
| Ag | 109 | 114.002 | 13.1 | 52.667 | 0.00460 | 0.001 | 24.8 | ug/L |
| Cd | 111 | 243.775 | 2.7 | 249.856 | 0.00083 | 0.003 | 331.3 | ug/L |
| Cd | 114 | 61.365 | 8.2 | 64.386 | -0.00010 | 0.001 | 767.3 | ug/L |
| > In | 115 | 382674.079 | 1.1 | 396447.935 | | | | ug/L |
| Sb | 121 | 1189.431 | 14.3 | 62.334 | 0.11370 | 0.016 | 14.2 | ug/L |
| Sb | 123 | 898.152 | 12.7 | 53.222 | 0.11284 | 0.014 | 12.5 | ug/L |
| Ba | 135 | 47.334 | 16.0 | 56.334 | -0.00194 | 0.003 | 145.1 | ug/L |
| Ba | 137 | 63.001 | 10.4 | 65.001 | 0.00067 | 0.002 | 236.4 | ug/L |
| > Tb | 159 | 450420.485 | 1.2 | 486746.910 | | | | ug/L |
| > Ho | 165 | 434348.978 | 1.4 | 457509.069 | | | | ug/L |
| Tl | 203 | 73.668 | 5.7 | 48.667 | 0.00346 | 0.000 | 13.4 | ug/L |
| Tl | 205 | 118.669 | 6.0 | 63.334 | 0.00324 | 0.000 | 14.2 | ug/L |
| Pb | 208 | 478.010 | 4.8 | 537.345 | -0.00126 | 0.001 | 67.1 | ug/L |

Sample ID: QC Std 2

Report Date/Time: Monday, November 20, 2006 10:01:43

Page 1

624

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|------------|
| | Pb | 206 | 132.002 | 8.3 | 135.336 | 0.00054 | 0.002 | 332.7 ug/L |
| | Pb | 207 | 107.335 | 5.5 | 124.336 | -0.00191 | 0.001 | 42.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 94.478 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 94.111 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 96.526 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 92.537 | | | |
| > [Ho | 165 | | 94.938 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Monday, November 20, 2006 10:04:39

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 3.007

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1273.443 | 1.0 | 51.334 | 1.05366 | 0.004 | 0.4 | ug/L |
| Al | 27 | 99427.136 | 2.2 | 4379.197 | 10.85761 | 0.330 | 3.0 | ug/L |
| > Sc | 45 | 408774.423 | 0.7 | 424656.486 | | | | ug/L |
| V | 51 | 23065.036 | 2.2 | 5557.188 | 1.09054 | 0.033 | 3.1 | ug/L |
| Cr | 52 | 32870.706 | 1.5 | 18419.857 | 1.09521 | 0.054 | 4.9 | ug/L |
| Cr | 53 | 2646.447 | 1.2 | 945.730 | 1.00888 | 0.014 | 1.4 | ug/L |
| Mn | 55 | 21520.302 | 1.0 | 692.369 | 1.10754 | 0.012 | 1.1 | ug/L |
| Co | 59 | 17730.688 | 1.0 | 265.007 | 1.05097 | 0.009 | 0.9 | ug/L |
| Ni | 60 | 4179.090 | 2.5 | 177.337 | 1.10219 | 0.025 | 2.3 | ug/L |
| Ni | 62 | 1840.555 | 4.0 | 902.391 | 1.79012 | 0.130 | 7.2 | ug/L |
| Cu | 63 | 10089.205 | 1.4 | 876.388 | 1.08985 | 0.014 | 1.3 | ug/L |
| Cu | 65 | 4521.271 | 0.8 | 254.340 | 1.04430 | 0.011 | 1.1 | ug/L |
| Zn | 66 | 15101.490 | 1.2 | 2747.481 | 5.28087 | 0.059 | 1.1 | ug/L |
| Zn | 67 | 2362.692 | 2.5 | 502.020 | 4.63761 | 0.132 | 2.8 | ug/L |
| Zn | 68 | 10954.976 | 2.8 | 1975.921 | 5.31610 | 0.172 | 3.2 | ug/L |
| > Ge | 72 | 215085.477 | 0.3 | 227398.462 | | | | ug/L |
| As | 75 | 2914.205 | 0.1 | 127.002 | 1.03873 | 0.003 | 0.3 | ug/L |
| Se | 77 | 430.144 | 2.2 | 226.870 | 1.07154 | 0.052 | 4.9 | ug/L |
| Se | 78 | 15988.033 | 2.4 | 16063.843 | 1.25584 | 0.575 | 45.8 | mg/L |
| Se | 82 | 1097.206 | 1.8 | 661.626 | 1.69824 | 0.063 | 3.7 | ug/L |
| Kr | 83 | 804.380 | 1.7 | 694.703 | | | | mg/L |
| Y | 89 | 399877.338 | 1.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 6029.908 | 1.4 | 127.336 | 1.02046 | 0.028 | 2.7 | ug/L |
| Mo | 97 | 3865.602 | 3.2 | 61.668 | 1.07665 | 0.060 | 5.6 | ug/L |
| Mo | 98 | 9536.646 | 0.7 | 69.388 | 1.00743 | 0.022 | 2.2 | ug/L |
| Rh | 103 | 364094.390 | 2.5 | 381957.031 | | | | ug/L |
| Ag | 107 | 15405.716 | 1.5 | 56.667 | 1.08883 | 0.027 | 2.5 | ug/L |
| Ag | 109 | 13782.537 | 3.8 | 52.667 | 1.01367 | 0.029 | 2.8 | ug/L |
| Cd | 111 | 3632.141 | 0.4 | 249.856 | 1.07106 | 0.031 | 2.9 | ug/L |
| Cd | 114 | 7605.241 | 4.6 | 64.386 | 1.05567 | 0.069 | 6.5 | ug/L |
| > In | 115 | 377085.541 | 2.7 | 396447.935 | | | | ug/L |
| Sb | 121 | 10529.423 | 2.6 | 62.334 | 1.07151 | 0.052 | 4.8 | ug/L |
| Sb | 123 | 7786.788 | 2.6 | 53.222 | 1.04695 | 0.002 | 0.2 | ug/L |
| Ba | 135 | 2695.796 | 2.3 | 56.334 | 1.02844 | 0.037 | 3.6 | ug/L |
| Ba | 137 | 4776.752 | 4.4 | 65.001 | 1.07758 | 0.031 | 2.9 | ug/L |
| > Tb | 159 | 462660.847 | 1.8 | 486746.910 | | | | ug/L |
| > Ho | 165 | 437908.226 | 1.0 | 457509.069 | | | | ug/L |
| Tl | 203 | 8768.366 | 2.1 | 48.667 | 1.08953 | 0.034 | 3.1 | ug/L |
| Tl | 205 | 21044.417 | 0.9 | 63.334 | 1.15162 | 0.014 | 1.3 | ug/L |
| Pb | 208 | 28328.389 | 0.7 | 537.345 | 1.08485 | 0.006 | 0.5 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Monday, November 20, 2006 10:07:39

Page 1

627

| | | | | | | | | |
|---|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 7216.195 | 0.4 | 135.336 | 1.05303 | 0.006 | 0.6 ug/L |
| L | Pb | 207 | 6190.363 | 3.9 | 124.336 | 1.07343 | 0.039 | 3.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 105.366 | | | | |
| Al | 27 | 108.576 | | | | |
| > Sc | 45 | | 96.260 | | | |
| V | 51 | 109.054 | | | | |
| Cr | 52 | 109.521 | | | | |
| Cr | 53 | 100.888 | | | | |
| Mn | 55 | 110.754 | | | | |
| Co | 59 | 105.097 | | | | |
| Ni | 60 | 110.219 | | | | |
| Ni | 62 | 179.012 | | | | |
| Cu | 63 | 108.985 | | | | |
| Cu | 65 | 104.430 | | | | |
| Zn | 66 | 105.617 | | | | |
| Zn | 67 | 92.752 | | | | |
| Zn | 68 | 106.322 | | | | |
| > Ge | 72 | | 94.585 | | | |
| As | 75 | 103.873 | | | | |
| Se | 77 | 107.154 | | | | |
| Se | 78 | 125.584 | | | | |
| Se | 82 | 169.824 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 102.046 | | | | |
| Mo | 97 | 107.665 | | | | |
| Mo | 98 | 100.743 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 108.883 | | | | |
| Ag | 109 | 101.367 | | | | |
| Cd | 111 | 107.106 | | | | |
| Cd | 114 | 105.567 | | | | |
| > In | 115 | | 95.116 | | | |
| Sb | 121 | 107.151 | | | | |
| Sb | 123 | 104.695 | | | | |
| Ba | 135 | 102.844 | | | | |
| Ba | 137 | 107.758 | | | | |
| > Tb | 159 | | 95.052 | | | |
| > Ho | 165 | | 95.716 | | | |
| Tl | 203 | 108.953 | | | | |
| Tl | 205 | 115.162 | | | | |
| Pb | 208 | 108.485 | | | | |
| Pb | 206 | 105.303 | | | | |
| Pb | 207 | 107.343 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 4

Sample Date/Time: Monday, November 20, 2006 10:10:35

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 4.008

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| Be | 9 | 67.668 | 16.5 | 51.334 | 0.01506 | 0.010 | 66.9 | ug/L |
| Al | 27 | 198882767.818 | 3.3 | 4379.197 | 22398.40108 | 967.537 | 4.3 | ug/L |
| > Sc | 45 | 413965.768 | 1.2 | 424656.486 | | | | ug/L |
| V | 51 | 4346.576 | 2.5 | 5557.188 | -0.06511 | 0.004 | 5.5 | ug/L |
| Cr | 52 | 28264.491 | 2.7 | 18419.857 | 0.73677 | 0.078 | 10.5 | ug/L |
| [Cr | 53 | 7961.907 | 10.1 | 945.730 | 4.04360 | 0.509 | 12.6 | ug/L |
| [Mn | 55 | 7461.748 | 2.3 | 692.369 | 0.32976 | 0.012 | 3.6 | ug/L |
| Co | 59 | 1237.104 | 2.4 | 265.007 | 0.05337 | 0.001 | 2.7 | ug/L |
| Ni | 60 | 2832.511 | 6.3 | 177.337 | 0.67032 | 0.050 | 7.5 | ug/L |
| Ni | 62 | 3595.812 | 1.0 | 902.391 | 4.45384 | 0.126 | 2.8 | ug/L |
| Cu | 63 | 8628.555 | 3.5 | 876.388 | 0.83717 | 0.043 | 5.2 | ug/L |
| Cu | 65 | 3087.270 | 2.3 | 254.340 | 0.63442 | 0.021 | 3.3 | ug/L |
| Zn | 66 | 5484.526 | 2.4 | 2747.481 | 1.03368 | 0.024 | 2.3 | ug/L |
| Zn | 67 | 2337.685 | 4.4 | 502.020 | 4.11802 | 0.237 | 5.8 | ug/L |
| Zn | 68 | 2582.759 | 2.4 | 1975.921 | 0.29743 | 0.053 | 17.9 | ug/L |
| > Ge | 72 | 233761.707 | 1.4 | 227398.462 | | | | ug/L |
| As | 75 | 1985.593 | 13.5 | 127.002 | 0.63481 | 0.093 | 14.7 | ug/L |
| Se | 77 | 865.645 | 6.5 | 226.870 | 2.89415 | 0.287 | 9.9 | ug/L |
| Se | 78 | 16120.201 | 2.3 | 16063.843 | -0.56662 | 0.761 | 134.3 | mg/L |
| Se | 82 | 933.986 | 2.1 | 661.626 | 0.84163 | 0.062 | 7.3 | ug/L |
| Kr | 83 | 971.733 | 3.8 | 694.703 | | | | mg/L |
| [Y | 89 | 417918.384 | 4.1 | 420425.593 | | | | ug/L |
| [Mo | 95 | 2708242.175 | 1.2 | 127.336 | 469.30560 | 9.132 | 1.9 | ug/L |
| [Mo | 97 | 1431620.808 | 0.7 | 51.668 | 406.03565 | 5.710 | 1.4 | ug/L |
| [Mo | 98 | 4409468.461 | 0.7 | 69.388 | 470.65429 | 6.777 | 1.4 | ug/L |
| [Rh | 103 | 354016.501 | 3.0 | 381957.031 | | | | ug/L |
| [Ag | 107 | 422.682 | 6.5 | 56.667 | 0.02626 | 0.002 | 7.4 | ug/L |
| [Ag | 109 | 403.014 | 3.5 | 52.667 | 0.02617 | 0.001 | 4.9 | ug/L |
| [Cd | 111 | 308.919 | 40.5 | 249.856 | 0.02277 | 0.039 | 172.8 | ug/L |
| [Cd | 114 | 5017.656 | 0.9 | 64.386 | 0.69562 | 0.011 | 1.6 | ug/L |
| > [In | 115 | 375672.695 | 0.8 | 396447.935 | | | | ug/L |
| [Sb | 121 | 3573.135 | 0.3 | 62.334 | 0.36071 | 0.003 | 0.9 | ug/L |
| [Sb | 123 | 2651.838 | 2.9 | 53.222 | 0.35335 | 0.009 | 2.5 | ug/L |
| [Ba | 135 | 163.670 | 11.9 | 56.334 | 0.04685 | 0.009 | 18.5 | ug/L |
| [Ba | 137 | 224.339 | 4.6 | 65.001 | 0.04035 | 0.003 | 6.3 | ug/L |
| > [Tb | 159 | 435601.754 | 0.9 | 486746.910 | | | | ug/L |
| > [Ho | 165 | 416992.380 | 1.4 | 457509.069 | | | | ug/L |
| [Tl | 203 | 1096.083 | 4.0 | 48.667 | 0.13792 | 0.004 | 3.0 | ug/L |
| [Tl | 205 | 2599.766 | 5.2 | 63.334 | 0.14645 | 0.006 | 3.9 | ug/L |
| [Pb | 208 | 1719.084 | 2.6 | 537.345 | 0.05035 | 0.001 | 2.9 | ug/L |

Sample ID: QC Std 4

Report Date/Time: Monday, November 20, 2006 10:13:36

Page 1

630

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 458.684 | 4.6 | 135.336 | 0.05230 | 0.002 | 4.3 ug/L |
| | Pb | 207 | 396.680 | 4.5 | 124.336 | 0.05262 | 0.003 | 6.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | 111.992 | | | | |
| > [Sc | 45 | | 97.483 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 102.798 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | 117.326 | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 94.760 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 89.492 | | | |
| > [Ho | 165 | | 91.144 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 5

Sample Date/Time: Monday, November 20, 2006 10:16:32

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 5.009

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| Be | 9 | 145.669 | 8.7 | 51.334 | 0.08051 | 0.012 | 15.3 | ug/L |
| Al | 27 | 194855918.919 | 2.0 | 4379.197 | 21784.17442 | 533.373 | 2.4 | ug/L |
| > Sc | 45 | 416953.102 | 1.4 | 424656.486 | | | | ug/L |
| V | 51 | -2488.016 | 74.2 | 5557.188 | -0.47840 | 0.110 | 23.0 | ug/L |
| Cr | 52 | 326324.986 | 2.0 | 18419.857 | 21.86241 | 0.761 | 3.5 | ug/L |
| Cr | 53 | 46607.126 | 1.7 | 945.730 | 26.02996 | 0.719 | 2.8 | ug/L |
| Mn | 55 | 418007.746 | 1.6 | 692.369 | 20.56168 | 0.112 | 0.5 | ug/L |
| Co | 59 | 361558.037 | 1.4 | 265.007 | 20.16910 | 0.524 | 2.6 | ug/L |
| Ni | 60 | 79324.945 | 1.6 | 177.337 | 20.18778 | 0.209 | 1.0 | ug/L |
| Ni | 62 | 14933.520 | 1.7 | 902.391 | 23.60488 | 0.881 | 3.7 | ug/L |
| Cu | 63 | 333439.081 | 2.0 | 876.388 | 36.34690 | 1.395 | 3.8 | ug/L |
| Cu | 65 | 157875.878 | 2.3 | 254.340 | 35.70684 | 1.368 | 3.8 | ug/L |
| Zn | 66 | 53725.853 | 1.3 | 2747.481 | 19.96925 | 0.267 | 1.3 | ug/L |
| Zn | 67 | 9863.600 | 1.3 | 502.020 | 21.33441 | 0.685 | 3.2 | ug/L |
| Zn | 68 | 35656.823 | 1.6 | 1975.921 | 18.27422 | 0.278 | 1.5 | ug/L |
| > Ge | 72 | 231711.891 | 1.8 | 227398.462 | | | | ug/L |
| As | 75 | 60488.009 | 0.6 | 127.002 | 20.83467 | 0.496 | 2.4 | ug/L |
| Se | 77 | 952.121 | 6.0 | 226.870 | 3.32520 | 0.223 | 6.7 | ug/L |
| Se | 78 | 16189.424 | 0.4 | 16063.843 | -0.25899 | 0.339 | 130.7 | mg/L |
| Se | 82 | 954.055 | 2.0 | 661.626 | 0.93655 | 0.081 | 8.6 | ug/L |
| Kr | 83 | 946.730 | 1.3 | 694.703 | | | | mg/L |
| Y | 89 | 409495.696 | 0.4 | 420425.593 | | | | ug/L |
| Mo | 95 | 2823492.619 | 1.8 | 127.336 | 494.31618 | 10.970 | 2.2 | ug/L |
| Mo | 97 | 1434480.357 | 2.5 | 61.668 | 411.00868 | 9.160 | 2.2 | ug/L |
| Mo | 98 | 4490391.344 | 3.2 | 69.388 | 484.17324 | 13.557 | 2.8 | ug/L |
| Rh | 103 | 345728.440 | 1.6 | 381957.031 | | | | ug/L |
| Ag | 107 | 287232.819 | 1.5 | 56.667 | 20.64834 | 0.290 | 1.4 | ug/L |
| Ag | 109 | 267306.882 | 1.7 | 52.667 | 20.00693 | 0.388 | 1.9 | ug/L |
| Cd | 111 | 63850.265 | 3.0 | 249.856 | 20.34787 | 0.707 | 3.5 | ug/L |
| Cd | 114 | 147252.351 | 2.8 | 64.386 | 20.86750 | 0.496 | 2.4 | ug/L |
| > In | 115 | 371828.474 | 0.4 | 396447.935 | | | | ug/L |
| Sb | 121 | 3397.393 | 2.1 | 62.334 | 0.34624 | 0.006 | 1.7 | ug/L |
| Sb | 123 | 2568.666 | 1.3 | 53.222 | 0.34567 | 0.003 | 0.9 | ug/L |
| Ba | 135 | 174.337 | 9.8 | 56.334 | 0.05207 | 0.007 | 12.5 | ug/L |
| Ba | 137 | 261.673 | 6.4 | 65.001 | 0.05020 | 0.004 | 8.0 | ug/L |
| > Tb | 159 | 430298.129 | 1.1 | 486746.910 | | | | ug/L |
| > Ho | 165 | 418146.227 | 0.4 | 457509.069 | | | | ug/L |
| Tl | 203 | 1074.747 | 7.7 | 48.667 | 0.13475 | 0.011 | 7.9 | ug/L |
| Tl | 205 | 2557.085 | 2.9 | 63.334 | 0.14362 | 0.004 | 2.6 | ug/L |
| Pb | 208 | 2300.478 | 1.8 | 537.345 | 0.07391 | 0.002 | 2.9 | ug/L |

Sample ID: QC Std 5

Report Date/Time: Monday, November 20, 2006 10:19:33

Page 1

633

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 592.694 | 5.3 | 135.336 | 0.07300 | 0.005 | 7.3 ug/L |
| | Pb | 207 | 521.355 | 5.7 | 124.336 | 0.07550 | 0.006 | 7.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | 108.921 | | | | |
| > Sc | 45 | | 98.186 | | | |
| V | 51 | | | | | |
| Cr | 52 | 109.312 | | | | |
| Cr | 53 | 130.150 | | | | |
| [Mn | 55 | 102.808 | | | | |
| Co | 59 | 100.846 | | | | |
| Ni | 60 | 100.939 | | | | |
| Ni | 62 | 118.024 | | | | |
| Cu | 63 | 181.734 | | | | |
| Cu | 65 | 178.534 | | | | |
| Zn | 66 | 99.846 | | | | |
| Zn | 67 | 106.672 | | | | |
| Zn | 68 | 91.371 | | | | |
| > Ge | 72 | | 101.897 | | | |
| As | 75 | 104.173 | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | 123.579 | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 103.242 | | | | |
| Ag | 109 | 100.035 | | | | |
| Cd | 111 | 101.739 | | | | |
| Cd | 114 | 104.337 | | | | |
| > In | 115 | | 93.790 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 88.403 | | | |
| > Ho | 165 | | 91.396 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 20, 2006 10:22:30

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 6.010

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54184.808 | 1.0 | 51.334 | 46.65775 | 1.160 | 2.5 | ug/L |
| Al | 27 | 451067.108 | 1.0 | 4379.197 | 51.00455 | 0.565 | 1.1 | ug/L |
| > Sc | 45 | 408374.168 | 1.5 | 424656.486 | | | | ug/L |
| V | 51 | 846668.398 | 1.8 | 5557.188 | 51.84479 | 1.141 | 2.2 | ug/L |
| Cr | 52 | 751674.328 | 2.5 | 18419.857 | 53.12858 | 0.572 | 1.1 | ug/L |
| Cr | 53 | 88597.112 | 1.7 | 945.730 | 51.00775 | 0.467 | 0.9 | ug/L |
| Mn | 55 | 1026191.645 | 2.8 | 692.369 | 53.15469 | 0.992 | 1.9 | ug/L |
| Co | 59 | 865399.183 | 3.7 | 265.007 | 50.78390 | 1.026 | 2.0 | ug/L |
| Ni | 60 | 193507.604 | 1.7 | 177.337 | 51.89463 | 1.630 | 3.1 | ug/L |
| Ni | 62 | 29976.479 | 2.8 | 902.391 | 51.53905 | 0.440 | 0.9 | ug/L |
| Cu | 63 | 446485.558 | 2.9 | 876.388 | 51.21178 | 0.768 | 1.5 | ug/L |
| Cu | 65 | 220283.968 | 1.8 | 254.340 | 52.42564 | 1.061 | 2.0 | ug/L |
| Zn | 66 | 123182.351 | 0.8 | 2747.481 | 49.71866 | 0.696 | 1.4 | ug/L |
| Zn | 67 | 20554.199 | 2.4 | 502.020 | 48.16869 | 2.116 | 4.4 | ug/L |
| Zn | 68 | 89493.546 | 0.6 | 1975.921 | 50.05742 | 1.373 | 2.7 | ug/L |
| > Ge | 72 | 220268.204 | 2.2 | 227398.462 | | | | ug/L |
| As | 75 | 136809.956 | 0.9 | 127.002 | 49.63259 | 1.022 | 2.1 | ug/L |
| Se | 77 | 10808.405 | 1.3 | 226.870 | 51.40224 | 0.730 | 1.4 | ug/L |
| Se | 78 | 49385.408 | 0.7 | 16063.843 | 52.29138 | 2.036 | 3.9 | mg/L |
| Se | 82 | 15391.402 | 1.3 | 661.626 | 51.91653 | 1.769 | 3.4 | ug/L |
| Kr | 83 | 902.391 | 2.2 | 694.703 | | | | mg/L |
| Y | 89 | 416512.099 | 0.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 287267.291 | 1.8 | 127.336 | 50.40894 | 1.168 | 2.3 | ug/L |
| Mo | 97 | 182139.723 | 2.7 | 61.668 | 52.35950 | 3.029 | 5.8 | ug/L |
| Mo | 98 | 473856.111 | 3.7 | 69.388 | 51.22641 | 1.876 | 3.7 | ug/L |
| Rh | 103 | 363309.035 | 2.1 | 381957.031 | | | | ug/L |
| Ag | 107 | 706974.599 | 1.1 | 56.667 | 50.98317 | 1.793 | 3.5 | ug/L |
| Ag | 109 | 662287.879 | 1.8 | 52.667 | 49.71163 | 1.284 | 2.6 | ug/L |
| Cd | 111 | 161935.326 | 0.2 | 249.856 | 51.87833 | 1.933 | 3.7 | ug/L |
| Cd | 114 | 364859.070 | 1.5 | 64.386 | 51.86911 | 1.445 | 2.8 | ug/L |
| > In | 115 | 371029.654 | 4.0 | 396447.935 | | | | ug/L |
| Sb | 121 | 483417.334 | 2.0 | 62.334 | 50.27964 | 1.991 | 4.0 | ug/L |
| Sb | 123 | 361233.977 | 1.3 | 53.222 | 49.71150 | 1.356 | 2.7 | ug/L |
| Ba | 135 | 126188.856 | 0.7 | 56.334 | 51.45126 | 0.797 | 1.5 | ug/L |
| Ba | 137 | 218465.085 | 0.4 | 65.001 | 52.34353 | 0.819 | 1.6 | ug/L |
| > Tb | 159 | 441378.067 | 1.2 | 486746.910 | | | | ug/L |
| > Ho | 165 | 418050.236 | 1.1 | 457509.069 | | | | ug/L |
| Tl | 203 | 401759.814 | 0.6 | 48.667 | 52.55796 | 0.323 | 0.6 | ug/L |
| Tl | 205 | 926033.626 | 1.6 | 63.334 | 53.23360 | 0.981 | 1.8 | ug/L |
| Pb | 208 | 1278317.369 | 1.8 | 537.345 | 52.20322 | 0.406 | 0.8 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Monday, November 20, 2006 10:25:32

Page 1

636

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 328117.225 | 2.7 | 135.336 | 51.04668 | 1.015 | 2.0 ug/L |
| | Pb | 207 | 276276.780 | 0.2 | 124.336 | 51.15287 | 0.556 | 1.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 93.316 | | | | |
| Al | 27 | 102.009 | | | | |
| > Sc | 45 | | 96.166 | | | |
| V | 51 | 103.690 | | | | |
| Cr | 52 | 106.257 | | | | |
| Cr | 53 | 102.015 | | | | |
| Mn | 55 | 106.309 | | | | |
| Co | 59 | 101.568 | | | | |
| Ni | 60 | 103.789 | | | | |
| Ni | 62 | 103.078 | | | | |
| Cu | 63 | 102.424 | | | | |
| Cu | 65 | 104.851 | | | | |
| Zn | 66 | 99.437 | | | | |
| Zn | 67 | 96.337 | | | | |
| Zn | 68 | 100.115 | | | | |
| > Ge | 72 | | 96.864 | | | |
| As | 75 | 99.265 | | | | |
| Se | 77 | 102.804 | | | | |
| Se | 78 | 104.583 | | | | |
| Se | 82 | 103.833 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 100.818 | | | | |
| Mo | 97 | 104.719 | | | | |
| Mo | 98 | 102.453 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 101.966 | | | | |
| Ag | 109 | 99.423 | | | | |
| Cd | 111 | 103.757 | | | | |
| Cd | 114 | 103.738 | | | | |
| > In | 115 | | 93.588 | | | |
| Sb | 121 | 100.559 | | | | |
| Sb | 123 | 99.423 | | | | |
| Ba | 135 | 102.903 | | | | |
| Ba | 137 | 104.687 | | | | |
| > Tb | 159 | | 90.679 | | | |
| > Ho | 165 | | 91.375 | | | |
| Tl | 203 | 105.116 | | | | |
| Tl | 205 | 106.467 | | | | |
| Pb | 208 | 104.406 | | | | |
| Pb | 206 | 102.093 | | | | |
| Pb | 207 | 102.306 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 20, 2006 10:28:28

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 7.011

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 49.001 | 16.7 | 51.334 | -0.00071 | 0.007 | 1000.1 | ug/L |
| Al | 27 | 3558.796 | 3.5 | 4379.197 | -0.07839 | 0.014 | 18.2 | ug/L |
| > Sc | 45 | 412354.261 | 0.3 | 424656.486 | | | | ug/L |
| V | 51 | 4750.348 | 4.3 | 5557.188 | -0.03939 | 0.013 | 34.0 | ug/L |
| Cr | 52 | 16711.243 | 1.7 | 18419.857 | -0.08421 | 0.023 | 27.0 | ug/L |
| Cr | 53 | 1842.889 | 6.1 | 945.730 | 0.53258 | 0.064 | 11.9 | ug/L |
| Mn | 55 | 667.367 | 1.8 | 692.369 | -0.00079 | 0.001 | 105.0 | ug/L |
| Co | 59 | 216.005 | 6.8 | 265.007 | -0.00262 | 0.001 | 29.4 | ug/L |
| Ni | 60 | 146.336 | 0.4 | 177.337 | -0.00754 | 0.000 | 5.4 | ug/L |
| Ni | 62 | 936.062 | 0.9 | 902.391 | 0.07974 | 0.012 | 15.3 | ug/L |
| Cu | 63 | 831.717 | 4.6 | 876.388 | -0.00372 | 0.004 | 101.5 | ug/L |
| Cu | 65 | 223.672 | 3.0 | 254.340 | -0.00636 | 0.002 | 29.0 | ug/L |
| Zn | 66 | 2389.366 | 0.9 | 2747.481 | -0.13002 | 0.004 | 2.7 | ug/L |
| Zn | 67 | 541.023 | 4.8 | 502.020 | 0.10762 | 0.054 | 50.3 | ug/L |
| Zn | 68 | 1748.201 | 3.7 | 1975.921 | -0.11288 | 0.031 | 27.9 | ug/L |
| > Ge | 72 | 224329.623 | 0.7 | 227398.462 | | | | ug/L |
| As | 75 | 213.338 | 4.9 | 127.002 | 0.03138 | 0.003 | 10.8 | ug/L |
| Se | 77 | 266.471 | 4.0 | 226.870 | 0.20313 | 0.043 | 21.0 | ug/L |
| Se | 78 | 15625.449 | 1.5 | 16063.843 | -0.33701 | 0.197 | 58.4 | mg/L |
| Se | 82 | 892.648 | 3.6 | 661.626 | 0.82863 | 0.098 | 11.8 | ug/L |
| Kr | 83 | 899.391 | 1.4 | 694.703 | | | | mg/L |
| Y | 89 | 397898.315 | 1.0 | 420425.593 | | | | ug/L |
| Mo | 95 | 905.725 | 10.2 | 127.336 | 0.13267 | 0.017 | 12.9 | ug/L |
| Mo | 97 | 513.688 | 9.8 | 51.668 | 0.12596 | 0.015 | 12.0 | ug/L |
| Mo | 98 | 1282.244 | 12.7 | 69.388 | 0.12694 | 0.018 | 14.5 | ug/L |
| Rh | 103 | 352492.417 | 1.2 | 381957.031 | | | | ug/L |
| Ag | 107 | 135.002 | 8.7 | 56.667 | 0.00558 | 0.001 | 15.8 | ug/L |
| Ag | 109 | 138.336 | 13.8 | 52.667 | 0.00633 | 0.001 | 22.4 | ug/L |
| Cd | 111 | 218.293 | 13.5 | 249.856 | -0.00743 | 0.009 | 114.7 | ug/L |
| Cd | 114 | 58.830 | 7.7 | 64.386 | -0.00049 | 0.001 | 131.9 | ug/L |
| > In | 115 | 384168.705 | 1.0 | 396447.935 | | | | ug/L |
| Sb | 121 | 974.067 | 13.0 | 62.334 | 0.09180 | 0.014 | 14.9 | ug/L |
| Sb | 123 | 756.433 | 15.8 | 53.222 | 0.09374 | 0.017 | 18.0 | ug/L |
| Ba | 135 | 51.334 | 18.9 | 56.334 | 0.00023 | 0.004 | 1760.8 | ug/L |
| Ba | 137 | 67.001 | 11.9 | 65.001 | 0.00202 | 0.002 | 90.1 | ug/L |
| > Tb | 159 | 438791.593 | 0.7 | 486746.910 | | | | ug/L |
| > Ho | 165 | 430432.912 | 1.9 | 457509.069 | | | | ug/L |
| Tl | 203 | 138.669 | 4.8 | 48.667 | 0.01180 | 0.001 | 4.3 | ug/L |
| Tl | 205 | 267.340 | 19.4 | 63.334 | 0.01157 | 0.003 | 22.4 | ug/L |
| Pb | 208 | 445.676 | 2.7 | 537.345 | -0.00237 | 0.001 | 31.3 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Monday, November 20, 2006 10:31:29

Page 1

639

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|------------|
| | Pb | 206 | 117.669 | 6.4 | 135.336 | -0.00144 | 0.001 | 99.4 ug/L |
| | Pb | 207 | 108.002 | 14.3 | 124.336 | -0.00162 | 0.003 | 169.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 97.103 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 98.650 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 96.903 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 90.148 | | | |
| > Ho | 165 | | 94.082 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| L Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 8

Sample Date/Time: Monday, November 20, 2006 10:34:26

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 8.012

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 112692.920 | 2.3 | 51.334 | 100.64980 | 4.118 | 4.1 | ug/L |
| Al | 27 | 846264.859 | 1.4 | 4379.197 | 99.63363 | 0.874 | 0.9 | ug/L |
| > Sc | 45 | 394007.032 | 1.8 | 424656.486 | | | | ug/L |
| V | 51 | 1611689.099 | 1.4 | 5557.188 | 102.60368 | 1.014 | 1.0 | ug/L |
| Cr | 52 | 1389022.273 | 3.3 | 18419.857 | 102.92321 | 1.756 | 1.7 | ug/L |
| Cr | 53 | 172362.675 | 2.4 | 945.730 | 103.39120 | 1.865 | 1.8 | ug/L |
| Mn | 55 | 1872644.578 | 2.7 | 692.369 | 99.66114 | 2.026 | 2.0 | ug/L |
| Co | 59 | 1614811.445 | 1.5 | 265.007 | 97.38080 | 2.020 | 2.1 | ug/L |
| Ni | 60 | 382752.076 | 1.1 | 177.337 | 105.45051 | 1.344 | 1.3 | ug/L |
| Ni | 62 | 56896.890 | 2.5 | 902.391 | 101.95105 | 1.323 | 1.3 | ug/L |
| Cu | 63 | 856993.975 | 2.0 | 876.388 | 101.06460 | 0.877 | 0.9 | ug/L |
| Cu | 65 | 416444.399 | 2.2 | 254.340 | 101.84907 | 2.385 | 2.3 | ug/L |
| Zn | 66 | 235000.825 | 1.4 | 2747.481 | 98.47382 | 1.826 | 1.9 | ug/L |
| Zn | 67 | 41510.882 | 0.6 | 502.020 | 101.14412 | 2.447 | 2.4 | ug/L |
| Zn | 68 | 176245.166 | 2.1 | 1975.921 | 102.33670 | 1.338 | 1.3 | ug/L |
| > Ge | 72 | 214448.970 | 1.8 | 227398.462 | | | | ug/L |
| As | 75 | 279595.080 | 1.8 | 127.002 | 104.21922 | 2.055 | 2.0 | ug/L |
| Se | 77 | 20524.311 | 0.4 | 226.870 | 101.27411 | 1.710 | 1.7 | ug/L |
| Se | 78 | 80691.285 | 0.3 | 16063.843 | 104.04874 | 2.773 | 2.7 | mg/L |
| Se | 82 | 28714.186 | 0.5 | 661.626 | 101.51893 | 1.486 | 1.5 | ug/L |
| Kr | 83 | 905.058 | 1.4 | 694.703 | | | | mg/L |
| Y | 89 | 393747.882 | 0.9 | 420425.593 | | | | ug/L |
| Mo | 95 | 564662.704 | 1.3 | 127.336 | 102.14072 | 1.277 | 1.3 | ug/L |
| Mo | 97 | 357392.250 | 3.3 | 61.668 | 105.81251 | 3.299 | 3.1 | ug/L |
| Mo | 98 | 878061.018 | 0.7 | 69.388 | 97.84632 | 0.937 | 1.0 | ug/L |
| Rh | 103 | 353652.252 | 2.7 | 381957.031 | | | | ug/L |
| Ag | 107 | 1383999.833 | 0.9 | 56.667 | 102.83312 | 0.587 | 0.6 | ug/L |
| Ag | 109 | 1291873.806 | 1.6 | 52.667 | 99.93378 | 1.288 | 1.3 | ug/L |
| Cd | 111 | 318590.625 | 4.1 | 249.856 | 105.21956 | 4.096 | 3.9 | ug/L |
| Cd | 114 | 692379.028 | 1.6 | 64.386 | 101.44004 | 1.651 | 1.6 | ug/L |
| > In | 115 | 359796.636 | 0.4 | 396447.935 | | | | ug/L |
| Sb | 121 | 931802.840 | 0.6 | 62.334 | 99.85803 | 0.759 | 0.8 | ug/L |
| Sb | 123 | 720378.088 | 1.5 | 53.222 | 102.16267 | 1.314 | 1.3 | ug/L |
| Ba | 135 | 241754.680 | 1.8 | 56.334 | 99.48493 | 1.843 | 1.9 | ug/L |
| Ba | 137 | 421936.006 | 1.1 | 65.001 | 102.05391 | 3.269 | 3.2 | ug/L |
| > Tb | 159 | 437490.994 | 3.0 | 486746.910 | | | | ug/L |
| > Ho | 165 | 409033.553 | 0.9 | 457509.069 | | | | ug/L |
| Tl | 203 | 779903.850 | 1.7 | 48.667 | 104.28081 | 1.911 | 1.8 | ug/L |
| Tl | 205 | 1737353.541 | 1.6 | 63.334 | 102.08244 | 2.298 | 2.3 | ug/L |
| Pb | 208 | 2451156.643 | 2.1 | 537.345 | 102.33916 | 2.541 | 2.5 | ug/L |

Sample ID: QC Std 8

Report Date/Time: Monday, November 20, 2006 10:37:27

Page 1

642

| | | | | | | | | |
|--|----|-----|------------|-----|---------|-----------|-------|----------|
| | Pb | 206 | 643310.892 | 1.1 | 135.336 | 102.32453 | 1.707 | 1.7 ug/L |
| | Pb | 207 | 552511.511 | 2.1 | 124.336 | 104.56851 | 2.085 | 2.0 ug/L |

Sample ID: QC Std 8

Report Date/Time: Monday, November 20, 2006 10:37:27

Page 2

643

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 100.650 | | | | |
| Al | 27 | 99.634 | | | | |
| > Sc | 45 | | 92.783 | | | |
| V | 51 | 102.604 | | | | |
| Cr | 52 | 102.923 | | | | |
| Cr | 53 | 103.391 | | | | |
| Mn | 55 | 99.661 | | | | |
| Co | 59 | 97.381 | | | | |
| Ni | 60 | 105.451 | | | | |
| Ni | 62 | 101.951 | | | | |
| Cu | 63 | 101.065 | | | | |
| Cu | 65 | 101.849 | | | | |
| Zn | 66 | 98.474 | | | | |
| Zn | 67 | 101.144 | | | | |
| Zn | 68 | 102.337 | | | | |
| > Ge | 72 | | 94.305 | | | |
| As | 75 | 104.219 | | | | |
| Se | 77 | 101.274 | | | | |
| Se | 78 | | | | | |
| Se | 82 | 101.519 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 102.141 | | | | |
| Mo | 97 | 105.813 | | | | |
| Mo | 98 | 97.846 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 102.833 | | | | |
| Ag | 109 | 99.934 | | | | |
| Cd | 111 | 105.220 | | | | |
| Cd | 114 | 101.440 | | | | |
| > In | 115 | | 90.755 | | | |
| Sb | 121 | 99.858 | | | | |
| Sb | 123 | 102.163 | | | | |
| Ba | 135 | 99.485 | | | | |
| Ba | 137 | 102.054 | | | | |
| > Tb | 159 | | 89.881 | | | |
| > Ho | 165 | | 89.404 | | | |
| Tl | 203 | 104.281 | | | | |
| Tl | 205 | 102.082 | | | | |
| Pb | 208 | 102.339 | | | | |
| Pb | 206 | 102.325 | | | | |
| Pb | 207 | 104.569 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: PBW-M3990143

Sample Date/Time: Monday, November 20, 2006 10:40:24

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\PBW-M3990143.013

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59.001 | 4.5 | 51.334 | 0.01051 | 0.002 | 22.6 | ug/L |
| Al | 27 | 6282.767 | 4.7 | 4379.197 | 0.26770 | 0.039 | 14.6 | ug/L |
| > Sc | 45 | 391387.601 | 1.0 | 424656.486 | | | | ug/L |
| V | 51 | 4786.964 | 5.5 | 5557.188 | -0.02142 | 0.019 | 90.4 | ug/L |
| Cr | 52 | 16948.057 | 2.0 | 18419.857 | -0.00209 | 0.029 | 1379.5 | ug/L |
| Cr | 53 | 1383.795 | 3.1 | 945.730 | 0.31074 | 0.018 | 5.8 | ug/L |
| Mn | 55 | 830.716 | 4.0 | 692.369 | 0.01023 | 0.001 | 12.8 | ug/L |
| Co | 59 | 235.006 | 0.4 | 265.007 | -0.00065 | 0.000 | 35.6 | ug/L |
| Ni | 60 | 194.671 | 8.6 | 177.337 | 0.00848 | 0.004 | 50.0 | ug/L |
| Ni | 62 | 879.722 | 0.4 | 902.391 | 0.08044 | 0.026 | 32.7 | ug/L |
| Cu | 63 | 814.715 | 2.5 | 876.388 | 0.00029 | 0.002 | 747.9 | ug/L |
| Cu | 65 | 228.672 | 7.5 | 254.340 | -0.00170 | 0.005 | 317.4 | ug/L |
| Zn | 66 | 1822.884 | 3.0 | 2747.481 | -0.31157 | 0.035 | 11.3 | ug/L |
| Zn | 67 | 418.681 | 4.9 | 502.020 | -0.11616 | 0.069 | 59.2 | ug/L |
| Zn | 68 | 1365.792 | 3.6 | 1975.921 | -0.27788 | 0.032 | 11.6 | ug/L |
| > Ge | 72 | 210780.480 | 2.0 | 227398.462 | | | | ug/L |
| As | 75 | 215.338 | 2.8 | 127.002 | 0.03705 | 0.003 | 7.7 | ug/L |
| Se | 77 | 257.804 | 4.5 | 226.870 | 0.24065 | 0.039 | 16.3 | ug/L |
| Se | 78 | 15536.498 | 1.5 | 16063.843 | 1.05265 | 0.744 | 70.6 | mg/L |
| Se | 82 | 927.052 | 2.5 | 661.626 | 1.15333 | 0.030 | 2.6 | ug/L |
| Kr | 83 | 958.065 | 2.0 | 694.703 | | | | mg/L |
| Y | 89 | 397456.187 | 0.5 | 420425.593 | | | | ug/L |
| Mo | 95 | 1383.135 | 29.2 | 127.336 | 0.22908 | 0.071 | 30.8 | ug/L |
| Mo | 97 | 839.054 | 32.4 | 61.668 | 0.23139 | 0.078 | 33.6 | ug/L |
| Mo | 98 | 2105.845 | 35.4 | 69.388 | 0.22727 | 0.081 | 35.5 | ug/L |
| Rh | 103 | 347375.945 | 2.0 | 381957.031 | | | | ug/L |
| Ag | 107 | 170.670 | 2.2 | 56.667 | 0.00887 | 0.000 | 2.3 | ug/L |
| Ag | 109 | 156.336 | 1.0 | 52.667 | 0.00841 | 0.000 | 1.7 | ug/L |
| Cd | 111 | 217.531 | 10.5 | 249.856 | -0.00301 | 0.007 | 236.0 | ug/L |
| Cd | 114 | 74.314 | 24.1 | 64.386 | 0.00235 | 0.003 | 113.9 | ug/L |
| > In | 115 | 359495.017 | 1.8 | 396447.935 | | | | ug/L |
| Sb | 121 | 1387.798 | 17.2 | 62.334 | 0.14255 | 0.023 | 16.4 | ug/L |
| Sb | 123 | 981.296 | 19.1 | 53.222 | 0.13229 | 0.025 | 19.0 | ug/L |
| Ba | 135 | 66.668 | 4.3 | 56.334 | 0.00715 | 0.002 | 25.3 | ug/L |
| Ba | 137 | 89.335 | 8.4 | 65.001 | 0.00792 | 0.002 | 29.4 | ug/L |
| > Tb | 159 | 429289.478 | 2.1 | 486746.910 | | | | ug/L |
| > Ho | 165 | 412977.309 | 1.8 | 457509.069 | | | | ug/L |
| Tl | 203 | 89.001 | 5.8 | 48.667 | 0.00596 | 0.001 | 9.0 | ug/L |
| Tl | 205 | 158.670 | 4.7 | 63.334 | 0.00591 | 0.000 | 7.7 | ug/L |
| Pb | 208 | 492.344 | 6.8 | 537.345 | 0.00031 | 0.002 | 515.7 | ug/L |

Sample ID: PBW-M3990143

Report Date/Time: Monday, November 20, 2006 10:43:25

Page 1

645

| | | | | | | | | |
|--|----|-----|---------|------|---------|---------|-------|------------|
| | Pb | 206 | 127.336 | 13.0 | 135.336 | 0.00085 | 0.003 | 347.5 ug/L |
| | Pb | 207 | 118.002 | 11.5 | 124.336 | 0.00107 | 0.002 | 218.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 92.166 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 92.692 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 90.679 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 88.196 | | | |
| > [Ho | 165 | | 90.266 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: LCSW-M3990143

Sample Date/Time: Monday, November 20, 2006 10:46:21

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\LCSW-M3990143.014

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 21678.717 | 1.8 | 51.334 | 17.70331 | 0.419 | 2.4 | ug/L |
| Al | 27 | 209169.960 | 1.3 | 4379.197 | 22.19799 | 0.401 | 1.8 | ug/L |
| Sc | 45 | 429907.658 | 0.8 | 424656.486 | | | | ug/L |
| V | 51 | 364239.963 | 1.4 | 5557.188 | 20.98974 | 0.298 | 1.4 | ug/L |
| Cr | 52 | 328717.686 | 2.1 | 18419.857 | 21.32118 | 0.309 | 1.5 | ug/L |
| Cr | 53 | 37351.565 | 0.9 | 945.730 | 20.10991 | 0.090 | 0.4 | ug/L |
| Mn | 55 | 431908.019 | 2.4 | 692.369 | 22.17721 | 0.183 | 0.8 | ug/L |
| Co | 59 | 361077.579 | 1.1 | 265.007 | 21.02544 | 0.512 | 2.4 | ug/L |
| Ni | 60 | 83193.844 | 2.3 | 177.337 | 22.11407 | 0.904 | 4.1 | ug/L |
| Ni | 62 | 12754.881 | 0.6 | 902.391 | 20.87372 | 0.538 | 2.6 | ug/L |
| Cu | 63 | 191214.246 | 3.2 | 876.388 | 21.71398 | 0.862 | 4.0 | ug/L |
| Cu | 65 | 92842.920 | 0.5 | 254.340 | 21.89169 | 0.424 | 1.9 | ug/L |
| Zn | 66 | 46510.930 | 1.9 | 2747.481 | 17.93908 | 0.338 | 1.9 | ug/L |
| Zn | 67 | 8365.948 | 0.9 | 502.020 | 18.75144 | 0.403 | 2.2 | ug/L |
| Zn | 68 | 34700.460 | 1.9 | 1975.921 | 18.58348 | 0.532 | 2.9 | ug/L |
| Ge | 72 | 221983.890 | 1.8 | 227398.462 | | | | ug/L |
| As | 75 | 53073.014 | 1.2 | 127.002 | 19.07883 | 0.548 | 2.9 | ug/L |
| Se | 77 | 3699.154 | 0.5 | 226.870 | 16.75183 | 0.252 | 1.5 | ug/L |
| Se | 78 | 27632.979 | 0.8 | 16063.843 | 18.33431 | 0.974 | 5.3 | mg/L |
| Se | 82 | 5655.652 | 0.3 | 661.626 | 17.49166 | 0.319 | 1.8 | ug/L |
| Kr | 83 | 989.402 | 5.1 | 694.703 | | | | mg/L |
| Y | 89 | 426596.359 | 1.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 122915.147 | 1.1 | 127.336 | 20.68454 | 0.419 | 2.0 | ug/L |
| Mo | 97 | 80231.177 | 0.5 | 61.668 | 22.10228 | 0.141 | 0.6 | ug/L |
| Mo | 98 | 198543.082 | 2.8 | 69.388 | 20.58946 | 0.430 | 2.1 | ug/L |
| Rh | 103 | 370926.036 | 3.0 | 381957.031 | | | | ug/L |
| Ag | 107 | 308321.880 | 0.3 | 56.667 | 21.32522 | 0.168 | 0.8 | ug/L |
| Ag | 109 | 281840.838 | 1.4 | 52.667 | 20.29376 | 0.136 | 0.7 | ug/L |
| Cd | 111 | 63830.207 | 0.9 | 249.856 | 19.56776 | 0.365 | 1.9 | ug/L |
| Cd | 114 | 144586.865 | 3.3 | 64.386 | 19.71122 | 0.475 | 2.4 | ug/L |
| In | 115 | 386481.506 | 1.0 | 396447.935 | | | | ug/L |
| Sb | 121 | 197197.285 | 0.7 | 62.334 | 19.66925 | 0.138 | 0.7 | ug/L |
| Sb | 123 | 147446.244 | 0.2 | 53.222 | 19.46263 | 0.164 | 0.8 | ug/L |
| Ba | 135 | 53163.586 | 1.1 | 56.334 | 20.97461 | 0.344 | 1.6 | ug/L |
| Ba | 137 | 93163.227 | 1.7 | 65.001 | 21.60687 | 0.682 | 3.2 | ug/L |
| Tb | 159 | 455935.553 | 2.4 | 486746.910 | | | | ug/L |
| Ho | 165 | 423552.904 | 0.3 | 457509.069 | | | | ug/L |
| Tl | 203 | 167417.016 | 0.6 | 48.667 | 21.61257 | 0.136 | 0.6 | ug/L |
| Tl | 205 | 389336.587 | 1.4 | 63.334 | 22.08683 | 0.278 | 1.3 | ug/L |
| Pb | 208 | 534509.974 | 0.7 | 537.345 | 21.53394 | 0.194 | 0.9 | ug/L |

Sample ID: LCSW-M3990143

Report Date/Time: Monday, November 20, 2006 10:49:22

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 135452.013 | 0.8 | 135.336 | 20.78923 | 0.115 | 0.6 ug/L |
| | Pb | 207 | 115322.152 | 2.0 | 124.336 | 21.06138 | 0.472 | 2.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 101.237 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 97.619 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 97.486 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 93.670 | | | |
| > [Ho | 165 | | 92.578 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950470

Sample Date/Time: Monday, November 20, 2006 10:52:19

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950470.015

| | Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| [| Be | 9 | 108.335 | 8.8 | 51.334 | 0.03374 | 0.007 | 19.8 | ug/L |
| | Al | 27 | 313906.197 | 5.1 | 4379.197 | 28.79062 | 1.455 | 5.1 | ug/L |
| > | Sc | 45 | 499845.253 | 1.3 | 424656.486 | | | | ug/L |
| | V | 51 | 9682.445 | 9.9 | 5557.188 | 0.15828 | 0.049 | 31.3 | ug/L |
| | Cr | 52 | 90109.226 | 1.8 | 18419.857 | 4.04863 | 0.165 | 4.1 | ug/L |
| [| Cr | 53 | 9832.229 | 1.4 | 945.730 | 4.14430 | 0.096 | 2.3 | ug/L |
| | Mn | 55 | 1776771.307 | 1.5 | 692.369 | 87.09722 | 1.385 | 1.6 | ug/L |
| | Co | 59 | 19095.044 | 0.8 | 265.007 | 1.04582 | 0.028 | 2.7 | ug/L |
| | Ni | 60 | 72251.538 | 3.7 | 177.337 | 18.28869 | 0.303 | 1.7 | ug/L |
| | Ni | 62 | 9850.253 | 2.7 | 902.391 | 14.95397 | 0.108 | 0.7 | ug/L |
| | Cu | 63 | 19886.567 | 0.9 | 876.388 | 2.06528 | 0.061 | 3.0 | ug/L |
| | Cu | 65 | 9576.601 | 4.0 | 254.340 | 2.09882 | 0.043 | 2.0 | ug/L |
| | Zn | 66 | 11084.145 | 1.2 | 2747.481 | 3.22763 | 0.041 | 1.3 | ug/L |
| | Zn | 67 | 2693.129 | 2.3 | 502.020 | 4.94498 | 0.052 | 1.0 | ug/L |
| | Zn | 68 | 11666.949 | 2.8 | 1975.921 | 5.21167 | 0.062 | 1.2 | ug/L |
| > | Ge | 72 | 232842.660 | 2.1 | 227398.462 | | | | ug/L |
| | As | 75 | 1808.548 | 3.4 | 127.002 | 0.57630 | 0.008 | 1.4 | ug/L |
| | Se | 77 | 370.742 | 2.7 | 226.870 | 0.63556 | 0.020 | 3.1 | ug/L |
| | Se | 78 | 17198.327 | 1.9 | 16063.843 | 1.09708 | 0.168 | 15.3 | mg/L |
| | Se | 82 | 1214.555 | 2.1 | 661.626 | 1.78819 | 0.099 | 5.5 | ug/L |
| | Kr | 83 | 1060.745 | 1.6 | 694.703 | | | | mg/L |
| [| Y | 89 | 489670.595 | 0.4 | 420425.593 | | | | ug/L |
| | Mo | 95 | 1468.811 | 3.7 | 127.336 | 0.22667 | 0.005 | 2.3 | ug/L |
| | Mo | 97 | 922.394 | 9.3 | 61.668 | 0.23765 | 0.018 | 7.4 | ug/L |
| | Mo | 98 | 2326.371 | 2.9 | 69.388 | 0.23463 | 0.008 | 3.6 | ug/L |
| | Rh | 103 | 363101.739 | 0.8 | 381957.031 | | | | ug/L |
| | Ag | 107 | 130.669 | 9.1 | 56.667 | 0.00524 | 0.001 | 19.8 | ug/L |
| | Ag | 109 | 97.668 | 6.2 | 52.667 | 0.00335 | 0.001 | 18.1 | ug/L |
| | Cd | 111 | 616.737 | 4.3 | 249.856 | 0.11511 | 0.011 | 9.5 | ug/L |
| | Cd | 114 | 904.843 | 8.1 | 64.386 | 0.11508 | 0.011 | 9.9 | ug/L |
| > | In | 115 | 386149.095 | 2.5 | 396447.935 | | | | ug/L |
| | Sb | 121 | 790.046 | 9.6 | 62.334 | 0.07291 | 0.008 | 11.5 | ug/L |
| [| Sb | 123 | 596.308 | 7.5 | 53.222 | 0.07199 | 0.006 | 8.7 | ug/L |
| | Ba | 135 | 109663.630 | 0.7 | 56.334 | 43.78017 | 0.608 | 1.4 | ug/L |
| | Ba | 137 | 185183.094 | 2.2 | 65.001 | 43.44567 | 1.222 | 2.8 | ug/L |
| > | Tb | 159 | 450734.274 | 0.8 | 486746.910 | | | | ug/L |
| > | Ho | 165 | 421211.218 | 2.0 | 457509.069 | | | | ug/L |
| | Tl | 203 | 509.354 | 2.7 | 48.667 | 0.06031 | 0.000 | 0.7 | ug/L |
| | Tl | 205 | 1201.765 | 2.8 | 63.334 | 0.06528 | 0.003 | 5.0 | ug/L |
| | Pb | 208 | 3487.653 | 2.9 | 537.345 | 0.12145 | 0.007 | 5.8 | ug/L |

Sample ID: 950470

Report Date/Time: Monday, November 20, 2006 10:55:20

Page 1

651

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 892.057 | 2.9 | 135.336 | 0.11864 | 0.007 | 5.6 ug/L |
| | Pb | 207 | 759.042 | 5.4 | 124.336 | 0.11860 | 0.010 | 8.3 ug/L |

Sample ID: 950470

Report Date/Time: Monday, November 20, 2006 10:55:20

Page 2

652

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 117.706 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 102.394 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 97.402 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 92.601 | | | |
| > Ho | 165 | | 92.066 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950471

Sample Date/Time: Monday, November 20, 2006 10:58:16

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950471.016

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 117.669 | 12.9 | 51.334 | 0.03501 | 0.011 | 31.1 | ug/L |
| Al | 27 | 3017078.421 | 1.2 | 4379.197 | 262.66020 | 6.227 | 2.4 | ug/L |
| Sc | 45 | 534586.360 | 2.6 | 424656.486 | | | | ug/L |
| V | 51 | 17743.489 | 5.6 | 5557.188 | 0.50619 | 0.051 | 10.1 | ug/L |
| Cr | 52 | 142154.539 | 1.8 | 18419.857 | 6.58474 | 0.333 | 5.1 | ug/L |
| Cr | 53 | 16378.578 | 1.0 | 945.730 | 6.75308 | 0.245 | 3.6 | ug/L |
| Mn | 55 | 1269336.682 | 2.0 | 692.369 | 56.84637 | 1.109 | 2.0 | ug/L |
| Co | 59 | 26161.602 | 1.5 | 265.007 | 1.31290 | 0.021 | 1.6 | ug/L |
| Ni | 60 | 82733.494 | 0.6 | 177.337 | 19.14668 | 0.193 | 1.0 | ug/L |
| Ni | 62 | 12842.687 | 2.4 | 902.391 | 18.11611 | 0.384 | 2.1 | ug/L |
| Cu | 63 | 18361.392 | 1.3 | 876.388 | 1.72688 | 0.027 | 1.6 | ug/L |
| Cu | 65 | 8758.023 | 3.0 | 254.340 | 1.74523 | 0.061 | 3.5 | ug/L |
| Zn | 66 | 13912.747 | 2.3 | 2747.481 | 3.86326 | 0.090 | 2.3 | ug/L |
| Zn | 67 | 2635.443 | 1.4 | 502.020 | 4.29923 | 0.054 | 1.3 | ug/L |
| Zn | 68 | 12334.912 | 0.1 | 1975.921 | 4.99957 | 0.027 | 0.5 | ug/L |
| Ge | 72 | 254769.368 | 0.4 | 227398.462 | | | | ug/L |
| As | 75 | 2590.429 | 3.1 | 127.002 | 0.76843 | 0.029 | 3.7 | ug/L |
| Se | 77 | 355.874 | 0.8 | 226.870 | 0.42676 | 0.012 | 2.9 | ug/L |
| Se | 78 | 17947.887 | 0.9 | 16063.843 | -0.06642 | 0.113 | 169.4 | mg/L |
| Se | 82 | 1196.953 | 2.2 | 661.626 | 1.38609 | 0.086 | 6.2 | ug/L |
| Kr | 83 | 1116.419 | 2.5 | 694.703 | | | | mg/L |
| Y | 89 | 505396.840 | 1.7 | 420425.593 | | | | ug/L |
| Mo | 95 | 1426.803 | 6.3 | 127.336 | 0.20418 | 0.014 | 7.0 | ug/L |
| Mo | 97 | 840.384 | 1.4 | 61.668 | 0.20041 | 0.002 | 0.8 | ug/L |
| Mo | 98 | 2150.281 | 4.6 | 69.388 | 0.20183 | 0.006 | 3.1 | ug/L |
| Rh | 103 | 381748.524 | 2.5 | 381957.031 | | | | ug/L |
| Ag | 107 | 109.668 | 16.2 | 56.667 | 0.00330 | 0.001 | 38.9 | ug/L |
| Ag | 109 | 75.334 | 4.3 | 52.667 | 0.00138 | 0.000 | 13.2 | ug/L |
| Cd | 111 | 625.674 | 2.0 | 249.856 | 0.10534 | 0.001 | 0.9 | ug/L |
| Cd | 114 | 991.173 | 3.4 | 64.386 | 0.11804 | 0.003 | 2.1 | ug/L |
| In | 115 | 412679.653 | 1.7 | 396447.935 | | | | ug/L |
| Sb | 121 | 565.025 | 3.8 | 62.334 | 0.04676 | 0.003 | 5.9 | ug/L |
| Sb | 123 | 438.291 | 4.3 | 53.222 | 0.04735 | 0.002 | 4.7 | ug/L |
| Ba | 135 | 42048.593 | 1.8 | 56.334 | 16.50509 | 0.407 | 2.5 | ug/L |
| Ba | 137 | 72994.030 | 0.7 | 65.001 | 16.83980 | 0.127 | 0.8 | ug/L |
| Tb | 159 | 458094.779 | 1.0 | 486746.910 | | | | ug/L |
| Ho | 165 | 443688.884 | 0.6 | 457509.069 | | | | ug/L |
| Tl | 203 | 232.006 | 10.6 | 48.667 | 0.02277 | 0.003 | 12.7 | ug/L |
| Tl | 205 | 518.688 | 6.2 | 63.334 | 0.02476 | 0.002 | 6.7 | ug/L |
| Pb | 208 | 15532.457 | 1.4 | 537.345 | 0.57784 | 0.005 | 0.9 | ug/L |

Sample ID: 950471

Report Date/Time: Monday, November 20, 2006 11:01:17

Page 1

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 4119.726 | 2.3 | 135.336 | 0.58488 | 0.011 | 1.8 ug/L |
| | Pb | 207 | 3272.342 | 1.1 | 124.336 | 0.55002 | 0.007 | 1.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 125.887 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 112.037 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.094 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 94.114 | | | |
| > Ho | 165 | | 96.979 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950472

Sample Date/Time: Monday, November 20, 2006 11:04:14

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950472.017

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 110.669 | 23.0 | 51.334 | 0.03343 | 0.016 | 47.8 | ug/L |
| Al | 27 | 1260212.164 | 7.4 | 4379.197 | 114.26829 | 5.719 | 5.0 | ug/L |
| > Sc | 45 | 511444.937 | 2.5 | 424656.486 | | | | ug/L |
| V | 51 | 14975.431 | 2.2 | 5557.188 | 0.40753 | 0.005 | 1.3 | ug/L |
| Cr | 52 | 41563.828 | 1.6 | 18419.857 | 1.12186 | 0.099 | 8.8 | ug/L |
| Cr | 53 | 4248.793 | 3.1 | 945.730 | 1.44422 | 0.016 | 1.1 | ug/L |
| Mn | 55 | 1712332.389 | 1.3 | 692.369 | 80.17112 | 1.178 | 1.5 | ug/L |
| Co | 59 | 22523.291 | 1.2 | 265.007 | 1.18003 | 0.025 | 2.1 | ug/L |
| Ni | 60 | 53053.274 | 2.5 | 177.337 | 12.81972 | 0.419 | 3.3 | ug/L |
| Ni | 62 | 6563.650 | 1.0 | 902.391 | 8.95737 | 0.134 | 1.5 | ug/L |
| Cu | 63 | 16446.050 | 2.5 | 876.388 | 1.61030 | 0.031 | 1.9 | ug/L |
| Cu | 65 | 8585.506 | 0.8 | 254.340 | 1.78955 | 0.019 | 1.1 | ug/L |
| Zn | 66 | 9697.070 | 1.5 | 2747.481 | 2.51645 | 0.019 | 0.8 | ug/L |
| Zn | 67 | 1877.230 | 2.8 | 502.020 | 2.90349 | 0.138 | 4.8 | ug/L |
| Zn | 68 | 8488.742 | 2.9 | 1975.921 | 3.28935 | 0.128 | 3.9 | ug/L |
| > Ge | 72 | 243749.722 | 0.9 | 227398.462 | | | | ug/L |
| As | 75 | 3911.624 | 1.0 | 127.002 | 1.23855 | 0.013 | 1.0 | ug/L |
| Se | 77 | 614.289 | 1.4 | 226.870 | 1.62770 | 0.031 | 1.9 | ug/L |
| Se | 78 | 18268.121 | 2.9 | 16063.843 | 1.47081 | 0.976 | 66.4 | mg/L |
| Se | 82 | 1569.081 | 1.4 | 661.626 | 2.73348 | 0.028 | 1.0 | ug/L |
| Kr | 83 | 1121.087 | 4.1 | 694.703 | | | | mg/L |
| Y | 89 | 495619.081 | 0.5 | 420425.593 | | | | ug/L |
| Mo | 95 | 4702.373 | 0.6 | 127.336 | 0.75958 | 0.009 | 1.2 | ug/L |
| Mo | 97 | 2834.844 | 4.1 | 61.668 | 0.75378 | 0.040 | 5.3 | ug/L |
| Mo | 98 | 7358.153 | 0.8 | 69.388 | 0.74526 | 0.012 | 1.6 | ug/L |
| Rh | 103 | 374979.631 | 0.2 | 381957.031 | | | | ug/L |
| Ag | 107 | 132.669 | 2.6 | 56.667 | 0.00522 | 0.000 | 6.3 | ug/L |
| Ag | 109 | 109.335 | 6.5 | 52.667 | 0.00407 | 0.001 | 14.3 | ug/L |
| Cd | 111 | 493.760 | 7.9 | 249.856 | 0.07469 | 0.010 | 13.9 | ug/L |
| Cd | 114 | 723.464 | 7.0 | 64.386 | 0.08870 | 0.007 | 8.1 | ug/L |
| > In | 115 | 392224.468 | 1.1 | 396447.935 | | | | ug/L |
| Sb | 121 | 679.368 | 1.7 | 62.334 | 0.06074 | 0.002 | 2.9 | ug/L |
| Sb | 123 | 489.125 | 2.4 | 53.222 | 0.05680 | 0.002 | 3.8 | ug/L |
| Ba | 135 | 39605.301 | 1.5 | 56.334 | 15.57587 | 0.446 | 2.9 | ug/L |
| Ba | 137 | 67293.284 | 0.4 | 65.001 | 15.55412 | 0.245 | 1.6 | ug/L |
| > Tb | 159 | 457246.317 | 1.5 | 486746.910 | | | | ug/L |
| > Ho | 165 | 432684.736 | 0.8 | 457509.069 | | | | ug/L |
| Tl | 203 | 456.017 | 3.9 | 48.667 | 0.05182 | 0.002 | 4.1 | ug/L |
| Tl | 205 | 1038.075 | 3.0 | 63.334 | 0.05434 | 0.002 | 3.8 | ug/L |
| Pb | 208 | 12499.106 | 1.0 | 537.345 | 0.47332 | 0.003 | 0.6 | ug/L |

Sample ID: 950472

Report Date/Time: Monday, November 20, 2006 11:07:15

Page 1

657

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 3226.324 | 2.8 | 135.336 | 0.46588 | 0.010 | 2.0 ug/L |
| | Pb | 207 | 2713.136 | 2.1 | 124.336 | 0.46452 | 0.012 | 2.7 ug/L |

Sample ID: 950472

Report Date/Time: Monday, November 20, 2006 11:07:15

Page 2

658

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|-----------------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 120.437 | | | |
| [V | 51 | | | 120% ^{ok} SD: 120% | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 107.191 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 98.935 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 93.939 | | | |
| > [Ho | 165 | | 94.574 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950473

Sample Date/Time: Monday, November 20, 2006 11:10:11

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950473.018

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 67.668 | 7.0 | 51.334 | 0.00444 | 0.003 | 74.7 | ug/L |
| Al | 27 | 35950.415 | 1.4 | 4379.197 | 2.82558 | 0.071 | 2.5 | ug/L |
| > Sc | 45 | 506851.718 | 0.7 | 424656.486 | | | | ug/L |
| V | 51 | 9089.376 | 1.7 | 5557.188 | 0.12194 | 0.006 | 4.5 | ug/L |
| Cr | 52 | 28490.571 | 0.4 | 18419.857 | 0.37952 | 0.016 | 4.1 | ug/L |
| Cr | 53 | 2838.845 | 1.4 | 945.730 | 0.80144 | 0.013 | 1.6 | ug/L |
| Mn | 55 | 6332221.664 | 0.8 | 692.369 | 282.87181 | 3.251 | 1.1 | ug/L |
| Co | 59 | 7977.909 | 6.8 | 265.007 | 0.38871 | 0.029 | 7.4 | ug/L |
| Ni | 60 | 15780.453 | 5.9 | 177.337 | 3.60307 | 0.204 | 5.7 | ug/L |
| Ni | 62 | 812.381 | 5.8 | 902.391 | -0.30804 | 0.068 | 22.2 | ug/L |
| Cu | 63 | 8402.993 | 5.3 | 876.388 | 0.73493 | 0.046 | 6.3 | ug/L |
| Cu | 65 | 4060.697 | 1.8 | 254.340 | 0.77512 | 0.017 | 2.2 | ug/L |
| Zn | 66 | 4306.822 | 0.6 | 2747.481 | 0.43346 | 0.006 | 1.4 | ug/L |
| Zn | 67 | 1287.112 | 2.5 | 502.020 | 1.49501 | 0.075 | 5.0 | ug/L |
| Zn | 68 | 5652.640 | 1.5 | 1975.921 | 1.69026 | 0.045 | 2.7 | ug/L |
| > Ge | 72 | 255543.870 | 0.3 | 227398.462 | | | | ug/L |
| As | 75 | 1344.789 | 3.1 | 127.002 | 0.37612 | 0.013 | 3.4 | ug/L |
| Se | 77 | 548.351 | 1.1 | 226.870 | 1.22749 | 0.026 | 2.2 | ug/L |
| Se | 78 | 18955.611 | 0.4 | 16063.843 | 1.20328 | 0.063 | 5.3 | mg/L |
| Se | 82 | 1449.459 | 0.3 | 661.626 | 2.14069 | 0.026 | 1.2 | ug/L |
| Kr | 83 | 1133.422 | 3.0 | 694.703 | | | | mg/L |
| Y | 89 | 482817.671 | 1.1 | 420425.593 | | | | ug/L |
| Mo | 95 | 5946.180 | 1.0 | 127.336 | 0.89848 | 0.010 | 1.1 | ug/L |
| Mo | 97 | 3581.138 | 0.7 | 61.668 | 0.88979 | 0.017 | 1.9 | ug/L |
| Mo | 98 | 8881.026 | 1.5 | 69.388 | 0.83890 | 0.021 | 2.5 | ug/L |
| Rh | 103 | 391533.757 | 4.0 | 381957.031 | | | | ug/L |
| Ag | 107 | 72.334 | 6.4 | 56.667 | 0.00077 | 0.000 | 30.9 | ug/L |
| Ag | 109 | 58.001 | 24.0 | 52.667 | 0.00013 | 0.001 | 670.4 | ug/L |
| Cd | 111 | 449.532 | 6.3 | 249.856 | 0.05199 | 0.007 | 13.6 | ug/L |
| Cd | 114 | 290.686 | 53.1 | 64.386 | 0.02791 | 0.019 | 69.7 | ug/L |
| > In | 115 | 421032.946 | 1.3 | 396447.935 | | | | ug/L |
| Sb | 121 | 1402.465 | 2.0 | 62.334 | 0.12242 | 0.004 | 3.5 | ug/L |
| Sb | 123 | 1079.610 | 1.7 | 53.222 | 0.12400 | 0.002 | 1.5 | ug/L |
| Ba | 135 | 58854.022 | 0.6 | 56.334 | 22.27688 | 0.219 | 1.0 | ug/L |
| Ba | 137 | 105394.773 | 1.5 | 65.001 | 23.44567 | 0.275 | 1.2 | ug/L |
| > Tb | 159 | 475168.181 | 0.9 | 486746.910 | | | | ug/L |
| > Ho | 165 | 447037.190 | 0.5 | 457509.069 | | | | ug/L |
| Tl | 203 | 467.684 | 5.4 | 48.667 | 0.05140 | 0.003 | 5.9 | ug/L |
| Tl | 205 | 1070.747 | 9.7 | 63.334 | 0.05422 | 0.005 | 9.8 | ug/L |
| Pb | 208 | 828.024 | 4.3 | 537.345 | 0.01157 | 0.001 | 10.4 | ug/L |

Sample ID: 950473

Report Date/Time: Monday, November 20, 2006 11:13:12

Page 1

660

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|-----------|
| | Pb | 206 | 222.339 | 7.1 | 135.336 | 0.01312 | 0.002 | 18.2 ug/L |
| | Pb | 207 | 192.004 | 6.0 | 124.336 | 0.01221 | 0.002 | 15.1 ug/L |

Sample ID: 950473

Report Date/Time: Monday, November 20, 2006 11:13:12

Page 2

661

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 119.356 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 112.377 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 106.201 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 97.621 | | | |
| > [Ho | 165 | | 97.711 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950474

Sample Date/Time: Monday, November 20, 2006 11:16:08

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950474.019

| | Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| [| Be | 9 | 81.335 | 8.7 | 51.334 | 0.01255 | 0.004 | 31.9 | ug/L |
| | Al | 27 | 517748.123 | 9.3 | 4379.197 | 46.05688 | 5.094 | 11.1 | ug/L |
| > | Sc | 45 | 519185.186 | 1.7 | 424656.486 | | | | ug/L |
| | V | 51 | 10210.062 | 15.4 | 5557.188 | 0.16515 | 0.071 | 43.3 | ug/L |
| | Cr | 52 | 87185.691 | 2.0 | 18419.857 | 3.68208 | 0.013 | 0.3 | ug/L |
| [| Cr | 53 | 9472.810 | 1.6 | 945.730 | 3.80674 | 0.139 | 3.6 | ug/L |
| | Mn | 55 | 524127.389 | 1.0 | 692.369 | 24.31104 | 0.461 | 1.9 | ug/L |
| | Co | 59 | 6101.965 | 5.0 | 265.007 | 0.30591 | 0.015 | 4.8 | ug/L |
| | Ni | 60 | 30145.138 | 4.7 | 177.337 | 7.20289 | 0.367 | 5.1 | ug/L |
| | Ni | 62 | 3744.212 | 1.7 | 902.391 | 4.39519 | 0.162 | 3.7 | ug/L |
| | Cu | 63 | 13491.715 | 1.2 | 876.388 | 1.29182 | 0.007 | 0.5 | ug/L |
| | Cu | 65 | 6489.592 | 2.3 | 254.340 | 1.32686 | 0.046 | 3.5 | ug/L |
| | Zn | 66 | 26398.015 | 1.5 | 2747.481 | 8.66014 | 0.236 | 2.7 | ug/L |
| | Zn | 67 | 4709.044 | 1.8 | 502.020 | 8.95543 | 0.106 | 1.2 | ug/L |
| | Zn | 68 | 22699.102 | 1.2 | 1975.921 | 10.52860 | 0.206 | 2.0 | ug/L |
| > | Ge | 72 | 245815.162 | 1.1 | 227398.462 | | | | ug/L |
| | As | 75 | 1428.137 | 5.6 | 127.002 | 0.41989 | 0.026 | 6.1 | ug/L |
| | Se | 77 | 433.345 | 0.3 | 226.870 | 0.81826 | 0.025 | 3.1 | ug/L |
| | Se | 78 | 18220.977 | 1.3 | 16063.843 | 1.18639 | 0.351 | 29.6 | mg/L |
| | Se | 82 | 1284.232 | 1.8 | 661.626 | 1.79365 | 0.045 | 2.5 | ug/L |
| | Kr | 83 | 1133.088 | 4.1 | 694.703 | | | | mg/L |
| [| Y | 89 | 492743.538 | 0.6 | 420425.593 | | | | ug/L |
| | Mo | 95 | 2650.448 | 2.3 | 127.336 | 0.39969 | 0.019 | 4.9 | ug/L |
| | Mo | 97 | 1675.519 | 6.0 | 61.668 | 0.41868 | 0.033 | 7.9 | ug/L |
| | Mo | 98 | 4069.719 | 2.7 | 69.388 | 0.39067 | 0.016 | 4.0 | ug/L |
| | Rh | 103 | 391137.273 | 3.4 | 381957.031 | | | | ug/L |
| | Ag | 107 | 76.001 | 12.6 | 56.667 | 0.00114 | 0.001 | 63.2 | ug/L |
| | Ag | 109 | 65.001 | 10.1 | 52.667 | 0.00072 | 0.001 | 75.8 | ug/L |
| | Cd | 111 | 374.223 | 5.6 | 249.856 | 0.03344 | 0.005 | 14.6 | ug/L |
| | Cd | 114 | 233.751 | 18.9 | 64.386 | 0.02153 | 0.006 | 28.4 | ug/L |
| > | In | 115 | 410503.860 | 2.3 | 396447.935 | | | | ug/L |
| | Sb | 121 | 673.367 | 1.3 | 62.334 | 0.05720 | 0.001 | 1.1 | ug/L |
| [| Sb | 123 | 505.228 | 6.6 | 53.222 | 0.05591 | 0.003 | 4.8 | ug/L |
| | Ba | 135 | 66209.025 | 1.8 | 56.334 | 25.34756 | 0.457 | 1.8 | ug/L |
| | Ba | 137 | 115723.470 | 0.5 | 65.001 | 26.04399 | 0.718 | 2.8 | ug/L |
| > | Tb | 159 | 469962.048 | 2.9 | 486746.910 | | | | ug/L |
| > | Ho | 165 | 447385.544 | 1.6 | 457509.069 | | | | ug/L |
| | Tl | 203 | 419.015 | 4.0 | 48.667 | 0.04539 | 0.001 | 2.9 | ug/L |
| | Tl | 205 | 977.067 | 6.5 | 63.334 | 0.04916 | 0.003 | 6.8 | ug/L |
| | Pb | 208 | 3213.937 | 1.2 | 537.345 | 0.10264 | 0.001 | 0.7 | ug/L |

Sample ID: 950474

Report Date/Time: Monday, November 20, 2006 11:19:10

Page 1

| | | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|-----|------|
| | Pb | 206 | 846.718 | 1.2 | 135.336 | 0.10392 | 0.002 | 2.1 | ug/L |
| | Pb | 207 | 705.037 | 0.9 | 124.336 | 0.10101 | 0.003 | 2.9 | ug/L |

Sample ID: 950474

Report Date/Time: Monday, November 20, 2006 11:19:10

Page 2

664

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 122.260 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 108.099 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 103.545 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 96.552 | | | |
| > Ho | 165 | | 97.787 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950475

Sample Date/Time: Monday, November 20, 2006 11:22:06

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950475.020

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 94.335 | 7.4 | 51.334 | 0.02331 | 0.005 | 20.1 | ug/L |
| Al | 27 | 699023.467 | 1.0 | 4379.197 | 64.15686 | 0.648 | 1.0 | ug/L |
| > Sc | 45 | 504048.748 | 0.3 | 424656.486 | | | | ug/L |
| V | 51 | 11083.017 | 3.6 | 5557.188 | 0.22395 | 0.018 | 8.0 | ug/L |
| Cr | 52 | 31572.692 | 1.8 | 18419.857 | 0.56941 | 0.027 | 4.8 | ug/L |
| Cr | 53 | 3161.631 | 1.2 | 945.730 | 0.96096 | 0.014 | 1.4 | ug/L |
| Mn | 55 | 9211825.070 | 1.2 | 692.369 | 426.53063 | 7.660 | 1.8 | ug/L |
| Co | 59 | 26349.202 | 2.3 | 265.007 | 1.36680 | 0.022 | 1.6 | ug/L |
| Ni | 60 | 50026.909 | 1.8 | 177.337 | 11.94604 | 0.270 | 2.3 | ug/L |
| Ni | 62 | 5526.220 | 1.1 | 902.391 | 7.19622 | 0.164 | 2.3 | ug/L |
| Cu | 63 | 225621.175 | 2.0 | 876.388 | 23.06566 | 0.390 | 1.7 | ug/L |
| Cu | 65 | 109566.071 | 2.9 | 254.340 | 23.26174 | 0.856 | 3.7 | ug/L |
| Zn | 66 | 471567.948 | 1.1 | 2747.481 | 172.66047 | 2.227 | 1.3 | ug/L |
| Zn | 67 | 71012.676 | 0.9 | 502.020 | 151.02569 | 2.527 | 1.7 | ug/L |
| Zn | 68 | 334046.042 | 3.0 | 1975.921 | 169.43304 | 6.340 | 3.7 | ug/L |
| > Ge | 72 | 246566.066 | 0.7 | 227398.462 | | | | ug/L |
| As | 75 | 4174.754 | 0.9 | 127.002 | 1.30918 | 0.005 | 0.4 | ug/L |
| Se | 77 | 616.223 | 3.0 | 226.870 | 1.60571 | 0.098 | 6.1 | ug/L |
| Se | 78 | 18433.595 | 0.7 | 16063.843 | 1.40347 | 0.333 | 23.7 | mg/L |
| Se | 82 | 1622.891 | 1.7 | 661.626 | 2.84633 | 0.126 | 4.4 | ug/L |
| Kr | 83 | 1150.091 | 2.9 | 694.703 | | | | mg/L |
| Y | 89 | 497564.326 | 1.7 | 420425.593 | | | | ug/L |
| Mo | 95 | 9828.224 | 0.9 | 127.336 | 1.54073 | 0.029 | 1.9 | ug/L |
| Mo | 97 | 6027.239 | 1.3 | 61.668 | 1.55069 | 0.008 | 0.5 | ug/L |
| Mo | 98 | 15848.206 | 0.5 | 69.388 | 1.54397 | 0.018 | 1.2 | ug/L |
| Rh | 103 | 384161.272 | 2.5 | 381957.031 | | | | ug/L |
| Ag | 107 | 413.348 | 4.5 | 56.667 | 0.02315 | 0.001 | 5.1 | ug/L |
| Ag | 109 | 366.012 | 3.2 | 52.667 | 0.02117 | 0.001 | 5.2 | ug/L |
| Cd | 111 | 622.596 | 3.1 | 249.856 | 0.10574 | 0.004 | 4.2 | ug/L |
| Cd | 114 | 957.452 | 3.9 | 64.386 | 0.11467 | 0.006 | 5.2 | ug/L |
| > In | 115 | 409743.391 | 1.2 | 396447.935 | | | | ug/L |
| Sb | 121 | 60706.924 | 0.3 | 62.334 | 5.70754 | 0.076 | 1.3 | ug/L |
| Sb | 123 | 44457.131 | 0.4 | 53.222 | 5.53062 | 0.087 | 1.6 | ug/L |
| Ba | 135 | 141707.463 | 0.5 | 56.334 | 54.83296 | 1.121 | 2.0 | ug/L |
| Ba | 137 | 237518.160 | 0.8 | 65.001 | 54.00021 | 0.692 | 1.3 | ug/L |
| > Tb | 159 | 465144.481 | 1.5 | 486746.910 | | | | ug/L |
| > Ho | 165 | 454598.107 | 1.5 | 457509.069 | | | | ug/L |
| Tl | 203 | 867.054 | 2.3 | 48.667 | 0.09853 | 0.004 | 3.9 | ug/L |
| Tl | 205 | 2135.962 | 4.3 | 63.334 | 0.10963 | 0.006 | 5.5 | ug/L |
| Pb | 208 | 51986.376 | 1.3 | 537.345 | 1.93350 | 0.047 | 2.4 | ug/L |

Sample ID: 950475

Report Date/Time: Monday, November 20, 2006 11:25:08

Page 1

666

| | | | | | | | | |
|--|----|-----|-----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 13095.412 | 0.7 | 135.336 | 1.85538 | 0.028 | 1.5 ug/L |
| | Pb | 207 | 11142.224 | 2.0 | 124.336 | 1.87721 | 0.058 | 3.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 118.696 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 108.429 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 103.354 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 95.562 | | | |
| > [Ho | 165 | | 99.364 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950476

Sample Date/Time: Monday, November 20, 2006 11:28:04

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950476.021

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 113.669 | 4.3 | 51.334 | 0.03616 | 0.002 | 6.0 | ug/L |
| Al | 27 | 380941.840 | 2.8 | 4379.197 | 34.47068 | 1.184 | 3.4 | ug/L |
| > Sc | 45 | 508100.362 | 1.6 | 424656.486 | | | | ug/L |
| V | 51 | 10358.957 | 3.7 | 5557.188 | 0.18378 | 0.020 | 10.9 | ug/L |
| Cr | 52 | 29364.951 | 1.8 | 18419.857 | 0.42623 | 0.013 | 3.0 | ug/L |
| Cr | 53 | 2950.552 | 0.7 | 945.730 | 0.85075 | 0.031 | 3.7 | ug/L |
| Mn | 55 | 8915417.885 | 1.6 | 692.369 | 413.98580 | 11.016 | 2.7 | ug/L |
| Co | 59 | 25958.968 | 1.6 | 265.007 | 1.35019 | 0.018 | 1.3 | ug/L |
| Ni | 60 | 48275.589 | 1.2 | 177.337 | 11.55844 | 0.230 | 2.0 | ug/L |
| Ni | 62 | 5018.895 | 2.1 | 902.391 | 6.41383 | 0.061 | 0.9 | ug/L |
| Cu | 63 | 174780.736 | 1.0 | 876.388 | 17.89630 | 0.166 | 0.9 | ug/L |
| Cu | 65 | 82497.512 | 3.6 | 254.340 | 17.55232 | 0.863 | 4.9 | ug/L |
| Zn | 66 | 393047.378 | 1.0 | 2747.481 | 144.12415 | 1.208 | 0.8 | ug/L |
| Zn | 67 | 62017.258 | 2.0 | 502.020 | 132.10205 | 2.310 | 1.7 | ug/L |
| Zn | 68 | 286130.073 | 2.3 | 1975.921 | 145.38128 | 4.868 | 3.3 | ug/L |
| > Ge | 72 | 245900.903 | 1.5 | 227398.462 | | | | ug/L |
| As | 75 | 4098.717 | 4.7 | 127.002 | 1.28833 | 0.066 | 5.1 | ug/L |
| Se | 77 | 633.557 | 1.7 | 226.870 | 1.68791 | 0.024 | 1.4 | ug/L |
| Se | 78 | 18941.597 | 1.0 | 16063.843 | 2.18033 | 0.649 | 29.8 | mg/L |
| Se | 82 | 1617.690 | 1.2 | 661.626 | 2.84453 | 0.140 | 4.9 | ug/L |
| Kr | 83 | 1165.760 | 2.1 | 694.703 | | | | mg/L |
| Y | 89 | 494386.668 | 2.1 | 420425.593 | | | | ug/L |
| Mo | 95 | 9137.766 | 1.2 | 127.336 | 1.40194 | 0.031 | 2.2 | ug/L |
| Mo | 97 | 5479.522 | 1.1 | 61.668 | 1.37995 | 0.031 | 2.3 | ug/L |
| Mo | 98 | 14017.704 | 4.2 | 69.388 | 1.33689 | 0.039 | 2.9 | ug/L |
| Rh | 103 | 385945.178 | 0.5 | 381957.031 | | | | ug/L |
| Ag | 107 | 238.006 | 12.0 | 56.667 | 0.01141 | 0.002 | 17.5 | ug/L |
| Ag | 109 | 192.004 | 6.9 | 52.667 | 0.00908 | 0.001 | 8.7 | ug/L |
| Cd | 111 | 615.822 | 3.2 | 249.856 | 0.10018 | 0.004 | 4.3 | ug/L |
| Cd | 114 | 849.089 | 6.5 | 64.386 | 0.09845 | 0.006 | 5.8 | ug/L |
| > In | 115 | 418124.889 | 1.2 | 396447.935 | | | | ug/L |
| Sb | 121 | 33911.550 | 2.0 | 62.334 | 3.12176 | 0.083 | 2.6 | ug/L |
| Sb | 123 | 25926.728 | 1.2 | 53.222 | 3.15742 | 0.015 | 0.5 | ug/L |
| Ba | 135 | 135824.706 | 1.0 | 56.334 | 51.83526 | 0.912 | 1.8 | ug/L |
| Ba | 137 | 240144.045 | 0.2 | 65.001 | 53.85179 | 0.464 | 0.9 | ug/L |
| > Tb | 159 | 471551.622 | 0.8 | 486746.910 | | | | ug/L |
| > Ho | 165 | 456365.919 | 1.5 | 457509.069 | | | | ug/L |
| Tl | 203 | 850.052 | 1.8 | 48.667 | 0.09608 | 0.003 | 3.1 | ug/L |
| Tl | 205 | 2007.596 | 4.8 | 63.334 | 0.10236 | 0.004 | 3.5 | ug/L |
| Pb | 208 | 33509.517 | 0.1 | 537.345 | 1.23420 | 0.017 | 1.4 | ug/L |

Sample ID: 950476

Report Date/Time: Monday, November 20, 2006 11:31:05

Page 1

669

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 8575.162 | 1.0 | 135.336 | 1.20355 | 0.021 | 1.7 ug/L |
| | Pb | 207 | 7350.982 | 1.8 | 124.336 | 1.22621 | 0.020 | 1.7 ug/L |

Sample ID: 950476

Report Date/Time: Monday, November 20, 2006 11:31:05

Page 2

670

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 119.650 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 108.137 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 105.468 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 96.878 | | | |
| > [Ho | 165 | | 99.750 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 20, 2006 11:34:02

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 6.022

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 61809.680 | 1.1 | 51.334 | 50.89309 | 1.172 | 2.3 | ug/L |
| Al | 27 | 501697.471 | 0.5 | 4379.197 | 54.27735 | 0.828 | 1.5 | ug/L |
| > Sc | 45 | 427097.936 | 1.6 | 424656.486 | | | | ug/L |
| V | 51 | 880895.769 | 0.8 | 5557.188 | 51.57576 | 0.830 | 1.6 | ug/L |
| Cr | 52 | 759854.893 | 1.6 | 18419.857 | 51.32226 | 1.070 | 2.1 | ug/L |
| Cr | 53 | 90130.384 | 3.4 | 945.730 | 49.59286 | 0.981 | 2.0 | ug/L |
| Mn | 55 | 1048897.237 | 1.8 | 692.369 | 52.52004 | 0.368 | 0.7 | ug/L |
| Co | 59 | 857867.137 | 2.8 | 265.007 | 48.66650 | 0.563 | 1.2 | ug/L |
| Ni | 60 | 195892.973 | 2.1 | 177.337 | 50.76212 | 0.469 | 0.9 | ug/L |
| Ni | 62 | 30111.318 | 3.6 | 902.391 | 49.99379 | 0.967 | 1.9 | ug/L |
| Cu | 63 | 454442.505 | 3.2 | 876.388 | 50.38040 | 0.767 | 1.5 | ug/L |
| Cu | 65 | 219390.889 | 1.9 | 254.340 | 50.46951 | 1.111 | 2.2 | ug/L |
| Zn | 66 | 128184.431 | 2.7 | 2747.481 | 50.00452 | 0.511 | 1.0 | ug/L |
| Zn | 67 | 21443.780 | 2.5 | 502.020 | 48.55586 | 0.380 | 0.8 | ug/L |
| Zn | 68 | 92404.173 | 1.7 | 1975.921 | 49.95899 | 1.626 | 3.3 | ug/L |
| > Ge | 72 | 227859.025 | 1.7 | 227398.462 | | | | ug/L |
| As | 75 | 140967.610 | 1.7 | 127.002 | 49.44334 | 1.722 | 3.5 | ug/L |
| Se | 77 | 11251.993 | 1.7 | 226.870 | 51.72915 | 0.548 | 1.1 | ug/L |
| Se | 78 | 49730.110 | 1.1 | 16063.843 | 50.25283 | 1.715 | 3.4 | mg/L |
| Se | 82 | 16311.418 | 1.7 | 661.626 | 53.22041 | 0.787 | 1.5 | ug/L |
| Kr | 83 | 1046.076 | 2.1 | 694.703 | | | | mg/L |
| Y | 89 | 442476.225 | 2.2 | 420425.593 | | | | ug/L |
| Mo | 95 | 303066.748 | 2.5 | 127.336 | 50.35932 | 0.611 | 1.2 | ug/L |
| Mo | 97 | 194548.234 | 2.9 | 61.668 | 52.93580 | 2.009 | 3.8 | ug/L |
| Mo | 98 | 498077.234 | 3.6 | 69.388 | 50.98390 | 0.847 | 1.7 | ug/L |
| Rh | 103 | 376966.404 | 0.4 | 381957.031 | | | | ug/L |
| Ag | 107 | 748420.388 | 0.5 | 56.667 | 51.10651 | 0.989 | 1.9 | ug/L |
| Ag | 109 | 705849.698 | 2.0 | 52.667 | 50.17021 | 0.355 | 0.7 | ug/L |
| Cd | 111 | 173129.360 | 2.6 | 249.856 | 52.53414 | 2.377 | 4.5 | ug/L |
| Cd | 114 | 384944.838 | 3.3 | 64.386 | 51.80994 | 0.949 | 1.8 | ug/L |
| > In | 115 | 391578.701 | 2.0 | 396447.935 | | | | ug/L |
| Sb | 121 | 515677.408 | 2.2 | 62.334 | 50.77553 | 0.691 | 1.4 | ug/L |
| Sb | 123 | 383744.128 | 0.8 | 53.222 | 50.01049 | 0.654 | 1.3 | ug/L |
| Ba | 135 | 135910.664 | 2.1 | 56.334 | 52.12977 | 0.883 | 1.7 | ug/L |
| Ba | 137 | 230227.929 | 1.9 | 65.001 | 51.89129 | 0.819 | 1.6 | ug/L |
| > Tb | 159 | 469129.413 | 0.7 | 486746.910 | | | | ug/L |
| > Ho | 165 | 439814.144 | 1.0 | 457509.069 | | | | ug/L |
| Tl | 203 | 417347.116 | 0.7 | 48.667 | 51.89451 | 0.247 | 0.5 | ug/L |
| Tl | 205 | 984068.828 | 1.0 | 63.334 | 53.76707 | 0.216 | 0.4 | ug/L |
| Pb | 208 | 1350668.974 | 2.0 | 537.345 | 52.42841 | 0.642 | 1.2 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Monday, November 20, 2006 11:37:05

Page 1

672

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 347046.880 | 2.9 | 135.336 | 51.32169 | 1.225 | 2.4 ug/L |
| | Pb | 207 | 291019.035 | 0.8 | 124.336 | 51.21732 | 0.832 | 1.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 101.786 | | | | |
| Al | 27 | 108.555 | | | | |
| > Sc | 45 | | 100.575 | | | |
| V | 51 | 103.152 | | | | |
| Cr | 52 | 102.645 | | | | |
| Cr | 53 | 99.186 | | | | |
| Mn | 55 | 105.040 | | | | |
| Co | 59 | 97.333 | | | | |
| Ni | 60 | 101.524 | | | | |
| Ni | 62 | 99.988 | | | | |
| Cu | 63 | 100.761 | | | | |
| Cu | 65 | 100.939 | | | | |
| Zn | 66 | 100.009 | | | | |
| Zn | 67 | 97.112 | | | | |
| Zn | 68 | 99.918 | | | | |
| > Ge | 72 | | 100.203 | | | |
| As | 75 | 98.887 | | | | |
| Se | 77 | 103.458 | | | | |
| Se | 78 | 100.506 | | | | |
| Se | 82 | 106.441 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 100.719 | | | | |
| Mo | 97 | 105.872 | | | | |
| Mo | 98 | 101.968 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 102.213 | | | | |
| Ag | 109 | 100.340 | | | | |
| Cd | 111 | 105.068 | | | | |
| Cd | 114 | 103.620 | | | | |
| > In | 115 | | 98.772 | | | |
| Sb | 121 | 101.551 | | | | |
| Sb | 123 | 100.021 | | | | |
| Ba | 135 | 104.260 | | | | |
| Ba | 137 | 103.783 | | | | |
| > Tb | 159 | | 96.381 | | | |
| > Ho | 165 | | 96.132 | | | |
| Tl | 203 | 103.789 | | | | |
| Tl | 205 | 107.534 | | | | |
| Pb | 208 | 104.857 | | | | |
| Pb | 206 | 102.643 | | | | |
| Pb | 207 | 102.435 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 20, 2006 11:40:00

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 7.023

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 48.667 | 8.6 | 51.334 | -0.00156 | 0.004 | 251.2 | ug/L |
| Al | 27 | 3644.500 | 2.1 | 4379.197 | -0.07451 | 0.004 | 5.3 | ug/L |
| > Sc | 45 | 418242.347 | 1.7 | 424656.486 | | | | ug/L |
| V | 51 | 5436.101 | 1.5 | 5557.188 | -0.00221 | 0.004 | 191.5 | ug/L |
| Cr | 52 | 17998.264 | 1.2 | 18419.857 | -0.00985 | 0.029 | 296.5 | ug/L |
| Cr | 53 | 1037.742 | 2.1 | 945.730 | 0.06036 | 0.005 | 8.6 | ug/L |
| Mn | 55 | 638.698 | 1.6 | 692.369 | -0.00195 | 0.001 | 46.0 | ug/L |
| Co | 59 | 174.004 | 4.0 | 265.007 | -0.00495 | 0.000 | 8.8 | ug/L |
| Ni | 60 | 158.670 | 10.1 | 177.337 | -0.00392 | 0.004 | 101.9 | ug/L |
| Ni | 62 | 205.338 | 5.1 | 902.391 | -1.18773 | 0.019 | 1.6 | ug/L |
| Cu | 63 | 358.678 | 0.8 | 876.388 | -0.05672 | 0.000 | 0.9 | ug/L |
| Cu | 65 | 260.340 | 6.4 | 254.340 | 0.00276 | 0.004 | 143.2 | ug/L |
| Zn | 66 | 2381.698 | 3.8 | 2747.481 | -0.12454 | 0.029 | 23.1 | ug/L |
| Zn | 67 | 468.351 | 3.4 | 502.020 | -0.05331 | 0.037 | 69.4 | ug/L |
| Zn | 68 | 1785.543 | 2.6 | 1975.921 | -0.08247 | 0.038 | 46.5 | ug/L |
| > Ge | 72 | 222318.663 | 1.3 | 227398.462 | | | | ug/L |
| As | 75 | 144.336 | 10.8 | 127.002 | 0.00731 | 0.006 | 86.0 | ug/L |
| Se | 77 | 238.470 | 4.7 | 226.870 | 0.08008 | 0.049 | 61.2 | ug/L |
| Se | 78 | 15592.175 | 0.9 | 16063.843 | -0.17125 | 0.246 | 143.6 | mg/L |
| Se | 82 | 1063.601 | 2.0 | 661.626 | 1.45236 | 0.029 | 2.0 | ug/L |
| Kr | 83 | 1070.746 | 2.8 | 694.703 | | | | mg/L |
| Y | 89 | 425536.359 | 2.4 | 420425.593 | | | | ug/L |
| Mo | 95 | 525.022 | 15.8 | 127.336 | 0.06527 | 0.013 | 20.4 | ug/L |
| Mo | 97 | 302.009 | 19.5 | 61.668 | 0.06456 | 0.016 | 24.0 | ug/L |
| Mo | 98 | 731.021 | 20.1 | 69.388 | 0.06688 | 0.015 | 21.8 | ug/L |
| Rh | 103 | 373961.119 | 2.0 | 381957.031 | | | | ug/L |
| Ag | 107 | 136.669 | 18.0 | 56.667 | 0.00539 | 0.002 | 30.6 | ug/L |
| Ag | 109 | 109.335 | 6.7 | 52.667 | 0.00398 | 0.000 | 12.4 | ug/L |
| Cd | 111 | 237.443 | 3.1 | 249.856 | -0.00372 | 0.002 | 66.8 | ug/L |
| Cd | 114 | 61.609 | 9.4 | 64.386 | -0.00037 | 0.001 | 202.2 | ug/L |
| > In | 115 | 396445.115 | 0.4 | 396447.935 | | | | ug/L |
| Sb | 121 | 898.058 | 13.4 | 62.334 | 0.08126 | 0.011 | 14.0 | ug/L |
| Sb | 123 | 692.851 | 13.8 | 53.222 | 0.08230 | 0.012 | 14.5 | ug/L |
| Ba | 135 | 49.334 | 10.2 | 56.334 | -0.00209 | 0.002 | 96.3 | ug/L |
| Ba | 137 | 67.001 | 8.3 | 65.001 | 0.00084 | 0.001 | 173.2 | ug/L |
| > Tb | 159 | 473985.498 | 1.4 | 486746.910 | | | | ug/L |
| > Ho | 165 | 443723.011 | 1.3 | 457509.069 | | | | ug/L |
| Tl | 203 | 60.001 | 15.3 | 48.667 | 0.00157 | 0.001 | 66.0 | ug/L |
| Tl | 205 | 112.669 | 8.2 | 63.334 | 0.00277 | 0.000 | 15.4 | ug/L |
| Pb | 208 | 399.007 | 3.3 | 537.345 | -0.00470 | 0.001 | 14.7 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Monday, November 20, 2006 11:43:01

Page 1

675

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|-----------|
| | Pb | 206 | 116.335 | 4.7 | 135.336 | -0.00218 | 0.001 | 45.4 ug/L |
| | Pb | 207 | 95.335 | 6.7 | 124.336 | -0.00440 | 0.001 | 29.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 98.490 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 97.766 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 99.999 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.378 | | | |
| > Ho | 165 | | 96.987 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477

Sample Date/Time: Monday, November 20, 2006 11:45:58

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950477.024

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 85.668 | 9.4 | 51.334 | 0.01595 | 0.007 | 43.2 | ug/L |
| Al | 27 | 33926.602 | 1.4 | 4379.197 | 2.58245 | 0.037 | 1.4 | ug/L |
| > Sc | 45 | 516328.424 | 2.5 | 424656.486 | | | | ug/L |
| V | 51 | 9415.129 | 2.7 | 5557.188 | 0.12953 | 0.001 | 0.9 | ug/L |
| Cr | 52 | 27733.021 | 1.5 | 18419.857 | 0.30649 | 0.058 | 18.8 | ug/L |
| Cr | 53 | 2442.049 | 2.1 | 945.730 | 0.59498 | 0.038 | 6.4 | ug/L |
| Mn | 55 | 6576222.642 | 1.4 | 692.369 | 305.89519 | 4.183 | 1.4 | ug/L |
| Co | 59 | 12345.598 | 2.4 | 265.007 | 0.63549 | 0.016 | 2.6 | ug/L |
| Ni | 60 | 38238.420 | 5.5 | 177.337 | 9.16270 | 0.510 | 5.6 | ug/L |
| Ni | 62 | 3100.608 | 2.2 | 902.391 | 3.38074 | 0.112 | 3.3 | ug/L |
| Cu | 63 | 7590.867 | 2.8 | 876.388 | 0.68543 | 0.021 | 3.1 | ug/L |
| Cu | 65 | 4201.768 | 2.1 | 254.340 | 0.83968 | 0.019 | 2.3 | ug/L |
| Zn | 66 | 26303.051 | 1.9 | 2747.481 | 8.63955 | 0.195 | 2.3 | ug/L |
| Zn | 67 | 5584.594 | 2.5 | 502.020 | 10.85774 | 0.314 | 2.9 | ug/L |
| Zn | 68 | 24569.750 | 1.4 | 1975.921 | 11.50574 | 0.169 | 1.5 | ug/L |
| > Ge | 72 | 245412.281 | 0.1 | 227398.462 | | | | ug/L |
| As | 75 | 7409.369 | 3.6 | 127.002 | 2.36943 | 0.087 | 3.7 | ug/L |
| Se | 77 | 451.612 | 1.7 | 226.870 | 0.90075 | 0.033 | 3.6 | ug/L |
| Se | 78 | 18386.765 | 2.0 | 16063.843 | 1.45693 | 0.539 | 37.0 | mg/L |
| Se | 82 | 1399.851 | 0.6 | 661.626 | 2.16547 | 0.029 | 1.3 | ug/L |
| Kr | 83 | 1185.096 | 3.0 | 694.703 | | | | mg/L |
| Y | 89 | 502373.646 | 3.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 10884.214 | 2.2 | 127.336 | 1.61457 | 0.060 | 3.7 | ug/L |
| Mo | 97 | 6695.423 | 2.2 | 61.668 | 1.63019 | 0.064 | 3.9 | ug/L |
| Mo | 98 | 16513.581 | 1.5 | 69.388 | 1.52155 | 0.058 | 3.8 | ug/L |
| Rh | 103 | 401822.899 | 1.5 | 381957.031 | | | | ug/L |
| Ag | 107 | 92.001 | 13.6 | 56.667 | 0.00184 | 0.001 | 34.8 | ug/L |
| Ag | 109 | 63.668 | 6.5 | 52.667 | 0.00040 | 0.000 | 87.6 | ug/L |
| Cd | 111 | 548.837 | 2.1 | 249.856 | 0.07575 | 0.007 | 9.0 | ug/L |
| Cd | 114 | 555.302 | 14.1 | 64.386 | 0.05901 | 0.010 | 16.1 | ug/L |
| > In | 115 | 433438.928 | 2.6 | 396447.935 | | | | ug/L |
| Sb | 121 | 987.069 | 10.1 | 62.334 | 0.08194 | 0.011 | 13.7 | ug/L |
| Sb | 123 | 736.612 | 5.9 | 53.222 | 0.07998 | 0.007 | 8.7 | ug/L |
| Ba | 135 | 166546.319 | 1.4 | 56.334 | 61.73683 | 0.432 | 0.7 | ug/L |
| Ba | 137 | 297217.582 | 0.8 | 65.001 | 64.74766 | 1.023 | 1.6 | ug/L |
| > Tb | 159 | 485448.286 | 0.7 | 486746.910 | | | | ug/L |
| > Ho | 165 | 462529.270 | 0.9 | 457509.069 | | | | ug/L |
| Tl | 203 | 470.685 | 5.3 | 48.667 | 0.04986 | 0.003 | 6.7 | ug/L |
| Tl | 205 | 1042.742 | 1.2 | 63.334 | 0.05086 | 0.001 | 2.3 | ug/L |
| Pb | 208 | 9529.540 | 1.5 | 537.345 | 0.33183 | 0.004 | 1.2 | ug/L |

Sample ID: 950477

Report Date/Time: Monday, November 20, 2006 11:48:59

Page 1

678

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 2480.394 | 2.3 | 135.336 | 0.32967 | 0.006 | 1.8 ug/L |
| | Pb | 207 | 2077.613 | 3.0 | 124.336 | 0.32675 | 0.010 | 3.0 ug/L |

Sample ID: 950477

Report Date/Time: Monday, November 20, 2006 11:48:59

Page 2

679

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 121.587 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 107.922 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 109.331 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 99.733 | | | |
| > [Ho | 165 | | 101.097 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477D

Sample Date/Time: Monday, November 20, 2006 11:51:56

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950477D.025

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 86.001 | 9.3 | 51.334 | 0.01454 | 0.005 | 37.1 | ug/L |
| Al | 27 | 35958.782 | 1.2 | 4379.197 | 2.68073 | 0.082 | 3.1 | ug/L |
| > Sc | 45 | 530278.794 | 1.6 | 424656.486 | | | | ug/L |
| V | 51 | 9226.289 | 8.3 | 5557.188 | 0.10892 | 0.043 | 39.2 | ug/L |
| Cr | 52 | 26577.642 | 4.7 | 18419.857 | 0.20032 | 0.093 | 46.2 | ug/L |
| Cr | 53 | 2437.714 | 2.8 | 945.730 | 0.56305 | 0.028 | 5.0 | ug/L |
| Mn | 55 | 6653730.398 | 1.7 | 692.369 | 296.01422 | 10.115 | 3.4 | ug/L |
| Co | 59 | 12275.492 | 1.6 | 265.007 | 0.60350 | 0.016 | 2.6 | ug/L |
| Ni | 60 | 36349.552 | 4.0 | 177.337 | 8.32722 | 0.450 | 5.4 | ug/L |
| Ni | 62 | 3170.635 | 2.7 | 902.391 | 3.27267 | 0.201 | 6.2 | ug/L |
| Cu | 63 | 7671.273 | 1.6 | 876.388 | 0.65899 | 0.008 | 1.1 | ug/L |
| Cu | 65 | 4130.399 | 3.0 | 254.340 | 0.78603 | 0.039 | 4.9 | ug/L |
| Zn | 66 | 16830.151 | 2.0 | 2747.481 | 4.86166 | 0.232 | 4.8 | ug/L |
| Zn | 67 | 3919.295 | 3.7 | 502.020 | 6.90641 | 0.440 | 6.4 | ug/L |
| Zn | 68 | 17181.208 | 2.8 | 1975.921 | 7.33185 | 0.295 | 4.0 | ug/L |
| > Ge | 72 | 256697.738 | 1.9 | 227398.462 | | | | ug/L |
| As | 75 | 7225.537 | 0.8 | 127.002 | 2.20669 | 0.053 | 2.4 | ug/L |
| Se | 77 | 455.612 | 2.6 | 226.870 | 0.83148 | 0.066 | 7.9 | ug/L |
| Se | 78 | 17751.655 | 0.4 | 16063.843 | -0.50042 | 0.482 | 96.4 | mg/L |
| Se | 82 | 1419.254 | 0.8 | 661.626 | 2.03070 | 0.087 | 4.3 | ug/L |
| Kr | 83 | 1219.768 | 5.0 | 694.703 | | | | mg/L |
| Y | 89 | 519125.397 | 2.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 10467.342 | 1.4 | 127.336 | 1.57208 | 0.030 | 1.9 | ug/L |
| Mo | 97 | 6439.552 | 0.7 | 61.668 | 1.58740 | 0.017 | 1.1 | ug/L |
| Mo | 98 | 16912.312 | 1.2 | 69.388 | 1.57826 | 0.020 | 1.3 | ug/L |
| Rh | 103 | 396969.551 | 1.0 | 381957.031 | | | | ug/L |
| Ag | 107 | 92.668 | 2.5 | 56.667 | 0.00197 | 0.000 | 7.2 | ug/L |
| Ag | 109 | 68.668 | 19.6 | 52.667 | 0.00077 | 0.001 | 116.2 | ug/L |
| Cd | 111 | 500.070 | 3.3 | 249.856 | 0.06410 | 0.006 | 8.7 | ug/L |
| Cd | 114 | 533.200 | 21.3 | 64.386 | 0.05721 | 0.014 | 25.2 | ug/L |
| > In | 115 | 427767.858 | 0.7 | 396447.935 | | | | ug/L |
| Sb | 121 | 778.711 | 5.9 | 62.334 | 0.06414 | 0.004 | 6.5 | ug/L |
| Sb | 123 | 571.834 | 4.7 | 53.222 | 0.06136 | 0.003 | 4.8 | ug/L |
| Ba | 135 | 171416.506 | 0.8 | 56.334 | 64.14371 | 1.056 | 1.6 | ug/L |
| Ba | 137 | 292725.980 | 0.8 | 65.001 | 64.36461 | 1.016 | 1.6 | ug/L |
| > Tb | 159 | 480961.111 | 0.9 | 486746.910 | | | | ug/L |
| > Ho | 165 | 462333.693 | 0.5 | 457509.069 | | | | ug/L |
| Tl | 203 | 438.016 | 7.5 | 48.667 | 0.04601 | 0.004 | 9.0 | ug/L |
| Tl | 205 | 1066.746 | 5.3 | 63.334 | 0.05213 | 0.003 | 6.2 | ug/L |
| Pb | 208 | 9397.827 | 1.8 | 537.345 | 0.32714 | 0.008 | 2.5 | ug/L |

Sample ID: 950477D

Report Date/Time: Monday, November 20, 2006 11:54:58

Page 1

681

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 2435.380 | 2.0 | 135.336 | 0.32353 | 0.008 | 2.6 ug/L |
| | Pb | 207 | 2020.932 | 4.2 | 124.336 | 0.31744 | 0.015 | 4.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 124.872 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 112.885 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 107.900 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.811 | | | |
| > [Ho | 165 | | 101.055 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477S

Sample Date/Time: Monday, November 20, 2006 11:57:56

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950477S.026

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 23383.668 | 1.6 | 51.334 | 15.95989 | 0.101 | 0.6 | ug/L |
| Al | 27 | 227456.302 | 1.3 | 4379.197 | 20.13922 | 0.329 | 1.6 | ug/L |
| > Sc | 45 | 514172.296 | 1.2 | 424656.486 | | | | ug/L |
| V | 51 | 384924.997 | 2.1 | 5557.188 | 18.50746 | 0.294 | 1.6 | ug/L |
| Cr | 52 | 327427.993 | 1.1 | 18419.857 | 17.54711 | 0.415 | 2.4 | ug/L |
| Cr | 53 | 40076.544 | 1.1 | 945.730 | 17.98660 | 0.046 | 0.3 | ug/L |
| Mn | 55 | 6888257.361 | 1.1 | 692.369 | 320.75625 | 3.588 | 1.1 | ug/L |
| Co | 59 | 405741.007 | 3.6 | 265.007 | 21.38752 | 0.735 | 3.4 | ug/L |
| Ni | 60 | 119658.817 | 2.4 | 177.337 | 28.80172 | 0.726 | 2.5 | ug/L |
| Ni | 62 | 15274.138 | 0.7 | 902.391 | 22.75841 | 0.229 | 1.0 | ug/L |
| Cu | 63 | 197812.691 | 3.5 | 876.388 | 20.32697 | 0.636 | 3.1 | ug/L |
| Cu | 65 | 93699.721 | 2.9 | 254.340 | 19.99494 | 0.499 | 2.5 | ug/L |
| Zn | 66 | 55077.303 | 0.9 | 2747.481 | 19.31349 | 0.228 | 1.2 | ug/L |
| Zn | 67 | 11071.129 | 2.2 | 502.020 | 22.69499 | 0.433 | 1.9 | ug/L |
| Zn | 68 | 45499.347 | 1.6 | 1975.921 | 22.26449 | 0.449 | 2.0 | ug/L |
| > Ge | 72 | 245150.441 | 0.4 | 227398.462 | | | | ug/L |
| As | 75 | 64555.215 | 3.1 | 127.002 | 21.01133 | 0.667 | 3.2 | ug/L |
| Se | 77 | 4448.654 | 0.4 | 226.870 | 18.33425 | 0.156 | 0.8 | ug/L |
| Se | 78 | 29583.288 | 0.8 | 16063.843 | 17.02845 | 0.467 | 2.7 | mg/L |
| Se | 82 | 6947.495 | 0.5 | 661.626 | 19.70560 | 0.091 | 0.5 | ug/L |
| Kr | 83 | 1200.099 | 5.6 | 694.703 | | | | mg/L |
| Y | 89 | 499974.487 | 1.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 151001.438 | 1.3 | 127.336 | 23.55115 | 0.153 | 0.7 | ug/L |
| Mo | 97 | 92586.529 | 1.8 | 61.668 | 23.63848 | 0.233 | 1.0 | ug/L |
| Mo | 98 | 243709.068 | 1.7 | 69.388 | 23.43272 | 0.732 | 3.1 | ug/L |
| Rh | 103 | 383325.729 | 2.7 | 381957.031 | | | | ug/L |
| Ag | 107 | 309068.604 | 1.8 | 56.667 | 19.81212 | 0.383 | 1.9 | ug/L |
| Ag | 109 | 295265.881 | 1.2 | 52.667 | 19.70519 | 0.198 | 1.0 | ug/L |
| Cd | 111 | 69543.525 | 3.7 | 249.856 | 19.75466 | 0.592 | 3.0 | ug/L |
| Cd | 114 | 152289.768 | 0.8 | 64.386 | 19.24815 | 0.459 | 2.4 | ug/L |
| > In | 115 | 417035.596 | 1.9 | 396447.935 | | | | ug/L |
| Sb | 121 | 214215.831 | 0.3 | 62.334 | 19.80490 | 0.328 | 1.7 | ug/L |
| Sb | 123 | 159091.922 | 2.1 | 53.222 | 19.46466 | 0.535 | 2.7 | ug/L |
| Ba | 135 | 224036.370 | 2.2 | 56.334 | 85.29717 | 1.619 | 1.9 | ug/L |
| Ba | 137 | 380374.272 | 1.7 | 65.001 | 85.08999 | 0.012 | 0.0 | ug/L |
| > Tb | 159 | 472729.779 | 1.7 | 486746.910 | | | | ug/L |
| > Ho | 165 | 459588.745 | 1.3 | 457509.069 | | | | ug/L |
| Tl | 203 | 170216.214 | 1.8 | 48.667 | 20.24977 | 0.095 | 0.5 | ug/L |
| Tl | 205 | 409242.861 | 0.6 | 63.334 | 21.39891 | 0.367 | 1.7 | ug/L |
| Pb | 208 | 550917.231 | 1.6 | 537.345 | 20.45304 | 0.066 | 0.3 | ug/L |

Sample ID: 950477S

Report Date/Time: Monday, November 20, 2006 12:00:58

Page 1

684

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 142756.465 | 2.1 | 135.336 | 20.19106 | 0.210 | 1.0 ug/L |
| | Pb | 207 | 118340.840 | 2.4 | 124.336 | 19.91465 | 0.266 | 1.3 ug/L |

Sample ID: 950477S

Report Date/Time: Monday, November 20, 2006 12:00:58

Page 2

685

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 121.080 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 107.807 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 105.193 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.120 | | | |
| > Ho | 165 | | 100.455 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477A

Sample Date/Time: Monday, November 20, 2006 12:03:54

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950477A.027

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 24712.840 | 1.3 | 51.334 | 16.83099 | 0.525 | 3.1 | ug/L |
| Al | 27 | 240239.712 | 2.4 | 4379.197 | 21.23881 | 0.410 | 1.9 | ug/L |
| > Sc | 45 | 515593.587 | 2.3 | 424656.486 | | | | ug/L |
| V | 51 | 411084.276 | 1.8 | 5557.188 | 19.74228 | 0.701 | 3.6 | ug/L |
| Cr | 52 | 352998.000 | 1.3 | 18419.857 | 18.96568 | 0.541 | 2.9 | ug/L |
| Cr | 53 | 41158.836 | 2.2 | 945.730 | 18.43631 | 0.321 | 1.7 | ug/L |
| Mn | 55 | 6898940.555 | 1.0 | 692.369 | 324.52360 | 7.501 | 2.3 | ug/L |
| Co | 59 | 410481.859 | 1.3 | 265.007 | 21.85710 | 0.423 | 1.9 | ug/L |
| Ni | 60 | 124002.066 | 1.0 | 177.337 | 30.14842 | 0.315 | 1.0 | ug/L |
| Ni | 62 | 15203.675 | 0.3 | 902.391 | 22.89067 | 0.378 | 1.7 | ug/L |
| Cu | 63 | 206925.350 | 0.6 | 876.388 | 21.48432 | 0.207 | 1.0 | ug/L |
| Cu | 65 | 98748.615 | 4.2 | 254.340 | 21.28526 | 0.734 | 3.4 | ug/L |
| Zn | 66 | 72124.553 | 1.8 | 2747.481 | 25.90454 | 0.827 | 3.2 | ug/L |
| Zn | 67 | 13919.421 | 0.5 | 502.020 | 29.13837 | 0.460 | 1.6 | ug/L |
| Zn | 68 | 57246.253 | 2.2 | 1975.921 | 28.58549 | 0.353 | 1.2 | ug/L |
| > Ge | 72 | 242727.366 | 1.3 | 227398.462 | | | | ug/L |
| As | 75 | 68390.877 | 1.4 | 127.002 | 22.48510 | 0.187 | 0.8 | ug/L |
| Se | 77 | 4600.736 | 0.7 | 226.870 | 19.19995 | 0.323 | 1.7 | ug/L |
| Se | 78 | 31502.187 | 0.5 | 16063.843 | 20.13263 | 0.591 | 2.9 | mg/L |
| Se | 82 | 7266.433 | 0.5 | 661.626 | 20.94665 | 0.421 | 2.0 | ug/L |
| Kr | 83 | 1193.764 | 1.7 | 694.703 | | | | mg/L |
| Y | 89 | 495530.260 | 1.7 | 420425.593 | | | | ug/L |
| Mo | 95 | 162665.779 | 2.4 | 127.336 | 24.88064 | 0.405 | 1.6 | ug/L |
| Mo | 97 | 99546.042 | 0.7 | 61.668 | 24.92944 | 0.375 | 1.5 | ug/L |
| Mo | 98 | 255045.303 | 2.9 | 69.388 | 24.04176 | 0.573 | 2.4 | ug/L |
| Rh | 103 | 387606.846 | 1.5 | 381957.031 | | | | ug/L |
| Ag | 107 | 332249.599 | 1.0 | 56.667 | 20.88881 | 0.386 | 1.8 | ug/L |
| Ag | 109 | 308600.246 | 1.4 | 52.667 | 20.19729 | 0.176 | 0.9 | ug/L |
| Cd | 111 | 73599.574 | 1.0 | 249.856 | 20.51142 | 0.369 | 1.8 | ug/L |
| Cd | 114 | 160583.673 | 2.0 | 64.386 | 19.90385 | 0.528 | 2.7 | ug/L |
| > In | 115 | 425199.131 | 0.9 | 396447.935 | | | | ug/L |
| Sb | 121 | 223252.958 | 0.7 | 62.334 | 20.24063 | 0.165 | 0.8 | ug/L |
| Sb | 123 | 169528.217 | 1.1 | 53.222 | 20.33894 | 0.114 | 0.6 | ug/L |
| Ba | 135 | 223184.119 | 0.6 | 56.334 | 83.69971 | 0.891 | 1.1 | ug/L |
| Ba | 137 | 396257.160 | 0.6 | 65.001 | 87.32036 | 0.894 | 1.0 | ug/L |
| > Tb | 159 | 479913.057 | 0.8 | 486746.910 | | | | ug/L |
| > Ho | 165 | 460664.199 | 0.4 | 457509.069 | | | | ug/L |
| Tl | 203 | 183140.516 | 1.1 | 48.667 | 21.73838 | 0.298 | 1.4 | ug/L |
| Tl | 205 | 420136.932 | 0.1 | 63.334 | 21.91455 | 0.122 | 0.6 | ug/L |
| Pb | 208 | 576672.845 | 1.1 | 537.345 | 21.36148 | 0.326 | 1.5 | ug/L |

Sample ID: 950477A

Report Date/Time: Monday, November 20, 2006 12:06:56

Page 1

687

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 150069.077 | 0.9 | 135.336 | 21.17787 | 0.201 | 0.9 ug/L |
| | Pb | 207 | 124826.703 | 1.7 | 124.336 | 20.96099 | 0.446 | 2.1 ug/L |

Sample ID: 950477A

Report Date/Time: Monday, November 20, 2006 12:06:56

Page 2

688

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 121.414 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 106.741 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 107.252 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.596 | | | |
| > Ho | 165 | | 100.690 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477L

Sample Date/Time: Monday, November 20, 2006 12:09:52

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950477L.028

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59.001 | 26.6 | 51.334 | 0.00448 | 0.013 | 281.8 | ug/L |
| Al | 27 | 9335.320 | 1.0 | 4379.197 | 0.50400 | 0.022 | 4.4 | ug/L |
| > Sc | 45 | 441990.731 | 1.6 | 424656.486 | | | | ug/L |
| V | 51 | 5697.609 | 0.7 | 5557.188 | -0.00487 | 0.005 | 101.4 | ug/L |
| Cr | 52 | 18558.498 | 1.6 | 18419.857 | -0.04067 | 0.036 | 88.1 | ug/L |
| Cr | 53 | 1336.454 | 2.3 | 945.730 | 0.18928 | 0.015 | 7.7 | ug/L |
| Mn | 55 | 1130379.287 | 0.9 | 692.369 | 58.20492 | 1.211 | 2.1 | ug/L |
| Co | 59 | 2470.057 | 0.6 | 265.007 | 0.12908 | 0.003 | 2.0 | ug/L |
| Ni | 60 | 6982.661 | 1.5 | 177.337 | 1.81650 | 0.057 | 3.1 | ug/L |
| Ni | 62 | 724.372 | 2.8 | 902.391 | -0.27323 | 0.016 | 5.9 | ug/L |
| Cu | 63 | 1691.522 | 3.7 | 876.388 | 0.09573 | 0.010 | 10.2 | ug/L |
| Cu | 65 | 1090.416 | 0.6 | 254.340 | 0.19952 | 0.006 | 2.8 | ug/L |
| Zn | 66 | 10055.831 | 0.6 | 2747.481 | 3.02523 | 0.088 | 2.9 | ug/L |
| Zn | 67 | 1904.904 | 5.3 | 502.020 | 3.37574 | 0.249 | 7.4 | ug/L |
| Zn | 68 | 8089.673 | 2.2 | 1975.921 | 3.50176 | 0.173 | 4.9 | ug/L |
| > Ge | 72 | 221631.534 | 1.6 | 227398.462 | | | | ug/L |
| As | 75 | 1595.169 | 1.3 | 127.002 | 0.53088 | 0.006 | 1.2 | ug/L |
| Se | 77 | 268.804 | 1.3 | 226.870 | 0.23022 | 0.024 | 10.5 | ug/L |
| Se | 78 | 15772.523 | 1.2 | 16063.843 | 0.18261 | 0.505 | 276.4 | mg/L |
| Se | 82 | 1129.743 | 0.8 | 661.626 | 1.69569 | 0.035 | 2.0 | ug/L |
| Kr | 83 | 1114.419 | 3.6 | 694.703 | | | | mg/L |
| Y | 89 | 440980.260 | 1.3 | 420425.593 | | | | ug/L |
| Mo | 95 | 2092.284 | 1.2 | 127.336 | 0.30865 | 0.003 | 0.9 | ug/L |
| Mo | 97 | 1216.101 | 5.0 | 61.668 | 0.29698 | 0.016 | 5.6 | ug/L |
| Mo | 98 | 3120.113 | 0.9 | 69.388 | 0.29570 | 0.003 | 0.9 | ug/L |
| Rh | 103 | 376345.631 | 1.4 | 381957.031 | | | | ug/L |
| Ag | 107 | 91.001 | 6.7 | 56.667 | 0.00206 | 0.000 | 18.2 | ug/L |
| Ag | 109 | 69.334 | 11.2 | 52.667 | 0.00097 | 0.001 | 52.8 | ug/L |
| Cd | 111 | 292.818 | 8.6 | 249.856 | 0.00930 | 0.007 | 74.6 | ug/L |
| Cd | 114 | 151.433 | 28.0 | 64.386 | 0.01075 | 0.005 | 49.8 | ug/L |
| > In | 115 | 413269.236 | 0.4 | 396447.935 | | | | ug/L |
| Sb | 121 | 445.683 | 8.9 | 62.334 | 0.03553 | 0.004 | 10.6 | ug/L |
| Sb | 123 | 343.868 | 10.4 | 53.222 | 0.03562 | 0.005 | 12.7 | ug/L |
| Ba | 135 | 34077.210 | 0.9 | 56.334 | 13.01795 | 0.301 | 2.3 | ug/L |
| Ba | 137 | 59890.722 | 1.0 | 65.001 | 13.44973 | 0.311 | 2.3 | ug/L |
| > Tb | 159 | 470586.064 | 1.5 | 486746.910 | | | | ug/L |
| > Ho | 165 | 453490.466 | 1.9 | 457509.069 | | | | ug/L |
| Tl | 203 | 147.003 | 7.2 | 48.667 | 0.01192 | 0.001 | 12.3 | ug/L |
| Tl | 205 | 298.675 | 3.0 | 63.334 | 0.01251 | 0.001 | 5.3 | ug/L |
| Pb | 208 | 2333.484 | 1.6 | 537.345 | 0.06786 | 0.003 | 4.2 | ug/L |

Sample ID: 950477L

Report Date/Time: Monday, November 20, 2006 12:12:53

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 604.695 | 3.8 | 135.336 | 0.06753 | 0.003 | 5.0 ug/L |
| | Pb | 207 | 502.687 | 2.0 | 124.336 | 0.06483 | 0.003 | 5.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 104.082 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 97.464 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.243 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 96.680 | | | |
| > Ho | 165 | | 99.122 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956 D.10

Sample Date/Time: Monday, November 20, 2006 12:15:50

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\948956 D.10.029

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55.001 | 14.4 | 51.334 | 0.00169 | 0.007 | 438.8 | ug/L |
| Al | 27 | 6482.252 | 2.2 | 4379.197 | 0.20794 | 0.014 | 6.6 | ug/L |
| > Sc | 45 | 438855.320 | 2.6 | 424656.486 | | | | ug/L |
| V | 51 | 5019.656 | 5.1 | 5557.188 | -0.04155 | 0.009 | 22.4 | ug/L |
| Cr | 52 | 16899.957 | 1.6 | 18419.857 | -0.14366 | 0.014 | 9.5 | ug/L |
| Cr | 53 | 1139.089 | 4.4 | 945.730 | 0.08810 | 0.039 | 44.3 | ug/L |
| Mn | 55 | 14387526.925 | 1.7 | 692.369 | 709.99038 | 8.445 | 1.2 | ug/L |
| Co | 59 | 26159.600 | 1.9 | 265.007 | 1.44737 | 0.033 | 2.3 | ug/L |
| Ni | 60 | 5593.266 | 2.5 | 177.337 | 1.38302 | 0.044 | 3.2 | ug/L |
| Ni | 62 | 804.380 | 6.7 | 902.391 | -0.19137 | 0.095 | 49.8 | ug/L |
| Cu | 63 | 1472.145 | 0.8 | 876.388 | 0.06353 | 0.001 | 2.2 | ug/L |
| Cu | 65 | 486.352 | 4.1 | 254.340 | 0.05162 | 0.004 | 7.9 | ug/L |
| Zn | 66 | 1374.128 | 8.3 | 2747.481 | -0.55818 | 0.041 | 7.4 | ug/L |
| Zn | 67 | 366.012 | 2.9 | 502.020 | -0.33046 | 0.026 | 7.8 | ug/L |
| Zn | 68 | 1393.464 | 2.2 | 1975.921 | -0.33550 | 0.013 | 3.8 | ug/L |
| > Ge | 72 | 231333.993 | 0.6 | 227398.462 | | | | ug/L |
| As | 75 | 74817.505 | 1.8 | 127.002 | 25.81459 | 0.304 | 1.2 | ug/L |
| Se | 77 | 249.137 | 3.0 | 226.870 | 0.08465 | 0.028 | 32.5 | ug/L |
| Se | 78 | 15997.211 | 0.1 | 16063.843 | -0.50648 | 0.136 | 26.9 | mg/L |
| Se | 82 | 1114.808 | 0.4 | 661.626 | 1.47968 | 0.009 | 0.6 | ug/L |
| Kr | 83 | 1149.758 | 5.9 | 694.703 | | | | mg/L |
| Y | 89 | 430730.593 | 1.4 | 420425.593 | | | | ug/L |
| Mo | 95 | 17569.346 | 1.4 | 127.336 | 2.70244 | 0.074 | 2.8 | ug/L |
| Mo | 97 | 11121.530 | 2.2 | 61.668 | 2.80440 | 0.056 | 2.0 | ug/L |
| Mo | 98 | 28336.823 | 1.8 | 69.388 | 2.69769 | 0.009 | 0.4 | ug/L |
| Rh | 103 | 388669.156 | 2.1 | 381957.031 | | | | ug/L |
| Ag | 107 | 78.001 | 6.8 | 56.667 | 0.00115 | 0.000 | 36.4 | ug/L |
| Ag | 109 | 54.001 | 9.3 | 52.667 | -0.00012 | 0.000 | 254.0 | ug/L |
| Cd | 111 | 229.012 | 12.2 | 249.856 | -0.01019 | 0.007 | 66.3 | ug/L |
| Cd | 114 | 94.748 | 18.8 | 64.386 | 0.00335 | 0.002 | 73.1 | ug/L |
| > In | 115 | 420083.930 | 1.8 | 396447.935 | | | | ug/L |
| Sb | 121 | 621.696 | 2.7 | 62.334 | 0.05100 | 0.001 | 1.0 | ug/L |
| Sb | 123 | 504.043 | 4.8 | 53.222 | 0.05442 | 0.004 | 7.2 | ug/L |
| Ba | 135 | 6724.446 | 0.3 | 56.334 | 2.48336 | 0.065 | 2.6 | ug/L |
| Ba | 137 | 12031.471 | 3.0 | 65.001 | 2.61844 | 0.105 | 4.0 | ug/L |
| > Tb | 159 | 483585.707 | 2.3 | 486746.910 | | | | ug/L |
| > Ho | 165 | 461125.752 | 0.5 | 457509.069 | | | | ug/L |
| Tl | 203 | 178.670 | 11.7 | 48.667 | 0.01538 | 0.003 | 16.8 | ug/L |
| Tl | 205 | 362.011 | 1.9 | 63.334 | 0.01554 | 0.000 | 2.9 | ug/L |
| Pb | 208 | 536.345 | 2.7 | 537.345 | -0.00019 | 0.001 | 309.6 | ug/L |

Sample ID: 948956 D.10

Report Date/Time: Monday, November 20, 2006 12:18:51

Page 1

| | | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|-------|------|
| | Pb | 206 | 142.336 | 6.0 | 135.336 | 0.00084 | 0.001 | 154.9 | ug/L |
| | Pb | 207 | 122.669 | 6.2 | 124.336 | -0.00044 | 0.001 | 303.6 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 103.344 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 101.731 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 105.962 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 99.351 | | | |
| > [Ho | 165 | | 100.791 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956D D.10

Sample Date/Time: Monday, November 20, 2006 12:23:23

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\948956D D.10.030

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 50.001 | 14.0 | 51.334 | -0.00251 | 0.005 | 206.1 | ug/L |
| Al | 27 | 8156.739 | 2.2 | 4379.197 | 0.38515 | 0.029 | 7.6 | ug/L |
| > Sc | 45 | 439222.748 | 1.2 | 424656.486 | | | | ug/L |
| V | 51 | 4900.725 | 2.3 | 5557.188 | -0.04855 | 0.003 | 6.3 | ug/L |
| Cr | 52 | 16675.504 | 1.7 | 18419.857 | -0.15993 | 0.015 | 9.2 | ug/L |
| Cr | 53 | 1083.748 | 5.3 | 945.730 | 0.05702 | 0.027 | 48.1 | ug/L |
| Mn | 55 | 14578380.992 | 0.1 | 692.369 | 726.59887 | 16.887 | 2.3 | ug/L |
| Co | 59 | 26413.728 | 1.0 | 265.007 | 1.47611 | 0.032 | 2.1 | ug/L |
| Ni | 60 | 5532.892 | 2.5 | 177.337 | 1.38136 | 0.041 | 3.0 | ug/L |
| Ni | 62 | 844.385 | 4.9 | 902.391 | -0.11088 | 0.046 | 41.6 | ug/L |
| Cu | 63 | 1491.148 | 4.4 | 876.388 | 0.06714 | 0.005 | 7.1 | ug/L |
| Cu | 65 | 400.347 | 6.2 | 254.340 | 0.03302 | 0.006 | 17.9 | ug/L |
| Zn | 66 | 1333.120 | 4.9 | 2747.481 | -0.56925 | 0.017 | 3.0 | ug/L |
| Zn | 67 | 338.677 | 5.4 | 502.020 | -0.38482 | 0.055 | 14.3 | ug/L |
| Zn | 68 | 1310.116 | 5.6 | 1975.921 | -0.37334 | 0.051 | 13.7 | ug/L |
| > Ge | 72 | 229132.324 | 2.2 | 227398.462 | | | | ug/L |
| As | 75 | 74454.561 | 1.0 | 127.002 | 25.94877 | 0.782 | 3.0 | ug/L |
| Se | 77 | 242.737 | 1.4 | 226.870 | 0.06641 | 0.033 | 50.2 | ug/L |
| Se | 78 | 15691.806 | 1.6 | 16063.843 | -0.72095 | 0.904 | 125.4 | mg/L |
| Se | 82 | 1094.805 | 0.4 | 661.626 | 1.44895 | 0.072 | 5.0 | ug/L |
| Kr | 83 | 1100.084 | 3.5 | 694.703 | | | | mg/L |
| Y | 89 | 433136.970 | 3.3 | 420425.593 | | | | ug/L |
| Mo | 95 | 17526.590 | 1.7 | 127.336 | 2.77859 | 0.063 | 2.3 | ug/L |
| Mo | 97 | 11166.255 | 1.0 | 61.668 | 2.90240 | 0.022 | 0.7 | ug/L |
| Mo | 98 | 29032.455 | 2.5 | 69.388 | 2.84878 | 0.045 | 1.6 | ug/L |
| Rh | 103 | 385733.440 | 1.2 | 381957.031 | | | | ug/L |
| Ag | 107 | 61.668 | 3.4 | 56.667 | 0.00023 | 0.000 | 83.1 | ug/L |
| Ag | 109 | 51.334 | 6.0 | 52.667 | -0.00019 | 0.000 | 133.7 | ug/L |
| Cd | 111 | 218.965 | 10.5 | 249.856 | -0.01110 | 0.006 | 54.4 | ug/L |
| Cd | 114 | 111.033 | 15.7 | 64.386 | 0.00582 | 0.002 | 41.7 | ug/L |
| > In | 115 | 407595.191 | 1.3 | 396447.935 | | | | ug/L |
| Sb | 121 | 619.363 | 3.9 | 62.334 | 0.05255 | 0.003 | 5.5 | ug/L |
| Sb | 123 | 489.217 | 5.1 | 53.222 | 0.05438 | 0.002 | 4.4 | ug/L |
| Ba | 135 | 6946.300 | 4.0 | 56.334 | 2.57061 | 0.115 | 4.5 | ug/L |
| Ba | 137 | 11973.716 | 0.5 | 65.001 | 2.61026 | 0.027 | 1.0 | ug/L |
| > Tb | 159 | 482611.126 | 1.5 | 486746.910 | | | | ug/L |
| > Ho | 165 | 467896.839 | 1.4 | 457509.069 | | | | ug/L |
| Tl | 203 | 183.337 | 11.9 | 48.667 | 0.01559 | 0.002 | 14.2 | ug/L |
| Tl | 205 | 412.681 | 6.5 | 63.334 | 0.01788 | 0.002 | 9.2 | ug/L |
| Pb | 208 | 469.676 | 6.5 | 537.345 | -0.00292 | 0.001 | 30.3 | ug/L |

Sample ID: 948956D D.10

Report Date/Time: Monday, November 20, 2006 12:26:24

Page 1

696

| | | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|-------|------|
| | Pb | 206 | 121.002 | 6.8 | 135.336 | -0.00243 | 0.001 | 41.0 | ug/L |
| | Pb | 207 | 113.002 | 16.8 | 124.336 | -0.00236 | 0.003 | 124.3 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 103.430 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 100.762 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 102.812 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 99.150 | | | |
| > [Ho | 165 | | 102.271 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956S D.10

Sample Date/Time: Monday, November 20, 2006 12:29:21

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\948956S D.10.031

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 2437.381 | 1.9 | 51.334 | 1.94102 | 0.090 | 4.7 | ug/L |
| Al | 27 | 25192.608 | 0.3 | 4379.197 | 2.23400 | 0.070 | 3.1 | ug/L |
| > Sc | 45 | 432733.523 | 2.6 | 424656.486 | | | | ug/L |
| V | 51 | 40663.054 | 1.5 | 5557.188 | 2.03687 | 0.099 | 4.9 | ug/L |
| Cr | 52 | 46429.173 | 2.7 | 18419.857 | 1.89199 | 0.152 | 8.0 | ug/L |
| Cr | 53 | 4505.596 | 1.8 | 945.730 | 1.94485 | 0.042 | 2.1 | ug/L |
| Mn | 55 | 13960541.042 | 1.1 | 692.369 | 700.27680 | 20.379 | 2.9 | ug/L |
| Co | 59 | 61600.469 | 1.1 | 265.007 | 3.48494 | 0.090 | 2.6 | ug/L |
| Ni | 60 | 13516.092 | 2.6 | 177.337 | 3.46591 | 0.198 | 5.7 | ug/L |
| Ni | 62 | 2012.263 | 1.9 | 902.391 | 1.90049 | 0.079 | 4.2 | ug/L |
| Cu | 63 | 20075.353 | 0.5 | 876.388 | 2.13601 | 0.090 | 4.2 | ug/L |
| Cu | 65 | 9473.144 | 1.6 | 254.340 | 2.12510 | 0.056 | 2.6 | ug/L |
| Zn | 66 | 6563.317 | 2.2 | 2747.481 | 1.52150 | 0.047 | 3.1 | ug/L |
| Zn | 67 | 1230.437 | 3.1 | 502.020 | 1.68868 | 0.032 | 1.9 | ug/L |
| Zn | 68 | 5071.262 | 4.3 | 1975.921 | 1.71195 | 0.179 | 10.5 | ug/L |
| > Ge | 72 | 227746.055 | 3.7 | 227398.462 | | | | ug/L |
| As | 75 | 75799.621 | 1.1 | 127.002 | 26.58661 | 0.795 | 3.0 | ug/L |
| Se | 77 | 654.959 | 1.1 | 226.870 | 2.01054 | 0.112 | 5.6 | ug/L |
| Se | 78 | 16826.788 | 1.0 | 16063.843 | 1.13132 | 1.146 | 101.3 | mg/L |
| Se | 82 | 1675.168 | 1.0 | 661.626 | 3.44936 | 0.184 | 5.3 | ug/L |
| Kr | 83 | 1119.086 | 5.0 | 694.703 | | | | mg/L |
| Y | 89 | 424098.822 | 0.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 29003.692 | 2.3 | 127.336 | 4.73570 | 0.079 | 1.7 | ug/L |
| Mo | 97 | 18991.818 | 2.9 | 61.668 | 5.08259 | 0.187 | 3.7 | ug/L |
| Mo | 98 | 47719.057 | 3.5 | 69.388 | 4.81353 | 0.160 | 3.3 | ug/L |
| Rh | 103 | 381876.757 | 1.3 | 381957.031 | | | | ug/L |
| Ag | 107 | 33564.134 | 1.4 | 56.667 | 2.25704 | 0.031 | 1.4 | ug/L |
| Ag | 109 | 31342.817 | 1.2 | 52.667 | 2.19433 | 0.022 | 1.0 | ug/L |
| Cd | 111 | 7455.635 | 2.8 | 249.856 | 2.15924 | 0.077 | 3.6 | ug/L |
| Cd | 114 | 16541.953 | 1.0 | 64.386 | 2.18856 | 0.006 | 0.3 | ug/L |
| > In | 115 | 396904.982 | 0.9 | 396447.935 | | | | ug/L |
| Sb | 121 | 22006.917 | 2.4 | 62.334 | 2.13187 | 0.042 | 2.0 | ug/L |
| Sb | 123 | 16656.007 | 1.9 | 53.222 | 2.13495 | 0.059 | 2.7 | ug/L |
| Ba | 135 | 12301.530 | 1.2 | 56.334 | 4.56573 | 0.097 | 2.1 | ug/L |
| Ba | 137 | 21367.915 | 2.1 | 65.001 | 4.66611 | 0.082 | 1.8 | ug/L |
| > Tb | 159 | 482901.876 | 1.5 | 486746.910 | | | | ug/L |
| > Ho | 165 | 455508.834 | 1.6 | 457509.069 | | | | ug/L |
| Tl | 203 | 18369.742 | 0.9 | 48.667 | 2.20040 | 0.054 | 2.5 | ug/L |
| Tl | 205 | 44117.925 | 1.1 | 63.334 | 2.32437 | 0.012 | 0.5 | ug/L |
| Pb | 208 | 57931.854 | 0.4 | 537.345 | 2.15241 | 0.028 | 1.3 | ug/L |

Sample ID: 948956S D.10

Report Date/Time: Monday, November 20, 2006 12:32:22

Page 1

| | | | | | | | | |
|--|----|-----|-----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 14618.626 | 1.6 | 135.336 | 2.06926 | 0.043 | 2.1 ug/L |
| | Pb | 207 | 12547.899 | 0.8 | 124.336 | 2.11241 | 0.051 | 2.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 101.902 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 100.153 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 100.115 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.210 | | | |
| > Ho | 165 | | 99.563 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956A D.10

Sample Date/Time: Monday, November 20, 2006 12:35:18

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\948956A D.10.032

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 23011.627 | 1.0 | 51.334 | 19.57201 | 0.485 | 2.5 | ug/L |
| Al | 27 | 199208.278 | 1.6 | 4379.197 | 22.00738 | 0.437 | 2.0 | ug/L |
| Sc | 45 | 413061.064 | 3.5 | 424656.486 | | | | ug/L |
| V | 51 | 351314.998 | 2.7 | 5557.188 | 21.08224 | 0.685 | 3.3 | ug/L |
| Cr | 52 | 304461.940 | 1.3 | 18419.857 | 20.52055 | 0.523 | 2.6 | ug/L |
| Cr | 53 | 34309.498 | 1.1 | 945.730 | 19.21681 | 0.660 | 3.4 | ug/L |
| Mn | 55 | 14483909.907 | 1.2 | 692.369 | 759.57332 | 3.169 | 0.4 | ug/L |
| Co | 59 | 375960.728 | 0.8 | 265.007 | 22.32281 | 0.473 | 2.1 | ug/L |
| Ni | 60 | 84537.392 | 3.0 | 177.337 | 22.91020 | 0.872 | 3.8 | ug/L |
| Ni | 62 | 12398.007 | 1.4 | 902.391 | 20.66959 | 0.064 | 0.3 | ug/L |
| Cu | 63 | 182229.562 | 1.2 | 876.388 | 21.09394 | 0.255 | 1.2 | ug/L |
| Cu | 65 | 87231.460 | 1.6 | 254.340 | 20.97188 | 0.598 | 2.9 | ug/L |
| Zn | 66 | 48559.560 | 0.7 | 2747.481 | 19.16858 | 0.128 | 0.7 | ug/L |
| Zn | 67 | 8302.884 | 1.2 | 502.020 | 18.98980 | 0.429 | 2.3 | ug/L |
| Zn | 68 | 36069.008 | 4.2 | 1975.921 | 19.75258 | 0.614 | 3.1 | ug/L |
| Ge | 72 | 217692.888 | 1.3 | 227398.462 | | | | ug/L |
| As | 75 | 124660.168 | 1.3 | 127.002 | 45.75009 | 0.943 | 2.1 | ug/L |
| Se | 77 | 4324.922 | 0.9 | 226.870 | 20.17522 | 0.301 | 1.5 | ug/L |
| Se | 78 | 28516.115 | 0.8 | 16063.843 | 20.54110 | 0.271 | 1.3 | mg/L |
| Se | 82 | 6721.176 | 1.2 | 661.626 | 21.67104 | 0.268 | 1.2 | ug/L |
| Kr | 83 | 1083.081 | 2.9 | 694.703 | | | | mg/L |
| Y | 89 | 411761.670 | 3.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 135704.390 | 0.6 | 127.336 | 22.70727 | 0.407 | 1.8 | ug/L |
| Mo | 97 | 89207.266 | 1.9 | 61.668 | 24.43388 | 0.349 | 1.4 | ug/L |
| Mo | 98 | 221600.117 | 0.5 | 69.388 | 22.85439 | 0.467 | 2.0 | ug/L |
| Rh | 103 | 362792.301 | 2.7 | 381957.031 | | | | ug/L |
| Ag | 107 | 309353.531 | 1.2 | 56.667 | 21.27218 | 0.103 | 0.5 | ug/L |
| Ag | 109 | 282029.195 | 2.8 | 52.667 | 20.19490 | 0.731 | 3.6 | ug/L |
| Cd | 111 | 69916.683 | 1.2 | 249.856 | 21.31765 | 0.488 | 2.3 | ug/L |
| Cd | 114 | 156193.193 | 1.2 | 64.386 | 21.17633 | 0.397 | 1.9 | ug/L |
| In | 115 | 388739.265 | 1.5 | 396447.935 | | | | ug/L |
| Sb | 121 | 207384.992 | 0.9 | 62.334 | 20.56907 | 0.439 | 2.1 | ug/L |
| Sb | 123 | 157289.847 | 2.2 | 53.222 | 20.63988 | 0.228 | 1.1 | ug/L |
| Ba | 135 | 61493.049 | 1.9 | 56.334 | 23.96214 | 0.322 | 1.3 | ug/L |
| Ba | 137 | 103133.976 | 0.5 | 65.001 | 23.62351 | 0.494 | 2.1 | ug/L |
| Tb | 159 | 461590.838 | 1.8 | 486746.910 | | | | ug/L |
| Ho | 165 | 435642.994 | 1.4 | 457509.069 | | | | ug/L |
| Tl | 203 | 173402.582 | 0.1 | 48.667 | 21.76671 | 0.289 | 1.3 | ug/L |
| Tl | 205 | 407698.141 | 1.4 | 63.334 | 22.48756 | 0.218 | 1.0 | ug/L |
| Pb | 208 | 545702.694 | 1.1 | 537.345 | 21.37529 | 0.175 | 0.8 | ug/L |

Sample ID: 948956A D.10

Report Date/Time: Monday, November 20, 2006 12:38:20

Page 1

702

| | | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|-----|------|
| | Pb | 206 | 139787.196 | 1.3 | 135.336 | 20.86100 | 0.298 | 1.4 | ug/L |
| | Pb | 207 | 118407.812 | 0.5 | 124.336 | 21.02579 | 0.200 | 0.9 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 97.269 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 95.732 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.056 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 94.832 | | | |
| > Ho | 165 | | 95.221 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948956L D.10

Sample Date/Time: Monday, November 20, 2006 12:41:16

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\948956L D.10.033

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 46.334 | 16.8 | 51.334 | -0.00362 | 0.007 | 186.9 | ug/L |
| Al | 27 | 4154.078 | 3.8 | 4379.197 | -0.01890 | 0.011 | 59.9 | ug/L |
| > Sc | 45 | 419229.812 | 1.4 | 424656.486 | | | | ug/L |
| V | 51 | 4495.275 | 4.5 | 5557.188 | -0.05945 | 0.012 | 20.9 | ug/L |
| Cr | 52 | 15447.798 | 2.5 | 18419.857 | -0.19309 | 0.013 | 6.5 | ug/L |
| Cr | 53 | 900.391 | 1.6 | 945.730 | -0.01876 | 0.012 | 64.9 | ug/L |
| Mn | 55 | 2767203.547 | 1.8 | 692.369 | 148.25335 | 3.458 | 2.3 | ug/L |
| Co | 59 | 5263.383 | 4.2 | 265.007 | 0.30470 | 0.022 | 7.1 | ug/L |
| Ni | 60 | 1110.752 | 8.3 | 177.337 | 0.26237 | 0.031 | 11.9 | ug/L |
| Ni | 62 | 338.344 | 4.6 | 902.391 | -0.92801 | 0.043 | 4.6 | ug/L |
| Cu | 63 | 511.354 | 5.5 | 876.388 | -0.03684 | 0.002 | 5.7 | ug/L |
| Cu | 65 | 240.006 | 1.9 | 254.340 | 0.00042 | 0.001 | 194.2 | ug/L |
| Zn | 66 | 895.724 | 1.7 | 2747.481 | -0.71571 | 0.007 | 1.0 | ug/L |
| Zn | 67 | 259.007 | 2.0 | 502.020 | -0.52424 | 0.007 | 1.3 | ug/L |
| Zn | 68 | 785.378 | 2.4 | 1975.921 | -0.62935 | 0.022 | 3.6 | ug/L |
| > Ge | 72 | 213110.203 | 2.6 | 227398.462 | | | | ug/L |
| As | 75 | 13802.896 | 1.9 | 127.002 | 5.13802 | 0.223 | 4.3 | ug/L |
| Se | 77 | 217.003 | 2.5 | 226.870 | 0.02289 | 0.052 | 227.4 | ug/L |
| Se | 78 | 14692.835 | 1.6 | 16063.843 | -0.56269 | 0.895 | 159.1 | mg/L |
| Se | 82 | 1054.333 | 2.0 | 661.626 | 1.58064 | 0.117 | 7.4 | ug/L |
| Kr | 83 | 1071.746 | 3.9 | 694.703 | | | | mg/L |
| Y | 89 | 399570.193 | 3.0 | 420425.593 | | | | ug/L |
| Mo | 95 | 3553.127 | 2.6 | 127.336 | 0.56583 | 0.020 | 3.6 | ug/L |
| Mo | 97 | 2149.966 | 3.7 | 61.668 | 0.56437 | 0.019 | 3.4 | ug/L |
| Mo | 98 | 5474.498 | 0.7 | 69.388 | 0.54979 | 0.012 | 2.2 | ug/L |
| Rh | 103 | 360062.405 | 0.2 | 381957.031 | | | | ug/L |
| Ag | 107 | 73.334 | 20.8 | 56.667 | 0.00115 | 0.001 | 90.4 | ug/L |
| Ag | 109 | 64.668 | 28.7 | 52.667 | 0.00088 | 0.001 | 153.3 | ug/L |
| Cd | 111 | 217.311 | 1.0 | 249.856 | -0.00940 | 0.001 | 6.7 | ug/L |
| Cd | 114 | 61.683 | 22.2 | 64.386 | -0.00031 | 0.002 | 616.5 | ug/L |
| > In | 115 | 394308.341 | 1.7 | 396447.935 | | | | ug/L |
| Sb | 121 | 417.681 | 5.0 | 62.334 | 0.03477 | 0.002 | 4.6 | ug/L |
| Sb | 123 | 300.478 | 8.8 | 53.222 | 0.03205 | 0.004 | 11.0 | ug/L |
| Ba | 135 | 1372.793 | 1.7 | 56.334 | 0.51497 | 0.015 | 2.9 | ug/L |
| Ba | 137 | 2262.330 | 5.2 | 65.001 | 0.50469 | 0.030 | 5.9 | ug/L |
| > Tb | 159 | 461314.839 | 1.1 | 486746.910 | | | | ug/L |
| > Ho | 165 | 452022.396 | 0.6 | 457509.069 | | | | ug/L |
| Tl | 203 | 76.001 | 6.6 | 48.667 | 0.00338 | 0.001 | 17.6 | ug/L |
| Tl | 205 | 155.003 | 8.7 | 63.334 | 0.00491 | 0.001 | 13.7 | ug/L |
| Pb | 208 | 417.675 | 4.8 | 537.345 | -0.00428 | 0.001 | 17.6 | ug/L |

Sample ID: 948956L D.10

Report Date/Time: Monday, November 20, 2006 12:44:17

Page 1

705

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|-----------|
| | Pb | 206 | 115.669 | 2.6 | 135.336 | -0.00260 | 0.000 | 19.1 ug/L |
| | Pb | 207 | 106.668 | 9.8 | 124.336 | -0.00277 | 0.002 | 64.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 98.722 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 93.717 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 99.460 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 94.775 | | | |
| > [Ho | 165 | | 98.801 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 948957 D.10

Sample Date/Time: Monday, November 20, 2006 12:47:14

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\948957 D.10.034

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54.334 | 13.9 | 51.334 | 0.00297 | 0.006 | 199.0 | ug/L |
| Al | 27 | 4866.136 | 2.4 | 4379.197 | 0.05966 | 0.017 | 29.1 | ug/L |
| > Sc | 45 | 419848.812 | 0.9 | 424656.486 | | | | ug/L |
| V | 51 | 4758.789 | 1.0 | 5557.188 | -0.04408 | 0.000 | 0.3 | ug/L |
| Cr | 52 | 16331.153 | 1.6 | 18419.857 | -0.13244 | 0.008 | 5.8 | ug/L |
| Cr | 53 | 989.069 | 2.5 | 945.730 | 0.03057 | 0.012 | 39.5 | ug/L |
| Mn | 55 | 15047745.126 | 0.7 | 692.369 | 782.55548 | 6.256 | 0.8 | ug/L |
| Co | 59 | 27356.446 | 1.9 | 265.007 | 1.59641 | 0.024 | 1.5 | ug/L |
| Ni | 60 | 5767.053 | 1.3 | 177.337 | 1.50684 | 0.043 | 2.9 | ug/L |
| Ni | 62 | 843.051 | 1.6 | 902.391 | -0.04962 | 0.044 | 88.0 | ug/L |
| Cu | 63 | 1474.145 | 4.0 | 876.388 | 0.07249 | 0.009 | 12.2 | ug/L |
| Cu | 65 | 346.677 | 4.5 | 254.340 | 0.02420 | 0.004 | 18.3 | ug/L |
| Zn | 66 | 2195.645 | 3.7 | 2747.481 | -0.18924 | 0.023 | 12.0 | ug/L |
| Zn | 67 | 463.351 | 3.5 | 502.020 | -0.05080 | 0.055 | 107.9 | ug/L |
| Zn | 68 | 1933.910 | 2.2 | 1975.921 | 0.01538 | 0.037 | 241.8 | ug/L |
| > Ge | 72 | 219538.110 | 1.4 | 227398.462 | | | | ug/L |
| As | 75 | 64038.127 | 1.7 | 127.002 | 23.28487 | 0.663 | 2.8 | ug/L |
| Se | 77 | 235.403 | 3.8 | 226.870 | 0.08025 | 0.058 | 72.7 | ug/L |
| Se | 78 | 15357.562 | 1.3 | 16063.843 | -0.23125 | 0.423 | 182.8 | mg/L |
| Se | 82 | 1092.138 | 1.6 | 661.626 | 1.60038 | 0.042 | 2.6 | ug/L |
| Kr | 83 | 1109.418 | 1.7 | 694.703 | | | | mg/L |
| Y | 89 | 419741.022 | 1.2 | 420425.593 | | | | ug/L |
| Mo | 95 | 18027.663 | 1.7 | 127.336 | 2.91020 | 0.025 | 0.9 | ug/L |
| Mo | 97 | 11794.459 | 0.9 | 61.668 | 3.12355 | 0.109 | 3.5 | ug/L |
| Mo | 98 | 29068.538 | 4.0 | 69.388 | 2.90403 | 0.105 | 3.6 | ug/L |
| Rh | 103 | 381247.626 | 1.5 | 381957.031 | | | | ug/L |
| Ag | 107 | 74.001 | 8.2 | 56.667 | 0.00112 | 0.000 | 32.3 | ug/L |
| Ag | 109 | 54.001 | 15.8 | 52.667 | 0.00006 | 0.001 | 1055.0 | ug/L |
| Cd | 111 | 234.575 | 10.2 | 249.856 | -0.00537 | 0.005 | 101.3 | ug/L |
| Cd | 114 | 90.785 | 7.0 | 64.386 | 0.00339 | 0.001 | 21.8 | ug/L |
| > In | 115 | 400429.675 | 2.6 | 396447.935 | | | | ug/L |
| Sb | 121 | 677.701 | 1.6 | 62.334 | 0.05924 | 0.002 | 4.2 | ug/L |
| Sb | 123 | 505.340 | 5.3 | 53.222 | 0.05758 | 0.004 | 6.7 | ug/L |
| Ba | 135 | 6706.431 | 0.7 | 56.334 | 2.52597 | 0.017 | 0.7 | ug/L |
| Ba | 137 | 11529.087 | 2.0 | 65.001 | 2.55872 | 0.077 | 3.0 | ug/L |
| > Tb | 159 | 474049.702 | 1.1 | 486746.910 | | | | ug/L |
| > Ho | 165 | 452769.345 | 1.7 | 457509.069 | | | | ug/L |
| Tl | 203 | 188.671 | 5.6 | 48.667 | 0.01699 | 0.002 | 9.6 | ug/L |
| Tl | 205 | 462.017 | 5.6 | 63.334 | 0.02119 | 0.001 | 4.7 | ug/L |
| Pb | 208 | 405.674 | 1.1 | 537.345 | -0.00475 | 0.000 | 7.7 | ug/L |

Sample ID: 948957 D.10

Report Date/Time: Monday, November 20, 2006 12:50:15

Page 1

708

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|-----------|
| | Pb | 206 | 109.335 | 7.6 | 135.336 | -0.00352 | 0.001 | 40.9 ug/L |
| | Pb | 207 | 105.002 | 4.4 | 124.336 | -0.00309 | 0.000 | 15.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 98.868 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 96.543 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 101.004 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 97.391 | | | |
| > [Ho | 165 | | 98.964 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950471 D.5

Sample Date/Time: Monday, November 20, 2006 12:53:12

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950471 D.5.035

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 62.334 | 8.8 | 51.334 | 0.00927 | 0.006 | 59.7 | ug/L |
| Al | 27 | 525672.945 | 0.7 | 4379.197 | 57.32328 | 1.506 | 2.6 | ug/L |
| > Sc | 45 | 424004.590 | 2.0 | 424656.486 | | | | ug/L |
| V | 51 | 7195.641 | 5.9 | 5557.188 | 0.09769 | 0.023 | 23.1 | ug/L |
| Cr | 52 | 39018.214 | 2.1 | 18419.857 | 1.43820 | 0.020 | 1.4 | ug/L |
| Cr | 53 | 3622.830 | 10.8 | 945.730 | 1.50292 | 0.248 | 16.5 | ug/L |
| Mn | 55 | 225279.961 | 2.2 | 692.369 | 11.96364 | 0.284 | 2.4 | ug/L |
| Co | 59 | 4674.358 | 1.4 | 265.007 | 0.26691 | 0.003 | 1.1 | ug/L |
| Ni | 60 | 15006.987 | 2.0 | 177.337 | 4.09157 | 0.096 | 2.3 | ug/L |
| Ni | 62 | 2368.360 | 2.7 | 902.391 | 2.76191 | 0.113 | 4.1 | ug/L |
| Cu | 63 | 3474.759 | 2.0 | 876.388 | 0.31279 | 0.009 | 3.0 | ug/L |
| Cu | 65 | 1768.205 | 1.8 | 254.340 | 0.37414 | 0.009 | 2.5 | ug/L |
| Zn | 66 | 3030.915 | 1.2 | 2747.481 | 0.18683 | 0.011 | 6.0 | ug/L |
| Zn | 67 | 624.030 | 1.3 | 502.020 | 0.37172 | 0.024 | 6.5 | ug/L |
| Zn | 68 | 2694.796 | 3.4 | 1975.921 | 0.48846 | 0.051 | 10.5 | ug/L |
| > Ge | 72 | 214364.592 | 0.4 | 227398.462 | | | | ug/L |
| As | 75 | 574.026 | 4.5 | 127.002 | 0.16945 | 0.009 | 5.4 | ug/L |
| Se | 77 | 243.804 | 1.6 | 226.870 | 0.14936 | 0.023 | 15.4 | ug/L |
| Se | 78 | 15100.872 | 1.7 | 16063.843 | -0.06675 | 0.414 | 619.9 | mg/L |
| Se | 82 | 1072.936 | 0.6 | 661.626 | 1.62398 | 0.036 | 2.2 | ug/L |
| Kr | 83 | 1072.746 | 2.3 | 694.703 | | | | mg/L |
| Y | 89 | 409833.347 | 2.9 | 420425.593 | | | | ug/L |
| Mo | 95 | 479.019 | 4.9 | 127.336 | 0.05833 | 0.003 | 5.7 | ug/L |
| Mo | 97 | 262.673 | 7.3 | 61.668 | 0.05450 | 0.004 | 7.1 | ug/L |
| Mo | 98 | 640.749 | 4.4 | 69.388 | 0.05826 | 0.002 | 3.3 | ug/L |
| Rh | 103 | 373433.692 | 1.3 | 381957.031 | | | | ug/L |
| Ag | 107 | 65.668 | 10.1 | 56.667 | 0.00065 | 0.001 | 79.6 | ug/L |
| Ag | 109 | 53.667 | 12.0 | 52.667 | 0.00011 | 0.001 | 504.4 | ug/L |
| Cd | 111 | 294.870 | 8.8 | 249.856 | 0.01429 | 0.010 | 67.4 | ug/L |
| Cd | 114 | 228.073 | 17.0 | 64.386 | 0.02194 | 0.005 | 21.1 | ug/L |
| > In | 115 | 393492.002 | 1.9 | 396447.935 | | | | ug/L |
| Sb | 121 | 151.336 | 4.4 | 62.334 | 0.00877 | 0.001 | 7.8 | ug/L |
| Sb | 123 | 128.059 | 7.9 | 53.222 | 0.00977 | 0.002 | 15.8 | ug/L |
| Ba | 135 | 8094.010 | 1.3 | 56.334 | 3.09930 | 0.030 | 1.0 | ug/L |
| Ba | 137 | 14261.003 | 1.6 | 65.001 | 3.21624 | 0.074 | 2.3 | ug/L |
| > Tb | 159 | 466979.190 | 0.7 | 486746.910 | | | | ug/L |
| > Ho | 165 | 446343.722 | 0.8 | 457509.069 | | | | ug/L |
| Tl | 203 | 81.001 | 12.5 | 48.667 | 0.00411 | 0.001 | 31.7 | ug/L |
| Tl | 205 | 164.337 | 3.1 | 63.334 | 0.00552 | 0.000 | 5.4 | ug/L |
| Pb | 208 | 3431.640 | 1.4 | 537.345 | 0.11127 | 0.003 | 2.6 | ug/L |

Sample ID: 950471 D.5

Report Date/Time: Monday, November 20, 2006 12:56:14

Page 1

711

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 885.723 | 0.9 | 135.336 | 0.10987 | 0.001 | 0.6 ug/L |
| | Pb | 207 | 764.709 | 4.3 | 124.336 | 0.11165 | 0.007 | 6.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 99.846 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 94.268 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 99.254 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 95.939 | | | |
| > [Ho | 165 | | 97.560 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950474 D.5

Sample Date/Time: Monday, November 20, 2006 12:59:11

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950474 D.5.036

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 50.001 | 8.0 | 51.334 | -0.00117 | 0.003 | 254.8 | ug/L |
| Al | 27 | 101663.222 | 15.5 | 4379.197 | 10.66332 | 1.709 | 16.0 | ug/L |
| > Sc | 45 | 425127.583 | 0.9 | 424656.486 | | | | ug/L |
| V | 51 | 5751.431 | 11.1 | 5557.188 | 0.01128 | 0.039 | 348.7 | ug/L |
| Cr | 52 | 28271.181 | 2.7 | 18419.857 | 0.68395 | 0.067 | 9.7 | ug/L |
| Cr | 53 | 2310.010 | 1.7 | 945.730 | 0.76189 | 0.030 | 4.0 | ug/L |
| Mn | 55 | 92102.196 | 1.8 | 692.369 | 4.82950 | 0.066 | 1.4 | ug/L |
| Co | 59 | 1159.426 | 2.8 | 265.007 | 0.05429 | 0.002 | 2.8 | ug/L |
| Ni | 60 | 5415.815 | 3.2 | 177.337 | 1.43505 | 0.063 | 4.4 | ug/L |
| Ni | 62 | 821.382 | 1.7 | 902.391 | -0.06568 | 0.027 | 41.1 | ug/L |
| Cu | 63 | 2574.424 | 5.7 | 876.388 | 0.20381 | 0.014 | 6.8 | ug/L |
| Cu | 65 | 1310.449 | 1.5 | 254.340 | 0.25940 | 0.003 | 1.2 | ug/L |
| Zn | 66 | 5552.572 | 2.5 | 2747.481 | 1.23584 | 0.048 | 3.9 | ug/L |
| Zn | 67 | 987.402 | 0.4 | 502.020 | 1.24722 | 0.025 | 2.0 | ug/L |
| Zn | 68 | 4650.011 | 2.1 | 1975.921 | 1.61419 | 0.085 | 5.3 | ug/L |
| > Ge | 72 | 216168.528 | 1.1 | 227398.462 | | | | ug/L |
| As | 75 | 337.677 | 3.8 | 127.002 | 0.08023 | 0.004 | 4.7 | ug/L |
| Se | 77 | 247.470 | 6.7 | 226.870 | 0.15797 | 0.095 | 60.1 | ug/L |
| Se | 78 | 15359.436 | 1.7 | 16063.843 | 0.14508 | 0.683 | 471.1 | mg/L |
| Se | 82 | 1106.740 | 2.5 | 661.626 | 1.71364 | 0.137 | 8.0 | ug/L |
| Kr | 83 | 1102.751 | 2.2 | 694.703 | | | | mg/L |
| Y | 89 | 411423.008 | 4.3 | 420425.593 | | | | ug/L |
| Mo | 95 | 621.363 | 0.9 | 127.336 | 0.08159 | 0.000 | 0.5 | ug/L |
| Mo | 97 | 413.014 | 3.1 | 61.668 | 0.09494 | 0.004 | 4.0 | ug/L |
| Mo | 98 | 899.962 | 5.8 | 69.388 | 0.08441 | 0.005 | 5.8 | ug/L |
| Rh | 103 | 374028.026 | 3.4 | 381957.031 | | | | ug/L |
| Ag | 107 | 63.668 | 7.1 | 56.667 | 0.00049 | 0.000 | 65.6 | ug/L |
| Ag | 109 | 51.667 | 9.9 | 52.667 | -0.00005 | 0.000 | 639.0 | ug/L |
| Cd | 111 | 264.032 | 4.3 | 249.856 | 0.00461 | 0.003 | 69.8 | ug/L |
| Cd | 114 | 105.488 | 10.3 | 64.386 | 0.00553 | 0.001 | 25.2 | ug/L |
| > In | 115 | 394622.558 | 0.5 | 396447.935 | | | | ug/L |
| Sb | 121 | 212.672 | 5.7 | 62.334 | 0.01472 | 0.001 | 7.6 | ug/L |
| Sb | 123 | 151.696 | 6.8 | 53.222 | 0.01277 | 0.001 | 10.4 | ug/L |
| Ba | 135 | 12905.783 | 1.6 | 56.334 | 4.87479 | 0.084 | 1.7 | ug/L |
| Ba | 137 | 22236.851 | 0.2 | 65.001 | 4.94191 | 0.007 | 0.1 | ug/L |
| > Tb | 159 | 474561.014 | 0.1 | 486746.910 | | | | ug/L |
| > Ho | 165 | 445348.201 | 0.8 | 457509.069 | | | | ug/L |
| Tl | 203 | 111.002 | 2.4 | 48.667 | 0.00781 | 0.000 | 3.9 | ug/L |
| Tl | 205 | 243.339 | 0.9 | 63.334 | 0.00981 | 0.000 | 2.0 | ug/L |
| Pb | 208 | 926.029 | 1.2 | 537.345 | 0.01546 | 0.001 | 3.3 | ug/L |

Sample ID: 950474 D.5

Report Date/Time: Monday, November 20, 2006 13:02:13

Page 1

714

| | | | | | | | | |
|--|----|-----|---------|------|---------|---------|-------|-----------|
| | Pb | 206 | 242.339 | 6.4 | 135.336 | 0.01616 | 0.002 | 14.2 ug/L |
| | Pb | 207 | 207.338 | 10.4 | 124.336 | 0.01501 | 0.004 | 25.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 100.111 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 95.062 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 99.540 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 97.496 | | | |
| > [Ho | 165 | | 97.342 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477 D.5

Sample Date/Time: Monday, November 20, 2006 13:05:10

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950477 D.5.037

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55.001 | 16.4 | 51.334 | 0.00223 | 0.007 | 317.8 | ug/L |
| Al | 27 | 9175.810 | 2.9 | 4379.197 | 0.50915 | 0.027 | 5.3 | ug/L |
| > Sc | 45 | 432078.248 | 0.6 | 424656.486 | | | | ug/L |
| V | 51 | 5696.784 | 3.3 | 5557.188 | 0.00245 | 0.010 | 393.4 | ug/L |
| Cr | 52 | 18157.612 | 1.7 | 18419.857 | -0.04000 | 0.017 | 42.4 | ug/L |
| Cr | 53 | 1068.079 | 3.3 | 945.730 | 0.05826 | 0.023 | 39.4 | ug/L |
| Mn | 55 | 1101203.791 | 2.2 | 692.369 | 58.66897 | 2.619 | 4.5 | ug/L |
| Co | 59 | 2284.669 | 0.4 | 265.007 | 0.12285 | 0.004 | 3.2 | ug/L |
| Ni | 60 | 6879.241 | 1.4 | 177.337 | 1.85135 | 0.029 | 1.6 | ug/L |
| Ni | 62 | 707.037 | 3.3 | 902.391 | -0.25989 | 0.074 | 28.3 | ug/L |
| Cu | 63 | 1553.494 | 0.9 | 876.388 | 0.08599 | 0.004 | 4.5 | ug/L |
| Cu | 65 | 894.057 | 6.2 | 254.340 | 0.16050 | 0.019 | 11.6 | ug/L |
| Zn | 66 | 5766.052 | 1.3 | 2747.481 | 1.34709 | 0.035 | 2.6 | ug/L |
| Zn | 67 | 1178.762 | 2.3 | 502.020 | 1.73980 | 0.017 | 1.0 | ug/L |
| Zn | 68 | 5091.606 | 1.5 | 1975.921 | 1.89814 | 0.115 | 6.1 | ug/L |
| > Ge | 72 | 214318.522 | 2.5 | 227398.462 | | | | ug/L |
| As | 75 | 1447.807 | 2.4 | 127.002 | 0.49593 | 0.026 | 5.3 | ug/L |
| Se | 77 | 248.737 | 4.3 | 226.870 | 0.17499 | 0.070 | 39.9 | ug/L |
| Se | 78 | 15371.882 | 1.7 | 16063.843 | 0.38028 | 0.817 | 214.8 | mg/L |
| Se | 82 | 1118.008 | 1.5 | 661.626 | 1.78845 | 0.051 | 2.8 | ug/L |
| Kr | 83 | 1110.752 | 2.6 | 694.703 | | | | mg/L |
| Y | 89 | 413660.482 | 0.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 1979.588 | 2.7 | 127.336 | 0.30620 | 0.009 | 3.1 | ug/L |
| Mo | 97 | 1213.768 | 8.5 | 61.668 | 0.31171 | 0.028 | 9.1 | ug/L |
| Mo | 98 | 2942.680 | 2.9 | 69.388 | 0.29249 | 0.009 | 3.2 | ug/L |
| Rh | 103 | 369465.823 | 0.6 | 381957.031 | | | | ug/L |
| Ag | 107 | 57.667 | 8.2 | 56.667 | 0.00009 | 0.000 | 341.0 | ug/L |
| Ag | 109 | 46.001 | 14.3 | 52.667 | -0.00045 | 0.000 | 104.4 | ug/L |
| Cd | 111 | 305.700 | 3.3 | 249.856 | 0.01733 | 0.003 | 18.6 | ug/L |
| Cd | 114 | 126.243 | 23.2 | 64.386 | 0.00833 | 0.004 | 46.5 | ug/L |
| > In | 115 | 393959.930 | 0.3 | 396447.935 | | | | ug/L |
| Sb | 121 | 172.003 | 3.5 | 62.334 | 0.01077 | 0.001 | 5.2 | ug/L |
| Sb | 123 | 145.642 | 3.0 | 53.222 | 0.01202 | 0.001 | 5.1 | ug/L |
| Ba | 135 | 32556.465 | 0.6 | 56.334 | 12.59504 | 0.156 | 1.2 | ug/L |
| Ba | 137 | 57285.799 | 0.5 | 65.001 | 13.02852 | 0.143 | 1.1 | ug/L |
| > Tb | 159 | 464585.667 | 1.1 | 486746.910 | | | | ug/L |
| > Ho | 165 | 443211.380 | 2.0 | 457509.069 | | | | ug/L |
| Tl | 203 | 133.002 | 7.6 | 48.667 | 0.01059 | 0.001 | 9.9 | ug/L |
| Tl | 205 | 274.341 | 6.3 | 63.334 | 0.01154 | 0.001 | 5.5 | ug/L |
| Pb | 208 | 2209.801 | 0.3 | 537.345 | 0.06512 | 0.001 | 2.2 | ug/L |

Sample ID: 950477 D.5

Report Date/Time: Monday, November 20, 2006 13:08:12

Page 1

717

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 577.359 | 0.9 | 135.336 | 0.06554 | 0.002 | 3.1 ug/L |
| | Pb | 207 | 496.353 | 1.3 | 124.336 | 0.06570 | 0.003 | 4.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 101.748 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 94.248 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 99.372 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 95.447 | | | |
| > Ho | 165 | | 96.875 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477D D.5

Sample Date/Time: Monday, November 20, 2006 13:11:09

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950477D D.5.038

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 56.001 | 14.6 | 51.334 | 0.00443 | 0.007 | 163.3 | ug/L |
| Al | 27 | 9163.461 | 1.2 | 4379.197 | 0.53647 | 0.014 | 2.7 | ug/L |
| > Sc | 45 | 419928.447 | 1.0 | 424656.486 | | | | ug/L |
| V | 51 | 5544.401 | 1.3 | 5557.188 | 0.00297 | 0.006 | 209.3 | ug/L |
| Cr | 52 | 17555.983 | 0.9 | 18419.857 | -0.04633 | 0.012 | 26.2 | ug/L |
| Cr | 53 | 1115.753 | 2.2 | 945.730 | 0.10225 | 0.019 | 18.6 | ug/L |
| Mn | 55 | 1041130.841 | 1.9 | 692.369 | 54.83225 | 1.939 | 3.5 | ug/L |
| Co | 59 | 2303.675 | 4.1 | 265.007 | 0.12236 | 0.004 | 3.1 | ug/L |
| Ni | 60 | 6940.960 | 2.5 | 177.337 | 1.84682 | 0.042 | 2.2 | ug/L |
| Ni | 62 | 687.369 | 5.2 | 902.391 | -0.31004 | 0.080 | 25.9 | ug/L |
| Cu | 63 | 1578.499 | 1.8 | 876.388 | 0.08687 | 0.005 | 6.2 | ug/L |
| Cu | 65 | 946.397 | 3.9 | 254.340 | 0.17045 | 0.008 | 4.9 | ug/L |
| Zn | 66 | 3679.849 | 2.5 | 2747.481 | 0.44500 | 0.033 | 7.5 | ug/L |
| Zn | 67 | 904.725 | 6.1 | 502.020 | 1.04079 | 0.165 | 15.8 | ug/L |
| Zn | 68 | 3489.099 | 0.9 | 1975.921 | 0.93295 | 0.039 | 4.2 | ug/L |
| > Ge | 72 | 216720.167 | 1.6 | 227398.462 | | | | ug/L |
| As | 75 | 1498.150 | 3.9 | 127.002 | 0.50842 | 0.031 | 6.0 | ug/L |
| Se | 77 | 251.270 | 2.2 | 226.870 | 0.17301 | 0.026 | 14.9 | ug/L |
| Se | 78 | 15432.251 | 0.9 | 16063.843 | 0.19478 | 0.203 | 104.4 | mg/L |
| Se | 82 | 1106.473 | 0.9 | 661.626 | 1.70197 | 0.030 | 1.7 | ug/L |
| Kr | 83 | 1058.411 | 3.0 | 694.703 | | | | mg/L |
| Y | 89 | 416560.620 | 1.8 | 420425.593 | | | | ug/L |
| Mo | 95 | 1958.917 | 4.5 | 127.336 | 0.29585 | 0.018 | 6.2 | ug/L |
| Mo | 97 | 1122.087 | 2.4 | 61.668 | 0.28037 | 0.012 | 4.3 | ug/L |
| Mo | 98 | 2881.322 | 4.3 | 69.388 | 0.27982 | 0.012 | 4.3 | ug/L |
| Rh | 103 | 360767.165 | 1.4 | 381957.031 | | | | ug/L |
| Ag | 107 | 63.668 | 6.5 | 56.667 | 0.00041 | 0.000 | 83.0 | ug/L |
| Ag | 109 | 52.667 | 6.1 | 52.667 | -0.00006 | 0.000 | 380.3 | ug/L |
| Cd | 111 | 288.691 | 9.9 | 249.856 | 0.01025 | 0.008 | 76.1 | ug/L |
| Cd | 114 | 132.367 | 6.6 | 64.386 | 0.00877 | 0.001 | 15.4 | ug/L |
| > In | 115 | 402788.332 | 1.7 | 396447.935 | | | | ug/L |
| Sb | 121 | 179.004 | 11.5 | 62.334 | 0.01106 | 0.002 | 15.3 | ug/L |
| Sb | 123 | 141.071 | 6.3 | 53.222 | 0.01104 | 0.001 | 12.7 | ug/L |
| Ba | 135 | 33105.962 | 0.5 | 56.334 | 12.86114 | 0.180 | 1.4 | ug/L |
| Ba | 137 | 57799.354 | 1.4 | 65.001 | 13.20128 | 0.330 | 2.5 | ug/L |
| > Tb | 159 | 462704.637 | 1.7 | 486746.910 | | | | ug/L |
| > Ho | 165 | 446789.364 | 1.2 | 457509.069 | | | | ug/L |
| Tl | 203 | 135.669 | 4.9 | 48.667 | 0.01079 | 0.001 | 6.4 | ug/L |
| Tl | 205 | 275.674 | 6.7 | 63.334 | 0.01150 | 0.001 | 7.8 | ug/L |
| Pb | 208 | 2193.467 | 3.0 | 537.345 | 0.06382 | 0.003 | 5.4 | ug/L |

Sample ID: 950477D D.5

Report Date/Time: Monday, November 20, 2006 13:14:10

Page 1

720

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 570.025 | 1.8 | 135.336 | 0.06379 | 0.003 | 4.0 ug/L |
| | Pb | 207 | 486.352 | 3.0 | 124.336 | 0.06327 | 0.004 | 5.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 98.887 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 95.304 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 101.599 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 95.061 | | | |
| > [Ho | 165 | | 97.657 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 20, 2006 13:17:07

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 6.039

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 60074.695 | 0.5 | 51.334 | 52.33774 | 1.403 | 2.7 | ug/L |
| Al | 27 | 489053.394 | 2.4 | 4379.197 | 55.97737 | 0.408 | 0.7 | ug/L |
| > Sc | 45 | 403738.979 | 2.4 | 424656.486 | | | | ug/L |
| V | 51 | 835159.603 | 1.8 | 5557.188 | 51.73078 | 1.018 | 2.0 | ug/L |
| Cr | 52 | 712738.473 | 3.4 | 18419.857 | 50.90048 | 0.734 | 1.4 | ug/L |
| Cr | 53 | 84372.857 | 1.2 | 945.730 | 49.13990 | 1.696 | 3.5 | ug/L |
| Mn | 55 | 971027.107 | 1.6 | 692.369 | 52.64104 | 0.883 | 1.7 | ug/L |
| Co | 59 | 826083.261 | 0.8 | 265.007 | 50.74916 | 0.889 | 1.8 | ug/L |
| Ni | 60 | 188259.840 | 1.3 | 177.337 | 52.82369 | 0.949 | 1.8 | ug/L |
| Ni | 62 | 27151.780 | 2.2 | 902.391 | 48.77814 | 0.844 | 1.7 | ug/L |
| Cu | 63 | 437404.990 | 0.6 | 876.388 | 52.51377 | 0.266 | 0.5 | ug/L |
| Cu | 65 | 212629.379 | 2.1 | 254.340 | 52.95526 | 1.243 | 2.3 | ug/L |
| Zn | 66 | 115533.598 | 1.3 | 2747.481 | 48.77335 | 0.394 | 0.8 | ug/L |
| Zn | 67 | 20545.510 | 2.3 | 502.020 | 50.41063 | 0.723 | 1.4 | ug/L |
| Zn | 68 | 87483.341 | 3.3 | 1975.921 | 51.21143 | 1.386 | 2.7 | ug/L |
| > Ge | 72 | 210464.489 | 1.0 | 227398.462 | | | | ug/L |
| As | 75 | 136273.202 | 3.7 | 127.002 | 51.72483 | 1.694 | 3.3 | ug/L |
| Se | 77 | 10351.959 | 0.6 | 226.870 | 51.52032 | 0.422 | 0.8 | ug/L |
| Se | 78 | 48057.483 | 2.7 | 16063.843 | 53.66910 | 1.959 | 3.7 | mg/L |
| Se | 82 | 15216.016 | 2.0 | 661.626 | 53.76793 | 1.001 | 1.9 | ug/L |
| Kr | 83 | 1075.413 | 1.9 | 694.703 | | | | mg/L |
| Y | 89 | 405675.845 | 1.7 | 420425.593 | | | | ug/L |
| Mo | 95 | 294720.236 | 1.4 | 127.336 | 49.01495 | 0.692 | 1.4 | ug/L |
| Mo | 97 | 185151.293 | 1.2 | 61.668 | 50.40710 | 0.927 | 1.8 | ug/L |
| Mo | 98 | 461728.120 | 2.2 | 69.388 | 47.31869 | 1.408 | 3.0 | ug/L |
| Rh | 103 | 360673.742 | 3.4 | 381957.031 | | | | ug/L |
| Ag | 107 | 734889.489 | 4.0 | 56.667 | 50.22181 | 2.325 | 4.6 | ug/L |
| Ag | 109 | 681790.674 | 0.7 | 52.667 | 48.50041 | 0.427 | 0.9 | ug/L |
| Cd | 111 | 168993.781 | 2.3 | 249.856 | 51.28363 | 0.597 | 1.2 | ug/L |
| Cd | 114 | 369212.152 | 2.8 | 64.386 | 49.74226 | 1.479 | 3.0 | ug/L |
| > In | 115 | 391268.365 | 1.3 | 396447.935 | | | | ug/L |
| Sb | 121 | 485867.080 | 0.5 | 62.334 | 47.88346 | 0.809 | 1.7 | ug/L |
| Sb | 123 | 378024.099 | 1.2 | 53.222 | 49.29832 | 0.538 | 1.1 | ug/L |
| Ba | 135 | 130231.457 | 2.6 | 56.334 | 51.29478 | 1.139 | 2.2 | ug/L |
| Ba | 137 | 226648.130 | 0.6 | 65.001 | 52.47156 | 1.345 | 2.6 | ug/L |
| > Tb | 159 | 456941.638 | 2.7 | 486746.910 | | | | ug/L |
| > Ho | 165 | 435464.713 | 2.2 | 457509.069 | | | | ug/L |
| Tl | 203 | 422557.493 | 0.7 | 48.667 | 53.08786 | 1.507 | 2.8 | ug/L |
| Tl | 205 | 977935.621 | 1.6 | 63.334 | 53.97043 | 0.375 | 0.7 | ug/L |
| Pb | 208 | 1326741.792 | 0.7 | 537.345 | 52.02796 | 0.793 | 1.5 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Monday, November 20, 2006 13:20:10

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 343709.746 | 0.4 | 135.336 | 51.35252 | 0.976 | 1.9 ug/L |
| | Pb | 207 | 289889.985 | 2.2 | 124.336 | 51.53679 | 1.453 | 2.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 104.675 | | | | |
| Al | 27 | 111.955 | | | | |
| > Sc | 45 | | 95.074 | | | |
| V | 51 | 103.462 | | | | |
| Cr | 52 | 101.801 | | | | |
| Cr | 53 | 98.280 | | | | |
| Mn | 55 | 105.282 | | | | |
| Co | 59 | 101.498 | | | | |
| Ni | 60 | 105.647 | | | | |
| Ni | 62 | 97.556 | | | | |
| Cu | 63 | 105.028 | | | | |
| Cu | 65 | 105.911 | | | | |
| Zn | 66 | 97.547 | | | | |
| Zn | 67 | 100.821 | | | | |
| Zn | 68 | 102.423 | | | | |
| > Ge | 72 | | 92.553 | | | |
| As | 75 | 103.450 | | | | |
| Se | 77 | 103.041 | | | | |
| Se | 78 | 107.338 | | | | |
| Se | 82 | 107.536 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 98.030 | | | | |
| Mo | 97 | 100.814 | | | | |
| Mo | 98 | 94.637 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 100.444 | | | | |
| Ag | 109 | 97.001 | | | | |
| Cd | 111 | 102.567 | | | | |
| Cd | 114 | 99.485 | | | | |
| > In | 115 | | 98.694 | | | |
| Sb | 121 | 95.767 | | | | |
| Sb | 123 | 98.597 | | | | |
| Ba | 135 | 102.590 | | | | |
| Ba | 137 | 104.943 | | | | |
| > Tb | 159 | | 93.877 | | | |
| > Ho | 165 | | 95.182 | | | |
| Tl | 203 | 106.176 | | | | |
| Tl | 205 | 107.941 | | | | |
| Pb | 208 | 104.056 | | | | |
| Pb | 206 | 102.705 | | | | |
| Pb | 207 | 103.074 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 20, 2006 13:23:05

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 7.040

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54.667 | 6.4 | 51.334 | 0.00513 | 0.003 | 50.6 | ug/L |
| Al | 27 | 3389.390 | 0.5 | 4379.197 | -0.08901 | 0.005 | 5.8 | ug/L |
| > Sc | 45 | 403420.013 | 1.5 | 424656.486 | | | | ug/L |
| V | 51 | 4961.191 | 3.5 | 5557.188 | -0.01975 | 0.014 | 68.8 | ug/L |
| Cr | 52 | 16586.662 | 2.4 | 18419.857 | -0.06658 | 0.038 | 56.9 | ug/L |
| Cr | 53 | 824.716 | 5.0 | 945.730 | -0.04358 | 0.017 | 40.1 | ug/L |
| Mn | 55 | 705.370 | 1.1 | 692.369 | 0.00313 | 0.001 | 17.0 | ug/L |
| Co | 59 | 170.337 | 2.8 | 265.007 | -0.00470 | 0.000 | 9.0 | ug/L |
| Ni | 60 | 138.003 | 7.0 | 177.337 | -0.00774 | 0.002 | 27.7 | ug/L |
| Ni | 62 | 206.671 | 4.3 | 902.391 | -1.16886 | 0.013 | 1.1 | ug/L |
| Cu | 63 | 356.678 | 6.0 | 876.388 | -0.05510 | 0.002 | 3.5 | ug/L |
| Cu | 65 | 222.339 | 3.4 | 254.340 | -0.00379 | 0.002 | 55.8 | ug/L |
| Zn | 66 | 2255.661 | 0.6 | 2747.481 | -0.13347 | 0.015 | 11.4 | ug/L |
| Zn | 67 | 435.016 | 2.2 | 502.020 | -0.08504 | 0.026 | 30.7 | ug/L |
| Zn | 68 | 1613.172 | 3.8 | 1975.921 | -0.13812 | 0.045 | 32.9 | ug/L |
| > Ge | 72 | 212567.124 | 1.5 | 227398.462 | | | | ug/L |
| As | 75 | 136.336 | 11.8 | 127.002 | 0.00669 | 0.007 | 100.9 | ug/L |
| Se | 77 | 219.470 | 4.1 | 226.870 | 0.03783 | 0.062 | 165.1 | ug/L |
| Se | 78 | 14470.574 | 0.3 | 16063.843 | -0.86913 | 0.422 | 48.6 | mg/L |
| Se | 82 | 1057.200 | 0.2 | 661.626 | 1.59989 | 0.056 | 3.5 | ug/L |
| Kr | 83 | 1056.411 | 2.3 | 694.703 | | | | mg/L |
| Y | 89 | 408028.511 | 2.5 | 420425.593 | | | | ug/L |
| Mo | 95 | 495.020 | 14.9 | 127.336 | 0.06298 | 0.012 | 18.9 | ug/L |
| Mo | 97 | 281.341 | 23.7 | 61.668 | 0.06139 | 0.018 | 28.9 | ug/L |
| Mo | 98 | 724.872 | 24.6 | 69.388 | 0.06856 | 0.018 | 26.0 | ug/L |
| Rh | 103 | 362027.125 | 2.0 | 381957.031 | | | | ug/L |
| Ag | 107 | 128.669 | 4.3 | 56.667 | 0.00514 | 0.000 | 5.1 | ug/L |
| Ag | 109 | 111.335 | 14.9 | 52.667 | 0.00437 | 0.001 | 25.8 | ug/L |
| Cd | 111 | 247.297 | 7.2 | 249.856 | 0.00162 | 0.004 | 276.1 | ug/L |
| Cd | 114 | 57.482 | 5.4 | 64.386 | -0.00067 | 0.000 | 67.0 | ug/L |
| > In | 115 | 383876.489 | 1.5 | 396447.935 | | | | ug/L |
| Sb | 121 | 912.393 | 12.3 | 62.334 | 0.08551 | 0.010 | 12.0 | ug/L |
| Sb | 123 | 653.022 | 9.2 | 53.222 | 0.07991 | 0.007 | 8.9 | ug/L |
| Ba | 135 | 49.001 | 17.7 | 56.334 | -0.00152 | 0.003 | 224.5 | ug/L |
| Ba | 137 | 62.334 | 15.8 | 65.001 | 0.00030 | 0.002 | 737.6 | ug/L |
| > Tb | 159 | 456818.833 | 0.7 | 486746.910 | | | | ug/L |
| > Ho | 165 | 436757.991 | 0.6 | 457509.069 | | | | ug/L |
| Tl | 203 | 63.334 | 4.8 | 48.667 | 0.00211 | 0.000 | 16.1 | ug/L |
| Tl | 205 | 114.335 | 12.3 | 63.334 | 0.00296 | 0.001 | 25.1 | ug/L |
| Pb | 208 | 377.674 | 2.7 | 537.345 | -0.00529 | 0.000 | 7.5 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Monday, November 20, 2006 13:26:06

Page 1

726

| | | | | | | | | |
|--|----|-----|--------|------|---------|----------|-------|-----------|
| | Pb | 206 | 93.335 | 10.6 | 135.336 | -0.00534 | 0.001 | 27.7 ug/L |
| | Pb | 207 | 98.668 | 11.7 | 124.336 | -0.00354 | 0.002 | 60.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 94.999 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 93.478 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 96.829 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 93.851 | | | |
| > Ho | 165 | | 95.464 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477S D.5

Sample Date/Time: Monday, November 20, 2006 13:29:02

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950477S D.5.041

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 4670.022 | 1.3 | 51.334 | 3.85482 | 0.196 | 5.1 | ug/L |
| Al | 27 | 48789.921 | 1.6 | 4379.197 | 4.90888 | 0.123 | 2.5 | ug/L |
| > Sc | 45 | 422169.840 | 3.7 | 424656.486 | | | | ug/L |
| V | 51 | 74153.897 | 0.8 | 5557.188 | 4.09420 | 0.154 | 3.8 | ug/L |
| Cr | 52 | 74796.595 | 0.7 | 18419.857 | 3.95974 | 0.171 | 4.3 | ug/L |
| Cr | 53 | 7726.324 | 0.9 | 945.730 | 3.82353 | 0.204 | 5.3 | ug/L |
| Mn | 55 | 1147605.620 | 0.8 | 692.369 | 62.97603 | 0.400 | 0.6 | ug/L |
| Co | 59 | 68703.453 | 1.7 | 265.007 | 4.25749 | 0.026 | 0.6 | ug/L |
| Ni | 60 | 21519.635 | 1.4 | 177.337 | 6.07029 | 0.062 | 1.0 | ug/L |
| Ni | 62 | 2832.510 | 2.5 | 902.391 | 3.76548 | 0.081 | 2.1 | ug/L |
| Cu | 63 | 35126.568 | 1.2 | 876.388 | 4.17916 | 0.080 | 1.9 | ug/L |
| Cu | 65 | 17423.707 | 1.8 | 254.340 | 4.33831 | 0.092 | 2.1 | ug/L |
| Zn | 66 | 11218.326 | 1.3 | 2747.481 | 3.80436 | 0.108 | 2.8 | ug/L |
| Zn | 67 | 2240.990 | 2.3 | 502.020 | 4.52809 | 0.120 | 2.7 | ug/L |
| Zn | 68 | 9243.552 | 2.4 | 1975.921 | 4.50181 | 0.179 | 4.0 | ug/L |
| > Ge | 72 | 207941.760 | 1.3 | 227398.462 | | | | ug/L |
| As | 75 | 12242.776 | 0.5 | 127.002 | 4.66378 | 0.084 | 1.8 | ug/L |
| Se | 77 | 1016.795 | 1.3 | 226.870 | 4.16227 | 0.139 | 3.3 | ug/L |
| Se | 78 | 17559.135 | 2.7 | 16063.843 | 4.70615 | 1.128 | 24.0 | mg/L |
| Se | 82 | 2179.952 | 1.7 | 661.626 | 5.86929 | 0.127 | 2.2 | ug/L |
| Kr | 83 | 1103.084 | 3.0 | 694.703 | | | | mg/L |
| Y | 89 | 403847.926 | 1.2 | 420425.593 | | | | ug/L |
| Mo | 95 | 25464.789 | 2.8 | 127.336 | 4.24260 | 0.132 | 3.1 | ug/L |
| Mo | 97 | 16523.869 | 2.0 | 61.668 | 4.51187 | 0.129 | 2.9 | ug/L |
| Mo | 98 | 41450.125 | 2.9 | 69.388 | 4.26778 | 0.145 | 3.4 | ug/L |
| Rh | 103 | 358232.394 | 3.1 | 381957.031 | | | | ug/L |
| Ag | 107 | 61448.762 | 2.5 | 56.667 | 4.22171 | 0.129 | 3.0 | ug/L |
| Ag | 109 | 55583.981 | 0.4 | 52.667 | 3.97549 | 0.051 | 1.3 | ug/L |
| Cd | 111 | 13684.632 | 0.3 | 249.856 | 4.11053 | 0.040 | 1.0 | ug/L |
| Cd | 114 | 30007.324 | 1.6 | 64.386 | 4.06043 | 0.102 | 2.5 | ug/L |
| > In | 115 | 388833.939 | 0.9 | 396447.935 | | | | ug/L |
| Sb | 121 | 42402.375 | 1.4 | 62.334 | 4.19916 | 0.073 | 1.7 | ug/L |
| Sb | 123 | 31286.377 | 0.6 | 53.222 | 4.09921 | 0.013 | 0.3 | ug/L |
| Ba | 135 | 42625.851 | 1.6 | 56.334 | 16.44750 | 0.270 | 1.6 | ug/L |
| Ba | 137 | 74193.253 | 1.2 | 65.001 | 16.82707 | 0.159 | 0.9 | ug/L |
| > Tb | 159 | 465947.424 | 0.3 | 486746.910 | | | | ug/L |
| > Ho | 165 | 440379.201 | 0.8 | 457509.069 | | | | ug/L |
| Tl | 203 | 34624.464 | 0.8 | 48.667 | 4.29449 | 0.043 | 1.0 | ug/L |
| Tl | 205 | 82755.442 | 1.7 | 63.334 | 4.51248 | 0.040 | 0.9 | ug/L |
| Pb | 208 | 111299.515 | 0.8 | 537.345 | 4.29654 | 0.019 | 0.4 | ug/L |

Sample ID: 950477S D.5

Report Date/Time: Monday, November 20, 2006 13:32:04

Page 1

729

| | | | | | | | | |
|--|----|-----|-----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 28282.194 | 0.2 | 135.336 | 4.15973 | 0.035 | 0.9 ug/L |
| | Pb | 207 | 24236.771 | 0.8 | 124.336 | 4.24063 | 0.065 | 1.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 99.414 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 91.444 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 98.079 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 95.727 | | | |
| > [Ho | 165 | | 96.256 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477A D.5

Sample Date/Time: Monday, November 20, 2006 13:35:01

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950477A D.5.042

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 23094.193 | 1.8 | 51.334 | 19.01294 | 0.490 | 2.6 | ug/L |
| Al | 27 | 192566.998 | 2.0 | 4379.197 | 20.56633 | 0.638 | 3.1 | ug/L |
| > Sc | 45 | 426542.951 | 1.5 | 424656.486 | | | | ug/L |
| V | 51 | 342748.457 | 1.1 | 5557.188 | 19.89493 | 0.525 | 2.6 | ug/L |
| Cr | 52 | 299875.475 | 1.7 | 18419.857 | 19.50797 | 0.639 | 3.3 | ug/L |
| Cr | 53 | 34929.074 | 1.4 | 945.730 | 18.92762 | 0.466 | 2.5 | ug/L |
| Mn | 55 | 1465331.373 | 0.9 | 692.369 | 77.95531 | 1.742 | 2.2 | ug/L |
| Co | 59 | 337599.667 | 1.3 | 265.007 | 20.33398 | 0.070 | 0.3 | ug/L |
| Ni | 60 | 78344.368 | 1.3 | 177.337 | 21.54041 | 0.588 | 2.7 | ug/L |
| Ni | 62 | 11623.553 | 2.1 | 902.391 | 19.58557 | 0.157 | 0.8 | ug/L |
| Cu | 63 | 171694.163 | 0.9 | 876.388 | 20.16109 | 0.118 | 0.6 | ug/L |
| Cu | 65 | 80488.005 | 1.2 | 254.340 | 19.62686 | 0.236 | 1.2 | ug/L |
| Zn | 66 | 50534.266 | 0.5 | 2747.481 | 20.30255 | 0.222 | 1.1 | ug/L |
| Zn | 67 | 8879.486 | 2.8 | 502.020 | 20.70376 | 0.625 | 3.0 | ug/L |
| Zn | 68 | 37475.455 | 1.0 | 1975.921 | 20.88914 | 0.121 | 0.6 | ug/L |
| > Ge | 72 | 214549.944 | 1.4 | 227398.462 | | | | ug/L |
| As | 75 | 54301.578 | 1.5 | 127.002 | 20.19383 | 0.263 | 1.3 | ug/L |
| Se | 77 | 4095.273 | 1.1 | 226.870 | 19.34211 | 0.313 | 1.6 | ug/L |
| Se | 78 | 27108.160 | 1.6 | 16063.843 | 18.96811 | 1.145 | 6.0 | mg/L |
| Se | 82 | 6439.554 | 0.2 | 661.626 | 21.00594 | 0.296 | 1.4 | ug/L |
| Kr | 83 | 1091.416 | 1.7 | 694.703 | | | | mg/L |
| Y | 89 | 409558.191 | 1.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 120504.079 | 1.9 | 127.336 | 20.20498 | 0.469 | 2.3 | ug/L |
| Mo | 97 | 75498.979 | 2.1 | 61.668 | 20.72586 | 0.507 | 2.9 | ug/L |
| Mo | 98 | 201658.603 | 2.0 | 69.388 | 20.83917 | 0.353 | 1.7 | ug/L |
| Rh | 103 | 350071.357 | 0.7 | 381957.031 | | | | ug/L |
| Ag | 107 | 288367.241 | 1.7 | 56.667 | 19.87182 | 0.225 | 1.1 | ug/L |
| Ag | 109 | 277808.208 | 2.7 | 52.667 | 19.93157 | 0.471 | 2.4 | ug/L |
| Cd | 111 | 66034.336 | 0.6 | 249.856 | 20.17256 | 0.291 | 1.4 | ug/L |
| Cd | 114 | 149636.873 | 1.3 | 64.386 | 20.33056 | 0.317 | 1.6 | ug/L |
| > In | 115 | 387871.686 | 0.9 | 396447.935 | | | | ug/L |
| Sb | 121 | 205434.822 | 0.7 | 62.334 | 20.41907 | 0.328 | 1.6 | ug/L |
| Sb | 123 | 150357.331 | 0.9 | 53.222 | 19.77654 | 0.315 | 1.6 | ug/L |
| Ba | 135 | 85326.197 | 1.6 | 56.334 | 33.61413 | 1.094 | 3.3 | ug/L |
| Ba | 137 | 145969.576 | 2.4 | 65.001 | 33.78954 | 1.093 | 3.2 | ug/L |
| > Tb | 159 | 456836.940 | 1.7 | 486746.910 | | | | ug/L |
| > Ho | 165 | 447025.136 | 0.3 | 457509.069 | | | | ug/L |
| Tl | 203 | 168345.443 | 0.6 | 48.667 | 20.59087 | 0.051 | 0.2 | ug/L |
| Tl | 205 | 397939.845 | 0.5 | 63.334 | 21.39001 | 0.181 | 0.8 | ug/L |
| Pb | 208 | 535691.126 | 1.2 | 537.345 | 20.44717 | 0.246 | 1.2 | ug/L |

Sample ID: 950477A D.5

Report Date/Time: Monday, November 20, 2006 13:38:02

Page 1

732

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 137063.715 | 0.6 | 135.336 | 19.93135 | 0.100 | 0.5 ug/L |
| | Pb | 207 | 113243.824 | 1.5 | 124.336 | 19.59339 | 0.254 | 1.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 100.444 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 94.350 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 97.837 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 93.855 | | | |
| > [Ho | 165 | | 97.708 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950477L D.5

Sample Date/Time: Monday, November 20, 2006 13:40:59

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990143

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\950477L D.5.043

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 53.001 | 16.8 | 51.334 | 0.00323 | 0.008 | 244.5 | ug/L |
| Al | 27 | 4242.789 | 2.9 | 4379.197 | 0.00448 | 0.018 | 390.9 | ug/L |
| > Sc | 45 | 407704.694 | 0.9 | 424656.486 | | | | ug/L |
| V | 51 | 4776.399 | 2.6 | 5557.188 | -0.03446 | 0.009 | 27.1 | ug/L |
| Cr | 52 | 15831.518 | 1.7 | 18419.857 | -0.13421 | 0.029 | 21.4 | ug/L |
| Cr | 53 | 853.719 | 2.4 | 945.730 | -0.03157 | 0.014 | 43.2 | ug/L |
| Mn | 55 | 216593.851 | 0.5 | 692.369 | 11.72436 | 0.295 | 2.5 | ug/L |
| Co | 59 | 555.691 | 2.5 | 265.007 | 0.01909 | 0.000 | 1.5 | ug/L |
| Ni | 60 | 1374.127 | 3.6 | 177.337 | 0.33994 | 0.009 | 2.8 | ug/L |
| Ni | 62 | 279.674 | 12.6 | 902.391 | -1.03019 | 0.055 | 5.3 | ug/L |
| Cu | 63 | 516.355 | 5.0 | 876.388 | -0.03539 | 0.004 | 10.3 | ug/L |
| Cu | 65 | 373.679 | 1.3 | 254.340 | 0.03454 | 0.002 | 4.9 | ug/L |
| Zn | 66 | 1612.172 | 3.6 | 2747.481 | -0.40091 | 0.038 | 9.5 | ug/L |
| Zn | 67 | 354.678 | 3.4 | 502.020 | -0.27537 | 0.035 | 12.6 | ug/L |
| Zn | 68 | 1329.453 | 3.9 | 1975.921 | -0.29765 | 0.044 | 14.6 | ug/L |
| > Ge | 72 | 210359.452 | 2.1 | 227398.462 | | | | ug/L |
| As | 75 | 362.345 | 13.5 | 127.002 | 0.09309 | 0.019 | 19.9 | ug/L |
| Se | 77 | 223.203 | 4.4 | 226.870 | 0.06874 | 0.072 | 105.4 | ug/L |
| Se | 78 | 14425.628 | 1.7 | 16063.843 | -0.69824 | 0.497 | 71.2 | mg/L |
| Se | 82 | 1059.201 | 0.3 | 661.626 | 1.64835 | 0.088 | 5.3 | ug/L |
| Kr | 83 | 1074.080 | 1.7 | 694.703 | | | | mg/L |
| Y | 89 | 390475.001 | 1.9 | 420425.593 | | | | ug/L |
| Mo | 95 | 533.356 | 1.4 | 127.336 | 0.06792 | 0.001 | 2.1 | ug/L |
| Mo | 97 | 285.008 | 9.8 | 61.668 | 0.06112 | 0.008 | 12.4 | ug/L |
| Mo | 98 | 699.089 | 2.5 | 69.388 | 0.06470 | 0.002 | 3.0 | ug/L |
| Rh | 103 | 345441.642 | 1.6 | 381957.031 | | | | ug/L |
| Ag | 107 | 84.001 | 8.3 | 56.667 | 0.00192 | 0.000 | 25.3 | ug/L |
| Ag | 109 | 70.001 | 21.0 | 52.667 | 0.00129 | 0.001 | 82.1 | ug/L |
| Cd | 111 | 250.594 | 0.6 | 249.856 | 0.00130 | 0.000 | 33.3 | ug/L |
| Cd | 114 | 62.614 | 17.4 | 64.386 | -0.00012 | 0.001 | 1206.1 | ug/L |
| > In | 115 | 390851.811 | 0.4 | 396447.935 | | | | ug/L |
| Sb | 121 | 454.017 | 9.8 | 62.334 | 0.03872 | 0.004 | 11.0 | ug/L |
| Sb | 123 | 357.498 | 16.1 | 53.222 | 0.03981 | 0.007 | 18.5 | ug/L |
| Ba | 135 | 6487.923 | 1.6 | 56.334 | 2.57205 | 0.058 | 2.3 | ug/L |
| Ba | 137 | 11411.924 | 1.4 | 65.001 | 2.66513 | 0.008 | 0.3 | ug/L |
| > Tb | 159 | 450505.676 | 1.4 | 486746.910 | | | | ug/L |
| > Ho | 165 | 443786.566 | 0.9 | 457509.069 | | | | ug/L |
| Tl | 203 | 76.668 | 18.6 | 48.667 | 0.00362 | 0.002 | 45.8 | ug/L |
| Tl | 205 | 133.336 | 4.8 | 63.334 | 0.00389 | 0.000 | 8.2 | ug/L |
| Pb | 208 | 756.354 | 3.4 | 537.345 | 0.00905 | 0.001 | 12.5 | ug/L |

Sample ID: 950477L D.5

Report Date/Time: Monday, November 20, 2006 13:44:00

Page 1

735

| | | | | | | | | |
|--|----|-----|---------|------|---------|---------|-------|-----------|
| | Pb | 206 | 191.337 | 11.4 | 135.336 | 0.00883 | 0.003 | 38.9 ug/L |
| | Pb | 207 | 189.337 | 8.6 | 124.336 | 0.01199 | 0.003 | 24.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 96.008 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 92.507 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.588 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 92.554 | | | |
| > Ho | 165 | | 97.001 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Monday, November 20, 2006 13:46:56

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 3.044

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1317.451 | 5.5 | 51.334 | 1.10027 | 0.083 | 7.5 | ug/L |
| Al | 27 | 101898.950 | 3.1 | 4379.197 | 11.21575 | 0.167 | 1.5 | ug/L |
| > Sc | 45 | 406003.755 | 1.9 | 424656.486 | | | | ug/L |
| V | 51 | 21761.453 | 1.7 | 5557.188 | 1.01963 | 0.029 | 2.9 | ug/L |
| Cr | 52 | 31057.767 | 2.4 | 18419.857 | 0.97915 | 0.031 | 3.2 | ug/L |
| Cr | 53 | 2552.417 | 2.6 | 945.730 | 0.96460 | 0.042 | 4.3 | ug/L |
| Mn | 55 | 20676.169 | 2.5 | 692.369 | 1.11321 | 0.034 | 3.1 | ug/L |
| Co | 59 | 16913.652 | 1.6 | 265.007 | 1.04849 | 0.013 | 1.2 | ug/L |
| Ni | 60 | 3981.324 | 2.4 | 177.337 | 1.09808 | 0.026 | 2.4 | ug/L |
| Ni | 62 | 739.707 | 3.4 | 902.391 | -0.14484 | 0.049 | 33.7 | ug/L |
| Cu | 63 | 8878.817 | 1.5 | 876.388 | 0.99533 | 0.011 | 1.1 | ug/L |
| Cu | 65 | 4391.536 | 4.4 | 254.340 | 1.06199 | 0.055 | 5.2 | ug/L |
| Zn | 66 | 14818.645 | 0.4 | 2747.481 | 5.44883 | 0.034 | 0.6 | ug/L |
| Zn | 67 | 2415.708 | 2.6 | 502.020 | 5.03993 | 0.130 | 2.6 | ug/L |
| Zn | 68 | 10778.075 | 2.1 | 1975.921 | 5.50263 | 0.166 | 3.0 | ug/L |
| > Ge | 72 | 205647.948 | 0.5 | 227398.462 | | | | ug/L |
| As | 75 | 2859.519 | 2.7 | 127.002 | 1.06725 | 0.034 | 3.1 | ug/L |
| Se | 77 | 402.876 | 3.5 | 226.870 | 1.02764 | 0.064 | 6.3 | ug/L |
| Se | 78 | 15061.872 | 1.5 | 16063.843 | 0.88376 | 0.258 | 29.2 | mg/L |
| Se | 82 | 1324.105 | 0.7 | 661.626 | 2.73476 | 0.037 | 1.4 | ug/L |
| Kr | 83 | 1070.413 | 4.9 | 694.703 | | | | mg/L |
| Y | 89 | 389450.292 | 1.5 | 420425.593 | | | | ug/L |
| Mo | 95 | 6073.941 | 2.3 | 127.336 | 0.99546 | 0.014 | 1.4 | ug/L |
| Mo | 97 | 3781.896 | 2.0 | 61.668 | 1.01931 | 0.020 | 1.9 | ug/L |
| Mo | 98 | 9417.615 | 1.4 | 69.388 | 0.96401 | 0.030 | 3.2 | ug/L |
| Rh | 103 | 360946.513 | 1.5 | 381957.031 | | | | ug/L |
| Ag | 107 | 15395.031 | 1.9 | 56.667 | 1.05444 | 0.030 | 2.8 | ug/L |
| Ag | 109 | 14080.695 | 1.5 | 52.667 | 1.00417 | 0.034 | 3.3 | ug/L |
| Cd | 111 | 3717.790 | 2.3 | 249.856 | 1.06152 | 0.014 | 1.3 | ug/L |
| Cd | 114 | 7583.589 | 2.7 | 64.386 | 1.01949 | 0.039 | 3.9 | ug/L |
| > In | 115 | 389023.926 | 1.9 | 396447.935 | | | | ug/L |
| Sb | 121 | 10261.750 | 0.7 | 62.334 | 1.01130 | 0.018 | 1.8 | ug/L |
| Sb | 123 | 7875.320 | 1.6 | 53.222 | 1.02653 | 0.031 | 3.0 | ug/L |
| Ba | 135 | 2816.838 | 1.8 | 56.334 | 1.07091 | 0.006 | 0.6 | ug/L |
| Ba | 137 | 4950.520 | 2.1 | 65.001 | 1.11368 | 0.042 | 3.8 | ug/L |
| > Tb | 159 | 464473.618 | 1.9 | 486746.910 | | | | ug/L |
| > Ho | 165 | 436022.239 | 0.9 | 457509.069 | | | | ug/L |
| Tl | 203 | 9061.348 | 1.2 | 48.667 | 1.13089 | 0.020 | 1.8 | ug/L |
| Tl | 205 | 21140.663 | 1.4 | 63.334 | 1.16183 | 0.008 | 0.6 | ug/L |
| Pb | 208 | 28774.541 | 0.4 | 537.345 | 1.10715 | 0.014 | 1.2 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Monday, November 20, 2006 13:49:56

Page 1

738

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 7341.306 | 1.7 | 135.336 | 1.07625 | 0.009 | 0.9 ug/L |
| | Pb | 207 | 6387.178 | 1.2 | 124.336 | 1.11323 | 0.015 | 1.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | 110.027 | | | | |
| [Al | 27 | 112.157 | | | | |
| > [Sc | 45 | | 95.608 | | | |
| [V | 51 | 101.963 | | | | |
| [Cr | 52 | 97.915 | | | | |
| [Cr | 53 | 96.460 | | | | |
| [Mn | 55 | 111.321 | | | | |
| [Co | 59 | 104.849 | | | | |
| [Ni | 60 | 109.808 | | | | |
| [Ni | 62 | -14.484 | | | | |
| [Cu | 63 | 99.533 | | | | |
| [Cu | 65 | 106.199 | | | | |
| [Zn | 66 | 108.977 | | | | |
| [Zn | 67 | 100.799 | | | | |
| [Zn | 68 | 110.053 | | | | |
| > [Ge | 72 | | 90.435 | | | |
| [As | 75 | 106.725 | | | | |
| [Se | 77 | 102.764 | | | | |
| [Se | 78 | 88.376 | | | | |
| [Se | 82 | 273.476 | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | 99.546 | | | | |
| [Mo | 97 | 101.931 | | | | |
| [Mo | 98 | 96.401 | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | 105.444 | | | | |
| [Ag | 109 | 100.417 | | | | |
| [Cd | 111 | 106.152 | | | | |
| [Cd | 114 | 101.949 | | | | |
| > [In | 115 | | 98.127 | | | |
| [Sb | 121 | 101.130 | | | | |
| [Sb | 123 | 102.653 | | | | |
| [Ba | 135 | 107.091 | | | | |
| [Ba | 137 | 111.368 | | | | |
| > [Tb | 159 | | 95.424 | | | |
| > [Ho | 165 | | 95.304 | | | |
| [Tl | 203 | 113.089 | | | | |
| [Tl | 205 | 116.183 | | | | |
| [Pb | 208 | 110.715 | | | | |
| [Pb | 206 | 107.625 | | | | |
| [Pb | 207 | 111.323 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: HLCCV2

Sample Date/Time: Monday, November 20, 2006 13:52:53

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\HLCCV2.045

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 230401.919 | 2.2 | 51.334 | 195.30059 | 3.080 | 1.6 | ug/L |
| Al | 27 | 1735567.496 | 1.0 | 4379.197 | 194.47995 | 5.212 | 2.7 | ug/L |
| > Sc | 45 | 415043.195 | 1.7 | 424656.486 | | | | ug/L |
| V | 51 | 3672647.217 | 1.5 | 5557.188 | 222.41027 | 7.299 | 3.3 | ug/L |
| Cr | 52 | 3142273.370 | 2.6 | 18419.857 | 222.65387 | 9.692 | 4.4 | ug/L |
| Cr | 53 | 327760.296 | 1.7 | 945.730 | 187.06618 | 0.233 | 0.1 | ug/L |
| Mn | 55 | 4224872.298 | 1.4 | 692.369 | 226.96844 | 6.825 | 3.0 | ug/L |
| Co | 59 | 3582456.822 | 2.6 | 265.007 | 217.93913 | 3.710 | 1.7 | ug/L |
| Ni | 60 | 694721.209 | 1.4 | 177.337 | 193.18551 | 5.741 | 3.0 | ug/L |
| Ni | 62 | 106472.592 | 0.1 | 902.391 | 193.91248 | 3.786 | 2.0 | ug/L |
| Cu | 63 | 1516353.043 | 2.2 | 876.388 | 180.51796 | 4.472 | 2.5 | ug/L |
| Cu | 65 | 737102.428 | 1.5 | 254.340 | 181.92394 | 3.069 | 1.7 | ug/L |
| Zn | 66 | 449436.080 | 0.7 | 2747.481 | 191.03520 | 3.423 | 1.8 | ug/L |
| Zn | 67 | 76177.478 | 2.3 | 502.020 | 188.22277 | 4.318 | 2.3 | ug/L |
| Zn | 68 | 322460.960 | 0.2 | 1975.921 | 189.87686 | 4.229 | 2.2 | ug/L |
| > Ge | 72 | 212561.989 | 2.1 | 227398.462 | | | | ug/L |
| As | 75 | 505507.883 | 1.8 | 127.002 | 190.20603 | 7.012 | 3.7 | ug/L |
| Se | 77 | 38715.058 | 0.6 | 226.870 | 193.69997 | 3.518 | 1.8 | ug/L |
| Se | 78 | 136631.311 | 1.7 | 16063.843 | 194.82847 | 8.227 | 4.2 | mg/L |
| Se | 82 | 54805.502 | 0.8 | 661.626 | 197.59427 | 4.393 | 2.2 | ug/L |
| Kr | 83 | 1075.747 | 3.8 | 694.703 | | | | mg/L |
| Y | 89 | 411398.879 | 2.1 | 420425.593 | | | | ug/L |
| Mo | 95 | 1096226.815 | 2.0 | 127.336 | 183.31769 | 4.051 | 2.2 | ug/L |
| Mo | 97 | 682821.667 | 0.7 | 61.668 | 186.97211 | 6.794 | 3.6 | ug/L |
| Mo | 98 | 1755687.177 | 1.2 | 69.388 | 180.91212 | 6.145 | 3.4 | ug/L |
| Rh | 103 | 363672.037 | 2.1 | 381957.031 | | | | ug/L |
| Ag | 107 | 3295282.233 | 0.4 | 56.667 | 226.44511 | 8.691 | 3.8 | ug/L |
| Ag | 109 | 3133879.760 | 1.1 | 52.667 | 224.16480 | 7.077 | 3.2 | ug/L |
| Cd | 111 | 623470.427 | 2.2 | 249.856 | 190.53416 | 9.411 | 4.9 | ug/L |
| Cd | 114 | 1387473.267 | 2.9 | 64.386 | 187.87989 | 3.525 | 1.9 | ug/L |
| > In | 115 | 389469.245 | 4.3 | 396447.935 | | | | ug/L |
| Sb | 121 | 1869112.658 | 0.1 | 62.334 | 185.26670 | 7.665 | 4.1 | ug/L |
| Sb | 123 | 1408717.472 | 2.2 | 53.222 | 184.68009 | 3.887 | 2.1 | ug/L |
| Ba | 135 | 499330.587 | 2.0 | 56.334 | 192.08172 | 2.560 | 1.3 | ug/L |
| Ba | 137 | 834222.374 | 2.0 | 65.001 | 188.55264 | 2.406 | 1.3 | ug/L |
| > Tb | 159 | 467888.526 | 0.8 | 486746.910 | | | | ug/L |
| > Ho | 165 | 452829.503 | 2.1 | 457509.069 | | | | ug/L |
| Tl | 203 | 1522466.854 | 1.6 | 48.667 | 183.89182 | 1.435 | 0.8 | ug/L |
| Tl | 205 | 4568280.215 | 1.0 | 63.334 | 242.53678 | 7.293 | 3.0 | ug/L |
| Pb | 208 | 5687525.948 | 0.3 | 537.345 | 214.55547 | 4.217 | 2.0 | ug/L |

Sample ID: HLCCV2

Report Date/Time: Monday, November 20, 2006 13:55:54

Page 1

741

| | | | | | | | | |
|--|----|-----|-------------|-----|---------|-----------|-------|----------|
| | Pb | 206 | 1299113.585 | 1.5 | 135.336 | 186.67181 | 2.056 | 1.1 ug/L |
| | Pb | 207 | 1084679.054 | 1.1 | 124.336 | 185.47267 | 2.193 | 1.2 ug/L |

Sample ID: HLCCV2

Report Date/Time: Monday, November 20, 2006 13:55:54

Page 2

742

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 97.736 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 93.476 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 98.240 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 96.126 | | | |
| > [Ho | 165 | | 98.977 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Monday, November 20, 2006 13:58:51

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 6.046

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 56466.597 | 1.7 | 51.334 | 49.18232 | 1.266 | 2.6 | ug/L |
| Al | 27 | 463724.180 | 2.0 | 4379.197 | 53.05798 | 1.055 | 2.0 | ug/L |
| > Sc | 45 | 403742.166 | 1.9 | 424656.486 | | | | ug/L |
| V | 51 | 801902.810 | 0.8 | 5557.188 | 49.65780 | 0.968 | 1.9 | ug/L |
| Cr | 52 | 689846.936 | 1.4 | 18419.857 | 49.24972 | 1.555 | 3.2 | ug/L |
| Cr | 53 | 82304.365 | 4.0 | 945.730 | 47.90872 | 2.202 | 4.6 | ug/L |
| Mn | 55 | 935054.587 | 1.7 | 692.369 | 52.18164 | 1.357 | 2.6 | ug/L |
| Co | 59 | 788901.472 | 3.9 | 265.007 | 49.87635 | 1.811 | 3.6 | ug/L |
| Ni | 60 | 174082.205 | 0.1 | 177.337 | 50.27246 | 0.465 | 0.9 | ug/L |
| Ni | 62 | 26457.531 | 0.3 | 902.391 | 48.93171 | 0.387 | 0.8 | ug/L |
| Cu | 63 | 410791.751 | 3.5 | 876.388 | 50.75150 | 1.368 | 2.7 | ug/L |
| Cu | 65 | 196335.371 | 2.8 | 254.340 | 50.32141 | 1.247 | 2.5 | ug/L |
| Zn | 66 | 112954.406 | 2.2 | 2747.481 | 49.08909 | 1.100 | 2.2 | ug/L |
| Zn | 67 | 19498.000 | 3.8 | 502.020 | 49.21231 | 1.562 | 3.2 | ug/L |
| Zn | 68 | 81322.399 | 1.4 | 1975.921 | 48.95579 | 0.213 | 0.4 | ug/L |
| > Ge | 72 | 204476.403 | 1.0 | 227398.462 | | | | ug/L |
| As | 75 | 126959.786 | 0.8 | 127.002 | 49.60314 | 0.204 | 0.4 | ug/L |
| Se | 77 | 9800.226 | 0.5 | 226.870 | 50.17534 | 0.361 | 0.7 | ug/L |
| Se | 78 | 44028.894 | 2.7 | 16063.843 | 49.23265 | 1.313 | 2.7 | mg/L |
| Se | 82 | 14262.595 | 0.7 | 661.626 | 51.80106 | 0.892 | 1.7 | ug/L |
| Kr | 83 | 1043.076 | 2.5 | 694.703 | | | | mg/L |
| Y | 89 | 389887.225 | 2.1 | 420425.593 | | | | ug/L |
| Mo | 95 | 276853.584 | 2.2 | 127.336 | 48.18902 | 3.121 | 6.5 | ug/L |
| Mo | 97 | 173766.893 | 3.2 | 61.668 | 49.50816 | 3.369 | 6.8 | ug/L |
| Mo | 98 | 454597.857 | 1.3 | 69.388 | 48.70948 | 1.764 | 3.6 | ug/L |
| Rh | 103 | 344840.119 | 2.2 | 381957.031 | | | | ug/L |
| Ag | 107 | 681099.957 | 2.3 | 56.667 | 48.64256 | 0.999 | 2.1 | ug/L |
| Ag | 109 | 656374.189 | 0.5 | 52.667 | 48.84328 | 2.320 | 4.7 | ug/L |
| Cd | 111 | 160183.967 | 2.0 | 249.856 | 50.83581 | 1.952 | 3.8 | ug/L |
| Cd | 114 | 360078.339 | 1.3 | 64.386 | 50.72480 | 1.781 | 3.5 | ug/L |
| > In | 115 | 374541.237 | 4.4 | 396447.935 | | | | ug/L |
| Sb | 121 | 484853.873 | 0.8 | 62.334 | 49.98217 | 2.425 | 4.9 | ug/L |
| Sb | 123 | 358003.824 | 1.4 | 53.222 | 48.81727 | 1.640 | 3.4 | ug/L |
| Ba | 135 | 124722.726 | 2.6 | 56.334 | 50.70306 | 1.837 | 3.6 | ug/L |
| Ba | 137 | 214061.282 | 3.7 | 65.001 | 51.13788 | 2.342 | 4.6 | ug/L |
| > Tb | 159 | 442744.540 | 1.1 | 486746.910 | | | | ug/L |
| > Ho | 165 | 432819.337 | 1.7 | 457509.069 | | | | ug/L |
| Tl | 203 | 406822.024 | 1.7 | 48.667 | 51.40247 | 0.288 | 0.6 | ug/L |
| Tl | 205 | 945524.102 | 1.0 | 63.334 | 52.49999 | 0.427 | 0.8 | ug/L |
| Pb | 208 | 1295445.504 | 0.8 | 537.345 | 51.10836 | 0.878 | 1.7 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Monday, November 20, 2006 14:01:54

Page 1

744

| | | | | | | | | |
|---|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 334032.812 | 1.3 | 135.336 | 50.19969 | 0.211 | 0.4 ug/L |
| L | Pb | 207 | 277609.291 | 1.0 | 124.336 | 49.65080 | 0.986 | 2.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 98.365 | | | | |
| Al | 27 | 106.116 | | | | |
| > Sc | 45 | | 95.075 | | | |
| V | 51 | 99.316 | | | | |
| Cr | 52 | 98.499 | | | | |
| Cr | 53 | 95.817 | | | | |
| Mn | 55 | 104.363 | | | | |
| Co | 59 | 99.753 | | | | |
| Ni | 60 | 100.545 | | | | |
| Ni | 62 | 97.863 | | | | |
| Cu | 63 | 101.503 | | | | |
| Cu | 65 | 100.643 | | | | |
| Zn | 66 | 98.178 | | | | |
| Zn | 67 | 98.425 | | | | |
| Zn | 68 | 97.912 | | | | |
| > Ge | 72 | | 89.920 | | | |
| As | 75 | 99.206 | | | | |
| Se | 77 | 100.351 | | | | |
| Se | 78 | 98.465 | | | | |
| Se | 82 | 103.602 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 96.378 | | | | |
| Mo | 97 | 99.016 | | | | |
| Mo | 98 | 97.419 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 97.285 | | | | |
| Ag | 109 | 97.687 | | | | |
| Cd | 111 | 101.672 | | | | |
| Cd | 114 | 101.450 | | | | |
| > In | 115 | | 94.474 | | | |
| Sb | 121 | 99.964 | | | | |
| Sb | 123 | 97.635 | | | | |
| Ba | 135 | 101.406 | | | | |
| Ba | 137 | 102.276 | | | | |
| > Tb | 159 | | 90.960 | | | |
| > Ho | 165 | | 94.603 | | | |
| Tl | 203 | 102.805 | | | | |
| Tl | 205 | 105.000 | | | | |
| Pb | 208 | 102.217 | | | | |
| Pb | 206 | 100.399 | | | | |
| Pb | 207 | 99.302 | | | | |

746

Sample ID: QC Std 6

Report Date/Time: Monday, November 20, 2006 14:01:54

Page 3

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Monday, November 20, 2006 14:04:49

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112006\QC Std 7.047

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 50.334 | 11.6 | 51.334 | 0.00290 | 0.006 | 203.7 | ug/L |
| Al | 27 | 3344.705 | 2.7 | 4379.197 | -0.08111 | 0.013 | 15.8 | ug/L |
| > Sc | 45 | 390245.925 | 1.3 | 424656.486 | | | | ug/L |
| V | 51 | 4683.278 | 3.4 | 5557.188 | -0.02720 | 0.014 | 50.5 | ug/L |
| Cr | 52 | 15962.440 | 2.6 | 18419.857 | -0.07287 | 0.039 | 53.5 | ug/L |
| Cr | 53 | 775.044 | 0.6 | 945.730 | -0.05718 | 0.009 | 15.2 | ug/L |
| Mn | 55 | 658.033 | 2.4 | 692.369 | 0.00264 | 0.000 | 8.0 | ug/L |
| Co | 59 | 168.670 | 6.5 | 265.007 | -0.00420 | 0.001 | 19.7 | ug/L |
| Ni | 60 | 145.336 | 10.7 | 177.337 | -0.00331 | 0.005 | 142.0 | ug/L |
| Ni | 62 | 216.338 | 3.0 | 902.391 | -1.12765 | 0.020 | 1.8 | ug/L |
| Cu | 63 | 355.678 | 2.0 | 876.388 | -0.05271 | 0.002 | 3.5 | ug/L |
| Cu | 65 | 200.004 | 7.0 | 254.340 | -0.00643 | 0.004 | 55.2 | ug/L |
| Zn | 66 | 2138.963 | 5.1 | 2747.481 | -0.13029 | 0.041 | 31.6 | ug/L |
| Zn | 67 | 427.349 | 3.4 | 502.020 | -0.04213 | 0.038 | 90.9 | ug/L |
| Zn | 68 | 1610.838 | 0.9 | 1975.921 | -0.08379 | 0.032 | 38.3 | ug/L |
| > Ge | 72 | 200870.377 | 2.5 | 227398.462 | | | | ug/L |
| As | 75 | 143.336 | 9.2 | 127.002 | 0.01248 | 0.006 | 50.2 | ug/L |
| Se | 77 | 217.069 | 3.9 | 226.870 | 0.08967 | 0.067 | 74.6 | ug/L |
| Se | 78 | 14496.983 | 1.1 | 16063.843 | 0.53415 | 0.853 | 159.7 | mg/L |
| Se | 82 | 1042.532 | 1.9 | 661.626 | 1.76766 | 0.044 | 2.5 | ug/L |
| Kr | 83 | 1077.414 | 2.1 | 694.703 | | | | mg/L |
| Y | 89 | 382098.232 | 0.6 | 420425.593 | | | | ug/L |
| Mo | 95 | 710.704 | 13.9 | 127.336 | 0.10022 | 0.016 | 15.7 | ug/L |
| Mo | 97 | 408.348 | 15.7 | 61.668 | 0.09732 | 0.017 | 17.2 | ug/L |
| Mo | 98 | 966.082 | 21.5 | 69.388 | 0.09434 | 0.021 | 21.9 | ug/L |
| Rh | 103 | 344279.705 | 1.4 | 381957.031 | | | | ug/L |
| Ag | 107 | 157.336 | 28.7 | 56.667 | 0.00718 | 0.003 | 42.3 | ug/L |
| Ag | 109 | 133.669 | 33.7 | 52.667 | 0.00603 | 0.003 | 52.9 | ug/L |
| Cd | 111 | 236.712 | 1.2 | 249.856 | -0.00118 | 0.001 | 123.3 | ug/L |
| Cd | 114 | 45.830 | 15.7 | 64.386 | -0.00223 | 0.001 | 43.3 | ug/L |
| > In | 115 | 381650.253 | 1.1 | 396447.935 | | | | ug/L |
| Sb | 121 | 1290.114 | 11.9 | 62.334 | 0.12420 | 0.014 | 11.6 | ug/L |
| Sb | 123 | 972.549 | 12.8 | 53.222 | 0.12316 | 0.016 | 13.3 | ug/L |
| Ba | 135 | 49.334 | 16.9 | 56.334 | -0.00081 | 0.003 | 363.3 | ug/L |
| Ba | 137 | 72.334 | 18.0 | 65.001 | 0.00311 | 0.003 | 83.7 | ug/L |
| > Tb | 159 | 442680.058 | 3.3 | 486746.910 | | | | ug/L |
| > Ho | 165 | 429058.954 | 1.5 | 457509.069 | | | | ug/L |
| Tl | 203 | 82.668 | 13.9 | 48.667 | 0.00473 | 0.002 | 33.7 | ug/L |
| Tl | 205 | 137.003 | 14.6 | 63.334 | 0.00436 | 0.001 | 27.8 | ug/L |
| Pb | 208 | 412.675 | 5.1 | 537.345 | -0.00362 | 0.001 | 28.8 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Monday, November 20, 2006 14:07:50

Page 1

747

| | | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|-------|------|
| | Pb | 206 | 124.336 | 9.3 | 135.336 | -0.00037 | 0.002 | 542.6 | ug/L |
| | Pb | 207 | 91.668 | 11.7 | 124.336 | -0.00451 | 0.002 | 38.8 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 91.897 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 88.334 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 96.267 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 90.947 | | | |
| > [Ho | 165 | | 93.782 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Metals Cover Page

Analyst: Silento

Date: 11/21/06

Instrument: ELAN

Data File: 112106

Reviewed By: SD 11/22/06

Entered By: SD 11/22/06

Approval: CH 11/22/06

| Starlims Run # | Analytes Used | Batch ID | Method | Failed Analytes | Comments/ Problems |
|----------------|---------------|----------|--------|-----------------|--------------------|
| 137822 | Pb | M3990146 | 2008 | | |
| | | | | | |

| | | | | | |
|--------|--------------------|----------|------|----|--|
| 137823 | Be, Mn, Ni, As, Cd | M3990146 | 6020 | Cu | |
| | | | | | |

| | | | | | |
|--|--|--|--|--|--|
| | | | | | |
| | | | | | |

| | | | | | |
|--|--|--|--|--|--|
| | | | | | |
| | | | | | |

| | | | | | |
|--|--|--|--|--|--|
| | | | | | |
| | | | | | |

Package Data:

| Client Sub# | Package | Analytes Used | Failed Metals | Batch ID | Stds Attached? | Tranferred To LIMS | Raw Data Copied? |
|-------------|---------|--------------------------------------|---------------|----------|----------------|--------------------|------------------|
| 33493 | 5 / ASP | Be, Mn, Ni, As, Cd | Cu | M3990146 | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | 95003 ³ ₆ - Mn | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |

750

Daily Performance Report

Sample ID: Sample

Sample Date/Time: Tuesday, November 21, 2006 09:17:36

Sample Description:

Method File: c:\elandata\Method\EPA DAILY.mth

Dataset File: c:\elandata\Dataset\Daily2006\Sample.241

Tuning File: c:\elandata\Tuning\epa.tun

Optimization File: c:\elandata\Optimize\epa2.dac

Dual Detector Mode: Dual

Acq. Dead Time(ns): 60

Current Dead Time (ns): 60

Summary

| Analyte | Mass | Meas. Intens. Mean | Net Intens. Mean | Net Intens. SD | Net Intens. RSD |
|---------|-------|--------------------|------------------|----------------|-----------------|
| Mg | 24.0 | 63564.4 | 63564.430 | 2015.118 | 3.2 |
| Rh | 102.9 | 352900.7 | 352900.729 | 8653.625 | 2.5 |
| In | 114.9 | 359254.9 | 359254.922 | 7755.537 | 2.2 |
| Pb | 208.0 | 144816.7 | 144816.738 | 3293.502 | 2.3 |
| U | 238.1 | 248906.1 | 248906.117 | 5969.677 | 2.4 |
| [> Ba | 137.9 | 289673.2 | 289673.159 | 7353.083 | 2.5 |
| [Ba++ | 69.0 | 6979.0 | 0.024 | 0.000 | 1.5 |
| [> Ce | 139.9 | 392279.8 | 392279.799 | 11566.557 | 2.9 |
| [CeO | 155.9 | 7748.8 | 0.020 | 0.001 | 2.9 |
| Bkgd | 220.0 | 34.2 | 34.203 | 4.765 | 13.9 |

Current Optimization File Data

| Current Value | Description |
|---------------|-------------------------|
| 1.01 | Nebulizer Gas Flow |
| 8.00 | Lens Voltage |
| 1500.00 | ICP RF Power |
| -1832.50 | Analog Stage Voltage |
| 1017.50 | Pulse Stage Voltage |
| 70.00 | Discriminator Threshold |
| -2.50 | AC Rod Offset |

Current Autolens Data

| Analyte | Mass | Num of Pts | DAC Value | Maximum Intensity |
|---------|------|------------|-----------|-------------------|
| Be | 9 | 29 | 6.0 | 11347.2 |
| Co | 59 | 29 | 7.8 | 163395.3 |
| In | 115 | 29 | 8.0 | 266809.4 |

Elan 9000 Method 6020 - Summary Report

Sample ID: Blank

Sample Date/Time: Tuesday, November 21, 2006 09:33:02

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\Blank.001

*Sketch
11/21/06*

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54.001 | 8.1 | | | | | ug/L |
| Al | 27 | 9687.584 | 37.5 | | | | | ug/L |
| > Sc | 45 | 378480.621 | 2.0 | | | | | ug/L |
| V | 51 | 4514.855 | 2.8 | | | | | ug/L |
| Cr | 52 | 14908.140 | 0.9 | | | | | ug/L |
| Cr | 53 | 661.366 | 1.5 | | | | | ug/L |
| Mn | 55 | 587.693 | 8.5 | | | | | ug/L |
| Co | 59 | 242.339 | 6.4 | | | | | ug/L |
| Ni | 60 | 623.696 | 8.9 | | | | | ug/L |
| Ni | 62 | 504.354 | 3.7 | | | | | ug/L |
| Cu | 63 | 1290.783 | 21.5 | | | | | ug/L |
| Cu | 65 | 588.027 | 20.6 | | | | | ug/L |
| Zn | 66 | 2796.188 | 28.1 | | | | | ug/L |
| Zn | 67 | 500.354 | 24.6 | | | | | ug/L |
| Zn | 68 | 2052.621 | 28.7 | | | | | ug/L |
| > Ge | 72 | 193550.369 | 2.5 | | | | | ug/L |
| As | 75 | 97.335 | 6.8 | | | | | ug/L |
| Se | 77 | 187.669 | 1.5 | | | | | ug/L |
| Se | 78 | 13588.495 | 1.5 | | | | | mg/L |
| Se | 82 | 1139.011 | 2.2 | | | | | ug/L |
| Kr | 83 | 1141.423 | 2.7 | | | | | mg/L |
| Y | 89 | 354910.360 | 4.5 | | | | | ug/L |
| Mo | 95 | 114.335 | 3.6 | | | | | ug/L |
| Mo | 97 | 49.001 | 10.8 | | | | | ug/L |
| Mo | 98 | 58.127 | 6.6 | | | | | ug/L |
| Rh | 103 | 323620.727 | 1.9 | | | | | ug/L |
| Ag | 107 | 57.001 | 15.0 | | | | | ug/L |
| Ag | 109 | 41.334 | 22.5 | | | | | ug/L |
| Cd | 111 | 233.296 | 9.2 | | | | | ug/L |
| Cd | 114 | 64.652 | 18.9 | | | | | ug/L |
| > In | 115 | 364581.825 | 1.7 | | | | | ug/L |
| Sb | 121 | 51.001 | 23.9 | | | | | ug/L |
| Sb | 123 | 45.100 | 6.7 | | | | | ug/L |
| Ba | 135 | 65.001 | 24.2 | | | | | ug/L |
| Ba | 137 | 74.668 | 31.4 | | | | | ug/L |
| > Tb | 159 | 439210.410 | 1.8 | | | | | ug/L |
| > Ho | 165 | 425708.154 | 1.3 | | | | | ug/L |
| Tl | 203 | 51.001 | 10.4 | | | | | ug/L |
| Tl | 205 | 72.668 | 10.3 | | | | | ug/L |
| Pb | 208 | 767.689 | 35.2 | | | | | ug/L |

Sample ID: Blank

Report Date/Time: Tuesday, November 21, 2006 09:36:02

Page 1

752

| | | | | | |
|--|----|-----|---------|------|------|
| | Pb | 206 | 194.671 | 31.6 | ug/L |
| | Pb | 207 | 181.671 | 35.0 | ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 1

Sample Date/Time: Tuesday, November 21, 2006 09:38:58

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\Standard 1.002

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 10964.986 | 1.5 | 54.001 | 10.00000 | 0.211 | 2.1 | ug/L |
| Al | 27 | 88120.569 | 2.7 | 9687.584 | 10.00000 | 0.245 | 2.5 | ug/L |
| > Sc | 45 | 360234.652 | 3.2 | 378480.621 | | | | ug/L |
| V | 51 | 159192.082 | 3.0 | 4514.855 | 10.00000 | 0.088 | 0.9 | ug/L |
| Cr | 52 | 144871.255 | 1.0 | 14908.140 | 10.00000 | 0.305 | 3.1 | ug/L |
| Cr | 53 | 16042.921 | 0.3 | 661.366 | 10.00000 | 0.303 | 3.0 | ug/L |
| Mn | 55 | 173217.554 | 0.9 | 587.693 | 10.00000 | 0.127 | 1.3 | ug/L |
| Co | 59 | 154126.474 | 0.7 | 242.339 | 10.00000 | 0.088 | 0.9 | ug/L |
| Ni | 60 | 34218.144 | 2.4 | 623.696 | 10.00000 | 0.207 | 2.1 | ug/L |
| Ni | 62 | 5351.772 | 2.5 | 504.354 | 10.00000 | 0.319 | 3.2 | ug/L |
| Cu | 63 | 77795.984 | 2.0 | 1290.783 | 10.00000 | 0.242 | 2.4 | ug/L |
| Cu | 65 | 37313.729 | 0.9 | 588.027 | 10.00000 | 0.127 | 1.3 | ug/L |
| Zn | 66 | 22384.247 | 0.6 | 2796.188 | 10.00000 | 0.114 | 1.1 | ug/L |
| Zn | 67 | 4026.347 | 3.4 | 500.354 | 10.00000 | 0.413 | 4.1 | ug/L |
| Zn | 68 | 16579.983 | 2.5 | 2052.621 | 10.00000 | 0.262 | 2.6 | ug/L |
| > Ge | 72 | 189838.191 | 0.4 | 193550.369 | | | | ug/L |
| As | 75 | 25039.485 | 1.6 | 97.335 | 10.00000 | 0.181 | 1.8 | ug/L |
| Se | 77 | 1932.891 | 3.2 | 187.669 | 10.00000 | 0.397 | 4.0 | ug/L |
| Se | 78 | 19421.524 | 2.1 | 13588.495 | 10.00000 | 0.790 | 7.9 | mg/L |
| Se | 82 | 3524.212 | 2.1 | 1139.011 | 10.00000 | 0.367 | 3.7 | ug/L |
| Kr | 83 | 1128.088 | 1.7 | 1141.423 | | | | mg/L |
| Y | 89 | 348769.309 | 2.3 | 354910.360 | | | | ug/L |
| Mo | 95 | 53971.147 | 2.4 | 114.335 | 10.00000 | 0.218 | 2.2 | ug/L |
| Mo | 97 | 32590.299 | 2.9 | 49.001 | 10.00000 | 0.352 | 3.5 | ug/L |
| Mo | 98 | 84343.314 | 2.9 | 58.127 | 10.00000 | 0.273 | 2.7 | ug/L |
| Rh | 103 | 322108.223 | 2.9 | 323620.727 | | | | ug/L |
| Ag | 107 | 141559.673 | 3.0 | 57.001 | 10.00000 | 0.312 | 3.1 | ug/L |
| Ag | 109 | 128823.500 | 1.4 | 41.334 | 10.00000 | 0.143 | 1.4 | ug/L |
| Cd | 111 | 30646.534 | 1.2 | 233.296 | 10.00000 | 0.183 | 1.8 | ug/L |
| Cd | 114 | 67842.105 | 0.8 | 64.652 | 10.00000 | 0.106 | 1.1 | ug/L |
| > In | 115 | 367532.976 | 0.9 | 364581.825 | | | | ug/L |
| Sb | 121 | 96738.219 | 0.1 | 51.001 | 10.00000 | 0.089 | 0.9 | ug/L |
| Sb | 123 | 75255.026 | 1.4 | 45.100 | 10.00000 | 0.084 | 0.8 | ug/L |
| Ba | 135 | 25097.017 | 3.6 | 65.001 | 10.00000 | 0.498 | 5.0 | ug/L |
| Ba | 137 | 43919.896 | 1.8 | 74.668 | 10.00000 | 0.336 | 3.4 | ug/L |
| > Tb | 159 | 421509.211 | 2.1 | 439210.410 | | | | ug/L |
| > Ho | 165 | 421554.780 | 0.9 | 425708.154 | | | | ug/L |
| Tl | 203 | 82720.703 | 0.6 | 51.001 | 10.00000 | 0.029 | 0.3 | ug/L |
| Tl | 205 | 192256.829 | 1.8 | 72.668 | 10.00000 | 0.248 | 2.5 | ug/L |
| Pb | 208 | 262893.819 | 0.7 | 767.689 | 10.00000 | 0.042 | 0.4 | ug/L |

Sample ID: Standard 1

Report Date/Time: Tuesday, November 21, 2006 09:41:59

Page 1

| | | | | | | | | |
|--|----|-----|-----------|-----|---------|----------|-------|----------|
| | Pb | 206 | 67856.495 | 0.4 | 194.671 | 10.00000 | 0.075 | 0.7 ug/L |
| | Pb | 207 | 57542.599 | 1.8 | 181.671 | 10.00000 | 0.119 | 1.2 ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 2

Sample Date/Time: Tuesday, November 21, 2006 09:44:55

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\Standard 2.003

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 21751.239 | 1.6 | 54.001 | 19.86165 | 0.394 | 2.0 | ug/L |
| Al | 27 | 177683.932 | 1.3 | 9687.584 | 20.14340 | 0.952 | 4.7 | ug/L |
| > Sc | 45 | 370581.167 | 3.3 | 378480.621 | | | | ug/L |
| V | 51 | 309278.227 | 1.5 | 4514.855 | 19.82155 | 0.372 | 1.9 | ug/L |
| Cr | 52 | 279191.744 | 0.8 | 14908.140 | 19.93554 | 0.564 | 2.8 | ug/L |
| Cr | 53 | 31324.433 | 2.5 | 661.366 | 19.86401 | 0.170 | 0.9 | ug/L |
| Mn | 55 | 355277.731 | 2.5 | 587.693 | 20.14724 | 0.334 | 1.7 | ug/L |
| Co | 59 | 298738.414 | 1.1 | 242.339 | 19.91871 | 0.092 | 0.5 | ug/L |
| Ni | 60 | 66612.203 | 1.4 | 623.696 | 19.97020 | 0.540 | 2.7 | ug/L |
| Ni | 62 | 10429.962 | 1.9 | 504.354 | 20.13178 | 0.120 | 0.6 | ug/L |
| Cu | 63 | 150544.547 | 0.9 | 1290.783 | 19.94177 | 0.302 | 1.5 | ug/L |
| Cu | 65 | 72611.406 | 1.5 | 588.027 | 19.96249 | 0.080 | 0.4 | ug/L |
| Zn | 66 | 43705.464 | 2.6 | 2796.188 | 20.20783 | 0.258 | 1.3 | ug/L |
| Zn | 67 | 7521.802 | 0.9 | 500.354 | 20.02184 | 0.351 | 1.8 | ug/L |
| Zn | 68 | 32490.553 | 1.8 | 2052.621 | 20.22089 | 0.150 | 0.7 | ug/L |
| > Ge | 72 | 187877.387 | 1.4 | 193550.369 | | | | ug/L |
| As | 75 | 47441.132 | 0.6 | 97.335 | 19.83073 | 0.321 | 1.6 | ug/L |
| Se | 77 | 3632.458 | 2.2 | 187.669 | 19.98685 | 0.457 | 2.3 | ug/L |
| Se | 78 | 24602.117 | 1.3 | 13588.495 | 19.77574 | 0.984 | 5.0 | mg/L |
| Se | 82 | 5933.379 | 1.8 | 1139.011 | 20.05227 | 0.269 | 1.3 | ug/L |
| Kr | 83 | 1165.426 | 1.2 | 1141.423 | | | | mg/L |
| Y | 89 | 354663.162 | 1.3 | 354910.360 | | | | ug/L |
| Mo | 95 | 100710.977 | 1.3 | 114.335 | 19.96497 | 0.174 | 0.9 | ug/L |
| Mo | 97 | 65338.190 | 1.9 | 49.001 | 20.24543 | 0.129 | 0.6 | ug/L |
| Mo | 98 | 166055.347 | 3.1 | 58.127 | 20.17444 | 0.614 | 3.0 | ug/L |
| Rh | 103 | 331253.768 | 5.3 | 323620.727 | | | | ug/L |
| Ag | 107 | 267674.789 | 1.7 | 57.001 | 20.01475 | 0.437 | 2.2 | ug/L |
| Ag | 109 | 248298.566 | 1.1 | 41.334 | 20.09054 | 0.314 | 1.6 | ug/L |
| Cd | 111 | 61109.157 | 1.7 | 233.296 | 20.23756 | 0.203 | 1.0 | ug/L |
| Cd | 114 | 137700.695 | 5.4 | 64.652 | 20.29069 | 0.799 | 3.9 | ug/L |
| > In | 115 | 346305.329 | 1.5 | 364581.825 | | | | ug/L |
| Sb | 121 | 191359.658 | 3.7 | 51.001 | 20.19120 | 0.446 | 2.2 | ug/L |
| Sb | 123 | 142294.002 | 0.9 | 45.100 | 20.01533 | 0.358 | 1.8 | ug/L |
| Ba | 135 | 48382.690 | 4.2 | 65.001 | 19.74514 | 0.527 | 2.7 | ug/L |
| Ba | 137 | 84203.800 | 0.8 | 74.668 | 19.72259 | 0.192 | 1.0 | ug/L |
| > Tb | 159 | 432664.206 | 1.5 | 439210.410 | | | | ug/L |
| > Ho | 165 | 411626.794 | 0.7 | 425708.154 | | | | ug/L |
| Tl | 203 | 161366.398 | 1.0 | 51.001 | 19.99667 | 0.072 | 0.4 | ug/L |
| Tl | 205 | 385796.797 | 2.6 | 72.668 | 20.10787 | 0.453 | 2.3 | ug/L |
| Pb | 208 | 517203.702 | 2.1 | 767.689 | 20.03502 | 0.338 | 1.7 | ug/L |

Sample ID: Standard 2

Report Date/Time: Tuesday, November 21, 2006 09:47:57

Page 1

756

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 132148.109 | 1.9 | 194.671 | 19.99433 | 0.348 | 1.7 ug/L |
| | Pb | 207 | 111400.108 | 0.5 | 181.671 | 19.97152 | 0.147 | 0.7 ug/L |

Sample ID: Standard 2

Report Date/Time: Tuesday, November 21, 2006 09:47:57

Page 2

757

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 3

Sample Date/Time: Tuesday, November 21, 2006 09:50:53

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\Standard 3.004

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 104113.691 | 2.7 | 54.001 | 99.73120 | 0.916 | 0.9 | ug/L |
| Al | 27 | 825652.075 | 2.9 | 9687.584 | 99.85985 | 5.345 | 5.4 | ug/L |
| > Sc | 45 | 372854.254 | 3.2 | 378480.621 | | | | ug/L |
| V | 51 | 1407087.546 | 1.9 | 4514.855 | 99.51021 | 1.579 | 1.6 | ug/L |
| Cr | 52 | 1242958.112 | 4.0 | 14908.140 | 99.58533 | 4.367 | 4.4 | ug/L |
| Cr | 53 | 150677.167 | 1.9 | 661.366 | 99.83077 | 1.526 | 1.5 | ug/L |
| Mn | 55 | 1645969.080 | 2.3 | 587.693 | 99.51149 | 1.984 | 2.0 | ug/L |
| Co | 59 | 1424048.044 | 2.8 | 242.339 | 99.59503 | 0.296 | 0.3 | ug/L |
| Ni | 60 | 316444.688 | 3.1 | 623.696 | 99.62352 | 2.242 | 2.2 | ug/L |
| Ni | 62 | 48941.482 | 1.8 | 504.354 | 99.75790 | 0.960 | 1.0 | ug/L |
| Cu | 63 | 737825.733 | 3.1 | 1290.783 | 99.77048 | 0.604 | 0.6 | ug/L |
| Cu | 65 | 359579.143 | 2.2 | 588.027 | 99.82646 | 0.408 | 0.4 | ug/L |
| Zn | 66 | 207772.523 | 3.0 | 2796.188 | 99.90325 | 1.662 | 1.7 | ug/L |
| Zn | 67 | 35283.563 | 1.2 | 500.354 | 99.80187 | 1.471 | 1.5 | ug/L |
| Zn | 68 | 150454.600 | 2.1 | 2052.621 | 99.77321 | 2.150 | 2.2 | ug/L |
| > Ge | 72 | 193730.226 | 2.6 | 193550.369 | | | | ug/L |
| As | 75 | 233120.836 | 2.3 | 97.335 | 99.73315 | 3.483 | 3.5 | ug/L |
| Se | 77 | 17187.513 | 2.4 | 187.669 | 99.77607 | 0.355 | 0.4 | ug/L |
| Se | 78 | 68541.595 | 2.5 | 13588.495 | 99.60401 | 0.268 | 0.3 | mg/L |
| Se | 82 | 24850.627 | 3.5 | 1139.011 | 99.77598 | 1.500 | 1.5 | ug/L |
| Kr | 83 | 1145.090 | 3.6 | 1141.423 | | | | mg/L |
| Y | 89 | 355332.011 | 4.3 | 354910.360 | | | | ug/L |
| Mo | 95 | 485276.269 | 2.1 | 114.335 | 99.75777 | 0.964 | 1.0 | ug/L |
| Mo | 97 | 316026.611 | 2.5 | 49.001 | 99.84408 | 1.004 | 1.0 | ug/L |
| Mo | 98 | 811235.155 | 2.3 | 58.127 | 99.87399 | 1.054 | 1.1 | ug/L |
| Rh | 103 | 328715.119 | 1.9 | 323620.727 | | | | ug/L |
| Ag | 107 | 1242195.325 | 1.1 | 57.001 | 99.57663 | 1.059 | 1.1 | ug/L |
| Ag | 109 | 1208090.648 | 1.9 | 41.334 | 99.83286 | 0.612 | 0.6 | ug/L |
| Cd | 111 | 288843.716 | 2.5 | 233.296 | 99.73951 | 1.615 | 1.6 | ug/L |
| Cd | 114 | 660238.152 | 2.3 | 64.652 | 99.81295 | 0.828 | 0.8 | ug/L |
| > In | 115 | 350410.136 | 1.6 | 364581.825 | | | | ug/L |
| Sb | 121 | 915602.086 | 2.8 | 51.001 | 99.77646 | 1.424 | 1.4 | ug/L |
| Sb | 123 | 686795.082 | 2.4 | 45.100 | 99.77474 | 0.855 | 0.9 | ug/L |
| Ba | 135 | 240835.762 | 2.3 | 65.001 | 99.97039 | 2.569 | 2.6 | ug/L |
| Ba | 137 | 402746.085 | 2.9 | 74.668 | 99.76561 | 2.121 | 2.1 | ug/L |
| > Tb | 159 | 428496.661 | 1.0 | 439210.410 | | | | ug/L |
| > Ho | 165 | 414540.098 | 1.9 | 425708.154 | | | | ug/L |
| Tl | 203 | 760928.705 | 2.1 | 51.001 | 99.67873 | 1.480 | 1.5 | ug/L |
| Tl | 205 | 1726745.758 | 2.4 | 72.668 | 99.43741 | 1.221 | 1.2 | ug/L |
| Pb | 208 | 2407794.514 | 2.3 | 767.689 | 99.62755 | 0.769 | 0.8 | ug/L |

Sample ID: Standard 3

Report Date/Time: Tuesday, November 21, 2006 09:53:55

Page 1

758

| | | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|-----|------|
| | Pb | 206 | 634928.801 | 4.1 | 194.671 | 99.77481 | 2.279 | 2.3 | ug/L |
| | Pb | 207 | 527777.931 | 2.0 | 181.671 | 99.70068 | 0.910 | 0.9 | ug/L |

Sample ID: Standard 3

Report Date/Time: Tuesday, November 21, 2006 09:53:55

Page 2

759

Quantitative Analysis Calibration Report

File Name: 112106.cal
File Path: C:\elandata\System
Calibration Type: External Calibration

| Analyte | Mass | Curve Type | Slope | Intercept | Corr. Coeff. |
|---------|---------|------------------|-------|-----------|--------------|
| Be | 9.012 | Linear Thru Zero | 0.00 | 0.00 | 0.999923 |
| Al | 26.982 | Linear Thru Zero | 0.02 | 0.00 | 0.999975 |
| Sc | 44.956 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| V | 50.944 | Linear Thru Zero | 0.04 | 0.00 | 0.999751 |
| Cr | 51.941 | Linear Thru Zero | 0.03 | 0.00 | 0.999827 |
| Cr | 52.941 | Linear Thru Zero | 0.00 | 0.00 | 0.999967 |
| Mn | 54.938 | Linear Thru Zero | 0.09 | 0.00 | 0.999755 |
| Co | 58.933 | Linear Thru Zero | 0.07 | 0.00 | 0.999834 |
| Ni | 59.933 | Linear Thru Zero | 0.02 | 0.00 | 0.999858 |
| Ni | 61.928 | Linear Thru Zero | 0.00 | 0.00 | 0.999937 |
| Cu | 62.930 | Linear Thru Zero | 0.04 | 0.00 | 0.999946 |
| Cu | 64.928 | Linear Thru Zero | 0.02 | 0.00 | 0.999970 |
| Zn | 65.926 | Linear Thru Zero | 0.01 | 0.00 | 0.999980 |
| Zn | 66.927 | Linear Thru Zero | 0.00 | 0.00 | 0.999961 |
| Zn | 67.925 | Linear Thru Zero | 0.01 | 0.00 | 0.999936 |
| Ge | 71.922 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| As | 74.922 | Linear Thru Zero | 0.01 | 0.00 | 0.999921 |
| Se | 76.920 | Linear Thru Zero | 0.00 | 0.00 | 0.999950 |
| Se | 77.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999829 |
| Se | 81.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999949 |
| Kr | 82.914 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Y | 88.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Mo | 94.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999941 |
| Mo | 96.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999960 |
| Mo | 97.906 | Linear Thru Zero | 0.02 | 0.00 | 0.999977 |
| Rh | 102.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ag | 106.905 | Linear Thru Zero | 0.04 | 0.00 | 0.999821 |
| Ag | 108.905 | Linear Thru Zero | 0.03 | 0.00 | 0.999970 |
| Cd | 110.904 | Linear Thru Zero | 0.01 | 0.00 | 0.999917 |
| Cd | 113.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999943 |
| In | 114.904 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Sb | 120.904 | Linear Thru Zero | 0.03 | 0.00 | 0.999941 |
| Sb | 122.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999949 |
| Ba | 134.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999983 |
| Ba | 136.905 | Linear Thru Zero | 0.01 | 0.00 | 0.999925 |
| Tb | 158.925 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ho | 164.930 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Tl | 202.972 | Linear Thru Zero | 0.02 | 0.00 | 0.999897 |
| Tl | 204.975 | Linear Thru Zero | 0.04 | 0.00 | 0.999680 |
| Pb | 207.977 | Linear Thru Zero | 0.06 | 0.00 | 0.999861 |

| | | | | | |
|----|---------|------------------|------|------|----------|
| Pb | 205.975 | Linear Thru Zero | 0.02 | 0.00 | 0.999949 |
| Pb | 206.976 | Linear Thru Zero | 0.01 | 0.00 | 0.999910 |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 1

Sample Date/Time: Tuesday, November 21, 2006 09:56:52

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 1.005

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 50482.396 | 3.3 | 54.001 | 49.28973 | 1.277 | 2.6 | ug/L |
| Al | 27 | 422973.985 | 3.5 | 9687.584 | 51.56228 | 1.082 | 2.1 | ug/L |
| > Sc | 45 | 365552.790 | 1.8 | 378480.621 | | | | ug/L |
| V | 51 | 735933.185 | 3.4 | 4514.855 | 52.91584 | 1.190 | 2.2 | ug/L |
| Cr | 52 | 628608.266 | 2.1 | 14908.140 | 50.77442 | 0.760 | 1.5 | ug/L |
| Cr | 53 | 76762.411 | 1.5 | 661.366 | 51.65365 | 0.347 | 0.7 | ug/L |
| Mn | 55 | 844913.869 | 2.9 | 587.693 | 53.32936 | 1.265 | 2.4 | ug/L |
| Co | 59 | 725485.467 | 0.6 | 242.339 | 52.99564 | 0.307 | 0.6 | ug/L |
| Ni | 60 | 158514.742 | 1.0 | 623.696 | 52.03288 | 0.576 | 1.1 | ug/L |
| Ni | 62 | 24448.395 | 1.7 | 504.354 | 51.54838 | 0.536 | 1.0 | ug/L |
| Cu | 63 | 380096.306 | 0.9 | 1290.783 | 53.61705 | 0.861 | 1.6 | ug/L |
| Cu | 65 | 177963.436 | 1.1 | 588.027 | 51.52825 | 0.703 | 1.4 | ug/L |
| Zn | 66 | 103056.396 | 1.1 | 2796.188 | 51.10601 | 0.661 | 1.3 | ug/L |
| Zn | 67 | 17717.328 | 1.6 | 500.354 | 51.65703 | 1.106 | 2.1 | ug/L |
| Zn | 68 | 72519.599 | 1.2 | 2052.621 | 49.54425 | 1.084 | 2.2 | ug/L |
| > Ge | 72 | 185465.453 | 1.1 | 193550.369 | | | | ug/L |
| As | 75 | 112560.722 | 1.9 | 97.335 | 50.25574 | 0.465 | 0.9 | ug/L |
| Se | 77 | 8597.032 | 0.5 | 187.669 | 51.60481 | 0.327 | 0.6 | ug/L |
| Se | 78 | 40027.907 | 3.4 | 13588.495 | 51.13168 | 1.868 | 3.7 | mg/L |
| Se | 82 | 12904.184 | 1.2 | 1139.011 | 51.93171 | 0.629 | 1.2 | ug/L |
| Kr | 83 | 1181.096 | 3.5 | 1141.423 | | | | mg/L |
| Y | 89 | 343157.022 | 1.0 | 354910.360 | | | | ug/L |
| Mo | 95 | 248103.117 | 0.9 | 114.335 | 52.75170 | 0.323 | 0.6 | ug/L |
| Mo | 97 | 153302.475 | 0.7 | 49.001 | 50.10347 | 0.655 | 1.3 | ug/L |
| Mo | 98 | 407336.960 | 2.0 | 58.127 | 51.87368 | 0.670 | 1.3 | ug/L |
| Rh | 103 | 307742.040 | 1.7 | 323620.727 | | | | ug/L |
| Ag | 107 | 620526.135 | 1.2 | 57.001 | 51.45028 | 0.307 | 0.6 | ug/L |
| Ag | 109 | 600265.680 | 2.4 | 41.334 | 51.30989 | 0.870 | 1.7 | ug/L |
| Cd | 111 | 139358.399 | 2.0 | 233.296 | 49.74074 | 0.642 | 1.3 | ug/L |
| Cd | 114 | 327564.468 | 1.5 | 64.652 | 51.23267 | 1.181 | 2.3 | ug/L |
| > In | 115 | 338734.915 | 0.9 | 364581.825 | | | | ug/L |
| Sb | 121 | 447049.676 | 3.3 | 51.001 | 50.40225 | 1.752 | 3.5 | ug/L |
| Sb | 123 | 338106.225 | 2.5 | 45.100 | 50.80836 | 0.868 | 1.7 | ug/L |
| Ba | 135 | 121274.448 | 1.7 | 65.001 | 52.66838 | 0.627 | 1.2 | ug/L |
| Ba | 137 | 206368.038 | 2.5 | 74.668 | 53.49524 | 0.949 | 1.8 | ug/L |
| > Tb | 159 | 409428.971 | 1.2 | 439210.410 | | | | ug/L |
| > Ho | 165 | 404747.142 | 2.2 | 425708.154 | | | | ug/L |
| Tl | 203 | 381805.312 | 0.7 | 51.001 | 51.23703 | 1.230 | 2.4 | ug/L |
| Tl | 205 | 895744.810 | 1.0 | 72.668 | 52.85362 | 1.622 | 3.1 | ug/L |
| Pb | 208 | 1219104.689 | 1.8 | 767.689 | 51.66642 | 1.436 | 2.8 | ug/L |

Sample ID: QC Std 1

Report Date/Time: Tuesday, November 21, 2006 09:59:54

Page 1

762

| | | | | | | | |
|----|-----|------------|-----|---------|----------|-------|----------|
| Pb | 206 | 318108.888 | 2.6 | 194.671 | 51.21597 | 1.840 | 3.6 ug/L |
| Pb | 207 | 259672.379 | 1.3 | 181.671 | 50.24086 | 1.339 | 2.7 ug/L |

Sample ID: QC Std 1

Report Date/Time: Tuesday, November 21, 2006 09:59:54

Page 2

763

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 98.579 | | | | |
| Al | 27 | 103.125 | | | | |
| > Sc | 45 | | 96.584 | | | |
| V | 51 | 105.832 | | | | |
| Cr | 52 | 101.549 | | | | |
| Cr | 53 | 103.307 | | | | |
| Mn | 55 | 106.659 | | | | |
| Co | 59 | 105.991 | | | | |
| Ni | 60 | 104.066 | | | | |
| Ni | 62 | 103.097 | | | | |
| Cu | 63 | 107.234 | | | | |
| Cu | 65 | 103.057 | | | | |
| Zn | 66 | 102.212 | | | | |
| Zn | 67 | 103.314 | | | | |
| Zn | 68 | 99.088 | | | | |
| > Ge | 72 | | 95.823 | | | |
| As | 75 | 100.511 | | | | |
| Se | 77 | 103.210 | | | | |
| Se | 78 | 102.263 | | | | |
| Se | 82 | 103.863 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 105.503 | | | | |
| Mo | 97 | 100.207 | | | | |
| Mo | 98 | 103.747 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 102.901 | | | | |
| Ag | 109 | 102.620 | | | | |
| Cd | 111 | 99.481 | | | | |
| Cd | 114 | 102.465 | | | | |
| > In | 115 | | 92.911 | | | |
| Sb | 121 | 100.804 | | | | |
| Sb | 123 | 101.617 | | | | |
| Ba | 135 | 105.337 | | | | |
| Ba | 137 | 106.990 | | | | |
| > Tb | 159 | | 93.219 | | | |
| > Ho | 165 | | 95.076 | | | |
| Tl | 203 | 102.474 | | | | |
| Tl | 205 | 105.707 | | | | |
| Pb | 208 | 103.333 | | | | |
| Pb | 206 | 102.432 | | | | |
| Pb | 207 | 100.482 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 2

Sample Date/Time: Tuesday, November 21, 2006 10:02:50

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 2.006

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 52.667 | 7.2 | 54.001 | -0.00036 | 0.006 | 1664.0 | ug/L |
| Al | 27 | 3133.620 | 0.9 | 9687.584 | -0.78317 | 0.020 | 2.6 | ug/L |
| > Sc | 45 | 373071.384 | 4.6 | 378480.621 | | | | ug/L |
| V | 51 | 4367.326 | 3.0 | 4514.855 | -0.00552 | 0.015 | 267.0 | ug/L |
| Cr | 52 | 14443.320 | 2.0 | 14908.140 | -0.01892 | 0.052 | 277.5 | ug/L |
| Cr | 53 | 652.365 | 4.7 | 661.366 | 0.00030 | 0.004 | 1409.8 | ug/L |
| Mn | 55 | 501.353 | 4.8 | 587.693 | -0.00453 | 0.001 | 33.0 | ug/L |
| Co | 59 | 224.005 | 6.7 | 242.339 | -0.00090 | 0.001 | 163.6 | ug/L |
| Ni | 60 | 518.355 | 3.5 | 623.696 | -0.02950 | 0.006 | 19.2 | ug/L |
| Ni | 62 | 549.024 | 3.4 | 504.354 | 0.11884 | 0.065 | 54.5 | ug/L |
| Cu | 63 | 971.733 | 1.3 | 1290.783 | -0.04020 | 0.004 | 9.8 | ug/L |
| Cu | 65 | 407.347 | 3.4 | 588.027 | -0.04756 | 0.007 | 15.7 | ug/L |
| Zn | 66 | 1590.501 | 3.5 | 2796.188 | -0.57037 | 0.026 | 4.6 | ug/L |
| Zn | 67 | 312.342 | 5.4 | 500.354 | -0.51957 | 0.038 | 7.4 | ug/L |
| Zn | 68 | 1169.427 | 1.6 | 2052.621 | -0.57568 | 0.035 | 6.1 | ug/L |
| > Ge | 72 | 189259.912 | 3.1 | 193550.369 | | | | ug/L |
| As | 75 | 131.669 | 11.6 | 97.335 | 0.01590 | 0.005 | 33.9 | ug/L |
| Se | 77 | 192.602 | 1.3 | 187.669 | 0.05508 | 0.022 | 40.0 | ug/L |
| Se | 78 | 13473.750 | 1.4 | 13588.495 | 0.36021 | 0.765 | 212.5 | mg/L |
| Se | 82 | 1172.816 | 3.8 | 1139.011 | 0.25375 | 0.039 | 15.5 | ug/L |
| Kr | 83 | 1159.759 | 2.4 | 1141.423 | | | | mg/L |
| Y | 89 | 356439.907 | 2.8 | 354910.360 | | | | ug/L |
| Mo | 95 | 631.364 | 12.8 | 114.335 | 0.10787 | 0.013 | 11.7 | ug/L |
| Mo | 97 | 345.011 | 13.6 | 49.001 | 0.09459 | 0.010 | 10.6 | ug/L |
| Mo | 98 | 809.064 | 18.8 | 58.127 | 0.09305 | 0.015 | 16.1 | ug/L |
| Rh | 103 | 322748.798 | 1.0 | 323620.727 | | | | ug/L |
| Ag | 107 | 132.336 | 21.2 | 57.001 | 0.00626 | 0.002 | 32.8 | ug/L |
| Ag | 109 | 120.335 | 9.0 | 41.334 | 0.00673 | 0.001 | 12.2 | ug/L |
| Cd | 111 | 205.850 | 5.8 | 233.296 | -0.00573 | 0.006 | 107.9 | ug/L |
| Cd | 114 | 57.723 | 7.1 | 64.652 | -0.00059 | 0.001 | 149.3 | ug/L |
| > In | 115 | 348086.270 | 4.3 | 364581.825 | | | | ug/L |
| Sb | 121 | 1053.411 | 11.5 | 51.001 | 0.11010 | 0.010 | 9.3 | ug/L |
| Sb | 123 | 790.866 | 13.6 | 45.100 | 0.10912 | 0.012 | 10.5 | ug/L |
| Ba | 135 | 44.667 | 1.3 | 65.001 | -0.00796 | 0.000 | 1.7 | ug/L |
| Ba | 137 | 59.334 | 18.6 | 74.668 | -0.00346 | 0.003 | 85.2 | ug/L |
| > Tb | 159 | 432622.687 | 1.6 | 439210.410 | | | | ug/L |
| > Ho | 165 | 411041.049 | 3.3 | 425708.154 | | | | ug/L |
| Tl | 203 | 66.001 | 8.0 | 51.001 | 0.00223 | 0.001 | 43.4 | ug/L |
| Tl | 205 | 139.669 | 7.9 | 72.668 | 0.00403 | 0.000 | 11.7 | ug/L |
| Pb | 208 | 414.341 | 10.6 | 767.689 | -0.01366 | 0.001 | 10.7 | ug/L |

Sample ID: QC Std 2

Report Date/Time: Tuesday, November 21, 2006 10:05:50

Page 1

765

| | | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|------|------|
| | Pb | 206 | 118.002 | 18.1 | 194.671 | -0.01111 | 0.003 | 28.9 | ug/L |
| | Pb | 207 | 98.335 | 4.1 | 181.671 | -0.01469 | 0.000 | 1.8 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 98.571 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 97.783 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 95.475 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.500 | | | |
| > [Ho | 165 | | 96.555 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Tuesday, November 21, 2006 10:08:46

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 3.007

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1127.754 | 4.2 | 54.001 | 1.02269 | 0.075 | 7.4 | ug/L |
| Al | 27 | 92342.105 | 1.2 | 9687.584 | 10.03899 | 0.355 | 3.5 | ug/L |
| > Sc | 45 | 375866.215 | 3.6 | 378480.621 | | | | ug/L |
| V | 51 | 19679.943 | 4.7 | 4514.855 | 1.06928 | 0.048 | 4.5 | ug/L |
| Cr | 52 | 27868.810 | 1.7 | 14908.140 | 1.05170 | 0.067 | 6.4 | ug/L |
| Cr | 53 | 2157.968 | 2.9 | 661.366 | 0.99113 | 0.034 | 3.4 | ug/L |
| Mn | 55 | 19138.486 | 2.6 | 587.693 | 1.15020 | 0.022 | 1.9 | ug/L |
| Co | 59 | 15564.679 | 1.0 | 242.339 | 1.09872 | 0.008 | 0.7 | ug/L |
| Ni | 60 | 3646.168 | 2.1 | 623.696 | 0.98152 | 0.015 | 1.5 | ug/L |
| Ni | 62 | 1004.737 | 3.0 | 504.354 | 1.08031 | 0.046 | 4.2 | ug/L |
| Cu | 63 | 8184.101 | 3.2 | 1290.783 | 0.96093 | 0.026 | 2.7 | ug/L |
| Cu | 65 | 3989.662 | 1.8 | 588.027 | 0.97306 | 0.012 | 1.2 | ug/L |
| Zn | 66 | 13074.379 | 0.8 | 2796.188 | 5.16622 | 0.093 | 1.8 | ug/L |
| Zn | 67 | 2161.302 | 5.5 | 500.354 | 4.91473 | 0.295 | 6.0 | ug/L |
| Zn | 68 | 9437.437 | 2.5 | 2052.621 | 5.11960 | 0.166 | 3.2 | ug/L |
| > Ge | 72 | 189058.854 | 0.9 | 193550.369 | | | | ug/L |
| As | 75 | 2569.422 | 2.4 | 97.335 | 1.08461 | 0.017 | 1.6 | ug/L |
| Se | 77 | 361.408 | 3.9 | 187.669 | 1.07068 | 0.066 | 6.2 | ug/L |
| Se | 78 | 14267.577 | 3.0 | 13588.495 | 1.84427 | 0.575 | 31.2 | mg/L |
| Se | 82 | 1430.990 | 2.5 | 1139.011 | 1.37258 | 0.097 | 7.1 | ug/L |
| Kr | 83 | 1198.431 | 1.4 | 1141.423 | | | | mg/L |
| Y | 89 | 351304.106 | 0.8 | 354910.360 | | | | ug/L |
| Mo | 95 | 5397.135 | 2.2 | 114.335 | 1.05819 | 0.025 | 2.3 | ug/L |
| Mo | 97 | 3354.375 | 2.6 | 49.001 | 1.01736 | 0.021 | 2.0 | ug/L |
| Mo | 98 | 8628.461 | 3.5 | 58.127 | 1.02741 | 0.012 | 1.2 | ug/L |
| Rh | 103 | 332499.322 | 1.1 | 323620.727 | | | | ug/L |
| Ag | 107 | 13913.746 | 1.2 | 57.001 | 1.08212 | 0.036 | 3.3 | ug/L |
| Ag | 109 | 12707.477 | 1.8 | 41.334 | 1.01959 | 0.028 | 2.8 | ug/L |
| Cd | 111 | 3242.739 | 1.6 | 233.296 | 1.01412 | 0.032 | 3.2 | ug/L |
| Cd | 114 | 6928.765 | 0.9 | 64.652 | 1.01157 | 0.047 | 4.6 | ug/L |
| > In | 115 | 360056.672 | 4.6 | 364581.825 | | | | ug/L |
| Sb | 121 | 10015.452 | 3.2 | 51.001 | 1.05816 | 0.051 | 4.8 | ug/L |
| Sb | 123 | 7522.032 | 4.9 | 45.100 | 1.05736 | 0.018 | 1.7 | ug/L |
| Ba | 135 | 2625.440 | 2.5 | 65.001 | 1.01985 | 0.030 | 2.9 | ug/L |
| Ba | 137 | 4624.329 | 2.0 | 74.668 | 1.08173 | 0.028 | 2.6 | ug/L |
| > Tb | 159 | 446482.324 | 0.6 | 439210.410 | | | | ug/L |
| > Ho | 165 | 409021.416 | 0.7 | 425708.154 | | | | ug/L |
| Tl | 203 | 8277.193 | 2.2 | 51.001 | 1.09236 | 0.018 | 1.7 | ug/L |
| Tl | 205 | 19950.397 | 2.8 | 72.668 | 1.16026 | 0.024 | 2.1 | ug/L |
| Pb | 208 | 26946.636 | 1.3 | 767.689 | 1.09948 | 0.014 | 1.3 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Tuesday, November 21, 2006 10:11:46

Page 1

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 6922.944 | 0.6 | 194.671 | 1.07338 | 0.001 | 0.1 ug/L |
| | Pb | 207 | 5790.402 | 1.2 | 181.671 | 1.07555 | 0.013 | 1.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 102.269 | | | | |
| Al | 27 | 100.390 | | | | |
| > Sc | 45 | | 99.309 | | | |
| V | 51 | 106.928 | | | | |
| Cr | 52 | 105.170 | | | | |
| Cr | 53 | 99.113 | | | | |
| Mn | 55 | 115.020 | | | | |
| Co | 59 | 109.872 | | | | |
| Ni | 60 | 98.152 | | | | |
| Ni | 62 | 108.031 | | | | |
| Cu | 63 | 96.093 | | | | |
| Cu | 65 | 97.306 | | | | |
| Zn | 66 | 103.324 | | | | |
| Zn | 67 | 98.295 | | | | |
| Zn | 68 | 102.392 | | | | |
| > Ge | 72 | | 97.679 | | | |
| As | 75 | 108.461 | | | | |
| Se | 77 | 107.068 | | | | |
| Se | 78 | 184.427 | | | | |
| Se | 82 | 137.258 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 105.819 | | | | |
| Mo | 97 | 101.736 | | | | |
| Mo | 98 | 102.741 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 108.212 | | | | |
| Ag | 109 | 101.959 | | | | |
| Cd | 111 | 101.412 | | | | |
| Cd | 114 | 101.157 | | | | |
| > In | 115 | | 98.759 | | | |
| Sb | 121 | 105.816 | | | | |
| Sb | 123 | 105.736 | | | | |
| Ba | 135 | 101.985 | | | | |
| Ba | 137 | 108.173 | | | | |
| > Tb | 159 | | 101.656 | | | |
| > Ho | 165 | | 96.080 | | | |
| Tl | 203 | 109.236 | | | | |
| Tl | 205 | 116.026 | | | | |
| Pb | 208 | 109.948 | | | | |
| Pb | 206 | 107.338 | | | | |
| Pb | 207 | 107.555 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 4

Sample Date/Time: Tuesday, November 21, 2006 10:14:42

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 4.008

| | Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| [| Be | 9 | 62.668 | 6.0 | 54.001 | 0.00828 | 0.004 | 43.9 | ug/L |
| | Al | 27 | 187845464.156 | 1.1 | 9687.584 | 22656.56731 | 337.765 | 1.5 | ug/L |
| > | Sc | 45 | 377954.768 | 2.4 | 378480.621 | | | | ug/L |
| | V | 51 | 3696.997 | 5.2 | 4514.855 | -0.05690 | 0.007 | 12.6 | ug/L |
| | Cr | 52 | 23223.558 | 2.2 | 14908.140 | 0.66655 | 0.009 | 1.4 | ug/L |
| [| Cr | 53 | 7614.894 | 5.3 | 661.366 | 4.56183 | 0.160 | 3.5 | ug/L |
| | Mn | 55 | 6419.203 | 1.5 | 587.693 | 0.32304 | 0.017 | 5.1 | ug/L |
| | Co | 59 | 1012.738 | 3.2 | 242.339 | 0.04842 | 0.000 | 0.2 | ug/L |
| | Ni | 60 | 2362.026 | 5.3 | 623.696 | 0.49065 | 0.026 | 5.4 | ug/L |
| | Ni | 62 | 2251.994 | 1.9 | 504.354 | 3.24293 | 0.137 | 4.2 | ug/L |
| | Cu | 63 | 8076.996 | 3.5 | 1290.783 | 0.83531 | 0.039 | 4.7 | ug/L |
| | Cu | 65 | 3209.317 | 1.7 | 588.027 | 0.66022 | 0.013 | 1.9 | ug/L |
| | Zn | 66 | 4229.784 | 5.5 | 2796.188 | 0.53792 | 0.060 | 11.1 | ug/L |
| | Zn | 67 | 1909.238 | 6.6 | 500.354 | 3.61773 | 0.287 | 7.9 | ug/L |
| | Zn | 68 | 2001.927 | 1.9 | 2052.621 | -0.13840 | 0.037 | 26.7 | ug/L |
| > | Ge | 72 | 209902.814 | 3.2 | 193550.369 | | | | ug/L |
| | As | 75 | 2062.610 | 8.5 | 97.335 | 0.77182 | 0.043 | 5.5 | ug/L |
| | Se | 77 | 841.443 | 5.1 | 187.669 | 3.45391 | 0.106 | 3.1 | ug/L |
| | Se | 78 | 14663.230 | 1.1 | 13588.495 | -0.10307 | 0.951 | 923.0 | mg/L |
| | Se | 82 | 1319.971 | 3.1 | 1139.011 | 0.32961 | 0.080 | 24.1 | ug/L |
| | Kr | 83 | 1407.800 | 3.4 | 1141.423 | | | | mg/L |
| [| Y | 89 | 362047.318 | 1.8 | 354910.360 | | | | ug/L |
| | Mo | 95 | 2487134.152 | 2.6 | 114.335 | 522.40966 | 17.219 | 3.3 | ug/L |
| | Mo | 97 | 1283890.018 | 0.6 | 49.001 | 414.42809 | 6.920 | 1.7 | ug/L |
| | Mo | 98 | 3896078.057 | 3.2 | 58.127 | 489.92074 | 12.550 | 2.6 | ug/L |
| | Rh | 103 | 307023.384 | 2.5 | 323620.727 | | | | ug/L |
| | Ag | 107 | 416.015 | 3.6 | 57.001 | 0.02968 | 0.002 | 5.2 | ug/L |
| | Ag | 109 | 363.012 | 3.4 | 41.334 | 0.02737 | 0.001 | 5.0 | ug/L |
| | Cd | 111 | 321.075 | 21.1 | 233.296 | 0.03598 | 0.025 | 69.4 | ug/L |
| | Cd | 114 | 4080.305 | 0.9 | 64.652 | 0.62083 | 0.013 | 2.0 | ug/L |
| > | In | 115 | 343076.654 | 1.1 | 364581.825 | | | | ug/L |
| | Sb | 121 | 3204.982 | 1.1 | 51.001 | 0.35146 | 0.004 | 1.2 | ug/L |
| [| Sb | 123 | 2483.866 | 3.1 | 45.100 | 0.36237 | 0.013 | 3.6 | ug/L |
| | Ba | 135 | 140.003 | 9.4 | 65.001 | 0.03540 | 0.006 | 16.6 | ug/L |
| | Ba | 137 | 208.671 | 6.1 | 74.668 | 0.03686 | 0.003 | 8.9 | ug/L |
| > | Tb | 159 | 403570.433 | 2.0 | 439210.410 | | | | ug/L |
| > | Ho | 165 | 395355.359 | 1.6 | 425708.154 | | | | ug/L |
| | Tl | 203 | 2064.944 | 6.7 | 51.001 | 0.27699 | 0.015 | 5.4 | ug/L |
| | Tl | 205 | 4879.151 | 8.7 | 72.668 | 0.29034 | 0.021 | 7.3 | ug/L |
| | Pb | 208 | 1573.739 | 6.4 | 767.689 | 0.03736 | 0.004 | 11.2 | ug/L |

Sample ID: QC Std 4

Report Date/Time: Tuesday, November 21, 2006 10:17:43

Page 1

771

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|-----------|
| | Pb | 206 | 408.681 | 4.8 | 194.671 | 0.03757 | 0.003 | 8.0 ug/L |
| | Pb | 207 | 358.678 | 5.5 | 181.671 | 0.03768 | 0.005 | 12.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | 113.283 | | | | |
| > Sc | 45 | | 99.861 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 108.449 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 130.602 | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 94.101 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 91.885 | | | |
| > Ho | 165 | | 92.870 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 5

Sample Date/Time: Tuesday, November 21, 2006 10:20:39

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 5.009

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| Be | 9 | 142.669 | 6.7 | 54.001 | 0.07842 | 0.010 | 12.5 | ug/L |
| Al | 27 | 196112578.793 | 0.6 | 9687.584 | 22679.20501 | 294.397 | 1.3 | ug/L |
| > Sc | 45 | 394152.255 | 1.6 | 378480.621 | | | | ug/L |
| V | 51 | -1300.882 | 233.1 | 4514.855 | -0.40480 | 0.204 | 50.4 | ug/L |
| Cr | 52 | 305359.255 | 3.0 | 14908.140 | 22.21705 | 0.382 | 1.7 | ug/L |
| Cr | 53 | 42844.982 | 2.0 | 661.366 | 26.52751 | 0.202 | 0.8 | ug/L |
| Mn | 55 | 387853.011 | 1.9 | 587.693 | 20.87530 | 0.650 | 3.1 | ug/L |
| Co | 59 | 325663.760 | 1.1 | 242.339 | 20.29533 | 0.591 | 2.9 | ug/L |
| Ni | 60 | 72835.096 | 2.4 | 623.696 | 20.28495 | 0.632 | 3.1 | ug/L |
| Ni | 62 | 13087.066 | 0.6 | 504.354 | 22.98762 | 0.527 | 2.3 | ug/L |
| Cu | 63 | 311270.995 | 2.2 | 1290.783 | 37.40946 | 0.283 | 0.8 | ug/L |
| Cu | 65 | 145427.411 | 2.0 | 588.027 | 35.89187 | 1.232 | 3.4 | ug/L |
| Zn | 66 | 50338.759 | 1.0 | 2796.188 | 20.50674 | 0.199 | 1.0 | ug/L |
| Zn | 67 | 8909.518 | 2.5 | 500.354 | 21.34923 | 0.739 | 3.5 | ug/L |
| Zn | 68 | 33562.505 | 3.4 | 2052.621 | 18.73908 | 1.030 | 5.5 | ug/L |
| > Ge | 72 | 217351.434 | 1.8 | 193550.369 | | | | ug/L |
| As | 75 | 55054.166 | 1.5 | 97.335 | 20.95358 | 0.307 | 1.5 | ug/L |
| Se | 77 | 914.650 | 2.4 | 187.669 | 3.68474 | 0.202 | 5.5 | ug/L |
| Se | 78 | 15336.682 | 2.2 | 13588.495 | 0.13114 | 0.761 | 580.3 | mg/L |
| Se | 82 | 1369.246 | 1.7 | 1139.011 | 0.34039 | 0.179 | 52.6 | ug/L |
| Kr | 83 | 1356.457 | 2.7 | 1141.423 | | | | mg/L |
| Y | 89 | 376576.835 | 2.8 | 354910.360 | | | | ug/L |
| Mo | 95 | 2695823.794 | 3.1 | 114.335 | 537.44958 | 25.328 | 4.7 | ug/L |
| Mo | 97 | 1345501.164 | 1.8 | 49.001 | 412.11333 | 9.386 | 2.3 | ug/L |
| Mo | 98 | 4344717.695 | 1.5 | 58.127 | 518.45752 | 4.944 | 1.0 | ug/L |
| Rh | 103 | 331777.317 | 3.0 | 323620.727 | | | | ug/L |
| Ag | 107 | 275230.459 | 2.0 | 57.001 | 21.37602 | 0.165 | 0.8 | ug/L |
| Ag | 109 | 255850.541 | 1.4 | 41.334 | 20.49066 | 0.397 | 1.9 | ug/L |
| Cd | 111 | 60735.625 | 1.0 | 233.296 | 20.26580 | 0.198 | 1.0 | ug/L |
| Cd | 114 | 140503.277 | 1.3 | 64.652 | 20.58392 | 0.517 | 2.5 | ug/L |
| > In | 115 | 361572.621 | 1.6 | 364581.825 | | | | ug/L |
| Sb | 121 | 3254.335 | 2.2 | 51.001 | 0.33848 | 0.010 | 3.1 | ug/L |
| Sb | 123 | 2507.849 | 3.3 | 45.100 | 0.34680 | 0.008 | 2.3 | ug/L |
| Ba | 135 | 188.337 | 3.2 | 65.001 | 0.05465 | 0.002 | 4.5 | ug/L |
| Ba | 137 | 293.675 | 2.4 | 74.668 | 0.05732 | 0.002 | 3.4 | ug/L |
| > Tb | 159 | 413740.827 | 0.2 | 439210.410 | | | | ug/L |
| > Ho | 165 | 405545.944 | 1.5 | 425708.154 | | | | ug/L |
| Tl | 203 | 1948.914 | 3.6 | 51.001 | 0.25446 | 0.008 | 3.2 | ug/L |
| Tl | 205 | 4571.635 | 5.6 | 72.668 | 0.26494 | 0.011 | 4.2 | ug/L |
| Pb | 208 | 2349.818 | 3.0 | 767.689 | 0.06848 | 0.002 | 3.6 | ug/L |

Sample ID: QC Std 5

Report Date/Time: Tuesday, November 21, 2006 10:23:40

Page 1

774

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 624.030 | 6.5 | 194.671 | 0.07045 | 0.005 | 7.8 ug/L |
| | Pb | 207 | 509.021 | 1.7 | 181.671 | 0.06490 | 0.002 | 2.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | 113.396 | | | | |
| > Sc | 45 | | 104.141 | | | |
| V | 51 | | | | | |
| Cr | 52 | 111.085 | | | | |
| Cr | 53 | 132.638 | | | | |
| Mn | 55 | 104.377 | | | | |
| Co | 59 | 101.477 | | | | |
| Ni | 60 | 101.425 | | | | |
| Ni | 62 | 114.938 | | | | |
| Cu | 63 | 187.047 | | | | |
| Cu | 65 | 179.459 | | | | |
| Zn | 66 | 102.534 | | | | |
| Zn | 67 | 106.746 | | | | |
| Zn | 68 | 93.695 | | | | |
| > Ge | 72 | | 112.297 | | | |
| As | 75 | 104.768 | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 134.362 | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 106.880 | | | | |
| Ag | 109 | 102.453 | | | | |
| Cd | 111 | 101.329 | | | | |
| Cd | 114 | 102.920 | | | | |
| > In | 115 | | 99.175 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 94.201 | | | |
| > Ho | 165 | | 95.264 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Tuesday, November 21, 2006 10:26:37

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 6.010

| | Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| | Be | 9 | 53925.511 | 2.3 | 54.001 | 51.66875 | 1.518 | 2.9 | ug/L |
| | Al | 27 | 429802.180 | 3.1 | 9687.584 | 51.40847 | 1.494 | 2.9 | ug/L |
| > | Sc | 45 | 372823.237 | 4.4 | 378480.621 | | | | ug/L |
| | V | 51 | 781968.803 | 4.1 | 4514.855 | 55.15451 | 0.186 | 0.3 | ug/L |
| | Cr | 52 | 673161.399 | 0.9 | 14908.140 | 53.43323 | 2.175 | 4.1 | ug/L |
| L | Cr | 53 | 79953.195 | 0.7 | 661.366 | 52.83785 | 2.689 | 5.1 | ug/L |
| | Mn | 55 | 909850.773 | 2.6 | 587.693 | 53.73498 | 0.697 | 1.3 | ug/L |
| | Co | 59 | 792968.091 | 4.3 | 242.339 | 54.18832 | 1.706 | 3.1 | ug/L |
| | Ni | 60 | 173919.173 | 1.7 | 623.696 | 53.42219 | 0.326 | 0.6 | ug/L |
| | Ni | 62 | 25818.869 | 1.9 | 504.354 | 50.92648 | 0.454 | 0.9 | ug/L |
| | Cu | 63 | 417203.691 | 3.2 | 1290.783 | 55.06058 | 1.052 | 1.9 | ug/L |
| | Cu | 65 | 195698.410 | 1.4 | 588.027 | 53.02682 | 0.745 | 1.4 | ug/L |
| | Zn | 66 | 109624.122 | 2.8 | 2796.188 | 50.85409 | 0.794 | 1.6 | ug/L |
| | Zn | 67 | 19360.682 | 4.1 | 500.354 | 52.83553 | 1.526 | 2.9 | ug/L |
| | Zn | 68 | 80343.951 | 1.2 | 2052.621 | 51.41367 | 1.076 | 2.1 | ug/L |
| > | Ge | 72 | 198201.872 | 1.3 | 193550.369 | | | | ug/L |
| | As | 75 | 126065.388 | 1.1 | 97.335 | 52.67561 | 0.562 | 1.1 | ug/L |
| | Se | 77 | 9661.201 | 3.1 | 187.669 | 54.31184 | 1.051 | 1.9 | ug/L |
| | Se | 78 | 45628.151 | 2.0 | 13588.495 | 56.19116 | 0.598 | 1.1 | mg/L |
| | Se | 82 | 14065.199 | 2.6 | 1139.011 | 53.05426 | 0.795 | 1.5 | ug/L |
| | Kr | 83 | 1328.453 | 2.6 | 1141.423 | | | | mg/L |
| L | Y | 89 | 367124.430 | 0.8 | 354910.360 | | | | ug/L |
| | Mo | 95 | 274793.133 | 2.8 | 114.335 | 54.45207 | 1.783 | 3.3 | ug/L |
| | Mo | 97 | 168182.253 | 2.0 | 49.001 | 51.22751 | 1.506 | 2.9 | ug/L |
| | Mo | 98 | 431105.258 | 4.2 | 58.127 | 51.13462 | 0.442 | 0.9 | ug/L |
| | Rh | 103 | 326432.594 | 1.3 | 323620.727 | | | | ug/L |
| | Ag | 107 | 665330.085 | 3.4 | 57.001 | 51.39831 | 1.241 | 2.4 | ug/L |
| | Ag | 109 | 629920.373 | 2.2 | 41.334 | 50.17680 | 0.854 | 1.7 | ug/L |
| | Cd | 111 | 152733.032 | 3.3 | 233.296 | 50.79134 | 0.764 | 1.5 | ug/L |
| | Cd | 114 | 336286.176 | 2.7 | 64.652 | 49.00672 | 1.311 | 2.7 | ug/L |
| > | In | 115 | 363629.938 | 3.4 | 364581.825 | | | | ug/L |
| | Sb | 121 | 454685.505 | 3.1 | 51.001 | 47.75540 | 0.686 | 1.4 | ug/L |
| L | Sb | 123 | 350403.940 | 1.3 | 45.100 | 49.07829 | 1.043 | 2.1 | ug/L |
| | Ba | 135 | 124134.200 | 3.1 | 65.001 | 53.24613 | 2.048 | 3.8 | ug/L |
| | Ba | 137 | 219576.740 | 1.4 | 74.668 | 56.21176 | 0.787 | 1.4 | ug/L |
| > | Tb | 159 | 414625.191 | 1.0 | 439210.410 | | | | ug/L |
| > | Ho | 165 | 404488.507 | 2.6 | 425708.154 | | | | ug/L |
| | Tl | 203 | 391319.334 | 1.2 | 51.001 | 52.55882 | 1.748 | 3.3 | ug/L |
| | Tl | 205 | 883274.789 | 1.0 | 72.668 | 52.14400 | 0.972 | 1.9 | ug/L |
| | Pb | 208 | 1217810.063 | 2.2 | 767.689 | 51.63875 | 1.056 | 2.0 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Tuesday, November 21, 2006 10:29:39

Page 1

777

| | | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|-----|------|
| | Pb | 206 | 316569.175 | 1.5 | 194.671 | 50.99924 | 1.234 | 2.4 | ug/L |
| | Pb | 207 | 261518.305 | 1.5 | 181.671 | 50.62379 | 0.683 | 1.3 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 103.338 | | | | |
| Al | 27 | 102.817 | | | | |
| > Sc | 45 | | 98.505 | | | |
| V | 51 | 110.309 | | | | |
| Cr | 52 | 106.866 | | | | |
| Cr | 53 | 105.676 | | | | |
| Mn | 55 | 107.470 | | | | |
| Co | 59 | 108.377 | | | | |
| Ni | 60 | 106.844 | | | | |
| Ni | 62 | 101.853 | | | | |
| Cu | 63 | 110.121 | | | | |
| Cu | 65 | 106.054 | | | | |
| Zn | 66 | 101.708 | | | | |
| Zn | 67 | 105.671 | | | | |
| Zn | 68 | 102.827 | | | | |
| > Ge | 72 | | 102.403 | | | |
| As | 75 | 105.351 | | | | |
| Se | 77 | 108.624 | | | | |
| Se | 78 | 112.382 | | | | |
| Se | 82 | 106.109 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 108.904 | | | | |
| Mo | 97 | 102.455 | | | | |
| Mo | 98 | 102.269 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 102.797 | | | | |
| Ag | 109 | 100.354 | | | | |
| Cd | 111 | 101.583 | | | | |
| Cd | 114 | 98.013 | | | | |
| > In | 115 | | 99.739 | | | |
| Sb | 121 | 95.511 | | | | |
| Sb | 123 | 98.157 | | | | |
| Ba | 135 | 106.492 | | | | |
| Ba | 137 | 112.424 | | | | |
| > Tb | 159 | | 94.402 | | | |
| > Ho | 165 | | 95.015 | | | |
| Tl | 203 | 105.118 | | | | |
| Tl | 205 | 104.288 | | | | |
| Pb | 208 | 103.278 | | | | |
| Pb | 206 | 101.998 | | | | |
| Pb | 207 | 101.248 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Tuesday, November 21, 2006 10:32:35

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 7.011

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55.667 | 9.0 | 54.001 | 0.00248 | 0.007 | 275.9 | ug/L |
| Al | 27 | 3445.080 | 1.4 | 9687.584 | -0.74560 | 0.018 | 2.4 | ug/L |
| > Sc | 45 | 373458.387 | 5.0 | 378480.621 | | | | ug/L |
| V | 51 | 4006.417 | 5.1 | 4514.855 | -0.03151 | 0.015 | 48.7 | ug/L |
| Cr | 52 | 14299.071 | 2.4 | 14908.140 | -0.03201 | 0.044 | 137.0 | ug/L |
| Cr | 53 | 1629.176 | 5.1 | 661.366 | 0.65212 | 0.106 | 16.3 | ug/L |
| Mn | 55 | 545.023 | 2.7 | 587.693 | -0.00369 | 0.001 | 19.2 | ug/L |
| Co | 59 | 207.671 | 2.7 | 242.339 | -0.00291 | 0.001 | 24.4 | ug/L |
| Ni | 60 | 538.023 | 2.3 | 623.696 | -0.03273 | 0.004 | 13.5 | ug/L |
| Ni | 62 | 591.360 | 3.9 | 504.354 | 0.13803 | 0.025 | 18.2 | ug/L |
| Cu | 63 | 1045.076 | 2.8 | 1290.783 | -0.03798 | 0.007 | 18.7 | ug/L |
| Cu | 65 | 443.683 | 4.8 | 588.027 | -0.04439 | 0.002 | 4.9 | ug/L |
| Zn | 66 | 1676.185 | 1.7 | 2796.188 | -0.57347 | 0.032 | 5.5 | ug/L |
| Zn | 67 | 401.680 | 3.5 | 500.354 | -0.32158 | 0.054 | 16.9 | ug/L |
| Zn | 68 | 1263.775 | 3.5 | 2052.621 | -0.55942 | 0.020 | 3.6 | ug/L |
| > Ge | 72 | 200325.553 | 3.0 | 193550.369 | | | | ug/L |
| As | 75 | 219.672 | 12.9 | 97.335 | 0.04933 | 0.013 | 26.3 | ug/L |
| Se | 77 | 244.537 | 1.2 | 187.669 | 0.28659 | 0.056 | 19.6 | ug/L |
| Se | 78 | 15029.547 | 2.2 | 13588.495 | 1.70000 | 0.567 | 33.3 | mg/L |
| Se | 82 | 1337.041 | 1.9 | 1139.011 | 0.64522 | 0.097 | 15.1 | ug/L |
| Kr | 83 | 1408.133 | 2.7 | 1141.423 | | | | mg/L |
| Y | 89 | 365299.421 | 2.1 | 354910.360 | | | | ug/L |
| Mo | 95 | 897.391 | 8.2 | 114.335 | 0.15890 | 0.022 | 14.1 | ug/L |
| Mo | 97 | 528.689 | 13.7 | 49.001 | 0.14958 | 0.029 | 19.1 | ug/L |
| Mo | 98 | 1286.539 | 15.0 | 58.127 | 0.14923 | 0.030 | 19.9 | ug/L |
| Rh | 103 | 332619.135 | 3.8 | 323620.727 | | | | ug/L |
| Ag | 107 | 134.002 | 11.6 | 57.001 | 0.00614 | 0.001 | 18.6 | ug/L |
| Ag | 109 | 118.002 | 9.6 | 41.334 | 0.00629 | 0.001 | 16.3 | ug/L |
| Cd | 111 | 192.329 | 7.2 | 233.296 | -0.01213 | 0.007 | 61.2 | ug/L |
| Cd | 114 | 55.622 | 12.6 | 64.652 | -0.00114 | 0.001 | 100.9 | ug/L |
| > In | 115 | 357461.068 | 4.2 | 364581.825 | | | | ug/L |
| Sb | 121 | 835.051 | 12.8 | 51.001 | 0.08429 | 0.015 | 17.8 | ug/L |
| Sb | 123 | 639.749 | 9.4 | 45.100 | 0.08512 | 0.012 | 13.7 | ug/L |
| Ba | 135 | 40.334 | 25.3 | 65.001 | -0.00948 | 0.004 | 44.4 | ug/L |
| Ba | 137 | 56.667 | 8.2 | 74.668 | -0.00393 | 0.001 | 23.0 | ug/L |
| > Tb | 159 | 425928.755 | 2.6 | 439210.410 | | | | ug/L |
| > Ho | 165 | 405528.229 | 2.0 | 425708.154 | | | | ug/L |
| Tl | 203 | 173.004 | 15.4 | 51.001 | 0.01664 | 0.003 | 19.7 | ug/L |
| Tl | 205 | 388.013 | 18.7 | 72.668 | 0.01877 | 0.004 | 22.4 | ug/L |
| Pb | 208 | 398.674 | 10.2 | 767.689 | -0.01405 | 0.002 | 14.8 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Tuesday, November 21, 2006 10:35:35

Page 1

780

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|-----------|
| | Pb | 206 | 111.669 | 17.7 | 194.671 | -0.01182 | 0.003 | 29.6 ug/L |
| | Pb | 207 | 98.335 | 14.8 | 181.671 | -0.01439 | 0.003 | 22.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 98.673 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 103.500 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.047 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 96.976 | | | |
| > Ho | 165 | | 95.260 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 8

Sample Date/Time: Tuesday, November 21, 2006 10:38:32

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 8.012

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 106137.294 | 2.5 | 54.001 | 102.62923 | 2.062 | 2.0 | ug/L |
| Al | 27 | 825138.747 | 1.7 | 9687.584 | 100.66406 | 1.243 | 1.2 | ug/L |
| Sc | 45 | 369305.883 | 0.5 | 378480.621 | | | | ug/L |
| V | 51 | 1467456.748 | 1.7 | 4514.855 | 104.76288 | 1.750 | 1.7 | ug/L |
| Cr | 52 | 1288364.630 | 1.8 | 14908.140 | 104.22570 | 1.548 | 1.5 | ug/L |
| Cr | 53 | 151858.353 | 0.4 | 661.366 | 101.55903 | 0.375 | 0.4 | ug/L |
| Mn | 55 | 1712441.274 | 3.3 | 587.693 | 104.93101 | 2.776 | 2.6 | ug/L |
| Co | 59 | 1472868.836 | 3.1 | 242.339 | 104.42404 | 2.500 | 2.4 | ug/L |
| Ni | 60 | 336738.801 | 2.8 | 623.696 | 107.46727 | 1.733 | 1.6 | ug/L |
| Ni | 62 | 50071.643 | 4.1 | 504.354 | 103.47246 | 3.254 | 3.1 | ug/L |
| Cu | 63 | 764270.731 | 1.2 | 1290.783 | 104.79190 | 1.186 | 1.1 | ug/L |
| Cu | 65 | 376041.377 | 3.6 | 588.027 | 105.82455 | 2.982 | 2.8 | ug/L |
| Zn | 66 | 214205.190 | 2.4 | 2796.188 | 104.48210 | 2.551 | 2.4 | ug/L |
| Zn | 67 | 36981.260 | 1.7 | 500.354 | 106.10259 | 0.166 | 0.2 | ug/L |
| Zn | 68 | 156534.855 | 1.2 | 2052.621 | 105.28813 | 0.551 | 0.5 | ug/L |
| Ge | 72 | 191104.981 | 1.5 | 193550.369 | | | | ug/L |
| As | 75 | 243383.066 | 1.8 | 97.335 | 105.50892 | 0.820 | 0.8 | ug/L |
| Se | 77 | 18033.034 | 2.8 | 187.669 | 106.17781 | 1.738 | 1.6 | ug/L |
| Se | 78 | 72408.419 | 1.4 | 13588.495 | 108.44817 | 3.513 | 3.2 | mg/L |
| Se | 82 | 25821.821 | 1.9 | 1139.011 | 105.37069 | 1.616 | 1.5 | ug/L |
| Kr | 83 | 1310.116 | 2.6 | 1141.423 | | | | mg/L |
| Y | 89 | 361393.665 | 4.2 | 354910.360 | | | | ug/L |
| Mo | 95 | 516668.746 | 2.5 | 114.335 | 107.26394 | 0.959 | 0.9 | ug/L |
| Mo | 97 | 327442.949 | 3.2 | 49.001 | 104.48051 | 2.297 | 2.2 | ug/L |
| Mo | 98 | 820278.524 | 3.9 | 58.127 | 101.97263 | 2.268 | 2.2 | ug/L |
| Rh | 103 | 336297.417 | 3.2 | 323620.727 | | | | ug/L |
| Ag | 107 | 1272436.611 | 1.7 | 57.001 | 103.05820 | 4.017 | 3.9 | ug/L |
| Ag | 109 | 1149670.594 | 0.3 | 41.334 | 95.99178 | 2.978 | 3.1 | ug/L |
| Cd | 111 | 294675.167 | 0.6 | 233.296 | 102.80510 | 2.711 | 2.6 | ug/L |
| Cd | 114 | 648221.418 | 1.8 | 64.652 | 98.98432 | 1.489 | 1.5 | ug/L |
| In | 115 | 347035.964 | 3.1 | 364581.825 | | | | ug/L |
| Sb | 121 | 897782.689 | 2.1 | 51.001 | 98.84386 | 3.005 | 3.0 | ug/L |
| Sb | 123 | 687521.761 | 2.1 | 45.100 | 100.88326 | 1.306 | 1.3 | ug/L |
| Ba | 135 | 235637.852 | 3.2 | 65.001 | 100.56201 | 2.336 | 2.3 | ug/L |
| Ba | 137 | 415477.980 | 0.9 | 74.668 | 105.84967 | 1.148 | 1.1 | ug/L |
| Tb | 159 | 416705.792 | 1.2 | 439210.410 | | | | ug/L |
| Ho | 165 | 396005.221 | 1.4 | 425708.154 | | | | ug/L |
| Tl | 203 | 742525.344 | 2.6 | 51.001 | 101.83633 | 3.344 | 3.3 | ug/L |
| Tl | 205 | 1669837.254 | 2.6 | 72.668 | 100.69564 | 3.780 | 3.8 | ug/L |
| Pb | 208 | 2329959.884 | 2.4 | 767.689 | 100.94955 | 3.407 | 3.4 | ug/L |

Sample ID: QC Std 8

Report Date/Time: Tuesday, November 21, 2006 10:41:34

Page 1

783

| | | | | | | | | |
|---|----|-----|------------|-----|---------|-----------|-------|----------|
| | Pb | 206 | 607702.598 | 3.0 | 194.671 | 100.01872 | 3.872 | 3.9 ug/L |
| L | Pb | 207 | 520624.813 | 0.8 | 181.671 | 102.97431 | 2.303 | 2.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 102.629 | | | | |
| Al | 27 | 100.664 | | | | |
| > Sc | 45 | | 97.576 | | | |
| V | 51 | 104.763 | | | | |
| Cr | 52 | 104.226 | | | | |
| Cr | 53 | 101.559 | | | | |
| Mn | 55 | 104.931 | | | | |
| Co | 59 | 104.424 | | | | |
| Ni | 60 | 107.467 | | | | |
| Ni | 62 | 103.472 | | | | |
| Cu | 63 | 104.792 | | | | |
| Cu | 65 | 105.825 | | | | |
| Zn | 66 | 104.482 | | | | |
| Zn | 67 | 106.103 | | | | |
| Zn | 68 | 105.288 | | | | |
| > Ge | 72 | | 98.737 | | | |
| As | 75 | 105.509 | | | | |
| Se | 77 | 106.178 | | | | |
| Se | 78 | | | | | |
| Se | 82 | 105.371 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 107.264 | | | | |
| Mo | 97 | 104.481 | | | | |
| Mo | 98 | 101.973 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 103.058 | | | | |
| Ag | 109 | 95.992 | | | | |
| Cd | 111 | 102.805 | | | | |
| Cd | 114 | 98.984 | | | | |
| > In | 115 | | 95.187 | | | |
| Sb | 121 | 98.844 | | | | |
| Sb | 123 | 100.883 | | | | |
| Ba | 135 | 100.562 | | | | |
| Ba | 137 | 105.850 | | | | |
| > Tb | 159 | | 94.876 | | | |
| > Ho | 165 | | 93.023 | | | |
| Tl | 203 | 101.836 | | | | |
| Tl | 205 | 100.696 | | | | |
| Pb | 208 | 100.950 | | | | |
| Pb | 206 | 100.019 | | | | |
| Pb | 207 | 102.974 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: PBW-M3990146

Sample Date/Time: Tuesday, November 21, 2006 10:44:30

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\PBW-M3990146.013

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 53.334 | 6.6 | 54.001 | -0.00117 | 0.003 | 259.8 | ug/L |
| Al | 27 | 850437.345 | 1.3 | 9687.584 | 100.19649 | 2.940 | 2.9 | ug/L |
| > Sc | 45 | 382526.931 | 1.9 | 378480.621 | | | | ug/L |
| V | 51 | 4310.676 | 4.7 | 4514.855 | -0.01745 | 0.013 | 74.1 | ug/L |
| Cr | 52 | 15775.748 | 2.3 | 14908.140 | 0.05590 | 0.011 | 20.5 | ug/L |
| Cr | 53 | 1318.451 | 3.3 | 661.366 | 0.42202 | 0.044 | 10.4 | ug/L |
| Mn | 55 | 1094.750 | 2.2 | 587.693 | 0.03050 | 0.002 | 6.4 | ug/L |
| Co | 59 | 363.345 | 0.8 | 242.339 | 0.00840 | 0.000 | 5.3 | ug/L |
| Ni | 60 | 288.008 | 1.9 | 623.696 | -0.10623 | 0.003 | 2.8 | ug/L |
| Ni | 62 | 548.357 | 3.8 | 504.354 | 0.08704 | 0.027 | 31.2 | ug/L |
| Cu | 63 | 639.364 | 1.7 | 1290.783 | -0.08859 | 0.000 | 0.3 | ug/L |
| Cu | 65 | 248.340 | 6.1 | 588.027 | -0.09472 | 0.005 | 5.0 | ug/L |
| Zn | 66 | 1779.208 | 4.4 | 2796.188 | -0.49858 | 0.042 | 8.4 | ug/L |
| Zn | 67 | 391.013 | 1.1 | 500.354 | -0.31718 | 0.020 | 6.3 | ug/L |
| Zn | 68 | 1303.782 | 3.4 | 2052.621 | -0.50637 | 0.031 | 6.2 | ug/L |
| > Ge | 72 | 194135.134 | 1.4 | 193550.369 | | | | ug/L |
| As | 75 | 209.338 | 15.4 | 97.335 | 0.04767 | 0.014 | 28.6 | ug/L |
| Se | 77 | 228.203 | 5.8 | 187.669 | 0.23359 | 0.061 | 25.9 | ug/L |
| Se | 78 | 14708.177 | 1.4 | 13588.495 | 1.95220 | 0.278 | 14.2 | mg/L |
| Se | 82 | 1342.508 | 1.6 | 1139.011 | 0.84069 | 0.105 | 12.5 | ug/L |
| Kr | 83 | 1335.454 | 3.0 | 1141.423 | | | | mg/L |
| Y | 89 | 363095.780 | 1.4 | 354910.360 | | | | ug/L |
| Mo | 95 | 1517.496 | 32.6 | 114.335 | 0.28476 | 0.104 | 36.4 | ug/L |
| Mo | 97 | 897.394 | 33.9 | 49.001 | 0.26446 | 0.098 | 37.0 | ug/L |
| Mo | 98 | 2219.875 | 33.8 | 58.127 | 0.26237 | 0.094 | 35.9 | ug/L |
| Rh | 103 | 329141.177 | 0.6 | 323620.727 | | | | ug/L |
| Ag | 107 | 170.670 | 9.0 | 57.001 | 0.00905 | 0.001 | 11.9 | ug/L |
| Ag | 109 | 135.002 | 3.2 | 41.334 | 0.00768 | 0.000 | 3.1 | ug/L |
| Cd | 111 | 214.595 | 7.9 | 233.296 | -0.00464 | 0.005 | 111.6 | ug/L |
| Cd | 114 | 76.296 | 23.0 | 64.652 | 0.00196 | 0.003 | 138.3 | ug/L |
| > In | 115 | 356574.589 | 1.1 | 364581.825 | | | | ug/L |
| Sb | 121 | 1294.449 | 15.9 | 51.001 | 0.13347 | 0.024 | 17.7 | ug/L |
| Sb | 123 | 971.046 | 15.2 | 45.100 | 0.13249 | 0.022 | 16.9 | ug/L |
| Ba | 135 | 87.001 | 9.4 | 65.001 | 0.01053 | 0.003 | 30.1 | ug/L |
| Ba | 137 | 119.669 | 4.9 | 74.668 | 0.01223 | 0.002 | 14.1 | ug/L |
| > Tb | 159 | 419726.159 | 0.9 | 439210.410 | | | | ug/L |
| > Ho | 165 | 404487.705 | 2.0 | 425708.154 | | | | ug/L |
| Tl | 203 | 73.001 | 14.5 | 51.001 | 0.00330 | 0.001 | 45.2 | ug/L |
| Tl | 205 | 143.669 | 19.5 | 72.668 | 0.00443 | 0.002 | 41.7 | ug/L |
| Pb | 208 | 586.680 | 2.1 | 767.689 | -0.00604 | 0.001 | 16.8 | ug/L |

Sample ID: PBW-M3990146

Report Date/Time: Tuesday, November 21, 2006 10:47:31

Page 1

786

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|-----------|
| | Pb | 206 | 157.670 | 3.9 | 194.671 | -0.00438 | 0.001 | 32.1 ug/L |
| | Pb | 207 | 131.002 | 6.7 | 181.671 | -0.00807 | 0.001 | 15.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 101.069 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 100.302 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 97.804 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 95.564 | | | |
| > Ho | 165 | | 95.015 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| L Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: LCSW-M3990146

Sample Date/Time: Tuesday, November 21, 2006 10:50:28

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\LCSW-M3990146.014

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 21200.158 | 2.8 | 54.001 | 19.30905 | 0.480 | 2.5 | ug/L |
| Al | 27 | 203611.455 | 0.2 | 9687.584 | 22.55358 | 0.150 | 0.7 | ug/L |
| > Sc | 45 | 391245.089 | 0.6 | 378480.621 | | | | ug/L |
| V | 51 | 345028.561 | 1.1 | 4514.855 | 23.00652 | 0.394 | 1.7 | ug/L |
| Cr | 52 | 307198.879 | 0.4 | 14908.140 | 22.53646 | 0.059 | 0.3 | ug/L |
| Cr | 53 | 35450.303 | 2.8 | 661.366 | 22.04059 | 0.609 | 2.8 | ug/L |
| Mn | 55 | 406995.050 | 3.5 | 587.693 | 23.34215 | 0.516 | 2.2 | ug/L |
| Co | 59 | 335800.807 | 1.3 | 242.339 | 22.30629 | 0.617 | 2.8 | ug/L |
| Ni | 60 | 75996.849 | 2.4 | 623.696 | 22.57608 | 0.300 | 1.3 | ug/L |
| Ni | 62 | 11427.277 | 0.7 | 504.354 | 21.31934 | 0.217 | 1.0 | ug/L |
| Cu | 63 | 177627.886 | 2.3 | 1290.783 | 22.69392 | 0.787 | 3.5 | ug/L |
| Cu | 65 | 84871.222 | 1.3 | 588.027 | 22.25887 | 0.297 | 1.3 | ug/L |
| Zn | 66 | 41904.904 | 2.8 | 2796.188 | 18.03846 | 0.319 | 1.8 | ug/L |
| Zn | 67 | 7489.773 | 1.7 | 500.354 | 18.97791 | 0.408 | 2.2 | ug/L |
| Zn | 68 | 31421.115 | 1.5 | 2052.621 | 18.68917 | 0.497 | 2.7 | ug/L |
| > Ge | 72 | 203910.314 | 1.5 | 193550.369 | | | | ug/L |
| As | 75 | 48641.702 | 0.5 | 97.335 | 19.73190 | 0.343 | 1.7 | ug/L |
| Se | 77 | 3353.475 | 1.3 | 187.669 | 17.59743 | 0.142 | 0.8 | ug/L |
| Se | 78 | 26325.121 | 0.7 | 13588.495 | 20.69322 | 0.875 | 4.2 | mg/L |
| Se | 82 | 5690.009 | 1.5 | 1139.011 | 17.95501 | 0.369 | 2.1 | ug/L |
| Kr | 83 | 1426.803 | 1.5 | 1141.423 | | | | mg/L |
| Y | 89 | 392735.812 | 0.6 | 354910.360 | | | | ug/L |
| Mo | 95 | 118363.203 | 2.6 | 114.335 | 22.97671 | 0.679 | 3.0 | ug/L |
| Mo | 97 | 75439.782 | 2.1 | 49.001 | 22.51575 | 0.695 | 3.1 | ug/L |
| Mo | 98 | 187478.485 | 0.7 | 58.127 | 21.80746 | 0.366 | 1.7 | ug/L |
| Rh | 103 | 347820.403 | 3.3 | 323620.727 | | | | ug/L |
| Ag | 107 | 291081.797 | 1.9 | 57.001 | 22.04689 | 0.636 | 2.9 | ug/L |
| Ag | 109 | 267522.939 | 0.3 | 41.334 | 20.88796 | 0.161 | 0.8 | ug/L |
| Cd | 111 | 62481.203 | 1.6 | 233.296 | 20.32745 | 0.425 | 2.1 | ug/L |
| Cd | 114 | 135983.724 | 1.3 | 64.652 | 19.42104 | 0.414 | 2.1 | ug/L |
| > In | 115 | 370843.796 | 1.0 | 364581.825 | | | | ug/L |
| Sb | 121 | 194252.283 | 0.7 | 51.001 | 20.00043 | 0.122 | 0.6 | ug/L |
| Sb | 123 | 148139.016 | 1.8 | 45.100 | 20.33221 | 0.329 | 1.6 | ug/L |
| Ba | 135 | 53548.027 | 0.2 | 65.001 | 22.03895 | 0.404 | 1.8 | ug/L |
| Ba | 137 | 93524.967 | 2.1 | 74.668 | 22.98686 | 0.844 | 3.7 | ug/L |
| > Tb | 159 | 431820.506 | 1.7 | 439210.410 | | | | ug/L |
| > Ho | 165 | 414237.824 | 1.9 | 425708.154 | | | | ug/L |
| Tl | 203 | 165396.930 | 1.9 | 51.001 | 21.68586 | 0.804 | 3.7 | ug/L |
| Tl | 205 | 385505.007 | 2.2 | 72.668 | 22.21449 | 0.363 | 1.6 | ug/L |
| Pb | 208 | 520714.187 | 0.9 | 767.689 | 21.54200 | 0.393 | 1.8 | ug/L |

Sample ID: LCSW-M3990146

Report Date/Time: Tuesday, November 21, 2006 10:53:29

Page 1

789

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 133570.080 | 1.4 | 194.671 | 20.98820 | 0.138 | 0.7 ug/L |
| | Pb | 207 | 113684.720 | 1.1 | 181.671 | 21.47135 | 0.552 | 2.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 103.373 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 105.353 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 101.718 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.317 | | | |
| > [Ho | 165 | | 97.306 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 952000 D.2

Sample Date/Time: Tuesday, November 21, 2006 10:56:25

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\952000 D.2.015

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 73.334 | 11.4 | 54.001 | 0.02033 | 0.007 | 36.0 | ug/L |
| Al | 27 | 232296.244 | 0.7 | 9687.584 | 27.67436 | 0.610 | 2.2 | ug/L |
| Sc | 45 | 367182.240 | 1.6 | 378480.621 | | | | ug/L |
| V | 51 | 10080.661 | 11.4 | 4514.855 | 0.41140 | 0.092 | 22.5 | ug/L |
| Cr | 52 | 24058.256 | 1.5 | 14908.140 | 0.79030 | 0.061 | 7.7 | ug/L |
| Cr | 53 | 22287.942 | 12.0 | 661.366 | 14.63521 | 1.939 | 13.3 | ug/L |
| Mn | 55 | 274303.439 | 1.8 | 587.693 | 18.59657 | 0.214 | 1.2 | ug/L |
| Co | 59 | 10784.753 | 3.2 | 242.339 | 0.83056 | 0.028 | 3.4 | ug/L |
| Ni | 60 | 44109.818 | 6.0 | 623.696 | 15.44174 | 1.128 | 7.3 | ug/L |
| Ni | 62 | 1257.107 | 2.0 | 504.354 | 1.86921 | 0.096 | 5.1 | ug/L |
| Cu | 63 | 364927.997 | 1.6 | 1290.783 | 55.36526 | 1.138 | 2.1 | ug/L |
| Cu | 65 | 175001.270 | 0.9 | 588.027 | 54.50300 | 0.828 | 1.5 | ug/L |
| Zn | 66 | 45933.830 | 3.9 | 2796.188 | 23.78322 | 0.847 | 3.6 | ug/L |
| Zn | 67 | 7802.396 | 0.4 | 500.354 | 23.71026 | 0.526 | 2.2 | ug/L |
| Zn | 68 | 34973.929 | 1.4 | 2052.621 | 25.03085 | 0.593 | 2.4 | ug/L |
| Ge | 72 | 172468.825 | 1.7 | 193550.369 | | | | ug/L |
| As | 75 | 12401.051 | 8.1 | 97.335 | 5.92221 | 0.548 | 9.3 | ug/L |
| Se | 77 | 4452.195 | 8.6 | 187.669 | 28.27397 | 2.868 | 10.1 | ug/L |
| Se | 78 | 13035.997 | 1.2 | 13588.495 | 1.89057 | 0.159 | 8.4 | mg/L |
| Se | 82 | 1421.655 | 1.7 | 1139.011 | 1.92291 | 0.069 | 3.6 | ug/L |
| Kr | 83 | 1336.787 | 3.0 | 1141.423 | | | | mg/L |
| Y | 89 | 335909.449 | 1.0 | 354910.360 | | | | ug/L |
| Mo | 95 | 31689.467 | 1.7 | 114.335 | 7.19576 | 0.093 | 1.3 | ug/L |
| Mo | 97 | 19830.099 | 1.0 | 49.001 | 6.92777 | 0.117 | 1.7 | ug/L |
| Mo | 98 | 51895.959 | 1.0 | 58.127 | 7.07309 | 0.170 | 2.4 | ug/L |
| Rh | 103 | 280652.789 | 1.5 | 323620.727 | | | | ug/L |
| Ag | 107 | 464.018 | 5.6 | 57.001 | 0.03684 | 0.003 | 7.8 | ug/L |
| Ag | 109 | 404.014 | 12.7 | 41.334 | 0.03373 | 0.005 | 14.8 | ug/L |
| Cd | 111 | 240.305 | 17.1 | 233.296 | 0.01456 | 0.016 | 111.6 | ug/L |
| Cd | 114 | 182.287 | 21.2 | 64.652 | 0.02120 | 0.007 | 32.6 | ug/L |
| In | 115 | 316326.220 | 1.5 | 364581.825 | | | | ug/L |
| Sb | 121 | 4212.774 | 1.4 | 51.001 | 0.50330 | 0.005 | 1.0 | ug/L |
| Sb | 123 | 3087.226 | 2.3 | 45.100 | 0.49057 | 0.005 | 1.0 | ug/L |
| Ba | 135 | 55475.606 | 1.0 | 65.001 | 24.43513 | 0.315 | 1.3 | ug/L |
| Ba | 137 | 94900.970 | 1.2 | 74.668 | 24.95512 | 0.201 | 0.8 | ug/L |
| Tb | 159 | 403472.079 | 0.7 | 439210.410 | | | | ug/L |
| Ho | 165 | 387076.892 | 1.9 | 425708.154 | | | | ug/L |
| Tl | 203 | 1024.408 | 19.4 | 51.001 | 0.13689 | 0.025 | 18.4 | ug/L |
| Tl | 205 | 2474.066 | 17.9 | 72.668 | 0.14820 | 0.024 | 16.4 | ug/L |
| Pb | 208 | 2366.820 | 1.9 | 767.689 | 0.07397 | 0.000 | 0.4 | ug/L |

Sample ID: 952000 D.2

Report Date/Time: Tuesday, November 21, 2006 10:59:26

Page 1

792

| | | | | | | | | |
|---|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 637.031 | 2.0 | 194.671 | 0.07748 | 0.003 | 3.2 ug/L |
| L | Pb | 207 | 500.020 | 1.9 | 181.671 | 0.06777 | 0.001 | 1.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 97.015 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 89.108 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 86.764 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 91.863 | | | |
| > [Ho | 165 | | 90.925 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030

Sample Date/Time: Tuesday, November 21, 2006 11:02:23

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950030.016

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 85.001 | 5.1 | 54.001 | 0.01472 | 0.004 | 28.9 | ug/L |
| Al | 27 | 1551253.753 | 0.4 | 9687.584 | 151.70503 | 2.747 | 1.8 | ug/L |
| > Sc | 45 | 462585.975 | 1.6 | 378480.621 | | | | ug/L |
| V | 51 | 9679.722 | 18.4 | 4514.855 | 0.23731 | 0.097 | 40.9 | ug/L |
| Cr | 52 | 132156.575 | 3.7 | 14908.140 | 7.44328 | 0.312 | 4.2 | ug/L |
| Cr | 53 | 19365.342 | 2.2 | 661.366 | 9.95319 | 0.345 | 3.5 | ug/L |
| Mn | 55 | 292805.275 | 4.1 | 587.693 | 16.57069 | 0.390 | 2.4 | ug/L |
| Co | 59 | 8181.096 | 0.8 | 242.339 | 0.52019 | 0.018 | 3.5 | ug/L |
| Ni | 60 | 24664.695 | 0.9 | 623.696 | 7.10524 | 0.249 | 3.5 | ug/L |
| Ni | 62 | 3735.875 | 1.7 | 504.354 | 6.17922 | 0.165 | 2.7 | ug/L |
| Cu | 63 | 7657.928 | 1.9 | 1290.783 | 0.79934 | 0.057 | 7.1 | ug/L |
| Cu | 65 | 3585.141 | 4.0 | 588.027 | 0.77165 | 0.036 | 4.6 | ug/L |
| Zn | 66 | 6487.590 | 2.0 | 2796.188 | 1.60279 | 0.064 | 4.0 | ug/L |
| Zn | 67 | 1566.830 | 2.7 | 500.354 | 2.78530 | 0.272 | 9.8 | ug/L |
| Zn | 68 | 6013.230 | 3.1 | 2052.621 | 2.41072 | 0.074 | 3.1 | ug/L |
| > Ge | 72 | 206580.003 | 3.9 | 193550.369 | | | | ug/L |
| As | 75 | 1195.098 | 11.2 | 97.335 | 0.43966 | 0.073 | 16.6 | ug/L |
| Se | 77 | 476.214 | 8.4 | 187.669 | 1.52699 | 0.326 | 21.3 | ug/L |
| Se | 78 | 15443.879 | 1.2 | 13588.495 | 1.61862 | 0.770 | 47.6 | mg/L |
| Se | 82 | 1451.260 | 2.9 | 1139.011 | 0.93118 | 0.058 | 6.2 | ug/L |
| Kr | 83 | 1444.140 | 1.0 | 1141.423 | | | | mg/L |
| Y | 89 | 409366.125 | 5.3 | 354910.360 | | | | ug/L |
| Mo | 95 | 1378.795 | 3.0 | 114.335 | 0.23857 | 0.008 | 3.3 | ug/L |
| Mo | 97 | 812.714 | 3.4 | 49.001 | 0.22170 | 0.003 | 3.7 | ug/L |
| Mo | 98 | 2099.525 | 4.3 | 58.127 | 0.23128 | 0.011 | 4.8 | ug/L |
| Rh | 103 | 345028.472 | 2.1 | 323620.727 | | | | ug/L |
| Ag | 107 | 91.001 | 11.2 | 57.001 | 0.00233 | 0.001 | 32.2 | ug/L |
| Ag | 109 | 75.001 | 12.7 | 41.334 | 0.00243 | 0.001 | 29.4 | ug/L |
| Cd | 111 | 277.641 | 2.8 | 233.296 | 0.01090 | 0.003 | 26.4 | ug/L |
| Cd | 114 | 187.144 | 42.1 | 64.652 | 0.01666 | 0.011 | 65.6 | ug/L |
| > In | 115 | 380401.737 | 0.4 | 364581.825 | | | | ug/L |
| Sb | 121 | 421.682 | 8.2 | 51.001 | 0.03700 | 0.004 | 9.9 | ug/L |
| Sb | 123 | 337.322 | 7.7 | 45.100 | 0.03886 | 0.004 | 9.5 | ug/L |
| Ba | 135 | 25472.803 | 1.9 | 65.001 | 10.13703 | 0.164 | 1.6 | ug/L |
| Ba | 137 | 43474.577 | 2.2 | 74.668 | 10.33402 | 0.180 | 1.7 | ug/L |
| > Tb | 159 | 445868.385 | 0.6 | 439210.410 | | | | ug/L |
| > Ho | 165 | 437425.655 | 2.3 | 425708.154 | | | | ug/L |
| Tl | 203 | 305.009 | 19.5 | 51.001 | 0.03135 | 0.007 | 22.8 | ug/L |
| Tl | 205 | 682.368 | 14.3 | 72.668 | 0.03317 | 0.005 | 15.9 | ug/L |
| Pb | 208 | 8881.955 | 2.3 | 767.689 | 0.31746 | 0.001 | 0.2 | ug/L |

Sample ID: 950030

Report Date/Time: Tuesday, November 21, 2006 11:05:24

Page 1

795

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 2294.672 | 2.4 | 194.671 | 0.31211 | 0.001 | 0.5 ug/L |
| | Pb | 207 | 1854.892 | 3.8 | 181.671 | 0.29872 | 0.008 | 2.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 122.222 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 106.732 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 104.339 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 101.516 | | | |
| > [Ho | 165 | | 102.752 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030D

Sample Date/Time: Tuesday, November 21, 2006 11:08:20

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950030D.017

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 88.335 | 6.5 | 54.001 | 0.01642 | 0.003 | 20.4 | ug/L |
| Al | 27 | 2001241.484 | 11.2 | 9687.584 | 194.01145 | 25.555 | 13.2 | ug/L |
| > Sc | 45 | 468062.963 | 2.0 | 378480.621 | | | | ug/L |
| V | 51 | 13239.497 | 8.5 | 4514.855 | 0.43279 | 0.066 | 15.1 | ug/L |
| Cr | 52 | 166221.915 | 1.3 | 14908.140 | 9.54558 | 0.354 | 3.7 | ug/L |
| Cr | 53 | 20605.662 | 2.6 | 661.366 | 10.49236 | 0.496 | 4.7 | ug/L |
| Mn | 55 | 304621.092 | 1.1 | 587.693 | 16.50236 | 0.245 | 1.5 | ug/L |
| Co | 59 | 8589.178 | 2.2 | 242.339 | 0.52258 | 0.019 | 3.6 | ug/L |
| Ni | 60 | 27446.095 | 3.2 | 623.696 | 7.57528 | 0.246 | 3.2 | ug/L |
| Ni | 62 | 4109.055 | 3.6 | 504.354 | 6.55663 | 0.250 | 3.8 | ug/L |
| Cu | 63 | 7988.240 | 0.7 | 1290.783 | 0.79666 | 0.020 | 2.5 | ug/L |
| Cu | 65 | 3981.658 | 2.2 | 588.027 | 0.83027 | 0.019 | 2.3 | ug/L |
| Zn | 66 | 7175.160 | 2.2 | 2796.188 | 1.77532 | 0.048 | 2.7 | ug/L |
| Zn | 67 | 1512.819 | 2.7 | 500.354 | 2.45963 | 0.115 | 4.7 | ug/L |
| Zn | 68 | 6631.373 | 3.9 | 2052.621 | 2.61948 | 0.091 | 3.5 | ug/L |
| > Ge | 72 | 215811.515 | 1.9 | 193550.369 | | | | ug/L |
| As | 75 | 935.395 | 1.9 | 97.335 | 0.31765 | 0.011 | 3.5 | ug/L |
| Se | 77 | 375.742 | 4.4 | 187.669 | 0.87870 | 0.124 | 14.1 | ug/L |
| Se | 78 | 15979.470 | 2.8 | 13588.495 | 1.35223 | 0.814 | 60.2 | mg/L |
| Se | 82 | 1530.607 | 0.7 | 1139.011 | 0.98597 | 0.122 | 12.4 | ug/L |
| Kr | 83 | 1425.470 | 2.1 | 1141.423 | | | | mg/L |
| Y | 89 | 431014.053 | 1.1 | 354910.360 | | | | ug/L |
| Mo | 95 | 1340.121 | 3.5 | 114.335 | 0.22836 | 0.011 | 5.0 | ug/L |
| Mo | 97 | 817.715 | 5.5 | 49.001 | 0.22044 | 0.014 | 6.5 | ug/L |
| Mo | 98 | 2050.362 | 3.9 | 58.127 | 0.22312 | 0.013 | 6.0 | ug/L |
| Rh | 103 | 360904.331 | 0.8 | 323620.727 | | | | ug/L |
| Ag | 107 | 100.668 | 10.5 | 57.001 | 0.00296 | 0.001 | 27.0 | ug/L |
| Ag | 109 | 76.668 | 5.4 | 41.334 | 0.00248 | 0.000 | 10.5 | ug/L |
| Cd | 111 | 280.101 | 5.0 | 233.296 | 0.01060 | 0.003 | 27.3 | ug/L |
| Cd | 114 | 221.135 | 34.3 | 64.652 | 0.02113 | 0.011 | 51.4 | ug/L |
| > In | 115 | 384912.402 | 2.0 | 364581.825 | | | | ug/L |
| Sb | 121 | 396.347 | 2.5 | 51.001 | 0.03399 | 0.001 | 2.5 | ug/L |
| Sb | 123 | 290.168 | 8.3 | 45.100 | 0.03211 | 0.004 | 11.3 | ug/L |
| Ba | 135 | 25583.802 | 0.7 | 65.001 | 9.82403 | 0.060 | 0.6 | ug/L |
| Ba | 137 | 43709.114 | 1.4 | 74.668 | 10.02634 | 0.188 | 1.9 | ug/L |
| > Tb | 159 | 462058.219 | 0.7 | 439210.410 | | | | ug/L |
| > Ho | 165 | 442464.891 | 2.0 | 425708.154 | | | | ug/L |
| Tl | 203 | 214.672 | 5.4 | 51.001 | 0.01983 | 0.001 | 4.7 | ug/L |
| Tl | 205 | 483.019 | 3.3 | 72.668 | 0.02198 | 0.000 | 1.6 | ug/L |
| Pb | 208 | 8938.979 | 0.4 | 767.689 | 0.31580 | 0.008 | 2.5 | ug/L |

Sample ID: 950030D

Report Date/Time: Tuesday, November 21, 2006 11:11:21

Page 1

798

| | | | | | | | | |
|---|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 2274.333 | 1.4 | 194.671 | 0.30535 | 0.011 | 3.5 ug/L |
| L | Pb | 207 | 1896.235 | 2.1 | 181.671 | 0.30246 | 0.013 | 4.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 123.669 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 111.501 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 105.576 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 105.202 | | | |
| > [Ho | 165 | | 103.936 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030S

Sample Date/Time: Tuesday, November 21, 2006 11:14:18

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950030S.018

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 21921.360 | 2.6 | 54.001 | 16.37847 | 0.653 | 4.0 | ug/L |
| Al | 27 | 2637761.833 | 0.5 | 9687.584 | 250.94409 | 2.580 | 1.0 | ug/L |
| Sc | 45 | 476912.362 | 1.4 | 378480.621 | | | | ug/L |
| V | 51 | 354214.974 | 2.1 | 4514.855 | 19.33032 | 0.625 | 3.2 | ug/L |
| Cr | 52 | 443937.101 | 1.0 | 14908.140 | 26.93952 | 0.194 | 0.7 | ug/L |
| Cr | 53 | 55111.866 | 1.0 | 661.366 | 28.23556 | 0.666 | 2.4 | ug/L |
| Mn | 55 | 714939.631 | 0.9 | 587.693 | 38.74911 | 0.253 | 0.7 | ug/L |
| Co | 59 | 347143.152 | 1.0 | 242.339 | 21.77017 | 0.362 | 1.7 | ug/L |
| Ni | 60 | 100423.505 | 1.0 | 623.696 | 28.22135 | 0.309 | 1.1 | ug/L |
| Ni | 62 | 14791.265 | 1.5 | 504.354 | 26.29188 | 0.764 | 2.9 | ug/L |
| Cu | 63 | 188020.393 | 1.8 | 1290.783 | 22.67995 | 0.623 | 2.7 | ug/L |
| Cu | 65 | 88068.904 | 1.9 | 588.027 | 21.80689 | 0.489 | 2.2 | ug/L |
| Zn | 66 | 47920.935 | 2.7 | 2796.188 | 19.59313 | 0.716 | 3.7 | ug/L |
| Zn | 67 | 8370.287 | 2.3 | 500.354 | 20.11023 | 0.779 | 3.9 | ug/L |
| Zn | 68 | 36415.128 | 2.8 | 2052.621 | 20.57793 | 0.558 | 2.7 | ug/L |
| Ge | 72 | 215953.511 | 1.4 | 193550.369 | | | | ug/L |
| As | 75 | 51930.507 | 1.3 | 97.335 | 19.89074 | 0.372 | 1.9 | ug/L |
| Se | 77 | 3788.461 | 0.5 | 187.669 | 18.84581 | 0.187 | 1.0 | ug/L |
| Se | 78 | 26501.642 | 2.2 | 13588.495 | 18.45596 | 1.489 | 8.1 | mg/L |
| Se | 82 | 6271.359 | 0.7 | 1139.011 | 18.88112 | 0.230 | 1.2 | ug/L |
| Kr | 83 | 1472.478 | 4.1 | 1141.423 | | | | mg/L |
| Y | 89 | 428236.384 | 4.3 | 354910.360 | | | | ug/L |
| Mo | 95 | 123670.240 | 1.4 | 114.335 | 23.09589 | 0.984 | 4.3 | ug/L |
| Mo | 97 | 78238.543 | 2.9 | 49.001 | 22.46740 | 1.256 | 5.6 | ug/L |
| Mo | 98 | 205193.407 | 0.2 | 58.127 | 22.95740 | 0.713 | 3.1 | ug/L |
| Rh | 103 | 343960.482 | 1.3 | 323620.727 | | | | ug/L |
| Ag | 107 | 285125.443 | 2.0 | 57.001 | 20.76559 | 0.574 | 2.8 | ug/L |
| Ag | 109 | 274190.570 | 2.7 | 41.334 | 20.58339 | 0.365 | 1.8 | ug/L |
| Cd | 111 | 61281.331 | 0.8 | 233.296 | 19.17207 | 0.613 | 3.2 | ug/L |
| Cd | 114 | 142862.879 | 1.7 | 64.652 | 19.63034 | 0.913 | 4.7 | ug/L |
| In | 115 | 385746.209 | 2.9 | 364581.825 | | | | ug/L |
| Sb | 121 | 204206.422 | 1.5 | 51.001 | 20.22191 | 0.561 | 2.8 | ug/L |
| Sb | 123 | 150586.896 | 1.8 | 45.100 | 19.87559 | 0.423 | 2.1 | ug/L |
| Ba | 135 | 80130.556 | 0.8 | 65.001 | 31.81984 | 0.376 | 1.2 | ug/L |
| Ba | 137 | 136310.668 | 1.6 | 74.668 | 32.31161 | 0.389 | 1.2 | ug/L |
| Tb | 159 | 447645.925 | 0.5 | 439210.410 | | | | ug/L |
| Ho | 165 | 434233.250 | 1.3 | 425708.154 | | | | ug/L |
| Tl | 203 | 163968.560 | 1.3 | 51.001 | 20.50029 | 0.289 | 1.4 | ug/L |
| Tl | 205 | 386218.777 | 0.5 | 72.668 | 21.23255 | 0.358 | 1.7 | ug/L |
| Pb | 208 | 532393.902 | 2.2 | 767.689 | 21.00971 | 0.608 | 2.9 | ug/L |

Sample ID: 950030S

Report Date/Time: Tuesday, November 21, 2006 11:17:19

Page 1

801

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 139183.464 | 0.8 | 194.671 | 20.86411 | 0.336 | 1.6 ug/L |
| | Pb | 207 | 112534.604 | 1.2 | 181.671 | 20.26987 | 0.368 | 1.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 126.007 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 111.575 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 105.805 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 101.921 | | | |
| > Ho | 165 | | 102.003 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030A

Sample Date/Time: Tuesday, November 21, 2006 11:20:15

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950030A.019

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 22789.013 | 0.6 | 54.001 | 17.28982 | 0.369 | 2.1 | ug/L |
| Al | 27 | 1768329.308 | 2.3 | 9687.584 | 170.53260 | 7.485 | 4.4 | ug/L |
| Sc | 45 | 469694.482 | 2.1 | 378480.621 | | | | ug/L |
| V | 51 | 375869.076 | 1.5 | 4514.855 | 20.84833 | 0.159 | 0.8 | ug/L |
| Cr | 52 | 425078.323 | 1.6 | 14908.140 | 26.16335 | 0.598 | 2.3 | ug/L |
| Cr | 53 | 52020.768 | 2.2 | 661.366 | 27.03905 | 0.385 | 1.4 | ug/L |
| Mn | 55 | 706015.404 | 1.4 | 587.693 | 38.53688 | 1.275 | 3.3 | ug/L |
| Co | 59 | 351076.178 | 0.3 | 242.339 | 22.17038 | 0.594 | 2.7 | ug/L |
| Ni | 60 | 103972.059 | 1.6 | 623.696 | 29.43487 | 1.054 | 3.6 | ug/L |
| Ni | 62 | 14644.009 | 2.9 | 504.354 | 26.19292 | 0.416 | 1.6 | ug/L |
| Cu | 63 | 185286.458 | 0.8 | 1290.783 | 22.50049 | 0.503 | 2.2 | ug/L |
| Cu | 65 | 90862.237 | 3.2 | 588.027 | 22.67243 | 1.280 | 5.6 | ug/L |
| Zn | 66 | 47192.054 | 0.4 | 2796.188 | 19.41783 | 0.640 | 3.3 | ug/L |
| Zn | 67 | 8852.791 | 3.2 | 500.354 | 21.49377 | 0.189 | 0.9 | ug/L |
| Zn | 68 | 38250.308 | 1.2 | 2052.621 | 21.85247 | 0.894 | 4.1 | ug/L |
| Ge | 72 | 214538.288 | 2.7 | 193550.369 | | | | ug/L |
| As | 75 | 54767.329 | 2.4 | 97.335 | 21.11695 | 0.126 | 0.6 | ug/L |
| Se | 77 | 3901.313 | 0.1 | 187.669 | 19.58436 | 0.579 | 3.0 | ug/L |
| Se | 78 | 27949.291 | 1.0 | 13588.495 | 21.12525 | 1.552 | 7.3 | mg/L |
| Se | 82 | 6451.030 | 1.8 | 1139.011 | 19.72272 | 0.249 | 1.3 | ug/L |
| Kr | 83 | 1464.143 | 4.8 | 1141.423 | | | | mg/L |
| Y | 89 | 429840.232 | 1.0 | 354910.360 | | | | ug/L |
| Mo | 95 | 129538.088 | 2.6 | 114.335 | 24.22533 | 0.423 | 1.7 | ug/L |
| Mo | 97 | 81791.703 | 4.2 | 49.001 | 23.52264 | 1.148 | 4.9 | ug/L |
| Mo | 98 | 203072.460 | 2.0 | 58.127 | 22.76159 | 0.667 | 2.9 | ug/L |
| Rh | 103 | 357056.681 | 3.6 | 323620.727 | | | | ug/L |
| Ag | 107 | 302216.430 | 3.2 | 57.001 | 22.05544 | 0.875 | 4.0 | ug/L |
| Ag | 109 | 278753.268 | 1.1 | 41.334 | 20.97168 | 0.356 | 1.7 | ug/L |
| Cd | 111 | 65073.787 | 2.0 | 233.296 | 20.39836 | 0.452 | 2.2 | ug/L |
| Cd | 114 | 143223.907 | 0.6 | 64.652 | 19.70807 | 0.260 | 1.3 | ug/L |
| In | 115 | 384884.280 | 1.0 | 364581.825 | | | | ug/L |
| Sb | 121 | 205648.588 | 0.2 | 51.001 | 20.40198 | 0.163 | 0.8 | ug/L |
| Sb | 123 | 158785.762 | 0.8 | 45.100 | 20.99946 | 0.237 | 1.1 | ug/L |
| Ba | 135 | 80075.721 | 1.2 | 65.001 | 31.84663 | 0.736 | 2.3 | ug/L |
| Ba | 137 | 140245.077 | 1.0 | 74.668 | 33.29492 | 0.506 | 1.5 | ug/L |
| Tb | 159 | 447032.437 | 1.3 | 439210.410 | | | | ug/L |
| Ho | 165 | 423418.574 | 0.7 | 425708.154 | | | | ug/L |
| Tl | 203 | 168357.420 | 1.0 | 51.001 | 21.58544 | 0.118 | 0.5 | ug/L |
| Tl | 205 | 388838.358 | 0.8 | 72.668 | 21.91997 | 0.173 | 0.8 | ug/L |
| Pb | 208 | 539239.940 | 1.1 | 767.689 | 21.82201 | 0.347 | 1.6 | ug/L |

Sample ID: 950030A

Report Date/Time: Tuesday, November 21, 2006 11:23:16

Page 1

804

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 137543.340 | 2.6 | 194.671 | 21.14112 | 0.426 | 2.0 ug/L |
| | Pb | 207 | 116484.399 | 1.4 | 181.671 | 21.51824 | 0.411 | 1.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 124.100 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 110.844 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 105.569 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 101.781 | | | |
| > Ho | 165 | | 99.462 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030L

Sample Date/Time: Tuesday, November 21, 2006 11:26:13

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950030L.020

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 70.001 | 21.0 | 54.001 | 0.01141 | 0.013 | 111.8 | ug/L |
| Al | 27 | 326247.661 | 1.1 | 9687.584 | 35.96115 | 0.316 | 0.9 | ug/L |
| > Sc | 45 | 400501.500 | 0.8 | 378480.621 | | | | ug/L |
| V | 51 | 5418.786 | 5.4 | 4514.855 | 0.04227 | 0.017 | 39.9 | ug/L |
| Cr | 52 | 38379.564 | 0.9 | 14908.140 | 1.70546 | 0.003 | 0.2 | ug/L |
| Cr | 53 | 4538.282 | 4.2 | 661.366 | 2.37788 | 0.140 | 5.9 | ug/L |
| Mn | 55 | 61421.831 | 1.3 | 587.693 | 3.41387 | 0.088 | 2.6 | ug/L |
| Co | 59 | 1731.197 | 1.2 | 242.339 | 0.09550 | 0.003 | 2.7 | ug/L |
| Ni | 60 | 5172.990 | 1.1 | 623.696 | 1.31919 | 0.067 | 5.1 | ug/L |
| Ni | 62 | 879.055 | 2.5 | 504.354 | 0.64124 | 0.031 | 4.9 | ug/L |
| Cu | 63 | 1859.559 | 1.8 | 1290.783 | 0.05891 | 0.005 | 7.8 | ug/L |
| Cu | 65 | 1008.405 | 4.7 | 588.027 | 0.09711 | 0.021 | 21.9 | ug/L |
| Zn | 66 | 2006.928 | 2.4 | 2796.188 | -0.45532 | 0.042 | 9.2 | ug/L |
| Zn | 67 | 481.685 | 1.5 | 500.354 | -0.15265 | 0.062 | 40.8 | ug/L |
| Zn | 68 | 1744.200 | 1.8 | 2052.621 | -0.29226 | 0.023 | 8.0 | ug/L |
| > Ge | 72 | 208714.180 | 3.5 | 193550.369 | | | | ug/L |
| As | 75 | 320.676 | 5.0 | 97.335 | 0.08572 | 0.007 | 7.7 | ug/L |
| Se | 77 | 253.604 | 1.2 | 187.669 | 0.27988 | 0.034 | 12.1 | ug/L |
| Se | 78 | 14864.637 | 1.5 | 13588.495 | 0.38035 | 1.096 | 288.2 | mg/L |
| Se | 82 | 1426.189 | 0.4 | 1139.011 | 0.77818 | 0.210 | 27.0 | ug/L |
| Kr | 83 | 1439.139 | 1.1 | 1141.423 | | | | mg/L |
| Y | 89 | 393262.336 | 3.1 | 354910.360 | | | | ug/L |
| Mo | 95 | 392.013 | 12.3 | 114.335 | 0.05537 | 0.010 | 18.6 | ug/L |
| Mo | 97 | 211.671 | 4.9 | 49.001 | 0.04979 | 0.004 | 7.4 | ug/L |
| Mo | 98 | 476.554 | 5.9 | 58.127 | 0.04985 | 0.004 | 7.7 | ug/L |
| Rh | 103 | 350423.349 | 2.2 | 323620.727 | | | | ug/L |
| Ag | 107 | 94.668 | 6.5 | 57.001 | 0.00295 | 0.001 | 18.6 | ug/L |
| Ag | 109 | 75.334 | 6.5 | 41.334 | 0.00274 | 0.000 | 16.2 | ug/L |
| Cd | 111 | 216.857 | 2.0 | 233.296 | -0.00505 | 0.002 | 39.7 | ug/L |
| Cd | 114 | 109.523 | 20.2 | 64.652 | 0.00663 | 0.003 | 51.1 | ug/L |
| > In | 115 | 362572.447 | 1.0 | 364581.825 | | | | ug/L |
| Sb | 121 | 381.013 | 9.2 | 51.001 | 0.03482 | 0.004 | 11.8 | ug/L |
| Sb | 123 | 271.737 | 8.2 | 45.100 | 0.03187 | 0.003 | 10.6 | ug/L |
| Ba | 135 | 4982.207 | 3.6 | 65.001 | 1.97726 | 0.055 | 2.8 | ug/L |
| Ba | 137 | 8395.645 | 1.8 | 74.668 | 1.99801 | 0.071 | 3.5 | ug/L |
| > Tb | 159 | 442338.784 | 1.9 | 439210.410 | | | | ug/L |
| > Ho | 165 | 417037.797 | 2.2 | 425708.154 | | | | ug/L |
| Tl | 203 | 89.335 | 15.4 | 51.001 | 0.00511 | 0.002 | 30.2 | ug/L |
| Tl | 205 | 161.670 | 14.2 | 72.668 | 0.00518 | 0.001 | 25.0 | ug/L |
| Pb | 208 | 2336.150 | 3.0 | 767.689 | 0.06520 | 0.003 | 5.3 | ug/L |

Sample ID: 950030L

Report Date/Time: Tuesday, November 21, 2006 11:29:14

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|-----------|
| | Pb | 206 | 600.028 | 4.0 | 194.671 | 0.06397 | 0.003 | 5.0 ug/L |
| | Pb | 207 | 515.021 | 9.9 | 181.671 | 0.06341 | 0.011 | 16.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 105.818 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 107.835 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 99.449 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 100.712 | | | |
| > [Ho | 165 | | 97.963 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950031

Sample Date/Time: Tuesday, November 21, 2006 11:32:11

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950031.021

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 121.002 | 8.6 | 54.001 | 0.03996 | 0.007 | 17.5 | ug/L |
| Al | 27 | 6924219.820 | 0.7 | 9687.584 | 663.05424 | 10.623 | 1.6 | ug/L |
| > Sc | 45 | 475195.689 | 1.4 | 378480.621 | | | | ug/L |
| V | 51 | 30971.759 | 20.3 | 4514.855 | 1.40860 | 0.350 | 24.9 | ug/L |
| Cr | 52 | 524095.795 | 3.0 | 14908.140 | 32.14222 | 1.120 | 3.5 | ug/L |
| Cr | 53 | 60148.069 | 3.6 | 661.366 | 30.97342 | 1.481 | 4.8 | ug/L |
| Mn | 55 | 811751.620 | 1.3 | 587.693 | 43.91230 | 0.775 | 1.8 | ug/L |
| Co | 59 | 29374.986 | 1.8 | 242.339 | 1.82274 | 0.036 | 2.0 | ug/L |
| Ni | 60 | 84755.642 | 3.3 | 623.696 | 23.73621 | 0.721 | 3.0 | ug/L |
| Ni | 62 | 11461.324 | 0.7 | 504.354 | 20.09052 | 0.067 | 0.3 | ug/L |
| Cu | 63 | 25112.378 | 2.3 | 1290.783 | 2.87071 | 0.067 | 2.3 | ug/L |
| Cu | 65 | 12495.826 | 3.2 | 588.027 | 2.94675 | 0.083 | 2.8 | ug/L |
| Zn | 66 | 12191.033 | 0.8 | 2796.188 | 3.95550 | 0.040 | 1.0 | ug/L |
| Zn | 67 | 2339.685 | 1.8 | 500.354 | 4.57246 | 0.136 | 3.0 | ug/L |
| Zn | 68 | 10773.402 | 1.8 | 2052.621 | 5.10270 | 0.145 | 2.8 | ug/L |
| > Ge | 72 | 216391.695 | 0.5 | 193550.369 | | | | ug/L |
| As | 75 | 2728.807 | 2.2 | 97.335 | 1.00341 | 0.018 | 1.8 | ug/L |
| Se | 77 | 401.676 | 1.2 | 187.669 | 1.00813 | 0.025 | 2.5 | ug/L |
| Se | 78 | 16301.251 | 1.6 | 13588.495 | 1.79940 | 0.303 | 16.9 | mg/L |
| Se | 82 | 1651.364 | 1.8 | 1139.011 | 1.42444 | 0.140 | 9.8 | ug/L |
| Kr | 83 | 1540.825 | 1.9 | 1141.423 | | | | mg/L |
| Y | 89 | 451917.358 | 2.2 | 354910.360 | | | | ug/L |
| Mo | 95 | 9042.997 | 3.1 | 114.335 | 1.69807 | 0.026 | 1.5 | ug/L |
| Mo | 97 | 5734.364 | 2.6 | 49.001 | 1.66274 | 0.059 | 3.6 | ug/L |
| Mo | 98 | 14595.434 | 3.7 | 58.127 | 1.65586 | 0.020 | 1.2 | ug/L |
| Rh | 103 | 360638.321 | 2.5 | 323620.727 | | | | ug/L |
| Ag | 107 | 141.669 | 8.8 | 57.001 | 0.00613 | 0.001 | 18.3 | ug/L |
| Ag | 109 | 104.335 | 8.4 | 41.334 | 0.00470 | 0.001 | 15.2 | ug/L |
| Cd | 111 | 347.692 | 6.2 | 233.296 | 0.03384 | 0.009 | 27.0 | ug/L |
| Cd | 114 | 276.146 | 29.1 | 64.652 | 0.02918 | 0.011 | 36.8 | ug/L |
| > In | 115 | 378651.249 | 2.5 | 364581.825 | | | | ug/L |
| Sb | 121 | 722.372 | 4.8 | 51.001 | 0.06750 | 0.002 | 3.3 | ug/L |
| Sb | 123 | 549.881 | 4.7 | 45.100 | 0.06767 | 0.004 | 5.8 | ug/L |
| Ba | 135 | 37107.814 | 1.2 | 65.001 | 14.48622 | 0.259 | 1.8 | ug/L |
| Ba | 137 | 64669.699 | 2.4 | 74.668 | 15.08165 | 0.638 | 4.2 | ug/L |
| > Tb | 159 | 454968.047 | 1.9 | 439210.410 | | | | ug/L |
| > Ho | 165 | 426375.226 | 1.8 | 425708.154 | | | | ug/L |
| Tl | 203 | 415.681 | 3.4 | 51.001 | 0.04643 | 0.001 | 2.7 | ug/L |
| Tl | 205 | 937.396 | 6.8 | 72.668 | 0.04838 | 0.003 | 5.6 | ug/L |
| Pb | 208 | 35135.165 | 2.3 | 767.689 | 1.38294 | 0.018 | 1.3 | ug/L |

Sample ID: 950031

Report Date/Time: Tuesday, November 21, 2006 11:35:13

Page 1

810

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 9045.999 | 2.3 | 194.671 | 1.35308 | 0.025 | 1.9 ug/L |
| | Pb | 207 | 7648.920 | 2.4 | 181.671 | 1.37224 | 0.046 | 3.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 125.554 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 111.801 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 103.859 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 103.588 | | | |
| > Ho | 165 | | 100.157 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Tuesday, November 21, 2006 11:38:10

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 6.022

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55173.986 | 2.1 | 54.001 | 52.11732 | 1.308 | 2.5 | ug/L |
| Al | 27 | 440750.974 | 3.5 | 9687.584 | 51.97669 | 1.124 | 2.2 | ug/L |
| > Sc | 45 | 377951.029 | 1.9 | 378480.621 | | | | ug/L |
| V | 51 | 784125.687 | 1.2 | 4514.855 | 54.55246 | 0.400 | 0.7 | ug/L |
| Cr | 52 | 665311.130 | 0.4 | 14908.140 | 52.01656 | 1.126 | 2.2 | ug/L |
| Cr | 53 | 80537.116 | 0.7 | 661.366 | 52.43448 | 1.197 | 2.3 | ug/L |
| Mn | 55 | 918833.460 | 1.8 | 587.693 | 54.30764 | 0.796 | 1.5 | ug/L |
| Co | 59 | 780365.013 | 2.3 | 242.339 | 53.37707 | 1.286 | 2.4 | ug/L |
| Ni | 60 | 173046.933 | 4.5 | 623.696 | 53.19648 | 2.534 | 4.8 | ug/L |
| Ni | 62 | 25517.264 | 0.5 | 504.354 | 50.35874 | 0.565 | 1.1 | ug/L |
| Cu | 63 | 409867.224 | 2.1 | 1290.783 | 54.13634 | 1.196 | 2.2 | ug/L |
| Cu | 65 | 193015.191 | 2.5 | 588.027 | 52.33188 | 1.380 | 2.6 | ug/L |
| Zn | 66 | 110233.818 | 1.4 | 2796.188 | 51.18939 | 0.914 | 1.8 | ug/L |
| Zn | 67 | 19421.135 | 1.6 | 500.354 | 53.05938 | 1.196 | 2.3 | ug/L |
| Zn | 68 | 77855.440 | 0.2 | 2052.621 | 49.80719 | 0.388 | 0.8 | ug/L |
| > Ge | 72 | 198067.551 | 0.6 | 193550.369 | | | | ug/L |
| As | 75 | 127440.663 | 2.3 | 97.335 | 53.28247 | 1.024 | 1.9 | ug/L |
| Se | 77 | 9497.544 | 1.9 | 187.669 | 53.42341 | 1.334 | 2.5 | ug/L |
| Se | 78 | 43792.484 | 0.2 | 13588.495 | 52.99764 | 0.423 | 0.8 | mg/L |
| Se | 82 | 14033.941 | 0.7 | 1139.011 | 52.97288 | 0.557 | 1.1 | ug/L |
| Kr | 83 | 1365.792 | 3.6 | 1141.423 | | | | mg/L |
| Y | 89 | 367738.309 | 2.4 | 354910.360 | | | | ug/L |
| Mo | 95 | 271191.098 | 2.0 | 114.335 | 54.21739 | 0.808 | 1.5 | ug/L |
| Mo | 97 | 167580.127 | 2.3 | 49.001 | 51.50865 | 1.730 | 3.4 | ug/L |
| Mo | 98 | 431749.300 | 0.4 | 58.127 | 51.71568 | 1.312 | 2.5 | ug/L |
| Rh | 103 | 323879.516 | 0.5 | 323620.727 | | | | ug/L |
| Ag | 107 | 678076.370 | 3.1 | 57.001 | 52.85657 | 0.941 | 1.8 | ug/L |
| Ag | 109 | 632882.822 | 1.9 | 41.334 | 50.88321 | 1.561 | 3.1 | ug/L |
| Cd | 111 | 153903.085 | 2.2 | 233.296 | 51.65457 | 0.587 | 1.1 | ug/L |
| Cd | 114 | 338784.097 | 0.6 | 64.652 | 49.82520 | 0.985 | 2.0 | ug/L |
| > In | 115 | 360304.981 | 2.5 | 364581.825 | | | | ug/L |
| Sb | 121 | 464347.726 | 2.3 | 51.001 | 49.23072 | 1.447 | 2.9 | ug/L |
| Sb | 123 | 355061.060 | 0.8 | 45.100 | 50.19398 | 1.640 | 3.3 | ug/L |
| Ba | 135 | 126752.301 | 0.5 | 65.001 | 53.52916 | 0.784 | 1.5 | ug/L |
| Ba | 137 | 222912.145 | 1.7 | 74.668 | 56.18665 | 0.661 | 1.2 | ug/L |
| > Tb | 159 | 421090.063 | 1.1 | 439210.410 | | | | ug/L |
| > Ho | 165 | 408058.363 | 0.8 | 425708.154 | | | | ug/L |
| Tl | 203 | 390392.158 | 3.7 | 51.001 | 51.95736 | 2.264 | 4.4 | ug/L |
| Tl | 205 | 900334.640 | 2.4 | 72.668 | 52.67947 | 1.715 | 3.3 | ug/L |
| Pb | 208 | 1244522.460 | 1.7 | 767.689 | 52.30203 | 1.004 | 1.9 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Tuesday, November 21, 2006 11:41:12

Page 1

813

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 325142.433 | 0.8 | 194.671 | 51.90727 | 0.604 | 1.2 ug/L |
| | Pb | 207 | 269596.391 | 2.8 | 181.671 | 51.72368 | 1.555 | 3.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 104.235 | | | | |
| Al | 27 | 103.953 | | | | |
| > Sc | 45 | | 99.860 | | | |
| V | 51 | 109.105 | | | | |
| Cr | 52 | 104.033 | | | | |
| Cr | 53 | 104.869 | | | | |
| Mn | 55 | 108.615 | | | | |
| Co | 59 | 106.754 | | | | |
| Ni | 60 | 106.393 | | | | |
| Ni | 62 | 100.717 | | | | |
| Cu | 63 | 108.273 | | | | |
| Cu | 65 | 104.664 | | | | |
| Zn | 66 | 102.379 | | | | |
| Zn | 67 | 106.119 | | | | |
| Zn | 68 | 99.614 | | | | |
| > Ge | 72 | | 102.334 | | | |
| As | 75 | 106.565 | | | | |
| Se | 77 | 106.847 | | | | |
| Se | 78 | 105.995 | | | | |
| Se | 82 | 105.946 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 108.435 | | | | |
| Mo | 97 | 103.017 | | | | |
| Mo | 98 | 103.431 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 105.713 | | | | |
| Ag | 109 | 101.766 | | | | |
| Cd | 111 | 103.309 | | | | |
| Cd | 114 | 99.650 | | | | |
| > In | 115 | | 98.827 | | | |
| Sb | 121 | 98.461 | | | | |
| Sb | 123 | 100.388 | | | | |
| Ba | 135 | 107.058 | | | | |
| Ba | 137 | 112.373 | | | | |
| > Tb | 159 | | 95.874 | | | |
| > Ho | 165 | | 95.854 | | | |
| Tl | 203 | 103.915 | | | | |
| Tl | 205 | 105.359 | | | | |
| Pb | 208 | 104.604 | | | | |
| Pb | 206 | 103.815 | | | | |
| Pb | 207 | 103.447 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Tuesday, November 21, 2006 11:44:07

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 7.023

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 56.667 | 17.4 | 54.001 | 0.00257 | 0.011 | 420.6 | ug/L |
| Al | 27 | 3222.989 | 1.6 | 9687.584 | -0.77916 | 0.016 | 2.1 | ug/L |
| > Sc | 45 | 379424.610 | 2.7 | 378480.621 | | | | ug/L |
| V | 51 | 4093.407 | 6.1 | 4514.855 | -0.02993 | 0.021 | 70.7 | ug/L |
| Cr | 52 | 14448.008 | 4.5 | 14908.140 | -0.03843 | 0.076 | 199.0 | ug/L |
| Cr | 53 | 1318.784 | 5.4 | 661.366 | 0.42863 | 0.038 | 9.0 | ug/L |
| Mn | 55 | 546.690 | 4.9 | 587.693 | -0.00375 | 0.001 | 38.7 | ug/L |
| Co | 59 | 177.670 | 5.2 | 242.339 | -0.00500 | 0.001 | 12.0 | ug/L |
| Ni | 60 | 519.021 | 3.5 | 623.696 | -0.03930 | 0.006 | 14.5 | ug/L |
| Ni | 62 | 293.341 | 4.3 | 504.354 | -0.45802 | 0.025 | 5.5 | ug/L |
| Cu | 63 | 842.051 | 1.3 | 1290.783 | -0.06521 | 0.001 | 1.3 | ug/L |
| Cu | 65 | 444.683 | 1.9 | 588.027 | -0.04461 | 0.003 | 6.5 | ug/L |
| Zn | 66 | 1686.854 | 2.1 | 2796.188 | -0.57256 | 0.020 | 3.4 | ug/L |
| Zn | 67 | 367.678 | 1.9 | 500.354 | -0.42131 | 0.014 | 3.4 | ug/L |
| Zn | 68 | 1214.101 | 5.2 | 2052.621 | -0.59547 | 0.037 | 6.3 | ug/L |
| > Ge | 72 | 201237.511 | 0.6 | 193550.369 | | | | ug/L |
| As | 75 | 171.670 | 5.2 | 97.335 | 0.02901 | 0.003 | 11.3 | ug/L |
| Se | 77 | 217.670 | 1.0 | 187.669 | 0.12737 | 0.006 | 4.6 | ug/L |
| Se | 78 | 14028.133 | 1.2 | 13588.495 | -0.17384 | 0.361 | 207.6 | mg/L |
| Se | 82 | 1353.977 | 0.7 | 1139.011 | 0.68775 | 0.045 | 6.5 | ug/L |
| Kr | 83 | 1363.792 | 1.8 | 1141.423 | | | | mg/L |
| Y | 89 | 373310.791 | 0.1 | 354910.360 | | | | ug/L |
| Mo | 95 | 501.687 | 17.1 | 114.335 | 0.07944 | 0.017 | 21.0 | ug/L |
| Mo | 97 | 305.342 | 14.5 | 49.001 | 0.08057 | 0.013 | 16.2 | ug/L |
| Mo | 98 | 693.721 | 18.6 | 58.127 | 0.07761 | 0.015 | 19.5 | ug/L |
| Rh | 103 | 330440.396 | 1.0 | 323620.727 | | | | ug/L |
| Ag | 107 | 133.002 | 3.3 | 57.001 | 0.00616 | 0.000 | 5.9 | ug/L |
| Ag | 109 | 107.002 | 20.1 | 41.334 | 0.00546 | 0.002 | 31.1 | ug/L |
| Cd | 111 | 219.703 | 9.5 | 233.296 | -0.00236 | 0.007 | 281.5 | ug/L |
| Cd | 114 | 51.425 | 15.2 | 64.652 | -0.00169 | 0.001 | 72.5 | ug/L |
| > In | 115 | 353966.299 | 0.8 | 364581.825 | | | | ug/L |
| Sb | 121 | 907.726 | 15.9 | 51.001 | 0.09252 | 0.015 | 16.1 | ug/L |
| Sb | 123 | 657.703 | 17.0 | 45.100 | 0.08823 | 0.015 | 17.5 | ug/L |
| Ba | 135 | 46.667 | 23.9 | 65.001 | -0.00701 | 0.005 | 67.4 | ug/L |
| Ba | 137 | 53.334 | 14.1 | 74.668 | -0.00490 | 0.002 | 35.1 | ug/L |
| > Tb | 159 | 430339.820 | 1.6 | 439210.410 | | | | ug/L |
| > Ho | 165 | 422726.015 | 1.0 | 425708.154 | | | | ug/L |
| Tl | 203 | 89.335 | 13.4 | 51.001 | 0.00496 | 0.001 | 28.5 | ug/L |
| Tl | 205 | 159.670 | 8.3 | 72.668 | 0.00494 | 0.001 | 13.8 | ug/L |
| Pb | 208 | 414.675 | 7.1 | 767.689 | -0.01412 | 0.001 | 7.7 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Tuesday, November 21, 2006 11:47:08

Page 1

816

| | | | | | | | | |
|--|----|-----|---------|-----|---------|----------|-------|----------|
| | Pb | 206 | 115.002 | 5.7 | 194.671 | -0.01208 | 0.001 | 7.1 ug/L |
| | Pb | 207 | 103.002 | 6.7 | 181.671 | -0.01434 | 0.001 | 9.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 100.249 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 103.972 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 97.088 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.980 | | | |
| > Ho | 165 | | 99.299 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950032

Sample Date/Time: Tuesday, November 21, 2006 11:50:05

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950032.024

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1119.420 | 3.0 | 54.001 | 0.78225 | 0.018 | 2.3 | ug/L |
| Al | 27 | 29719929.117 | 1.9 | 9687.584 | 2821.00124 | 37.651 | 1.3 | ug/L |
| > Sc | 45 | 479965.663 | 1.0 | 378480.621 | | | | ug/L |
| V | 51 | 60021.767 | 15.1 | 4514.855 | 2.99249 | 0.507 | 16.9 | ug/L |
| Cr | 52 | 627945.655 | 1.3 | 14908.140 | 38.34855 | 0.789 | 2.1 | ug/L |
| Cr | 53 | 78623.385 | 2.2 | 661.366 | 40.20317 | 1.141 | 2.8 | ug/L |
| Mn | 55 | 11189928.369 | 2.8 | 587.693 | 608.24363 | 29.424 | 4.8 | ug/L |
| Co | 59 | 303825.642 | 1.6 | 242.339 | 19.08263 | 0.550 | 2.9 | ug/L |
| Ni | 60 | 257080.147 | 0.6 | 623.696 | 72.66769 | 1.297 | 1.8 | ug/L |
| Ni | 62 | 39811.656 | 2.9 | 504.354 | 72.66073 | 3.637 | 5.0 | ug/L |
| Cu | 63 | 43963.781 | 1.3 | 1290.783 | 5.17658 | 0.098 | 1.9 | ug/L |
| Cu | 65 | 17572.026 | 2.9 | 588.027 | 4.22872 | 0.217 | 5.1 | ug/L |
| Zn | 66 | 169372.621 | 0.6 | 2796.188 | 72.82210 | 1.840 | 2.5 | ug/L |
| Zn | 67 | 26837.761 | 2.2 | 500.354 | 67.73154 | 1.259 | 1.9 | ug/L |
| Zn | 68 | 122465.903 | 0.9 | 2052.621 | 72.60102 | 2.151 | 3.0 | ug/L |
| > Ge | 72 | 215648.188 | 2.1 | 193550.369 | | | | ug/L |
| As | 75 | 4718.716 | 1.9 | 97.335 | 1.77202 | 0.028 | 1.6 | ug/L |
| Se | 77 | 814.440 | 0.8 | 187.669 | 3.19251 | 0.058 | 1.8 | ug/L |
| Se | 78 | 15881.834 | 1.1 | 13588.495 | 1.21459 | 0.520 | 42.8 | mg/L |
| Se | 82 | 1634.560 | 0.5 | 1139.011 | 1.38414 | 0.159 | 11.5 | ug/L |
| Kr | 83 | 1582.499 | 3.1 | 1141.423 | | | | mg/L |
| Y | 89 | 754422.207 | 1.2 | 354910.360 | | | | ug/L |
| Mo | 95 | 4720.718 | 1.8 | 114.335 | 0.88418 | 0.014 | 1.6 | ug/L |
| Mo | 97 | 2799.498 | 2.0 | 49.001 | 0.81154 | 0.014 | 1.8 | ug/L |
| Mo | 98 | 7256.584 | 0.6 | 58.127 | 0.82780 | 0.004 | 0.5 | ug/L |
| Rh | 103 | 345528.935 | 2.3 | 323620.727 | | | | ug/L |
| Ag | 107 | 287.341 | 4.4 | 57.001 | 0.01713 | 0.001 | 5.6 | ug/L |
| Ag | 109 | 252.673 | 5.8 | 41.334 | 0.01622 | 0.001 | 7.1 | ug/L |
| Cd | 111 | 3806.286 | 4.2 | 233.296 | 1.15143 | 0.054 | 4.7 | ug/L |
| Cd | 114 | 8287.189 | 4.8 | 64.652 | 1.16107 | 0.053 | 4.6 | ug/L |
| > In | 115 | 375097.536 | 0.3 | 364581.825 | | | | ug/L |
| Sb | 121 | 1004.071 | 7.5 | 51.001 | 0.09690 | 0.008 | 8.2 | ug/L |
| Sb | 123 | 746.898 | 10.8 | 45.100 | 0.09510 | 0.011 | 11.8 | ug/L |
| Ba | 135 | 142724.815 | 1.7 | 65.001 | 56.58048 | 1.633 | 2.9 | ug/L |
| Ba | 137 | 242737.434 | 1.5 | 74.668 | 57.43691 | 1.457 | 2.5 | ug/L |
| > Tb | 159 | 448666.938 | 1.5 | 439210.410 | | | | ug/L |
| > Ho | 165 | 439400.206 | 0.8 | 425708.154 | | | | ug/L |
| Tl | 203 | 866.055 | 24.5 | 51.001 | 0.10046 | 0.026 | 25.7 | ug/L |
| Tl | 205 | 1998.933 | 20.2 | 72.668 | 0.10447 | 0.021 | 20.6 | ug/L |
| Pb | 208 | 65017.484 | 1.6 | 767.689 | 2.50829 | 0.062 | 2.5 | ug/L |

Sample ID: 950032

Report Date/Time: Tuesday, November 21, 2006 11:53:07

Page 1

| | | | | | | | | |
|---|----|-----|-----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 17057.952 | 2.6 | 194.671 | 2.50085 | 0.081 | 3.2 ug/L |
| L | Pb | 207 | 13364.846 | 2.2 | 181.671 | 2.34960 | 0.072 | 3.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 126.814 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 111.417 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 102.884 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 102.153 | | | |
| > Ho | 165 | | 103.216 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950033

Sample Date/Time: Tuesday, November 21, 2006 11:56:04

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950033.025

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 70.001 | 11.2 | 54.001 | 0.00615 | 0.007 | 109.3 | ug/L |
| Al | 27 | 312477.640 | 1.5 | 9687.584 | 31.35017 | 0.755 | 2.4 | ug/L |
| > Sc | 45 | 438046.667 | 0.8 | 378480.621 | | | | ug/L |
| V | 51 | 9154.406 | 1.1 | 4514.855 | 0.23724 | 0.010 | 4.4 | ug/L |
| Cr | 52 | 31916.333 | 1.7 | 14908.140 | 1.01174 | 0.056 | 5.6 | ug/L |
| Cr | 53 | 3652.504 | 2.9 | 661.366 | 1.63456 | 0.047 | 2.8 | ug/L |
| Mn | 55 | 3193518.368 | 1.0 | 587.693 | 181.64713 | 3.472 | 1.9 | ug/L |
| Co | 59 | 6357.489 | 2.7 | 242.339 | 0.40145 | 0.013 | 3.3 | ug/L |
| Ni | 60 | 16937.376 | 3.2 | 623.696 | 4.83017 | 0.210 | 4.3 | ug/L |
| Ni | 62 | 971.400 | 0.5 | 504.354 | 0.84240 | 0.028 | 3.3 | ug/L |
| Cu | 63 | 9967.724 | 0.5 | 1290.783 | 1.09536 | 0.014 | 1.3 | ug/L |
| Cu | 65 | 4645.675 | 2.2 | 588.027 | 1.05179 | 0.039 | 3.7 | ug/L |
| Zn | 66 | 5696.004 | 2.5 | 2796.188 | 1.24729 | 0.045 | 3.6 | ug/L |
| Zn | 67 | 1604.171 | 3.2 | 500.354 | 2.89366 | 0.191 | 6.6 | ug/L |
| Zn | 68 | 6714.110 | 5.8 | 2052.621 | 2.86379 | 0.221 | 7.7 | ug/L |
| > Ge | 72 | 205940.895 | 1.2 | 193550.369 | | | | ug/L |
| As | 75 | 1184.763 | 3.8 | 97.335 | 0.43514 | 0.018 | 4.2 | ug/L |
| Se | 77 | 335.607 | 4.3 | 187.669 | 0.75024 | 0.069 | 9.2 | ug/L |
| Se | 78 | 15317.952 | 0.5 | 13588.495 | 1.46750 | 0.222 | 15.1 | mg/L |
| Se | 82 | 1557.879 | 1.3 | 1139.011 | 1.36988 | 0.079 | 5.8 | ug/L |
| Kr | 83 | 1488.815 | 2.5 | 1141.423 | | | | mg/L |
| Y | 89 | 417139.479 | 0.7 | 354910.360 | | | | ug/L |
| Mo | 95 | 12615.671 | 2.2 | 114.335 | 2.38327 | 0.030 | 1.3 | ug/L |
| Mo | 97 | 7943.865 | 2.1 | 49.001 | 2.31553 | 0.126 | 5.4 | ug/L |
| Mo | 98 | 20243.386 | 1.6 | 58.127 | 2.30543 | 0.060 | 2.6 | ug/L |
| Rh | 103 | 349073.276 | 2.1 | 323620.727 | | | | ug/L |
| Ag | 107 | 91.668 | 0.6 | 57.001 | 0.00243 | 0.000 | 10.5 | ug/L |
| Ag | 109 | 78.668 | 16.3 | 41.334 | 0.00275 | 0.001 | 37.7 | ug/L |
| Cd | 111 | 351.703 | 5.2 | 233.296 | 0.03517 | 0.003 | 8.2 | ug/L |
| Cd | 114 | 240.330 | 32.5 | 64.652 | 0.02407 | 0.010 | 41.5 | ug/L |
| > In | 115 | 377921.968 | 3.4 | 364581.825 | | | | ug/L |
| Sb | 121 | 2869.189 | 2.2 | 51.001 | 0.28469 | 0.004 | 1.2 | ug/L |
| Sb | 123 | 2128.569 | 2.1 | 45.100 | 0.28077 | 0.014 | 5.1 | ug/L |
| Ba | 135 | 82945.268 | 1.0 | 65.001 | 33.05722 | 0.467 | 1.4 | ug/L |
| Ba | 137 | 141112.656 | 1.6 | 74.668 | 33.57110 | 0.413 | 1.2 | ug/L |
| > Tb | 159 | 446043.696 | 0.5 | 439210.410 | | | | ug/L |
| > Ho | 165 | 425703.207 | 1.1 | 425708.154 | | | | ug/L |
| Tl | 203 | 495.686 | 2.2 | 51.001 | 0.05673 | 0.001 | 2.3 | ug/L |
| Tl | 205 | 1138.089 | 0.9 | 72.668 | 0.05975 | 0.000 | 0.8 | ug/L |
| Pb | 208 | 2910.561 | 2.4 | 767.689 | 0.08640 | 0.004 | 4.6 | ug/L |

Sample ID: 950033

Report Date/Time: Tuesday, November 21, 2006 11:59:06

Page 1

| | | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|-----|------|
| | Pb | 206 | 752.708 | 3.3 | 194.671 | 0.08543 | 0.003 | 3.9 | ug/L |
| | Pb | 207 | 624.696 | 2.7 | 181.671 | 0.08153 | 0.003 | 4.2 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 115.738 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 106.402 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 103.659 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 101.556 | | | |
| > Ho | 165 | | 99.999 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950034

Sample Date/Time: Tuesday, November 21, 2006 12:02:04

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950034.026

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 147.003 | 7.6 | 54.001 | 0.06164 | 0.007 | 12.0 | ug/L |
| Al | 27 | 8694897.636 | 0.9 | 9687.584 | 848.95808 | 8.358 | 1.0 | ug/L |
| Sc | 45 | 466181.872 | 1.1 | 378480.621 | | | | ug/L |
| V | 51 | 41041.954 | 53.4 | 4514.855 | 2.00680 | 1.229 | 61.2 | ug/L |
| Cr | 52 | 716290.590 | 9.1 | 14908.140 | 45.22538 | 3.934 | 8.7 | ug/L |
| Cr | 53 | 85045.276 | 0.4 | 661.366 | 44.82028 | 0.672 | 1.5 | ug/L |
| Mn | 55 | 72986110.154 | 0.4 | 587.693 | 4060.86773 | 46.770 | 1.2 | ug/L |
| Co | 59 | 147724.109 | 2.4 | 242.339 | 9.49117 | 0.238 | 2.5 | ug/L |
| Ni | 60 | 128908.022 | 0.6 | 623.696 | 37.21515 | 0.319 | 0.9 | ug/L |
| Ni | 62 | 18319.637 | 2.2 | 504.354 | 33.67631 | 1.067 | 3.2 | ug/L |
| Cu | 63 | 33803.779 | 2.0 | 1290.783 | 4.03873 | 0.100 | 2.5 | ug/L |
| Cu | 65 | 16132.429 | 0.8 | 588.027 | 3.96366 | 0.037 | 0.9 | ug/L |
| Zn | 66 | 23865.705 | 1.8 | 2796.188 | 9.33760 | 0.104 | 1.1 | ug/L |
| Zn | 67 | 4498.926 | 1.3 | 500.354 | 10.43709 | 0.047 | 0.4 | ug/L |
| Zn | 68 | 19133.139 | 2.5 | 2052.621 | 10.45385 | 0.376 | 3.6 | ug/L |
| Ge | 72 | 210559.818 | 0.9 | 193550.369 | | | | ug/L |
| As | 75 | 11238.353 | 1.5 | 97.335 | 4.38172 | 0.028 | 0.6 | ug/L |
| Se | 77 | 575.420 | 2.7 | 187.669 | 2.00508 | 0.095 | 4.7 | ug/L |
| Se | 78 | 16095.730 | 1.3 | 13588.495 | 2.19056 | 0.315 | 14.4 | mg/L |
| Se | 82 | 1609.089 | 0.8 | 1139.011 | 1.43278 | 0.047 | 3.3 | ug/L |
| Kr | 83 | 1511.819 | 3.5 | 1141.423 | | | | mg/L |
| Y | 89 | 479937.362 | 1.8 | 354910.360 | | | | ug/L |
| Mo | 95 | 6475.247 | 2.1 | 114.335 | 1.24769 | 0.029 | 2.4 | ug/L |
| Mo | 97 | 3499.770 | 1.7 | 49.001 | 1.04047 | 0.033 | 3.1 | ug/L |
| Mo | 98 | 8943.767 | 1.7 | 58.127 | 1.04367 | 0.013 | 1.3 | ug/L |
| Rh | 103 | 337282.304 | 2.4 | 323620.727 | | | | ug/L |
| Ag | 107 | 229.005 | 7.2 | 57.001 | 0.01313 | 0.002 | 11.6 | ug/L |
| Ag | 109 | 167.337 | 10.4 | 41.334 | 0.00990 | 0.001 | 11.7 | ug/L |
| Cd | 111 | 1171.751 | 1.2 | 233.296 | 0.30885 | 0.006 | 1.8 | ug/L |
| Cd | 114 | 2070.858 | 3.1 | 64.652 | 0.28942 | 0.013 | 4.4 | ug/L |
| In | 115 | 367330.038 | 1.6 | 364581.825 | | | | ug/L |
| Sb | 121 | 1027.074 | 6.6 | 51.001 | 0.10151 | 0.008 | 8.1 | ug/L |
| Sb | 123 | 727.788 | 4.2 | 45.100 | 0.09463 | 0.006 | 5.9 | ug/L |
| Ba | 135 | 110071.729 | 1.6 | 65.001 | 44.10855 | 1.398 | 3.2 | ug/L |
| Ba | 137 | 186559.239 | 1.4 | 74.668 | 44.61688 | 0.802 | 1.8 | ug/L |
| Tb | 159 | 443830.719 | 1.6 | 439210.410 | | | | ug/L |
| Ho | 165 | 426157.497 | 0.3 | 425708.154 | | | | ug/L |
| Tl | 203 | 3667.177 | 3.4 | 51.001 | 0.46078 | 0.015 | 3.3 | ug/L |
| Tl | 205 | 8869.807 | 1.3 | 72.668 | 0.49280 | 0.005 | 1.0 | ug/L |
| Pb | 208 | 62721.577 | 1.1 | 767.689 | 2.49438 | 0.022 | 0.9 | ug/L |

Sample ID: 950034

Report Date/Time: Tuesday, November 21, 2006 12:05:06

Page 1

825

| | | | | | | | | |
|---|----|-----|-----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 16363.549 | 1.4 | 194.671 | 2.47289 | 0.032 | 1.3 ug/L |
| L | Pb | 207 | 13223.950 | 1.0 | 181.671 | 2.39736 | 0.023 | 1.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 123.172 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 108.788 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 100.754 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 101.052 | | | |
| > [Ho | 165 | | 100.106 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950035

Sample Date/Time: Tuesday, November 21, 2006 12:08:02

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950035.027

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 96.668 | 16.2 | 54.001 | 0.02658 | 0.012 | 43.7 | ug/L |
| Al | 27 | 251962.916 | 2.4 | 9687.584 | 24.66888 | 1.122 | 4.5 | ug/L |
| > Sc | 45 | 444753.036 | 2.0 | 378480.621 | | | | ug/L |
| V | 51 | 9460.970 | 7.2 | 4514.855 | 0.24692 | 0.035 | 14.1 | ug/L |
| Cr | 52 | 75154.867 | 1.9 | 14908.140 | 3.91721 | 0.134 | 3.4 | ug/L |
| Cr | 53 | 8690.953 | 3.3 | 661.366 | 4.41507 | 0.198 | 4.5 | ug/L |
| Mn | 55 | 26463274.056 | 1.9 | 587.693 | 1413.37779 | 48.659 | 3.4 | ug/L |
| Co | 59 | 23199.821 | 1.8 | 242.339 | 1.41639 | 0.045 | 3.2 | ug/L |
| Ni | 60 | 44637.398 | 2.6 | 623.696 | 12.23660 | 0.366 | 3.0 | ug/L |
| Ni | 62 | 4975.535 | 0.7 | 504.354 | 8.00818 | 0.106 | 1.3 | ug/L |
| Cu | 63 | 11482.022 | 2.4 | 1290.783 | 1.19887 | 0.050 | 4.2 | ug/L |
| Cu | 65 | 5192.337 | 3.7 | 588.027 | 1.11164 | 0.061 | 5.5 | ug/L |
| Zn | 66 | 11299.439 | 2.8 | 2796.188 | 3.50056 | 0.205 | 5.9 | ug/L |
| Zn | 67 | 2729.141 | 2.9 | 500.354 | 5.47494 | 0.100 | 1.8 | ug/L |
| Zn | 68 | 11269.728 | 0.6 | 2052.621 | 5.30840 | 0.079 | 1.5 | ug/L |
| > Ge | 72 | 219409.846 | 1.5 | 193550.369 | | | | ug/L |
| As | 75 | 948.063 | 2.3 | 97.335 | 0.31645 | 0.007 | 2.3 | ug/L |
| Se | 77 | 616.356 | 0.9 | 187.669 | 2.09238 | 0.078 | 3.7 | ug/L |
| Se | 78 | 16847.955 | 0.3 | 13588.495 | 2.31533 | 0.394 | 17.0 | mg/L |
| Se | 82 | 2062.322 | 0.2 | 1139.011 | 2.86671 | 0.117 | 4.1 | ug/L |
| Kr | 83 | 1575.498 | 3.5 | 1141.423 | | | | mg/L |
| Y | 89 | 454035.045 | 0.4 | 354910.360 | | | | ug/L |
| Mo | 95 | 126679.951 | 1.2 | 114.335 | 23.34467 | 0.393 | 1.7 | ug/L |
| Mo | 97 | 80669.485 | 2.1 | 49.001 | 22.85413 | 0.561 | 2.5 | ug/L |
| Mo | 98 | 207668.320 | 2.3 | 58.127 | 22.92953 | 0.492 | 2.1 | ug/L |
| Rh | 103 | 357021.948 | 1.1 | 323620.727 | | | | ug/L |
| Ag | 107 | 103.668 | 4.9 | 57.001 | 0.00306 | 0.000 | 10.4 | ug/L |
| Ag | 109 | 70.334 | 7.2 | 41.334 | 0.00193 | 0.000 | 18.5 | ug/L |
| Cd | 111 | 1024.078 | 6.2 | 233.296 | 0.24007 | 0.022 | 9.0 | ug/L |
| Cd | 114 | 2023.263 | 6.1 | 64.652 | 0.26503 | 0.017 | 6.3 | ug/L |
| > In | 115 | 390638.716 | 0.8 | 364581.825 | | | | ug/L |
| Sb | 121 | 1385.462 | 2.7 | 51.001 | 0.13013 | 0.004 | 3.4 | ug/L |
| Sb | 123 | 1011.838 | 1.8 | 45.100 | 0.12558 | 0.002 | 1.7 | ug/L |
| Ba | 135 | 125053.718 | 1.6 | 65.001 | 49.20466 | 0.980 | 2.0 | ug/L |
| Ba | 137 | 212801.344 | 1.6 | 74.668 | 49.97994 | 0.938 | 1.9 | ug/L |
| > Tb | 159 | 451917.117 | 0.4 | 439210.410 | | | | ug/L |
| > Ho | 165 | 435928.320 | 0.7 | 425708.154 | | | | ug/L |
| Tl | 203 | 277.341 | 4.0 | 51.001 | 0.02805 | 0.002 | 5.6 | ug/L |
| Tl | 205 | 604.695 | 2.7 | 72.668 | 0.02904 | 0.001 | 2.8 | ug/L |
| Pb | 208 | 5492.432 | 1.4 | 767.689 | 0.18524 | 0.001 | 0.8 | ug/L |

Sample ID: 950035

Report Date/Time: Tuesday, November 21, 2006 12:11:04

Page 1

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 1413.801 | 4.2 | 194.671 | 0.18156 | 0.008 | 4.5 ug/L |
| | Pb | 207 | 1169.761 | 3.9 | 181.671 | 0.17676 | 0.008 | 4.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 117.510 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 113.361 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 107.147 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 102.893 | | | |
| > [Ho | 165 | | 102.401 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950036

Sample Date/Time: Tuesday, November 21, 2006 12:14:00

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950036.028

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| Be | 9 | 6745.463 | 1.2 | 54.001 | 4.58950 | 0.126 | 2.8 | ug/L |
| Al | 27 | 108989287.982 | 1.2 | 9687.584 | 9562.15454 | 200.421 | 2.1 | ug/L |
| > Sc | 45 | 519629.765 | 2.9 | 378480.621 | | | | ug/L |
| V | 51 | 5705.793 | 7.8 | 4514.855 | -0.02526 | 0.017 | 66.7 | ug/L |
| Cr | 52 | 49331.764 | 1.4 | 14908.140 | 1.68005 | 0.089 | 5.3 | ug/L |
| Cr | 53 | 5494.867 | 2.2 | 661.366 | 2.18981 | 0.021 | 1.0 | ug/L |
| Mn | 55 | 318457145.414 | 2.2 | 587.693 | 16700.66592 | 576.516 | 3.5 | ug/L |
| Co | 59 | 4788091.081 | 1.3 | 242.339 | 290.42540 | 6.407 | 2.2 | ug/L |
| Ni | 60 | 2840581.892 | 1.6 | 623.696 | 776.82538 | 22.232 | 2.9 | ug/L |
| Ni | 62 | 346748.230 | 1.6 | 504.354 | 618.36767 | 25.191 | 4.1 | ug/L |
| Cu | 63 | 25481692.071 | 3.1 | 1290.783 | 2992.05838 | 25.957 | 0.9 | ug/L |
| Cu | 65 | 12265628.248 | 0.9 | 588.027 | 2957.16092 | 47.806 | 1.6 | ug/L |
| Zn | 66 | 3937656.427 | 3.3 | 2796.188 | 1662.13065 | 14.534 | 0.9 | ug/L |
| Zn | 67 | 496735.168 | 1.4 | 500.354 | 1234.36861 | 38.122 | 3.1 | ug/L |
| Zn | 68 | 2753359.656 | 2.6 | 2052.621 | 1603.19683 | 32.235 | 2.0 | ug/L |
| > Ge | 72 | 223478.973 | 2.5 | 193550.369 | | | | ug/L |
| As | 75 | 2310.344 | 3.1 | 97.335 | 0.81510 | 0.013 | 1.6 | ug/L |
| Se | 77 | 772.502 | 1.0 | 187.669 | 2.82895 | 0.068 | 2.4 | ug/L |
| Se | 78 | 18336.044 | 0.3 | 13588.495 | 4.17174 | 0.773 | 18.5 | mg/L |
| Se | 82 | 2117.336 | 1.4 | 1139.011 | 2.92983 | 0.217 | 7.4 | ug/L |
| Kr | 83 | 1786.210 | 5.3 | 1141.423 | | | | mg/L |
| Y | 89 | 3348963.503 | 1.2 | 354910.360 | | | | ug/L |
| Mo | 95 | 2942.883 | 3.2 | 114.335 | 0.52813 | 0.013 | 2.5 | ug/L |
| Mo | 97 | 288.008 | 6.9 | 49.001 | 0.06800 | 0.006 | 9.5 | ug/L |
| Mo | 98 | 1148.974 | 3.7 | 58.127 | 0.12190 | 0.005 | 3.9 | ug/L |
| Rh | 103 | 349632.776 | 2.2 | 323620.727 | | | | ug/L |
| Ag | 107 | 153.336 | 1.4 | 57.001 | 0.00680 | 0.000 | 3.3 | ug/L |
| Ag | 109 | 78.001 | 3.8 | 41.334 | 0.00258 | 0.000 | 6.8 | ug/L |
| Cd | 111 | 35269.563 | 0.8 | 233.296 | 11.01820 | 0.175 | 1.6 | ug/L |
| Cd | 114 | 74369.081 | 2.1 | 64.652 | 10.22590 | 0.183 | 1.8 | ug/L |
| > In | 115 | 384965.065 | 0.9 | 364581.825 | | | | ug/L |
| Sb | 121 | 535.023 | 3.0 | 51.001 | 0.04773 | 0.001 | 2.6 | ug/L |
| Sb | 123 | 417.660 | 3.2 | 45.100 | 0.04893 | 0.001 | 2.8 | ug/L |
| Ba | 135 | 41855.946 | 1.2 | 65.001 | 15.53348 | 0.275 | 1.8 | ug/L |
| Ba | 137 | 71410.045 | 0.7 | 74.668 | 15.82424 | 0.018 | 0.1 | ug/L |
| > Tb | 159 | 478585.266 | 0.6 | 439210.410 | | | | ug/L |
| > Ho | 165 | 474687.495 | 1.4 | 425708.154 | | | | ug/L |
| Tl | 203 | 8536.456 | 0.9 | 51.001 | 0.97015 | 0.012 | 1.3 | ug/L |
| Tl | 205 | 20408.168 | 1.8 | 72.668 | 1.02243 | 0.022 | 2.2 | ug/L |
| Pb | 208 | 78939.471 | 1.5 | 767.689 | 2.82311 | 0.077 | 2.7 | ug/L |

Sample ID: 950036

Report Date/Time: Tuesday, November 21, 2006 12:17:02

Page 1

831

| | | | | | | | | | |
|--|----|-----|-----------|-----|---------|---------|-------|-----|------|
| | Pb | 206 | 20611.666 | 0.9 | 194.671 | 2.80080 | 0.055 | 2.0 | ug/L |
| | Pb | 207 | 16894.945 | 0.7 | 181.671 | 2.75518 | 0.059 | 2.1 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 137.294 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 115.463 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 105.591 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 108.965 | | | |
| > Ho | 165 | | 111.505 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Tuesday, November 21, 2006 12:19:57

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 3.029

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1224.769 | 2.7 | 54.001 | 1.04030 | 0.043 | 4.1 | ug/L |
| Al | 27 | 92773.671 | 2.4 | 9687.584 | 9.37752 | 0.374 | 4.0 | ug/L |
| Sc | 45 | 401142.451 | 1.4 | 378480.621 | | | | ug/L |
| V | 51 | 20741.273 | 1.6 | 4514.855 | 1.05198 | 0.024 | 2.3 | ug/L |
| Cr | 52 | 29149.195 | 1.9 | 14908.140 | 1.00557 | 0.033 | 3.3 | ug/L |
| Cr | 53 | 3064.594 | 2.6 | 661.366 | 1.46206 | 0.071 | 4.9 | ug/L |
| Mn | 55 | 21205.497 | 1.8 | 587.693 | 1.11800 | 0.031 | 2.7 | ug/L |
| Co | 59 | 16772.698 | 1.2 | 242.339 | 1.03845 | 0.016 | 1.6 | ug/L |
| Ni | 60 | 3905.287 | 1.3 | 623.696 | 0.91123 | 0.023 | 2.5 | ug/L |
| Ni | 62 | 871.054 | 5.3 | 504.354 | 0.57374 | 0.081 | 14.0 | ug/L |
| Cu | 63 | 9090.383 | 3.4 | 1290.783 | 0.93288 | 0.045 | 4.8 | ug/L |
| Cu | 65 | 4405.542 | 2.7 | 588.027 | 0.93833 | 0.034 | 3.6 | ug/L |
| Zn | 66 | 14621.964 | 0.8 | 2796.188 | 5.04657 | 0.072 | 1.4 | ug/L |
| Zn | 67 | 2327.682 | 0.8 | 500.354 | 4.56955 | 0.045 | 1.0 | ug/L |
| Zn | 68 | 10220.700 | 1.1 | 2052.621 | 4.79918 | 0.107 | 2.2 | ug/L |
| Ge | 72 | 215376.292 | 0.8 | 193550.369 | | | | ug/L |
| As | 75 | 2841.846 | 1.9 | 97.335 | 1.05190 | 0.019 | 1.8 | ug/L |
| Se | 77 | 419.877 | 1.5 | 187.669 | 1.11434 | 0.044 | 4.0 | ug/L |
| Se | 78 | 15187.375 | 2.9 | 13588.495 | 0.10941 | 0.740 | 676.0 | mg/L |
| Se | 82 | 1676.702 | 1.0 | 1139.011 | 1.54941 | 0.067 | 4.3 | ug/L |
| Kr | 83 | 1401.465 | 2.6 | 1141.423 | | | | mg/L |
| Y | 89 | 402094.790 | 2.7 | 354910.360 | | | | ug/L |
| Mo | 95 | 5860.454 | 3.7 | 114.335 | 1.07071 | 0.037 | 3.4 | ug/L |
| Mo | 97 | 3580.472 | 3.4 | 49.001 | 1.01165 | 0.030 | 3.0 | ug/L |
| Mo | 98 | 9329.887 | 0.8 | 58.127 | 1.03562 | 0.024 | 2.3 | ug/L |
| Rh | 103 | 360453.405 | 0.8 | 323620.727 | | | | ug/L |
| Ag | 107 | 14733.833 | 2.5 | 57.001 | 1.06730 | 0.030 | 2.9 | ug/L |
| Ag | 109 | 13924.767 | 2.1 | 41.334 | 1.04090 | 0.025 | 2.4 | ug/L |
| Cd | 111 | 3408.796 | 2.0 | 233.296 | 0.99128 | 0.007 | 0.7 | ug/L |
| Cd | 114 | 7528.635 | 0.5 | 64.652 | 1.02361 | 0.021 | 2.1 | ug/L |
| In | 115 | 386223.279 | 1.6 | 364581.825 | | | | ug/L |
| Sb | 121 | 10393.916 | 1.1 | 51.001 | 1.02268 | 0.024 | 2.3 | ug/L |
| Sb | 123 | 7835.869 | 4.4 | 45.100 | 1.02635 | 0.030 | 2.9 | ug/L |
| Ba | 135 | 2779.825 | 2.0 | 65.001 | 1.08466 | 0.006 | 0.6 | ug/L |
| Ba | 137 | 4884.814 | 1.8 | 74.668 | 1.14741 | 0.032 | 2.8 | ug/L |
| Tb | 159 | 445107.734 | 1.5 | 439210.410 | | | | ug/L |
| Ho | 165 | 443933.293 | 1.1 | 425708.154 | | | | ug/L |
| Tl | 203 | 8623.547 | 1.7 | 51.001 | 1.04856 | 0.029 | 2.7 | ug/L |
| Tl | 205 | 20406.501 | 2.3 | 72.668 | 1.09358 | 0.036 | 3.3 | ug/L |
| Pb | 208 | 26771.649 | 1.3 | 767.689 | 1.00396 | 0.024 | 2.4 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Tuesday, November 21, 2006 12:22:58

Page 1

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 7001.010 | 1.3 | 194.671 | 0.99824 | 0.023 | 2.3 ug/L |
| | Pb | 207 | 5744.372 | 3.6 | 181.671 | 0.98053 | 0.047 | 4.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 104.030 | | | | |
| Al | 27 | 93.775 | | | | |
| > Sc | 45 | | 105.988 | | | |
| V | 51 | 105.198 | | | | |
| Cr | 52 | 100.557 | | | | |
| Cr | 53 | 146.206 | | | | |
| Mn | 55 | 111.800 | | | | |
| Co | 59 | 103.845 | | | | |
| Ni | 60 | 91.123 | | | | |
| Ni | 62 | 57.374 | | | | |
| Cu | 63 | 93.288 | | | | |
| Cu | 65 | 93.833 | | | | |
| Zn | 66 | 100.931 | | | | |
| Zn | 67 | 91.391 | | | | |
| Zn | 68 | 95.984 | | | | |
| > Ge | 72 | | 111.277 | | | |
| As | 75 | 105.190 | | | | |
| Se | 77 | 111.434 | | | | |
| Se | 78 | 10.941 | | | | |
| Se | 82 | 154.941 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 107.071 | | | | |
| Mo | 97 | 101.165 | | | | |
| Mo | 98 | 103.562 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 106.730 | | | | |
| Ag | 109 | 104.090 | | | | |
| Cd | 111 | 99.128 | | | | |
| Cd | 114 | 102.361 | | | | |
| > In | 115 | | 105.936 | | | |
| Sb | 121 | 102.268 | | | | |
| Sb | 123 | 102.635 | | | | |
| Ba | 135 | 108.466 | | | | |
| Ba | 137 | 114.741 | | | | |
| > Tb | 159 | | 101.343 | | | |
| > Ho | 165 | | 104.281 | | | |
| Tl | 203 | 104.856 | | | | |
| Tl | 205 | 109.358 | | | | |
| Pb | 208 | 100.396 | | | | |
| Pb | 206 | 99.824 | | | | |
| Pb | 207 | 98.053 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: HLCCV2

Sample Date/Time: Tuesday, November 21, 2006 12:25:54

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\HLCCV2.030

not poured up

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| Be | 9 | 41.001 | 13.6 | 54.001 | 3.88513 | 0.500 | 12.9 | ug/L |
| Al | 27 | 360.011 | 2.6 | 9687.584 | 3.24558 | 0.097 | 3.0 | ug/L |
| > Sc | 45 | 3718.867 | 1.3 | 378480.621 | | | | ug/L |
| V | 51 | 2796.863 | 4.7 | 4514.855 | 19.57093 | 0.834 | 4.3 | ug/L |
| Cr | 52 | 9618.310 | 0.5 | 14908.140 | 76.97300 | 1.107 | 1.4 | ug/L |
| Cr | 53 | 778.044 | 4.0 | 661.366 | 51.45034 | 1.554 | 3.0 | ug/L |
| Mn | 55 | 4317.161 | 0.7 | 587.693 | 145.90055 | 3.064 | 2.1 | ug/L |
| Co | 59 | 100.002 | 11.4 | 242.339 | 3.90189 | 0.555 | 14.2 | ug/L |
| Ni | 60 | 85.335 | 7.6 | 623.696 | 14.86927 | 1.520 | 10.2 | ug/L |
| Ni | 62 | 102.002 | 2.6 | 504.354 | 116.40923 | 4.887 | 4.2 | ug/L |
| Cu | 63 | 147.336 | 10.5 | 1290.783 | 10.97894 | 1.120 | 10.2 | ug/L |
| Cu | 65 | 168.337 | 8.5 | 588.027 | 26.03260 | 2.732 | 10.5 | ug/L |
| Zn | 66 | 146.336 | 15.0 | 2796.188 | 38.52623 | 6.137 | 15.9 | ug/L |
| Zn | 67 | 105.668 | 14.2 | 500.354 | 168.02264 | 24.105 | 14.3 | ug/L |
| Zn | 68 | 422.682 | 5.9 | 2052.621 | 157.34900 | 6.932 | 4.4 | ug/L |
| > Ge | 72 | 346.677 | 2.7 | 193550.369 | | | | ug/L |
| As | 75 | 116.669 | 11.5 | 97.335 | 27.83201 | 2.858 | 10.3 | ug/L |
| Se | 77 | 146.868 | 2.2 | 187.669 | 481.00934 | 23.740 | 4.9 | ug/L |
| Se | 78 | 19156.511 | 1.1 | 13588.495 | 19394.72361 | 691.440 | 3.6 | mg/L |
| Se | 82 | 3264.506 | 0.6 | 1139.011 | 7676.14112 | 193.861 | 2.5 | ug/L |
| Kr | 83 | 3312.692 | 1.6 | 1141.423 | | | | mg/L |
| Y | 89 | 34.000 | 5.1 | 354910.360 | | | | ug/L |
| Mo | 95 | 109.668 | 6.7 | 114.335 | 281.62749 | 89.012 | 31.6 | ug/L |
| Mo | 97 | 28.667 | 19.2 | 49.001 | 118.19447 | 63.297 | 53.6 | ug/L |
| Mo | 98 | 27.346 | 8.0 | 58.127 | 42.98274 | 17.688 | 41.2 | ug/L |
| Rh | 103 | 33.334 | 1.7 | 323620.727 | | | | ug/L |
| Ag | 107 | 48.001 | 10.8 | 57.001 | 48.47556 | 19.010 | 39.2 | ug/L |
| Ag | 109 | 43.667 | 27.3 | 41.334 | 42.55754 | 5.455 | 12.8 | ug/L |
| Cd | 111 | 62.135 | 22.0 | 233.296 | 282.52414 | 159.599 | 56.5 | ug/L |
| Cd | 114 | 133.510 | 19.0 | 64.652 | 254.48774 | 110.341 | 43.4 | ug/L |
| > In | 115 | 30.189 | 33.5 | 364581.825 | | | | ug/L |
| Sb | 121 | 33.334 | 6.2 | 51.001 | 46.01320 | 17.285 | 37.6 | ug/L |
| Sb | 123 | 30.724 | 14.7 | 45.100 | 57.82623 | 28.467 | 49.2 | ug/L |
| Ba | 135 | 28.000 | 27.0 | 65.001 | 172.63321 | 39.303 | 22.8 | ug/L |
| Ba | 137 | 35.667 | 29.2 | 74.668 | 132.59173 | 38.983 | 29.4 | ug/L |
| > Tb | 159 | 28.667 | 8.8 | 439210.410 | | | | ug/L |
| > Ho | 165 | 32.667 | 22.6 | 425708.154 | | | | ug/L |
| Tl | 203 | 171.670 | 12.0 | 51.001 | 289.62775 | 28.439 | 9.8 | ug/L |
| Tl | 205 | 394.680 | 20.5 | 72.668 | 289.53838 | 14.476 | 5.0 | ug/L |
| Pb | 208 | 144.002 | 11.2 | 767.689 | 77.10192 | 11.794 | 15.3 | ug/L |

Sample ID: HLCCV2

Report Date/Time: Tuesday, November 21, 2006 12:28:55

Page 1

837

| | | | | | | | | |
|--|----|-----|--------|------|---------|-----------|--------|-----------|
| | Pb | 206 | 50.667 | 20.2 | 194.671 | 101.91851 | 15.226 | 14.9 ug/L |
| | Pb | 207 | 37.000 | 29.2 | 181.671 | 91.68731 | 36.574 | 39.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 0.983 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 0.179 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 0.008 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 0.007 | | | |
| > Ho | 165 | | 0.008 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| L Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Tuesday, November 21, 2006 12:31:53

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 6.031

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54326.180 | 3.4 | 54.001 | 50.45865 | 2.074 | 4.1 | ug/L |
| Al | 27 | 441062.709 | 2.0 | 9687.584 | 51.14390 | 1.609 | 3.1 | ug/L |
| > Sc | 45 | 384383.648 | 1.1 | 378480.621 | | | | ug/L |
| V | 51 | 780477.702 | 1.6 | 4514.855 | 53.37712 | 0.391 | 0.7 | ug/L |
| Cr | 52 | 668054.598 | 0.5 | 14908.140 | 51.33069 | 0.369 | 0.7 | ug/L |
| Cr | 53 | 82141.710 | 1.3 | 661.366 | 52.57267 | 0.612 | 1.2 | ug/L |
| Mn | 55 | 911516.026 | 1.3 | 587.693 | 52.22278 | 1.173 | 2.2 | ug/L |
| Co | 59 | 797585.795 | 1.7 | 242.339 | 52.87949 | 1.255 | 2.4 | ug/L |
| Ni | 60 | 171711.321 | 1.5 | 623.696 | 51.15302 | 1.108 | 2.2 | ug/L |
| Ni | 62 | 26651.490 | 1.6 | 504.354 | 50.98632 | 0.456 | 0.9 | ug/L |
| Cu | 63 | 417601.680 | 3.3 | 1290.783 | 53.46946 | 2.299 | 4.3 | ug/L |
| Cu | 65 | 197372.177 | 2.4 | 588.027 | 51.87292 | 1.763 | 3.4 | ug/L |
| Zn | 66 | 112697.060 | 0.6 | 2796.188 | 50.71156 | 0.830 | 1.6 | ug/L |
| Zn | 67 | 19128.142 | 4.0 | 500.354 | 50.59515 | 2.539 | 5.0 | ug/L |
| Zn | 68 | 81476.637 | 2.2 | 2052.621 | 50.54629 | 1.601 | 3.2 | ug/L |
| > Ge | 72 | 204361.631 | 0.9 | 193550.369 | | | | ug/L |
| As | 75 | 127446.089 | 2.3 | 97.335 | 51.65399 | 1.643 | 3.2 | ug/L |
| Se | 77 | 9593.119 | 0.9 | 187.669 | 52.27735 | 0.993 | 1.9 | ug/L |
| Se | 78 | 43945.774 | 3.8 | 13588.495 | 50.89035 | 3.592 | 7.1 | mg/L |
| Se | 82 | 14296.255 | 1.7 | 1139.011 | 52.24799 | 1.497 | 2.9 | ug/L |
| Kr | 83 | 1430.470 | 1.7 | 1141.423 | | | | mg/L |
| Y | 89 | 383157.047 | 0.8 | 354910.360 | | | | ug/L |
| Mo | 95 | 278401.824 | 2.6 | 114.335 | 54.90182 | 1.385 | 2.5 | ug/L |
| Mo | 97 | 168818.266 | 2.0 | 49.001 | 51.18553 | 1.777 | 3.5 | ug/L |
| Mo | 98 | 451314.092 | 1.3 | 58.127 | 53.33058 | 1.900 | 3.6 | ug/L |
| Rh | 103 | 333473.946 | 1.7 | 323620.727 | | | | ug/L |
| Ag | 107 | 677933.087 | 3.8 | 57.001 | 52.11040 | 0.065 | 0.1 | ug/L |
| Ag | 109 | 635808.327 | 1.3 | 41.334 | 50.42156 | 1.406 | 2.8 | ug/L |
| Cd | 111 | 154322.599 | 1.3 | 233.296 | 51.10053 | 1.230 | 2.4 | ug/L |
| Cd | 114 | 352848.602 | 0.5 | 64.652 | 51.20376 | 1.931 | 3.8 | ug/L |
| > In | 115 | 365378.557 | 3.7 | 364581.825 | | | | ug/L |
| Sb | 121 | 479817.406 | 1.0 | 51.001 | 50.20508 | 2.310 | 4.6 | ug/L |
| Sb | 123 | 361311.810 | 3.0 | 45.100 | 50.35552 | 1.033 | 2.1 | ug/L |
| Ba | 135 | 133091.238 | 1.7 | 65.001 | 54.19486 | 0.708 | 1.3 | ug/L |
| Ba | 137 | 222919.138 | 1.9 | 74.668 | 54.18247 | 0.790 | 1.5 | ug/L |
| > Tb | 159 | 436659.988 | 0.5 | 439210.410 | | | | ug/L |
| > Ho | 165 | 427671.924 | 1.1 | 425708.154 | | | | ug/L |
| Tl | 203 | 397876.242 | 1.9 | 51.001 | 50.51426 | 0.792 | 1.6 | ug/L |
| Tl | 205 | 930486.745 | 1.0 | 72.668 | 51.93802 | 0.221 | 0.4 | ug/L |
| Pb | 208 | 1272803.475 | 1.3 | 767.689 | 51.03510 | 0.540 | 1.1 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Tuesday, November 21, 2006 12:34:55

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 334398.103 | 1.6 | 194.671 | 50.93459 | 0.748 | 1.5 ug/L |
| | Pb | 207 | 269400.617 | 2.9 | 181.671 | 49.30950 | 1.199 | 2.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | 100.917 | | | | |
| Al | 27 | 102.288 | | | | |
| > Sc | 45 | | 101.560 | | | |
| V | 51 | 106.754 | | | | |
| Cr | 52 | 102.661 | | | | |
| [Cr | 53 | 105.145 | | | | |
| [Mn | 55 | 104.446 | | | | |
| Co | 59 | 105.759 | | | | |
| Ni | 60 | 102.306 | | | | |
| Ni | 62 | 101.973 | | | | |
| Cu | 63 | 106.939 | | | | |
| Cu | 65 | 103.746 | | | | |
| Zn | 66 | 101.423 | | | | |
| Zn | 67 | 101.190 | | | | |
| Zn | 68 | 101.093 | | | | |
| > Ge | 72 | | 105.586 | | | |
| As | 75 | 103.308 | | | | |
| Se | 77 | 104.555 | | | | |
| Se | 78 | 101.781 | | | | |
| Se | 82 | 104.496 | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | 109.804 | | | | |
| Mo | 97 | 102.371 | | | | |
| Mo | 98 | 106.661 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 104.221 | | | | |
| Ag | 109 | 100.843 | | | | |
| Cd | 111 | 102.201 | | | | |
| Cd | 114 | 102.408 | | | | |
| > In | 115 | | 100.219 | | | |
| Sb | 121 | 100.410 | | | | |
| [Sb | 123 | 100.711 | | | | |
| [Ba | 135 | 108.390 | | | | |
| Ba | 137 | 108.365 | | | | |
| > Tb | 159 | | 99.419 | | | |
| > Ho | 165 | | 100.461 | | | |
| Tl | 203 | 101.029 | | | | |
| Tl | 205 | 103.876 | | | | |
| Pb | 208 | 102.070 | | | | |
| Pb | 206 | 101.869 | | | | |
| [Pb | 207 | 98.619 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Tuesday, November 21, 2006 12:37:50

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 7.032

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 57.667 | 12.8 | 54.001 | 0.00394 | 0.007 | 181.7 | ug/L |
| Al | 27 | 3328.698 | 1.2 | 9687.584 | -0.76234 | 0.006 | 0.8 | ug/L |
| > Sc | 45 | 375292.267 | 0.3 | 378480.621 | | | | ug/L |
| V | 51 | 4241.049 | 2.9 | 4514.855 | -0.01661 | 0.009 | 53.5 | ug/L |
| Cr | 52 | 14473.705 | 1.5 | 14908.140 | -0.02485 | 0.020 | 78.6 | ug/L |
| Cr | 53 | 992.402 | 2.9 | 661.366 | 0.22249 | 0.020 | 9.1 | ug/L |
| Mn | 55 | 687.369 | 10.5 | 587.693 | 0.00511 | 0.004 | 68.6 | ug/L |
| Co | 59 | 192.337 | 2.9 | 242.339 | -0.00378 | 0.001 | 16.6 | ug/L |
| Ni | 60 | 570.025 | 1.8 | 623.696 | -0.02070 | 0.004 | 20.0 | ug/L |
| Ni | 62 | 320.676 | 2.2 | 504.354 | -0.39253 | 0.004 | 1.1 | ug/L |
| Cu | 63 | 876.388 | 5.7 | 1290.783 | -0.05862 | 0.008 | 13.6 | ug/L |
| Cu | 65 | 493.353 | 6.2 | 588.027 | -0.02910 | 0.011 | 38.5 | ug/L |
| Zn | 66 | 1647.179 | 0.2 | 2796.188 | -0.57722 | 0.019 | 3.3 | ug/L |
| Zn | 67 | 356.345 | 3.8 | 500.354 | -0.43463 | 0.048 | 11.1 | ug/L |
| Zn | 68 | 1231.770 | 1.9 | 2052.621 | -0.56962 | 0.016 | 2.8 | ug/L |
| > Ge | 72 | 197735.065 | 2.6 | 193550.369 | | | | ug/L |
| As | 75 | 138.336 | 20.2 | 97.335 | 0.01614 | 0.010 | 63.1 | ug/L |
| Se | 77 | 210.136 | 0.2 | 187.669 | 0.10636 | 0.029 | 27.6 | ug/L |
| Se | 78 | 14476.420 | 2.2 | 13588.495 | 1.07516 | 1.187 | 110.4 | mg/L |
| Se | 82 | 1376.580 | 1.8 | 1139.011 | 0.88173 | 0.229 | 26.0 | ug/L |
| Kr | 83 | 1401.799 | 1.2 | 1141.423 | | | | mg/L |
| Y | 89 | 375092.015 | 2.2 | 354910.360 | | | | ug/L |
| Mo | 95 | 528.356 | 18.3 | 114.335 | 0.08315 | 0.021 | 25.0 | ug/L |
| Mo | 97 | 299.675 | 10.9 | 49.001 | 0.07723 | 0.011 | 14.6 | ug/L |
| Mo | 98 | 687.087 | 22.1 | 58.127 | 0.07549 | 0.019 | 25.4 | ug/L |
| Rh | 103 | 337337.894 | 4.2 | 323620.727 | | | | ug/L |
| Ag | 107 | 116.002 | 4.5 | 57.001 | 0.00464 | 0.000 | 6.4 | ug/L |
| Ag | 109 | 101.668 | 15.7 | 41.334 | 0.00488 | 0.001 | 25.8 | ug/L |
| Cd | 111 | 207.588 | 12.8 | 233.296 | -0.00779 | 0.009 | 112.8 | ug/L |
| Cd | 114 | 63.074 | 13.6 | 64.652 | -0.00012 | 0.001 | 1192.5 | ug/L |
| > In | 115 | 360636.361 | 1.4 | 364581.825 | | | | ug/L |
| Sb | 121 | 868.388 | 18.7 | 51.001 | 0.08678 | 0.018 | 21.2 | ug/L |
| Sb | 123 | 650.223 | 15.6 | 45.100 | 0.08564 | 0.016 | 18.2 | ug/L |
| Ba | 135 | 48.001 | 3.6 | 65.001 | -0.00706 | 0.000 | 4.0 | ug/L |
| Ba | 137 | 60.001 | 10.4 | 74.668 | -0.00368 | 0.001 | 32.5 | ug/L |
| > Tb | 159 | 442979.988 | 2.1 | 439210.410 | | | | ug/L |
| > Ho | 165 | 417591.090 | 0.9 | 425708.154 | | | | ug/L |
| Tl | 203 | 80.001 | 7.0 | 51.001 | 0.00390 | 0.001 | 19.1 | ug/L |
| Tl | 205 | 129.669 | 9.4 | 72.668 | 0.00333 | 0.001 | 19.1 | ug/L |
| Pb | 208 | 385.007 | 1.8 | 767.689 | -0.01512 | 0.000 | 2.7 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Tuesday, November 21, 2006 12:40:51

Page 1

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|-----------|
| | Pb | 206 | 102.002 | 10.8 | 194.671 | -0.01388 | 0.002 | 13.2 ug/L |
| | Pb | 207 | 102.002 | 4.3 | 181.671 | -0.01430 | 0.001 | 5.3 ug/L |

Sample ID: QC Std 7

Report Date/Time: Tuesday, November 21, 2006 12:40:51

Page 2

844

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 99.158 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 102.162 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 98.918 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 100.858 | | | |
| > [Ho | 165 | | 98.093 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030 D.5

Sample Date/Time: Tuesday, November 21, 2006 12:49:10

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950030 D.5.033

| | Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| [| Be | 9 | 63.001 | 9.9 | 54.001 | 0.00582 | 0.006 | 102.1 | ug/L |
| [| Al | 27 | 319943.758 | 1.9 | 9687.584 | 35.61114 | 0.423 | 1.2 | ug/L |
| > | Sc | 45 | 396475.326 | 0.8 | 378480.621 | | | | ug/L |
| [| V | 51 | 5296.979 | 11.2 | 4514.855 | 0.03804 | 0.042 | 110.8 | ug/L |
| [| Cr | 52 | 37699.503 | 2.8 | 14908.140 | 1.68358 | 0.103 | 6.1 | ug/L |
| [| Cr | 53 | 3639.164 | 1.8 | 661.366 | 1.84318 | 0.032 | 1.7 | ug/L |
| [| Mn | 55 | 58540.178 | 1.5 | 587.693 | 3.41684 | 0.103 | 3.0 | ug/L |
| [| Co | 59 | 1730.197 | 2.1 | 242.339 | 0.10105 | 0.003 | 2.9 | ug/L |
| [| Ni | 60 | 5274.722 | 2.2 | 623.696 | 1.42519 | 0.017 | 1.2 | ug/L |
| [| Ni | 62 | 851.719 | 1.2 | 504.354 | 0.67078 | 0.034 | 5.0 | ug/L |
| [| Cu | 63 | 1833.220 | 1.2 | 1290.783 | 0.06719 | 0.007 | 10.4 | ug/L |
| [| Cu | 65 | 982.068 | 1.8 | 588.027 | 0.10266 | 0.008 | 7.6 | ug/L |
| [| Zn | 66 | 5604.608 | 2.7 | 2796.188 | 1.30067 | 0.121 | 9.3 | ug/L |
| [| Zn | 67 | 1007.404 | 2.3 | 500.354 | 1.38198 | 0.105 | 7.6 | ug/L |
| [| Zn | 68 | 4511.934 | 4.1 | 2052.621 | 1.57620 | 0.118 | 7.5 | ug/L |
| > | Ge | 72 | 198704.266 | 1.9 | 193550.369 | | | | ug/L |
| [| As | 75 | 232.672 | 3.8 | 97.335 | 0.05535 | 0.002 | 4.3 | ug/L |
| [| Se | 77 | 234.670 | 5.1 | 187.669 | 0.24015 | 0.058 | 24.0 | ug/L |
| [| Se | 78 | 14712.579 | 0.5 | 13588.495 | 1.35409 | 0.556 | 41.1 | mg/L |
| [| Se | 82 | 1445.392 | 1.1 | 1139.011 | 1.13340 | 0.064 | 5.7 | ug/L |
| [| Kr | 83 | 1497.816 | 2.8 | 1141.423 | | | | mg/L |
| [| Y | 89 | 373828.254 | 1.1 | 354910.360 | | | | ug/L |
| [| Mo | 95 | 479.685 | 8.6 | 114.335 | 0.06974 | 0.009 | 12.3 | ug/L |
| [| Mo | 97 | 272.341 | 3.9 | 49.001 | 0.06570 | 0.004 | 6.8 | ug/L |
| [| Mo | 98 | 624.417 | 6.9 | 58.127 | 0.06513 | 0.006 | 9.3 | ug/L |
| [| Rh | 103 | 339198.644 | 5.3 | 323620.727 | | | | ug/L |
| [| Ag | 107 | 79.335 | 7.7 | 57.001 | 0.00157 | 0.001 | 35.2 | ug/L |
| [| Ag | 109 | 55.334 | 4.5 | 41.334 | 0.00100 | 0.000 | 25.4 | ug/L |
| [| Cd | 111 | 208.575 | 7.1 | 233.296 | -0.01005 | 0.005 | 44.9 | ug/L |
| [| Cd | 114 | 100.423 | 19.5 | 64.652 | 0.00483 | 0.003 | 59.9 | ug/L |
| > | In | 115 | 374466.756 | 1.8 | 364581.825 | | | | ug/L |
| [| Sb | 121 | 242.673 | 2.9 | 51.001 | 0.01941 | 0.001 | 3.8 | ug/L |
| [| Sb | 123 | 178.685 | 3.0 | 45.100 | 0.01801 | 0.001 | 5.9 | ug/L |
| [| Ba | 135 | 4890.818 | 3.1 | 65.001 | 1.96882 | 0.065 | 3.3 | ug/L |
| [| Ba | 137 | 8760.692 | 2.4 | 74.668 | 2.11454 | 0.028 | 1.3 | ug/L |
| > | Tb | 159 | 436203.171 | 2.6 | 439210.410 | | | | ug/L |
| > | Ho | 165 | 423188.890 | 1.1 | 425708.154 | | | | ug/L |
| [| Tl | 203 | 69.334 | 12.1 | 51.001 | 0.00240 | 0.001 | 48.4 | ug/L |
| [| Tl | 205 | 141.669 | 5.0 | 72.668 | 0.00392 | 0.000 | 9.2 | ug/L |
| [| Pb | 208 | 2307.478 | 0.9 | 767.689 | 0.06262 | 0.000 | 0.7 | ug/L |

Sample ID: 950030 D.5

Report Date/Time: Tuesday, November 21, 2006 12:52:12

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 615.696 | 3.8 | 194.671 | 0.06502 | 0.004 | 5.4 ug/L |
| | Pb | 207 | 516.021 | 5.2 | 181.671 | 0.06210 | 0.005 | 8.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 104.754 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 102.663 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 102.711 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 99.315 | | | |
| > [Ho | 165 | | 99.408 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030D D.5

Sample Date/Time: Tuesday, November 21, 2006 12:55:08

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950030D D.5.034

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 61.668 | 21.9 | 54.001 | 0.00478 | 0.011 | 231.0 | ug/L |
| Al | 27 | 375499.775 | 0.6 | 9687.584 | 42.27755 | 1.392 | 3.3 | ug/L |
| > Sc | 45 | 394168.457 | 2.7 | 378480.621 | | | | ug/L |
| V | 51 | 5729.210 | 9.6 | 4514.855 | 0.06903 | 0.038 | 54.6 | ug/L |
| Cr | 52 | 43159.602 | 2.0 | 14908.140 | 2.12040 | 0.126 | 5.9 | ug/L |
| Cr | 53 | 4172.420 | 2.5 | 661.366 | 2.19318 | 0.088 | 4.0 | ug/L |
| Mn | 55 | 58190.728 | 1.2 | 587.693 | 3.36586 | 0.087 | 2.6 | ug/L |
| Co | 59 | 1793.544 | 1.8 | 242.339 | 0.10435 | 0.005 | 4.9 | ug/L |
| Ni | 60 | 5761.048 | 1.0 | 623.696 | 1.56019 | 0.068 | 4.3 | ug/L |
| Ni | 62 | 965.399 | 2.5 | 504.354 | 0.88165 | 0.034 | 3.9 | ug/L |
| Cu | 63 | 2641.779 | 5.5 | 1290.783 | 0.17120 | 0.027 | 15.7 | ug/L |
| Cu | 65 | 1352.123 | 4.3 | 588.027 | 0.20002 | 0.024 | 12.1 | ug/L |
| Zn | 66 | 2155.300 | 0.6 | 2796.188 | -0.34842 | 0.036 | 10.2 | ug/L |
| Zn | 67 | 473.018 | 7.1 | 500.354 | -0.12357 | 0.124 | 100.5 | ug/L |
| Zn | 68 | 1921.241 | 5.8 | 2052.621 | -0.13323 | 0.061 | 46.1 | ug/L |
| > Ge | 72 | 200505.151 | 3.0 | 193550.369 | | | | ug/L |
| As | 75 | 230.672 | 4.2 | 97.335 | 0.05377 | 0.006 | 11.3 | ug/L |
| Se | 77 | 227.003 | 4.1 | 187.669 | 0.18544 | 0.062 | 33.4 | ug/L |
| Se | 78 | 14635.759 | 1.1 | 13588.495 | 0.99979 | 1.044 | 104.4 | mg/L |
| Se | 82 | 1443.258 | 1.3 | 1139.011 | 1.07506 | 0.229 | 21.3 | ug/L |
| Kr | 83 | 1476.479 | 1.7 | 1141.423 | | | | mg/L |
| Y | 89 | 383029.330 | 2.7 | 354910.360 | | | | ug/L |
| Mo | 95 | 415.014 | 4.0 | 114.335 | 0.05948 | 0.001 | 1.7 | ug/L |
| Mo | 97 | 201.338 | 4.6 | 49.001 | 0.04637 | 0.004 | 7.8 | ug/L |
| Mo | 98 | 496.704 | 4.7 | 58.127 | 0.05194 | 0.001 | 2.6 | ug/L |
| Rh | 103 | 341480.756 | 3.4 | 323620.727 | | | | ug/L |
| Ag | 107 | 80.001 | 11.5 | 57.001 | 0.00179 | 0.001 | 44.3 | ug/L |
| Ag | 109 | 56.334 | 8.2 | 41.334 | 0.00120 | 0.000 | 40.0 | ug/L |
| Cd | 111 | 221.604 | 4.8 | 233.296 | -0.00372 | 0.005 | 142.7 | ug/L |
| Cd | 114 | 74.641 | 28.9 | 64.652 | 0.00141 | 0.003 | 201.1 | ug/L |
| > In | 115 | 364243.383 | 2.7 | 364581.825 | | | | ug/L |
| Sb | 121 | 189.004 | 9.2 | 51.001 | 0.01451 | 0.002 | 15.5 | ug/L |
| Sb | 123 | 149.569 | 5.0 | 45.100 | 0.01460 | 0.001 | 4.6 | ug/L |
| Ba | 135 | 4979.537 | 1.7 | 65.001 | 1.97646 | 0.039 | 2.0 | ug/L |
| Ba | 137 | 8704.632 | 2.0 | 74.668 | 2.07140 | 0.045 | 2.2 | ug/L |
| > Tb | 159 | 442330.642 | 0.4 | 439210.410 | | | | ug/L |
| > Ho | 165 | 412057.647 | 0.6 | 425708.154 | | | | ug/L |
| Tl | 203 | 92.668 | 14.7 | 51.001 | 0.00570 | 0.002 | 30.0 | ug/L |
| Tl | 205 | 163.337 | 0.9 | 72.668 | 0.00539 | 0.000 | 0.5 | ug/L |
| Pb | 208 | 2320.814 | 3.6 | 767.689 | 0.06571 | 0.004 | 6.2 | ug/L |

Sample ID: 950030D D.5

Report Date/Time: Tuesday, November 21, 2006 12:58:09

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 615.029 | 3.6 | 194.671 | 0.06748 | 0.004 | 5.4 ug/L |
| | Pb | 207 | 514.354 | 1.6 | 181.671 | 0.06436 | 0.002 | 3.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 104.145 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 103.593 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 99.907 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 100.710 | | | |
| > Ho | 165 | | 96.793 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| L Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030S D.5

Sample Date/Time: Tuesday, November 21, 2006 13:01:06

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950030S D.5.035

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 4378.527 | 2.2 | 54.001 | 3.93306 | 0.130 | 3.3 | ug/L |
| Al | 27 | 443630.033 | 1.6 | 9687.584 | 50.32035 | 1.185 | 2.4 | ug/L |
| Sc | 45 | 392769.156 | 1.1 | 378480.621 | | | | ug/L |
| V | 51 | 76924.414 | 12.8 | 4514.855 | 4.86152 | 0.633 | 13.0 | ug/L |
| Cr | 52 | 112026.607 | 20.8 | 14908.140 | 7.42330 | 1.748 | 23.5 | ug/L |
| Cr | 53 | 10569.808 | 2.7 | 661.366 | 6.24226 | 0.206 | 3.3 | ug/L |
| Mn | 55 | 138468.086 | 1.3 | 587.693 | 7.93683 | 0.131 | 1.6 | ug/L |
| Co | 59 | 66610.856 | 1.3 | 242.339 | 4.41932 | 0.034 | 0.8 | ug/L |
| Ni | 60 | 19884.232 | 1.8 | 623.696 | 5.77519 | 0.139 | 2.4 | ug/L |
| Ni | 62 | 3081.934 | 2.3 | 504.354 | 5.00355 | 0.168 | 3.4 | ug/L |
| Cu | 63 | 36867.766 | 2.1 | 1290.783 | 4.58067 | 0.119 | 2.6 | ug/L |
| Cu | 65 | 17810.861 | 1.6 | 588.027 | 4.55197 | 0.102 | 2.2 | ug/L |
| Zn | 66 | 10781.748 | 2.7 | 2796.188 | 3.63935 | 0.139 | 3.8 | ug/L |
| Zn | 67 | 1910.238 | 1.5 | 500.354 | 3.78055 | 0.065 | 1.7 | ug/L |
| Zn | 68 | 8018.937 | 1.0 | 2052.621 | 3.75096 | 0.034 | 0.9 | ug/L |
| Ge | 72 | 203474.550 | 0.6 | 193550.369 | | | | ug/L |
| As | 75 | 10530.755 | 0.4 | 97.335 | 4.24772 | 0.011 | 0.2 | ug/L |
| Se | 77 | 969.456 | 0.8 | 187.669 | 4.31488 | 0.039 | 0.9 | ug/L |
| Se | 78 | 16827.646 | 3.3 | 13588.495 | 4.39064 | 1.052 | 24.0 | mg/L |
| Se | 82 | 2482.703 | 2.3 | 1139.011 | 5.14953 | 0.168 | 3.3 | ug/L |
| Kr | 83 | 1453.141 | 3.9 | 1141.423 | | | | mg/L |
| Y | 89 | 379066.466 | 2.1 | 354910.360 | | | | ug/L |
| Mo | 95 | 22718.157 | 1.6 | 114.335 | 4.40351 | 0.057 | 1.3 | ug/L |
| Mo | 97 | 14771.896 | 1.1 | 49.001 | 4.40856 | 0.080 | 1.8 | ug/L |
| Mo | 98 | 37850.548 | 2.8 | 58.127 | 4.40920 | 0.131 | 3.0 | ug/L |
| Rh | 103 | 341574.855 | 1.3 | 323620.727 | | | | ug/L |
| Ag | 107 | 55943.771 | 2.2 | 57.001 | 4.24521 | 0.123 | 2.9 | ug/L |
| Ag | 109 | 54223.401 | 1.4 | 41.334 | 4.24260 | 0.047 | 1.1 | ug/L |
| Cd | 111 | 12701.041 | 3.8 | 233.296 | 4.08220 | 0.180 | 4.4 | ug/L |
| Cd | 114 | 29480.472 | 1.9 | 64.652 | 4.21401 | 0.063 | 1.5 | ug/L |
| In | 115 | 369820.032 | 0.7 | 364581.825 | | | | ug/L |
| Sb | 121 | 41291.815 | 1.8 | 51.001 | 4.25893 | 0.072 | 1.7 | ug/L |
| Sb | 123 | 30303.835 | 1.4 | 45.100 | 4.16610 | 0.087 | 2.1 | ug/L |
| Ba | 135 | 15813.150 | 1.8 | 65.001 | 6.48554 | 0.187 | 2.9 | ug/L |
| Ba | 137 | 27047.430 | 1.1 | 74.668 | 6.62944 | 0.170 | 2.6 | ug/L |
| Tb | 159 | 432117.024 | 1.6 | 439210.410 | | | | ug/L |
| Ho | 165 | 420679.116 | 1.3 | 425708.154 | | | | ug/L |
| Tl | 203 | 32991.507 | 0.2 | 51.001 | 4.25276 | 0.056 | 1.3 | ug/L |
| Tl | 205 | 79941.812 | 1.7 | 72.668 | 4.53382 | 0.138 | 3.0 | ug/L |
| Pb | 208 | 107362.473 | 0.8 | 767.689 | 4.34860 | 0.070 | 1.6 | ug/L |

Sample ID: 950030S D.5

Report Date/Time: Tuesday, November 21, 2006 13:04:07

Page 1

| | | | | | | | | |
|--|----|-----|-----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 27430.012 | 0.6 | 194.671 | 4.22077 | 0.076 | 1.8 ug/L |
| | Pb | 207 | 22885.950 | 1.6 | 181.671 | 4.22879 | 0.097 | 2.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 103.775 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 105.127 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 101.437 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.385 | | | |
| > Ho | 165 | | 98.819 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Tuesday, November 21, 2006 13:07:04

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 6.036

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54186.855 | 2.0 | 54.001 | 50.28737 | 1.463 | 2.9 | ug/L |
| Al | 27 | 428214.052 | 0.4 | 9687.584 | 49.57244 | 0.641 | 1.3 | ug/L |
| > Sc | 45 | 384688.113 | 1.0 | 378480.621 | | | | ug/L |
| V | 51 | 772124.428 | 3.7 | 4514.855 | 52.77530 | 2.391 | 4.5 | ug/L |
| Cr | 52 | 651085.257 | 1.7 | 14908.140 | 49.95676 | 0.980 | 2.0 | ug/L |
| Cr | 53 | 80146.434 | 1.7 | 661.366 | 51.24033 | 0.406 | 0.8 | ug/L |
| Mn | 55 | 905453.486 | 1.0 | 587.693 | 52.42362 | 0.545 | 1.0 | ug/L |
| Co | 59 | 771849.927 | 2.6 | 242.339 | 51.72351 | 1.794 | 3.5 | ug/L |
| Ni | 60 | 165850.100 | 2.5 | 623.696 | 49.91761 | 0.641 | 1.3 | ug/L |
| Ni | 62 | 24926.143 | 1.4 | 504.354 | 48.15098 | 1.425 | 3.0 | ug/L |
| Cu | 63 | 402052.552 | 2.0 | 1290.783 | 52.00486 | 0.286 | 0.5 | ug/L |
| Cu | 65 | 191046.369 | 3.8 | 588.027 | 50.72300 | 1.454 | 2.9 | ug/L |
| Zn | 66 | 109849.098 | 1.2 | 2796.188 | 49.94232 | 1.314 | 2.6 | ug/L |
| Zn | 67 | 18999.160 | 1.5 | 500.354 | 50.78555 | 1.100 | 2.2 | ug/L |
| Zn | 68 | 80120.460 | 0.8 | 2052.621 | 50.21988 | 0.547 | 1.1 | ug/L |
| > Ge | 72 | 202212.332 | 1.5 | 193550.369 | | | | ug/L |
| As | 75 | 122937.066 | 0.4 | 97.335 | 50.35444 | 0.912 | 1.8 | ug/L |
| Se | 77 | 9423.460 | 1.9 | 187.669 | 51.88336 | 0.498 | 1.0 | ug/L |
| Se | 78 | 44102.899 | 2.3 | 13588.495 | 51.93732 | 0.728 | 1.4 | mg/L |
| Se | 82 | 14040.351 | 0.3 | 1139.011 | 51.82350 | 1.053 | 2.0 | ug/L |
| Kr | 83 | 1440.472 | 4.7 | 1141.423 | | | | mg/L |
| Y | 89 | 366270.034 | 1.4 | 354910.360 | | | | ug/L |
| Mo | 95 | 269199.859 | 2.8 | 114.335 | 53.71608 | 0.585 | 1.1 | ug/L |
| Mo | 97 | 166877.591 | 3.0 | 49.001 | 51.18123 | 0.639 | 1.2 | ug/L |
| Mo | 98 | 442188.577 | 1.3 | 58.127 | 52.87573 | 1.588 | 3.0 | ug/L |
| Rh | 103 | 328468.148 | 0.7 | 323620.727 | | | | ug/L |
| Ag | 107 | 666735.061 | 2.2 | 57.001 | 51.88659 | 0.569 | 1.1 | ug/L |
| Ag | 109 | 649227.905 | 1.6 | 41.334 | 52.09640 | 0.855 | 1.6 | ug/L |
| Cd | 111 | 149541.916 | 1.3 | 233.296 | 50.10405 | 0.216 | 0.4 | ug/L |
| Cd | 114 | 343057.656 | 1.8 | 64.652 | 50.36605 | 1.338 | 2.7 | ug/L |
| > In | 115 | 360893.256 | 1.7 | 364581.825 | | | | ug/L |
| Sb | 121 | 461600.389 | 0.6 | 51.001 | 48.85244 | 0.804 | 1.6 | ug/L |
| Sb | 123 | 355724.537 | 1.2 | 45.100 | 50.18112 | 0.264 | 0.5 | ug/L |
| Ba | 135 | 128362.096 | 1.3 | 65.001 | 54.27509 | 0.613 | 1.1 | ug/L |
| Ba | 137 | 219740.625 | 1.9 | 74.668 | 55.46266 | 1.159 | 2.1 | ug/L |
| > Tb | 159 | 420539.470 | 0.7 | 439210.410 | | | | ug/L |
| > Ho | 165 | 411673.005 | 0.7 | 425708.154 | | | | ug/L |
| Tl | 203 | 391162.921 | 2.2 | 51.001 | 51.59286 | 1.132 | 2.2 | ug/L |
| Tl | 205 | 908360.316 | 1.4 | 72.668 | 52.67689 | 1.036 | 2.0 | ug/L |
| Pb | 208 | 1245274.193 | 0.8 | 767.689 | 51.87264 | 0.479 | 0.9 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Tuesday, November 21, 2006 13:10:07

Page 1

855

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 329079.395 | 1.6 | 194.671 | 52.07224 | 0.777 | 1.5 ug/L |
| | Pb | 207 | 267763.831 | 1.2 | 181.671 | 50.91737 | 0.430 | 0.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 100.575 | | | | |
| Al | 27 | 99.145 | | | | |
| > Sc | 45 | | 101.640 | | | |
| V | 51 | 105.551 | | | | |
| Cr | 52 | 99.914 | | | | |
| Cr | 53 | 102.481 | | | | |
| Mn | 55 | 104.847 | | | | |
| Co | 59 | 103.447 | | | | |
| Ni | 60 | 99.835 | | | | |
| Ni | 62 | 96.302 | | | | |
| Cu | 63 | 104.010 | | | | |
| Cu | 65 | 101.446 | | | | |
| Zn | 66 | 99.885 | | | | |
| Zn | 67 | 101.571 | | | | |
| Zn | 68 | 100.440 | | | | |
| > Ge | 72 | | 104.475 | | | |
| As | 75 | 100.709 | | | | |
| Se | 77 | 103.767 | | | | |
| Se | 78 | 103.875 | | | | |
| Se | 82 | 103.647 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 107.432 | | | | |
| Mo | 97 | 102.362 | | | | |
| Mo | 98 | 105.751 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 103.773 | | | | |
| Ag | 109 | 104.193 | | | | |
| Cd | 111 | 100.208 | | | | |
| Cd | 114 | 100.732 | | | | |
| > In | 115 | | 98.988 | | | |
| Sb | 121 | 97.705 | | | | |
| Sb | 123 | 100.362 | | | | |
| Ba | 135 | 108.550 | | | | |
| Ba | 137 | 110.925 | | | | |
| > Tb | 159 | | 95.749 | | | |
| > Ho | 165 | | 96.703 | | | |
| Tl | 203 | 103.186 | | | | |
| Tl | 205 | 105.354 | | | | |
| Pb | 208 | 103.745 | | | | |
| Pb | 206 | 104.144 | | | | |
| Pb | 207 | 101.835 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Tuesday, November 21, 2006 13:13:02

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 7.037

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 50.667 | 11.6 | 54.001 | -0.00198 | 0.005 | 256.8 | ug/L |
| Al | 27 | 3376.051 | 2.1 | 9687.584 | -0.74973 | 0.012 | 1.6 | ug/L |
| Sc | 45 | 369172.344 | 1.4 | 378480.621 | | | | ug/L |
| V | 51 | 4351.782 | 1.8 | 4514.855 | -0.00374 | 0.002 | 53.5 | ug/L |
| Cr | 52 | 14883.097 | 1.7 | 14908.140 | 0.02799 | 0.016 | 56.0 | ug/L |
| Cr | 53 | 789.045 | 1.6 | 661.366 | 0.09671 | 0.005 | 5.4 | ug/L |
| Mn | 55 | 586.693 | 2.9 | 587.693 | 0.00001 | 0.001 | 8516.6 | ug/L |
| Co | 59 | 190.337 | 5.2 | 242.339 | -0.00361 | 0.001 | 21.5 | ug/L |
| Ni | 60 | 515.688 | 2.6 | 623.696 | -0.03378 | 0.004 | 12.6 | ug/L |
| Ni | 62 | 288.341 | 3.6 | 504.354 | -0.44403 | 0.023 | 5.1 | ug/L |
| Cu | 63 | 829.383 | 7.9 | 1290.783 | -0.06235 | 0.009 | 14.2 | ug/L |
| Cu | 65 | 438.349 | 4.8 | 588.027 | -0.04140 | 0.006 | 15.0 | ug/L |
| Zn | 66 | 1624.175 | 3.0 | 2796.188 | -0.57026 | 0.020 | 3.5 | ug/L |
| Zn | 67 | 320.009 | 7.9 | 500.354 | -0.51625 | 0.067 | 13.1 | ug/L |
| Zn | 68 | 1219.435 | 3.9 | 2052.621 | -0.55907 | 0.027 | 4.8 | ug/L |
| Ge | 72 | 193169.869 | 0.7 | 193550.369 | | | | ug/L |
| As | 75 | 131.002 | 6.1 | 97.335 | 0.01454 | 0.004 | 25.9 | ug/L |
| Se | 77 | 208.536 | 4.7 | 187.669 | 0.12504 | 0.058 | 46.5 | ug/L |
| Se | 78 | 14270.965 | 1.1 | 13588.495 | 1.29049 | 0.374 | 29.0 | mg/L |
| Se | 82 | 1377.114 | 0.3 | 1139.011 | 1.01462 | 0.046 | 4.5 | ug/L |
| Kr | 83 | 1437.805 | 0.5 | 1141.423 | | | | mg/L |
| Y | 89 | 361508.896 | 3.1 | 354910.360 | | | | ug/L |
| Mo | 95 | 514.355 | 14.3 | 114.335 | 0.08102 | 0.014 | 16.8 | ug/L |
| Mo | 97 | 304.675 | 19.4 | 49.001 | 0.07938 | 0.017 | 21.4 | ug/L |
| Mo | 98 | 687.755 | 19.6 | 58.127 | 0.07605 | 0.015 | 20.1 | ug/L |
| Rh | 103 | 339310.595 | 1.7 | 323620.727 | | | | ug/L |
| Ag | 107 | 107.335 | 17.8 | 57.001 | 0.00404 | 0.001 | 34.9 | ug/L |
| Ag | 109 | 103.002 | 24.4 | 41.334 | 0.00506 | 0.002 | 39.5 | ug/L |
| Cd | 111 | 212.263 | 7.0 | 233.296 | -0.00554 | 0.005 | 98.2 | ug/L |
| Cd | 114 | 57.193 | 21.4 | 64.652 | -0.00090 | 0.002 | 211.4 | ug/L |
| In | 115 | 357338.674 | 1.4 | 364581.825 | | | | ug/L |
| Sb | 121 | 908.059 | 14.7 | 51.001 | 0.09162 | 0.013 | 14.4 | ug/L |
| Sb | 123 | 735.013 | 11.1 | 45.100 | 0.09833 | 0.010 | 10.3 | ug/L |
| Ba | 135 | 46.667 | 6.9 | 65.001 | -0.00743 | 0.001 | 12.4 | ug/L |
| Ba | 137 | 55.334 | 6.8 | 74.668 | -0.00467 | 0.001 | 13.7 | ug/L |
| Tb | 159 | 438943.395 | 2.3 | 439210.410 | | | | ug/L |
| Ho | 165 | 408216.159 | 0.9 | 425708.154 | | | | ug/L |
| Tl | 203 | 70.334 | 10.8 | 51.001 | 0.00285 | 0.001 | 34.1 | ug/L |
| Tl | 205 | 122.335 | 6.0 | 72.668 | 0.00308 | 0.000 | 14.4 | ug/L |
| Pb | 208 | 385.674 | 11.4 | 767.689 | -0.01472 | 0.002 | 13.1 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Tuesday, November 21, 2006 13:16:03

Page 1

858

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|-----------|
| | Pb | 206 | 107.335 | 19.6 | 194.671 | -0.01265 | 0.003 | 27.6 ug/L |
| | Pb | 207 | 92.335 | 11.3 | 181.671 | -0.01571 | 0.002 | 12.6 ug/L |

Sample ID: QC Std 7

Report Date/Time: Tuesday, November 21, 2006 13:16:03

Page 2

859

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 97.541 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 99.803 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.013 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.939 | | | |
| > Ho | 165 | | 95.891 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030A D.5

Sample Date/Time: Tuesday, November 21, 2006 13:18:59

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950030A D.5.038

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 38324.695 | 88.5 | 54.001 | 36.08310 | 32.614 | 90.4 | ug/L |
| Al | 27 | 610932.691 | 44.6 | 9687.584 | 71.71003 | 34.447 | 48.0 | ug/L |
| > Sc | 45 | 385523.002 | 3.0 | 378480.621 | | | | ug/L |
| V | 51 | 551187.747 | 89.4 | 4514.855 | 38.14663 | 35.076 | 91.9 | ug/L |
| Cr | 52 | 480110.155 | 85.2 | 14908.140 | 37.06221 | 33.325 | 89.9 | ug/L |
| Cr | 53 | 58188.900 | 83.7 | 661.366 | 37.61573 | 32.571 | 86.6 | ug/L |
| Mn | 55 | 665239.303 | 80.3 | 587.693 | 41.28588 | 33.564 | 81.3 | ug/L |
| Co | 59 | 524330.501 | 86.3 | 242.339 | 37.71036 | 32.800 | 87.0 | ug/L |
| Ni | 60 | 125274.109 | 88.1 | 623.696 | 40.42539 | 36.056 | 89.2 | ug/L |
| Ni | 62 | 17946.544 | 87.0 | 504.354 | 36.94891 | 33.343 | 90.2 | ug/L |
| Cu | 63 | 279332.085 | 87.7 | 1290.783 | 38.75221 | 34.373 | 88.7 | ug/L |
| Cu | 65 | 133035.849 | 91.3 | 588.027 | 37.88653 | 34.947 | 92.2 | ug/L |
| Zn | 66 | 71669.164 | 86.6 | 2796.188 | 34.55362 | 31.349 | 90.7 | ug/L |
| Zn | 67 | 12735.245 | 85.5 | 500.354 | 36.11819 | 32.373 | 89.6 | ug/L |
| Zn | 68 | 52003.508 | 87.3 | 2052.621 | 34.55322 | 31.620 | 91.5 | ug/L |
| > Ge | 72 | 191313.874 | 3.9 | 193550.369 | | | | ug/L |
| As | 75 | 86604.799 | 90.9 | 97.335 | 38.06933 | 34.856 | 91.6 | ug/L |
| Se | 77 | 6232.933 | 85.6 | 187.669 | 36.50122 | 32.457 | 88.9 | ug/L |
| Se | 78 | 33862.154 | 50.5 | 13588.495 | 38.10561 | 32.794 | 86.1 | mg/L |
| Se | 82 | 9685.971 | 74.5 | 1139.011 | 37.03300 | 31.619 | 85.4 | ug/L |
| Kr | 83 | 1454.475 | 1.1 | 1141.423 | | | | mg/L |
| Y | 89 | 364559.704 | 1.6 | 354910.360 | | | | ug/L |
| Mo | 95 | 183969.118 | 87.8 | 114.335 | 36.82476 | 32.397 | 88.0 | ug/L |
| Mo | 97 | 114593.172 | 91.9 | 49.001 | 35.25877 | 32.429 | 92.0 | ug/L |
| Mo | 98 | 299486.792 | 88.1 | 58.127 | 35.91241 | 31.691 | 88.2 | ug/L |
| Rh | 103 | 324914.766 | 1.1 | 323620.727 | | | | ug/L |
| Ag | 107 | 422902.310 | 58.8 | 57.001 | 33.00423 | 19.453 | 58.9 | ug/L |
| Ag | 109 | 384829.266 | 56.9 | 41.334 | 30.96302 | 17.666 | 57.1 | ug/L |
| Cd | 111 | 102719.856 | 93.7 | 233.296 | 34.50189 | 32.429 | 94.0 | ug/L |
| Cd | 114 | 221712.125 | 91.6 | 64.652 | 32.64489 | 29.928 | 91.7 | ug/L |
| > In | 115 | 360318.812 | 0.4 | 364581.825 | | | | ug/L |
| Sb | 121 | 316695.253 | 88.3 | 51.001 | 33.61642 | 29.733 | 88.4 | ug/L |
| Sb | 123 | 248236.902 | 89.3 | 45.100 | 35.12664 | 31.389 | 89.4 | ug/L |
| Ba | 135 | 83552.640 | 57.4 | 65.001 | 35.54698 | 20.372 | 57.3 | ug/L |
| Ba | 137 | 145200.302 | 57.2 | 74.668 | 36.87650 | 21.033 | 57.0 | ug/L |
| > Tb | 159 | 418120.374 | 0.9 | 439210.410 | | | | ug/L |
| > Ho | 165 | 398192.988 | 2.0 | 425708.154 | | | | ug/L |
| Tl | 203 | 263421.167 | 88.0 | 51.001 | 36.33372 | 32.467 | 89.4 | ug/L |
| Tl | 205 | 590188.109 | 87.2 | 72.668 | 35.78613 | 31.712 | 88.6 | ug/L |
| Pb | 208 | 803968.171 | 90.7 | 767.689 | 35.02425 | 32.265 | 92.1 | ug/L |

Sample ID: 950030A D.5

Report Date/Time: Tuesday, November 21, 2006 13:22:00

Page 1

861

| | | | | | | | | | |
|--|----|-----|------------|------|---------|----------|--------|------|------|
| | Pb | 206 | 212819.965 | 90.0 | 194.671 | 35.21782 | 32.198 | 91.4 | ug/L |
| | Pb | 207 | 175278.239 | 92.8 | 181.671 | 34.86540 | 32.836 | 94.2 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 101.861 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 98.844 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 98.831 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 95.198 | | | |
| > [Ho | 165 | | 93.537 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030L D.5

Sample Date/Time: Tuesday, November 21, 2006 13:24:57

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950030L D.5.039

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 56.334 | 11.8 | 54.001 | 0.00428 | 0.006 | 144.8 | ug/L |
| Al | 27 | 63649.313 | 3.5 | 9687.584 | 6.80097 | 0.227 | 3.3 | ug/L |
| > Sc | 45 | 364055.302 | 0.7 | 378480.621 | | | | ug/L |
| V | 51 | 4523.105 | 3.7 | 4514.855 | 0.01305 | 0.010 | 77.8 | ug/L |
| Cr | 52 | 18631.000 | 2.8 | 14908.140 | 0.35622 | 0.044 | 12.4 | ug/L |
| Cr | 53 | 1278.444 | 2.4 | 661.366 | 0.43771 | 0.026 | 6.0 | ug/L |
| Mn | 55 | 11519.739 | 0.5 | 587.693 | 0.65734 | 0.003 | 0.5 | ug/L |
| Co | 59 | 460.351 | 2.9 | 242.339 | 0.01506 | 0.001 | 5.8 | ug/L |
| Ni | 60 | 1114.753 | 5.6 | 623.696 | 0.15288 | 0.020 | 13.3 | ug/L |
| Ni | 62 | 345.344 | 2.5 | 504.354 | -0.33214 | 0.018 | 5.5 | ug/L |
| Cu | 63 | 688.035 | 2.8 | 1290.783 | -0.08231 | 0.003 | 3.4 | ug/L |
| Cu | 65 | 364.345 | 5.8 | 588.027 | -0.06288 | 0.006 | 9.4 | ug/L |
| Zn | 66 | 1558.828 | 5.4 | 2796.188 | -0.60840 | 0.039 | 6.5 | ug/L |
| Zn | 67 | 329.010 | 0.8 | 500.354 | -0.49782 | 0.008 | 1.6 | ug/L |
| Zn | 68 | 1201.765 | 0.6 | 2052.621 | -0.57746 | 0.005 | 0.8 | ug/L |
| > Ge | 72 | 194756.789 | 0.2 | 193550.369 | | | | ug/L |
| As | 75 | 131.002 | 5.3 | 97.335 | 0.01407 | 0.003 | 21.8 | ug/L |
| Se | 77 | 215.003 | 1.6 | 187.669 | 0.15277 | 0.022 | 14.4 | ug/L |
| Se | 78 | 14165.216 | 0.1 | 13588.495 | 0.88734 | 0.046 | 5.2 | mg/L |
| Se | 82 | 1362.111 | 1.1 | 1139.011 | 0.90421 | 0.053 | 5.8 | ug/L |
| Kr | 83 | 1434.471 | 1.0 | 1141.423 | | | | mg/L |
| Y | 89 | 356521.641 | 1.7 | 354910.360 | | | | ug/L |
| Mo | 95 | 235.339 | 10.1 | 114.335 | 0.02487 | 0.004 | 18.0 | ug/L |
| Mo | 97 | 118.669 | 6.9 | 49.001 | 0.02193 | 0.005 | 12.4 | ug/L |
| Mo | 98 | 259.357 | 0.9 | 58.127 | 0.02446 | 0.000 | 1.2 | ug/L |
| Rh | 103 | 318935.239 | 1.8 | 323620.727 | | | | ug/L |
| Ag | 107 | 84.001 | 8.6 | 57.001 | 0.00222 | 0.001 | 26.5 | ug/L |
| Ag | 109 | 67.668 | 13.7 | 41.334 | 0.00221 | 0.001 | 35.6 | ug/L |
| Cd | 111 | 221.814 | 7.7 | 233.296 | -0.00226 | 0.006 | 259.5 | ug/L |
| Cd | 114 | 56.060 | 17.8 | 64.652 | -0.00108 | 0.001 | 137.5 | ug/L |
| > In | 115 | 357065.602 | 0.7 | 364581.825 | | | | ug/L |
| Sb | 121 | 446.350 | 9.8 | 51.001 | 0.04241 | 0.005 | 11.6 | ug/L |
| Sb | 123 | 364.366 | 17.2 | 45.100 | 0.04569 | 0.009 | 20.2 | ug/L |
| Ba | 135 | 990.735 | 2.8 | 65.001 | 0.39587 | 0.017 | 4.4 | ug/L |
| Ba | 137 | 1671.518 | 1.5 | 74.668 | 0.40691 | 0.003 | 0.7 | ug/L |
| > Tb | 159 | 417628.564 | 1.5 | 439210.410 | | | | ug/L |
| > Ho | 165 | 405417.238 | 1.3 | 425708.154 | | | | ug/L |
| Tl | 203 | 61.001 | 9.1 | 51.001 | 0.00167 | 0.001 | 44.0 | ug/L |
| Tl | 205 | 100.002 | 8.9 | 72.668 | 0.00181 | 0.000 | 25.0 | ug/L |
| Pb | 208 | 976.365 | 3.9 | 767.689 | 0.01037 | 0.001 | 12.0 | ug/L |

Sample ID: 950030L D.5

Report Date/Time: Tuesday, November 21, 2006 13:27:58

Page 1

864

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 256.006 | 1.4 | 194.671 | 0.01136 | 0.001 | 9.1 ug/L |
| | Pb | 207 | 231.339 | 2.6 | 181.671 | 0.01127 | 0.001 | 6.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 96.189 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 100.623 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 97.938 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 95.086 | | | |
| > Ho | 165 | | 95.234 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950031 D.5

Sample Date/Time: Tuesday, November 21, 2006 13:30:55

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950031 D.5.040

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55.334 | 8.3 | 54.001 | 0.00124 | 0.003 | 265.9 | ug/L |
| Al | 27 | 1138877.059 | 0.3 | 9687.584 | 136.15097 | 5.098 | 3.7 | ug/L |
| > Sc | 45 | 378355.456 | 3.7 | 378480.621 | | | | ug/L |
| V | 51 | 9343.354 | 11.6 | 4514.855 | 0.33633 | 0.051 | 15.2 | ug/L |
| Cr | 52 | 107785.301 | 2.6 | 14908.140 | 7.42236 | 0.247 | 3.3 | ug/L |
| Cr | 53 | 11211.984 | 1.5 | 661.366 | 6.92098 | 0.182 | 2.6 | ug/L |
| Mn | 55 | 146491.579 | 1.0 | 587.693 | 8.70194 | 0.133 | 1.5 | ug/L |
| Co | 59 | 5316.416 | 2.0 | 242.339 | 0.34984 | 0.007 | 1.9 | ug/L |
| Ni | 60 | 15645.165 | 1.8 | 623.696 | 4.67188 | 0.167 | 3.6 | ug/L |
| Ni | 62 | 2346.021 | 4.2 | 504.354 | 3.72561 | 0.206 | 5.5 | ug/L |
| Cu | 63 | 5076.598 | 3.2 | 1290.783 | 0.50363 | 0.033 | 6.5 | ug/L |
| Cu | 65 | 2531.076 | 0.6 | 588.027 | 0.53054 | 0.009 | 1.7 | ug/L |
| Zn | 66 | 3102.609 | 2.7 | 2796.188 | 0.12800 | 0.065 | 50.7 | ug/L |
| Zn | 67 | 604.695 | 3.1 | 500.354 | 0.27386 | 0.028 | 10.1 | ug/L |
| Zn | 68 | 2590.762 | 3.5 | 2052.621 | 0.33615 | 0.032 | 9.5 | ug/L |
| > Ge | 72 | 196433.249 | 1.7 | 193550.369 | | | | ug/L |
| As | 75 | 613.029 | 1.3 | 97.335 | 0.21706 | 0.008 | 3.5 | ug/L |
| Se | 77 | 242.870 | 0.6 | 187.669 | 0.30368 | 0.030 | 10.0 | ug/L |
| Se | 78 | 14351.672 | 1.5 | 13588.495 | 1.00949 | 0.700 | 69.3 | mg/L |
| Se | 82 | 1433.990 | 2.3 | 1139.011 | 1.15620 | 0.221 | 19.1 | ug/L |
| Kr | 83 | 1430.137 | 2.3 | 1141.423 | | | | mg/L |
| Y | 89 | 380132.168 | 1.6 | 354910.360 | | | | ug/L |
| Mo | 95 | 1879.231 | 2.4 | 114.335 | 0.35439 | 0.016 | 4.5 | ug/L |
| Mo | 97 | 1229.770 | 2.7 | 49.001 | 0.36430 | 0.018 | 5.0 | ug/L |
| Mo | 98 | 2983.618 | 2.1 | 58.127 | 0.35160 | 0.017 | 4.9 | ug/L |
| Rh | 103 | 336156.205 | 1.5 | 323620.727 | | | | ug/L |
| Ag | 107 | 81.001 | 4.5 | 57.001 | 0.00195 | 0.000 | 22.7 | ug/L |
| Ag | 109 | 67.668 | 10.4 | 41.334 | 0.00218 | 0.001 | 33.3 | ug/L |
| Cd | 111 | 235.218 | 4.6 | 233.296 | 0.00177 | 0.003 | 180.5 | ug/L |
| Cd | 114 | 88.646 | 64.2 | 64.652 | 0.00352 | 0.008 | 227.9 | ug/L |
| > In | 115 | 359415.710 | 2.9 | 364581.825 | | | | ug/L |
| Sb | 121 | 365.678 | 4.9 | 51.001 | 0.03351 | 0.001 | 4.0 | ug/L |
| Sb | 123 | 265.367 | 3.4 | 45.100 | 0.03132 | 0.002 | 6.2 | ug/L |
| Ba | 135 | 7149.804 | 0.3 | 65.001 | 2.90592 | 0.038 | 1.3 | ug/L |
| Ba | 137 | 12347.264 | 0.4 | 74.668 | 3.00425 | 0.053 | 1.8 | ug/L |
| > Tb | 159 | 433837.456 | 1.5 | 439210.410 | | | | ug/L |
| > Ho | 165 | 412871.702 | 2.4 | 425708.154 | | | | ug/L |
| Tl | 203 | 200.671 | 8.7 | 51.001 | 0.01986 | 0.002 | 8.3 | ug/L |
| Tl | 205 | 427.015 | 6.3 | 72.668 | 0.02061 | 0.001 | 6.1 | ug/L |
| Pb | 208 | 7575.428 | 3.3 | 767.689 | 0.28387 | 0.007 | 2.4 | ug/L |

Sample ID: 950031 D.5

Report Date/Time: Tuesday, November 21, 2006 13:33:57

Page 1

867

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 1909.571 | 2.5 | 194.671 | 0.27170 | 0.007 | 2.5 ug/L |
| | Pb | 207 | 1645.512 | 4.6 | 181.671 | 0.27876 | 0.012 | 4.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 99.967 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 101.489 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 98.583 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.777 | | | |
| > [Ho | 165 | | 96.985 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950032 D.5

Sample Date/Time: Tuesday, November 21, 2006 13:36:54

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950032 D.5.041

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 280.341 | 5.5 | 54.001 | 0.20555 | 0.019 | 9.0 | ug/L |
| Al | 27 | 5745599.490 | 2.1 | 9687.584 | 669.00012 | 9.990 | 1.5 | ug/L |
| > Sc | 45 | 390890.483 | 3.5 | 378480.621 | | | | ug/L |
| V | 51 | 13791.260 | 6.2 | 4514.855 | 0.61801 | 0.061 | 9.8 | ug/L |
| Cr | 52 | 131192.345 | 2.5 | 14908.140 | 8.95993 | 0.443 | 4.9 | ug/L |
| Cr | 53 | 14978.600 | 1.1 | 661.366 | 9.07646 | 0.233 | 2.6 | ug/L |
| Mn | 55 | 1813046.684 | 1.7 | 587.693 | 108.28219 | 2.627 | 2.4 | ug/L |
| Co | 59 | 54860.569 | 1.7 | 242.339 | 3.77400 | 0.040 | 1.1 | ug/L |
| Ni | 60 | 48997.851 | 2.7 | 623.696 | 15.07261 | 0.487 | 3.2 | ug/L |
| Ni | 62 | 7432.721 | 1.4 | 504.354 | 14.08146 | 0.240 | 1.7 | ug/L |
| Cu | 63 | 8631.225 | 4.0 | 1290.783 | 0.97991 | 0.038 | 3.8 | ug/L |
| Cu | 65 | 3618.155 | 0.6 | 588.027 | 0.83025 | 0.011 | 1.3 | ug/L |
| Zn | 66 | 34456.768 | 0.6 | 2796.188 | 15.22730 | 0.189 | 1.2 | ug/L |
| Zn | 67 | 5720.354 | 2.2 | 500.354 | 14.77507 | 0.417 | 2.8 | ug/L |
| Zn | 68 | 26424.453 | 3.1 | 2052.621 | 16.16911 | 0.677 | 4.2 | ug/L |
| > Ge | 72 | 196105.973 | 0.7 | 193550.369 | | | | ug/L |
| As | 75 | 1005.404 | 4.8 | 97.335 | 0.38315 | 0.018 | 4.6 | ug/L |
| Se | 77 | 310.806 | 2.8 | 187.669 | 0.69966 | 0.054 | 7.7 | ug/L |
| Se | 78 | 14372.575 | 2.4 | 13588.495 | 1.08582 | 0.745 | 68.6 | mg/L |
| Se | 82 | 1433.257 | 0.8 | 1139.011 | 1.16084 | 0.032 | 2.7 | ug/L |
| Kr | 83 | 1467.477 | 1.0 | 1141.423 | | | | mg/L |
| Y | 89 | 422407.033 | 2.8 | 354910.360 | | | | ug/L |
| Mo | 95 | 976.400 | 2.3 | 114.335 | 0.17304 | 0.006 | 3.5 | ug/L |
| Mo | 97 | 574.692 | 2.0 | 49.001 | 0.16210 | 0.006 | 3.7 | ug/L |
| Mo | 98 | 1375.477 | 4.4 | 58.127 | 0.15820 | 0.010 | 6.0 | ug/L |
| Rh | 103 | 326838.821 | 1.1 | 323620.727 | | | | ug/L |
| Ag | 107 | 115.669 | 8.9 | 57.001 | 0.00465 | 0.001 | 19.4 | ug/L |
| Ag | 109 | 85.335 | 2.7 | 41.334 | 0.00359 | 0.000 | 1.8 | ug/L |
| Cd | 111 | 872.959 | 8.4 | 233.296 | 0.21641 | 0.024 | 11.2 | ug/L |
| Cd | 114 | 1777.711 | 2.3 | 64.652 | 0.25245 | 0.002 | 0.9 | ug/L |
| > In | 115 | 359700.565 | 2.0 | 364581.825 | | | | ug/L |
| Sb | 121 | 280.674 | 6.7 | 51.001 | 0.02449 | 0.002 | 10.2 | ug/L |
| Sb | 123 | 226.117 | 0.9 | 45.100 | 0.02572 | 0.001 | 3.1 | ug/L |
| Ba | 135 | 27673.818 | 0.6 | 65.001 | 11.36706 | 0.202 | 1.8 | ug/L |
| Ba | 137 | 48263.565 | 2.5 | 74.668 | 11.83897 | 0.251 | 2.1 | ug/L |
| > Tb | 159 | 432171.665 | 1.2 | 439210.410 | | | | ug/L |
| > Ho | 165 | 410072.164 | 1.2 | 425708.154 | | | | ug/L |
| Tl | 203 | 903.059 | 16.4 | 51.001 | 0.11296 | 0.018 | 16.4 | ug/L |
| Tl | 205 | 2033.941 | 18.9 | 72.668 | 0.11420 | 0.021 | 18.6 | ug/L |
| Pb | 208 | 13506.744 | 1.2 | 767.689 | 0.53423 | 0.007 | 1.3 | ug/L |

Sample ID: 950032 D.5

Report Date/Time: Tuesday, November 21, 2006 13:39:55

Page 1

870

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 3535.786 | 2.5 | 194.671 | 0.53222 | 0.014 | 2.7 ug/L |
| | Pb | 207 | 2856.518 | 2.0 | 181.671 | 0.51221 | 0.005 | 1.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 103.279 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 101.320 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.661 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.397 | | | |
| > Ho | 165 | | 96.327 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950034 D.100

Sample Date/Time: Tuesday, November 21, 2006 13:42:53

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950034 D.100.042

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54.001 | 6.4 | 54.001 | 0.00195 | 0.003 | 165.5 | ug/L |
| Al | 27 | 78706.595 | 2.9 | 9687.584 | 8.67446 | 0.284 | 3.3 | ug/L |
| > Sc | 45 | 364521.576 | 0.4 | 378480.621 | | | | ug/L |
| V | 51 | 4281.229 | 4.5 | 4514.855 | -0.00484 | 0.015 | 305.4 | ug/L |
| Cr | 52 | 20354.032 | 1.1 | 14908.140 | 0.49708 | 0.024 | 4.8 | ug/L |
| Cr | 53 | 1620.174 | 5.3 | 661.366 | 0.66909 | 0.060 | 8.9 | ug/L |
| Mn | 55 | 630491.805 | 1.7 | 587.693 | 38.42308 | 0.785 | 2.0 | ug/L |
| Co | 59 | 1593.502 | 4.8 | 242.339 | 0.09547 | 0.005 | 5.6 | ug/L |
| Ni | 60 | 1381.128 | 1.9 | 623.696 | 0.24251 | 0.008 | 3.2 | ug/L |
| Ni | 62 | 382.679 | 3.1 | 504.354 | -0.24470 | 0.023 | 9.3 | ug/L |
| Cu | 63 | 1214.767 | 2.7 | 1290.783 | -0.00904 | 0.004 | 39.2 | ug/L |
| Cu | 65 | 592.027 | 5.2 | 588.027 | 0.00244 | 0.010 | 403.4 | ug/L |
| Zn | 66 | 1165.093 | 2.2 | 2796.188 | -0.79137 | 0.008 | 1.0 | ug/L |
| Zn | 67 | 270.674 | 6.5 | 500.354 | -0.65302 | 0.060 | 9.1 | ug/L |
| Zn | 68 | 905.725 | 3.1 | 2052.621 | -0.76702 | 0.012 | 1.6 | ug/L |
| > Ge | 72 | 192067.944 | 1.2 | 193550.369 | | | | ug/L |
| As | 75 | 232.006 | 4.4 | 97.335 | 0.05842 | 0.004 | 6.1 | ug/L |
| Se | 77 | 215.603 | 3.7 | 187.669 | 0.17434 | 0.062 | 35.3 | ug/L |
| Se | 78 | 13592.815 | 1.1 | 13588.495 | 0.19935 | 0.275 | 138.0 | mg/L |
| Se | 82 | 1359.044 | 1.0 | 1139.011 | 0.97142 | 0.068 | 7.0 | ug/L |
| Kr | 83 | 1405.133 | 2.7 | 1141.423 | | | | mg/L |
| Y | 89 | 351643.310 | 1.9 | 354910.360 | | | | ug/L |
| Mo | 95 | 217.338 | 10.1 | 114.335 | 0.02127 | 0.005 | 21.8 | ug/L |
| Mo | 97 | 100.335 | 14.1 | 49.001 | 0.01622 | 0.004 | 26.6 | ug/L |
| Mo | 98 | 188.134 | 4.1 | 58.127 | 0.01585 | 0.001 | 5.3 | ug/L |
| Rh | 103 | 309973.389 | 1.3 | 323620.727 | | | | ug/L |
| Ag | 107 | 54.334 | 25.8 | 57.001 | -0.00012 | 0.001 | 876.2 | ug/L |
| Ag | 109 | 47.667 | 13.5 | 41.334 | 0.00058 | 0.001 | 89.4 | ug/L |
| Cd | 111 | 214.387 | 8.6 | 233.296 | -0.00482 | 0.006 | 119.5 | ug/L |
| Cd | 114 | 82.864 | 15.6 | 64.652 | 0.00289 | 0.002 | 63.8 | ug/L |
| > In | 115 | 357138.230 | 0.6 | 364581.825 | | | | ug/L |
| Sb | 121 | 141.003 | 10.5 | 51.001 | 0.00974 | 0.002 | 17.2 | ug/L |
| Sb | 123 | 126.429 | 16.2 | 45.100 | 0.01172 | 0.003 | 24.7 | ug/L |
| Ba | 135 | 1098.083 | 3.2 | 65.001 | 0.44362 | 0.017 | 3.7 | ug/L |
| Ba | 137 | 1862.227 | 2.3 | 74.668 | 0.45756 | 0.010 | 2.2 | ug/L |
| > Tb | 159 | 415791.053 | 2.3 | 439210.410 | | | | ug/L |
| > Ho | 165 | 413577.025 | 0.8 | 425708.154 | | | | ug/L |
| Tl | 203 | 180.004 | 4.5 | 51.001 | 0.01713 | 0.001 | 7.0 | ug/L |
| Tl | 205 | 381.013 | 6.4 | 72.668 | 0.01792 | 0.002 | 8.7 | ug/L |
| Pb | 208 | 1274.716 | 1.6 | 767.689 | 0.02194 | 0.000 | 2.1 | ug/L |

Sample ID: 950034 D.100

Report Date/Time: Tuesday, November 21, 2006 13:45:54

Page 1

873

| | | | | | | | | | |
|---|----|-----|---------|-----|---------|---------|-------|-----|------|
| | Pb | 206 | 360.011 | 4.4 | 194.671 | 0.02693 | 0.002 | 8.6 | ug/L |
| L | Pb | 207 | 279.674 | 2.9 | 181.671 | 0.01955 | 0.002 | 8.8 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 96.312 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 99.234 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 97.958 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 94.668 | | | |
| > Ho | 165 | | 97.150 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950034 D.5

Sample Date/Time: Tuesday, November 21, 2006 13:48:52

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950034 D.5.043

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 72.668 | 3.2 | 54.001 | 0.01693 | 0.001 | 5.7 | ug/L |
| Al | 27 | 1624012.055 | 10.0 | 9687.584 | 192.81067 | 23.911 | 12.4 | ug/L |
| > Sc | 45 | 382289.000 | 2.4 | 378480.621 | | | | ug/L |
| V | 51 | 10883.572 | 28.9 | 4514.855 | 0.43786 | 0.218 | 49.7 | ug/L |
| Cr | 52 | 148383.947 | 2.2 | 14908.140 | 10.54202 | 0.316 | 3.0 | ug/L |
| Cr | 53 | 16792.740 | 1.6 | 661.366 | 10.46336 | 0.088 | 0.8 | ug/L |
| Mn | 55 | 14436742.420 | 0.0 | 587.693 | 840.75894 | 10.049 | 1.2 | ug/L |
| Co | 59 | 29238.848 | 2.3 | 242.339 | 1.95330 | 0.068 | 3.5 | ug/L |
| Ni | 60 | 26733.087 | 1.8 | 623.696 | 7.92457 | 0.179 | 2.3 | ug/L |
| Ni | 62 | 3830.252 | 2.3 | 504.354 | 6.55690 | 0.181 | 2.8 | ug/L |
| Cu | 63 | 6837.873 | 0.9 | 1290.783 | 0.71717 | 0.014 | 1.9 | ug/L |
| Cu | 65 | 3535.119 | 1.9 | 588.027 | 0.78320 | 0.029 | 3.7 | ug/L |
| Zn | 66 | 5853.781 | 2.3 | 2796.188 | 1.38428 | 0.094 | 6.8 | ug/L |
| Zn | 67 | 1149.091 | 3.0 | 500.354 | 1.73797 | 0.096 | 5.5 | ug/L |
| Zn | 68 | 4751.402 | 1.5 | 2052.621 | 1.69524 | 0.073 | 4.3 | ug/L |
| > Ge | 72 | 201163.588 | 1.2 | 193550.369 | | | | ug/L |
| As | 75 | 2330.016 | 5.1 | 97.335 | 0.91824 | 0.047 | 5.1 | ug/L |
| Se | 77 | 265.271 | 7.8 | 187.669 | 0.39618 | 0.100 | 25.2 | ug/L |
| Se | 78 | 14481.789 | 1.0 | 13588.495 | 0.62893 | 0.403 | 64.0 | mg/L |
| Se | 82 | 1502.335 | 0.5 | 1139.011 | 1.29175 | 0.100 | 7.7 | ug/L |
| Kr | 83 | 1499.483 | 0.9 | 1141.423 | | | | mg/L |
| Y | 89 | 403255.822 | 1.1 | 354910.360 | | | | ug/L |
| Mo | 95 | 1315.117 | 1.9 | 114.335 | 0.24110 | 0.008 | 3.2 | ug/L |
| Mo | 97 | 730.706 | 4.9 | 49.001 | 0.21019 | 0.009 | 4.2 | ug/L |
| Mo | 98 | 1767.485 | 4.4 | 58.127 | 0.20531 | 0.009 | 4.6 | ug/L |
| Rh | 103 | 331244.603 | 2.0 | 323620.727 | | | | ug/L |
| Ag | 107 | 90.001 | 7.7 | 57.001 | 0.00264 | 0.000 | 17.9 | ug/L |
| Ag | 109 | 75.001 | 16.2 | 41.334 | 0.00276 | 0.001 | 35.3 | ug/L |
| Cd | 111 | 415.194 | 3.7 | 233.296 | 0.06245 | 0.007 | 10.5 | ug/L |
| Cd | 114 | 454.641 | 1.5 | 64.652 | 0.05762 | 0.000 | 0.6 | ug/L |
| > In | 115 | 359404.199 | 1.0 | 364581.825 | | | | ug/L |
| Sb | 121 | 314.676 | 3.0 | 51.001 | 0.02810 | 0.001 | 4.5 | ug/L |
| Sb | 123 | 219.486 | 9.8 | 45.100 | 0.02478 | 0.003 | 11.5 | ug/L |
| Ba | 135 | 21988.206 | 2.8 | 65.001 | 8.80582 | 0.284 | 3.2 | ug/L |
| Ba | 137 | 38077.509 | 0.3 | 74.668 | 9.11002 | 0.131 | 1.4 | ug/L |
| > Tb | 159 | 442956.324 | 1.3 | 439210.410 | | | | ug/L |
| > Ho | 165 | 416433.546 | 1.1 | 425708.154 | | | | ug/L |
| Tl | 203 | 1306.782 | 5.1 | 51.001 | 0.16392 | 0.009 | 5.4 | ug/L |
| Tl | 205 | 3225.996 | 12.1 | 72.668 | 0.18091 | 0.023 | 12.7 | ug/L |
| Pb | 208 | 13843.307 | 2.0 | 767.689 | 0.53943 | 0.008 | 1.5 | ug/L |

Sample ID: 950034 D.5

Report Date/Time: Tuesday, November 21, 2006 13:51:54

Page 1

876

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 3590.809 | 0.9 | 194.671 | 0.53223 | 0.004 | 0.7 ug/L |
| | Pb | 207 | 2938.214 | 2.9 | 181.671 | 0.51932 | 0.017 | 3.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 101.006 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 103.933 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 98.580 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 100.853 | | | |
| > [Ho | 165 | | 97.821 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950035 D.20

Sample Date/Time: Tuesday, November 21, 2006 13:54:51

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950035 D.20.044

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 47.667 | 10.6 | 54.001 | -0.00606 | 0.004 | 64.6 | ug/L |
| Al | 27 | 15201.673 | 1.5 | 9687.584 | 0.66279 | 0.024 | 3.6 | ug/L |
| > Sc | 45 | 378782.232 | 2.1 | 378480.621 | | | | ug/L |
| V | 51 | 4708.618 | 3.0 | 4514.855 | 0.01326 | 0.006 | 46.4 | ug/L |
| Cr | 52 | 17945.491 | 2.9 | 14908.140 | 0.24123 | 0.016 | 6.5 | ug/L |
| Cr | 53 | 1159.759 | 1.5 | 661.366 | 0.32638 | 0.027 | 8.2 | ug/L |
| Mn | 55 | 1109624.477 | 0.4 | 587.693 | 67.61997 | 0.359 | 0.5 | ug/L |
| Co | 59 | 1153.091 | 3.7 | 242.339 | 0.06435 | 0.002 | 3.7 | ug/L |
| Ni | 60 | 2236.990 | 5.1 | 623.696 | 0.51450 | 0.035 | 6.8 | ug/L |
| Ni | 62 | 462.684 | 3.2 | 504.354 | -0.07893 | 0.028 | 35.1 | ug/L |
| Cu | 63 | 915.393 | 4.9 | 1290.783 | -0.04996 | 0.007 | 14.0 | ug/L |
| Cu | 65 | 514.688 | 3.2 | 588.027 | -0.01935 | 0.005 | 24.3 | ug/L |
| Zn | 66 | 1228.436 | 1.1 | 2796.188 | -0.76036 | 0.011 | 1.5 | ug/L |
| Zn | 67 | 351.678 | 7.5 | 500.354 | -0.41987 | 0.067 | 15.9 | ug/L |
| Zn | 68 | 1140.423 | 2.6 | 2052.621 | -0.60801 | 0.024 | 3.9 | ug/L |
| > Ge | 72 | 192139.150 | 0.9 | 193550.369 | | | | ug/L |
| As | 75 | 153.670 | 5.8 | 97.335 | 0.02459 | 0.003 | 13.4 | ug/L |
| Se | 77 | 223.070 | 2.1 | 187.669 | 0.21763 | 0.029 | 13.4 | ug/L |
| Se | 78 | 14231.214 | 0.5 | 13588.495 | 1.35808 | 0.358 | 26.4 | mg/L |
| Se | 82 | 1440.324 | 1.8 | 1139.011 | 1.31460 | 0.153 | 11.7 | ug/L |
| Kr | 83 | 1383.462 | 5.0 | 1141.423 | | | | mg/L |
| Y | 89 | 367224.126 | 5.2 | 354910.360 | | | | ug/L |
| Mo | 95 | 5894.144 | 3.0 | 114.335 | 1.17654 | 0.032 | 2.7 | ug/L |
| Mo | 97 | 3638.497 | 1.6 | 49.001 | 1.12281 | 0.017 | 1.5 | ug/L |
| Mo | 98 | 9083.282 | 1.7 | 58.127 | 1.09967 | 0.005 | 0.4 | ug/L |
| Rh | 103 | 333992.726 | 1.1 | 323620.727 | | | | ug/L |
| Ag | 107 | 62.668 | 12.2 | 57.001 | 0.00058 | 0.001 | 104.6 | ug/L |
| Ag | 109 | 40.334 | 10.0 | 41.334 | 0.00001 | 0.000 | 2259.8 | ug/L |
| Cd | 111 | 248.296 | 5.4 | 233.296 | 0.00738 | 0.003 | 46.3 | ug/L |
| Cd | 114 | 145.211 | 14.0 | 64.652 | 0.01231 | 0.003 | 22.2 | ug/L |
| > In | 115 | 354155.578 | 1.4 | 364581.825 | | | | ug/L |
| Sb | 121 | 167.670 | 15.6 | 51.001 | 0.01274 | 0.003 | 22.5 | ug/L |
| Sb | 123 | 145.199 | 6.8 | 45.100 | 0.01457 | 0.001 | 8.9 | ug/L |
| Ba | 135 | 5954.520 | 0.9 | 65.001 | 2.42546 | 0.030 | 1.2 | ug/L |
| Ba | 137 | 10307.474 | 1.3 | 74.668 | 2.51490 | 0.037 | 1.5 | ug/L |
| > Tb | 159 | 432102.460 | 1.5 | 439210.410 | | | | ug/L |
| > Ho | 165 | 411191.961 | 0.9 | 425708.154 | | | | ug/L |
| Tl | 203 | 51.667 | 26.8 | 51.001 | 0.00033 | 0.002 | 578.0 | ug/L |
| Tl | 205 | 94.001 | 7.4 | 72.668 | 0.00138 | 0.000 | 26.3 | ug/L |
| Pb | 208 | 865.359 | 1.8 | 767.689 | 0.00517 | 0.001 | 15.0 | ug/L |

Sample ID: 950035 D.20

Report Date/Time: Tuesday, November 21, 2006 13:57:52

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|-----------|
| | Pb | 206 | 233.006 | 5.7 | 194.671 | 0.00712 | 0.002 | 26.2 ug/L |
| | Pb | 207 | 191.337 | 3.2 | 181.671 | 0.00302 | 0.001 | 36.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 100.080 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 99.271 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 97.140 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.382 | | | |
| > [Ho | 165 | | 96.590 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950036 D.500

Sample Date/Time: Tuesday, November 21, 2006 14:00:49

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950036 D.500.045

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 64.668 | 8.5 | 54.001 | 0.01173 | 0.006 | 50.1 | ug/L |
| Al | 27 | 181125.689 | 0.1 | 9687.584 | 21.23301 | 0.558 | 2.6 | ug/L |
| > Sc | 45 | 368706.503 | 2.6 | 378480.621 | | | | ug/L |
| V | 51 | 4429.278 | 0.5 | 4514.855 | 0.00235 | 0.007 | 308.3 | ug/L |
| Cr | 52 | 14854.378 | 1.6 | 14908.140 | 0.02801 | 0.050 | 178.3 | ug/L |
| Cr | 53 | 772.044 | 3.4 | 661.366 | 0.08587 | 0.004 | 5.0 | ug/L |
| Mn | 55 | 504234.364 | 1.0 | 587.693 | 30.46008 | 0.727 | 2.4 | ug/L |
| Co | 59 | 7753.685 | 2.7 | 242.339 | 0.52557 | 0.021 | 4.0 | ug/L |
| Ni | 60 | 4390.200 | 1.5 | 623.696 | 1.18816 | 0.040 | 3.4 | ug/L |
| Ni | 62 | 910.726 | 3.9 | 504.354 | 0.83676 | 0.101 | 12.1 | ug/L |
| Cu | 63 | 40955.206 | 3.3 | 1290.783 | 5.37560 | 0.265 | 4.9 | ug/L |
| Cu | 65 | 19288.157 | 1.1 | 588.027 | 5.19945 | 0.030 | 0.6 | ug/L |
| Zn | 66 | 7699.299 | 1.2 | 2796.188 | 2.38928 | 0.103 | 4.3 | ug/L |
| Zn | 67 | 1232.770 | 4.4 | 500.354 | 2.09845 | 0.107 | 5.1 | ug/L |
| Zn | 68 | 5378.789 | 1.3 | 2052.621 | 2.23455 | 0.048 | 2.2 | ug/L |
| > Ge | 72 | 193742.889 | 1.5 | 193550.369 | | | | ug/L |
| As | 75 | 111.335 | 6.7 | 97.335 | 0.00599 | 0.004 | 65.5 | ug/L |
| Se | 77 | 196.269 | 1.9 | 187.669 | 0.04941 | 0.016 | 33.2 | ug/L |
| Se | 78 | 13646.154 | 0.8 | 13588.495 | 0.08601 | 0.586 | 681.1 | mg/L |
| Se | 82 | 1401.785 | 0.6 | 1139.011 | 1.10233 | 0.124 | 11.3 | ug/L |
| Kr | 83 | 1418.802 | 4.3 | 1141.423 | | | | mg/L |
| Y | 89 | 359752.254 | 1.0 | 354910.360 | | | | ug/L |
| Mo | 95 | 146.003 | 3.8 | 114.335 | 0.00730 | 0.002 | 25.0 | ug/L |
| Mo | 97 | 56.334 | 8.4 | 49.001 | 0.00285 | 0.002 | 64.6 | ug/L |
| Mo | 98 | 92.940 | 9.7 | 58.127 | 0.00449 | 0.001 | 17.2 | ug/L |
| Rh | 103 | 324258.914 | 2.3 | 323620.727 | | | | ug/L |
| Ag | 107 | 53.667 | 2.8 | 57.001 | -0.00011 | 0.000 | 151.5 | ug/L |
| Ag | 109 | 46.001 | 7.8 | 41.334 | 0.00050 | 0.000 | 43.6 | ug/L |
| Cd | 111 | 277.322 | 4.5 | 233.296 | 0.01781 | 0.002 | 9.3 | ug/L |
| Cd | 114 | 203.162 | 7.4 | 64.652 | 0.02117 | 0.002 | 10.8 | ug/L |
| > In | 115 | 352305.178 | 3.1 | 364581.825 | | | | ug/L |
| Sb | 121 | 97.002 | 11.6 | 51.001 | 0.00518 | 0.001 | 25.3 | ug/L |
| Sb | 123 | 89.822 | 12.1 | 45.100 | 0.00666 | 0.001 | 17.9 | ug/L |
| Ba | 135 | 123.002 | 6.3 | 65.001 | 0.02598 | 0.005 | 17.5 | ug/L |
| Ba | 137 | 192.337 | 4.9 | 74.668 | 0.03072 | 0.003 | 8.3 | ug/L |
| > Tb | 159 | 418850.638 | 2.3 | 439210.410 | | | | ug/L |
| > Ho | 165 | 412001.737 | 1.8 | 425708.154 | | | | ug/L |
| Tl | 203 | 66.668 | 15.4 | 51.001 | 0.00230 | 0.001 | 64.7 | ug/L |
| Tl | 205 | 128.002 | 7.5 | 72.668 | 0.00334 | 0.000 | 14.5 | ug/L |
| Pb | 208 | 862.359 | 1.5 | 767.689 | 0.00498 | 0.001 | 21.8 | ug/L |

Sample ID: 950036 D.500

Report Date/Time: Tuesday, November 21, 2006 14:03:50

Page 1

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|-----------|
| | Pb | 206 | 222.005 | 4.8 | 194.671 | 0.00532 | 0.002 | 32.2 ug/L |
| | Pb | 207 | 191.004 | 6.9 | 181.671 | 0.00288 | 0.002 | 79.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 97.418 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 100.099 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 96.633 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > [Tb | 159 | | 95.364 | | | |
| > [Ho | 165 | | 96.780 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950036 D.100

Sample Date/Time: Tuesday, November 21, 2006 14:06:47

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950036 D.100.046

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 122.669 | 0.9 | 54.001 | 0.06764 | 0.004 | 5.4 | ug/L |
| Al | 27 | 921752.940 | 0.7 | 9687.584 | 112.52827 | 3.029 | 2.7 | ug/L |
| > Sc | 45 | 369653.563 | 2.2 | 378480.621 | | | | ug/L |
| V | 51 | 4393.676 | 2.4 | 4514.855 | -0.00104 | 0.010 | 981.8 | ug/L |
| Cr | 52 | 15125.866 | 0.5 | 14908.140 | 0.04672 | 0.033 | 71.5 | ug/L |
| Cr | 53 | 803.713 | 0.2 | 661.366 | 0.10603 | 0.011 | 10.7 | ug/L |
| Mn | 55 | 2820622.681 | 1.4 | 587.693 | 175.05487 | 1.027 | 0.6 | ug/L |
| Co | 59 | 37625.171 | 2.9 | 242.339 | 2.68561 | 0.104 | 3.9 | ug/L |
| Ni | 60 | 22379.243 | 2.3 | 623.696 | 7.05039 | 0.191 | 2.7 | ug/L |
| Ni | 62 | 3511.109 | 3.8 | 504.354 | 6.38045 | 0.133 | 2.1 | ug/L |
| Cu | 63 | 197898.712 | 1.0 | 1290.783 | 27.34824 | 0.267 | 1.0 | ug/L |
| Cu | 65 | 99305.884 | 1.0 | 588.027 | 28.18420 | 0.299 | 1.1 | ug/L |
| Zn | 66 | 35219.624 | 0.9 | 2796.188 | 16.26138 | 0.408 | 2.5 | ug/L |
| Zn | 67 | 5294.735 | 1.2 | 500.354 | 14.16024 | 0.482 | 3.4 | ug/L |
| Zn | 68 | 24915.440 | 0.4 | 2052.621 | 15.81538 | 0.397 | 2.5 | ug/L |
| > Ge | 72 | 188732.008 | 2.0 | 193550.369 | | | | ug/L |
| As | 75 | 125.002 | 11.5 | 97.335 | 0.01315 | 0.005 | 39.7 | ug/L |
| Se | 77 | 198.536 | 3.4 | 187.669 | 0.09361 | 0.032 | 34.2 | ug/L |
| Se | 78 | 13852.645 | 0.4 | 13588.495 | 1.12928 | 0.616 | 54.6 | mg/L |
| Se | 82 | 1408.052 | 1.0 | 1139.011 | 1.28701 | 0.173 | 13.4 | ug/L |
| Kr | 83 | 1446.807 | 1.3 | 1141.423 | | | | mg/L |
| Y | 89 | 378055.973 | 4.0 | 354910.360 | | | | ug/L |
| Mo | 95 | 167.003 | 9.4 | 114.335 | 0.01273 | 0.003 | 27.0 | ug/L |
| Mo | 97 | 59.334 | 25.7 | 49.001 | 0.00436 | 0.005 | 108.0 | ug/L |
| Mo | 98 | 97.753 | 8.2 | 58.127 | 0.00549 | 0.001 | 16.7 | ug/L |
| Rh | 103 | 326519.872 | 1.3 | 323620.727 | | | | ug/L |
| Ag | 107 | 55.334 | 18.1 | 57.001 | 0.00016 | 0.001 | 470.7 | ug/L |
| Ag | 109 | 41.334 | 7.8 | 41.334 | 0.00023 | 0.000 | 134.2 | ug/L |
| Cd | 111 | 528.412 | 8.3 | 233.296 | 0.11034 | 0.016 | 14.6 | ug/L |
| Cd | 114 | 781.969 | 1.8 | 64.652 | 0.11220 | 0.002 | 1.5 | ug/L |
| > In | 115 | 340732.929 | 1.2 | 364581.825 | | | | ug/L |
| Sb | 121 | 94.335 | 4.8 | 51.001 | 0.00523 | 0.001 | 11.3 | ug/L |
| Sb | 123 | 80.974 | 4.0 | 45.100 | 0.00581 | 0.001 | 10.7 | ug/L |
| Ba | 135 | 454.017 | 2.5 | 65.001 | 0.16362 | 0.005 | 3.2 | ug/L |
| Ba | 137 | 724.372 | 2.2 | 74.668 | 0.16282 | 0.005 | 2.9 | ug/L |
| > Tb | 159 | 425284.309 | 1.7 | 439210.410 | | | | ug/L |
| > Ho | 165 | 401866.010 | 1.6 | 425708.154 | | | | ug/L |
| Tl | 203 | 136.002 | 1.3 | 51.001 | 0.01188 | 0.001 | 4.3 | ug/L |
| Tl | 205 | 278.341 | 0.7 | 72.668 | 0.01246 | 0.000 | 3.0 | ug/L |
| Pb | 208 | 1907.770 | 4.6 | 767.689 | 0.05054 | 0.004 | 8.5 | ug/L |

use 15

| | | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|------|------|
| | Pb | 206 | 476.352 | 2.2 | 194.671 | 0.04746 | 0.001 | 3.0 | ug/L |
| | Pb | 207 | 444.350 | 7.9 | 181.671 | 0.05317 | 0.006 | 12.1 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 97.668 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 97.511 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 93.459 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 96.829 | | | |
| > Ho | 165 | | 94.399 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Tuesday, November 21, 2006 14:12:46

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 6.047

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54029.187 | 2.4 | 54.001 | 52.82699 | 2.231 | 4.2 | ug/L |
| Al | 27 | 441972.780 | 1.9 | 9687.584 | 53.98295 | 0.273 | 0.5 | ug/L |
| > Sc | 45 | 365292.975 | 2.4 | 378480.621 | | | | ug/L |
| V | 51 | 764590.713 | 1.0 | 4514.855 | 55.06362 | 1.856 | 3.4 | ug/L |
| Cr | 52 | 648637.496 | 0.2 | 14908.140 | 52.48602 | 1.249 | 2.4 | ug/L |
| Cr | 53 | 74955.744 | 1.8 | 661.366 | 50.46679 | 0.411 | 0.8 | ug/L |
| Mn | 55 | 880477.629 | 2.3 | 587.693 | 54.34933 | 1.767 | 3.3 | ug/L |
| Co | 59 | 729356.686 | 2.0 | 242.339 | 52.09416 | 1.342 | 2.6 | ug/L |
| Ni | 60 | 168890.756 | 1.1 | 623.696 | 54.21142 | 0.824 | 1.5 | ug/L |
| Ni | 62 | 24681.422 | 2.2 | 504.354 | 50.87728 | 1.660 | 3.3 | ug/L |
| Cu | 63 | 387945.361 | 1.5 | 1290.783 | 53.49892 | 0.690 | 1.3 | ug/L |
| Cu | 65 | 193189.000 | 2.3 | 588.027 | 54.70747 | 1.795 | 3.3 | ug/L |
| Zn | 66 | 104375.312 | 2.9 | 2796.188 | 50.60217 | 1.999 | 3.9 | ug/L |
| Zn | 67 | 18288.901 | 1.8 | 500.354 | 52.13946 | 0.552 | 1.1 | ug/L |
| Zn | 68 | 77834.072 | 2.6 | 2052.621 | 52.06128 | 1.895 | 3.6 | ug/L |
| > Ge | 72 | 189696.801 | 1.0 | 193550.369 | | | | ug/L |
| As | 75 | 121245.609 | 1.2 | 97.335 | 52.93016 | 0.159 | 0.3 | ug/L |
| Se | 77 | 9029.156 | 1.0 | 187.669 | 53.02276 | 1.000 | 1.9 | ug/L |
| Se | 78 | 42789.380 | 1.7 | 13588.495 | 54.57624 | 1.953 | 3.6 | mg/L |
| Se | 82 | 13663.459 | 0.6 | 1139.011 | 53.93273 | 0.783 | 1.5 | ug/L |
| Kr | 83 | 1330.119 | 0.7 | 1141.423 | | | | mg/L |
| Y | 89 | 361422.432 | 3.2 | 354910.360 | | | | ug/L |
| Mo | 95 | 264254.322 | 2.2 | 114.335 | 54.71140 | 1.142 | 2.1 | ug/L |
| Mo | 97 | 165524.726 | 2.5 | 49.001 | 52.69039 | 1.992 | 3.8 | ug/L |
| Mo | 98 | 411452.443 | 1.1 | 58.127 | 51.03339 | 1.192 | 2.3 | ug/L |
| Rh | 103 | 325342.096 | 3.0 | 323620.727 | | | | ug/L |
| Ag | 107 | 654265.720 | 1.4 | 57.001 | 52.83591 | 1.494 | 2.8 | ug/L |
| Ag | 109 | 601035.096 | 1.6 | 41.334 | 50.03241 | 0.872 | 1.7 | ug/L |
| Cd | 111 | 149797.588 | 1.9 | 233.296 | 52.07081 | 0.982 | 1.9 | ug/L |
| Cd | 114 | 332323.881 | 1.4 | 64.652 | 50.60446 | 0.339 | 0.7 | ug/L |
| > In | 115 | 347882.471 | 1.4 | 364581.825 | | | | ug/L |
| Sb | 121 | 453463.779 | 3.1 | 51.001 | 49.79274 | 2.034 | 4.1 | ug/L |
| Sb | 123 | 349072.010 | 0.5 | 45.100 | 51.08855 | 0.789 | 1.5 | ug/L |
| Ba | 135 | 124523.112 | 2.6 | 65.001 | 52.95465 | 0.360 | 0.7 | ug/L |
| Ba | 137 | 216237.425 | 0.5 | 74.668 | 54.90755 | 0.942 | 1.7 | ug/L |
| > Tb | 159 | 418099.003 | 2.1 | 439210.410 | | | | ug/L |
| > Ho | 165 | 405251.271 | 1.7 | 425708.154 | | | | ug/L |
| Tl | 203 | 394511.742 | 1.4 | 51.001 | 52.87668 | 1.613 | 3.1 | ug/L |
| Tl | 205 | 894543.186 | 1.8 | 72.668 | 52.69796 | 0.845 | 1.6 | ug/L |
| Pb | 208 | 1229323.565 | 2.5 | 767.689 | 52.02491 | 1.356 | 2.6 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Tuesday, November 21, 2006 14:15:48

Page 1

888

| | | | | | | | |
|----|-----|------------|-----|---------|----------|-------|----------|
| Pb | 206 | 317414.440 | 0.7 | 194.671 | 51.03443 | 1.149 | 2.3 ug/L |
| Pb | 207 | 271684.234 | 0.8 | 181.671 | 52.49323 | 0.990 | 1.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | 105.654 | | | | |
| Al | 27 | 107.966 | | | | |
| > Sc | 45 | | 96.516 | | | |
| V | 51 | 110.127 | | | | |
| Cr | 52 | 104.972 | | | | |
| [Cr | 53 | 100.934 | | | | |
| [Mn | 55 | 108.699 | | | | |
| Co | 59 | 104.188 | | | | |
| Ni | 60 | 108.423 | | | | |
| Ni | 62 | 101.755 | | | | |
| Cu | 63 | 106.998 | | | | |
| Cu | 65 | 109.415 | | | | |
| Zn | 66 | 101.204 | | | | |
| Zn | 67 | 104.279 | | | | |
| Zn | 68 | 104.123 | | | | |
| > Ge | 72 | | 98.009 | | | |
| As | 75 | 105.860 | | | | |
| Se | 77 | 106.046 | | | | |
| Se | 78 | 109.152 | | | | |
| Se | 82 | 107.865 | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | 109.423 | | | | |
| Mo | 97 | 105.381 | | | | |
| Mo | 98 | 102.067 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 105.672 | | | | |
| Ag | 109 | 100.065 | | | | |
| Cd | 111 | 104.142 | | | | |
| Cd | 114 | 101.209 | | | | |
| > In | 115 | | 95.420 | | | |
| Sb | 121 | 99.585 | | | | |
| [Sb | 123 | 102.177 | | | | |
| [Ba | 135 | 105.909 | | | | |
| Ba | 137 | 109.815 | | | | |
| > Tb | 159 | | 95.193 | | | |
| > Ho | 165 | | 95.195 | | | |
| Tl | 203 | 105.753 | | | | |
| Tl | 205 | 105.396 | | | | |
| Pb | 208 | 104.050 | | | | |
| Pb | 206 | 102.069 | | | | |
| [Pb | 207 | 104.986 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Tuesday, November 21, 2006 14:18:43

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 7.048

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 51.667 | 4.0 | 54.001 | -0.00137 | 0.003 | 203.1 | ug/L |
| Al | 27 | 3181.973 | 1.3 | 9687.584 | -0.77697 | 0.011 | 1.5 | ug/L |
| > Sc | 45 | 372315.969 | 1.5 | 378480.621 | | | | ug/L |
| V | 51 | 4270.306 | 5.3 | 4514.855 | -0.01194 | 0.021 | 173.2 | ug/L |
| Cr | 52 | 14560.858 | 1.8 | 14908.140 | -0.00810 | 0.038 | 471.8 | ug/L |
| Cr | 53 | 728.039 | 1.3 | 661.366 | 0.05161 | 0.001 | 2.4 | ug/L |
| Mn | 55 | 500.353 | 5.1 | 587.693 | -0.00462 | 0.002 | 40.5 | ug/L |
| Co | 59 | 179.004 | 5.0 | 242.339 | -0.00415 | 0.001 | 20.6 | ug/L |
| Ni | 60 | 535.689 | 2.8 | 623.696 | -0.02411 | 0.004 | 17.3 | ug/L |
| Ni | 62 | 289.008 | 3.9 | 504.354 | -0.43056 | 0.034 | 8.0 | ug/L |
| Cu | 63 | 799.380 | 4.5 | 1290.783 | -0.06421 | 0.007 | 10.5 | ug/L |
| Cu | 65 | 419.348 | 3.3 | 588.027 | -0.04440 | 0.004 | 8.5 | ug/L |
| Zn | 66 | 1547.493 | 4.8 | 2796.188 | -0.59242 | 0.046 | 7.8 | ug/L |
| Zn | 67 | 337.677 | 2.7 | 500.354 | -0.44609 | 0.018 | 4.1 | ug/L |
| Zn | 68 | 1203.432 | 3.0 | 2052.621 | -0.55334 | 0.039 | 7.0 | ug/L |
| > Ge | 72 | 189443.072 | 1.7 | 193550.369 | | | | ug/L |
| As | 75 | 129.669 | 15.2 | 97.335 | 0.01513 | 0.009 | 61.5 | ug/L |
| Se | 77 | 196.336 | 3.0 | 187.669 | 0.07588 | 0.026 | 33.7 | ug/L |
| Se | 78 | 13517.683 | 1.0 | 13588.495 | 0.40931 | 0.575 | 140.4 | mg/L |
| Se | 82 | 1356.577 | 1.0 | 1139.011 | 1.04093 | 0.054 | 5.2 | ug/L |
| Kr | 83 | 1394.464 | 3.1 | 1141.423 | | | | mg/L |
| Y | 89 | 357385.275 | 1.1 | 354910.360 | | | | ug/L |
| Mo | 95 | 512.688 | 12.8 | 114.335 | 0.07976 | 0.013 | 16.3 | ug/L |
| Mo | 97 | 294.008 | 16.0 | 49.001 | 0.07532 | 0.014 | 19.0 | ug/L |
| Mo | 98 | 684.752 | 22.3 | 58.127 | 0.07497 | 0.018 | 24.2 | ug/L |
| Rh | 103 | 321088.999 | 1.2 | 323620.727 | | | | ug/L |
| Ag | 107 | 133.669 | 13.1 | 57.001 | 0.00601 | 0.001 | 22.2 | ug/L |
| Ag | 109 | 111.002 | 16.9 | 41.334 | 0.00562 | 0.002 | 26.8 | ug/L |
| Cd | 111 | 211.986 | 3.6 | 233.296 | -0.00636 | 0.003 | 40.3 | ug/L |
| Cd | 114 | 54.765 | 6.4 | 64.652 | -0.00135 | 0.001 | 39.5 | ug/L |
| > In | 115 | 360905.439 | 0.6 | 364581.825 | | | | ug/L |
| Sb | 121 | 972.067 | 16.5 | 51.001 | 0.09751 | 0.017 | 17.2 | ug/L |
| Sb | 123 | 761.361 | 22.6 | 45.100 | 0.10110 | 0.024 | 23.9 | ug/L |
| Ba | 135 | 45.667 | 20.3 | 65.001 | -0.00704 | 0.004 | 57.9 | ug/L |
| Ba | 137 | 52.001 | 10.7 | 74.668 | -0.00494 | 0.002 | 30.6 | ug/L |
| > Tb | 159 | 421577.587 | 1.2 | 439210.410 | | | | ug/L |
| > Ho | 165 | 417899.123 | 1.0 | 425708.154 | | | | ug/L |
| Tl | 203 | 55.334 | 19.9 | 51.001 | 0.00068 | 0.001 | 205.3 | ug/L |
| Tl | 205 | 117.669 | 6.0 | 72.668 | 0.00265 | 0.000 | 14.0 | ug/L |
| Pb | 208 | 380.007 | 10.7 | 767.689 | -0.01534 | 0.002 | 10.7 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Tuesday, November 21, 2006 14:21:44

Page 1

| | | | | | | | | |
|---|----|-----|---------|------|---------|----------|-------|-----------|
| | Pb | 206 | 106.002 | 9.8 | 194.671 | -0.01327 | 0.002 | 12.6 ug/L |
| L | Pb | 207 | 91.001 | 16.6 | 181.671 | -0.01639 | 0.003 | 16.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 98.371 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 97.878 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 98.992 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 95.985 | | | |
| > Ho | 165 | | 98.166 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950036 D.5

Sample Date/Time: Tuesday, November 21, 2006 14:24:41

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950036 D.5.049

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1347.122 | 2.1 | 54.001 | 1.09978 | 0.013 | 1.2 | ug/L |
| Al | 27 | 20593955.903 | 1.7 | 9687.584 | 2244.38160 | 99.170 | 4.4 | ug/L |
| > Sc | 45 | 418333.399 | 2.8 | 378480.621 | | | | ug/L |
| V | 51 | 4562.545 | 3.0 | 4514.855 | -0.02702 | 0.005 | 18.2 | ug/L |
| Cr | 52 | 21035.397 | 1.5 | 14908.140 | 0.32954 | 0.018 | 5.6 | ug/L |
| Cr | 53 | 1522.821 | 4.0 | 661.366 | 0.47023 | 0.052 | 11.2 | ug/L |
| Mn | 55 | 58162560.156 | 2.0 | 587.693 | 3444.34556 | 39.638 | 1.2 | ug/L |
| Co | 59 | 805182.865 | 0.7 | 242.339 | 55.15728 | 1.265 | 2.3 | ug/L |
| Ni | 60 | 441947.777 | 1.7 | 623.696 | 136.37413 | 4.617 | 3.4 | ug/L |
| Ni | 62 | 68054.261 | 3.0 | 504.354 | 136.20365 | 3.258 | 2.4 | ug/L |
| Cu | 63 | 4796168.055 | 2.3 | 1290.783 | 636.10357 | 4.954 | 0.8 | ug/L |
| Cu | 65 | 1798610.703 | 1.6 | 588.027 | 489.65718 | 7.474 | 1.5 | ug/L |
| Zn | 66 | 669727.077 | 2.0 | 2796.188 | 318.34287 | 6.368 | 2.0 | ug/L |
| Zn | 67 | 103361.853 | 1.5 | 500.354 | 288.94453 | 0.578 | 0.2 | ug/L |
| Zn | 68 | 462713.373 | 1.7 | 2052.621 | 303.27974 | 7.606 | 2.5 | ug/L |
| > Ge | 72 | 197817.394 | 1.6 | 193550.369 | | | | ug/L |
| As | 75 | 508.687 | 8.5 | 97.335 | 0.17129 | 0.015 | 8.6 | ug/L |
| Se | 77 | 309.739 | 3.8 | 187.669 | 0.67865 | 0.091 | 13.3 | ug/L |
| Se | 78 | 14508.321 | 1.1 | 13588.495 | 1.10597 | 0.519 | 46.9 | mg/L |
| Se | 82 | 1543.143 | 0.4 | 1139.011 | 1.56328 | 0.103 | 6.6 | ug/L |
| Kr | 83 | 1494.482 | 1.8 | 1141.423 | | | | mg/L |
| Y | 89 | 774132.853 | 3.6 | 354910.360 | | | | ug/L |
| Mo | 95 | 723.039 | 2.2 | 114.335 | 0.11912 | 0.003 | 2.1 | ug/L |
| Mo | 97 | 164.670 | 5.2 | 49.001 | 0.03475 | 0.003 | 9.3 | ug/L |
| Mo | 98 | 481.071 | 4.9 | 58.127 | 0.04962 | 0.004 | 7.3 | ug/L |
| Rh | 103 | 325888.272 | 1.4 | 323620.727 | | | | ug/L |
| Ag | 107 | 95.335 | 18.5 | 57.001 | 0.00289 | 0.001 | 46.4 | ug/L |
| Ag | 109 | 63.001 | 18.0 | 41.334 | 0.00167 | 0.001 | 48.9 | ug/L |
| Cd | 111 | 7075.277 | 0.7 | 233.296 | 2.25360 | 0.036 | 1.6 | ug/L |
| Cd | 114 | 15180.892 | 3.2 | 64.652 | 2.17921 | 0.088 | 4.0 | ug/L |
| > In | 115 | 367609.445 | 1.6 | 364581.825 | | | | ug/L |
| Sb | 121 | 447.016 | 6.9 | 51.001 | 0.04108 | 0.003 | 6.3 | ug/L |
| Sb | 123 | 349.916 | 6.3 | 45.100 | 0.04216 | 0.003 | 6.6 | ug/L |
| Ba | 135 | 8281.865 | 3.0 | 65.001 | 3.37950 | 0.106 | 3.1 | ug/L |
| Ba | 137 | 14027.273 | 2.1 | 74.668 | 3.42486 | 0.087 | 2.6 | ug/L |
| > Tb | 159 | 432633.090 | 1.2 | 439210.410 | | | | ug/L |
| > Ho | 165 | 419586.931 | 1.0 | 425708.154 | | | | ug/L |
| Tl | 203 | 1839.221 | 1.4 | 51.001 | 0.23155 | 0.004 | 1.8 | ug/L |
| Tl | 205 | 4269.470 | 1.3 | 72.668 | 0.23885 | 0.002 | 1.0 | ug/L |
| Pb | 208 | 16326.051 | 0.7 | 767.689 | 0.63673 | 0.008 | 1.2 | ug/L |

Sample ID: 950036 D.5

Report Date/Time: Tuesday, November 21, 2006 14:27:42

Page 1

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 4299.819 | 1.5 | 194.671 | 0.63814 | 0.009 | 1.4 ug/L |
| | Pb | 207 | 3471.091 | 2.8 | 181.671 | 0.61468 | 0.021 | 3.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 110.530 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 102.205 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 100.830 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.502 | | | |
| > [Ho | 165 | | 98.562 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Tuesday, November 21, 2006 14:30:38

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 3.050

| | Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| | Be | 9 | 1201.099 | 5.5 | 54.001 | 1.05140 | 0.079 | 7.5 | ug/L |
| | Al | 27 | 89995.975 | 1.4 | 9687.584 | 9.36194 | 0.029 | 0.3 | ug/L |
| > | Sc | 45 | 389602.867 | 1.7 | 378480.621 | | | | ug/L |
| | V | 51 | 20183.134 | 2.3 | 4514.855 | 1.05449 | 0.022 | 2.1 | ug/L |
| | Cr | 52 | 28973.926 | 2.5 | 14908.140 | 1.05676 | 0.019 | 1.8 | ug/L |
| [| Cr | 53 | 2369.694 | 0.1 | 661.366 | 1.07549 | 0.024 | 2.3 | ug/L |
| | Mn | 55 | 19724.193 | 3.1 | 587.693 | 1.10306 | 0.018 | 1.6 | ug/L |
| | Co | 59 | 16182.533 | 2.6 | 242.339 | 1.06376 | 0.010 | 0.9 | ug/L |
| | Ni | 60 | 3742.544 | 0.7 | 623.696 | 0.93075 | 0.039 | 4.2 | ug/L |
| | Ni | 62 | 789.712 | 3.9 | 504.354 | 0.51321 | 0.057 | 11.0 | ug/L |
| | Cu | 63 | 8395.978 | 0.3 | 1290.783 | 0.91137 | 0.031 | 3.4 | ug/L |
| | Cu | 65 | 4109.054 | 1.1 | 588.027 | 0.92783 | 0.041 | 4.4 | ug/L |
| | Zn | 66 | 14139.460 | 0.7 | 2796.188 | 5.21744 | 0.141 | 2.7 | ug/L |
| | Zn | 67 | 2187.309 | 0.7 | 500.354 | 4.55696 | 0.200 | 4.4 | ug/L |
| | Zn | 68 | 9680.385 | 2.7 | 2052.621 | 4.83682 | 0.330 | 6.8 | ug/L |
| > | Ge | 72 | 202932.017 | 2.7 | 193550.369 | | | | ug/L |
| | As | 75 | 2689.462 | 5.1 | 97.335 | 1.05639 | 0.033 | 3.1 | ug/L |
| | Se | 77 | 394.276 | 1.1 | 187.669 | 1.10734 | 0.041 | 3.7 | ug/L |
| | Se | 78 | 14573.563 | 1.2 | 13588.495 | 0.57865 | 0.818 | 141.4 | mg/L |
| | Se | 82 | 1656.431 | 2.6 | 1139.011 | 1.85740 | 0.061 | 3.3 | ug/L |
| | Kr | 83 | 1435.471 | 1.3 | 1141.423 | | | | mg/L |
| [| Y | 89 | 379349.203 | 1.7 | 354910.360 | | | | ug/L |
| | Mo | 95 | 5487.531 | 5.0 | 114.335 | 1.03966 | 0.020 | 1.9 | ug/L |
| | Mo | 97 | 3410.399 | 3.2 | 49.001 | 1.00094 | 0.051 | 5.1 | ug/L |
| | Mo | 98 | 9043.902 | 0.9 | 58.127 | 1.04234 | 0.024 | 2.3 | ug/L |
| | Rh | 103 | 344384.010 | 0.2 | 323620.727 | | | | ug/L |
| | Ag | 107 | 13977.853 | 0.9 | 57.001 | 1.05132 | 0.024 | 2.3 | ug/L |
| | Ag | 109 | 13156.844 | 1.4 | 41.334 | 1.02110 | 0.019 | 1.9 | ug/L |
| | Cd | 111 | 3364.590 | 1.8 | 233.296 | 1.01789 | 0.015 | 1.5 | ug/L |
| | Cd | 114 | 7284.918 | 2.7 | 64.652 | 1.02805 | 0.004 | 0.4 | ug/L |
| > | In | 115 | 372071.216 | 3.1 | 364581.825 | | | | ug/L |
| | Sb | 121 | 10169.971 | 1.1 | 51.001 | 1.03902 | 0.022 | 2.1 | ug/L |
| [| Sb | 123 | 7541.427 | 2.8 | 45.100 | 1.02614 | 0.036 | 3.5 | ug/L |
| | Ba | 135 | 2608.434 | 2.8 | 65.001 | 1.03794 | 0.033 | 3.1 | ug/L |
| | Ba | 137 | 4647.676 | 1.7 | 74.668 | 1.11365 | 0.021 | 1.9 | ug/L |
| > | Tb | 159 | 436049.481 | 0.3 | 439210.410 | | | | ug/L |
| > | Ho | 165 | 423455.577 | 3.3 | 425708.154 | | | | ug/L |
| | Tl | 203 | 8181.096 | 1.6 | 51.001 | 1.04354 | 0.044 | 4.2 | ug/L |
| | Tl | 205 | 19770.290 | 1.1 | 72.668 | 1.11108 | 0.026 | 2.3 | ug/L |
| | Pb | 208 | 26340.842 | 0.4 | 767.689 | 1.03705 | 0.030 | 2.9 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Tuesday, November 21, 2006 14:33:38

Page 1

897

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 6875.238 | 2.5 | 194.671 | 1.02889 | 0.031 | 3.0 ug/L |
| | Pb | 207 | 5598.604 | 2.9 | 181.671 | 1.00306 | 0.047 | 4.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 105.140 | | | | |
| Al | 27 | 93.619 | | | | |
| > Sc | 45 | | 102.939 | | | |
| V | 51 | 105.449 | | | | |
| Cr | 52 | 105.676 | | | | |
| Cr | 53 | 107.549 | | | | |
| Mn | 55 | 110.306 | | | | |
| Co | 59 | 106.376 | | | | |
| Ni | 60 | 93.075 | | | | |
| Ni | 62 | 51.321 | | | | |
| Cu | 63 | 91.137 | | | | |
| Cu | 65 | 92.783 | | | | |
| Zn | 66 | 104.349 | | | | |
| Zn | 67 | 91.139 | | | | |
| Zn | 68 | 96.736 | | | | |
| > Ge | 72 | | 104.847 | | | |
| As | 75 | 105.639 | | | | |
| Se | 77 | 110.734 | | | | |
| Se | 78 | 57.865 | | | | |
| Se | 82 | 185.740 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 103.966 | | | | |
| Mo | 97 | 100.094 | | | | |
| Mo | 98 | 104.234 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 105.132 | | | | |
| Ag | 109 | 102.110 | | | | |
| Cd | 111 | 101.789 | | | | |
| Cd | 114 | 102.805 | | | | |
| > In | 115 | | 102.054 | | | |
| Sb | 121 | 103.902 | | | | |
| Sb | 123 | 102.614 | | | | |
| Ba | 135 | 103.794 | | | | |
| Ba | 137 | 111.365 | | | | |
| > Tb | 159 | | 99.280 | | | |
| > Ho | 165 | | 99.471 | | | |
| Tl | 203 | 104.354 | | | | |
| Tl | 205 | 111.108 | | | | |
| Pb | 208 | 103.705 | | | | |
| Pb | 206 | 102.889 | | | | |
| Pb | 207 | 100.306 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: HLCCV2

Sample Date/Time: Tuesday, November 21, 2006 14:36:35

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\HLCCV2.051

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 216960.652 | 1.6 | 54.001 | 216.66622 | 5.063 | 2.3 | ug/L |
| Al | 27 | 1589195.734 | 3.9 | 9687.584 | 201.28978 | 7.223 | 3.6 | ug/L |
| Sc | 45 | 357741.516 | 0.8 | 378480.621 | | | | ug/L |
| V | 51 | 3504968.836 | 1.0 | 4514.855 | 258.79258 | 4.316 | 1.7 | ug/L |
| Cr | 52 | 2861500.965 | 1.5 | 14908.140 | 240.53137 | 4.565 | 1.9 | ug/L |
| Cr | 53 | 298584.375 | 1.1 | 661.366 | 206.60012 | 3.406 | 1.6 | ug/L |
| Mn | 55 | 3903610.465 | 0.5 | 587.693 | 245.59299 | 4.163 | 1.7 | ug/L |
| Co | 59 | 3384432.172 | 1.4 | 242.339 | 246.35716 | 6.324 | 2.6 | ug/L |
| Ni | 60 | 655097.564 | 1.8 | 623.696 | 214.78653 | 1.646 | 0.8 | ug/L |
| Ni | 62 | 95155.221 | 1.6 | 504.354 | 202.83038 | 0.647 | 0.3 | ug/L |
| Cu | 63 | 1419242.923 | 0.8 | 1290.783 | 199.90133 | 3.893 | 1.9 | ug/L |
| Cu | 65 | 698872.756 | 3.0 | 588.027 | 201.99768 | 3.738 | 1.9 | ug/L |
| Zn | 66 | 398621.258 | 1.6 | 2796.188 | 200.78780 | 2.896 | 1.4 | ug/L |
| Zn | 67 | 71463.510 | 0.9 | 500.354 | 211.86804 | 2.477 | 1.2 | ug/L |
| Zn | 68 | 299880.655 | 1.4 | 2052.621 | 208.35407 | 2.812 | 1.3 | ug/L |
| Ge | 72 | 186198.941 | 1.3 | 193550.369 | | | | ug/L |
| As | 75 | 480251.334 | 1.8 | 97.335 | 213.71970 | 2.389 | 1.1 | ug/L |
| Se | 77 | 35112.153 | 0.9 | 187.669 | 213.31849 | 1.708 | 0.8 | ug/L |
| Se | 78 | 128941.391 | 0.8 | 13588.495 | 218.56885 | 1.702 | 0.8 | mg/L |
| Se | 82 | 49707.477 | 2.6 | 1139.011 | 212.83645 | 3.044 | 1.4 | ug/L |
| Kr | 83 | 1227.771 | 13.9 | 1141.423 | | | | mg/L |
| Y | 89 | 344363.689 | 1.4 | 354910.360 | | | | ug/L |
| Mo | 95 | 1007030.610 | 0.7 | 114.335 | 211.54519 | 2.760 | 1.3 | ug/L |
| Mo | 97 | 632075.478 | 2.1 | 49.001 | 204.07253 | 5.141 | 2.5 | ug/L |
| Mo | 98 | 1542199.915 | 0.9 | 58.127 | 193.99515 | 0.416 | 0.2 | ug/L |
| Rh | 103 | 319308.140 | 4.0 | 323620.727 | | | | ug/L |
| Ag | 107 | 3198922.837 | 1.3 | 57.001 | 261.98207 | 3.659 | 1.4 | ug/L |
| Ag | 109 | 2936284.622 | 3.2 | 41.334 | 247.88355 | 5.883 | 2.4 | ug/L |
| Cd | 111 | 584755.688 | 2.9 | 233.296 | 206.41040 | 6.905 | 3.3 | ug/L |
| Cd | 114 | 1254581.733 | 1.8 | 64.652 | 193.81194 | 4.436 | 2.3 | ug/L |
| In | 115 | 342977.797 | 0.8 | 364581.825 | | | | ug/L |
| Sb | 121 | 1732671.411 | 1.7 | 51.001 | 192.95923 | 4.843 | 2.5 | ug/L |
| Sb | 123 | 1358832.762 | 1.9 | 45.100 | 201.69941 | 2.661 | 1.3 | ug/L |
| Ba | 135 | 468000.593 | 0.5 | 65.001 | 205.92088 | 6.100 | 3.0 | ug/L |
| Ba | 137 | 804998.094 | 1.8 | 74.668 | 211.32702 | 2.369 | 1.1 | ug/L |
| Tb | 159 | 404487.726 | 2.8 | 439210.410 | | | | ug/L |
| Ho | 165 | 389059.007 | 0.8 | 425708.154 | | | | ug/L |
| Tl | 203 | 1439143.584 | 1.8 | 51.001 | 200.85557 | 2.162 | 1.1 | ug/L |
| Tl | 205 | 4294367.978 | 1.0 | 72.668 | 263.51126 | 2.549 | 1.0 | ug/L |
| Pb | 208 | 5258738.142 | 0.6 | 767.689 | 231.89237 | 0.596 | 0.3 | ug/L |

Sample ID: HLCCV2

Report Date/Time: Tuesday, November 21, 2006 14:39:36

Page 1

900

| | | | | | | | | |
|--|----|-----|-------------|-----|---------|-----------|-------|----------|
| | Pb | 206 | 1190780.335 | 1.6 | 194.671 | 199.45272 | 1.833 | 0.9 ug/L |
| | Pb | 207 | 1014216.452 | 2.5 | 181.671 | 204.15493 | 3.619 | 1.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 94.520 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 96.202 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 94.074 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 92.094 | | | |
| > Ho | 165 | | 91.391 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Tuesday, November 21, 2006 14:42:33

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 6.052

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 53095.245 | 3.1 | 54.001 | 53.09245 | 1.112 | 2.1 | ug/L |
| Al | 27 | 426745.075 | 1.0 | 9687.584 | 53.33934 | 1.450 | 2.7 | ug/L |
| > Sc | 45 | 356958.020 | 1.9 | 378480.621 | | | | ug/L |
| V | 51 | 747604.586 | 1.2 | 4514.855 | 55.08208 | 1.242 | 2.3 | ug/L |
| Cr | 52 | 640678.801 | 2.2 | 14908.140 | 53.07270 | 2.189 | 4.1 | ug/L |
| Cr | 53 | 74907.589 | 0.8 | 661.366 | 51.62657 | 0.869 | 1.7 | ug/L |
| Mn | 55 | 857641.848 | 1.9 | 587.693 | 54.18327 | 0.665 | 1.2 | ug/L |
| Co | 59 | 723966.859 | 0.8 | 242.339 | 52.93619 | 0.875 | 1.7 | ug/L |
| Ni | 60 | 165936.011 | 2.3 | 623.696 | 54.52171 | 0.870 | 1.6 | ug/L |
| Ni | 62 | 24740.589 | 1.2 | 504.354 | 52.23400 | 1.164 | 2.2 | ug/L |
| Cu | 63 | 386324.569 | 1.0 | 1290.783 | 54.54305 | 0.141 | 0.3 | ug/L |
| Cu | 65 | 188482.555 | 2.2 | 588.027 | 54.62798 | 0.890 | 1.6 | ug/L |
| Zn | 66 | 100381.342 | 1.1 | 2796.188 | 49.79352 | 0.963 | 1.9 | ug/L |
| Zn | 67 | 18039.355 | 1.8 | 500.354 | 52.66224 | 0.403 | 0.8 | ug/L |
| Zn | 68 | 77051.358 | 0.8 | 2052.621 | 52.77538 | 1.038 | 2.0 | ug/L |
| > Ge | 72 | 185299.158 | 1.1 | 193550.369 | | | | ug/L |
| As | 75 | 119379.289 | 1.3 | 97.335 | 53.35254 | 0.227 | 0.4 | ug/L |
| Se | 77 | 9100.233 | 0.5 | 187.669 | 54.74193 | 0.659 | 1.2 | ug/L |
| Se | 78 | 42908.310 | 1.9 | 13588.495 | 56.67870 | 1.885 | 3.3 | mg/L |
| Se | 82 | 13460.797 | 0.9 | 1139.011 | 54.43331 | 0.655 | 1.2 | ug/L |
| Kr | 83 | 1374.795 | 10.6 | 1141.423 | | | | mg/L |
| Y | 89 | 348754.670 | 2.7 | 354910.360 | | | | ug/L |
| Mo | 95 | 260567.410 | 0.8 | 114.335 | 53.89814 | 0.642 | 1.2 | ug/L |
| Mo | 97 | 164131.083 | 2.3 | 49.001 | 52.18327 | 1.251 | 2.4 | ug/L |
| Mo | 98 | 410610.580 | 2.6 | 58.127 | 50.88774 | 1.998 | 3.9 | ug/L |
| Rh | 103 | 315037.487 | 2.3 | 323620.727 | | | | ug/L |
| Ag | 107 | 660765.617 | 0.6 | 57.001 | 53.30588 | 1.101 | 2.1 | ug/L |
| Ag | 109 | 599971.653 | 1.5 | 41.334 | 49.90038 | 1.200 | 2.4 | ug/L |
| Cd | 111 | 150067.442 | 3.2 | 233.296 | 52.12436 | 2.113 | 4.1 | ug/L |
| Cd | 114 | 330630.634 | 1.6 | 64.652 | 50.30271 | 0.980 | 1.9 | ug/L |
| > In | 115 | 348218.051 | 1.5 | 364581.825 | | | | ug/L |
| Sb | 121 | 445047.053 | 1.4 | 51.001 | 48.81814 | 1.312 | 2.7 | ug/L |
| Sb | 123 | 347398.340 | 0.8 | 45.100 | 50.79145 | 0.460 | 0.9 | ug/L |
| Ba | 135 | 120256.013 | 0.4 | 65.001 | 52.19993 | 1.360 | 2.6 | ug/L |
| Ba | 137 | 214406.320 | 0.4 | 74.668 | 55.54910 | 1.080 | 1.9 | ug/L |
| > Tb | 159 | 409796.126 | 2.3 | 439210.410 | | | | ug/L |
| > Ho | 165 | 392963.599 | 0.7 | 425708.154 | | | | ug/L |
| Tl | 203 | 384436.995 | 0.8 | 51.001 | 53.12278 | 0.758 | 1.4 | ug/L |
| Tl | 205 | 883415.869 | 2.3 | 72.668 | 53.66746 | 1.286 | 2.4 | ug/L |
| Pb | 208 | 1193638.880 | 1.1 | 767.689 | 52.08835 | 0.485 | 0.9 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Tuesday, November 21, 2006 14:45:35

Page 1

903

| | | | | | | | | |
|---|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 309660.929 | 0.5 | 194.671 | 51.33268 | 0.279 | 0.5 ug/L |
| L | Pb | 207 | 261260.656 | 0.9 | 181.671 | 52.05010 | 0.727 | 1.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 106.185 | | | | |
| Al | 27 | 106.679 | | | | |
| > Sc | 45 | | 94.313 | | | |
| V | 51 | 110.164 | | | | |
| Cr | 52 | 106.145 | | | | |
| Cr | 53 | 103.253 | | | | |
| Mn | 55 | 108.367 | | | | |
| Co | 59 | 105.872 | | | | |
| Ni | 60 | 109.043 | | | | |
| Ni | 62 | 104.468 | | | | |
| Cu | 63 | 109.086 | | | | |
| Cu | 65 | 109.256 | | | | |
| Zn | 66 | 99.587 | | | | |
| Zn | 67 | 105.324 | | | | |
| Zn | 68 | 105.551 | | | | |
| > Ge | 72 | | 95.737 | | | |
| As | 75 | 106.705 | | | | |
| Se | 77 | 109.484 | | | | |
| Se | 78 | 113.357 | | | | |
| Se | 82 | 108.867 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 107.796 | | | | |
| Mo | 97 | 104.367 | | | | |
| Mo | 98 | 101.775 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 106.612 | | | | |
| Ag | 109 | 99.801 | | | | |
| Cd | 111 | 104.249 | | | | |
| Cd | 114 | 100.605 | | | | |
| > In | 115 | | 95.512 | | | |
| Sb | 121 | 97.636 | | | | |
| Sb | 123 | 101.583 | | | | |
| Ba | 135 | 104.400 | | | | |
| Ba | 137 | 111.098 | | | | |
| > Tb | 159 | | 93.303 | | | |
| > Ho | 165 | | 92.308 | | | |
| Tl | 203 | 106.246 | | | | |
| Tl | 205 | 107.335 | | | | |
| Pb | 208 | 104.177 | | | | |
| Pb | 206 | 102.665 | | | | |
| Pb | 207 | 104.100 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Tuesday, November 21, 2006 14:48:31

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 7.053

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 53.001 | 9.8 | 54.001 | -0.00013 | 0.006 | 4283.2 | ug/L |
| Al | 27 | 3259.003 | 0.9 | 9687.584 | -0.76803 | 0.002 | 0.3 | ug/L |
| > Sc | 45 | 372676.921 | 1.1 | 378480.621 | | | | ug/L |
| V | 51 | 4550.034 | 1.2 | 4514.855 | 0.00742 | 0.004 | 55.3 | ug/L |
| Cr | 52 | 14860.392 | 2.4 | 14908.140 | 0.01456 | 0.018 | 120.8 | ug/L |
| Cr | 53 | 667.033 | 3.3 | 661.366 | 0.01050 | 0.013 | 122.3 | ug/L |
| Mn | 55 | 515.688 | 9.3 | 587.693 | -0.00429 | 0.003 | 61.7 | ug/L |
| Co | 59 | 170.003 | 5.2 | 242.339 | -0.00502 | 0.001 | 16.0 | ug/L |
| Ni | 60 | 522.688 | 7.1 | 623.696 | -0.03131 | 0.014 | 45.1 | ug/L |
| Ni | 62 | 316.009 | 5.0 | 504.354 | -0.38602 | 0.042 | 11.0 | ug/L |
| Cu | 63 | 853.719 | 4.8 | 1290.783 | -0.05898 | 0.004 | 7.1 | ug/L |
| Cu | 65 | 427.015 | 7.7 | 588.027 | -0.04448 | 0.009 | 20.1 | ug/L |
| Zn | 66 | 1643.512 | 0.5 | 2796.188 | -0.56000 | 0.014 | 2.6 | ug/L |
| Zn | 67 | 307.342 | 6.2 | 500.354 | -0.55124 | 0.065 | 11.9 | ug/L |
| Zn | 68 | 1204.432 | 1.4 | 2052.621 | -0.56844 | 0.001 | 0.3 | ug/L |
| > Ge | 72 | 193022.756 | 1.5 | 193550.369 | | | | ug/L |
| As | 75 | 124.669 | 6.5 | 97.335 | 0.01189 | 0.004 | 36.2 | ug/L |
| Se | 77 | 210.203 | 2.8 | 187.669 | 0.13626 | 0.053 | 38.8 | ug/L |
| Se | 78 | 13482.348 | 1.7 | 13588.495 | -0.11946 | 0.711 | 595.4 | mg/L |
| Se | 82 | 1334.507 | 3.2 | 1139.011 | 0.84132 | 0.260 | 30.9 | ug/L |
| Kr | 83 | 1359.791 | 2.7 | 1141.423 | | | | mg/L |
| Y | 89 | 359934.416 | 3.1 | 354910.360 | | | | ug/L |
| Mo | 95 | 743.708 | 16.5 | 114.335 | 0.12799 | 0.019 | 14.8 | ug/L |
| Mo | 97 | 439.350 | 24.4 | 49.001 | 0.12155 | 0.028 | 22.6 | ug/L |
| Mo | 98 | 1085.171 | 17.4 | 58.127 | 0.12467 | 0.017 | 13.9 | ug/L |
| Rh | 103 | 320540.200 | 0.9 | 323620.727 | | | | ug/L |
| Ag | 107 | 150.670 | 14.9 | 57.001 | 0.00751 | 0.001 | 17.0 | ug/L |
| Ag | 109 | 130.336 | 4.7 | 41.334 | 0.00737 | 0.001 | 7.4 | ug/L |
| Cd | 111 | 204.216 | 3.3 | 233.296 | -0.00772 | 0.002 | 24.8 | ug/L |
| Cd | 114 | 54.622 | 6.4 | 64.652 | -0.00121 | 0.001 | 68.6 | ug/L |
| > In | 115 | 354608.831 | 4.3 | 364581.825 | | | | ug/L |
| Sb | 121 | 1413.135 | 13.7 | 51.001 | 0.14645 | 0.015 | 10.0 | ug/L |
| Sb | 123 | 1061.846 | 17.7 | 45.100 | 0.14558 | 0.021 | 14.1 | ug/L |
| Ba | 135 | 45.667 | 24.6 | 65.001 | -0.00694 | 0.005 | 69.7 | ug/L |
| Ba | 137 | 53.667 | 7.5 | 74.668 | -0.00446 | 0.001 | 21.5 | ug/L |
| > Tb | 159 | 419165.588 | 0.5 | 439210.410 | | | | ug/L |
| > Ho | 165 | 410692.778 | 1.3 | 425708.154 | | | | ug/L |
| Tl | 203 | 68.001 | 9.6 | 51.001 | 0.00249 | 0.001 | 35.7 | ug/L |
| Tl | 205 | 129.669 | 15.8 | 72.668 | 0.00346 | 0.001 | 33.4 | ug/L |
| Pb | 208 | 436.675 | 6.6 | 767.689 | -0.01271 | 0.001 | 7.6 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Tuesday, November 21, 2006 14:51:32

Page 1

906

| | | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|------|------|
| | Pb | 206 | 111.002 | 11.7 | 194.671 | -0.01220 | 0.002 | 15.2 | ug/L |
| | Pb | 207 | 101.002 | 4.0 | 181.671 | -0.01416 | 0.001 | 7.0 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 98.467 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 99.727 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 97.265 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 95.436 | | | |
| > [Ho | 165 | | 96.473 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950032 D.10

Sample Date/Time: Tuesday, November 21, 2006 15:04:04

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\950032 D.10.054

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 159.670 | 11.6 | 54.001 | 0.10356 | 0.020 | 19.6 | ug/L |
| Al | 27 | 2839468.385 | 1.6 | 9687.584 | 349.01146 | 11.306 | 3.2 | ug/L |
| > Sc | 45 | 369721.286 | 2.0 | 378480.621 | | | | ug/L |
| V | 51 | 9540.630 | 8.4 | 4514.855 | 0.36637 | 0.043 | 11.8 | ug/L |
| Cr | 52 | 70505.762 | 1.6 | 14908.140 | 4.57284 | 0.075 | 1.6 | ug/L |
| Cr | 53 | 7676.947 | 3.2 | 661.366 | 4.71645 | 0.107 | 2.3 | ug/L |
| Mn | 55 | 946203.510 | 8.2 | 587.693 | 58.50582 | 4.583 | 7.8 | ug/L |
| Co | 59 | 26469.251 | 2.4 | 242.339 | 1.87777 | 0.049 | 2.6 | ug/L |
| Ni | 60 | 23936.912 | 2.2 | 623.696 | 7.53578 | 0.431 | 5.7 | ug/L |
| Ni | 62 | 3912.291 | 1.0 | 504.354 | 7.20596 | 0.214 | 3.0 | ug/L |
| Cu | 63 | 4396.537 | 2.7 | 1290.783 | 0.43452 | 0.020 | 4.6 | ug/L |
| Cu | 65 | 1852.224 | 1.9 | 588.027 | 0.36378 | 0.028 | 7.8 | ug/L |
| Zn | 66 | 17878.675 | 1.9 | 2796.188 | 7.55297 | 0.190 | 2.5 | ug/L |
| Zn | 67 | 2930.211 | 2.7 | 500.354 | 7.16294 | 0.100 | 1.4 | ug/L |
| Zn | 68 | 12942.840 | 1.2 | 2052.621 | 7.52242 | 0.199 | 2.6 | ug/L |
| > Ge | 72 | 189395.154 | 3.4 | 193550.369 | | | | ug/L |
| As | 75 | 529.022 | 0.9 | 97.335 | 0.18996 | 0.006 | 3.2 | ug/L |
| Se | 77 | 251.737 | 2.2 | 187.669 | 0.40929 | 0.026 | 6.3 | ug/L |
| Se | 78 | 13753.074 | 1.3 | 13588.495 | 0.87324 | 1.211 | 138.7 | mg/L |
| Se | 82 | 1355.244 | 2.5 | 1139.011 | 1.03857 | 0.156 | 15.0 | ug/L |
| Kr | 83 | 1372.460 | 2.2 | 1141.423 | | | | mg/L |
| Y | 89 | 378285.272 | 3.7 | 354910.360 | | | | ug/L |
| Mo | 95 | 616.029 | 9.5 | 114.335 | 0.10768 | 0.013 | 12.2 | ug/L |
| Mo | 97 | 342.010 | 7.9 | 49.001 | 0.09622 | 0.009 | 9.1 | ug/L |
| Mo | 98 | 856.365 | 5.1 | 58.127 | 0.10147 | 0.004 | 3.9 | ug/L |
| Rh | 103 | 317242.465 | 0.8 | 323620.727 | | | | ug/L |
| Ag | 107 | 87.335 | 18.9 | 57.001 | 0.00281 | 0.001 | 50.7 | ug/L |
| Ag | 109 | 74.334 | 6.1 | 41.334 | 0.00303 | 0.000 | 11.7 | ug/L |
| Cd | 111 | 579.886 | 5.2 | 233.296 | 0.12847 | 0.009 | 6.9 | ug/L |
| Cd | 114 | 879.541 | 4.0 | 64.652 | 0.12727 | 0.004 | 2.9 | ug/L |
| > In | 115 | 340885.995 | 1.4 | 364581.825 | | | | ug/L |
| Sb | 121 | 350.011 | 10.6 | 51.001 | 0.03385 | 0.004 | 11.1 | ug/L |
| Sb | 123 | 249.343 | 13.0 | 45.100 | 0.03092 | 0.005 | 14.8 | ug/L |
| Ba | 135 | 13673.355 | 3.7 | 65.001 | 5.81735 | 0.212 | 3.6 | ug/L |
| Ba | 137 | 22846.178 | 2.1 | 74.668 | 5.81025 | 0.172 | 3.0 | ug/L |
| > Tb | 159 | 416269.295 | 1.1 | 439210.410 | | | | ug/L |
| > Ho | 165 | 399857.962 | 3.3 | 425708.154 | | | | ug/L |
| Tl | 203 | 649.365 | 12.1 | 51.001 | 0.08157 | 0.009 | 10.4 | ug/L |
| Tl | 205 | 1537.824 | 7.3 | 72.668 | 0.08767 | 0.004 | 4.5 | ug/L |
| Pb | 208 | 6921.868 | 1.5 | 767.689 | 0.26622 | 0.007 | 2.5 | ug/L |

Sample ID: 950032 D.10

Report Date/Time: Tuesday, November 21, 2006 15:07:06

Page 1

909

| | | | | | | | | | |
|---|----|-----|----------|-----|---------|---------|-------|-----|------|
| | Pb | 206 | 1800.546 | 0.9 | 194.671 | 0.26387 | 0.008 | 3.1 | ug/L |
| L | Pb | 207 | 1439.139 | 1.2 | 181.671 | 0.24865 | 0.006 | 2.6 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 97.686 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 97.853 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 93.501 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 94.777 | | | |
| > Ho | 165 | | 93.928 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Tuesday, November 21, 2006 15:10:01

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 3.055

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1095.416 | 3.9 | 54.001 | 1.01455 | 0.053 | 5.2 | ug/L |
| Al | 27 | 89618.826 | 3.0 | 9687.584 | 9.95278 | 0.454 | 4.6 | ug/L |
| > Sc | 45 | 367450.264 | 1.1 | 378480.621 | | | | ug/L |
| V | 51 | 19524.471 | 1.1 | 4514.855 | 1.08974 | 0.018 | 1.7 | ug/L |
| Cr | 52 | 28120.314 | 0.7 | 14908.140 | 1.12232 | 0.010 | 0.9 | ug/L |
| Cr | 53 | 2283.336 | 1.7 | 661.366 | 1.10798 | 0.031 | 2.8 | ug/L |
| Mn | 55 | 18485.333 | 1.0 | 587.693 | 1.10390 | 0.019 | 1.7 | ug/L |
| Co | 59 | 15255.123 | 4.6 | 242.339 | 1.07021 | 0.025 | 2.3 | ug/L |
| Ni | 60 | 3571.468 | 2.1 | 623.696 | 0.95145 | 0.028 | 2.9 | ug/L |
| Ni | 62 | 767.710 | 4.1 | 504.354 | 0.57158 | 0.052 | 9.1 | ug/L |
| Cu | 63 | 8165.414 | 1.2 | 1290.783 | 0.95299 | 0.041 | 4.3 | ug/L |
| Cu | 65 | 3946.975 | 4.2 | 588.027 | 0.95583 | 0.068 | 7.2 | ug/L |
| Zn | 66 | 13341.472 | 1.4 | 2796.188 | 5.26636 | 0.227 | 4.3 | ug/L |
| Zn | 67 | 2081.614 | 2.5 | 500.354 | 4.65294 | 0.275 | 5.9 | ug/L |
| Zn | 68 | 9394.386 | 0.8 | 2052.621 | 5.05773 | 0.200 | 3.9 | ug/L |
| > Ge | 72 | 190092.713 | 2.4 | 193550.369 | | | | ug/L |
| As | 75 | 2483.061 | 0.8 | 97.335 | 1.04149 | 0.035 | 3.4 | ug/L |
| Se | 77 | 373.675 | 6.3 | 187.669 | 1.13247 | 0.128 | 11.3 | ug/L |
| Se | 78 | 14116.384 | 0.4 | 13588.495 | 1.43304 | 0.570 | 39.8 | mg/L |
| Se | 82 | 1548.277 | 0.4 | 1139.011 | 1.84522 | 0.160 | 8.7 | ug/L |
| Kr | 83 | 1360.458 | 1.2 | 1141.423 | | | | mg/L |
| Y | 89 | 355842.326 | 2.5 | 354910.360 | | | | ug/L |
| Mo | 95 | 5404.140 | 2.0 | 114.335 | 1.09531 | 0.050 | 4.6 | ug/L |
| Mo | 97 | 3459.419 | 2.5 | 49.001 | 1.08417 | 0.016 | 1.5 | ug/L |
| Mo | 98 | 8532.024 | 2.4 | 58.127 | 1.04992 | 0.047 | 4.5 | ug/L |
| Rh | 103 | 335406.352 | 0.3 | 323620.727 | | | | ug/L |
| Ag | 107 | 13241.650 | 2.9 | 57.001 | 1.06376 | 0.062 | 5.8 | ug/L |
| Ag | 109 | 12547.234 | 2.4 | 41.334 | 1.03926 | 0.021 | 2.0 | ug/L |
| Cd | 111 | 3154.954 | 2.2 | 233.296 | 1.01903 | 0.037 | 3.6 | ug/L |
| Cd | 114 | 6939.840 | 2.5 | 64.652 | 1.04557 | 0.020 | 1.9 | ug/L |
| > In | 115 | 348613.308 | 3.1 | 364581.825 | | | | ug/L |
| Sb | 121 | 9962.052 | 1.6 | 51.001 | 1.08663 | 0.033 | 3.1 | ug/L |
| Sb | 123 | 7271.353 | 1.9 | 45.100 | 1.05631 | 0.037 | 3.5 | ug/L |
| Ba | 135 | 2565.754 | 2.5 | 65.001 | 1.01905 | 0.014 | 1.4 | ug/L |
| Ba | 137 | 4395.536 | 0.7 | 74.668 | 1.05096 | 0.009 | 0.8 | ug/L |
| > Tb | 159 | 436589.570 | 1.2 | 439210.410 | | | | ug/L |
| > Ho | 165 | 412142.522 | 1.8 | 425708.154 | | | | ug/L |
| Tl | 203 | 7998.584 | 1.8 | 51.001 | 1.04743 | 0.011 | 1.0 | ug/L |
| Tl | 205 | 19566.474 | 0.9 | 72.668 | 1.12950 | 0.018 | 1.6 | ug/L |
| Pb | 208 | 26288.482 | 1.1 | 767.689 | 1.06359 | 0.008 | 0.7 | ug/L |

| | | | | | | | | |
|---|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 6763.813 | 2.7 | 194.671 | 1.03976 | 0.011 | 1.1 ug/L |
| L | Pb | 207 | 5632.960 | 2.1 | 181.671 | 1.03756 | 0.036 | 3.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 101.455 | | | | |
| Al | 27 | 99.528 | | | | |
| > Sc | 45 | | 97.086 | | | |
| V | 51 | 108.974 | | | | |
| Cr | 52 | 112.232 | | | | |
| Cr | 53 | 110.798 | | | | |
| Mn | 55 | 110.390 | | | | |
| Co | 59 | 107.021 | | | | |
| Ni | 60 | 95.145 | | | | |
| Ni | 62 | 57.158 | | | | |
| Cu | 63 | 95.299 | | | | |
| Cu | 65 | 95.583 | | | | |
| Zn | 66 | 105.327 | | | | |
| Zn | 67 | 93.059 | | | | |
| Zn | 68 | 101.155 | | | | |
| > Ge | 72 | | 98.214 | | | |
| As | 75 | 104.149 | | | | |
| Se | 77 | 113.247 | | | | |
| Se | 78 | 143.304 | | | | |
| Se | 82 | 184.522 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 109.531 | | | | |
| Mo | 97 | 108.417 | | | | |
| Mo | 98 | 104.992 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 106.376 | | | | |
| Ag | 109 | 103.926 | | | | |
| Cd | 111 | 101.903 | | | | |
| Cd | 114 | 104.557 | | | | |
| > In | 115 | | 95.620 | | | |
| Sb | 121 | 108.663 | | | | |
| Sb | 123 | 105.631 | | | | |
| Ba | 135 | 101.905 | | | | |
| Ba | 137 | 105.096 | | | | |
| > Tb | 159 | | 99.403 | | | |
| > Ho | 165 | | 96.813 | | | |
| Tl | 203 | 104.743 | | | | |
| Tl | 205 | 112.950 | | | | |
| Pb | 208 | 106.359 | | | | |
| Pb | 206 | 103.976 | | | | |
| Pb | 207 | 103.756 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Tuesday, November 21, 2006 15:15:58

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 6.056

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 51640.701 | 0.9 | 54.001 | 51.91901 | 1.687 | 3.3 | ug/L |
| Al | 27 | 430749.559 | 1.9 | 9687.584 | 54.14312 | 2.460 | 4.5 | ug/L |
| > Sc | 45 | 355235.268 | 2.6 | 378480.621 | | | | ug/L |
| V | 51 | 734967.836 | 0.7 | 4514.855 | 54.42630 | 1.718 | 3.2 | ug/L |
| Cr | 52 | 639078.318 | 0.9 | 14908.140 | 53.18879 | 0.930 | 1.7 | ug/L |
| Cr | 53 | 74173.239 | 3.0 | 661.366 | 51.35508 | 0.622 | 1.2 | ug/L |
| Mn | 55 | 869791.191 | 2.9 | 587.693 | 54.99712 | 0.729 | 1.3 | ug/L |
| Co | 59 | 720510.029 | 3.1 | 242.339 | 52.72259 | 1.187 | 2.3 | ug/L |
| Ni | 60 | 163885.891 | 2.1 | 623.696 | 53.91125 | 1.559 | 2.9 | ug/L |
| Ni | 62 | 24851.273 | 3.2 | 504.354 | 52.50489 | 0.793 | 1.5 | ug/L |
| Cu | 63 | 375747.094 | 1.4 | 1290.783 | 53.09628 | 0.412 | 0.8 | ug/L |
| Cu | 65 | 186214.893 | 1.0 | 588.027 | 54.03261 | 1.188 | 2.2 | ug/L |
| Zn | 66 | 102562.306 | 0.3 | 2796.188 | 50.95785 | 0.963 | 1.9 | ug/L |
| Zn | 67 | 17425.040 | 0.4 | 500.354 | 50.88185 | 0.953 | 1.9 | ug/L |
| Zn | 68 | 76762.457 | 2.1 | 2052.621 | 52.63852 | 2.058 | 3.9 | ug/L |
| > Ge | 72 | 185129.023 | 1.8 | 193550.369 | | | | ug/L |
| As | 75 | 116415.529 | 1.9 | 97.335 | 52.08941 | 1.529 | 2.9 | ug/L |
| Se | 77 | 8759.402 | 1.5 | 187.669 | 52.69699 | 0.128 | 0.2 | ug/L |
| Se | 78 | 40795.909 | 2.3 | 13588.495 | 52.77411 | 3.080 | 5.8 | mg/L |
| Se | 82 | 13098.553 | 0.9 | 1139.011 | 52.89717 | 0.789 | 1.5 | ug/L |
| Kr | 83 | 1313.450 | 3.4 | 1141.423 | | | | mg/L |
| Y | 89 | 350709.276 | 4.0 | 354910.360 | | | | ug/L |
| Mo | 95 | 248561.052 | 1.8 | 114.335 | 52.97830 | 0.690 | 1.3 | ug/L |
| Mo | 97 | 160958.367 | 1.4 | 49.001 | 52.74325 | 1.369 | 2.6 | ug/L |
| Mo | 98 | 407007.184 | 0.8 | 58.127 | 51.96701 | 0.751 | 1.4 | ug/L |
| Rh | 103 | 319262.566 | 2.6 | 323620.727 | | | | ug/L |
| Ag | 107 | 628310.292 | 2.2 | 57.001 | 52.22720 | 1.179 | 2.3 | ug/L |
| Ag | 109 | 589756.641 | 2.2 | 41.334 | 50.53896 | 0.929 | 1.8 | ug/L |
| Cd | 111 | 146875.407 | 1.5 | 233.296 | 52.55948 | 0.384 | 0.7 | ug/L |
| Cd | 114 | 335647.234 | 1.0 | 64.652 | 52.62291 | 0.657 | 1.2 | ug/L |
| > In | 115 | 337906.030 | 1.3 | 364581.825 | | | | ug/L |
| Sb | 121 | 454419.017 | 1.5 | 51.001 | 51.35493 | 0.300 | 0.6 | ug/L |
| Sb | 123 | 336307.250 | 1.4 | 45.100 | 50.67808 | 1.352 | 2.7 | ug/L |
| Ba | 135 | 122189.155 | 2.3 | 65.001 | 52.30226 | 2.055 | 3.9 | ug/L |
| Ba | 137 | 208971.452 | 1.5 | 74.668 | 53.37405 | 0.598 | 1.1 | ug/L |
| > Tb | 159 | 415586.262 | 1.7 | 439210.410 | | | | ug/L |
| > Ho | 165 | 398437.415 | 1.6 | 425708.154 | | | | ug/L |
| Tl | 203 | 382403.759 | 1.3 | 51.001 | 52.11402 | 0.163 | 0.3 | ug/L |
| Tl | 205 | 897049.719 | 0.8 | 72.668 | 53.75337 | 0.902 | 1.7 | ug/L |
| Pb | 208 | 1221764.449 | 1.3 | 767.689 | 52.58551 | 0.398 | 0.8 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Tuesday, November 21, 2006 15:19:01

Page 1

915

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 308128.444 | 2.7 | 194.671 | 50.36982 | 0.573 | 1.1 ug/L |
| | Pb | 207 | 265346.684 | 0.5 | 181.671 | 52.14083 | 0.577 | 1.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 103.838 | | | | |
| Al | 27 | 108.286 | | | | |
| > Sc | 45 | | 93.858 | | | |
| V | 51 | 108.853 | | | | |
| Cr | 52 | 106.378 | | | | |
| Cr | 53 | 102.710 | | | | |
| Mn | 55 | 109.994 | | | | |
| Co | 59 | 105.445 | | | | |
| Ni | 60 | 107.823 | | | | |
| Ni | 62 | 105.010 | | | | |
| Cu | 63 | 106.193 | | | | |
| Cu | 65 | 108.065 | | | | |
| Zn | 66 | 101.916 | | | | |
| Zn | 67 | 101.764 | | | | |
| Zn | 68 | 105.277 | | | | |
| > Ge | 72 | | 95.649 | | | |
| As | 75 | 104.179 | | | | |
| Se | 77 | 105.394 | | | | |
| Se | 78 | 105.548 | | | | |
| Se | 82 | 105.794 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 105.957 | | | | |
| Mo | 97 | 105.487 | | | | |
| Mo | 98 | 103.934 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 104.454 | | | | |
| Ag | 109 | 101.078 | | | | |
| Cd | 111 | 105.119 | | | | |
| Cd | 114 | 105.246 | | | | |
| > In | 115 | | 92.683 | | | |
| Sb | 121 | 102.710 | | | | |
| Sb | 123 | 101.356 | | | | |
| Ba | 135 | 104.605 | | | | |
| Ba | 137 | 106.748 | | | | |
| > Tb | 159 | | 94.621 | | | |
| > Ho | 165 | | 93.594 | | | |
| Tl | 203 | 104.228 | | | | |
| Tl | 205 | 107.507 | | | | |
| Pb | 208 | 105.171 | | | | |
| Pb | 206 | 100.740 | | | | |
| Pb | 207 | 104.282 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Tuesday, November 21, 2006 15:21:56

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112106\QC Std 7.057

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 48.667 | 9.7 | 54.001 | -0.00195 | 0.005 | 239.4 | ug/L |
| Al | 27 | 3313.692 | 1.7 | 9687.584 | -0.74063 | 0.016 | 2.1 | ug/L |
| > Sc | 45 | 354726.257 | 2.0 | 378480.621 | | | | ug/L |
| V | 51 | 4129.380 | 1.9 | 4514.855 | -0.00751 | 0.009 | 125.7 | ug/L |
| Cr | 52 | 14035.617 | 0.2 | 14908.140 | 0.00567 | 0.022 | 384.1 | ug/L |
| Cr | 53 | 680.701 | 2.1 | 661.366 | 0.04259 | 0.008 | 18.6 | ug/L |
| Mn | 55 | 504.687 | 8.8 | 587.693 | -0.00315 | 0.003 | 95.6 | ug/L |
| Co | 59 | 163.003 | 10.5 | 242.339 | -0.00485 | 0.001 | 27.7 | ug/L |
| Ni | 60 | 508.021 | 1.6 | 623.696 | -0.02673 | 0.004 | 16.0 | ug/L |
| Ni | 62 | 322.009 | 0.6 | 504.354 | -0.33541 | 0.009 | 2.6 | ug/L |
| Cu | 63 | 815.381 | 1.1 | 1290.783 | -0.05774 | 0.000 | 0.6 | ug/L |
| Cu | 65 | 406.347 | 8.8 | 588.027 | -0.04372 | 0.010 | 22.3 | ug/L |
| Zn | 66 | 1543.492 | 1.2 | 2796.188 | -0.56523 | 0.015 | 2.6 | ug/L |
| Zn | 67 | 332.010 | 2.7 | 500.354 | -0.42512 | 0.036 | 8.6 | ug/L |
| Zn | 68 | 1200.765 | 1.3 | 2052.621 | -0.52385 | 0.019 | 3.6 | ug/L |
| > Ge | 72 | 182449.917 | 1.0 | 193550.369 | | | | ug/L |
| As | 75 | 121.669 | 1.7 | 97.335 | 0.01360 | 0.001 | 9.9 | ug/L |
| Se | 77 | 199.336 | 3.7 | 187.669 | 0.13967 | 0.039 | 28.1 | ug/L |
| Se | 78 | 13543.869 | 0.7 | 13588.495 | 1.41722 | 0.441 | 31.1 | mg/L |
| Se | 82 | 1318.771 | 0.8 | 1139.011 | 1.09568 | 0.083 | 7.5 | ug/L |
| Kr | 83 | 1378.795 | 2.6 | 1141.423 | | | | mg/L |
| Y | 89 | 342236.814 | 2.3 | 354910.360 | | | | ug/L |
| Mo | 95 | 542.023 | 18.4 | 114.335 | 0.08917 | 0.022 | 24.3 | ug/L |
| Mo | 97 | 314.009 | 20.3 | 49.001 | 0.08462 | 0.021 | 24.8 | ug/L |
| Mo | 98 | 742.319 | 20.3 | 58.127 | 0.08479 | 0.020 | 23.1 | ug/L |
| Rh | 103 | 318350.753 | 0.5 | 323620.727 | | | | ug/L |
| Ag | 107 | 141.669 | 21.1 | 57.001 | 0.00700 | 0.003 | 36.4 | ug/L |
| Ag | 109 | 118.669 | 9.8 | 41.334 | 0.00655 | 0.001 | 16.5 | ug/L |
| Cd | 111 | 206.589 | 4.4 | 233.296 | -0.00600 | 0.002 | 41.3 | ug/L |
| Cd | 114 | 52.497 | 17.4 | 64.652 | -0.00143 | 0.001 | 104.1 | ug/L |
| > In | 115 | 349852.016 | 1.2 | 364581.825 | | | | ug/L |
| Sb | 121 | 981.736 | 20.8 | 51.001 | 0.10199 | 0.023 | 23.0 | ug/L |
| Sb | 123 | 772.757 | 13.5 | 45.100 | 0.10624 | 0.016 | 15.1 | ug/L |
| Ba | 135 | 46.001 | 13.0 | 65.001 | -0.00658 | 0.003 | 40.5 | ug/L |
| Ba | 137 | 58.001 | 7.5 | 74.668 | -0.00319 | 0.001 | 38.6 | ug/L |
| > Tb | 159 | 414556.676 | 0.8 | 439210.410 | | | | ug/L |
| > Ho | 165 | 400530.010 | 1.9 | 425708.154 | | | | ug/L |
| Tl | 203 | 59.001 | 19.5 | 51.001 | 0.00151 | 0.002 | 110.7 | ug/L |
| Tl | 205 | 111.669 | 22.4 | 72.668 | 0.00258 | 0.001 | 57.5 | ug/L |
| Pb | 208 | 401.674 | 5.0 | 767.689 | -0.01373 | 0.001 | 6.0 | ug/L |

| | | | | | | | | |
|--|----|-----|---------|------|---------|----------|-------|-----------|
| | Pb | 206 | 112.335 | 8.0 | 194.671 | -0.01151 | 0.002 | 14.2 ug/L |
| | Pb | 207 | 100.335 | 12.1 | 181.671 | -0.01382 | 0.002 | 15.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 93.724 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 94.265 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 95.960 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 94.387 | | | |
| > Ho | 165 | | 94.086 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Metals Cover Page

Analyst: SDellb

Date: 11/22/06

Instrument: ECLAN

Data File: 112206

Reviewed By: SD 11/22/06

Entered By: SD 11/22/06

Approval: DCS 11/28/06

| Starlims Run # | Analytes Used | Batch ID | Method | Failed Analytes | Comments/ Problems |
|----------------|---------------------|----------|--------|-----------------|--------------------|
| 137904 | Be Cu Mn | M3990146 | 6020 | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

Package Data:

| Client Sub# | Package | Analytes Used | Failed Metals | Batch ID | Stds Attached? | Tranferred To LIMS | Raw Data Copied? |
|-------------|---------|---------------------|---------------|----------|----------------|--------------------|------------------|
| 34493 | 5 / ASP | Be Cu Mn | | M3990146 | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |
| | 5 / ASP | | | | Yes / No | MARRS / Run above | Yes / No |

921

Daily Performance Report

Sample ID: Sample

Sample Date/Time: Wednesday, November 22, 2006 08:53:12

Sample Description:

Method File: c:\elandata\Method\EPA DAILY.mth

Dataset File: c:\elandata\Dataset\Daily2006\Sample.242

Tuning File: c:\elandata\Tuning\epa.tun

Optimization File: c:\elandata\Optimize\epa2.dac

Dual Detector Mode: Dual

Acq. Dead Time(ns): 60

Current Dead Time (ns): 60

Summary

| Analyte | Mass | Meas. Intens. Mean | Net Intens. Mean | Net Intens. SD | Net Intens. RSD |
|---------|-------|--------------------|------------------|----------------|-----------------|
| Mg | 24.0 | 61815.4 | 61815.385 | 316.143 | 0.5 |
| Rh | 102.9 | 342509.9 | 342509.889 | 3894.385 | 1.1 |
| In | 114.9 | 350492.4 | 350492.433 | 4753.695 | 1.4 |
| Pb | 208.0 | 135304.9 | 135304.908 | 1365.238 | 1.0 |
| U | 238.1 | 234462.1 | 234462.092 | 1973.190 | 0.8 |
| [> Ba | 137.9 | 249014.8 | 249014.773 | 1519.593 | 0.6 |
| [Ba++ | 69.0 | 6746.2 | 0.027 | 0.001 | 1.9 |
| [> Ce | 139.9 | 350409.6 | 350409.591 | 3528.518 | 1.0 |
| [CeO | 155.9 | 7056.7 | 0.020 | 0.000 | 0.8 |
| Bkgd | 220.0 | 31.6 | 31.603 | 5.030 | 15.9 |

Current Optimization File Data

| Current Value | Description |
|---------------|-------------------------|
| 1.01 | Nebulizer Gas Flow |
| 8.00 | Lens Voltage |
| 1500.00 | ICP RF Power |
| -1832.50 | Analog Stage Voltage |
| 1017.50 | Pulse Stage Voltage |
| 70.00 | Discriminator Threshold |
| -2.50 | AC Rod Offset |

Current Autolens Data

| Analyte | Mass | Num of Pts | DAC Value | Maximum Intensity |
|---------|------|------------|-----------|-------------------|
| Be | 9 | 29 | 6.0 | 11347.2 |
| Co | 59 | 29 | 7.8 | 163395.3 |
| In | 115 | 29 | 8.0 | 266809.4 |

Elan 9000 Method 6020 - Summary Report

Sample ID: Blank

Sample Date/Time: Wednesday, November 22, 2006 09:48:54

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\Blank.001

*Skello
11/22/06*

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 49.334 | 1.2 | | | | | ug/L |
| Al | 27 | 2679.805 | 22.4 | | | | | ug/L |
| > Sc | 45 | 378193.541 | 2.4 | | | | | ug/L |
| V | 51 | 4537.327 | 1.7 | | | | | ug/L |
| Cr | 52 | 15100.490 | 2.0 | | | | | ug/L |
| Cr | 53 | 618.029 | 5.4 | | | | | ug/L |
| Mn | 55 | 580.693 | 7.6 | | | | | ug/L |
| Co | 59 | 202.004 | 5.6 | | | | | ug/L |
| Ni | 60 | 196.338 | 11.0 | | | | | ug/L |
| Ni | 62 | 499.020 | 5.7 | | | | | ug/L |
| Cu | 63 | 505.687 | 11.2 | | | | | ug/L |
| Cu | 65 | 212.672 | 17.8 | | | | | ug/L |
| Zn | 66 | 1298.448 | 11.7 | | | | | ug/L |
| Zn | 67 | 302.342 | 6.6 | | | | | ug/L |
| Zn | 68 | 996.736 | 7.3 | | | | | ug/L |
| > Ge | 72 | 197196.226 | 0.6 | | | | | ug/L |
| As | 75 | 96.335 | 13.5 | | | | | ug/L |
| Se | 77 | 202.002 | 2.3 | | | | | ug/L |
| Se | 78 | 14431.438 | 1.8 | | | | | mg/L |
| Se | 82 | 1747.050 | 0.8 | | | | | ug/L |
| Kr | 83 | 1793.211 | 5.0 | | | | | mg/L |
| Y | 89 | 365281.373 | 1.4 | | | | | ug/L |
| Mo | 95 | 120.335 | 18.7 | | | | | ug/L |
| Mo | 97 | 52.667 | 23.0 | | | | | ug/L |
| Mo | 98 | 70.498 | 34.3 | | | | | ug/L |
| Rh | 103 | 350376.944 | 2.2 | | | | | ug/L |
| Ag | 107 | 46.001 | 21.4 | | | | | ug/L |
| Ag | 109 | 42.334 | 11.9 | | | | | ug/L |
| Cd | 111 | 203.876 | 3.0 | | | | | ug/L |
| Cd | 114 | 55.152 | 19.8 | | | | | ug/L |
| > In | 115 | 366049.872 | 1.4 | | | | | ug/L |
| Sb | 121 | 54.667 | 15.2 | | | | | ug/L |
| Sb | 123 | 37.221 | 19.4 | | | | | ug/L |
| Ba | 135 | 52.001 | 18.9 | | | | | ug/L |
| Ba | 137 | 70.668 | 5.0 | | | | | ug/L |
| > Tb | 159 | 427712.876 | 0.7 | | | | | ug/L |
| > Ho | 165 | 412683.278 | 2.1 | | | | | ug/L |
| Tl | 203 | 51.667 | 22.3 | | | | | ug/L |
| Tl | 205 | 75.334 | 2.8 | | | | | ug/L |
| Pb | 208 | 440.342 | 39.2 | | | | | ug/L |

Sample ID: Blank

Report Date/Time: Wednesday, November 22, 2006 09:51:55

Page 1

923

| | | | | | |
|--|----|-----|---------|------|------|
| | Pb | 206 | 119.335 | 32.5 | ug/L |
| | Pb | 207 | 109.335 | 39.0 | ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 1

Sample Date/Time: Wednesday, November 22, 2006 09:54:51

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\Standard 1.002

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 10660.927 | 3.5 | 49.334 | 10.00000 | 0.531 | 5.3 | ug/L |
| Al | 27 | 89892.501 | 1.0 | 2679.805 | 10.00000 | 0.171 | 1.7 | ug/L |
| > Sc | 45 | 370838.752 | 1.9 | 378193.541 | | | | ug/L |
| V | 51 | 157762.142 | 1.9 | 4537.327 | 10.00000 | 0.358 | 3.6 | ug/L |
| Cr | 52 | 143102.747 | 2.3 | 15100.490 | 10.00000 | 0.421 | 4.2 | ug/L |
| Cr | 53 | 16137.114 | 3.1 | 618.029 | 10.00000 | 0.509 | 5.1 | ug/L |
| Mn | 55 | 173909.026 | 0.7 | 580.693 | 10.00000 | 0.136 | 1.4 | ug/L |
| Co | 59 | 154574.500 | 1.5 | 202.004 | 10.00000 | 0.311 | 3.1 | ug/L |
| Ni | 60 | 33691.317 | 1.6 | 196.338 | 10.00000 | 0.320 | 3.2 | ug/L |
| Ni | 62 | 5433.492 | 1.8 | 499.020 | 10.00000 | 0.180 | 1.8 | ug/L |
| Cu | 63 | 78187.536 | 0.5 | 505.687 | 10.00000 | 0.225 | 2.3 | ug/L |
| Cu | 65 | 36705.699 | 0.9 | 212.672 | 10.00000 | 0.237 | 2.4 | ug/L |
| Zn | 66 | 23695.545 | 0.5 | 1298.448 | 10.00000 | 0.144 | 1.4 | ug/L |
| Zn | 67 | 4054.027 | 1.4 | 302.342 | 10.00000 | 0.065 | 0.7 | ug/L |
| Zn | 68 | 17240.992 | 1.6 | 996.736 | 10.00000 | 0.077 | 0.8 | ug/L |
| > Ge | 72 | 192496.953 | 1.8 | 197196.226 | | | | ug/L |
| As | 75 | 24442.711 | 1.5 | 96.335 | 10.00000 | 0.324 | 3.2 | ug/L |
| Se | 77 | 1941.026 | 1.4 | 202.002 | 10.00000 | 0.269 | 2.7 | ug/L |
| Se | 78 | 20238.254 | 1.6 | 14431.438 | 10.00000 | 0.803 | 8.0 | mg/L |
| Se | 82 | 4236.210 | 0.7 | 1747.050 | 10.00000 | 0.417 | 4.2 | ug/L |
| Kr | 83 | 1771.539 | 2.3 | 1793.211 | | | | mg/L |
| Y | 89 | 357604.013 | 2.3 | 365281.373 | | | | ug/L |
| Mo | 95 | 53927.525 | 2.3 | 120.335 | 10.00000 | 0.202 | 2.0 | ug/L |
| Mo | 97 | 33005.570 | 1.3 | 52.667 | 10.00000 | 0.181 | 1.8 | ug/L |
| Mo | 98 | 86237.788 | 2.8 | 70.498 | 10.00000 | 0.343 | 3.4 | ug/L |
| Rh | 103 | 325859.643 | 1.7 | 350376.944 | | | | ug/L |
| Ag | 107 | 141421.192 | 1.7 | 46.001 | 10.00000 | 0.118 | 1.2 | ug/L |
| Ag | 109 | 133874.368 | 2.9 | 42.334 | 10.00000 | 0.341 | 3.4 | ug/L |
| Cd | 111 | 30874.125 | 0.9 | 203.876 | 10.00000 | 0.043 | 0.4 | ug/L |
| Cd | 114 | 70180.939 | 0.4 | 55.152 | 10.00000 | 0.101 | 1.0 | ug/L |
| > In | 115 | 367083.884 | 0.6 | 366049.872 | | | | ug/L |
| Sb | 121 | 95725.999 | 1.1 | 54.667 | 10.00000 | 0.124 | 1.2 | ug/L |
| Sb | 123 | 72525.911 | 1.3 | 37.221 | 10.00000 | 0.119 | 1.2 | ug/L |
| Ba | 135 | 23473.586 | 1.3 | 52.001 | 10.00000 | 0.156 | 1.6 | ug/L |
| Ba | 137 | 39690.030 | 1.1 | 70.668 | 10.00000 | 0.110 | 1.1 | ug/L |
| > Tb | 159 | 408896.293 | 1.1 | 427712.876 | | | | ug/L |
| > Ho | 165 | 409298.267 | 0.8 | 412683.278 | | | | ug/L |
| Tl | 203 | 82620.042 | 0.6 | 51.667 | 10.00000 | 0.127 | 1.3 | ug/L |
| Tl | 205 | 194208.973 | 0.8 | 75.334 | 10.00000 | 0.063 | 0.6 | ug/L |
| Pb | 208 | 262525.065 | 1.1 | 440.342 | 10.00000 | 0.091 | 0.9 | ug/L |

Sample ID: Standard 1

Report Date/Time: Wednesday, November 22, 2006 09:57:52

Page 1

925

| | | | | | | | | |
|--|----|-----|-----------|-----|---------|----------|-------|----------|
| | Pb | 206 | 69148.418 | 1.1 | 119.335 | 10.00000 | 0.140 | 1.4 ug/L |
| | Pb | 207 | 56455.866 | 1.9 | 109.335 | 10.00000 | 0.175 | 1.8 ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 2

Sample Date/Time: Wednesday, November 22, 2006 10:00:48

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\Standard 2.003

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 21259.975 | 2.5 | 49.334 | 19.98880 | 0.756 | 3.8 | ug/L |
| Al | 27 | 172925.978 | 2.1 | 2679.805 | 19.89343 | 0.515 | 2.6 | ug/L |
| Sc | 45 | 371526.580 | 1.6 | 378193.541 | | | | ug/L |
| V | 51 | 299381.932 | 0.5 | 4537.327 | 19.83396 | 0.338 | 1.7 | ug/L |
| Cr | 52 | 266775.800 | 1.0 | 15100.490 | 19.91809 | 0.508 | 2.6 | ug/L |
| Cr | 53 | 31166.499 | 2.0 | 618.029 | 19.92595 | 0.734 | 3.7 | ug/L |
| Mn | 55 | 348518.445 | 0.9 | 580.693 | 19.95163 | 0.352 | 1.8 | ug/L |
| Co | 59 | 307265.401 | 1.2 | 202.004 | 19.91360 | 0.157 | 0.8 | ug/L |
| Ni | 60 | 66225.137 | 1.5 | 196.338 | 19.87712 | 0.422 | 2.1 | ug/L |
| Ni | 62 | 10502.720 | 1.6 | 499.020 | 19.98327 | 0.161 | 0.8 | ug/L |
| Cu | 63 | 154877.567 | 0.8 | 505.687 | 19.90997 | 0.254 | 1.3 | ug/L |
| Cu | 65 | 71968.494 | 0.8 | 212.672 | 19.86675 | 0.058 | 0.3 | ug/L |
| Zn | 66 | 45143.732 | 0.5 | 1298.448 | 19.84518 | 0.234 | 1.2 | ug/L |
| Zn | 67 | 7772.034 | 1.1 | 302.342 | 19.91289 | 0.403 | 2.0 | ug/L |
| Zn | 68 | 32732.517 | 2.7 | 996.736 | 19.83768 | 0.723 | 3.6 | ug/L |
| Ge | 72 | 195526.271 | 0.8 | 197196.226 | | | | ug/L |
| As | 75 | 48973.078 | 3.4 | 96.335 | 19.95127 | 0.794 | 4.0 | ug/L |
| Se | 77 | 3750.911 | 0.8 | 202.002 | 20.00821 | 0.243 | 1.2 | ug/L |
| Se | 78 | 25249.502 | 1.9 | 14431.438 | 19.44559 | 1.208 | 6.2 | mg/L |
| Se | 82 | 6699.826 | 0.7 | 1747.050 | 19.85926 | 0.230 | 1.2 | ug/L |
| Kr | 83 | 1809.548 | 1.8 | 1793.211 | | | | mg/L |
| Y | 89 | 359707.461 | 2.2 | 365281.373 | | | | ug/L |
| Mo | 95 | 105260.684 | 0.7 | 120.335 | 19.87371 | 0.343 | 1.7 | ug/L |
| Mo | 97 | 65742.034 | 2.1 | 52.667 | 19.95407 | 0.467 | 2.3 | ug/L |
| Mo | 98 | 172289.266 | 2.5 | 70.498 | 19.96499 | 0.710 | 3.6 | ug/L |
| Rh | 103 | 332717.682 | 1.3 | 350376.944 | | | | ug/L |
| Ag | 107 | 276989.917 | 0.4 | 46.001 | 19.88431 | 0.442 | 2.2 | ug/L |
| Ag | 109 | 264134.271 | 2.2 | 42.334 | 19.91223 | 0.207 | 1.0 | ug/L |
| Cd | 111 | 61175.749 | 1.4 | 203.876 | 19.94328 | 0.343 | 1.7 | ug/L |
| Cd | 114 | 138234.623 | 1.9 | 55.152 | 19.90840 | 0.715 | 3.6 | ug/L |
| In | 115 | 370131.730 | 2.1 | 366049.872 | | | | ug/L |
| Sb | 121 | 190351.496 | 1.8 | 54.667 | 19.94607 | 0.610 | 3.1 | ug/L |
| Sb | 123 | 140522.193 | 0.7 | 37.221 | 19.84051 | 0.508 | 2.6 | ug/L |
| Ba | 135 | 46042.667 | 1.9 | 52.001 | 19.99288 | 0.313 | 1.6 | ug/L |
| Ba | 137 | 77704.490 | 2.2 | 70.668 | 19.98462 | 0.410 | 2.1 | ug/L |
| Tb | 159 | 402140.640 | 1.3 | 427712.876 | | | | ug/L |
| Ho | 165 | 407128.789 | 0.8 | 412683.278 | | | | ug/L |
| Tl | 203 | 162158.244 | 1.1 | 51.667 | 19.94681 | 0.224 | 1.1 | ug/L |
| Tl | 205 | 376764.272 | 0.5 | 75.334 | 19.89962 | 0.243 | 1.2 | ug/L |
| Pb | 208 | 516129.891 | 0.5 | 440.342 | 19.95610 | 0.251 | 1.3 | ug/L |

Sample ID: Standard 2

Report Date/Time: Wednesday, November 22, 2006 10:03:49

Page 1

927

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 136011.335 | 0.6 | 119.335 | 19.95795 | 0.256 | 1.3 ug/L |
| | Pb | 207 | 111283.365 | 1.7 | 109.335 | 19.96720 | 0.434 | 2.2 ug/L |

Elan 9000 Method 6020 - Summary Report

Sample ID: Standard 3

Sample Date/Time: Wednesday, November 22, 2006 10:06:46

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\Standard 3.004

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 101673.604 | 1.6 | 49.334 | 99.78635 | 2.998 | 3.0 | ug/L |
| Al | 27 | 827174.916 | 1.9 | 2679.805 | 99.81487 | 2.165 | 2.2 | ug/L |
| > Sc | 45 | 371874.089 | 3.1 | 378193.541 | | | | ug/L |
| V | 51 | 1402884.189 | 0.7 | 4537.327 | 99.69648 | 2.518 | 2.5 | ug/L |
| Cr | 52 | 1245698.556 | 1.6 | 15100.490 | 99.86440 | 1.751 | 1.8 | ug/L |
| Cr | 53 | 149527.025 | 1.9 | 618.029 | 99.85335 | 2.051 | 2.1 | ug/L |
| Mn | 55 | 1648492.522 | 1.2 | 580.693 | 99.88633 | 0.322 | 0.3 | ug/L |
| Co | 59 | 1421542.453 | 1.7 | 202.004 | 99.76446 | 0.689 | 0.7 | ug/L |
| Ni | 60 | 318046.467 | 0.5 | 196.338 | 99.94715 | 0.969 | 1.0 | ug/L |
| Ni | 62 | 49825.027 | 1.5 | 499.020 | 100.08680 | 1.281 | 1.3 | ug/L |
| Cu | 63 | 744571.312 | 2.8 | 505.687 | 99.96075 | 2.133 | 2.1 | ug/L |
| Cu | 65 | 363143.168 | 2.6 | 212.672 | 100.17712 | 1.725 | 1.7 | ug/L |
| Zn | 66 | 211331.582 | 2.0 | 1298.448 | 99.91636 | 2.697 | 2.7 | ug/L |
| Zn | 67 | 35522.658 | 4.2 | 302.342 | 99.85410 | 3.232 | 3.2 | ug/L |
| Zn | 68 | 152545.132 | 1.0 | 996.736 | 99.89819 | 1.013 | 1.0 | ug/L |
| > Ge | 72 | 189166.123 | 1.5 | 197196.226 | | | | ug/L |
| As | 75 | 233290.046 | 2.9 | 96.335 | 99.92143 | 2.568 | 2.6 | ug/L |
| Se | 77 | 17532.157 | 0.9 | 202.002 | 100.04676 | 0.684 | 0.7 | ug/L |
| Se | 78 | 68702.451 | 1.6 | 14431.438 | 100.03555 | 0.537 | 0.5 | mg/L |
| Se | 82 | 25096.537 | 1.2 | 1747.050 | 99.84249 | 2.274 | 2.3 | ug/L |
| Kr | 83 | 1047.743 | 7.1 | 1793.211 | | | | mg/L |
| Y | 89 | 353008.635 | 1.5 | 365281.373 | | | | ug/L |
| Mo | 95 | 499210.828 | 1.1 | 120.335 | 99.86691 | 2.009 | 2.0 | ug/L |
| Mo | 97 | 313701.800 | 1.6 | 52.667 | 99.91694 | 4.025 | 4.0 | ug/L |
| Mo | 98 | 810387.952 | 1.4 | 70.498 | 99.84491 | 1.140 | 1.1 | ug/L |
| Rh | 103 | 321017.884 | 2.1 | 350376.944 | | | | ug/L |
| Ag | 107 | 1266378.888 | 1.1 | 46.001 | 99.68304 | 1.515 | 1.5 | ug/L |
| Ag | 109 | 1214209.766 | 2.8 | 42.334 | 99.71791 | 1.713 | 1.7 | ug/L |
| Cd | 111 | 295956.756 | 1.0 | 203.876 | 99.98829 | 1.537 | 1.5 | ug/L |
| Cd | 114 | 681784.505 | 3.9 | 55.152 | 100.05666 | 1.447 | 1.4 | ug/L |
| > In | 115 | 358981.062 | 2.5 | 366049.872 | | | | ug/L |
| Sb | 121 | 899997.889 | 1.1 | 54.667 | 99.86547 | 1.487 | 1.5 | ug/L |
| Sb | 123 | 664241.599 | 2.3 | 37.221 | 99.83722 | 0.298 | 0.3 | ug/L |
| Ba | 135 | 219886.002 | 2.9 | 52.001 | 99.75203 | 2.838 | 2.8 | ug/L |
| Ba | 137 | 370939.098 | 2.2 | 70.668 | 99.74692 | 1.880 | 1.9 | ug/L |
| > Tb | 159 | 404341.529 | 0.8 | 427712.876 | | | | ug/L |
| > Ho | 165 | 390874.409 | 1.7 | 412683.278 | | | | ug/L |
| Tl | 203 | 748999.959 | 0.6 | 51.667 | 99.80199 | 1.341 | 1.3 | ug/L |
| Tl | 205 | 1709592.758 | 1.3 | 75.334 | 99.70047 | 0.865 | 0.9 | ug/L |
| Pb | 208 | 2403409.124 | 1.9 | 440.342 | 99.84529 | 0.451 | 0.5 | ug/L |

Sample ID: Standard 3

Report Date/Time: Wednesday, November 22, 2006 10:09:48

Page 1

929

| | | | | | | | | |
|---|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 623595.420 | 1.9 | 119.335 | 99.76921 | 0.173 | 0.2 ug/L |
| L | Pb | 207 | 524509.836 | 2.8 | 109.335 | 99.90717 | 1.666 | 1.7 ug/L |

Quantitative Analysis Calibration Report

File Name: 112206.cal
File Path: C:\elandata\System
Calibration Type: External Calibration

| Analyte | Mass | Curve Type | Slope | Intercept | Corr. Coeff. |
|---------|---------|------------------|-------|-----------|--------------|
| Be | 9.012 | Linear Thru Zero | 0.00 | 0.00 | 0.999954 |
| Al | 26.982 | Linear Thru Zero | 0.02 | 0.00 | 0.999963 |
| Sc | 44.956 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| V | 50.944 | Linear Thru Zero | 0.04 | 0.00 | 0.999901 |
| Cr | 51.941 | Linear Thru Zero | 0.03 | 0.00 | 0.999980 |
| Cr | 52.941 | Linear Thru Zero | 0.00 | 0.00 | 0.999977 |
| Mn | 54.938 | Linear Thru Zero | 0.09 | 0.00 | 0.999986 |
| Co | 58.933 | Linear Thru Zero | 0.08 | 0.00 | 0.999943 |
| Ni | 59.933 | Linear Thru Zero | 0.02 | 0.00 | 0.999994 |
| Ni | 61.928 | Linear Thru Zero | 0.00 | 0.00 | 0.999992 |
| Cu | 62.930 | Linear Thru Zero | 0.04 | 0.00 | 0.999996 |
| Cu | 64.928 | Linear Thru Zero | 0.02 | 0.00 | 0.999965 |
| Zn | 65.926 | Linear Thru Zero | 0.01 | 0.00 | 0.999987 |
| Zn | 66.927 | Linear Thru Zero | 0.00 | 0.00 | 0.999977 |
| Zn | 67.925 | Linear Thru Zero | 0.01 | 0.00 | 0.999983 |
| Ge | 71.922 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| As | 74.922 | Linear Thru Zero | 0.01 | 0.00 | 0.999993 |
| Se | 76.920 | Linear Thru Zero | 0.00 | 0.00 | 0.999998 |
| Se | 77.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999927 |
| Se | 81.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999970 |
| Kr | 82.914 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Y | 88.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Mo | 94.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999978 |
| Mo | 96.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999993 |
| Mo | 97.906 | Linear Thru Zero | 0.02 | 0.00 | 0.999976 |
| Rh | 102.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ag | 106.905 | Linear Thru Zero | 0.04 | 0.00 | 0.999896 |
| Ag | 108.905 | Linear Thru Zero | 0.03 | 0.00 | 0.999918 |
| Cd | 110.904 | Linear Thru Zero | 0.01 | 0.00 | 0.999999 |
| Cd | 113.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999995 |
| In | 114.904 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Sb | 120.904 | Linear Thru Zero | 0.03 | 0.00 | 0.999981 |
| Sb | 122.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999967 |
| Ba | 134.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999939 |
| Ba | 136.905 | Linear Thru Zero | 0.01 | 0.00 | 0.999936 |
| Tb | 158.925 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ho | 164.930 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Tl | 202.972 | Linear Thru Zero | 0.02 | 0.00 | 0.999960 |
| Tl | 204.975 | Linear Thru Zero | 0.04 | 0.00 | 0.999908 |
| Pb | 207.977 | Linear Thru Zero | 0.06 | 0.00 | 0.999976 |

931

| | | | | | |
|----|---------|------------------|------|------|----------|
| Pb | 205.975 | Linear Thru Zero | 0.02 | 0.00 | 0.999946 |
| Pb | 206.976 | Linear Thru Zero | 0.01 | 0.00 | 0.999991 |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 1

Sample Date/Time: Wednesday, November 22, 2006 10:12:45

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 1.005

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 50452.788 | 1.3 | 49.334 | 51.21575 | 0.700 | 1.4 | ug/L |
| Al | 27 | 427869.523 | 2.7 | 2679.805 | 53.27605 | 0.389 | 0.7 | ug/L |
| > Sc | 45 | 359228.951 | 2.1 | 378193.541 | | | | ug/L |
| V | 51 | 746076.573 | 0.4 | 4537.327 | 54.72861 | 1.025 | 1.9 | ug/L |
| Cr | 52 | 623363.383 | 2.6 | 15100.490 | 51.13446 | 0.861 | 1.7 | ug/L |
| Cr | 53 | 72788.231 | 0.2 | 618.029 | 50.11320 | 1.067 | 2.1 | ug/L |
| Mn | 55 | 839656.193 | 1.4 | 580.693 | 53.13955 | 0.552 | 1.0 | ug/L |
| Co | 59 | 705828.157 | 1.5 | 202.004 | 51.75501 | 1.147 | 2.2 | ug/L |
| Ni | 60 | 161273.724 | 2.3 | 196.338 | 52.91643 | 0.886 | 1.7 | ug/L |
| Ni | 62 | 24329.708 | 0.7 | 499.020 | 50.58702 | 0.498 | 1.0 | ug/L |
| Cu | 63 | 384805.664 | 0.6 | 505.687 | 53.95079 | 0.417 | 0.8 | ug/L |
| Cu | 65 | 185574.718 | 1.6 | 212.672 | 53.46170 | 0.490 | 0.9 | ug/L |
| Zn | 66 | 101076.642 | 0.5 | 1298.448 | 49.62723 | 0.380 | 0.8 | ug/L |
| Zn | 67 | 17826.560 | 1.3 | 302.342 | 51.97740 | 0.933 | 1.8 | ug/L |
| Zn | 68 | 75093.030 | 2.4 | 996.736 | 51.06725 | 0.896 | 1.8 | ug/L |
| > Ge | 72 | 181049.459 | 0.7 | 197196.226 | | | | ug/L |
| As | 75 | 116965.690 | 1.0 | 96.335 | 52.32714 | 0.816 | 1.6 | ug/L |
| Se | 77 | 8732.373 | 0.2 | 202.002 | 51.52674 | 0.300 | 0.6 | ug/L |
| Se | 78 | 42436.477 | 1.0 | 14431.438 | 55.60766 | 0.318 | 0.6 | mg/L |
| Se | 82 | 12500.235 | 0.8 | 1747.050 | 48.52506 | 0.462 | 1.0 | ug/L |
| Kr | 83 | 651.032 | 10.4 | 1793.211 | | | | mg/L |
| Y | 89 | 344695.701 | 3.1 | 365281.373 | | | | ug/L |
| Mo | 95 | 255509.550 | 0.5 | 120.335 | 52.23858 | 0.851 | 1.6 | ug/L |
| Mo | 97 | 160536.511 | 2.6 | 52.667 | 52.24807 | 1.916 | 3.7 | ug/L |
| Mo | 98 | 404621.964 | 1.1 | 70.498 | 50.95561 | 0.372 | 0.7 | ug/L |
| Rh | 103 | 324823.697 | 2.5 | 350376.944 | | | | ug/L |
| Ag | 107 | 654139.719 | 1.0 | 46.001 | 52.63723 | 1.098 | 2.1 | ug/L |
| Ag | 109 | 618066.483 | 1.1 | 42.334 | 51.89320 | 0.376 | 0.7 | ug/L |
| Cd | 111 | 147204.922 | 2.8 | 203.876 | 50.81607 | 2.030 | 4.0 | ug/L |
| Cd | 114 | 330420.816 | 1.5 | 55.152 | 49.59421 | 1.257 | 2.5 | ug/L |
| > In | 115 | 351117.924 | 1.2 | 366049.872 | | | | ug/L |
| Sb | 121 | 433915.609 | 1.2 | 54.667 | 49.21633 | 0.900 | 1.8 | ug/L |
| Sb | 123 | 331348.341 | 1.2 | 37.221 | 50.91758 | 0.863 | 1.7 | ug/L |
| Ba | 135 | 109267.468 | 0.6 | 52.001 | 50.59546 | 0.199 | 0.4 | ug/L |
| Ba | 137 | 191464.111 | 1.6 | 70.668 | 52.55614 | 0.895 | 1.7 | ug/L |
| > Tb | 159 | 396060.269 | 0.8 | 427712.876 | | | | ug/L |
| > Ho | 165 | 381586.394 | 0.3 | 412683.278 | | | | ug/L |
| Tl | 203 | 386040.187 | 1.7 | 51.667 | 52.67848 | 0.716 | 1.4 | ug/L |
| Tl | 205 | 876732.221 | 1.0 | 75.334 | 52.36861 | 0.501 | 1.0 | ug/L |
| Pb | 208 | 1212474.975 | 1.7 | 440.342 | 51.58725 | 0.716 | 1.4 | ug/L |

Sample ID: QC Std 1

Report Date/Time: Wednesday, November 22, 2006 10:15:47

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 315384.443 | 1.7 | 119.335 | 51.67845 | 0.844 | 1.6 ug/L |
| | Pb | 207 | 263594.145 | 2.7 | 109.335 | 51.42291 | 1.258 | 2.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 102.432 | | | | |
| Al | 27 | 106.552 | | | | |
| > Sc | 45 | | 94.985 | | | |
| V | 51 | 109.457 | | | | |
| Cr | 52 | 102.269 | | | | |
| Cr | 53 | 100.226 | | | | |
| Mn | 55 | 106.279 | | | | |
| Co | 59 | 103.510 | | | | |
| Ni | 60 | 105.833 | | | | |
| Ni | 62 | 101.174 | | | | |
| Cu | 63 | 107.902 | | | | |
| Cu | 65 | 106.923 | | | | |
| Zn | 66 | 99.254 | | | | |
| Zn | 67 | 103.955 | | | | |
| Zn | 68 | 102.134 | | | | |
| > Ge | 72 | | 91.812 | | | |
| As | 75 | 104.654 | | | | |
| Se | 77 | 103.053 | | | | |
| Se | 78 | 111.215 | | | | |
| Se | 82 | 97.050 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 104.477 | | | | |
| Mo | 97 | 104.496 | | | | |
| Mo | 98 | 101.911 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 105.274 | | | | |
| Ag | 109 | 103.786 | | | | |
| Cd | 111 | 101.632 | | | | |
| Cd | 114 | 99.188 | | | | |
| > In | 115 | | 95.921 | | | |
| Sb | 121 | 98.433 | | | | |
| Sb | 123 | 101.835 | | | | |
| Ba | 135 | 101.191 | | | | |
| Ba | 137 | 105.112 | | | | |
| > Tb | 159 | | 92.600 | | | |
| > Ho | 165 | | 92.465 | | | |
| Tl | 203 | 105.357 | | | | |
| Tl | 205 | 104.737 | | | | |
| Pb | 208 | 103.175 | | | | |
| Pb | 206 | 103.357 | | | | |
| Pb | 207 | 102.846 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 2

Sample Date/Time: Wednesday, November 22, 2006 10:18:43

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 2.006

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 48.334 | 22.8 | 49.334 | -0.00079 | 0.011 | 1435.9 | ug/L |
| Al | 27 | 2223.986 | 1.5 | 2679.805 | -0.05370 | 0.004 | 8.3 | ug/L |
| Sc | 45 | 377464.987 | 1.7 | 378193.541 | | | | ug/L |
| V | 51 | 4161.402 | 3.3 | 4537.327 | -0.02562 | 0.014 | 55.2 | ug/L |
| Cr | 52 | 14010.580 | 2.6 | 15100.490 | -0.08424 | 0.047 | 56.2 | ug/L |
| Cr | 53 | 586.693 | 2.8 | 618.029 | -0.01980 | 0.014 | 72.3 | ug/L |
| Mn | 55 | 519.355 | 3.3 | 580.693 | -0.00262 | 0.001 | 47.1 | ug/L |
| Co | 59 | 212.005 | 4.1 | 202.004 | 0.00112 | 0.001 | 61.8 | ug/L |
| Ni | 60 | 168.003 | 6.3 | 196.338 | -0.00695 | 0.004 | 53.8 | ug/L |
| Ni | 62 | 569.025 | 1.2 | 499.020 | 0.17061 | 0.005 | 2.7 | ug/L |
| Cu | 63 | 524.355 | 5.4 | 505.687 | 0.00449 | 0.003 | 73.0 | ug/L |
| Cu | 65 | 167.670 | 7.6 | 212.672 | -0.01054 | 0.003 | 31.1 | ug/L |
| Zn | 66 | 1168.094 | 3.0 | 1298.448 | -0.04281 | 0.020 | 46.7 | ug/L |
| Zn | 67 | 264.340 | 4.3 | 302.342 | -0.08075 | 0.038 | 47.1 | ug/L |
| Zn | 68 | 842.718 | 4.2 | 996.736 | -0.08067 | 0.027 | 33.1 | ug/L |
| Ge | 72 | 191249.712 | 1.0 | 197196.226 | | | | ug/L |
| As | 75 | 128.336 | 12.4 | 96.335 | 0.01475 | 0.006 | 42.2 | ug/L |
| Se | 77 | 205.269 | 4.6 | 202.002 | 0.05345 | 0.055 | 102.3 | ug/L |
| Se | 78 | 14229.810 | 0.4 | 14431.438 | 0.42308 | 0.298 | 70.3 | mg/L |
| Se | 82 | 667.493 | 1.7 | 1747.050 | -4.32875 | 0.063 | 1.5 | ug/L |
| Kr | 83 | 629.363 | 5.7 | 1793.211 | | | | mg/L |
| Y | 89 | 356025.555 | 1.1 | 365281.373 | | | | ug/L |
| Mo | 95 | 660.033 | 20.4 | 120.335 | 0.10555 | 0.027 | 25.8 | ug/L |
| Mo | 97 | 388.013 | 27.9 | 52.667 | 0.10443 | 0.034 | 33.0 | ug/L |
| Mo | 98 | 954.271 | 22.1 | 70.498 | 0.10650 | 0.026 | 24.6 | ug/L |
| Rh | 103 | 329740.074 | 2.7 | 350376.944 | | | | ug/L |
| Ag | 107 | 119.335 | 26.9 | 46.001 | 0.00564 | 0.003 | 44.9 | ug/L |
| Ag | 109 | 98.668 | 22.6 | 42.334 | 0.00452 | 0.002 | 41.1 | ug/L |
| Cd | 111 | 213.887 | 11.2 | 203.876 | 0.00306 | 0.008 | 258.7 | ug/L |
| Cd | 114 | 68.414 | 13.7 | 55.152 | 0.00188 | 0.001 | 74.8 | ug/L |
| In | 115 | 367364.842 | 1.1 | 366049.872 | | | | ug/L |
| Sb | 121 | 1210.435 | 19.0 | 54.667 | 0.12542 | 0.026 | 20.6 | ug/L |
| Sb | 123 | 883.465 | 17.9 | 37.221 | 0.12439 | 0.024 | 19.4 | ug/L |
| Ba | 135 | 52.667 | 12.6 | 52.001 | 0.00201 | 0.003 | 148.7 | ug/L |
| Ba | 137 | 56.334 | 12.5 | 70.668 | -0.00255 | 0.002 | 77.3 | ug/L |
| Tb | 159 | 397339.456 | 0.4 | 427712.876 | | | | ug/L |
| Ho | 165 | 399632.571 | 1.8 | 412683.278 | | | | ug/L |
| Tl | 203 | 66.668 | 19.5 | 51.667 | 0.00217 | 0.002 | 78.2 | ug/L |
| Tl | 205 | 117.335 | 12.4 | 75.334 | 0.00254 | 0.001 | 33.9 | ug/L |
| Pb | 208 | 358.673 | 5.4 | 440.342 | -0.00275 | 0.001 | 32.3 | ug/L |

Sample ID: QC Std 2

Report Date/Time: Wednesday, November 22, 2006 10:21:43

Page 1

936

| | | | | | | | | | |
|---|----|-----|---------|-----|---------|----------|-------|------|------|
| I | Pb | 206 | 104.668 | 7.3 | 119.335 | -0.00170 | 0.001 | 70.6 | ug/L |
| L | Pb | 207 | 86.668 | 5.9 | 109.335 | -0.00357 | 0.001 | 34.0 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 99.807 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 96.984 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 100.359 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 92.899 | | | |
| > Ho | 165 | | 96.838 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Wednesday, November 22, 2006 10:24:39

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 3.007

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1108.085 | 4.1 | 49.334 | 1.06024 | 0.039 | 3.7 | ug/L |
| Al | 27 | 91982.218 | 1.8 | 2679.805 | 11.02442 | 0.323 | 2.9 | ug/L |
| > Sc | 45 | 364990.698 | 1.4 | 378193.541 | | | | ug/L |
| V | 51 | 19543.788 | 1.0 | 4537.327 | 1.10126 | 0.034 | 3.1 | ug/L |
| Cr | 52 | 27915.968 | 1.7 | 15100.490 | 1.10326 | 0.073 | 6.6 | ug/L |
| Cr | 53 | 2134.628 | 2.2 | 618.029 | 1.05084 | 0.049 | 4.6 | ug/L |
| Mn | 55 | 18755.275 | 2.1 | 580.693 | 1.10646 | 0.054 | 4.8 | ug/L |
| Co | 59 | 15372.653 | 0.6 | 202.004 | 1.06851 | 0.040 | 3.7 | ug/L |
| Ni | 60 | 3576.803 | 1.6 | 196.338 | 1.06901 | 0.058 | 5.5 | ug/L |
| Ni | 62 | 1110.419 | 4.5 | 499.020 | 1.28578 | 0.062 | 4.8 | ug/L |
| Cu | 63 | 8168.751 | 1.9 | 505.687 | 1.03493 | 0.020 | 1.9 | ug/L |
| Cu | 65 | 3850.595 | 3.3 | 212.672 | 1.01056 | 0.077 | 7.6 | ug/L |
| Zn | 66 | 15129.881 | 2.9 | 1298.448 | 6.61790 | 0.065 | 1.0 | ug/L |
| Zn | 67 | 2271.666 | 0.1 | 302.342 | 5.63594 | 0.248 | 4.4 | ug/L |
| Zn | 68 | 10570.472 | 0.3 | 996.736 | 6.35597 | 0.276 | 4.3 | ug/L |
| > Ge | 72 | 188793.391 | 3.7 | 197196.226 | | | | ug/L |
| As | 75 | 2435.714 | 1.8 | 96.335 | 1.00663 | 0.022 | 2.2 | ug/L |
| Se | 77 | 371.608 | 5.4 | 202.002 | 1.02995 | 0.067 | 6.5 | ug/L |
| Se | 78 | 14678.115 | 1.6 | 14431.438 | 1.60751 | 1.372 | 85.4 | mg/L |
| Se | 82 | 906.916 | 0.9 | 1747.050 | -3.26591 | 0.167 | 5.1 | ug/L |
| Kr | 83 | 667.033 | 2.7 | 1793.211 | | | | mg/L |
| Y | 89 | 357120.365 | 0.8 | 365281.373 | | | | ug/L |
| Mo | 95 | 5462.513 | 4.4 | 120.335 | 1.07741 | 0.069 | 6.4 | ug/L |
| Mo | 97 | 3467.756 | 2.3 | 52.667 | 1.09565 | 0.046 | 4.2 | ug/L |
| Mo | 98 | 8768.306 | 2.4 | 70.498 | 1.07932 | 0.031 | 2.8 | ug/L |
| Rh | 103 | 327015.307 | 2.0 | 350376.944 | | | | ug/L |
| Ag | 107 | 13786.538 | 2.7 | 46.001 | 1.08949 | 0.049 | 4.5 | ug/L |
| Ag | 109 | 12853.041 | 3.5 | 42.334 | 1.05918 | 0.018 | 1.7 | ug/L |
| Cd | 111 | 3383.919 | 1.1 | 203.876 | 1.08444 | 0.034 | 3.2 | ug/L |
| Cd | 114 | 7231.829 | 1.7 | 55.152 | 1.06105 | 0.009 | 0.9 | ug/L |
| > In | 115 | 356530.918 | 1.9 | 366049.872 | | | | ug/L |
| Sb | 121 | 9890.299 | 1.8 | 54.667 | 1.09890 | 0.014 | 1.2 | ug/L |
| Sb | 123 | 7264.570 | 2.0 | 37.221 | 1.09393 | 0.010 | 0.9 | ug/L |
| Ba | 135 | 2396.369 | 3.0 | 52.001 | 1.04562 | 0.033 | 3.2 | ug/L |
| Ba | 137 | 3987.327 | 1.6 | 70.668 | 1.03536 | 0.025 | 2.4 | ug/L |
| > Tb | 159 | 411714.707 | 0.7 | 427712.876 | | | | ug/L |
| > Ho | 165 | 397195.435 | 1.1 | 412683.278 | | | | ug/L |
| Tl | 203 | 8131.046 | 0.6 | 51.667 | 1.05972 | 0.018 | 1.7 | ug/L |
| Tl | 205 | 19774.632 | 0.2 | 75.334 | 1.13079 | 0.015 | 1.3 | ug/L |
| Pb | 208 | 26592.130 | 0.9 | 440.342 | 1.07004 | 0.003 | 0.3 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Wednesday, November 22, 2006 10:27:39

Page 1

939

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 6833.869 | 0.6 | 119.335 | 1.05815 | 0.012 | 1.1 ug/L |
| | Pb | 207 | 5768.387 | 1.1 | 109.335 | 1.06182 | 0.003 | 0.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 106.024 | | | | |
| Al | 27 | 110.244 | | | | |
| > Sc | 45 | | 96.509 | | | |
| V | 51 | 110.126 | | | | |
| Cr | 52 | 110.326 | | | | |
| Cr | 53 | 105.084 | | | | |
| Mn | 55 | 110.646 | | | | |
| Co | 59 | 106.851 | | | | |
| Ni | 60 | 106.901 | | | | |
| Ni | 62 | 128.578 | | | | |
| Cu | 63 | 103.493 | | | | |
| Cu | 65 | 101.056 | | | | |
| Zn | 66 | 132.358 | | | | |
| Zn | 67 | 112.719 | | | | |
| Zn | 68 | 127.119 | | | | |
| > Ge | 72 | | 95.739 | | | |
| As | 75 | 100.663 | | | | |
| Se | 77 | 102.995 | | | | |
| Se | 78 | 160.751 | | | | |
| Se | 82 | -326.591 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 107.741 | | | | |
| Mo | 97 | 109.565 | | | | |
| Mo | 98 | 107.932 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 108.949 | | | | |
| Ag | 109 | 105.918 | | | | |
| Cd | 111 | 108.444 | | | | |
| Cd | 114 | 106.105 | | | | |
| > In | 115 | | 97.400 | | | |
| Sb | 121 | 109.890 | | | | |
| Sb | 123 | 109.393 | | | | |
| Ba | 135 | 104.562 | | | | |
| Ba | 137 | 103.536 | | | | |
| > Tb | 159 | | 96.260 | | | |
| > Ho | 165 | | 96.247 | | | |
| Tl | 203 | 105.972 | | | | |
| Tl | 205 | 113.079 | | | | |
| Pb | 208 | 107.004 | | | | |
| Pb | 206 | 105.815 | | | | |
| Pb | 207 | 106.182 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 4

Sample Date/Time: Wednesday, November 22, 2006 10:30:35

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 4.008

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| Be | 9 | 60.667 | 6.9 | 49.334 | 0.00916 | 0.004 | 43.1 | ug/L |
| Al | 27 | 199524941.009 | 1.2 | 2679.805 | 23018.84915 | 224.555 | 1.0 | ug/L |
| Sc | 45 | 390067.288 | 1.2 | 378193.541 | | | | ug/L |
| V | 51 | 4595.660 | 11.8 | 4537.327 | -0.00569 | 0.037 | 652.3 | ug/L |
| Cr | 52 | 25189.955 | 3.0 | 15100.490 | 0.74324 | 0.037 | 5.0 | ug/L |
| Cr | 53 | 6908.278 | 8.2 | 618.029 | 4.00614 | 0.342 | 8.5 | ug/L |
| Mn | 55 | 5426.154 | 2.7 | 580.693 | 0.25941 | 0.004 | 1.5 | ug/L |
| Co | 59 | 1095.750 | 4.3 | 202.004 | 0.05494 | 0.002 | 2.9 | ug/L |
| Ni | 60 | 2573.424 | 4.6 | 196.338 | 0.66212 | 0.032 | 4.8 | ug/L |
| Ni | 62 | 2762.819 | 2.6 | 499.020 | 4.02445 | 0.094 | 2.3 | ug/L |
| Cu | 63 | 9612.639 | 2.5 | 505.687 | 1.08621 | 0.027 | 2.5 | ug/L |
| Cu | 65 | 3778.562 | 4.3 | 212.672 | 0.87324 | 0.025 | 2.9 | ug/L |
| Zn | 66 | 4573.634 | 1.5 | 1298.448 | 1.34734 | 0.065 | 4.9 | ug/L |
| Zn | 67 | 2117.958 | 7.6 | 302.342 | 4.52657 | 0.322 | 7.1 | ug/L |
| Zn | 68 | 2253.327 | 2.7 | 996.736 | 0.69356 | 0.020 | 2.8 | ug/L |
| Ge | 72 | 212199.225 | 2.0 | 197196.226 | | | | ug/L |
| As | 75 | 1904.571 | 8.1 | 96.335 | 0.68741 | 0.048 | 6.9 | ug/L |
| Se | 77 | 826.708 | 8.3 | 202.002 | 3.13117 | 0.285 | 9.1 | ug/L |
| Se | 78 | 15790.235 | 3.9 | 14431.438 | 0.42235 | 0.783 | 185.5 | mg/L |
| Se | 82 | 662.026 | 9.9 | 1747.050 | -4.62436 | 0.292 | 6.3 | ug/L |
| Kr | 83 | 643.032 | 16.0 | 1793.211 | | | | mg/L |
| Y | 89 | 375786.210 | 0.5 | 365281.373 | | | | ug/L |
| Mo | 95 | 2617091.150 | 2.8 | 120.335 | 532.22525 | 12.766 | 2.4 | ug/L |
| Mo | 97 | 1337969.140 | 0.4 | 52.667 | 433.22495 | 14.635 | 3.4 | ug/L |
| Mo | 98 | 4123355.117 | 2.6 | 70.498 | 516.42681 | 10.094 | 2.0 | ug/L |
| Rh | 103 | 332711.838 | 3.1 | 350376.944 | | | | ug/L |
| Ag | 107 | 430.015 | 2.7 | 46.001 | 0.03088 | 0.002 | 5.9 | ug/L |
| Ag | 109 | 373.345 | 4.1 | 42.334 | 0.02779 | 0.002 | 7.0 | ug/L |
| Cd | 111 | 205.805 | 22.7 | 203.876 | 0.00331 | 0.017 | 510.5 | ug/L |
| Cd | 114 | 4251.032 | 2.5 | 55.152 | 0.62714 | 0.036 | 5.7 | ug/L |
| In | 115 | 353212.238 | 3.6 | 366049.872 | | | | ug/L |
| Sb | 121 | 3274.343 | 1.7 | 54.667 | 0.36362 | 0.017 | 4.7 | ug/L |
| Sb | 123 | 2426.185 | 2.6 | 37.221 | 0.36524 | 0.006 | 1.5 | ug/L |
| Ba | 135 | 129.336 | 10.3 | 52.001 | 0.03632 | 0.006 | 17.4 | ug/L |
| Ba | 137 | 189.337 | 5.4 | 70.668 | 0.03288 | 0.003 | 7.9 | ug/L |
| Tb | 159 | 404898.033 | 0.5 | 427712.876 | | | | ug/L |
| Ho | 165 | 382936.727 | 0.6 | 412683.278 | | | | ug/L |
| Tl | 203 | 2847.182 | 2.8 | 51.667 | 0.38071 | 0.011 | 3.0 | ug/L |
| Tl | 205 | 6770.820 | 3.6 | 75.334 | 0.39892 | 0.016 | 4.1 | ug/L |
| Pb | 208 | 1562.072 | 5.1 | 440.342 | 0.04893 | 0.004 | 7.6 | ug/L |

Sample ID: QC Std 4

Report Date/Time: Wednesday, November 22, 2006 10:33:35

Page 1

| | | | | | | | | |
|---|----|-----|---------|-----|---------|---------|-------|-----------|
| | Pb | 206 | 413.348 | 7.3 | 119.335 | 0.04945 | 0.005 | 10.7 ug/L |
| L | Pb | 207 | 348.344 | 1.4 | 109.335 | 0.04802 | 0.001 | 2.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | 115.094 | | | | |
| > Sc | 45 | | 103.140 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 107.608 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 133.056 | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 96.493 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 94.666 | | | |
| > Ho | 165 | | 92.792 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 5

Sample Date/Time: Wednesday, November 22, 2006 10:36:32

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 5.009

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|----------|-----------|-------|
| Be | 9 | 60.001 | 25.2 | 49.334 | 0.00517 | 0.013 | 249.4 | ug/L |
| Al | 27 | 197457681.682 | 2.8 | 2679.805 | 21468.83629 | 1194.371 | 5.6 | ug/L |
| > Sc | 45 | 414304.944 | 2.7 | 378193.541 | | | | ug/L |
| V | 51 | -3236.435 | 89.5 | 4537.327 | -0.52764 | 0.193 | 36.5 | ug/L |
| Cr | 52 | 299927.685 | 1.5 | 15100.490 | 20.63679 | 0.415 | 2.0 | ug/L |
| Cr | 53 | 40503.335 | 3.3 | 618.029 | 23.95861 | 0.217 | 0.9 | ug/L |
| Mn | 55 | 383095.620 | 1.7 | 580.693 | 19.71324 | 0.112 | 0.6 | ug/L |
| Co | 59 | 327028.994 | 2.4 | 202.004 | 19.50630 | 0.239 | 1.2 | ug/L |
| Ni | 60 | 72450.322 | 1.0 | 196.338 | 19.31656 | 0.389 | 2.0 | ug/L |
| Ni | 62 | 13053.347 | 1.3 | 499.020 | 21.54690 | 0.429 | 2.0 | ug/L |
| Cu | 63 | 162369.575 | 0.8 | 505.687 | 18.48736 | 0.094 | 0.5 | ug/L |
| Cu | 65 | 77080.008 | 1.7 | 212.672 | 18.04202 | 0.488 | 2.7 | ug/L |
| Zn | 66 | 46843.786 | 1.8 | 1298.448 | 18.35116 | 0.143 | 0.8 | ug/L |
| Zn | 67 | 8843.112 | 1.7 | 302.342 | 20.49875 | 0.492 | 2.4 | ug/L |
| Zn | 68 | 31523.166 | 1.4 | 996.736 | 17.03630 | 0.156 | 0.9 | ug/L |
| > Ge | 72 | 222425.433 | 1.2 | 197196.226 | | | | ug/L |
| As | 75 | 54794.790 | 1.3 | 96.335 | 19.92784 | 0.097 | 0.5 | ug/L |
| Se | 77 | 883.914 | 4.5 | 202.002 | 3.21837 | 0.152 | 4.7 | ug/L |
| Se | 78 | 16091.243 | 2.0 | 14431.438 | -0.28295 | 0.791 | 279.7 | mg/L |
| Se | 82 | 456.546 | 2.1 | 1747.050 | -5.48789 | 0.044 | 0.8 | ug/L |
| Kr | 83 | 486.019 | 3.9 | 1793.211 | | | | mg/L |
| Y | 89 | 390710.559 | 1.0 | 365281.373 | | | | ug/L |
| Mo | 95 | 2735097.663 | 1.6 | 120.335 | 531.76414 | 10.415 | 2.0 | ug/L |
| Mo | 97 | 1331989.802 | 2.0 | 52.667 | 412.15006 | 10.124 | 2.5 | ug/L |
| Mo | 98 | 4187801.975 | 2.5 | 70.498 | 501.42057 | 12.254 | 2.4 | ug/L |
| Rh | 103 | 338175.985 | 1.3 | 350376.944 | | | | ug/L |
| Ag | 107 | 269289.928 | 1.3 | 46.001 | 20.59412 | 0.225 | 1.1 | ug/L |
| Ag | 109 | 255168.809 | 4.3 | 42.334 | 20.36276 | 0.814 | 4.0 | ug/L |
| Cd | 111 | 60383.298 | 1.5 | 203.876 | 19.76988 | 0.399 | 2.0 | ug/L |
| Cd | 114 | 135311.394 | 1.4 | 55.152 | 19.29838 | 0.239 | 1.2 | ug/L |
| > In | 115 | 369348.607 | 0.5 | 366049.872 | | | | ug/L |
| Sb | 121 | 3081.267 | 0.6 | 54.667 | 0.32630 | 0.002 | 0.5 | ug/L |
| Sb | 123 | 2383.317 | 1.7 | 37.221 | 0.34267 | 0.005 | 1.3 | ug/L |
| Ba | 135 | 126.336 | 9.5 | 52.001 | 0.03505 | 0.006 | 16.4 | ug/L |
| Ba | 137 | 186.004 | 4.3 | 70.668 | 0.03208 | 0.002 | 7.6 | ug/L |
| > Tb | 159 | 404276.959 | 0.6 | 427712.876 | | | | ug/L |
| > Ho | 165 | 386831.109 | 1.4 | 412683.278 | | | | ug/L |
| Tl | 203 | 2752.816 | 4.7 | 51.667 | 0.36429 | 0.023 | 6.2 | ug/L |
| Tl | 205 | 6611.025 | 5.0 | 75.334 | 0.38562 | 0.025 | 6.4 | ug/L |
| Pb | 208 | 1370.057 | 2.3 | 440.342 | 0.04021 | 0.002 | 5.2 | ug/L |

Sample ID: QC Std 5

Report Date/Time: Wednesday, November 22, 2006 10:39:33

Page 1

945

| | | | | | | | | |
|---|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 387.346 | 5.0 | 119.335 | 0.04456 | 0.004 | 8.0 ug/L |
| L | Pb | 207 | 285.008 | 0.6 | 109.335 | 0.03514 | 0.001 | 1.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | 107.344 | | | | |
| > Sc | 45 | | 109.548 | | | |
| V | 51 | | | | | |
| Cr | 52 | 103.184 | | | | |
| Cr | 53 | 119.793 | | | | |
| Mn | 55 | 98.566 | | | | |
| Co | 59 | 97.531 | | | | |
| Ni | 60 | 96.583 | | | | |
| Ni | 62 | 107.735 | | | | |
| Cu | 63 | 92.437 | | | | |
| Cu | 65 | 90.210 | | | | |
| Zn | 66 | 91.756 | | | | |
| Zn | 67 | 102.494 | | | | |
| Zn | 68 | 85.182 | | | | |
| > Ge | 72 | | 112.794 | | | |
| As | 75 | 99.639 | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 132.941 | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 102.971 | | | | |
| Ag | 109 | 101.814 | | | | |
| Cd | 111 | 98.849 | | | | |
| Cd | 114 | 96.492 | | | | |
| > In | 115 | | 100.901 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 94.521 | | | |
| > Ho | 165 | | 93.736 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Wednesday, November 22, 2006 10:42:30

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 6.010

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 52235.464 | 2.6 | 49.334 | 47.25540 | 0.367 | 0.8 | ug/L |
| Al | 27 | 439042.691 | 1.0 | 2679.805 | 48.72920 | 1.425 | 2.9 | ug/L |
| > Sc | 45 | 402962.522 | 1.9 | 378193.541 | | | | ug/L |
| V | 51 | 792097.773 | 2.5 | 4537.327 | 51.76753 | 0.807 | 1.6 | ug/L |
| Cr | 52 | 678308.182 | 0.3 | 15100.490 | 49.57885 | 1.013 | 2.0 | ug/L |
| Cr | 53 | 82513.741 | 1.8 | 618.029 | 50.64351 | 1.231 | 2.4 | ug/L |
| Mn | 55 | 950082.838 | 1.4 | 580.693 | 52.90666 | 1.712 | 3.2 | ug/L |
| Co | 59 | 795184.456 | 1.8 | 202.004 | 51.27880 | 0.366 | 0.7 | ug/L |
| Ni | 60 | 175809.023 | 2.6 | 196.338 | 50.73294 | 0.354 | 0.7 | ug/L |
| Ni | 62 | 27074.201 | 2.7 | 499.020 | 49.49694 | 1.451 | 2.9 | ug/L |
| Cu | 63 | 417739.902 | 0.8 | 505.687 | 51.51524 | 0.572 | 1.1 | ug/L |
| Cu | 65 | 202984.352 | 2.8 | 212.672 | 51.46345 | 2.430 | 4.7 | ug/L |
| Zn | 66 | 113690.207 | 1.6 | 1298.448 | 49.09440 | 0.888 | 1.8 | ug/L |
| Zn | 67 | 19380.706 | 1.2 | 302.342 | 49.66656 | 0.408 | 0.8 | ug/L |
| Zn | 68 | 82254.879 | 2.0 | 996.736 | 49.18538 | 0.982 | 2.0 | ug/L |
| > Ge | 72 | 205849.394 | 1.9 | 197196.226 | | | | ug/L |
| As | 75 | 126553.787 | 2.8 | 96.335 | 49.78515 | 0.432 | 0.9 | ug/L |
| Se | 77 | 9882.523 | 0.5 | 202.002 | 51.29125 | 0.778 | 1.5 | ug/L |
| Se | 78 | 46215.355 | 0.4 | 14431.438 | 52.22305 | 1.796 | 3.4 | mg/L |
| Se | 82 | 13565.700 | 0.6 | 1747.050 | 46.00161 | 0.907 | 2.0 | ug/L |
| Kr | 83 | 426.015 | 2.7 | 1793.211 | | | | mg/L |
| Y | 89 | 389256.961 | 1.7 | 365281.373 | | | | ug/L |
| Mo | 95 | 277918.503 | 2.9 | 120.335 | 53.37970 | 0.479 | 0.9 | ug/L |
| Mo | 97 | 172421.384 | 1.3 | 52.667 | 52.72540 | 0.840 | 1.6 | ug/L |
| Mo | 98 | 451650.316 | 2.0 | 70.498 | 53.45278 | 1.049 | 2.0 | ug/L |
| Rh | 103 | 335992.710 | 1.4 | 350376.944 | | | | ug/L |
| Ag | 107 | 676069.079 | 3.1 | 46.001 | 51.10786 | 0.904 | 1.8 | ug/L |
| Ag | 109 | 643362.521 | 3.6 | 42.334 | 50.75623 | 1.491 | 2.9 | ug/L |
| Cd | 111 | 150686.673 | 2.4 | 203.876 | 48.86690 | 1.052 | 2.2 | ug/L |
| Cd | 114 | 350598.205 | 0.7 | 55.152 | 49.45642 | 1.345 | 2.7 | ug/L |
| > In | 115 | 373674.648 | 2.2 | 366049.872 | | | | ug/L |
| Sb | 121 | 458531.621 | 2.2 | 54.667 | 48.88452 | 1.753 | 3.6 | ug/L |
| Sb | 123 | 335680.097 | 2.8 | 37.221 | 48.47043 | 1.243 | 2.6 | ug/L |
| Ba | 135 | 115231.890 | 3.1 | 52.001 | 53.06349 | 1.143 | 2.2 | ug/L |
| Ba | 137 | 192356.622 | 1.5 | 70.668 | 52.51419 | 0.341 | 0.6 | ug/L |
| > Tb | 159 | 398218.267 | 1.5 | 427712.876 | | | | ug/L |
| > Ho | 165 | 389816.161 | 1.3 | 412683.278 | | | | ug/L |
| Tl | 203 | 370846.965 | 2.1 | 51.667 | 49.54620 | 1.374 | 2.8 | ug/L |
| Tl | 205 | 880485.604 | 0.7 | 75.334 | 51.49074 | 0.967 | 1.9 | ug/L |
| Pb | 208 | 1198294.958 | 0.5 | 440.342 | 49.91613 | 0.890 | 1.8 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Wednesday, November 22, 2006 10:45:32

Page 1

| | | | | | | | | |
|---|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 313603.564 | 1.6 | 119.335 | 50.30346 | 0.691 | 1.4 ug/L |
| L | Pb | 207 | 255999.856 | 1.1 | 109.335 | 48.89472 | 0.956 | 2.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | 94.511 | | | | |
| [Al | 27 | 97.458 | | | | |
| > [Sc | 45 | | 106.549 | | | |
| [V | 51 | 103.535 | | | | |
| [Cr | 52 | 99.158 | | | | |
| [Cr | 53 | 101.287 | | | | |
| [Mn | 55 | 105.813 | | | | |
| [Co | 59 | 102.558 | | | | |
| [Ni | 60 | 101.466 | | | | |
| [Ni | 62 | 98.994 | | | | |
| [Cu | 63 | 103.030 | | | | |
| [Cu | 65 | 102.927 | | | | |
| [Zn | 66 | 98.189 | | | | |
| [Zn | 67 | 99.333 | | | | |
| [Zn | 68 | 98.371 | | | | |
| > [Ge | 72 | | 104.388 | | | |
| [As | 75 | 99.570 | | | | |
| [Se | 77 | 102.583 | | | | |
| [Se | 78 | 104.446 | | | | |
| [Se | 82 | 92.003 | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | 106.759 | | | | |
| [Mo | 97 | 105.451 | | | | |
| [Mo | 98 | 106.906 | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | 102.216 | | | | |
| [Ag | 109 | 101.512 | | | | |
| [Cd | 111 | 97.734 | | | | |
| [Cd | 114 | 98.913 | | | | |
| > [In | 115 | | 102.083 | | | |
| [Sb | 121 | 97.769 | | | | |
| [Sb | 123 | 96.941 | | | | |
| [Ba | 135 | 106.127 | | | | |
| [Ba | 137 | 105.028 | | | | |
| > [Tb | 159 | | 93.104 | | | |
| > [Ho | 165 | | 94.459 | | | |
| [Tl | 203 | 99.092 | | | | |
| [Tl | 205 | 102.981 | | | | |
| [Pb | 208 | 99.832 | | | | |
| [Pb | 206 | 100.607 | | | | |
| [Pb | 207 | 97.789 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Wednesday, November 22, 2006 10:48:28

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 7.011

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 48.001 | 11.6 | 49.334 | -0.00442 | 0.004 | 101.6 | ug/L |
| Al | 27 | 2645.113 | 1.9 | 2679.805 | -0.02505 | 0.009 | 37.9 | ug/L |
| > Sc | 45 | 405258.918 | 1.7 | 378193.541 | | | | ug/L |
| V | 51 | 4157.819 | 3.6 | 4537.327 | -0.04588 | 0.015 | 31.6 | ug/L |
| Cr | 52 | 14843.359 | 1.9 | 15100.490 | -0.09913 | 0.040 | 39.9 | ug/L |
| Cr | 53 | 1455.475 | 7.5 | 618.029 | 0.48731 | 0.052 | 10.7 | ug/L |
| Mn | 55 | 573.359 | 4.8 | 580.693 | -0.00280 | 0.002 | 55.2 | ug/L |
| Co | 59 | 236.672 | 1.9 | 202.004 | 0.00120 | 0.000 | 39.4 | ug/L |
| Ni | 60 | 152.670 | 5.3 | 196.338 | -0.01642 | 0.003 | 17.1 | ug/L |
| Ni | 62 | 699.703 | 2.4 | 499.020 | 0.29397 | 0.047 | 15.8 | ug/L |
| Cu | 63 | 620.029 | 0.4 | 505.687 | 0.00906 | 0.001 | 13.1 | ug/L |
| Cu | 65 | 167.670 | 9.7 | 212.672 | -0.01504 | 0.005 | 30.1 | ug/L |
| Zn | 66 | 1300.114 | 1.9 | 1298.448 | -0.04139 | 0.012 | 29.5 | ug/L |
| Zn | 67 | 336.010 | 4.9 | 302.342 | 0.02650 | 0.040 | 149.1 | ug/L |
| Zn | 68 | 941.729 | 1.9 | 996.736 | -0.07705 | 0.014 | 18.4 | ug/L |
| > Ge | 72 | 212306.152 | 1.3 | 197196.226 | | | | ug/L |
| As | 75 | 213.672 | 17.4 | 96.335 | 0.04186 | 0.013 | 31.1 | ug/L |
| Se | 77 | 253.804 | 1.7 | 202.002 | 0.18709 | 0.040 | 21.2 | ug/L |
| Se | 78 | 15608.107 | 0.2 | 14431.438 | 0.11771 | 0.291 | 246.9 | mg/L |
| Se | 82 | 454.546 | 0.4 | 1747.050 | -5.41668 | 0.018 | 0.3 | ug/L |
| Kr | 83 | 449.017 | 5.4 | 1793.211 | | | | mg/L |
| Y | 89 | 397332.991 | 1.3 | 365281.373 | | | | ug/L |
| Mo | 95 | 1075.749 | 20.0 | 120.335 | 0.18300 | 0.040 | 21.6 | ug/L |
| Mo | 97 | 649.032 | 12.5 | 52.667 | 0.18208 | 0.023 | 12.9 | ug/L |
| Mo | 98 | 1604.559 | 17.7 | 70.498 | 0.18134 | 0.032 | 17.8 | ug/L |
| Rh | 103 | 348834.904 | 0.9 | 350376.944 | | | | ug/L |
| Ag | 107 | 137.669 | 10.3 | 46.001 | 0.00686 | 0.001 | 13.5 | ug/L |
| Ag | 109 | 114.335 | 15.9 | 42.334 | 0.00560 | 0.001 | 23.2 | ug/L |
| Cd | 111 | 197.300 | 4.1 | 203.876 | -0.00345 | 0.003 | 84.9 | ug/L |
| Cd | 114 | 60.432 | 21.5 | 55.152 | 0.00057 | 0.002 | 297.6 | ug/L |
| > In | 115 | 373410.027 | 1.6 | 366049.872 | | | | ug/L |
| Sb | 121 | 1047.745 | 18.5 | 54.667 | 0.10575 | 0.020 | 19.2 | ug/L |
| Sb | 123 | 743.481 | 20.5 | 37.221 | 0.10181 | 0.021 | 20.8 | ug/L |
| Ba | 135 | 46.001 | 15.2 | 52.001 | -0.00172 | 0.003 | 185.4 | ug/L |
| Ba | 137 | 59.667 | 15.6 | 70.668 | -0.00215 | 0.002 | 111.1 | ug/L |
| > Tb | 159 | 410122.851 | 0.5 | 427712.876 | | | | ug/L |
| > Ho | 165 | 396333.844 | 0.8 | 412683.278 | | | | ug/L |
| Tl | 203 | 210.005 | 16.9 | 51.667 | 0.02108 | 0.005 | 22.5 | ug/L |
| Tl | 205 | 480.686 | 15.4 | 75.334 | 0.02350 | 0.004 | 18.7 | ug/L |
| Pb | 208 | 317.672 | 5.9 | 440.342 | -0.00431 | 0.001 | 19.2 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Wednesday, November 22, 2006 10:51:28

Page 1

951

| | | | | | | | | |
|--|----|-----|--------|------|---------|----------|-------|-----------|
| | Pb | 206 | 84.335 | 9.0 | 119.335 | -0.00478 | 0.001 | 25.8 ug/L |
| | Pb | 207 | 82.335 | 17.2 | 109.335 | -0.00427 | 0.003 | 60.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 107.156 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 107.662 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 102.011 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 95.887 | | | |
| > [Ho | 165 | | 96.038 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 8

Sample Date/Time: Wednesday, November 22, 2006 10:54:25

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 8.012

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 106425.737 | 1.3 | 49.334 | 102.26469 | 2.830 | 2.8 | ug/L |
| Al | 27 | 863869.763 | 2.3 | 2679.805 | 102.05638 | 1.556 | 1.5 | ug/L |
| > Sc | 45 | 379722.589 | 1.5 | 378193.541 | | | | ug/L |
| V | 51 | 1494297.421 | 2.4 | 4537.327 | 103.96020 | 2.157 | 2.1 | ug/L |
| Cr | 52 | 1306524.292 | 2.7 | 15100.490 | 102.56037 | 1.376 | 1.3 | ug/L |
| Cr | 53 | 158280.847 | 3.1 | 618.029 | 103.48023 | 1.978 | 1.9 | ug/L |
| Mn | 55 | 1752852.262 | 1.6 | 580.693 | 102.10738 | 0.419 | 0.4 | ug/L |
| Co | 59 | 1512079.702 | 0.8 | 202.004 | 102.04307 | 2.180 | 2.1 | ug/L |
| Ni | 60 | 348867.798 | 0.7 | 196.338 | 105.40629 | 1.422 | 1.3 | ug/L |
| Ni | 62 | 52702.395 | 2.6 | 499.020 | 101.77672 | 0.718 | 0.7 | ug/L |
| Cu | 63 | 795062.763 | 1.6 | 505.687 | 102.65301 | 3.033 | 3.0 | ug/L |
| Cu | 65 | 395595.874 | 2.4 | 212.672 | 104.91341 | 0.504 | 0.5 | ug/L |
| Zn | 66 | 222039.285 | 2.2 | 1298.448 | 100.91857 | 1.904 | 1.9 | ug/L |
| Zn | 67 | 37703.146 | 0.9 | 302.342 | 101.95343 | 2.713 | 2.7 | ug/L |
| Zn | 68 | 163589.701 | 3.1 | 996.736 | 102.98649 | 1.254 | 1.2 | ug/L |
| > Ge | 72 | 196770.850 | 1.9 | 197196.226 | | | | ug/L |
| As | 75 | 254202.937 | 2.7 | 96.335 | 104.68859 | 3.161 | 3.0 | ug/L |
| Se | 77 | 18698.822 | 0.5 | 202.002 | 102.62451 | 1.823 | 1.8 | ug/L |
| Se | 78 | 76477.073 | 1.0 | 14431.438 | 108.84904 | 2.370 | 2.2 | mg/L |
| Se | 82 | 26177.119 | 0.8 | 1747.050 | 100.13338 | 1.369 | 1.4 | ug/L |
| Kr | 83 | 476.018 | 2.8 | 1793.211 | | | | mg/L |
| Y | 89 | 367481.489 | 1.3 | 365281.373 | | | | ug/L |
| Mo | 95 | 535453.837 | 0.4 | 120.335 | 107.51704 | 1.995 | 1.9 | ug/L |
| Mo | 97 | 340930.500 | 2.3 | 52.667 | 108.92576 | 0.937 | 0.9 | ug/L |
| Mo | 98 | 824255.800 | 1.2 | 70.498 | 101.93478 | 1.573 | 1.5 | ug/L |
| Rh | 103 | 335088.700 | 3.6 | 350376.944 | | | | ug/L |
| Ag | 107 | 1309470.693 | 2.0 | 46.001 | 103.44351 | 1.187 | 1.1 | ug/L |
| Ag | 109 | 1223859.569 | 2.2 | 42.334 | 100.88527 | 0.721 | 0.7 | ug/L |
| Cd | 111 | 304721.387 | 2.3 | 203.876 | 103.35956 | 3.941 | 3.8 | ug/L |
| Cd | 114 | 666638.955 | 1.2 | 55.152 | 98.23888 | 1.138 | 1.2 | ug/L |
| > In | 115 | 357640.334 | 2.2 | 366049.872 | | | | ug/L |
| Sb | 121 | 885316.961 | 1.3 | 54.667 | 98.59500 | 1.124 | 1.1 | ug/L |
| Sb | 123 | 674992.378 | 1.2 | 37.221 | 101.85757 | 2.284 | 2.2 | ug/L |
| Ba | 135 | 216161.880 | 1.5 | 52.001 | 98.79638 | 1.391 | 1.4 | ug/L |
| Ba | 137 | 375167.526 | 1.2 | 70.668 | 101.64850 | 1.784 | 1.8 | ug/L |
| > Tb | 159 | 401359.979 | 1.5 | 427712.876 | | | | ug/L |
| > Ho | 165 | 383376.723 | 2.3 | 412683.278 | | | | ug/L |
| Tl | 203 | 738559.049 | 0.5 | 51.667 | 100.34781 | 1.756 | 1.8 | ug/L |
| Tl | 205 | 1635062.346 | 2.0 | 75.334 | 97.21779 | 0.506 | 0.5 | ug/L |
| Pb | 208 | 2307453.978 | 1.3 | 440.342 | 97.74996 | 0.967 | 1.0 | ug/L |

Sample ID: QC Std 8

Report Date/Time: Wednesday, November 22, 2006 10:57:27

Page 1

954

| | | | | | | | | |
|--|----|-----|------------|-----|---------|-----------|-------|----------|
| | Pb | 206 | 604871.126 | 1.0 | 119.335 | 98.68892 | 1.417 | 1.4 ug/L |
| | Pb | 207 | 516314.778 | 0.9 | 109.335 | 100.29741 | 1.367 | 1.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 102.265 | | | | |
| Al | 27 | 102.056 | | | | |
| > Sc | 45 | | 100.404 | | | |
| V | 51 | 103.960 | | | | |
| Cr | 52 | 102.560 | | | | |
| Cr | 53 | 103.480 | | | | |
| Mn | 55 | 102.107 | | | | |
| Co | 59 | 102.043 | | | | |
| Ni | 60 | 105.406 | | | | |
| Ni | 62 | 101.777 | | | | |
| Cu | 63 | 102.653 | | | | |
| Cu | 65 | 104.913 | | | | |
| Zn | 66 | 100.919 | | | | |
| Zn | 67 | 101.953 | | | | |
| Zn | 68 | 102.986 | | | | |
| > Ge | 72 | | 99.784 | | | |
| As | 75 | 104.689 | | | | |
| Se | 77 | 102.625 | | | | |
| Se | 78 | | | | | |
| Se | 82 | 100.133 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 107.517 | | | | |
| Mo | 97 | 108.926 | | | | |
| Mo | 98 | 101.935 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 103.444 | | | | |
| Ag | 109 | 100.885 | | | | |
| Cd | 111 | 103.360 | | | | |
| Cd | 114 | 98.239 | | | | |
| > In | 115 | | 97.703 | | | |
| Sb | 121 | 98.595 | | | | |
| Sb | 123 | 101.858 | | | | |
| Ba | 135 | 98.796 | | | | |
| Ba | 137 | 101.648 | | | | |
| > Tb | 159 | | 93.839 | | | |
| > Ho | 165 | | 92.899 | | | |
| Tl | 203 | 100.348 | | | | |
| Tl | 205 | 97.218 | | | | |
| Pb | 208 | 97.750 | | | | |
| Pb | 206 | 98.689 | | | | |
| Pb | 207 | 100.297 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: PBW-M3990146

Sample Date/Time: Wednesday, November 22, 2006 11:00:23

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\PBW-M3990146.013

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 48.334 | 11.8 | 49.334 | -0.00143 | 0.006 | 403.0 | ug/L |
| Al | 27 | 957742.266 | 1.6 | 2679.805 | 112.42740 | 2.750 | 2.4 | ug/L |
| > Sc | 45 | 382356.092 | 1.9 | 378193.541 | | | | ug/L |
| V | 51 | 5192.642 | 5.0 | 4537.327 | 0.04227 | 0.025 | 58.8 | ug/L |
| Cr | 52 | 18056.406 | 3.7 | 15100.490 | 0.22105 | 0.080 | 36.1 | ug/L |
| Cr | 53 | 1233.770 | 4.1 | 618.029 | 0.39676 | 0.018 | 4.5 | ug/L |
| Mn | 55 | 1212.434 | 2.8 | 580.693 | 0.03584 | 0.001 | 3.1 | ug/L |
| Co | 59 | 373.345 | 6.4 | 202.004 | 0.01122 | 0.001 | 12.4 | ug/L |
| Ni | 60 | 294.675 | 4.1 | 196.338 | 0.02856 | 0.004 | 13.0 | ug/L |
| Ni | 62 | 754.375 | 4.7 | 499.020 | 0.47815 | 0.053 | 11.0 | ug/L |
| Cu | 63 | 840.717 | 1.9 | 505.687 | 0.04186 | 0.003 | 8.1 | ug/L |
| Cu | 65 | 287.008 | 2.9 | 212.672 | 0.01873 | 0.001 | 7.7 | ug/L |
| Zn | 66 | 1876.563 | 1.5 | 1298.448 | 0.25305 | 0.009 | 3.6 | ug/L |
| Zn | 67 | 412.348 | 8.0 | 302.342 | 0.28550 | 0.094 | 32.9 | ug/L |
| Zn | 68 | 1380.128 | 4.4 | 996.736 | 0.23191 | 0.049 | 21.2 | ug/L |
| > Ge | 72 | 199688.805 | 1.4 | 197196.226 | | | | ug/L |
| As | 75 | 181.337 | 10.4 | 96.335 | 0.03397 | 0.007 | 20.5 | ug/L |
| Se | 77 | 241.137 | 4.1 | 202.002 | 0.19984 | 0.047 | 23.7 | ug/L |
| Se | 78 | 15750.944 | 1.2 | 14431.438 | 1.97037 | 0.678 | 34.4 | mg/L |
| Se | 82 | 466.213 | 5.5 | 1747.050 | -5.26111 | 0.086 | 1.6 | ug/L |
| Kr | 83 | 452.350 | 7.0 | 1793.211 | | | | mg/L |
| Y | 89 | 383625.354 | 1.2 | 365281.373 | | | | ug/L |
| Mo | 95 | 1698.869 | 32.7 | 120.335 | 0.31460 | 0.109 | 34.7 | ug/L |
| Mo | 97 | 1054.749 | 32.9 | 52.667 | 0.31773 | 0.109 | 34.3 | ug/L |
| Mo | 98 | 2665.032 | 39.6 | 70.498 | 0.31817 | 0.128 | 40.3 | ug/L |
| Rh | 103 | 341273.056 | 2.1 | 350376.944 | | | | ug/L |
| Ag | 107 | 170.003 | 5.4 | 46.001 | 0.00977 | 0.001 | 7.3 | ug/L |
| Ag | 109 | 147.336 | 13.8 | 42.334 | 0.00864 | 0.002 | 19.7 | ug/L |
| Cd | 111 | 213.219 | 8.0 | 203.876 | 0.00419 | 0.006 | 133.4 | ug/L |
| Cd | 114 | 63.888 | 71.7 | 55.152 | 0.00139 | 0.007 | 480.4 | ug/L |
| > In | 115 | 360459.450 | 0.3 | 366049.872 | | | | ug/L |
| Sb | 121 | 1511.155 | 18.0 | 54.667 | 0.16096 | 0.029 | 18.3 | ug/L |
| Sb | 123 | 1095.561 | 23.0 | 37.221 | 0.15843 | 0.037 | 23.5 | ug/L |
| Ba | 135 | 85.668 | 21.3 | 52.001 | 0.01595 | 0.008 | 52.2 | ug/L |
| Ba | 137 | 125.002 | 12.5 | 70.668 | 0.01511 | 0.004 | 28.7 | ug/L |
| > Tb | 159 | 411168.588 | 0.6 | 427712.876 | | | | ug/L |
| > Ho | 165 | 384336.230 | 1.1 | 412683.278 | | | | ug/L |
| Tl | 203 | 88.335 | 13.6 | 51.667 | 0.00546 | 0.002 | 31.6 | ug/L |
| Tl | 205 | 140.336 | 5.1 | 75.334 | 0.00416 | 0.000 | 7.8 | ug/L |
| Pb | 208 | 613.348 | 5.1 | 440.342 | 0.00859 | 0.001 | 16.2 | ug/L |

Sample ID: PBW-M3990146

Report Date/Time: Wednesday, November 22, 2006 11:03:24

Page 1

957

| | | | | | | | | |
|--|----|-----|---------|------|---------|---------|-------|-----------|
| | Pb | 206 | 162.670 | 4.4 | 119.335 | 0.00839 | 0.001 | 14.5 ug/L |
| | Pb | 207 | 136.336 | 10.7 | 109.335 | 0.00669 | 0.003 | 43.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 101.101 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 101.264 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 98.473 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 96.132 | | | |
| > [Ho | 165 | | 93.131 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: LCSW-M3990146

Sample Date/Time: Wednesday, November 22, 2006 11:06:20

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\LCSW-M3990146.014

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 20648.759 | 1.1 | 49.334 | 17.60836 | 0.602 | 3.4 | ug/L |
| Al | 27 | 207864.175 | 1.3 | 2679.805 | 21.60126 | 0.906 | 4.2 | ug/L |
| > Sc | 45 | 427087.662 | 3.1 | 378193.541 | | | | ug/L |
| V | 51 | 351489.467 | 0.6 | 4537.327 | 21.50557 | 0.787 | 3.7 | ug/L |
| Cr | 52 | 318415.288 | 2.4 | 15100.490 | 21.29940 | 0.990 | 4.6 | ug/L |
| Cr | 53 | 38060.435 | 0.9 | 618.029 | 21.81563 | 0.484 | 2.2 | ug/L |
| Mn | 55 | 416311.532 | 2.1 | 580.693 | 21.74614 | 0.655 | 3.0 | ug/L |
| Co | 59 | 361640.776 | 2.1 | 202.004 | 21.89036 | 0.214 | 1.0 | ug/L |
| Ni | 60 | 77862.526 | 0.9 | 196.338 | 21.06941 | 0.354 | 1.7 | ug/L |
| Ni | 62 | 12132.949 | 1.6 | 499.020 | 20.26440 | 0.169 | 0.8 | ug/L |
| Cu | 63 | 184238.152 | 2.2 | 505.687 | 21.29496 | 0.404 | 1.9 | ug/L |
| Cu | 65 | 87476.957 | 0.8 | 212.672 | 20.78332 | 0.303 | 1.5 | ug/L |
| Zn | 66 | 44386.016 | 1.3 | 1298.448 | 17.62208 | 0.154 | 0.9 | ug/L |
| Zn | 67 | 7939.529 | 2.9 | 302.342 | 18.59743 | 0.394 | 2.1 | ug/L |
| Zn | 68 | 32048.509 | 1.9 | 996.736 | 17.59888 | 0.540 | 3.1 | ug/L |
| > Ge | 72 | 219200.576 | 1.1 | 197196.226 | | | | ug/L |
| As | 75 | 49057.799 | 0.2 | 96.335 | 18.10203 | 0.239 | 1.3 | ug/L |
| Se | 77 | 3524.278 | 0.6 | 202.002 | 16.43101 | 0.095 | 0.6 | ug/L |
| Se | 78 | 27432.637 | 2.5 | 14431.438 | 17.92092 | 0.604 | 3.4 | mg/L |
| Se | 82 | 5098.893 | 1.0 | 1747.050 | 11.61246 | 0.182 | 1.6 | ug/L |
| Kr | 83 | 474.352 | 1.8 | 1793.211 | | | | mg/L |
| Y | 89 | 418229.724 | 2.6 | 365281.373 | | | | ug/L |
| Mo | 95 | 123998.044 | 2.7 | 120.335 | 23.01321 | 0.408 | 1.8 | ug/L |
| Mo | 97 | 76902.314 | 0.5 | 52.667 | 22.72996 | 0.660 | 2.9 | ug/L |
| Mo | 98 | 202250.822 | 1.4 | 70.498 | 23.14089 | 0.702 | 3.0 | ug/L |
| Rh | 103 | 361387.929 | 2.3 | 350376.944 | | | | ug/L |
| Ag | 107 | 301016.693 | 4.1 | 46.001 | 21.98964 | 0.304 | 1.4 | ug/L |
| Ag | 109 | 290355.202 | 1.7 | 42.334 | 22.14483 | 0.256 | 1.2 | ug/L |
| Cd | 111 | 64474.139 | 2.3 | 203.876 | 20.17317 | 0.410 | 2.0 | ug/L |
| Cd | 114 | 144539.099 | 2.6 | 55.152 | 19.69710 | 0.045 | 0.2 | ug/L |
| > In | 115 | 386572.405 | 2.8 | 366049.872 | | | | ug/L |
| Sb | 121 | 196087.910 | 0.8 | 54.667 | 20.20951 | 0.744 | 3.7 | ug/L |
| Sb | 123 | 144888.688 | 1.2 | 37.221 | 20.22622 | 0.513 | 2.5 | ug/L |
| Ba | 135 | 49571.171 | 1.0 | 52.001 | 21.71871 | 0.653 | 3.0 | ug/L |
| Ba | 137 | 84276.897 | 1.3 | 70.668 | 21.89199 | 0.728 | 3.3 | ug/L |
| > Tb | 159 | 418501.762 | 2.1 | 427712.876 | | | | ug/L |
| > Ho | 165 | 411248.539 | 1.1 | 412683.278 | | | | ug/L |
| Tl | 203 | 160560.019 | 0.9 | 51.667 | 20.32627 | 0.030 | 0.1 | ug/L |
| Tl | 205 | 378012.691 | 0.6 | 75.334 | 20.94958 | 0.223 | 1.1 | ug/L |
| Pb | 208 | 517543.004 | 1.2 | 440.342 | 20.42220 | 0.192 | 0.9 | ug/L |

Sample ID: LCSW-M3990146

Report Date/Time: Wednesday, November 22, 2006 11:09:21

Page 1

960

| | | | | | | | | |
|---|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 132891.350 | 2.6 | 119.335 | 20.19269 | 0.401 | 2.0 ug/L |
| L | Pb | 207 | 109371.600 | 1.7 | 109.335 | 19.78541 | 0.135 | 0.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 112.928 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 111.159 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 105.606 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 97.846 | | | |
| > [Ho | 165 | | 99.652 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030

Sample Date/Time: Wednesday, November 22, 2006 11:12:18

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950030.015

rpt. MS 7/20/06

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 75.668 | 3.1 | 49.334 | 0.00616 | 0.001 | 11.4 | ug/L |
| Al | 27 | 1756925.626 | 10.4 | 2679.805 | 153.46935 | 13.079 | 8.5 | ug/L |
| > Sc | 45 | 513615.422 | 2.5 | 378193.541 | | | | ug/L |
| V | 51 | 12481.211 | 16.2 | 4537.327 | 0.32797 | 0.120 | 36.6 | ug/L |
| Cr | 52 | 149681.011 | 3.8 | 15100.490 | 7.58967 | 0.416 | 5.5 | ug/L |
| Cr | 53 | 16423.001 | 1.6 | 618.029 | 7.56438 | 0.123 | 1.6 | ug/L |
| Mn | 55 | 323899.876 | 0.3 | 580.693 | 15.94752 | 0.251 | 1.6 | ug/L |
| Co | 59 | 9036.654 | 0.7 | 202.004 | 0.50274 | 0.009 | 1.8 | ug/L |
| Ni | 60 | 28402.301 | 3.1 | 196.338 | 7.21095 | 0.288 | 4.0 | ug/L |
| Ni | 62 | 4383.530 | 0.9 | 499.020 | 6.26612 | 0.113 | 1.8 | ug/L |
| Cu | 63 | 8810.744 | 1.6 | 505.687 | 0.89832 | 0.016 | 1.8 | ug/L |
| Cu | 65 | 4070.037 | 5.8 | 212.672 | 0.85829 | 0.057 | 6.6 | ug/L |
| Zn | 66 | 7648.919 | 1.4 | 1298.448 | 2.36815 | 0.022 | 0.9 | ug/L |
| Zn | 67 | 1450.808 | 7.1 | 302.342 | 2.52707 | 0.274 | 10.8 | ug/L |
| Zn | 68 | 7285.592 | 3.7 | 996.736 | 3.27896 | 0.188 | 5.7 | ug/L |
| > Ge | 72 | 232415.227 | 1.6 | 197196.226 | | | | ug/L |
| As | 75 | 732.706 | 4.2 | 96.335 | 0.21602 | 0.013 | 6.0 | ug/L |
| Se | 77 | 350.674 | 4.3 | 202.002 | 0.52863 | 0.062 | 11.8 | ug/L |
| Se | 78 | 18044.872 | 2.2 | 14431.438 | 1.54524 | 0.883 | 57.2 | mg/L |
| Se | 82 | 581.354 | 4.7 | 1747.050 | -5.12598 | 0.100 | 2.0 | ug/L |
| Kr | 83 | 455.017 | 2.0 | 1793.211 | | | | mg/L |
| Y | 89 | 465568.099 | 1.2 | 365281.373 | | | | ug/L |
| Mo | 95 | 1415.468 | 2.6 | 120.335 | 0.23161 | 0.012 | 5.1 | ug/L |
| Mo | 97 | 918.727 | 2.1 | 52.667 | 0.24704 | 0.004 | 1.7 | ug/L |
| Mo | 98 | 2219.482 | 3.1 | 70.498 | 0.23789 | 0.010 | 4.4 | ug/L |
| Rh | 103 | 379229.607 | 1.7 | 350376.944 | | | | ug/L |
| Ag | 107 | 126.002 | 5.2 | 46.001 | 0.00538 | 0.000 | 6.7 | ug/L |
| Ag | 109 | 98.668 | 5.8 | 42.334 | 0.00389 | 0.000 | 8.7 | ug/L |
| Cd | 111 | 290.486 | 7.3 | 203.876 | 0.02084 | 0.006 | 27.0 | ug/L |
| Cd | 114 | 180.266 | 28.3 | 55.152 | 0.01601 | 0.007 | 45.8 | ug/L |
| > In | 115 | 398521.501 | 2.3 | 366049.872 | | | | ug/L |
| Sb | 121 | 573.692 | 13.1 | 54.667 | 0.05146 | 0.008 | 15.8 | ug/L |
| Sb | 123 | 449.558 | 12.7 | 37.221 | 0.05544 | 0.008 | 14.7 | ug/L |
| Ba | 135 | 22700.771 | 0.5 | 52.001 | 9.58490 | 0.122 | 1.3 | ug/L |
| Ba | 137 | 38157.206 | 0.2 | 70.668 | 9.55372 | 0.089 | 0.9 | ug/L |
| > Tb | 159 | 433551.051 | 0.8 | 427712.876 | | | | ug/L |
| > Ho | 165 | 409641.075 | 2.3 | 412683.278 | | | | ug/L |
| Tl | 203 | 172.337 | 6.5 | 51.667 | 0.01541 | 0.002 | 11.0 | ug/L |
| Tl | 205 | 401.014 | 7.0 | 75.334 | 0.01814 | 0.001 | 7.0 | ug/L |
| Pb | 208 | 8918.297 | 1.2 | 440.342 | 0.33641 | 0.011 | 3.1 | ug/L |

Sample ID: 950030

Report Date/Time: Wednesday, November 22, 2006 11:15:19

Page 1

963

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 2267.998 | 2.5 | 119.335 | 0.32832 | 0.011 | 3.4 ug/L |
| | Pb | 207 | 1912.572 | 2.0 | 109.335 | 0.32820 | 0.015 | 4.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 135.808 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 117.860 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 108.871 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 101.365 | | | |
| > [Ho | 165 | | 99.263 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030D

Sample Date/Time: Wednesday, November 22, 2006 11:18:15

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950030D.016

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 77.001 | 11.9 | 49.334 | 0.00727 | 0.006 | 87.8 | ug/L |
| Al | 27 | 2109297.952 | 13.9 | 2679.805 | 185.43952 | 29.357 | 15.8 | ug/L |
| > Sc | 45 | 512142.668 | 3.6 | 378193.541 | | | | ug/L |
| V | 51 | 13065.603 | 6.9 | 4537.327 | 0.35904 | 0.060 | 16.6 | ug/L |
| Cr | 52 | 175853.172 | 1.7 | 15100.490 | 9.15905 | 0.330 | 3.6 | ug/L |
| Cr | 53 | 20165.581 | 2.4 | 618.029 | 9.41508 | 0.407 | 4.3 | ug/L |
| Mn | 55 | 336713.844 | 3.4 | 580.693 | 16.28224 | 0.535 | 3.3 | ug/L |
| Co | 59 | 9789.845 | 1.0 | 202.004 | 0.53578 | 0.006 | 1.2 | ug/L |
| Ni | 60 | 31564.806 | 6.3 | 196.338 | 7.87496 | 0.494 | 6.3 | ug/L |
| Ni | 62 | 4879.811 | 3.2 | 499.020 | 6.94145 | 0.244 | 3.5 | ug/L |
| Cu | 63 | 9385.377 | 1.3 | 505.687 | 0.94291 | 0.014 | 1.5 | ug/L |
| Cu | 65 | 4363.186 | 3.4 | 212.672 | 0.90656 | 0.032 | 3.5 | ug/L |
| Zn | 66 | 7947.201 | 0.5 | 1298.448 | 2.42898 | 0.012 | 0.5 | ug/L |
| Zn | 67 | 1509.485 | 4.1 | 302.342 | 2.59881 | 0.144 | 5.6 | ug/L |
| Zn | 68 | 7587.529 | 0.4 | 996.736 | 3.36726 | 0.011 | 0.3 | ug/L |
| > Ge | 72 | 236607.986 | 0.2 | 197196.226 | | | | ug/L |
| As | 75 | 796.713 | 2.6 | 96.335 | 0.23333 | 0.007 | 3.1 | ug/L |
| Se | 77 | 358.141 | 5.0 | 202.002 | 0.53396 | 0.080 | 15.1 | ug/L |
| Se | 78 | 18426.751 | 2.1 | 14431.438 | 1.62008 | 0.592 | 36.5 | mg/L |
| Se | 82 | 589.688 | 2.3 | 1747.050 | -5.13358 | 0.049 | 1.0 | ug/L |
| Kr | 83 | 453.684 | 4.7 | 1793.211 | | | | mg/L |
| Y | 89 | 477082.212 | 1.6 | 365281.373 | | | | ug/L |
| Mo | 95 | 1457.142 | 4.0 | 120.335 | 0.24164 | 0.011 | 4.6 | ug/L |
| Mo | 97 | 926.394 | 3.1 | 52.667 | 0.25189 | 0.007 | 2.9 | ug/L |
| Mo | 98 | 2297.098 | 3.5 | 70.498 | 0.24898 | 0.009 | 3.6 | ug/L |
| Rh | 103 | 375813.655 | 2.4 | 350376.944 | | | | ug/L |
| Ag | 107 | 106.668 | 8.4 | 46.001 | 0.00409 | 0.001 | 15.6 | ug/L |
| Ag | 109 | 81.335 | 14.2 | 42.334 | 0.00267 | 0.001 | 33.1 | ug/L |
| Cd | 111 | 294.265 | 10.9 | 203.876 | 0.02291 | 0.010 | 42.1 | ug/L |
| Cd | 114 | 285.672 | 36.0 | 55.152 | 0.03026 | 0.014 | 45.9 | ug/L |
| > In | 115 | 394512.198 | 0.4 | 366049.872 | | | | ug/L |
| Sb | 121 | 409.014 | 7.8 | 54.667 | 0.03535 | 0.003 | 9.6 | ug/L |
| Sb | 123 | 326.412 | 2.6 | 37.221 | 0.03916 | 0.001 | 3.4 | ug/L |
| Ba | 135 | 23335.865 | 1.3 | 52.001 | 10.09574 | 0.130 | 1.3 | ug/L |
| Ba | 137 | 39790.168 | 0.6 | 70.668 | 10.20819 | 0.060 | 0.6 | ug/L |
| > Tb | 159 | 423150.155 | 0.1 | 427712.876 | | | | ug/L |
| > Ho | 165 | 405326.439 | 1.4 | 412683.278 | | | | ug/L |
| Tl | 203 | 202.004 | 9.0 | 51.667 | 0.01942 | 0.002 | 10.7 | ug/L |
| Tl | 205 | 439.683 | 6.8 | 75.334 | 0.02055 | 0.001 | 6.7 | ug/L |
| Pb | 208 | 8724.870 | 0.9 | 440.342 | 0.33229 | 0.002 | 0.7 | ug/L |

Sample ID: 950030D

Report Date/Time: Wednesday, November 22, 2006 11:21:16

Page 1

966

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 2270.666 | 4.4 | 119.335 | 0.33225 | 0.012 | 3.6 ug/L |
| | Pb | 207 | 1861.560 | 0.8 | 109.335 | 0.32232 | 0.002 | 0.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 135.418 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 119.986 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 107.776 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.933 | | | |
| > [Ho | 165 | | 98.217 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030S

Sample Date/Time: Wednesday, November 22, 2006 11:24:12

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950030S.017

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 22814.083 | 1.0 | 49.334 | 15.98922 | 0.501 | 3.1 | ug/L |
| Al | 27 | 2771039.207 | 1.0 | 2679.805 | 239.81352 | 4.099 | 1.7 | ug/L |
| > Sc | 45 | 519404.522 | 2.1 | 378193.541 | | | | ug/L |
| V | 51 | 389604.799 | 3.4 | 4537.327 | 19.55626 | 0.434 | 2.2 | ug/L |
| Cr | 52 | 490864.798 | 2.6 | 15100.490 | 27.30001 | 0.474 | 1.7 | ug/L |
| Cr | 53 | 57105.573 | 0.9 | 618.029 | 27.00612 | 0.656 | 2.4 | ug/L |
| Mn | 55 | 777353.628 | 0.3 | 580.693 | 37.25798 | 0.437 | 1.2 | ug/L |
| Co | 59 | 381067.803 | 0.4 | 202.004 | 21.15663 | 0.293 | 1.4 | ug/L |
| Ni | 60 | 109081.099 | 1.2 | 196.338 | 27.08731 | 0.594 | 2.2 | ug/L |
| Ni | 62 | 16883.591 | 1.7 | 499.020 | 26.13598 | 0.830 | 3.2 | ug/L |
| Cu | 63 | 204554.289 | 1.7 | 505.687 | 21.68942 | 0.679 | 3.1 | ug/L |
| Cu | 65 | 96986.891 | 1.9 | 212.672 | 21.13135 | 0.381 | 1.8 | ug/L |
| Zn | 66 | 52423.947 | 2.0 | 1298.448 | 19.13839 | 0.481 | 2.5 | ug/L |
| Zn | 67 | 9285.597 | 0.7 | 302.342 | 20.00942 | 0.168 | 0.8 | ug/L |
| Zn | 68 | 40598.440 | 2.7 | 996.736 | 20.54091 | 0.428 | 2.1 | ug/L |
| > Ge | 72 | 239028.396 | 1.4 | 197196.226 | | | | ug/L |
| As | 75 | 56572.964 | 1.3 | 96.335 | 19.14838 | 0.497 | 2.6 | ug/L |
| Se | 77 | 4177.647 | 1.0 | 202.002 | 17.95945 | 0.202 | 1.1 | ug/L |
| Se | 78 | 30113.531 | 2.7 | 14431.438 | 18.22976 | 1.781 | 9.8 | mg/L |
| Se | 82 | 5701.150 | 0.9 | 1747.050 | 12.09142 | 0.433 | 3.6 | ug/L |
| Kr | 83 | 333.010 | 4.1 | 1793.211 | | | | mg/L |
| Y | 89 | 489358.465 | 2.0 | 365281.373 | | | | ug/L |
| Mo | 95 | 135729.781 | 0.4 | 120.335 | 24.19657 | 0.545 | 2.3 | ug/L |
| Mo | 97 | 84221.108 | 2.3 | 52.667 | 23.91054 | 1.136 | 4.8 | ug/L |
| Mo | 98 | 222491.113 | 1.4 | 70.498 | 24.43981 | 0.475 | 1.9 | ug/L |
| Rh | 103 | 377551.911 | 0.7 | 350376.944 | | | | ug/L |
| Ag | 107 | 300018.865 | 1.5 | 46.001 | 21.05642 | 0.401 | 1.9 | ug/L |
| Ag | 109 | 288959.291 | 2.0 | 42.334 | 21.16084 | 0.285 | 1.3 | ug/L |
| Cd | 111 | 65408.682 | 2.0 | 203.876 | 19.65832 | 0.793 | 4.0 | ug/L |
| Cd | 114 | 147655.962 | 1.3 | 55.152 | 19.32902 | 0.527 | 2.7 | ug/L |
| > In | 115 | 402560.417 | 2.4 | 366049.872 | | | | ug/L |
| Sb | 121 | 197261.717 | 0.3 | 54.667 | 19.51685 | 0.474 | 2.4 | ug/L |
| Sb | 123 | 146165.047 | 1.8 | 37.221 | 19.58914 | 0.340 | 1.7 | ug/L |
| Ba | 135 | 74127.994 | 0.9 | 52.001 | 32.12390 | 0.131 | 0.4 | ug/L |
| Ba | 137 | 124025.015 | 0.2 | 70.668 | 31.86328 | 0.203 | 0.6 | ug/L |
| > Tb | 159 | 423073.670 | 0.6 | 427712.876 | | | | ug/L |
| > Ho | 165 | 413737.762 | 0.4 | 412683.278 | | | | ug/L |
| Tl | 203 | 161912.458 | 0.7 | 51.667 | 20.37392 | 0.100 | 0.5 | ug/L |
| Tl | 205 | 384971.247 | 1.6 | 75.334 | 21.20500 | 0.263 | 1.2 | ug/L |
| Pb | 208 | 527103.753 | 1.2 | 440.342 | 20.67506 | 0.335 | 1.6 | ug/L |

Sample ID: 950030S

Report Date/Time: Wednesday, November 22, 2006 11:27:14

Page 1

969

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 136510.344 | 2.0 | 119.335 | 20.62079 | 0.501 | 2.4 ug/L |
| | Pb | 207 | 110442.514 | 1.0 | 109.335 | 19.86002 | 0.214 | 1.1 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 137.338 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 121.213 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 109.974 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.915 | | | |
| > [Ho | 165 | | 100.256 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030A

Sample Date/Time: Wednesday, November 22, 2006 11:30:10

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950030A.018

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 24110.741 | 1.4 | 49.334 | 16.37068 | 0.225 | 1.4 | ug/L |
| Al | 27 | 2164969.443 | 11.7 | 2679.805 | 181.58875 | 22.834 | 12.6 | ug/L |
| > Sc | 45 | 535964.532 | 1.3 | 378193.541 | | | | ug/L |
| V | 51 | 428136.104 | 6.2 | 4537.327 | 20.84948 | 1.291 | 6.2 | ug/L |
| Cr | 52 | 523343.827 | 10.7 | 15100.490 | 28.26499 | 3.359 | 11.9 | ug/L |
| Cr | 53 | 57276.093 | 1.5 | 618.029 | 26.23451 | 0.637 | 2.4 | ug/L |
| Mn | 55 | 792960.588 | 2.4 | 580.693 | 36.99686 | 0.734 | 2.0 | ug/L |
| Co | 59 | 412459.002 | 0.5 | 202.004 | 22.30410 | 0.860 | 3.9 | ug/L |
| Ni | 60 | 127456.900 | 18.0 | 196.338 | 30.95682 | 6.706 | 21.7 | ug/L |
| Ni | 62 | 17177.546 | 4.3 | 499.020 | 25.85713 | 0.338 | 1.3 | ug/L |
| Cu | 63 | 210445.630 | 2.9 | 505.687 | 21.72665 | 0.931 | 4.3 | ug/L |
| Cu | 65 | 99183.117 | 3.2 | 212.672 | 21.05006 | 1.075 | 5.1 | ug/L |
| Zn | 66 | 54311.754 | 3.4 | 1298.448 | 19.29938 | 0.022 | 0.1 | ug/L |
| Zn | 67 | 9340.327 | 2.3 | 302.342 | 19.59220 | 1.054 | 5.4 | ug/L |
| Zn | 68 | 39524.923 | 1.7 | 996.736 | 19.43897 | 0.401 | 2.1 | ug/L |
| > Ge | 72 | 245604.607 | 3.5 | 197196.226 | | | | ug/L |
| As | 75 | 60034.148 | 2.4 | 96.335 | 19.77898 | 0.361 | 1.8 | ug/L |
| Se | 77 | 4356.138 | 0.7 | 202.002 | 18.25346 | 0.564 | 3.1 | ug/L |
| Se | 78 | 31794.979 | 1.8 | 14431.438 | 19.46237 | 2.256 | 11.6 | mg/L |
| Se | 82 | 6008.833 | 1.4 | 1747.050 | 12.59245 | 0.437 | 3.5 | ug/L |
| Kr | 83 | 293.008 | 7.1 | 1793.211 | | | | mg/L |
| Y | 89 | 489749.251 | 1.8 | 365281.373 | | | | ug/L |
| Mo | 95 | 144966.386 | 1.7 | 120.335 | 25.12773 | 0.230 | 0.9 | ug/L |
| Mo | 97 | 88025.378 | 1.1 | 52.667 | 24.29310 | 0.530 | 2.2 | ug/L |
| Mo | 98 | 229659.890 | 1.2 | 70.498 | 24.53492 | 0.533 | 2.2 | ug/L |
| Rh | 103 | 379125.943 | 1.7 | 350376.944 | | | | ug/L |
| Ag | 107 | 112.002 | 8.5 | 46.001 | 0.00410 | 0.001 | 17.1 | ug/L |
| Ag | 109 | 91.668 | 14.0 | 42.334 | 0.00311 | 0.001 | 26.8 | ug/L |
| Cd | 111 | 67695.864 | 1.1 | 203.876 | 19.77876 | 0.200 | 1.0 | ug/L |
| Cd | 114 | 149327.062 | 1.2 | 55.152 | 19.00713 | 0.274 | 1.4 | ug/L |
| > In | 115 | 413889.096 | 1.4 | 366049.872 | | | | ug/L |
| Sb | 121 | 206533.716 | 1.3 | 54.667 | 19.87248 | 0.546 | 2.7 | ug/L |
| Sb | 123 | 154628.048 | 1.3 | 37.221 | 20.15412 | 0.287 | 1.4 | ug/L |
| Ba | 135 | 23073.799 | 0.9 | 52.001 | 9.94695 | 0.196 | 2.0 | ug/L |
| Ba | 137 | 39653.195 | 1.5 | 70.668 | 10.13583 | 0.125 | 1.2 | ug/L |
| > Tb | 159 | 424707.050 | 1.2 | 427712.876 | | | | ug/L |
| > Ho | 165 | 417084.035 | 1.2 | 412683.278 | | | | ug/L |
| Tl | 203 | 168965.989 | 1.4 | 51.667 | 21.09541 | 0.538 | 2.5 | ug/L |
| Tl | 205 | 394969.787 | 1.4 | 75.334 | 21.58145 | 0.065 | 0.3 | ug/L |
| Pb | 208 | 547323.270 | 1.0 | 440.342 | 21.29807 | 0.387 | 1.8 | ug/L |

Sample ID: 950030A

Report Date/Time: Wednesday, November 22, 2006 11:33:11

Page 1

972

| | | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|-----|------|
| | Pb | 206 | 143259.098 | 1.2 | 119.335 | 21.47006 | 0.515 | 2.4 | ug/L |
| | Pb | 207 | 117032.048 | 1.7 | 109.335 | 20.88169 | 0.609 | 2.9 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 141.717 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 124.548 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 113.069 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.297 | | | |
| > Ho | 165 | | 101.066 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030L

Sample Date/Time: Wednesday, November 22, 2006 11:36:07

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950030L.019

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 59.667 | 10.9 | 49.334 | 0.00339 | 0.005 | 154.5 | ug/L |
| Al | 27 | 327550.929 | 1.6 | 2679.805 | 34.21710 | 0.334 | 1.0 | ug/L |
| > Sc | 45 | 426784.659 | 0.7 | 378193.541 | | | | ug/L |
| V | 51 | 6047.850 | 4.4 | 4537.327 | 0.05767 | 0.019 | 33.0 | ug/L |
| Cr | 52 | 39870.550 | 0.2 | 15100.490 | 1.61348 | 0.017 | 1.0 | ug/L |
| Cr | 53 | 3748.214 | 1.7 | 618.029 | 1.78189 | 0.043 | 2.4 | ug/L |
| Mn | 55 | 62912.424 | 3.7 | 580.693 | 3.12507 | 0.058 | 1.9 | ug/L |
| Co | 59 | 1875.563 | 0.5 | 202.004 | 0.09551 | 0.002 | 2.6 | ug/L |
| Ni | 60 | 5552.240 | 4.4 | 196.338 | 1.38815 | 0.086 | 6.2 | ug/L |
| Ni | 62 | 1134.755 | 1.8 | 499.020 | 0.93636 | 0.041 | 4.4 | ug/L |
| Cu | 63 | 2041.270 | 1.1 | 505.687 | 0.16214 | 0.007 | 4.1 | ug/L |
| Cu | 65 | 982.401 | 0.6 | 212.672 | 0.16843 | 0.005 | 2.7 | ug/L |
| Zn | 66 | 1961.917 | 3.1 | 1298.448 | 0.18059 | 0.009 | 5.0 | ug/L |
| Zn | 67 | 412.014 | 1.5 | 302.342 | 0.14574 | 0.020 | 13.6 | ug/L |
| Zn | 68 | 1736.532 | 2.2 | 996.736 | 0.31808 | 0.013 | 3.9 | ug/L |
| > Ge | 72 | 228303.376 | 1.9 | 197196.226 | | | | ug/L |
| As | 75 | 244.006 | 9.8 | 96.335 | 0.04702 | 0.008 | 17.4 | ug/L |
| Se | 77 | 246.670 | 4.7 | 202.002 | 0.06214 | 0.076 | 122.3 | ug/L |
| Se | 78 | 16867.502 | 2.0 | 14431.438 | 0.25199 | 0.933 | 370.1 | mg/L |
| Se | 82 | 324.206 | 2.0 | 1747.050 | -5.99766 | 0.039 | 0.6 | ug/L |
| Kr | 83 | 287.008 | 2.1 | 1793.211 | | | | mg/L |
| Y | 89 | 425580.130 | 2.0 | 365281.373 | | | | ug/L |
| Mo | 95 | 369.679 | 6.1 | 120.335 | 0.04424 | 0.004 | 9.0 | ug/L |
| Mo | 97 | 235.339 | 9.4 | 52.667 | 0.05228 | 0.006 | 11.7 | ug/L |
| Mo | 98 | 514.444 | 2.8 | 70.498 | 0.04964 | 0.002 | 3.8 | ug/L |
| Rh | 103 | 364966.324 | 1.1 | 350376.944 | | | | ug/L |
| Ag | 107 | 69.001 | 1.4 | 46.001 | 0.00143 | 0.000 | 4.1 | ug/L |
| Ag | 109 | 44.334 | 18.9 | 42.334 | -0.00007 | 0.001 | 874.7 | ug/L |
| Cd | 111 | 231.963 | 10.2 | 203.876 | 0.00434 | 0.007 | 161.7 | ug/L |
| Cd | 114 | 67.320 | 36.5 | 55.152 | 0.00113 | 0.003 | 292.3 | ug/L |
| > In | 115 | 391239.211 | 0.6 | 366049.872 | | | | ug/L |
| Sb | 121 | 406.347 | 10.5 | 54.667 | 0.03541 | 0.004 | 11.9 | ug/L |
| Sb | 123 | 313.908 | 14.8 | 37.221 | 0.03779 | 0.006 | 16.6 | ug/L |
| Ba | 135 | 4507.598 | 2.7 | 52.001 | 1.97166 | 0.066 | 3.3 | ug/L |
| Ba | 137 | 7637.575 | 1.1 | 70.668 | 1.98445 | 0.031 | 1.6 | ug/L |
| > Tb | 159 | 414819.345 | 0.9 | 427712.876 | | | | ug/L |
| > Ho | 165 | 401402.851 | 0.5 | 412683.278 | | | | ug/L |
| Tl | 203 | 82.668 | 6.7 | 51.667 | 0.00420 | 0.001 | 16.3 | ug/L |
| Tl | 205 | 147.003 | 16.1 | 75.334 | 0.00419 | 0.001 | 33.0 | ug/L |
| Pb | 208 | 1960.110 | 2.2 | 440.342 | 0.06199 | 0.002 | 3.5 | ug/L |

Sample ID: 950030L

Report Date/Time: Wednesday, November 22, 2006 11:39:09

Page 1

975

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 524.688 | 2.6 | 119.335 | 0.06368 | 0.002 | 3.9 ug/L |
| | Pb | 207 | 407.014 | 6.0 | 109.335 | 0.05580 | 0.005 | 8.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 112.848 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 115.775 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 106.881 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 96.985 | | | |
| > [Ho | 165 | | 97.267 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950031

Sample Date/Time: Wednesday, November 22, 2006 11:42:05

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950031.020

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 110.002 | 13.4 | 49.334 | 0.03102 | 0.010 | 32.5 | ug/L |
| Al | 27 | 7093123.747 | 2.2 | 2679.805 | 625.26267 | 17.593 | 2.8 | ug/L |
| > Sc | 45 | 510300.575 | 0.6 | 378193.541 | | | | ug/L |
| V | 51 | 34757.733 | 47.1 | 4537.327 | 1.49025 | 0.862 | 57.9 | ug/L |
| Cr | 52 | 560716.587 | 6.5 | 15100.490 | 31.94678 | 2.374 | 7.4 | ug/L |
| Cr | 53 | 63587.054 | 2.2 | 618.029 | 30.65229 | 0.655 | 2.1 | ug/L |
| Mn | 55 | 857929.000 | 1.3 | 580.693 | 40.93355 | 0.629 | 1.5 | ug/L |
| Co | 59 | 31685.775 | 0.4 | 202.004 | 1.73852 | 0.010 | 0.6 | ug/L |
| Ni | 60 | 90429.577 | 0.5 | 196.338 | 22.34020 | 0.212 | 0.9 | ug/L |
| Ni | 62 | 12300.862 | 0.5 | 499.020 | 18.68446 | 0.278 | 1.5 | ug/L |
| Cu | 63 | 28686.914 | 0.9 | 505.687 | 2.97117 | 0.046 | 1.5 | ug/L |
| Cu | 65 | 13571.847 | 1.8 | 212.672 | 2.89477 | 0.030 | 1.0 | ug/L |
| Zn | 66 | 13350.491 | 2.6 | 1298.448 | 4.40871 | 0.113 | 2.6 | ug/L |
| Zn | 67 | 2682.458 | 0.5 | 302.342 | 5.16842 | 0.081 | 1.6 | ug/L |
| Zn | 68 | 11780.773 | 1.1 | 996.736 | 5.48618 | 0.116 | 2.1 | ug/L |
| > Ge | 72 | 240122.612 | 0.9 | 197196.226 | | | | ug/L |
| As | 75 | 2933.879 | 2.5 | 96.335 | 0.95072 | 0.023 | 2.4 | ug/L |
| Se | 77 | 426.278 | 1.3 | 202.002 | 0.81966 | 0.032 | 3.8 | ug/L |
| Se | 78 | 18982.665 | 1.0 | 14431.438 | 2.02768 | 0.468 | 23.1 | mg/L |
| Se | 82 | 531.084 | 1.7 | 1747.050 | -5.35990 | 0.015 | 0.3 | ug/L |
| Kr | 83 | 344.011 | 11.0 | 1793.211 | | | | mg/L |
| Y | 89 | 492913.179 | 3.1 | 365281.373 | | | | ug/L |
| Mo | 95 | 10193.334 | 1.7 | 120.335 | 1.71246 | 0.071 | 4.1 | ug/L |
| Mo | 97 | 6094.289 | 1.4 | 52.667 | 1.63465 | 0.023 | 1.4 | ug/L |
| Mo | 98 | 15514.869 | 0.8 | 70.498 | 1.61859 | 0.051 | 3.2 | ug/L |
| Rh | 103 | 380930.114 | 2.1 | 350376.944 | | | | ug/L |
| Ag | 107 | 138.336 | 2.9 | 46.001 | 0.00571 | 0.000 | 1.8 | ug/L |
| Ag | 109 | 96.668 | 9.6 | 42.334 | 0.00336 | 0.001 | 24.1 | ug/L |
| Cd | 111 | 383.426 | 5.9 | 203.876 | 0.04272 | 0.007 | 15.3 | ug/L |
| Cd | 114 | 291.851 | 15.2 | 55.152 | 0.02859 | 0.006 | 21.7 | ug/L |
| > In | 115 | 421889.947 | 2.3 | 366049.872 | | | | ug/L |
| Sb | 121 | 757.042 | 3.3 | 54.667 | 0.06554 | 0.003 | 4.3 | ug/L |
| Sb | 123 | 546.796 | 7.1 | 37.221 | 0.06440 | 0.004 | 5.5 | ug/L |
| Ba | 135 | 34148.836 | 0.7 | 52.001 | 14.57901 | 0.151 | 1.0 | ug/L |
| Ba | 137 | 58697.922 | 0.4 | 70.668 | 14.85846 | 0.098 | 0.7 | ug/L |
| > Tb | 159 | 429110.866 | 0.9 | 427712.876 | | | | ug/L |
| > Ho | 165 | 416023.933 | 1.2 | 412683.278 | | | | ug/L |
| Tl | 203 | 473.685 | 16.4 | 51.667 | 0.05284 | 0.010 | 19.4 | ug/L |
| Tl | 205 | 1119.087 | 11.6 | 75.334 | 0.05720 | 0.008 | 13.5 | ug/L |
| Pb | 208 | 34783.161 | 0.7 | 440.342 | 1.34064 | 0.008 | 0.6 | ug/L |

Sample ID: 950031

Report Date/Time: Wednesday, November 22, 2006 11:45:07

Page 1

978

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 9062.351 | 2.3 | 119.335 | 1.34433 | 0.018 | 1.3 ug/L |
| | Pb | 207 | 7540.485 | 0.7 | 109.335 | 1.33017 | 0.013 | 1.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 134.931 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 121.768 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 115.255 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 100.327 | | | |
| > [Ho | 165 | | 100.809 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

121.768
rpt

Elan 9000 Method 6020 - Summary Report

Sample ID: 950032

Sample Date/Time: Wednesday, November 22, 2006 11:48:03

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950032.021

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1195.764 | 2.4 | 49.334 | 0.78492 | 0.012 | 1.5 | ug/L |
| Al | 27 | 32535108.719 | 0.2 | 2679.805 | 2794.37116 | 98.985 | 3.5 | ug/L |
| > Sc | 45 | 524310.826 | 3.4 | 378193.541 | | | | ug/L |
| V | 51 | 45651.390 | 152.6 | 4537.327 | 1.97763 | 3.575 | 180.8 | ug/L |
| Cr | 52 | 712825.235 | 7.8 | 15100.490 | 39.88073 | 4.237 | 10.6 | ug/L |
| Cr | 53 | 84041.374 | 2.8 | 618.029 | 39.55200 | 0.308 | 0.8 | ug/L |
| Mn | 55 | 12315236.466 | 3.5 | 580.693 | 591.40711 | 20.236 | 3.4 | ug/L |
| Co | 59 | 333713.740 | 0.4 | 202.004 | 18.55135 | 0.524 | 2.8 | ug/L |
| Ni | 60 | 290975.961 | 3.0 | 196.338 | 72.48888 | 4.129 | 5.7 | ug/L |
| Ni | 62 | 42952.879 | 2.3 | 499.020 | 68.06565 | 2.104 | 3.1 | ug/L |
| Cu | 63 | 50109.092 | 2.4 | 505.687 | 5.26834 | 0.066 | 1.3 | ug/L |
| Cu | 65 | 19850.163 | 3.3 | 212.672 | 4.28871 | 0.254 | 5.9 | ug/L |
| Zn | 66 | 186307.711 | 1.4 | 1298.448 | 69.60986 | 1.348 | 1.9 | ug/L |
| Zn | 67 | 30913.544 | 0.8 | 302.342 | 68.63844 | 2.455 | 3.6 | ug/L |
| Zn | 68 | 137553.086 | 1.1 | 996.736 | 71.22186 | 2.678 | 3.8 | ug/L |
| > Ge | 72 | 238792.652 | 2.7 | 197196.226 | | | | ug/L |
| As | 75 | 5209.680 | 0.6 | 96.335 | 1.72961 | 0.051 | 2.9 | ug/L |
| Se | 77 | 852.577 | 4.1 | 202.002 | 2.77868 | 0.115 | 4.1 | ug/L |
| Se | 78 | 18897.888 | 0.9 | 14431.438 | 2.07233 | 0.978 | 47.2 | mg/L |
| Se | 82 | 531.484 | 1.8 | 1747.050 | -5.34781 | 0.050 | 0.9 | ug/L |
| Kr | 83 | 429.015 | 2.3 | 1793.211 | | | | mg/L |
| Y | 89 | 832631.127 | 0.6 | 365281.373 | | | | ug/L |
| Mo | 95 | 5139.969 | 0.7 | 120.335 | 0.87487 | 0.019 | 2.2 | ug/L |
| Mo | 97 | 3066.595 | 1.9 | 52.667 | 0.83670 | 0.027 | 3.2 | ug/L |
| Mo | 98 | 7677.115 | 1.7 | 70.498 | 0.81778 | 0.009 | 1.1 | ug/L |
| Rh | 103 | 379322.094 | 0.3 | 350376.944 | | | | ug/L |
| Ag | 107 | 287.008 | 9.9 | 46.001 | 0.01617 | 0.002 | 10.6 | ug/L |
| Ag | 109 | 238.339 | 2.7 | 42.334 | 0.01370 | 0.001 | 5.6 | ug/L |
| Cd | 111 | 4195.543 | 2.0 | 203.876 | 1.17172 | 0.042 | 3.6 | ug/L |
| Cd | 114 | 8656.145 | 2.8 | 55.152 | 1.10240 | 0.034 | 3.1 | ug/L |
| > In | 115 | 410907.496 | 1.8 | 366049.872 | | | | ug/L |
| Sb | 121 | 676.034 | 2.3 | 54.667 | 0.05958 | 0.001 | 1.8 | ug/L |
| Sb | 123 | 524.879 | 5.2 | 37.221 | 0.06347 | 0.004 | 6.6 | ug/L |
| Ba | 135 | 131013.920 | 1.3 | 52.001 | 54.97310 | 0.723 | 1.3 | ug/L |
| Ba | 137 | 230524.416 | 1.5 | 70.668 | 57.34326 | 1.214 | 2.1 | ug/L |
| > Tb | 159 | 437088.180 | 0.8 | 427712.876 | | | | ug/L |
| > Ho | 165 | 419356.701 | 1.9 | 412683.278 | | | | ug/L |
| Tl | 203 | 1016.741 | 21.2 | 51.667 | 0.11991 | 0.028 | 23.1 | ug/L |
| Tl | 205 | 2380.705 | 18.6 | 75.334 | 0.12543 | 0.025 | 20.1 | ug/L |
| Pb | 208 | 65284.331 | 0.2 | 440.342 | 2.51165 | 0.046 | 1.8 | ug/L |

Sample ID: 950032

Report Date/Time: Wednesday, November 22, 2006 11:51:04

Page 1

981

| | | | | | | | | |
|---|----|-----|-----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 16905.305 | 2.3 | 119.335 | 2.50348 | 0.042 | 1.7 ug/L |
| L | Pb | 207 | 13858.321 | 1.7 | 109.335 | 2.44195 | 0.064 | 2.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 138.636 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 121.094 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 112.255 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 102.192 | | | |
| > Ho | 165 | | 101.617 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

121.094

rpt.

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Wednesday, November 22, 2006 11:54:01

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 6.022

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55131.653 | 0.3 | 49.334 | 50.08336 | 1.112 | 2.2 | ug/L |
| Al | 27 | 459751.381 | 3.4 | 2679.805 | 51.20454 | 0.625 | 1.2 | ug/L |
| > Sc | 45 | 401489.070 | 2.4 | 378193.541 | | | | ug/L |
| V | 51 | 818226.072 | 1.2 | 4537.327 | 53.70434 | 1.453 | 2.7 | ug/L |
| Cr | 52 | 705574.165 | 2.7 | 15100.490 | 51.79980 | 0.624 | 1.2 | ug/L |
| Cr | 53 | 82060.248 | 1.3 | 618.029 | 50.54846 | 0.680 | 1.3 | ug/L |
| Mn | 55 | 958677.247 | 2.2 | 580.693 | 52.33154 | 0.930 | 1.8 | ug/L |
| Co | 59 | 800858.810 | 2.9 | 202.004 | 50.64379 | 1.268 | 2.5 | ug/L |
| Ni | 60 | 185305.729 | 1.4 | 196.338 | 52.44701 | 0.542 | 1.0 | ug/L |
| Ni | 62 | 27360.830 | 4.0 | 499.020 | 49.03782 | 1.895 | 3.9 | ug/L |
| Cu | 63 | 428807.338 | 1.2 | 505.687 | 51.85246 | 0.441 | 0.9 | ug/L |
| Cu | 65 | 210697.809 | 1.5 | 212.672 | 52.35734 | 0.635 | 1.2 | ug/L |
| Zn | 66 | 119088.354 | 3.3 | 1298.448 | 50.44366 | 1.728 | 3.4 | ug/L |
| Zn | 67 | 20428.551 | 1.8 | 302.342 | 51.36561 | 0.960 | 1.9 | ug/L |
| Zn | 68 | 88110.324 | 1.7 | 996.736 | 51.69649 | 0.908 | 1.8 | ug/L |
| > Ge | 72 | 209896.617 | 0.4 | 197196.226 | | | | ug/L |
| As | 75 | 133904.286 | 0.8 | 96.335 | 51.66835 | 0.391 | 0.8 | ug/L |
| Se | 77 | 10279.470 | 1.3 | 202.002 | 52.33399 | 0.467 | 0.9 | ug/L |
| Se | 78 | 49127.948 | 0.6 | 14431.438 | 55.49342 | 0.437 | 0.8 | mg/L |
| Se | 82 | 14220.057 | 1.1 | 1747.050 | 47.47883 | 0.457 | 1.0 | ug/L |
| Kr | 83 | 317.009 | 6.8 | 1793.211 | | | | mg/L |
| Y | 89 | 405606.302 | 3.4 | 365281.373 | | | | ug/L |
| Mo | 95 | 285417.404 | 3.2 | 120.335 | 54.57122 | 1.879 | 3.4 | ug/L |
| Mo | 97 | 179920.777 | 2.5 | 52.667 | 54.74527 | 0.980 | 1.8 | ug/L |
| Mo | 98 | 452245.474 | 2.3 | 70.498 | 53.25635 | 0.627 | 1.2 | ug/L |
| Rh | 103 | 354820.820 | 1.1 | 350376.944 | | | | ug/L |
| Ag | 107 | 695650.857 | 0.8 | 46.001 | 52.35225 | 1.215 | 2.3 | ug/L |
| Ag | 109 | 645103.221 | 3.4 | 42.334 | 50.64755 | 1.395 | 2.8 | ug/L |
| Cd | 111 | 163299.848 | 0.7 | 203.876 | 52.70899 | 0.614 | 1.2 | ug/L |
| Cd | 114 | 357844.963 | 5.1 | 55.152 | 50.19661 | 1.569 | 3.1 | ug/L |
| > In | 115 | 375477.714 | 1.9 | 366049.872 | | | | ug/L |
| Sb | 121 | 468926.492 | 1.7 | 54.667 | 49.73785 | 0.891 | 1.8 | ug/L |
| Sb | 123 | 351729.806 | 1.3 | 37.221 | 50.55076 | 1.178 | 2.3 | ug/L |
| Ba | 135 | 114823.730 | 2.3 | 52.001 | 50.70099 | 0.718 | 1.4 | ug/L |
| Ba | 137 | 198951.181 | 0.1 | 70.668 | 52.08355 | 0.601 | 1.2 | ug/L |
| > Tb | 159 | 415305.810 | 1.2 | 427712.876 | | | | ug/L |
| > Ho | 165 | 391956.625 | 0.9 | 412683.278 | | | | ug/L |
| Tl | 203 | 388283.207 | 1.0 | 51.667 | 51.58558 | 0.524 | 1.0 | ug/L |
| Tl | 205 | 891124.249 | 4.5 | 75.334 | 51.82600 | 2.484 | 4.8 | ug/L |
| Pb | 208 | 1226979.366 | 1.6 | 440.342 | 50.82658 | 0.910 | 1.8 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Wednesday, November 22, 2006 11:57:04

Page 1

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 312905.965 | 1.8 | 119.335 | 49.91886 | 1.044 | 2.1 ug/L |
| | Pb | 207 | 265272.404 | 1.3 | 109.335 | 50.38414 | 0.683 | 1.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 100.167 | | | | |
| Al | 27 | 102.409 | | | | |
| > Sc | 45 | | 106.160 | | | |
| V | 51 | 107.409 | | | | |
| Cr | 52 | 103.600 | | | | |
| Cr | 53 | 101.097 | | | | |
| Mn | 55 | 104.663 | | | | |
| Co | 59 | 101.288 | | | | |
| Ni | 60 | 104.894 | | | | |
| Ni | 62 | 98.076 | | | | |
| Cu | 63 | 103.705 | | | | |
| Cu | 65 | 104.715 | | | | |
| Zn | 66 | 100.887 | | | | |
| Zn | 67 | 102.731 | | | | |
| Zn | 68 | 103.393 | | | | |
| > Ge | 72 | | 106.440 | | | |
| As | 75 | 103.337 | | | | |
| Se | 77 | 104.668 | | | | |
| Se | 78 | 110.987 | | | | |
| Se | 82 | 94.958 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 109.142 | | | | |
| Mo | 97 | 109.491 | | | | |
| Mo | 98 | 106.513 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 104.705 | | | | |
| Ag | 109 | 101.295 | | | | |
| Cd | 111 | 105.418 | | | | |
| Cd | 114 | 100.393 | | | | |
| > In | 115 | | 102.576 | | | |
| Sb | 121 | 99.476 | | | | |
| Sb | 123 | 101.102 | | | | |
| Ba | 135 | 101.402 | | | | |
| Ba | 137 | 104.167 | | | | |
| > Tb | 159 | | 97.099 | | | |
| > Ho | 165 | | 94.978 | | | |
| Tl | 203 | 103.171 | | | | |
| Tl | 205 | 103.652 | | | | |
| Pb | 208 | 101.653 | | | | |
| Pb | 206 | 99.838 | | | | |
| Pb | 207 | 100.768 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Wednesday, November 22, 2006 11:59:59

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 7.023

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 45.001 | 21.2 | 49.334 | -0.00699 | 0.009 | 126.0 | ug/L |
| Al | 27 | 2536.411 | 0.9 | 2679.805 | -0.03677 | 0.004 | 9.7 | ug/L |
| > Sc | 45 | 404637.925 | 0.6 | 378193.541 | | | | ug/L |
| V | 51 | 4444.238 | 3.8 | 4537.327 | -0.02684 | 0.012 | 44.5 | ug/L |
| Cr | 52 | 15054.407 | 2.2 | 15100.490 | -0.08218 | 0.021 | 25.1 | ug/L |
| Cr | 53 | 940.063 | 5.6 | 618.029 | 0.17178 | 0.033 | 19.2 | ug/L |
| Mn | 55 | 573.359 | 2.2 | 580.693 | -0.00338 | 0.001 | 32.3 | ug/L |
| Co | 59 | 165.337 | 2.1 | 202.004 | -0.00346 | 0.000 | 10.0 | ug/L |
| Ni | 60 | 171.003 | 15.5 | 196.338 | -0.01228 | 0.007 | 54.9 | ug/L |
| Ni | 62 | 436.682 | 5.8 | 499.020 | -0.19702 | 0.039 | 19.7 | ug/L |
| Cu | 63 | 403.014 | 7.5 | 505.687 | -0.01785 | 0.003 | 19.5 | ug/L |
| Cu | 65 | 212.338 | 9.3 | 212.672 | -0.00506 | 0.005 | 102.5 | ug/L |
| Zn | 66 | 1299.448 | 1.0 | 1298.448 | -0.05217 | 0.012 | 23.6 | ug/L |
| Zn | 67 | 276.007 | 7.5 | 302.342 | -0.13785 | 0.060 | 43.8 | ug/L |
| Zn | 68 | 930.728 | 1.2 | 996.736 | -0.09394 | 0.014 | 14.4 | ug/L |
| > Ge | 72 | 216452.530 | 1.4 | 197196.226 | | | | ug/L |
| As | 75 | 138.669 | 16.1 | 96.335 | 0.01238 | 0.009 | 70.8 | ug/L |
| Se | 77 | 235.803 | 4.8 | 202.002 | 0.07132 | 0.065 | 90.6 | ug/L |
| Se | 78 | 15688.853 | 2.4 | 14431.438 | -0.24345 | 0.379 | 155.7 | mg/L |
| Se | 82 | 461.946 | 6.8 | 1747.050 | -5.42185 | 0.124 | 2.3 | ug/L |
| Kr | 83 | 429.682 | 10.6 | 1793.211 | | | | mg/L |
| Y | 89 | 403901.314 | 1.5 | 365281.373 | | | | ug/L |
| Mo | 95 | 617.363 | 17.5 | 120.335 | 0.09221 | 0.019 | 20.3 | ug/L |
| Mo | 97 | 378.346 | 15.4 | 52.667 | 0.09654 | 0.016 | 16.6 | ug/L |
| Mo | 98 | 963.896 | 23.1 | 70.498 | 0.10278 | 0.024 | 23.4 | ug/L |
| Rh | 103 | 354684.820 | 1.1 | 350376.944 | | | | ug/L |
| Ag | 107 | 136.336 | 16.5 | 46.001 | 0.00652 | 0.002 | 25.0 | ug/L |
| Ag | 109 | 119.669 | 12.6 | 42.334 | 0.00583 | 0.001 | 21.3 | ug/L |
| Cd | 111 | 244.084 | 26.4 | 203.876 | 0.01003 | 0.021 | 209.0 | ug/L |
| Cd | 114 | 61.643 | 11.9 | 55.152 | 0.00055 | 0.001 | 172.1 | ug/L |
| > In | 115 | 382216.328 | 1.4 | 366049.872 | | | | ug/L |
| Sb | 121 | 1061.413 | 14.6 | 54.667 | 0.10451 | 0.015 | 14.0 | ug/L |
| Sb | 123 | 761.234 | 19.7 | 37.221 | 0.10179 | 0.020 | 19.3 | ug/L |
| Ba | 135 | 41.667 | 16.0 | 52.001 | -0.00432 | 0.003 | 69.0 | ug/L |
| Ba | 137 | 83.335 | 62.1 | 70.668 | 0.00341 | 0.013 | 394.2 | ug/L |
| > Tb | 159 | 425169.156 | 1.2 | 427712.876 | | | | ug/L |
| > Ho | 165 | 406310.324 | 0.9 | 412683.278 | | | | ug/L |
| Tl | 203 | 62.001 | 15.6 | 51.667 | 0.00142 | 0.001 | 81.8 | ug/L |
| Tl | 205 | 139.669 | 18.0 | 75.334 | 0.00368 | 0.001 | 39.2 | ug/L |
| Pb | 208 | 330.339 | 1.8 | 440.342 | -0.00412 | 0.000 | 8.3 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Wednesday, November 22, 2006 12:03:00

Page 1

987

| | | | | | | | | |
|--|----|-----|--------|------|---------|----------|-------|-----------|
| | Pb | 206 | 95.668 | 7.8 | 119.335 | -0.00336 | 0.001 | 32.8 ug/L |
| | Pb | 207 | 75.334 | 13.6 | 109.335 | -0.00592 | 0.002 | 32.5 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 106.992 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 109.765 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.416 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.405 | | | |
| > Ho | 165 | | 98.456 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950033 D.5

Sample Date/Time: Wednesday, November 22, 2006 12:05:57

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950033 D.5.024

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 66.668 | 9.6 | 49.334 | 0.01114 | 0.006 | 53.9 | ug/L |
| Al | 27 | 64551.079 | 1.9 | 2679.805 | 6.69278 | 0.184 | 2.7 | ug/L |
| > Sc | 45 | 414346.205 | 0.8 | 378193.541 | | | | ug/L |
| V | 51 | 5658.495 | 2.8 | 4537.327 | 0.04400 | 0.012 | 27.1 | ug/L |
| Cr | 52 | 19226.686 | 2.0 | 15100.490 | 0.19542 | 0.035 | 18.1 | ug/L |
| Cr | 53 | 1280.111 | 4.5 | 618.029 | 0.36260 | 0.029 | 7.9 | ug/L |
| Mn | 55 | 580356.913 | 2.4 | 580.693 | 30.57550 | 0.688 | 2.3 | ug/L |
| Co | 59 | 1428.803 | 2.4 | 202.004 | 0.07367 | 0.002 | 3.3 | ug/L |
| Ni | 60 | 3499.103 | 3.6 | 196.338 | 0.89810 | 0.034 | 3.7 | ug/L |
| Ni | 62 | 553.024 | 2.0 | 499.020 | 0.00522 | 0.024 | 466.5 | ug/L |
| Cu | 63 | 2521.073 | 2.2 | 505.687 | 0.22956 | 0.006 | 2.8 | ug/L |
| Cu | 65 | 1153.091 | 4.8 | 212.672 | 0.22070 | 0.015 | 6.6 | ug/L |
| Zn | 66 | 1601.837 | 1.3 | 1298.448 | 0.07055 | 0.010 | 14.3 | ug/L |
| Zn | 67 | 487.353 | 8.0 | 302.342 | 0.38031 | 0.101 | 26.6 | ug/L |
| Zn | 68 | 1736.532 | 5.0 | 996.736 | 0.36556 | 0.045 | 12.2 | ug/L |
| > Ge | 72 | 217385.056 | 0.5 | 197196.226 | | | | ug/L |
| As | 75 | 332.677 | 4.8 | 96.335 | 0.08443 | 0.005 | 6.4 | ug/L |
| Se | 77 | 252.537 | 2.1 | 202.002 | 0.14996 | 0.030 | 20.0 | ug/L |
| Se | 78 | 15894.815 | 1.6 | 14431.438 | -0.02291 | 0.331 | 1447.0 | mg/L |
| Se | 82 | 559.685 | 1.5 | 1747.050 | -5.06709 | 0.041 | 0.8 | ug/L |
| Kr | 83 | 553.357 | 3.2 | 1793.211 | | | | mg/L |
| Y | 89 | 418158.431 | 0.8 | 365281.373 | | | | ug/L |
| Mo | 95 | 2690.461 | 2.9 | 120.335 | 0.48345 | 0.007 | 1.4 | ug/L |
| Mo | 97 | 1640.178 | 0.6 | 52.667 | 0.47571 | 0.012 | 2.6 | ug/L |
| Mo | 98 | 4277.750 | 2.4 | 70.498 | 0.48809 | 0.011 | 2.2 | ug/L |
| Rh | 103 | 343253.127 | 0.9 | 350376.944 | | | | ug/L |
| Ag | 107 | 69.334 | 8.7 | 46.001 | 0.00160 | 0.001 | 37.3 | ug/L |
| Ag | 109 | 70.668 | 18.2 | 42.334 | 0.00205 | 0.001 | 45.7 | ug/L |
| Cd | 111 | 236.768 | 4.1 | 203.876 | 0.00792 | 0.005 | 67.3 | ug/L |
| Cd | 114 | 95.596 | 25.4 | 55.152 | 0.00522 | 0.003 | 55.9 | ug/L |
| > In | 115 | 381052.037 | 3.1 | 366049.872 | | | | ug/L |
| Sb | 121 | 921.394 | 6.3 | 54.667 | 0.09029 | 0.003 | 3.6 | ug/L |
| Sb | 123 | 664.515 | 9.7 | 37.221 | 0.08849 | 0.006 | 7.2 | ug/L |
| Ba | 135 | 14752.862 | 0.6 | 52.001 | 6.52123 | 0.011 | 0.2 | ug/L |
| Ba | 137 | 24952.221 | 1.3 | 70.668 | 6.54194 | 0.050 | 0.8 | ug/L |
| > Tb | 159 | 413648.205 | 0.5 | 427712.876 | | | | ug/L |
| > Ho | 165 | 407667.154 | 1.1 | 412683.278 | | | | ug/L |
| Tl | 203 | 168.670 | 8.1 | 51.667 | 0.01502 | 0.002 | 11.0 | ug/L |
| Tl | 205 | 362.012 | 11.7 | 75.334 | 0.01607 | 0.002 | 13.4 | ug/L |
| Pb | 208 | 977.365 | 4.3 | 440.342 | 0.02161 | 0.002 | 8.0 | ug/L |

Sample ID: 950033 D.5

Report Date/Time: Wednesday, November 22, 2006 12:08:58

Page 1

990

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|-----------|
| | Pb | 206 | 257.007 | 8.2 | 119.335 | 0.02134 | 0.003 | 14.8 ug/L |
| | Pb | 207 | 209.671 | 6.1 | 109.335 | 0.01856 | 0.002 | 11.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 109.559 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 110.238 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 104.098 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 96.712 | | | |
| > Ho | 165 | | 98.785 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950033

Sample Date/Time: Wednesday, November 22, 2006 12:11:55

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950033.025

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 70.334 | 13.5 | 49.334 | 0.00869 | 0.008 | 86.5 | ug/L |
| Al | 27 | 314096.036 | 1.4 | 2679.805 | 30.67930 | 0.483 | 1.6 | ug/L |
| > Sc | 45 | 456056.043 | 2.1 | 378193.541 | | | | ug/L |
| V | 51 | 10084.203 | 4.8 | 4537.327 | 0.26821 | 0.031 | 11.7 | ug/L |
| Cr | 52 | 33669.259 | 3.1 | 15100.490 | 1.02338 | 0.094 | 9.1 | ug/L |
| Cr | 53 | 3020.244 | 0.4 | 618.029 | 1.24383 | 0.031 | 2.5 | ug/L |
| Mn | 55 | 3401846.442 | 1.2 | 580.693 | 176.22090 | 2.065 | 1.2 | ug/L |
| Co | 59 | 7101.436 | 5.9 | 202.004 | 0.41227 | 0.019 | 4.6 | ug/L |
| Ni | 60 | 20719.601 | 0.9 | 196.338 | 5.51014 | 0.120 | 2.2 | ug/L |
| Ni | 62 | 1169.760 | 1.7 | 499.020 | 1.05761 | 0.064 | 6.0 | ug/L |
| Cu | 63 | 11284.417 | 2.3 | 505.687 | 1.23120 | 0.052 | 4.2 | ug/L |
| Cu | 65 | 5226.024 | 0.2 | 212.672 | 1.17690 | 0.021 | 1.7 | ug/L |
| Zn | 66 | 5959.190 | 2.0 | 1298.448 | 1.82984 | 0.037 | 2.0 | ug/L |
| Zn | 67 | 1697.523 | 3.5 | 302.342 | 3.29102 | 0.143 | 4.4 | ug/L |
| Zn | 68 | 7191.507 | 1.3 | 996.736 | 3.42063 | 0.021 | 0.6 | ug/L |
| > Ge | 72 | 221316.777 | 1.7 | 197196.226 | | | | ug/L |
| As | 75 | 1200.432 | 3.9 | 96.335 | 0.40014 | 0.020 | 4.9 | ug/L |
| Se | 77 | 347.141 | 2.6 | 202.002 | 0.59382 | 0.025 | 4.3 | ug/L |
| Se | 78 | 17844.146 | 0.3 | 14431.438 | 2.57247 | 0.402 | 15.6 | mg/L |
| Se | 82 | 713.364 | 2.0 | 1747.050 | -4.54398 | 0.052 | 1.1 | ug/L |
| Kr | 83 | 596.027 | 5.8 | 1793.211 | | | | mg/L |
| Y | 89 | 443185.619 | 2.1 | 365281.373 | | | | ug/L |
| Mo | 95 | 13628.939 | 0.4 | 120.335 | 2.43440 | 0.061 | 2.5 | ug/L |
| Mo | 97 | 8457.042 | 2.2 | 52.667 | 2.41054 | 0.061 | 2.5 | ug/L |
| Mo | 98 | 21393.821 | 2.0 | 70.498 | 2.36696 | 0.019 | 0.8 | ug/L |
| Rh | 103 | 366981.268 | 0.7 | 350376.944 | | | | ug/L |
| Ag | 107 | 106.002 | 5.7 | 46.001 | 0.00397 | 0.000 | 8.4 | ug/L |
| Ag | 109 | 78.001 | 15.1 | 42.334 | 0.00237 | 0.001 | 40.9 | ug/L |
| Cd | 111 | 375.199 | 15.4 | 203.876 | 0.04647 | 0.015 | 31.7 | ug/L |
| Cd | 114 | 395.482 | 16.6 | 55.152 | 0.04450 | 0.010 | 21.8 | ug/L |
| > In | 115 | 398325.583 | 2.5 | 366049.872 | | | | ug/L |
| Sb | 121 | 2957.554 | 1.6 | 54.667 | 0.28993 | 0.011 | 3.7 | ug/L |
| Sb | 123 | 2219.975 | 0.3 | 37.221 | 0.29536 | 0.008 | 2.6 | ug/L |
| Ba | 135 | 74545.348 | 0.4 | 52.001 | 32.70976 | 0.305 | 0.9 | ug/L |
| Ba | 137 | 131679.201 | 0.5 | 70.668 | 34.25331 | 0.296 | 0.9 | ug/L |
| > Tb | 159 | 417862.789 | 0.8 | 427712.876 | | | | ug/L |
| > Ho | 165 | 404351.218 | 1.3 | 412683.278 | | | | ug/L |
| Tl | 203 | 503.354 | 5.6 | 51.667 | 0.05834 | 0.004 | 7.2 | ug/L |
| Tl | 205 | 1140.423 | 4.5 | 75.334 | 0.06012 | 0.002 | 4.0 | ug/L |
| Pb | 208 | 2932.895 | 1.2 | 440.342 | 0.10048 | 0.002 | 1.8 | ug/L |

Sample ID: 950033

Report Date/Time: Wednesday, November 22, 2006 12:14:57

Page 1

993

| | | | | | | | | |
|---|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 752.708 | 2.1 | 119.335 | 0.09838 | 0.004 | 3.9 ug/L |
| L | Pb | 207 | 656.699 | 2.8 | 109.335 | 0.10121 | 0.002 | 2.4 ug/L |

Sample ID: 950033

Report Date/Time: Wednesday, November 22, 2006 12:14:57

Page 2

994

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 120.588 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 112.232 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 108.817 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 97.697 | | | |
| > [Ho | 165 | | 97.981 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950034

Sample Date/Time: Wednesday, November 22, 2006 12:17:55

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950034.026

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 161.670 | 6.2 | 49.334 | 0.07208 | 0.008 | 10.6 | ug/L |
| Al | 27 | 9269269.523 | 1.4 | 2679.805 | 845.90445 | 21.119 | 2.5 | ug/L |
| Sc | 45 | 493031.068 | 1.5 | 378193.541 | | | | ug/L |
| V | 51 | 48879.120 | 51.0 | 4537.327 | 2.30596 | 1.323 | 57.4 | ug/L |
| Cr | 52 | 761716.714 | 7.8 | 15100.490 | 45.39110 | 3.499 | 7.7 | ug/L |
| Cr | 53 | 86598.569 | 1.6 | 618.029 | 43.37392 | 0.271 | 0.6 | ug/L |
| Mn | 55 | 79332290.326 | 1.6 | 580.693 | 4043.80234 | 64.294 | 1.6 | ug/L |
| Co | 59 | 154119.040 | 0.9 | 202.004 | 9.08443 | 0.143 | 1.6 | ug/L |
| Ni | 60 | 137687.602 | 3.8 | 196.338 | 36.34395 | 1.241 | 3.4 | ug/L |
| Ni | 62 | 19448.864 | 0.7 | 499.020 | 32.20356 | 0.440 | 1.4 | ug/L |
| Cu | 63 | 36237.344 | 2.5 | 505.687 | 4.02872 | 0.077 | 1.9 | ug/L |
| Cu | 65 | 17420.719 | 4.3 | 212.672 | 3.98752 | 0.166 | 4.2 | ug/L |
| Zn | 66 | 25321.006 | 1.9 | 1298.448 | 9.53460 | 0.252 | 2.6 | ug/L |
| Zn | 67 | 4766.744 | 2.5 | 302.342 | 10.54217 | 0.347 | 3.3 | ug/L |
| Zn | 68 | 21006.654 | 0.7 | 996.736 | 11.01144 | 0.107 | 1.0 | ug/L |
| Ge | 72 | 224935.303 | 0.7 | 197196.226 | | | | ug/L |
| As | 75 | 11776.768 | 1.6 | 96.335 | 4.20410 | 0.070 | 1.7 | ug/L |
| Se | 77 | 577.220 | 3.6 | 202.002 | 1.68264 | 0.091 | 5.4 | ug/L |
| Se | 78 | 17858.681 | 1.5 | 14431.438 | 2.14186 | 0.238 | 11.1 | mg/L |
| Se | 82 | 804.572 | 1.4 | 1747.050 | -4.25885 | 0.060 | 1.4 | ug/L |
| Kr | 83 | 634.364 | 3.9 | 1793.211 | | | | mg/L |
| Y | 89 | 515683.228 | 0.8 | 365281.373 | | | | ug/L |
| Mo | 95 | 6892.251 | 0.4 | 120.335 | 1.25499 | 0.016 | 1.3 | ug/L |
| Mo | 97 | 3775.227 | 3.1 | 52.667 | 1.09854 | 0.052 | 4.8 | ug/L |
| Mo | 98 | 9495.349 | 3.4 | 70.498 | 1.07613 | 0.030 | 2.8 | ug/L |
| Rh | 103 | 358379.229 | 3.8 | 350376.944 | | | | ug/L |
| Ag | 107 | 229.339 | 7.0 | 46.001 | 0.01319 | 0.001 | 8.7 | ug/L |
| Ag | 109 | 187.004 | 2.1 | 42.334 | 0.01083 | 0.000 | 1.9 | ug/L |
| Cd | 111 | 1199.674 | 2.7 | 203.876 | 0.30856 | 0.015 | 5.0 | ug/L |
| Cd | 114 | 2088.478 | 3.2 | 55.152 | 0.27639 | 0.010 | 3.5 | ug/L |
| In | 115 | 387137.705 | 1.6 | 366049.872 | | | | ug/L |
| Sb | 121 | 1008.405 | 5.8 | 54.667 | 0.09778 | 0.005 | 5.6 | ug/L |
| Sb | 123 | 713.028 | 5.8 | 37.221 | 0.09386 | 0.005 | 5.1 | ug/L |
| Ba | 135 | 99787.724 | 2.1 | 52.001 | 43.40258 | 0.617 | 1.4 | ug/L |
| Ba | 137 | 167775.421 | 0.3 | 70.668 | 43.26271 | 0.359 | 0.8 | ug/L |
| Tb | 159 | 421583.405 | 0.8 | 427712.876 | | | | ug/L |
| Ho | 165 | 406091.303 | 1.1 | 412683.278 | | | | ug/L |
| Tl | 203 | 3797.904 | 4.2 | 51.667 | 0.48043 | 0.015 | 3.1 | ug/L |
| Tl | 205 | 9156.119 | 0.9 | 75.334 | 0.50980 | 0.003 | 0.5 | ug/L |
| Pb | 208 | 62777.511 | 0.9 | 440.342 | 2.49350 | 0.023 | 0.9 | ug/L |

Sample ID: 950034

Report Date/Time: Wednesday, November 22, 2006 12:20:57

Page 1

996

| | | | | | | | | |
|--|----|-----|-----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 16133.101 | 2.3 | 119.335 | 2.46663 | 0.029 | 1.2 ug/L |
| | Pb | 207 | 13405.910 | 1.3 | 109.335 | 2.43885 | 0.031 | 1.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 130.365 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 114.067 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 105.761 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 98.567 | | | |
| > Ho | 165 | | 98.403 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950035

Sample Date/Time: Wednesday, November 22, 2006 12:23:53

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950035.027

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 91.668 | 4.9 | 49.334 | 0.02288 | 0.004 | 17.5 | ug/L |
| Al | 27 | 266827.552 | 2.0 | 2679.805 | 24.97324 | 0.512 | 2.0 | ug/L |
| > Sc | 45 | 474762.553 | 0.8 | 378193.541 | | | | ug/L |
| V | 51 | 9058.062 | 3.4 | 4537.327 | 0.18761 | 0.014 | 7.7 | ug/L |
| Cr | 52 | 80933.367 | 2.1 | 15100.490 | 3.93750 | 0.111 | 2.8 | ug/L |
| Cr | 53 | 8511.430 | 1.6 | 618.029 | 4.06189 | 0.107 | 2.6 | ug/L |
| Mn | 55 | 29069470.652 | 0.8 | 580.693 | 1425.77326 | 11.416 | 0.8 | ug/L |
| Co | 59 | 25357.107 | 0.4 | 202.004 | 1.42673 | 0.016 | 1.1 | ug/L |
| Ni | 60 | 48841.205 | 1.0 | 196.338 | 12.36703 | 0.047 | 0.4 | ug/L |
| Ni | 62 | 5493.532 | 0.6 | 499.020 | 8.04546 | 0.091 | 1.1 | ug/L |
| Cu | 63 | 12851.038 | 3.6 | 505.687 | 1.33200 | 0.053 | 4.0 | ug/L |
| Cu | 65 | 5762.383 | 1.2 | 212.672 | 1.23088 | 0.021 | 1.7 | ug/L |
| Zn | 66 | 12207.058 | 1.9 | 1298.448 | 4.10475 | 0.070 | 1.7 | ug/L |
| Zn | 67 | 2931.878 | 1.6 | 302.342 | 5.90371 | 0.158 | 2.7 | ug/L |
| Zn | 68 | 12485.813 | 3.6 | 996.736 | 6.02788 | 0.236 | 3.9 | ug/L |
| > Ge | 72 | 233766.216 | 0.8 | 197196.226 | | | | ug/L |
| As | 75 | 997.403 | 0.9 | 96.335 | 0.30626 | 0.006 | 1.8 | ug/L |
| Se | 77 | 676.694 | 3.3 | 202.002 | 2.04115 | 0.087 | 4.3 | ug/L |
| Se | 78 | 18956.367 | 0.9 | 14431.438 | 2.73027 | 0.465 | 17.0 | mg/L |
| Se | 82 | 1242.826 | 1.0 | 1747.050 | -2.85626 | 0.065 | 2.3 | ug/L |
| Kr | 83 | 735.707 | 6.1 | 1793.211 | | | | mg/L |
| Y | 89 | 490738.440 | 0.8 | 365281.373 | | | | ug/L |
| Mo | 95 | 136002.530 | 0.6 | 120.335 | 24.56822 | 0.395 | 1.6 | ug/L |
| Mo | 97 | 88010.657 | 2.1 | 52.667 | 25.30529 | 0.286 | 1.1 | ug/L |
| Mo | 98 | 221464.893 | 1.2 | 70.498 | 24.65353 | 0.485 | 2.0 | ug/L |
| Rh | 103 | 377603.550 | 0.8 | 350376.944 | | | | ug/L |
| Ag | 107 | 112.335 | 10.1 | 46.001 | 0.00445 | 0.001 | 20.0 | ug/L |
| Ag | 109 | 62.001 | 2.8 | 42.334 | 0.00119 | 0.000 | 14.4 | ug/L |
| Cd | 111 | 1064.330 | 5.1 | 203.876 | 0.25751 | 0.015 | 5.7 | ug/L |
| Cd | 114 | 2056.214 | 4.9 | 55.152 | 0.26489 | 0.013 | 5.0 | ug/L |
| > In | 115 | 397175.310 | 1.0 | 366049.872 | | | | ug/L |
| Sb | 121 | 1359.791 | 3.2 | 54.667 | 0.13040 | 0.004 | 3.1 | ug/L |
| Sb | 123 | 974.215 | 3.3 | 37.221 | 0.12689 | 0.005 | 4.1 | ug/L |
| Ba | 135 | 112690.881 | 2.3 | 52.001 | 48.47326 | 1.043 | 2.2 | ug/L |
| Ba | 137 | 192798.358 | 1.6 | 70.668 | 49.15938 | 0.461 | 0.9 | ug/L |
| > Tb | 159 | 426352.384 | 1.2 | 427712.876 | | | | ug/L |
| > Ho | 165 | 401016.008 | 2.1 | 412683.278 | | | | ug/L |
| Tl | 203 | 267.674 | 1.8 | 51.667 | 0.02825 | 0.001 | 2.1 | ug/L |
| Tl | 205 | 609.695 | 4.7 | 75.334 | 0.03052 | 0.002 | 7.1 | ug/L |
| Pb | 208 | 5421.740 | 1.6 | 440.342 | 0.20233 | 0.007 | 3.3 | ug/L |

Sample ID: 950035

Report Date/Time: Wednesday, November 22, 2006 12:26:55

Page 1

999

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 1381.795 | 2.0 | 119.335 | 0.19746 | 0.003 | 1.6 ug/L |
| | Pb | 207 | 1193.764 | 3.2 | 109.335 | 0.20213 | 0.012 | 5.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 125.534 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 118.545 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 108.503 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 99.682 | | | |
| > Ho | 165 | | 97.173 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950036 D.100

Sample Date/Time: Wednesday, November 22, 2006 12:29:51

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950036 D.100.028

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 114.002 | 6.1 | 49.334 | 0.05074 | 0.010 | 19.8 | ug/L |
| Al | 27 | 985385.305 | 1.5 | 2679.805 | 104.34817 | 4.986 | 4.8 | ug/L |
| > Sc | 45 | 424237.122 | 4.5 | 378193.541 | | | | ug/L |
| V | 51 | 4861.686 | 1.9 | 4537.327 | -0.01384 | 0.014 | 104.0 | ug/L |
| Cr | 52 | 16507.502 | 1.7 | 15100.490 | -0.02934 | 0.049 | 166.4 | ug/L |
| Cr | 53 | 1033.075 | 6.9 | 618.029 | 0.19922 | 0.015 | 7.3 | ug/L |
| Mn | 55 | 3210281.393 | 1.3 | 580.693 | 163.97771 | 6.383 | 3.9 | ug/L |
| Co | 59 | 43898.474 | 2.5 | 202.004 | 2.58197 | 0.028 | 1.1 | ug/L |
| Ni | 60 | 24586.466 | 1.4 | 196.338 | 6.45549 | 0.209 | 3.2 | ug/L |
| Ni | 62 | 4185.426 | 0.5 | 499.020 | 6.18212 | 0.160 | 2.6 | ug/L |
| Cu | 63 | 223440.299 | 2.5 | 505.687 | 25.22449 | 0.536 | 2.1 | ug/L |
| Cu | 65 | 105098.401 | 1.5 | 212.672 | 24.38928 | 0.654 | 2.7 | ug/L |
| Zn | 66 | 40368.299 | 1.9 | 1298.448 | 15.57904 | 0.147 | 0.9 | ug/L |
| Zn | 67 | 6015.898 | 2.7 | 302.342 | 13.54478 | 0.367 | 2.7 | ug/L |
| Zn | 68 | 28329.359 | 1.2 | 996.736 | 15.10525 | 0.617 | 4.1 | ug/L |
| > Ge | 72 | 224580.648 | 2.8 | 197196.226 | | | | ug/L |
| As | 75 | 157.336 | 8.8 | 96.335 | 0.01715 | 0.004 | 23.1 | ug/L |
| Se | 77 | 236.003 | 2.0 | 202.002 | 0.02972 | 0.048 | 160.2 | ug/L |
| Se | 78 | 15842.025 | 1.5 | 14431.438 | -0.89442 | 0.960 | 107.3 | mg/L |
| Se | 82 | 604.089 | 1.3 | 1747.050 | -4.97333 | 0.059 | 1.2 | ug/L |
| Kr | 83 | 576.026 | 0.6 | 1793.211 | | | | mg/L |
| Y | 89 | 458722.653 | 1.2 | 365281.373 | | | | ug/L |
| Mo | 95 | 173.004 | 6.7 | 120.335 | 0.00778 | 0.003 | 34.7 | ug/L |
| Mo | 97 | 63.001 | 15.1 | 52.667 | 0.00170 | 0.002 | 138.8 | ug/L |
| Mo | 98 | 105.013 | 15.0 | 70.498 | 0.00322 | 0.002 | 60.5 | ug/L |
| Rh | 103 | 369408.653 | 0.5 | 350376.944 | | | | ug/L |
| Ag | 107 | 43.001 | 16.8 | 46.001 | -0.00049 | 0.000 | 91.5 | ug/L |
| Ag | 109 | 44.667 | 11.5 | 42.334 | -0.00008 | 0.000 | 554.4 | ug/L |
| Cd | 111 | 598.590 | 1.3 | 203.876 | 0.11578 | 0.005 | 4.5 | ug/L |
| Cd | 114 | 910.515 | 1.1 | 55.152 | 0.11318 | 0.002 | 1.9 | ug/L |
| > In | 115 | 396241.088 | 2.1 | 366049.872 | | | | ug/L |
| Sb | 121 | 91.335 | 3.3 | 54.667 | 0.00324 | 0.000 | 15.0 | ug/L |
| Sb | 123 | 68.900 | 5.1 | 37.221 | 0.00390 | 0.001 | 16.0 | ug/L |
| Ba | 135 | 434.016 | 3.7 | 52.001 | 0.16677 | 0.006 | 3.4 | ug/L |
| Ba | 137 | 692.369 | 5.0 | 70.668 | 0.16079 | 0.007 | 4.3 | ug/L |
| > Tb | 159 | 421106.167 | 1.3 | 427712.876 | | | | ug/L |
| > Ho | 165 | 407280.875 | 2.2 | 412683.278 | | | | ug/L |
| Tl | 203 | 145.669 | 8.2 | 51.667 | 0.01212 | 0.002 | 13.9 | ug/L |
| Tl | 205 | 310.009 | 6.7 | 75.334 | 0.01318 | 0.001 | 7.1 | ug/L |
| Pb | 208 | 1008.033 | 3.4 | 440.342 | 0.02287 | 0.001 | 3.9 | ug/L |

Sample ID: 950036 D.100

Report Date/Time: Wednesday, November 22, 2006 12:32:52

Page 1

1002

| | | | | | | | | |
|--|----|-----|---------|------|---------|---------|-------|-----------|
| | Pb | 206 | 275.007 | 5.6 | 119.335 | 0.02413 | 0.001 | 6.1 ug/L |
| | Pb | 207 | 218.005 | 10.6 | 109.335 | 0.02015 | 0.004 | 21.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 112.175 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 113.887 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 108.248 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.455 | | | |
| > [Ho | 165 | | 98.691 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Wednesday, November 22, 2006 12:35:48

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 3.029

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1239.105 | 4.3 | 49.334 | 1.07281 | 0.040 | 3.7 | ug/L |
| Al | 27 | 98391.483 | 1.3 | 2679.805 | 10.65310 | 0.030 | 0.3 | ug/L |
| Sc | 45 | 403540.694 | 1.1 | 378193.541 | | | | ug/L |
| V | 51 | 21260.928 | 0.9 | 4537.327 | 1.07823 | 0.015 | 1.4 | ug/L |
| Cr | 52 | 30197.259 | 1.8 | 15100.490 | 1.05266 | 0.025 | 2.3 | ug/L |
| Cr | 53 | 2637.110 | 2.4 | 618.029 | 1.22141 | 0.022 | 1.8 | ug/L |
| Mn | 55 | 20484.354 | 1.5 | 580.693 | 1.07234 | 0.014 | 1.3 | ug/L |
| Co | 59 | 17584.049 | 2.4 | 202.004 | 1.08599 | 0.028 | 2.6 | ug/L |
| Ni | 60 | 4073.036 | 1.6 | 196.338 | 1.08168 | 0.019 | 1.8 | ug/L |
| Ni | 62 | 1030.074 | 2.5 | 499.020 | 0.89027 | 0.042 | 4.7 | ug/L |
| Cu | 63 | 9297.276 | 0.2 | 505.687 | 1.04762 | 0.005 | 0.5 | ug/L |
| Cu | 65 | 4468.242 | 1.5 | 212.672 | 1.04247 | 0.014 | 1.3 | ug/L |
| Zn | 66 | 16770.359 | 0.6 | 1298.448 | 6.51230 | 0.057 | 0.9 | ug/L |
| Zn | 67 | 2695.463 | 1.2 | 302.342 | 5.98496 | 0.099 | 1.6 | ug/L |
| Zn | 68 | 12142.628 | 0.6 | 996.736 | 6.49842 | 0.036 | 0.6 | ug/L |
| Ge | 72 | 212331.493 | 0.3 | 197196.226 | | | | ug/L |
| As | 75 | 2882.861 | 1.2 | 96.335 | 1.06086 | 0.013 | 1.2 | ug/L |
| Se | 77 | 424.277 | 1.8 | 202.002 | 1.06283 | 0.034 | 3.2 | ug/L |
| Se | 78 | 16602.840 | 2.2 | 14431.438 | 1.72774 | 0.555 | 32.1 | mg/L |
| Se | 82 | 864.912 | 1.5 | 1747.050 | -3.85881 | 0.047 | 1.2 | ug/L |
| Kr | 83 | 565.358 | 2.8 | 1793.211 | | | | mg/L |
| Y | 89 | 408898.760 | 1.3 | 365281.373 | | | | ug/L |
| Mo | 95 | 6100.628 | 2.9 | 120.335 | 1.10662 | 0.034 | 3.0 | ug/L |
| Mo | 97 | 3836.922 | 2.1 | 52.667 | 1.11483 | 0.025 | 2.2 | ug/L |
| Mo | 98 | 9435.782 | 0.8 | 70.498 | 1.06805 | 0.009 | 0.8 | ug/L |
| Rh | 103 | 368153.193 | 0.5 | 350376.944 | | | | ug/L |
| Ag | 107 | 15573.028 | 1.3 | 46.001 | 1.13150 | 0.014 | 1.3 | ug/L |
| Ag | 109 | 14213.922 | 1.5 | 42.334 | 1.07768 | 0.014 | 1.3 | ug/L |
| Cd | 111 | 3756.558 | 2.6 | 203.876 | 1.10835 | 0.032 | 2.9 | ug/L |
| Cd | 114 | 7784.324 | 3.2 | 55.152 | 1.05041 | 0.033 | 3.2 | ug/L |
| In | 115 | 387609.537 | 0.2 | 366049.872 | | | | ug/L |
| Sb | 121 | 10100.555 | 2.7 | 54.667 | 1.03188 | 0.029 | 2.9 | ug/L |
| Sb | 123 | 7593.776 | 1.8 | 37.221 | 1.05159 | 0.018 | 1.8 | ug/L |
| Ba | 135 | 2441.382 | 1.4 | 52.001 | 1.04547 | 0.020 | 1.9 | ug/L |
| Ba | 137 | 4291.814 | 0.1 | 70.668 | 1.09461 | 0.005 | 0.4 | ug/L |
| Tb | 159 | 419517.360 | 0.5 | 427712.876 | | | | ug/L |
| Ho | 165 | 400424.125 | 1.8 | 412683.278 | | | | ug/L |
| Tl | 203 | 8562.486 | 3.6 | 51.667 | 1.10776 | 0.059 | 5.3 | ug/L |
| Tl | 205 | 19828.770 | 2.5 | 75.334 | 1.12483 | 0.033 | 2.9 | ug/L |
| Pb | 208 | 26893.745 | 0.5 | 440.342 | 1.07377 | 0.024 | 2.3 | ug/L |

| | | | | | | | | |
|---|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 6913.936 | 0.2 | 119.335 | 1.06217 | 0.022 | 2.1 ug/L |
| L | Pb | 207 | 5931.503 | 1.7 | 109.335 | 1.08389 | 0.039 | 3.6 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 107.281 | | | | |
| Al | 27 | 106.531 | | | | |
| > Sc | 45 | | 106.702 | | | |
| V | 51 | 107.823 | | | | |
| Cr | 52 | 105.266 | | | | |
| Cr | 53 | 122.141 | | | | |
| Mn | 55 | 107.234 | | | | |
| Co | 59 | 108.599 | | | | |
| Ni | 60 | 108.168 | | | | |
| Ni | 62 | 89.027 | | | | |
| Cu | 63 | 104.762 | | | | |
| Cu | 65 | 104.247 | | | | |
| Zn | 66 | 130.246 | | | | |
| Zn | 67 | 119.699 | | | | |
| Zn | 68 | 129.968 | | | | |
| > Ge | 72 | | 107.675 | | | |
| As | 75 | 106.086 | | | | |
| Se | 77 | 106.283 | | | | |
| Se | 78 | 172.774 | | | | |
| Se | 82 | -385.881 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 110.662 | | | | |
| Mo | 97 | 111.483 | | | | |
| Mo | 98 | 106.805 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 113.150 | | | | |
| Ag | 109 | 107.768 | | | | |
| Cd | 111 | 110.835 | | | | |
| Cd | 114 | 105.041 | | | | |
| > In | 115 | | 105.890 | | | |
| Sb | 121 | 103.188 | | | | |
| Sb | 123 | 105.159 | | | | |
| Ba | 135 | 104.547 | | | | |
| Ba | 137 | 109.461 | | | | |
| > Tb | 159 | | 98.084 | | | |
| > Ho | 165 | | 97.029 | | | |
| Tl | 203 | 110.776 | | | | |
| Tl | 205 | 112.483 | | | | |
| Pb | 208 | 107.377 | | | | |
| Pb | 206 | 106.217 | | | | |
| Pb | 207 | 108.389 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: HLCCV2

Sample Date/Time: Wednesday, November 22, 2006 12:41:45

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\HLCCV2.030

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 231373.873 | 1.6 | 49.334 | 204.71230 | 6.969 | 3.4 | ug/L |
| Al | 27 | 1749318.959 | 1.7 | 2679.805 | 190.67577 | 10.030 | 5.3 | ug/L |
| > Sc | 45 | 412844.149 | 5.0 | 378193.541 | | | | ug/L |
| V | 51 | 3818218.884 | 1.0 | 4537.327 | 245.12576 | 11.580 | 4.7 | ug/L |
| Cr | 52 | 3214943.805 | 1.8 | 15100.490 | 234.03982 | 11.906 | 5.1 | ug/L |
| Cr | 53 | 328491.099 | 3.6 | 618.029 | 198.02873 | 4.097 | 2.1 | ug/L |
| Mn | 55 | 4446847.708 | 1.1 | 580.693 | 244.43302 | 6.701 | 2.7 | ug/L |
| Co | 59 | 3826570.994 | 0.4 | 202.004 | 243.58975 | 5.561 | 2.3 | ug/L |
| Ni | 60 | 692498.498 | 1.7 | 196.338 | 197.40251 | 4.772 | 2.4 | ug/L |
| Ni | 62 | 108140.659 | 1.5 | 499.020 | 197.98433 | 6.982 | 3.5 | ug/L |
| Cu | 63 | 1546801.898 | 1.8 | 505.687 | 188.41328 | 5.508 | 2.9 | ug/L |
| Cu | 65 | 734316.278 | 0.6 | 212.672 | 183.78681 | 4.584 | 2.5 | ug/L |
| Zn | 66 | 445736.227 | 0.5 | 1298.448 | 191.63300 | 3.510 | 1.8 | ug/L |
| Zn | 67 | 78013.010 | 2.1 | 302.342 | 199.73473 | 5.819 | 2.9 | ug/L |
| Zn | 68 | 330507.364 | 1.1 | 996.736 | 196.91296 | 5.580 | 2.8 | ug/L |
| > Ge | 72 | 208629.692 | 2.0 | 197196.226 | | | | ug/L |
| As | 75 | 518053.887 | 4.2 | 96.335 | 201.21317 | 7.123 | 3.5 | ug/L |
| Se | 77 | 40182.717 | 0.8 | 202.002 | 209.13630 | 2.796 | 1.3 | ug/L |
| Se | 78 | 142604.498 | 0.8 | 14431.438 | 210.59361 | 4.549 | 2.2 | mg/L |
| Se | 82 | 56230.276 | 0.5 | 1747.050 | 210.21314 | 3.949 | 1.9 | ug/L |
| Kr | 83 | 493.353 | 20.8 | 1793.211 | | | | mg/L |
| Y | 89 | 410403.642 | 0.7 | 365281.373 | | | | ug/L |
| Mo | 95 | 1107301.970 | 2.1 | 120.335 | 209.21809 | 3.158 | 1.5 | ug/L |
| Mo | 97 | 708060.907 | 2.0 | 52.667 | 212.93137 | 4.059 | 1.9 | ug/L |
| Mo | 98 | 1786098.612 | 0.3 | 70.498 | 207.86449 | 0.696 | 0.3 | ug/L |
| Rh | 103 | 351855.840 | 0.6 | 350376.944 | | | | ug/L |
| Ag | 107 | 3397421.136 | 0.3 | 46.001 | 252.58949 | 1.152 | 0.5 | ug/L |
| Ag | 109 | 3304387.790 | 2.2 | 42.334 | 256.35382 | 4.493 | 1.8 | ug/L |
| Cd | 111 | 628003.803 | 3.9 | 203.876 | 200.42954 | 6.718 | 3.4 | ug/L |
| Cd | 114 | 1414634.242 | 1.6 | 55.152 | 196.17582 | 2.009 | 1.0 | ug/L |
| > In | 115 | 379989.132 | 0.6 | 366049.872 | | | | ug/L |
| Sb | 121 | 1847853.841 | 0.5 | 54.667 | 193.67236 | 2.231 | 1.2 | ug/L |
| Sb | 123 | 1367653.297 | 0.7 | 37.221 | 194.19535 | 1.122 | 0.6 | ug/L |
| Ba | 135 | 450358.987 | 1.2 | 52.001 | 204.35966 | 3.128 | 1.5 | ug/L |
| Ba | 137 | 744347.446 | 2.3 | 70.668 | 200.17184 | 1.328 | 0.7 | ug/L |
| > Tb | 159 | 404350.449 | 2.1 | 427712.876 | | | | ug/L |
| > Ho | 165 | 391529.291 | 2.0 | 412683.278 | | | | ug/L |
| Tl | 203 | 1433882.115 | 2.6 | 51.667 | 190.70525 | 1.894 | 1.0 | ug/L |
| Tl | 205 | 4564878.448 | 1.7 | 75.334 | 265.87880 | 9.292 | 3.5 | ug/L |
| Pb | 208 | 5498505.591 | 0.5 | 440.342 | 228.13527 | 5.138 | 2.3 | ug/L |

Sample ID: HLCCV2

Report Date/Time: Wednesday, November 22, 2006 12:44:46

Page 1

1008

| | | | | | | | | |
|--|----|-----|-------------|-----|---------|-----------|-------|----------|
| | Pb | 206 | 1235357.975 | 3.2 | 119.335 | 197.30528 | 2.739 | 1.4 ug/L |
| | Pb | 207 | 1018817.056 | 0.3 | 109.335 | 193.81170 | 3.317 | 1.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 109.162 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 105.798 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 103.808 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 94.538 | | | |
| > [Ho | 165 | | 94.874 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Wednesday, November 22, 2006 12:47:42

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 3.031

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1203.766 | 2.1 | 49.334 | 1.01790 | 0.029 | 2.8 | ug/L |
| Al | 27 | 96225.714 | 1.2 | 2679.805 | 10.18427 | 0.247 | 2.4 | ug/L |
| > Sc | 45 | 412377.106 | 1.7 | 378193.541 | | | | ug/L |
| V | 51 | 21348.585 | 0.9 | 4537.327 | 1.05422 | 0.032 | 3.0 | ug/L |
| Cr | 52 | 30459.547 | 1.7 | 15100.490 | 1.02429 | 0.071 | 7.0 | ug/L |
| Cr | 53 | 2524.741 | 1.8 | 618.029 | 1.11878 | 0.017 | 1.5 | ug/L |
| Mn | 55 | 20770.061 | 1.0 | 580.693 | 1.08415 | 0.026 | 2.4 | ug/L |
| Co | 59 | 17360.905 | 0.1 | 202.004 | 1.06855 | 0.026 | 2.5 | ug/L |
| Ni | 60 | 3934.968 | 2.0 | 196.338 | 1.03984 | 0.049 | 4.7 | ug/L |
| Ni | 62 | 1055.411 | 1.5 | 499.020 | 0.92972 | 0.034 | 3.7 | ug/L |
| Cu | 63 | 8916.525 | 2.3 | 505.687 | 0.99833 | 0.018 | 1.8 | ug/L |
| Cu | 65 | 4222.779 | 3.4 | 212.672 | 0.97937 | 0.060 | 6.1 | ug/L |
| Zn | 66 | 16459.739 | 1.2 | 1298.448 | 6.35873 | 0.208 | 3.3 | ug/L |
| Zn | 67 | 2569.088 | 0.9 | 302.342 | 5.64589 | 0.217 | 3.8 | ug/L |
| Zn | 68 | 11568.479 | 3.3 | 996.736 | 6.13754 | 0.185 | 3.0 | ug/L |
| > Ge | 72 | 213096.009 | 2.4 | 197196.226 | | | | ug/L |
| As | 75 | 2860.853 | 1.2 | 96.335 | 1.04882 | 0.018 | 1.7 | ug/L |
| Se | 77 | 434.878 | 2.6 | 202.002 | 1.11118 | 0.113 | 10.2 | ug/L |
| Se | 78 | 16164.558 | 1.4 | 14431.438 | 0.93562 | 0.896 | 95.7 | mg/L |
| Se | 82 | 686.295 | 2.5 | 1747.050 | -4.54642 | 0.006 | 0.1 | ug/L |
| Kr | 83 | 359.678 | 9.9 | 1793.211 | | | | mg/L |
| Y | 89 | 416663.093 | 1.7 | 365281.373 | | | | ug/L |
| Mo | 95 | 7163.825 | 6.6 | 120.335 | 1.29413 | 0.081 | 6.3 | ug/L |
| Mo | 97 | 4512.935 | 3.7 | 52.667 | 1.30477 | 0.044 | 3.4 | ug/L |
| Mo | 98 | 12126.007 | 5.2 | 70.498 | 1.36519 | 0.066 | 4.9 | ug/L |
| Rh | 103 | 360177.637 | 0.4 | 350376.944 | | | | ug/L |
| Ag | 107 | 14898.123 | 1.4 | 46.001 | 1.07478 | 0.016 | 1.5 | ug/L |
| Ag | 109 | 14318.440 | 2.8 | 42.334 | 1.07809 | 0.031 | 2.9 | ug/L |
| Cd | 111 | 3487.143 | 1.9 | 203.876 | 1.01646 | 0.025 | 2.4 | ug/L |
| Cd | 114 | 7679.400 | 1.9 | 55.152 | 1.02884 | 0.014 | 1.4 | ug/L |
| > In | 115 | 390324.710 | 0.5 | 366049.872 | | | | ug/L |
| Sb | 121 | 12166.332 | 1.8 | 54.667 | 1.23542 | 0.022 | 1.8 | ug/L |
| Sb | 123 | 8823.590 | 3.5 | 37.221 | 1.21418 | 0.040 | 3.3 | ug/L |
| Ba | 135 | 2497.066 | 3.2 | 52.001 | 1.09405 | 0.035 | 3.2 | ug/L |
| Ba | 137 | 4237.786 | 1.7 | 70.668 | 1.10500 | 0.013 | 1.2 | ug/L |
| > Tb | 159 | 410385.541 | 0.8 | 427712.876 | | | | ug/L |
| > Ho | 165 | 402956.516 | 2.0 | 412683.278 | | | | ug/L |
| Tl | 203 | 8159.742 | 1.8 | 51.667 | 1.04810 | 0.005 | 0.5 | ug/L |
| Tl | 205 | 19601.223 | 1.2 | 75.334 | 1.10492 | 0.024 | 2.2 | ug/L |
| Pb | 208 | 26862.227 | 0.8 | 440.342 | 1.06566 | 0.024 | 2.3 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Wednesday, November 22, 2006 12:50:42

Page 1

1011

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 6877.907 | 2.5 | 119.335 | 1.04979 | 0.033 | 3.1 ug/L |
| | Pb | 207 | 5760.382 | 2.4 | 109.335 | 1.04508 | 0.029 | 2.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 101.790 | | | | |
| Al | 27 | 101.843 | | | | |
| > Sc | 45 | | 109.039 | | | |
| V | 51 | 105.422 | | | | |
| Cr | 52 | 102.429 | | | | |
| Cr | 53 | 111.878 | | | | |
| Mn | 55 | 108.415 | | | | |
| Co | 59 | 106.855 | | | | |
| Ni | 60 | 103.984 | | | | |
| Ni | 62 | 92.972 | | | | |
| Cu | 63 | 99.833 | | | | |
| Cu | 65 | 97.937 | | | | |
| Zn | 66 | 127.175 | | | | |
| Zn | 67 | 112.918 | | | | |
| Zn | 68 | 122.751 | | | | |
| > Ge | 72 | | 108.063 | | | |
| As | 75 | 104.882 | | | | |
| Se | 77 | 111.118 | | | | |
| Se | 78 | 93.562 | | | | |
| Se | 82 | -454.642 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 129.413 | | | | |
| Mo | 97 | 130.477 | | | | |
| Mo | 98 | 136.519 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 107.478 | | | | |
| Ag | 109 | 107.809 | | | | |
| Cd | 111 | 101.646 | | | | |
| Cd | 114 | 102.884 | | | | |
| > In | 115 | | 106.632 | | | |
| Sb | 121 | 123.542 | | | | |
| Sb | 123 | 121.418 | | | | |
| Ba | 135 | 109.405 | | | | |
| Ba | 137 | 110.500 | | | | |
| > Tb | 159 | | 95.949 | | | |
| > Ho | 165 | | 97.643 | | | |
| Tl | 203 | 104.810 | | | | |
| Tl | 205 | 110.492 | | | | |
| Pb | 208 | 106.566 | | | | |
| Pb | 206 | 104.979 | | | | |
| Pb | 207 | 104.508 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Wednesday, November 22, 2006 12:53:39

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 6.032

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54885.060 | 1.6 | 49.334 | 50.42748 | 1.182 | 2.3 | ug/L |
| Al | 27 | 457111.032 | 0.5 | 2679.805 | 51.54094 | 2.102 | 4.1 | ug/L |
| > Sc | 45 | 397049.418 | 3.7 | 378193.541 | | | | ug/L |
| V | 51 | 785806.961 | 3.3 | 4537.327 | 52.13855 | 1.208 | 2.3 | ug/L |
| Cr | 52 | 682653.140 | 1.8 | 15100.490 | 50.70193 | 2.226 | 4.4 | ug/L |
| Cr | 53 | 79281.829 | 1.0 | 618.029 | 49.40635 | 1.775 | 3.6 | ug/L |
| Mn | 55 | 935775.832 | 1.9 | 580.693 | 52.54231 | 1.591 | 3.0 | ug/L |
| Co | 59 | 784989.651 | 3.2 | 202.004 | 51.03667 | 0.705 | 1.4 | ug/L |
| Ni | 60 | 174891.716 | 1.1 | 196.338 | 50.95258 | 2.828 | 5.6 | ug/L |
| Ni | 62 | 27024.708 | 2.8 | 499.020 | 49.82503 | 1.339 | 2.7 | ug/L |
| Cu | 63 | 411230.011 | 0.8 | 505.687 | 51.16959 | 2.269 | 4.4 | ug/L |
| Cu | 65 | 200602.038 | 2.0 | 212.672 | 51.29609 | 2.505 | 4.9 | ug/L |
| Zn | 66 | 113273.928 | 4.0 | 1298.448 | 49.30331 | 0.591 | 1.2 | ug/L |
| Zn | 67 | 19465.241 | 2.0 | 302.342 | 50.32186 | 1.523 | 3.0 | ug/L |
| Zn | 68 | 82493.159 | 1.2 | 996.736 | 49.76879 | 1.823 | 3.7 | ug/L |
| > Ge | 72 | 204249.403 | 4.5 | 197196.226 | | | | ug/L |
| As | 75 | 129040.863 | 2.8 | 96.335 | 51.21699 | 2.025 | 4.0 | ug/L |
| Se | 77 | 9988.984 | 1.3 | 202.002 | 52.31601 | 1.874 | 3.6 | ug/L |
| Se | 78 | 46003.050 | 1.9 | 14431.438 | 52.51681 | 2.422 | 4.6 | mg/L |
| Se | 82 | 13931.106 | 2.4 | 1747.050 | 47.90486 | 2.183 | 4.6 | ug/L |
| Kr | 83 | 365.345 | 4.9 | 1793.211 | | | | mg/L |
| Y | 89 | 407080.054 | 2.2 | 365281.373 | | | | ug/L |
| Mo | 95 | 279921.486 | 1.1 | 120.335 | 52.92098 | 0.783 | 1.5 | ug/L |
| Mo | 97 | 178357.462 | 2.7 | 52.667 | 53.69735 | 2.598 | 4.8 | ug/L |
| Mo | 98 | 458163.886 | 1.9 | 70.498 | 53.35871 | 1.072 | 2.0 | ug/L |
| Rh | 103 | 349244.474 | 0.8 | 350376.944 | | | | ug/L |
| Ag | 107 | 686502.891 | 1.7 | 46.001 | 51.07479 | 0.386 | 0.8 | ug/L |
| Ag | 109 | 658002.916 | 4.0 | 42.334 | 51.06873 | 0.936 | 1.8 | ug/L |
| Cd | 111 | 159238.638 | 1.2 | 203.876 | 50.83315 | 1.524 | 3.0 | ug/L |
| Cd | 114 | 368666.947 | 1.5 | 55.152 | 51.16160 | 0.495 | 1.0 | ug/L |
| > In | 115 | 379744.377 | 2.4 | 366049.872 | | | | ug/L |
| Sb | 121 | 470841.738 | 0.3 | 54.667 | 49.39093 | 1.087 | 2.2 | ug/L |
| Sb | 123 | 347209.947 | 1.2 | 37.221 | 49.33969 | 0.817 | 1.7 | ug/L |
| Ba | 135 | 114372.260 | 2.3 | 52.001 | 51.25517 | 0.975 | 1.9 | ug/L |
| Ba | 137 | 195036.869 | 1.5 | 70.668 | 51.82200 | 1.245 | 2.4 | ug/L |
| > Tb | 159 | 409211.681 | 0.9 | 427712.876 | | | | ug/L |
| > Ho | 165 | 389059.272 | 2.4 | 412683.278 | | | | ug/L |
| Tl | 203 | 379286.762 | 1.5 | 51.667 | 50.78726 | 1.636 | 3.2 | ug/L |
| Tl | 205 | 901215.217 | 1.4 | 75.334 | 52.81119 | 1.064 | 2.0 | ug/L |
| Pb | 208 | 1225955.449 | 1.5 | 440.342 | 51.17554 | 1.190 | 2.3 | ug/L |

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 312629.911 | 1.6 | 119.335 | 50.26558 | 1.585 | 3.2 ug/L |
| | Pb | 207 | 262149.403 | 0.1 | 109.335 | 50.17934 | 1.205 | 2.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 100.855 | | | | |
| Al | 27 | 103.082 | | | | |
| > Sc | 45 | | 104.986 | | | |
| V | 51 | 104.277 | | | | |
| Cr | 52 | 101.404 | | | | |
| Cr | 53 | 98.813 | | | | |
| Mn | 55 | 105.085 | | | | |
| Co | 59 | 102.073 | | | | |
| Ni | 60 | 101.905 | | | | |
| Ni | 62 | 99.650 | | | | |
| Cu | 63 | 102.339 | | | | |
| Cu | 65 | 102.592 | | | | |
| Zn | 66 | 98.607 | | | | |
| Zn | 67 | 100.644 | | | | |
| Zn | 68 | 99.538 | | | | |
| > Ge | 72 | | 103.577 | | | |
| As | 75 | 102.434 | | | | |
| Se | 77 | 104.632 | | | | |
| Se | 78 | 105.034 | | | | |
| Se | 82 | 95.810 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 105.842 | | | | |
| Mo | 97 | 107.395 | | | | |
| Mo | 98 | 106.717 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 102.150 | | | | |
| Ag | 109 | 102.137 | | | | |
| Cd | 111 | 101.666 | | | | |
| Cd | 114 | 102.323 | | | | |
| > In | 115 | | 103.741 | | | |
| Sb | 121 | 98.782 | | | | |
| Sb | 123 | 98.679 | | | | |
| Ba | 135 | 102.510 | | | | |
| Ba | 137 | 103.644 | | | | |
| > Tb | 159 | | 95.674 | | | |
| > Ho | 165 | | 94.276 | | | |
| Tl | 203 | 101.575 | | | | |
| Tl | 205 | 105.622 | | | | |
| Pb | 208 | 102.351 | | | | |
| Pb | 206 | 100.531 | | | | |
| Pb | 207 | 100.359 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Wednesday, November 22, 2006 12:59:37

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 7.033

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55.001 | 13.7 | 49.334 | 0.00217 | 0.007 | 339.9 | ug/L |
| Al | 27 | 2536.745 | 0.7 | 2679.805 | -0.03604 | 0.003 | 8.5 | ug/L |
| > Sc | 45 | 403663.600 | 1.4 | 378193.541 | | | | ug/L |
| V | 51 | 4723.583 | 1.5 | 4537.327 | -0.00783 | 0.002 | 21.8 | ug/L |
| Cr | 52 | 15883.950 | 1.1 | 15100.490 | -0.01733 | 0.018 | 105.0 | ug/L |
| Cr | 53 | 706.370 | 3.7 | 618.029 | 0.02891 | 0.017 | 60.1 | ug/L |
| Mn | 55 | 581.359 | 4.3 | 580.693 | -0.00116 | 0.002 | 155.8 | ug/L |
| Co | 59 | 185.337 | 8.9 | 202.004 | -0.00156 | 0.001 | 79.9 | ug/L |
| Ni | 60 | 170.670 | 3.9 | 196.338 | -0.00956 | 0.003 | 27.9 | ug/L |
| Ni | 62 | 480.352 | 3.9 | 499.020 | -0.06944 | 0.046 | 66.6 | ug/L |
| Cu | 63 | 450.683 | 3.1 | 505.687 | -0.00918 | 0.001 | 15.1 | ug/L |
| Cu | 65 | 185.337 | 7.6 | 212.672 | -0.00903 | 0.003 | 31.5 | ug/L |
| Zn | 66 | 1285.112 | 4.7 | 1298.448 | -0.02703 | 0.029 | 105.6 | ug/L |
| Zn | 67 | 287.675 | 4.1 | 302.342 | -0.06810 | 0.022 | 32.5 | ug/L |
| Zn | 68 | 960.732 | 4.1 | 996.736 | -0.04423 | 0.033 | 74.0 | ug/L |
| > Ge | 72 | 204539.147 | 1.5 | 197196.226 | | | | ug/L |
| As | 75 | 132.002 | 20.4 | 96.335 | 0.01279 | 0.011 | 87.7 | ug/L |
| Se | 77 | 226.536 | 4.6 | 202.002 | 0.09145 | 0.071 | 77.8 | ug/L |
| Se | 78 | 15097.852 | 2.2 | 14431.438 | 0.22729 | 0.943 | 415.0 | mg/L |
| Se | 82 | 383.476 | 6.9 | 1747.050 | -5.63113 | 0.109 | 1.9 | ug/L |
| Kr | 83 | 371.679 | 6.0 | 1793.211 | | | | mg/L |
| Y | 89 | 391170.478 | 2.3 | 365281.373 | | | | ug/L |
| Mo | 95 | 753.709 | 22.7 | 120.335 | 0.11242 | 0.029 | 26.0 | ug/L |
| Mo | 97 | 440.683 | 20.8 | 52.667 | 0.11016 | 0.025 | 22.3 | ug/L |
| Mo | 98 | 1082.578 | 16.0 | 70.498 | 0.11188 | 0.018 | 15.7 | ug/L |
| Rh | 103 | 357808.064 | 2.1 | 350376.944 | | | | ug/L |
| Ag | 107 | 150.670 | 15.3 | 46.001 | 0.00717 | 0.002 | 23.3 | ug/L |
| Ag | 109 | 141.669 | 8.8 | 42.334 | 0.00711 | 0.001 | 14.0 | ug/L |
| Cd | 111 | 226.957 | 5.2 | 203.876 | 0.00179 | 0.004 | 232.5 | ug/L |
| Cd | 114 | 57.372 | 8.7 | 55.152 | -0.00033 | 0.001 | 189.0 | ug/L |
| > In | 115 | 397120.402 | 1.4 | 366049.872 | | | | ug/L |
| Sb | 121 | 1322.785 | 8.4 | 54.667 | 0.12662 | 0.009 | 7.4 | ug/L |
| Sb | 123 | 998.091 | 10.1 | 37.221 | 0.13001 | 0.012 | 9.1 | ug/L |
| Ba | 135 | 40.000 | 18.9 | 52.001 | -0.00444 | 0.003 | 78.8 | ug/L |
| Ba | 137 | 53.334 | 15.6 | 70.668 | -0.00385 | 0.002 | 58.2 | ug/L |
| > Tb | 159 | 411066.157 | 1.0 | 427712.876 | | | | ug/L |
| > Ho | 165 | 404258.400 | 1.2 | 412683.278 | | | | ug/L |
| Tl | 203 | 68.001 | 5.1 | 51.667 | 0.00224 | 0.000 | 16.5 | ug/L |
| Tl | 205 | 123.335 | 6.6 | 75.334 | 0.00279 | 0.000 | 15.0 | ug/L |
| Pb | 208 | 343.339 | 6.6 | 440.342 | -0.00354 | 0.001 | 21.6 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Wednesday, November 22, 2006 13:02:37

Page 1

1017

| | | | | | | | | |
|--|----|-----|--------|-----|---------|----------|-------|-----------|
| | Pb | 206 | 87.668 | 9.2 | 119.335 | -0.00452 | 0.001 | 27.0 ug/L |
| | Pb | 207 | 89.001 | 8.1 | 109.335 | -0.00333 | 0.001 | 40.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 106.735 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 103.724 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 108.488 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 96.108 | | | |
| > [Ho | 165 | | 97.959 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: CCV

Sample Date/Time: Wednesday, November 22, 2006 13:29:46

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\CCV.034

MGT needed

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 51634.768 | 3.3 | 49.334 | 48.85640 | 0.490 | 1.0 | ug/L |
| Al | 27 | 451982.003 | 2.2 | 2679.805 | 52.49399 | 1.731 | 3.3 | ug/L |
| > Sc | 45 | 385408.067 | 4.0 | 378193.541 | | | | ug/L |
| V | 51 | 761492.039 | 2.6 | 4537.327 | 52.05621 | 0.748 | 1.4 | ug/L |
| Cr | 52 | 662663.131 | 1.3 | 15100.490 | 50.69927 | 1.766 | 3.5 | ug/L |
| Cr | 53 | 78951.291 | 3.3 | 618.029 | 50.67585 | 1.435 | 2.8 | ug/L |
| Mn | 55 | 882682.881 | 0.6 | 580.693 | 50.68429 | 1.084 | 2.1 | ug/L |
| Co | 59 | 759780.780 | 2.0 | 202.004 | 50.53028 | 0.589 | 1.2 | ug/L |
| Ni | 60 | 173071.485 | 4.2 | 196.338 | 51.51265 | 1.894 | 3.7 | ug/L |
| Ni | 62 | 26232.486 | 0.4 | 499.020 | 49.46365 | 0.924 | 1.9 | ug/L |
| Cu | 63 | 405029.445 | 2.4 | 505.687 | 51.52292 | 1.803 | 3.5 | ug/L |
| Cu | 65 | 197368.145 | 2.0 | 212.672 | 51.57955 | 0.812 | 1.6 | ug/L |
| Zn | 66 | 109987.922 | 3.0 | 1298.448 | 48.96873 | 0.512 | 1.0 | ug/L |
| Zn | 67 | 18597.961 | 5.7 | 302.342 | 49.13078 | 2.396 | 4.9 | ug/L |
| Zn | 68 | 80433.847 | 1.6 | 996.736 | 49.60473 | 0.303 | 0.6 | ug/L |
| > Ge | 72 | 199601.828 | 2.1 | 197196.226 | | | | ug/L |
| As | 75 | 124492.805 | 3.8 | 96.335 | 50.51269 | 1.556 | 3.1 | ug/L |
| Se | 77 | 9626.024 | 1.5 | 202.002 | 51.52786 | 0.863 | 1.7 | ug/L |
| Se | 78 | 45199.504 | 4.8 | 14431.438 | 52.84376 | 2.344 | 4.4 | mg/L |
| Se | 82 | 13247.991 | 1.7 | 1747.050 | 46.37315 | 0.208 | 0.4 | ug/L |
| Kr | 83 | 320.676 | 11.0 | 1793.211 | | | | mg/L |
| Y | 89 | 379406.222 | 3.9 | 365281.373 | | | | ug/L |
| Mo | 95 | 270879.586 | 0.6 | 120.335 | 52.22220 | 0.585 | 1.1 | ug/L |
| Mo | 97 | 173130.819 | 2.6 | 52.667 | 53.13194 | 1.773 | 3.3 | ug/L |
| Mo | 98 | 451014.451 | 3.6 | 70.498 | 53.56881 | 2.165 | 4.0 | ug/L |
| Rh | 103 | 356364.604 | 1.1 | 350376.944 | | | | ug/L |
| Ag | 107 | 686307.940 | 4.1 | 46.001 | 52.08321 | 2.489 | 4.8 | ug/L |
| Ag | 109 | 654838.390 | 0.6 | 42.334 | 51.85027 | 0.609 | 1.2 | ug/L |
| Cd | 111 | 158802.755 | 3.0 | 203.876 | 51.69001 | 1.863 | 3.6 | ug/L |
| Cd | 114 | 365730.979 | 0.7 | 55.152 | 51.75823 | 0.264 | 0.5 | ug/L |
| > In | 115 | 372326.307 | 0.7 | 366049.872 | | | | ug/L |
| Sb | 121 | 471816.709 | 1.6 | 54.667 | 50.46259 | 0.815 | 1.6 | ug/L |
| Sb | 123 | 347763.578 | 1.2 | 37.221 | 50.39530 | 0.928 | 1.8 | ug/L |
| Ba | 135 | 117501.500 | 1.1 | 52.001 | 52.42343 | 1.009 | 1.9 | ug/L |
| Ba | 137 | 194223.931 | 0.5 | 70.668 | 51.36600 | 0.780 | 1.5 | ug/L |
| > Tb | 159 | 411108.788 | 1.2 | 427712.876 | | | | ug/L |
| > Ho | 165 | 397343.449 | 1.2 | 412683.278 | | | | ug/L |
| Tl | 203 | 388534.641 | 1.3 | 51.667 | 50.92355 | 0.983 | 1.9 | ug/L |
| Tl | 205 | 910464.629 | 2.0 | 75.334 | 52.22761 | 0.877 | 1.7 | ug/L |
| Pb | 208 | 1237941.863 | 0.5 | 440.342 | 50.58638 | 0.410 | 0.8 | ug/L |

| | | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|-----|------|
| | Pb | 206 | 319239.907 | 2.6 | 119.335 | 50.23455 | 1.046 | 2.1 | ug/L |
| | Pb | 207 | 265925.667 | 1.2 | 109.335 | 49.82945 | 1.062 | 2.1 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 101.908 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 101.220 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 101.715 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 96.118 | | | |
| > [Ho | 165 | | 96.283 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: CCB

Sample Date/Time: Wednesday, November 22, 2006 13:35:43

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\CCB.035

Not needed

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 50.001 | 10.4 | 49.334 | -0.00064 | 0.004 | 590.0 | ug/L |
| Al | 27 | 2587.761 | 0.4 | 2679.805 | -0.01862 | 0.008 | 43.4 | ug/L |
| Sc | 45 | 388018.799 | 2.3 | 378193.541 | | | | ug/L |
| V | 51 | 4996.755 | 6.3 | 4537.327 | 0.02313 | 0.014 | 61.8 | ug/L |
| Cr | 52 | 16407.659 | 4.8 | 15100.490 | 0.07063 | 0.031 | 44.1 | ug/L |
| Cr | 53 | 776.711 | 6.2 | 618.029 | 0.09141 | 0.023 | 25.1 | ug/L |
| Mn | 55 | 809.381 | 3.9 | 580.693 | 0.01241 | 0.002 | 17.8 | ug/L |
| Co | 59 | 285.341 | 5.1 | 202.004 | 0.00524 | 0.001 | 18.4 | ug/L |
| Ni | 60 | 163.337 | 4.4 | 196.338 | -0.01088 | 0.003 | 23.7 | ug/L |
| Ni | 62 | 460.017 | 3.8 | 499.020 | -0.09320 | 0.025 | 26.9 | ug/L |
| Cu | 63 | 419.348 | 8.6 | 505.687 | -0.01219 | 0.004 | 33.5 | ug/L |
| Cu | 65 | 193.004 | 12.8 | 212.672 | -0.00614 | 0.007 | 111.8 | ug/L |
| Zn | 66 | 1247.439 | 3.6 | 1298.448 | -0.03418 | 0.019 | 57.0 | ug/L |
| Zn | 67 | 279.341 | 13.1 | 302.342 | -0.07712 | 0.098 | 126.5 | ug/L |
| Zn | 68 | 939.396 | 0.3 | 996.736 | -0.04759 | 0.007 | 14.3 | ug/L |
| Ge | 72 | 201051.860 | 0.9 | 197196.226 | | | | ug/L |
| As | 75 | 119.335 | 3.8 | 96.335 | 0.00852 | 0.002 | 25.0 | ug/L |
| Se | 77 | 231.470 | 2.3 | 202.002 | 0.13871 | 0.037 | 26.8 | ug/L |
| Se | 78 | 14764.859 | 2.8 | 14431.438 | 0.08530 | 0.507 | 594.8 | mg/L |
| Se | 82 | 338.207 | 3.0 | 1747.050 | -5.78645 | 0.052 | 0.9 | ug/L |
| Kr | 83 | 297.008 | 5.3 | 1793.211 | | | | mg/L |
| Y | 89 | 384007.952 | 2.2 | 365281.373 | | | | ug/L |
| Mo | 95 | 643.698 | 15.0 | 120.335 | 0.09989 | 0.020 | 19.6 | ug/L |
| Mo | 97 | 392.680 | 18.6 | 52.667 | 0.10356 | 0.024 | 23.3 | ug/L |
| Mo | 98 | 921.634 | 18.8 | 70.498 | 0.10051 | 0.022 | 22.3 | ug/L |
| Rh | 103 | 359120.480 | 3.3 | 350376.944 | | | | ug/L |
| Ag | 107 | 153.336 | 12.1 | 46.001 | 0.00802 | 0.001 | 18.4 | ug/L |
| Ag | 109 | 131.336 | 3.1 | 42.334 | 0.00693 | 0.000 | 7.2 | ug/L |
| Cd | 111 | 232.980 | 4.8 | 203.876 | 0.00784 | 0.002 | 22.5 | ug/L |
| Cd | 114 | 86.646 | 9.2 | 55.152 | 0.00427 | 0.001 | 33.0 | ug/L |
| In | 115 | 374678.238 | 2.5 | 366049.872 | | | | ug/L |
| Sb | 121 | 1108.086 | 13.0 | 54.667 | 0.11208 | 0.018 | 16.0 | ug/L |
| Sb | 123 | 827.998 | 14.8 | 37.221 | 0.11397 | 0.020 | 17.3 | ug/L |
| Ba | 135 | 38.667 | 32.3 | 52.001 | -0.00557 | 0.005 | 95.8 | ug/L |
| Ba | 137 | 55.001 | 22.1 | 70.668 | -0.00385 | 0.003 | 79.6 | ug/L |
| Tb | 159 | 423484.834 | 1.6 | 427712.876 | | | | ug/L |
| Ho | 165 | 394832.321 | 0.8 | 412683.278 | | | | ug/L |
| Tl | 203 | 74.001 | 8.4 | 51.667 | 0.00324 | 0.001 | 27.2 | ug/L |
| Tl | 205 | 127.669 | 16.6 | 75.334 | 0.00322 | 0.001 | 39.8 | ug/L |
| Pb | 208 | 365.340 | 8.5 | 440.342 | -0.00230 | 0.001 | 58.5 | ug/L |

Sample ID: CCB

Report Date/Time: Wednesday, November 22, 2006 13:38:44

Page 1

1023

| | | | | | | | | | |
|--|----|-----|--------|------|---------|----------|-------|-------|------|
| | Pb | 206 | 97.335 | 15.0 | 119.335 | -0.00267 | 0.002 | 84.5 | ug/L |
| | Pb | 207 | 90.335 | 20.9 | 109.335 | -0.00267 | 0.004 | 138.3 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 102.598 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 101.955 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 102.357 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 99.011 | | | |
| > [Ho | 165 | | 95.674 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030

Sample Date/Time: Wednesday, November 22, 2006 13:41:40

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950030.036

*Sample
cup dry*

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|-------------|-----------|-----------|-------|
| Be | 9 | 39.667 | 22.0 | 49.334 | 2.15885 | 1.515 | 70.2 | ug/L |
| Al | 27 | 35145.687 | 171.1 | 2679.805 | 57.43004 | 92.365 | 160.8 | ug/L |
| > Sc | 45 | 12470.255 | 112.2 | 378193.541 | | | | ug/L |
| V | 51 | 3511.261 | 13.2 | 4537.327 | 13.99178 | 9.179 | 65.6 | ug/L |
| Cr | 52 | 12139.125 | 29.2 | 15100.490 | 50.73307 | 30.266 | 59.7 | ug/L |
| Cr | 53 | 712.044 | 56.3 | 618.029 | 21.18565 | 9.852 | 46.5 | ug/L |
| Mn | 55 | 8400.163 | 81.0 | 580.693 | 105.70483 | 64.610 | 61.1 | ug/L |
| Co | 59 | 266.676 | 100.8 | 202.004 | 3.16013 | 1.646 | 52.1 | ug/L |
| Ni | 60 | 378.022 | 128.3 | 196.338 | 13.90443 | 4.110 | 29.6 | ug/L |
| Ni | 62 | 328.343 | 25.5 | 499.020 | 208.42812 | 159.318 | 76.4 | ug/L |
| Cu | 63 | 312.010 | 52.2 | 505.687 | 10.93734 | 7.685 | 70.3 | ug/L |
| Cu | 65 | 167.004 | 41.2 | 212.672 | 13.01405 | 9.468 | 72.7 | ug/L |
| Zn | 66 | 224.339 | 60.1 | 1298.448 | 25.83110 | 18.029 | 69.8 | ug/L |
| Zn | 67 | 111.669 | 14.6 | 302.342 | 105.33999 | 82.412 | 78.2 | ug/L |
| Zn | 68 | 461.684 | 14.1 | 996.736 | 101.40157 | 78.671 | 77.6 | ug/L |
| > Ge | 72 | 2226.405 | 145.3 | 197196.226 | | | | ug/L |
| As | 75 | 88.668 | 19.7 | 96.335 | 12.45164 | 9.683 | 77.8 | ug/L |
| Se | 77 | 140.935 | 1.1 | 202.002 | 292.25760 | 232.105 | 79.4 | ug/L |
| Se | 78 | 18908.529 | 3.4 | 14431.438 | 12685.28468 | 10121.155 | 79.8 | mg/L |
| Se | 82 | 1876.411 | 3.9 | 1747.050 | 2944.70663 | 2353.774 | 79.9 | ug/L |
| Kr | 83 | 1900.903 | 2.8 | 1793.211 | | | | mg/L |
| Y | 89 | 2333.978 | 169.8 | 365281.373 | | | | ug/L |
| Mo | 95 | 109.335 | 18.9 | 120.335 | 143.39028 | 138.949 | 96.9 | ug/L |
| Mo | 97 | 42.334 | 49.1 | 52.667 | 73.39690 | 75.084 | 102.3 | ug/L |
| Mo | 98 | 45.161 | 70.3 | 70.498 | 24.30604 | 22.796 | 93.8 | ug/L |
| Rh | 103 | 1671.174 | 170.2 | 350376.944 | | | | ug/L |
| Ag | 107 | 48.001 | 14.4 | 46.001 | 27.68780 | 24.762 | 89.4 | ug/L |
| Ag | 109 | 43.334 | 13.3 | 42.334 | 23.96655 | 22.862 | 95.4 | ug/L |
| Cd | 111 | 87.376 | 16.1 | 203.876 | 196.52499 | 173.334 | 88.2 | ug/L |
| Cd | 114 | 151.775 | 12.8 | 55.152 | 151.18769 | 135.266 | 89.5 | ug/L |
| > In | 115 | 1414.507 | 168.8 | 366049.872 | | | | ug/L |
| Sb | 121 | 36.334 | 22.1 | 54.667 | 25.27883 | 22.295 | 88.2 | ug/L |
| Sb | 123 | 35.408 | 25.1 | 37.221 | 35.66360 | 30.544 | 85.6 | ug/L |
| Ba | 135 | 96.002 | 111.9 | 52.001 | 82.23161 | 90.388 | 109.9 | ug/L |
| Ba | 137 | 156.005 | 128.9 | 70.668 | 54.55911 | 52.291 | 95.8 | ug/L |
| > Tb | 159 | 1454.369 | 164.0 | 427712.876 | | | | ug/L |
| > Ho | 165 | 1329.977 | 164.4 | 412683.278 | | | | ug/L |
| Tl | 203 | 105.002 | 8.3 | 51.667 | 107.96400 | 143.674 | 133.1 | ug/L |
| Tl | 205 | 229.672 | 19.2 | 75.334 | 96.12320 | 121.257 | 126.1 | ug/L |
| Pb | 208 | 196.003 | 24.8 | 440.342 | 53.87630 | 72.010 | 133.7 | ug/L |

Sample ID: 950030

Report Date/Time: Wednesday, November 22, 2006 13:44:41

Page 1

1026

| | | | | | | | | | |
|--|----|-----|--------|------|---------|----------|--------|-------|------|
| | Pb | 206 | 58.001 | 23.7 | 119.335 | 60.65583 | 79.857 | 131.7 | ug/L |
| | Pb | 207 | 50.001 | 23.1 | 109.335 | 63.71387 | 85.143 | 133.6 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 3.297 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 1.129 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 0.386 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 0.340 | | | |
| > Ho | 165 | | 0.322 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Wednesday, November 22, 2006 13:47:38

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 6.037

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 52390.694 | 0.2 | 49.334 | 50.07421 | 0.755 | 1.5 | ug/L |
| Al | 27 | 448387.690 | 2.1 | 2679.805 | 52.57198 | 1.070 | 2.0 | ug/L |
| Sc | 45 | 381528.234 | 1.6 | 378193.541 | | | | ug/L |
| V | 51 | 763510.189 | 2.7 | 4537.327 | 52.71457 | 1.488 | 2.8 | ug/L |
| Cr | 52 | 674336.613 | 1.9 | 15100.490 | 52.10710 | 0.851 | 1.6 | ug/L |
| Cr | 53 | 77771.158 | 2.7 | 618.029 | 50.39676 | 0.568 | 1.1 | ug/L |
| Mn | 55 | 907879.305 | 0.4 | 580.693 | 52.37048 | 1.891 | 3.6 | ug/L |
| Co | 59 | 762287.345 | 2.6 | 202.004 | 50.91408 | 1.039 | 2.0 | ug/L |
| Ni | 60 | 170968.456 | 1.9 | 196.338 | 51.11552 | 1.344 | 2.6 | ug/L |
| Ni | 62 | 26176.352 | 4.0 | 499.020 | 49.54867 | 1.227 | 2.5 | ug/L |
| Cu | 63 | 400951.733 | 1.7 | 505.687 | 51.21461 | 1.137 | 2.2 | ug/L |
| Cu | 65 | 196362.464 | 2.6 | 212.672 | 51.54347 | 1.536 | 3.0 | ug/L |
| Zn | 66 | 110002.591 | 4.3 | 1298.448 | 49.17413 | 0.893 | 1.8 | ug/L |
| Zn | 67 | 18609.609 | 0.6 | 302.342 | 49.41368 | 1.838 | 3.7 | ug/L |
| Zn | 68 | 81773.259 | 2.7 | 996.736 | 50.67819 | 2.010 | 4.0 | ug/L |
| Ge | 72 | 198805.022 | 3.6 | 197196.226 | | | | ug/L |
| As | 75 | 121472.809 | 0.3 | 96.335 | 49.52493 | 1.697 | 3.4 | ug/L |
| Se | 77 | 9436.610 | 2.9 | 202.002 | 50.73076 | 2.265 | 4.5 | ug/L |
| Se | 78 | 44246.889 | 2.2 | 14431.438 | 51.61914 | 4.066 | 7.9 | mg/L |
| Se | 82 | 13168.466 | 2.0 | 1747.050 | 46.28931 | 1.365 | 2.9 | ug/L |
| Kr | 83 | 332.677 | 4.1 | 1793.211 | | | | mg/L |
| Y | 89 | 385344.943 | 3.5 | 365281.373 | | | | ug/L |
| Mo | 95 | 274167.483 | 1.6 | 120.335 | 54.08085 | 0.928 | 1.7 | ug/L |
| Mo | 97 | 177817.506 | 3.6 | 52.667 | 55.82912 | 2.085 | 3.7 | ug/L |
| Mo | 98 | 451267.123 | 3.9 | 70.498 | 54.82195 | 1.605 | 2.9 | ug/L |
| Rh | 103 | 349677.741 | 3.4 | 350376.944 | | | | ug/L |
| Ag | 107 | 675039.132 | 2.2 | 46.001 | 52.40442 | 1.147 | 2.2 | ug/L |
| Ag | 109 | 635492.067 | 3.0 | 42.334 | 51.47312 | 0.999 | 1.9 | ug/L |
| Cd | 111 | 158106.055 | 0.1 | 203.876 | 52.65205 | 0.599 | 1.1 | ug/L |
| Cd | 114 | 359081.026 | 4.3 | 55.152 | 51.98326 | 1.791 | 3.4 | ug/L |
| In | 115 | 363905.132 | 1.1 | 366049.872 | | | | ug/L |
| Sb | 121 | 463323.517 | 2.3 | 54.667 | 50.69572 | 0.628 | 1.2 | ug/L |
| Sb | 123 | 335469.803 | 1.2 | 37.221 | 49.73753 | 0.649 | 1.3 | ug/L |
| Ba | 135 | 113820.398 | 2.2 | 52.001 | 51.48448 | 0.561 | 1.1 | ug/L |
| Ba | 137 | 191633.688 | 0.8 | 70.668 | 51.39072 | 0.565 | 1.1 | ug/L |
| Tb | 159 | 405440.194 | 1.9 | 427712.876 | | | | ug/L |
| Ho | 165 | 388503.176 | 3.1 | 412683.278 | | | | ug/L |
| Tl | 203 | 376340.021 | 0.9 | 51.667 | 50.46528 | 1.181 | 2.3 | ug/L |
| Tl | 205 | 895526.261 | 1.1 | 75.334 | 52.56151 | 1.139 | 2.2 | ug/L |
| Pb | 208 | 1216950.666 | 1.2 | 440.342 | 50.87780 | 1.045 | 2.1 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Wednesday, November 22, 2006 13:50:40

Page 1

1029

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 313369.901 | 1.5 | 119.335 | 50.45021 | 0.789 | 1.6 ug/L |
| | Pb | 207 | 263337.300 | 1.1 | 109.335 | 50.49969 | 1.999 | 4.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 100.148 | | | | |
| Al | 27 | 105.144 | | | | |
| > Sc | 45 | | 100.882 | | | |
| V | 51 | 105.429 | | | | |
| Cr | 52 | 104.214 | | | | |
| Cr | 53 | 100.794 | | | | |
| Mn | 55 | 104.741 | | | | |
| Co | 59 | 101.828 | | | | |
| Ni | 60 | 102.231 | | | | |
| Ni | 62 | 99.097 | | | | |
| Cu | 63 | 102.429 | | | | |
| Cu | 65 | 103.087 | | | | |
| Zn | 66 | 98.348 | | | | |
| Zn | 67 | 98.827 | | | | |
| Zn | 68 | 101.356 | | | | |
| > Ge | 72 | | 100.816 | | | |
| As | 75 | 99.050 | | | | |
| Se | 77 | 101.462 | | | | |
| Se | 78 | 103.238 | | | | |
| Se | 82 | 92.579 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 108.162 | | | | |
| Mo | 97 | 111.658 | | | | |
| Mo | 98 | 109.644 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 104.809 | | | | |
| Ag | 109 | 102.946 | | | | |
| Cd | 111 | 105.304 | | | | |
| Cd | 114 | 103.967 | | | | |
| > In | 115 | | 99.414 | | | |
| Sb | 121 | 101.391 | | | | |
| Sb | 123 | 99.475 | | | | |
| Ba | 135 | 102.969 | | | | |
| Ba | 137 | 102.781 | | | | |
| > Tb | 159 | | 94.793 | | | |
| > Ho | 165 | | 94.141 | | | |
| Tl | 203 | 100.931 | | | | |
| Tl | 205 | 105.123 | | | | |
| Pb | 208 | 101.756 | | | | |
| Pb | 206 | 100.900 | | | | |
| Pb | 207 | 100.999 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Wednesday, November 22, 2006 13:53:36

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 7.038

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 55.001 | 7.3 | 49.334 | 0.00294 | 0.003 | 107.4 | ug/L |
| Al | 27 | 2626.440 | 3.2 | 2679.805 | -0.02118 | 0.005 | 21.9 | ug/L |
| > Sc | 45 | 397120.925 | 3.8 | 378193.541 | | | | ug/L |
| V | 51 | 4695.291 | 3.7 | 4537.327 | -0.00458 | 0.006 | 120.2 | ug/L |
| Cr | 52 | 15610.433 | 1.8 | 15100.490 | -0.01806 | 0.025 | 139.7 | ug/L |
| Cr | 53 | 684.035 | 2.9 | 618.029 | 0.02213 | 0.007 | 29.8 | ug/L |
| Mn | 55 | 662.366 | 8.0 | 580.693 | 0.00336 | 0.004 | 107.1 | ug/L |
| Co | 59 | 230.339 | 5.6 | 202.004 | 0.00135 | 0.001 | 85.8 | ug/L |
| Ni | 60 | 147.003 | 7.1 | 196.338 | -0.01653 | 0.003 | 17.4 | ug/L |
| Ni | 62 | 507.021 | 4.9 | 499.020 | -0.02158 | 0.020 | 94.1 | ug/L |
| Cu | 63 | 438.016 | 2.2 | 505.687 | -0.01077 | 0.003 | 26.1 | ug/L |
| Cu | 65 | 181.670 | 6.8 | 212.672 | -0.00999 | 0.003 | 30.9 | ug/L |
| Zn | 66 | 1259.441 | 6.9 | 1298.448 | -0.03974 | 0.019 | 48.6 | ug/L |
| Zn | 67 | 277.341 | 9.3 | 302.342 | -0.09697 | 0.047 | 48.8 | ug/L |
| Zn | 68 | 896.724 | 6.0 | 996.736 | -0.08384 | 0.041 | 48.4 | ug/L |
| > Ge | 72 | 204868.353 | 3.5 | 197196.226 | | | | ug/L |
| As | 75 | 115.335 | 9.3 | 96.335 | 0.00614 | 0.005 | 88.8 | ug/L |
| Se | 77 | 228.870 | 1.0 | 202.002 | 0.10198 | 0.030 | 29.9 | ug/L |
| Se | 78 | 14768.183 | 3.9 | 14431.438 | -0.36941 | 0.922 | 249.5 | mg/L |
| Se | 82 | 340.274 | 2.3 | 1747.050 | -5.80208 | 0.078 | 1.3 | ug/L |
| Kr | 83 | 308.675 | 2.3 | 1793.211 | | | | mg/L |
| Y | 89 | 385016.004 | 2.5 | 365281.373 | | | | ug/L |
| Mo | 95 | 670.034 | 17.8 | 120.335 | 0.10214 | 0.021 | 20.3 | ug/L |
| Mo | 97 | 396.347 | 23.5 | 52.667 | 0.10191 | 0.026 | 26.0 | ug/L |
| Mo | 98 | 915.928 | 22.7 | 70.498 | 0.09727 | 0.023 | 23.2 | ug/L |
| Rh | 103 | 348763.506 | 2.9 | 350376.944 | | | | ug/L |
| Ag | 107 | 158.336 | 17.7 | 46.001 | 0.00814 | 0.002 | 23.7 | ug/L |
| Ag | 109 | 141.336 | 20.9 | 42.334 | 0.00747 | 0.002 | 28.4 | ug/L |
| Cd | 111 | 210.404 | 6.5 | 203.876 | -0.00080 | 0.003 | 408.4 | ug/L |
| Cd | 114 | 72.878 | 20.2 | 55.152 | 0.00213 | 0.002 | 100.8 | ug/L |
| > In | 115 | 382078.307 | 1.7 | 366049.872 | | | | ug/L |
| Sb | 121 | 1212.769 | 17.4 | 54.667 | 0.12028 | 0.020 | 16.9 | ug/L |
| Sb | 123 | 913.511 | 20.3 | 37.221 | 0.12327 | 0.024 | 19.8 | ug/L |
| Ba | 135 | 49.334 | 12.2 | 52.001 | 0.00016 | 0.003 | 1850.5 | ug/L |
| Ba | 137 | 57.667 | 24.3 | 70.668 | -0.00239 | 0.004 | 161.8 | ug/L |
| > Tb | 159 | 403204.942 | 1.0 | 427712.876 | | | | ug/L |
| > Ho | 165 | 402032.958 | 0.7 | 412683.278 | | | | ug/L |
| Tl | 203 | 64.668 | 14.4 | 51.667 | 0.00186 | 0.001 | 67.6 | ug/L |
| Tl | 205 | 117.669 | 12.4 | 75.334 | 0.00251 | 0.001 | 32.6 | ug/L |
| Pb | 208 | 342.339 | 1.4 | 440.342 | -0.00350 | 0.000 | 3.3 | ug/L |

Sample ID: QC Std 7

Report Date/Time: Wednesday, November 22, 2006 13:56:37

Page 1

1032

| | | | | | | | | |
|--|----|-----|--------|------|---------|----------|-------|-----------|
| | Pb | 206 | 96.335 | 5.2 | 119.335 | -0.00310 | 0.001 | 24.1 ug/L |
| | Pb | 207 | 90.335 | 14.4 | 109.335 | -0.00300 | 0.002 | 79.3 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 105.005 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 103.891 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 104.379 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 94.270 | | | |
| > [Ho | 165 | | 97.419 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030

Sample Date/Time: Wednesday, November 22, 2006 14:04:24

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950030.039

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 75.334 | 11.1 | 49.334 | 0.00712 | 0.006 | 84.6 | ug/L |
| Al | 27 | 1848628.606 | 10.9 | 2679.805 | 165.37562 | 19.520 | 11.8 | ug/L |
| > Sc | 45 | 502477.810 | 2.3 | 378193.541 | | | | ug/L |
| V | 51 | 21009.724 | 46.3 | 4537.327 | 0.79599 | 0.526 | 66.1 | ug/L |
| Cr | 52 | 169853.098 | 14.5 | 15100.490 | 9.01049 | 1.632 | 18.1 | ug/L |
| Cr | 53 | 15646.166 | 1.6 | 618.029 | 7.35588 | 0.152 | 2.1 | ug/L |
| Mn | 55 | 310145.460 | 1.5 | 580.693 | 15.75983 | 0.107 | 0.7 | ug/L |
| Co | 59 | 9227.198 | 0.4 | 202.004 | 0.53057 | 0.004 | 0.7 | ug/L |
| Ni | 60 | 28976.288 | 3.6 | 196.338 | 7.59652 | 0.315 | 4.1 | ug/L |
| Ni | 62 | 3954.978 | 1.2 | 499.020 | 5.76907 | 0.122 | 2.1 | ug/L |
| Cu | 63 | 8870.808 | 1.4 | 505.687 | 0.93617 | 0.016 | 1.7 | ug/L |
| Cu | 65 | 3988.662 | 3.2 | 212.672 | 0.86866 | 0.026 | 3.0 | ug/L |
| Zn | 66 | 7137.796 | 3.3 | 1298.448 | 2.25915 | 0.078 | 3.4 | ug/L |
| Zn | 67 | 1412.134 | 3.7 | 302.342 | 2.54054 | 0.099 | 3.9 | ug/L |
| Zn | 68 | 6824.528 | 0.6 | 996.736 | 3.14842 | 0.028 | 0.9 | ug/L |
| > Ge | 72 | 225146.593 | 0.8 | 197196.226 | | | | ug/L |
| As | 75 | 720.705 | 3.0 | 96.335 | 0.21983 | 0.006 | 2.6 | ug/L |
| Se | 77 | 338.940 | 1.9 | 202.002 | 0.52519 | 0.039 | 7.5 | ug/L |
| Se | 78 | 17234.549 | 0.9 | 14431.438 | 1.16092 | 0.173 | 14.9 | mg/L |
| Se | 82 | 460.613 | 1.4 | 1747.050 | -5.49352 | 0.022 | 0.4 | ug/L |
| Kr | 83 | 354.011 | 1.1 | 1793.211 | | | | mg/L |
| Y | 89 | 452555.866 | 0.6 | 365281.373 | | | | ug/L |
| Mo | 95 | 1523.489 | 10.9 | 120.335 | 0.23714 | 0.029 | 12.3 | ug/L |
| Mo | 97 | 921.394 | 5.4 | 52.667 | 0.23450 | 0.014 | 6.1 | ug/L |
| Mo | 98 | 2254.605 | 6.8 | 70.498 | 0.22911 | 0.017 | 7.4 | ug/L |
| Rh | 103 | 368802.219 | 0.3 | 350376.944 | | | | ug/L |
| Ag | 107 | 102.335 | 8.3 | 46.001 | 0.00334 | 0.001 | 17.5 | ug/L |
| Ag | 109 | 76.001 | 10.5 | 42.334 | 0.00193 | 0.001 | 30.6 | ug/L |
| Cd | 111 | 298.664 | 8.2 | 203.876 | 0.01876 | 0.007 | 36.8 | ug/L |
| Cd | 114 | 172.267 | 86.5 | 55.152 | 0.01368 | 0.019 | 136.5 | ug/L |
| > In | 115 | 419659.132 | 0.5 | 366049.872 | | | | ug/L |
| Sb | 121 | 619.696 | 8.0 | 54.667 | 0.05287 | 0.005 | 9.1 | ug/L |
| Sb | 123 | 483.215 | 8.2 | 37.221 | 0.05665 | 0.005 | 9.3 | ug/L |
| Ba | 135 | 22343.480 | 2.2 | 52.001 | 9.76806 | 0.284 | 2.9 | ug/L |
| Ba | 137 | 39995.531 | 2.8 | 70.668 | 10.36725 | 0.197 | 1.9 | ug/L |
| > Tb | 159 | 418779.217 | 1.1 | 427712.876 | | | | ug/L |
| > Ho | 165 | 409300.098 | 0.8 | 412683.278 | | | | ug/L |
| Tl | 203 | 176.670 | 5.7 | 51.667 | 0.01597 | 0.001 | 9.0 | ug/L |
| Tl | 205 | 402.014 | 2.4 | 75.334 | 0.01823 | 0.001 | 3.2 | ug/L |
| Pb | 208 | 8824.916 | 0.7 | 440.342 | 0.33287 | 0.004 | 1.3 | ug/L |

Sample ID: 950030

Report Date/Time: Wednesday, November 22, 2006 14:07:25

Page 1

1035

| | | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|-----|------|
| | Pb | 206 | 2275.333 | 0.2 | 119.335 | 0.32964 | 0.003 | 1.0 | ug/L |
| | Pb | 207 | 1887.233 | 2.6 | 109.335 | 0.32370 | 0.011 | 3.4 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 132.863 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 114.174 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 114.645 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.911 | | | |
| > Ho | 165 | | 99.180 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| L Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030D

Sample Date/Time: Wednesday, November 22, 2006 14:10:21

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950030D.040

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 70.334 | 6.4 | 49.334 | 0.00325 | 0.003 | 92.8 | ug/L |
| Al | 27 | 1923009.969 | 1.1 | 2679.805 | 171.17576 | 1.196 | 0.7 | ug/L |
| Sc | 45 | 504610.461 | 1.0 | 378193.541 | | | | ug/L |
| V | 51 | 13483.917 | 7.0 | 4537.327 | 0.39035 | 0.053 | 13.7 | ug/L |
| Cr | 52 | 173913.750 | 1.7 | 15100.490 | 9.19193 | 0.240 | 2.6 | ug/L |
| Cr | 53 | 18961.073 | 1.5 | 618.029 | 8.96028 | 0.232 | 2.6 | ug/L |
| Mn | 55 | 322992.002 | 1.0 | 580.693 | 16.27493 | 0.202 | 1.2 | ug/L |
| Co | 59 | 9475.814 | 2.3 | 202.004 | 0.54056 | 0.018 | 3.3 | ug/L |
| Ni | 60 | 32890.782 | 1.3 | 196.338 | 8.55798 | 0.281 | 3.3 | ug/L |
| Ni | 62 | 4516.602 | 1.4 | 499.020 | 6.66223 | 0.250 | 3.7 | ug/L |
| Cu | 63 | 8946.227 | 3.9 | 505.687 | 0.93650 | 0.053 | 5.7 | ug/L |
| Cu | 65 | 4455.569 | 2.9 | 212.672 | 0.96813 | 0.025 | 2.6 | ug/L |
| Zn | 66 | 7926.848 | 1.6 | 1298.448 | 2.54847 | 0.098 | 3.9 | ug/L |
| Zn | 67 | 1476.812 | 4.6 | 302.342 | 2.66420 | 0.130 | 4.9 | ug/L |
| Zn | 68 | 7478.095 | 1.0 | 996.736 | 3.47495 | 0.041 | 1.2 | ug/L |
| Ge | 72 | 227108.444 | 2.0 | 197196.226 | | | | ug/L |
| As | 75 | 761.709 | 1.8 | 96.335 | 0.23238 | 0.010 | 4.2 | ug/L |
| Se | 77 | 354.008 | 2.2 | 202.002 | 0.58420 | 0.071 | 12.2 | ug/L |
| Se | 78 | 17723.675 | 2.3 | 14431.438 | 1.69076 | 1.150 | 68.0 | mg/L |
| Se | 82 | 479.214 | 3.5 | 1747.050 | -5.44196 | 0.036 | 0.7 | ug/L |
| Kr | 83 | 351.011 | 7.7 | 1793.211 | | | | mg/L |
| Y | 89 | 461187.766 | 1.8 | 365281.373 | | | | ug/L |
| Mo | 95 | 1473.478 | 2.5 | 120.335 | 0.23759 | 0.005 | 2.1 | ug/L |
| Mo | 97 | 923.060 | 1.8 | 52.667 | 0.24399 | 0.005 | 2.2 | ug/L |
| Mo | 98 | 2127.492 | 4.1 | 70.498 | 0.22380 | 0.011 | 4.9 | ug/L |
| Rh | 103 | 383350.402 | 1.2 | 350376.944 | | | | ug/L |
| Ag | 107 | 129.669 | 10.2 | 46.001 | 0.00549 | 0.001 | 16.4 | ug/L |
| Ag | 109 | 95.001 | 5.3 | 42.334 | 0.00350 | 0.000 | 10.3 | ug/L |
| Cd | 111 | 288.427 | 2.0 | 203.876 | 0.01881 | 0.001 | 6.2 | ug/L |
| Cd | 114 | 164.365 | 52.4 | 55.152 | 0.01347 | 0.011 | 83.7 | ug/L |
| In | 115 | 405063.314 | 0.6 | 366049.872 | | | | ug/L |
| Sb | 121 | 478.685 | 0.7 | 54.667 | 0.04112 | 0.000 | 0.1 | ug/L |
| Sb | 123 | 360.159 | 4.8 | 37.221 | 0.04250 | 0.003 | 6.0 | ug/L |
| Ba | 135 | 22793.696 | 1.4 | 52.001 | 9.91296 | 0.229 | 2.3 | ug/L |
| Ba | 137 | 39404.686 | 1.6 | 70.668 | 10.16267 | 0.245 | 2.4 | ug/L |
| Tb | 159 | 420982.243 | 0.9 | 427712.876 | | | | ug/L |
| Ho | 165 | 395760.284 | 1.6 | 412683.278 | | | | ug/L |
| Tl | 203 | 190.004 | 11.5 | 51.667 | 0.01846 | 0.002 | 13.5 | ug/L |
| Tl | 205 | 388.680 | 5.7 | 75.334 | 0.01823 | 0.001 | 7.9 | ug/L |
| Pb | 208 | 8608.154 | 0.5 | 440.342 | 0.33598 | 0.004 | 1.2 | ug/L |

Sample ID: 950030D

Report Date/Time: Wednesday, November 22, 2006 14:13:22

Page 1

1038

| | | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|-----|------|
| | Pb | 206 | 2217.651 | 2.5 | 119.335 | 0.33244 | 0.009 | 2.6 | ug/L |
| | Pb | 207 | 1859.226 | 2.6 | 109.335 | 0.33024 | 0.013 | 3.9 | ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 133.427 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 115.169 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 110.658 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 98.426 | | | |
| > [Ho | 165 | | 95.899 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030S

Sample Date/Time: Wednesday, November 22, 2006 14:16:18

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950030S.041

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 22533.652 | 0.9 | 49.334 | 15.75518 | 0.422 | 2.7 | ug/L |
| Al | 27 | 2782959.788 | 0.9 | 2679.805 | 240.30430 | 3.916 | 1.6 | ug/L |
| > Sc | 45 | 520571.640 | 2.1 | 378193.541 | | | | ug/L |
| V | 51 | 388694.187 | 2.2 | 4537.327 | 19.46697 | 0.088 | 0.5 | ug/L |
| Cr | 52 | 468857.641 | 2.3 | 15100.490 | 25.96033 | 0.195 | 0.8 | ug/L |
| Cr | 53 | 56349.773 | 0.4 | 618.029 | 26.58340 | 0.670 | 2.5 | ug/L |
| Mn | 55 | 759925.382 | 1.2 | 580.693 | 37.04847 | 0.191 | 0.5 | ug/L |
| Co | 59 | 374923.467 | 0.8 | 202.004 | 21.17348 | 0.091 | 0.4 | ug/L |
| Ni | 60 | 107483.502 | 1.0 | 196.338 | 27.14999 | 0.426 | 1.6 | ug/L |
| Ni | 62 | 16182.860 | 0.9 | 499.020 | 25.45625 | 0.486 | 1.9 | ug/L |
| Cu | 63 | 205459.527 | 1.1 | 505.687 | 22.16084 | 0.486 | 2.2 | ug/L |
| Cu | 65 | 96004.147 | 0.7 | 212.672 | 21.28073 | 0.348 | 1.6 | ug/L |
| Zn | 66 | 51527.345 | 1.3 | 1298.448 | 19.13368 | 0.105 | 0.6 | ug/L |
| Zn | 67 | 9269.245 | 0.7 | 302.342 | 20.33368 | 0.376 | 1.9 | ug/L |
| Zn | 68 | 39544.333 | 0.6 | 996.736 | 20.35090 | 0.309 | 1.5 | ug/L |
| > Ge | 72 | 234965.056 | 1.1 | 197196.226 | | | | ug/L |
| As | 75 | 56142.750 | 1.7 | 96.335 | 19.33135 | 0.553 | 2.9 | ug/L |
| Se | 77 | 4074.996 | 0.5 | 202.002 | 17.81303 | 0.261 | 1.5 | ug/L |
| Se | 78 | 29600.077 | 0.2 | 14431.438 | 18.21521 | 0.562 | 3.1 | mg/L |
| Se | 82 | 5664.725 | 1.0 | 1747.050 | 12.29512 | 0.026 | 0.2 | ug/L |
| Kr | 83 | 363.345 | 7.6 | 1793.211 | | | | mg/L |
| Y | 89 | 475633.910 | 1.5 | 365281.373 | | | | ug/L |
| Mo | 95 | 138469.704 | 2.2 | 120.335 | 24.58152 | 0.898 | 3.7 | ug/L |
| Mo | 97 | 84284.376 | 2.0 | 52.667 | 23.82481 | 1.087 | 4.6 | ug/L |
| Mo | 98 | 222402.300 | 1.9 | 70.498 | 24.33869 | 1.178 | 4.8 | ug/L |
| Rh | 103 | 376487.173 | 0.9 | 350376.944 | | | | ug/L |
| Ag | 107 | 302270.461 | 1.8 | 46.001 | 21.13046 | 0.836 | 4.0 | ug/L |
| Ag | 109 | 281491.439 | 0.4 | 42.334 | 20.53869 | 0.884 | 4.3 | ug/L |
| Cd | 111 | 65333.121 | 1.3 | 203.876 | 19.55115 | 0.762 | 3.9 | ug/L |
| Cd | 114 | 146051.434 | 0.8 | 55.152 | 19.04500 | 0.862 | 4.5 | ug/L |
| > In | 115 | 404429.536 | 3.8 | 366049.872 | | | | ug/L |
| Sb | 121 | 203710.840 | 0.2 | 54.667 | 20.07462 | 0.803 | 4.0 | ug/L |
| Sb | 123 | 150200.795 | 2.1 | 37.221 | 20.04327 | 0.435 | 2.2 | ug/L |
| Ba | 135 | 71656.842 | 1.3 | 52.001 | 32.12590 | 0.286 | 0.9 | ug/L |
| Ba | 137 | 121822.899 | 0.8 | 70.668 | 32.37884 | 0.245 | 0.8 | ug/L |
| > Tb | 159 | 408939.677 | 0.4 | 427712.876 | | | | ug/L |
| > Ho | 165 | 403637.292 | 1.1 | 412683.278 | | | | ug/L |
| Tl | 203 | 159127.638 | 1.2 | 51.667 | 20.52667 | 0.358 | 1.7 | ug/L |
| Tl | 205 | 376622.492 | 1.9 | 75.334 | 21.26674 | 0.470 | 2.2 | ug/L |
| Pb | 208 | 518468.097 | 0.8 | 440.342 | 20.84721 | 0.384 | 1.8 | ug/L |

Sample ID: 950030S

Report Date/Time: Wednesday, November 22, 2006 14:19:20

Page 1

1041

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 134660.878 | 1.9 | 119.335 | 20.85156 | 0.490 | 2.3 ug/L |
| | Pb | 207 | 111393.102 | 1.4 | 109.335 | 20.53599 | 0.489 | 2.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 137.647 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 119.153 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 110.485 | | | |
| Sb | 121 | | | | | |
| Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 95.611 | | | |
| > Ho | 165 | | 97.808 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030A

Sample Date/Time: Wednesday, November 22, 2006 14:22:16

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950030A.042

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 24356.469 | 2.6 | 49.334 | 17.13702 | 0.337 | 2.0 | ug/L |
| Al | 27 | 2326513.922 | 0.8 | 2679.805 | 202.13886 | 4.639 | 2.3 | ug/L |
| > Sc | 45 | 517238.950 | 1.5 | 378193.541 | | | | ug/L |
| V | 51 | 425721.461 | 5.9 | 4537.327 | 21.48661 | 1.107 | 5.2 | ug/L |
| Cr | 52 | 525540.212 | 10.5 | 15100.490 | 29.43340 | 3.094 | 10.5 | ug/L |
| Cr | 53 | 66581.871 | 18.8 | 618.029 | 31.70884 | 6.242 | 19.7 | ug/L |
| Mn | 55 | 774696.562 | 3.5 | 580.693 | 37.95970 | 2.206 | 5.8 | ug/L |
| Co | 59 | 399908.893 | 3.2 | 202.004 | 22.67608 | 0.298 | 1.3 | ug/L |
| Ni | 60 | 116894.653 | 3.5 | 196.338 | 29.64740 | 0.417 | 1.4 | ug/L |
| Ni | 62 | 16505.508 | 3.5 | 499.020 | 26.09801 | 0.991 | 3.8 | ug/L |
| Cu | 63 | 203910.753 | 3.0 | 505.687 | 22.07987 | 0.288 | 1.3 | ug/L |
| Cu | 65 | 100024.788 | 1.4 | 212.672 | 22.27483 | 0.740 | 3.3 | ug/L |
| Zn | 66 | 53984.520 | 1.3 | 1298.448 | 20.16351 | 0.198 | 1.0 | ug/L |
| Zn | 67 | 9149.446 | 2.3 | 302.342 | 20.14508 | 0.205 | 1.0 | ug/L |
| Zn | 68 | 39852.476 | 1.4 | 996.736 | 20.60913 | 0.655 | 3.2 | ug/L |
| > Ge | 72 | 233991.015 | 2.3 | 197196.226 | | | | ug/L |
| As | 75 | 59367.648 | 0.4 | 96.335 | 20.53082 | 0.393 | 1.9 | ug/L |
| Se | 77 | 4351.869 | 0.2 | 202.002 | 19.18804 | 0.437 | 2.3 | ug/L |
| Se | 78 | 31066.586 | 2.1 | 14431.438 | 20.58338 | 1.999 | 9.7 | mg/L |
| Se | 82 | 6065.473 | 0.5 | 1747.050 | 13.76240 | 0.377 | 2.7 | ug/L |
| Kr | 83 | 369.345 | 3.2 | 1793.211 | | | | mg/L |
| Y | 89 | 476918.064 | 2.1 | 365281.373 | | | | ug/L |
| Mo | 95 | 147544.737 | 3.3 | 120.335 | 25.99563 | 1.003 | 3.9 | ug/L |
| Mo | 97 | 90801.308 | 1.4 | 52.667 | 25.46585 | 0.555 | 2.2 | ug/L |
| Mo | 98 | 229429.222 | 1.3 | 70.498 | 24.91363 | 0.855 | 3.4 | ug/L |
| Rh | 103 | 389099.213 | 1.4 | 350376.944 | | | | ug/L |
| Ag | 107 | 115.669 | 8.7 | 46.001 | 0.00448 | 0.001 | 19.2 | ug/L |
| Ag | 109 | 86.668 | 5.2 | 42.334 | 0.00287 | 0.000 | 13.0 | ug/L |
| Cd | 111 | 70532.299 | 2.7 | 203.876 | 20.95789 | 1.035 | 4.9 | ug/L |
| Cd | 114 | 150923.026 | 2.4 | 55.152 | 19.53191 | 0.906 | 4.6 | ug/L |
| > In | 115 | 407328.984 | 2.3 | 366049.872 | | | | ug/L |
| Sb | 121 | 207419.140 | 0.9 | 54.667 | 20.28199 | 0.542 | 2.7 | ug/L |
| Sb | 123 | 158006.282 | 1.3 | 37.221 | 20.93554 | 0.714 | 3.4 | ug/L |
| Ba | 135 | 22183.712 | 1.1 | 52.001 | 9.71697 | 0.066 | 0.7 | ug/L |
| Ba | 137 | 38720.808 | 1.0 | 70.668 | 10.05877 | 0.126 | 1.3 | ug/L |
| > Tb | 159 | 417898.799 | 0.7 | 427712.876 | | | | ug/L |
| > Ho | 165 | 406237.510 | 0.8 | 412683.278 | | | | ug/L |
| Tl | 203 | 168463.224 | 1.1 | 51.667 | 21.59057 | 0.248 | 1.1 | ug/L |
| Tl | 205 | 388510.074 | 1.4 | 75.334 | 21.79735 | 0.415 | 1.9 | ug/L |
| Pb | 208 | 536846.673 | 0.8 | 440.342 | 21.44721 | 0.317 | 1.5 | ug/L |

Sample ID: 950030A

Report Date/Time: Wednesday, November 22, 2006 14:25:17

Page 1

1044

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 138882.198 | 1.1 | 119.335 | 21.36601 | 0.209 | 1.0 ug/L |
| | Pb | 207 | 116718.984 | 1.4 | 109.335 | 21.38000 | 0.476 | 2.2 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 136.766 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 118.659 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 111.277 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 97.705 | | | |
| > Ho | 165 | | 98.438 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950030L

Sample Date/Time: Wednesday, November 22, 2006 14:28:13

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950030L.043

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 50.001 | 19.3 | 49.334 | -0.00410 | 0.008 | 189.6 | ug/L |
| Al | 27 | 327766.643 | 2.5 | 2679.805 | 34.92477 | 1.439 | 4.1 | ug/L |
| > Sc | 45 | 418707.580 | 2.0 | 378193.541 | | | | ug/L |
| V | 51 | 5516.888 | 12.2 | 4537.327 | 0.03121 | 0.042 | 134.2 | ug/L |
| Cr | 52 | 39459.266 | 0.8 | 15100.490 | 1.63862 | 0.037 | 2.3 | ug/L |
| Cr | 53 | 3456.751 | 0.8 | 618.029 | 1.65113 | 0.049 | 3.0 | ug/L |
| Mn | 55 | 62441.448 | 2.5 | 580.693 | 3.30358 | 0.057 | 1.7 | ug/L |
| Co | 59 | 1832.220 | 2.2 | 202.004 | 0.09982 | 0.003 | 2.8 | ug/L |
| Ni | 60 | 5443.500 | 4.1 | 196.338 | 1.44981 | 0.047 | 3.3 | ug/L |
| Ni | 62 | 1033.074 | 1.3 | 499.020 | 0.87700 | 0.032 | 3.6 | ug/L |
| Cu | 63 | 1907.571 | 2.0 | 505.687 | 0.16089 | 0.007 | 4.5 | ug/L |
| Cu | 65 | 1012.405 | 2.2 | 212.672 | 0.19021 | 0.009 | 4.7 | ug/L |
| Zn | 66 | 1955.916 | 1.0 | 1298.448 | 0.22798 | 0.012 | 5.3 | ug/L |
| Zn | 67 | 404.681 | 1.9 | 302.342 | 0.18942 | 0.009 | 4.6 | ug/L |
| Zn | 68 | 1679.186 | 1.0 | 996.736 | 0.34576 | 0.005 | 1.3 | ug/L |
| > Ge | 72 | 214509.916 | 1.4 | 197196.226 | | | | ug/L |
| As | 75 | 217.672 | 7.9 | 96.335 | 0.04262 | 0.006 | 13.7 | ug/L |
| Se | 77 | 253.137 | 2.0 | 202.002 | 0.16991 | 0.015 | 8.7 | ug/L |
| Se | 78 | 16266.708 | 0.6 | 14431.438 | 0.91842 | 0.512 | 55.8 | mg/L |
| Se | 82 | 364.608 | 1.7 | 1747.050 | -5.77226 | 0.040 | 0.7 | ug/L |
| Kr | 83 | 328.343 | 10.5 | 1793.211 | | | | mg/L |
| Y | 89 | 419214.150 | 3.4 | 365281.373 | | | | ug/L |
| Mo | 95 | 357.345 | 2.6 | 120.335 | 0.04235 | 0.002 | 4.2 | ug/L |
| Mo | 97 | 196.004 | 9.4 | 52.667 | 0.04114 | 0.006 | 13.6 | ug/L |
| Mo | 98 | 461.182 | 2.8 | 70.498 | 0.04391 | 0.002 | 3.7 | ug/L |
| Rh | 103 | 358290.922 | 1.0 | 350376.944 | | | | ug/L |
| Ag | 107 | 76.334 | 11.3 | 46.001 | 0.00199 | 0.001 | 32.5 | ug/L |
| Ag | 109 | 66.001 | 20.0 | 42.334 | 0.00159 | 0.001 | 63.0 | ug/L |
| Cd | 111 | 240.701 | 4.3 | 203.876 | 0.00748 | 0.003 | 41.8 | ug/L |
| Cd | 114 | 70.790 | 35.8 | 55.152 | 0.00166 | 0.003 | 209.2 | ug/L |
| > In | 115 | 389080.316 | 0.4 | 366049.872 | | | | ug/L |
| Sb | 121 | 460.017 | 14.3 | 54.667 | 0.04116 | 0.007 | 16.8 | ug/L |
| Sb | 123 | 339.486 | 15.1 | 37.221 | 0.04161 | 0.007 | 17.5 | ug/L |
| Ba | 135 | 4378.194 | 1.4 | 52.001 | 1.90333 | 0.025 | 1.3 | ug/L |
| Ba | 137 | 7689.624 | 1.4 | 70.668 | 1.98674 | 0.028 | 1.4 | ug/L |
| > Tb | 159 | 417152.578 | 0.9 | 427712.876 | | | | ug/L |
| > Ho | 165 | 392098.178 | 1.7 | 412683.278 | | | | ug/L |
| Tl | 203 | 59.001 | 6.8 | 51.667 | 0.00131 | 0.000 | 31.1 | ug/L |
| Tl | 205 | 145.003 | 4.2 | 75.334 | 0.00427 | 0.000 | 9.5 | ug/L |
| Pb | 208 | 1950.107 | 2.4 | 440.342 | 0.06346 | 0.003 | 4.0 | ug/L |

Sample ID: 950030L

Report Date/Time: Wednesday, November 22, 2006 14:31:14

Page 1

1047

| | | | | | | | | |
|--|----|-----|---------|-----|---------|---------|-------|----------|
| | Pb | 206 | 534.022 | 4.7 | 119.335 | 0.06716 | 0.005 | 7.9 ug/L |
| | Pb | 207 | 414.014 | 6.4 | 109.335 | 0.05889 | 0.005 | 7.8 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 110.713 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 108.780 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 106.292 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 97.531 | | | |
| > [Ho | 165 | | 95.012 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950031

Sample Date/Time: Wednesday, November 22, 2006 14:34:11

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950031.044

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 121.669 | 7.5 | 49.334 | 0.03988 | 0.011 | 26.5 | ug/L |
| Al | 27 | 7217610.894 | 2.1 | 2679.805 | 637.86166 | 23.681 | 3.7 | ug/L |
| Sc | 45 | 509486.381 | 4.7 | 378193.541 | | | | ug/L |
| V | 51 | 43686.637 | 27.1 | 4537.327 | 1.97334 | 0.722 | 36.6 | ug/L |
| Cr | 52 | 579176.578 | 7.3 | 15100.490 | 33.19963 | 4.026 | 12.1 | ug/L |
| Cr | 53 | 64558.080 | 0.5 | 618.029 | 31.22454 | 1.526 | 4.9 | ug/L |
| Mn | 55 | 855375.601 | 1.2 | 580.693 | 42.68797 | 1.542 | 3.6 | ug/L |
| Co | 59 | 31550.602 | 1.3 | 202.004 | 1.81173 | 0.085 | 4.7 | ug/L |
| Ni | 60 | 90024.020 | 5.0 | 196.338 | 23.29188 | 1.979 | 8.5 | ug/L |
| Ni | 62 | 12884.418 | 2.2 | 499.020 | 20.56603 | 1.001 | 4.9 | ug/L |
| Cu | 63 | 27721.314 | 1.4 | 505.687 | 3.00358 | 0.108 | 3.6 | ug/L |
| Cu | 65 | 13374.199 | 3.4 | 212.672 | 2.98889 | 0.227 | 7.6 | ug/L |
| Zn | 66 | 14063.666 | 1.5 | 1298.448 | 4.91751 | 0.168 | 3.4 | ug/L |
| Zn | 67 | 2555.418 | 3.9 | 302.342 | 5.14645 | 0.296 | 5.8 | ug/L |
| Zn | 68 | 11774.100 | 2.4 | 996.736 | 5.76277 | 0.249 | 4.3 | ug/L |
| Ge | 72 | 229772.382 | 3.9 | 197196.226 | | | | ug/L |
| As | 75 | 2805.834 | 0.3 | 96.335 | 0.95114 | 0.037 | 3.9 | ug/L |
| Se | 77 | 435.745 | 2.5 | 202.002 | 0.95341 | 0.077 | 8.0 | ug/L |
| Se | 78 | 17766.800 | 0.4 | 14431.438 | 1.45464 | 1.010 | 69.4 | mg/L |
| Se | 82 | 567.619 | 1.0 | 1747.050 | -5.14964 | 0.063 | 1.2 | ug/L |
| Kr | 83 | 371.679 | 4.7 | 1793.211 | | | | mg/L |
| Y | 89 | 492780.305 | 1.4 | 365281.373 | | | | ug/L |
| Mo | 95 | 10137.937 | 3.8 | 120.335 | 1.84128 | 0.077 | 4.2 | ug/L |
| Mo | 97 | 6391.848 | 2.2 | 52.667 | 1.85452 | 0.033 | 1.8 | ug/L |
| Mo | 98 | 16408.263 | 3.1 | 70.498 | 1.85030 | 0.063 | 3.4 | ug/L |
| Rh | 103 | 377403.948 | 2.3 | 350376.944 | | | | ug/L |
| Ag | 107 | 126.002 | 9.2 | 46.001 | 0.00557 | 0.001 | 14.6 | ug/L |
| Ag | 109 | 110.335 | 5.5 | 42.334 | 0.00492 | 0.000 | 9.1 | ug/L |
| Cd | 111 | 415.679 | 6.2 | 203.876 | 0.06161 | 0.008 | 13.0 | ug/L |
| Cd | 114 | 382.880 | 30.7 | 55.152 | 0.04378 | 0.016 | 36.7 | ug/L |
| In | 115 | 390405.123 | 0.4 | 366049.872 | | | | ug/L |
| Sb | 121 | 802.047 | 8.3 | 54.667 | 0.07588 | 0.007 | 9.2 | ug/L |
| Sb | 123 | 594.223 | 2.8 | 37.221 | 0.07663 | 0.002 | 2.7 | ug/L |
| Ba | 135 | 34252.262 | 1.1 | 52.001 | 15.27690 | 0.196 | 1.3 | ug/L |
| Ba | 137 | 57873.558 | 1.9 | 70.668 | 15.30482 | 0.348 | 2.3 | ug/L |
| Tb | 159 | 410775.406 | 0.8 | 427712.876 | | | | ug/L |
| Ho | 165 | 396732.427 | 1.8 | 412683.278 | | | | ug/L |
| Tl | 203 | 406.681 | 6.3 | 51.667 | 0.04684 | 0.002 | 5.1 | ug/L |
| Tl | 205 | 939.396 | 7.6 | 75.334 | 0.04979 | 0.004 | 7.1 | ug/L |
| Pb | 208 | 34928.487 | 0.1 | 440.342 | 1.41290 | 0.028 | 2.0 | ug/L |

Sample ID: 950031

Report Date/Time: Wednesday, November 22, 2006 14:37:12

Page 1

1050

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 9048.334 | 1.1 | 119.335 | 1.40860 | 0.012 | 0.8 ug/L |
| | Pb | 207 | 7294.932 | 1.6 | 109.335 | 1.35007 | 0.040 | 3.0 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| Al | 27 | | | | | |
| > Sc | 45 | | 134.716 | | | |
| V | 51 | | | | | |
| Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| Mn | 55 | | | | | |
| Co | 59 | | | | | |
| Ni | 60 | | | | | |
| Ni | 62 | | | | | |
| Cu | 63 | | | | | |
| Cu | 65 | | | | | |
| Zn | 66 | | | | | |
| Zn | 67 | | | | | |
| Zn | 68 | | | | | |
| > Ge | 72 | | 116.520 | | | |
| As | 75 | | | | | |
| Se | 77 | | | | | |
| Se | 78 | | | | | |
| Se | 82 | | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| Mo | 95 | | | | | |
| Mo | 97 | | | | | |
| Mo | 98 | | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | | | | | |
| Ag | 109 | | | | | |
| Cd | 111 | | | | | |
| Cd | 114 | | | | | |
| > In | 115 | | 106.654 | | | |
| Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| Ba | 135 | | | | | |
| Ba | 137 | | | | | |
| > Tb | 159 | | 96.040 | | | |
| > Ho | 165 | | 96.135 | | | |
| Tl | 203 | | | | | |
| Tl | 205 | | | | | |
| Pb | 208 | | | | | |
| Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: 950032

Sample Date/Time: Wednesday, November 22, 2006 14:40:09

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID: M3990146

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\950032.045

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1179.429 | 1.8 | 49.334 | 0.76436 | 0.010 | 1.3 | ug/L |
| Al | 27 | 31347665.117 | 0.5 | 2679.805 | 2660.99768 | 27.220 | 1.0 | ug/L |
| > Sc | 45 | 530086.828 | 0.7 | 378193.541 | | | | ug/L |
| V | 51 | 30345.010 | 289.4 | 4537.327 | 1.18136 | 4.379 | 370.7 | ug/L |
| Cr | 52 | 737367.884 | 11.1 | 15100.490 | 40.74277 | 4.539 | 11.1 | ug/L |
| Cr | 53 | 84184.258 | 0.4 | 618.029 | 39.17879 | 0.149 | 0.4 | ug/L |
| Mn | 55 | 12007406.121 | 2.3 | 580.693 | 578.46262 | 20.689 | 3.6 | ug/L |
| Co | 59 | 325794.853 | 1.2 | 202.004 | 18.16212 | 0.478 | 2.6 | ug/L |
| Ni | 60 | 296801.524 | 12.4 | 196.338 | 74.19524 | 10.390 | 14.0 | ug/L |
| Ni | 62 | 42508.591 | 1.8 | 499.020 | 67.53381 | 0.270 | 0.4 | ug/L |
| Cu | 63 | 49577.871 | 0.5 | 505.687 | 5.22852 | 0.106 | 2.0 | ug/L |
| Cu | 65 | 19445.188 | 0.3 | 212.672 | 4.20929 | 0.053 | 1.3 | ug/L |
| Zn | 66 | 185466.672 | 1.6 | 1298.448 | 69.48879 | 0.738 | 1.1 | ug/L |
| Zn | 67 | 30020.634 | 2.6 | 302.342 | 66.82066 | 2.624 | 3.9 | ug/L |
| Zn | 68 | 135055.000 | 2.4 | 996.736 | 70.11425 | 2.732 | 3.9 | ug/L |
| > Ge | 72 | 238058.259 | 1.5 | 197196.226 | | | | ug/L |
| As | 75 | 5121.960 | 3.7 | 96.335 | 1.70505 | 0.087 | 5.1 | ug/L |
| Se | 77 | 868.245 | 2.3 | 202.002 | 2.86278 | 0.073 | 2.5 | ug/L |
| Se | 78 | 17677.253 | 1.7 | 14431.438 | 0.37691 | 0.757 | 200.9 | mg/L |
| Se | 82 | 545.818 | 2.7 | 1747.050 | -5.29402 | 0.063 | 1.2 | ug/L |
| Kr | 83 | 427.349 | 5.3 | 1793.211 | | | | mg/L |
| Y | 89 | 831481.709 | 1.7 | 365281.373 | | | | ug/L |
| Mo | 95 | 5365.451 | 5.9 | 120.335 | 0.92429 | 0.053 | 5.7 | ug/L |
| Mo | 97 | 3182.306 | 1.7 | 52.667 | 0.87836 | 0.012 | 1.3 | ug/L |
| Mo | 98 | 8524.912 | 0.7 | 70.498 | 0.91920 | 0.016 | 1.7 | ug/L |
| Rh | 103 | 371976.256 | 3.4 | 350376.944 | | | | ug/L |
| Ag | 107 | 300.675 | 5.4 | 46.001 | 0.01736 | 0.001 | 7.5 | ug/L |
| Ag | 109 | 243.006 | 3.3 | 42.334 | 0.01422 | 0.001 | 5.2 | ug/L |
| Cd | 111 | 4254.203 | 0.6 | 203.876 | 1.20254 | 0.016 | 1.3 | ug/L |
| Cd | 114 | 8811.608 | 2.3 | 55.152 | 1.13469 | 0.029 | 2.5 | ug/L |
| > In | 115 | 406429.901 | 1.1 | 366049.872 | | | | ug/L |
| Sb | 121 | 689.035 | 3.5 | 54.667 | 0.06159 | 0.003 | 4.7 | ug/L |
| Sb | 123 | 531.122 | 4.4 | 37.221 | 0.06501 | 0.002 | 3.7 | ug/L |
| Ba | 135 | 132093.809 | 2.6 | 52.001 | 57.23763 | 2.327 | 4.1 | ug/L |
| Ba | 137 | 224051.030 | 1.6 | 70.668 | 57.52627 | 0.174 | 0.3 | ug/L |
| > Tb | 159 | 423424.580 | 1.6 | 427712.876 | | | | ug/L |
| > Ho | 165 | 410752.626 | 1.1 | 412683.278 | | | | ug/L |
| Tl | 203 | 703.037 | 12.9 | 51.667 | 0.08262 | 0.012 | 14.0 | ug/L |
| Tl | 205 | 1713.530 | 17.1 | 75.334 | 0.09095 | 0.017 | 18.2 | ug/L |
| Pb | 208 | 64167.904 | 2.1 | 440.342 | 2.52037 | 0.076 | 3.0 | ug/L |

Sample ID: 950032

Report Date/Time: Wednesday, November 22, 2006 14:43:11

Page 1

1053

| | | | | | | | | |
|--|----|-----|-----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 17018.200 | 1.9 | 119.335 | 2.57394 | 0.076 | 3.0 ug/L |
| | Pb | 207 | 13303.413 | 1.9 | 109.335 | 2.39263 | 0.064 | 2.7 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > Sc | 45 | | 140.163 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > Ge | 72 | | 120.722 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > In | 115 | | 111.031 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > Tb | 159 | | 98.997 | | | |
| > Ho | 165 | | 99.532 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 3

Sample Date/Time: Wednesday, November 22, 2006 14:46:06

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 3.046

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 1214.767 | 4.5 | 49.334 | 1.03321 | 0.066 | 6.4 | ug/L |
| Al | 27 | 95678.432 | 0.8 | 2679.805 | 10.18119 | 0.543 | 5.3 | ug/L |
| > Sc | 45 | 410693.900 | 4.5 | 378193.541 | | | | ug/L |
| V | 51 | 21556.096 | 1.4 | 4537.327 | 1.07437 | 0.052 | 4.9 | ug/L |
| Cr | 52 | 30663.286 | 0.8 | 15100.490 | 1.05037 | 0.093 | 8.8 | ug/L |
| Cr | 53 | 2863.521 | 4.8 | 618.029 | 1.33045 | 0.007 | 0.5 | ug/L |
| Mn | 55 | 20905.065 | 0.9 | 580.693 | 1.06528 | 0.012 | 1.1 | ug/L |
| Co | 59 | 17648.193 | 3.6 | 202.004 | 1.06075 | 0.034 | 3.2 | ug/L |
| Ni | 60 | 4054.027 | 1.6 | 196.338 | 1.04631 | 0.013 | 1.2 | ug/L |
| Ni | 62 | 967.066 | 3.2 | 499.020 | 0.73049 | 0.060 | 8.3 | ug/L |
| Cu | 63 | 9188.488 | 0.5 | 505.687 | 1.00562 | 0.016 | 1.6 | ug/L |
| Cu | 65 | 4415.881 | 1.8 | 212.672 | 1.00128 | 0.038 | 3.8 | ug/L |
| Zn | 66 | 17129.763 | 1.9 | 1298.448 | 6.47244 | 0.094 | 1.4 | ug/L |
| Zn | 67 | 2628.107 | 0.5 | 302.342 | 5.63982 | 0.088 | 1.6 | ug/L |
| Zn | 68 | 11906.623 | 2.7 | 996.736 | 6.17682 | 0.253 | 4.1 | ug/L |
| > Ge | 72 | 218112.929 | 1.8 | 197196.226 | | | | ug/L |
| As | 75 | 2969.892 | 0.2 | 96.335 | 1.06425 | 0.017 | 1.6 | ug/L |
| Se | 77 | 465.213 | 2.6 | 202.002 | 1.20972 | 0.021 | 1.8 | ug/L |
| Se | 78 | 16213.482 | 0.3 | 14431.438 | 0.40312 | 0.481 | 119.3 | mg/L |
| Se | 82 | 617.356 | 2.4 | 1747.050 | -4.86113 | 0.015 | 0.3 | ug/L |
| Kr | 83 | 332.343 | 4.6 | 1793.211 | | | | mg/L |
| Y | 89 | 420876.743 | 0.9 | 365281.373 | | | | ug/L |
| Mo | 95 | 5998.885 | 0.7 | 120.335 | 1.10069 | 0.031 | 2.8 | ug/L |
| Mo | 97 | 3752.216 | 4.0 | 52.667 | 1.10319 | 0.067 | 6.1 | ug/L |
| Mo | 98 | 9790.646 | 1.6 | 70.498 | 1.12167 | 0.041 | 3.7 | ug/L |
| Rh | 103 | 372116.704 | 1.8 | 350376.944 | | | | ug/L |
| Ag | 107 | 14806.293 | 1.8 | 46.001 | 1.08780 | 0.003 | 0.3 | ug/L |
| Ag | 109 | 14013.916 | 1.7 | 42.334 | 1.07453 | 0.005 | 0.4 | ug/L |
| Cd | 111 | 3537.564 | 0.8 | 203.876 | 1.05258 | 0.026 | 2.5 | ug/L |
| Cd | 114 | 7905.431 | 3.5 | 55.152 | 1.07890 | 0.026 | 2.4 | ug/L |
| > In | 115 | 383293.525 | 2.1 | 366049.872 | | | | ug/L |
| Sb | 121 | 10189.998 | 2.8 | 54.667 | 1.05301 | 0.031 | 3.0 | ug/L |
| Sb | 123 | 7569.543 | 2.6 | 37.221 | 1.06020 | 0.025 | 2.4 | ug/L |
| Ba | 135 | 2522.074 | 4.1 | 52.001 | 1.07548 | 0.035 | 3.2 | ug/L |
| Ba | 137 | 4206.104 | 1.9 | 70.668 | 1.06750 | 0.024 | 2.2 | ug/L |
| > Tb | 159 | 421462.957 | 1.8 | 427712.876 | | | | ug/L |
| > Ho | 165 | 407971.397 | 2.5 | 412683.278 | | | | ug/L |
| Tl | 203 | 8138.388 | 1.8 | 51.667 | 1.03253 | 0.014 | 1.3 | ug/L |
| Tl | 205 | 19905.945 | 0.3 | 75.334 | 1.10847 | 0.025 | 2.3 | ug/L |
| Pb | 208 | 26704.680 | 1.0 | 440.342 | 1.04607 | 0.018 | 1.8 | ug/L |

Sample ID: QC Std 3

Report Date/Time: Wednesday, November 22, 2006 14:49:07

Page 1

1056

| | | | | | | | | |
|--|----|-----|----------|-----|---------|---------|-------|----------|
| | Pb | 206 | 6842.545 | 2.7 | 119.335 | 1.03108 | 0.020 | 1.9 ug/L |
| | Pb | 207 | 5736.365 | 1.7 | 109.335 | 1.02792 | 0.035 | 3.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| Be | 9 | 103.321 | | | | |
| Al | 27 | 101.812 | | | | |
| > Sc | 45 | | 108.594 | | | |
| V | 51 | 107.437 | | | | |
| Cr | 52 | 105.037 | | | | |
| Cr | 53 | 133.045 | | | | |
| Mn | 55 | 106.528 | | | | |
| Co | 59 | 106.075 | | | | |
| Ni | 60 | 104.631 | | | | |
| Ni | 62 | 73.049 | | | | |
| Cu | 63 | 100.562 | | | | |
| Cu | 65 | 100.128 | | | | |
| Zn | 66 | 129.449 | | | | |
| Zn | 67 | 112.796 | | | | |
| Zn | 68 | 123.536 | | | | |
| > Ge | 72 | | 110.607 | | | |
| As | 75 | 106.425 | | | | |
| Se | 77 | 120.972 | | | | |
| Se | 78 | 40.312 | | | | |
| Se | 82 | -486.113 | | | | |
| Kr | 83 | | | | | |
| Y | 89 | | | | | |
| Mo | 95 | 110.069 | | | | |
| Mo | 97 | 110.319 | | | | |
| Mo | 98 | 112.167 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 108.780 | | | | |
| Ag | 109 | 107.453 | | | | |
| Cd | 111 | 105.258 | | | | |
| Cd | 114 | 107.890 | | | | |
| > In | 115 | | 104.711 | | | |
| Sb | 121 | 105.301 | | | | |
| Sb | 123 | 106.020 | | | | |
| Ba | 135 | 107.548 | | | | |
| Ba | 137 | 106.750 | | | | |
| > Tb | 159 | | 98.539 | | | |
| > Ho | 165 | | 98.858 | | | |
| Tl | 203 | 103.253 | | | | |
| Tl | 205 | 110.847 | | | | |
| Pb | 208 | 104.607 | | | | |
| Pb | 206 | 103.108 | | | | |
| Pb | 207 | 102.792 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 6

Sample Date/Time: Wednesday, November 22, 2006 14:52:04

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 6.047

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 54537.422 | 0.1 | 49.334 | 50.08772 | 1.496 | 3.0 | ug/L |
| Al | 27 | 453031.190 | 2.5 | 2679.805 | 51.02215 | 1.465 | 2.9 | ug/L |
| Sc | 45 | 397223.175 | 3.0 | 378193.541 | | | | ug/L |
| V | 51 | 790126.485 | 2.8 | 4537.327 | 52.39151 | 0.308 | 0.6 | ug/L |
| Cr | 52 | 688820.238 | 2.0 | 15100.490 | 51.13562 | 2.145 | 4.2 | ug/L |
| Cr | 53 | 81108.354 | 1.7 | 618.029 | 50.50182 | 0.736 | 1.5 | ug/L |
| Mn | 55 | 940533.488 | 1.4 | 580.693 | 51.28539 | 1.210 | 2.4 | ug/L |
| Co | 59 | 803800.940 | 2.0 | 202.004 | 50.76394 | 0.251 | 0.5 | ug/L |
| Ni | 60 | 177338.834 | 0.1 | 196.338 | 50.13570 | 1.024 | 2.0 | ug/L |
| Ni | 62 | 27215.984 | 1.7 | 499.020 | 48.70926 | 0.187 | 0.4 | ug/L |
| Cu | 63 | 419188.033 | 3.9 | 505.687 | 50.60732 | 1.021 | 2.0 | ug/L |
| Cu | 65 | 201774.332 | 0.9 | 212.672 | 50.08270 | 1.070 | 2.1 | ug/L |
| Zn | 66 | 116274.728 | 2.5 | 1298.448 | 49.17202 | 1.013 | 2.1 | ug/L |
| Zn | 67 | 19377.381 | 3.5 | 302.342 | 48.60466 | 0.922 | 1.9 | ug/L |
| Zn | 68 | 83606.219 | 1.7 | 996.736 | 48.97145 | 1.564 | 3.2 | ug/L |
| Ge | 72 | 210186.502 | 2.1 | 197196.226 | | | | ug/L |
| As | 75 | 127849.333 | 2.7 | 96.335 | 49.26376 | 0.991 | 2.0 | ug/L |
| Se | 77 | 10094.110 | 0.9 | 202.002 | 51.31271 | 1.103 | 2.1 | ug/L |
| Se | 78 | 45754.405 | 4.2 | 14431.438 | 49.87814 | 3.827 | 7.7 | mg/L |
| Se | 82 | 13914.348 | 3.2 | 1747.050 | 46.22512 | 0.857 | 1.9 | ug/L |
| Kr | 83 | 323.343 | 6.8 | 1793.211 | | | | mg/L |
| Y | 89 | 406489.349 | 3.8 | 365281.373 | | | | ug/L |
| Mo | 95 | 285445.767 | 0.8 | 120.335 | 54.19094 | 0.560 | 1.0 | ug/L |
| Mo | 97 | 181690.179 | 2.9 | 52.667 | 54.92054 | 2.385 | 4.3 | ug/L |
| Mo | 98 | 472879.282 | 0.7 | 70.498 | 55.30681 | 0.907 | 1.6 | ug/L |
| Rh | 103 | 357605.260 | 1.7 | 350376.944 | | | | ug/L |
| Ag | 107 | 694668.701 | 4.1 | 46.001 | 51.88568 | 1.393 | 2.7 | ug/L |
| Ag | 109 | 652294.995 | 3.9 | 42.334 | 50.84960 | 1.611 | 3.2 | ug/L |
| Cd | 111 | 159155.218 | 2.6 | 203.876 | 51.00196 | 1.021 | 2.0 | ug/L |
| Cd | 114 | 370385.838 | 2.9 | 55.152 | 51.60558 | 0.605 | 1.2 | ug/L |
| In | 115 | 378129.081 | 1.8 | 366049.872 | | | | ug/L |
| Sb | 121 | 479834.866 | 1.2 | 54.667 | 50.53634 | 0.516 | 1.0 | ug/L |
| Sb | 123 | 347450.986 | 0.8 | 37.221 | 49.58638 | 1.150 | 2.3 | ug/L |
| Ba | 135 | 115243.281 | 2.8 | 52.001 | 51.15484 | 1.283 | 2.5 | ug/L |
| Ba | 137 | 195410.072 | 3.9 | 70.668 | 51.43123 | 2.352 | 4.6 | ug/L |
| Tb | 159 | 413141.563 | 1.1 | 427712.876 | | | | ug/L |
| Ho | 165 | 395054.097 | 1.9 | 412683.278 | | | | ug/L |
| Tl | 203 | 373716.290 | 1.9 | 51.667 | 49.25896 | 0.137 | 0.3 | ug/L |
| Tl | 205 | 897499.494 | 1.4 | 75.334 | 51.78929 | 0.913 | 1.8 | ug/L |
| Pb | 208 | 1215435.646 | 1.0 | 440.342 | 49.95707 | 0.544 | 1.1 | ug/L |

Sample ID: QC Std 6

Report Date/Time: Wednesday, November 22, 2006 14:55:06

Page 1

1059

| | | | | | | | | |
|--|----|-----|------------|-----|---------|----------|-------|----------|
| | Pb | 206 | 314146.152 | 3.5 | 119.335 | 49.71051 | 0.863 | 1.7 ug/L |
| | Pb | 207 | 259149.695 | 1.1 | 109.335 | 48.85048 | 1.429 | 2.9 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | 100.175 | | | | |
| Al | 27 | 102.044 | | | | |
| > Sc | 45 | | 105.032 | | | |
| V | 51 | 104.783 | | | | |
| Cr | 52 | 102.271 | | | | |
| [Cr | 53 | 101.004 | | | | |
| Mn | 55 | 102.571 | | | | |
| Co | 59 | 101.528 | | | | |
| Ni | 60 | 100.271 | | | | |
| Ni | 62 | 97.419 | | | | |
| Cu | 63 | 101.215 | | | | |
| Cu | 65 | 100.165 | | | | |
| Zn | 66 | 98.344 | | | | |
| Zn | 67 | 97.209 | | | | |
| Zn | 68 | 97.943 | | | | |
| > Ge | 72 | | 106.587 | | | |
| As | 75 | 98.528 | | | | |
| Se | 77 | 102.625 | | | | |
| Se | 78 | 99.756 | | | | |
| Se | 82 | 92.450 | | | | |
| Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| Mo | 95 | 108.382 | | | | |
| Mo | 97 | 109.841 | | | | |
| Mo | 98 | 110.614 | | | | |
| Rh | 103 | | | | | |
| Ag | 107 | 103.771 | | | | |
| Ag | 109 | 101.699 | | | | |
| Cd | 111 | 102.004 | | | | |
| Cd | 114 | 103.211 | | | | |
| > In | 115 | | 103.300 | | | |
| Sb | 121 | 101.073 | | | | |
| [Sb | 123 | 99.173 | | | | |
| Ba | 135 | 102.310 | | | | |
| Ba | 137 | 102.862 | | | | |
| > Tb | 159 | | 96.593 | | | |
| > Ho | 165 | | 95.728 | | | |
| Tl | 203 | 98.518 | | | | |
| Tl | 205 | 103.579 | | | | |
| Pb | 208 | 99.914 | | | | |
| Pb | 206 | 99.421 | | | | |
| [Pb | 207 | 97.701 | | | | |

Elan 9000 Method 6020 - Summary Report

Sample ID: QC Std 7

Sample Date/Time: Wednesday, November 22, 2006 14:58:02

Sample Type:

Sample Description:

Number of Replicates: 3

Batch ID:

Method File: c:\elandata\Method\epa 6020b.mth

Dataset File: C:\elandata\Dataset\112206\QC Std 7.048

| Analyte | Mass | Meas. Intens. | Intens. RSD | Blank Intensity | Conc. Mean | Conc. SD | Conc. RSD | Units |
|---------|------|---------------|-------------|-----------------|------------|----------|-----------|-------|
| Be | 9 | 49.001 | 10.8 | 49.334 | -0.00428 | 0.005 | 106.6 | ug/L |
| Al | 27 | 2727.474 | 1.1 | 2679.805 | -0.02141 | 0.005 | 21.5 | ug/L |
| > Sc | 45 | 412663.121 | 1.4 | 378193.541 | | | | ug/L |
| V | 51 | 4570.405 | 2.1 | 4537.327 | -0.02434 | 0.010 | 40.3 | ug/L |
| Cr | 52 | 15249.093 | 1.4 | 15100.490 | -0.08957 | 0.023 | 25.7 | ug/L |
| Cr | 53 | 794.713 | 5.9 | 618.029 | 0.07264 | 0.026 | 35.7 | ug/L |
| Mn | 55 | 580.359 | 4.7 | 580.693 | -0.00243 | 0.002 | 62.4 | ug/L |
| Co | 59 | 169.670 | 12.1 | 202.004 | -0.00299 | 0.001 | 45.0 | ug/L |
| Ni | 60 | 222.672 | 39.8 | 196.338 | 0.00337 | 0.026 | 768.1 | ug/L |
| Ni | 62 | 383.679 | 2.2 | 499.020 | -0.27774 | 0.022 | 7.8 | ug/L |
| Cu | 63 | 406.681 | 1.8 | 505.687 | -0.01651 | 0.001 | 6.8 | ug/L |
| Cu | 65 | 199.004 | 3.1 | 212.672 | -0.00738 | 0.002 | 28.0 | ug/L |
| Zn | 66 | 1281.445 | 4.8 | 1298.448 | -0.04980 | 0.020 | 39.2 | ug/L |
| Zn | 67 | 291.675 | 5.1 | 302.342 | -0.08581 | 0.037 | 43.0 | ug/L |
| Zn | 68 | 953.397 | 1.8 | 996.736 | -0.07059 | 0.007 | 9.8 | ug/L |
| > Ge | 72 | 212421.070 | 1.4 | 197196.226 | | | | ug/L |
| As | 75 | 140.336 | 9.0 | 96.335 | 0.01400 | 0.006 | 39.9 | ug/L |
| Se | 77 | 234.870 | 2.2 | 202.002 | 0.08893 | 0.033 | 36.8 | ug/L |
| Se | 78 | 15240.844 | 1.7 | 14431.438 | -0.49333 | 0.426 | 86.4 | mg/L |
| Se | 82 | 340.140 | 1.9 | 1747.050 | -5.85182 | 0.031 | 0.5 | ug/L |
| Kr | 83 | 325.676 | 4.5 | 1793.211 | | | | mg/L |
| Y | 89 | 406483.312 | 0.7 | 365281.373 | | | | ug/L |
| Mo | 95 | 662.700 | 20.2 | 120.335 | 0.09818 | 0.022 | 22.2 | ug/L |
| Mo | 97 | 404.347 | 21.5 | 52.667 | 0.10181 | 0.023 | 22.3 | ug/L |
| Mo | 98 | 996.680 | 28.5 | 70.498 | 0.10416 | 0.030 | 28.4 | ug/L |
| Rh | 103 | 357338.810 | 0.8 | 350376.944 | | | | ug/L |
| Ag | 107 | 143.003 | 15.8 | 46.001 | 0.00680 | 0.001 | 20.6 | ug/L |
| Ag | 109 | 145.669 | 11.7 | 42.334 | 0.00760 | 0.001 | 13.4 | ug/L |
| Cd | 111 | 238.575 | 9.6 | 203.876 | 0.00678 | 0.008 | 111.3 | ug/L |
| Cd | 114 | 74.077 | 13.2 | 55.152 | 0.00207 | 0.001 | 56.2 | ug/L |
| > In | 115 | 389552.067 | 2.6 | 366049.872 | | | | ug/L |
| Sb | 121 | 1200.767 | 19.9 | 54.667 | 0.11645 | 0.021 | 18.4 | ug/L |
| Sb | 123 | 863.087 | 19.2 | 37.221 | 0.11375 | 0.020 | 17.7 | ug/L |
| Ba | 135 | 43.001 | 8.1 | 52.001 | -0.00335 | 0.001 | 43.9 | ug/L |
| Ba | 137 | 47.667 | 17.5 | 70.668 | -0.00552 | 0.002 | 37.8 | ug/L |
| > Tb | 159 | 416198.054 | 0.7 | 427712.876 | | | | ug/L |
| > Ho | 165 | 407479.229 | 1.6 | 412683.278 | | | | ug/L |
| Tl | 203 | 66.001 | 6.6 | 51.667 | 0.00191 | 0.000 | 21.8 | ug/L |
| Tl | 205 | 121.335 | 12.0 | 75.334 | 0.00262 | 0.001 | 28.3 | ug/L |
| Pb | 208 | 327.672 | 4.3 | 440.342 | -0.00427 | 0.000 | 8.1 | ug/L |

| | | | | | | | | |
|--|----|-----|--------|------|---------|----------|-------|-----------|
| | Pb | 206 | 92.335 | 14.9 | 119.335 | -0.00393 | 0.002 | 47.7 ug/L |
| | Pb | 207 | 74.001 | 2.3 | 109.335 | -0.00620 | 0.000 | 7.4 ug/L |

QC Calculated Values

| Analyte | Mass | QC Std % Recovery | Int Std % Recovery | Spike % Recovery | Dilution % Diff | Dup. Rel. % Diff |
|---------|------|-------------------|--------------------|------------------|-----------------|------------------|
| [Be | 9 | | | | | |
| [Al | 27 | | | | | |
| > [Sc | 45 | | 109.114 | | | |
| [V | 51 | | | | | |
| [Cr | 52 | | | | | |
| [Cr | 53 | | | | | |
| [Mn | 55 | | | | | |
| [Co | 59 | | | | | |
| [Ni | 60 | | | | | |
| [Ni | 62 | | | | | |
| [Cu | 63 | | | | | |
| [Cu | 65 | | | | | |
| [Zn | 66 | | | | | |
| [Zn | 67 | | | | | |
| [Zn | 68 | | | | | |
| > [Ge | 72 | | 107.721 | | | |
| [As | 75 | | | | | |
| [Se | 77 | | | | | |
| [Se | 78 | | | | | |
| [Se | 82 | | | | | |
| [Kr | 83 | | | | | |
| [Y | 89 | | | | | |
| [Mo | 95 | | | | | |
| [Mo | 97 | | | | | |
| [Mo | 98 | | | | | |
| [Rh | 103 | | | | | |
| [Ag | 107 | | | | | |
| [Ag | 109 | | | | | |
| [Cd | 111 | | | | | |
| [Cd | 114 | | | | | |
| > [In | 115 | | 106.420 | | | |
| [Sb | 121 | | | | | |
| [Sb | 123 | | | | | |
| [Ba | 135 | | | | | |
| [Ba | 137 | | | | | |
| > [Tb | 159 | | 97.308 | | | |
| > [Ho | 165 | | 98.739 | | | |
| [Tl | 203 | | | | | |
| [Tl | 205 | | | | | |
| [Pb | 208 | | | | | |
| [Pb | 206 | | | | | |
| [Pb | 207 | | | | | |

Quantitative Analysis Calibration Report

File Name: 112206.cal
File Path: C:\elandata\System
Calibration Type: External Calibration

| Analyte | Mass | Curve Type | Slope | Intercept | Corr. Coeff. |
|---------|---------|------------------|-------|-----------|--------------|
| Be | 9.012 | Linear Thru Zero | 0.00 | 0.00 | 0.999954 |
| Al | 26.982 | Linear Thru Zero | 0.02 | 0.00 | 0.999963 |
| Sc | 44.956 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| V | 50.944 | Linear Thru Zero | 0.04 | 0.00 | 0.999901 |
| Cr | 51.941 | Linear Thru Zero | 0.03 | 0.00 | 0.999980 |
| Cr | 52.941 | Linear Thru Zero | 0.00 | 0.00 | 0.999977 |
| Mn | 54.938 | Linear Thru Zero | 0.09 | 0.00 | 0.999986 |
| Co | 58.933 | Linear Thru Zero | 0.08 | 0.00 | 0.999943 |
| Ni | 59.933 | Linear Thru Zero | 0.02 | 0.00 | 0.999994 |
| Ni | 61.928 | Linear Thru Zero | 0.00 | 0.00 | 0.999992 |
| Cu | 62.930 | Linear Thru Zero | 0.04 | 0.00 | 0.999996 |
| Cu | 64.928 | Linear Thru Zero | 0.02 | 0.00 | 0.999965 |
| Zn | 65.926 | Linear Thru Zero | 0.01 | 0.00 | 0.999987 |
| Zn | 66.927 | Linear Thru Zero | 0.00 | 0.00 | 0.999977 |
| Zn | 67.925 | Linear Thru Zero | 0.01 | 0.00 | 0.999983 |
| Ge | 71.922 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| As | 74.922 | Linear Thru Zero | 0.01 | 0.00 | 0.999993 |
| Se | 76.920 | Linear Thru Zero | 0.00 | 0.00 | 0.999998 |
| Se | 77.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999927 |
| Se | 81.917 | Linear Thru Zero | 0.00 | 0.00 | 0.999970 |
| Kr | 82.914 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Y | 88.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Mo | 94.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999978 |
| Mo | 96.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999993 |
| Mo | 97.906 | Linear Thru Zero | 0.02 | 0.00 | 0.999976 |
| Rh | 102.905 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ag | 106.905 | Linear Thru Zero | 0.04 | 0.00 | 0.999896 |
| Ag | 108.905 | Linear Thru Zero | 0.03 | 0.00 | 0.999918 |
| Cd | 110.904 | Linear Thru Zero | 0.01 | 0.00 | 0.999999 |
| Cd | 113.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999995 |
| In | 114.904 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Sb | 120.904 | Linear Thru Zero | 0.03 | 0.00 | 0.999981 |
| Sb | 122.904 | Linear Thru Zero | 0.02 | 0.00 | 0.999967 |
| Ba | 134.906 | Linear Thru Zero | 0.01 | 0.00 | 0.999939 |
| Ba | 136.905 | Linear Thru Zero | 0.01 | 0.00 | 0.999936 |
| Tb | 158.925 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Ho | 164.930 | Linear Thru Zero | 0.00 | 0.00 | 0.000000 |
| Tl | 202.972 | Linear Thru Zero | 0.02 | 0.00 | 0.999960 |
| Tl | 204.975 | Linear Thru Zero | 0.04 | 0.00 | 0.999908 |
| Pb | 207.977 | Linear Thru Zero | 0.06 | 0.00 | 0.999976 |

| | | | | | |
|----|---------|------------------|------|------|----------|
| Pb | 205.975 | Linear Thru Zero | 0.02 | 0.00 | 0.999946 |
| Pb | 206.976 | Linear Thru Zero | 0.01 | 0.00 | 0.999991 |

CAS - Rochester, NY: ICP-MS // GFAA Water Digestion Log

6010B/SW846 // 200 Series/Part 136 (6020) / 200.8 // CLP 5.3

Analyt: CAMW Date: 10/31/06

Report Type: Routine // 6 // ASP // Pkg 5

Prep Method: 3020 Modified // CLP

Spike Witness / Lot Approval: DK 10/31/06

Digest: Initial Redigest Of: _____

Batch ID: M3990131

Batch Temp: 93°C

| Submission / Order # | pH | Initial Vol(ml) | Final Vol(ml) | Initial Color / Clarity | Final Color / Clarity | Metals | Spike Added Vol(ml) |
|----------------------|----|-----------------|---------------|-------------------------|-----------------------|--|-----------------------|
| 1 | | 50 | 50 | C-CUR | C-CUR | | |
| 2 | | | | Y-CUR | | As, Be, Cd, Co, Mn, Ni by MSX Se, Ti by GFAA | 0.1 ml spk #1, spk #2 |
| 3 | <2 | | | | | As, Be, Cd, Co, Mn, Ni by 1CPMS | |
| 4 | | | | | | | |
| 5 | | | | | | | |
| 6 | | | | | | | |
| 7 | | | | | | | |
| 8 | | | | | | | |
| 9 | | | | | | | |
| 10 | | | | | | | |
| 11 | | | | | | | |
| 12 | | | | | | | |
| 13 | | | | | | | |
| 14 | | | | | | | |
| 15 | | | | | | | |
| 16 | | | | B-CDY | | Se, Ti by GFAA | 0.1 ml spk #1, spk #2 |
| 17 | <2 | | | Y-CUR | | | TO IDL |
| 18 | | | | C-CUR | | As, Mn by 1CPMS | |
| 19 | <2 | | | | | | |
| 20 | | | | | | | |
| 21 | | | | | | | |
| 22 | | | | | | | |
| 23 | | | | | | | |
| 24 | <2 | 50 | | C-CUR | | SEE BELOW | 0.1 ml spk #1, spk #2 |
| 25 | | | | | | | |
| 26 | | | | | | | |

Spiking Standards / Reagent Lot Numbers:
 Spike A, B: _____ Spike 4: _____
 MS Spk 1: M1780069J MS Spk 2: M1780069I
 HNO3: M1780071Q HCL: _____
 H2O2: M1780071S

Color / Clarity Key:
 Color: C = Colorless; Y = Yellow; B = Brown; G = Grey
 BL = Black
 Clarity: CDY = Cloudy; CLR = Clear; OP = Opaque

HB#1 R-33943 = As, Pb, Se, Ti by GFAA **131**
 COMMENTS: R-33532 = RTN = As, Be, Cd, Co, Mn, Ni, Pb, Se, Ti by GFAA
 by VMS

Analyst: CMW Date: 11/15/06

Report Type: Routine // 6 // ASP // Pkg5

Batch ID: M3990143

Prep Method: 3020 Modified // CLP

Spike Witness / Lot Approval: DK 11/15/06

Batch Temp: 940C

Digest: Initial Redigest OR M3990131

| Submission / Order # | pH | Initial Vol(ml) | Final Vol(ml) | Initial Color / Clarity | Final Color / Clarity | Metals | Spike Added Vol(ml) |
|----------------------|----|-----------------|---------------|-------------------------|-----------------------|--------------------|---------------------|
| 1 | | 50 | 50 | C-CUR | C-CUR | As, Be, Cu, Mn, Cd | 0.1ml spike #1, #2 |
| 2 | | | | Y-CUR | | Be, Cu, Mn | |
| 3 R-34493 | <2 | | | | | | |
| 4 | | | | | | | |
| 5 | | | | | | | |
| 6 | | | | | | | |
| 7 | | | | | | | |
| 8 | | | | | | | |
| 9 | | | | | | | |
| 10 | | | | | | | |
| 11 | | | | | | | |
| 12 | | | | | | | |
| 13 | | | | | | | |
| 14 | | | | | | | |
| 15 | | | | | | | |
| 16 | | | | | | | |
| 17 R-34382 | <2 | | | C-CUR | | As, Mn | 0.1ml spike #1, #2 |
| 18 | | | | | | | |
| 19 | | | | | | | |
| 20 | | | | | | | |
| 21 | | | | | | | |
| 22 | | | | | | | |
| 23 | | | | | | | |
| 24 | | | | | | | |
| 25 | | | | | | | |
| 26 | | | | | | | |

Color / Clarity Key:
 Color: C = Colorless; Y = Yellow; B = Brown; G = Grey
 BL = Black
 Clarity: CDY = Cloudy; CLR = Clear; OP = Opaque

Spiking Standards / Reagent Lot Numbers:
 Spike A, B: _____ Spike 4: _____
 MS Spk 1: M1780073P MS Spk 2: M1780073Q
 HNO3: M1780073N HCL: _____
 H2O2: M1780071S

CPI-A

COMMENTS:

CAS - Rochester, NY: ICP-MS // GFAA Water Digestion Log

6010B/SW846 // 200Series/Part136 // 6020 // 200.8 // CLP5.3

Analyst: CMW Date: 11/15/06

Report Type: Routine // 6 // ASP // Pkg5

Prep Method: 3020 Modified // CLP

Spike Witness / Lot Approval: DK 11/15/06

Batch ID: M390146

Batch Temp: 93.0C

Digest: Initial // Redigest Of: _____

| Submission / Order # | pH | Initial Vol(ml) | Final Vol(ml) | Initial Color / Clarity | Final Color / Clarity | Metals | Spike Added Vol(ml) |
|----------------------|----|-----------------|---------------|-------------------------|-----------------------|----------------------------|--------------------------------|
| 1 | | 50 | 50 | C-CUR | C-CUR | As, Be, Cd, Cu, Mn, Ni, Pb | |
| 2 | | | | Y-CUR | | | |
| 3 | ~2 | | | | | As, Be, Cd, Cu, Mn, Ni | Dil. metal spike #1, #2 846 |
| 4 | | | | | | | |
| 5 | | | | | | | |
| 6 | | | | | | | |
| 7 | | | | | | | |
| 8 | | | | | | | |
| 9 | | | | | | | |
| 10 | | | | | | | |
| 11 | | | | | | | |
| 12 | ~2 | | | | | Pb | 136 GE |
| 13 | | | | | | | |
| 14 | | | | | | | |
| 15 | | | | | | | |
| 16 | | | | | | | |
| 17 | | | | | | | |
| 18 | | | | | | | |
| 19 | | | | | | | |
| 20 | | | | | | | |
| 21 | | | | | | | |
| 22 | | | | | | | |
| 23 | | | | | | | |
| 24 | | | | | | | |
| 25 | | | | | | | |
| 26 | | | | | | | |

CMW
11/15/06

Spiking Standards / Reagent Lot Numbers:
 Spike A, B: _____ Spike 4: _____
 MS Spk 1: M1780073P MS Spk 2: M1780073Q
 HNO3: M1780073N HCL: _____
 H2O2: M1780071S

Color / Clarity Key:
 Color: C = Colorless ; Y = Yellow ; B = Brown ; G = Grey
 BL = Black
 Clarity: CDY = Cloudy ; CLR = Clear ; OP = Opaque

HB #1 R-34493=ASP

COMMENTS:

P-MS CALIBRATION STANDARD #1
 REPAIRED MONTHLY OR AS NECESSARY

| Metal | CAS Lot # | Conc. (ppb) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst / Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|-------|-----------|-------------|------------|------------------|-------------------|---------------------|----------------|-----------|-------------------|-----------|-----------------|----------|
| SB | M1780065G | 20000 | 0.250 | 500 | 10 | 1% HNO ₃ | SD 2/3/06 | A | M1780065G | - | 3/3/06 | M13 |
| MO | | | | | | | SD 3/16/06 | B | M17800670 | - | 4/16/06 | M13 |
| AL | | | 0.250 | | | | DCS 4/6/06 | C | M17800670 | - | 5/6/06 | M7 |
| AS | M1780067H | | | | | | SD 5/1/06 | D | M1780068G | - | 6/1/06 | M13 |
| BA | | | | | | | SD 5/17/06 | E | M1780068W | - | 6/17/06 | M13 |
| BE | | | | | | | DCS 6/2/06 | F | M1780068D | - | 7/2/06 | M13 |
| CD | | | | | | | SD 6/23/06 | G | M1780070G | - | 7/23/06 | M13 |
| CR | | | | | | | SD 7/24/06 | H | M1780070G | - | 8/24/06 | M13 |
| CO | | | | | | | DCS 8/18/06 | I | M1780070G | - | 9/18/06 | M13 |
| CU | | | | | | | SD 9/8/06 | J | M1780070G | - | 10/8/06 | M13 |
| PB | | | | | | | DCS 10/14/06 | K | M1780071Q | - | 11/4/06 | M13 |
| MN | | | | | | | SD 10/18/06 | L | M1780071Q | - | 11/25/06 | M13 |
| NI | | | | | | | SD 10/24/06 | M | M1780071Q | - | 11/30/06 | M13 |
| AG | | | | | | | | N | | | | |
| TL | | | | | | | | O | | | | |
| V | | | | | | | | P | | | | |
| ZN | | | | | | | | Q | | | | |
| SE | | | | | | | | R | | | | |

1070

SD 11/15/06
 SD 11/16/06

CP-MS CALIBRATION STANDARD #1
 PREPARED MONTHLY OR AS NECESSARY

| Cal Std | Metal | CAS Lot # | Conc. (ppb) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst / Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|-----------|-------|-----------|-------------|------------|------------------|-------------------|---------------------|----------------|-----------|-------------------|-----------|-----------------|----------|
| Cal Std 1 | SB | M17800656 | 20000 | 0.250 | 500 | 10 | 1% HNO ₃ | SD 11/14/06 | A | M1780073N | — | 12/14/06 | M/3 |
| | MO | — | | | | | | | B | | | | |
| Cal Std 2 | AL | M1780073Y | | 0.250 | | | | | C | | | | |
| | AS | | | | | | | | D | | | | |
| | BA | | | | | | | | E | | | | |
| | BE | | | | | | | | F | | | | |
| | CD | | | | | | | | G | | | | |
| | CR | | | | | | | | H | | | | |
| | CO | | | | | | | | I | | | | |
| | CU | | | | | | | | J | | | | |
| | PB | | | | | | | | K | | | | |
| | MN | | | | | | | | L | | | | |
| | NI | | | | | | | | M | | | | |
| | AG | | | | | | | | N | | | | |
| | TL | | | | | | | | O | | | | |
| | V | | | | | | | | P | | | | |
| | ZN | | | | | | | | Q | | | | |
| | SE | | | | | | | | R | | | | |

MS CALIBRATION STANDARD #2
 SPARED MONTHLY OR AS NECESSARY

| Metal | CAS Lot # | Conc. (ppb) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst/ Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|-------|-----------|-------------|------------|------------------|-------------------|---------|---------------|-----------|-------------------|-----------|-----------------|----------|
| SB | M17800656 | 20000 | 0.500 | 500 | 20 | 1% HNO3 | SD 2/3/06 | A | M17800654 | - | 3/3/06 | M13 |
| MO | | | | | | | SD 3/6/06 | B | M17800670 | - | 4/6/06 | M13 |
| AL | | | 0.500 | | | | DCS 4/6/06 | C | M17800670 | - | 5/6/06 | M10 |
| AS | M1780067A | | | | | | SN 5/1/06 | D | M1780068W | - | 6/1/06 | M10 |
| BA | | | | | | | SD 5/17/06 | E | M1780068W | - | 6/17/06 | M13 |
| BE | | | | | | | DCS 6/6/06 | F | M17800682 | - | 7/2/06 | M13 |
| CD | | | | | | | SD 6/23/06 | G | M17800670G | - | 7/23/06 | M13 |
| CR | | | | | | | SD 7/14/06 | H | M1780070G | - | 8/24/06 | M13 |
| CO | | | | | | | DCS 8/18/06 | I | M17800706 | - | 9/18/06 | M23 |
| CU | | | | | | | SD 9/8/06 | J | M1780070G | - | 10/8/06 | M23 |
| PB | | | | | | | DCS 10/4/06 | K | M17800710 | - | 11/4/06 | M23 |
| MN | | | | | | | SD 10/25/06 | L | M1780071Q | - | 11/25/06 | M23 |
| NI | | | | | | | SN 10/23/06 | M | M1780071Q | - | 11/30/06 | M23 |
| AG | | | | | | | | N | | | | |
| TL | | | | | | | | O | | | | |
| V | | | | | | | | P | | | | |
| ZN | | | | | | | | Q | | | | |
| SE | | | | | | | | R | | | | |

SD 11/5/06
 SD 10/17/06

CP-MS CALIBRATION STANDARD #2
 PREPARED MONTHLY OR AS NECESSARY

| Cal Std | Metal | CAS Lot # | Conc. (ppb) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst / Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|-----------|-------|-----------|-------------|------------|------------------|-------------------|---------------------|----------------|-----------|-------------------|-----------|-----------------|----------|
| Cal Std 1 | SB | M1780065G | 20000 | 0.500 | 500 | 20 | 1% HNO ₃ | SD 11/14/06 | A | M1180073N | - | 12/14/06 | M13 |
| | MO | _____ | | | | | | | B | | | | |
| Cal Std 2 | AL | M1780073X | | 0.500 | | | | | C | | | | |
| | AS | | | | | | | | D | | | | |
| | BA | | | | | | | | E | | | | |
| | BE | | | | | | | | F | | | | |
| | CD | | | | | | | | G | | | | |
| | CR | | | | | | | | H | | | | |
| | CO | | | | | | | | I | | | | |
| | CU | | | | | | | | J | | | | |
| | PB | | | | | | | | K | | | | |
| | MN | | | | | | | | L | | | | |
| | NI | | | | | | | | M | | | | |
| | AG | | | | | | | | N | | | | |
| | TL | | | | | | | | O | | | | |
| | V | | | | | | | | P | | | | |
| | ZN | | | | | | | | Q | | | | |
| | SE | | | | | | | | R | | | | |

CP-MS CALIBRATION STANDARD #3
 PREPARED MONTHLY OR AS NECESSARY

| Cal Std | Metal | CAS Lot # | Conc (ppb) | Vol (mls) | Final Vol (mls) | Final Conc (ppb) | Matrix | Analyst / Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|-----------|-------|-----------|------------|-----------|-----------------|------------------|---------------------|----------------|-----------|-------------------|-----------|-----------------|----------|
| Cal Std 1 | SB | M1780065G | 20000 | 2.50 | 500 | 100 | 1% HNO ₃ | SD 2/3/06 | A | M1780065G | - | 3/3/06 | M18 |
| | MO | | | | | | | SD 3/6/06 | B | M17800670 | - | 4/6/06 | M18/M19 |
| Cal Std 2 | AL | M1780067H | | 2.50 | | | | DCB 4/4/06 | C | M17800670 | - | 5/6/06 | M18 |
| | AS | | | | | | | SD 5/1/06 | D | M1780068W | - | 6/1/06 | M18 |
| | BA | | | | | | | SD 5/17/06 | E | M1780068W | - | 6/17/06 | M18 |
| | BE | | | | | | | DCB 6/2/06 | F | M1780068W | - | 7/2/06 | M18 |
| | CD | | | | | | | SD 6/23/06 | G | M1780070G | - | 7/23/06 | M18/M19 |
| | CR | | | | | | | SD 7/24/06 | H | M1780070G | - | 8/24/06 | M18/M19 |
| | CO | | | | | | | DCB 8/18/06 | I | M1780070G | - | 9/18/06 | M18 |
| | CU | | | | | | | SD 9/18/06 | J | M1780070G | - | 10/18/06 | M18/M19 |
| | PB | | | | | | | DCB 10/4/06 | K | M1780071Q | - | 11/4/06 | M18 |
| | MN | | | | | | | SD 10/25/06 | L | M1780071Q | - | 11/25/06 | M18 |
| | NI | | | | | | | SD 10/21/06 | M | M1780071Q | - | 11/30/06 | M18/M19 |
| | AG | | | | | | | | N | | | | |
| | TL | | | | | | | | O | | | | |
| | V | | | | | | | | P | | | | |
| | ZN | | | | | | | | Q | | | | |
| | SE | | | | | | | | R | | | | |

✓ SD 4/5/06
 SD 7/14/06

ICP-MS CALIBRATION STANDARD #3
(PREPARED MONTHLY OR AS NECESSARY)

| Metal | CAS Lot # | Conc. (ppb) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst / Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|-----------|-----------|-------------|------------|------------------|-------------------|---------------------|----------------|-----------|-------------------|-----------|-----------------|----------|
| Cal Std 1 | M17800656 | 20000 | 2.50 | 500 | 100 | 1% HNO ₃ | SJ 11/14/06 | A | M17800732 | - | 12/14/06 | MIR/ADJ |
| | | | | | | | | B | | | | |
| Cal Std 2 | M1780073X | | 2.50 | | | | | C | | | | |
| | | | | | | | | D | | | | |
| | | | | | | | | E | | | | |
| | | | | | | | | F | | | | |
| | | | | | | | | G | | | | |
| | | | | | | | | H | | | | |
| | | | | | | | | I | | | | |
| | | | | | | | | J | | | | |
| | | | | | | | | K | | | | |
| | | | | | | | | L | | | | |
| | | | | | | | | M | | | | |
| | | | | | | | | N | | | | |
| | | | | | | | | O | | | | |
| | | | | | | | | P | | | | |
| | | | | | | | | Q | | | | |
| | | | | | | | | R | | | | |
| SB | | | | | | | | | | | | |
| MO | | | | | | | | | | | | |
| AL | | | | | | | | | | | | |
| AS | | | | | | | | | | | | |
| BA | | | | | | | | | | | | |
| BE | | | | | | | | | | | | |
| CD | | | | | | | | | | | | |
| CR | | | | | | | | | | | | |
| CO | | | | | | | | | | | | |
| CU | | | | | | | | | | | | |
| PB | | | | | | | | | | | | |
| MN | | | | | | | | | | | | |
| NI | | | | | | | | | | | | |
| AG | | | | | | | | | | | | |
| TL | | | | | | | | | | | | |
| V | | | | | | | | | | | | |
| ZN | | | | | | | | | | | | |
| SE | | | | | | | | | | | | |

P-MS ICV / CCV STANDARD
 REPAIRED DAILY

| al Std 1 | Metal | CAS Lot # | Conc. (ppb) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst / Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|----------|-------|-----------|-------------|------------|------------------|-------------------|---------------------|----------------|-----------|-------------------|-----------|-----------------|----------|
| | AL | M1780073P | 10000 | 0.500 | 100 | 50 | 1% HNO ₃ | SD 11/18/06 | A | M1780073N | - | 11/19/06 | M23 |
| | SB | | | | | | | SD 11/19/06 | B | M1780073N | - | 11/16/06 | M23 |
| | AS | | | | | | | SD 11/18/06 | C | M1780073N | - | 11/11/06 | M23 |
| | BE | | | | | | | SD 11/13/06 | D | M1780073N | - | 11/14/06 | M23 |
| | CD | | | | | | | SD 11/14/06 | E | M1780073N | - | 11/15/06 | M23 |
| | CR | | | | | | | SD 11/15/06 | F | M1780073N | - | 11/16/06 | M23 |
| | CO | | | | | | | SD 11/16/06 | G | M1780073N | - | 11/17/06 | M23 |
| | CU | | | | | | | SD 11/17/06 | H | M1780073N | - | 11/18/06 | M23 |
| | PB | | | | | | | SD 11/18/06 | I | M1780073N | - | 11/21/06 | M23 |
| | MIN | | | | | | | SD 11/21/06 | J | M1780073N | - | 11/22/06 | M23 |
| | MO | | | | | | | SD 11/23/06 | K | M1780073N | - | 11/23/06 | M23 |
| | NI | | | | | | | | L | | | | |
| | TL | | | | | | | | M | | | | |
| | V | | | | | | | | N | | | | |
| | ZN | | | | | | | | O | | | | |
| | SE | | | | | | | | P | | | | |
| al Std 2 | BA | M1780073Q | | 0.500 | | | | | Q | | | | |
| | AG | | | | | | | | R | | | | |

MS HLCV2 STANDARD
 EPARED MONTHLY

| Metal | CAS Lot # | Conc. (ppb) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst / Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|-------|-----------|-------------|------------|------------------|-------------------|---------------------|----------------|-----------|-------------------|-----------|-----------------|----------|
| AL | M1780067A | 20000 | 0.500 | 50 | 200 | 1% HNO ₃ | SD 3/1/06 | A | M17800670 | - | 4/1/06 | M13 |
| BA | | | | | | 1% HNO ₃ | DCS 3/14/06 | B | M17800670 | - | 3/8/06 | M13 |
| AS | | | | | | 1% HNO ₃ | DCS 4/18/06 | C | M17800670 | - | 4/14/06 | M10 |
| BE | | | | | | 1% HNO ₃ | SD 5/3/06 | D | M1780068W | - | 2/24/06 | M13 |
| CD | | | | | | 1% HNO ₃ | SD 5/16/06 | E | M1780068W | - | 5/18/06 | M10 |
| CR | | | | | | 1% HNO ₃ | SD 5/30/06 | F | M1180068W | - | 6/30/06 | M10 |
| CO | | | | | | 1% HNO ₃ | DCS 6/5/06 | G | M1780068W | - | 7/15/06 | M10 |
| CU | | | | | | 1% HNO ₃ | SD 6/23/06 | H | M1180070U | - | 7/23/06 | M13 |
| PB | | | | | | 1% HNO ₃ | SD 7/24/06 | I | M1780070U | - | 8/24/06 | M13 |
| MN | | | | | | 1% HNO ₃ | SD 8/4/06 | J | M1780070G | - | 9/4/06 | M13 |
| AG | | | | | | 1% HNO ₃ | DCS 8/17/06 | K | M1780070G | - | 9/11/06 | M23 |
| NI | | | | | | 1% HNO ₃ | DCS 9/5/06 | L | M1780070G | - | 9/19/06 | M23 |
| TL | | | | | | 1% HNO ₃ | SD 9/19/06 | M | M1780070G | - | 10/19/06 | M13 |
| V | | | | | | 1% HNO ₃ | SD 10/3/06 | N | M1780071Q | - | 11/3/06 | M13 |
| ZN | | | | | | 1% HNO ₃ | SD 10/3/06 | O | M1780071Q | - | 10/13/06 | M13 |
| SE | | | | | | 1% HNO ₃ | SD 10/3/06 | P | M1780071Q | - | 11/30/06 | M13 |
| SB | M1780065G | | 0.500 | | | 1% HNO ₃ | SD 11/9/06 | Q | M1780073N | - | 12/19/06 | M13 |
| MO | | | | | | | | R | | | | |

✓ SD 5/15/06
 SD 7/16/06

P-MS HLCCV2 STANDARD
REPAIRED MONTHLY)

| Metal | CAS Lot # | Conc. (ppb) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst / Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|----------|-----------|-------------|------------|------------------|-------------------|---------------------|----------------|-----------|-------------------|-----------|-----------------|----------|
| al Std 1 | M1780073X | 20000 | 0.500 | 50 | 200 | 1% HNO ₃ | SD 11/16/06 | A | M1780073N | - | 12/16/06 | M23 |
| BA | | | | | | | SD 11/23/06 | B | M1780073N | - | 12/22/06 | M23 |
| AS | | | | | | | | C | | | | |
| BE | | | | | | | | D | | | | |
| CD | | | | | | | | E | | | | |
| CR | | | | | | | | F | | | | |
| CO | | | | | | | | G | | | | |
| CU | | | | | | | | H | | | | |
| PB | | | | | | | | I | | | | |
| MN | | | | | | | | J | | | | |
| AG | | | | | | | | K | | | | |
| NI | | | | | | | | L | | | | |
| TL | | | | | | | | M | | | | |
| V | | | | | | | | N | | | | |
| ZN | | | | | | | | O | | | | |
| SE | | | | | | | | P | | | | |
| SB | M1780065G | | 0.500 | | | | | Q | | | | |
| MO | | | | | | | | R | | | | |

ICP-MS MRL STANDARD
(PREPARED MONTHLY OR AS NECESSARY)

| Metal | CAS Lot # | Conc. (ppb) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst/Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|------------|-----------|-------------|------------|------------------|-------------------|----------------------|--------------|-----------|-------------------|-----------|-----------------|----------|
| Cal Std 1 | SB | 20000 | 0.025 | 500 | 1.0 | 17, HNO ₃ | SD 11/10/06 | A | M1780073N | - | 12/10/06 | M17 |
| | MO | | | | 1.0 | | | B | | | | M13 |
| Cal Std 2 | AL | | 0.025 | | below | | | C | | | | |
| | AS | | | | 1.0 | | | D | | | | |
| | BA | | | | | | | E | | | | |
| | BE | | | | | | | F | | | | |
| | CD | | | | | | | G | | | | |
| | CR | | | | | | | H | | | | |
| | CO | | | | | | | I | | | | |
| | CU | | | | | | | J | | | | |
| | PB | | | | | | | K | | | | |
| | MN | | | | | | | L | | | | |
| | NI | | | | | | | M | | | | |
| | AG | | | | | | | N | | | | |
| | TL | | | | | | | O | | | | |
| | V | | | | | | | P | | | | |
| | ZN | | | | | | | Q | | | | |
| | SE | | | | | | | R | | | | |
| Indiv. Std | AL | 10000 | 0.450 | | 10.0 | | | S | | | | |
| | ZN | 10000 | 0.150 | | 1.0 | | | T | | | | |
| | | | 0.200 | | below | | | | | | | |
| | | | | | 40 | | | | | | | |
| | | | | | 510 | | | | | | | |

SP1410

ICP-MS MRL STANDARD
(PREPARED MONTHLY OR AS NECESSARY)

| Metal | CAS Lot # | Conc. (ppb) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst / Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|------------|-----------|-------------|---------------------------|------------------|-----------------------|---------------------|----------------|-----------|-------------------|-----------|-----------------|----------|
| Cal Std 1 | M17800656 | 20000 | 0.025 | 500 | 1.0 | 1% HNO ₃ | SD 11/14/06 | A | M1780073N | - | 12/19/06 | M13 |
| | | | | | 1.0 | | | B | | | | M17 |
| Cal Std 2 | M1780067K | | 0.025 | | below | | | C | | | | |
| | | | | | 1.0 | | | D | | | | |
| AS | | | | | | | | E | | | | |
| BA | | | | | | | | F | | | | |
| BE | | | | | | | | G | | | | |
| CD | | | | | | | | H | | | | |
| CR | | | | | | | | I | | | | |
| CO | | | | | | | | J | | | | |
| CU | | | | | | | | K | | | | |
| PB | | | | | | | | L | | | | |
| MIN | | | | | | | | M | | | | |
| NI | | | | | | | | N | | | | |
| AG | | | | | | | | O | | | | |
| TL | | | | | | | | P | | | | |
| V | | | | | | | | Q | | | | |
| ZN | | | | | | | | R | | | | |
| SE | | | | | | | | S | | | | |
| Indiv. Std | | 10000 | 0.450 | | 10.0 | | | T | | | | |
| | | 10000 | 0.150 0.200 | | 5.0 5.0 | | | | | | | |

5000123C
M178006
M3690178P

SS10610

1080

ICP-MS ICSA SOLUTION
(PREPARED WEEKLY OR AS NECESSARY)

| Metal | CAS Lot # | Conc. (ppm) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst / Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|-------|-----------|-------------|------------|------------------|-------------------|---------------------|----------------|-----------|-------------------|-----------|-----------------|----------|
| ICSA | M1780071Q | 10000 | 2.00 | 100 | 200000 | 1% HNO ₃ | SD 9/26/06 | A | M1780071Q | - | 10/3/06 | MIP |
| AL | | 1000 | | | 20000 | 1% HNO ₃ | DCS 10/4/06 | B | M1780071Q | - | 10/11/06 | m18 |
| CA | | | | | | 1% HNO ₃ | SID 10/12/06 | C | M1780071Q | - | 10/19/06 | MIP |
| FE | | | | | | 1% HNO ₃ | SD 10/20/06 | D | M1780071Q | - | 10/27/06 | MIP |
| MG | | | | | | 1% HNO ₃ | DCS 10/20/06 | E | M1780071Q | - | 11/7/06 | m18 |
| P | | | | | | 1% HNO ₃ | SD 11/6/06 | F | M1780073N | - | 11/13/06 | MIP |
| K | | | | | | 1% HNO ₃ | SD 11/13/06 | G | M1780073N | - | 11/20/06 | MIP |
| NA | | | | | | 1% HNO ₃ | SD 11/20/06 | H | M1780073N | - | 11/27/06 | MIP |
| S | | | | | | | | I | | | | |
| C | | 2000 | | | 40000 | | | J | | | | |
| MO | | 20 | | | 400 | | | K | | | | |
| TI | | 20 | | | 400 | | | L | | | | |
| | | | | | | | | M | | | | |
| | | | | | | | | N | | | | |
| | | | | | | | | O | | | | |
| | | | | | | | | P | | | | |
| | | | | | | | | Q | | | | |
| | | | | | | | | R | | | | |
| | | | | | | | | S | | | | |
| | | | | | | | | T | | | | |

CP-MS ICSAB SOLUTION
 PREPARED WEEKLY OR AS NECESSARY

| ICSA | Metal | CAS Lot # | Conc. (ppm) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst/Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID | |
|-------|-------|-----------|-------------|------------|------------------|-------------------|---------------------|---------------------|-------------|-------------------|-----------|-----------------|----------|-----|
| ICSA | CL- | M1780072L | 10000 | 2.00 | 100 | 200000 | 1% HNO ₃ | SD 9/26/06 | A | M1780071Q | - | 10/2/06 | M18 | |
| | AL,CA | | 1000 | | | 20000 | 1% HNO ₃ | DCS 10/4/06 | B | M1780071Q | - | 10/4/06 | M18 | |
| | FE,MG | | | | | | 1% HNO ₃ | SD 10/12/06 | C | M1780071Q | - | 10/19/06 | M18 | |
| | P,K | | | | | | 1% HNO ₃ | SD 10/20/06 | D | M1780071Q | - | 10/17/06 | M18 | |
| | NA,S | | | | | | 1% HNO ₃ | DCS 10/26/06 | E | M1780071Q | - | 11/1/06 | M18 | |
| | C | | 2000 | | | 40000 | 1% HNO ₃ | SD 11/6/06 | F | M1780073N | - | 11/13/06 | M18 | |
| | MO,TI | | 20 | | | 400 | 1% HNO ₃ | SD 11/13/06 | G | M1780073N | - | 11/20/06 | M18 | |
| | | | | | | | | 1% HNO ₃ | SD 11/20/06 | H | M1780073N | - | 11/27/06 | M14 |
| | | | | | | | | 1% HNO ₃ | SD 11/22/06 | I | M1780073N | - | 11/29/06 | M18 |
| | | | | | | | | | J | | | | | |
| | | | | | | | | | K | | | | | |
| | | | | | | | | | L | | | | | |
| | | | | | | | | | M | | | | | |
| ICSAB | NI | M1780067G | 2 | 1.00 | | 20.0 | | | N | | | | | |
| | MIN | | 2 | | | | | | O | | | | | |
| | CR | | 2 | | | | | | P | | | | | |
| | AS | | 2 | | | | | | Q | | | | | |
| | CO,CU | | 2 | | | | | | R | | | | | |
| | AG,CD | | 2 | | | | | | S | | | | | |
| | ZN | | 2 | | | | | | T | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | |

ICP-MS INTERNAL STANDARD SOLUTION
(PREPARED EVERY 6 MONTHS OR AS NECESSARY)

| Metal | CAS Lot # | Conc. (ppb) | Vol. (mls) | Final Vol. (mls) | Final Conc. (ppb) | Matrix | Analyst / Date | Letter ID | Nitric Acid Lot # | HCL Lot # | Expiration Date | Pipet ID |
|----------------|------------|-------------|------------|------------------|-------------------|---------------------|----------------|-----------|-------------------|-----------|-----------------|----------|
| I.S. STD | M1780073C | 10000 | 50.0 | 500 | 1000 | 1% HNO ₃ | SD 10/31/06 | A | M1780071Q | -- | 4/30/06 | -- |
| HO | | | | | | | | B | | | | |
| IN | | | | | | | | C | | | | |
| LI +6 | | | | | | | | D | | | | |
| RH | | | | | | | | E | | | | |
| SC | | | | | | | | F | | | | |
| TB | | | | | | | | G | | | | |
| Y | | | | | | | | H | | | | |
| SC | M1780573M | 100000 | 5.00 | | 2000 | | | I | | | | |
| GE | M17800064S | 100000 | 25 | | 5000 | | | J | | | | |
| Single Element | | | | | | | | K | | | | |
| | | | | | | | | L | | | | |
| | | | | | | | | M | | | | |
| | | | | | | | | N | | | | |
| | | | | | | | | O | | | | |
| | | | | | | | | P | | | | |
| | | | | | | | | Q | | | | |
| | | | | | | | | R | | | | |
| | | | | | | | | S | | | | |
| | | | | | | | | T | | | | |

GENERAL CHEMISTRY DATA

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton
Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006
Client Sample ID : SPMW-01

Date Sampled : 10/24/06 10:25 Order #: 950030 Sample Matrix: WATER
Date Received: 10/25/06 Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE | TIME | DILUTION |
|--------------------------|--------|--------|----------|-------|----------|----------|----------|
| | | | | | ANALYZED | ANALYZED | |
| AMMONIA | 350.1 | 0.0500 | 0.0500 U | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 1.77 | MG/L | 11/01/06 | 10:13 | 1.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPMW-05

Date Sampled : 10/24/06 11:10
Date Received: 10/25/06

Order #: 950031
Submission #: R2634493

Sample Matrix: WATER

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE ANALYZED | TIME ANALYZED | DILUTION |
|--------------------------|--------|--------|----------|-------|---------------|---------------|----------|
| AMMONIA | 350.1 | 0.0500 | 0.0500 U | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 2.44 | MG/L | 11/01/06 | 10:13 | 2.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPMW-10R

Date Sampled : 10/24/06 11:55 Order #: 950032 Sample Matrix: WATER
Date Received: 10/25/06 Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE ANALYZED | TIME ANALYZED | DILUTION |
|--------------------------|--------|--------|----------|-------|---------------|---------------|----------|
| AMMONIA | 350.1 | 0.0500 | 0.0500 U | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 2.06 | MG/L | 11/01/06 | 10:13 | 2.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton
Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006
Client Sample ID : SPMW-02

Date Sampled : 10/24/06 13:20 Order #: 950033 Sample Matrix: WATER
Date Received: 10/25/06 Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE | TIME | DILUTION |
|--------------------------|--------|--------|----------|-------|----------|----------|----------|
| | | | | | ANALYZED | ANALYZED | |
| AMMONIA | 350.1 | 0.0500 | 0.0500 U | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 3.89 | MG/L | 11/01/06 | 10:13 | 4.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPMW-06R

Date Sampled : 10/24/06 14:10

Order #: 950034

Sample Matrix: WATER

Date Received: 10/25/06

Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE ANALYZED | TIME ANALYZED | DILUTION |
|--------------------------|--------|--------|--------|-------|---------------|---------------|----------|
| AMMONIA | 350.1 | 0.0500 | 39.9 | MG/L | 11/07/06 | 09:50 | 100.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 28.6 | MG/L | 11/01/06 | 10:13 | 20.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPMW-08

Date Sampled : 10/24/06 14:50 Order #: 950035 Sample Matrix: WATER
Date Received: 10/25/06 Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE | TIME | DILUTION |
|--------------------------|--------|--------|--------|-------|----------|----------|----------|
| | | | | | ANALYZED | ANALYZED | |
| AMMONIA | 350.1 | 0.0500 | 0.172 | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 0.230 | MG/L | 11/01/06 | 10:13 | 1.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPMW-09

Date Sampled : 10/24/06 15:40 Order #: 950036 Sample Matrix: WATER
Date Received: 10/25/06 Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE | TIME | DILUTION |
|--------------------------|--------|--------|--------|-------|----------|----------|----------|
| | | | | | ANALYZED | ANALYZED | |
| AMMONIA | 350.1 | 0.0500 | 36.7 | MG/L | 11/07/06 | 09:50 | 50.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 24.9 | MG/L | 11/01/06 | 10:13 | 20.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton
Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006
Client Sample ID : SPMW-03

Date Sampled : 10/25/06 08:55 Order #: 950466 Sample Matrix: WATER
Date Received: 10/26/06 Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE | TIME | DILUTION |
|--------------------------|--------|--------|--------|-------|----------|----------|----------|
| | | | | | ANALYZED | ANALYZED | |
| AMMONIA | 350.1 | 0.0500 | 0.154 | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 3.14 | MG/L | 11/01/06 | 10:13 | 2.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPMW-07

Date Sampled : 10/25/06 09:45 Order #: 950467 Sample Matrix: WATER
Date Received: 10/26/06 Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE ANALYZED | TIME ANALYZED | DILUTION |
|--------------------------|--------|--------|--------|-------|---------------|---------------|----------|
| AMMONIA | 350.1 | 0.0500 | 130 | MG/L | 11/07/06 | 09:50 | 100.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 38.4 | MG/L | 11/01/06 | 10:13 | 20.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPMW-07 DUP

Date Sampled : 10/25/06 09:45

Order #: 950468

Sample Matrix: WATER

Date Received: 10/26/06

Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE | TIME | DILUTION |
|--------------------------|--------|--------|--------|-------|----------|----------|----------|
| | | | | | ANALYZED | ANALYZED | |
| AMMONIA | 350.1 | 0.0500 | 131 | MG/L | 11/07/06 | 09:50 | 100.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 38.4 | MG/L | 11/01/06 | 10:13 | 20.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPOB-34

Date Sampled : 10/25/06 10:35 Order #: 950469 Sample Matrix: WATER
Date Received: 10/26/06 Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE ANALYZED | TIME ANALYZED | DILUTION |
|--------------------------|--------|--------|----------|-------|---------------|---------------|----------|
| AMMONIA | 350.1 | 0.0500 | 0.768 | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 0.0500 U | MG/L | 11/01/06 | 10:13 | 1.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPOB-12R2

Date Sampled : 10/25/06 11:05

Order #: 950470

Sample Matrix: WATER

Date Received: 10/26/06

Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE | TIME | DILUTION |
|--------------------------|--------|--------|--------|-------|----------|----------|----------|
| | | | | | ANALYZED | ANALYZED | |
| AMMONIA | 350.1 | 0.0500 | 1.50 | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 9.17 | MG/L | 11/01/06 | 10:13 | 5.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton
Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006
Client Sample ID : SPMW-11R2

Date Sampled : 10/25/06 11:40 Order #: 950471 Sample Matrix: WATER
Date Received: 10/26/06 Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE ANALYZED | TIME ANALYZED | DILUTION |
|--------------------------|--------|--------|--------|-------|---------------|---------------|----------|
| AMMONIA | 350.1 | 0.0500 | 0.0530 | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 2.69 | MG/L | 11/01/06 | 10:13 | 2.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPMW-12

Date Sampled : 10/25/06 13:00
Date Received: 10/26/06

Order #: 950472
Submission #: R2634493

Sample Matrix: WATER

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE ANALYZED | TIME ANALYZED | DILUTION |
|--------------------------|--------|--------|--------|-------|---------------|---------------|----------|
| AMMONIA | 350.1 | 0.0500 | 0.400 | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 3.58 | MG/L | 11/01/06 | 10:13 | 4.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPMW-13

Date Sampled : 10/25/06 13:35 Order #: 950473 Sample Matrix: WATER
Date Received: 10/26/06 Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE ANALYZED | TIME ANALYZED | DILUTION |
|--------------------------|--------|--------|----------|-------|---------------|---------------|----------|
| AMMONIA | 350.1 | 0.0500 | 0.0500 U | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 1.14 | MG/L | 11/01/06 | 10:13 | 1.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPMW-04

Date Sampled : 10/25/06 14:10

Order #: 950474

Sample Matrix: WATER

Date Received: 10/26/06

Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE | TIME | DILUTION |
|--------------------------|--------|--------|----------|-------|----------|----------|----------|
| | | | | | ANALYZED | ANALYZED | |
| AMMONIA | 350.1 | 0.0500 | 0.0500 U | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 3.68 | MG/L | 11/01/06 | 10:13 | 4.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPIS-24

Date Sampled : 10/25/06 14:25 Order #: 950475 Sample Matrix: WATER
Date Received: 10/26/06 Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE | TIME | DILUTION |
|--------------------------|--------|--------|--------|-------|----------|----------|----------|
| | | | | | ANALYZED | ANALYZED | |
| AMMONIA | 350.1 | 0.0500 | 24.8 | MG/L | 11/07/06 | 09:50 | 40.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 9.66 | MG/L | 11/01/06 | 10:13 | 10.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPIS-24 DUP

Date Sampled : 10/25/06 14:25

Order #: 950476

Sample Matrix: WATER

Date Received: 10/26/06

Submission #: R2634493

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE | TIME | DILUTION |
|--------------------------|--------|--------|--------|-------|----------|----------|----------|
| | | | | | ANALYZED | ANALYZED | |
| AMMONIA | 350.1 | 0.0500 | 24.3 | MG/L | 11/07/06 | 09:50 | 40.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 9.73 | MG/L | 11/01/06 | 10:13 | 10.0 |

COLUMBIA ANALYTICAL SERVICES

Reported: 11/28/06

OMI/Ironton

Project Reference: IRONTON - SOUTH POINT - OCTOBER 2006

Client Sample ID : SPIS-23

Date Sampled : 10/25/06 14:45
Date Received: 10/26/06

Order #: 950477
Submission #: R2634493

Sample Matrix: WATER

| ANALYTE | METHOD | PQL | RESULT | UNITS | DATE ANALYZED | TIME ANALYZED | DILUTION |
|--------------------------|--------|--------|--------|-------|---------------|---------------|----------|
| AMMONIA | 350.1 | 0.0500 | 0.570 | MG/L | 11/07/06 | 09:50 | 1.0 |
| NITRATE/NITRITE NITROGEN | 353.2 | 0.0500 | 3.05 | MG/L | 11/01/06 | 10:13 | 4.0 |

COLUMBIA ANALYTICAL SERVICES

INORGANIC QUALITY CONTROL SUMMARY

Report Date : 11/28/06
 CAS Order # : 950477 - SPIS-23
 Client : OMI/Ironton
 IRONTON - SOUTH POINT - OCTOBER 2006
 Reported Units: MG/L
 Run # : 137085

PRECISION ACCURACY

| ORIGINAL | DUPLICATE | RPD | FOUND | ADDED | % REC. | LIMITS |
|----------|-----------|-----|-------|-------|--------|----------|
| 0.570 | 0.573 | 1 | 1.09 | 0.500 | 104 | 59 - 129 |

AMMONIA

COLUMBIA ANALYTICAL SERVICES

INORGANIC QUALITY CONTROL SUMMARY

Report Date : 11/28/06
CAS Order # : 950477 - SPIS-23
Client : OMI/Ironton
IRONTON - SOUTH POINT - OCTOBER 2006
Reported Units: MG/L
Run # : 136743

| PRECISION | | | | ACCURACY | | |
|-----------|-----------|-----|-------|----------|--------|----------|
| ORIGINAL | DUPLICATE | RPD | FOUND | ADDED | % REC. | LIMITS |
| 3.05 | 3.06 | 0 | 5.09 | 2.00 | 102 | 69 - 123 |

NITRATE/NITRITE NITROGEN

COLUMBIA ANALYTICAL SERVICES

INORGANIC BLANK SPIKE SUMMARY

CAS Submission #: R2634493
Client: OMI/Ironton
IRONTON - SOUTH POINT - OCTOBER 2006

BLANK SPIKES

| BLANK | FOUND | ADDED | % REC | LIMITS | RUN | UNITS |
|----------|-------|-------|-------|----------|--------|-------|
| 0.0500 U | 0.480 | 0.500 | 96 | 90 - 110 | 136743 | MG/L |
| 0.0500 U | 0.482 | 0.500 | 96 | 90 - 110 | 137085 | MG/L |

NITRATE/NITRITE NITROGEN

AMMONIA

Run #: 137085
 Analyte: NH3 350.1 AMMONIA
 Printed: 11/07/06 14:15

5 Copies
 R-33531 R-34493
 R-34431 R-33526
 R-34486

| TYPE | SUBMISSION | ORDER # | MATRIX | REPORTED | | DILUTION | PQL | % RECOVERY | % RSD | DATE | QC | PKG # |
|------|------------|---------|--------|----------|---|----------|--------|------------|-------|------------|-----|-------|
| | | | | RESULT | | | | | | ANALYZED | | |
| CHK1 | | 953751 | WATER | 1.72 | | 1.0 | 0.0500 | 95.6 | | 11/07/2006 | | |
| BLK1 | | 953752 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | |
| SPKB | | 953753 | WATER | 0.472 | | 1.0 | 0.0500 | 94.4 | | 11/07/2006 | | |
| ESMP | R2633956 | 942493 | WATER | 6.57 | | 5.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2634516 | 950648 | WATER | 0.653 | | 1.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2634516 | 950650 | WATER | 0.308 | | 1.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2633531 | 935129 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | RUN | ASPB |
| ESMP | R2634431 | 944243 | WATER | 0.290 | | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634431 | 944279 | WATER | 22.8 | | 40.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634431 | 944282 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634431 | 944283 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634431 | 944284 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2633525 | 934985 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2633525 | 934986 | WATER | 6.78 | | 5.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2633525 | 934987 | WATER | 102 | | 100.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2633525 | 934988 | WATER | 0.421 | | 1.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2633525 | 934989 | WATER | 1.96 | | 5.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2634486 | 944236 | WATER | 39.0 | | 100.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634486 | 944285 | WATER | 0.221 | | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| SPKB | | 953756 | WATER | 0.464 | | 1.0 | 0.0500 | 92.8 | | 11/07/2006 | | |
| ESMP | R2634486 | 944286 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634486 | 944289 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634481 | 949821 | WATER | 2.60 | | 5.0 | 0.0500 | | | 11/07/2006 | | 1 |
| ESMP | R2634481 | 949825 | WATER | 0.274 | | 1.0 | 0.0500 | | | 11/07/2006 | | 1 |
| LDUP | | 953754 | WATER | 0.274 | | 1.0 | 0.0500 | | | 11/07/2006 | | |
| SPK1 | | 953755 | WATER | 0.756 | | 1.0 | 0.0500 | 96.4 | | 11/07/2006 | | |
| ESMP | R2634481 | 949826 | WATER | 0.175 | | 1.0 | 0.0500 | | | 11/07/2006 | | 1 |
| ESMP | R2634481 | 949827 | WATER | 0.132 | | 1.0 | 0.0500 | | | 11/07/2006 | | 1 |
| ESMP | R2634493 | 950030 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| LDUP | | 953757 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | |
| SPK1 | | 953758 | WATER | 0.474 | | 1.0 | 0.0500 | 94.8 | | 11/07/2006 | | |
| ESMP | R2634493 | 950031 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | 950032 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | 950033 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | 950034 | WATER | 39.9 | | 100.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | 950035 | WATER | 0.172 | | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | 950036 | WATER | 36.7 | | 50.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2633525 | 934990 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2633525 | 934991 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2634486 | 944247 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634486 | 944248 | WATER | 0.304 | | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634486 | 944249 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634486 | 944250 | WATER | 0.0723 | | 1.0 | 0.0500 | | | 11/07/2006 | QC | ASPB |
| LDUP | | 953759 | WATER | 0.0772 | | 1.0 | 0.0500 | | | 11/07/2006 | | |
| SPK1 | | 953760 | WATER | 0.559 | | 1.0 | 0.0500 | 97.3 | | 11/07/2006 | | |
| ESMP | R2634486 | 944251 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634486 | 944252 | WATER | 1.42 | | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634406 | 948476 | WATER | 19.5 | | 20.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| LDUP | | 953761 | WATER | 19.0 | | 20.0 | 0.0500 | | 2.60 | 11/07/2006 | | |
| SPK1 | | 953762 | WATER | 30.4 | | 20.0 | 0.0500 | 109.0 | | 11/07/2006 | | |
| ESMP | R2634406 | 948478 | WATER | 0.455 | | 1.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |

Reviewed & Approved
 11/9/06

ANALYTE:G:\STARLIMS\ASBAR.RP1

| <u>TYPE</u> | <u>SUBMISSION</u> | <u>ORDER #</u> | <u>MATRIX</u> | <u>RESULT</u> | | <u>DILUTION</u> | <u>PQL</u> | <u>% RECOVERY</u> | <u>% RSD</u> | <u>ANALYZED</u> | <u>QC</u> | <u>PKG #</u> |
|-------------|-------------------|----------------|---------------|---------------|---|-----------------|------------|-------------------|--------------|-----------------|-----------|--------------|
| ESMP | R2634406 | - 948479 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| SPKB | | - 953763 | WATER | 0.482 | | 1.0 | 0.0500 | 96.4 | | 11/07/2006 | | |
| ESMP | R2634406 | - 948480 | WATER | 0.0940 | | 1.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2634406 | - 948482 | WATER | 16.0 | | 20.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2634493 | - 950466 | WATER | 0.154 | | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | - 950467 | WATER | 130 | | 100.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | - 950468 | WATER | 131 | | 100.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | - 950469 | WATER | 0.768 | | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | - 950470 | WATER | 1.50 | | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | - 950471 | WATER | 0.0530 | | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | - 950472 | WATER | 0.400 | | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | - 950473 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | - 950474 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | - 950475 | WATER | 24.8 | | 40.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | - 950476 | WATER | 24.3 | | 40.0 | 0.0500 | | | 11/07/2006 | | ASPB |
| ESMP | R2634493 | - 950477 | WATER | 0.570 | | 1.0 | 0.0500 | | | 11/07/2006 | QC | ASPB |
| LDUP | | - 953764 | WATER | 0.573 | | 1.0 | 0.0500 | | 0.52 | 11/07/2006 | | |
| SPK1 | | - 953765 | WATER | 1.09 | | 1.0 | 0.0500 | 104.0 | | 11/07/2006 | | |
| ESMP | R2634516 | - 950649 | WATER | 0.342 | | 1.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2634516 | - 950651 | WATER | 0.504 | | 1.0 | 0.0500 | | | 11/07/2006 | RUN | 2 |
| ESMP | R2633526 | - 934995 | WATER | 0.0500 | U | 1.0 | 0.0500 | | | 11/07/2006 | RUN | ASPB |
| ESMP | R2633526 | - 934999 | WATER | 5.62 | | 5.0 | 0.0500 | | | 11/07/2006 | RUN | ASPB |
| ESMP | R2633526 | - 935000 | WATER | 0.222 | | 1.0 | 0.0500 | | | 11/07/2006 | RUN | ASPB |
| LDUP | | - 953766 | WATER | 0.215 | | 1.0 | 0.0500 | | 3.20 | 11/07/2006 | | |
| SPK1 | | - 953767 | WATER | 0.718 | | 1.0 | 0.0500 | 99.2 | | 11/07/2006 | | |
| ESMP | R2634588 | - 951910 | WATER | 0.607 | | 1.0 | 0.0500 | | | 11/07/2006 | | 1 |

Records printed: 77

Columbia Analytical Services
 Rochester, NY 14607
 Aquakem 200
 Analyst: *S. Place*

07.11.2006 09:50

Test Ammonia

350.1

pipets: E2, Sally

Accepted

07.11.2006 09:50

Factor

4.93421


Bias

0.04772

Coeff. of det.

0.998551

Errors



| | Calibrator | Response | Calc. con. | Conc. | Errors |
|---|------------------|----------|------------|---------|--------|
| 1 | NH3-0 | 0.04886 | 0.00563 | 0.00000 | |
| 2 | NH3-2 | 0.06221 | 0.07152 | 0.05000 | |
| 3 | NH3-2 | 0.07068 | 0.11329 | 0.10000 | |
| 4 | NH3-2 | 0.08912 | 0.20430 | 0.20000 | |
| 5 | NH3-2 | 0.14413 | 0.47573 | 0.50000 | |
| 6 | NH3-2 | 0.24029 | 0.95019 | 1.00000 | |
| 7 | NH3-2 | 0.45900 | 2.02934 | 2.00000 | |
| 8 | 1 ICV-NH3 (contr | 0.39663 | 1.72161 | 1.80000 | |
| 9 | 2 ICB-NH3 (contr | 0.04803 | 0.00155 | 0.00000 | |

Columbia Analytical Services
 Rochester, NY 14607
 Aquakem 200
 Analyst: *S. Place*

Date : 2006-11-07
 Time : 12.50

| Test Unit | Ammonia mg/l | 350.1 | | | |
|------------|--------------|-------------|-----------|-------|------------------|
| Sample ID: | Resp. | Result | Man.dilut | Dilut | Date and Time |
| 1 ICV-NH3 | 0.397 | 1.7216 | | | 2006-11-07 09.50 |
| 2 ICB-NH3 | 0.048 | 0.0016 | | | 2006-11-07 09.50 |
| 3 CCV-NH3 | 0.390 | 1.6911 | | | 2006-11-07 10.32 |
| 4 CCB-NH3 | 0.052 | 0.0209 | | | 2006-11-07 10.32 |
| 951910 | 0.171 | 0.6065 | | | 2006-11-07 10.32 |
| LCS1 | 0.143 | 0.4722 | | | 2006-11-07 10.32 |
| 950648 | 0.180 | 0.6530 | | | 2006-11-07 10.32 |
| 950650 | 0.110 | 0.3082 | | | 2006-11-07 10.32 |
| 935129 | 0.052 | 0.0210 | | | 2006-11-07 10.32 |
| 944243 | 0.107 | 0.2901 | | | 2006-11-07 10.32 |
| 944279 | 3.791 | <u>OVER</u> | | | - |
| 944282 | 0.051 | 0.0138 | | | 2006-11-07 10.32 |
| 944283 | 0.048 | 0.0012 | | | 2006-11-07 10.32 |
| 944284 | 0.048 | -0.0001 | | | 2006-11-07 10.32 |
| 3 CCV-NH3 | 0.390 | 1.6874 | | | 2006-11-07 10.43 |
| 4 CCB-NH3 | 0.050 | 0.0090 | | | 2006-11-07 10.43 |
| 949821 | 0.607 | <u>OVER</u> | | | - |
| 949825 | 0.103 | 0.2744 | | | 2006-11-07 10.43 |
| 825 DUP | 0.103 | 0.2744 | | | 2006-11-07 10.43 |
| 825 SPK | 0.201 | 0.7564 | | | 2006-11-07 10.43 |
| 949826 | 0.083 | 0.1747 | | | 2006-11-07 10.43 |
| 949827 | 0.074 | 0.1321 | | | 2006-11-07 10.43 |
| 934985 | 0.048 | 0.0033 | | | 2006-11-07 10.43 |
| 934986 | 0.884 | <u>OVER</u> | | | - |
| 934987 | 10.027 | <u>OVER</u> | | | - |
| 934988 | 0.133 | 0.4208 | | | 2006-11-07 10.43 |
| 3 CCV-NH3 | 0.399 | 1.7309 | | | 2006-11-07 10.53 |
| 4 CCB-NH3 | 0.052 | 0.0223 | | | 2006-11-07 10.53 |
| 934989 | 0.460 | <u>OVER</u> | | | - |
| 944236 | 10.030 | <u>OVER</u> | | | - |
| 944285 | 0.092 | 0.2206 | | | 2006-11-07 10.53 |
| LCS2 | 0.142 | 0.4641 | | | 2006-11-07 10.53 |
| 944286 | 0.050 | 0.0101 | | | 2006-11-07 10.53 |
| 944289 | 0.048 | 0.0004 | | | 2006-11-07 10.53 |
| 950030 | 0.049 | 0.0068 | | | 2006-11-07 10.53 |
| 030 DUP | 0.047 | -0.0020 | | | 2006-11-07 10.53 |
| 030 SPK | 0.144 | 0.4740 | | | 2006-11-07 10.53 |
| 950031 | 0.047 | -0.0012 | | | 2006-11-07 10.54 |
| 3 CCV-NH3 | 0.404 | 1.7561 | | | 2006-11-07 11.04 |
| 4 CCB-NH3 | 0.050 | 0.0128 | | | 2006-11-07 11.04 |
| 950032 | 0.048 | 0.0036 | | | 2006-11-07 11.04 |
| 950033 | 0.054 | 0.0308 | | | 2006-11-07 11.04 |
| 950034 | 10.030 | <u>OVER</u> | | | - |
| 950035 | 0.083 | 0.1722 | | | 2006-11-07 11.04 |
| 950036 | 7.055 | <u>OVER</u> | | | - |
| 934990 | 0.053 | 0.0266 | | | 2006-11-07 11.04 |
| 934991 | 0.055 | 0.0360 | | | 2006-11-07 11.04 |
| 944247 | 0.047 | -0.0021 | | | 2006-11-07 11.04 |
| 944248 | 0.109 | 0.3041 | | | 2006-11-07 11.04 |
| 944249 | 0.048 | 0.0006 | | | 2006-11-07 11.04 |
| 3 CCV-NH3 | 0.397 | 1.7254 | | | 2006-11-07 11.15 |

Columbia Analytical Services
Rochester, NY 14607
AquaKem 200
Analyst: S. Place

Date : 2006-11-07
Time : 12.50

Test Unit

Ammonia 350.1
mg/l

| Sample ID: | Resp. | Result | Man.dilut | Dilut | Date and Time |
|------------|--------|----------|-----------|--------|------------------|
| 4 CCB-NH3 | 0.051 | 0.0144 | | | 2006-11-07 11.15 |
| 944250 | 0.062 | 0.0723 | | | 2006-11-07 11.15 |
| 250 DUP | 0.063 | 0.0772 | | | 2006-11-07 11.15 |
| 250 SPK | 0.161 | 0.5590 | | | 2006-11-07 11.15 |
| 944251 | 0.047 | -0.0039 | | | 2006-11-07 11.15 |
| 944252 | 0.336 | 1.4213 | | | 2006-11-07 11.15 |
| 948476 | 3.947 | OVER | | | - |
| 476 DUP | 3.937 | L | | | - |
| 476 SPK | 3.993 | | | | - |
| 948478 | 0.140 | 0.4548 | | | 2006-11-07 11.15 |
| 948479 | 0.047 | -0.0040 | | | 2006-11-07 11.15 |
| 3 CCV-NH3 | 0.398 | 1.7264 | | | 2006-11-07 11.25 |
| 4 CCB-NH3 | 0.051 | 0.0145 | | | 2006-11-07 11.25 |
| LCS3 | 0.145 | 0.4816 | | | 2006-11-07 11.25 |
| 948480 | 0.067 | 0.0940 | | | 2006-11-07 11.25 |
| 948482 | 2.736 | OVER | | | - |
| 950466 | 0.079 | 0.1544 | | | 2006-11-07 11.25 |
| 950467 | 10.029 | OVER | | | - |
| 950468 | 10.029 | L | | | - |
| 950469 | 0.203 | 0.7681 | | | 2006-11-07 11.25 |
| 950470 | 0.352 | 1.4999 | | | 2006-11-07 11.25 |
| 950471 | 0.058 | 0.0530 | | | 2006-11-07 11.25 |
| 950472 | 0.129 | 0.3996 | | | 2006-11-07 11.25 |
| 3 CCV-NH3 | 0.399 | 1.7333 | | | 2006-11-07 11.36 |
| 4 CCB-NH3 | 0.051 | 0.0160 | | | 2006-11-07 11.36 |
| 950473 | 0.047 | -0.0033 | | | 2006-11-07 11.36 |
| 950474 | 0.052 | 0.0217 | | | 2006-11-07 11.36 |
| 950475 | 4.828 | OVER | | | - |
| 950476 | 4.666 | L | | | - |
| 950477 | 0.163 | 0.5701 | | | 2006-11-07 11.36 |
| 477 DUP | 0.164 | 0.5729 | | | 2006-11-07 11.36 |
| 477 SPK | 0.268 | 1.0882 | | | 2006-11-07 11.36 |
| 950649 | 0.117 | 0.3415 | | | 2006-11-07 11.36 |
| 950651 | 0.150 | 0.5043 | | | 2006-11-07 11.36 |
| 934995 | 0.048 | 0.0019 | | | 2006-11-07 11.36 |
| 3 CCV-NH3 | 0.399 | 1.7338 | | | 2006-11-07 11.43 |
| 4 CCB-NH3 | 0.051 | 0.0179 | | | 2006-11-07 11.43 |
| 934999 | 1.173 | OVER | | | - |
| 935000 | 0.093 | 0.2215 | | | 2006-11-07 11.43 |
| 5000 DUP | 0.091 | 0.2150 | | | 2006-11-07 11.43 |
| 5000 SPK | 0.193 | 0.7181 | | | 2006-11-07 11.43 |
| 944279 | 0.163 | 22.7508 | | 1+39.0 | 2006-11-07 11.53 |
| 949821 | 0.153 | 2.6049 | | 1+4.0 | 2006-11-07 11.53 |
| 934986 | 0.323 | 6.7818 | | 1+4.0 | 2006-11-07 11.53 |
| 934987 | 0.255 | 102.4881 | | 1+99.0 | 2006-11-07 11.53 |
| 934989 | 0.127 | 1.9599 | | 1+4.0 | 2006-11-07 11.53 |
| 944236 | 0.127 | 38.9765 | | 1+99.0 | 2006-11-07 11.53 |
| 3 CCV-NH3 | 0.397 | 1.7229 | | | 2006-11-07 12.02 |
| 4 CCB-NH3 | 0.050 | 0.0106 | | | 2006-11-07 12.02 |
| 950034 | 0.129 | 39.9282 | | 1+99.0 | 2006-11-07 12.02 |
| 950036 | 0.196 | 36.6595 | | 1+49.0 | 2006-11-07 12.02 |

Columbia Analytical Services
Rochester, NY 14607
AquaKem 200
Analyst: *S. Place*

Date : 2006-11-07
Time : 12.50

Test Unit

Ammonia *350.1*
mg/l

| Sample ID: | Resp. | Result | Man.dilut Dilut | Date and Time |
|-------------------------|-------|--------------------|-----------------|--|
| 948476 | 0.245 | 19.4862 | 1+19.0 | 2006-11-07 12.02 |
| 476 DUP | 0.240 | 19.0070 | 1+19.0 | 2006-11-07 12.02 |
| 476 SPK | 0.241 | 19.0962 | 1+19.0 | 2006-11-07 12.12 <i>-SPK diluted out 1/2</i> |
| 948482 | 0.210 | 16.0120 | 1+19.0 | 2006-11-07 12.12 |
| 950467 | 0.312 | 130.4654 | 1+99.0 | 2006-11-07 12.12 |
| 950468 | 0.313 | 130.8828 | 1+99.0 | 2006-11-07 12.12 |
| 950475 | 0.173 | 24.7500 | 1+39.0 | 2006-11-07 12.12 |
| 950476 | 0.171 | 24.3325 | 1+39.0 | 2006-11-07 12.12 |
| 3 CCV-NH3 | 0.409 | 1.7814 | | 2006-11-07 12.19 |
| 4 CCB-NH3 | 0.050 | 0.0104 | | 2006-11-07 12.19 |
| 934999 | 0.276 | 5.6229 | 1+4.0 | 2006-11-07 12.19 |
| 942493 | 0.681 | 6.2525 <i>OVER</i> | 1+1.0 | 2006-11-07 12.19 |
| 3 CCV-NH3 | 0.396 | 1.7197 | | 2006-11-07 12.22 |
| 4 CCB-NH3 | 0.049 | 0.0066 | | 2006-11-07 12.22 |
| 948476 SPK 1/20 | 0.356 | 30.3830 1+19.0 | | 2006-11-07 12.41 |
| 942493 | 0.314 | 6.5661 | 1+4.0 | 2006-11-07 12.47 |
| 942493 <i>1/50 1/50</i> | 0.182 | 6.6345 | 1+9.0 | 2006-11-07 12.47 |
| 3 CCV-NH3 | 0.413 | 1.8010 | | 2006-11-07 12.50 |
| 4 CCB-NH3 | 0.051 | 0.0162 | | 2006-11-07 12.50 |

Columbia Analytical Services
1 Mustard St., Rochester NY 14609

General Chemistry Analytical Run Cover Sheet

Analyst: S. Place

Date: 11/7/06

Analysis: Ammonia

Instrument: Aquakem

Quality Control:

| | Same as Log#, Date, | Stocks Prep. Log#, Date, | Stock Sol (mLs) | Stock Sol (mg/L) | Final Vol (mLs) | True Value (mg/L) |
|------------------------|---------------------|--------------------------|-----------------|------------------|-----------------|-------------------|
| a) Standards Prep.: | WC65166A, 4/7/03 | WC76104A, 3/9/06 | | | | |
| b) ICV Preparation: | WC65166B, 4/7/03 | WC76104B, 3/9/06 | 1 | 18 | 10 | 1.80 |
| c) LCS Preparation: | WC65166D, 4/7/03 | WC76104A, 3/9/06 | 0.05 | 100 | 10 | 0.50 |
| d) Matrix Spike Prep.: | WC65166D, 4/7/03 | WC76104A, 3/9/06 | 0.05 | 100 | 10 | 0.50 |

Instrument log filled in? (Y) (N) (N)

Packages: Copy and attach Standards Preparation

Comments:

Production:

| | Start Time | End Time | Total (minutes) |
|--------------------|------------|----------|-----------------|
| Preparation Time : | | | |
| Analytical Time: | | | |
| Finish Time: | | | |

of Samples (including Mtx QC): _____
Repeats due to Sample: _____
Repeats due to Error: _____

4/7/03
DMG

Ammonia (NH_3) [LaChat: pg 1 = 0.050 Reg Level, 0.010 - Low Level]

(A) STANDARDS

| STD. | CONC (mg/L) | mls 100ppm (WCL65166C) | mls Carrier-Diluent (WCL65165F) |
|------|-------------|---------------------------------------|---------------------------------|
| A | 2.000 | 2.00 | 8.00 |
| B | 1.000 | 1.00 | 9.00 |
| C | 0.500 | 0.50 | 9.50 |
| D | 0.200 | 0.20 | 9.80 |
| E | 0.100 | $\frac{1}{10}$ Dil'n of STD B.) 1.000 | |
| F | 0.050 | $\frac{1}{10}$ Dil'n of STD C.) 0.500 | |
| G | 0.020 | $\frac{1}{10}$ Dil'n of STD D.) 0.200 | |
| H | 0.010 | $\frac{1}{10}$ Dil'n of STD E.) 0.100 | |
| I | 0.000 | 10 mls of Carrier-Diluent | |

(B) LEV/CCV: (TV = 1.80 mg/L)

Do two (2) $\frac{1}{10}$ serial dilutions of the 180 ppm Reference Stock (WCL65156B). Prepare using Carrier-Diluent (WCL65165F)

(C) 10.0 ppm Working Stock

Do two (2) $\frac{1}{10}$ serial dilutions of the 1000 ppm Standard Stock (WCL65156A). Prepare using Carrier-Diluent (WCL65165F)

(D) LES/MATRIX SPIKE: (TV = 0.500 mg/L)

Add 0.050 mls 100 ppm working stock (WCL65166C, 1st $\frac{1}{10}$ serial dilution) to 10 mls Carrier-Diluent (WCL65165F) or sample.

3/9/06
NM

(A) NH₃/TKN 1000 ppm Standard Stock

3.517g granular NH₄Cl (WC69234H), previously dried for 2 hrs. @ 104°C; dissolve in ~800 mL DI in a 1-L volumetric flask. Bring to volume w/ DI. Store @ 4°C in amber glass. Expires 3/9/07.

(B) NH₃ 150 ppm Reference Stock

0.687g granular NH₄Cl (WC69234H), previously dried for 2 hrs. @ 104°C; dissolve in ~800 mL DI in a 1-L volumetric flask. Bring to volume with DI. Store @ 4°C in amber glass. Expires 3/9/07.

(C) TKN 400 ppm Reference Stock

1.5276g granular NH₄Cl (WC69234H), previously dried for 2 hrs. @ 104°C; dissolve in ~800 mL DI in a 1-L volumetric flask. Bring to volume with DI. Store @ 4°C in amber glass. Expires 3/9/07.

3/9/06
GN

(D) Stock Ammonium Metaphosphate Solution - TPO₂/OPO₂

- Same as ^{on 11/10/06} ~~WC669~~ WC760696. Exp 3/9/07.

3/9/06
CMW

(E) Cr⁶⁺ Soils 7196 Color Reagent

Dissolve 1.00g 1,5-diphenyl carb, hydrazide (WC69027) in 200mls acetone (WC760060F) volumetrically. Store in amber glass @ 4°C. Expires 1 month (4/9/06)

3/10/06
NM

(F) Post-Digestion Matrix Match - TKN

- same as WC76101D. Exp. 4/1/06.

(G) Hypochlorite - TKN

- same as WC76101C. Prepare fresh each run.

2 runs
A

4 copies

33532
34348
34419
34493

Run #: 136743
Analyte: TOTN 353.2 NITRATE/NITRITE AS N
Printed: 11/01/06 14:19

| TYPE | SUBMISSION | ORDER # | MATRIX | REPORTED | DILUTION | POL | % RECOVERY | % RSD | DATE | QC | PKG # |
|------|------------|---------|--------|----------|----------|--------|------------|-------|------------|-----|-------|
| | | | | RESULT | | | | | ANALYZED | | |
| CHK1 | | 952244 | WATER | 1.81 | 1.0 | 0.0500 | 100.7 | | 11/01/2006 | | |
| CHK1 | | 952245 | WATER | 0.0500 | 1.0 | 0.0500 | | | 11/01/2006 | | |
| CHK1 | | 952246 | WATER | 0.501 | 1.0 | 0.0500 | 100.1 | | 11/01/2006 | | |
| SMP | R2634349 | 947855 | WATER | 2.84 | 4.0 | 0.0500 | | | 11/01/2006 | | |
| DUP | | 952247 | WATER | 2.83 | 4.0 | 0.0500 | | 0.33 | 11/01/2006 | | |
| CHK1 | | 952248 | WATER | 4.72 | 4.0 | 0.0500 | 94.0 | | 11/01/2006 | | |
| SMP | R2634349 | 947856 | WATER | 0.184 | 1.0 | 0.0500 | | | 11/01/2006 | | 6 |
| SMP | R2634349 | 947857 | WATER | 0.0156 | 1.0 | 0.0500 | | | 11/01/2006 | | 6 |
| SMP | R2633532 | 935153 | WATER | 0.0500 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | ASPB |
| SMP | R2633532 | 935155 | WATER | 0.473 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | ASPB |
| SMP | R2634205 | 946023 | WATER | 0.100 | 2.0 | 0.0500 | | | 11/01/2006 | RUN | 2 |
| DUP | | 952249 | WATER | 0.100 | 2.0 | 0.0500 | | | 11/01/2006 | | |
| CHK1 | | 952250 | WATER | 0.507 | 2.0 | 0.0500 | 50.7 | | 11/01/2006 | | |
| SMP | R2634205 | 946024 | WATER | 0.0266 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | 2 |
| SMP | R2634205 | 946025 | WATER | 0.0403 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | 2 |
| SMP | R2634205 | 946026 | WATER | 0.200 | 4.0 | 0.0500 | | | 11/01/2006 | RUN | 2 |
| SMP | R2634205 | 946027 | WATER | 0.283 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | 2 |
| SMP | R2634348 | 948150 | WATER | 0.0202 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634348 | 948151 | WATER | 1.11 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634348 | 948152 | WATER | 0.512 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| DUP | | 952251 | WATER | 0.512 | 1.0 | 0.0500 | | 0.06 | 11/01/2006 | | |
| CHK1 | | 952252 | WATER | 0.504 | 1.0 | 0.0500 | 100.9 | | 11/01/2006 | | |
| CHK1 | | 952253 | WATER | 1.01 | 1.0 | 0.0500 | 100.1 | | 11/01/2006 | | |
| SMP | R2634348 | 948153 | WATER | 0.0985 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634348 | 948154 | WATER | 1.02 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634381 | 948173 | WATER | 13.7 | 20.0 | 0.0500 | | | 11/01/2006 | | 1 |
| SMP | R2634381 | 948174 | WATER | 17.2 | 40.0 | 0.0500 | | | 11/01/2006 | | 1 |
| SMP | R2634381 | 948175 | WATER | 17.1 | 40.0 | 0.0500 | | | 11/01/2006 | | 1 |
| SMP | R2634381 | 948176 | WATER | 16.0 | 40.0 | 0.0500 | | | 11/01/2006 | | 1 |
| SMP | R2634381 | 948177 | WATER | 19.2 | 40.0 | 0.0500 | | | 11/01/2006 | | 1 |
| SMP | R2634381 | 948178 | WATER | 19.7 | 40.0 | 0.0500 | | | 11/01/2006 | | 1 |
| SMP | R2634381 | 948179 | WATER | 19.2 | 40.0 | 0.0500 | | | 11/01/2006 | | 1 |
| SMP | R2634419 | 948570 | WATER | 0.0413 | 1.0 | 0.0500 | | | 11/01/2006 | QC | 5 |
| DUP | | 952254 | WATER | 0.0414 | 1.0 | 0.0500 | | 0.24 | 11/01/2006 | | |
| CHK1 | | 952255 | WATER | 0.466 | 1.0 | 0.0500 | 93.1 | | 11/01/2006 | | |
| SMP | R2634419 | 948573 | WATER | 0.106 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634419 | 948575 | WATER | 0.0165 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634419 | 948578 | WATER | 0.0170 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634419 | 948580 | WATER | 0.0401 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634419 | 948581 | WATER | 0.0767 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634419 | 948584 | WATER | 0.0260 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634419 | 948586 | WATER | 0.0238 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| CHK1 | | 952256 | WATER | 0.501 | 1.0 | 0.0500 | 100.1 | | 11/01/2006 | | |
| SMP | R2634419 | 948587 | WATER | 0.0865 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634419 | 948588 | WATER | 0.0257 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634419 | 948590 | WATER | 0.0376 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634419 | 948591 | WATER | 0.0417 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634432 | 948836 | WATER | 0.437 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | 6 |
| SMP | R2634432 | 948839 | WATER | 0.0928 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | 6 |
| SMP | R2634419 | 948944 | WATER | 0.0201 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| SMP | R2634419 | 948945 | WATER | 0.0125 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |

6 0.00284

B AS 11/2/06
POL/MIL

Reviewed & Approved

By: B. Bone

Date: 11/2/06

1116

| TYPE | SUBMISSION | ORDER # | MATRIX | RESULT | DILUTION | PQL | % RECOVERY | % RSD | ANALYZED | QC | PKG # |
|------|------------|---------|--------|--------|----------|--------|------------|-------|------------|-----|-------|
| ESMP | R2634419 | 948946 | WATER | 0.475 | 1.0 | 0.0500 | | | 11/01/2006 | QC | 5 |
| LDUP | | 952257 | WATER | 0.465 | 1.0 | 0.0500 | | 2.17 | 11/01/2006 | | |
| SPK1 | | 952258 | WATER | 0.982 | 1.0 | 0.0500 | 101.4 | | 11/01/2006 | | |
| ESMP | R2634419 | 948947 | WATER | 0.682 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| ESMP | R2634419 | 948949 | WATER | 0.0282 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| ESMP | R2634419 | 948950 | WATER | 0.0230 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| ESMP | R2634419 | 948951 | WATER | 0.0495 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| ESMP | R2634419 | 948952 | WATER | 0.0677 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| ESMP | R2634419 | 948953 | WATER | 0.0254 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| ESMP | R2634419 | 948954 | WATER | 0.279 | 1.0 | 0.0500 | | | 11/01/2006 | | 5 |
| ESMP | R2634463 | 949504 | WATER | 0.206 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | 6 |
| ESMP | R2634463 | 949505 | WATER | 0.753 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | 6 |
| SPKB | | 952259 | WATER | 0.488 | 1.0 | 0.0500 | 97.6 | | 11/01/2006 | | |
| LDUP | | 952260 | WATER | 0.740 | 1.0 | 0.0500 | | 1.74 | 11/01/2006 | | |
| SPK1 | | 952261 | WATER | 1.24 | 1.0 | 0.0500 | 98.1 | | 11/01/2006 | | |
| ESMP | R2634463 | 949506 | WATER | 1.16 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | 6 |
| ESMP | R2634481 | 949824 | WATER | 0.135 | 1.0 | 0.0500 | | | 11/01/2006 | | 1 |
| ESMP | R2634493 | 950030 | WATER | 1.77 | 1.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| LDUP | | 952262 | WATER | 1.78 | 1.0 | 0.0500 | | 0.56 | 11/01/2006 | | |
| SPK1 | | 952263 | WATER | 2.68 | 2.0 | 0.0500 | 90.9 | | 11/01/2006 | | |
| ESMP | R2634493 | 950031 | WATER | 2.44 | 2.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950032 | WATER | 2.06 | 2.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950033 | WATER | 3.89 | 4.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950034 | WATER | 28.6 | 20.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950035 | WATER | 0.230 | 1.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950036 | WATER | 24.9 | 20.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634508 | 950450 | WATER | 1.79 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | 6 |
| ESMP | R2634493 | 950466 | WATER | 3.14 | 2.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950467 | WATER | 38.4 | 20.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950468 | WATER | 38.4 | 20.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950469 | WATER | 0.0283 | 1.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950470 | WATER | 9.17 | 5.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950471 | WATER | 2.69 | 2.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| SPKB | | 952264 | WATER | 0.492 | 1.0 | 0.0500 | 98.3 | | 11/01/2006 | | |
| ESMP | R2634493 | 950472 | WATER | 3.58 | 4.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950473 | WATER | 1.14 | 1.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950474 | WATER | 3.68 | 4.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950475 | WATER | 9.66 | 10.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950476 | WATER | 9.73 | 10.0 | 0.0500 | | | 11/01/2006 | | ASPB |
| ESMP | R2634493 | 950477 | WATER | 3.05 | 4.0 | 0.0500 | | | 11/01/2006 | QC | ASPB |
| LDUP | | 952265 | WATER | 3.06 | 4.0 | 0.0500 | | 0.22 | 11/01/2006 | | |
| SPK1 | | 952266 | WATER | 5.09 | 4.0 | 0.0500 | 101.9 | | 11/01/2006 | | |
| ESMP | R2634538 | 951016 | WATER | 0.0156 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | 6 |
| ESMP | R2634538 | 951017 | WATER | 1.15 | 1.0 | 0.0500 | | | 11/01/2006 | RUN | 6 |
| SPKB | | 952267 | WATER | 0.480 | 1.0 | 0.0500 | 95.9 | | 11/01/2006 | | |

B
11/2/06

Records printed: 96

Creator: NMEAD

Creation Date: Nov 1, 2006 9:27:43

Last Modified: Nov 1, 2006 12:30:30

Description: QC 8000 353.2 TOTN - RUN LOG - 0611010A

| Cup # | Sample ID | Manual Dilution | Sample Type | |
|-------|--------------------|-----------------|-------------|-----------------------------|
| 1 | Standard A - 2.000 | 1.0000 | CalStd | |
| 2 | Standard B - 1.000 | 1.0000 | CalStd | |
| 3 | Standard C - 0.500 | 1.0000 | CalStd | |
| 4 | Standard D - 0.200 | 1.0000 | CalStd | |
| 5 | Standard E - 0.100 | 1.0000 | CalStd | |
| 6 | Standard F - 0.050 | 1.0000 | CalStd | |
| 7 | Standard G - 0.020 | 1.0000 | CalStd | |
| 8 | Standard H - 0.010 | 1.0000 | CalStd | |
| 9 | Standard I - 0.000 | 1.0000 | CalStd | |
| 1 | 1.00 NO3 | 1.0000 | Unknown | |
| 2 | 1.00 NO2 | 1.0000 | Unknown | |
| 3 | ICV TV = 1.80 | 1.0000 | Unknown | |
| 4 | ICB | 1.0000 | Unknown | |
| 5 | LCS TV = 0.500 | 1.0000 | Unknown | |
| 6 | CRDL - 0.100 | 1.0000 | Unknown | |
| 7 | CRDL - 0.050 | 1.0000 | Unknown | |
| 8 | 947855-34349 | 1.0000 | Unknown | } rpt @ #118-120-1/4 |
| 9 | 855 DUP | 1.0000 | Unknown | |
| 10 | 855 SPK TV = 0.500 | 1.0000 | Unknown | |
| 11 | 947856 | 1.0000 | Unknown | |
| 12 | 947857 | 1.0000 | Unknown | |
| 13 | 935153-33532 | 1.0000 | Unknown | -neg. peak - LPO L |
| 14 | 935155 | 1.0000 | Unknown | |
| 15 | 946023-34295 | 1.0000 | Unknown | -neg. peak - rpt @ #121-1/2 |
| 16 | CCV | 1.0000 | Unknown | |
| 17 | CCB | 1.0000 | Unknown | |
| 18 | 023 DUP | 1.0000 | Unknown | -neg. peak - rpt @ #122-1/2 |
| 19 | 023 SPK TV = 0.500 | 1.0000 | Unknown | -low - rpt @ #123-1/2 |
| 20 | 946024 | 1.0000 | Unknown | |
| 21 | 946025 | 1.0000 | Unknown | |
| 22 | 946026 | 1.0000 | Unknown | -neg. peak - rpt @ #124 |
| 23 | 946027 | 1.0000 | Unknown | 1/2 |
| 24 | 948150-34348 | 1.0000 | Unknown | |
| 25 | 948151 | 1.0000 | Unknown | |
| 26 | 948152 | 1.0000 | Unknown | |
| 27 | 152 DUP | 1.0000 | Unknown | |
| 28 | CCV | 1.0000 | Unknown | |
| 29 | CCB | 1.0000 | Unknown | |
| 30 | LCS | 1.0000 | Unknown | |
| 31 | 152 SPK TV = 0.500 | 1.0000 | Unknown | |

| Cup # | Sample ID | Manual Dilution | Sample Type | |
|-------|--------------------|-----------------|-------------|--|
| 32 | 948153 | 1.0000 | Unknown | |
| 33 | 948154 | 1.0000 | Unknown | |
| 34 | 948173-34381 | 20.0000 | Unknown | |
| 35 | 948174 | 40.0000 | Unknown | |
| 36 | 948175 | 40.0000 | Unknown | |
| 37 | 948176 | 40.0000 | Unknown | |
| 38 | 948177 | 40.0000 | Unknown | |
| 39 | 948178 | 40.0000 | Unknown | |
| 40 | 948179 | 40.0000 | Unknown | |
| 41 | CCV | 1.0000 | Unknown | |
| 42 | CCB | 1.0000 | Unknown | |
| 43 | 948570-34419 | 1.0000 | Unknown | |
| 44 | 570 DUP | 1.0000 | Unknown | |
| 45 | 570 SPK TV = 0.500 | 1.0000 | Unknown | |
| 46 | 948573 | 1.0000 | Unknown | |
| 47 | 948575 | 1.0000 | Unknown | |
| 48 | 948578 | 1.0000 | Unknown | |
| 49 | 948580 | 1.0000 | Unknown | |
| 50 | 948581 | 1.0000 | Unknown | |
| 51 | 948584 | 1.0000 | Unknown | |
| 52 | 948586 | 1.0000 | Unknown | |
| 53 | CCV | 1.0000 | Unknown | |
| 54 | CCB | 1.0000 | Unknown | |
| 55 | LCS | 1.0000 | Unknown | |
| 56 | 948587 | 1.0000 | Unknown | |
| 57 | 948588 | 1.0000 | Unknown | |
| 58 | 948590 | 1.0000 | Unknown | |
| 59 | 948591 | 1.0000 | Unknown | |
| 60 | 948836-34432 | 1.0000 | Unknown | |
| 61 | 948839 | 1.0000 | Unknown | |
| 62 | 948944-34419 | 1.0000 | Unknown | |
| 63 | 948945 | 1.0000 | Unknown | |
| 64 | 948946 | 1.0000 | Unknown | |
| 65 | 946 DUP | 1.0000 | Unknown | |
| 66 | CCV | 1.0000 | Unknown | |
| 67 | CCB | 1.0000 | Unknown | |
| 68 | 946 SPK TV = 0.500 | 1.0000 | Unknown | |
| 69 | 948947 | 1.0000 | Unknown | |
| 70 | 948949 | 1.0000 | Unknown | |
| 71 | 948950 | 1.0000 | Unknown | |
| 72 | 948951 | 1.0000 | Unknown | |
| 73 | 948952 | 1.0000 | Unknown | |
| 74 | 948953 | 1.0000 | Unknown | |
| 75 | 948954 | 1.0000 | Unknown | |
| 76 | 949504-34463 | 1.0000 | Unknown | |

| Cup # | Sample ID | Manual Dilution | Sample Type | |
|-------|-------------------------|-----------------|-------------|-------------------------|
| 77 | 949505 | 1.0000 | Unknown | |
| 78 | CCV | 1.0000 | Unknown | |
| 79 | CCB | 1.0000 | Unknown | |
| 80 | LCS | 1.0000 | Unknown | |
| 81 | 505 DUP | 1.0000 | Unknown | |
| 82 | 505 SPK TV = 0.500 | 1.0000 | Unknown | |
| 83 | 949506 | 1.0000 | Unknown | |
| 84 | 949824-34481 | 1.0000 | Unknown | |
| 85 | 950030-34493 | 1.0000 | Unknown | |
| 86 | 030 DUP | 1.0000 | Unknown | |
| 87 | 030 SPK TV = 0.500 | 1.0000 | Unknown | - rpt@#125-1/2 |
| 88 | 950031 | 1.0000 | Unknown | - rpt@#126-1/2 |
| 89 | 950032 | 1.0000 | Unknown | - rpt@#127-1/2 |
| 90 | 950033 | 1.0000 | Unknown | - rpt@#131-1/4 |
| 91 | CCV | 1.0000 | Unknown | |
| 92 | CCB | 1.0000 | Unknown | |
| 93 | 950034 | 1.0000 | Unknown | - rpt@#132-1/20 |
| 94 | 950035 | 1.0000 | Unknown | - carryover? - rpt@#133 |
| 95 | 950036 | 1.0000 | Unknown | - rpt@#134-1/20 |
| 96 | 950450-34508 | 1.0000 | Unknown | - carryover? - rpt@#135 |
| 97 | 950466-34493 | 1.0000 | Unknown | - rpt@#136-1/2 |
| 98 | 950467 | 1.0000 | Unknown | - rpt@#137-1/20 |
| 99 | 950468 | 1.0000 | Unknown | - rpt@#138-1/20 |
| 100 | 950469 | 1.0000 | Unknown | - carryover? - rpt@#139 |
| 101 | 950470 | 1.0000 | Unknown | - rpt@#140-1/5 |
| 102 | 950471 | 1.0000 | Unknown | - rpt@#143-1/2 |
| 103 | CCV | 1.0000 | Unknown | |
| 104 | CCB | 1.0000 | Unknown | |
| 105 | LCS | 1.0000 | Unknown | |
| 106 | 950472 | 1.0000 | Unknown | - rpt@#144-1/4 |
| 107 | 950473 | 1.0000 | Unknown | |
| 108 | 950474 | 1.0000 | Unknown | - rpt@#145-1/4 |
| 109 | 950475 | 1.0000 | Unknown | - rpt@#146-1/10 |
| 110 | 950476 | 1.0000 | Unknown | - rpt@#147-1/10 |
| 111 | 950477 | 1.0000 | Unknown | } rpt@#148-150-1/4 |
| 112 | 477 DUP | 1.0000 | Unknown | |
| 113 | 477 SPK TV = 0.500 | 1.0000 | Unknown | |
| 114 | 951016-34538 | 1.0000 | Unknown | |
| 115 | 951017 | 1.0000 | Unknown | |
| 116 | CCV | 1.0000 | Unknown | |
| 117 | CCB | 1.0000 | Unknown | |
| 118 | 947855 RPT 1/4 | 4.0000 | Unknown | |
| 119 | 855 DUP RPT 1/4 | 4.0000 | Unknown | |
| 120 | 855SPK RPT1/4 TV = 0.50 | 4.0000 | Unknown | |
| 121 | 946023 RPT 1/2 | 2.0000 | Unknown | |

| Cup # | Sample ID | Manual Dilution | Sample Type | |
|-------|------------------------|-----------------|-------------|-------------------------------|
| 122 | 023 DUP RPT 1/2 | 2.0000 | Unknown | |
| 123 | 023SPK RPT1/2 TV= 0.50 | 2.0000 | Unknown | -low-rpt @ #151 |
| 124 | 946026 RPT 1/2 | 2.0000 | Unknown | -neg. peak - rpt @ #152 - 1/4 |
| 125 | 950030SPKRPT1/2TV=0.5 | 2.0000 | Unknown | |
| 126 | 950031 RPT 1/2 | 2.0000 | Unknown | |
| 127 | 950032 RPT 1/2 | 2.0000 | Unknown | |
| 128 | CCV | 1.0000 | Unknown | |
| 129 | CCB | 1.0000 | Unknown | |
| 130 | LCS | 1.0000 | Unknown | |
| 131 | 950033 RPT 1/4 | 4.0000 | Unknown | |
| 132 | 950034 RPT 1/20 | 20.0000 | Unknown | |
| 133 | 950035 RPT | 1.0000 | Unknown | |
| 134 | 950036 RPT 1/20 | 20.0000 | Unknown | |
| 135 | 950450 RPT | 1.0000 | Unknown | |
| 136 | 950466 RPT 1/2 | 2.0000 | Unknown | |
| 137 | 950467 RPT 1/20 | 20.0000 | Unknown | |
| 138 | 950468 RPT 1/20 | 20.0000 | Unknown | |
| 139 | 950469 RPT | 1.0000 | Unknown | |
| 140 | 950470 RPT 1/5 | 5.0000 | Unknown | |
| 141 | CCV | 1.0000 | Unknown | |
| 142 | CCB | 1.0000 | Unknown | |
| 143 | 950471 RPT 1/2 | 2.0000 | Unknown | |
| 144 | 950472 RPT 1/4 | 4.0000 | Unknown | |
| 145 | 950474 RPT 1/4 | 4.0000 | Unknown | |
| 146 | 950475 RPT 1/10 | 10.0000 | Unknown | |
| 147 | 950476 RPT 1/10 | 10.0000 | Unknown | |
| 148 | 950477 RPT 1/4 | 4.0000 | Unknown | |
| 149 | 477 DUP RPT 1/4 | 4.0000 | Unknown | |
| 150 | 477 SPK RPT1/4 TV=0.50 | 4.0000 | Unknown | |
| 151 | 946023SPKRPT1/2TV=0.5 | 2.0000 | Unknown | |
| 152 | 946026 RPT 1/4 | 4.0000 | Unknown | |
| 153 | CCV | 1.0000 | Unknown | |
| 154 | CCB | 1.0000 | Unknown | |

OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA

Multi-Channel Table
Type: Unknowns
Channel Range: 1 to 8 - Cup Range: 1 to 25

| Cup | Sample ID | Sampling Date | Sampling Time | Rep # | QC 8000 353.2 NO3+NO2 (TOTN) (mg/l) | Man Dil Factor | Auto Dil Factor |
|-----|-------------------|---------------|---------------|-------|--|----------------|-----------------|
| 1 | 1.00 NO3 | 01 Nov 2006 | 10:27:29 | 1 | 0.9857 | 1.0 | 1.00 |
| 2 | 1.00 NO2 | 01 Nov 2006 | 10:28:32 | 1 | 1.0667 | 1.0 | 1.00 |
| 3 | ICV TV= 1.80 | 01 Nov 2006 | 10:29:36 | 1 | 1.8117 | 1.0 | 1.00 |
| 4 | ICB | 01 Nov 2006 | 10:30:39 | 1 | 0.0010 | 1.0 | 1.00 |
| 5 | LCS TV= 0.500 | 01 Nov 2006 | 10:31:42 | 1 | 0.5006 | 1.0 | 1.00 |
| 6 | CRDL - 0.100 | 01 Nov 2006 | 10:32:46 | 1 | 0.1027 | 1.0 | 1.00 |
| 7 | CRDL - 0.050 | 01 Nov 2006 | 10:33:48 | 1 | 0.0543 | 1.0 | 1.00 |
| 8 | 947855-34349 | 01 Nov 2006 | 10:34:50 | 1 | 2.9366 | 1.0 | 1.00 |
| 9 | 855 DUP | 01 Nov 2006 | 10:35:52 | 1 | 2.9190 | 1.0 | 1.00 |
| 10 | 855 SPK TV= 0.500 | 01 Nov 2006 | 10:36:55 | 1 | 3.4224 | 1.0 | 1.00 |
| 11 | 947856 | 01 Nov 2006 | 10:37:57 | 1 | 0.1835 | 1.0 | 1.00 |
| 12 | 947857 | 01 Nov 2006 | 10:38:59 | 1 | 0.0156 | 1.0 | 1.00 |
| 13 | 935153-33532 | 01 Nov 2006 | 10:40:01 | 1 | 0.0294 | 1.0 | 1.00 |
| 14 | 935155 | 01 Nov 2006 | 10:41:04 | 1 | 0.4732 | 1.0 | 1.00 |
| 15 | 946023-34295 | 01 Nov 2006 | 10:42:05 | 1 | 0.0010 | 1.0 | 1.00 |
| 16 | CCV | 01 Nov 2006 | 10:43:09 | 1 | 1.8024 | 1.0 | 1.00 |
| 17 | CCB | 01 Nov 2006 | 10:44:12 | 1 | 0.0010 | 1.0 | 1.00 |
| 18 | 023 DUP | 01 Nov 2006 | 10:45:15 | 1 | 0.0010 | 1.0 | 1.00 |
| 19 | 023 SPK TV= 0.500 | 01 Nov 2006 | 10:46:19 | 1 | 0.1219 | 1.0 | 1.00 |
| 20 | 946024 | 01 Nov 2006 | 10:47:22 | 1 | 0.0266 | 1.0 | 1.00 |
| 21 | 946025 | 01 Nov 2006 | 10:48:25 | 1 | 0.0403 | 1.0 | 1.00 |
| 22 | 946026 | 01 Nov 2006 | 10:49:28 | 1 | 0.0010 | 1.0 | 1.00 |
| 23 | 946027 | 01 Nov 2006 | 10:50:32 | 1 | 0.2834 | 1.0 | 1.00 |
| 24 | 948150-34348 | 01 Nov 2006 | 10:51:34 | 1 | 0.0202 | 1.0 | 1.00 |
| 25 | 948151 | 01 Nov 2006 | 10:52:36 | 1 | 1.1097 | 1.0 | 1.00 |

rpt@#118-120-1/4

1.00 - neg. peak - < PQL

1.00 - neg. peak - rpt@#121-1/2

1.00 - neg. peak - rpt@#122-1/2

1.00 - low - rpt@#123-1/2

1.00 - neg. peak - rpt@#124-1/2

OPERATOR: NMEAD
 ACQ. TIME: Nov 1, 2006 10:27:26
 DATA FILENAME: C:\OMNION\DATA\061101A1.FDT
 TRAY FILENAME: C:\OMNION\TRAYS\0611010A.TRA

Multi-Channel Table
 Type: Unknowns
 Channel Range: 1 to 8 -- Cup Range: 26 to 50

| Cup | Sample ID | Sampling Date | Sampling Time | Rep # | QC 8000 353.2 NO3+NO2 (TOTN) (mg/l) | Man Dil Factor | Auto Dil Factor |
|-----|-------------------|---------------|---------------|-------|--|----------------|-----------------|
| 26 | 948152 | 01 Nov 2006 | 10:53:39 | 1 | 0.5120 | 1.0 | 1.00 |
| 27 | 152 DUP | 01 Nov 2006 | 10:54:41 | 1 | 0.5117 | 1.0 | 1.00 |
| 28 | CCV | 01 Nov 2006 | 10:55:43 | 1 | 1.8245 | 1.0 | 1.00 |
| 29 | CCB | 01 Nov 2006 | 10:56:46 | 1 | 0.0010 | 1.0 | 1.00 |
| 30 | LCS | 01 Nov 2006 | 10:57:48 | 1 | 0.5044 | 1.0 | 1.00 |
| 31 | 152 SPK TV= 0.500 | 01 Nov 2006 | 10:58:52 | 1 | 1.0126 | 1.0 | 1.00 |
| 32 | 948153 | 01 Nov 2006 | 10:59:55 | 1 | 0.0985 | 1.0 | 1.00 |
| 33 | 948154 | 01 Nov 2006 | 11:00:59 | 1 | 1.0150 | 1.0 | 1.00 |
| 34 | 948173-34381 | 01 Nov 2006 | 11:02:02 | 1 | 13.6966 | 20.0 | 1.00 |
| 35 | 948174 | 01 Nov 2006 | 11:03:05 | 1 | 17.2287 | 40.0 | 1.00 |
| 36 | 948175 | 01 Nov 2006 | 11:04:09 | 1 | 17.0988 | 40.0 | 1.00 |
| 37 | 948176 | 01 Nov 2006 | 11:05:12 | 1 | 15.9668 | 40.0 | 1.00 |
| 38 | 948177 | 01 Nov 2006 | 11:06:16 | 1 | 19.1597 | 40.0 | 1.00 |
| 39 | 948178 | 01 Nov 2006 | 11:07:18 | 1 | 19.7445 | 40.0 | 1.00 |
| 40 | 948179 | 01 Nov 2006 | 11:08:20 | 1 | 19.1505 | 40.0 | 1.00 |
| 41 | CCV | 01 Nov 2006 | 11:09:23 | 1 | 1.8188 | 1.0 | 1.00 |
| 42 | CCB | 01 Nov 2006 | 11:10:25 | 1 | 0.0010 | 1.0 | 1.00 |
| 43 | 948570-34419 | 01 Nov 2006 | 11:11:27 | 1 | 0.0413 | 1.0 | 1.00 |
| 44 | 570 DUP | 01 Nov 2006 | 11:12:30 | 1 | 0.0414 | 1.0 | 1.00 |
| 45 | 570 SPK TV= 0.500 | 01 Nov 2006 | 11:13:32 | 1 | 0.4655 | 1.0 | 1.00 |
| 46 | 948573 | 01 Nov 2006 | 11:14:37 | 1 | 0.1059 | 1.0 | 1.00 |
| 47 | 948575 | 01 Nov 2006 | 11:15:40 | 1 | 0.0165 | 1.0 | 1.00 |
| 48 | 948578 | 01 Nov 2006 | 11:16:43 | 1 | 0.0170 | 1.0 | 1.00 |
| 49 | 948580 | 01 Nov 2006 | 11:17:47 | 1 | 0.0401 | 1.0 | 1.00 |
| 50 | 948581 | 01 Nov 2006 | 11:18:50 | 1 | 0.0767 | 1.0 | 1.00 |

OPERATOR: NMEAD
ACQ. TIME: Nov 1, 2006 10:27:26
DATA FILENAME: C:\OMNION\DATA\061101A1.FDT
TRAY FILENAME: C:\OMNION\TRAYS\0611010A.TRA

Multi-Channel Table
 Type: Unknowns
 Channel Range: 1 to 8 – Cup Range: 51 to 75

| Cup | Sample ID | Sampling Date | Sampling Time | Rep # | QC 8000 353.2 NO3+NO2 (TOTN) (mg/l) | Man Dil Factor | Auto Dil Factor |
|-----|-------------------|---------------|---------------|-------|--|----------------|-----------------|
| 51 | 948584 | 01 Nov 2006 | 11:19:54 | 1 | 0.0260 | 1.0 | 1.00 |
| 52 | 948586 | 01 Nov 2006 | 11:20:57 | 1 | 0.0238 | 1.0 | 1.00 |
| 53 | CCV | 01 Nov 2006 | 11:22:01 | 1 | 1.8106 | 1.0 | 1.00 |
| 54 | CCB | 01 Nov 2006 | 11:23:04 | 1 | 0.0010 | 1.0 | 1.00 |
| 55 | LCS | 01 Nov 2006 | 11:24:07 | 1 | 0.5007 | 1.0 | 1.00 |
| 56 | 948587 | 01 Nov 2006 | 11:25:10 | 1 | 0.0865 | 1.0 | 1.00 |
| 57 | 948588 | 01 Nov 2006 | 11:26:12 | 1 | 0.0257 | 1.0 | 1.00 |
| 58 | 948590 | 01 Nov 2006 | 11:27:14 | 1 | 0.0376 | 1.0 | 1.00 |
| 59 | 948591 | 01 Nov 2006 | 11:28:17 | 1 | 0.0417 | 1.0 | 1.00 |
| 60 | 948836-34432 | 01 Nov 2006 | 11:29:19 | 1 | 0.4370 | 1.0 | 1.00 |
| 61 | 948839 | 01 Nov 2006 | 11:30:24 | 1 | 0.0928 | 1.0 | 1.00 |
| 62 | 948944-34419 | 01 Nov 2006 | 11:31:28 | 1 | 0.0201 | 1.0 | 1.00 |
| 63 | 948945 | 01 Nov 2006 | 11:32:33 | 1 | 0.0125 | 1.0 | 1.00 |
| 64 | 948946 | 01 Nov 2006 | 11:33:37 | 1 | 0.4750 | 1.0 | 1.00 |
| 65 | 946 DUP | 01 Nov 2006 | 11:34:40 | 1 | 0.4648 | 1.0 | 1.00 |
| 66 | CCV | 01 Nov 2006 | 11:35:44 | 1 | 1.7757 | 1.0 | 1.00 |
| 67 | CCB | 01 Nov 2006 | 11:36:47 | 1 | 0.0010 | 1.0 | 1.00 |
| 68 | 946 SPK TV= 0.500 | 01 Nov 2006 | 11:37:51 | 1 | 0.9822 | 1.0 | 1.00 |
| 69 | 948947 | 01 Nov 2006 | 11:38:54 | 1 | 0.6821 | 1.0 | 1.00 |
| 70 | 948949 | 01 Nov 2006 | 11:39:57 | 1 | 0.0282 | 1.0 | 1.00 |
| 71 | 948950 | 01 Nov 2006 | 11:41:01 | 1 | 0.0230 | 1.0 | 1.00 |
| 72 | 948951 | 01 Nov 2006 | 11:42:03 | 1 | 0.0495 | 1.0 | 1.00 |
| 73 | 948952 | 01 Nov 2006 | 11:43:05 | 1 | 0.0677 | 1.0 | 1.00 |
| 74 | 948953 | 01 Nov 2006 | 11:44:08 | 1 | 0.0254 | 1.0 | 1.00 |
| 75 | 948954 | 01 Nov 2006 | 11:45:10 | 1 | 0.2786 | 1.0 | 1.00 |

OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA

Multi-Channel Table
Type: Unknowns
Channel Range: 1 to 8 - Cup Range: 76 to 100

| Cup | Sample ID | Sampling Date | Sampling Time | Rep # | QC 8000 353.2 NO3+NO2 (TOTN) (mg/l) | Man Dil Factor | Auto Dil Factor |
|-----|-------------------|---------------|---------------|-------|--|----------------|------------------------------|
| 76 | 949504-34463 | 01 Nov 2006 | 11:46:15 | 1 | 0.2059 | 1.0 | 1.00 |
| 77 | 949505 | 01 Nov 2006 | 11:47:19 | 1 | 0.7533 | 1.0 | 1.00 |
| 78 | CCV | 01 Nov 2006 | 11:48:24 | 1 | 1.7498 | 1.0 | 1.00 |
| 79 | CCB | 01 Nov 2006 | 11:49:27 | 1 | 0.0010 | 1.0 | 1.00 |
| 80 | LCS | 01 Nov 2006 | 11:50:31 | 1 | 0.4878 | 1.0 | 1.00 |
| 81 | 505 DUP | 01 Nov 2006 | 11:51:35 | 1 | 0.7400 | 1.0 | 1.00 |
| 82 | 505 SPK TV= 0.500 | 01 Nov 2006 | 11:52:38 | 1 | 1.2433 | 1.0 | 1.00 |
| 83 | 949506 | 01 Nov 2006 | 11:53:42 | 1 | 1.1658 | 1.0 | 1.00 |
| 84 | 949824-34481 | 01 Nov 2006 | 11:54:45 | 1 | 0.1346 | 1.0 | 1.00 |
| 85 | 950030-34493 | 01 Nov 2006 | 11:55:49 | 1 | 1.7731 | 1.0 | 1.00 |
| 86 | 030 DUP | 01 Nov 2006 | 11:56:52 | 1 | 1.7800 | 1.0 | 1.00 |
| 87 | 030 SPK TV= 0.500 | 01 Nov 2006 | 11:57:55 | 1 | 2.2632 | 1.0 | 1.00 - rpt@#125-1/2 |
| 88 | 950031 | 01 Nov 2006 | 11:58:58 | 1 | 2.4767 | 1.0 | 1.00 - rpt@#126-1/2 |
| 89 | 950032 | 01 Nov 2006 | 12:00:00 | 1 | 2.1162 | 1.0 | 1.00 - rpt@#127-1/2 |
| 90 | 950033 | 01 Nov 2006 | 12:01:03 | 1 | 3.9828 | 1.0 | 1.00 - rpt@#131-1/4 |
| 91 | CCV | 01 Nov 2006 | 12:02:07 | 1 | 1.7436 | 1.0 | 1.00 |
| 92 | CCB | 01 Nov 2006 | 12:03:12 | 1 | 0.0010 | 1.0 | 1.00 |
| 93 | 950034 | 01 Nov 2006 | 12:04:16 | 1 | 15.3217 | 1.0 | 1.00 - rpt@#132-1/20 |
| 94 | 950035 | 01 Nov 2006 | 12:05:21 | 1 | 0.2280 | 1.0 | 1.00 - carryover? - rpt@#133 |
| 95 | 950036 | 01 Nov 2006 | 12:06:25 | 1 | 14.5540 | 1.0 | 1.00 - rpt@#134-1/20 |
| 96 | 950450-34508 | 01 Nov 2006 | 12:07:29 | 1 | 1.8083 | 1.0 | 1.00 - carryover? - rpt@#135 |
| 97 | 950466-34493 | 01 Nov 2006 | 12:08:32 | 1 | 3.2085 | 1.0 | 1.00 - rpt@#136-1/2 |
| 98 | 950467 | 01 Nov 2006 | 12:09:35 | 1 | 16.5892 | 1.0 | 1.00 - rpt@#137-1/20 |
| 99 | 950468 | 01 Nov 2006 | 12:10:39 | 1 | 16.5261 | 1.0 | 1.00 - rpt@#138-1/20 |
| 100 | 950469 | 01 Nov 2006 | 12:11:42 | 1 | 0.0224 | 1.0 | 1.00 - carryover? - rpt@#139 |

OPERATOR: NMEAD
 ACQ. TIME: Nov 1, 2006 10:27:26
 DATA FILENAME: C:\OMNION\DATA\061101A1.FDT
 TRAY FILENAME: C:\OMNION\TRAYS\0611010A.TRA

Multi-Channel Table
 Type: Unknowns
 Channel Range: 1 to 8 - Cup Range: 101 to 125

| Cup | Sample ID | Sampling Date | Sampling Time | Rep # | QC 8000 353.2 NO3+NO2 (TOTN) (mg/l) | Man Dil Factor | Auto Dil Factor | |
|-----|------------------------|---------------|---------------|-------|--|----------------|-----------------|-------------------------------|
| 101 | 950470 | 01 Nov 2006 | 12:12:46 | 1 | 8.4328 | 1.0 | 1.00 | - rpt@ #140 - 1/5 |
| 102 | 950471 | 01 Nov 2006 | 12:13:49 | 1 | 2.7659 | 1.0 | 1.00 | - rpt@ #143 - 1/2 |
| 103 | CCV | 01 Nov 2006 | 12:14:53 | 1 | 1.7513 | 1.0 | 1.00 | |
| 104 | CCB | 01 Nov 2006 | 12:15:55 | 1 | 0.0010 | 1.0 | 1.00 | |
| 105 | LCS | 01 Nov 2006 | 12:16:57 | 1 | 0.4917 | 1.0 | 1.00 | |
| 106 | 950472 | 01 Nov 2006 | 12:18:02 | 1 | 3.5984 | 1.0 | 1.00 | - rpt@ #144 - 1/4 |
| 107 | 950473 | 01 Nov 2006 | 12:19:06 | 1 | 1.1384 | 1.0 | 1.00 | |
| 108 | 950474 | 01 Nov 2006 | 12:20:11 | 1 | 3.7556 | 1.0 | 1.00 | - rpt@ #145 - 1/4 |
| 109 | 950475 | 01 Nov 2006 | 12:21:15 | 1 | 8.5818 | 1.0 | 1.00 | - rpt@ #146 - 1/10 |
| 110 | 950476 | 01 Nov 2006 | 12:22:19 | 1 | 8.7196 | 1.0 | 1.00 | - rpt@ #147 - 1/10 |
| 111 | 950477 | 01 Nov 2006 | 12:23:24 | 1 | 3.0737 | 1.0 | 1.00 | } rpt@ #148 - 150 - 1/4 |
| 112 | 477 DUP | 01 Nov 2006 | 12:24:27 | 1 | 3.1035 | 1.0 | 1.00 | |
| 113 | 477 SPK TV= 0.500 | 01 Nov 2006 | 12:25:31 | 1 | 3.6077 | 1.0 | 1.00 | |
| 114 | 951016-34538 | 01 Nov 2006 | 12:26:34 | 1 | 0.0156 | 1.0 | 1.00 | |
| 115 | 951017 | 01 Nov 2006 | 12:27:38 | 1 | 1.1492 | 1.0 | 1.00 | |
| 116 | CCV | 01 Nov 2006 | 12:28:41 | 1 | 1.7133 | 1.0 | 1.00 | |
| 117 | CCB | 01 Nov 2006 | 12:29:44 | 1 | 0.0010 | 1.0 | 1.00 | |
| 118 | 947855 RPT 1/4 | 01 Nov 2006 | 12:30:48 | 1 | 2.8383 | 4.0 | 1.00 | |
| 119 | 855 DUP RPT 1/4 | 01 Nov 2006 | 12:31:50 | 1 | 2.8307 | 4.0 | 1.00 | |
| 120 | 855SPK RPT1/4 TV= 0.50 | 01 Nov 2006 | 12:32:54 | 1 | 4.7197 | 4.0 | 1.00 | |
| 121 | 946023 RPT 1/2 | 01 Nov 2006 | 12:33:58 | 1 | 0.0866 | 2.0 | 1.00 | Sine peak, < 0.05 |
| 122 | 023 DUP RPT 1/2 | 01 Nov 2006 | 12:35:03 | 1 | 0.0854 | 2.0 | 1.00 | ↓ |
| 123 | 023SPK RPT1/2 TV= 0.50 | 01 Nov 2006 | 12:36:07 | 1 | 0.5071 | 2.0 | 1.00 | - low - rpt@ #151 |
| 124 | 946026 RPT 1/2 | 01 Nov 2006 | 12:37:12 | 1 | 0.1560 | 2.0 | 1.00 | - neg. peak - rpt@ #152 - 1/4 |
| 125 | 950030SPKRPT1/2TV=0.5 | 01 Nov 2006 | 12:38:16 | 1 | 2.6790 | 2.0 | 1.00 | |

OPERATOR: NMEAD
 ACQ. TIME: Nov 1, 2006 10:27:26
 DATA FILENAME: C:\OMNION\DATA\061101A1.FDT
 TRAY FILENAME: C:\OMNION\TRAYS\0611010A.TRA

Multi-Channel Table
 Type: Unknowns
 Channel Range: 1 to 8 -- Cup Range: 126 to 150

| Cup | Sample ID | Sampling Date | Sampling Time | Rep # | QC 8000 353.2 NO3+NO2 (TOTN) (mg/l) | Man Dil Factor | Auto Dil Factor |
|-----|------------------------|---------------|---------------|-------|--|----------------|-----------------|
| 126 | 950031 RPT 1/2 | 01 Nov 2006 | 12:39:20 | 1 | 2.4400 | 2.0 | 1.00 |
| 127 | 950032 RPT 1/2 | 01 Nov 2006 | 12:40:25 | 1 | 2.0654 | 2.0 | 1.00 |
| 128 | CCV | 01 Nov 2006 | 12:41:29 | 1 | 1.7114 | 1.0 | 1.00 |
| 129 | CCB | 01 Nov 2006 | 12:42:33 | 1 | 0.0010 | 1.0 | 1.00 |
| 130 | LCS | 01 Nov 2006 | 12:43:36 | 1 | 0.4797 | 1.0 | 1.00 |
| 131 | 950033 RPT 1/4 | 01 Nov 2006 | 12:44:40 | 1 | 3.8918 | 4.0 | 1.00 |
| 132 | 950034 RPT 1/20 | 01 Nov 2006 | 12:45:43 | 1 | 28.5582 | 20.0 | 1.00 |
| 133 | 950035 RPT | 01 Nov 2006 | 12:46:46 | 1 | 0.2295 | 1.0 | 1.00 |
| 134 | 950036 RPT 1/20 | 01 Nov 2006 | 12:47:50 | 1 | 24.8790 | 20.0 | 1.00 |
| 135 | 950450 RPT | 01 Nov 2006 | 12:48:53 | 1 | 1.7902 | 1.0 | 1.00 |
| 136 | 950466 RPT 1/2 | 01 Nov 2006 | 12:49:59 | 1 | 3.1455 | 2.0 | 1.00 |
| 137 | 950467 RPT 1/20 | 01 Nov 2006 | 12:51:04 | 1 | 38.3732 | 20.0 | 1.00 |
| 138 | 950468 RPT 1/20 | 01 Nov 2006 | 12:52:08 | 1 | 38.4165 | 20.0 | 1.00 |
| 139 | 950469 RPT | 01 Nov 2006 | 12:53:13 | 1 | 0.0283 | 1.0 | 1.00 |
| 140 | 950470 RPT 1/5 | 01 Nov 2006 | 12:54:17 | 1 | 9.1721 | 5.0 | 1.00 |
| 141 | CCV | 01 Nov 2006 | 12:55:22 | 1 | 1.6999 | 1.0 | 1.00 |
| 142 | CCB | 01 Nov 2006 | 12:56:26 | 1 | 0.0010 | 1.0 | 1.00 |
| 143 | 950471 RPT 1/2 | 01 Nov 2006 | 12:57:31 | 1 | 2.6949 | 2.0 | 1.00 |
| 144 | 950472 RPT 1/4 | 01 Nov 2006 | 12:58:35 | 1 | 3.5801 | 4.0 | 1.00 |
| 145 | 950474 RPT 1/4 | 01 Nov 2006 | 12:59:38 | 1 | 3.6782 | 4.0 | 1.00 |
| 146 | 950475 RPT 1/10 | 01 Nov 2006 | 13:00:42 | 1 | 9.6644 | 10.0 | 1.00 |
| 147 | 950476 RPT 1/10 | 01 Nov 2006 | 13:01:45 | 1 | 9.7271 | 10.0 | 1.00 |
| 148 | 950477 RPT 1/4 | 01 Nov 2006 | 13:02:49 | 1 | 3.0530 | 4.0 | 1.00 |
| 149 | 477 DUP RPT 1/4 | 01 Nov 2006 | 13:03:52 | 1 | 3.0568 | 4.0 | 1.00 |
| 150 | 477 SPK RPT1/4 TV=0.50 | 01 Nov 2006 | 13:04:55 | 1 | 5.0872 | 4.0 | 1.00 |

OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA

Multi-Channel Table
Type: Unknowns
Channel Range: 1 to 8 - Cup Range: 151 to 175

| Cup | Sample ID | Sampling Date | Sampling Time | Rep # | QC 8000 353.2 NO3+NO2 (TOTN) (mg/l) | Man Dil Factor | Auto Dil Factor |
|-----|-----------------------|---------------|---------------|-------|--|----------------|-----------------|
| 151 | 946023SPKRPT1/2TV=0.5 | 01 Nov 2006 | 13:06:01 | 1 | 0.5168 | 2.0 | 1.00 |
| 152 | 946026 RPT 1/4 | 01 Nov 2006 | 13:07:06 | 1 | 0.2024 | 4.0 | 1.00 |
| 153 | CCV | 01 Nov 2006 | 13:08:11 | 1 | 1.6894 | 1.0 | 1.00 |
| 154 | CCB | 01 Nov 2006 | 13:09:15 | 1 | 0.0010 | 1.0 | 1.00 |


- report original 1/2 result
- sine peak - height < PQL
result = < 0.200
= < 0.05

BB 11/1/06

OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:13:27
C:\OMNION\DATA\0611010A.FDT
C:\OMNION\TRAYS\0611010A.TRA


Channel 1 - QC 8000 353.2 NO3 + NO2 (TOTN)



OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA


Channel 1 - QC 8000 353.2 NO3+NO2 (TOTN)



OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA


Channel 1 - QC 8000 353.2 NO3+NO2 (TOTN)



OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA


Channel 1 - QC 8000 353.2 NO3+NO2 (TOTN)



OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA


Channel 1 - QC 8000 353.2 NO3+NO2 (TOTN)



OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA


Channel 1 - QC 8000 353.2 NO3+NO2 (TOTN)



OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNIONDATA\061101A1.FDT
C:\OMNIONTRAYS\0611010A.TRA


Channel 1 - QC 8000 353.2 NO3+NO2 (TOTN)



OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA


Channel 1 - QC 8000 353.2 NO3+NO2 (TOTN)



OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA


Channel 1 - QC 8000 353.2 NO3+NO2 (TOTN)



OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA


Channel 1 - QC 8000 353.2 NO3+NO2 (TOTN)



OPERATOR:
ACQ. TIME:
DATA FILENAME:
TRAY FILENAME:

NMEAD
Nov 1, 2006 10:27:26
C:\OMNION\DATA\061101A1.FDT
C:\OMNION\TRAYS\0611010A.TRA

Channel 1 - QC 8000 353.2 NO3 + NO2 (TOTN)



OPERATOR: NMEAD
ACQ. TIME: Nov 1, 2006 10:13:27
DATA FILENAME: C:\OMNION\DATA\0611010A.FDT
METHOD FILENAME:
TRAY FILENAME: C:\OMNION\TRAYS\0611010A.TRA

TRAY DESCRIPTION:

Created: Nov 1, 2006 9:27:43
Modified: Nov 1, 2006 10:09:21
QC 8000 353.2 TOTN - RUN LOG - 0611010A

DATA DESCRIPTION:

Created: Nov 1, 2006 10:13:27
Modified: Nov 1, 2006 10:13:27

Method - Ch. 1 (QC 8000 353.2 NO3+NO2 (TOTN))

METHOD DESCRIPTION:

Created: Oct 1, 2004 11:03:56
Modified: Nov 1, 2006 10:04:24
Nitrate + Nitrite (TOTN) 000516A1

ANALYTE DATA:

Analyte Name: QC 8000 353.2 NO3+NO2 (TOTN)
Concentration Units: mg/l
Chemistry: Direct
Inject to Peak Start (s): 15.0
Peak Base Width (s): 50.915
% Width Tolerance: 1.000
Threshold: 3083.000
Autodilution Trigger: Off
QuikChem Method:

CALIBRATION DATA:

Levels:
 1 : 2.000 2 : 1.000 3 : 0.500 4 : 0.200
 5 : 0.100 6 : 0.050 7 : 0.020 8 : 0.010
 9 : 0.000

Calibration Rep Handling: Average
Calibration Fit Type: 1st Order Poly
Force Though Zero: No
Weighting Method: None
Concentration Scaling: None


QC 8000 353.2 NO3+NO2 (TOTN)

| Lvl | Area | mg/l | Rep 1 | Rep 2 | Rep 3 | Rep 4 | Rep 5 | Replic STD | Replic % RSD | Residual 1st Poly |
|-----|----------|------|----------|--------|-------|-------|-------|---------------|-----------------|----------------------|
| 1 | 12369773 | 2.00 | 12369773 | | | | | 0.0 | 0.0 | -0.5 |
| 2 | 6049634 | 1.00 | 6049634 | | | | | 0.0 | 0.0 | 1.6 |
| 3 | 3015337 | 0.50 | 3015337 | | | | | 0.0 | 0.0 | 1.9 |
| 4 | 1228422 | 0.20 | 1228422 | | | | | 0.0 | 0.0 | -0.2 |
| 5 | 610515 | 0.10 | 610515 | | | | | 0.0 | 0.0 | -0.1 |
| 6 | 335348 | 0.05 | 335348 | | | | | 0.0 | 0.0 | -10.9 |
| 7 | 148458 | 0.02 | 145762 | 151154 | | | | 3812.7 | 2.6 | -25.4 |
| 8 | 77912 | 0.01 | 79061 | 76762 | | | | 1625.6 | 2.1 | -36.2 |
| 9 | 0 | 0.00 | 0 | 0 | | | | 0.0 | 0.0 | |

1st Order Poly
 Conc = 1.624e-007 Area + 9.693e-004
 r = 0.9999

pipette ID is: TY
 sally

Scaling: None - Weighting: None



General Chemistry Analytical Run Cover Sheet

Analyst: N. Mead

Date: ~~10/3~~ ^{11/11/06} 11/1/06

Analysis: NO3 + NO2 (Regular Level 0.01 - 2.0)

Instrument: Lachat

Quality Control:

| | Same as Log#, Date, | Stocks Prep. Log#, Date, | Stock Sol (mLs) | Stock Sol (mg/L) | Final Vol (mLs) | True Value (mg/L) |
|------------------------|---------------------|--------------------------|-----------------|------------------|-----------------|-------------------|
| a) Standards Prep.: | WC69091D, 3/4/04 | WC72002K, 10/05/06 | | | | |
| b) ICV Preparation: | WC69091E, 3/4/04 | WC72007K, 10/05/06 | 1 | 18 | 10 | 1.80 |
| c) LCS Preparation: | WC69091F, 3/4/04 | WC72002K, 10/05/06 | 0.05 | 100 | 10 | 0.50 |
| d) Matrix Spike Prep.: | WC69091F, 3/4/04 | WC72002K, 10/05/06 | 0.05 | 100 | 10 | 0.50 |
| e) Column check: | WC69091G, 3/4/04 | WC72001H, 2/22/06 | | | | |

Instrument log filled in? (Y) (N)

Packages: Copy and attach Standards Preparation

Comments:

Production:

| | Start Time | End Time | Total (minutes) |
|--------------------|------------|----------|-----------------|
| Preparation Time : | | | |
| Analytical Time: | | | |
| Finish Time: | | | |

of Samples (including Mtx QC): _____
 Repeats due to Sample: _____
 Repeats due to Error: _____

3/3/04
 CMW
 ④ ^{3/1/04} Nitrite (NO_2) Continued
 ⑥ ICV/CCV: (TV=0.900 mg/L)
 Add 0.50 mLs of 18.0 ppm reference stock
 (i) one $\frac{1}{10}$ dilution of 180 ppm reference stock
 (WCG9089B) to 9.5 mLs DI.

④ ^{3/1/04} LCS/Matrix Spike (TV=0.250 mg/L)
 Add 0.25 mLs 10 ppm working stock (WCG9090E)
 to 10 mLs DI or sample.

3/4/04
 CC
 ③ Nitrate/Nitrite (TOTN) - Regular Level (Zachat 8000 GC)
 → 10 ppm Standard Working Stock - Do two (2) $\frac{1}{10}$ serial
 dilutions of 1000 ppm standard NO_3 Stock (WCG9083E)
 Make fresh each run.

④ Standards - make fresh each run

| Standard | Conc. | mLs 10 ppm (WCG9083E) ^{7/10} | MIS DI |
|----------|-------|---------------------------------------|--------|
| A | 2.00 | 2.00 | 9.0 |
| B | 1.00 | 1.00 | 9.0 |
| C | 0.50 | 0.50 | 9.5 |
| D | 0.20 | 0.20 | 9.8 |
| E | 0.10 | $\frac{1}{10}$ dil'n of B) 1.00 | 9.0 |
| F | 0.05 | $\frac{1}{10}$ dil'n of C) 0.50 | 9.0 |
| G | 0.02 | $\frac{1}{10}$ dil'n of D) 0.20 | 9.0 |
| H | 0.01 | $\frac{1}{10}$ dil'n of E) 0.10 | 9.0 |
| I | 0.00 | | 10.0 |

⑤ Reference ICV/CCV (TV=1.80)

Make two (2) $\frac{1}{10}$ serial dilutions of 180 ppm NO_3
 reference stock (WCG9083E). Make fresh each run.

⑥ LCS/Matrix spike (TV=0.50)

Add 0.050 mLs 100 ppm working stock (one (1) $\frac{1}{10}$ serial
 dilution of 1000 ppm NO_3 standard stock (WCG9083E) to 10 mLs of DI
 or sample. Make fresh each run.

⑦ Column Checks Make fresh each run

100 ppm NO_3 = 7.00 cal STD B

100 ppm NO_2 = (3) three $\frac{1}{10}$ serial dilutions of 1000 ppm NO_2

REFERENCE (ICV / CCV) STOCK PREP
 (Fluoride and Bromide are purchased 1000ppm standards)

Reviewed & Approved

By: CK

Date: 10/10/06

Chloride 650ppm Stock: 1.070g NaCl crystals dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ room temp. for 1 year.

| ID Letter | NaCl Source | Analyst | Date Prepared | Date Expires | Final Cl Reference Stock ID |
|-----------|-------------|---------|---------------|--------------|-----------------------------|
| A | | | | | |
| B | | | | | |
| C | | | | | |
| D | | | | | |
| E | | | | | |

Nitrite 180ppm Stock: 1.09g KNO₂ previously dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ 4 for 1 year.

| ID Letter | KNO ₂ Source | Analyst | Date Prepared | Date Expires | Final NO ₂ Reference Stock ID |
|-----------|-------------------------|---------|---------------|--------------|--|
| F | | | | | |
| G | | | | | |
| H | | | | | |
| I | | | | | |
| J | | | | | |

Nitrate 180ppm Stock: 1.30g KNO₃ crystals dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Transfer to amber jar and add 1.0ml Chloroform. Store in amber jar @ room temp. for 6 months.

| ID Letter | ^{CK 10/5/04} KNO ₃ Source | Chloroform Source ID | Analyst | Date Prepared | Date Expires | Final NO ₃ Reference Stock ID |
|-----------|--|----------------------|---------|---------------|--------------|--|
| K | WC76115G | WC76170J | FN | 10/5/06 | 4/5/07 | WC72007 K |
| L | | | | | | |
| M | | | | | | |
| N | | | | | | |
| O | | | | | | |

OPO4 180ppm Stock: 0.7909g granular KH₂PO₄ dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ 4 for 1 year.

| ID Letter | KH ₂ PO ₄ Source | Analyst | Date Prepared | Date Expires | Final OPO ₄ /TPO ₄ Reference Stock ID |
|-----------|--|---------|---------------|--------------|---|
| P | | | | | |
| Q | | | | | |
| R | | | | | |
| S | | | | | |
| T | | | | | |

Sulfate 3200ppm Stock: 5.80g K₂SO₄ dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ 4 for 1 year.

| ID Letter | K ₂ SO ₄ Source | Analyst | Date Prepared | Date Expires | Final SO ₄ Reference Stock ID |
|-----------|---------------------------------------|---------|---------------|--------------|--|
| U | | | | | |
| V | | | | | |
| W | | | | | |
| X | | | | | |
| Y | | | | | |

By: CK

Date: 10/16/06

STANDARD STOCK PREP

(Fluoride and Bromide are purchased 1000ppm standards)

Chloride 1000ppm Stock: 1.648g NaCl crystals dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ room temp. for 1 year.

| ID Letter | NaCl Source | Analyst | Date Prepared | Date Expires | Final Cl 1000ppm Stock ID |
|-----------|-------------|---------|---------------|--------------|---------------------------|
| A | | | | | |
| B | | | | | |
| C | | | | | |
| D | | | | | |
| E | | | | | |

Nitrite 1000ppm Stock: 6.07g KNO2 previously dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ 4 for 1 year.

| ID Letter | KNO2 Source | Analyst | Date Prepared | Date Expires | Final NO2 1000ppm Stock ID |
|-----------|-------------|---------|---------------|--------------|----------------------------|
| F | | | | | |
| G | | | | | |
| H | | | | | |
| I | | | | | |
| J | | | | | |

Nitrate 1000ppm Stock: 7.22g KNO3 crystals dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Transfer to amber jar and add 1.0ml Chloroform. Store in amber jar @ room temp. for 6 months.

| ID Letter | ^{CK 10/16/04} KNO3 Source | Chloroform Source ID | Analyst | Date Prepared | Date Expires | Final NO3 1000ppm Stock ID |
|-----------|---------------------------------------|----------------------|---------|---------------|--------------|----------------------------|
| K | WC76114C | WC76170J | FJ | 10/5/06 | 4/5/07 | WC72002K |
| L | | | | | | |
| M | | | | | | |
| N | | | | | | |
| O | | | | | | |

OPO4 / TPO4 1000ppm Stock: 4.394g KH2PO4 dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ 4 for 1 year.

| ID Letter | KH2PO4 Source | Analyst | Date Prepared | Date Expires | Final OPO4/TPO4 1000ppm Stock ID |
|-----------|---------------|---------|---------------|--------------|----------------------------------|
| P | | | | | |
| Q | | | | | |
| R | | | | | |
| S | | | | | |
| T | | | | | |

Sulfate 1000ppm Stock: 1.479g Na2SO4 dried overnight at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ 4 for 1 year.

| ID Letter | Na2SO4 Source | Analyst | Date Prepared | Date Expires | Final SO4 1000ppm Stock ID |
|-----------|---------------|---------|---------------|--------------|----------------------------|
| U | | | | | |
| V | | | | | |
| W | | | | | |
| X | | | | | |
| Y | | | | | |

By: CB / CK / CK
 Date: 5/9/05 / 7/19/06 / 10/16/06

STANDARD STOCK PREP

(Fluoride and Bromide are purchased 1000ppm standards)

Chloride 1000ppm Stock: 1.648g NaCl crystals dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ room temp. for 1 year.

| ID Letter | NaCl Source | Analyst | Date Prepared | Date Expires | Final Cl 1000ppm Stock ID |
|-----------|-------------|---------|---------------|--------------|---------------------------|
| * A | WC69074D | BB | 2/23/04 | 2/23/05 | WC72001A |
| B | WC69074D | BB | 2/23/05 | 2/23/06 | WC72001B |
| C | WC69074D | TC | 2/21/06 | 2/14/07 | WC72001C |
| D | | | | | |
| E | | | | | |

* Previously WC69084A

Nitrite 1000ppm Stock: 6.07g KNO2 previously dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ 4 for 1 year.

| ID Letter | KNO2 Source | Analyst | Date Prepared | Date Expires | Final NO2 1000ppm Stock ID |
|-----------|-------------|---------|---------------|--------------|----------------------------|
| 2* F | WC55288D | BB | 2/27/04 | 2/27/05 | WC72001F |
| G | WC69234I | BB | 2/23/05 | 2/23/06 | WC72001G |
| H | WC69234I | TC | 2/22/06 | 2/22/07 | WC72001H |
| I | | | | | |
| J | | | | | |

2* Previously WC69089A

Nitrate 1000ppm Stock: 7.22g KNO3 crystals dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Transfer to amber jar and add 1.0ml Chloroform. Store in amber jar @ room temp. for 6 months.

| ID Letter | KNO3 Source | Chloroform Source ID | Analyst | Date Prepared | Date Expires | Final NO3 1000ppm Stock ID |
|-----------|-------------|----------------------|---------|---------------|--------------|----------------------------|
| 3* K | WC65173E | WC69078E | BB | 8/10/04 | 2/10/05 | WC72001K |
| L | WC65017E | WC69108E | BB | 2/8/05 | 8/8/05 | WC72001L |
| M | WC65017E | WC69174F | JPM | 7/25/05 | 1/25/06 | WC72001M |
| N | WC65017E | WC69245F | FN | 1/23/06 | 7/23/06 | WC72001N |
| O | WC65176114C | WC69245F | FN | 4/2/06 | 10/12/06 | WC72001O |

3* Previously WC690163E

OPO4/TPO4 1000ppm Stock: 4.394g KH2PO4 dried for 2 hrs at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ 4 for 1 year.

| ID Letter | KH2PO4 Source | Analyst | Date Prepared | Date Expires | Final OPO4/TPO4 1000ppm Stock ID |
|-----------|---------------|---------|---------------|--------------|----------------------------------|
| 4* P | WC65017D | BB | 2/24/04 | 2/24/05 | WC72001P |
| Q | WC65017D | BB | 2/23/05 | 2/23/06 | WC72001Q |
| R | WC69196E | TC | 2/21/06 | 2/21/07 | WC72001R |
| S | | | | | |
| T | | | | | |

4* Previously WC69085D

Sulfate 1000ppm Stock: 1.479g Na2SO4 dried overnight at 104 . Dissolve in approx. 800mls DI in 1 Liter volumetric flask. Bring to volume with DI water. Store in amber jar @ 4 for 1 year.

| ID Letter | Na2SO4 Source | Analyst | Date Prepared | Date Expires | Final SO4 1000ppm Stock ID |
|-----------|---------------|---------|---------------|--------------|----------------------------|
| 5* U | WC65168D | BB | 2/24/04 | 2/24/05 | WC72001U |
| V | WC65168D | BB | 2/23/05 | 2/23/06 | WC72001V |
| W | WC6018A | TC | 2/22/06 | 2/22/07 | WC72001W |
| X | | | | | |
| Y | | | | | |

Previously WC69085A

**DATA VALIDATION SUMMARY REPORT
HONEYWELL SOUTH POINT SUPERFUND SITE
SOUTH POINT, OHIO**

1.0 INTRODUCTION:

Data validation was completed on groundwater samples collected during the in April 2006. Groundwater samples were analyzed by Severn Trent Laboratories in Pittsburgh, Pennsylvania (SLT-Pittsburgh). The following U.S. Environmental Protection Agency (USEPA) analytical methods were performed:

- metals by USEPA Method ICLP ILM04.0/4.1
- Nitrate-Nitrite by USEPA Method MCAWW 353.2
- Nitrogen, Ammonia by USEPA Method MCAWW 350.1

Data validation was completed by the MACTEC project chemist using Honeywell Level II procedures described for Honeywell projects. During the Level II review the following data quality indicators were reviewed:

- Sample Collection and Holding Times
- QC Blank
- Laboratory Control Samples (LCS)
- Laboratory and Field Duplicates
- Matrix Spike/Matrix Spike Duplicates (MS/MSD)
- Reporting Limits and Data Completeness

Data were reviewed using precision and accuracy control limits established by the laboratory. Data quality reviews were completed using general procedures described in USEPA National Functional guidance documents (USEPA, 2004).

A summary of final sample results is presented in Table 1.

Data qualifications were completed if necessary in accordance with the guidelines and professional judgment using the following qualifiers:

U = The target compound was not detected at concentrations greater than the associated quantitation limit

J = The reported concentration is considered an estimated value

The following samples collected during April 2006 are included in the data evaluation:

| Sample ID | Sample Date | Metals | Nitrate-Nitrite | Ammonia | Comment |
|------------------|--------------------|---------------|------------------------|----------------|-----------------|
| SPMW-01 | 4/11/06 | X | X | X | |
| SPMW-10R | 4/11/06 | X | X | X | |
| SPMW-05 | 4/11/06 | X | X | X | |
| SPMW-03 | 4/11/06 | X | X | X | |
| SPMW-07 | 4/11/06 | X | X | X | |
| SPMW-07 (dup) | 4/11/06 | X | X | X | Field Duplicate |
| Sample ID | Sample Date | Metals | Nitrate-Nitrite | Ammonia | Comment |

| | | | | | |
|---------------|---------|---|---|---|------------------------|
| SPMW-02 | 4/11/06 | X | X | X | |
| SPIS-23 | 4/11/06 | X | X | X | |
| SPIS-23 MS | 4/11/06 | X | X | X | Matrix Spike |
| SPIS-23 MSD | 4/11/06 | X | X | X | Matrix Spike Duplicate |
| SPMW-06R | 4/12/06 | X | X | X | |
| SPMW-08 | 4/12/06 | X | X | X | |
| SPMW-09 | 4/12/06 | X | X | X | |
| SPOB-34 | 4/12/06 | X | X | X | |
| SPOB-12R2 | 4/12/06 | X | X | X | |
| SPMW-11R | 4/12/06 | X | X | X | |
| SPMW-12 | 4/12/06 | X | X | X | |
| SPMW-13 | 4/12/06 | X | X | X | |
| SPMW-04 | 4/12/06 | X | X | X | |
| SPIS-24 | 4/12/06 | X | X | X | |
| SPIS-24 (DUP) | 4/12/06 | X | X | X | Field Duplicate |

2.0 DATA VALIDATION ACTIONS AND OBSERVATIONS

Detections between the reporting limit (RL) and the method detection limit (MDL) were flagged with a "B" by the laboratory. Laboratory "B" flags were removed and detections between the RL and MLD were qualified as estimated (J). With the exception of the items discussed below, QC parameters and measurements checked during validation met requirements in the analytical method, validation guidelines, and quality assurance (QA) plan goals. Unless specified below, results are usable without qualification.

2.1 Metals

QC Blank

Blank contamination was observed in the method blank associated with a subset of samples for cadmium. An action level was established at five times the blank concentration. Cadmium detections in samples SPMW-01, SPMW-10R, SPMW-03, SPMW-07, SPMW-07 (DUP) and SPMW-02 were below the action level and were qualified as non-detect (U).

2.2 Ammonia

MS/MSD


The MS associated with sample SPMW-01 had a percent recovery above the laboratory QC limits (90%-110%) for ammonia (134). The relative percent difference (RPD) between the MS and MSD also exceeded the laboratory QC limit (20) for ammonia (84). Ammonia results in associated samples SPMW-01, SPMW-10R, SPMW-05, SPMR-03, SPMR-07, SPMR-07 (DUP) and SPMW-02 were qualified as estimated (J/UJ).

References:

U.S. Environmental Protection Agency (USEPA), 1996. "Test Methods for Evaluating Solid Waste"; Laboratory Manual Physical/Chemical Methods; Office of Solid Waste and Emergency Response; Washington, DC; SW-846; November 1986; Revision 4 -December 1996.

U.S. Environmental Protection Agency (USEPA), 2004. "USEPA Contract Laboratory Program National Functional Guidelines for Inorganic Data Review"; Office of Superfund Remediation and Technology Innovation; EPA-540-R-04-004; October 2004.

Data validator: Bradley B. LaForest, NRCC-EAC

A handwritten signature in black ink, appearing to read "Bradley B. LaForest", with a long horizontal flourish extending to the right.

Signature:

Date: 5/30/06

**DATA VALIDATION SUMMARY REPORT
HONEYWELL SOUTH POINT SUPERFUND SITE
OCTOBER 2006
SOUTH POINT, OHIO**

1.0 INTRODUCTION:

Data validation was completed on groundwater samples collected during October 2006. Groundwater samples were analyzed by Severn Trent Laboratories in Pittsburgh, Pennsylvania (SLT-Pittsburgh). The following U.S. Environmental Protection Agency (USEPA) analytical methods were performed:

- Metals by USEPA Method 6020B
- Nitrate-Nitrite by USEPA Method 353.2
- Nitrogen, Ammonia by USEPA Method 350.1

Data validation was completed by the MACTEC project chemist using Honeywell Level II procedures described for Honeywell projects. During the Level II review the following data quality indicators were reviewed:

- Sample Collection and Holding Times
- QC Blanks
- Laboratory Control Samples (LCS)
- Laboratory and Field Duplicates
- Matrix Spike/Matrix Spike Duplicates (MS/MSD)
- Reporting Limits and Data Completeness

Data were reviewed using precision and accuracy control limits established by the laboratory. Data quality reviews were completed using general procedures described in USEPA National Functional guidance documents (USEPA, 2004).

A summary of final sample results is presented in Table 1.

Data qualifications were completed if necessary in accordance with the guidelines and professional judgment using the following qualifiers:

U = The target compound was not detected at concentrations greater than the associated quantitation limit

J = The reported concentration is considered an estimated value

The following samples collected during October 2006 are included in the data evaluation:

| Sample ID | Sample Date | Metals | Nitrate-Nitrite | Ammonia | Comment |
|-----------|-------------|--------|-----------------|---------|---------|
| SPMW-01 | 10/24/06 | X | X | X | |
| SPMW-05 | 10/24/06 | X | X | X | |
| SPMW-10R | 10/24/06 | X | X | X | |
| SPMW-02 | 10/24/06 | X | X | X | |
| SPMW-06R | 10/24/06 | X | X | X | |
| SPMW-08 | 10/24/06 | X | X | X | |
| SPMW-09 | 10/24/06 | X | X | X | |
| SPMW-03 | 10/25/06 | X | X | X | |
| SPMW-07 | 10/25/06 | X | X | X | |

| Sample ID | Sample Date | Metals | Nitrate-Nitrite | Ammonia | Comment |
|-------------|-------------|--------|-----------------|---------|------------------------|
| SPMW-07 DUP | 10/25/06 | X | X | X | Field Duplicate |
| SPOB-34 | 10/25/06 | X | X | X | |
| SPOB-12R2 | 10/25/06 | X | X | X | |
| SPMW-11R2 | 10/25/06 | X | X | X | |
| SPMW-12 | 10/25/06 | X | X | X | |
| SPMW-13 | 10/25/06 | X | X | X | |
| SPMW-04 | 10/25/06 | X | X | X | |
| SPIS-24 | 10/25/06 | X | X | X | |
| SPIS-24 DUP | 10/25/06 | X | X | X | Field Duplicate |
| SPIS-23 | 10/25/06 | X | X | X | |
| SPIS-23 MS | 10/25/06 | X | X | X | Matrix Spike |
| SPIS-23 MSD | 10/25/06 | X | X | X | Matrix Spike Duplicate |

2.0 DATA VALIDATION ACTIONS AND OBSERVATIONS

With the exception of the items discussed below, QC parameters and measurements checked during validation met requirements in the analytical method, validation guidelines, and quality assurance (QA) plan goals. Unless specified below, results are usable without qualification.

2.1 Metals

No data quality issues were identified and results are interpreted to be usable as reported by the lab.

2.2 Ammonia and Nitrate


No data quality issues were identified and results are interpreted to be usable as reported by the lab.

References:

U.S. Environmental Protection Agency (USEPA), 1996. "Test Methods for Evaluating Solid Waste"; Laboratory Manual Physical/Chemical Methods; Office of Solid Waste and Emergency Response; Washington, DC; SW-846; November 1986; Revision 4 -December 1996.

U.S. Environmental Protection Agency (USEPA), 2004. "USEPA Contract Laboratory Program National Functional Guidelines for Inorganic Data Review"; Office of Superfund Remediation and Technology Innovation; EPA-540-R-04-004; October 2004.

Data validator: Bradley B. LaForest, NRCC-EAC

Signature: 

Date: 12/19/06