# MEMORANDUM



2100 Corporate Drive Addison, IL

Tel: (630) 691-5020 Fax: (630) 691-5133

FAX TO: Sheri Bianchin

(312) 886-4071

708 591 5133

**Date:** October 30, 1996

Holly Grejda

(317) 308-3063

Steve Mrkvika

(312) 346-4781

cc:

Ron Frehner

(612) 639-0923

From:

Peter Vagt

Subject:

Sampling Plan Total PCB Field Screening

PGCS Extraction Trench Alignment

ACS NPL Site RD/RA

The sampling for total PCB concentrations in surficial soils/sediments along the PGCS Alignment is scheduled to begin at 8 AM CT at the ACS Site on Thursday, October 31, 1996.

A map of the revised alignment and a description of the sampling procedure is attached for your review.

PIV
C:\MSOFFICE\WINWORD\JOBS\FAXM-EPA.DOC
4077.0074

US EPA RECORDS CENTER REGION 5

## MONTGOMERY WATSON FIELD SAMPLING SPECIFIC OPERATING PROCEDURE (SOP)

Sampling and Field Screening for Total PCBs along PGCS Extraction Trench Alignment

#### Scope and Application:

The objective is to collect soil/sediment samples along the alignment of the Peximeter Groundwater Containment System (PGCS) extraction trench and analyze them for the presence of PCBs. Analysis will be at field screening level for total PCBs using the Omicron RaPID Assay Method. The SOP previously approved by U.S. EPA for the Barrier Wall Alignment Investigation, will be used for the analyses.

Soil/sediments are defined here as the material underlying a continuous or intermittent water body. As such, sediments can range from compacted clay to loose fine-grained materials. Typically rubble or rock bottoms are not sampled as part of a sediment investigation. Sediments may include organic soils and wetlands that are only periodically inundated or saturated. Soils will not be collected from upland areas, away from wedand soils and vegetation.

### Reagents and Apparatus:

- 1. Sampling devices: coring tube and hand auger
- Stainless steel bowls, spatulas, and spoons
- Sample containers
- Stakes and flagging to mark sampled locations
- 100 or 200 foot measuring tape
- Labels, record books/forms

#### Procedures:

- 1. Apply at least a temporary label to the sampling containers prior to sample collection. Label information must include the sampling location, and should include date, time, sampling personnel, and project number.
- 2. Locations for sampling will be selected at 100 foot or closer intervals along the alignment of the PGCS extraction trench. (The alignment was marked in the field on October 16, 1996 by U.S. EPA and Montgomery Watson, and is shown on the

# MONTGOMERY WATSON FIELD SAMPLING SPECIFIC OPERATING PROCEDURE (SOP)

Sampling and Field Screening for Total PCBs along PGCS Extraction Trench Alignment

attached map). Locations will be selected in the field on the sampling day, with concurrence of the U.S. EPA or its oversight subcontractor.

- 3. Sample material will be collected to represent the upper 24 inches of the soil profile at each sampling location. At the specific sampling location, push, or twist the sampling device into the sediment to the required depth. (It may require two or more excursions of the sampling device to reach the full 24 inch depth.) Remove the sampler from the ground and transfer the sampler to a stainless steel bowl. A stainless steel spoon may be used to help transfer the sample to the bowl.
- 4. Composite sediments from the 24 inch column in the stainless steel bowl and mix them thoroughly with the stainless steel spoon prior to filling sample containers (samples will not be analyzed for VOCs). Fill two sample containers with sediment. One will be marked for field screening analysis, and the other will be marked for laboratory sampling. (Laboratory sampling may be conducted on the second sample if the field screening indicates total PCB concentrations above 10 ppm.) Sample volume will be made available to the U.S. EPA oversight contractor if requested.
- 5. Clean the sampling device, spoons or spatulas, and compositing bowl prior to use at the first sampling location and between sampling locations. Cleaning is by means of a tap water and detergent wash and tap water and deionized water rinses. A bristle brush may be used for the wash. Cleaning water will be discharged to the ground at the sampling location.
- 6. Sample descriptive information should be entered into a bound field notebook and/or field data sheet.

C:\MSOFFICE\WINWORD\JOBS\ACS\SPBC-SOP.DOC

LEGEND

UPPER AQUIFER WELL LOCATION AND NUMBER

TOTAL VOC CONCENTRATIONS GREATER
THAN DELECTION LIMITS DELINEATED BY
CEOPROBE INVESTIGATION


PRODUCT APPROXIMATE LOCATION OF BARRIER WALL

PERIMETER GROUNDWATER CONTAINMENT SYSTEM (PGCS)

REVISED PGCS EXTRACTION TRENCH ALIGNMENT

NOTES

1. REVISED ALICHMENT IS BASED ON SITE DOSERVATIONS BY U.S. E.P.A., BLACK & VEATCH, AND MONTGOMERY WATSON.



90° 1996, 10-30 то 4077.0074 **B6** MOSTGOMERY WATSON