# PATHWAY IDENTIFICATION DURING SUCCESSFUL ISCR-ENHANCED BIOREMEDIATION OF A TCE DNAPL SOURCE AREA

James G.D. Peale, RG Erik I. Bakkom, PE (Maul Foster Alongi)

> Josephine Molin Andrzej Przepiora Jim Mueller Fayaz Lakhwala (Adventus Americas Inc.)



## TOPICS

- Site Overview
- Bench Test
- Field Pilot
- Full-Scale Data
- Summary



## Site Overview

- Former MGP waste site redeveloped for manufacturing in 1970s
- 80+ acres adjacent to Portland Harbor NPL site
- TCE or TCE+wastewater released from a recycling system (1980-1985)
- Impacts from release discovered in 2002



## Site Overview

- Source Zone
  - Impacts from about 15-34 m bgs
  - TCE up to 592,000 ug/L (DNAPL levels)
    - No TCE DNAPL observed
  - Cis-1,2-DCE up to 90,800 ug/L
  - Very little VC (< 100 ug/L)</p>
- Riverbank
  - Impacts from about 24-43 m bgs
  - TCE up to 8,640 ug/L
  - Cis-1,2-DCE up to 34,000 ug/L
  - VC up to 5,170 ug/L



## Site Overview



MAUL Foster Algneg

## Bench and Pilot Test Summary

- Comparative Bench Test
  - Multiple columns and runs, TCE spikes up to 870 mg/L
  - EHC+KB-1 outperformed other amendments
    - EHC ZVI+hydrophilic organic carbon
    - KB-1 *Dhc* consortium
- Source Area Pilot EHC+KB-1 PRB
  - TCE from DNAPL levels (93 mg/L) to ND in 6 months
- Riverbank Pilot EHC+KB-1 PRB
  - All CVOCs to ND in ~12 months




# Technology Summary

#### EHC

- Powdered blend of zero-valent iron (ZVI) and hydrophilic organic carbon
- Creates strongly reducing conditions in groundwater
  (ORP ~ -500 mV) in situ chemical reduction (ISCR)
- ISCR results in abiotic dechlorination and supports anaerobic bacteria
- □ KB-1
  - Anaerobic consortium of dechlorinating bacteria
  - Includes dehalococcoides sp.
  - Requires ORP < -75 mV</p>



## Field Pilot Data – CVOC rates






## Full Scale

- EHC+KB-1 Full-Scale Implementation
  - 46 m x 21 m x 3 m PRB Source area only
    - Injected from ~12 34 m bgs
    - Supplemental upgradient areas
  - 200+ injection points
    - ~269,400 kg EHC
    - 1,831 L KB-1
  - Direct-push drilling
- 23 Performance Monitoring Wells
  - Group 1 Upgradient or within injection zone
  - Group 2 Downgradient of injection zone



# tull Scale



# TCE Results (ug/L)

		Pre-Injection	December	February	April	June	August
Well ID	Group ID	(Q4-08/Q1-09)	2009	2010	2010	2010	2010
W13-69	1	174,000	6 <b>,</b> 050	4,400	9,510	10,100	1 <i>,</i> 570
W30-96	1	80,900	90.7	83.2	22.2	21.3	18.9
W31-106	1	23,800	1.57	<0.3	<0.3	0.35	<0.3
W32-106	1	17,400	30.5	9.45	5.92	6.51	3.23
W32-76	1	44,500	51.6	52.1	66.9	43.2	7.3
W35-106	1	157,000	14.9	8.84	3.99	6.61	5.43
W33-81	2	21,400	92.2	160	64.8	24.4	20
W36-81	2	13,800	22.7	18.1	10.2	7.78	1.87
W39-101	2	120,000	7,800	7,780	4.88	6.31	4.37
		72.500	4 530	4 200	4 033	4 4 2 5	4.04
Mean		72,533	1,573	1,390	1,077	1,135	181

Subset of wells with pre-injection TCE > 11,000 ug/L



## Results

- Remedial action objective is 11,000 ug/L
  - Threshold indicator for TCE DNAPL
  - 1 % of aqueous solubility limit
  - Achieved in less than 12 months
- TCE generally less than 100 ug/L
- Estimated 99.9% mass removal




# Pathway Identification

- Mix of abiotic and biological pathways
- Evidence of abiotic degradation
  - Simultaneous decline of TCE/DCE/VC in some wells
  - Abiotic degradation products
    - Hydrogenation of chlorethenes to chloroethanes
    - Low concentrations but consistent
- Clear evidence of sequential dechlorination
  - Production of DCE isomers and VC



# Pathway Identification - Abiotic






## TCE DNAPL Remediation

- No TCE DNAPL observed
  - Elevated groundwater concentrations
  - 592,000 ug/L (direct-push)
  - 259,000 ug/L (monitoring well)
- Indirect evidence of TCE DNAPL
  - Mass balance using chloride?
- Evaluate entire source area data set
  - EVS estimates of 3-D source area volume



## TCE DNAPL Remediation





## TCE DNAPL Remediation

Observed Net Increase in Cl (M)	22,498
Net Theoretical CI from Degradation of CVOCs (M)	9,073
Difference (M)	13,425
TCE Equivalents ( <i>M</i> )	4,475

- Mass balance example
  - Convert molar TCE/DCE/VC to molar chloride
  - Compare theoretical total CI (M) to observed
  - Difference implies degradation of TCE DNAPL
    - Includes degradation of desorbed TCE
  - Action implies accelerated desorption from non-aqueous phases(s) to aqueous phase



# Summary

- Combined EHC+KB-1 is a demonstrated technology for TCE DNAPL
  - Abiotic and biological pathways identified
  - Both pathways demonstrated success
- Mass balance approach useful for identifying DNAPL degradation
  - CI data suggest TCE (or TCE equivalents) in nonaqueous phase or phases
- Removal mechanism
  - Accelerated desorption from NA phase
  - Destruction in aqueous phase



# Acknowledgements

- Adventus Americas Inc.
- SiRem Laboratories

Questions?