

9/8/95  
Revised

PCDR \ PCDR3 \ FORT DRUM  
\ 052008 \ 00787

**OCCUPATIONAL HAZARD ANALYSIS  
BUILDING T4002  
FORT DRUM, NEW YORK**



**CDM FEDERAL PROGRAMS CORPORATION**  
a subsidiary of Camp Dresser & McKee Inc.

#787

MISCELLANEOUS MILITARY AND CIVIL  
HAZARDOUS WASTE CLEANUP PROJECTS  
FOR  
U. S. ARMY CORPS OF ENGINEERS  
KANSAS CITY DISTRICT

OCCUPATIONAL HAZARD ANALYSIS  
BUILDING T4002  
FORT DRUM, NEW YORK

CONTRACT NO. DACW41-89-D-0086  
D.O. NO. 024

Prepared By:

CDM FEDERAL PROGRAMS CORPORATION  
8215 Melrose Drive, Suite 100  
Lenexa, KS 66214

June 1995

---

9/8/95



CDM FEDERAL PROGRAMS CORPORATION  
a subsidiary of Camp Dresser & McKee Inc.

September 8, 1995

Mr. Brian Roberts (CEMRK-EP-EC)  
U. S. Army Corps of Engineers  
Kansas City District  
700 Federal Building  
601 East 12th Street  
Kansas City, Missouri 64106-2896

Project: Contract No. DACW41-89-D-0086  
Delivery Order No. 024 - Building T4002  
Subject: Revised Occupational Hazard Analysis Report

Dear Mr. Roberts:

CDM Federal Programs Corporation (CDM Federal) is pleased to submit two copies of the revised Occupational Hazard Analysis Report for Building T4002, Fort Drum, New York. This report has been revised to correct several editorial errors in the previous version.

If you have any questions, please contact me at (913) 492-8181.

Sincerely,

CDM FEDERAL PROGRAMS CORPORATION

*Jacqueline M. Mosher*

Jacqueline M. Mosher, P.E.  
Project Manager

Enclosure

cc: J. Haynes, Fort Drum - 10 copies  
R. Myerson, WOHA - 1 copy  
C. Myers  
7801-034-RT  
RF

JMM3.98

MISCELLANEOUS MILITARY AND CIVIL  
HAZARDOUS WASTE CLEANUP PROJECTS  
FOR  
U. S. ARMY CORPS OF ENGINEERS  
KANSAS CITY DISTRICT


OCCUPATIONAL HAZARD ANALYSIS  
BUILDING T4002  
FORT DRUM, NEW YORK

CONTRACT NO. DACW41-89-D-0086  
D.O. NO. 024


Prepared By:

CDM FEDERAL PROGRAMS CORPORATION  
8215 Melrose Drive, Suite 100  
Lenexa, KS 66214


June 1995

Prepared by:   
Ross S. Myerson, M.D., M.D.H.  
Washington Occupational Health Associates, Inc.

Date: 6/12/95

Reviewed by:   
Charles Myers, CIH  
CDM Federal

Date: 6/27/95

Approved by:   
Jackie M. Mosher, P.E.  
CDM Federal Project Manager

Date: 6/30/95

## **POTENTIAL TOXICOLOGICAL IMPACT OF EXPOSURES ON WORKERS AT BUILDING T4002, FORT DRUM, NY**

by Ross S. Myerson, M.D., M.P.H.

### **Executive Summary**

Building T4002 is a wooden-framed structure with steel siding, built in the 1940s. The western room of the building was used as a storage and mixing area for the Pest Controller on Fort Drum. The building is scheduled for demolition in early 1996. In 1989 and 1994, building material samples were collected and found to be contaminated with pesticides and herbicides. Contamination was throughout the building. Employees who occupied the east end of the building have expressed concern at potential exposures from the pesticide and herbicide contamination. To address their concerns, Fort Drum requested that an evaluation of the potential health hazards associated with working in the building be conducted.

CDM Federal Programs Corporation (CDM Federal) was tasked by the U.S. Army Corps of Engineers, Kansas City District, to identify and interview potential employees who may have occupied the building since it was used as a pesticide storage and mixing area; collect air samples to evaluate existing contamination; evaluate existing building conditions; obtain the services of a board-certified occupational physician to determine any health hazard potential; and prepare and present a report outlining results of the investigation.

Washington Occupational Health Associates, Inc., (WOHA) was tasked by CDM Federal to conduct a study of individuals who were concerned that they had been exposed to organochlorine pesticides (DDD, DDE, DDT) and chlorophenoxy herbicides (2,4-D, 2,4,5-T) while working at Building T4002. The concern was that this potential exposure may have adversely affected their health. Our occupational and environmental health professionals reviewed exposure data and medical records and interviewed 17 of the concerned individuals. Based on these data, it is our opinion that there were no long-term health consequences from the potential exposures.

### **Potential Acute and Chronic Effects of Chlorophenoxy Herbicides (2,4-D, 2,4,5-T) and Organochlorine Pesticides**

The potential effects of each contaminant group were reviewed to determine the potential toxicological impact to workers at Building T4002. These effects are discussed below.

**Chlorophenoxy Herbicides (2,4-D, 2,4,5-T)** - The acute, or short term, effects of exposures to these types of materials include skin, mucus membrane and respiratory tract irritation. Most incidences of acute poisoning with this class of compounds occurs with intentional ingestion of 2,4-D. Symptoms include vomiting, chest and abdominal pain, diarrhea, headache, mental confusion and behavioral abnormalities. Unconsciousness with metabolic disturbances can occur. Mild transient kidney and liver dysfunction are also sometimes found.

Scandinavian studies have demonstrated increased risks for Hodgkins disease and non-Hodgkins lymphomas associated with exposure to 2,4-D and 2,4,5-T. Studies in the United States have found an increase in non-Hodgkins lymphoma among farmers associated with herbicide (primarily 2,4-D) exposure.

Several studies in animals, models and human population have investigated the reproductive toxicity of phenoxy herbicides. The animal studies demonstrate adverse effects however, human studies have not shown definite evidence of the same. Studies of males occupationally exposed to phenoxy herbicides during manufacturing and spraying have observed no increased birth defects or other reproductive effects.

**Organochlorine Pesticides (DDD, DDE, DDT)** - Acute organochlorine pesticide effects have included sensory disturbances resulting in lack of coordination, headaches, dizziness, numbness, nausea, vomiting, tremors, convulsions, and mental confusion. Sufficiently high doses can result in seizures leading to coma and respiratory depression.

Acute effects of pesticides have been well studied and understood, however, long term effects have not been as consistent in findings, and are often unclear. Some pesticides have been shown to cause cancer, and adverse reproductive effects in laboratory animals. There is, however, a lack of consistent evidence from epidemiological and clinical studies that these chronic effects have been observed in humans. These human studies have focused on individuals involved with manufacturing and application of pesticides. Some studies have shown small increases in lung cancer mortality for various classes of pesticides.

Organochlorines, including DDT, have been implicated in a variety of adverse reproductive outcomes, however, epidemiologic evidence is tentative.

### **Interview Process**

As part of the overall Occupational Hazard Analysis for Building T4002, it was necessary to identify former building occupants for potential interviews. To facilitate this identification, a meeting was held with Tim Tanner, presently supervisor of the estimators, who has 10 years of experience working in the building. This meeting was held at Fort Drum on November 3, 1994. Meeting participants included Dave Linneman, USACE - Kansas City District, Chuck Myers, CDM Federal Programs Corporation, and Tim Tanner. Between this meeting and discussions with Captain George Fisher, Chief of Occupational Health at Fort Drum, seventeen individuals were identified as former building occupants.

With the list finalized, a pre-interview questionnaire was prepared. The questionnaire, a medical release form, a disclosure form, a layout of the building, and a cover letter outlining the objectives of the project were sent to the identified individuals, return receipt requested. All 17 of the individuals responded. The medical release forms were sent to Captain Fisher. These forms requested that any existing medical records be forwarded to Washington Occupational Health Associates (WOHA) for review by an occupational physician. Following this review, an interview questionnaire was prepared and interviews were scheduled for April 13 and 14 at the conference room in Building 4836. Shelly Wolfe, a certified nurse practitioner employed by WOHA, conducted the interviews. The interviews were 45 minutes in duration and focused on the completion of information contained in the interview questionnaire. A copy of the questionnaire appears in Appendix A.

These interviews were used to help clarify and supplement the existing database. The nurse practitioner also responded to individual health questions posed by the interviewees. Data from these interviews was summarized in an internal report. This report listed each person's age, title, dates at Building T4002, medical history, personal health risk factors, the individual's recall of any temporal relationship of symptoms to work, and WOHA's impression concerning the work-relatedness of that person's medical problems.

Air sampling was performed by CDM Federal April 11 through April 13, 1995, inside Building T4002. Results of this sampling are reported in the Sampling and Analysis Report that appears in Appendix B.

All information collected during this project was given to the occupational physician. This included the results of wipe, soil, air, and building composition sampling; previous medical information provided by Fort Drum; locations of areas worked by the building occupants; pre-interview and interview questionnaire information; and an inventory of materials stored in the building, as provided by Tim Tanner. This information was thoroughly reviewed by the physician.

### **Exhibits**

All available and gathered information was formatted into a table. The format allowed for a detailed review of similarities and trends of each of the identified building occupants. The table and interview reports contain both personal and work-related medical data. Both must be considered, together, as part of this study. For reasons of confidentiality, the table and interview reports are excluded from this report. They will be maintained with the WOHA project file.

### **Results, Conclusions, and Recommendations**

In our opinion, the workers at Fort Drum, NY, experienced no long-term health problems related to their potential exposures to herbicides and pesticides at Building T4002. Several workers reported that their eyes and throat were irritated during their assignment in the building, this finding may be exposure-related. The other reported symptoms and medical illnesses do not predominate in any one organ system, nor do they otherwise suggest a common cause.

Although the wipe, soil, and air samples were collected after activities at Building T4002 had ceased, these pesticides and herbicides are relatively persistent in the environment; i.e., they tend not to readily chemically decompose. Therefore, the results of this sampling suggest a small exposure potential during the preceding years of occupancy.

The individuals who worked at Building T4002 should be reassured that their health was not jeopardized by the exposures. Their medical concerns should be evaluated and treated by their personal physicians.



**APPENDIX A**

## Fort Drum Questionnaire

## REVIEW OF SYSTEMS

*Have you experienced any of the following symptoms recently, or on a continuing basis? Describe any "yes" responses, by number, at the end of this section.*

	#	SYMPTOM	Y	N	DATE		#	SYMPTOM	Y	N	DATE
MISCELLANEOUS	1	Fever				HEART/LUNGS, CONTINUED	35	Chest Pain/Angina			
	2	Chills					36	Wheezing			
	3	Weight Loss					37	Emphysema			
	4	Loss of Energy/Fatigue					38	Heart Surgery			
	5	Cancer or Tumors					39	High Blood Pressure			
	6	Heat-Related Illness					40	Heart Murmur			
EYES	7	Eye Surgery					41	Enlarged Heart			
	8	Color Blindness					42	Stress Electrocardiogram			
	9	Double Vision				43	Rheumatic Fever				
	10	Eye Injury				44	Heart Palpitations				
	11	Cataract				45	Heart Attack				
	12	Glaucoma				46	Heart Medication				
	13	Wear glasses/contacts				CIRCULATION	47	Varicose Veins			
EARS	14	Ear Infection					48	Stroke			
	15	Ear Surgery					49	Leg Ulcers			
	16	Loss of Hearing					50	Swelling of Ankles			
	17	Ringling in Ears (Tinnitus)					51	Leg Pain on Walking			
	18	Hearing Aid Use				BLOOD	52	Anemia			
NOSE/THROAT	19	Sinus Trouble					53	Leukemia/Lymphoma			
	20	Hay Fever/Allergies					54	Other Blood Diseases			
	21	Frequent Colds				HEAD	55	Head Injury			
	22	Sore Throats					56	Neck Injury			
	23	Frequent Hoarsness				ENDOCRIN	57	Diabetes			
	24	Mouth/Dental Problems					58	Pituitary Problems			
	25	Frequent Nose Bleeds					59	Thyroid Problems			
HEART/LUNGS	26	Tuberculosis				NERVOUS SYSTEM	60	Frequent Headaches			
	27	Chest Surgery					61	Epilepsy/Seizures			
	28	Asthma					62	Fainting Spells			
	29	Lung Collapse					63	Loss of Consciousness			
	30	Bronchitis					64	Dizziness or Vertigo			
	31	Pneumonia					65	Frequent Exhaustion			
	32	Asbestosis/Silicosis					66	Trouble with Nerves			
	33	Shortness of Breath					67	Worry/Depression			
	34	Chronic Cough									

# Fort Drum Questionnaire

Please list each medication you currently take, the dosage, the frequency with which it is taken, and the reason for taking it:

MEDICATION	DOSAGE	FREQUENCY	REASON

## FAMILY HISTORY

*For Annual or Exit Exam - Indicate Change Since Last Exam*

Father:	<input type="checkbox"/> Living	List Diseases _____	If deceased, cause of death _____
Mother:	<input type="checkbox"/> Living	List Diseases _____	If deceased, cause of death _____
Brothers:	<input type="checkbox"/> Living	List Diseases _____	If deceased, cause of death _____
Sisters:	<input type="checkbox"/> Living	List Diseases _____	If deceased, cause of death _____

Has any member of your immediate family had any of the following:

	YES	NO		YES	NO		YES	NO
Cancer	<input type="checkbox"/>	<input type="checkbox"/>	Diabetes	<input type="checkbox"/>	<input type="checkbox"/>	Epilepsy	<input type="checkbox"/>	<input type="checkbox"/>
Hypertension	<input type="checkbox"/>	<input type="checkbox"/>	Tuberculosis	<input type="checkbox"/>	<input type="checkbox"/>	Rheumatism	<input type="checkbox"/>	<input type="checkbox"/>
Kidney Disease	<input type="checkbox"/>	<input type="checkbox"/>	Heart Disease	<input type="checkbox"/>	<input type="checkbox"/>	Anemia/Blood Disorder	<input type="checkbox"/>	<input type="checkbox"/>

## OCCUPATIONAL HISTORY

*Beginning with most recent, list all jobs held including military. Check boxes to right for indicated exposures.*

Type of Work	Employer	Dates From (mo/day/yr) To (mo/day/yr)	LEAD	BENZENE	ASBESTOS	INSECTICIDES/PESTICIDES	ORGANIC SOLVENTS	PCBs	IONIZING RADIATION	HEAVY METALS (MERCURY, CADMIUM, ETC.)	OTHER

Have you ever been off work because of an illness related to work or had an illness caused by your work? ☐ Yes ☐ No  
 If "yes", were you seen by a physician? Please describe, including the exposure(s) and note which job above it corresponds to.  
 Please also describe any hazardous exposure(s) not addressed above:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

## Appendix B

30

**SAMPLING AND ANALYSIS REPORT  
OCCUPATIONAL HAZARD ANALYSIS  
BUILDING T4002, FORT DRUM, NEW YORK  
DELIVERY ORDER NO. 0024**

## **1.0 INTRODUCTION**

### **1.1 Purpose of Report**

This report provides the results of the air sampling conducted by CDM Federal Programs Corporation (CDM Federal) at Building T4002, Fort Drum, New York.

## **2.0 SITE BACKGROUND**

### **2.1 Site Description**

Building T4002 is a five-room, rectangular structure, approximately 96 feet long and 14 feet wide. The building is separated into five rooms of differing lengths and equal width. The structure was built in a way that allowed transit from one room to the next through successive doorways. Every room in the building has a visible layer of dust (a heavy layer at times) covering floors, furniture, window sills, etc. It has a wooden frame with steel siding and was built in the 1940s. The length of the building runs roughly from east to west, with the far western end used for working with pesticides and herbicides.

### **2.2 Site History**

The western room of the building was used as a storage and mixing area for the Pest Controller on Fort Drum. In 1989 and 1994, samples of the surface soil surrounding the building and samples of building materials were collected and found to be contaminated with pesticides and herbicides. The results of this sampling were as follows.

Surface soil (0-2 feet) contaminant levels beneath the mixing and storage area and outside, immediately adjacent to this area:

- 4,4-DDT - 170,000  $\mu\text{g/kg}$
- 4,4-DDD - 40,000  $\mu\text{g/kg}$
- 4,4-DDE - 9,300  $\mu\text{g/kg}$
- 2,4-D - 140  $\mu\text{g/kg}$
- 2,4,5-TP - 49  $\mu\text{g/kg}$
- 2,4,5-T - 660  $\mu\text{g/kg}$

Composite building material samples from the east and west ends of the building and the roof. The following analytes were detected:

and filter combination were assigned a sampling location. All sample locations were checked periodically to ensure continuous operation throughout the sampling event. Additionally, a random check with the MiniBuck Calibrator was performed twice per day to ensure an acceptable pump volume was maintained. Finally, data collected and recorded daily for each sample location included: the sampling pump serial numbers and its assigned filter number; the calibrated pumps flow rate; the room number assigned to each pump/filter combination; the time of placement; the time the sampling event ended; and the flow rate of the sampling pump with its assigned filter still inline at the conclusion of each sampling event, using the MiniBuck Calibrator.

### **3.3 Sample Results**

The collected samples were analyzed by Kemron Environmental Services of Novi, Michigan. Kemron Environmental is an AIHA accredited laboratory (PAT ID #9524). The procedure followed to analyze the 2,4-D and 2,4,5-T samples (specified in NIOSH method 5001) uses high performance liquid chromatography (HPLC) with ultraviolet (UV) detection. The procedure followed to analyze the DDD, DDE, and DDT samples (specified in NIOSH method S274) uses gas chromatography (GC). The results of these sampling events are shown in Table 1. Hard copies of these results have been provided to the Occupational Physician for incorporation into the final report. Copies of the laboratory results and quality control information appear in Attachment 2. Air Monitoring Data Sheets are included in Attachment 3.

### **3.4 Quality Assurance**

Air samples were collected and analyzed according to the Air Sampling Plan for Building T4002 dated April 5, 1995. The only deviation from the Sampling Plan was that samples were collected over a period of 6 to 7 hours rather than the original 8 hours of sampling outlined in the Sampling Plan. This shortened period was still within the recommended collection period outlined by the NIOSH methods and had no effect on the sample results.

CDM Federal reviewed the data submitted by Kemron to determine if the data quality objectives were met. The samples were analyzed according to the NIOSH procedures and all quality control samples were within the guidelines contained in the methods.

### **3.5 Results Summary**

There were no detectable concentrations of 2,4,5-T, 2,4-D, DDD, DDE, or DDT encountered during the sampling period. Analytical detection limits were 10 micrograms for 2,4,5-T and 2 micrograms for 2,4-D. Analytical detection limits for DDD, DDE, and DDT, were 0.01 micrograms for each of the three compounds.

**TABLE 1**  
**RESULTS OF AIR MONITORING**  
**PESTICIDES AND HERBICIDES**  
**FORT DRUM**  
**BUILDING T4002**

Sample Location	Sample Number	Sample Date	Sample Type	Analytical Result ( $\mu\text{g}$ )*	Sample Volume ( $\text{m}^3$ )**	Sample Result ( $\mu\text{g}/\text{m}^3$ )
RM-1	2005	4/11/95	2,4,5-T 2,4-D	< 10 < 2	0.746 0.746	< 13 < 3
RM-2	2004	4/11/95	2,4,5-T 2,4-D	< 10 < 2	0.716 0.716	< 14 < 3
RM-3	2001	4/11/95	2,4,5-T 2,4-D	< 10 < 2	0.754 0.754	< 13 < 3
RM-4	2003	4/11/95	2,4,5-T 2,4-D	< 10 < 2	0.758 0.758	< 13 < 3
RM-5	2002	4/11/95	2,4,5-T 2,4-D	< 10 < 2	0.726 0.726	< 14 < 3
RM-1	D004	4/11/95	DDD DDE DDT	< 0.01 < 0.01 < 0.01	0.746 0.746 0.746	< 0.01 < 0.01 < 0.01
RM-2	D001	4/11/95	DDD DDE DDT	< 0.01 < 0.01 < 0.01	0.752 0.752 0.752	< 0.01 < 0.01 < 0.01
RM-3	D003	4/11/95	DDD DDE DDT	< 0.01 < 0.01 < 0.01	0.718 0.718 0.718	< 0.01 < 0.01 < 0.01
RM-4	D002	4/11/95	DDD DDE DDT	< 0.01 < 0.01 < 0.01	0.722 0.722 0.722	< 0.01 < 0.01 < 0.01
RM-5	D005	4/11/95	DDD DDE DDT	< 0.01 < 0.01 < 0.01	0.762 0.762 0.762	< 0.01 < 0.01 < 0.01
RM-1	2006	4/12/95	2,4,5-T 2,4-D	< 10 < 2	0.830 0.830	< 12 < 2
RM-2	2010	4/12/95	2,4,5-T 2,4-D	< 10 < 2	0.830 0.830	< 12 < 2

TABLE 1 (continued)

**RESULTS OF AIR MONITORING  
PESTICIDES AND HERBICIDES  
FORT DRUM  
BUILDING T4002**

<b>Sample Location</b>	<b>Sample Number</b>	<b>Sample Date</b>	<b>Sample Type</b>	<b>Analytical Result (µg)*</b>	<b>Sample Volume (m³)**</b>	<b>Sample Result (µg/m³)</b>
RM-4	2015	4/13/95	2,4,5-T 2,4-D	< 10 < 2	0.779 0.779	< 13 < 3
RM-5	2014	4/13/95	2,4,5-T 2,4-D	< 10 < 2	0.738 0.738	< 14 < 3
Trip Blank	D011	--	DDD DDE DDT	< 0.01 < 0.01 < 0.01	-- -- --	-- -- --
RM-1	D013	4/13/95	DDD DDE DDT	< 0.01 < 0.01 < 0.01	0.774 0.774 0.774	< 0.01 < 0.01 < 0.01
RM-2	D012	4/13/95	DDD DDE DDT	< 0.01 < 0.01 < 0.01	0.768 0.768 0.768	< 0.01 < 0.01 < 0.01
RM-3	D016	4/13/95	DDD DDE DDT	< 0.01 < 0.01 < 0.01	0.800 0.800 0.800	< 0.01 < 0.01 < 0.01
RM-4	D014	4/13/95	DDD DDE DDT	< 0.01 < 0.01 < 0.01	0.742 0.742 0.742	< 0.01 < 0.01 < 0.01
RM-5	D015	4/13/95	DDD DDE DDT	< 0.01 < 0.01 < 0.01	0.775 0.775 0.775	< 0.01 < 0.01 < 0.01

\* micrograms

\*\* cubic meters



**ATTACHMENT 1**


# NIOSH Manual of Analytical Methods

Compiled by NIOSH. All rights reserved (1994). Protected under International Copyright  
U.S. Department of Health and Human Services. Provided by CCOHS.

2,4-D and 2,4,5-T

METHOD: 5001

FORMULA:  $C_8H_6Cl_2O_3$  (2,4-D) ;  $C_8H_5Cl_3O_3$  (2,4,5-T)



M.W.: 201.04 (2,4-D); 255.49 (2,4,5-T)

ISSUED: 1/15/84

OSHA: 10 mg/m<sup>3</sup> (2,4-D or 2,4,5-T)  
 NIOSH: Group I, II and III Pesticides [1]  
 ACGIH: 10 mg/m<sup>3</sup>, STEL 20 mg/m<sup>3</sup>

PROPERTIES: solid; MP 153 °C (2,4,5-T); MP 138 °C (2,4-D); VP not significant

## SYNONYMS:

2,4-D: (2,4-dichlorophenoxy)acetic acid; CAS #94-75-7.  
 2,4,5-T: (2,4,5-trichlorophenoxy)acetic acid; CAS #93-76-5.

## SAMPLING

SAMPLER: FILTER glass fiber, binderless

FLOW RATE: 1 to 3 L/min

VOL-MIN: 15 L @ 10 mg/m<sup>3</sup>  
 -MAX: 200 L

SHIPMENT: routine

SAMPLE STABILITY: at least 1 week @ 25 °C

BLANKS: 2 to 10 field blanks per set

## ACCURACY

RANGE STUDIED: 5 to 20 mg/m<sup>3</sup> [2,3] (100-L samples)

BIAS: not significant [2,3]

OVERALL PRECISION  $s_r$ : 0.001 (2,4-D) [2]; 0.053 (2,4,5-T) [3]

---

MEASUREMENT

TECHNIQUE: HPLC, UV DETECTION

ANALYTE: 2,4-D or 2,4,5-T anion

DESCRIPTION: 15 mL CH<sub>3</sub>OH; stand 30 min

INJECTION VOLUME: 50  $\mu$ L

ELUENT: 0.001 M NaClO<sub>4</sub>-0.001 M Na<sub>2</sub>B<sub>4</sub>O<sub>7</sub> (2,4-D)  
0.003 M NaClO<sub>4</sub>-0.001 M Na<sub>2</sub>B<sub>4</sub>O<sub>7</sub> (2,4,5-T)

FLOW RATE: 1.7 mL/min

DETECTOR: UV @ 289 nm (2,4,5-T); 284 nm (2,4-D)

COLUMN: stainless steel, 50 cm x 2 mm ID, packed with Zipax SAX  
(DuPont); ambient temperature; 6900 kPa (1000 psi)

CALIBRATION: solutions of analyte in methanol

RANGE: 0.15 to 2 mg per filter

ESTIMATED LOD: 0.015 mg per filter (2,4-D) [2]; 0.030 mg per filter  
(2,4,5-T) [3]

PRECISION ( $s_r$ ): 0.01 (2,4-D) [2]; 0.025 (2,4,5-T) [3]

---

APPLICABILITY:

The working range is 1.5 to 20 mg/m<sup>3</sup> of either compound for a 100-L air sample. This method determines 2,4-D, 2,4,5-T, and their salts, but not their esters.

---

INTERFERENCES:

High concentrations of esters of either compound do not interfere but require the use of a precolumn to prevent degradation of the HPLC column.

---

OTHER METHODS:

This method combines and replaces Methods S279 [4] and S303 [4] which are the same except for eluent composition and UV detector wavelength.

---

**PROCEDURE**

---

**REAGENTS:**

1. 2,4-dichlorophenoxyacetic acid.\*
  2. 2,4,6-trichlorophenoxyacetic acid.\*
  3. Methanol, HPLC grade.
  4. LC eluent:
    - a. 2,4-D: 0.001 M NaClO<sub>4</sub> and 0.001 M Na<sub>2</sub>B<sub>4</sub>O<sub>7</sub>. Add 0.122 g NaClO<sub>4</sub> and 0.381 g Na<sub>2</sub>B<sub>4</sub>O<sub>7</sub> x 10H<sub>2</sub>O to a 1-L volumetric flask. Bring to volume with distilled water. Mix, filter and degas the solution.
    - b. 2,4,5-T: 0.003 M NaClO<sub>4</sub> and 0.001 M Na<sub>2</sub>B<sub>4</sub>O<sub>7</sub> x 10H<sub>2</sub>O. Add 0.366 g NaClO<sub>4</sub> and 0.381 g Na<sub>2</sub>B<sub>4</sub>O<sub>7</sub> x 10H<sub>2</sub>O to a 1-L volumetric flask. Bring to volume with distilled water. Mix, filter and degas the solution.
  5. Compressed, filtered air or nitrogen for drying syringes.
  6. Ethanol, absolute.
  7. Acetone.
  8. Calibration stock solution, 400 µg/mL. Dissolve 0.400 g 2,4-D or 2,4,5-T in methanol and dilute to 1 L with methanol.
  9. Recovery stock solution:
    - a. Dissolve 0.248 g 2,4-D in ethanol. Dilute to 10 mL with ethanol.
    - b. Dissolve 0.250 g 2,4,5-T, triethylamine salt, in acetone (or 0.250 g 2,4,5-T in methanol). Dilute to 10 mL with acetone.
- NOTE: Use the same form (e.g., acid or salt) of 2,4,5-T as in the air sample. Recovery may vary with the chemical form.
- See special precautions.

**EQUIPMENT:**

1. Sampler: filter, glass fiber, binderless, in a 37-mm polystyrene two-piece cassette filter holder (Gelman type AE or equivalent).
2. Personal sampling pump, 1 to 3 L/min, with flexible connecting tubing.
3. High pressure liquid chromatograph, UV detector at 284 nm (2,4-D) and 289 nm (2,4,5-T), integrator and column (page 2).
4. Filter, PTFE, 5-µm, 13-mm diameter in Swinny stainless (13-mm) filter holder.

5. Tweezers.
6. Syringes, 20-mL luer-lock.\*
7. Vials, glass, 20-mL.\*
8. Volumetric flasks, convenient sizes for preparing standard solutions.\*
- \* Wash all glassware with detergent, thoroughly rinse with tap water and distilled water.

---

**SPECIAL PRECAUTIONS:**

2,4-D and 2,4,5-T are suspected animal carcinogens [1]. 2,3,7,8-Tetra-chlorodibenzo-1,4-dioxin has been identified as an impurity in 2,4,5-T. Avoid any contact with these substances.

---

**SAMPLING:**

1. Calibrate each personal sampling pump with a representative filter in line.
2. Sample at an accurately known flow rate between 1 and 3 L/min for a total sample size of 15 to 200 L. Do not exceed a total dust loading of 2 mg on the filter.
3. Obtain information on the chemical form of the analyte (i.e., ester, salt or free acid) likely to be present in the air sample.

**SAMPLE PREPARATION:**

4. Remove the filter from the cassette with clean tweezers and place it in a 20-mL vial.
5. Add 15 mL methanol and mix by swirling. Allow to stand at least 30 min.
6. Filter the sample.
  - a. Pour the sample solution into a 20-mL syringe which is fitted with a 5- $\mu$ m PTFE filter.
  - b. Filter the sample into a clean vial.
  - c. Clean the PTFE filter by backflushing with methanol. Rinse the syringe and plunger with methanol. Dry with air or nitrogen.

**CALIBRATION AND QUALITY CONTROL:**

7. Calibrate daily with at least five working standards.
  - a. Dilute aliquots of calibration stock solution to 10 mL with methanol in volumetric flasks.

- c. Analyze working standards steps 9 and 10 .
- d. Prepare calibration graph (peak area vs. mg 2,4-D or mg 2,4,5-T) .
9. Check recovery with at least four spiked media blanks at each of four levels.
  - a. Add aliquot of recovery stock solution to media blank.
  - b. Analyze using standards prepared from the recovery stock solution.
  - c. Calculate R (mg recovered/mg added).

MEASUREMENT:

9. Establish chromatographic conditions listed on page 2 for either 2,4-D or 2,4,5-T.
10. Inject 50 µL of sample in duplicate. Rinse and dry the syringe between samples.

NOTE 1: The analyte is the chlorinated phenoxyacetate, whether the air sample contained salts or free acid forms of 2,4-D and 2,4,5-T.

NOTE 2: Esters of 2,4-D and 2,4,5-T will not elute from the HPLC column and may, if present in large amounts, degrade the HPLC column. Protect the main column with a precolumn of Zipax SAX if esters are known to be present. The sample preparation conditions are sufficiently mild so as to preclude hydrolysis of the esters.

CALCULATIONS:

1. Read the mass of analyte, mg (corrected for recovery), in the sample (W) and average media blank (B) from the calibration curve.
2. Calculate the concentration, C (mg/m<sup>3</sup>), of 2,4-D or 2,4,5-T in air volume, V (L), taken:

$$C = \frac{(W - B) \times 10^3}{V} \text{ mg/m}^3.$$

EVALUATION OF METHOD:

Methods S279 (2,4-D) and S303 (2,4,5-T) were issued on February 17, 1978, and March 17, 1978, respectively [4], and validated using 100-L air samples [2,3,5]. Atmospheres were generated using 2,4-D dimethylamine salt for S279 and Weedar Amine BK (Amchem; equal parts of 2,4-D dimethylamine salt and 2,4,5-T triethylamine salt) for S303. Overall precision and recovery for 100-L samples were as shown, representing non-significant bias in each method:

Method	Overall Precision (%)	Range Studied		Recovery @ 0.5 mg	7-Day Storage Stability, of Day 1
		mg/m <sup>3</sup>	mg per sample		
S279	0.051	5 to 20	0.5 to 1	0.97	99
S303	0.053	5 to 21	0.5 to 1	0.86 to 0.99	104

REFERENCES:

- 1] Criteria for a Recommended Standard...Occupational Exposure During Manufacture and Formulation of Pesticides, U.S. Department of Health, Education, and Welfare, Publ. (NIOSH) 78-174 (1978).
- 2] Backup Data Report S279 for 2,4-D prepared under NIOSH Contract No. 210-76-0123 (unpublished, 1976), available as "Ten NIOSH Analytical Methods, Set 6," Order No. PB 288-629 from NTIS, Springfield, VA 22161.
- 3] Backup Data Report S303 for 2,4,5-T prepared under NIOSH Contract No. 210-76-0123 (unpublished, 1976), available as "Ten NIOSH Analytical Methods, Set 6," Order No. PB 288-629 from NTIS, Springfield, VA 22161.
- 4] NIOSH Manual of Analytical Methods, 2nd ed., V. 5, U.S. Department of Health, Education, and Welfare, Publ. (NIOSH) 79-141 (1979).
- 5] NIOSH Research Report-Development and Validation of Methods for Sampling and Analysis of Workplace Toxic Substances, U.S. Department of Health and Human Services, Publ. (NIOSH) 80-133 (1980).

METHOD REVISED BY: Robert W. Kurimo, NIOSH/DPSE; originally validated under NIOSH Contract No. 210-76-0123.

---

Analyte:	DDT	Method No.:	S274
Matrix:	Air	Range:	0.49-2.60 mg/cu m
OSHA Standard:	1.0 mg/cu m - skin	Precision ( $\overline{CV}_m$ ):	0.061
Procedure:	Filter collection, iso-octane extraction, GC	Validation Date:	2/27/76

---

## 1. Principle of the Method

- 1.1 A known volume of air is drawn through a glass fiber filter to collect particulate matter.
- 1.2 The filter is transferred to a screw cap bottle within one hour after sampling and stored for analysis.
- 1.3 The analyte is extracted from the filter with iso-octane. An aliquot of the extract is analyzed by gas chromatography.
- 1.4 The area of the resulting peak is determined and compared with the areas for standards.

## 2. Range and Sensitivity

- 2.1 This method was validated over the range of 0.494-2.60 mg/cu m at an atmospheric temperature and pressure of 26°C and 760 mm Hg, using a 90-liter sample. The probable useful range of this method is 0.10-0.30 mg/cu m for 90-liter samples.
- 2.2 The upper limit of the range of the method is dependent on the capacity of the glass fiber filter. If higher concentrations than those tested are to be sampled, smaller sample volumes should be used.

## 3. Interferences

- 3.1 When interfering compounds are known or suspected to be present in the air, such information, including their suspected identities, should be transmitted with the sample.



66

3.2 It must be emphasized that any compound which has the same retention time as the analyte at the operating conditions described in this method is an interference.

#### 4. Precision and Accuracy

4.1 The Coefficient of Variation ( $\overline{CV}_m$ ) for the total analytical and sampling method in the range of 0.494-2.60 mg/cu m was 0.061. This value corresponds to a standard deviation of 0.06 mg/cu m at the OSHA standard level. Statistical information and details of the validation and experimental test procedures can be found in Reference 11.1.

4.2 A collection efficiency of 1.00 was determined for the collection medium, thus, no bias was introduced in the sample collection step, and no correction for collection efficiency is necessary. There was also no bias in the sampling and analytical method, since analytical method recovery corrections were made. Thus,  $\overline{CV}_m$  is a satisfactory measure of both accuracy and precision of the sampling and analytical method.

#### 5. Advantages and Disadvantages of the Method

The sampling device is small, portable, and involves no liquids. Samples collected on filters are analyzed by means of a quick, instrumental method.

#### 6. Apparatus

6.1 The sampling unit for the collection of personal air samples for the determination of organic aerosol has the following components:

6.1.1 The filter unit consisting of the filter media (Section 6.2) and a polystyrene 37-mm two-piece cassette filter holder. Do not use Tenite filter holders.

6.1.2 Personal Sampling Pump: A calibrated personal sampling pump whose flow can be determined to an accuracy of  $\pm 5\%$  (Reference 11.1) at the recommended flow rate. The pump must be calibrated with a representative filter holder and filter in the line.

6.1.3 Manometer.

6.1.4 Thermometer.

6.1.5 Stopwatch.

6.2 Glass fiber filter, similar to Gelman Type AE with a 37-mm diameter. The filter must be free of organic binders. The filter is held in the two-piece filter holder supported by a backup pad. The glass fiber filter should be at least 99.7% efficient against particles as small as 0.3 microns.

- 6.3 Screw cap bottles. Within 1 hour after sample has been collected, the filter is transferred to a clean screw cap bottle (a 45-mm tissue sample holder is satisfactory) for snipping. The bottle caps should be lined with Teflon for proper seal.
- 6.4 Gas chromatograph equipped with an electrolytic conductivity detector (Tracor or equivalent). The system includes an in-line vent between the exhaust end of the GC column and the reduction furnace, a quartz furnace operated in the reductive mode, an electrolytic conductivity cell, and a conductivity bridge.
- 6.5 Column (4-ft long X 1/2-in O.D. glass) packed with 5% SE-30 on 80/100 mesh, acid washed DMCS Chromosorb W.
- 6.6 An electronic integrator or some other suitable method for measuring peak areas.
- 6.7 Microliter syringes: 10-microliter and other convenient sizes for making standard solutions, and 25-microliter for making GC injections.
- 6.8 Volumetric flasks: Convenient sizes for preparing standard solutions.
- 6.9 Pipets of convenient sizes.
- 6.10 Tweezers.
7. Reagents
  - 7.1 DDT, reagent grade.
  - 7.2 Iso-octane, nanograde.
  - 7.3 Benzene, reagent grade.
  - 7.4 Purified nitrogen.
  - 7.5 Prepurified hydrogen.
8. Procedure
  - 8.1 Cleaning of Equipment. All glassware used for the laboratory analysis as well as the screw cap bottles should be detergent washed and thoroughly rinsed with tap water and distilled water, and dried.
  - 8.2 Calibration of Personal Sampling Pumps. Each personal sampling pump must be calibrated with a representative filter cassette in the line. This will minimize errors associated with uncertainties in the sample volume collected.

### 8.3 Collection and Shipping of Samples

- 8.3.1 Assemble the filter in the two-piece filter cassette holder and close firmly. The filter is held in place by a backup pad.
- 8.3.2 Remove the cassette plugs and attach to the personal sampling pump tubing. Clip the cassette to the worker's lapel.
- 8.3.3 Air being sampled should not pass through any hose or tubing before entering the filter cassette.
- 8.3.4 A sample size of 90 liters is recommended. Sample at a flow rate of 1.5 liters per minute. The flow rate should be known with an accuracy of  $\pm 5\%$ .
- 8.3.5 Turn the pump on and begin sample collection. Since it is possible for a filter to become plugged by heavy particulate loading or by the presence of oil mists or other liquids in the air, the pump rotameter should be observed frequently, and the sampling should be terminated at any evidence of a problem.
- 8.3.6 Terminate sampling at the predetermined time and note sample flow rate, collection time and ambient temperature and pressure. If pressure reading is not available, record the elevation.
- 8.3.7 The glass fiber filter should be removed from the cassette filter holder within 1 hour of sampling and placed in a clean screw cap bottle. Care must be taken to handle the filter only with clean tweezers.
- 8.3.8 Carefully record the sample identity and all relevant sampling data.
- 8.3.9 With each batch of ten samples, submit one filter from the same lot of filters which was used for sample collection and which is subjected to exactly the same handling as for the samples except that no air is drawn through it. Label this as a blank.
- 8.3.10 The screw cap bottles in which the samples are stored should be shipped in a suitable container, designed to prevent damage in transit.

### 8.4 Analysis of Samples

- 8.4.1 Each sample is analyzed separately.
- 8.4.2 Pipet 15 ml of iso-octane into each screw cap bottle.

- 8.4.3 Swirl the contents in each bottle occasionally for one hour.
- 8.4.4 Appropriate filter blanks must be analyzed at the same time as the samples.
- 8.4.5 GC Conditions. The typical operating conditions for the gas chromatograph are:
1. 115 ml/min nitrogen carrier gas flow
  2. 35 ml/min hydrogen gas flow to furnace
  3. 790°C furnace temperature
  4. 225°C transfer temperature
  5. 260°C vent temperature
  6. 190°C column temperature
- 8.4.6 Injection. The first step in the analysis is the injection of an aliquot of the sample into the gas chromatograph. To eliminate difficulties arising from blow back or evaporation of solvent within the syringe needle, one should employ the solvent flush injection technique. The 25-microliter syringe is first flushed with solvent several times to wet the barrel and plunger. Three microliters of solvent are drawn into the syringe to increase the accuracy and reproducibility of the injected sample volume. The needle is removed from the solvent, and the plunger is pulled back about 1.0 microliter to separate the solvent flush from the sample with a pocket of air to be used as a marker. The needle is then immersed in the sample, and a 15-microliter aliquot is withdrawn, taking into consideration the volume of the needle, since the sample in the needle will be completely injected. After the needle is removed from the sample and prior to injection, the plunger is pulled back 1.0 microliter to minimize evaporation of the sample from the tip of the needle. Observe that the sample occupies 14.9-15.0 microliters in the barrel of the syringe. The gas chromatograph is equipped with a valve to vent the solvent peak after it passes through the GC column, but before it enters a reduction furnace. Since a 15-microliter aliquot is likely to cause malfunction of the conductivity cell, the valve should be opened when injection is made and should be closed after the solvent (iso-octane) has been vented and before the analyte is eluted. Under the conditions above (Section 8.4.5), it was found that 20 seconds was adequate to elute the solvent. Duplicate injections of each sample and standard should be made. No more than a 3% difference in area is to be expected.

74

8.4.7 Measurement of area. The area of the sample peak is measured by an electronic integrator or some other suitable form of area measurement, and preliminary results are read from a standard curve prepared as discussed in Section 9.

## 8.5 Determination of Analytical Method Recovery

8.5.1 Need for Determination. To eliminate any bias in the analytical method, it is necessary to determine the recovery of the analyte. The analytical method recovery should be determined over the concentration range of interest.

8.5.2 Procedure for determining analytical method recovery. Six filters are spiked at each of the three levels (0.5X, 1X, and 2X the OSHA standard) using a stock solution of 225 mg of DDT in 2 ml of benzene and diluting to 10 ml with iso-octane. Three sets of six filters are spiked with appropriate volumes of the stock solution to correspond to the amount of DDT which would be collected in a 90-liter sample at the 0.5X, 1X, and 2X the OSHA standard level. Allow the filters to dry and place each filter in a cassette filter holder and allow to stand overnight. The filters are extracted and analyzed as described in Section 8.4. A parallel blank filter is also treated in the same manner except that no sample is added to it.

Analytical Method Recovery (A.M.R.) equals the weight in mg found divided by the weight in mg added to the filter, or,

$$\text{A.M.R.} = \frac{\text{mg found}}{\text{mg added}}$$

## 9. Calibration and Standards

It is convenient to express concentration of standards in terms of mg/15 ml iso-octane, because samples are extracted in this amount of iso-octane. A series of standards, varying in concentration over the range of interest, are prepared from the above stock solution. Dilute standards are prepared by diluting measured volumes of stock solution to known volumes with iso-octane. The standards are analyzed under the same GC conditions and during the same time period as the unknown samples. Curves are established by plotting concentration in mg/15 ml versus peak area. Note: Since no internal standard is used in the method, standard solutions must be analyzed at the same time that the sample analysis is done. This will minimize the effect of day-to-day variations and variations during the same day of the electrolytic conductivity detector response.

## 10. Calculations

10.1 Read the weight, in mg, corresponding to each peak area from the standard curve. No volume correction is needed, because the standard curve is based on mg/15 ml of iso-octane and the volume of sample injected is identical to the volume of the standards injected.

10.2 A correction for the blank must be made for each sample.

$$\text{mg} = \text{mg sample} - \text{mg blank}$$

where:

mg sample = mg found in sample filter

mg blank = mg found in blank filter

10.3 Divide the total weight by the analytical method recovery (A.M.R.) to obtain corrected mg/sample.

$$\text{Corrected mg/sample} = \frac{\text{mg found (Section 10.2)}}{\text{A.M.R.}}$$

10.4 The concentration of the analyte in the air sample can be expressed in mg/cu m.

$$\text{mg/cu m} = \frac{\text{mg (Section 10.3)} \times 1000 \text{ (liter/cu m)}}{\text{Air Volume Sampled (liter)}}$$

## 11. Reference

11.1 Documentation of NIOSH Validation Tests, NIOSH Contract No. CDC-99-74-45.

**ATTACHMENT 2**

# SAMPLE CUSTODY

SOP 1-2

Revision: 1

Date: June 30, 1994

Page 1 of 8

Prepared: David O. Johnson 7-14-94 Signature/Date Technical Review: [Signature] 7/21/94 Signature/Date  
 QA Review: Marquise E. Jones 7/22/94 Signature/Date Approved: [Signature] 8/12/94 Signature/Date  
 Issued: Rosemary Ellevick 8/19/94 Signature/Date

## 1.0 OBJECTIVE

Due to the evidentiary nature of samples collected during environmental investigations, possession must be traceable from the time the samples are collected until their derived data are introduced as evidence in legal proceedings. To maintain and document sample possession, sample custody procedures are followed. All paperwork associated with the sample custody procedures will be retained in CDM Federal Programs Corporation (CDM Federal) files unless the client requests that it be transferred to them for use in legal proceedings or at the completion of the contract.

## 2.0 BACKGROUND

### 2.1 Definitions

Sample - A material to be analyzed that is contained in single or multiple containers representing a unique sample identification number.

Sample Custody - A sample is under custody if:

1. It is in your possession.
2. It is in your view, after being in your possession.
3. It was in your possession and you locked it up.
4. It is in a designated secure area.

Chain-of-Custody Record - Form used to document the transfer of custody of samples from one individual to another.

Custody Seal - A custody seal is a tape-like seal that is part of the chain-of-custody process and is used to detect tampering with samples after they have been packed for shipping.



## **SAMPLE CUSTODY**

SOP 1-2

Revision: 1

Date: June 30, 1994

Page 2 of 8

Sample Label - Adhesive label placed on sample containers to designate a sample identification number and other sampling information.

Sample Tag - Tag attached with string to a sample container to designate a sample identification number and other sampling information. Tags may be used when it is difficult to physically place adhesive labels on the container (e.g., in the case of small air sampling tubes).

### **3.0 RESPONSIBILITIES**

**Sampler** - The sampler is personally responsible for the care and custody of the samples collected until they are properly transferred or dispatched.

**Field Team Leader** - The Field Team Leader is responsible for ensuring that strict chain-of-custody procedures are maintained during all sampling events. The Field Team Leader is also responsible for coordinating with the subcontractor laboratory to ensure that adequate information is recorded on custody records.

### **4.0 REQUIRED SUPPLIES**

- Chain-of-Custody Records (applicable CDM Federal forms)
- Custody seals
- Sample labels or tags
- Clear Tape

### **5.0 PROCEDURES**

#### **5.1 Chain-of-Custody Record**

This procedure establishes a method for maintaining custody of samples through use of a Chain-of-Custody Record. This procedure will be followed for all samples collected or split samples accepted.

## **SAMPLE CUSTODY**

SOP 1-2

Revision: 1

Date: June 30, 1994

Page 3 of 8

### **Field Custody**

1. Collect only the number of samples needed to represent the media being sampled. To the extent possible, determine the quantity and types of samples and sample locations prior to the actual fieldwork. As few people as possible should handle samples.
2. The field sampler is personally responsible for the care and custody of the samples collected until they are properly transferred or dispatched.
3. Sample labels or tags shall be completed for each sample, using waterproof ink.
4. The Field Team Leader determines whether proper custody procedures were followed during the fieldwork and decides if additional samples are required.

### **Transfer of Custody and Shipment**

1. Samples are accompanied by a Chain-of-Custody Record (see Figure 1 for example of Chain-of-Custody Record). When transferring the possession of samples, the individuals relinquishing and receiving will sign, date, and note the time on the record. This record documents sample custody transfer from the sampler, often through another person, to the analyst in the appropriate laboratory.
  - The date/time will be the same for both signatures when custody is transferred directly to another person. When samples are shipped via common carrier (e.g., Federal Express), the date/time will not be the same for both signatures. Common carriers are not required to sign the form.
  - In all cases, it must be readily apparent that the person who received custody is the same person who relinquished custody to the next custodian.
  - If samples are left unattended or a person refuses to sign, this must be documented and explained on the Chain-of-Custody Record.
2. Samples will be packaged properly for shipment and dispatched to the appropriate laboratory for analysis, with a separate custody record accompanying each shipment.
3. All shipments will be accompanied by the Chain-of-Custody Record identifying its contents. The original record will accompany the shipment, and the copies will be retained by the Field

**SAMPLE CUSTODY**

SOP 1-2

Revision: 1

Date: June 30, 1994

Page 4 of 8

Team Leader and if applicable, distributed to the appropriate sample coordinators. Freight bills will also be retained by the Field Team Leader as part of the permanent documentation. (Refer to Figure 1)

**Procedure for Completing CDM Federal Chain-of-Custody Record** (Refer to Figure 1.)

1. Record project number.
2. Record Field Team Leader for the project.
3. Record the name and address of the laboratory to which samples are being shipped.
4. Record the record number and total number of records being shipped for the day.
5. Enter the project name/location or code number.
6. Record overnight courier's airbill number.
7. Note sample type (matrix) and reference number. Include reference number on the Chain-of-Custody Record, box #9.
8. Record sample identification number.
9. Enter the reference number from box #7.
10. Enter date of sample collection.
11. Enter time of sample collection in military time.
12. Enter an X in appropriate box for sample designation - composite or grab.
13. Samplers must enter their initials next to the samples they collected.
14. List parameters for analysis and the number of containers submitted for each analysis.
15. Enter MS/MSD (matrix spike/matrix spike duplicate) if sample is for laboratory quality control, or other remarks (e.g. sample depth).

# SAMPLE CUSTODY


SOP 1-2

Revision: 1

Date: June 30, 1994

Page 5 of 8

Figure 1  
EXAMPLE CDM Federal Chain-of-Custody Record



**CDM FEDERAL PROGRAMS CORPORATION**  
A subsidiary of CDMC Group & United Inc.

30 North Westborough Street, Suite 200  
Barnstable, MA 02714  
017-742-2888

## CHAIN OF CUSTODY RECORD

PROJECT NO. 01		FIELD TEAM LEADER 02		LABORATORY AND ADDRESS 03		RECORD OF 04	
PROJECT NAME/LOCATION 05				ANALYST NO. 06			
<b>SAMPLE TYPES</b> 1. SURFACE WATER 2. SEDIMENTATION 3. LEACHATE 4. RESIDUE 5. SOLIDIFICATION 6. OIL 7. WASTE 8. OTHER		17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100		<b>ANALYSES</b> 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200		<b>REMARKS</b> 201 202 203 204 205 206 207 208 209 210 211 212 213 214 215 216 217 218 219 220 221 222 223 224 225 226 227 228 229 230 231 232 233 234 235 236 237 238 239 240 241 242 243 244 245 246 247 248 249 250 251 252 253 254 255 256 257 258 259 260 261 262 263 264 265 266 267 268 269 270 271 272 273 274 275 276 277 278 279 280 281 282 283 284 285 286 287 288 289 290 291 292 293 294 295 296 297 298 299 300	

\* ANALYST SIGNATURES 017

RELEASED BY: 018	DATE/TIME: 019	RECEIVED BY: 020	DATE/TIME: 021	RECEIVED BY: 022	DATE/TIME: 023

RECEIVED BY: 024

DATE/TIME: 025

RECEIVED BY: 026

DATE/TIME: 027

RECEIVED BY: 028

DATE/TIME: 029

RECEIVED BY: 030

DATE/TIME: 031

RECEIVED BY: 032

DATE/TIME: 033

RECEIVED BY: 034

DATE/TIME: 035

RECEIVED BY: 036

DATE/TIME: 037

RECEIVED BY: 038

DATE/TIME: 039

RECEIVED BY: 040

DATE/TIME: 041

RECEIVED BY: 042

DATE/TIME: 043

RECEIVED BY: 044

DATE/TIME: 045

RECEIVED BY: 046

DATE/TIME: 047

RECEIVED BY: 048

DATE/TIME: 049

RECEIVED BY: 050

DATE/TIME: 051

RECEIVED BY: 052

DATE/TIME: 053

RECEIVED BY: 054

DATE/TIME: 055

RECEIVED BY: 056

DATE/TIME: 057

RECEIVED BY: 058

DATE/TIME: 059

RECEIVED BY: 060

DATE/TIME: 061

RECEIVED BY: 062

DATE/TIME: 063

RECEIVED BY: 064

DATE/TIME: 065

RECEIVED BY: 066

DATE/TIME: 067

RECEIVED BY: 068

DATE/TIME: 069

RECEIVED BY: 070

DATE/TIME: 071

RECEIVED BY: 072

DATE/TIME: 073

RECEIVED BY: 074

DATE/TIME: 075

RECEIVED BY: 076

DATE/TIME: 077

RECEIVED BY: 078

DATE/TIME: 079

RECEIVED BY: 080

DATE/TIME: 081

RECEIVED BY: 082

DATE/TIME: 083

RECEIVED BY: 084

DATE/TIME: 085

RECEIVED BY: 086

DATE/TIME: 087

RECEIVED BY: 088

DATE/TIME: 089

RECEIVED BY: 090

DATE/TIME: 091

RECEIVED BY: 092

DATE/TIME: 093

RECEIVED BY: 094

DATE/TIME: 095

RECEIVED BY: 096

DATE/TIME: 097

RECEIVED BY: 098

DATE/TIME: 099

RECEIVED BY: 100

DATE/TIME: 101

RECEIVED BY: 102

DATE/TIME: 103

RECEIVED BY: 104

DATE/TIME: 105

RECEIVED BY: 106

DATE/TIME: 107

RECEIVED BY: 108

DATE/TIME: 109

RECEIVED BY: 110

DATE/TIME: 111

RECEIVED BY: 112

DATE/TIME: 113

RECEIVED BY: 114

DATE/TIME: 115

RECEIVED BY: 116

DATE/TIME: 117

RECEIVED BY: 118

DATE/TIME: 119

RECEIVED BY: 120

DATE/TIME: 121

RECEIVED BY: 122

DATE/TIME: 123

RECEIVED BY: 124

DATE/TIME: 125

RECEIVED BY: 126

DATE/TIME: 127

RECEIVED BY: 128

DATE/TIME: 129

RECEIVED BY: 130

DATE/TIME: 131

RECEIVED BY: 132

DATE/TIME: 133

RECEIVED BY: 134

DATE/TIME: 135

RECEIVED BY: 136

DATE/TIME: 137

RECEIVED BY: 138

DATE/TIME: 139

RECEIVED BY: 140

DATE/TIME: 141

RECEIVED BY: 142

DATE/TIME: 143

RECEIVED BY: 144

DATE/TIME: 145

RECEIVED BY: 146

DATE/TIME: 147

RECEIVED BY: 148

DATE/TIME: 149

RECEIVED BY: 150

DATE/TIME: 151

RECEIVED BY: 152

DATE/TIME: 153

RECEIVED BY: 154

DATE/TIME: 155

RECEIVED BY: 156

DATE/TIME: 157

RECEIVED BY: 158

DATE/TIME: 159

RECEIVED BY: 160

DATE/TIME: 161

RECEIVED BY: 162

DATE/TIME: 163

RECEIVED BY: 164

DATE/TIME: 165

RECEIVED BY: 166

DATE/TIME: 167

RECEIVED BY: 168

DATE/TIME: 169

RECEIVED BY: 170

DATE/TIME: 171

RECEIVED BY: 172

DATE/TIME: 173

RECEIVED BY: 174

DATE/TIME: 175

RECEIVED BY: 176

DATE/TIME: 177

RECEIVED BY: 178

DATE/TIME: 179

RECEIVED BY: 180

DATE/TIME: 181

RECEIVED BY: 182

DATE/TIME: 183

RECEIVED BY: 184

DATE/TIME: 185

RECEIVED BY: 186

DATE/TIME: 187

RECEIVED BY: 188

DATE/TIME: 189

RECEIVED BY: 190

DATE/TIME: 191

RECEIVED BY: 192

DATE/TIME: 193

RECEIVED BY: 194

DATE/TIME: 195

RECEIVED BY: 196

DATE/TIME: 197

RECEIVED BY: 198

DATE/TIME: 199

RECEIVED BY: 200

DATE/TIME: 201

RECEIVED BY: 202

DATE/TIME: 203

RECEIVED BY: 204

DATE/TIME: 205

RECEIVED BY: 206

DATE/TIME: 207

RECEIVED BY: 208

DATE/TIME: 209

RECEIVED BY: 210

DATE/TIME: 211

RECEIVED BY: 212

DATE/TIME: 213

RECEIVED BY: 214

DATE/TIME: 215

RECEIVED BY: 216

DATE/TIME: 217

RECEIVED BY: 218

DATE/TIME: 219

RECEIVED BY: 220

DATE/TIME: 221

RECEIVED BY: 222

DATE/TIME: 223

RECEIVED BY: 224

DATE/TIME: 225

RECEIVED BY: 226

DATE/TIME: 227

RECEIVED BY: 228

DATE/TIME: 229

RECEIVED BY: 230

DATE/TIME: 231

RECEIVED BY: 232

DATE/TIME: 233

RECEIVED BY: 234

DATE/TIME: 235

RECEIVED BY: 236

DATE/TIME: 237

RECEIVED BY: 238

DATE/TIME: 239

RECEIVED BY: 240

DATE/TIME: 241

RECEIVED BY: 242

DATE/TIME: 243

RECEIVED BY: 244

DATE/TIME: 245

RECEIVED BY: 246

DATE/TIME: 247

RECEIVED BY: 248

DATE/TIME: 249

RECEIVED BY: 250

DATE/TIME: 251

RECEIVED BY: 252

DATE/TIME: 253

RECEIVED BY: 254

DATE/TIME: 255

RECEIVED BY: 256

DATE/TIME: 257

RECEIVED BY: 258

DATE/TIME: 259

RECEIVED BY: 260

DATE/TIME: 261

RECEIVED BY: 262

DATE/TIME: 263

RECEIVED BY: 264

DATE/TIME: 265

RECEIVED BY: 266

DATE/TIME: 267

RECEIVED BY: 268

DATE/TIME: 269

RECEIVED BY: 270

DATE/TIME: 271

RECEIVED BY: 272

DATE/TIME: 273

RECEIVED BY: 274

DATE/TIME: 275

RECEIVED BY: 276

DATE/TIME: 277

RECEIVED BY: 278

DATE/TIME: 279

RECEIVED BY: 280

DATE/TIME: 281

RECEIVED BY: 282

DATE/TIME: 283

RECEIVED BY: 284

DATE/TIME: 285

RECEIVED BY: 286

DATE/TIME: 287

RECEIVED BY: 288

DATE/TIME: 289

RECEIVED BY: 290

DATE/TIME: 291

RECEIVED BY: 292

DATE/TIME: 293

RECEIVED BY: 294

DATE/TIME: 295

RECEIVED BY: 296

DATE/TIME: 297

RECEIVED BY: 298

DATE/TIME: 299

RECEIVED BY: 300

DATE/TIME: 301

RECEIVED BY: 302

DATE/TIME: 303

RECEIVED BY: 304

DATE/TIME: 305

RECEIVED BY: 306

DATE/TIME: 307

RECEIVED BY: 308

DATE/TIME: 309

RECEIVED BY: 310

DATE/TIME: 311

RECEIVED BY: 312

DATE/TIME: 313

RECEIVED BY: 314

DATE/TIME: 315

RECEIVED BY: 316

DATE/TIME: 317

RECEIVED BY: 318

DATE/TIME: 319

RECEIVED BY: 320

DATE/TIME: 321

RECEIVED BY: 322

DATE/TIME: 323

RECEIVED BY: 324

DATE/TIME: 325

RECEIVED BY: 326

DATE/TIME: 327

RECEIVED BY: 328

DATE/TIME: 329

RECEIVED BY: 330

DATE/TIME: 331

RECEIVED BY: 332

DATE/TIME: 333

RECEIVED BY: 334

DATE/TIME: 335

RECEIVED BY: 336

DATE/TIME: 337

RECEIVED BY: 338

DATE/TIME: 339

RECEIVED BY: 340

DATE/TIME: 341

RECEIVED BY: 342

DATE/TIME: 343

RECEIVED BY: 344

DATE/TIME: 345

RECEIVED BY: 346

DATE/TIME: 347

RECEIVED BY: 348

DATE/TIME: 349

RECEIVED BY: 350

DATE/TIME: 351

RECEIVED BY: 352

DATE/TIME: 353

RECEIVED BY: 354

DATE/TIME: 355

RECEIVED BY: 356

DATE/TIME: 357

RECEIVED BY: 358

DATE/TIME: 359

RECEIVED BY: 360

DATE/TIME: 361

RECEIVED BY: 362

DATE/TIME: 363

RECEIVED BY: 364

DATE/TIME: 365

RECEIVED BY: 366

DATE/TIME: 367

RECEIVED BY: 368

DATE/TIME: 369

RECEIVED BY: 370

DATE/TIME: 371

RECEIVED BY: 372

DATE/TIME: 373

RECEIVED BY: 374

DATE/TIME: 375

RECEIVED BY: 376

DATE/TIME: 377

RECEIVED BY: 378

DATE/TIME: 379

RECEIVED BY: 380

DATE/TIME: 381

RECEIVED BY: 382

DATE/TIME: 383

RECEIVED BY: 384

DATE/TIME: 385

RECEIVED BY: 386

DATE/TIME: 387

RECEIVED BY: 388

DATE/TIME: 389

RECEIVED BY: 390

DATE/TIME: 391

RECEIVED BY: 392

DATE/TIME: 393

RECEIVED BY: 394

DATE/TIME: 395

RECEIVED BY: 396

DATE/TIME: 397

RECEIVED BY: 398

DATE/TIME: 399

RECEIVED BY: 400

DATE/TIME: 401

RECEIVED BY: 402

DATE/TIME: 403

RECEIVED BY: 404

DATE/TIME: 405

RECEIVED BY: 406

DATE/TIME: 407

RECEIVED BY: 408

DATE/TIME: 409

RECEIVED BY: 410

DATE/TIME: 411

RECEIVED BY: 412

DATE/TIME: 413

RECEIVED BY: 414

DATE/TIME: 415

RECEIVED BY: 416

DATE/TIME: 417

RECEIVED BY: 418

DATE/TIME: 419

RECEIVED BY: 420

DATE/TIME: 421

RECEIVED BY: 422

DATE/TIME: 423

RECEIVED BY: 424

DATE/TIME: 425

RECEIVED BY: 426

DATE/TIME: 427

RECEIVED BY: 428

DATE/TIME: 429

RECEIVED BY: 430

DATE/TIME: 431

RECEIVED BY: 432

DATE/TIME: 433

RECEIVED BY: 434

DATE/TIME: 435

RECEIVED BY: 436

DATE/TIME: 437

RECEIVED BY: 438

DATE/TIME: 439

RECEIVED BY: 440

DATE/TIME: 441

RECEIVED BY: 442

DATE/TIME: 443

RECEIVED BY: 444

DATE/TIME: 445

RECEIVED BY: 446

DATE/TIME: 447

RECEIVED BY: 448

DATE/TIME: 449

RECEIVED BY: 450

DATE/TIME: 451

RECEIVED BY: 452

DATE/TIME: 453

RECEIVED BY: 454

DATE/TIME: 455

RECEIVED BY: 456

DATE/TIME: 457

RECEIVED BY: 458

DATE/TIME: 459

RECEIVED BY: 460

DATE/TIME: 461

RECEIVED BY: 462

DATE/TIME: 463

RECEIVED BY: 464

DATE/TIME: 465

RECEIVED BY: 466

DATE/TIME: 467

RECEIVED BY: 468

DATE/TIME: 469

RECEIVED BY: 470

DATE/TIME: 471

RECEIVED BY: 472

DATE/TIME: 473

RECEIVED BY: 474

DATE/TIME: 475

RECEIVED BY: 476

DATE/TIME: 477

RECEIVED BY: 478

DATE/TIME: 479

RECEIVED BY: 480

DATE/TIME: 481

RECEIVED BY: 482

DATE/TIME: 483

RECEIVED BY: 484

DATE/TIME: 485

RECEIVED BY: 486

DATE/TIME: 487

RECEIVED BY: 488

DATE/TIME: 489

RECEIVED BY: 490

DATE/TIME: 491

RECEIVED BY: 492

DATE/TIME: 493

RECEIVED BY: 494

DATE/TIME: 495

RECEIVED BY: 496

DATE/TIME: 497

RECEIVED BY: 498

DATE/TIME: 499

RECEIVED BY: 500

DATE/TIME: 501

RECEIVED BY: 502

DATE/TIME: 503

RECEIVED BY: 504

DATE/TIME: 505

RECEIVED BY: 506

DATE/TIME: 507

RECEIVED BY: 508

DATE/TIME: 509

RECEIVED BY: 510

DATE/TIME: 511

RECEIVED BY: 512

DATE/TIME: 513

RECEIVED BY: 514

DATE/TIME: 515

RECEIVED BY: 516

DATE/TIME: 517

RECEIVED BY: 518

DATE/TIME: 519

RECEIVED BY: 520

DATE/TIME: 521

RECEIVED BY: 522

DATE/TIME: 523

RECEIVED BY: 524

DATE/TIME: 525

RECEIVED BY: 526

DATE/TIME: 527

RECEIVED BY: 528

DATE/TIME: 529

RECEIVED BY: 530

DATE/TIME: 531

RECEIVED BY: 532

DATE/TIME: 533

RECEIVED BY: 534

DATE/TIME: 535

RECEIVED BY: 536

DATE/TIME: 537

RECEIVED BY: 538

DATE/TIME: 539

RECEIVED BY: 540

DATE/TIME: 541

RECEIVED BY: 542

DATE/TIME: 543

RECEIVED BY: 544

DATE/TIME: 545

RECEIVED BY: 546

DATE/TIME: 547

RECEIVED BY: 548

DATE/TIME: 549

RECEIVED BY: 550

DATE/TIME: 551

RECEIVED BY: 552

DATE/TIME: 553

RECEIVED BY: 554

DATE/TIME: 555

RECEIVED BY: 556

DATE/TIME: 557

RECEIVED BY: 558

DATE/TIME: 559

RECEIVED BY: 560

DATE/TIME: 561

RECEIVED BY: 562

DATE/TIME: 563

RECEIVED BY: 564

DATE/TIME: 565

RECEIVED BY: 566

DATE/TIME: 567

RECEIVED BY: 568

DATE/TIME: 569

RECEIVED BY: 570

DATE/TIME: 571

RECEIVED BY: 572

DATE/TIME: 573

RECEIVED BY: 574

DATE/TIME: 575

RECEIVED BY: 576

DATE/TIME: 577

RECEIVED BY: 578

DATE/TIME: 579

RECEIVED BY: 580

DATE/TIME: 581

RECEIVED BY: 582

DATE/TIME: 583

RECEIVED BY: 584

DATE/TIME: 585

RECEIVED BY: 586

DATE/TIME: 587

RECEIVED BY: 588

DATE/TIME: 589

RECEIVED BY: 590

DATE/TIME: 591

RECEIVED BY: 592

DATE/TIME: 593

RECEIVED BY: 594

DATE/TIME: 595

RECEIVED BY: 596

DATE/TIME: 597

RECEIVED BY: 598

DATE/TIME: 599

RECEIVED BY: 600

DATE/TIME: 601

RECEIVED BY: 602

DATE/TIME: 603

RECEIVED BY: 604

DATE/TIME: 605

RECEIVED BY: 606

DATE/TIME: 607

RECEIVED BY: 608

DATE/TIME: 609

RECEIVED BY: 610

DATE/TIME: 611

RECEIVED BY: 612

DATE/TIME: 613

RECEIVED BY: 614

DATE/TIME: 615

RECEIVED BY: 616

DATE/TIME: 617

RECEIVED BY: 618

DATE/TIME: 619

RECEIVED BY: 620

DATE/TIME: 621

RECEIVED BY: 622

DATE/TIME: 623

RECEIVED BY: 624

DATE/TIME: 625

RECEIVED BY: 626

DATE/TIME: 627

RECEIVED BY: 628

DATE/TIME: 629

RECEIVED BY: 630

DATE/TIME: 631

RECEIVED BY: 632

DATE/TIME: 633

RECEIVED BY: 634

DATE/TIME: 635

RECEIVED BY: 636

DATE/TIME: 637

RECEIVED BY: 638

DATE/TIME: 639

RECEIVED BY: 640

DATE/TIME: 641

RECEIVED BY: 642

DATE/TIME: 643

RECEIVED BY: 644

DATE/TIME: 645

RECEIVED BY: 646

DATE/TIME: 64

## SAMPLE CUSTODY

SOP 1-2

Revision: 1

Date: June 30, 1994

Page 6 of 8

16. Record the type of the preservative added by reference number and sample pH. Use the remarks column if no space is dedicated to preservative.
17. All samplers must sign in the space provided.
18. The originator checks information entered in items 1 through 17 and then signs the top left "Relinquished by" box, prints his/her name, and enters the current date and time (military).
  - Upon completion of the custody record form, the top two copies (usually white and yellow) shall be sent with the samples to the laboratory; the bottom copy (usually pink) is retained for the project files. Additional copies will be retained for the project file or distributed as required to the appropriate sample coordinators.
19. The laboratory sample custodian receiving the samples checks the sample label information against the custody record form. He or she also checks sample condition and notes anything unusual under "Remarks" on the custody record form. The laboratory custodian receiving custody signs in the adjacent "Received by" box and keeps the pink copy. The white copy is returned to CDM Federal.

### 5.2 Sample Labels and Tags

Sample labels or tags will be utilized for all samples collected or accepted for CDM Federal projects.

1. Place adhesive labels directly on the sample containers. Place clear tape over the label to protect from moisture.
2. Sample tags will be securely attached to the sample bottle. On 80 oz. amber bottles, the tag string may be looped through the ring style handle and tied. On all other containers, it is recommended that the string be looped around the neck of the bottle, then twisted and relooped around the neck until the slack in the string is removed.
3. One label or tag will be completed for each sample container collected. Each label or tag will be completed as follows (see Figure 2 for example of sample tag); labels are completed with the equivalent information:
  - Record the Project Code (i.e., project or task number).
  - Enter the Station Number if applicable.
  - Record the date to indicate the month, day, and year of sample collection.
  - Enter the time (military) of sample collection.



## SAMPLE CUSTODY

SOP 1-2

Revision: 1

Date: June 30, 1994

Page 8 of 8

- Place a check to indicate composite or grab sample.
- Record the sample location.
- Samplers must sign in the space provided.
- Place a check next to "yes" or "no" to indicate if a preservative was added.
- Under "analyses," place a check next to the parameters for which the sample is to be analyzed. If the desired analysis is not listed, write it in the empty slot. Note: Do not write in the box for "laboratory sample number."
- Under "remarks," add additional, relevant information.

### 5.3 Custody Seals

Custody seals must be placed on the shipping containers prior to shipment. The seal should be signed and dated by a field team member.

Custody seals may also be placed on individual sample bottles. Check with the client or refer to EPA regional guidelines for direction.

### 5.4 Sample Shipping

CDM Federal's Standard Operating Procedure 2-5: Packaging and Shipping of Environmental Samples establishes a uniform method for packaging and shipping low-level environmental samples.

## 6.0 RESTRICTIONS/LIMITATIONS

For EPA Contract Laboratory Program (CLP) sampling events, combined chain-of-custody/traffic report forms or other EPA-specific records may be utilized. Refer to regional guidelines for completing these forms.

## 7.0 REFERENCES

U.S. Environmental Protection Agency, *A Compendium of Superfund Field Operations Methods*, EPA/540/P-87/001, December 1987.

U.S. Environmental Protection Agency, *Samplers Guide to the Contract Laboratory Program*, EPA/540/P-90/006, December 1990.

# PACKAGING AND SHIPPING OF ENVIRONMENTAL SAMPLES

SOP 2-5

Revision: 1

Date: June 30, 1994

Page 1 of 3

Prepared: David O. John / 7-19-94      Technical Review: [Signature] 7/21/94  
 Signature/Date      Signature/Date  
 QA Review: Marguerite E. Jones 7/22/94      Approved: [Signature] 8/12/94  
 Signature/Date      Signature/Date  
 Issued: Lashley Eldersick 8/19/94  
 Signature/Date

## 1.0 OBJECTIVE

The objective of this standard operating procedure (SOP) is to establish packaging and shipping requirements and guidelines for environmental sample shipping.

## 2.0 BACKGROUND

### 2.1 Definitions

Environmental Sample - Environmental Sample is any sample that has less than reportable quantities for any hazardous constituents according to Department of Transportation (DOT) regulations promulgated in 49 CFR - Part 172.

### 2.2 Discussion

Proper packaging and shipping is necessary to ensure the protection of the integrity of environmental samples shipped for analysis.

### 2.3 Associated Procedure

- CDM Federal SOP 1-2, Sample Custody

## 3.0 RESPONSIBILITIES

**Field Team Leader** - The Field Team Leader is responsible for ensuring that packaging and sampling procedures are conducted in accordance with this SOP. The Field Team Leader is also responsible for ensuring that laboratory analysis of samples is properly coordinated by CDM Federal.



## **PACKAGING AND SHIPPING OF ENVIRONMENTAL SAMPLES**

SOP 2-5

Revision: 1

Date: June 30, 1994

Page 2 of 3

### **4.0 REQUIRED EQUIPMENT**

- Coolers with return address of CDM Federal office
- Heavy-duty plastic garbage bags
- Plastic zip-top bags, small and large
- Clear Tape
- Fiber tape
- Duct tape
- Vermiculite
- Bubble wrap (optional)
- Ice
- Chain-of-Custody seals
- Completed Chain-of-Custody record or CLP custody records if applicable
- Completed Bill of Lading
- "This End Up" and directional arrow labels

### **5.0 PROCEDURES**

The following steps must be followed when packing sample bottles and jars for shipment:

1. Select a sturdy cooler in good repair. Secure and tape the drain plug with fiber or duct tape. Line the cooler with a large heavy-duty plastic garbage bag.
2. Be sure the caps on all bottles are tight (will not leak); check to see that labels and chain-of-custody records are completed properly.
3. Place all bottles in separate and appropriately sized plastic zip-top bags and close the bags. Up to three VOA vials may be packed in one bag. Bottles may be wrapped in bubble wrap. Optionally, place three to six VOA vials in a quart metal can and then fill the can with vermiculite.
4. Place two to four inches of vermiculite into the bag in the cooler and then place the bottles and cans in the bag with sufficient space to allow for the addition of more vermiculite between the bottles and cans. It is preferable to place glass sample bottles and jars into the cooler vertically. Due to the strength properties of a glass container, there is much less chance for breakage when the container is packed vertically rather than horizontally.

## PACKAGING AND SHIPPING OF ENVIRONMENTAL SAMPLES

SOP 2-5

Revision: 1

Date: June 30, 1994

Page 3 of 3

5. Put ice in large plastic zip-top bags (double bagging the zip-tops is preferred) and properly seal. Place these ice bags on top of, or between, the samples. Several bags of ice are required for temperature control. Fill all remaining space between the bottles or cans with vermiculite. Securely fasten the top of the large garbage bag with fiber or duct tape.
6. Place the completed Chain-of-Custody Record or the CLP Traffic Report Form (if applicable) for the laboratory into a plastic zip-top bag, seal the bag, tape the bag to the inner side of the cooler's lid, and then close the cooler.
7. Fiber tape shall be wrapped around each end of the cooler two times, and completed Chain-of-Custody seals affixed to the top opposite sides of the cooler, half on the fiber tape so that the cooler cannot be opened without breaking the seal. Complete two more wrap arounds with fiber tape; place clear tape over custody seals.
8. The shipping container lid must be marked "THIS END UP" and arrow labels which indicate the proper upward position of the container should be affixed to the cooler. A label containing the name and address of the shipper (CDM Federal) shall be placed on the outside of the container. Labels used in the shipment of hazardous materials (such as Cargo Only Air Craft, Flammable Solids, etc.) are not permitted to be on the outside of the container used to transport environmental samples and shall not be used. The name and address of the laboratory shall be placed on the container, or when shipping by common courier, the Bill of Lading shall be completed and attached to the lid of the shipping container.

### 6.0 RESTRICTIONS/LIMITATIONS

The holding times for the samples packed for shipment must not be exceeded. It is recommended that samples be packed in time to be shipped nightly for overnight delivery. Use caution when shipping samples for weekend delivery; make arrangements with laboratory before sending samples.

### 7.0 REFERENCES

U.S. Environmental Protection Agency, *Sampler's Guide to the Contract Laboratory Program*, EPA/540/P-90/006, December 1990.

U.S. Environmental Protection Agency, Region IV, *Standard Operating Procedures and Quality Assurance Manual*, February 1991.

**FIELD LOGBOOK CONTENT AND CONTROL**

SOP 4-1

Revision: 2

Date: January 5, 1995

Page 1 of 6

Prepared: Donnie McLean 12/22/94

Signature/Date

Technical Review: Jackie McLean 12/28/94

Signature/Date

QA Review: Shirley C. Smith 12/30/94

Signature/Date

Approved: [Signature] 1/5/95

Signature/Date

Issued: Barbara E. Elwick 1/5/95

Signature/Date

**1.0 OBJECTIVE**

The objective of this standard operating procedure (SOP) is to set CDM Federal criteria for content entry and form of field logbooks.

**2.0 BACKGROUND****2.1 Definitions**

Biota - The flora and fauna of a region.

Decontamination - To remove contaminants from field sampling equipment that might bias analytical results.

Magnetic Declination Corrections - Compass adjustments to correct for the angle between magnetic north and geographical meridians.

**2.2 Discussion**

Information recorded in field logbooks include observations, data, calculations, time, weather, description of the data collection activity, methods, instruments, and results. Additionally, the logbook may contain descriptions of wastes, biota, geologic material, and site features including sketches, maps, or drawings as appropriate.

**3.0 RESPONSIBILITIES**

**Field Team Leader (FTL)** - The FTL is responsible for ensuring the nature and form of data entries are conducted in accordance with this procedure.

## FIELD LOGBOOK CONTENT AND CONTROL

SOP 4-1

Revision: 2

Date: January 5, 1995

Page 2 of 6

**Site Personnel** - All CDM Federal employees who make entries in field logbooks during on-site activities are required to read this procedure prior to engaging in this activity. The FTL will assign field logbooks to site personnel who will be responsible for their care and maintenance.

### 4.0 REQUIRED EQUIPMENT

- Site-specific plans
- Field notebook
- Indelible black or blue ink pen
- Ruler or similar scale (in some circumstances)

### 5.0 PROCEDURES

#### 5.1 Preparation

In addition to this SOP, site personnel responsible for maintaining logbooks must be familiar with other pertinent CDM Federal and site SOPs. These should be consulted as necessary to obtain specific information about equipment and supplies, health and safety, sample collection, packaging, decontamination, and documentation. These procedures should be located at the field office.

Field logbooks shall be bound with lined, consecutively numbered pages. All pages must be numbered prior to initial use of the logbook. Prior to use in the field, each logbook will be marked with a specific document control number issued by the document control administrator. The following information shall be recorded on the cover of the logbook:

- Field Logbook Document Control Number
- Activity (if the logbook is to be activity-specific)
- Name of CDM Federal contact and phone number(s)
- Start date

The first few (approximately five) pages of the logbook shall be reserved for a table of contents. Mark the first page with the heading and enter the following:

# FIELD LOGBOOK CONTENT AND CONTROL

SOP 4-1

Revision: 2

Date: January 5, 1995

Page 3 of 6

## TABLE OF CONTENTS

Date/Description	Page
(Start Date)/Reserved for TOC	1-5

The remaining pages of the Table of Contents will be designated as such with "TOC" written on the top center of each page.

### 5.2 Operation

The following is a list of requirements that must be followed when using a logbook:

- Record work, observations, quantities of materials, calculations, drawings, and related information directly in the logbook. If data collection forms are specified by an activity-specific plan, this information need not be duplicated in the logbook. However, any forms used to record site information must be referenced in the logbook.
- Do not start a new page until the previous one is full or has been marked with a single diagonal line so that additional entries cannot be made. Use both sides of each page.
- Do not erase or blot out any entry at any time. Indicate any deletion by a single line through the material to be deleted. Initial and date each deletion. Take care to not obliterate what was written previously.
- Do not remove any pages from the book.
- Record as much information as possible.

Specific requirements for field logbook entries include:

- Initial and date each page
- Sign and date the final page of entries for each day
- Initial and date all changes
- Multiple authors must sign out the logbook by inserting the following:

Above notes authored by:

- (Sign name)

# FIELD LOGBOOK CONTENT AND CONTROL

SOP 4-1

Revision: 2

Date: January 5, 1995

Page 4 of 6

- (Print name)
- (Date)
- A new author must sign and print his/her name before additional entries are made
- Draw a diagonal line through the remainder of the final page at the end of the day
- Record the following information on a daily basis:
  - Date and time
  - Name of individual making entry
  - Names of field team and other persons on-site
  - Description of activity being conducted including station (i.e., well, boring, sampling location number) if appropriate
  - Weather conditions (i.e., temperature, cloud cover, precipitation, wind direction, and speed) and other pertinent data
  - Level of personal protection to be used
  - Serial numbers of instruments
  - Required calibration information
  - Serial/tracking numbers on documentation (e.g., carrier airbills)

Entries into the field logbook shall be preceded with the time (written in military units) of the observation. The time should be recorded frequently and at the point of events or measurements that are critical to the activity being logged. All measurements made and samples collected must be recorded unless they are documented by automatic methods (e.g., data logger) or on a separate form required by an operating procedure. In these cases, the logbook must reference the automatic data record or form.

At each station where a sample is collected or an observation or measurement made, a detailed description of the location of the station is required. Use a compass (include a reference to magnetic declination corrections), scale, or nearby survey markers, as appropriate. A sketch of station location may be warranted. All maps or sketches made in the logbook should have descriptions of the features shown and a direction indicator. It is preferred that maps and sketches be oriented so that north is toward the top of the page.

Other events and observations that should be recorded include:

- Changes in weather that impact field activities
- Deviations from procedures outlined in any governing documents. Also record the reason for any noted deviation.

## FIELD LOGBOOK CONTENT AND CONTROL

SOP 4-1

Revision: 2

Date: January 5, 1995

Page 5 of 6

- Problems, downtime, or delays
- Upgrade or downgrade of personal protection equipment

### 5.3 Post-Operation

To guard against loss of data due to damage or disappearance of logbooks, completed pages shall be periodically photocopied (weekly, at a minimum) and forwarded to the field or project office. Other field records shall be photocopied and submitted regularly and as promptly as possible to the office. When possible, electronic media such as disks and tapes should be copied and forwarded to the office.

At the conclusion of each activity or phase of site work, the individual responsible for the logbook will ensure that all entries have been appropriately signed and dated, and that corrections were made properly (single lines drawn through incorrect information, then initialed and dated). The completed logbook shall be submitted to the records file.

### 6.0 RESTRICTIONS/LIMITATIONS

Field logbooks constitute the official record of on-site technical work, investigations, and data collection activities. Their use, control, and ownership are restricted to activities pertaining to specific field operations carried out by CDM Federal personnel and their subcontractors. They are documents that may be used in court to indicate and defend dates, personnel, procedures, and techniques employed during site activities. Entries made in these notebooks should be factual, clear, precise, and as non-subjective as possible. Field logbooks, and entries within, are not to be utilized for personal use.

### 7.0 REFERENCES

Sandia National Laboratories, *Procedure for Preparing, Sampling and Analysis Plan, Site-Specific Sampling Plan, and Field Operating Procedures*, QA-02-03, Albuquerque Environmental Program Department 3220, Albuquerque, New Mexico, 1991.

Sandia National Laboratories, Division 7723, *Field Operation Procedure for Field Logbook Content and Control*, Environmental Restoration Department, Albuquerque, New Mexico, 1992.

**FIELD LOGBOOK CONTENT AND CONTROL**

SOP 4-1

Revision: 2

Date: January 5, 1995

Page 6 of 6

**THIS PAGE INTENTIONALLY BLANK TO CORRECT AN ERROR IN PAGE NUMBERING. The total number of pages should have been 5. The procedure is complete in 5 pages.**



**ATTACHMENT 2**

KEMRON ENVIRONMENTAL SERVICES  
39830 GRAND RIVER B-2  
NOVI, MICHIGAN 48375

Phone: (810) 474-4200

CDM/FEDERAL PROGRAMS CORP.  
13135 LEE JACKSON  
MEMORIAL HWY  
FAIRFAX, VIRGINIA 22033  
Attn: CHUCK MEYERS  
Invoice Number:

Order #: 95-04-136  
Date: 05/04/95 18:41  
Work ID: 7801034PRSITE  
Date Received: 04/20/95  
Date Completed: 05/04/95  
Client Code: 05\_CDM

SAMPLE IDENTIFICATION

<u>Sample Number</u>	<u>Sample Description</u>
01	D004
02	D001
03	D003
04	D002
05	D005
06	D008
07	D010
08	D009
09	D006
10	D007
11	D011
12	D013
13	D012
14	D016
15	D014
16	D015

<u>Sample Number</u>	<u>Sample Description</u>
17	2-005
18	2-004
19	2-001
20	W-003
21	2-002
22	2-006
23	2-010
24	2-007
25	2-008
26	2-009
27	2-011
28	2-016
29	2-013
30	2-012
31	2-015
32	2-014

Charles O'Bryan  
Certified By  
Charles O'Bryan

Order # 95-04-136  
05/04/95 18:41

KEMRON ENVIRONMENTAL SERVICES  
TEST RESULTS BY SAMPLE

---

Page 2

Sample: 01A D004

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 02A D001

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 03A D003

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 04A D002

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 05A D005

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 06A D008

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL

118

Order # 95-04-136  
05/04/95 18:41

KEMRON ENVIRONMENTAL SERVICES  
TEST RESULTS BY SAMPLE

---

Page 3

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 07A D010

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 08A D009

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 09A D006

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 10A D007

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 11A D011

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

120

Sample: 12A D013

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 13A D012

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 14A D016

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 15A D014

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 16A D015

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
DDD	<0.01	0.01	ug	05/04/95	JL
DDE	<0.01	0.01	ug	05/04/95	JL
DDT	<0.01	0.01	ug	05/04/95	JL

Sample: 17A 2-005

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

122

Order # 95-04-136  
05/04/95 18:41

KEMRON ENVIRONMENTAL SERVICES  
TEST RESULTS BY SAMPLE

---

Page 5

Sample: 18A 2-004

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 19A 2-001

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 20A W-003

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 21A 2-002

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 22A 2-006

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 23A 2-010

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 24A 2-007

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB

124

Order # 95-04-136  
05/04/95 18:41

KEMRON ENVIRONMENTAL SERVICES  
TEST RESULTS BY SAMPLE

---

Page 6

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4-D	<2	2	ug	05/04/95	KB

Sample: 25A 2-008

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 26A 2-009

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 27A 2-011

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 28A 2-016

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 29A 2-013

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 30A 2-012

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

126

Order # 95-04-136  
05/04/95 18:41

KEMRON ENVIRONMENTAL SERVICES  
TEST RESULTS BY SAMPLE

---

Page 7

Sample: 31A 2-015

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

Sample: 32A 2-014

Collected:

<u>Test Description</u>	<u>Result</u>	<u>Det Limit</u>	<u>Units</u>	<u>Analyzed</u>	<u>By</u>
2,4,5-T	<10	10	ug	05/04/95	KB
2,4-D	<2	2	ug	05/04/95	KB

128



Order # 95-04-136  
05/04/95 18:44

KEMRON ENVIRONMENTAL SERVICES  
TEST METHODOLOGIES

Page 8

DDD METHOD:P&CAM S274

DDE METHOD:P&CAM S274

DDT METHOD:P&CAM S274

2,4,5-T Method: NIOSH 5001

2,4-D Method: NIOSH 5001

# Calibration Curves Report

File: c:\star\ecd052.mth

Detector: ADC Board, Address: 16, Channel ID: A

## DDE

External Standard Analysis


Curve Type: Linear

Origin: Force (Edited)

$$y = +4.125858e+003x$$

Resp. Fact. RSD: 17.44%

Corr. Coef.(R<sup>2</sup>): 0.990823



## DDD

External Standard Analysis


Curve Type: Linear

Origin: Force (Edited)

$$y = +3.427347e+003x$$

Resp. Fact. RSD: 12.48%

Corr. Coef.(R<sup>2</sup>): 0.999308



## DDT

External Standard Analysis


Curve Type: Linear

Origin: Force (Edited)

$$y = +3.909758e+003x$$

Resp. Fact. RSD: 15.18%

Corr. Coef.(R<sup>2</sup>): 0.995684



## GC/ECD - Spike Recovery Report

Date: 5/5/95Analyst: JL

<u>Compound</u>	<u>Amount Spiked</u>	<u>Amount Recovered</u>	<u>% Recovery</u>
DDD	200 ng	224 ng	112
DDE	200 ng	239.5 ng	119.7
DDT	200 ng	221 ng	110

Title : DB5-30 meter-Channel A  
Run File : C:\STAR\MODU. 16\SUB\EC502001.RUN  
Method File : C:\STAR\ECD052.MTH  
Sample ID : DDT Breakdown


136

Injection Date: 2-MAY-95 4:22 PM Calculation Date: 3-MAY-95 10:14 AM

Operator : Lane Detector Type: ADCB (10 Volts)  
Workstation: DIGITAL Bus Address : 16  
Instrument : Varian 3400 ECD Sample Rate : 10.00 Hz  
Channel : A = ECD A 10 VDC Run Time : 30.002 min

\*\*\*\*\* Star Chromatography Software \*\*\*\*\* Version 4.01 \*\*\*\*\*

Chart Speed = 0.66 cm/min Attenuation = 1580 Zero Offset = 4%  
Start Time = 0.000 min End Time = 30.002 min Min / Tick = 1.00



Title : DB5-30 mete. Channel A  
 Run File : C:\STAR\MODULE16\SUB\EC502001.RUN  
 Method File : C:\STAR\ECD052.MTH  
 Sample ID : DDT Breakdown

138

Injection Date: 2-MAY-95 4:22 PM Calculation Date: 3-MAY-95 10:14 AM

Operator : Lane Detector Type: ADCB (10 Volts)  
 Workstation: DIGITAL Bus Address : 16  
 Instrument : Varian 3400 ECD Sample Rate : 10.00 Hz  
 Channel : A = ECD A 10 VDC Run Time : 30.002 min

\*\*\*\*\* Star Chromatography Software \*\*\*\*\* Version 4.01 \*\*\*\*\*

Run Mode : Analysis  
 Peak Measurement: Peak Area  
 Calculation Type: External Standard

Peak No.	Peak Name	Result (ppb)	Ret. Time (min)	Time Offset (min)	Area (counts)	Sep. Code	Width 1/2 (sec)	Status Codes
1		0.0000	0.212	0.000	25577	BV	18.1	
2		0.0000	0.306	0.000	31924	VV	3.9	
3		0.0000	0.471	0.000	81561	VV	1.5	
4		0.0000	0.506	0.000	185259	VP	0.1	
5		0.0000	0.574	0.000	117117	PV	0.7	
6		0.0000	0.699	0.000	21414	TS	0.0	
7		0.0000	0.798	0.000	114381	VV	1.4	
8		0.0000	0.924	0.000	51317	VV	5.7	
9		0.0000	1.036	0.000	14639	VV	2.4	
10		0.0000	1.094	0.000	19501	VV	2.6	
11		0.0000	1.164	0.000	27755	VV	2.0	
12		0.0000	1.213	0.000	18607	VV	2.1	
13		0.0000	1.307	0.000	33854	VV	2.3	
14		0.0000	1.443	0.000	11033	VV	2.1	
15		0.0000	1.541	0.000	27739	VV	1.7	
16		0.0000	1.603	0.000	6707	VV	2.9	
17		0.0000	1.669	0.000	2996	VB	0.0	
18		0.0000	1.972	0.000	2147	BB	2.9	
19		0.0000	2.423	0.000	3071	VV	4.0	
20		0.0000	2.586	0.000	4614	VB	3.5	
21		0.0000	3.518	0.000	2700	BV	3.5	
22		0.0000	4.632	0.000	4891	BB	4.2	
23		0.0000	7.254	0.000	10670	BB	5.5	
24		0.0000	7.976	0.000	2315	BB	3.8	
25		0.0000	17.025	0.000	85441	BB	3.9	
26	DDE	0.7606	18.309	0.408	3138	BB	3.5	
27	DDT	157.3891	19.493	0.003	615354	BB	3.6	
28		0.0000	20.156	0.000	12514	BB	3.9	
29		0.0000	20.575	0.000	55131	BB	4.2	
Totals:		158.1497		0.411	1593367			

$\frac{0.7606}{157.3891 + 0.7606} \times 100 = 0.4$

Total Unidentified Counts : 974874 counts

Detected Peaks: 39 Rejected Peaks: 10 Identified Peaks: 2

Amount Standard: N/A Multiplier: 1.000000 Divisor: 1.000000

Baseline Offset: -70 microVolts

140

Noise (used): 1170 microVolts - monitored before this run

Rack: 1      Vial: 1      Injection Number: 1      Injection Volume: 1.0 ul

\*\*\*\*\*

Title : DB-608 30 meter-Channel B  
Run File : C:\STAR\MODU 16\SUB\EC502001.RUN  
Method File : C:\STAR\ECD052.MTH  
Sample ID : DDT Breakdown


142

Injection Date: 2-MAY-95 4:22 PM Calculation Date: 3-MAY-95 10:21 AM

Operator : Lane Detector Type: ADCB (10 Volts)  
Workstation: DIGITAL Bus Address : 16  
Instrument : Varian 3400 ECD Sample Rate : 10.00 Hz  
Channel : B = ECD B 10 VDC Run Time : 30.002 min

\*\*\*\*\* Star Chromatography Software \*\*\*\*\* Version 4.01 \*\*\*\*\*

Chart Speed = 0.66 cm/min Attenuation = 545 Zero Offset = 7%  
Start Time = 0.000 min End Time = 30.002 min Min / Tick = 1.00



Title : DB-608 30 m 2r-Channel B  
 Run File : C:\STAR\MODULE16\SUB\EC502001.RUN  
 Method File : C:\STAR\ECD052.MTH  
 Sample ID : DDT Breakdown

14

Injection Date: 2-MAY-95 4:22 PM Calculation Date: 3-MAY-95 10:21 AM

Operator : Lane Detector Type: ADCB (10 Volts)  
 Workstation: DIGITAL Bus Address : 16  
 Instrument : Varian 3400 ECD Sample Rate : 10.00 Hz  
 Channel : B = ECD B 10 VDC Run Time : 30.002 min

\*\*\*\*\* Star Chromatography Software \*\*\*\*\* Version 4.01 \*\*\*\*\*

Run Mode : Analysis  
 Peak Measurement: Peak Area  
 Calculation Type: External Standard

Peak No.	Peak Name	Result (ppb)	Ret. Time (min)	Time Offset (min)	Area (counts)	Sep. Code	Width 1/2 (sec)	Status Codes
1		0.0000	0.213	0.000	3282	BV	18.1	
2		0.0000	0.522	0.000	50652	BP	0.6	
3		0.0000	0.592	0.000	86383	PV	1.3	
4		0.0000	0.710	0.000	27478	VB	1.1	
5		0.0000	0.877	0.000	2706	BV	1.8	
6		0.0000	0.912	0.000	3660	VV	1.7	
7		0.0000	0.993	0.000	3666	VV	1.8	
8		0.0000	1.101	0.000	8023	VB	1.9	
9		0.0000	1.332	0.000	3793	BB	3.0	
10		0.0000	5.478	0.000	2789	BB	0.0	
11	DDD	10.0487	19.101	-0.010	24646	BB	3.5	
12	DDT	147.0232	19.721	0.001	391347	BB	3.5	
13		0.0000	20.330	0.000	11035	BV	4.1	
14		0.0000	20.481	0.000	4383	VB	0.0	
15		0.0000	23.940	0.000	9642	BB	8.5	
Totals:		157.0719		-0.009	633485			

$\frac{10.0487}{147.0232 + 10.0487} \times 100 =$

Total Unidentified Counts : 217491 counts

Detected Peaks: 17 Rejected Peaks: 2 Identified Peaks: 2

Amount Standard: N/A Multiplier: 1.000000 Divisor: 1.000000

Baseline Offset: -8 microVolts

Noise (used): 1850 microVolts - monitored before this run

Rack: 1 Vial: 1 Injection Number: 1 Injection Volume: 1.0 ul


\*\*\*\*\*



CALPLOR Output For Sample File: "C:\DATA\2450.SMP"  
 Date: 6/8/95 Time: 14:48

Curve Parameters:

Curve 01: First Order Polynomial Fit  
 Weighting Factor = 1/x  $r^2 = 0.997682$   
 Calibration Curve =  $(-733.947266) + (28769.658283)X$



	ug Spiked	ug Recovered	% Recovery
Rec B/LK	—	—	—
Rec 1	10.0	9.7	97
Rec 2	10.0	10.2	102

CALPLOT Data Lists For Sample File: "C:\DATA\AN2450.SMP"  
 Date: 5/1/95 Time: 05:52

Data Lists With Calculated Values For Each Fit:

Curve #1 : First Order Polynomial Fit  
 Weighting Factor =  $1/x$   $r^2 = 0.997802$


Calibration Curve =  $(-733.947266) + (20769.658283)X$

Level Name	Observed X-Value	Calculated X-Value	Delta	%Diff.	Observed Y-Value	Calculated Y-Value	Delta	%Diff.
A	0.990000	1.019011	-0.029011	-3.011	20447.185547	19028.013672	619.171875	3.028
B	1.560000	1.937303	-0.022697	-1.158	39503.179688	39974.582031	-471.402344	-1.193
C	4.760000	4.854983	-0.104983	-2.206	100310.083938	98129.617188	2180.466750	2.174
D	9.090000	8.587056	0.502944	6.413	179954.763125	188662.250000	-12107.546875	-6.881
E	20.000000	20.478844	-0.478844	-2.394	424438.580000	414639.218750	9799.361250	2.304

CALPLOT Output For Sample File: "C:\DATA\2450.SMP"  
 Date: 6/8/95 Time: 14:46

Curve Parameters:

Curve #1: First Order Polynomial Fit  
 Weighting Factor = 1/x  $r^2 = 0.997602$   
 Calibration Curve =  $(495.498877) + (15235.061523)X$



	ug Spiked	ug Recovered	% Recovery
Rec Blk	—	—	—
Rec 1	10.0	10.2	102
Rec 2	10.0	11.0	111

CALPLOT Data Lists For Sample File: "C:\DATA\2450.SMP"

Date: 5/1/95 Time: 05:52

Data Lists With Calculated Values For Each Fit:

Curve #1 : First Order Polynomial Fit

Weighting Factor =  $1/x$   $r^2 = 0.997602$

Calibration Curve =  $(495.490077) + (13233.061321)X$

Level Name	Observed Y-Value	Calculated Y-Value	Delta	%Diff.	Observed Y-Value	Calculated Y-Value	Delta	%Diff.
A	0.990000	1.023857	-0.033857	-3.39	16081.829182	15578.208904	503.620117	3.132
B	1.960000	1.959657	0.000343	0.018	30350.984375	30336.216797	14.767578	0.049
C	4.760000	4.805765	-0.045765	-0.962	73711.625000	73014.398625	697.226375	0.946
D	9.090000	8.463431	0.626569	6.893	129436.398438	128982.283125	454.115313	0.351
E	21.000000	21.540090	-0.540090	-2.570	320781.968750	320431.781250	350.187500	0.110

**ATTACHMENT 3**

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

Rm #1

Sample Number: 2-005Sampler: D. O'DonnellDate: 4/11/95Project: Ft. DrumPump Number: 15991PreCalibration Rate: 2,005 cc/minutePost Calibration Rate: 2,186 cc/minuteSample Start Time: 0850Sample Stop Time: 1445

Sample Run Time: \_\_\_\_\_

Run Time: 355 min. Flow Rate: 2.1 l/min. Total Volume: 745.5 l  
0.7455 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

## Perimeter Sample

## Sample Locations:

Sample Results: < 0.01  $\mu\text{g}/\text{m}^3$  < 10  $\mu\text{g}/\text{m}^3$  - 2, 4, 5 - T< 2  $\mu\text{g}/\text{m}^3$  - 2, 4 - D< 0.01  $\mu\text{g}/\text{m}^3$  for - BDD, BDE, BDT< 13  $\mu\text{g}/\text{m}^3$  - 2, 4, 5 - T< 3  $\mu\text{g}/\text{m}^3$  - 2, 4 - D

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

RM #2

Sample Number: 2-004Sampler: D. O'DonnellDate: 4/11/95Project: FA. DrumPump Number: 16203PreCalibration Rate: 1,996 cc/minutePost Calibration Rate: 2,110 cc/minuteSample Start Time: 0850Sample Stop Time: 1448

Sample Run Time: \_\_\_\_\_

Run Time: 358 min.Flow Rate: 2.0 l/min.Total Volume: 716 l0.716 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

## Perimeter Sample

## Sample Locations:

Sample Results: \_\_\_\_\_

<0.01  $\mu\text{g}$ <10  $\mu\text{g}$  - 2,4,5-T<2  $\mu\text{g}$  - 2,4-D<0.01  $\mu\text{g}/\text{m}^3$ <14  $\mu\text{g}/\text{m}^3$  - 2,4,5-T<3  $\mu\text{g}/\text{m}^3$  - 2,4-D

CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

RM #3

Sample Number: 2-001

Sampler: D. O'Donnell

Date: 4/11/95

Project: Ft. Drum

Pump Number: 2259

PreCalibration Rate: 2,008 cc/minute

Post Calibration Rate: 2,166 cc/minute

Sample Start Time: 0851

Sample Stop Time: 1450

Sample Run Time: \_\_\_\_\_

Run Time: 359 min Flow Rate: 2.1 L/min Total Volume: 0.754 m<sup>3</sup>

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

\_\_\_\_\_

Sample Results: < 10 µg - 2, 4, 5 - T

< 2 µg - 2, 4 - D

< 13 µg/m<sup>3</sup> - 2, 4, 5 - T

< 3 µg/m<sup>3</sup> 2, 4 - D

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_



162

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

~~RM #3~~  
RM #4Sample Number: 2-003Sampler: D. O'ConnellDate: 4/11/95Project: Ext. DrumPump Number: 1775PreCalibration Rate: 1,994 cc/minutePost Calibration Rate: 2,157 cc/minuteSample Start Time: 0851Sample Stop Time: 1452

Sample Run Time: \_\_\_\_\_

Run Time: 361 min. Flow Rate: 2.1 l/min. Total Volume: 0.758 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

## Perimeter Sample

## Sample Locations:

Sample Results: <10 µg - 2,4,5-T<2 µg - 2,4-D<13 µg/m<sup>3</sup> - 2,4,5-T<3 µg/m<sup>3</sup> - 2,4-D

CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

Rm # 5

Sample Number: 2-002

Sampler: D. O'Donnell

Date: 4/11/95

Project: Ft. Drum

Pump Number: 2066

PreCalibration Rate: 2,008 cc/minute

Post Calibration Rate: 2,089 cc/minute

Sample Start Time: 0852

Sample Stop Time: 1455

Sample Run Time: \_\_\_\_\_

Run Time: 363 min. Flow Rate: 2.0 L/min.

Total Volume: 0.726

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Sample Results: < 10 µg - 2, 4, 5 - T

< 2 µg - 2, 4 - D

< 14 µg/m<sup>3</sup> - 2, 4, 5 - T

< 3 µg/m<sup>3</sup> - 2, 4 - D

CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

RM #1

Sample Number: D004

Sampler: D. O'Donnell

Date: 4/11/95

Project: Ft. Drum

Pump Number: 7397

PreCalibration Rate: 2,007 cc/minute

Post Calibration Rate: 2,173 cc/minute

Sample Start Time: 0850

Sample Stop Time: 1445

Sample Run Time: \_\_\_\_\_

Run Time: 5hr. 55min Flow Rate: 2.1 l/min  
3:55 min

Total Volume: 745.5 l  
0.7455 m<sup>3</sup>

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Sample Results: < 0.01  $\mu\text{g}$

< 0.01  $\mu\text{g}/\text{m}^3$  DDD, DDE, DDT

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

RM #2

Sample Number: D001Sampler: D. O'DonnellDate: 4/11/95Project: Pt. DrumPump Number: 10925PreCalibration Rate: 1,998 cc/minutePost Calibration Rate: 2,140 cc/minuteSample Start Time: 0850Sample Stop Time: 1448

Sample Run Time: \_\_\_\_\_

Run Time: 358 min. Flow Rate: 2.1 L/min. Total Volume: 0.752 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Sample Results: 40.01  $\mu\text{g}/\text{m}^3$ 

## Perimeter Sample

## Sample Locations:

40.01  $\mu\text{g}/\text{m}^3$  for DDD, DDE, and DDT

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

RM # 3

Sample Number: 0003Sampler: D. O'DonnellDate: 4/11/95Project: Ft. DrumPump Number: 1763PreCalibration Rate: 2,005 cc/minutePost Calibration Rate: 2,050 cc/minuteSample Start Time: 0851Sample Stop Time: 1450

Sample Run Time: \_\_\_\_\_

Run Time: 359 min. Flow Rate: 2.0 l/min. Total Volume: 0.718 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Sample Results: < 0.01 ug/m<sup>3</sup>

## Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

## Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

< 0.01 ug/m<sup>3</sup> for BBO, DDT, DDE

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

RM #4

Sample Number: D002Sampler: D. O'DonnellDate: 4/11/95Project: Ft. DrumPump Number: 1766PreCalibration Rate: 2,009 cc/minutePost Calibration Rate: 2,005 cc/minuteSample Start Time: 0951Sample Stop Time: 1452

Sample Run Time: \_\_\_\_\_

Run Time: 361 min Flow Rate: 2.02 l/min Total Volume: 0.722

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

\_\_\_\_\_

Sample Results: < 0.01 ug/l

\_\_\_\_\_

< 0.01 ug/m<sup>3</sup> for DDO, DDE, and DDT

## Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

## Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

RM #5

Sample Number: D005

Sampler: D. O'Sonnell

Date: 4/11/95

Project: Ft. Drum

Pump Number: 05221

PreCalibration Rate: 2,011 cc/minute

Post Calibration Rate: 2,177 cc/minute

Sample Start Time: 0852

Sample Stop Time: 1455

Sample Run Time: \_\_\_\_\_

Run Time: 363

Flow Rate: 2.1 l/min

Total Volume: 0.762

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

\_\_\_\_\_

Sample Results: <0.01 ug

\_\_\_\_\_

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

<0.01 ug/m<sup>3</sup> for ODD, DDE, and DDT

CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

#1

Sample Number: 2-006

Sampler: D. O'Donnell

Date: 4/12/95

Project: Ft. Drum

Pump Number: 1763

PreCalibration Rate: 2,008 cc/minute

Post Calibration Rate: 2,020 cc/minute

Sample Start Time: 0740

Sample Stop Time: 1435

Sample Run Time: \_\_\_\_\_

Run Time: 415 min Flow Rate: 2.0 l/min Total Volume: 0.830 m<sup>3</sup>

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

\_\_\_\_\_

Sample Results: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

<10 µg - 2,4,5-T

<2 µg - 2,4-D

<12 µg/m<sup>3</sup> - 2,4,5-T

<2 µg/m<sup>3</sup> - 2,4-D



CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

#2

Sample Number: 2-010

Sampler: D. O'Donnell

Date: 4/12/95

Project: Ft. Drum

Pump Number: 16203

PreCalibration Rate: 2,023 cc/minute

Post Calibration Rate: 2,042 cc/minute

Sample Start Time: 0742

Sample Stop Time: 1437

Sample Run Time: \_\_\_\_\_

Run Time: 415 min

Flow Rate: 2.0 l/min.

Total Volume: 0.830 m<sup>3</sup>

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

Sample Results: < 10 µg - 2, 4, 5 - T

< 2 µg - 2, 4 - D

< 12 µg/m<sup>3</sup> - 2, 4, 5 - T

< 2 µg/m<sup>3</sup> - 2, 4 - D

180

CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

# 3

Sample Number: 2-007

Sampler: D. O'Donnell

Date: 4/12/95

Project: St. James

Pump Number: 1766

PreCalibration Rate: 2,019 cc/minute

Post Calibration Rate: 2,008 cc/minute

Sample Start Time: 0743

Sample Stop Time: 1438

Sample Run Time: \_\_\_\_\_

Run Time: 415

Flow Rate: 2.0 L/min

Total Volume: 0.830 m<sup>3</sup>

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

Sample Results: < 10 µg/m<sup>3</sup> - 2, 4, 5 - T

< 2 µg - 2, 4 - D

< 12 µg/m<sup>3</sup> - 2, 4, 5 - T

< 2 µg/m<sup>3</sup> - 2, 4 - D

CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

#4

Sample Number: 2-008

Sampler: D. O'Donnell

Date: 4/12/95

Project: Fit Drum

Pump Number: 7397

PreCalibration Rate: 2010 cc/minute

Post Calibration Rate: 2,057 cc/minute

Sample Start Time: 0744

Sample Stop Time: 1439

Sample Run Time: \_\_\_\_\_

Run Time: 415

Flow Rate: 2.02/min.

Total Volume: .830 m<sup>3</sup>

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

\_\_\_\_\_

Sample Results: \_\_\_\_\_

\_\_\_\_\_

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

< 10 µg - 2, 4, 5 - T

< 2 µg - 2, 4 - D

< 12 µg/m<sup>3</sup> - 2, 4, 5 - T

< 2 µg/m<sup>3</sup> - 2, 4 - D

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

#5

Sample Number: 2-009Sampler: J. O'DonnellDate: 4/12/95Project: St. DrumPump Number: 7396PreCalibration Rate: 2,026 cc/minutePost Calibration Rate: 2,121 cc/minuteSample Start Time: 0745Sample Stop Time: 1440

Sample Run Time: \_\_\_\_\_

Run Time: 415Flow Rate: 2.1Total Volume: 0.871

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

## Perimeter Sample

## Sample Locations:

Sample Results: <10 ug - 2,4,5-T<2 ug - 2,4-D<11 ug/m<sup>3</sup> - 2,4,5-T<2 ug/m<sup>3</sup> - 2,4-D

CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

#1

Sample Number: D008

Sampler: D.O. Sonnell

Date: 4/12/95

Project: XX. Drum

Pump Number: 10925

PreCalibration Rate: 2,018 cc/minute

Post Calibration Rate: 2,053 cc/minute

Sample Start Time: 0740

Sample Stop Time: 1435

Sample Run Time: \_\_\_\_\_

Run Time: 415 min. Flow Rate: 2.02/min.

Total Volume: 0.830

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

\_\_\_\_\_

Sample Results: <0.01 ug

\_\_\_\_\_

<0.01 ug/m<sup>3</sup> for DDB, DDE, DDT

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

#2

Sample Number: D010Sampler: D. O'DonnellDate: 4/12/95Project: Ft. DrumPump Number: 05221PreCalibration Rate: 2,008 cc/minutePost Calibration Rate: 2,023 cc/minuteSample Start Time: 0742Sample Stop Time: 1437

Sample Run Time: \_\_\_\_\_

Run Time: 415 min. Flow Rate: 2.0 l/min. Total Volume: 0.830 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

\_\_\_\_\_

Sample Results: LO.01 ug

\_\_\_\_\_

LO.01 ug/m<sup>3</sup> for DDD, DDE, and DDT

## Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

## Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

# 3

Sample Number: D009

Sampler: D. O'Donnell

Date: 4/12/95

Project: Fit. Drum

Pump Number: 2066

PreCalibration Rate: 2,015 cc/minute

Post Calibration Rate: 2,031 cc/minute

Sample Start Time: 0743

Sample Stop Time: 1438

Sample Run Time: \_\_\_\_\_

Run Time: 415 min Flow Rate: 2.0 L/min

Total Volume: 0.830 m<sup>3</sup>

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Sample Results: 40.01  $\mu\text{g}$

Perimeter Sample

Sample Locations:

< 0.01  $\mu\text{g}/\text{m}^3$  for DDB, DDB<sub>2</sub>, and DDT

## CDM FEDERAL PROGRAMS CORPORATION

#4

## AIR MONITORING DATA SHEET

Sample Number: D006Sampler: D. O'DonnellDate: 4/12/95Project: Ft. DrumPump Number: 2259PreCalibration Rate: 2,012 cc/minutePost Calibration Rate: 2,090 cc/minuteSample Start Time: 0744Sample Stop Time: 1439

Sample Run Time: \_\_\_\_\_

Run Time: 415 min. Flow Rate: 2.0Total Volume: 0.830 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Sample Results: <0.01

## Perimeter Sample

## Sample Locations:

<0.01 ug/m<sup>3</sup> for DDB, DDB, and DBT



## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

#5

Sample Number: D007Sampler: D. O'DonnellDate: 4/12/95Project: Ext. DrumPump Number: 1775PreCalibration Rate: 2,007 cc/minutePost Calibration Rate: 2,072 cc/minuteSample Start Time: 0745Sample Stop Time: 1440

Sample Run Time: \_\_\_\_\_

Run Time: 415 min Flow Rate: 2.0 l/min Total Volume: 0.830 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Sample Results: <0.01

## Perimeter Sample

## Sample Locations:

<0.01 µg/m<sup>3</sup> DDD, DDE, DDT

CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

Sample Number: 2-011

Sampler: D. O'Donnell

Date: 4/12/95

Project: Ext. Drum

Pump Number: N/A

PreCalibration Rate: N/A cc/minute

Post Calibration Rate: \_\_\_\_\_ cc/minute

Sample Start Time: N/A

Sample Stop Time: \_\_\_\_\_

Sample Run Time: \_\_\_\_\_

Run Time: \_\_\_\_\_

Flow Rate: \_\_\_\_\_

Total Volume: \_\_\_\_\_

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

\_\_\_\_\_

Sample Results: <10 µg - 2,4,5-T

<2 µg - 2,4-D

<10 µg/m<sup>3</sup> - 2,4,5-T

<2 µg/m<sup>3</sup> - 2,4-D

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

RM #1

Sample Number: 2-016

Sampler: D. O'Donnell

Date: 4/13/95

Project: Ext. Drum

Pump Number: 1836

PreCalibration Rate: 2,005 cc/minute

Post Calibration Rate: 2,012 cc/minute

Sample Start Time: 0800

Sample Stop Time: 1427

Sample Run Time: \_\_\_\_\_

Run Time: 387 min. Flow Rate: 2.02 l/min. Total Volume: 0.774 m<sup>3</sup>

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Sample Results: < 10 µg - 2, 4, 5-T

< 2 µg - 2, 4-D

< 15 µg/m<sup>3</sup> - 2, 4, 5-T

< 3 µg/m<sup>3</sup> 2, 4-D

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

RM#2

Sample Number: 2-013Sampler: D. O'DonnellDate: 4/13/95Project: Fit. DrumPump Number: 04114PreCalibration Rate: 2,011 cc/minutePost Calibration Rate: 2,096 cc/minuteSample Start Time: 0801Sample Stop Time: 1425

Sample Run Time: \_\_\_\_\_

Run Time: 384 min. Flow Rate: 2.0 l/min. Total Volume: 0.768 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

## Perimeter Sample

## Sample Locations:

Sample Results: <10 µg - 2,4,5 - T<2 µg - 2,4 - D<13 µg/l<sup>3</sup> - 2,4,5 - T<3 µg/l<sup>3</sup> - 2,4 - D

CDM FEDERAL PROGRAMS CORPORATION  
AIR MONITORING DATA SHEET

#3

Sample Number: 2-012

Sampler: D. O'Donnell

Date: 4/13/95

Project: Fit. Dunn

Pump Number: 7397

PreCalibration Rate: 2,014 cc/minute

Post Calibration Rate: 2,086 cc/minute

Sample Start Time: 0804

Sample Stop Time: 1425

Sample Run Time: \_\_\_\_\_

Run Time: 381 min.

Flow Rate: 2.0 l/min.

Total Volume: 0.762

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Perimeter Sample

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Sample Locations:

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Sample Results: <10 µg - 2,4,5-T

<2 µg - 2,4-D

<13 µg/m<sup>3</sup> - 2,4,5-T

<3 µg/m<sup>3</sup> - 2,4-D

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

#4

Sample Number: 2-015Sampler: D. O'SonnellDate: 4/13/95Project: Fit. DrumPump Number: 1775PreCalibration Rate: 2,057 cc/minutePost Calibration Rate: 2,098 cc/minuteSample Start Time: 0810Sample Stop Time: 1421

Sample Run Time: \_\_\_\_\_

Run Time: 371 min.Flow Rate: 2.1 lpm.Total Volume: 0.779

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

## Perimeter Sample

## Sample Locations:

Sample Results: <10 µg - 2,4,5-T<2 µg - 2,4-D<13 µg/m<sup>3</sup> - 2,4,5-T<3 µg/m<sup>3</sup> - 2,4-D

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

#5

Sample Number: 2-014Sampler: D. O'SullivanDate: 4/13/95Project: St. DrumPump Number: 2066PreCalibration Rate: 2,008 cc/minutePost Calibration Rate: 2,062 cc/minuteSample Start Time: 0811Sample Stop Time: 1420

Sample Run Time: \_\_\_\_\_

Run Time: 369 min.Flow Rate: 2.0 lpmTotal Volume: 0.738

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

## Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

## Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Sample Results: 210 µg - 2,4,5-T22 µg - 2,4-D214 µg/m<sup>3</sup> - 2,4,5-T23 µg/m<sup>3</sup> - 2,4-D

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

Sample Number: D011Sampler: D. O. JonnellDate: 4/12/95Project: Ft. DrumPump Number: N/APreCalibration Rate: N/A cc/minute

Post Calibration Rate: \_\_\_\_\_ cc/minute

Sample Start Time: N/A

Sample Stop Time: \_\_\_\_\_

Sample Run Time: \_\_\_\_\_

Run Time: \_\_\_\_\_ Flow Rate: \_\_\_\_\_

Total Volume: \_\_\_\_\_

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

## Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

## Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Sample Results: < 0.01  $\mu\text{g}$



CDM FEDERAL PROGRAMS CORPORATION

AIR MONITORING DATA SHEET

#1

Sample Number: D013

Sampler: D. O'Sonnell

Date: 4/13/95

Project: Fix. Drum

Pump Number: 1766

PreCalibration Rate: 2,006 cc/minute

Post Calibration Rate: 2,001 cc/minute

Sample Start Time: 0800

Sample Stop Time: 1427

Sample Run Time: \_\_\_\_\_

Run Time: 387 min. Flow Rate: 2.02 l/min. Total Volume: 0.774 m<sup>3</sup>

Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: tv

Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Sample Results: <0.01  $\mu\text{g}$

<0.01  $\mu\text{g}/\text{m}^3$  for DDD, DDE, and DDT

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

# 2

Sample Number: 5012Sampler: D. O. DonnellDate: 4/13/95Project: FA. DrumPump Number: 1763PreCalibration Rate: 2,006 cc/minutePost Calibration Rate: 2,029 cc/minuteSample Start Time: 0801Sample Stop Time: 1425

Sample Run Time: \_\_\_\_\_

Run Time: 384 min. Flow Rate: 2.0 l/min Total Volume: 0.768 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Sample Results: 40.01  $\mu\text{g}$ 

## Perimeter Sample

## Sample Locations:

< 0.01  $\mu\text{g}/\text{m}^3$  for DDD, DDE, and DDT

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

#3

Sample Number: D016Sampler: A. O'DonnellDate: 4/13/95Project: Fit. DrumPump Number: 10925PreCalibration Rate: 2,032 cc/minutePost Calibration Rate: 2,141 cc/minuteSample Start Time: 0804Sample Stop Time: 1426

Sample Run Time: \_\_\_\_\_

Run Time: 381 Flow Rate: 2.1 L/min Total Volume: 0.800 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Sample Results: <0.01 ug

\_\_\_\_\_

\_\_\_\_\_

<0.01 ug/m<sup>3</sup> for DDD, DDE, DDT

## Perimeter Sample

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

## Sample Locations:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

#4

Sample Number: D014Sampler: D. O'DonnellDate: 4/13/95Project: It. DrumPump Number: 05221PreCalibration Rate: 2,007 cc/minutePost Calibration Rate: 2,062 cc/minuteSample Start Time: 0810Sample Stop Time: 1421

Sample Run Time: \_\_\_\_\_

Run Time: 371 min. Flow Rate: 2.0 l/min. Total Volume: 0.742 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Sample Results: 40.01

## Perimeter Sample

## Sample Locations:

<0.01  $\mu\text{g}/\text{m}^3$  for DDD, DDE, and DDT

## CDM FEDERAL PROGRAMS CORPORATION

## AIR MONITORING DATA SHEET

Sample Number: 6015Date: 4/13/95Pump Number: 16203PreCalibration Rate: 2,076 cc/minutePost Calibration Rate: 2,075 cc/minuteSample Start Time: 0811Sample Stop Time: 1420

Sample Run Time: \_\_\_\_\_

Run Time: 369 min Flow Rate: 2.12/min Total Volume: 0.775 m<sup>3</sup>

## Personal Sample

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Social Security No: \_\_\_\_\_

Phone Number: \_\_\_\_\_

Activity: \_\_\_\_\_

Sample Results: < 0.01  $\mu\text{g}$ 

## Perimeter Sample

## Sample Locations:

< 0.01  $\mu\text{g}/\text{m}^3$  DDD, DDE, and DDT