APPENDIX D QUALITY ASSURANCE/QUALITY CONTROL

CALIBRATION PROCEDURES AND RESULTS

All of the equipment used is calibrated in accordance with the procedures outlined in the *Quality Assurance Handbook for Air Pollution Measurement Systems, Volume III (EPA-600/4-77-027b)*. The following pages describe these procedures and include the data sheets.

DRY GAS METER AND ORIFICE METER

Dry gas meters and orifices are calibrated in accordance with Section 3.3.2 of the QA Handbook. This procedure involves direct comparison of the dry gas meter to a reference dry test meter. The reference dry test meter is routinely calibrated using a liquid displacement technique. Before its initial use in the field, the metering system is calibrated over the entire range of operation. After each field use, the metering system is calibrated at a single intermediate setting based on the previous field test. Acceptable tolerances for the initial and final gas meter factors and orifice calibration factors are Y ± 0.02 and $\Delta H \pm 0.015$ from average, respectively.

Box No.:	2	Bar, Press.(Pb):		29.87	in. Hg			
Date:	December 29, 2015	Calibrated By:		BF				
		RUN 1	RUN 2	RUN 3	RUN 4	RUN 5	RUN 6	
DH	Delta H	0.50	0.75	1.00	1.50	2.00	4.00	
in Hg	Vacuum	10	10	10	10	10	10	
$Vw_{\rm I}$	Initial RTM	135,096	146.103	159.132	173.657	190.840	210.929	
Vw_2	Final RTM	145.783	158.926	173.445	190.537	210.472	238.321	
Vd_1	Initial DGM	294.981	305,983	319.065	333.718	351.136	371.614	
Vd_2	Final DGM	305,670	318.853	333,495	350.842	371.150	399.604	
Tw	Ave. Temp RTM °F	67	67	67	67	69	68	
Td	Ave. Temp DGM °F	68	74	79	82	85	89	
t	Time (min.)	25.0	25.0	25.0	25.0	25.0	25,0	
Vw ₂ - Vw ₁	Net Volume RTM	10.687	12.823	14.313	16.880	19.632	27.392	
Vd ₂ - Vd ₁	Net Volume DGM	10.689	12.870	14,430	17.124	20,014	27.990	
	Y	1.001	1.008	1.011	1,009	1.006	1.007	
	dH@	1.524	1.572	1.670	1.791	1.766	1.797	
AVERAGE Y =	1.005	(Reference meter	correction	factor of 0.9979)				
Average Y R	ange =		0.985	TO	1.025	ACC	CEPT	
AVERAGE dH@	= 1.687							
Average dF	Average dH@ Range =			то	1.887	ACC	СЕРТ	
Calculations								
	$Y = (V_W * Pb * (Td + 460)) / (Vd * (Pb + (dHd / 13.6)) * (Tw + 460))$							
$dH@=0.0317*dHd/(Pb(Td+460))*(((Tw+460)*t)/Vw)^2$								

Meter Box:	2	Bar. Press.(Pb):	30.20	in. Hg
Date:	September 21, 2016	Pretest Gamma:	1.005	
Calibrated By	: BF	Pretest dH@:	1.687	
Plant:	AK Middletown ICR			
in A		RUN 1	RUN 2	RUN 3
DH	Delta H	1.70	1.70	1.70
in Hg	Vacuum	10.00	10.00	10.00
Vw_1	Initial RTM	815.108	834.195	851.095
Vw_2	Final RTM	834.195	851.095	869.481
Vd_1	Initial DGM	92.059	111.184	128.072
Vd_2	Final DGM	111.184	128.072	146.353
Tw	Ave, Temp RTM °F	77.5	82.0	84.0
Td	Ave. Temp DGM °F	68.5	70.5	72.0
t	Time (min.)	26.5	23.5	25.5
Vw ₂ - Vw ₁	Net Volume RTM	19.087	16.900	18.386
Vd ₂ - Vd ₁	Net Volume DGM	19.125	16.888	18.281
	Y	0.977	0.975	0.980
	dH@	1.880	1.911	1.909
AVERAGE Y	<i>'</i> =	0.975		

% Difference from Yearly Y = -2.950

ACCEPT

AVERAGE dH@ = 1.900

Calculations

Y = (Vw * Pb * (Td + 460)) / (Vd * (Pb + (dHd / 13.6)) * (Tw + 460))

 $dH@=0.0317*dHd/(Pb(Td+460))*(((Tw+460)*time)/Vw)^2$

Box No.:	3 01/26/2016	Bar, Press.(Pb): Calibrated By:		29.99 BF	in. Hg				
Date.	01/20/2010	Cantilated By .		Бľ					
		E RUN 1	RUN 2	RUN 3	RUN 4	RUN 5	RUN 6		
DH	Delta H	0.50	0.75	1.00	1.50	2.00	4.00		
in Hg	Vacuum	10	10	10	10	10	10		
Vw_1	Initial RTM	444.013	454.677	467.904	484.045	504.465	522.160		
Vw ₂	Final RTM	454.474	467.699	483,885	504.250	521.906	549.310		
Vd_1	Initial DGM	341.794	352,359	365.433	381.412	401.652	419,242		
Vd_2	Final DGM	352.148	365.236	381.250	401.453	418.989	446.270		
Tw	Ave. Temp RTM °F	68	71	74	75	75	75		
Τđ	Ave. Temp DGM °F	67	72	76	79	82	84		
t	Time (min.)	27.0	27.0	29.0	30,5	23.0	25.5		
					76				
Vw ₂ - Vw ₁	Net Volume RTM	10.461	13.022	15.981	20.205	17.441	27,150		
Vd ₂ - Vd ₁	Net Volume DGM	10,354	12.877	15.817	20.041	17.337	27.028		
	Y	1.007	1.011	1.013	1,013	1.013	1,011		
	dH@	1.862	1.806	1.848	1.915	1,943	1.964		
AVERAGE Y =	1.009	(Reference meter	correction fa	actor of 0.9979)					
Average Y Ra	ange =		0.989	то	1.029	ACC	СЕРТ		
AVERAGE dH@	= 1.890								
Average dH	I@ Range =		1.690	TO	2.090	ACC	СЕРТ		
			alculations				****		
	Y = (Vw * Pb * (Td + 460)) / (Vd * (Pb + (dHd / 13.6)) * (Tw + 460))								
	$dH@ = 0.0317 * dHd / (Pb (Td + 460)) * (((Tw + 460) * t) / Vw)^2$								

Meter Box:	3	Bar. Press.(Pb):	30.13	in. Hg
Date:	September 20, 2016	Pretest Gamma:	1.009	
Calibrated By:	BF	Pretest dH@:	1.890	
Plant:	AK Middletown ICR			
		RUN 1	RUN 2	RUN 3
DH	Delta H	1.90	1.90	1.90
in Hg	Vacuum	10.00	10.00	10.00
Vw_1	Initial RTM	832.289	852.041	869.534
Vw ₂	Final RTM	852.041	869.534	897.428
Vd_1	Initial DGM	429.134	448.755	466.176
Vd_2	Final DGM	448.755	466.176	494.087
Tw	Ave. Temp RTM °F	72.0	74.5	75.5
Td	Ave. Temp DGM °F	75.0	72.5	87.0
t	Time (min.)	26.5	23.5	37.5
Vw ₂ - Vw ₁	Net Volume RTM	19.752	17,493	27.894
Vd ₂ - Vd ₁	Net Volume DGM	19.621	17.421	27.911
	Y	1.008	0.996	1.016
	dH@	1.903	1.936	1.894

AVERAGE Y = 1.004

% Difference from Yearly Y = -0.455 ACCEPT

AVERAGE dH@= 1.911

Calculations

Y = (Vw * Pb * (Td + 460)) / (Vd * (Pb + (dHd / 13.6)) * (Tw + 460))

 $dH@ = 0.0317 * dHd / (Pb (Td + 460)) * (((Tw + 460) * time) / Vw)^2$

Box No.:	5	Bar. Press.(Pb):		30.24	in. Hg			
Date:	01/08/2016	Calibrated By:		BF				
		RUN 1	RUN 2	RUN 3	RUN 4	RUN 5	RUN 6	
DH	Delta H	0.50	0.75	1.00	1,50	2,00	4.00	
in Hg	Vacuum	10	10	10	10	10	10	
Vw_1	Initial RTM	754.542	764.887	777.082	790.827	807.485	826.087	
Vw_2	Final RTM	764.648	776.828	790.660	807.269	825.798	852.168	
Vd_1	Initial DGM	84.754	95.104	107,365	121.218	138,041	156.874	
Vd ₂	Final DGM	94.868	107.112	121.044	137.830	156.592	183.282	
Tw	Ave. Temp RTM °F	67	67	67	67	66	68	
Tď	Ave. Temp DGM °F	66	69	70	71	73	75	
t	Time (min.)	26,0	25,0	25.0	25,0	25.0	25.0	
		9 m						
Vw ₂ - Vw ₁	Net Volume RTM	10.106	11.941	13.578	16.442	18.313	26.081	
Vd ₂ - Vd ₁	Net Volume DGM	10.114	12.008	13.679	16.612	18.551	26.408	
	Y	0.996	0.995	0.997	0.994	0.995	0.991	
	dH@	1.830	1.811	1.859	1.901	2.030	2.006	
AVERAGE Y =	0.993	(Reference meter	correction fa	actor of 0.9979)				
Average Y Ra	ange =		0.973	то	1.013	ACC	серт	
AVERAGE dH@	= 1.906							
Average dH	@ Range =		1.706	то	2.106	ACC	серт	
	Calculations							
	Y = (Vw * Pb * (Td + 460)) / (Vd * (Pb + (dHd / 13.6)) * (Tw + 460))							
	dH@ = 0.0317 * dHd / (Pb (Td + 460)) * (((Tw +460) * t) / Vw)^2							

Meter Box:	5	Bar. Press.(Pb):	30.13	in. Hg
Date:	September 20,2016	Pretest Gamma:	0.993	
Calibrated By	: BF	Pretest dH@:	1.906	
Plant:	AK Middletown ICR			
		RUN 1	RUN 2	RUN 3
DH	Delta H	1.90	1.90	1.90
in Hg	Vacuum	10.00	10.00	10.00
Vw_1	Initial RTM	443.490	463.586	480.387
Vw_2	Final RTM	463.586	480.387	494.716
Vd_i	Initial DGM	984.057	1004.092	1020.765
Vd_2	Final DGM	1004.092	1020.765	1034.870
Tw	Ave, Temp RTM °F	75.0	81.5	86.0
Td	Ave. Temp DGM °F	71.0	73.5	74.5
t	Time (min.)	27.5	23.0	19.5
Vw ₂ - Vw ₁	Net Volume RTM	20.096	16.801	14.329
Vd ₂ - Vd ₁	Net Volume DGM	20.035	16.673	14.105
	Y	0.991	0.988	0.990
	dH@	2.018	2.059	2.065

AVERAGE Y = 0.988

% Difference from Yearly Y = -0.543

ACCEPT

AVERAGE dH@ = 2.047

Calculations

Y = (Vw * Pb * (Td + 460)) / (Vd * (Pb + (dHd / 13.6)) * (Tw + 460))

 $dH@=0.0317*dHd/(Pb(Td+460))*(((Tw+460)*time)/Vw)^2$

Box No.:	11	Bar. Press.(Pb):		30.22	in. Hg			
Date:	December 30, 2015	Calibrated By:		BF				
		RUN 1	RUN 2	RUN 3	RUN 4	RUN 5	RUN 6	
DH	Delta H	0.50	0.75	1.00	1.50	2.00	4.00	
in Hg	Vacuum	10	10	10	10	10	10	
Vw_1	Initial RTM	540.469	550.679	563.459	578.412	596.004	615.600	
Vw ₂	Final RTM	550.527	562.897	578.163	595.867	615.156	642.405	
Vd_1	Initial DGM	278.965	289.097	301.826	316.756	334.403	354.130	
Vd_2	Final DGM	288.949	301.255	316,510	334.265	353.690	381.159	
Tw	Ave. Temp RTM °F	69	69	69	69	69	70	
Td	Ave. Temp DGM °F	69	73	78	81	83	86	
t	Time (min.)	25.0	25.0	26.5	26.0	25.0	25.0	
					- Francisco			
Vw ₂ - Vw ₁	Net Volume RTM	10.058	12,218	14.704	17.455	19.152	26,805	
Vd ₂ - Vd ₁	Net Volume DGM	9.984	12.158	14.684	17.509	19.287	27.029	
	Y	1.005	1,011	1.016	1.016	1.013	1.012	
	dH@	1.716	1.729	1.772	1.806	1.844	1.876	
AVERAGE Y =	1.010	(Reference meter	correction f	actor of 0.9979)				
Average Y Ra	ange =		0.990	ТО	1,030	ACC	ЕРТ	
AVERAGE dH@	= 1.791							
Average dH	@ Range =		1.591	ТО	1.991	ACC	серт	
Calculations								
	Y = (Vw * Pb * (Td + 460)) / (Vd * (Pb + (dHd / 13.6)) * (Tw +460)) dH@ = 0.0317 * dHd / (Pb (Td + 460)) * (((Tw +460) * t) / Vw)^2							
	dH@ — 0.0317 * dHd / (Рб (1d + 460)) * (((1w +460) * t) / Vw) * 2							

Meter Box:	11	Bar. Press.(Pb):	30.20	in. Hg
Date:	September 21, 2016	Pretest Gamma:	1.010	
Calibrated By	: BF	Pretest dH@:	1.791	
Plant:	Ak Middletown ICR			
		RUN 1	RUN 2	RUN 3
DH	Delta H	1.80	1.80	1.80
in Hg	Vacuum	10.00	10.00	10.00
Vw_1	Initial RTM	626.676	644.902	661.703
Vw ₂	Final RTM	644.902	661.703	688,444
Vd_I	Initial DGM	147.153	165.469	182.282
Vd_2	Final DGM	165.469	182,282	208.942
Tw	Ave. Temp RTM °F	75.0	81.5	86.0
Td	Ave. Temp DGM °F	71.5	73.0	74.5
t	Time (min.)	25.0	23.0	36.5
$Vw_2 - Vw_1$	Net Volume RTM	18.226	16.801	26.741
Vd ₂ - Vd ₁	Net Volume DGM	18.316	16.813	26.660
	Y	0.984	0.979	0.978
	dH@	1.914	1.948	1.963
AVERAGE Y =		0.978		
% Difference from Yearly Y =		-3.135	AC	СЕРТ

Calculations

AVERAGE dH@=

Y = (Vw * Pb * (Td + 460)) / (Vd * (Pb + (dHd / 13.6)) * (Tw + 460))

1.942

 $dH@=0.0317*dHd/(Pb(Td+460))*(((Tw+460)*time)/Vw)^2\\$

Box No.:	13	Bar. Press.(Pb):		30.22	in, Hg			
Date:	12/30/2015	Calibrated By:		NP/EZ				
		RUN 1	RUN 2	RUN 3	RUN 4	RUN 5	RUN 6	
DH	Delta H	0.50	0.75	1.00	1.50	2.00	4.00	
in Hg	Vacuum	10	10	10	10	10	10	
Vw_1	Initial RTM	642,983	652.972	666.164	680.190	698.497	718.536	
Vw ₂	Final RTM	652.972	665.432	680.190	697.497	717.788	746.718	
Vd_1	Initial DGM	4.031	14.014	27.228	41.318	59.876	80.121	
Vd_2	Final DGM	14.014	26,493	41.318	58.876	79.362	108.770	
Tw	Ave. Temp RTM °F	70	69	74	77	70	70	
Td	Ave. Temp DGM °F	66	69	74	70	78	81	
t	Time (min.)	25.0	25.0	25,0	26.0	25.0	25.0	
				10 m 1 m 1 m 1 m 1 m 1 m 1 m 1 m 1 m 1 m				
Vw ₂ - Vw _I	Net Volume RTM	9.989	12,460	14.026	17.307	19.291	28.182	
Vd ₂ - Vd ₁	Net Volume DGM	9.983	12.479	14.090	17.558	19.486	28.649	
	Y	0.992	0.997	0.993	0.969	1.000	0.994	
	dH@	1.754	1.675	1.780	1.932	1.840	1.714	
AVERAGE Y =	0.989	(Reference meter	correction f	actor of 0.9979)				
Average Y Ra	ange =		0.969	ТО	1.009	ACC	CEPT	
AVERAGE dH@	= 1.783							
Average dH		1,583	TO	1.983	ACC	CEPT		
Calculations								
Y = (Vw * Pb * (Td + 460)) / (Vd * (Pb + (dHd / 13.6)) * (Tw + 460))								
	$dH@=0.0317*dHd/(Pb(Td+460))*(((Tw+460)*t)/Vw)^2$							

Meter Box:	13	Bar. Press.(Pb):	30.13	in. Hg
Date:	September 20, 2016	Pretest Gamma:	0.989	
Calibrated By	; BF	Pretest dH@:	1.783	
Plant:	AK Middletown ICR			
		RUN 1	RUN 2	RUN 3
DH	Delta H	1.80	1.80	1.80
in Hg	Vacuum	10.00	10.00	10.00
Vw_1	Initial RTM	799.662	814.322	833.764
Vw_2	Final RTM	814.322	833.764	853.297
Vd_1	Initial DGM	35.806	50.501	69.887
Vd_2	Final DGM	50.501	69.887	89.235
Tw	Ave. Temp RTM °F	63.5	81.5	86.5
Td	Ave. Temp DGM °F	72.5	75.0	75.5
t	Time (min.)	20.0	26.5	26.5
Vw ₂ - Vw ₁	Net Volume RTM	14.660	19,442	19.533
Vd ₂ - Vd ₁	Net Volume DGM	14.695	19.386	19.348
	Y	1.010	0.987	0.985
	dH@	1.814	1.928	1.944
AVEDAGEV	_	0 992		

AVERAGE Y = **0.992**

% Difference from Yearly Y = 0.287

ACCEPT

AVERAGE dH@=

1.895

Calculations

Y = (Vw * Pb * (Td + 460)) / (Vd * (Pb + (dHd / 13.6)) * (Tw + 460))

 $dH@ = 0.0317 * dHd / (Pb (Td + 460)) * (((Tw + 460) * time) / Vw)^2$

Date:

Vost Box Number:

9/23/2016

VB-1

Flow Rate:

1.0 l/min

Rotameter Setting:

1.0 l/min

70

		Run 1	
Bubbl	e Meter	Meter Box	
1	1018.3	Initial Volume	7865.00
2	1017.90	Final Volume	7886.38
3	1017.8	Initial Temp.	69
4	1017	Final Temp.	75
5	1018.5	Average Temp.	72
6	1020.2	Time:	20
7	1019.2	QDGM=	1064.981
Average:	1018.41	Υ=	0.9563

		Run 2	·
Bubbl	e Meter	Meter Box	
1	1011.70	Initial Volume	7886.38
2	1009.90	Final Volume	7907.72
3	1008.2	Initial Temp.	75
4	1007.3	Final Temp.	79
5	1006.9	Average Temp.	77
6	1006.8	Time:	20
7	1005.4	QDGM=	1053.091
Average:	1008.03	Y=	0.9572

		Run 3	
Bubble Meter Meter Box			
1	1009.40	Initial Volume	7907.72
2	1008.40	Final Volume	7929.23
3	1007.10	Initial Temp.	79
4	1006.40	Final Temp.	81
5	1007.00	Average Temp.	80
6	1005.60	Time:	20
7	1004.70	QDGM=	1055,583
Average:	1006.94	Y=	0.9539

QDGM = $(((Vm_2 - Vm_1) * TBm^{\circ}R) / (Tm^{\circ}R * Time)) * 1000$

Y = Bm Average / QDGM

Average Y=

0.9558

Date:

9/23/2016

Flow Rate:

1.0 l/min

Vost Box Number:

VB-2

Rotameter Setting:

1.0 l/min

Bubble Meter Temp.:

70

		Run 1	
Bubble	Meter	Meter Box	
1	949.9	Initial Volume	4935.50
2	949.9	Final Volume	4954.40
3	972.9	Initial Temp.	75
4	971.7	Final Temp.	77
5	980.1	Average Temp.	76
6	979.1	Time:	21
7	950.5	QDGM=	889.925
Average:	964.87	Y==	1.0842

		Run 2	
Bubbl	e Meter	Meter Box	
1	1008.6	Initial Volume	4954.40
2	1009.9	Final Volume	4975.10
3	1009.8	Initial Temp.	77
4	1003	Final Temp.	80
5	1004.5	Average Temp.	78.5
6	1006.6	Time:	22
7	1003.2	QDGM=	926.057
Average:	1006.51	Y=	1.0869

		Run 3	
Bubbl	e Meter	Meter Box	
1	1028.50	Initial Volume	4975.10
2	1029.70	Final Volume	4996.41
3	1030.00	Initial Temp.	80
4	1029.70	Final Temp.	81
5	1029.80	Average Temp.	80.5
6	1030.20	Time:	22
7	1028.90	QDGM=	949.819
Average:	1029.54	Y=	1.0839

QDGM = $(((Vm_2 - Vm_1) * TBm^{\circ}R) / (Tm^{\circ}R * Time)) * 1000$

Y = Bm Average / QDGM

Average Y=

1.0850

DIGITAL INDICATORS FOR THERMOCOUPLE READOUT

A digital indicator is calibrated by feeding a series of millivolt signals to the input and comparing the indicator reading with the reading the signal should have generated. Errors did not exceed 0.5 percent when the temperatures were expressed in degrees Rankine. Calibration data are included in the following Thermocouple Digital Indicator Calibration Data Sheet(s).

THERMOCOUPLE DIGITAL INDICATOR CALIBRATION DATA SHEET

DATE: 2	28-Dec-15	INDICATOR NO.:	MB-2	
OPERATOR:	BF	SERIAL NO.:	10285505	
CALIBRATION D	EVI Thermocouple Simulator	MANUFACTURER:	Omega	

TEST POINT NO.	MILLIVOLT SIGINAL	EQUIVALEN T TEMP, °F	DIGITAL INDICATOR TEMP READING, °F	DIFFERENCE, %
1	0	0	0	0.0
2	100	100	98	0.4
3	200	200	200	0.0
4	300	300	300	0.0
5	400	400	397	0.3
6	500	500	497	0.3
7	1000	1000	1001	0.1
8	1300	1300	1300	0.0
9	1600	1600	1601	0.0
10	1900	1900	1901	0.0

Percent difference must be less than or equal to 0.5 %

Percent difference: (Equivalent Temp, °R - Digital Indicator Temp., °R) * (100%)

(Equivalent Temp., °R)

Where ${}^{\circ}R = {}^{\circ}F + 460$

THERMOCOUPLE DIGITAL INDICATOR CALIBRATION DATA SHEET

DATE:	23-Dec-15	INDICATOR NO.:	MB-3	
OPERATOR:	BF	SERIAL NO.:	10285505	
CALIBRATION I	DEVI Thermocouple Simulator	MANUFACTURER:	Omega	

TEST POINT NO.	MILLIVOLT SIGINAL	EQUIVALEN T TEMP, °F	DIGITAL INDICATOR TEMP READING, °F	DIFFERENCE, %
1	0	0	0	0.0
2	100	100	98	0.4
3	200	200	201	0.2
4	300	300	300	0.0
5	400	400	397	0.3
6	500	500	498	0.2
7	1000	1000	1003	0.2
8	1300	1300	1303	0.2
9	1600	1600	1604	0.2
10	1900	1900	1904	0.2

Percent difference must be less than or equal to 0.5 %

Percent difference: (Equivalent Temp,. °R - Digital Indicator Temp., °R) * (100%)

(Equivalent Temp., °R)

Where ${}^{\circ}R = {}^{\circ}F + 460$

THERMOCOUPLE DIGITAL INDICATOR CALIBRATION DATA SHEET

DATE: 28-Dec	-15	INDICATOR NO.:	MB5	
OPERATOR:	СЈ	SERIAL NO.:	10285505	
CALIBRATION DEVI T	hermocouple Simulator	MANUFACTURER:	Omega	

TEST POINT NO.	MILLIVOLT SIGINAL	EQUIVALEN T TEMP, °F	DIGITAL INDICATOR TEMP READING, °F	DIFFERENCE, %
1	0	0	-1	0.2
2	100	100	98	0.4
3	200	200	200	0.0
4	300	300	299	0.1
5	400	400	396	0.5
6	500	500	496	0.4
7	1000	1000	1000	0.0
8	1300	1300	1299	0.1
9	1600	1600	1599	0.0
10	1900	1900	1899	0.0

Percent difference must be less than or equal to $0.5\ \%$

Percent difference: (Equivalent Temp,.°R - Digital Indicator Temp., °R) * (100%)

(Equivalent Temp., °R)

Where ${}^{\circ}R = {}^{\circ}F + 460$

THERMOCOUPLE DIGITAL INDICATOR CALIBRATION DATA SHEET

DATE:	28-Dec-15	INDICATOR NO.:	MB11	
OPERATOR:	СЈ	SERIAL NO.:	10285505	
CALIBRATION	DEVI Thermocouple Simulator	MANUFACTURER:	Omega	

TEST POINT NO.	MILLIVOLT SIGINAL	EQUIVALEN T TEMP, °F	DIGITAL INDICATOR TEMP READING, °F	DIFFERENCE, %
I	0	0	0	0.0
2	100	100	98	0.4
3	200	200	201	0.2
4	300	300	300	0.0
5	400	400	398	0.2
6	500	500	497	0.3
7	1000	1000	1003	0.2
8	1300	1300	1302	0.1
9	1600	1600	1604	0.2
10	1900	1900	1903	0.1

Percent difference must be less than or equal to 0.5 %

Percent difference: (Equivalent Temp, °R - Digital Indicator Temp., °R) * (100%)

(Equivalent Temp, °R)

Where ${}^{o}R = {}^{o}F + 460$

THERMOCOUPLE DIGITAL INDICATOR CALIBRATION DATA SHEET

DATE: 2	8-Dec-15	INDICATOR NO.:	MB13	
OPERATOR:	CJ	SERIAL NO.:	10285505	
CALIBRATION DI	EVI Thermocouple Simulator	MANUFACTURER:	Omega	

TEST POINT NO.	MILLIVOLT SIGINAL	EQUIVALEN T TEMP, °F	DIGITAL INDICATOR TEMP READING, °F	DIFFERENCE, %
1	0	0	-1	0.2
2	100	100	98	0.4
3	200	200	200	0.0
4	300	300	299	0.1
5	400	400	398	0.2
6	500	500	497	0.3
7	1000	1000	1002	0.1
8	1300	1300	1302	0.1
9	1600	1600	1604	0.2
10	1900	1900	1903	0.1

Percent difference must be less than or equal to 0.5 %

Percent difference: (Equivalent Temp,.°R - Digital Indicator Temp., °R) * (100%)

(Equivalent Temp., °R)

Where ${}^{\circ}R = {}^{\circ}F + 460$

THERMOCOUPLE DIGITAL INDICATOR CALIBRATION DATA SHEET

TE:				INDICATOR NO.:	VB-1
ERATO			BF	SERIAL NO.:	10285505
LIBRA	TION DEVICE:	Thermocouple S	imulator	MANUFACTURER:	Omega
	TEST POINT NO.	MILLIVOLT SIGINAL	EQUIVALENT TEMP, °F	DIGITAL INDICATOR TEMP READING, °F	DIFFERENCE, %
	1	-0.692	0	-1	0.2
	2	1.520	100	98	0.4
	3	3.819	200	198	0.3
	4	6.092	300	297	0.4
	5	8.314	400	396	0.5
	6	10.560	500	497	0.3
	7	22.251	1000	999	0.1
	8	29,315	1300	1297	0.2
	9	36.166	1600	1598	0.1
	10	42.732	1900	1900	0.0

Percent difference: (Equivalent Temp., °R - Digital Indicator Temp., °R) * (100%)

(Equivalent Temp., °R)

Where ${}^{o}R = {}^{o}F + 460$

THERMOCOUPLE DIGITAL INDICATOR CALIBRATION DATA SHEET

DATE:	28-J	an-16		INDICATOR NO.:	VB-2	
OPERATO	ERATOR:		BF	SERIAL NO.:	10285505	
CALIBRA	TION DEVICE:	Thermocouple Si	mulator	MANUFACTURER:	Omega	
	TEST POINT NO.	MILLIVOLT SIGINAL	EQUIVALENT TEMP, °F	DIGITAL INDICATOR TEMP READING, °F	DIFFERENCE, %	
	1	-0.692	0	-1	0.2	
	2	1.520	100	98	0.4	
	3	3.819	200	198	0.3	
	4	6.092	300	297	0.4	
	5	8.314	400	397	0.3	
	6	10.560	500	497	0.3	
	7	22.251	1000	999	0.1	
	8	29.315	1300	1297	0.2	
	9	36.166	1600	1598	0.1	
	10	42,732	1900	1897	0.1	

Percent difference:

(Equivalent Temp,.°R - Digital Indicator Temp., °R) * (100%)

(Equivalent Temp., °R)

Where ${}^{o}R = {}^{o}F + 460$

DRY GAS THERMOCOUPLES AND IMPINGER THERMOCOUPLES

The dry gas thermocouples are calibrated by comparing them with an ASTM-3 thermometer at approximately 32°F, ambient temperature, and a higher temperature between approximately 100°F and 200°F. The thermocouples agreed within 5°F of the reference thermometer. The impinger thermocouples are checked in a similar manner at approximately 32°F and ambient temperature, and they agreed within 2°F. The thermocouples may be checked at ambient temperature prior to the test series to verify calibration. Calibration data are included in the following Dry Gas Thermometer and Impinger Thermocouple Calibration Data Sheet(s).

TEMPERATURE SENSOR CALIBRATION DATA FORM FOR METER BOX

DATE:	28-Dec-15		THERMOCOUPLE NUMBER:	MB2
AMBIENT TEMP	ERATURE:	68 °F	BAROMETRIC PRES.(In.Hg):	30.11
CALIBRATOR:	BF			

Reference point number	Source* (Specify)	Reference Thermometer I emperature, "F	Thermocouple Potentiometer I emperature, "F	Temperature Difference," ~
Inlet 1	Ambient Air	68	66	2
2	Cold Bath	36	34	2
3	Hot Bath	212	210	2
Outlet 1	Ambient Air	68	65	3
2	Cold Bath	36	37	1
3	Hot Bath	212	211	1
	1			1

_	
^e Type of calibration used.	ACCEPT
"Allowable tolerance ±5"F	

TEMPERATURE SENSOR CALIBRATION DATA FORM FOR METER BOX

DATE:	23-Dec-15		THERMOCOUPLE NUMBER:	MB3
AMBIENT TEMP	ERATURE:	67.5 °F	BAROMETRIC PRES.(In.Hg):	29.85
CALIBRATOR:	BF			

Reference	Source*	Reference	Thermocouple	Temperature
point	(Specify)	Thermometer	Potentiometer	Difference,"
number		l emperature, "F	I emperature, "⊢	ĭ+
Inlet		07.5	00	0.5
1	Ambient Air	67.5	68	0.5
2	Cold Bath	34	33	1
3	Hot Bath	212	213	1
Outlet				
1	Ambient Air	67.5	69	1.5
2	Cold Bath	34	36	2
3	Hot Bath	212	210	2

Type of calibration used.		ACCEPT
"Allowable tolerance <u>+</u> 5"F	1	******
Comments:		

TEMPERATURE SENSOR CALIBRATION DATA FORM FOR METER BOX

DATE:	28-Dec-15	THERMOCOUPLE NUMBER: _	MB5
AMBIENT TEMP	ERATURE: 68 °F	BAROMETRIC PRES.(In.Hg):	30.11
CALIBRATOR:	BF		

Reference point number	Source ⁴ (Specify)	Reference Thermometer I emperature, ̆ ⊢	Thermocouple Potentiometer I emperature, "F	Temperature Difference,″ ັ⊢
Inlet 1	Ambient Air	68	67	1
2	Cold Bath	34	35	1
3	Hot Bath	212	211	1
Outlet 1	Ambient Air	68	66	2
2	Cold Bath	34	35	1
3	Hot Bath	212	209	3

⁴ Type of calibration used.	ACCEPT
"Allowable tolerance <u>+</u> 5"F	

TEMPERATURE SENSOR CALIBRATION DATA FORM FOR METER BOX

DATE:	28-Dec-15	THERMOCOUPLE NUMBER:	MB11
AMBIENT TEMPI	ERATURE: 68 F	BAROMETRIC PRES.(In.Hg):	30.11
CALIBRATOR:	BF		

Reference point number	Source ⁴ (Specify)	Reference Thermometer I emperature, "F	Thermocouple Potentiometer I emperature, T	Temperature Difference," ~
Inlet 1	Ambient Air	68	67	1
2	Cold Bath	36	36	0
3	Hot Bath	212	209	3
Outlet 1	Ambient Air	68	66	2
2	Cold Bath	36	36	0
3	Hot Bath	212	214	2
I				

"Type of calibration used.	ACCEPT
"Allowable tolerance ±5"F	<u> </u>

TEMPERATURE SENSOR CALIBRATION DATA FORM FOR METER BOX

DATE:	28-Dec-15		THERMOCOUPLE NUMBER: _	MB13
AMBIENT TEMPE	RATURE:	68 °F	BAROMETRIC PRES.(in.Hg): _	30.11
CALIBRATOR:	BF			

Reference point number	Source" (Specify)	Reference Thermometer I emperature, ĭ ⊢	Thermocouple Potentiometer I emperature, ˇF	Temperature Difference," "F
Inlet 1	Ambient Air	68	66	2
2	Cold Bath	36	35	1
3	Hot Bath	212	210	2
Outlet 1	Ambient Air	68	66	2
2	Cold Bath	36	37	1
3	Hot Bath	212	211	1

⁴Type of calibration used.	ACCEPT
"Allowable tolerance <u>+</u> 5°F	<u>"" " " " " " " " " " " " " " " " " " "</u>

TEMPERATURE SENSOR CALIBRATION DATA FORM FOR METER BOX

DATE: 27-Jan-16		THERMOCOUPLE NUMBER:	VB-1
AMBIENT TEMPERATURE:	65.5 °F	BAROMETRIC PRES.(In.Hg):	30.20
CALIBRATOR: Npharo	-b		

Reference point	Source ^a (Specify)	Reference Thermometer	Thermocouple Potentiometer	Temperature Difference, ^b
number		Temperature,⁰F	Temperature,°F	°F
Inlet 1	Ambient Air	65.5	65.4	0.1
2	Cold Bath	39	38.5	0.5
3	Hot Bath	212	209.3	2.7
Outlet 1	Ambient Air	65.5	65.4	0.1
2	Cold Bath	39	39.4	0.4
3	Hot Bath	212	211.8	0.2

^a Type of calibration used.	ACCEPT
^b Allowable tolerance <u>±</u> 5°F	

TEMPERATURE SENSOR CALIBRATION DATA FORM FOR METER BOX

DATE:	27-Jan-16		THERMOCOUPLE NUMBER:	VB-2
AMBIENT TEMPER	ATURE:	65.8 °F	BAROMETRIC PRES.(In.Hg):	30.20
CALIBRATOR:	Npharo			

Reference	Source ^a	Reference	Thermocouple	Temperature
point	(Specify)	Thermometer	Potentiometer	Difference, ^b
number		Temperature,°F	Temperature,°F	°F
Inlet				
1	Ambient Air	65.8	65.2	0.6
_	0.115.11		07.5	4.5
2	Cold Bath	39	37.5	1.5
3	Hot Bath	212	214.5	2.5
,	TIOL Datii	612	211.0	2.0
Outlet				
1	Ambient Air	65.8	64.9	0.9
2	Cold Bath	39	39.1	0.1
_	II-4 Dath	242	212.7	0.7
3	Hot Bath	212	212.7	U./
i	1	l l		i

^bAllowable tolerance <u>+</u>5°F

TEMPERATURE SENSOR CALIBRATION DATA FORM FOR SAMPLE HEADS

12/28/2015

Reference point number	Source ^a (Specify)	Reference Thermometer Temperature,°F	Thermocouple Potentiometer Temperature,°F	Temperature Difference, ^b °F	
Sample Head N	No. 1				
1	Ambient Air	65.7	66.6	0.9	ACCEPT
2	Cold Bath	34	33.5	-0.5	ACCLIT
Sample Head N	No. 2				
1	Ambient Air	65.7	66.6	0.9	ACCEPT
2	Cold Bath	34	32.9	-1.1	ACCLIT
Sample Head N	No. 3				
1	Ambient Air	65.7	66.4	0.7	ACCEPT
2	Cold Bath	34	33.1	-0.9	ACCEPT
Sample Head N	No. 4				
1	Ambient Air	65.7	66.5	0.8	ACCEPT
2	Cold Bath	34	33.3	-0.7	ACCEPT
Sample Head N	No. 5				
1	Ambient Air	65.7	67.1	1.4	ACCEPT
2	Cold Bath	34	32.7	-1.3	ACCEPT
Sample Head N	No. 6				
1	Ambient Air	N/A	N/A	N/A	N/A
2	Cold Bath	N/A	N/A	N/A	N/A
Sample Head N	No. 7				
1	Ambient Air	65.7	66.2	0.5	ACCEPT
2	Cold Bath	34	32.9	-1.1	ACCEPT
Sample Head N	No. 8				
1	Ambient Air	65.7	66.3	0.6	ACCEPT
2	Cold Bath	34	32.7	-1.3	ACCEPT
Sample Head N	No. 9				
1	Ambient Air	65.7	66.5	0.8	ACCEPT
2	Cold Bath	34	32.7	-1.3	ACCEPT
Sample Head N	No. 10				
1	Ambient Air	65.7	66.5	0.8	ACCEPT
2	Cold Bath	34	32.9	-1.1	ACCEPT
Sample Head N					
1	Ambient Air	65.7	66.5	8.0	ACCEPT
2	Cold Bath	34	32.7	-1.3	ACCEPT
Sample Head N					
1	Ambient Air	65.7	66.4	0.7	ACCEPT
2	Cold Bath	34	32.7	-1.3	ACCEPT
Sample Head I					
1	Ambient Air	65.7	66.2	0.5	ACCEPT
2	Cold Bath	34	33.3	-0.7	ACCEPT

Calibrated By: EZ

^aType of calibration used. ^bAllowable tolerance <u>+</u>2°F

STACK THERMOCOUPLES

Each thermocouple is calibrated by comparing it with an ASTM-3F thermometer at approximately 32°F, ambient temperature, 212°F, and 500°F. The thermocouple reads within 1.5 percent of the reference thermometer throughout the entire range when expressed in degrees Rankine. The thermocouples may be checked at ambient temperature at the test site to verify the calibration. Calibration data are included in the following Thermocouple Calibration Data Sheet(s).

2016 YEARLY THERMOCOUPLE CALIBRATIONS

Thermo.	Therm.	Date	Ambient	Diff., %	Cold Bath	Diff., %	Hot Bath	Diff., %	Hot Oil	Diff., %	Accept/Reject
T2-1	Reference	12/21/2015	69.1	0.00	34	0.02	214	0.22	396	0.06	ACCEPT
	Pitot		69.1	0.00	34.1	0.02	212.5		395.5		
P2-2	Reference Pitot	12/21/2015	68.9 67.3	0.30	33.8	0.04	214 213.8	0.03	422 420	0.23	ACCEPT
0700774	Reference	12/21/2015	69	242000 000	33.6	40 (40)	213.6	5057790000	389	CANSONS	12 ASSESSED 1 ASSESSED
T2-2	Pitot	12/21/2015	67.1	0.36	36.3	0.47	213.9	0.31	387.3	0.20	ACCEPT
	Reference	12/21/2015	68.9	0.10	34		216	0.01	440	0.50	LCOPPE
T2-3	Pitot		67.9	0.19	34.9	0.18	214.6	0.21	433	0.78	ACCEPT
T2-4	Reference	12/21/2015	68.7	0.30	34	0.20	214	0.04	408	0.15	ACCEPT
12-4	Pitot		67.1	0.50	35	0.20	214.3	0.04	409.3	0.15	ACCELL
T2-5	Reference	12/21/2015	68.9	0.79	36	0.14	218	0.07	403	0.10	ACCEPT
	Pitot	10/01/0015	64.7		35.3		217.5	10,0716.1	402.1	77.71	
T2-6	Reference Pitot	12/21/2015	69.5 68.3	0.23	33.7	0.06	216 213.3	0.40	360 355	0.61	ACCEPT
A2080.00	Reference	12/28/2015	65.5	2000000	35.7	200000	213.3	8.000	320	oundo	NI samakaranda
T2-7	Pitot	12/26/2013	65,9	0.08	35	0.00	210.9	0.16	320.1	0.01	ACCEPT
774.0	Reference	12/21/2015	68.6	0.10	34	0.10	214	0.00	404	0.20	ACCEPT
T2-8	Pitot		67.7	0.17	34.6	0.12	212.5	0.22	400.6	0.39	ACCEPT
T3-1	Reference	12/22/2015	65.9	0.57	37	0.06	214	0.25	350	0.27	ACCEPT
13-1	Pitot		68.9	520000000	36.7	1000000	212.3	34.200360	347.8	10.00000000	ACCELL
T3-2	Reference	12/21/2015	68.5	0.04	35	0.10	217	0.65	402	0.01	ACCEPT
	Pitot	10/00/0015	68.3 67.5	0.04	34.5	0.00	212.6 213	0.10	402.1 440	0.00	
T3-3P	Reference Pitot	12/29/2015	67.3	0.04	35 34.9	0.02	212.3	0.10	432	0.89	ACCEPT
200 m 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Reference	12/22/2015	68.5	0.08	33	0.18	212.3	0.18	374	0.14	ACCEPT
T3-4P	Pitot	12/22/2013	68.1	0.00	33.9	0.10	212.8	0.10	372.8	0.14	ACCELL
Tra E	Reference	12/22/2015	66.1	0.49	38	0.30	212	0.06	366	0.04	ACCEPT
T3-5	Pitot		68.7		39.5		212.4		365.7		
T3-6	Reference	12/28/2015	65.8	0.02	36	0.02	212	0.16	373	0.28	ACCEPT
13-0	Pitot		65.7		36.1		213.1		375.3		
T3-7	Reference	12/22/2015	67.9	0.17	36	0.12	218 213	0.74	319 322.2	0.41	ACCEPT
	Pitot Reference	10/01/2015	67 68.9	0.20	35.4 34	0.14	213	0.07	440	0.64	ACCEPT
T3-8	Pitot	12/21/2015	67.4	0.28	34.7	0.14	214.5	0.07	434.2	0.04	ACCEPT
12.25 526	Reference	12/22/2015	65.9	0.46	37	0.04	214	0.13	338	0.21	ACCEPT
T3-9I	Pitot	12/22/2012	68.3	0.10	36.8	0.01	213.1	0.15	336.3	0.21	neez.
T3-10I	Reference	12/22/2015	69.5	0.23	37	0.28	214	0.06	332	0.29	ACCEPT
13-101	Pitot		68.3		38.4		209.2		329.7		
T3-11	Reference	1/27/2016	65.2	0.06	38	0.14	212	0.06	380	0.17	ACCEPT
(AEGS 688EG	Pitot	1/07/0016	64.9	0.04	37.3	0.00	212.5	0.10	378.6 340	0.20	LCCEPT
T3-67	Reference Pitot	1/27/2016	65.3 65	0.06	34 35.1	0.22	212 212.8	0.12	337.8	0.28	ACCEPT
1 December 2	Reference	12/22/2015	69.2	0.17	36	0.06	216	0.19	320	0.22	ACCEPT
T4-1	Pitot	12/22/2015	68.3	0.17	35.7	0.00	214.7	0.15	318.3	0.22	THE CELL X
T4-2	Reference	12/29/2015	67.3	0.04	34	0.02	212	0.04	330	0.04	ACCEPT
14-2	Pitot		67.1	1.500 0.000	33.9		212.3	Name of Asia	329.7	.13535	
T4-3	Reference	12/22/2015	66.7	0.04	35	0.08	213	0.22	360	0.06	ACCEPT
212	Pitot	12/22/2015	66.5	0.06	34.6	0.00	211.5	0.05	359.5	0.10	A COURT
T4-4P	Reference Pitot	12/22/2015	65.6 66.9	0.25	38 38.4	0.08	212 210.3	0.25	278 277.1	0.12	ACCEPT
	Reference	12/22/2015	68.4	0.17	35	0.06	210.3	0.22	300	0.50	ACCEPT
T4-5	Pitot	14/44/4013	67.5	0.17	35.3	0,00	210.5	0.22	296.2	0.50	ACCEPT
TACD	Reference	12/22/2015	66	0.25	35	0.14	214	0.27	340	0.04	ACCEPT
T4-6P	Pitot		67.3		35.7		212.2		340.3		
T4-7	Reference	12/21/2015	69.9	0.32	36	0.22	218	0.88	436	0.52	ACCEPT
17-1	Pitot		68.2		37.1		212		431.3		
T4-8	Reference	1/27/2016	65.3	0.02	32	0.22	212	0.04	332	0.21	ACCEPT
	Pitot Reference	12/22/2015	65.2 65.8	0.42	33.1 38	0.04	212.3 213	0.25	333.7 316	0.06	ACCEPT
T4-8P	Pitot	12/22/2015	68	0.42	38.2	0.04	211.3	0,23	315.5	0.06	ACCEPT
	Reference	12/28/2015	65.8	0.02	36	0.06	212	0.01	373	0.20	ACCEPT
T4-9	Pitot	22/20/2013	65.9	0.02	36.3	0.00	212.1	0.01	374.7	0.20	ACCEPT
	2.101		05.5		50.5		~		v. 11.1		

Thermo.	Therm.	Date	Ambient	Diff., %	Cold Bath	Diff., %	Hot Bath	Diff., %	Hot Oil	Diff., %	Accept/Reject
T4-10	Reference	1/27/2016	64.9	0.21	38	0.22	212	0.28	380	0.43	ACCEPT
14-10	Pitot	10/00/00/0	63.8	0.00	39.1	0.00	210.1 212	0.00	376.4 356	0.16	ACCEPT
T4-13	Reference Pitot	12/29/2015	67.3 67.2	0.02	34 34.1	0.02	212.4	0.06	354.7	0.16	ACCEPT
	Reference	12/29/2015	67.3	0.02	34	0.02	212	0.07	350	0.15	ACCEPT
T4-14	Pitot	12/27/2015	67.2	0.02	33.9	X.X.	212.5	3,300	348.8	3/45.5	J. C.
T4-15	Reference	12/22/2015	65.8	0.36	35	0.32	216	8.28	350	12.56	REJECT
* 1 - 1 - 1	Pitot		67.7	0.00	36.6	0.10	160 218	0.00	248.3 420	0.00	ACCEPT
T4-16	Reference Pitot	12/21/2015	70.1 68.4	0.32	34 34.6	0.12	214.1	0.58	425.8	0.66	ACCEPT
1200000	Reference	1/27/2016	65.2	0.08	38	0.26	212	0.03	346	0.29	ACCEPT
T4-17	Pitot		65.6		39.3		211.8	1400.000	348.3	50000000	
T5-1P	Reference	12/22/2015	67.3	0.15	34	0.08	212	0.01	356	0.16	ACCEPT
	Pitot	12/22/2016	68.1	0.44	34.4 36	0.34	211.9 213	0.12	354.7 360	0.05	ACCEPT
T5-2	Reference Pitot	12/22/2015	67.3 69.6	0.44	34.3	0.34	212.2	0.12	360.4	0.03	ACCEFI
	Reference	12/22/2015	67.2	0.13	35	0.34	214	0.49	360	0.02	ACCEPT
T5-3P	Pitot		67.9		36.7		210.7		359.8		
T5-4	Reference	12/23/2015	66.3	0.15	34	0.14	212	0.09	330	0.44	ACCEPT
	Pitot	1/27/2016	67.1 65.3	0.17	34.7 38	0.24	212.6 212	0.10	326.5 340	0.34	ACCEPT
T5-7P	Reference Pitot	1/27/2016	66.2	0.17	39.2	0.24	211.3	0.10	342.7	0.54	ACCELL
75.0	Reference	12/22/2015	67	0.02	34	0.04	214	0.04	360	0.16	ACCEPT
T5-8	Pitot	FE 848	66.9	F25050	34.2		213.7		358.7		
T5-9	Reference	12/22/2015	67.2	0.36	34	0.08	212	0.22	344	0.44	ACCEPT
	Pitot Reference	10/02/0015	69.1 67.5	0.08	34.4 35	0.04	213.5 212	0.07	347.5 370	0.31	ACCEPT
T6-1	Pitot	12/23/2015	67.1	0.08	34.8	0.04	211.5	0.07	367.4	0.51	ACCELL
Trea	Reference	12/23/2015	64.7	0.06	38	0.04	212	0.15	354	0.02	ACCEPT
T6-2	Pitot	MITOCOLONIA SIGNATA	65	N-95384509	38.2	SALVESSES (A. III.)	213		354.2	1100	
T6-3	Reference	12/23/2015	66.1	0.04	34	0.16	212	0.07	364	0.18	ACCEPT
200	Pitot	10/00/0015	65.9	0.01	34.8 36	0.04	212.5 212	0.16	362.5 378	0.05	ACCEPT
T6-3P	Reference Pitot	12/28/2015	64.9 65.1	0.04	35.8	0.04	210.9	0.10	378.4	0.05	ACCELL
me a	Reference	12/22/2015	66.9	0.30	34	0.24	214	0.22	370	0.16	ACCEPT
T6-5	Pitot	Section of the sectio	68.5		32.8	The state	212.5		371.3		
T6-5P	Reference	12/23/2015	67.3	0.02	34	0.06	212	0.12	352	0.70	ACCEPT
	Pitot	1/27/2016	67.4 65.3	0.08	34.3 38	0.16	212.8 212	0.03	346.3 390	0.39	ACCEPT
T6-7	Reference Pitot	1/27/2016	65.7	0.08	38.8	0.10	211.8	0.03	386.7	0,39	ACCELL
T(0	Reference	12/23/2015	67.5	0.04	36	0.06	212	0.03	366	0.06	ACCEPT
T6-9	Pitot		67.3		35.7		212.2		366.5		
T6-10	Reference	12/23/2015	67.3	0.04	34.7 34.7	0.14	212 212.2	0.03	366 367.8	0.22	ACCEPT
INDIVORCIONO	Pitot Reference	12/23/2015	67.5 67.5	0.04	34.7	0.06	212.2	0.09	360	0.11	ACCEPT
T6-12P	Pitot	12/23/2013	67.3	0.04	38.3	0.00	212.6	0.05	360.9	0	
T6-13	Reference	12/23/2015	67.1	0.04	34	0.02	212	0.01	360	0.21	ACCEPT
10-13	Pitot		66.9		33.9		211.9		361.7	0.00	LOCERT
T6-14P	Reference	12/23/2015	64.8 64.5	0.06	38 38.2	0.04	212	0.21	390 389.2	0.09	ACCEPT
	Pitot Reference	12/28/2015	64.9	0.04	36.2	0.02	210.0	0.13	388	0.24	ACCEPT
T6-15P	Pitot	12/20/2015	65.1	0.01	35.9	0.02	211.1	0.550	386	2500.0	855,6165,6
T7-1	Reference	12/28/2015	64.9	0.04	35	0.02	212	0.10	384	0.20	ACCEPT
1/-1	Pitot		65.1		35.1	0.10	212.7	0.01	382.3 382	0.00	LOCEPT
T7-2	Reference Pitot	12/22/2015	67 68.5	0.28	33.9	0.18	214.3	0.04	384.4	0.29	ACCEPT
50000 5000	Reference	12/28/2015	65.1	0.02	34	0.06	212	0.22	364	0.15	ACCEPT
T7-4I	Pitot	12.20.2010	65.2		34.3		210.5		362.8		30400 30000 30
T7-5I	Reference	12/28/2015	65.4	0.04	34	0.16	212	0.28	380	0.05	ACCEPT
	pitot		65.2		34.8	0.11	210.1	0.04	380.4	0.51	A COURT
T7-5	Reference	12/22/2015	66.9 68.6	0.32	32 32.8	0.16	214 213.7	0.04	366 370.5	0.54	ACCEPT
	Pitot Reference	12/28/2015	65.8	0.00	34	0.06	213.7	0.04	370.3	0.22	ACCEPT
T7-6I	Pitot	12,20,2013	65.8	0.00	34.3	5,00	212.3		368.2	1.55(1.59)	35.5.555.5
T8-1P	Reference	12/28/2015	65.6	0.08	34	0.06	212	0.19	380	0.36	ACCEPT
10-11	Pitot	1/00/2017	65.2	0.15	34.3	0.53	210.7	0.01	383	0.00	ACCEPT
T8-2	Reference	1/27/2016	65.7	0.13	39	0.72	212.3	0.04	338 332.7	0.66	ACCEPT
	Pitot		65		35.4	Ļ	212.3	ļ į	332.1	1	<u>I</u> ,


Thermo.	Therm.	Date	Ambient	Diff., %	Cold Bath	Diff., %	Hot Bath	Diff., %	Hot Oil	Diff., %	Accept/Reject
T8-3	Reference	12/28/2015	65.1	0.02	39	0.04	212	0.06	360	0.21	ACCEPT
	Pitot Reference	12/28/2015	65 65	0.02	39.2 36	0.06	211.6 212	0.21	361.7 388	0.20	ACCEPT
T8-7	Pitot	12/28/2013	64.9	0.02	36.3	0.00	213.4	AMERICANO.	389.7	50,75.00	
T8-8P	Reference Pitot	12/28/2015	65.5 65.3	0.04	35 35.9	0.18	212 210.7	0.19	380 379.3	0.08	ACCEPT
T8-9P	Reference Pitot	12/28/2015	65.7 65.2	0.10	36 35.8	0.04	212 210.3	0.25	384 385.8	0.21	ACCEPT
T8-10	Reference	12/28/2015	66.2	0.02	35 35.6	0.12	212 212.9	0.13	390 392.1	0.25	ACCEPT
T8-11	Pitot Reference	12/28/2015	65.6	0.08	35	0.02	212	0.03	382 381.2	0.10	ACCEPT
T8-14	Pitot Reference	12/18/2014	66 66	0.11	35.1 36	0.22	211.8	0.16	385.1	0.24	ACCEPT
8-18	Pitot Reference	12/28/2015	65.4 65.1	0.02	37.1 35	0.06	213.1 212	0.03	383.1 350	0.16	ACCEPT
	Pitot Reference	12/28/2015	65.2 64.9	0.00	34.7 34	0.02	212.2 212	0.03	348.7 348	0.02	ACCEPT
T8-19	Pitot Reference	12/28/2015	64.9 65.7	0.08	34.1 34	0.10	212.2 212	0.10	347.8 378	0.05	ACCEPT
T8-20	Pitot		66.1		34.5	0.02	212.7 212	0.25	378.4 370	0.11	ACCEPT
T8-21	Reference Pitot	12/28/2015	65 65.1	0.02	36 36.1	2000/00/8	213.7	223	370.9		
8-22	Reference Pitot	12/28/2015	65.1 65.3	0.04	34 34.1	0.02	212.9	0.13	350 351	0.12	ACCEPT
8-23	Reference Pitot	12/28/2015	65.1 65.3	0.04	35 35.1	0.02	212 212.3	0.04	384 384.6	0.07	ACCEPT
8-24	Reference Pitot	12/28/2015	65.8 65.8	0.00	35 35.4	0.08	212 212.2	0.03	368 363.7	0.52	ACCEPT
T9-1	Reference Pitot	12/28/2015	65.8 65.5	0.06	38 38.7	0.14	212 211.2	0.12	378 377.4	0.07	ACCEPT
T9-2	Reference	12/28/2015	65.9	0.06	37 37.3	0.06	212 212.4	0.06	380 379.7	0.04	ACCEPT
10-1	Pitot Reference	12/28/2015	66.2 65.8	0.04	37	0.04	212	0.06	376	0.17	ACCEPT
T10-2	Pitot Reference	12/28/2015	66 65.8	0.02	36.8 37	0.10	212.4 212	0.04	377.4 376	0.47	ACCEPT
	Pitot Reference	12/28/2015	65.9 65.8	0.02	37.5 38	0.06	212.3 212	0.06	372.1 354	0.10	ACCEPT
T10-2P	Pitot Reference	12/28/2015	65.9 65.8	0.06	38.3 38	0.06	212.4 212	0.04	353.2 350	0.20	ACCEPT
T10-4	Pitot		66.1		38.3	0.22	212.3 212	0.13	351.6 390	0.27	ACCEPT
T10-21	Reference Pitot	1/27/2016	65.6 66	0.08	39.1	1910/072620	212.9	520000	392.3		
T12-1	Reference Pitot	1/27/2016	65.3 66.2	0.17	38 38.7	0.14	212 211.2	0.12	346 349.7	0.46	ACCEPT
T12-2	Reference Pitot	12/28/2015	65.8 65.9	0.02	34.8	0.16	212 212.3	0.04	370 372.3	0.28	ACCEPT
T12-3	Reference Pitot	12/28/2015	65.8 66	0.04	35 34.7	0.06	212 212.2	0.03	370 368.4	0.19	ACCEPT
T12-4	Reference	12/28/2015	65.8 66	0.04	34.2	0.04	212 212.8	0.12	376 373.7	0.28	ACCEPT
T14-1	Pitot Reference	12/28/2015	65.8	0.02	36	0.02	212	0.06	375	0.02	ACCEPT
T20-1	Pitot Reference	12/28/2015	65.9 65.8	0.04	36.1 36	0.04	212.4 212	0.06	375.2 372	0.37	ACCEPT
	Pitot Reference	12/29/2015	66.6	0.17	36.2 32.3	0.00	212.4 212	0.21	375.1	0.00	ACCEPT
DB-1	Pitot Reference	12/29/2015	67.5 66.6	0.02	32.3 32.3	0.08	210.6 212	0.31		0.00	ACCEPT
WB-1	Pitot		66.7	0.23	32.7 32.3	0.04	209.9 212	0.31		0.00	ACCEPT
DB-2	Reference Pitot	12/29/2015	68		32.1		209.9				
WB-2	Reference Pitot	12/29/2015	66.8	0.23	32.3 32.5	0.04	212 209.1	0.43		0.00	ACCEPT
DB-3	Reference Pitot	12/29/2015	66.9 68.5	0.30	32.3 32.3	0.00	212 210.9	0.16		0.00	ACCEPT
WB-3	Reference Pitot	12/29/2015	66.9 68.5	0.30	32.3 32.3	0.00	212 210.6	0.21		0.00	ACCEPT
DB-4	Reference Pitot	12/29/2015	66.8 68.5	0.32	32.3 32.7	0.08	212 210.5	0.22		0.00	ACCEPT
WB-4	Reference	12/29/2015	66.8	0.23	32.3 32.2	0.02	212	0.19		0.00	ACCEPT
DB-5	Pitot Reference	12/29/2015	67.2	0.21	32.3	0.04	212	0.16		0.00	ACCEPT
1 200-3	Pitot		68.3		32.1		210.9	l.	Į,	Ī	Ī

Thermo.	Therm.	Date	Ambient	Diff., %	Cold Bath	Diff., %	Hot Bath	Diff., %	Hot Oil	Diff., %	Accept/Reject
	Reference	12/29/2015	67.2	0.17	32.3	0.04	212	0.15		0.00	ACCEPT
WB-5	Pitot	TO THE PERSON NAMED IN COLUMN TO A STATE OF THE PERSON NAMED IN COLUMN TO A ST	68.1	XX85.553	32.1	7,000,000	211				
DB-7	Reference	12/29/2015	67.2	0.17	32.3	0.12	212	0.22		0.00	ACCEPT
	Pitot Reference	12/20/2015	68.1 67.2	0.17	32.9 32.3	0.08	210.5 212	0.25		0.00	ACCEPT
WB-7	Pitot	12/29/2015	68.1	0.17	32.7	0.00	210.3	0.20		0.00	ACCELL
	Reference	12/29/2015	67.3	0.19	32.3	0.16	212	0.33		0.00	ACCEPT
DB-8	Pitot		68.3	TO THE STATE OF	33.1	219000100	209.8	3/5/6/4/588		40 VAC	
WB-8	Reference	12/29/2015	67.3	0.23	32.3	0.14	212	0.25		0.00	ACCEPT
112-0	Pitot		68.5	0.10	33	0.16	210.3	0.22	370	0.36	ACCEPT
4467	Reference Pitot	12/29/2015	66.9 67.7	0.15	33.5 32.7	0.16	212 213.5	0.22	367	0.50	ACCEPT
Automotive Company	Reference	12/29/2015	66.9	0.38	33.5	0.06	212	0.22	378	0.24	ACCEPT
4469	Pitot	12/23/2013	68.9	0.00	33.8	213.3	210.5	U MATAGORES	376	0.0000000000000000000000000000000000000	Maria Maria San Santa
4473	Reference	12/29/2015	66.9	0.15	33.5	0.08	212	0.01	360	0.12	ACCEPT
4473	Pitot		67.7		33.1		212.1	0.10	359	0.60	. COPPT
LT1-2	Reference	1/27/2016	65.2	0.10	38 40.8	0.56	212	0.10	384 389.1	0.60	ACCEPT
BH-1	Pitot Reference	12/29/2015	65.7 65.8	0.17	33.8	0.14	211.3	0.34	365.1	0	ACCEPT
DIL	Pitot	12/25/2015	64.9	0.17	33.1		209.7	0.000			99504089019904550
BH-2	Reference	12/29/2015	65.8	0.10	33.8	0.06	212	0.19		0	ACCEPT
	Pitot	375224637 (\$45000.77)	66.3	A1A-7021	33.5		210.7				LOCEPET
BH-4	Reference	12/29/2015	65.8	0.02	34	0.06	212	0.45		0	ACCEPT
DV 6	Pitot	12/20/2015	65.9	0.02	33.7 34	0.10	209 212	0.34		0	ACCEPT
BH-5	Reference Pitot	12/29/2015	65.8 65.9	0.02	33.5	0.10	214.3	0.34		ľ	ACCELL
BH-6	Reference	12/29/2015	65.8	0.10	34	0.22	212	0.19		0	ACCEPT
DIL	Pitot	12.22.2011	66.3	7177	32.9		210.7	0000000			
BH-7	Reference	12/29/2015	65.8	0.15	34	0.06	212	0.43		0	ACCEPT
	Pitot		66.6		33.7		209.1	0.00			LCCEPT
BH-8	Reference	12/29/2015	65.8	0.04	35	0.14	212	0.09		0	ACCEPT
BH-9	Pitot Reference	12/29/2015	66 65.8	0.00	34.3 35.8	0.22	211.4	0.09		0	ACCEPT
DI1-9	Pitot	12/29/2013	65.8	0.00	34.7	0.22	211.4	0.02	- Harris - Harris		
BH-10	Reference	12/29/2015	65.8	0.15	35.9	0.24	212	0.25		0	ACCEPT
	Pitot		66,6	9360	34.7		213.7				
BH-11	Reference	12/29/2015	67.8	0.09	35.5	0.20	212	0.25	E-1	0	ACCEPT
	Pitot		67.3	0.00	34.5	0.00	210.3	0.20	-	0	ACCEPT
BH-13	Reference	12/29/2015	67.1	0.09	34.5	0.20	212 210	0.30		1 "	ACCELL
DIVA	Pitot	10/00/0015	67.6 67	0.11	33.5 34.1	0.10	210	0.36	 	0	ACCEPT
BH-14	Reference Pitot	12/29/2015	67.6	0.11	33.6	0.10	209.6	0.30	-		ACCELL
BH-15	Reference	12/29/2015	66.9	0.11	34.1	0.08	212	0.45	 	0	ACCEPT
BH-13	Pitot	12/29/2013	67.5	0.11	33.7	0.00	209	0.12			
BH-16	Reference	12/29/2015	66.8	0.17	34.8	0.18	212	0.39		0	ACCEPT
DAI-10	Pitot		67.7		33.9		209.4				
BH-17	Reference	12/29/2015	66.8	0.09	33.9	0.02	212	0.09		0	ACCEPT
	Pitot		67.3	5000000	34		211.4				
BH-18	Reference	12/29/2015	66.7	0.15	34.5	0.10	212	1.04		0	ACCEPT
	Pitot		67.5	10000000	34		205				
BH-19	Reference	12/29/2015	66.7	0.11	34.2	0.02	212	0.30		0	ACCEPT
	Pitot		67.3		34.1	1,000	210				LOCERT
BH-20	Reference	12/29/2015	66.7	0.13	32.5	0.28	212	0.40		0	ACCEPT
	Pitot		67.4		33.9	0.10	209.3	0.10		^	ACCEPT
BH-21	Reference	12/29/2015	66.8	0.17	33	0.18	212	0.42		0	ACCEPT
DV:	Pitot	10/00/0015	67.7	0.12	33.9	0.20	209.2	0,09		0	ACCEPT
BH-22	Reference	12/29/2015	66.8	0.13	33.5	0.20	212	0,09		- ·	ACCELL
DIT 22	Pitot	12/29/2015	67.5 66.9	0.11	34.5 33.5	0.12	211.4	0.16	 	0	ACCEPT
BH-23	Reference Pitot	12/29/2013	67.5	0.11	34.1	0.12	210.9	0.10		1 ~	
BH-24	Reference	12/29/2015	66.8	0.13	33.5	0.22	212	0.46	1	0	ACCEPT
D11-4-1	Pitot	12/2/12013	67.5	0,13	34.6		208.9			1	
BH-25	Reference	12/29/2015	66.9	0.09	33.5	0.08	212	0.07		0	ACCEPT
	Pitot		67.4	0 000FE	33.1	=4/2/1	211.5				
	1										

PITOT TUBE CALIBRATION

Each pitot tube used in sampling meets all requirements of EPA Method 2, Section 4.1.**

Therefore, a baseline coefficient of 0.84 is assigned to each pitot tube. The following pages show the alignment requirements of Method 2 and the Pitot Tube Inspection Data Sheet(s) for each pitot tube used during the test program.



**40 CFR 60, Appendix A, July 1995

ENVIRONMENTAL QUALITY MANAGEMENT PITOT TUBE CALIBRATIONS

Accept/Reject	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT																																		
A/2/D _t	1.290	1.168	1.264	1.267	1.092	1.291	1.131	1.095	1.134	1.112	1.111	1.255	1.268	1.267	1.316	1.354	1.296	1.253	1.253	1.241	1.288	1.247	1.264	1.148	1.269	1.263	1.219	1.194	1.266	1.274	1.085	1.237	1.245	1.255	1 265	1 259	1257	1.252	1.273	1.232	1.171	1.261	1.264	1.276	1.282	1.266	1.229
å	0.248	0.374	0.375	0.371	0.375	0.368	0.366	0.374	0.373	0.375	0.375	0.253	0.373	0.372	0.373	0.373	0.372	0.375	0.375	0.372	0.248	0.374	0.373	0.371	0.370	0.373	0.375	0.373	0.370	0.372	0.372	0.375	0.372	0.372	0.370	0.373	0.372	0.375	0.370	0.375	0.359	0.371	0.375	0.372	0.370	0.374	0.375
or or	0.3215	0.437	0.474	0.470	0.410	0.475	0.414	0.410	0.423	0.417	0.417	0.318	0.473	0.472	0.491	0.505	0.482	0.470	0.470	0.462	0.320	0.467	0.472	0.426	0.470	0.471	0.457	0.446	0.469	0.474	0.404	0.464	0.463	0.46/	0.473	0.460	0.468	0.470	0.471	0.462	0.421	0.468	0.474	0.475	0.475	0.474	0.461
σ _s	0.320	0.437	0.474	0.470	0.410	0.475	0.414	0.410	0.423	0.417	0.417	0.318	0.473	0.472	0.491	0.505	0.482	0.470	0.470	0.462	0.320	0.467	0.472	0.426	0.470	0.471	0.457	0.446	0.469	0.474	0,404	0.464	0.463	0.467	0.473	0.400	0.468	0.470	0.471	0.462	0.421	0.468	0.474	0.475	0.475	0.474	0.461
>	0.008	0.014	0.005	0.016	0.020	0.030	0.013	0.021	0.016	0.010	0.003	0.011	0.010	0.003	0.010	0.028	0.022	0.023	0.008	0.003	0.003	0.005	0.012	900'0	0.028	0.026	0.029	0.019	0.031	0.030	0.020	0.011	0.031	0.013	0.010	0.00	0.024	0.003	0.031	0.003	0.018	0.016	0.020	0.010	0.025	0.028	0.013
2	0.013	0.034	0.015	0.033	0.024	0.031	0.007	900.0	0.034	0.125	0.109	900.0	0.048	0.069	0.075	0.053	0.063	0.075	0.041	0.034	0.015	0.000	0.084	0.022	0.020	0.082	0.030	0.022	0.111	0.021	0.013	0.030	0.016	0.031	0.000	0.030	0.103	0.008	0.008	900.0	0.018	0.124	0.084	0.048	0.074	0.051	0.026
4	0.64	0.874	0.948	0.94	0.819	0.950	0.828	0.819	0.846	0.834	0.833	0.635	0.946	0.943	0.982	1.010	0.964	0.940	0.940	0.923	0.639	0.933	0.943	0.852	0.939	0.942	0.914	0.891	0.937	0.948	0.807	0.928	0.926	0.934	0.940	0.930	0.935	0.939	0.942	0.924	0.841	0.936	0.948	0 949	0.949	0.947	0.922
θ	0.7	6.0	0.3	1.0	1.4	1.8	6.0	1.5	1.1	0.7	0.2	1.0	9.0	0.2	9.0	1.6	1.3	1.4	0.5	0.2	0.3	0.3	0.7	0.4	1.7	1.6	1.8	1.2	1.9	1.8	4.4	0.7	9.0	9.0	5. 6.	5.0		0.2	1.9	0.2	1.2	1.0	1.2	9.0	1.5	1.7	0.8
>	12	22	6.0	2.0	1.7	1.9	0.5	0.4	2.3	8.6	7.5	0.5	2.9	4.2	4.4	3.0	2.5	4.6	4.0	5.8	2.3	0.9	5.1	1.5	1.0	3.4	3.7	1.1	6.8	0.8	6.0	0.9	1.0	9. 0	2.0	1.0	. 6	0.5	0.5	0.4	1.2	7.6	5.1	2.9	4.5	3.1	1.6
β2	0.2	0.1	0.4	4.0	8.0	1.5	0.1	0.2	0.8	0.5	0.5	1.4	0.7	0.5	2.3	2.0	9.0	1.8	1.0	0.4	9.0	4.	3.7	0.3	0.1	4.5	0.8	1.0	1.9	0.3	3.0	1.5	2.1		300	0.0	4 6	-	1.3	0.2	1.1	6.0	0.3	0.3	8.0	1.0	2.3
రో	6.0	3.2	1.6	1.0	4.2	1.1	0.7	1.8	1.2	6.8	7.5	6.0	1.1	6.2	6.3	2.9	1.8	1.3	4.2	6.2	7.1	6.6	3.9	1,3	0.4	1.5	4.5	0.5	7.9	1.5	1.4	0.4	0.4	3.5	0.0	1.0	57	0.8	0.5	0.0	2.1	7.4	3.6	5.3	6.0	6.6	-
βι	0.3	0.3	0.5	0.2	6.0	1.3	0.2	0.1	8.0	0.4	9.0	0.5	0.5	0.1	1.3	3.1	0.1	2.2	1.0	1.1	9.0	2.1	4.4	0.2	8.0	4.4	3.0	9.0	1.8	0.1	0.7	0.2	9.6	0.4	0.0	0.0	4.8	2	1.2	0.3	0.4	1.5	0.7	1.2	1.5	0.5	4.1
ΰ	0.8	2.5	1.6	2.0	3.9	1.6	0.7	1.2	0.4	6.4	6.8	0.7	9.0	6.4	4.2	0.5	0.4	0.7	3.9	9.9	3.9	6.2	3.6	2.2	1.3	2.7	4.1	0.4	8.0	2.4	-	0.0	1.9	0.8	0.0	γ ς	6.5	90	1.0	1.0	1.4	8.2	4.1	2.9	5.8	2.6	1.7
Date Calibrated	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/28/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/16/2015	12/21/2015	12/21/2015	12/21/2015	12/21/2015	12/21/2015	12/21/2015	12/18/2015	12/21/2015	12/29/2015	12/16/2015	12/16/2015	12/21/2015	12/16/2015	12/10/2013	12/2/1/2015	12/22/2015	12/21/2015	12/21/2015	12/23/2015	12/21/2015	12/21/2015	12/21/2015	12/22/2015	12/21/2015	12/21/2015
Pitot ID	P1-1	P1-2	T2-1	P2-2	T2-2	T2-3	T2-4	T2-5	T2-6	T2-7	T2-8	W3-2I	T3-1	T3-2	T3-3P	T3-4P	T3-5	T3-6	T3-7	T3-8	T3-9I	T3-10I	T4-1	T4-2	T4-3	T4-4P	T4-5	T4-6P	T4-7	T4-8P	T4-10	T4-13	T4-14	T4-15	14-16 T4 47	4 18	TK-1P	T5-2	T5-3P	T5-4	T5-7P	T5-8	T5-9	T6-1	T6-2	T6-3P	T6-5P

ENVIRONMENTAL QUALITY MANAGEMENT PITOT TUBE CALIBRATIONS

Accept/Reject	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	ACCEPT	REJECT	REJECT										
A/2/D _t	1.253	1.232	1.280	1.255	1.228	1.267	1.224	1.154	1.346	1.240	1.340	1.187	1.208	1.221	1.210	1.293	1.273	1.263	1.264	1.249	1.264	1.260	1.193	1.257	1.261	1.272	1.204	1.261	1.192	1.302	1.238	1.259	1.355	1.166	1.315	1.380
ι	0.375	0.373	0.370	0.374	0.375	0.375	0.372	0.374	0.373	0.375	0.375	0.375	0.375	0.375	0.374	0.372	0.374	0.372	0.373	0.374	0.371	0.373	0.373	0.375	0.372	0.371	0.375	0.370	0.368	0.373	0.370	0.370	0.372	0.368	0.124	0.125
P _β	0.470	0.460	0.474	0.470	0.461	0.475	0.456	0.432	0.502	0.465	0.503	0.445	0.453	0.458	0.453	0.481	0.476	0.470	0.472	0.467	0.469	0.470	0.445	0.472	0.469	0.472	0.452	0.467	0.439	0.486	0.458	0.466	0.504	0.429	0.163	0.432
٩	0.470	0.460	0.474	0.470	0.461	0.475	0.456	0.432	0.502	0.465	0.503	0.445	0.453	0.458	0.453	0.481	0.476	0.470	0.472	0.467	0.469	0.470	0.445	0.472	0.469	0.472	0.452	0.467	0.439	0.486	0.458	0.466	0.504	0.429	0.163	0.173
*	0.015	0.017	0.026	0.002	0.005	0.030	0.014	0.014	0.026	0.024	0.009	0.000	0.013	0.013	0.019	0:030	0.005	0.021	0.005	0.031	0.029	0.021	0.022	0.030	0.025	0.030	0.019	0.024	0.024	0.020	0.022	0.024	0.030	0.025	0.003	0.001
z	0.005	0.038	0.007	0.080	960'0	0.084	0.010	0.053	0.086	0.049	0.026	0.074	0.030	0.063	0.024	0.008	0.053	0.016	0.064	0.112	0.082	0.025	0.085	0.030	0.098	0.081	0.013	0.028	0.026	0.014	0.120	0.023	0.035	0.063	0.005	0.001
4	0.940	0.919	0.947	0.939	0.921	0.950	0.911	0.863	1.004	0.930	1.005	0.890	906.0	0.916	906.0	0.962	0.952	0.940	0.943	0.934	0.938	0.940	0.890	0.943	0.938	0.944	0.903	0.933	0.877	0.971	0.916	0.932	1.008	0.858	0.326	0.345
θ	6.0	1.0	1.6	0.1	0.3	1.8	6.0	6.0	1.5	1.5	0.5	0.0	0.8	1.5	1.2	1,8	0.3	1.3	0.3	1.9	1.8	1.3	1.4	1.8	1.5	1.8	1.2	1.5	1.6	1.2	1.4	1.5	1.7	1.7	9.0	0.1
>	0.3	2.4	0.4	4.9	6.0	5.1	9.0	3.5	4.9	3.0	1.5	4.8	1.9	4.0	1.5	0.5	3.2	1.0	3.9	6.9	5.0	1.5	5.5	1.8	6.0	4.9	0.8	1.7	1.7	0.8	7.5	1.4	2.0	4.2	0.8	0.1
β2	1.1	3.3	2.7	2.0	9.0	0.2	1.0	0.7	0.1	0.5	1.2	9.0	0.4	6.0	0.5	1.3	6.0	6.0	1.8	2.2	0.7	4.0	0.3	9.0	6.0	1.0	2.0	1.8	1.5	3.1	1.5	0.2	0.0	9.0	2.9	0.3
αž	1.0	0.7	0.5	1.4	5.2	9.0	1.1	2.5	5.1	1.5	1.7	3.0	1.3	2.0	1.3	1.2	7.2	4.1	2.3	6.6	3.4	0.1	3.9	0.4	2.5	7.4	0.5	4.7	1.0	9.1	3.5	2.5	1.6	2.1	2.1	6.0
β1	1.8	9.0	1.0	1.6	8.0	1.0	9.0	0.2	1.1	1.6	4.8	0.2	9.0	0.2	0.5	0.1	1.0	1.0	2.1	0.5	0.1	0.2	9.0	1.0	0.0	0.5	9.0	1.6	4.5	1.7	2.7	0.1	0.5	0.2	2.5	0.2
α	2.2	1.5	0.8	9.0	6.7	0.5	9.0	2.3	3.1	2.3	1.2	3.0	1.4	3.2	1.1	3.2	8.0	3.7	2.2	9.3	4.1	0.0	4.9	0.5	ლ	6.7	2.3	3.7	1.2	9.0	4.8	2.2	1.5	1.8	3.5	0.8
Date Calibrated	12/23/2015	12/21/2015	12/21/2015	12/22/2015	12/22/2015	12/21/2015	12/21/2015	12/22/2015	12/22/2015	12/31/2015	12/22/2015	1/27/2016	1/27/2016	1/27/2016	12/22/2015	12/22/2015	12/23/2015	12/23/2015	12/22/2015	12/22/2015	12/22/2015	12/22/2015	12/31/2015	12/22/2015	12/22/2015	12/22/2015	12/22/2015	12/22/2015	12/22/2015	12/22/2015	12/22/2015	12/22/2015	12/22/2015	12/22/2015	12/16/2015	12/16/2015
Pitot ID	L-9T	T6-9	T6-10	T6-12P	T6-13	T6-14P	T6-15P	17-1	7-51	19-77	7-101	7-11	7-121	7-13	T8-1P	T8-3	T8-7	T8-8P	T8-9P	T8-19	T8-20	T8-21	8-24	T9-1	T9-2	T10-1	T10-2	T10-2P	T10-4	T12-1	T12-2	T12-3	T12-4	T14-1	Mp-1	Mp-2

TL-#P = Thermocouple, Pitot, and Probe assembly

PL-# = Pitot alone

PL-#I = Inconell

TL-# = Thermocouple and Pitot W#-I = Water Cooled Assembly

TRIP BALANCE

The trip balance is calibrated by comparing it with Class-S standard weights, and it agreed within 0.5g. Calibration data are shown in the following Trip Balance Calibration Data Sheet(s).



BALANCES & SCALES
P.O. Box 276, West Chester, OH 45069
513-777-1525 FAX 513-777-0819

								OF.	DTIL	TO ATE. D4949	0 00	11
COMPANY: Environmental C									KIII	ICATE: <u>D1813</u>	9-00	<u> </u>
LOCATION: 1800 Carillan Dr	ive, Cincinna	ti, O	H 4	5240			Attn: Ron Ko	olde				
MANUFACTURER: Sartorius		. CA	NPΑ	CITY: <u>210g</u>			- Constant	RE	SOLU	JTION: 0.1mg	-	
MODEL: BL210S	SERIAL NO:	910	010	24	ID:		10	S	CHEI	DULE: <u>yearly</u>		
This b	oalance/scale p	erfoi	med	to the followin	g val	lues	on the calibrati	ion d	late:			
WEIGHT	TOLERA	NCE		BEFORE	in	out	AFTER	in	out			
Zero	±0.3m	ıg		0.0000g	V		0.0000g	√				
20g	±0.3m	ıg		20.0003g	√		20.0000g	√				
50g	±0.3m	ıg		50.0009g		√	50.0000g	√				
100g	±0.3m	ıg		100.0015g		√	100.0001g	√				
200g	±0.3m	ıg		200.0028g		√	200.0000g	√				
	CORNERLO	AD	WEI	GHT: 10	00g		TOLERANC	E:		±0.5mg		
	A	in	out	В	in	out	С	in	out	D	in	out
BEFORE READING	+0.0004g	√		0.0000g	√		0.0000g	√		+0.0005g	√	
AFTER READING	0.0000g	√		-0.0003g	\		-0.0004g	\checkmark		0.0000g	√	
WEIGHT SET NUMBER			A50	0028)	1	
NIST TRACEABILITY NUMBER			197	3194				/	_			
NEXT CALIBRATION DUE		D	ecer	nber-16			A) в		
CALIBRATION DATE		14	4-D∈	ec-2015			*					
TECHNICIAN SIGNATURE		ÇX.	lacan	a Levo					_	č		
								79.W				
CALIBRATION SIT	E:	_√	Cu	stomer Site	L	abor	atory Ot	ther				
CALIBRATION ME	THOD:		_ M	anufacturer's Pr	oced	ure	Other					
ISO/IEC 17025:			Com	pliant No	n-co	ompl	iant <u>√</u> N	ot A	pplic	able		
ENVIRONMENT:			Exce	ellent <u>√</u> G	ood	_	_FairP	oor				
NOTES: 2 static masters												



BALANCES & SCALES
P.O. Box 276, West Chester, OH 45069
513-777-1525 FAX 513-777-0819

COMPANY: Environmental C	≀uality Manag	eme	ent, I	nc.				CE	RTIF	TICATE: <u>D1813</u>	9-00)2
LOCATION: 1800 Carillan Dr	ive, Cincinnat	ti, O	H 4	5240			Attn: Ron Ko	olde				
MANUFACTURER: Ohaus		C	APA	CITY: 2000g	J			RE	SOL	UTION: 0.1g		
MODEL: SP2001	SERIAL NO:	712	652	1909	ID:	FB3	3	. SO	CHEI	DULE: <u>yearly</u>		
This t	oalance/scale p	erfo	rmed	to the following	ıg val	ues (on the calibrat	ion d	late:			
WEIGHT	TOLERA	NCE	3	BEFORE	in	out	AFTER	in	out			
Zero	±0.3g	3		0.0g	√		0.0g	√				
200g	±0.3g	9		200.0g	V		200.0g	√				
500g	±0.3g)		500.1g	√		500.0g	√		(2.75)		
1000g	±0.3g)		1000.1g	√		1000.0g	√		11		
2000g	±0.3g	3		2000.2g	√		2000.0g	√				S.
	CORNERLO	AD	WEI	GHT: 10	000g		TOLERANC	E:		±0.3g		
	A	in	out	В	in	out	C	in	out	D	in	out
BEFORE READING	0.0g	√		0.0g	√		0.0g	√		0.0g	V	
AFTER READING	0.0g	√		0.0g	√		0.0g	√		0.0g	√	
WEIGHT SET NUMBER			A50	0120						D		
NIST TRACEABILITY NUMBER			197	3194				_/				
NEXT CALIBRATION DUE		D	ecer	nber-16			A			В		
CALIBRATION DATE		1	4-D∈	ec-2015				/				
TECHNICIAN SIGNATURE		A	luan	a. Levo					`	c		
											J	
CALIBRATION SIT	E:	_√	_ Cı	stomer Site	L	abor	atoryO	ther				
CALIBRATION ME	THOD:		_ M	anufacturer's P	roced	ure	Other					
ISO/IEC 17025:			Com	pliant N	on-co	mpli	iant <u>√</u> N	ot A	pplic	able		
ENVIRONMENT:			Exce	ellent <u>√</u> (Good	577	_FairP	oor				
NOTES:												



BALANCES & SCALES
P.O. Box 276, West Chester, OH 45069
513-777-1525 FAX 513-777-0819

COMPANY: Environmental C	≀uality Manag	ronmental Quality Management, Inc.									9-00)3_
LOCATION: 1800 Carillan Dr	ive, Cincinnat	ti, O	H 4	5240			Attn: Ron Ko	olde				
MANUFACTURER: Ohaus		CA	\PA	CITY: 2000g				. RE	SOLI	UTION: <u>0.1g</u>		
MODEL: SP2001	SERIAL NO:	712	933	0051	ID:	FB4		. S0	CHEI	DULE: <u>yearly</u>		
This b	palance/scale p	erfo	med	to the followin	g val	ues	on the calibrat	ion d	ate:			—
WEIGHT	TOLERA	NCE	2	BEFORE	in	out	AFTER	in	out			
Zero	±0.3g	3		0.0g	√		0.0g	√				
200g	±0.3g)		200.0g	√		200.0g	√				
500g	±0.3g	9		500.0g	√		500.0g	√				
1000g	±0.3g)		1000.0g	√		1000.0g	√				
2000g	±0.3g)		2000.0g	√		2000.0g	√				
	CORNERLO	AD	WEI	GHT: 10)00g		TOLERANC	E:		±0.3g		
	A	in	out	В	in	out	С	in	out	D	in	out
BEFORE READING	0.0g	√		0.0g	√		+0.1g	√		-0.1g	√	Ш
AFTER READING	0.0g	\checkmark		0.0g	√		+0.1g	√		-0.1g		
WEIGHT SET NUMBER			A50	0120						D		
NIST TRACEABILITY NUMBER			197	3194				/				
NEXT CALIBRATION DUE		D	ecer	nber-16			A) в		
CALIBRATION DATE		14	4-De	ec-2015				/				
TECHNICIAN SIGNATURE		Ç≪}	locar	a Levo					`	c		
								28			J	
CALIBRATION SIT	E:	_√	_ Cı	stomer Site	L	abor	atoryO	ther				
CALIBRATION ME	THOD:		_ M	anufacturer's Pr	oced	ure	Other					
ISO/IEC 17025:			Con	npliant N	on-co	mpl	iant <u>√</u> N	lot A	pplic	able		
ENVIRONMENT:			Exce	ellent <u>√</u> C	ood))	_FairP	oor				
NOTES:	w						a.e.v.			41.00		



BALANCES & SCALES
P.O. Box 276, West Chester, OH 45069
513-777-1525 FAX 513-777-0819

COMPANY: Environmental C	Environmental Quality Management, Inc.										9-0	04
LOCATION: 1800 Carillan Dr	ive, Cincinnal	ti, O	H 4	5240			Attn: Ron Ko	olde				
MANUFACTURER: Acculab		CA	APA	CITY:				RE	SOL	JTION: <u>0.1g</u>		
MODEL: VIC - 3101.1	SERIAL NO:	236	548	32	ID:	FB2	2	. SO	CHEI	OULE: yearly		
This t	palance/scale p	erfo	rmed	to the following	ıg va	lues o	on the calibrat	ion d	ate:			
WEIGHT	TOLERA	NCE)	BEFORE	in	out	AFTER	in	out			
Zero	±0.3g	9		0.0g	V		0.0g	V				
500g	±0.3g)		500.0g	√		200.0g	V				
1000g	±0.3g	9		1000.0g	√		500.0g	√				
2000g	±0.3g	9		2000.2g	√		1000.0g	√				
3000g	±0.3g	3		3000.4g		√	3000.1g	√				
	CORNERLO	AD	WEI	GHT: 5	00g		TOLERANC	E:		±0.3g		
	A	in	out	В	in	out	C	in	out	D	in	out
BEFORE READING	+0.1g	√		-0.1g	√		-0.1g	√		0.0g	√	
AFTER READING	+0.1g	√		-0.1g	V		-0.1g	√		0.0g	√	
WEIGHT SET NUMBER			A50	0120)	1	
NIST TRACEABILITY NUMBER			197	3194				/				
NEXT CALIBRATION DUE		D	ecer	nber-16			А			В		
CALIBRATION DATE		14	4-De	ec-2015								
TECHNICIAN SIGNATURE		Sea	east.	a. Levo					`	c c		
						*						
CALIBRATION SIT	E:	_√	_ Cu	stomer Site	L	abor	atoryO	ther				
CALIBRATION ME	THOD:		_ Ma	anufacturer's Pr	oced	ure	Other					
ISO/IEC 17025:			Com	pliantN	on-co	mpli	iant <u>√</u> N	ot A	pplic	able		
ENVIRONMENT:			Exce	ellent $\sqrt{}$	ood		_FairP	oor				
NOTES:										and the second s		



BALANCES & SCALES P.O. Box 276, West Chester, OH 45069 513-777-1525 FAX 513-777-0819

COMPANY: Environmental C	uality Manag	eme	ent, I	nc.				CE	RTIF	TICATE: D1813	9-00)5
LOCATION: 1800 Carillan Dr	ive, Cincinna	ti, O	H 4	5240			Attn: Ron Ko	olde				
MANUFACTURER: Ohaus								RE	SOLU	UTION: 0g		
MODEL: CS2000												
	7			to the followin								
WEIGHT	TOLERA	NCE	2	BEFORE	in	out	AFTER	in	out			
Zero	±3g			0g	√		0g	√				
200g	±3g			200g	√		200g	√				
500g	±3g			500g	√		500g	√				
1000g	±3g			1000g	√		1000g	√				
2000g	±3g			2000g	√		2000g	√				
	CORNERLO	AD	WEI	GHT: 10)00g		TOLERANC	E:		±3g		
	A	in	out	В	in	out	С	in	out	D	in	out
BEFORE READING	0g	√		0g	√		0g	√		0g	V	
AFTER READING	0g	√		0g	√		0g	V		0g	√	
WEIGHT SET NUMBER			A50	0120						D	1	
NIST TRACEABILITY NUMBER			197	3194				/				
NEXT CALIBRATION DUE		D	ecer	nber-16			A			В		
CALIBRATION DATE		1	4-De	ec-2015				/				
TECHNICIAN SIGNATURE		S	over_	a. Lews					`	c		
											J	
CALIBRATION SIT	E:	_√	_ Cu	stomer Site	L	abor	atoryO	ther				
CALIBRATION ME	THOD:		_ Ma	anufacturer's Pr	oced	ure	Other					
ISO/IEC 17025:			Com	pliant No	on-co	ompli	iant <u>√</u> N	lot A	pplic	able		
ENVIRONMENT:			Exce	ellent <u>√</u> C	lood		_FairP	oor				
NOTES:												

CONTINUOUS EMISSION MONITORS CALIBRATION STANDARDS

The calibration gases used for the calibration of the continuous gas analyzers must be within +/- 1 percent of the certified gas value. EQ calibration standards follow the Environmental Protection Agency Traceability Protocol Number 1. The calibration gas certifications used for this study are attached.



2009 BELLAIRE AVE ROYAL OAK, MI 48067 248-399-8020 Airgas.com

CERTIFICATE OF ANALYSIS

Grade of Product: EPA Protocol

Customer:

ENVIRONMENTAL QUALITY

MANAGEMENT

Part Number:

E03NI67E15A00A2

Cylinder Number:

Gas Code:

CC443447

Laboratory: PGVP Number: MIC - Royal Oak-32 (SAP) - MI

B62015

CO2,O2,BALN

Certification Date:

Reference Number:

Cylinder Volume:

32-400628908-1 160.0 CF

Cylinder Pressure: **2015 PSIG** Valve Outlet:

590

Nov 19, 2015

Certification performed in accordance with "EPA Traceability Protocol for Assay and Certification of Gaseous Calibration Standards (May 2012)" document EPA 600/R-12/531, using the assay procedures listed. Analytical Methodology does not require correction for analytical interference. This cylinder has a total analytical uncertainty as stated below with a confidence level of 95%. There are no significant impurities which affect the use of this calibration mixture. All concentrations are on a volume/volume basis unless otherwise noted.

Expiration Date: Nov 19, 2023

			ANALYTICA	L RESULTS		
Compon	ent	Requested Concentration	Actual Concentration	Protocol Method	Total Relative Uncertainty	Assay Dates
OXYGEN CARBON NITROGE	DIOXIDE	11.00 % 22.00 % Balance	11.02 % 21.94 %	G1 G1	+/- 1% NIST Traceable +/- 0.6% NIST Traceable	11/19/2015 11/19/2015
Туре	Lot ID	Cylinder No	CALIBRATION Concentration	STANDARDS	Uncertainty	Expiration Date
NTRM NTRM	98050917 13060812	SG9168288BAL CC416634	16.04 % OXYGEN 24.04 % CARBON	I/NITROGEN I DIOXIDE/NITROGEN	+/- 0.6% +/- 0.6%	Dec 01, 2015 May 16, 2019
Instrume	ent/Make/Mod	le l	ANALYTICAL Analytical Pri	EQUIPMENT	Last Multipoint Calil	bration
E/N 54 Ni	colet 6700 CO2	AT 6 E/N 182	FTIR Paramagnetic		Nov 18, 2015 Oct 23, 2015	

Triad Data Available Upon Request



Signature on file

Approved for Release



2009 BELLAIRE AVE ROYAL OAK, MI 48067 248-399-8020 Airgas.com

CERTIFICATE OF ANALYSIS Grade of Product: EPA Protocol

Customer:

ENVIRONMENTAL QUALITY

MANAGEMENT

Part Number:

E03NI67E15A52R2

Cylinder Number:

CC443456

Laboratory: PGVP Number: MIC - Royal Oak-32 (SAP) - MI

Gas Code: CO2, O2, BALN

B62015

Reference Number: 32-400628907-1

152.9 CF

Cylinder Volume: Cylinder Pressure: 2015 PSIG

590

Valve Outlet: Certification Date: Expiration Date: Nov 18, 2023

Nov 18, 2015

Certification performed in accordance with "EPA Traceability Protocol for Assay and Certification of Gaseous Calibration Standards (May 2012)" document EPA 600/R-12/531, using the assay procedures listed. Analytical Methodology does not require correction for analytical interference. This cylinder has a total analytical uncertainty as stated below with a confidence level of 95%. There are no significant impurities which affect the use of this calibration mixture. All concentrations are on a volume/volume basis unless otherwise noted.

Do Not Use This Cylinder below 100 psig, i.e. 0.7 megapascals.

		ANALYTICA	L RESULTS	# g 6	
Component	Requested Concentration	Actual Concentration	Protocol Method	Total Relative Uncertainty	Assay Dates
CARBON DIOXIDE	11.00 %	11.23 %	G1	+/- 0.7% NIST Traceable	11/18/2015
OXYGEN	22.00 %	21.89 %	G1	+/- 1,0% NIST Traceable	11/18/2015
NITROGEN	Balance				

Туре	Lot ID	Cylinder No	Concentration	Uncertainty	Expiration Date
NTRM	12061344	CC360802	11.002 % CARBON DIOXIDE/NITROGEN	+/- 0.6%	Jan 11, 2018
NTRM	12062011	CC367544	22.883 % OXYGEN/NITROGEN	+/-0.2%	Apr 24, 2018

Instrument/Make/Model	ANALYTICAL EQUIPMENT Analytical Principle	Last Multipoint Calibration
E/N 54 Nicolet 6700 CO2	FTIR	Oct 19, 2015
O2 FS, SIEMENS OXYMAT 6 E/N 182	Paramagnetic	Oct 23, 2015

Triad Data Available Upon Request



Approved for Release



CERTIFICATE OF ANALYSIS

Grade of Product: EPA Protocol

Airgas USA, LLC

· 2009 BELLAIRE AVENUE ROYAL OAK, MI 48067 248-399-8020

Customer:

ENVIRONMENTAL QUALITY

MANAGEMENT

Part Number:

E02NI99E15A0499

Cylinder Number: Laboratory:

CC73679

PGVP Number:

MIC - Royal Oak-32 (SAP) - MI

B62015

Gas Code:

CO BALN

Reference Number:

32-400493989-1

Airgas.com

Cylinder Volume:

144.3 CF 2015 PSIG

Cylinder Pressure: Valve Outlet:

350

Certification Date:

Feb 12, 2015

Expiration Date: Feb 12, 2023

Certification performed in accordance with "EPA Traceability Protocol for Assay and Certification of Gaseous Calibration Standards (May 2012)" document EPA 600/R-12/531, using the assay procedures listed. Analytical Methodology does not require correction for analytical interference. This cylinder has a total analytical uncertainty as stated below with a confidence level of 95%. There are no significant impurities which affect the use of this calibration mixture. All concentrations are on a volume/volume basis unless otherwise noted.

Do Not Use This Cylinder below 100 psig, i.e. 0.7 megapascals.

			ANALYTICAL	RESULTS		
CARBON MONOXIDE NITROGEN		Requested Concentration	Actual Concentration	Protocol Method	Total Relative Uncertainty	Assay Dates
		450.0 PPM Balance	454.8 PPM	G1	+/- 1.0% NIST Traceable	02/12/2015
Туре	Lot ID	Cylinder No	CALIBRATION Concentration	STANDARDS	Uncertainty	Expiration Date
NTRM	12062408	CC199564	487.1 PPM CARBON MO	NOXIDE/NITROGEN	+/-0.6%	Jun 22, 2018
Instrume	nt/Make/Mode	I	ANALYTICAL I Analytical Princip		Last Multipoint Ca	libration
CO SIEMENS ULTRAMAT 6 E/N 173			Nondispersive Infrared(NDIR)		Feb 07, 2015	

Triad Data Available Upon Request





2009 BELLAIRE AVE ROYAL OAK, MI 48067 248-399-8020 Airgas.com

CERTIFICATE OF ANALYSIS

Grade of Product: EPA Protocol

Customer:

ENVIRONMENTAL QUALITY

MANAGEMENT

Part Number:

E02NI99E15A0154

Cylinder Number:

CC66198

Laboratory: PGVP Number: MIC - Royal Oak-32 (SAP) - MI

B62015

Gas Code: -

SO2, BALN

Reference Number: 32-400586127-1

Cylinder Volume:

144.4 CF Cylinder Pressure: 2015 PSIG

Valve Outlet: 660

Certification Date:

Aug 27, 2015

Expiration Date: Aug 27, 2019

Certification performed in accordance with "EPA Traceability Protocol for Assay and Certification of Gaseous Calibration Standards (May 2012)" document EPA 600/R-12/531, using the assay procedures listed. Analytical Methodology does not require correction for analytical interference. This cylinder has a total analytical uncertainty as stated below with a confidence level of 95%. There are no significant impurities which affect the use of this calibration mixture. All concentrations are on a volume/volume basis unless otherwise noted.

Do Not Use This Cylinder below 100 psig, i.e. 0.7 megapascals

			ANALYT	ICAL RESU	LTS		
Component SULFUR DIOXIDE NITROGEN		Requested Concentration	Actual Concentration	Protocol Method	Total Relative Uncertainty +/- 1.0% NIST Traceable		Assay Dates 08/20/2015, 08/27/2015
		45.00 PPM Balance	44,88 PPM	. G1			
			CALIBRATI	ON STANI	DARDS		
Туре .	Lot ID	Cylinder No	Concentration			Uncertainty	Expiration Date
NTRM	12061827	CC352163	50.10 PPM SULF		ROGEN	+/- 1,0%	Арг 24, 2018
			ANALYTIC	AL EQUIP	MENT	· · · · · · · · · · · · · · · · · · ·	
Instrument/Make/Model		Analytical Principle		Lasi	Last Multipoint Calibration		
E/N 54 Nicolet 6700 SO2			FTIR Aug 11, 2015				

Triad Data Available Upon Request





2009 BELLAIRE AVE ROYAL OAK, MI 48067 248-399-8020 Airgas.com

CERTIFICATE OF ANALYSIS

Grade of Product: EPA Protocol

Customer:

ENVIRONMENTAL QUALITY

MANAGEMENT

Part Number:

E02NI99E15A0239 SG9134953BAL

Cylinder Number: Laboratory:

MIC - Royal Oak-32 (SAP) - MI

PGVP Number: Gas Code:

B62016

SO2, BALN

Reference Number: 32-400693191-1

Cylinder Volume:

144.4 CF

Cylinder Pressure:

2015 PSIG

Valve Outlet:

660

Certification Date:

Apr 08, 2016

Expiration Date: Apr 08, 2024

Certification performed in accordance with "EPA Traceability Protocol for Assay and Certification of Gaseous Calibration Standards (May 2012)" document EPA 600/R-12/531, using the assay procedures listed. Analytical Methodology does not require correction for analytical interference. This cylinder has a total analytical uncertainty as stated below with a confidence level of 95%. There are no significant impurities which affect the use of this calibration mixture. All concentrations are on a volume/volume basis unless otherwise noted,

Do Not Use This Cylinder below 100 psig, i.e. 0.7 megapascals.

			ANALYTI	CAL RESU	LTS		
Component SULFUR DIOXIDE NITROGEN		Requested Concentration	Actual Concentration	Protocol Method	Total Relative Uncertainty		Assay Dates
		90.00 PPM 89.09 PPM Balance		G1	+/- 0.9% NIST Traceable		04/01/2016, 04/08/2016
Туре	Lot ID	Cylinder No	CALIBRATION Concentration	ON STANI	DARDS	Uncertainty	Expiration Date
NTRM	12060238	CC351199	95.39 PPM SULFU	JR DIOXIDE/NI	rogen	+/-0.8%	Jan 10, 2018
	•		ANALYTICA		MENT		
Instrument/Make/Model		Analytical Principle Last I		st Multipoint Calib	oration		
E/N 54 Nicolet 6700 SO2		FTIR Mar			r 08, 2016		

Triad Data Available Upon Request



Approved for Release

Page 1 of 32-400693191-1



2009 BELLAIRE AVE ROYAL OAK, MI 48067 248-399-8020 Airgas.com

CERTIFICATE OF ANALYSIS

Grade of Product: EPA Protocol

Customer:

ENVIRONMENTAL QUALITY

MANAGEMENT

Part Number:

E02NI99E15A1004

Cylinder Number:

CC21157

Laboratory:

MIC - Royal Oak-32 (SAP) - MI

PGVP Number: Gas Code:

B62016

SO2.BALN

Reference Number:

Cylinder Volume:

32-400693196-1

144.4 CF

Cylinder Pressure:

2015 PSIG

Valve Outlet:

660

Certification Date:

Apr 08, 2016

Expiration Date: Apr 08, 2024

Certification performed in accordance with "EPA Traceability Protocol for Assay and Certification of Gaseous Calibration Standards (May 2012)" document EPA 600/R-12/531, using the assay procedures listed. Analytical Methodology does not require correction for analytical interference. This cylinder has a total analytical uncertainty as stated below with a confidence level of 95%. There are no significant impurities which affect the use of this calibration mixture. All concentrations are on a volume/volume basis unless otherwise noted.

Do Not Use This Cylinder below 100 psig, i.e. 0.7 megapascals.

		`	ANALYTI	CAL RESU	LTS	•		
Component SULFUR DIOXIDE NITROGEN		Requested Concentration	Actual Concentration	Protocol Method	Total Relative Uncertainty +/- 1.0% NIST Traceable		Assay Dates 04/01/2016, 04/08/2016	
		190.0 PPM Balance	189.4 PPM	G1				
		······································	CALIBRATI	ON STANI	DARDS			
Туре	Lot ID	Cylinder No	Concentration			Uncertainty	Expiration Date	
NTRM	15060637	CC450476	248.1 PPM SULF	JR DIOXIDE/NIT	ROGEN	+/-0.6%	Dec 17, 2020	
			ANALYTIC	AL EQUIP	MENT	,		
Instrument/Make/Model			Analytical Principle		Las	Last Multipoint Calibration		
E/N 54 Nicolet 6700 SO2			FTIR		Ma	Mar 08, 2016		

Triad Data Available Upon Request

Approved for Release

Page 1 of 32-400693196-1



2009 BELLAIRE AVE ROYAL OAK, MI 48067 248-399-8020 Airgas.com

CERTIFICATE OF ANALYSIS

Grade of Product: EPA Protocol

Customer:

ENVIRONMENTAL QUALITY

MANAGEMENT

Part Number:

E02NI99E15A0259

Cylinder Number: Laboratory:

CC208805.

PGVP Number:

MIC - Royal Oak-32 (SAP) - MI

B62016 SO2, BALN

Gas Code:

Reference Number: 32-400693192-1

Cylinder Volume:

Cylinder Pressure:

Valve Outlet:

2015 PSIG 660

144.4 CF

Certification Date:

Apr 11, 2016

Expiration Date: Apr 11, 2024

Certification performed in accordance with "EPA Traceability Protocol for Assay and Certification of Gaseous Calibration Standards (May 2012)" document EPA 600/R-12/531, using the assay procedures listed. Analytical Methodology does not require correction for analytical interference. This cylinder has a total analytical uncertainty as stated below with a confidence level of 95%. There are no significant impurities which affect the use of this calibration mixture, All concentrations are on a volume/volume basis unless otherwise noted.

Do Not Use This Cylinder below 100 psig, i.e. 0.7 megapascals.

	•		ANALYTI	CAL RESU	LTS		
Component SULFUR DIOXIDE NITROGEN		Requested Concentration	Actual Concentration	Protocol Method	Total Relative Uncertainty		Assay Dates
		450.0 PPM 453.7 PPM Balance		G1 +/- 1.1%		NIST Traceable	04/04/2016, 04/11/2016
Туре	Lot ID	Cylinder No	CALIBRATI Concentration	ON STANI	DARDS	Uncertainty	Expiration Date
NTRM	16060117	CC437401	515.2 PPM SULF	UR DIOXIDE/NI		+/- 0.8%	Nov 16, 2021
			ANALYTIC				
Instrume	nt/Make/Mo	del	Analytical Princi	ple	Las	st Multipoint Calib	oration
E/N 54 Nicolet 6700 SO2			FTIR	•	Apr	11, 2016	The second secon

Triad Data Available Upon Request



Approved for Release

Page 1 of 32-400693192-1