



UNITED STATES ENVIRONMENTAL PROTECTION AGENCY

SITE:	G.P.
BREAK:	1.2
OTHER:	

REGION 4

Science and Ecosystem Support Division
980 College Station Road
Athens, Georgia 30605-2720

May 29, 2003

10086217

4-SESD-EAB



MEMORANDUM

SUBJECT: Coosa River PCB TMDL Environmental Sampling Report

FROM: Lonnie Dorn *L.D*
Ecological Evaluation Section
Science & Ecosystem Support Division

Laura McGrath *Lcm*
Ecological Evaluation Section
Science & Ecosystem Support Division

THRU Bill Cosgrove, Chief *BCG*
Ecological Evaluation Section
Ecological Assessment Branch
Science & Ecosystem Support Division

TO: William Melville, Chief
TMDL Modeling and Support Section
Standards, Monitoring & TMDL Branch
Water Management Division

Enclosed is a copy of the final Coosa River PCB TMDL Environmental Sampling Report. If you have questions or comments on the report, please contact one of Project Leaders (Dorn x8683, McGrath x8776) or myself at 355-8616. Thanks for your support on this project.

Enclosure

✓ cc: Jim Kutzman (Waste Division)

COOSA RIVER PCB TMDL ENVIRONMENTAL SAMPLING REPORT

APRIL 2003



PREPARED BY:

**U.S. EPA, Region 4
Science and Ecosystem Support Division
Ecological Assessment Branch
Athens, Georgia**

PREPARED FOR:

**U.S. EPA, Region 4
Water Management Division
Water Quality Planning and Assessment Branch
Atlanta, Georgia**

BACKGROUND	3
SUMMARY	4
Sediment Sampling	4
Fish Sampling	4
Sediment Results	5
Fish Results	5
DISCUSSION OF RESULTS	7
Sediment	7
Fish Tissue Results	8
LITERATURE CITED	10
APPENDIX A	
TABLES	11
APPENDIX B	
FIGURES	13

INTRODUCTION

The U.S. Environmental Protection Agency's Region 4 Science and Ecosystem Support Division (SESD) was tasked by the Region 4 Water Management Division (WMD) to provide data for use in the derivation of a polychlorinated biphenyl (PCB) total maximum daily load (TMDL) for the segment of the Coosa River from Rome, GA to Lake Logan Martin near Pell City, AL.

BACKGROUND

The primary source of the PCBs is reported to be the General Electric (GE) Plant in Rome, Georgia. GE opened the plant in 1953. PCBs were used in the manufacture of transformers from 1953 until April 1977. In 1969, the GE plant was connected to the City of Rome's sewer system. Prior to that time, untreated wastewater was discharged to receiving waters. Originally, there were four storm water discharge drainage ditches referred to as Outfalls 001-004 in the NPDES permit. Outfalls 001 and 003 drained into Horseleg Creek and then into the Coosa River. Outfalls 002 and 004 drained into Little Dry Creek and then into the Oostanaula River.

In January 2002, at the request of GE-Rome, Blasland, Bouck and Lee, Inc. (BBL) conducted an environmental investigation in the Coosa River and selected tributaries to the Coosa River from Rome, GA to the Georgia-Alabama state line. BBL collected sediment samples from transects at eight stations in the Coosa River. Three points were sampled along each transect using a vibratory coring device similar to the one used by EPA (see Summary). Figure 1 in Appendix B shows the locations of the BBL samples and concentrations relative to depth. Table 1 in Appendix A contains the analytical results of the BBL sampling effort. None of the BBL samples contained PCBs equal to or greater than the Comprehensive Environmental Response Compensation and Liability Act (CERCLA) action level of 1 mg/kg. Sample R6-SD3 at a depth of 36"-60" contained 0.75 mg/kg and 0.82 mg/kg of Aroclors 1242 and 1260, respectively. During the EPA study in November 2002, sample SCR4 was collected in the same vicinity as R6-SD3 at 36"-60". SCR4 also contained levels of aroclors 1242 and 1260. The aroclors were detected in each of the three intervals sampled, but at lower levels than detected by BBL. It should be noted, the reporting limits of the analyses completed by BBL were approximately one order of magnitude higher than the reporting limits for the analyses completed on samples collected and analyzed by EPA.

During the weeks of November 8, 2002 and December 9, 2002, sediment and fish tissue samples were collected from the Coosa River system beginning in Rome, Georgia and concluding in Lake Logan Martin near Pell City, Alabama. Sampling began in the Coosa River downstream of the confluence of the Oostanaula and Etowah Rivers and concluded at Logan Martin Lake north of the I-20 overpass. A list of sediment sample stations and their locations are provided in Table 2 of Appendix A. The sediment sample stations are also depicted graphically in Figure 2 of Appendix B.

SUMMARY

Sediment Sampling

Sediment samples were collected from fourteen locations. Depositional areas of fine grained sediments were targeted for sampling. The samples were collected with a vibratory corer, which consisted of a 10' long, 3" diameter steel barrel with a tapered nose cone and retention device. A disposable plastic liner was threaded into the barrel at each sample location. The barrel was attached to a weighted, vibratory unit and advanced to refusal through a combination of vibration and direct weight. Upon retrieval the plastic liner was removed from the barrel. The core was measured and divided into intervals. In general, each core was sampled at the following intervals: 1) 0"-6"; 2) 6"-18"; 3) 18"-30"; 4) 30"-42"; 5) 42"-54". The actual sample interval was based on the total length of the core. The sediment samples were analyzed for PCB aroclors, percent volatile solids and particle size distribution. The intervals for each sample and the results for the PCB and percent volatile solids analyses are listed in Table 3 in Appendix A. Particle size distribution results for each station are depicted graphically in Figures 3-16 in Appendix B.

Fish Sampling

Since a TMDL will likely be based on human exposure to PCB's via fish consumption, legal-sized fish of species normally caught for human consumption were targeted for collection. At each station efforts were made to collect five trophic level 4 fish (top predator) and five trophic level 3 fish (bottom feeder). The trophic level 4 fish (the larger, primarily piscivorous, secondary carnivores) included largemouth bass and spotted bass. Trophic level 3 fish included catfish (channel and blue) and smallmouth buffalo.

Fish were sampled at seven sites along the Coosa River. Sample sites were selected based on sites previously sampled by the states. Three sites were within the state of Georgia from Rome to the Alabama state line. The most upstream sample collection site was above the Mayo's Bar Lock and Dam structure and just downstream of the confluence of the Etowah River and the Oostanaula River, near River Mile 2. The second site was below Hwy 100. The third site was at Brushy Branch/Fosters Bend near the State line. There were two sample sites within Lake Weiss. The first was in the vicinity of Poole's Ferry near Channel Marker 101. The second was upstream of the dam forebay in the vicinity of Bay Springs Marina. Two sample sites were located on the Coosa River downstream of the Weiss Dam Powerhouse. The first was in upper Neely Henry Reservoir in the vicinity of Croft Ferry near Murrycross, AL. The second was in the vicinity of the Interstate 20 bridge in Logan Martin Reservoir. Fish were collected from areas conducive to electrofishing, as close as possible to the target sample locations. Actual coordinates were obtained at sample locations using boat mounted or hand held GPS. Figures 17-23 show the reach where the fish samples were collected as well as the average aroclor 1260 concentration by trophic levels.

Immediately after collection, fish were chilled on wet ice. Fish were filleted in the field and the fillets frozen within 48 hours of collection. Processing followed general guidance described in US EPA (2000a) and the standard operating procedures specific to SESD (EPA

2002 Section 12). The two skin-on fillets including belly flap from each fish, homogenized together, constituted one fish sample. For scaleless fish (catfish), the sample consisted of skinned fillets. Fillets were homogenized using a high speed blender and dry ice. Five fish tissue samples were analyzed for PCB aroclors from each station for each trophic level using method 8082 according to US EPA 2000b. Fish tissue was analyzed for PCB aroclors 1016, 1221, 1232, 1242, 1248, 1254, and 1260. Three fish tissue samples from each station for each trophic level were analyzed for PCB congeners. PCB congener analyses were completed on the three largest fish from each trophic level.

Sediment Results

Relative to the CERCLA action level of 1 mg/kg, low to very low levels of PCB aroclors 1242, 1254, and 1260 were detected in varying combinations in the sediment samples collected throughout the study area. Figure 24 in Appendix B shows the total aroclor concentrations in the sediment samples at each sample interval from the most upstream to the most downstream location. There are no obvious contaminant patterns based on the results as depicted in Figure 24. The greatest individual aroclor concentration was detected in sample SLW1E at 610 µg/kg (Aroclor 1254) which is the equivalent of 0.610 mg/kg. This sample was collected from the eastern end of Lake Weiss from a depth range of 48"- 60". The 0" - 6" sediment interval is considered the most critical from an ecological standpoint because this is generally regarded as the zone of biological activity where macroinvertebrate organisms reside which are involved in foodweb dynamics. The greatest individual aroclor concentration detected in the 0" - 6" range was in sample SNHUA at 220 µg/kg (Aroclor 1260), which is the equivalent of 0.220mg/kg. This is well below the CERCLA action level of 1 mg/kg.

Fish Results

Both the state of Alabama and the state of Georgia have issued fish consumption advisories for segments of the Coosa River. The results of the fish tissue analyses from this study support the need for fish advisories based on the action levels used by both states. It should be noted that Georgia has a more conservative protocol for issuing fish advisories than does Alabama. Alabama issues fish advisories based on FDA action levels. The FDA action level for no consumption is 2 ppm for total PCB's while fish tissue with concentration of 1.0 to 1.99 ppm have limited consumption. A limited consumption advisory states that women of reproductive age and children less than 15 years old should avoid eating certain fish from the listed sites. Other people should limit their consumption of the particular species to one meal per month. Fish tissue concentrations less than 1.0 ppm are not limited in consumption. The action levels for Georgia are tiered to limit fish consumption to 1 meal per month for total PCB concentrations of 0.3-0.99 ppm, 1 meal per week for concentrations of 0.1-0.29 ppm and no restriction for fish with concentrations less than 0.1 ppm. The Georgia action level for total restriction for eating fish is 1.0 p.m. The Georgia and Alabama action levels are higher than the EPA screening value for recreational fishers which is 0.02 ppm.

Aroclor 1260 was detected in all fish samples. Aroclor 1016, 1221, 1232, 1242, 1248, and 1254 were generally not detected in the fish tissue. Concentrations of aroclor 1260 were found to be highest in the trophic level 3 fish. The mean tissue concentration for aroclor 1260

for all trophic level 3 fish was calculated to be 0.51 mg/kg. The highest concentration of aroclor 1260 was detected in a smallmouth buffalo from station CR1 at a concentration of 3.8 mg/kg. In comparison all trophic level 4 fish tissue concentrations for aroclor 1260 were lower resulting in a mean concentration of 0.2981 mg/kg. The PCB concentrations in fish tissue from this study are generally consistent with the guidance Georgia and Alabama recommends for eating fish from the sampled segments of the Coosa River.

The smallmouth buffalo samples collected at station CR1 had an average aroclor 1260 concentration of 1.1 mg/kg which supports the "do not eat" restriction that the State of Georgia has assessed based on their latest sampling. Spotted bass collected from CR1 had an average aroclor concentration of 0.54 mg/kg which would limit the consumption to 1 meal per month based on the Georgia guidelines. This is more restrictive than the current Georgia recommendation at this site which is 1 meal per week. The Georgia guidelines for site CR2 which is down stream of CR1 limit smallmouth buffalo consumption to 1 meal per month and largemouth bass to 1 meal per week. Smallmouth buffalo collected from site CR2 for this study had an average aroclor 1260 concentration of 0.71 mg/kg and largemouth bass had an average aroclor 1260 concentration of 0.11 mg/kg. The fish tissue concentrations for site CR2 from this study supports the consumption limits recommended by the Georgia guidelines for smallmouth buffalo and largemouth bass. Smallmouth buffalo collected for this study at site CR3 which is down stream of CR2 near the Alabama/Georgia state line had an average aroclor 1260 concentration of 0.14 mg/kg while the largemouth bass collected at this site had an average aroclor concentration of 0.41 mg/kg. Georgia recommends limiting the consumption of smallmouth buffalo at this site to 1 meal per month and largemouth bass to 1 meal per week. The results from this study indicated a consumption limit of 1 meal per week for smallmouth buffalo and 1 meal per month for largemouth bass based on the Georgia fish consumption guidelines.

Smallmouth buffalo collected for this study at site LW1 which is down stream of site CR3 and located in the upper portion of Lake Weiss had an average aroclor 1260 concentration of 0.36 mg/kg while largemouth bass collected at this site had an average aroclor 1260 concentration of 0.28 mg/kg. Alabama has no current advisory for these fish species at this site. However, catfish over one pound are listed as limited consumption for this site. Based on the Georgia guidelines smallmouth buffalo would be limited to 1 meal per month and largemouth bass would be limited to 1 meal per week. Smallmouth buffalo collected for this study at site LW2 which is down stream of site LW1 and located in the lower portion of Lake Weiss had an average aroclor 1260 concentration of 0.74 mg/kg while largemouth bass collected at this site had an average aroclor 1260 concentration of 0.19 mg/kg. One blue catfish over one pound was collected at this site and had an aroclor 1260 concentration of 0.23 mg/kg. The state advisory for catfish over one pound are listed as limited consumption for this site. The results of this analysis does not support the current advisory of limited consumption for catfish over one pound. Alabama has no current advisory for smallmouth buffalo or largemouth bass at this site. Based on the Georgia guidelines smallmouth buffalo would be limited to 1 meal per month and largemouth bass would be limited to 1 meal per week. Largemouth bass collected at site UNH for this study which is located down stream of Lake Weiss had an average aroclor 1260 concentration of 0.17 mg/kg while spotted bass had an average aroclor 1260 concentration of 0.54mg/kg. Smallmouth buffalo collected from this site

had an average aroclor 1260 concentration of 0.53 mg/kg. Alabama has no current fish advisory for this segment of the Coosa River. Based on the Georgia guidelines smallmouth buffalo and spotted bass would be limited to 1 meal per month while largemouth bass would be limited to 1 meal per week. Catfish collected at site LM which is the most down stream sampling point had an average aroclor 1260 concentration of 0.19 mg/kg while largemouth bass collected from this site had an average aroclor 1260 concentration of 0.16 mg/kg. The aroclor 1260 concentration in the largest catfish collected from this site which was over one pound was 0.19 mg/kg. Based on the Georgia guidelines catfish would be limited to 1 meal per week while largemouth bass would also be limited to 1 meal per week. The results of the aroclor analysis the, action levels used by Georgia and Alabama to issue fish advisories as well as the EPA screening levels (EPA 2000a) for carcinogens and noncarcinogens in fish tissue are displayed in Tables 4-10 in Appendix A . The results of this study indicated all fish samples collected exceeded the EPA screening level of 0.02 ppm for total PCB's for carcinogens as related to the recreational fishers. Figure 25 in Appendix B shows aroclor 1260 concentrations in all smallmouth buffalo regardless of size exceeded the EPA screening level of 0.02 ppm. Figure 26 in Appendix B shows aroclor 1260 tissue concentrations in all largemouth bass regardless of size exceeded the EPA screening value for of 0.02 ppm for total PCB's.

DISCUSSION OF RESULTS

Sediment

Low levels of several PCB aroclors were detected in the sediment samples. Figure 2 (Appendix B) shows the total aroclor concentrations at each station for each depth sampled. The individual aroclor values for each station were summed to arrive at the total aroclor value. Non-detects were assumed to have a value of zero. This assumption was made because the intent of Figure 2 is to show an overall snapshot of the PCB levels detected during this study. PCBs were detected in the 0" - 6" interval, at the concentrations listed, in the following samples:

	Sample	Individual Aroclor Concentration ($\mu\text{g}/\text{kg}$)			Total Aroclor Concentration ($\mu\text{g}/\text{kg}$)
		1242	1254	1260	
Upstream  Downstream	SCR4A	5.5J	--	15J	20.5J
	SLW1A	3.6J	7.7J	--	11.3J
	SLW2A	--	11J	--	11J
	SNHUA	--	--	220	220
	SNH3A	--	17	--	17
	SLMA	--	5.4J		5.4J

-- - Analyte not detected at or above reporting limit.

J - Identification of analyte is acceptable; reported value is an estimate.

These levels are considered extremely low with the exception of SNHU (220 µg/kg). However, 220 µg/kg is a great deal less than the CERCLA action level of 1 mg/kg.

Sporadic detections of higher PCB levels were found in several samples at depths greater than 6 inches. Following is a list of those samples, their concentrations, and depths.

	Sample	Individual Aroclor Concentration (µg/kg)			Total Aroclor Concentration (µg/kg)	Depth from Sediment Surface
		1242	1254	1260		
Upstream 	SCR5B	--	--	150J	150J	6" - 18"
	SLW1D	33J	--	72J	105J	36" - 48"
	SLW1E	--	610J	--	610	48" - 60"
	SLW2D	--	400J	--	400	36" - 48"
	SNHUB	--	--	220	220	6" - 18"
	SNH3C	--	160	--	160	18" - 30"
	SNH3D	35	110	70	215	30" - 42"
	SLMD	23	100	50	173	36" - 48"

-- - Analyte not detected at or above reporting limit.

J - Identification of analyte is acceptable; reported value is an estimate.

There is little risk of exposure to the macroinvertebrate organisms involved in foodweb dynamics or trophic level 3 fish at depths greater than 6" below the sediment surface. None of the deeper sediment intervals contained PCB levels greater than the CERCLA action level of 1 mg/kg.

None of the samples contained greater than 10 percent volatile solids. This indicates that the sample was composed primarily of sediment as opposed to detritus material. Clay and silt were the predominant fractions (>50 %) in the majority of the samples confirming that the goal of targeting fine sediment deposits was accomplished. No direct correlation can be made between sediment constitution and PCB presence/absence or quantity present with the data from this study.

Fish Tissue Results

The results of fish tissue analysis detected the presence of PCB aroclor 1260 in all fish samples. Specific PCB congener analysis also detected the presence of certain dioxin-like PCB's in all but one of the fish samples. The results from the congener analyses were used to calculate Toxicity Equivalency Quotients (TEQ's) based on Toxicity Equivalency Factors (TEF's) as outlined by the World Health Organization (WHO). The TEF's indicate a specific congener's toxicity relative to 2,3,7,8-tetrachlorodibenzo-p-dioxin (2378-TCDD). The TEQ's for samples

submitted for congener analyses were calculated three different ways in order to identify variability based on values reported as the reporting limit. Because of the high reporting limits the first and most conservative approach was to calculate the TEQ's using one-half of the reporting limit value for a specific congener. The second approach was to calculate the TEQ's using one-tenth of the reporting limit for a specific congener. The third and least conservative approach was to calculate the TEQ's using only the detected values. U.S. EPA Superfund Risk Assessment has established human health risk screening levels for PCB congeners. The results of this study revealed that all fish tissue samples collected from the reach sampled exceeded the first tier screening value of 2.1×10^{-8} used to document the magnitude of risk at a site, and the primary causes of that risk. The TEQ calculations using the detected values only, the calculations using one-half the MQL, and the calculations using one-tenth of the MQL for each site are provided in Tables 11-31 in Appendix A. Table 32 in Appendix A shows the physical measurements of the fish collected as well as the locational data where the samples were collected.

There was no significant difference in fish tissue PCB aroclor 1260 concentrations among the sampled sites when plotted by station, the variability in the size of fish and species collected limited comparison from site to site. Figure 27 in Appendix B shows the mean concentrations of aroclor 1260 for all trophic level 4 fish species by station. The overlapping standard deviations indicate no distinction can be made by station for aroclor 1260. The mean concentrations of aroclor 1260 for all trophic level 3 fish species are presented in Figure 28 in Appendix B. The overlapping standard deviations indicate no distinction can be made by station for aroclor 1260. No concentration gradient can be established for Aroclor 1260 due to the overlapping standard deviations as illustrated by Figures 27 and 28. The geometric mean for aroclor 1260 concentrations in trophic level 3 fish was calculated to be 0.3283 mg/kg. The geometric mean for aroclor 1260 concentrations in trophic level 4 fish was calculated to be 0.2325mg/kg.

LITERATURE CITED

- U.S. EPA. 2002. *Ecological Assessment Standard Operating Procedures and Quality Assurance Manual*. US Environmental Protection Agency, Region 4, Science and Ecosystem Support Division, Ecological Assessment Branch, Athens, GA.
- U.S. EPA. 2000a. *Guidance for Assessing Chemical Contaminant Data for Use in Fish Advisories, Third Edition*. Office of Science and Technology, Office of Water, Washington, DC.
- U.S. EPA. 2000b. *Analytical Support Branch Laboratory Operations and Quality Assurance Manual*. US Environmental Protection Agency, Region 4, Science and Ecosystem Support Division, Athens, GA.

APPENDIX A
TABLES

Table 2
Sample Stations and Locations

Sample I.D.	Station Location	Lat/Long
SCR1	Coosa River, Station 1	34 15.422/85 10.941
SCR3	Coosa River, Station 3	34 12.000/85 15.324
SCR4	Coosa River, Station 4	34 14.982/85 20.546
SCR5	Coosa River, Station 5	34 14.919/85 21.875
SCR6	Coosa River, Station 6	34 11.984/85 23.830
SLW1	Lake Weiss, Station 1	34 12.045/85 30.420
SLW2	Lake Weiss, Station 2	34 10.664/85 35.421
SLW3	Lake Weiss, Station 3	34 10.933/85 44.575
SLW4	Lake Weiss, Station 4	34 08.764/85 47.404
SNH1	Neely Henry Lake, Station 1	34 00.497/85 54.449
SNH2	Neely Henry Lake, Station 2	33 57.793/85 58.453
SNH3	Neely Henry Lake, Station 3	33 48.534/86 03.833
SNHU	Neely Henry Lake, Station 4	34 05.540/85 51.873
SLM	Logan Martin Lake	33 36.548/86 11.964

Table 3
EPA PCB Results
Sediment Samples
Coosa River TMDL
Nov/Dec 2002

		SCR1A 11/19/2002	SCR1B 11/19/2002	SCR3A 11/19/2002	SCR3B 11/19/2002	SCR3C 11/19/2002
		19:45 0" - 6"	9:45 6" - 18"	16:20 0" - 6"	16:20 6" - 18"	16:20 18" - 28"
PCB-1242 (Aroclor 1242)	µg/kg	5.3 UJ	5.6 UJ	6.2 U	6.2 U	6.4 U
PCB-1254 (Aroclor 1254)	µg/kg	5.3 UJ	5.6 UJ	6.2 U	6.2 U	6.4 U
PCB-1221 (Aroclor 1221)	µg/kg	5.3 UJ	5.6 UJ	6.2 U	6.2 U	6.4 U
PCB-1232 (Aroclor 1232)	µg/kg	5.3 UJ	5.6 UJ	6.2 U	6.2 U	6.4 U
PCB-1248 (Aroclor 1248)	µg/kg	5.3 UJ	5.6 UJ	6.2 U	6.2 U	6.4 U
PCB-1260 (Aroclor 1260)	µg/kg	5.3 UJ	5.6 UJ	6.2 U	6.2 U	6.4 U
PCB-1016 (Aroclor 1016)	µg/kg	5.3 UJ	5.6 UJ	6.2 U	6.2 U	6.4 U
Moisture	%	22	26	21	20	21
Volatile Solids	%	0.45	2.7	0.76	0.69	0.48
		SCR4A 11/20/2002	SCR4B 11/20/2002	SCR4C 11/20/2002	SCR5A 11/20/2002	SCR5B 11/20/2002
		11:10 0" - 6"	11:10 6" - 18"	11:10 18" - 24"	12:45 0" - 6"	12:45 6" - 18"
PCB-1242 (Aroclor 1242)	µg/kg	5.5 J	3.4 J	12 J	14 UJ	36 UJ
PCB-1254 (Aroclor 1254)	µg/kg	15 UJ	20 UJ	33 UJ	19 UJ	150 UJ
PCB-1221 (Aroclor 1221)	µg/kg	9.3 UJ	7.4 UJ	7.6 UJ	14 UJ	36 UJ
PCB-1232 (Aroclor 1232)	µg/kg	9.3 UJ	7.4 UJ	7.6 UJ	14 UJ	36 UJ
PCB-1248 (Aroclor 1248)	µg/kg	9.3 UJ	7.4 UJ	7.6 UJ	14 UJ	36 UJ
PCB-1260 (Aroclor 1260)	µg/kg	15 J	20 J	33 J	19 J	150 J
PCB-1016 (Aroclor 1016)	µg/kg	9.3 UJ	7.4 UJ	7.6 UJ	14 UJ	36 UJ
Moisture	%	44	40	39	44	29
Volatile Solids	%	5.1	6.2	6.2	5	3.8
		SCR5C 11/20/2002	SCR6A 11/20/2002	SCR6B 11/20/2002	SCR6C 11/20/2002	SCR6D 11/20/2002
		12:45 18" - 24"	14:25 0" - 6"	14:25 6" - 18"	14:25 18" - 30"	14:25 30" - 36"
PCB-1242 (Aroclor 1242)	µg/kg	6.6 UJ	8.0 U	7.2 UJ	6.7 U	7.1 UJ
PCB-1254 (Aroclor 1254)	µg/kg	6.6 UJ	8.0 U	7.2 UJ	6.7 U	7.1 UJ
PCB-1221 (Aroclor 1221)	µg/kg	6.6 UJ	8.0 U	7.2 UJ	6.7 U	7.1 UJ
PCB-1232 (Aroclor 1232)	µg/kg	6.6 UJ	8.0 U	7.2 UJ	6.7 U	7.1 UJ
PCB-1248 (Aroclor 1248)	µg/kg	6.6 UJ	8.0 U	7.2 UJ	6.7 U	7.1 UJ
PCB-1260 (Aroclor 1260)	µg/kg	5.9 J	8.0 U	7.2 UJ	6.7 U	7.1 UJ
PCB-1016 (Aroclor 1016)	µg/kg	6.6 UJ	8.0 U	7.2 UJ	6.7 U	7.1 UJ
Moisture	%	25	25	27	25	25
Volatile Solids	%	1.6	4.2	4.6	4.5	3.9

— Compound Detected.

U — Analyte not detected at or above reporting limit.

J — Estimated Value.

UJ — Analyte not detected at or above reporting limit. Reporting limit is an estimate.

Table 3 (cont)
EPA PCB Results
Sediment Samples
Coosa River TMDL
Nov/Dec 2002

		SLW1A 11/21/2002	SLW1B 11/21/2002	SLW1C 11/21/2002	SLW1D. 11/21/2002	SLW1E 11/21/2002
		10:30	10:30	10:30	10:30	10:30
		0" - 6"	6" - 24"	24" - 36"	36" - 48"	48" - 60"
PCB-1242 (Aroclor 1242)	µg/kg	[REDACTED]	[REDACTED]	[REDACTED]	[REDACTED]	210 UJ
PCB-1254 (Aroclor 1254)	µg/kg	[REDACTED]	28 UJ	27 UJ	72 UJ	[REDACTED]
PCB-1221 (Aroclor 1221)	µg/kg	8.0 UJ	10 UJ	13 UJ	33 UJ	210 UJ
PCB-1232 (Aroclor 1232)	µg/kg	8.0 UJ	10 UJ	13 UJ	33 UJ	210 UJ
PCB-1248 (Aroclor 1248)	µg/kg	8.0 UJ	10 UJ	13 UJ	33 UJ	210 UJ
PCB-1260 (Aroclor 1260)	µg/kg	7.7 UJ	[REDACTED]	[REDACTED]	[REDACTED]	610 UJ
PCB-1016 (Aroclor 1016)	µg/kg	8.0 UJ	10 UJ	13 UJ	33 UJ	210 UJ
Moisture	%	48	39	43	37	39
Volatile Solids	%	6.4	4.5	6	6.1	5.6
		SLW2A 11/21/2002	SLW2B 11/21/2002	SLW2C 11/21/2002	SLW2D 11/21/2002	SLW2E 11/21/2002
		12:25	12:25	12:25	12:25	12:25
		0" - 6"	6" - 24"	24" - 36"	36" - 48"	48" - 60"
PCB-1242 (Aroclor 1242)	µg/kg	9.8 UJ	12 U	[REDACTED]	82 UJ	13 UJ
PCB-1254 (Aroclor 1254)	µg/kg	[REDACTED]	23 U	[REDACTED]	[REDACTED]	[REDACTED]
PCB-1221 (Aroclor 1221)	µg/kg	9.8 UJ	12 U	13 UJ	82 UJ	13 UJ
PCB-1232 (Aroclor 1232)	µg/kg	9.8 UJ	12 U	13 UJ	82 UJ	13 UJ
PCB-1248 (Aroclor 1248)	µg/kg	9.8 UJ	12 U	13 UJ	82 UJ	13 UJ
PCB-1260 (Aroclor 1260)	µg/kg	11 UJ	[REDACTED]	57 UJ	400 UJ	30 UJ
PCB-1016 (Aroclor 1016)	µg/kg	9.8 UJ	12 U	13 UJ	82 UJ	13 UJ
Moisture	%	53	48	48	45	32
Volatile Solids	%	7.4	7.1	6.9	6.2	5.6
		SLW3A 12/12/2002	SLW3B 12/12/2002	SLW4A 12/12/2002	SLW4B 12/12/2002	SLMA 12/9/2002
		12:42	12:42	10:10	10:10	14:35
		0" - 6"	6" - 17"	0" - 6"	6" - 17"	0" - 6"
PCB-1242 (Aroclor 1242)	µg/kg	5.6 U	5.2 UJ	4.9 U	5.0 U	8.0 U
PCB-1254 (Aroclor 1254)	µg/kg	5.6 U	5.2 UJ	4.9 U	5.0 U	[REDACTED]
PCB-1221 (Aroclor 1221)	µg/kg	5.6 U	5.2 UJ	4.9 U	5.0 U	8.0 U
PCB-1232 (Aroclor 1232)	µg/kg	5.6 U	5.2 UJ	4.9 U	5.0 U	8.0 U
PCB-1248 (Aroclor 1248)	µg/kg	5.6 U	5.2 UJ	4.9 U	5.0 U	8.0 U
PCB-1260 (Aroclor 1260)	µg/kg	5.6 U	5.2 UJ	4.9 U	5.0 U	8.0 U
PCB-1016 (Aroclor 1016)	µg/kg	5.6 U	5.2 UJ	4.9 U	5.0 U	8.0 U
Moisture	%	26	22	17	19	49
Volatile Solids	%	3.2	2.6	1.7	1.7	7.5

[REDACTED] — Compound Detected

U — Analyte not detected at or above reporting limit.

J — Estimated Value.

UJ — Analyte not detected at or above reporting limit. Reporting limit is an estimate.

Table 3 (cont)
 EPA PCB Results
 Sediment Samples
 Coosa River TMDL
 Nov/Dec 2002

		SLMB 12/9/2002	SLMC 12/9/2002	SLMD 12/9/2002	SLME 12/9/2002	SNH1A 12/11/2002
		14:35	14:35	14:35	14:35	9:58
		6" - 24"	24" - 36"	36" - 48"	48" - 60"	0" - 6"
PCB-1242 (Aroclor 1242)	µg/kg	7.7 U	17 U	23	53	5.7 U
PCB-1254 (Aroclor 1254)	µg/kg	10	81	100	32 U	5.7 U
PCB-1221 (Aroclor 1221)	µg/kg	7.7 U	17 U	23 U	53 U	5.7 U
PCB-1232 (Aroclor 1232)	µg/kg	7.7 U	17 U	23 U	53 U	5.7 U
PCB-1248 (Aroclor 1248)	µg/kg	7.7 U	17 U	23 U	53 U	5.7 U
PCB-1260 (Aroclor 1260)	µg/kg	10 U	81 U	150	32	5.7 U
PCB-1016 (Aroclor 1016)	µg/kg	7.7 U	17 U	23 U	53 U	5.7 U
Moisture	%	46	41	39	40	29
Volatile Solids	%	6.6	6.2	6.6	6.4	3.9
		SNH1B 12/11/2002	SNH1C 12/11/2002	SNH2A 12/10/2002	SNH2B 12/10/2002	SNH2C 12/10/2002
		9:58	9:58	14:42	14:42	14:42
		6" - 18"	18" - 30"	0" - 6"	6" - 18"	18" - 30"
PCB-1242 (Aroclor 1242)	µg/kg	5.8 U	5.8 U	5.5 U	5.8 U	6.0 UJ
PCB-1254 (Aroclor 1254)	µg/kg	5.8 U	5.8 U	5.5 U	5.8 U	6.0 UJ
PCB-1221 (Aroclor 1221)	µg/kg	5.8 U	5.8 U	5.5 U	5.8 U	6.0 UJ
PCB-1232 (Aroclor 1232)	µg/kg	5.8 U	5.8 U	5.5 U	5.8 U	6.0 UJ
PCB-1248 (Aroclor 1248)	µg/kg	5.8 U	5.8 U	5.5 U	5.8 U	6.0 UJ
PCB-1260 (Aroclor 1260)	µg/kg	5.8 U	5.8 U	5.5 U	5.8 U	6.0 UJ
PCB-1016 (Aroclor 1016)	µg/kg	5.8 U	5.8 U	5.5 U	5.8 U	6.0 UJ
Moisture	%	30	30	28	31	31
Volatile Solids	%	4.5	4.5	3.6	5	5.5
		SNH2D 12/10/2002	SNH3A 12/10/2002	SNH3B 12/10/2002	SNH3C 12/10/2002	SNH3D 12/10/2002
		14:42	10:55	10:55	10:55	10:55
		30" - 42"	0" - 6"	6" - 18"	18" - 30"	30" - 42"
PCB-1242 (Aroclor 1242)	µg/kg	5.7 U	8.1 U	14 U	44 U	35
PCB-1254 (Aroclor 1254)	µg/kg	5.7 U	17	40	160	110
PCB-1221 (Aroclor 1221)	µg/kg	5.7 U	8.1 U	14 U	44 U	35 U
PCB-1232 (Aroclor 1232)	µg/kg	5.7 U	8.1 U	14 U	44 U	35 U
PCB-1248 (Aroclor 1248)	µg/kg	5.7 U	8.1 U	14 U	44 U	35 U
PCB-1260 (Aroclor 1260)	µg/kg	5.7 U	17 U	40 U	160 U	70
PCB-1016 (Aroclor 1016)	µg/kg	5.7 U	8.1 U	14 U	44 U	35 U
Moisture	%	27	49	45	42	45
Volatile Solids	%	3.4	7.8	6.4	6.1	7.6

■ — Compound Detected

— Analyte not detected at or above reporting limit.

J — Estimated Value.

Table 3 (cont)
EPA PCB Results
Sediment Samples
Coosa River TMDL
Nov/Dec 2002

	SNHUA 12/11/2002	SNHUB 12/11/2002
	13:50	13:50
	0" - 6"	6" - 18"
PCB-1242 (Aroclor 1242)	µg/kg	28 U
PCB-1254 (Aroclor 1254)	µg/kg	220 U
PCB-1221 (Aroclor 1221)	µg/kg	28 U
PCB-1232 (Aroclor 1232)	µg/kg	28 U
PCB-1248 (Aroclor 1248)	µg/kg	28 U
PCB-1260 (Aroclor 1260)	µg/kg	220 U
PCB-1016 (Aroclor 1016)	µg/kg	28 U
Moisture	%	41
Volatile Solids	%	8.9
		29 U
		29 U
		43
		9.5

— Compound Detected
U — Analyte not detected at or above reporting limit.

Table 4. Coosa River Fish Tissue PCB Arochlor Data for EPA Location CR1

PCB Item	Alabama Fish Advisory Criteria			Georgia Fish Advisory Criteria			EPA Region 3	Screening												
	No Limit	Limited	Total	Consumption Restriction (mg/kg)	1 Meal/Week	1 Meal/Month	Restriction (mg/kg)	RBC (mg/kg)	Non-Cancer (mg/kg)	Cancer (mg/kg)	CR1-SBF1 11/19/2002	CR1-SBF2 11/19/2002	CR1-SBF3 11/19/2002	CR1-SBF4 11/19/2002	CR1-SBF5 11/19/2002	CR1-SPB1 11/19/2002	CR1-SPB2 11/21/2002	CR1-SPB5 11/21/2002	CR1-SPB6 11/21/2002	CR1-SPB8 11/21/2002
PCB-1016 (Aroclor 10 5115 MG/KG)	<10	10-199	2	0.1-0.29	0.3-0.99	>10	0.0016	0.0451	EPA-823-B-00-007 (2000) Dose Response variables and Recommended SV for Target Analytes- Recreational Fishers	0.16 U 0.16 U 0.16 U 0.16 U 0.16 U 3.8	0.016 U 0.03 U 0.03 U 0.033 J 0.03 U 0.43	0.03 U 0.069 U 0.069 U 0.069 U 0.3 U 0.33	0.089 U 0.055 U 0.055 U 0.058 J 0.5 U 0.54	0.055 U 0.035 U 0.035 U 0.036 J 0.4 U 0.41	0.035 U 0.035 U 0.035 U 0.035 U 0.35 U 0.38	0.31 U 0.31 U 0.31 U 0.31 U 0.75 U 0.77	0.1 U 0.1 U 0.1 U 0.1 J 0.85 U 0.88	0.03 U 0.03 U 0.03 U 0.034 J 0.15 U 0.17	0.016 U 0.016 U 0.016 U 0.016 U 0.45 U 0.5	
PCB-1221 (Aroclor 12 5095 MG/KG)																				
PCB-1238 (Aroclor 12 5100 MG/KG)																				
PCB-1242 (Aroclor 12 5085 MG/KG)																				
PCB-1248 (Aroclor 12 5105 MG/KG)																				
PCB-1254 (Aroclor 12 5090 MG/KG)																				
PCB-1260 (Aroclor 12 5110 MG/KG)																				
Aroclor 1260	<10	10-199	2	0.1-0.29	0.3-0.99	>10	0.0016	0.0016	0.0016	0.0016	0.0016	0.0016	0.0016	0.0016	0.0016	0.0016	0.0016	0.0016	0.0016	
Total PCBs*																				

* Total calculated using U values as detects- worst case

Data Qualifiers

A-Average value N=Not analyzed N/A-Interference J-Estimated value

N-Presumptive evidence of presence of material

NR-Not Reported

K-Actual value is known to be less than value given

L-Actual value is known to be greater than value given

U-Material was analyzed but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification

C-Confirmed by GC/MS

1. When no value is reported, see chlordane constituents

2. Constituents or metabolites of technical chlordane

Table 5. Coosa River Fish Tissue PCB Arochlor Data for EPA Location CR2

PCB Item	Alabama Fish Advisory Criteria			Georgia Fish Advisory			EPA Screening Region 3 RBC (mg/kg)	Screening Non-Cancer (mg/kg)	Screening Cancer (mg/kg)	Total											
	No.	Limited	Total	1 Meal/Week	1 Meal/Month	Restriction (mg/kg)	Consumption (mg/kg)	Restriction (mg/kg)	11/18/2002	CR2-CCF1	CR2-LMB1	CR2-LMB2	CR2-LMB3	CR2-LMB4	CR2-LMB5	CR2-SBF1	CR2-SBF2	CR2-SBF3	CR2-SBF4	11/18/2002	
PCB-1016 (Aroclor 10	5115	MG/KG								0.0451	EPA-823-B-00-007 (2000)	0.031 U	0.008 U	0.032 U	0.032 U	0.031 U	0.16 U	0.32 U	0.16 U	0.081 U	
PCB-1221 (Aroclor 12	5095	MG/KG								0.0016	Dose-Response variables	0.031 U	0.008 U	0.032 U	0.032 U	0.031 U	0.16 U	0.32 U	0.16 U	0.081 U	
PCB-1232 (Aroclor 12	5100	MG/KG								0.0016	and Recommended SV	0.031 U	0.008 U	0.032 U	0.032 U	0.031 U	0.16 U	0.32 U	0.16 U	0.081 U	
PCB-1242 (Aroclor 12	5095	MG/KG								0.0016	for Target Analytes:	0.031 U	0.008 U	0.032 U	0.032 U	0.031 U	0.16 U	0.32 U	0.16 U	0.081 U	
PCB-1248 (Aroclor 12	5105	MG/KG								0.0016	Recreational Fishers	0.031 U	0.008 U	0.032 U	0.032 U	0.031 U	0.16 U	0.32 U	0.16 U	0.081 U	
PCB-1260 (Aroclor 12	5090	MG/KG								0.0016		0.19 U	0.061 U	0.18 U	0.13 U	0.091 U	0.12 U	0.75 U	1.4 U	0.46 U	0.23 U
PCB-1260 (Aroclor 12	5110	MG/KG								0.0016		0.19	0.061	0.16	0.13	0.091	0.12	0.75	1.4	0.46	0.23
Aroclor 1260	<10		2	0.1-0.29	0.3-0.99	>10				0.08		0.19	0.061	0.16	0.13	0.091	0.12	0.75	1.4	0.46	0.23
Total PCBs*										0.535		0.535	0.162	0.48	0.42	0.342	0.395	2.3	4.4	1.72	0.865

* Total calculated using U values as detects worst case

Data Outliers

A-Average value N=Not analyzed NAI-Inferences J-Estimated value

N=Presumptive evidence of presence of material

NR=Not Reported

K-Actual value is known to be less than value given

L-Actual value is known to be greater than value given

U-Material was analyzed for but not detected. The number is the minimum quantitation limit

R=OC Indicates that data unusable Compound may or may not be present Resampling and reanalysis is necessary for verification

C-Confirmed by GC/MS

1. When no value is reported, see chlordane constituents

2. Constituents or metabolites of technical chlordane

Table 6. Coosa River Fish Tissue PCB Aroclor Data for EPA Location CR3

PCB Item	Alabama Fish Advisory Criteria			Georgia Fish Advisory			EPA												
	No Restriction (mg/kg)	Limited Consumption (mg/kg)	Total Restriction (mg/kg)	1 Meal/Week (mg/kg)	1 Meal/Month (mg/kg)	Total Restriction (mg/kg)	Region 3 RBC 11/20/2002	Screening Non-Cancer 11/20/2002	Screening Cancer (mg/kg)	CR3-LMB1 11/20/2002	CR3-LMB2 11/20/2002	CR3-LMB3 11/20/2002	CR3-LMB4 11/20/2002	CR3-LMB5 11/20/2002	CR3-SBF1 11/20/2002	CR3-SBF2 11/20/2002	CR3-SBF3 12/09/2002	CR3-SBF4 12/09/2002	CR3-SBF5 12/09/2002
PCB-1018 (Aroclor 1018)	5115 MG/KG	5115 MG/KG	5115 MG/KG	0.0451	EPA 823-B-00-007 (2000)	0.0451	0.16 U	0.16 U	0.032 U	0.033 U	0.032 U	0.033 U	0.032 U	0.032 U	0.033 U	0.033 U	0.033 U	0.033 U	
PCB-1221 (Aroclor 1221)	5095 MG/KG	5095 MG/KG	5095 MG/KG	0.0016	Dose Response variables	0.0016	0.16 U	0.16 U	0.032 U	0.033 U	0.032 U	0.033 U	0.032 U	0.032 U	0.033 U	0.033 U	0.033 U	0.033 U	
PCB-1232 (Aroclor 1232)	5100 MG/KG	5100 MG/KG	5100 MG/KG	0.0016	and Recommended SV	0.0016	0.16 U	0.16 U	0.032 U	0.033 U	0.032 U	0.033 U	0.032 U	0.032 U	0.033 U	0.033 U	0.033 U	0.033 U	
PCB-1242 (Aroclor 1242)	5085 MG/KG	5085 MG/KG	5085 MG/KG	0.0016	for Target Analytes-	0.0016	0.16 U	0.16 U	0.032 U	0.033 U	0.032 U	0.033 U	0.032 U	0.032 U	0.033 U	0.033 U	0.033 U	0.033 U	
PCB-1248 (Aroclor 1248)	5105 MG/KG	5105 MG/KG	5105 MG/KG	0.0016	Recreational Fishers	0.0016	0.16 U	0.16 U	0.032 U	0.033 U	0.032 U	0.033 U	0.032 U	0.032 U	0.033 U	0.033 U	0.033 U	0.033 U	
PCB-1254 (Aroclor 1254)	5090 MG/KG	5090 MG/KG	5090 MG/KG	0.0016		0.0016	0.62 U	0.77 U	0.37 U	0.18 U	0.12 U	0.17 U	0.12 U	0.12 U	0.2 U	0.12 U	0.11 U	0.11 U	
PCB-1260 (Aroclor 1260)	5110 MG/KG	5110 MG/KG	5110 MG/KG	0.0016		0.0016	0.82	0.77	0.37	0.18	0.12	0.17	0.12	0.12	0.2	0.12	0.11	0.11	
Aroclor 1260	< 1.0	1.0-1.99	2	0.1-0.29	0.3-0.99	>10		0.08	0.02	0.82	0.77	0.37	0.18	0.12	0.17	0.12	0.2	0.12	0.11
Total PCBs*							2.04	2.34	1.54	0.52	0.405	0.5	0.405	0.58	0.405	0.58	0.405	0.385	

* Total calculated using U values as detects- worst case

Data Outliers

A-Average value N-Not analyzed NI-Interference J-Estimated value.

N=Presumptive evidence of presence of material

NR-Not Reported

K-Actual value is known to be less than value given

L-Actual value is known to be greater than value given

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-OC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GC/MS

1. When no value is reported, see chlordane constituents

2. Constituents or metabolites of technical chlordane.

Table 7. Coosa River Fish Tissue PCB Analysis Data for EPA Location Lake Weirs 1

PCB Item	Georgia Fish Advisory Criteria															
	No Listed	Total Production Consumption (mg/kg)	1 Non-Water Restriction (mg/kg)	1 Water Restriction (mg/kg)	Total Cancer (mg/kg)	Screening RBC (mg/kg)	Region 3 Cancer (mg/kg)	LWILMB1 11/19/2002	LWILMB2 11/19/2002	LWILMB3 11/19/2002	LWILMB4 11/19/2002	LWISBF1 12/11/2002	LWISBF2 12/11/2002	LWISBF3 12/11/2002	LWISBF4 12/11/2002	LWISBF5 12/11/2002
PCB-1018 (Aroclor 1018)	5115 MOKO	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018 U								
PCB-1221 (Aroclor 2211)	5095 MOKO	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018 U								
PCB-1232 (Aroclor 2232)	5100 MOKO	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018 U								
PCB-1242 (Aroclor 2242)	5095 MOKO	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018 U								
PCB-1248 (Aroclor 2248)	5105 MOKO	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018 U								
PCB-1254 (Aroclor 2254)	5090 MOKO	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018 U								
PCB-1260 (Aroclor 2260)	5110 MOKO	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018	0.0018 U								
Aroclor 1260	<10	10199	2	0.029	0.029	>10	0.06	0.02	0.33	0.23	0.41	0.22	0.21	0.54	0.23	0.26
Total PCBs*								0.068	0.488	0.826	0.52	0.5	1.088	0.866	0.76	1.14

* Total calculated using U values as detected- most case

Data Qualifiers

A=Average value N=Not analyzed NA=No reference J=Estimated value

N=Not Reported

K=Actual value is known to be less than value given

L=Actual value is known to be greater than value given

U=Material was analyzed for but not detected. The number is the minimum quantitation limit.

R=OC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification

C=Confirmed by GC/MS

1 When no value reported, use chlorobiphenyl constituents

2 Constituants or metabolites of technical chlordane

Table 8. Coosa River Fish Tissue PCB Arochlor Data for EPA Location Lake Weiss 2

PCB Beam ¹	Alabama Fish Advisory Criteria			Georgia Fish Advisory			EPA Region 3	Screening RBC (mg/kg)	Screening Non-Cancer (mg/kg)	Screening Cancer (mg/kg)	LW2-BCF1 11/19/2002		LW2-LMB1 11/19/2002		LW2-LMB2 11/19/2002		LW2-LMB3 11/19/2002		LW2-SBF1 12/10/2002		LW2-SBF2 12/10/2002		LW2-SBF3 12/10/2002		LW2-SBF4 12/10/2002		LW2-SPB1 #####	
	No Restriction (mg/kg)	Limited Consumption (mg/kg)	Total Restriction (mg/kg)	1 Meal/Week	1 Meal/Month	Total Restriction (mg/kg)					LW2-BCF1	LW2-LMB1	LW2-LMB2	LW2-LMB3	LW2-LMB4	LW2-SBF1	LW2-SBF2	LW2-SBF3	LW2-SBF4	LW2-SPB1	#####	#####	#####	#####	#####			
PCB-1016 (Aroclor 1016)	5115 MG/KG	5095 MG/KG	5110 MG/KG	<1.0	1.0-1.99	2	0.0451	EPA-623-B-00-007 (2000)	0.082 U	0.083 U	0.041 U	0.041 U	0.032 U	0.33 U	0.0082 U	0.16 U	0.16 U	0.16 U	0.16 U	0.081 U	0.081 U	0.081 U	0.081 U	0.081 U	0.081 U			
PCB-1221 (Aroclor 1221)	5095 MG/KG	5085 MG/KG	5090 MG/KG				0.0016	Dose-Response variables and Recommended SV for Target Aroclors-	0.082 U	0.083 U	0.041 U	0.041 U	0.032 U	0.33 U	0.0082 U	0.16 U	0.16 U	0.16 U	0.16 U	0.081 U	0.081 U	0.081 U	0.081 U	0.081 U	0.081 U			
PCB-1232 (Aroclor 1232)	5100 MG/KG	5085 MG/KG	5090 MG/KG				0.0016	Recreational Fishers	0.082 U	0.083 U	0.041 U	0.041 U	0.032 U	0.33 U	0.0082 U	0.16 U	0.16 U	0.16 U	0.16 U	0.081 U	0.081 U	0.081 U	0.081 U	0.081 U	0.081 U			
PCB-1242 (Aroclor 1242)	5085 MG/KG	5075 MG/KG	5080 MG/KG				0.0016		0.23 U	0.26 U	0.17 U	0.18 U	0.14 U	1.4 U	0.06 U	0.71 U	0.79 U	0.79 U	0.79 U	0.31 U	0.31 U	0.31 U	0.31 U	0.31 U	0.31 U			
PCB-1248 (Aroclor 1248)	5105 MG/KG	5095 MG/KG	5100 MG/KG				0.0016		0.23	0.28	0.17	0.18	0.14	1.4	0.06	0.71	0.79	0.79	0.79	0.31	0.31	0.31	0.31	0.31	0.31			
PCB-1254 (Aroclor 1254)	5090 MG/KG	5080 MG/KG	5085 MG/KG				0.0016		0.23	0.28	0.17	0.18	0.14	1.4	0.06	0.71	0.79	0.79	0.79	0.31	0.31	0.31	0.31	0.31	0.31			
PCB-1260 (Aroclor 1260)	5110 MG/KG	5100 MG/KG	5105 MG/KG				0.0016		0.23	0.28	0.17	0.18	0.14	1.4	0.06	0.71	0.79	0.79	0.79	0.31	0.31	0.31	0.31	0.31	0.31			
Aroclor 1260	<1.0	1.0-1.99	2	0.1-0.29	0.3-0.99	>1.0	0.08	0.02	0.23	0.26	0.17	0.18	0.14	1.4	0.06	0.71	0.79	0.79	0.79	0.31	0.31	0.31	0.31	0.31	0.31			
Total PCBs*							0.87	0.975	0.545	0.565	0.44	4.45	0.161	2.22	2.38	1.025												

* Total calculated using U values as detects- worst case

Data Qualifiers

A-Average value N=Not analyzed I=Interference J-Estimated value

N-Presumptive evidence of presence of material.

NR=Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-OC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS

1 When no value is reported, see chlordene constituents

2 Constituents or metabolites of technical chlordene

Table 9. Coosa River Fish Tissue PCB Aroclor Data for EPA Location Upper Neely-Henry

PCB Scan	Alabama Fish Advisory Criteria			Georgia Fish Advisory			EPA Screening												
	No Restriction	Unlimited Consumption	Total	1 Meal/Week	1 Meal/Month	Restriction	RBC	Screening Non-Cancer	Cancer	UNHLMB1	UNHLMB2	UNHLMB3	UNHSBF1	UNHSBF2	UNHSBF3	UNHSBF4	UNHSBF5	UNHSPB1	UNHSPB2
	(mg/kg)	(mg/kg)	(mg/kg)	(mg/kg)	(mg/kg)	(mg/kg)	(mg/kg)	(mg/kg)	11/20/2002	11/20/2002	11/20/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002	11/20/2002	11/20/2002	
PCB-1016 (Aroclor 1016)	5115 MG/KG	<10	10-199	2	0.1-3	0.3-99	>10	0.0451	EPA-623-B-00-007 (2000)	0.032 U	0.033 U	0.04 U	0.16 U	0.16 U	0.081 U	0.083 U	0.079 U	0.18 U	0.04 U
PCB-1221 (Aroclor 1221)	5095 MG/KG	<10	10-199	2	0.1-3	0.3-99	>10	0.0016	Dose-Response variables	0.032 U	0.033 U	0.04 U	0.16 U	0.16 U	0.081 U	0.083 U	0.079 U	0.16 U	0.04 U
PCB-1232 (Aroclor 1232)	5100 MG/KG	<10	10-199	2	0.1-3	0.3-99	>10	0.0016	and Recommended SV	0.032 U	0.033 U	0.04 U	0.16 U	0.16 U	0.081 U	0.083 U	0.079 U	0.16 U	0.04 U
PCB-1242 (Aroclor 1242)	5085 MG/KG	<10	10-199	2	0.1-3	0.3-99	>10	0.0016	for Target Analytes-	0.032 U	0.033 U	0.04 U	0.16 U	0.16 U	0.081 U	0.083 U	0.079 U	0.16 U	0.04 U
PCB-1248 (Aroclor 1248)	5105 MG/KG	<10	10-199	2	0.1-3	0.3-99	>10	0.0016	Recreational Fishers	0.032 U	0.033 U	0.04 U	0.16 U	0.16 U	0.081 U	0.083 U	0.079 U	0.16 U	0.04 U
PCB-1254 (Aroclor 1254)	5090 MG/KG	<10	10-199	2	0.1-3	0.3-99	>10	0.0016		0.19 U	0.16 U	0.16 U	1 U	0.68 U	0.32 U	0.31 U	0.32 U	0.92 U	0.15 U
PCB-1260 (Aroclor 1260)	5110 MG/KG	<10	10-199	2	0.1-3	0.3-99	>10	0.0016		0.19	0.16	0.16	1 J	0.68	0.32	0.31	0.32	0.92	0.15
Aroclor 1260		<10	10-199	2	0.1-3	0.3-99	>10	0.06		0.19	0.16	0.16	1	0.68	0.32	0.31	0.32	0.92	0.15
Total PCBs*								0.54		0.485	0.52	26	216	1045	1035	1035	264	264	0.6

* Total calculated using U values as detect- worst case

Data Qualifiers

A-Average value NA-Not analyzed NI-Interference JE-Estimated value

N-Presumptive evidence of presence of material

NR-Not Reported

K-Actual value is known to be less than value given

L-Actual value is known to be greater than value given

U-Material was analyzed for but not detected. The number is the minimum quantitation limit

R-OC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification

C-Confirmed by GCMS

1-When no value is reported, see chlordane constituents

2-Constituents or metabolites of technical chlordane.

Table 10. Coosa River Fish Tissue PCB Aroclor Data for EPA Location Logan Martin

PCB Item	Alabama Fish Advisory Criteria			Georgia Fish Advisory			EPA												
	No Restriction (mg/kg)	Limited Consumption (mg/kg)	Total Restriction (mg/kg)	1 Meal/Week (mg/kg)	1 Meal/Month (mg/kg)	Total Restriction (mg/kg)	Region 3 RBC (mg/kg)	Screening Non-Cancer (mg/kg)	Screening Cancer (mg/kg)	LM-BCF1 12/09/2002	LM-BCF2 12/09/2002	LM-BCF4 12/09/2002	LM-BCF5 12/09/2002	LM-CCF1 11/21/2002	LM-LMB1 11/21/2002	LM-LMB2 11/21/2002	LM-LMB3 11/21/2002	LM-LMB4 11/21/2002	LM-SPB1 11/21/2002
PCB-1016 (Aroclor 1016)	5115 MG/KG	5115 MG/KG	5115 MG/KG	0.0451	EPA-823-B-00-007 (2000)	0.016 U	0.016 U	0.0038 U	0.0036 U	0.0045 U	0.008 U	0.015 U	0.032 U	0.044 U					
PCB-1221 (Aroclor 1221)	5095 MG/KG	5095 MG/KG	5095 MG/KG	0.0016	DoS-Response variables and Recommended SV	0.016 U	0.016 U	0.0038 U	0.0036 U	0.0045 U	0.008 U	0.016 U	0.032 U	0.044 U					
PCB-1232 (Aroclor 1232)	5100 MG/KG	5100 MG/KG	5100 MG/KG	0.0016	for Target Analytes: Recreational Fishers	0.016 U	0.016 U	0.0038 U	0.0036 U	0.0045 U	0.008 U	0.016 U	0.032 U	0.044 U					
PCB-1242 (Aroclor 1242)	5085 MG/KG	5085 MG/KG	5085 MG/KG	0.0016		0.15 U	0.2 U	0.055 U	0.079 U	0.42 U	0.19 U	0.18 U	0.21 U	0.053 U	0.42 U				
PCB-1248 (Aroclor 1248)	5105 MG/KG	5105 MG/KG	5105 MG/KG	0.0016		0.19	0.21	0.06	0.079	0.42	0.19	0.18	0.21	0.053	0.42				
PCB-1254 (Aroclor 1254)	5090 MG/KG	5090 MG/KG	5090 MG/KG			0.42	0.49	0.195	0.177	0.650	0.4025	0.4	0.5	0.122	0.862				
Aroclor 1260	<10	10-199	2	0.1-0.29	0.3-0.99	>10	0.08	0.02											
Total PCBs*																			

* Total calculated using U values as detects- worst case

Data Qualifiers

A-Average value NA-Not analyzed NI-Interference JE-Estimated value

NP-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit

R-Or indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS

1. When no value is reported, see chlordane constituents

2. Constituents or metabolites of technical chlordane

Table 11. Coosa River Fish Tissue PCB Congener Data 1/10 Detection Calculations for Location CR1

Tissue Data	EPA							
	823-B-00-007	CR1-SBF1 TEFs 11/19/2002	CR1-SBF2 11/19/2002	CR1-SBF3 11/19/2002	CR1-SPB1 11/19/2002	CR1-SPB5 11/21/2002	CR1-SPB6 11/21/2002	
PCB Congener #105	MG/KG	0.0001	0.1	0.0076	0.013	0.01	0.016	0.0077
PCB Congener #114	MG/KG	0.0005	0.007 U	0.0019 U	0.0012 U	0.0031 U	0.0031 U	0.0025 U
PCB Congener #118	MG/KG	0.0001	0.16	0.011	0.016 C	0.015 C	0.056 C	0.0094
PCB Congener #123	MG/KG	0.0001	0.0063 U	0.0019 U	0.00062 U	0.0031 U	0.0031 U	0.0012 U
PCB Congener #126	MG/KG	0.1	0.00063 U	0.0019 U	0.00062 U	0.00063 U	0.0012 U	0.0012 U
PCB Congener #156	MG/KG	0.0005	0.052	0.0044	0.0026	0.0029	0.0048	0.0011
PCB Congener #157	MG/KG	0.0005	0.007 U	0.0028 U	0.00044 JN	0.00063 U	0.0031 U	0.00091 U
PCB Congener #167	MG/KG	0.00001	0.041	0.0042	0.0021	0.0032	0.0087	0.0018
PCB Congener #169	MG/KG	0.01	0.00063 U	0.00063 U	0.00062 U	0.00063 U	0.00062 U	0.00063 U
PCB Congener #189	MG/KG	0.0001	0.012	0.0013	0.00028 J	0.0002 J	0.00067 J	0.00017 J
PCB Congener #77	MG/KG	0.0001	0.013 U	0.0019 U	0.0025 U	0.0031 U	0.0062 U	0.0025 U
PCB Congener #81	MG/KG	0.0001	0.0016 U	0.00063 U	0.00062 U	0.00063 U	0.0012 U	0.0025 U

Tissue Data 1/10 of Non-detect Calculations

PCB Congener	TEFs	CR1-SBF1 11/19/2002	CR1-SBF2 11/19/2002	CR1-SBF3 11/19/2002	CR1-SPB1 11/19/2002	CR1-SPB5 11/21/2002	CR1-SPB6 11/21/2002	
		11/19/2002	11/19/2002	11/19/2002	11/19/2002	11/21/2002	11/21/2002	
PCB Congener #105	MG/KG	0.0001	1.000E-01	7.600E-03	1.300E-02	1.000E-02	1.600E-02	7.700E-03
PCB Congener #114	MG/KG	0.0005	7.000E-04 U	1.900E-04 U	1.200E-04 U	3.100E-04 U	3.100E-04 U	2.500E-04 U
PCB Congener #118	MG/KG	0.0001	1.600E-01	1.100E-02	1.600E-02 C	1.500E-02 C	5.600E-02 C	8.400E-03
PCB Congener #123	MG/KG	0.0001	6.300E-04 U	1.900E-04 U	6.200E-05 U	3.100E-04 U	3.100E-04 U	1.200E-04 U
PCB Congener #126	MG/KG	0.1	6.300E-05 U	1.900E-04 U	6.200E-05 U	6.300E-05 U	1.200E-04 U	1.200E-04 U
PCB Congener #156	MG/KG	0.0005	5.200E-02	4.400E-03	2.600E-03	2.900E-03	4.800E-03	1.100E-03
PCB Congener #157	MG/KG	0.0005	7.000E-04 U	2.800E-04 U	4.400E-04 JN	6.300E-05 U	3.100E-04 U	9.100E-05 U
PCB Congener #167	MG/KG	0.00001	4.100E-02	4.200E-03	2.100E-03	3.200E-03	8.700E-03	1.800E-03
PCB Congener #169	MG/KG	0.01	6.300E-05 U	6.300E-05 U	6.200E-05 U	6.300E-05 U	6.200E-05 U	6.300E-05 U
PCB Congener #189	MG/KG	0.0001	1.200E-02	1.300E-03	2.800E-04 J	2.000E-04 J	6.700E-04 J	1.700E-04 J
PCB Congener #77	MG/KG	0.0001	1.300E-03 U	1.900E-04 U	2.500E-04 U	3.100E-04 U	6.200E-04 U	2.500E-04 U
PCB Congener #81	MG/KG	0.0001	1.600E-04 U	6.300E-05 U	6.200E-05 U	6.300E-05 U	1.200E-04 U	2.500E-04 U

Tissue Data 1/10 of Non-detect TEQ Results

PCB Congener	TEFs	CR1-SBF1 11/19/2002	CR1-SBF2 11/19/2002	CR1-SBF3 11/19/2002	CR1-SPB1 11/19/2002	CR1-SPB5 11/21/2002	CR1-SPB6 11/21/2002	
		11/19/2002	11/19/2002	11/19/2002	11/19/2002	11/21/2002	11/21/2002	
PCB Congener #105	MG/KG	0.0001	1.0E-05	7.6E-07	1.3E-06	1.0E-06	1.6E-06	7.7E-07
PCB Congener #114	MG/KG	0.0005	3.5E-07 U	9.5E-08 U	6.0E-08 U	1.6E-07 U	1.6E-07 U	1.3E-07 U
PCB Congener #118	MG/KG	0.0001	1.8E-05	1.1E-06	1.6E-06 C	1.5E-06 C	5.6E-06 C	9.4E-07
PCB Congener #123	MG/KG	0.0001	6.3E-08 U	1.9E-08 U	6.2E-09 U	3.1E-08 U	3.1E-08 U	1.2E-08 U
PCB Congener #126	MG/KG	0.1	6.3E-06 U	1.9E-05 U	6.2E-06 U	6.3E-06 U	1.2E-05 U	1.2E-05 U
PCB Congener #156	MG/KG	0.0005	2.6E-05	2.2E-06	1.3E-06	1.5E-06	2.4E-06	5.5E-07
PCB Congener #157	MG/KG	0.0005	3.5E-07 U	1.4E-07 U	2.2E-07 JN	3.2E-08 U	1.6E-07 U	4.6E-08 U
PCB Congener #167	MG/KG	0.00001	4.1E-07	4.2E-08	2.1E-08	3.2E-08	8.7E-08	1.8E-08
PCB Congener #169	MG/KG	0.01	6.3E-07 U	6.3E-07 U	6.2E-07 U	6.3E-07 U	6.2E-07 U	6.3E-07 U
PCB Congener #189	MG/KG	0.0001	1.2E-06	1.3E-07	2.8E-08 J	2.0E-08 J	6.7E-08 J	1.7E-08 J
PCB Congener #77	MG/KG	0.0001	1.3E-07 U	1.9E-08 U	2.5E-08 U	3.1E-08 U	6.2E-08 U	2.5E-08 U
PCB Congener #81	MG/KG	0.0001	1.6E-08 U	6.3E-09 U	6.2E-09 U	6.3E-09 U	1.2E-08 U	2.5E-08 U
Total TEQ		6.1E-05	2.4E-05	1.1E-05	1.1E-05	2.3E-05	1.5E-05	

USEPA Screening Value, Frist Tier 2.1E-08
 USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1.When no value is reported, see chlordane constituents.

2.Constituents or metabolites of technical chlordane.

Table 12. Coosa River Fish Tissue PCB Congener Data 1/2 Detection Limit Calculations for Location CR1

Tissue Data	EPA							
	B23-B-00-007	CR1-SBF1	CR1-SBF2	CR1-SBF3	CR1-SPB1	CR1-SPB5	CR1-SPB6	
PCB Congener	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	11/21/2002	11/21/2002	
PCB Congener #105	MG/KG	0.0001	0.1	0.0076	0.013	0.01	0.016	0.0077
PCB Congener #114	MG/KG	0.0005	0.007 U	0.0019 U	0.0012 U	0.0031 U	0.0031 U	0.0025 U
PCB Congener #118	MG/KG	0.0001	0.16	0.011	0.018 C	0.015 C	0.056 C	0.0094
PCB Congener #123	MG/KG	0.0001	0.0063 U	0.0019 U	0.00062 U	0.0031 U	0.0031 U	0.0012 U
PCB Congener #126	MG/KG	0.1	0.00063 U	0.0019 U	0.00062 U	0.00063 U	0.0012 U	0.0012 U
PCB Congener #156	MG/KG	0.0005	0.052	0.0044	0.0026	0.0029	0.0048	0.0011
PCB Congener #157	MG/KG	0.0005	0.007 U	0.0028 U	0.00044 JN	0.00063 U	0.0031 U	0.00091 U
PCB Congener #167	MG/KG	0.00001	0.041	0.0042	0.0021	0.0032	0.0087	0.0018
PCB Congener #189	MG/KG	0.01	0.00063 U	0.00063 U	0.00062 U	0.00063 U	0.00062 U	0.00063 U
PCB Congener #189	MG/KG	0.0001	0.012	0.0013	0.00028 J	0.0002 J	0.00067 J	0.00017 J
PCB Congener #77	MG/KG	0.0001	0.013 U	0.0019 U	0.0025 U	0.0031 U	0.0062 U	0.0025 U
PCB Congener #81	MG/KG	0.0001	0.0016 U	0.00063 U	0.00062 U	0.00063 U	0.0012 U	0.0025 U

Tissue 1/2 of Non-detect Calculations

PCB Congener	TEFs	CR1-SBF1	CR1-SBF2	CR1-SBF3	CR1-SPB1	CR1-SPB5	CR1-SPB6	
		11/19/2002	11/19/2002	11/19/2002	11/19/2002	11/21/2002	11/21/2002	
PCB Congener #105	MG/KG	0.0001	1.0E-01	7.6E-03	1.3E-02	1.0E-02	1.6E-02	7.7E-03
PCB Congener #114	MG/KG	0.0005	3.5E-03 U	9.5E-04 U	6.0E-04 U	1.6E-03 U	1.6E-03 U	1.3E-03 U
PCB Congener #118	MG/KG	0.0001	1.6E-01	1.1E-02	1.6E-02 C	1.5E-02 C	5.6E-02 C	9.4E-03
PCB Congener #123	MG/KG	0.0001	3.2E-03 U	9.5E-04 U	3.1E-04 U	1.6E-03 U	1.6E-03 U	6.0E-04 U
PCB Congener #126	MG/KG	0.1	3.2E-04 U	9.5E-04 U	3.1E-04 U	3.2E-04 U	6.0E-04 U	6.0E-04 U
PCB Congener #156	MG/KG	0.0005	5.2E-02	4.4E-03	2.6E-03	2.9E-03	4.8E-03	1.1E-03
PCB Congener #157	MG/KG	0.0005	3.5E-03 U	1.4E-03 U	4.4E-04 JN	3.2E-04 U	1.6E-03 U	4.6E-04 U
PCB Congener #167	MG/KG	0.00001	4.1E-02	4.2E-03	2.1E-03	3.2E-03	8.7E-03	1.8E-03
PCB Congener #169	MG/KG	0.01	3.2E-04 U	3.2E-04 U	3.1E-04 U	3.2E-04 U	3.1E-04 U	3.2E-04 U
PCB Congener #189	MG/KG	0.0001	1.2E-02	1.3E-03	2.8E-04 J	2.0E-04 J	6.7E-04 J	1.7E-04 J
PCB Congener #77	MG/KG	0.0001	6.5E-03 U	9.5E-04 U	1.3E-03 U	1.6E-03 U	3.1E-03 U	1.3E-03 U
PCB Congener #81	MG/KG	0.0001	8.0E-04 U	3.2E-04 U	3.1E-04 U	3.2E-04 U	6.0E-04 U	1.3E-03 U

Tissue Data 1/2 of Non-detect Results

PCB Congener	TEFs	CR1-SBF1	CR1-SBF2	CR1-SBF3	CR1-SPB1	CR1-SPB5	CR1-SPB6	
		3.8E+04	3.8E+04	3.8E+04	3.8E+04	3.8E+04	3.8E+04	
PCB Congener #105	MG/KG	0.0001	1.0E-05	7.6E-07	1.3E-06	1.0E-06	1.6E-06	7.7E-07
PCB Congener #114	MG/KG	0.0005	1.8E-06 U	4.8E-07 U	3.0E-07 U	7.8E-07 U	7.8E-07 U	6.3E-07 U
PCB Congener #118	MG/KG	0.0001	1.6E-05	1.1E-06	1.6E-08 C	1.5E-06 C	5.6E-06 C	9.4E-07
PCB Congener #123	MG/KG	0.0001	3.2E-07 U	9.5E-08 U	3.1E-08 U	1.6E-07 U	1.6E-07 U	6.0E-08 U
PCB Congener #126	MG/KG	0.1	3.2E-05 U	9.5E-05 U	3.1E-05 U	3.2E-05 U	6.0E-05 U	6.0E-05 U
PCB Congener #156	MG/KG	0.0005	2.6E-05	2.2E-06	1.3E-06	1.5E-06	2.4E-06	5.5E-07
PCB Congener #157	MG/KG	0.0005	1.8E-06 U	7.0E-07 U	2.2E-07 JN	1.6E-07 U	7.8E-07 U	2.3E-07 U
PCB Congener #167	MG/KG	0.00001	4.1E-07	4.2E-06	2.1E-08	3.2E-06	8.7E-06	1.8E-06
PCB Congener #169	MG/KG	0.01	3.2E-06 U	3.2E-06 U	3.1E-06 U	3.2E-06 U	3.1E-06 U	3.2E-06 U
PCB Congener #189	MG/KG	0.0001	1.2E-06	1.3E-07	2.8E-08 J	2.0E-08 J	8.7E-08 J	1.7E-08 J
PCB Congener #77	MG/KG	0.0001	6.5E-07 U	9.5E-08 U	1.3E-07 U	1.6E-07 U	3.1E-07 U	1.3E-07 U
PCB Congener #81	MG/KG	0.0001	8.0E-08 U	3.2E-08 U	3.1E-08 U	3.2E-08 U	6.0E-08 U	1.3E-07 U
Total TEQ		9.3E-05	1.0E-04	3.0E-05	4.0E-05	7.5E-05	6.7E-05	

USEPA Screening Value, Frist Tier 2.1E-06
 USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1.When no value is reported, see chlordane constituents.

2.Constituents or metabolites of technical chlordane.

Table 13. Coosa River Fish Tissue PCB Congener Data Detects Only Calculations for Location CR1

PCB Congener	EPA							
	823-B-00-007	CR1-SBF1	CR1-SBF2	CR1-SBF3	CR1-SPB1	CR1-SPB5	CR1-SPB6	
	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	11/21/2002	11/21/2002	
PCB Congener #105	MG/KG	0.0001	1.0E-01	7.6E-03	1.3E-02	1.0E-02	1.6E-02	7.7E-03
PCB Congener #114	MG/KG	0.0005	7.0E-03 U	1.9E-03 U	1.2E-03 U	3.1E-03 U	3.1E-03 U	2.5E-03 U
PCB Congener #118	MG/KG	0.0001	1.6E-01	1.1E-02	1.6E-02 C	1.5E-02 C	5.6E-02 C	9.4E-03
PCB Congener #123	MG/KG	0.0001	6.3E-03 U	1.9E-03 U	6.2E-04 U	3.1E-03 U	3.1E-03 U	1.2E-03 U
PCB Congener #126	MG/KG	0.1	6.3E-04 U	1.9E-03 U	6.2E-04 U	6.3E-04 U	1.2E-03 U	1.2E-03 U
PCB Congener #156	MG/KG	0.0005	5.2E-02	4.4E-03	2.6E-03	2.9E-03	4.6E-03	1.1E-03
PCB Congener #157	MG/KG	0.0005	7.0E-03 U	2.8E-03 U	4.4E-04 JN	6.3E-04 U	3.1E-03 U	9.1E-04 U
PCB Congener #167	MG/KG	0.00001	4.1E-02	4.2E-03	2.1E-03	3.2E-03	8.7E-03	1.8E-03
PCB Congener #169	MG/KG	0.01	6.3E-04 U	6.3E-04 U	6.2E-04 U	6.3E-04 U	6.2E-04 U	6.3E-04 U
PCB Congener #189	MG/KG	0.0001	1.2E-02	1.3E-03	2.8E-04 J	2.0E-04 J	8.7E-04 J	1.7E-04 J
PCB Congener #77	MG/KG	0.0001	1.3E-02 U	1.9E-03 U	2.5E-03 U	3.1E-03 U	6.2E-03 U	2.5E-03 U
PCB Congener #81	MG/KG	0.0001	1.6E-03 U	6.3E-04 U	6.2E-04 U	6.3E-04 U	1.2E-03 U	2.5E-03 U

Tissue data detects only TEQ Results

PCB Congener	EPA							
	823-B-00-007	CR1-SBF1	CR1-SBF2	CR1-SBF3	CR1-SPB1	CR1-SPB5	CR1-SPB6	
	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	11/21/2002	11/21/2002	
PCB Congener #105	MG/KG	0.0001	1.0E-05	7.6E-07	1.3E-06	1.0E-06	1.6E-06	7.7E-07
PCB Congener #114	MG/KG	0.0005	U	U	U	U	U	U
PCB Congener #118	MG/KG	0.0001	1.6E-05	1.1E-06	1.6E-06 C	1.5E-06 C	5.6E-06 C	9.4E-07
PCB Congener #123	MG/KG	0.0001	U	U	U	U	U	U
PCB Congener #126	MG/KG	0.1	U	U	U	U	U	U
PCB Congener #156	MG/KG	0.0005	2.6E-05	2.2E-06	1.3E-06	1.5E-06	2.4E-06	5.5E-07
PCB Congener #157	MG/KG	0.0005	U	U	JN	U	U	U
PCB Congener #167	MG/KG	0.00001	4.1E-07	4.2E-08	2.1E-08	3.2E-08	8.7E-08	1.8E-08
PCB Congener #169	MG/KG	0.01	U	U	U	U	U	U
PCB Congener #189	MG/KG	0.0001	1.2E-06	1.3E-07	2.8E-08 J	2.0E-08 J	6.7E-08 J	1.7E-08 J
PCB Congener #77	MG/KG	0.0001	U	U	U	U	U	U
PCB Congener #81	MG/KG	0.0001	U	U	U	U	U	U
Total TEQ			5.36E-05	4.23E-06	4.25E-06	4.00E-06	9.75E-06	2.30E-06

USEPA Screening Value, Frist Tier
2.1E-08
USEPA Risk Value, Second Tier
2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-CC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1. When no value is reported, see chlordane constituents.

2. Constituents or metabolites of technical chlordane.

Table 14. Coosa River Fish Tissue PCB Congener Data 1/10 Detection Limit Calculations for Location CR2

Tissue Data	EPA								CR2 SBF1D 11/18/2002
	823-B-00-007	CR2-LMB1	CR-LMB2	CR-LMB3	CR2-SBF1	CR2-SBF2	CR-SBF3	11/18/2002	
PCB Congener	TEFs	11/18/2002	11/18/2002	11/18/2002	11/18/2002	11/18/2002	11/18/2002	11/18/2002	
PCB Congener #105	MG/KG	0.0001	0.00074 N	0.0031 N	0.0027 N	0.022 N	0.027 N	0.0091 N	0.016 N 0.02 U 0.046 0.018 U 0.0025 U 0.0038 0.012 N 0.0024 U 0.0064 U 0.009 U
PCB Congener #114	MG/KG	0.0005	0.0031 U	0.0022 U	0.0035 U	0.036 U	0.022 U	0.025 U	
PCB Congener #118	MG/KG	0.0001	0.0027 N	0.0077	0.0069	0.048	0.085	0.025	
PCB Congener #123	MG/KG	0.0001	0.00075 U	0.0018 U	0.0018 U	0.022 U	0.012 U	0.0045 U	
PCB Congener #126	MG/KG	0.1	0.00064 U	0.00064 U	0.00064 U	0.0036 U	0.014 U	0.0048 U	
PCB Congener #156	MG/KG	0.0005	0.00067 N	0.0013	0.0013 N	0.0038 J	0.013 J	0.0029 J	
PCB Congener #157	MG/KG	0.0005	0.0017 U	0.002 N	0.0029 U	0.0098 N	0.015 N	0.006 U	
PCB Congener #167	MG/KG	0.00001	0.00084 U	0.0003 J	0.00084 U	0.0033 U	0.0061 U	0.0026 U	
PCB Congener #169	MG/KG	0.01	0.00064 U	0.00064 U	0.00064 U	0.00065 U	0.00063 U	0.00064 U	
PCB Congener #189	MG/KG	0.0001	0.00074 U	0.00076 U	0.00078 U	0.00086 U	0.0018 U	0.00023 N	
PCB Congener #77	MG/KG	0.0001	0.00064 U	0.00064 U	0.00064 U	0.013 U	0.025 U	0.013 U	0.0025 U
PCB Congener #81	MG/KG	0.0001	0.004 U	0.012 U	0.016 U	0.11 U	0.14 U	0.061 U	0.095 U
Tissue Data 1/10 of Non-detect Calculations									CR2 SBF1D 11/18/2002
PCB Congener	TEFs	CR2-LMB1	CR-LMB2	CR-LMB3	CR2-SBF1	CR2-SBF2	CR-SBF3	11/18/2002	9.1E-04 N 2.5E-03 U 2.5E-02 4.6E-02 4.5E-04 U 1.6E-03 U 2.5E-04 U 3.8E-03 1.2E-03 N 4.5E-04 U 1.6E-03 U 2.5E-04 U 3.8E-03 6.0E-04 U 1.2E-03 N 2.5E-04 U 3.8E-03 6.3E-05 U 6.4E-05 U 9.0E-05 U 2.3E-05 N 1.3E-03 U 2.5E-04 U 8.1E-03 U 9.5E-03 U
PCB Congener #105	MG/KG	0.0001	7.4E-05 N	3.1E-04 N	2.7E-04 N	2.2E-03 N	2.7E-03 N	9.1E-04 N	
PCB Congener #114	MG/KG	0.0005	3.1E-04 U	2.2E-04 U	3.5E-04 U	3.6E-03 U	2.2E-03 U	2.5E-03 U	
PCB Congener #118	MG/KG	0.0001	2.7E-04 N	7.7E-03	6.9E-03	4.8E-02	8.5E-02	2.5E-02	
PCB Congener #123	MG/KG	0.0001	7.5E-05 U	1.9E-04 U	1.8E-04 U	2.2E-03 U	1.2E-03 U	4.5E-04 U	
PCB Congener #126	MG/KG	0.1	6.4E-05 U	6.4E-05 U	6.4E-05 U	3.6E-04 U	1.4E-03 U	4.8E-04 U	
PCB Congener #156	MG/KG	0.0005	6.7E-05 N	1.3E-03	1.3E-04 N	3.8E-03 J	1.3E-02 J	2.9E-03 J	
PCB Congener #157	MG/KG	0.0005	1.7E-04 U	2.0E-04 N	2.9E-04 U	9.8E-04 N	1.5E-03 N	6.0E-04 U	
PCB Congener #167	MG/KG	0.00001	6.4E-05 U	3.0E-04 J	6.4E-05 U	3.3E-04 U	6.1E-04 U	2.6E-04 U	
PCB Congener #169	MG/KG	0.01	6.4E-05 U	6.4E-05 U	6.4E-05 U	6.5E-05 U	6.3E-05 U	6.4E-05 U	
PCB Congener #189	MG/KG	0.0001	7.4E-05 U	7.6E-05 U	7.8E-05 U	8.6E-05 U	1.8E-04 U	2.3E-05 N	9.0E-05 U
PCB Congener #77	MG/KG	0.0001	6.4E-05 U	6.4E-05 U	6.4E-05 U	1.3E-03 U	2.5E-03 U	1.3E-03 U	2.5E-04 U
PCB Congener #81	MG/KG	0.0001	4.0E-04 U	1.2E-03 U	1.6E-03 U	1.1E-02 U	1.4E-02 U	8.1E-03 U	9.5E-03 U
Tissue Data 1/10 of Non-detect TEQ Results									CR2 SBF1D 11/18/2002
PCB Congener	TEFs	CR2-LMB1	CR-LMB2	CR-LMB3	CR2-SBF1	CR2-SBF2	CR-SBF3	11/18/2002	9.1E-08 N 1.3E-06 U 2.5E-06 4.6E-06 4.5E-08 U 1.6E-07 U 2.5E-07 3.8E-07 6.0E-07 U 1.3E-06 J 1.5E-06 J 1.9E-06 7.5E-07 N 3.0E-07 U 6.0E-07 N 6.3E-07 U 6.4E-07 U 9.0E-09 U 2.3E-09 N 9.0E-09 U 2.5E-08 U 8.1E-07 U 9.5E-07 U
PCB Congener #105	MG/KG	0.0001	7.4E-09 N	< 3.1E-08 N	2.7E-08 N	2.2E-07 N	2.7E-07 N	9.1E-08 N	
PCB Congener #114	MG/KG	0.0005	1.6E-07 U	1.1E-07 U	1.8E-07 U	1.8E-06 U	1.1E-06 U	1.3E-06 U	
PCB Congener #118	MG/KG	0.0001	2.7E-08 N	7.7E-07	6.9E-07	4.8E-06	8.5E-06	2.5E-06	
PCB Congener #123	MG/KG	0.0001	7.5E-09 U	1.9E-08 U	1.8E-08 U	2.2E-07 U	1.2E-07 U	4.5E-08 U	
PCB Congener #126	MG/KG	0.1	6.4E-08 U	6.4E-08 U	6.4E-08 U	3.6E-05 U	1.4E-04 U	4.8E-05 U	
PCB Congener #156	MG/KG	0.0005	3.4E-08 N	8.5E-07	6.5E-08 N	1.9E-06 J	6.5E-06 J	1.5E-06 J	
PCB Congener #157	MG/KG	0.0005	8.5E-08 U	1.0E-07 N	1.5E-07 U	4.9E-07 N	7.5E-07 N	3.0E-07 U	
PCB Congener #167	MG/KG	0.00001	6.4E-10 U	3.0E-09 J	6.4E-10 U	3.3E-09 U	6.1E-09 U	2.6E-09 U	
PCB Congener #169	MG/KG	0.01	6.4E-07 U	6.4E-07 U	6.4E-07 U	6.5E-07 U	6.3E-07 U	6.4E-07 U	
PCB Congener #189	MG/KG	0.0001	7.4E-09 U	7.6E-09 U	7.8E-09 U	8.6E-09 U	1.8E-08 U	2.3E-09 N	9.0E-09 U
PCB Congener #77	MG/KG	0.0001	6.4E-09 U	6.4E-09 U	6.4E-09 U	1.3E-07 U	2.5E-07 U	1.3E-07 U	2.5E-08 U
PCB Congener #81	MG/KG	0.0001	4.0E-08 U	1.2E-07 U	1.6E-07 U	1.1E-06 U	1.4E-06 U	6.1E-07 U	9.5E-07 U
Total TEQ		7.4E-06	8.9E-06	8.3E-06	4.7E-05	1.8E-04	5.4E-05	3.5E-05	

USEPA Screening Value, First Tier 2.1E-08
 USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NI-Inferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1. When no value is reported, see chlordane constituents.

2. Constituents or metabolites of technical chlordane.

Table 15. Coosa River Fish Tissue PCB Congener Data 1/2 Detection Limit Calculations for Location CR2

Tissue Data	EPA								CR2 SBF1D
	823-B-00-007	CR2-LMB1	CR-LMB2	CR-LMB3	CR2-SBF1	CR2-SBF2	CR-SBF3	11/18/2002	
PCB Congener	TEFs	11/18/2002	11/18/2002	11/18/2002	11/18/2002	11/18/2002	11/18/2002	11/18/2002	11/18/2002
PCB Congener #105	MG/KG	0.0001	0.00074 N	0.0031 N	0.0027 N	0.022 N	0.027 N	0.0091 N	0.016 N
PCB Congener #114	MG/KG	0.0005	0.0031 U	0.0022 U	0.0035 U	0.036 U	0.022 U	0.025 U	0.02 U
PCB Congener #118	MG/KG	0.0001	0.0027 N	0.0077	0.0069	0.048	0.085	0.025	0.046
PCB Congener #123	MG/KG	0.0001	0.00075 U	0.0019 U	0.0018 U	0.022 U	0.012 U	0.0045 U	0.018 U
PCB Congener #126	MG/KG	0.1	0.00084 U	0.00064 U	0.00064 U	0.0036 U	0.014 U	0.0048 U	0.0025 U
PCB Congener #156	MG/KG	0.0005	0.00067 N	0.0013	0.0013 N	0.0038 J	0.013 J	0.0029 J	0.0038
PCB Congener #157	MG/KG	0.0005	0.0017 U	0.002 N	0.0029 U	0.0098 N	0.015 N	0.006 U	0.012 N
PCB Congener #167	MG/KG	0.00001	0.00064 U	0.0003 J	0.00064 U	0.0033 U	0.0061 U	0.0026 U	0.0024 U
PCB Congener #169	MG/KG	0.01	0.00064 U	0.00064 U	0.00064 U	0.00065 U	0.00063 U	0.00064 U	0.00064 U
PCB Congener #189	MG/KG	0.0001	0.00074 U	0.00078 U	0.00078 U	0.00086 U	0.0018 U	0.00023 N	0.0009 U
PCB Congener #77	MG/KG	0.0001	0.00064 U	0.00064 U	0.00064 U	0.013 U	0.025 U	0.013 U	0.0025 U
PCB Congener #81	MG/KG	0.0001	0.004 U	0.012 U	0.016 U	0.11 U	0.14 U	0.061 U	0.095 U
Tissue Data 1/2 of Non-detect Calculations									CR2 SBF1D
PCB Congener	TEFs	CR2-LMB1	CR-LMB2	CR-LMB3	CR2-SBF1	CR2-SBF2	CR-SBF3	11/18/2002	11/18/2002
PCB Congener #105	MG/KG	0.0001	3.7E-04 N	1.6E-03 N	1.4E-03 N	1.1E-02 N	1.4E-02 N	4.6E-03 N	8.0E-03 N
PCB Congener #114	MG/KG	0.0005	1.6E-03 U	1.1E-03 U	1.8E-03 U	1.1E-02 U	1.3E-02 U	1.0E-02 U	1.0E-02 U
PCB Congener #118	MG/KG	0.0001	1.4E-03 N	7.7E-03	6.9E-03	4.8E-02	8.5E-02	2.5E-02	4.6E-02
PCB Congener #123	MG/KG	0.0001	3.8E-04 U	9.5E-04 U	9.0E-04 U	1.1E-02 U	6.0E-03 U	2.3E-03 U	8.0E-03 U
PCB Congener #126	MG/KG	0.1	3.2E-04 U	3.2E-04 U	3.2E-04 U	1.8E-03 U	7.0E-03 U	2.4E-03 U	1.3E-03 U
PCB Congener #156	MG/KG	0.0005	3.4E-04 N	1.3E-03	6.5E-04 N	3.8E-03 J	1.3E-02 J	2.9E-03 J	3.8E-03
PCB Congener #157	MG/KG	0.0005	8.5E-04 U	1.0E-03 N	1.5E-03 U	4.9E-03 N	7.5E-03 N	3.0E-03 U	6.0E-03 N
PCB Congener #167	MG/KG	0.00001	3.2E-04 U	3.0E-04 J	3.2E-04 U	1.7E-03 U	3.1E-03 U	1.3E-03 U	1.2E-03 U
PCB Congener #169	MG/KG	0.01	3.2E-04 U	3.2E-04 U	3.2E-04 U	3.3E-04 U	3.2E-04 U	3.2E-04 U	3.2E-04 U
PCB Congener #189	MG/KG	0.0001	3.7E-04 U	3.8E-04 U	3.9E-04 U	4.3E-04 U	8.0E-04 U	1.2E-04 N	4.5E-04 U
PCB Congener #77	MG/KG	0.0001	3.2E-04 U	3.2E-04 U	3.2E-04 U	6.5E-03 U	1.3E-02 U	8.5E-03 U	1.3E-03 U
PCB Congener #81	MG/KG	0.0001	2.0E-03 U	8.0E-03 U	8.0E-03 U	5.5E-02 U	7.0E-02 U	3.1E-02 U	4.8E-02 U
Tissue Data 1/2 of Non-detects TEQ Results									CR2 SBF1D
PCB Congener	TEFs	CR2-LMB1	CR-LMB2	CR-LMB3	CR2-SBF1	CR2-SBF2	CR-SBF3	11/18/2002	11/18/2002
PCB Congener #105	MG/KG	0.0001	3.7E-08 N	1.6E-07 N	1.4E-07 N	1.1E-06 N	1.4E-06 N	4.6E-07 N	8.0E-07 N
PCB Congener #114	MG/KG	0.0005	7.8E-07 U	5.5E-07 U	8.8E-07 U	9.0E-06 U	5.5E-06 U	6.3E-06 U	5.0E-06 U
PCB Congener #118	MG/KG	0.0001	1.4E-07 N	7.7E-07	8.8E-07	4.8E-06	8.5E-06	2.5E-06	4.6E-06
PCB Congener #123	MG/KG	0.0001	3.8E-08 U	9.5E-08 U	9.0E-08 U	1.1E-06 U	6.0E-07 U	2.3E-07 U	8.0E-07 U
PCB Congener #126	MG/KG	0.1	3.2E-05 U	3.2E-05 U	3.2E-05 U	1.8E-04 U	7.0E-04 U	2.4E-04 U	1.3E-04 U
PCB Congener #156	MG/KG	0.0005	1.7E-07 N	6.5E-07	3.3E-07 N	1.9E-06 J	8.5E-06 J	1.5E-06 J	1.8E-06
PCB Congener #157	MG/KG	0.0005	4.3E-07 U	5.0E-07 N	7.3E-07 U	2.5E-06 N	3.8E-06 N	1.5E-06 U	3.0E-06 N
PCB Congener #167	MG/KG	0.00001	3.2E-09 U	3.0E-09 J	3.2E-09 U	1.7E-08 U	3.1E-08 U	1.3E-08 U	1.2E-08 U
PCB Congener #169	MG/KG	0.01	3.2E-06 U	3.2E-06 U	3.2E-06 U	3.3E-06 U	3.2E-06 U	3.2E-06 U	3.2E-06 U
PCB Congener #189	MG/KG	0.0001	3.7E-08 U	3.8E-08 U	3.9E-08 U	4.3E-08 U	9.0E-08 U	1.2E-08 N	4.5E-08 U
PCB Congener #77	MG/KG	0.0001	3.2E-08 U	3.2E-08 U	3.2E-08 U	6.5E-07 U	1.3E-06 U	6.5E-07 U	1.3E-07 U
PCB Congener #81	MG/KG	0.0001	2.0E-07 U	6.0E-07 U	8.0E-07 U	5.5E-06 U	7.0E-06 U	3.1E-06 U	4.8E-06 U
Total TEQ		3.7E-05	3.8E-05	3.8E-05	2.1E-04	7.4E-04	2.6E-04		1.5E-04

USEPA Screening Value, First Tier 2.1E-08
 USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1. When no value is reported, see chlordane constituents.

2. Constituents or metabolites of technical chlordane.

Table 16. Coosa River Fish Tissue PCB Congener Data Detects Only Calculations for Location CR2

PCB Congener	EPA							
	823-B-00-007 TEFs	CR2-LMB1 11/18/2002	CR2-LMB2 11/18/2002	CR2-LMB3 11/18/2002	CR2-SBF1 11/18/2002	CR2-SBF2 11/18/2002	CR2-SBF3 11/18/2002	
PCB Congener #105	MG/KG	0.0001	0.00074 N	0.0031 N	0.0027 N	0.022 N	0.027 N	0.0091 N
PCB Congener #114	MG/KG	0.0005	0.0031 U	0.0022 U	0.0035 U	0.036 U	0.022 U	0.025 U
PCB Congener #118	MG/KG	0.0001	0.0027 N	0.0077	0.0069	0.048	0.085	0.025
PCB Congener #123	MG/KG	0.0001	0.00075 U	0.0019 U	0.0018 U	0.022 U	0.012 U	0.0045 U
PCB Congener #126	MG/KG	0.1	0.00064 U	0.00064 U	0.00064 U	0.0036 U	0.014 U	0.0048 U
PCB Congener #156	MG/KG	0.0005	0.00067 N	0.0013	0.0013 N	0.0038 J	0.013 J	0.0029 J
PCB Congener #157	MG/KG	0.0005	0.0017 U	0.002 N	0.0029 U	0.0098 N	0.015 N	0.006 U
PCB Congener #167	MG/KG	0.00001	0.00064 U	0.0003 J	0.00064 U	0.0033 U	0.0061 U	0.0026 U
PCB Congener #169	MG/KG	0.01	0.00064 U	0.00064 U	0.00064 U	0.00065 U	0.00063 U	0.00064 U
PCB Congener #189	MG/KG	0.0001	0.00074 U	0.00076 U	0.00078 U	0.00086 U	0.0018 U	0.00023 N
PCB Congener #77	MG/KG	0.0001	0.00064 U	0.00064 U	0.00064 U	0.013 U	0.025 U	0.013 U
PCB Congener #81	MG/KG	0.0001	0.004 U	0.012 U	0.016 U	0.11 U	0.14 U	0.061 U
Tissue data detects only TEQ Results								
PCB Congener	823-B-00-007 TEFs	CR2-LMB1 11/18/2002	CR2-LMB2 11/18/2002	CR2-LMB3 11/18/2002	CR2-SBF1 11/18/2002	CR2-SBF2 11/18/2002	CR2-SBF3 11/18/2002	
PCB Congener #105	MG/KG	0.0001						
PCB Congener #114	MG/KG	0.0005						
PCB Congener #118	MG/KG	0.0001		7.700E-07	6.900E-07	4.800E-06	6.500E-06	2.500E-06
PCB Congener #123	MG/KG	0.0001						
PCB Congener #126	MG/KG	0.1						
PCB Congener #156	MG/KG	0.0005		6.500E-07		1.800E-06	6.500E-06	1.450E-06
PCB Congener #157	MG/KG	0.0005						
PCB Congener #167	MG/KG	0.00001		3.000E-09				
PCB Congener #189	MG/KG	0.01						
PCB Congener #77	MG/KG	0.0001						
PCB Congener #81	MG/KG	0.0001						
Total TEQ				1.42E-06	6.90E-07	6.70E-06	1.50E-05	3.95E-06
USEPA Screening Value, Frist Tier		2.1E-08						
USEPA Risk Value, Second Tier		2.1E-06						

Data Qualifiers

A-Average value. NA-Not analyzed. NI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1.When no value is reported, see chlordane constituents.

2.Constituents or metabolites of technical chlordane.

Table 17 Coosa River Fish Tissue PCB Congener Data 1/10 Detection Limit Calculations for Location CR3

Tissue Data	EPA							CR3 SBF1D
	823-B-00-007	CR3-LMB1	CR3-LMB2	CR3-LMB3	CR3-SBF1	CR3-SBF2	CR3-SBF3	
PCB Congener	TEFs	11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	12/09/2002	11/20/2002
PCB Congener #105	MG/KG	0.0001	0.014 N	0.018 N	0.0068 N	0.0064 N	0.0038 N	0.0035 N
PCB Congener #114	MG/KG	0.0005	0.014 U	0.013 U	0.01 U	0.0076 U	0.004 U	0.0054 U
PCB Congener #118	MG/KG	0.0001	0.033 N	0.042	0.022	0.017	0.0081	0.014
PCB Congener #123	MG/KG	0.0001	0.0048 U	0.012 U	0.0047 U	0.0054 U	0.003 U	0.0037 U
PCB Congener #126	MG/KG	0.1	0.0041 U	0.014 U	0.0026 U	0.0026 U	0.0066 U	0.0026 U
PCB Congener #156	MG/KG	0.0005	0.0045 J	0.0093 N	0.0043 N	0.002 N	0.0012	0.0017
PCB Congener #157	MG/KG	0.0005	0.012 N	0.016 N	0.0071 N	0.0024 N	0.0036 N	0.0029 N
PCB Congener #167	MG/KG	0.00001	0.0033 U	0.0022 N	0.0015 J	0.0015 U	0.00025 J	0.0016 U
PCB Congener #169	MG/KG	0.01	0.00064 U	0.00065 U	0.00064 U	0.00065 U	0.00066 U	0.00066 U
PCB Congener #189	MG/KG	0.0001	0.00048 N	0.00054 J	0.00026 J	0.00078 U	0.0007 U	0.00065 U
PCB Congener #77	MG/KG	0.0001	0.0026 U	0.0065 U	0.0026 U	0.0026 U	0.0066 U	0.0026 U
PCB Congener #81	MG/KG	0.0001	0.068 U	0.062 U	0.039 U	0.031 U	0.02 U	0.025 U
Tissue Data 1/10 of Detection Limit Calculations								
PCB Congener	TEFs	CR3-LMB1	CR3-LMB2	CR3-LMB3	CR3-SBF1	CR3-SBF2	CR3-SBF3	CR3 SBF1D
PCB Congener #105	MG/KG	0.0001	7.0E-03 N	9.0E-03 N	3.4E-03 N	3.2E-03 N	1.9E-03 N	1.8E-03 N
PCB Congener #114	MG/KG	0.0005	7.0E-03 U	6.5E-03 U	5.0E-03 U	3.8E-03 U	2.0E-03 U	2.7E-03 U
PCB Congener #118	MG/KG	0.0001	1.7E-02 N	4.2E-02	2.2E-02	1.7E-02	8.1E-03	1.4E-02
PCB Congener #123	MG/KG	0.0001	2.4E-03 U	6.0E-03 U	2.4E-03 U	2.7E-03 U	1.5E-03 U	1.9E-03 U
PCB Congener #126	MG/KG	0.1	2.1E-03 U	7.0E-03 U	1.3E-03 U	1.3E-03 U	3.3E-04 U	1.3E-03 U
PCB Congener #156	MG/KG	0.0005	4.5E-03 J	4.7E-03 N	2.2E-03 N	1.0E-03 N	1.2E-03	1.7E-03
PCB Congener #157	MG/KG	0.0005	6.0E-03 N	8.0E-03 N	3.6E-03 N	1.2E-03 N	1.8E-03 N	1.5E-03 N
PCB Congener #167	MG/KG	0.00001	1.7E-03 U	1.1E-03 N	1.5E-03 J	7.5E-04 U	2.5E-04 J	8.0E-04 U
PCB Congener #169	MG/KG	0.01	3.2E-04 U	3.3E-04 U	3.2E-04 U	3.3E-04 U	3.3E-04 U	3.3E-04 U
PCB Congener #189	MG/KG	0.0001	2.4E-04 N	5.4E-04 J	2.6E-04 J	3.9E-04 U	3.5E-04 U	3.3E-04 U
PCB Congener #77	MG/KG	0.0001	1.3E-03 U	3.3E-03 U	1.3E-03 U	1.3E-03 U	3.3E-04 U	3.3E-04 U
PCB Congener #81	MG/KG	0.0001	3.4E-02 U	3.1E-02 U	2.0E-02 U	1.6E-02 U	1.0E-02 U	1.3E-02 U
Total TEQ								
Tissue Data 1/10 Detection Limit TEQ Results								
PCB Congener	TEFs	CR3-LMB1	CR3-LMB2	CR3-LMB3	CR3-SBF1	CR3-SBF2	CR3-SBF3	CR3 SBF1D
PCB Congener #105	MG/KG	0.0001	7.0E-07 N	9.0E-07 N	3.4E-07 N	3.2E-07 N	1.9E-07 N	1.8E-07 N
PCB Congener #114	MG/KG	0.0005	3.5E-06 U	3.3E-06 U	2.5E-06 U	1.9E-06 U	1.0E-06 U	1.4E-06 U
PCB Congener #118	MG/KG	0.0001	1.7E-06 N	4.2E-06	2.2E-06	1.7E-06	8.1E-07	1.4E-06
PCB Congener #123	MG/KG	0.0001	2.4E-07 U	6.0E-07 U	2.4E-07 U	2.7E-07 U	1.5E-07 U	1.9E-07 U
PCB Congener #126	MG/KG	0.1	2.1E-04 U	7.0E-04 U	1.3E-04 U	1.3E-04 U	3.3E-05 U	1.3E-04 U
PCB Congener #156	MG/KG	0.0005	2.3E-06 J	2.3E-06 N	1.1E-06 N	5.0E-07 N	6.0E-07	8.5E-07 J
PCB Congener #157	MG/KG	0.0005	3.0E-06 N	4.0E-06 N	1.8E-06 N	6.0E-07 N	9.0E-07 N	7.3E-07 N
PCB Congener #167	MG/KG	0.00001	1.7E-08 U	1.1E-08 N	1.5E-08 J	7.5E-09 U	2.5E-09 J	8.0E-09 U
PCB Congener #169	MG/KG	0.01	3.2E-06 U	3.3E-06 U	3.2E-06 U	3.3E-06 U	3.3E-06 U	3.3E-06 U
PCB Congener #189	MG/KG	0.0001	2.4E-08 N	5.4E-08 J	2.6E-08 J	3.9E-08 U	3.5E-08 U	3.3E-08 U
PCB Congener #77	MG/KG	0.0001	1.3E-07 U	3.3E-07 U	1.3E-07 U	1.3E-07 U	3.3E-08 U	3.3E-07 U
PCB Congener #81	MG/KG	0.0001	3.4E-06 U	3.1E-06 U	2.0E-06 U	1.6E-06 U	1.0E-06 U	1.3E-06 U
Total TEQ		2.2E-04	7.2E-04	1.4E-04	1.4E-04	4.1E-05	1.4E-04	4.2E-05

USEPA Screening Value, Frist Tier 2.1E-08
 USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1.When no value is reported, see chlordane constituents.

2 Constituents or metabolites of technical chlordane.

Table 18. Coosa River PCB Congener Data 1/2 Detection Limit Calculations for Location CR3

PCB Congener	TEFs	EPA						CR3 SBF1D	
		823-B-00-007	CR3-LMB1	CR3-LMB2	CR3-LMB3	CR3-SBF1	CR3-SBF2		
11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	12/09/2002	11/20/2002	
PCB Congener #105	MG/KG	0.0001	0.014 N	0.018 N	0.0068 N	0.0064 N	0.0038 N	0.0035 N	0.0035 N
PCB Congener #114	MG/KG	0.0005	0.014 U	0.013 U	0.01 U	0.0076 U	0.004 U	0.0054 U	0.0064 U
PCB Congener #118	MG/KG	0.0001	0.033 N	0.042	0.022	0.017	0.0081	0.014	0.014
PCB Congener #123	MG/KG	0.0001	0.0048 U	0.012 U	0.0047 U	0.0054 U	0.003 U	0.0037 U	0.0042 U
PCB Congener #126	MG/KG	0.1	0.0041 U	0.014 U	0.0026 U	0.0026 U	0.00066 U	0.0026 U	0.0066 U
PCB Congener #156	MG/KG	0.0005	0.0045 J	0.0093 N	0.0043 N	0.002 N	0.0012	0.0017	0.0014 J
PCB Congener #157	MG/KG	0.0005	0.012 N	0.016 N	0.0071 N	0.0024 N	0.0036 N	0.0029 N	0.0016 N
PCB Congener #167	MG/KG	0.00001	0.0033 U	0.0022 N	0.0015 J	0.0015 U	0.00025 J	0.0016 U	0.0015 J
PCB Congener #169	MG/KG	0.01	0.00064 U	0.00065 U	0.00064 U	0.00065 U	0.00066 U	0.00065 U	0.00066 U
PCB Congener #189	MG/KG	0.0001	0.00048 N	0.00054 J	0.00026 J	0.00078 U	0.0007 U	0.00065 U	0.00082 U
PCB Congener #77	MG/KG	0.0001	0.0026 U	0.0065 U	0.0026 U	0.0026 U	0.00066 U	0.00065 U	0.0026 U
PCB Congener #81	MG/KG	0.0001	0.068 U	0.062 U	0.039 U	0.031 U	0.02 U	0.025 U	0.026 U

Tissue Data 1/2 of Detection Limit Calculations

PCB Congener	TEFs	CR3						SBF1D	
		CR3-LMB1	CR3-LMB2	CR3-LMB3	CR3-SBF1	CR3-SBF2	CR3-SBF3		
11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	12/09/2002	11/20/2002	
PCB Congener #105	MG/KG	0.0001	7.0E-03 N	9.0E-03 N	3.4E-03 N	3.2E-03 N	1.9E-03 N	1.8E-03 N	1.8E-03 N
PCB Congener #114	MG/KG	0.0005	7.0E-03 U	6.5E-03 U	5.0E-03 U	3.8E-03 U	2.0E-03 U	2.7E-03 U	3.2E-03 U
PCB Congener #118	MG/KG	0.0001	1.7E-02 N	4.2E-02	2.2E-02	1.7E-02	8.1E-03	1.4E-02	1.4E-02
PCB Congener #123	MG/KG	0.0001	2.4E-03 U	6.0E-03 U	2.4E-03 U	2.7E-03 U	1.5E-03 U	1.9E-03 U	2.1E-03 U
PCB Congener #126	MG/KG	0.1	2.1E-03 U	7.0E-03 U	1.3E-03 U	1.3E-03 U	3.3E-04 U	1.3E-03 U	3.3E-04 U
PCB Congener #156	MG/KG	0.0005	4.5E-03 J	4.7E-03 N	2.2E-03 N	1.0E-03 N	1.2E-03	1.7E-03	1.4E-03 J
PCB Congener #157	MG/KG	0.0005	6.0E-03 N	8.0E-03 N	3.6E-03 N	1.2E-03 N	1.8E-03 N	1.5E-03 N	8.0E-04 N
PCB Congener #167	MG/KG	0.00001	1.7E-03 U	1.1E-03 N	1.5E-03 J	7.5E-04 U	2.5E-04 J	8.0E-04 U	1.5E-03 J
PCB Congener #169	MG/KG	0.01	3.2E-04 U	3.3E-04 U	3.2E-04 U	3.3E-04 U	3.3E-04 U	3.3E-04 U	3.3E-04 U
PCB Congener #189	MG/KG	0.0001	2.4E-04 N	5.4E-04 J	2.6E-04 J	3.9E-04 U	3.5E-04 U	3.5E-04 U	4.1E-04 U
PCB Congener #77	MG/KG	0.0001	1.3E-03 U	3.3E-03 U	1.3E-03 U	1.3E-03 U	3.3E-04 U	3.3E-04 U	1.3E-03 U
PCB Congener #81	MG/KG	0.0001	3.4E-02 U	3.1E-02 U	2.0E-02 U	1.6E-02 U	1.0E-02 U	1.3E-02 U	1.3E-02 U

Total TEQ

Tissue Data 1/2 Detection Limit TEQ Results

PCB Congener	TEFs	CR3						SBF1D	
		CR3-LMB1	CR3-LMB2	CR3-LMB3	CR3-SBF1	CR3-SBF2	CR3-SBF3		
11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	12/09/2002	11/20/2002	
PCB Congener #105	MG/KG	0.0001	7.0E-07 N	9.0E-07 N	3.4E-07 N	3.2E-07 N	1.9E-07 N	1.8E-07 N	1.8E-07 N
PCB Congener #114	MG/KG	0.0005	3.5E-06 U	3.3E-06 U	2.5E-06 U	1.9E-06 U	1.0E-06 U	1.4E-06 U	1.6E-06 U
PCB Congener #118	MG/KG	0.0001	1.7E-06 N	4.2E-06	2.2E-06	1.7E-06	8.1E-07	1.4E-06	1.4E-06
PCB Congener #123	MG/KG	0.0001	2.4E-07 U	6.0E-07 U	2.4E-07 U	2.7E-07 U	1.5E-07 U	1.9E-07 U	2.1E-07 U
PCB Congener #126	MG/KG	0.1	2.1E-04 U	7.0E-04 U	1.3E-04 U	1.3E-04 U	3.3E-05 U	1.3E-04 U	3.3E-05 U
PCB Congener #156	MG/KG	0.0005	2.3E-06 J	2.3E-06 N	1.1E-06 N	5.0E-07 N	6.0E-07	8.5E-07	7.0E-07 J
PCB Congener #157	MG/KG	0.0005	3.0E-06 N	4.0E-06 N	1.8E-06 N	6.0E-07 N	9.0E-07 N	7.3E-07 N	4.0E-07 N
PCB Congener #167	MG/KG	0.00001	1.7E-08 U	1.1E-08 N	1.5E-08 J	7.5E-09 U	2.5E-09 J	8.0E-09 U	1.5E-08 J
PCB Congener #169	MG/KG	0.01	3.2E-06 U	3.3E-06 U	3.2E-06 U	3.3E-06 U	3.3E-06 U	3.3E-06 U	3.3E-06 U
PCB Congener #189	MG/KG	0.0001	2.4E-08 N	5.4E-08 J	2.6E-08 J	3.9E-08 U	3.5E-08 U	3.3E-08 U	4.1E-08 U
PCB Congener #77	MG/KG	0.0001	1.3E-07 U	3.3E-07 U	1.3E-07 U	1.3E-07 U	3.3E-08 U	3.3E-08 U	1.3E-07 U
PCB Congener #81	MG/KG	0.0001	3.4E-06 U	3.1E-06 U	2.0E-06 U	1.6E-06 U	1.0E-06 U	1.3E-06 U	1.3E-06 U

Total TEQ 2.2E-04 7.2E-04 1.4E-04 1.4E-04 4.1E-05 1.4E-04 4.2E-05

USEPA Screening Value, First Tier 2.1E-08

USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1.When no value is reported, see chlordane constituents.

2.Constituents or metabolites of technical chlordane.

Table 19. Coosa River Fish Tissue PCB Congener Data Detects Only Calculations for Location CR3

PCB Congener	EPA							CR3 SBF1D
	823-B-00-007	CR3-LMB1	CR3-LMB2	CR3-LMB3	CR3-SBF1	CR3-SBF2	CR3-SBF3	
	TEFs	11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	12/09/2002	11/20/2002
PCB Congener #105	MG/KG	0.0001	0.014 N	0.018 N	0.0068 N	0.0064 N	0.0038 N	0.0035 N
PCB Congener #114	MG/KG	0.0005	0.014 U	0.013 U	0.01 U	0.0078 U	0.004 U	0.0054 U
PCB Congener #118	MG/KG	0.0001	0.033 N	0.042	0.022	0.017	0.0081	0.014
PCB Congener #123	MG/KG	0.0001	0.0048 U	0.012 U	0.0047 U	0.0054 U	0.003 U	0.0037 U
PCB Congener #126	MG/KG	0.1	0.0041 U	0.014 U	0.0026 U	0.0026 U	0.00066 U	0.0026 U
PCB Congener #156	MG/KG	0.0005	0.0045 J	0.0093 N	0.0043 N	0.002 N	0.0012	0.0017
PCB Congener #157	MG/KG	0.0005	0.012 N	0.016 N	0.0071 N	0.0024 N	0.0036 N	0.0029 N
PCB Congener #167	MG/KG	0.00001	0.0033 U	0.0022 N	0.0015 J	0.0015 U	0.00025 J	0.0018 U
PCB Congener #169	MG/KG	0.01	0.00064 U	0.00065 U	0.00064 U	0.00065 U	0.00066 U	0.00066 U
PCB Congener #189	MG/KG	0.0001	0.00048 N	0.00054 J	0.00026 J	0.00078 U	0.0007 U	0.00065 U
PCB Congener #77	MG/KG	0.0001	0.0026 U	0.0065 U	0.0026 U	0.0026 U	0.00066 U	0.0026 U
PCB Congener #81	MG/KG	0.0001	0.068 U	0.082 U	0.039 U	0.031 U	0.02 U	0.025 U
Tissue data detects only TEO Results								
PCB Congener	EPA							CR3 SBF1D
	823-B-00-007	CR3-LMB1	CR3-LMB2	CR3-LMB3	CR3-SBF1	CR3-SBF2	CR3-SBF3	
	TEFs	11/20/2002	11/20/2002	11/20/2002	11/20/2002	11/20/2002	12/09/2002	11/20/2002
PCB Congener #105	MG/KG	0.0001						
PCB Congener #114	MG/KG	0.0005						
PCB Congener #118	MG/KG	0.0001		4.200E-06	2.200E-06	1.700E-06	8.100E-07	1.400E-06
PCB Congener #123	MG/KG	0.0001						
PCB Congener #126	MG/KG	0.1						
PCB Congener #156	MG/KG	0.0005	2.250E-06				6.000E-07	8.500E-07
PCB Congener #157	MG/KG	0.0005						7.000E-07
PCB Congener #167	MG/KG	0.00001			1.500E-08		2.500E-09	
PCB Congener #169	MG/KG	0.01						
PCB Congener #189	MG/KG	0.0001		5.400E-08	2.800E-08			
PCB Congener #77	MG/KG	0.0001						
PCB Congener #81	MG/KG	0.0001						
Total TEQ		2.25E-06	4.25E-06	2.24E-06	1.70E-06	1.41E-06	2.25E-06	2.12E-06
USEPA Screening Value, Frist Tier		2.1E-08						
USEPA Risk Value, Second Tier		2.1E-06						

Data Qualifiers

A-Average value. NA-Not analyzed NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-OC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS

1.When no value is reported, see chlordane constituents.

2.Constituents or metabolites of technical chlordane.

Table 20. Coosa River PCB Congener Data 1/10 Detection Limit Calculations for Location Lake Weiss 1

Tissue Data	EPA LW1								
	823-B-00-007		LMB2D	LW1LMB1	LW1LMB2	LW1LMB3	LW1SBF1	LW1SBF2	LW1SBF3
PCB Congener	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	11/19/2002	12/11/2002	12/11/2002	12/11/2002
PCB Congener #105	MG/KG	0.0001	0.008 N	0.0032 J	0.0017 J	0.00091 J	0.0052 J	0.0063	0.0057
PCB Congener #114	MG/KG	0.0005	0.0064 U	0.002 N	0.0016 N	0.0028 N	0.0043 N	0.0076 U	0.0076 U
PCB Congener #118	MG/KG	0.0001	0.021	0.011 JC	0.0048 JC	0.021 JC	0.037 JC	0.021	0.016
PCB Congener #123	MG/KG	0.0001	0.0039 U	0.00027 N	0.00019 N	0.00095 N	0.00025 JN	0.0039 N	0.0034 N
PCB Congener #126	MG/KG	0.1	0.004 U	0.0023 J	0.00033 N	0.004 J	0.0013 J	0.0032 U	0.0032 U
PCB Congener #156	MG/KG	0.0005	0.0025	0.0015 J	0.00009 J	0.0031 J	0.0032 J	0.0027	0.0024
PCB Congener #157	MG/KG	0.0005	0.0046 N	0.00012 J	0.00007 J	0.00065 J	0.00073 J	0.0028 N	0.0054 N
PCB Congener #167	MG/KG	0.00001	0.002 U	0.0025 N	0.0039 N	0.00011 J	0.0002 J	0.00064 J	0.00075 N
PCB Congener #169	MG/KG	0.01	0.00066 U	0.00013 U	0.00013 U	0.00013 U	0.00013 U	0.00063 U	0.00064 U
PCB Congener #189	MG/KG	0.0001	0.00026 JN	0.00018 J	0.00016 J	0.00022 J	0.0002 J	0.00063 U	0.00064 U
PCB Congener #77	MG/KG	0.0001	0.00066 U	0.023	0.017	0.038	0.068	0.0032 U	0.0032 U
PCB Congener #81	MG/KG	0.0001	0.046 U	0.0015 N	0.00042 N	0.0029 N	0.0072 JN	0.041 U	0.045 U.

Tissue Data 1/2 of Detection Limit Calculations

PCB Congener	LW1								
	LMB2D	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	12/11/2002	12/11/2002	
PCB Congener #105	MG/KG	0.0001	8.0E-04 N	3.2E-03 J	1.7E-03 J	9.1E-04 J	5.2E-03 J	6.3E-03	5.7E-03
PCB Congener #114	MG/KG	0.0005	6.4E-04 U	2.0E-04 N	1.6E-04 N	2.8E-04 N	4.3E-04 N	7.6E-04 U	7.6E-04 U
PCB Congener #118	MG/KG	0.0001	2.1E-02	1.1E-02 JC	4.8E-03 JC	2.1E-02 JC	3.7E-02 JC	2.1E-02	1.6E-02
PCB Congener #123	MG/KG	0.0001	3.9E-04 U	2.7E-05 N	1.9E-05 N	9.5E-05 N	2.5E-04 JN	3.9E-04 N	3.4E-04 N
PCB Congener #126	MG/KG	0.1	4.0E-04 U	2.3E-03 J	3.3E-05 N	4.0E-03 J	1.3E-03 J	3.2E-04 U	3.2E-04 U
PCB Congener #156	MG/KG	0.0005	2.5E-03	1.5E-03 J	9.0E-05 J	3.1E-03 J	3.2E-03 J	2.7E-03	2.4E-03
PCB Congener #157	MG/KG	0.0005	4.6E-04 N	1.2E-04 J	7.0E-05 J	6.5E-04 J	7.3E-04 J	2.8E-04 N	5.4E-04 N
PCB Congener #167	MG/KG	0.00001	2.0E-04 U	2.5E-04 N	3.9E-04 N	1.1E-04 J	2.0E-04 J	6.4E-04 J	7.5E-05 N
PCB Congener #169	MG/KG	0.01	6.6E-05 U	1.3E-05 U	1.3E-05 U	1.3E-05 U	1.3E-05 U	6.3E-05 U	6.4E-05 U
PCB Congener #189	MG/KG	0.0001	2.6E-04 JN	1.8E-04 J	1.6E-04 J	2.2E-04 J	2.0E-04 J	6.3E-05 U	6.4E-05 U
PCB Congener #77	MG/KG	0.0001	6.6E-05 U	2.3E-02	1.7E-02	3.8E-02	6.8E-02	3.2E-04 U	3.2E-04 U
PCB Congener #81	MG/KG	0.0001	4.6E-03 U	1.5E-04 N	4.2E-05 N	2.9E-04 N	7.2E-03 JN	4.1E-03 U	4.5E-03 U

Tissue Data 1/2 Detection Limit TEQ Results

PCB Congener	LW1								
	LMB2D	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	12/11/2002	12/11/2002	
PCB Congener #105	MG/KG	0.0001	8.0E-08 N	3.2E-07 J	1.7E-07 J	9.1E-08 J	5.2E-07 J	6.3E-07	5.7E-07
PCB Congener #114	MG/KG	0.0005	3.2E-07 U	1.0E-07 N	8.0E-08 N	1.4E-07 N	2.2E-07 N	3.8E-07 U	3.8E-07 U
PCB Congener #118	MG/KG	0.0001	2.1E-06	1.1E-06 JC	4.8E-07 JC	2.1E-06 JC	3.7E-06 JC	2.1E-06	1.6E-06
PCB Congener #123	MG/KG	0.0001	3.9E-08 U	2.7E-09 N	1.9E-09 N	9.5E-09 N	2.5E-08 JN	3.9E-08 N	3.4E-08 N
PCB Congener #126	MG/KG	0.1	4.0E-05 U	2.3E-04 J	3.3E-06 N	4.0E-04 J	1.3E-04 J	3.2E-05 U	3.2E-05 U
PCB Congener #156	MG/KG	0.0005	1.3E-06	7.5E-07 J	4.5E-08 J	1.6E-06 J	1.6E-06 J	1.4E-06	1.2E-06
PCB Congener #157	MG/KG	0.0005	2.3E-07 N	6.0E-08 J	3.5E-08 J	3.3E-07 J	3.7E-07 J	1.4E-07 N	2.7E-07 N
PCB Congener #167	MG/KG	0.00001	2.0E-09 U	2.5E-09 N	3.9E-09 N	1.1E-09 J	2.0E-09 J	6.4E-09 J	7.5E-10 N
PCB Congener #169	MG/KG	0.01	6.6E-07 U	1.3E-07 U	1.3E-07 U	1.3E-07 U	1.3E-07 U	6.3E-07 U	6.4E-07 U
PCB Congener #189	MG/KG	0.0001	2.6E-08 JN	1.8E-08 J	1.6E-08 J	2.2E-08 J	2.0E-08 J	6.3E-09 U	6.4E-09 U
PCB Congener #77	MG/KG	0.0001	6.6E-09 U	2.3E-06	1.7E-06	3.8E-06	6.8E-06	3.2E-08 U	3.2E-08 U
PCB Congener #81	MG/KG	0.0001	4.6E-07 U	1.5E-08 N	4.2E-09 N	2.9E-08 N	7.2E-07 JN	4.1E-07 U	4.5E-07 U
Total TEQ			4.5E-05	2.3E-04	6.0E-06	4.1E-04	1.4E-04	3.8E-05	3.7E-05

USEPA Screening Value, Frist Tier 2.1E-08

USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1.When no value is reported, see chlordane constituents.

2.Constituents or metabolites of technical chlordane.

Table 21. Coosa River PCB Congener Data 1/2 Detection Limit Calculations for Location Lake Weiss 1

PCB Congener	EPA 823-B-00-007	LW1							
		LMB2D TEFs	11/19/2002	LW1LMB1 11/19/2002	LW1LMB2 11/19/2002	LW1LMB3 11/19/2002	LW1SBF1 12/11/2002	LW1SBF2 12/11/2002	LW1SBF3 12/11/2002
PCB Congener #105	MG/KG	0.0001	0.008 N	0.0032 J	0.0017 J	0.00091 J	0.0052 J	0.0063	0.0057
PCB Congener #114	MG/KG	0.0005	0.0064 U	0.002 N	0.0016 N	0.0028 N	0.0043 N	0.0076 U	0.0076 U
PCB Congener #118	MG/KG	0.0001	0.021	0.011 JC	0.0048 JC	0.021 JC	0.037 JC	0.021	0.016
PCB Congener #123	MG/KG	0.0001	0.0039 U	0.00027 N	0.00019 N	0.00095 N	0.00025 JN	0.0039 N	0.0034 N
PCB Congener #126	MG/KG	0.1	0.004 U	0.0023 J	0.00033 N	0.004 J	0.0013 J	0.0032 U	0.0032 U
PCB Congener #156	MG/KG	0.0005	0.0025	0.0015 J	0.00009 J	0.0031 J	0.0032 J	0.0027	0.0024
PCB Congener #157	MG/KG	0.0005	0.0048 N	0.00012 J	0.00007 J	0.00065 J	0.00073 J	0.0028 N	0.0054 N
PCB Congener #167	MG/KG	0.0001	0.002 U	0.0025 N	0.0039 N	0.0011 J	0.0002 J	0.0064 J	0.00075 N
PCB Congener #169	MG/KG	0.01	0.0066 U	0.00013 U	0.00013 U	0.00013 U	0.00013 U	0.00064 U	0.00064 U
PCB Congener #189	MG/KG	0.0001	0.00026 JN	0.00018 J	0.00016 J	0.00022 J	0.0002 J	0.00063 U	0.00064 U
PCB Congener #77	MG/KG	0.0001	0.00066 U	0.023	0.017	0.038	0.068	0.0032 U	0.0032 U
PCB Congener #81	MG/KG	0.0001	0.046 U	0.0015 N	0.00042 N	0.0029 N	0.0072 JN	0.041 U	0.045 U

Tissue Data 1/2 of Detection Limit Calculations

PCB Congener	TEFs	LW1							
		LMB2D 11/19/2002	LW1LMB1 11/19/2002	LW1LMB2 11/19/2002	LW1LMB3 11/19/2002	LW1SBF1 12/11/2002	LW1SBF2 12/11/2002	LW1SBF3 12/11/2002	
PCB Congener #105	MG/KG	0.0001	4.0E-03 N	3.2E-03 J	1.7E-03 J	9.1E-04 J	5.2E-03 J	6.3E-03	5.7E-03
PCB Congener #114	MG/KG	0.0005	3.2E-03 U	1.0E-03 N	8.0E-04 N	1.4E-03 N	2.2E-03 N	3.8E-03 U	3.8E-03 U
PCB Congener #118	MG/KG	0.0001	2.1E-02	1.1E-02 JC	4.8E-03 JC	2.1E-02 JC	3.7E-02 JC	2.1E-02	1.6E-02
PCB Congener #123	MG/KG	0.0001	2.0E-03 U	1.4E-04 N	9.5E-05 N	4.8E-04 N	2.5E-04 JN	2.0E-03 N	1.7E-03 N
PCB Congener #126	MG/KG	0.1	2.0E-03 U	2.3E-03 J	1.7E-04 N	4.0E-03 J	1.3E-03 J	1.6E-03 U	1.6E-03 U
PCB Congener #156	MG/KG	0.0005	2.5E-03	1.5E-03 J	9.0E-05 J	3.1E-03 J	3.2E-03 J	2.7E-03	2.4E-03
PCB Congener #157	MG/KG	0.0005	2.3E-03 N	1.2E-04 J	7.0E-05 J	6.5E-04 J	7.3E-04 J	1.4E-03 N	2.7E-03 N
PCB Congener #167	MG/KG	0.00001	1.0E-03 U	1.3E-03 N	2.0E-03 N	1.1E-04 J	2.0E-04 J	6.4E-04 J	3.8E-04 N
PCB Congener #169	MG/KG	0.01	3.3E-04 U	6.5E-05 U	6.5E-05 U	6.5E-05 U	6.5E-05 U	3.2E-04 U	3.2E-04 U
PCB Congener #189	MG/KG	0.0001	2.6E-04 JN	1.8E-04 J	1.8E-04 J	2.2E-04 J	2.0E-04 J	3.2E-04 U	3.2E-04 U
PCB Congener #77	MG/KG	0.0001	3.3E-04 U	2.3E-02	1.7E-02	3.8E-02	6.8E-02	1.6E-03 U	1.6E-03 U
PCB Congener #81	MG/KG	0.0001	2.3E-02 U	7.5E-04 N	2.1E-04 N	1.5E-03 N	7.2E-03 JN	2.1E-02 U	2.3E-02 U

Tissue Data 1/2 Detection Limit TEQ Results

PCB Congener	TEFs	LW1							
		LMB2D 11/19/2002	LW1LMB1 11/19/2002	LW1LMB2 11/19/2002	LW1LMB3 11/19/2002	LW1SBF1 12/11/2002	LW1SBF2 12/11/2002	LW1SBF3 12/11/2002	
PCB Congener #105	MG/KG	0.0001	4.0E-07 N	3.2E-07 J	1.7E-07 J	9.1E-08 J	5.2E-07 J	6.3E-07	5.7E-07
PCB Congener #114	MG/KG	0.0005	1.6E-06 U	5.0E-07 N	4.0E-07 N	7.0E-07 N	1.1E-06 N	1.9E-06 U	1.9E-06 U
PCB Congener #118	MG/KG	0.0001	2.1E-06	1.1E-06 JC	4.8E-07 JC	2.1E-06 JC	3.7E-06 JC	2.1E-06	1.6E-06
PCB Congener #123	MG/KG	0.0001	2.0E-07 U	1.4E-06 N	9.5E-09 N	4.8E-08 N	2.5E-08 JN	2.0E-07 N	1.7E-07 N
PCB Congener #126	MG/KG	0.1	2.0E-04 U	2.3E-04 J	1.7E-05 N	4.0E-04 J	1.3E-04 J	1.6E-04 U	1.6E-04 U
PCB Congener #156	MG/KG	0.0005	1.3E-06	7.5E-07 J	4.5E-08 J	1.6E-06 J	1.6E-06 J	1.4E-06	1.2E-06
PCB Congener #157	MG/KG	0.0005	1.2E-06 N	6.0E-08 J	3.5E-08 J	3.3E-07 J	3.7E-07 J	7.0E-07 N	1.4E-06 N
PCB Congener #167	MG/KG	0.00001	1.0E-08 U	1.3E-08 N	2.0E-08 N	1.1E-09 J	2.0E-09 J	6.4E-09 J	3.8E-09 N
PCB Congener #169	MG/KG	0.01	3.3E-06 U	6.5E-07 U	6.5E-07 U	6.5E-07 U	6.5E-07 U	3.2E-06 U	3.2E-06 U
PCB Congener #189	MG/KG	0.0001	2.6E-08 JN	1.8E-08 J	1.8E-08 J	2.2E-08 J	2.0E-08 J	3.2E-08 U	3.2E-08 U
PCB Congener #77	MG/KG	0.0001	3.3E-08 U	2.3E-06	1.7E-06	3.8E-06	6.8E-06	1.6E-07 U	1.6E-07 U
PCB Congener #81	MG/KG	0.0001	2.3E-06 U	7.5E-08 N	2.1E-08 N	1.5E-07 N	7.2E-07 JN	2.1E-06 U	2.3E-06 U
Total TEQ			2.1E-04	2.4E-04	2.0E-05	4.1E-04	1.5E-04	1.7E-04	1.7E-04

USEPA Screening Value, First Tier 2.1E-06

USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC Indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1. When no value is reported, see chlordane constituents.

2. Constituents or metabolites of technical chlordane..

Table 22. Coosa River Fish Tissue PCB Congener Data Detects Only Calculations for Location Lake Waiba 1

Tissue Data	EPA		LW1											
	823-B-00-007	LMB2D	11/19/2002	LW1LMB1	11/19/2002	LW1LMB2	11/19/2002	LW1LMB3	11/19/2002	LW1SBF1	12/11/2002	LW1SBF2	12/11/2002	LW1SBF3
PCB Congener	TEFs													
PCB Congener #105	MG/KG	0.0001	0.008 N	0.0032 J	0.0017 J	0.00091 J	0.0052 J	0.0063	0.0057					
PCB Congener #114	MG/KG	0.0005	0.0064 U	0.002 N	0.0018 N	0.0028 N	0.0043 N	0.0076 U	0.0076 U					
PCB Congener #118	MG/KG	0.0001	0.021	0.011 JC	0.0048 JC	0.021 JC	0.037 JC	0.021	0.016					
PCB Congener #123	MG/KG	0.0001	0.0039 U	0.00027 N	0.00019 N	0.00095 N	0.00025 JN	0.0039 N	0.0034 N					
PCB Congener #126	MG/KG	0.1	0.004 U	0.0023 J	0.00033 N	0.004 J	0.0013 J	0.0032 U	0.0032 U					
PCB Congener #156	MG/KG	0.0005	0.0025	0.0015 J	0.00009 J	0.0031 J	0.0032 J	0.0027	0.0024					
PCB Congener #157	MG/KG	0.0005	0.0046 N	0.00012 J	0.00007 J	0.00065 J	0.00073 J	0.0028 N	0.0054 N					
PCB Congener #167	MG/KG	0.00001	0.002 U	0.0025 N	0.0039 N	0.00011 J	0.0002 J	0.00064 J	0.00075 N					
PCB Congener #169	MG/KG	0.01	0.00066 U	0.00013 U	0.00013 U	0.00013 U	0.00013 U	0.00063 U	0.00064 U					
PCB Congener #189	MG/KG	0.0001	0.00026 JN	0.00018 J	0.00016 J	0.00022 J	0.0002 J	0.00063 U	0.00064 U					
PCB Congener #77	MG/KG	0.0001	0.00066 U	0.023	0.017	0.038	0.068	0.032 U	0.032 U					
PCB Congener #81	MG/KG	0.0001	0.046 U	0.0015 N	0.00042 N	0.0029 N	0.0072 JN	0.041 U	0.045 U					

Tissue Data Detects Only TEQ Results

PCB Congener	EPA		LW1											
	823-B-00-007	LMB2D	11/19/2002	LW1LMB1	11/19/2002	LW1LMB2	11/19/2002	LW1LMB3	11/19/2002	LW1SBF1	12/11/2002	LW1SBF2	12/11/2002	LW1SBF3
PCB Congener	TEFs													
PCB Congener #105	MG/KG	0.0001	N	3.200E-07 J	1.700E-07 J	9.100E-08 J	5.200E-07 J	6.300E-07	5.700E-07					
PCB Congener #114	MG/KG	0.0005	U	N	N	N	N	N	N	U	U			
PCB Congener #118	MG/KG	0.0001	2.100E-06	1.100E-06 JC	4.800E-07 JC	2.100E-06 JC	3.700E-06 JC	2.100E-06	1.600E-06					
PCB Congener #123	MG/KG	0.0001	U	N	N	N	N	JN	N	N	N			
PCB Congener #126	MG/KG	0.1	U	2.300E-04 J	N	4.000E-04 J	1.300E-04 J	U	U	U	U			
PCB Congener #156	MG/KG	0.0005	1.250E-06	7.500E-07 J	4.500E-08 J	1.550E-06 J	1.800E-06 J	1.350E-06	1.200E-06					
PCB Congener #157	MG/KG	0.0005	N	6.000E-08 J	3.500E-08 J	3.250E-07 J	3.650E-07 J	N	N					
PCB Congener #167	MG/KG	0.00001	U	N	N	N	1.100E-09 J	2.000E-09 J	6.400E-09 J					
PCB Congener #169	MG/KG	0.01	U	U	U	U	U	U	U	U	U			
PCB Congener #189	MG/KG	0.0001	JN	1.800E-08 J	1.600E-08 J	2.200E-08 J	2.000E-08 J	U	U					
PCB Congener #77	MG/KG	0.0001	U	2.300E-06	1.700E-06	3.800E-06	6.800E-06	U	U					
PCB Congener #81	MG/KG	0.0001	U	N	N	N	N	JN	U					
Total TEQ			3.35E-06	2.35E-04	2.45E-06	4.06E-04	1.43E-04	4.09E-06	3.37E-06					

USEPA Screening Value, First Tier 2.1E-08
 USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NI-Inferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1.When no value is reported, see chlordane constituents.

2.Constituents or metabolites of technical chlordane.

Table 23. Coosa River PCB Congener Data 1/10 Detection Limit Calculations for Location Lake Weiss 2

Tissue Data	EPA								LW2 SBF3D
	823-B-00-007	LW2-BCF1	LW2-LMB1	LW2-LMB2	LW2-LMB3	LW2-SBF1	LW2-SBF2	LW2-SBF3	
PCB Congener	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	12/10/2002	12/10/2002	12/10/2002	
PCB Congener #105	MG/KG	0.0001	0.0062 N	0.008	0.0059	0.0059	0.035	0.0015	0.018
PCB Congener #114	MG/KG	0.0005	0.0045 U	0.0062 U	0.0045 U	0.0048 U	0.01 U	0.0014 U	0.034 U
PCB Congener #118	MG/KG	0.0001	0.02	0.02	0.016	0.017	0.095 C	0.0024	0.074 C
PCB Congener #123	MG/KG	0.0001	0.0042 U	0.0025 N	0.0026 U	0.0032 U	0.0087 N	0.0014 U	0.0087 N
PCB Congener #126	MG/KG	0.1	0.0025 U	0.0066 U	0.0013 U	0.0013 U	0.004 U	0.00065 U	0.013 U
PCB Congener #156	MG/KG	0.0005	0.0017 J	0.0031	0.0017	0.0022	0.042	0.00089 J	0.0065
PCB Congener #157	MG/KG	0.0005	0.0016 N	0.005 N	0.0029 N	0.0031 N	0.005 N	0.0016 U	0.0032 N
PCB Congener #167	MG/KG	0.00001	0.00069 J	0.00069 J	0.00042 J	0.00028 J	0.0009 J	0.00059 J	0.0023 J
PCB Congener #169	MG/KG	0.01	0.00066 U	0.00066 U	0.00066 U	0.00065 U	0.00065 U	0.00065 U	0.00078 U
PCB Congener #189	MG/KG	0.0001	0.00075 U	0.00066 U	0.00066 U	0.00066 U	0.0024 U	0.00076 U	0.001 U
PCB Congener #77	MG/KG	0.0001	0.00066 U	0.0013 U	0.0033 U	0.0033 U	0.0013 U	0.00065 U	0.013 U
PCB Congener #81	MG/KG	0.0001	0.035 U	0.044 U	0.016 U	0.028 U	0.023 U	0.0049 U	0.13 U
									0.13 U

Tissue Data 1/10 of Detection Limit Calculations

PCB Congener	TEFs	LW2				LW2			
		LW2-BCF1	LW2-LMB1	LW2-LMB2	LW2-LMB3	LW2-SBF1	LW2-SBF2	LW2-SBF3	SBF3D
		11/19/2002	11/19/2002	11/19/2002	11/19/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002
PCB Congener #105	MG/KG	0.0001	6.2E-04 N	8.0E-03	5.9E-03	3.5E-02	1.5E-03	1.8E-02	1.8E-02
PCB Congener #114	MG/KG	0.0005	4.5E-04 U	6.2E-04 U	4.5E-04 U	4.8E-04 U	1.0E-03 U	1.4E-03 U	3.4E-03 U
PCB Congener #118	MG/KG	0.0001	2.0E-02	2.0E-02	1.6E-02	1.7E-02	9.5E-02 C	2.4E-03	7.4E-02 C
PCB Congener #123	MG/KG	0.0001	4.2E-04 U	2.5E-04 N	2.6E-04 U	3.2E-04 U	8.7E-04 N	1.4E-04 U	8.7E-04 N
PCB Congener #126	MG/KG	0.1	2.5E-04 U	6.6E-04 U	1.3E-04 U	1.3E-04 U	4.0E-04 U	6.5E-05 U	1.3E-03 U
PCB Congener #156	MG/KG	0.0005	1.7E-03 J	3.1E-03	1.7E-03	2.2E-03	4.2E-02	8.9E-04 J	6.5E-03
PCB Congener #157	MG/KG	0.0005	1.6E-04 N	5.0E-04 N	2.9E-04 N	3.1E-04 N	5.0E-04 N	1.6E-04 U	9.2E-04 N
PCB Congener #167	MG/KG	0.00001	6.9E-04 J	6.9E-04 J	4.2E-04 J	2.8E-04 J	9.9E-03 J	5.9E-04 J	2.3E-03 J
PCB Congener #169	MG/KG	0.01	6.6E-05 U	6.6E-05 U	6.6E-05 U	6.5E-05 U	6.5E-05 U	6.5E-05 U	7.6E-05 U
PCB Congener #189	MG/KG	0.0001	7.5E-05 U	6.6E-05 U	6.6E-05 U	6.6E-05 U	2.4E-04 U	7.6E-05 U	1.0E-04 U
PCB Congener #77	MG/KG	0.0001	6.6E-05 U	1.3E-04 U	3.3E-04 U	3.3E-04 U	1.3E-04 U	6.5E-05 U	1.3E-03 U
PCB Congener #81	MG/KG	0.0001	3.5E-03 U	4.4E-03 U	1.6E-03 U	2.8E-03 U	2.3E-03 U	4.9E-04 U	1.3E-02 U
									1.3E-02 U

Tissue Data 1/10 Detection Limit TEQ Results

PCB Congener	TEFs	LW2				LW2			
		LW2-BCF1	LW2-LMB1	LW2-LMB2	LW2-LMB3	LW2-SBF1	LW2-SBF2	LW2-SBF3	SBF3D
		11/19/2002	11/19/2002	11/19/2002	11/19/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002
PCB Congener #105	MG/KG	0.0001	6.2E-08 N	8.0E-07	5.9E-07	3.5E-06	1.5E-07	1.8E-06	1.8E-06
PCB Congener #114	MG/KG	0.0005	2.3E-07 U	3.1E-07 U	2.3E-07 U	2.4E-07 U	5.0E-07 U	7.0E-08 U	1.7E-06 U
PCB Congener #118	MG/KG	0.0001	2.0E-06	2.0E-06	1.6E-06	1.7E-06	9.5E-06 C	2.4E-07	7.4E-06 C
PCB Congener #123	MG/KG	0.0001	4.2E-08 U	2.5E-08 N	2.6E-08 U	3.2E-08 U	8.7E-08 N	1.4E-08 U	8.7E-08 N
PCB Congener #126	MG/KG	0.1	2.5E-05 U	6.6E-05 U	1.3E-06 U	1.3E-06 U	4.0E-06 U	6.5E-06 U	1.3E-04 U
PCB Congener #156	MG/KG	0.0005	8.5E-07 J	1.6E-06	8.5E-07	1.1E-06	2.1E-05	4.5E-07 J	3.3E-06
PCB Congener #157	MG/KG	0.0005	8.0E-08 N	2.5E-07 N	1.5E-07 N	1.6E-07 N	2.5E-07 N	8.0E-08 U	4.6E-07 N
PCB Congener #167	MG/KG	0.00001	6.9E-09 J	6.9E-09 J	4.2E-09 J	2.8E-09 J	9.9E-08 J	5.9E-09 J	2.3E-08 J
PCB Congener #169	MG/KG	0.01	6.6E-07 U	6.6E-07 U	6.6E-07 U	6.5E-07 U	6.5E-07 U	6.5E-07 U	7.6E-07 U
PCB Congener #189	MG/KG	0.0001	7.5E-09 U	6.6E-09 U	6.6E-09 U	6.6E-09 U	2.4E-08 U	7.6E-09 U	1.0E-08 U
PCB Congener #77	MG/KG	0.0001	6.6E-09 U	1.3E-08 U	3.3E-08 U	3.3E-08 U	1.3E-08 U	6.5E-09 U	1.3E-07 U
PCB Congener #81	MG/KG	0.0001	3.5E-07 U	4.4E-07 U	1.6E-07 U	2.8E-07 U	2.3E-07 U	4.9E-08 U	1.3E-06 U
Total TEQ		2.9E-05	7.2E-05	1.7E-05	1.8E-05	7.6E-05	8.2E-06	1.5E-04	1.4E-04

USEPA Screening Value, First Tier

2.1E-08

USEPA Risk Value, Second Tier

2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS

1.When no value is reported, see chlordane constituents.

2.Constituents or metabolites of technical chlordane.

Table 24 Coosa River PCB Congener Data 1/2 Detection Limit Calculations for Location Lake Weiss 2

Tissue Data	EPA									
	823-B-00-007	LW2-BCF1	LW2-LMB1	LW2-LMB2	LW2-LMB3	LW2-SBF1	LW2-SBF2	LW2-SBF3	LW2-SBF3D	
PCB Congener	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002
PCB Congener #105	MG/KG	0.0001	0.0062 N	0.008	0.0089	0.0059	0.035	0.0015	0.018	0.018
PCB Congener #114	MG/KG	0.0005	0.0045 U	0.0062 U	0.0045 U	0.0048 U	0.01 U	0.0014 U	0.034 U	0.034 U
PCB Congener #118	MG/KG	0.0001	0.02	0.02	0.016	0.017	0.095 C	0.0024	0.074 C	0.067 C
PCB Congener #123	MG/KG	0.0001	0.0042 U	0.0025 N	0.0026 U	0.0032 U	0.0087 N	0.0014 U	0.0087 N	0.0098 U
PCB Congener #126	MG/KG	0.1	0.0025 U	0.0066 U	0.0013 U	0.0013 U	0.004 U	0.00065 U	0.013 U	0.013 U
PCB Congener #156	MG/KG	0.0005	0.0017 J	0.0031	0.0017	0.0022	0.042	0.00089 J	0.0065	0.0053 N
PCB Congener #157	MG/KG	0.0005	0.0016 N	0.005 N	0.0029 N	0.0031 N	0.005 N	0.0016 U	0.0082 N	0.0088 N
PCB Congener #167	MG/KG	0.00001	0.00069 J	0.00069 J	0.00042 J	0.00028 J	0.0099 J	0.00059 J	0.0023 J	0.0025 J
PCB Congener #169	MG/KG	0.01	0.00066 U	0.00066 U	0.00066 U	0.00065 U	0.00065 U	0.00065 U	0.00076 U	0.00074 U
PCB Congener #189	MG/KG	0.0001	0.00075 U	0.00066 U	0.00066 U	0.00066 U	0.0024 U	0.00076 U	0.001 U	0.001 U
PCB Congener #77	MG/KG	0.0001	0.00066 U	0.0013 U	0.0033 U	0.0033 U	0.0013 U	0.00065 U	0.013 U	0.013 U
PCB Congener #81	MG/KG	0.0001	0.035 U	0.044 U	0.016 U	0.028 U	0.023 U	0.0049 U	0.13 U	0.13 U

Tissue Data 1/2 of Detection Limit Calculations

Tissue Data	LW2									
	LW2-BCF1	LW2-LMB1	LW2-LMB2	LW2-LMB3	LW2-SBF1	LW2-SBF2	LW2-SBF3	LW2-SBF3D		
PCB Congener	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002
PCB Congener #105	MG/KG	0.0001	3.1E-03 N	8.0E-03	5.9E-03	5.9E-03	3.5E-02	1.5E-03	1.8E-02	1.8E-02
PCB Congener #114	MG/KG	0.0005	2.3E-03 U	3.1E-03 U	2.3E-03 U	2.4E-03 U	5.0E-03 U	7.0E-04 U	1.7E-02 U	1.7E-02 U
PCB Congener #118	MG/KG	0.0001	2.0E-02	2.0E-02	1.6E-02	1.7E-02	9.5E-02 C	2.4E-03	7.4E-02 C	6.7E-02 C
PCB Congener #123	MG/KG	0.0001	2.1E-03 U	1.3E-03 N	1.3E-03 U	1.6E-03 U	4.4E-03 N	7.0E-04 U	4.4E-03 N	4.9E-03 U
PCB Congener #126	MG/KG	0.1	1.3E-03 U	3.3E-03 U	6.5E-04 U	6.5E-04 U	2.0E-03 U	3.3E-04 U	6.5E-03 U	6.5E-03 U
PCB Congener #156	MG/KG	0.0005	1.7E-03 J	3.1E-03	1.7E-03	2.2E-03	4.2E-02	8.9E-04 J	6.5E-03	2.7E-03 N
PCB Congener #157	MG/KG	0.0005	8.0E-04 N	2.5E-03 N	1.5E-03 N	1.6E-03 N	2.5E-03 N	8.0E-04 U	4.6E-03 N	4.4E-03 N
PCB Congener #167	MG/KG	0.00001	6.9E-04 J	6.9E-04 J	4.2E-04 J	2.8E-04 J	9.9E-03 J	5.9E-04 J	2.3E-03 J	2.5E-03 J
PCB Congener #169	MG/KG	0.01	3.3E-04 U	3.8E-04 U	3.7E-04 U					
PCB Congener #189	MG/KG	0.0001	3.8E-04 U	3.3E-04 U	3.3E-04 U	3.3E-04 U	1.2E-03 U	3.0E-04 U	5.0E-04 U	5.0E-04 U
PCB Congener #77	MG/KG	0.0001	3.3E-04 U	6.5E-04 U	1.7E-03 U	1.7E-03 U	6.5E-04 U	3.3E-04 U	6.5E-03 U	6.5E-03 U
PCB Congener #81	MG/KG	0.0001	1.8E-02 U	2.2E-02 U	8.0E-03 U	1.4E-02 U	1.2E-02 U	2.5E-03 U	6.5E-02 U	6.5E-02 U

Tissue Data 1/2 Detection Limit TEQ Results

Tissue Data	LW2									
	LW2-BCF1	LW2-LMB1	LW2-LMB2	LW2-LMB3	LW2-SBF1	LW2-SBF2	LW2-SBF3	LW2-SBF3D		
PCB Congener	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002
PCB Congener #105	MG/KG	0.0001	3.1E-07 N	8.0E-07	5.9E-07	5.9E-07	3.5E-06	1.5E-07	1.8E-06	1.8E-06
PCB Congener #114	MG/KG	0.0005	1.1E-06 U	1.6E-06 U	1.1E-06 U	1.2E-06 U	2.5E-06 U	3.5E-07 U	8.5E-06 U	8.5E-06 U
PCB Congener #118	MG/KG	0.0001	2.0E-06	2.0E-06	1.6E-06	1.7E-06	9.5E-06 C	2.4E-07	7.4E-06 C	6.7E-06 C
PCB Congener #123	MG/KG	0.0001	2.1E-07 U	1.3E-07 N	1.3E-07 U	1.6E-07 U	4.4E-07 N	7.0E-08 U	4.4E-07 N	4.9E-07 U
PCB Congener #126	MG/KG	0.1	1.3E-04 U	3.3E-04 U	6.5E-05 U	6.5E-05 U	2.0E-04 U	3.3E-05 U	6.5E-04 U	6.5E-04 U
PCB Congener #156	MG/KG	0.0005	8.5E-07 J	1.6E-06	8.5E-07	1.1E-06	2.1E-05	4.5E-07 J	3.3E-06	1.3E-06 N
PCB Congener #157	MG/KG	0.0005	4.0E-07 N	1.3E-06 N	7.3E-07 N	7.8E-07 N	1.3E-06 N	4.0E-07 U	2.3E-06 N	2.2E-06 N
PCB Congener #167	MG/KG	0.00001	6.9E-09 J	6.9E-09 J	4.2E-09 J	2.8E-09 J	9.9E-08 J	5.9E-09 J	2.3E-08 J	2.5E-08 J
PCB Congener #169	MG/KG	0.01	3.3E-06 U	3.8E-06 U	3.7E-06 U					
PCB Congener #189	MG/KG	0.0001	3.8E-08 U	3.3E-08 U	3.3E-08 U	3.3E-08 U	1.2E-07 U	3.8E-08 U	5.0E-08 U	5.0E-08 U
PCB Congener #77	MG/KG	0.0001	3.3E-08 U	6.5E-08 U	1.7E-07 U	1.7E-07 U	6.5E-08 U	3.3E-08 U	6.5E-07 U	6.5E-07 U
PCB Congener #81	MG/KG	0.0001	1.8E-06 U	2.2E-06 U	8.0E-07 U	1.4E-06 U	1.2E-06 U	2.5E-07 U	6.5E-06 U	6.5E-06 U
Total TEQ		1.4E-04	3.4E-04	7.4E-05	7.5E-05	2.4E-04	3.8E-05	6.8E-04	6.8E-04	

USEPA Screening Value, Frist Tier 2.1E-06

USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NP-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1.When no value is reported, see chlordane constituents.

2.Constituents or metabolites of technical chlordane.

Table 25. Coosa River Fish Tissue PCB Congener Data Detects Only Calculations for Location Lake Weiss 2

PCB Congener	EPA									
	823-B-00-007	LW2-BCF1	LW2-LMB1	LW2-LMB2	LW2-LMB3	LW2-SBF1	LW2-SBF2	LW2-SBF3	LW2-SBF3D	
	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002	
PCB Congener #105	MG/KG	0.0001	0.0062 N	0.008	0.0059	0.0059	0.035	0.0015	0.018	0.018
PCB Congener #114	MG/KG	0.0005	0.0045 U	0.0062 U	0.0045 U	0.0048 U	0.01 U	0.0014 U	0.034 U	0.034 U
PCB Congener #118	MG/KG	0.0001	0.02	0.02	0.016	0.017	0.065 C	0.0024	0.074 C	0.067 C
PCB Congener #123	MG/KG	0.0001	0.0042 U	0.0025 N	0.0026 U	0.0032 U	0.0087 N	0.0014 U	0.0087 N	0.0098 U
PCB Congener #126	MG/KG	0.1	0.0025 U	0.0066 U	0.0013 U	0.0013 U	0.004 U	0.00065 U	0.013 U	0.013 U
PCB Congener #156	MG/KG	0.0005	0.0017 J	0.0031	0.0017	0.0022	0.042	0.00069 J	0.0065	0.0053 N
PCB Congener #157	MG/KG	0.0005	0.0016 N	0.005 N	0.0029 N	0.0031 N	0.005 N	0.0016 U	0.0092 N	0.0088 N
PCB Congener #167	MG/KG	0.00001	0.00069 J	0.00069 J	0.00042 J	0.00026 J	0.0099 J	0.00059 J	0.0023 J	0.0025 J
PCB Congener #169	MG/KG	0.01	0.00066 U	0.00066 U	0.00066 U	0.00065 U	0.00065 U	0.00065 U	0.00076 U	0.00074 U
PCB Congener #189	MG/KG	0.0001	0.00075 U	0.00066 U	0.00066 U	0.00066 U	0.0024 U	0.00076 U	0.001 U	0.001 U
PCB Congener #77	MG/KG	0.0001	0.00066 U	0.0013 U	0.0033 U	0.0033 U	0.0013 U	0.00065 U	0.013 U	0.013 U
PCB Congener #81	MG/KG	0.0001	0.035 U	0.044 U	0.016 U	0.028 U	0.023 U	0.0049 U	0.13 U	0.13 U

Tissue data detects only TEO Results

PCB Congener	EPA									
	823-B-00-007	LW2-BCF1	LW2-LMB1	LW2-LMB2	LW2-LMB3	LW2-SBF1	LW2-SBF2	LW2-SBF3	LW2-SBF3D	
	TEFs	11/19/2002	11/19/2002	11/19/2002	11/19/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002	
PCB Congener #105	MG/KG	0.0001	N	8.000E-07	5.900E-07	5.900E-07	3.500E-06	1.500E-07	1.800E-06	1.800E-06
PCB Congener #114	MG/KG	0.0005	U	U	U	U	U	U	U	U
PCB Congener #118	MG/KG	0.0001	2.000E-06	2.000E-06	1.600E-06	1.700E-06	9.500E-06 C	2.400E-07	7.400E-06 C	6.700E-06 C
PCB Congener #123	MG/KG	0.0001	U	N	U	U	N	U	N	U
PCB Congener #126	MG/KG	0.1	U	U	U	U	U	U	U	U
PCB Congener #156	MG/KG	0.0005	8.500E-07 J	1.550E-06	8.500E-07	1.100E-06	2.100E-05	4.450E-07 J	3.250E-06	N
PCB Congener #157	MG/KG	0.0005	N	N	N	N	N	U	N	N
PCB Congener #167	MG/KG	0.00001	6.800E-09 J	6.800E-09 J	4.200E-09 J	2.800E-09 J	9.800E-09 J	5.900E-09 J	2.300E-08 J	2.500E-06 J
PCB Congener #189	MG/KG	0.01	U	U	U	U	U	U	U	U
PCB Congener #77	MG/KG	0.0001	U	U	U	U	U	U	U	U
PCB Congener #81	MG/KG	0.0001	U	U	U	U	U	U	U	U
Total TEQ		2.86E-06	4.36E-06	3.04E-06	3.38E-06	3.41E-05	8.41E-07	1.25E-05	8.53E-06	

USEPA Screening Value, Frist Tier 2.1E-06
 USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1.When no value is reported, see chlordane constituents.

2 Constituents or metabolites of technical chlordane.

Table 26. Coosa River PCB Congener Data 1/10 Detection Limit Calculations for Location Upper Neely-Henry

PCB Congener	EPA								
	823-B-00-007	UNH-LMB1D	UNHLMB1	UNHLMB2	UNHSBF1	UNHSBF2	UNHSBF3	UNHSPB1	11/20/2002
TEFs	11/20/2002	11/20/2002	11/20/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002	11/20/2002	11/20/2002
PCB Congener #105	MG/KG	0.0001	0.0072	0.0048	0.0042	0.033	0.017	0.0079	0.016 N
PCB Congener #114	MG/KG	0.0005	0.005 U	0.0068 U	0.0048 U	0.047 U	0.027 U	0.0068 U	0.032 U
PCB Congener #118	MG/KG	0.0001	0.02	0.018	0.016	0.11	0.077	0.032	0.069
PCB Congener #123	MG/KG	0.0001	0.0034 U	0.0032 N	0.0023 N	0.014 N	0.0067 JN	0.0048 N	0.017 U
PCB Congener #126	MG/KG	0.1	0.0013 U	0.0013 U	0.001 U	0.013 U	0.013 U	0.0064 U	0.0043 U
PCB Congener #156	MG/KG	0.0005	0.0023	0.0024	0.0018	0.01	0.0084	0.0031	0.009
PCB Congener #157	MG/KG	0.0005	0.0033 N	0.003 N	0.0022 N	0.011 N	0.0068 N	0.0045 N	0.013 N
PCB Congener #167	MG/KG	0.00001	0.0024 J	0.00063 J	0.00034 J	0.005 J	0.0036 J	0.0012 J	0.0037 J
PCB Congener #169	MG/KG	0.01	0.00066 U	0.00064 U	0.00066 U	0.00066 U	0.00066 U	0.00064 U	0.00093 U
PCB Congener #189	MG/KG	0.0001	0.00066 U	0.00064 U	0.00066 U	0.0015 U	0.00093 N	0.0002 N	0.00084 N
PCB Congener #77	MG/KG	0.0001	0.0033 U	0.0026 U	0.0026 U	0.013 U	0.013 U	0.0064 U	0.012 U
PCB Congener #81	MG/KG	0.0001	0.026 U	0.025 U	0.035 U	0.18 U	0.092 U	0.061 U	0.11 U

Tissue Data 1/10 of Non-detect Calculations

PCB Congener	UNH-LMB1D								
	TEFs	UNH-LMB1D	UNHLMB1	UNHLMB2	UNHSBF1	UNHSBF2	UNHSBF3	UNHSPB1	11/20/2002
		11/20/2002	11/20/2002	11/20/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002	11/20/2002
PCB Congener #105	MG/KG	0.0001	7.2E-03	4.8E-03	4.2E-03	3.3E-02	1.7E-02	7.9E-03	1.6E-03 N
PCB Congener #114	MG/KG	0.0005	5.0E-04 U	6.8E-04 U	4.6E-04 U	4.7E-03 U	2.7E-03 U	8.8E-04 U	3.2E-03 U
PCB Congener #118	MG/KG	0.0001	2.0E-02	1.8E-02	1.6E-02	1.1E-01	7.7E-02	3.2E-02	6.9E-02
PCB Congener #123	MG/KG	0.0001	3.4E-04 U	3.2E-04 N	2.3E-04 N	1.4E-03 N	6.7E-04 JN	4.8E-04 N	1.7E-03 U
PCB Congener #126	MG/KG	0.1	1.3E-04 U	1.3E-04 U	1.0E-04 U	1.3E-03 U	1.3E-03 U	6.4E-04 U	4.3E-04 U
PCB Congener #156	MG/KG	0.0005	2.3E-03	2.4E-03	1.8E-03	1.0E-02	8.4E-03	3.1E-03	9.0E-03
PCB Congener #157	MG/KG	0.0005	3.3E-04 N	3.0E-04 N	2.2E-04 N	1.1E-03 N	6.8E-04 N	4.5E-04 N	1.3E-03 N
PCB Congener #167	MG/KG	0.00001	2.4E-03 J	6.3E-04 J	3.4E-04 J	5.0E-03 J	3.6E-03 J	1.2E-03 J	3.7E-03 J
PCB Congener #169	MG/KG	0.01	6.8E-05 U	6.4E-05 U	6.6E-05 U	6.6E-05 U	6.6E-05 U	6.4E-05 U	9.3E-05 U
PCB Congener #189	MG/KG	0.0001	6.6E-05 U	6.4E-05 U	6.8E-05 U	1.5E-04 U	9.3E-05 N	2.0E-05 N	8.4E-05 N
PCB Congener #77	MG/KG	0.0001	3.3E-04 U	2.6E-04 U	2.6E-04 U	1.3E-03 U	1.3E-03 U	6.4E-04 U	1.2E-03 U
PCB Congener #81	MG/KG	0.0001	2.6E-03 U	2.5E-03 U	3.5E-03 U	1.8E-02 U	9.2E-03 U	6.1E-03 U	1.1E-02 U

Tissue Data 1/10 of Non-detect Results

PCB Congener	UNH-LMB1D								
	TEFs	UNH-LMB1D	UNHLMB1	UNHLMB2	UNHSBF1	UNHSBF2	UNHSBF3	UNHSPB1	11/20/2002
		11/20/2002	11/20/2002	11/20/2002	12/10/2002	12/10/2002	12/10/2002	12/10/2002	11/20/2002
PCB Congener #105	MG/KG	0.0001	7.2E-07	4.8E-07	4.2E-07	3.3E-06	1.7E-06	7.9E-07	1.6E-07 N
PCB Congener #114	MG/KG	0.0005	2.5E-07 U	3.4E-07 U	2.3E-07 U	2.4E-06 U	1.4E-06 U	4.4E-07 U	1.6E-06 U
PCB Congener #118	MG/KG	0.0001	2.0E-06	1.8E-06	1.6E-06	1.1E-05	7.7E-06	3.2E-06	6.9E-06
PCB Congener #123	MG/KG	0.0001	3.4E-08 U	3.2E-08 N	2.3E-08 N	1.4E-07 N	6.7E-08 JN	4.8E-08 N	1.7E-07 U
PCB Congener #126	MG/KG	0.1	1.3E-05 U	1.3E-05 U	1.0E-05 U	1.3E-04 U	1.3E-04 U	6.4E-05 U	4.3E-05 U
PCB Congener #156	MG/KG	0.0005	1.2E-06	1.2E-06	9.0E-07	5.0E-06	4.2E-06	1.8E-06	4.5E-06
PCB Congener #157	MG/KG	0.0005	1.7E-07 N	1.5E-07 N	1.1E-07 N	5.5E-07 N	3.4E-07 N	2.3E-07 N	6.5E-07 N
PCB Congener #167	MG/KG	0.00001	2.4E-08 J	6.3E-09 J	3.4E-09 J	5.0E-08 J	3.6E-08 J	1.2E-08 J	3.7E-08 J
PCB Congener #169	MG/KG	0.01	6.8E-07 U	6.4E-07 U	6.6E-07 U	6.6E-07 U	6.6E-07 U	6.4E-07 U	9.3E-07 U
PCB Congener #189	MG/KG	0.0001	6.6E-09 U	6.4E-09 U	6.6E-09 U	1.5E-08 U	9.3E-09 N	2.0E-09 N	8.4E-09 N
PCB Congener #77	MG/KG	0.0001	3.3E-08 U	2.6E-08 U	2.6E-08 U	1.3E-07 U	1.3E-07 U	6.4E-08 U	1.2E-07 U
PCB Congener #81	MG/KG	0.0001	2.6E-07 U	2.5E-07 U	3.5E-07 U	1.8E-06 U	9.2E-07 U	6.1E-07 U	1.1E-06 U
Total TEQ			1.8E-05	1.8E-05	1.4E-05	1.5E-04	1.5E-04	7.2E-05	5.9E-05

USEPA Screening Value, Frist Tier 2.1E-08
USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NJ-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-OC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1. When no value is reported, see chlordane constituents.

2. Constituents or metabolites of technical chlordane.

Table 27. Coosa River PCB Congener Data 1/2 Detection Limit Calculations for Location Upper Neely-Henry

PCB Congener	EPA								
	TEFs	823-B-00-007	UNH-LMB1D	UNHLMB1	UNHLMB2	UNHSBF1	UNHSBF2	UNHSBF3	UNHSPB1
		11/20/2002	11/20/2002	11/20/2002	12/10/2002	12/10/2002	12/10/2002	11/20/2002	
PCB Congener #105	MG/KG	0.0001	0.0072	0.0048	0.0042	0.033	0.017	0.0079	0.016 N
PCB Congener #114	MG/KG	0.0005	0.005 U	0.0068 U	0.0046 U	0.047 U	0.027 U	0.0088 U	0.032 U
PCB Congener #118	MG/KG	0.0001	0.02	0.018	0.016	0.11	0.077	0.032	0.069
PCB Congener #123	MG/KG	0.0001	0.0034 U	0.0032 N	0.0023 N	0.014 N	0.0067 JN	0.0048 N	0.017 U
PCB Congener #126	MG/KG	0.1	0.0013 U	0.0013 U	0.001 U	0.013 U	0.013 U	0.0064 U	0.0043 U
PCB Congener #156	MG/KG	0.0005	0.0023	0.0024	0.0018	0.01	0.0084	0.0031	0.009
PCB Congener #157	MG/KG	0.0005	0.0033 N	0.003 N	0.0022 N	0.011 N	0.0068 N	0.0045 N	0.013 N
PCB Congener #167	MG/KG	0.00001	0.0024 J	0.00063 J	0.00034 J	0.005 J	0.0036 J	0.0012 J	0.0037 J
PCB Congener #169	MG/KG	0.01	0.00066 U	0.00064 U	0.00066 U	0.00066 U	0.00066 U	0.00064 U	0.00093 U
PCB Congener #189	MG/KG	0.0001	0.00066 U	0.00064 U	0.00066 U	0.0015 U	0.00093 N	0.0002 N	0.00084 N
PCB Congener #77	MG/KG	0.0001	0.0033 U	0.0026 U	0.0026 U	0.013 U	0.013 U	0.0064 U	0.012 U
PCB Congener #81	MG/KG	0.0001	0.026 U	0.025 U	0.035 U	0.18 U	0.082 U	0.061 U	0.11 U

Tissue 1/2 of Non-detect Calculations

PCB Congener	UNH-LMB1D UNHMB1 UNHLMB2 UNHSBF1 UNHSBF2 UNHSBF3 UNHSPB1								
	TEFs	11/20/2002	11/20/2002	11/20/2002	12/10/2002	12/10/2002	12/10/2002	11/20/2002	
PCB Congener #105	MG/KG	0.0001	7.2E-03	4.8E-03	4.2E-03	3.3E-02	1.7E-02	7.9E-03	8.0E-03 N
PCB Congener #114	MG/KG	0.0005	2.5E-03 U	3.4E-03 U	2.3E-03 U	2.4E-02 U	1.4E-02 U	4.4E-03 U	1.6E-02 U
PCB Congener #118	MG/KG	0.0001	2.0E-02	1.8E-02	1.6E-02	1.1E-01	7.7E-02	3.2E-02	6.9E-02
PCB Congener #123	MG/KG	0.0001	1.7E-03 U	1.6E-03 N	1.2E-03 N	7.0E-03 N	3.4E-03 JN	2.4E-03 N	8.5E-03 U
PCB Congener #126	MG/KG	0.1	6.5E-04 U	6.5E-04 U	5.0E-04 U	6.5E-03 U	6.5E-03 U	3.2E-03 U	2.2E-03 U
PCB Congener #156	MG/KG	0.0005	2.3E-03	2.4E-03	1.8E-03	1.0E-02	8.4E-03	3.1E-03	9.0E-03
PCB Congener #157	MG/KG	0.0005	1.7E-03 N	1.5E-03 N	1.1E-03 N	5.5E-03 N	3.4E-03 N	2.3E-03 N	6.5E-03 N
PCB Congener #167	MG/KG	0.00001	2.4E-03 J	6.3E-04 J	3.4E-04 J	5.0E-03 J	3.6E-03 J	1.2E-03 J	3.7E-03 J
PCB Congener #169	MG/KG	0.01	3.3E-04 U	3.2E-04 U	3.3E-04 U	3.3E-04 U	3.3E-04 U	3.2E-04 U	4.7E-04 U
PCB Congener #189	MG/KG	0.0001	3.3E-04 U	3.2E-04 U	3.3E-04 U	7.5E-04 U	4.7E-04 N	1.0E-04 N	4.2E-04 N
PCB Congener #77	MG/KG	0.0001	1.7E-03 U	1.3E-03 U	1.3E-03 U	6.5E-03 U	6.5E-03 U	3.2E-03 U	6.0E-03 U
PCB Congener #81	MG/KG	0.0001	1.3E-02 U	1.3E-02 U	1.8E-02 U	9.0E-02 U	4.8E-02 U	3.1E-02 U	5.5E-02 U

Tissue 1/2 of Non-detect Results

PCB Congener	UNH-LMB1D UNHMB1 UNHLMB2 UNHSBF1 UNHSBF2 UNHSBF3 UNHSPB1								
	TEFs	11/20/2002	11/20/2002	11/20/2002	12/10/2002	12/10/2002	12/10/2002	11/20/2002	
PCB Congener #105	MG/KG	0.0001	7.2E-07	4.8E-07	4.2E-07	3.3E-06	1.7E-06	7.9E-07	8.0E-07 N
PCB Congener #114	MG/KG	0.0005	1.3E-06 U	1.7E-06 U	1.2E-06 U	1.2E-05 U	6.8E-06 U	2.2E-06 U	8.0E-06 U
PCB Congener #118	MG/KG	0.0001	2.0E-06	1.8E-06	1.6E-06	1.1E-05	7.7E-06	3.2E-06	6.9E-06
PCB Congener #123	MG/KG	0.0001	1.7E-07 U	1.6E-07 N	1.2E-07 N	7.0E-07 N	3.4E-07 JN	2.4E-07 N	8.5E-07 U
PCB Congener #126	MG/KG	0.1	6.5E-05 U	6.5E-05 U	5.0E-05 U	6.5E-04 U	6.5E-04 U	3.2E-04 U	2.2E-04 U
PCB Congener #156	MG/KG	0.0005	1.2E-06	1.2E-06	9.0E-07	5.0E-06	4.2E-06	1.6E-06	4.5E-06
PCB Congener #157	MG/KG	0.0005	8.3E-07 N	7.5E-07 N	5.5E-07 N	2.8E-06 N	1.7E-06 N	1.1E-06 N	3.3E-06 N
PCB Congener #167	MG/KG	0.00001	2.4E-08 J	6.3E-09 J	3.4E-09 J	5.0E-08 J	3.6E-08 J	1.2E-08 J	3.7E-08 J
PCB Congener #169	MG/KG	0.01	3.3E-06 U	3.2E-06 U	3.3E-06 U	3.3E-06 U	3.3E-06 U	3.2E-06 U	4.7E-06 U
PCB Congener #189	MG/KG	0.0001	3.3E-08 U	3.2E-08 U	3.3E-08 U	7.5E-08 U	4.7E-08 N	1.0E-08 N	4.2E-08 N
PCB Congener #77	MG/KG	0.0001	1.7E-07 U	1.3E-07 U	1.3E-07 U	6.5E-07 U	6.5E-07 U	3.2E-07 U	6.0E-07 U
PCB Congener #81	MG/KG	0.0001	1.3E-06 U	1.3E-06 U	1.8E-06 U	9.0E-06 U	4.8E-06 U	3.1E-06 U	5.5E-06 U
Total TEQ			7.6E-05	7.6E-05	6.0E-05	7.0E-04	6.8E-04	3.4E-04	2.5E-04

USEPA Screening Value, Frist Tier: 2.1E-08
 USEPA Risk Value, Second Tier: 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1. When no value is reported, see chlordane constituents.

2. Constituents or metabolites of technical chlordane.

Table 28. Coosa River Fish Tissue PCB Congener Data (Detects Only Calculations for Location Upper Neely-Henry)

PCB Congener	EPA									
	823-B-00-007	UNH-LMB1D	UNHLMB1	UNHLMB2	UNHSBF1	UNHSBF2	UNHSBF3	UNHSPB1		
PCB Congener #105	MG/KG	0.0001	0.0072	0.0048	0.0042	0.033	0.017	0.0079	0.016 N	
PCB Congener #114	MG/KG	0.0005	0.005 U	0.0068 U	0.0046 U	0.047 U	0.027 U	0.0088 U	0.032 U	
PCB Congener #118	MG/KG	0.0001	0.02	0.018	0.016	0.11	0.077	0.032	0.069	
PCB Congener #123	MG/KG	0.0001	0.0034 U	0.0032 N	0.0023 N	0.014 N	0.0067 JN	0.0048 N	0.017 U	
PCB Congener #126	MG/KG	0.1	0.0013 U	0.0013 U	0.001 U	0.013 U	0.013 U	0.0084 U	0.0043 U	
PCB Congener #156	MG/KG	0.0005	0.0023	0.0024	0.0018	0.01	0.0084	0.0031	0.009	
PCB Congener #157	MG/KG	0.0005	0.0033 N	0.003 N	0.0022 N	0.011 N	0.0088 N	0.0045 N	0.013 N	
PCB Congener #167	MG/KG	0.00001	0.0024 J	0.00063 J	0.00034 J	0.005 J	0.0036 J	0.0012 J	0.0037 J	
PCB Congener #169	MG/KG	0.01	0.00068 U	0.00064 U	0.00068 U	0.00066 U	0.00066 U	0.00084 U	0.00093 U	
PCB Congener #189	MG/KG	0.0001	0.00068 U	0.00064 U	0.00068 U	0.0015 U	0.00093 N	0.0002 N	0.00084 N	
PCB Congener #77	MG/KG	0.0001	0.0033 U	0.0028 U	0.0026 U	0.013 U	0.013 U	0.0084 U	0.012 U	
PCB Congener #81	MG/KG	0.0001	0.026 U	0.025 U	0.035 U	0.18 U	0.082 U	0.061 U	0.11 U	

Tissue data detects only TEQ Results

PCB Congener	EPA									
	823-B-00-007	UNH-LMB1D	UNHLMB1	UNHLMB2	UNHSBF1	UNHSBF2	UNHSBF3	UNHSPB1		
PCB Congener #105	MG/KG	0.0001	7.200E-07	4.800E-07	4.200E-07	3.300E-06	1.700E-06	7.800E-07	N	
PCB Congener #114	MG/KG	0.0005	U	U	U	U	U	U	U	U
PCB Congener #118	MG/KG	0.0001	2.000E-06	1.800E-06	1.600E-06	1.100E-05	7.700E-06	3.200E-06	6.900E-06	
PCB Congener #123	MG/KG	0.0001	U	N	N	N	JN	N	U	
PCB Congener #126	MG/KG	0.1	U	U	U	U	U	U	U	U
PCB Congener #156	MG/KG	0.0005	1.150E-06	1.200E-06	9.000E-07	5.000E-06	4.200E-06	1.550E-06	4.500E-06	
PCB Congener #157	MG/KG	0.0005	N	N	N	N	N	N	N	N
PCB Congener #167	MG/KG	0.00001	2.400E-06 J	6.300E-06 J	3.400E-09 J	5.000E-06 J	3.600E-06 J	1.200E-06 J	3.700E-06 J	
PCB Congener #169	MG/KG	0.01	U	U	U	U	U	U	U	U
PCB Congener #189	MG/KG	0.0001	U	U	U	U	U	N	N	
PCB Congener #77	MG/KG	0.0001	U	U	U	U	U	U	U	
PCB Congener #81	MG/KG	0.0001	U	U	U	U	U	U	U	
Total TEQ			3.89E-06	3.49E-06	2.92E-06	1.94E-05	1.36E-05	5.55E-06	1.14E-05	

USEPA Screening Value, Frist Tier 2.1E-08
 USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1. When no value is reported, see chlordane constituents.

2. Constituents or metabolites of technical chlordane.

Table 29. Coosa River PCB Congener Data 1/10 Detection Limit Calculations for Location Logan Martin

Tissue Data		EPA								
PCB Congener	TEFs	823-B-00-007		LM-BCF1	LM-BCF2	LM-CCF1	LM-LMB1	LM-LMB1D	LM-LMB2	LM-SPB1
		12/09/2002	12/09/2002	12/09/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002
PCB Congener #105	MG/KG	0.0001	0.0044	0.0079	0.0015 JC	0.00089 J	0.0067 N	0.0022 J	0.006 J	
PCB Congener #114	MG/KG	0.0005	0.00084 U	0.00063 U	0.0034 N	0.0016 N	0.0065 U	0.0018 N	0.0039 N	
PCB Congener #118	MG/KG	0.0001	0.011	0.011	0.024 JC	0.011 JC	0.023	0.009 C	0.023 JC	
PCB Congener #123	MG/KG	0.0001	0.0013 U	0.0012 U	0.0029 N	0.00007 N	0.0041 U	0.0013	0.0014 N	
PCB Congener #126	MG/KG	0.1	0.00064 U	0.00063 U	0.0046 J	0.0022 J	0.0038 U	0.0022 J	0.00086 J	
PCB Congener #156	MG/KG	0.0005	0.001 J	0.0022	0.0036 J	0.001 J	0.0033	0.00062 J	0.0025 J	
PCB Congener #157	MG/KG	0.0005	0.00064 U	0.0012 U	0.0012 J	0.00006 J	0.0037 N	0.00046 J	0.001 J	
PCB Congener #157	MG/KG	0.00001	0.0018	0.003	0.00022 J	0.002 N	0.0019 U	0.0005 J	0.00008 J	
PCB Congener #169	MG/KG	0.01	0.00064 U	0.00063 U	0.00013 U	0.00012 U	0.00066 U	0.00013 U	0.00012 U	
PCB Congener #189	MG/KG	0.0001	0.00037 J	0.00028 J	0.00021 J	0.00014 JN	0.0011 U	0.0003 J	0.0002 J	
PCB Congener #77	MG/KG	0.0001	0.00064 U	0.0012 U	0.033	0.013	0.0066 U	0.013	0.052	
PCB Congener #81	MG/KG	0.0001	0.00064 U	0.0012 U	0.00017 N	0.00081 N	0.045 U	0.002 N	0.0015 N	
Tissue Data 1/10 of Non-detect Calculations										
PCB Congener	TEFs	LM-BCF1		LM-BCF2	LM-CCF1	LM-LMB1	LM-LMB1D	LM-LMB2	LM-SPB1	
		12/09/2002	12/09/2002	12/09/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	
PCB Congener #105	MG/KG	0.0001	4.4E-03	7.9E-03	1.5E-03 JC	8.9E-04 J	6.7E-04 N	2.2E-03 J	6.0E-03 J	
PCB Congener #114	MG/KG	0.0005	6.4E-05 U	6.3E-05 U	3.4E-04 N	1.6E-04 N	6.5E-04 U	1.8E-04 N	3.9E-04 N	
PCB Congener #118	MG/KG	0.0001	1.1E-02	1.1E-02	2.4E-02 JC	1.1E-02 JC	2.3E-02	9.0E-03 C	2.3E-02 JC	
PCB Congener #123	MG/KG	0.0001	1.3E-04 U	1.2E-04 U	2.9E-04 N	7.0E-06 N	4.1E-04 U	1.3E-03	1.4E-04 N	
PCB Congener #126	MG/KG	0.1	6.4E-05 U	6.3E-05 U	4.6E-03 J	2.2E-03 J	3.8E-04 U	2.2E-03 J	6.6E-04 J	
PCB Congener #156	MG/KG	0.0005	1.0E-03 J	2.2E-03	3.6E-03 J	1.0E-03 J	3.3E-03	6.2E-04 J	2.5E-03 J	
PCB Congener #157	MG/KG	0.0005	6.4E-05 U	1.2E-04 U	1.2E-03 J	6.0E-05 J	3.7E-04 N	4.6E-04 J	1.0E-03 J	
PCB Congener #167	MG/KG	0.00001	1.8E-03	3.0E-03	2.2E-04 J	2.0E-04 N	1.9E-04 U	5.0E-04 J	8.0E-05 J	
PCB Congener #169	MG/KG	0.01	6.4E-05 U	6.3E-05 U	1.3E-05 U	1.2E-05 U	6.6E-05 U	1.3E-05 U	1.2E-05 U	
PCB Congener #189	MG/KG	0.0001	3.7E-04 J	2.8E-04 J	2.1E-04 J	1.4E-04 JN	1.1E-04 U	3.0E-04 J	2.0E-04 J	
PCB Congener #77	MG/KG	0.0001	6.4E-05 U	1.2E-04 U	3.3E-02	1.3E-02	6.6E-04 U	1.3E-02	5.2E-02	
PCB Congener #81	MG/KG	0.0001	6.4E-05 U	1.2E-04 U	1.7E-04 N	8.1E-05 N	4.5E-03 U	2.0E-04 N	1.5E-04 N	
Tissue Data 1/10 of Non-detect Results										
PCB Congener	TEFs	LM-BCF1		LM-BCF2	LM-CCF1	LM-LMB1	LM-LMB1D	LM-LMB2	LM-SPB1	
		12/09/2002	12/09/2002	12/09/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	
PCB Congener #105	MG/KG	0.0001	4.4E-07	7.9E-07	1.5E-07 JC	8.9E-08 J	6.7E-08 N	2.2E-07 J	6.0E-07 J	
PCB Congener #114	MG/KG	0.0005	3.2E-08 U	3.2E-08 U	1.7E-07 N	8.0E-08 N	3.3E-07 U	8.0E-08 N	2.0E-07 N	
PCB Congener #118	MG/KG	0.0001	1.1E-06	1.1E-06	2.4E-06 JC	1.1E-06 JC	2.3E-06	9.0E-07 C	2.3E-06 JC	
PCB Congener #123	MG/KG	0.0001	1.3E-08 U	1.2E-08 U	2.9E-08 N	7.0E-10 N	4.1E-08 U	1.3E-07	1.4E-08 N	
PCB Congener #126	MG/KG	0.1	6.4E-06 U	6.3E-06 U	4.6E-04 J	2.2E-04 J	3.8E-05 U	2.2E-04 J	6.6E-05 J	
PCB Congener #156	MG/KG	0.0005	5.0E-07 J	1.1E-06	1.8E-06 J	5.0E-07 J	1.7E-06	3.1E-07 J	1.3E-06 J	
PCB Congener #157	MG/KG	0.0005	3.2E-08 U	6.0E-08 U	6.0E-07 J	3.0E-08 J	1.9E-07 N	2.3E-07 J	5.0E-07 J	
PCB Congener #167	MG/KG	0.00001	1.8E-08	3.0E-08	2.2E-09 J	2.0E-09 N	1.9E-09 U	5.0E-09 J	8.0E-10 J	
PCB Congener #169	MG/KG	0.01	6.4E-07 U	6.3E-07 U	1.3E-07 U	1.2E-07 U	6.6E-07 U	1.3E-07 U	1.2E-07 U	
PCB Congener #189	MG/KG	0.0001	3.7E-08 J	2.8E-08 J	2.1E-08 J	1.4E-08 JN	1.1E-08 U	3.0E-08 J	2.0E-08 J	
PCB Congener #77	MG/KG	0.0001	6.4E-09 U	1.2E-08 U	3.3E-06	1.3E-06	6.6E-08 U	1.3E-06	5.2E-06	
PCB Congener #81	MG/KG	0.0001	6.4E-09 U	1.2E-08 U	1.7E-08 N	8.1E-09 N	4.5E-07 U	2.0E-08 N	1.5E-08 N	
Total TEQ			9.2E-06	1.0E-05	4.7E-04	2.2E-04	4.4E-05	2.2E-04	9.6E-05	

USEPA Screening Value, Frist Tier 2.1E-08
USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value:

N-Presumptive evidence of presence of material.

NR-Not Reported

K. Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-OC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-confirmed by GCMS

1 When no value is reported, see chlorine constituents.

3 Constituents or metabolites of technical chloroform

Table 30. Coosa River PCB Congener Data 1/2 Detection Limit Calculations for Location Logan Martin

Tissue Data	EPA								
	823-B-00-007	LM-BCF1	LM-BCF2	LM-CCF1	LM-LMB1	LM-LMB1D	LM-LMB2	LM-SPB1	
PCB Congener	TEF _b	12/09/2002	12/09/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	
PCB Congener #105	MG/KG	0.0001	0.0044	0.0079	0.0015 JC	0.00089 J	0.0067 N	0.0022 J	0.006 J
PCB Congener #114	MG/KG	0.0005	0.00084 U	0.00063 U	0.0034 N	0.0016 N	0.0065 U	0.0016 N	0.0039 N
PCB Congener #118	MG/KG	0.0001	0.011	0.011	0.024 JC	0.011 JC	0.023	0.009 C	0.023 JC
PCB Congener #123	MG/KG	0.0001	0.0013 U	0.0012 U	0.0029 N	0.00007 N	0.0041 U	0.0013	0.0014 N
PCB Congener #126	MG/KG	0.1	0.00064 U	0.00063 U	0.0046 J	0.0022 J	0.0038 U	0.0022 J	0.00066 J
PCB Congener #156	MG/KG	0.0005	0.001 J	0.0022	0.0036 J	0.001 J	0.0033	0.00062 J	0.0025 J
PCB Congener #157	MG/KG	0.0005	0.00084 U	0.0012 U	0.0012 J	0.00008 J	0.0037 N	0.00046 J	0.001 J
PCB Congener #167	MG/KG	0.00001	0.0018	0.003	0.00022 J	0.002 N	0.0019 U	0.0005 J	0.00008 J
PCB Congener #169	MG/KG	0.01	0.00064 U	0.00063 U	0.0013 U	0.00012 U	0.00066 U	0.00013 U	0.00012 U
PCB Congener #189	MG/KG	0.0001	0.00037 J	0.00028 J	0.00021 J	0.00014 JN	0.0011 U	0.0003 J	0.0002 J
PCB Congener #77	MG/KG	0.0001	0.00064 U	0.0012 U	0.033	0.013	0.0066 U	0.013	0.052
PCB Congener #81	MG/KG	0.0001	0.00064 U	0.0012 U	0.0017 N	0.00081 N	0.045 U	0.002 N	0.0015 N

Tissue Data 1/2 of Detection Limit Calculations

PCB Congener	1/2 of Detection Limit Calculations								
	LM-BCF1	LM-BCF2	LM-CCF1	LM-LMB1	LM-LMB1D	LM-LMB2	LM-SPB1	11/21/2002	
PCB Congener	TEF _b	12/09/2002	12/09/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	
PCB Congener #105	MG/KG	0.0001	4.4E-03	7.9E-03	1.5E-03 JC	8.9E-04 J	3.4E-03 N	2.2E-03 J	6.0E-03 J
PCB Congener #114	MG/KG	0.0005	3.2E-04 U	3.2E-04 U	1.7E-03 N	8.0E-04 N	3.3E-03 U	8.0E-04 N	2.0E-03 N
PCB Congener #118	MG/KG	0.0001	1.1E-02	1.1E-02	2.4E-02 JC	1.1E-02 JC	2.3E-02	9.0E-03 C	2.3E-02 JC
PCB Congener #123	MG/KG	0.0001	6.5E-04 U	6.0E-04 U	1.5E-03 N	3.5E-05 N	2.1E-03 U	1.3E-03	7.0E-04 N
PCB Congener #126	MG/KG	0.1	3.2E-04 U	3.2E-04 U	4.6E-03 J	2.2E-03 J	1.9E-03 U	2.2E-03 J	8.6E-04 J
PCB Congener #156	MG/KG	0.0005	1.0E-03 J	2.2E-03	3.6E-03 J	1.0E-03 J	3.3E-03	6.2E-04 J	2.5E-03 J
PCB Congener #157	MG/KG	0.0005	3.2E-04 U	6.0E-04 U	1.2E-03 J	6.0E-05 J	1.9E-03 N	4.6E-04 J	1.0E-03 J
PCB Congener #167	MG/KG	0.00001	1.8E-03	3.0E-03	2.2E-04 J	1.0E-03 N	9.5E-04 U	5.0E-04 J	8.0E-05 J
PCB Congener #169	MG/KG	0.01	3.2E-04 U	3.2E-04 U	6.5E-05 U	6.0E-05 U	3.3E-04 U	6.5E-05 U	6.0E-05 U
PCB Congener #189	MG/KG	0.0001	3.7E-04 J	2.8E-04 J	2.1E-04 J	1.4E-04 JN	5.5E-04 U	3.0E-04 J	2.0E-04 J
PCB Congener #77	MG/KG	0.0001	3.2E-04 U	6.0E-04 U	3.3E-02	1.3E-02	3.3E-03 U	1.3E-02	5.2E-02
PCB Congener #81	MG/KG	0.0001	3.2E-04 U	6.0E-04 U	8.5E-04 N	4.1E-04 N	2.3E-02 U	1.0E-03 N	7.5E-04 N

Tissue Data 1/2 Detection Limit TEQ Results

PCB Congener	1/2 Detection Limit TEQ Results								
	LM-BCF1	LM-BSF2	LM-CCF1	LM-LMB1	LM-LMB1D	LM-LMB2	LM-SPB1	11/21/2002	
PCB Congener	TEF _b	12/09/2002	12/09/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	11/21/2002	
PCB Congener #105	MG/KG	0.0001	4.4E-07	7.9E-07	1.5E-07 JC	8.9E-08 J	3.4E-07 N	2.2E-07 J	6.0E-07 J
PCB Congener #114	MG/KG	0.0005	1.6E-07 U	1.6E-07 U	8.5E-07 N	4.0E-07 N	1.6E-06 U	4.0E-07 N	9.8E-07 N
PCB Congener #118	MG/KG	0.0001	1.1E-06	1.1E-06	2.4E-06 JC	1.1E-06 JC	2.3E-06	9.0E-07 C	2.3E-06 JC
PCB Congener #123	MG/KG	0.0001	6.5E-08 U	6.0E-08 U	1.5E-07 N	3.5E-09 N	2.1E-07 U	1.3E-07	7.0E-08 N
PCB Congener #126	MG/KG	0.1	3.2E-05 U	3.2E-05 U	4.6E-04 J	2.2E-04 J	1.9E-04 U	2.2E-04 J	8.6E-05 J
PCB Congener #156	MG/KG	0.0005	5.0E-07 J	1.1E-06	1.8E-06 J	5.0E-07 J	1.7E-06	3.1E-07 J	1.3E-06 J
PCB Congener #157	MG/KG	0.0005	1.6E-07 U	3.0E-07 U	6.0E-07 J	3.0E-08 J	9.3E-07 N	2.3E-07 J	5.0E-07 J
PCB Congener #167	MG/KG	0.00001	1.8E-08	3.0E-08	2.2E-09 J	1.0E-08 N	9.5E-09 U	5.0E-09 J	8.0E-10 J
PCB Congener #169	MG/KG	0.01	3.2E-06 U	3.2E-06 U	6.5E-07 U	6.0E-07 U	3.3E-06 U	6.5E-07 U	6.0E-07 U
PCB Congener #189	MG/KG	0.0001	3.7E-06 J	2.8E-06 J	2.1E-06 J	1.4E-06 JN	5.5E-06 U	3.0E-06 J	2.0E-06 J
PCB Congener #77	MG/KG	0.0001	3.2E-08 U	6.0E-08 U	3.3E-06	1.3E-06	3.3E-07 U	1.3E-06	5.2E-06
PCB Congener #81	MG/KG	0.0001	3.2E-08 U	6.0E-08 U	8.5E-08 N	4.1E-08 N	2.3E-06 U	1.0E-07 N	7.5E-08 N
Total TEQ		3.8E-05	3.8E-05	4.7E-04	2.2E-04	2.0E-04	2.2E-04	9.8E-05	

USEPA Screening Value, Frist Tier 2.1E-08

USEPA Risk Value, Second Tier 2.1E-06

Data Qualifiers

A-Average value. NA-Not analyzed. NAI-Interferences. J-Estimated value.

N-Presumptive evidence of presence of material.

NR-Not Reported

K-Actual value is known to be less than value given.

L-Actual value is known to be greater than value given.

U-Material was analyzed for but not detected. The number is the minimum quantitation limit.

R-QC indicates that data unusable. Compound may or may not be present. Resampling and reanalysis is necessary for verification.

C-Confirmed by GCMS.

1.When no value is reported, see chlordane constituents.

2.Constituents or metabolites of technical chlordane.

Table 31: Current Home Tech Issues PCs Computer Data Devices Only for Location Logon Martin



Table 32. Coosa River Fish Physical Measurements and Location Data, November-December, 2002

Station	Station ID	Trophic level	Species	ASB ID	Total Length (mm)	Whole Weight (g)	Fillet Weight (g)	Sampling Location	
								Latitude (N)	Longitude (W)
River Mile 2, Rome GA	CR1	4	spotted bass	CR1-SPB1	426	1087	445	upper boundary	upper boundary
			spotted bass	CR1-SPB2	272	191	68	34° 15' 19.5"	85° 11' 31.5"
			spotted bass	CR1-SPB5	448	1302	526		
			spotted bass	CR1-SPB6	285	289	112		
			spotted bass	CR1-SPB7	245	139	61		
	CR2	3	smallmouth buffalo	CR1-SBF1	505	1714	585	lower boundary	lower boundary
			smallmouth buffalo	CR1-SBF2	486	1576	447	34° 14' 13.1"	85° 11' 36.0"
			smallmouth buffalo	CR1-SBF3	448	1208	436		
			smallmouth buffalo	CR1-SBF4	432	1155	451		
			smallmouth buffalo	CR1-SBF5	397	889	302		
Below Hwy 100	CR2	4	largemouth bass	CR2-LMB1	495	1625	659	upper boundary	upper boundary
			largemouth bass	CR2-LMB2	374	686	277	34° 15' 01.0"	85° 22' 15.9"
			largemouth bass	CR2-LMB3	338	563	231		
			largemouth bass	CR2-LMB4	345	466	200		
			largemouth bass	CR2-LMB5	324	402	180		
	CR3	3	channel catfish	CR2-CCF1	458	756	229	lower boundary	lower boundary
			smallmouth buffalo	CR2-SBF1	480	1957	814	34° 15' 06.2"	85° 22' 51.0"
			smallmouth buffalo	CR2-SBF2	476	1734	571		
			smallmouth buffalo	CR2-SBF3	369	751	292		
			smallmouth buffalo	CR2-SBF4	356	594	251		
Brushy Branch	CR3	4	largemouth bass	CR3-LMB1	523	2941	1054	upper boundary	upper boundary
			largemouth bass	CR3-LMB2	462	1344	495	34° 11' 8.6"	85° 24' 18.3"
			largemouth bass	CR3-LMB3	380	1006	422		
			largemouth bass	CR3-LMB4	374	767	322		
			largemouth bass	CR3-LMB5	352	854	366		
	CR3	3	smallmouth buffalo	CR3-SBF1	385	883	363	lower boundary	lower boundary
			smallmouth buffalo	CR3-SBF2	346	591	229	34° 10' 49.1"	85° 24' 49.6"
			smallmouth buffalo	CR3-SBF3	374	645	237		
			smallmouth buffalo	CR3-SBF4	345	533	216		
			smallmouth buffalo	CR3-SBF5	323	467	174		
Lake Weiss, Poole's Ferry	LW1	4	largemouth bass	LW1-LMB1	398	1033	416	upper boundary	upper boundary
			largemouth bass	LW1-LMB2	407	969	410	34° 11' 10.6"	85° 30' 40.8"
			largemouth bass	LW1-LMB3	425	968	398		
			largemouth bass	LW1-LMB4	365	775	312		
			largemouth bass	LW1-LMB5	322	494	178		
	LW1	3	smallmouth buffalo	LW1-SBF1	450	1528	590	lower boundary	lower boundary
			smallmouth buffalo	LW1-SBF2	411	991	395	34° 11' 52.1"	85° 30' 11.5"
			smallmouth buffalo	LW1-SBF3	397	693	370		
			smallmouth buffalo	LW1-SBF4	386	792	318		
			smallmouth buffalo	LW1-SBF5	390	823	342		
Lake Weiss, Bay Springs	LW2	4	largemouth bass	LW2-LMB1	444	1472	629	upper boundary	upper boundary
			largemouth bass	LW2-LMB2	438	1393	573	34° 10' 57.8"	85° 43' 58.8"
			largemouth bass	LW2-LMB3	423	1250	481		
			largemouth bass	LW2-LMB4	340	507	209		
			spotted bass	LW2-SPB1	406	842	339		
	LW2	3	blue catfish	LW2-BCF1	462	817	276	lower boundary	lower boundary
			smallmouth buffalo	LW2-SBF1	688	4422	1482	34° 10' 38.2"	85° 45' 14.0"
			smallmouth buffalo	LW2-SBF2	594	2762	813		
			smallmouth buffalo	LW2-SBF3	512	2372	789		
			smallmouth buffalo	LW2-SBF4	450	1515	657		
Upper Neely Henry Reservoir, Croft Ferry	UNH	4	largemouth bass	UNH-LMB1	500	2233	893	upper boundary	upper boundary
			largemouth bass	UNH-LMB2	371	887	383	34° 06' 41.0"	85° 50' 42.0"
			largemouth bass	UNH-LMB3	340	522	198		
			spotted bass	UNH-SPB1	495	1535	594		
			spotted bass	UNH-SPB2	383	639	343		
	UNH	3	smallmouth buffalo	UNH-SBF1	575	3222	1023	lower boundary	lower boundary
			smallmouth buffalo	UNH-SBF2	605	3244	1079	34° 06' 39.0"	85° 51' 27.8"
			smallmouth buffalo	UNH-SBF3	485	1579	599		
			smallmouth buffalo	UNH-SBF4	455	1520	592		
			smallmouth buffalo	UNH-SBF5	450	1492	560		
Logan Martin Reservoir, near I-20	LM	4	largemouth bass	LM-LMB1	372	946	397	upper boundary	upper boundary
			largemouth bass	LM-LMB2	375	946	395	33° 35' 34.7"	86° 11' 07.6"
			largemouth bass	LM-LMB3	335	638	273		
			largemouth bass	LM-LMB4	288	373	158		
	LM	3	spotted bass	LM-SPB1	384	771	309		
			channel catfish	LM-CCF1	334	289	88	lower boundary	lower boundary
			blue catfish	LM-BCF1	390	556	168	33° 35' 32.2"	86° 10' 52.6"
			blue catfish	LM-BCF2	340	260	74		
			blue catfish	LM-BCF4	300	202	61		
			blue catfish	LM-BCF5	300	178	55		

Fish handling and processing follows guidance in EPA 823-B-00-008.

**APPENDIX B
FIGURES**

Figure 1
GE - Rome
Sediment PCB Data
Total Aroclor Concentration
January, 2002



- Each box represents 6 inches of sediment depth.
- Blue = U only (below detection limits)
- Yellow = 1570 ug/kg
- ▲ GE Stations
- EPA Stations
- ★ Cities

Figure 2
Coosa River PCB TMDL
Sample Station Locations
Nov/ Dec, 2002




Figure 3
Particle Size Distribution
Station SCR1





Figure 4
Particle Size Distribution

Station SCR3



■ SCR3A ■ SCR3B □ SCR3C

Figure 5
Particle Size Distribution
Station SCR4




Figure 6
Particle Size Distribution
Station SCR5




Figure 7
Particle Size Distribution
Station SCR6





Figure 8
Particle Size Distribution
Station SLW1



■ SLW1A ■ SLW1B □ SLW1C □ SLW1D ■ SLW1E

Figure 9
Particle Size Distribution




Figure 10
Particle Size Distribution
Station SLW3




Figure 11
Particle Size Distribution
Station SLW4




Figure 12
Particle Size Distribution
Station SNHU




Figure 13
Particle Size Distribution
Station SNH1






Figure 14

Particle Size Distribution
Station SNH2



■ SNH2A ■ SNH2B □ SNH2C □ SNH2D

Figure 15
Particle Size Distribution
Station SNH3



■ SNH3A ■ SNH3B □ SNH3C □ SNH3D

Figure 16
Particle Size Distribution
Station SLM




Figure 19. Coosa River at Brushy Branch, Site CR 3
Fish Tissue Average PCB Aroclor 1260 Concentration
November - December, 2002




Figure 20. Coosa River at Lake Weiss, Site LW 1
Fish Tissue Average PCB Aroclor 1260 Concentration
November - December, 2002




Figure 21. Coosa River at Lake Weiss, Site LW 2
Fish Tissue Average PCB Aroclor 1260 Concentration
November - December, 2002




Figure 22. Coosa River at Upper Neely Henry Reservoir, Site UNH
Fish Tissue Average PCB Aroclor 1260 Concentration
November - December, 2002




Figure 23. Coosa River at Logan Martin Reservoir, Site LM
Fish Tissue Average PCB Aroclor 1260 Concentration
November - December, 2002






Figure 24
Coosa River PCB TMDL
Total Aroclor Concentration
EPA Samples, Nov/Dec, 2002



Each box represents 6 inches of sediment depth.

- Blue = U only (below detection limits)
- Green = 1 - 100 ug/kg
- Yellow = > 100 ug/kg

GE Stations

Cities

Depth (in)	Downstream												
	Total Aroclor Concentration (ug/kg)												
	SLM	SNH3	SNH2	SNH1	SNHU	SLW4	SLW3	SLW1	SCR6	SCR5	SCR4	SCR3	SCR1
0-6	5.4	17				220			11	11.3			
6-12						220	U	U					
12-18			40										
18-24			10							23	38		
24-30				160									
30-36				81						70	40		
36-42					215	U							
42-48						173					400	105	
48-54											30	610	
54-60							85						

5 0 5 10 15 20 Miles

Figure 25.




Figure 26

Largemouth Bass Aroclor 1260 Concentrations




Fig. 27 Mean Concentrations of Aroclor 1260 for All Trophic Level 4 Species by Station




Fig. 28 Mean Concentrations of Aroclor 1260 for All Trophic Level 3 Species by Station

