
POOR LEGIBILITY ONE OR MORE PAGES IN THIS DOCUMENT ARE DIFFICULT TO READ DUE TO THE QUALITY OF THE ORIGINAL

SFUND RECORDS CENTER 88133010

> SFUND RECORDS CTR 2166-03589

ARCSINIST



Remedial Activities at Selected Uncontrolled Hazardous Waste Sites in the Zone of Regions IX and X

FINAL REGIONAL GROUNDWATER
FIELD SAMPLING PLAN
REMEDIAL INVESTIGATION
SAN FERNANDO VALLEY BASIN
BURBANK, GLENDALE, AND
LOS ANGELES, CALIFORNIA

EPA WA No. 68-W9-0031 December 1991

SFO69114.FI.FQ



Environmental Protection Agency Contract No. 68-W9-0031

AR0003

FINAL REGIONAL GROUNDWATER
FIELD SAMPLING PLAN
REMEDIAL INVESTIGATION
SAN FERNANDO VALLEY BASIN
BURBANK, GLENDALE, AND
LOS ANGELES, CALIFORNIA

EPA WA No. 68-W9-0031 December 1991

SFO69114.FI.FQ

FINAL REGIONAL GROUNDWATER FIELD SAMPLING PLAN REMEDIAL INVESTIGATION

SAN FERNANDO VALLEY BASIN BURBANK, GLENDALE, AND LOS ANGELES, CALIFORNIA

EPA CONTRACT NO. 68-W9-0031 EPA WORK ASSIGNMENT NO. 31-03-9959 CH2M HILL PROJECT NO. SFO69114.FI.FQ

December 1991

SFO69114.FI.FQ

NONDISCLOSURE STATEMENT

This document has been prepared for the U.S. Environmental Protection Agency under Contract No. 68-W9-0031. The material contained herein is not to be disclosed to, discussed with, or made available to any person or persons for any reason without the prior express approval of a responsible official of the U.S. Environmental Protection Agency.

| Sample Plan Title: | GROUNDWATER SAMPLING PLAN | · | | |
|--|---------------------------------|------------------|-------------------------|--------|
| Site Name: | SAN FERNANDO VALLEY BASIN | · | | |
| Site Location: | LOS ANGELES COUNTY | | | |
| City/State/Zip: | LOS ANGELES, CALIFORNIA | | | |
| Site EPA ID #: | | | | |
| Anticipated Sampling Dates: | JANUARY 1992 TO JANUARY 1993 | · | | , |
| Prepared By: | Jess Brown and Peter Rude | OCT 1991 Date | | |
| Agency or Firm: | CH2M HILL, INC. | | | |
| Address: | 6425 CHRISTIE AVENUE, SUITE 500 | | | |
| City/State/Zip: | EMERYVILLE, CALIFORNIA 94608 | | | |
| Telephone: | 415/652-2426 | | | |
| EPA Project Officer: QAPjp Approval Date: | Kevin Mayer | Section: H-6-1 | 415/744-2260 Phone # | |
| * * * * * | * * * * * * | * * * * * | * * * * | * |
| Received by Superfund Re | emedial Project Hanager: | | | |
| | | | Date | F O |
| Reviewed by: | | | Date | R |
| Арр | proved/Not Approved | | Date | |
| * * * * * | * * * * * * * | * * * * * | * . * * * | * |
| Expedited Review? | | | Yes/No | E |
| Received by Quality Assu | urance Management Section: | | Date | P A |
| Reviewed by: | all P Manuell | | , | |
| Ару | proved Not Approved | | 11/18/91 Date | |
| Concurrence: | ttihy | | 11/18/91 | U S |
| | def, Quality/Assurance | | | E |

CONTENTS

| | | Page |
|------|---|--|
| List | of Acronyms | |
| Sec | tion | |
| 1 | Objectives of Sampling Effort Introduction Objectives | 1-1 1-1 1-1 |
| 2 | Site Background Site Location Previous Investigations | 2-1 2-1 2-1 |
| 3 | Groundwater Sampling Location Maps | 3-1 |
| 4 | Rationale for Sampling Locations, Number of Samples, and Analytical Parameters Sampling Locations Rationale for Number of Samples Selection of Analytical Parameters | 4-1 4-1 4-5 4-6 |
| 5 | Request for Analysis Introduction Quarterly and Annual Sampling Events | 5-1 5-1 5-1 |
| 6 | Methods and Procedures Groundwater Sampling Field Measurements Transport and Disposal of Derived Wastes Equipment Decontamination Sample Containers and Preservation Sample Packaging and Shipping Sample Documentation Quality Assurance | 6-1 6-7 6-8 6-9 6-10 6-11 6-14 |
| 7 | Site Health and Safety | 7-1 |
| 8 | References | 8-1 |

CONTENTS (Continued)

| • | | Page |
|------------|---|----------------|
| APPE | INDIXES | <u>r age</u> |
| Α | Monitoring Well Location Descriptions and Copies of 1991 Thomas Guide Maps | |
| В | Scaled Drawings of Monitoring Well Locations | |
| Č | Description of SAS Analytical Procedures | |
| D | CLP Paperwork Instructions | |
| E | Examples of Field Logbooks | |
| F | CH2M HILL Site Safety Plan | |
| TABI | LES | |
| 2-1 | JMM Laboratories Analytical Method References for Suite 1 | 2-2 |
| 2-2 | JMM Laboratories Analytical Method References for Suite 2 | 2-3 |
| 2-3 | VOCs Detected Above Primary MCL | 2-5 |
| 2-4 | Inorganic Analytes Detected Above Primary MCL | 2-7 |
| 2-5 | Metals Detected Above Primary MCL | 2-9 |
| 4-1 | San Fernando Valley Groundwater Basin | |
| | Monitoring Wells Included in Quarterly Sampling Events | . 4-2 |
| 4-2 | San Fernando Valley Groundwater Basin | |
| | Monitoring Wells Included in Annual Sampling Event | 4-3 |
| 4-3 | EPA and California Primary Maximum Contaminant Levels and | |
| | California State Action Levels for Selected Organic | . 4.7 |
| <i>5</i> 1 | Compounds, Metals, and Inorganic Compounds in Drinking Water | 4-7 |
| 5-1 | Groundwater Samples, Analytical Parameters, Methods, and | 5-2 |
| 5-2 | Detection Limits Request for Analysis, Quarterly Sampling Event | 5-2 5-4 |
| 5-2 5-3 | Request for Analysis, Annual Sampling Event | 5-6 |
| 6-1 | Monitoring Well Purge Volumes | 6-2 |
| | | |
| FIGU | JRES | Follows |
| | | Page |
| 3-1 | Site Location Map | 3-1 |
| 3-2 | RI Well Locations | 3-1 |
| 3-3 | RI Well Locations for Quarterly Sampling | 3-1 |
| 3-4 | RI Well Locations for Annual Sampling | 3-1 |

List of Acronyms

AAS Atomic Absorption Spectroscopy

bgs Below Ground Surface

BNA Base, Neutral, Acid Extractable Semi-Volatile Organic Chemical

BOW Bottom of Well cc Cubic Centimeter

CERCLA Comprehensive Environmental Response, Compensation and Liability

Act

CLP Contract Laboratory Program

CW Cluster Well DCA Dichloroethane

DHS Department of Health Services

DI Deionized Water
DL Detection Limit
DCE Dichloroethene

DQO Data Quality Objective

DTW Depth to Water DUP Duplicate Sample

DWR Department of Water Resources

EC Electrolytic Conductivity
FID Flame Ionization Detector

FS Feasibility Study

ft Feet

GC/MS Gas Chromatograph/Mass Spectrometer

gpm Gallons per Minute
GSE Ground Surface Elevation

GWE Groundwater Elevation

ID Inside Diameter

in Inch

JMM James M. Montgomery, Consulting Engineers, Inc. LACDPW Los Angeles County Department of Public Works

LACSD Los Angeles County Sanitation District

LADWP Los Angeles Department of Water and Power

LCS Laboratory Control Standard
MCL Maximum Contaminant Level
mg/kg Milligrams per Kilogram

mg/l Milligrams per Liter

MS/MSD Matrix Spike/Matrix Spike Duplicate

MW Monitoring Well
N/A Not Applicable
NA Not Analyzed
ND Not Detected

NPL National Priorities List

(Continued)

NS No Sample

OD Outside Diameter
OU Operable Unit
OW Observation Well

PCB Polychlorinated Biphenyl

PCE Tetrachloroethene or Perchloroethene or Tetrachloroethylene

PRP Potentially Responsible Party
QA/QC Quality Assurance/Quality Control

QC Quality Control
RE Reanalyzed Sample
RI Remedial Investigation

RIN Rinsate Water
ROW Right-of-Way
SAL State Action Level

SAP Sampling and Analysis Plan

SFVGB San Fernando Valley Groundwater Basin
SW Solid Waste (EPA SW846 Methods Manual)

SWAT Solid Waste Assessment Test

TB Travel Bank
TCA Trichloroethane

TCE Trichloroethene or Trichloroethylene

THM Trihalomethane

TM Technical Memorandum TSP Trisodium Phosphate

U.S. EPA United States Environmental Protection Agency

USGS United States Geological Survey

VOC Volatile Organic Chemical VPB Vertical Profile Boring

WL Waste Liquid

μg/l Micrograms per Liter

Section 1 OBJECTIVES OF SAMPLING EFFORT

INTRODUCTION

This sampling plan (SAP) presents the procedures for the quarterly sampling of 41 monitoring wells and annual sampling of 87 monitoring wells in the San Fernando Valley Groundwater Basin (SFVB). This work is part of the Remedial Investigation (RI) for the SFVB. This SAP addendum is an addendum to the SFVB previously prepared and submitted to EPA Region IX by James M. Montgomery, Consulting Engineers, Inc. (JMM), March 1989.

The SFVB contains four National Priorities List (NPL) sites: North Hollywood, Crystal Springs, Pollock, and Verdugo. Previous investigations have shown that groundwater contamination extends beyond the NPL site boundaries. Therefore, EPA has expanded the SFVB study area boundaries to include the eastern portion of the San Fernando Basin. The primary groundwater contaminants within the study area consist of the volatile organic compounds (VOCs), trichloroethene (TCE), and perchloroethene (PCE). The study area covers portions of the Cities of Los Angeles, Burbank, and Glendale, California, and unincorporated areas within Los Angeles County.

The wells to be sampled consist of 44 individual monitoring wells screened at different depths at 15 cluster well sites and 43 shallow vertical profile borings/monitoring wells (VPBs). The wells were installed by JMM during 1988 and 1989. Construction details and initial soil and water characterization data are found in a series of technical memorandums (JMM, 1990a,b,c,d, 1991a,b,c).

This SAP addendum includes the objectives of the sampling program, the site background, the rationale for groundwater monitoring, the rationale for sample locations, the number and frequency of samples to be collected, analytical parameters, and methods for obtaining samples.

OBJECTIVES

The objective of the groundwater SAP is monitor the horizontal and vertical extent of groundwater contamination beneath the SFVB site. The data collected during the groundwater sampling program will be used to estimate the extent of contamination and the rate of contaminant movement, and to assist in evaluating and selecting general response actions and remedial actions for contaminated groundwater.

Section 2 SITE BACKGROUND

SITE LOCATION

The SFVB study area is highly urbanized with residential and light industrial areas and the Burbank Airport. It is bounded by the Santa Monica Mountains on the south, Hollywood Freeway on the west, Verdugo Mountains on the north, and the Glendale Freeway on the east.

All of the 87 monitoring wells used in the sampling program are located throughout the study area within an 8-mile radius of each other.

PREVIOUS INVESTIGATIONS

In 1980, a water quality survey of selected Los Angeles Department of Water and Power (LADWP) production and observation wells revealed the presence of VOCs above California Department of Health Services (DHS) action levels in groundwater. These findings resulted in the closing of a number of LADWP wells and the blending of flows from selected wells with water from the Los Angeles Aqueduct (JMM, 1989).

A 2-year LADWP study, started in 1981, included field investigations, industrial site surveys, record and archive searches, literature reviews, and water quality analyses of more than 600 samples. Contamination in excess of United States Environmental Protection Agency (EPA) and DHS action levels was detected in about 45 percent of the LADWP supply wells in the eastern portion of the SFVB. Analyses of shallow groundwater samples collected from wells in 1988 detected maximum concentrations of PCE at 43,000 ppb and TCE at 7,800 ppb (JMM, 1989). TCE is present in the study area groundwater in average concentrations ranging from 5 to 50 ppb, with a maximum concentration ranging from 200 to 500 ppb. Average PCE concentrations range between 4 and 50 ppb, with a maximum level of 130 ppb (JMM, 1989). But, there are areas of elevated TCE and PCE contamination throughout the basin where VOC concentrations have been detected in the 10's of parts per million (ppm). Maximum Contaminant Levels (MCLs) for TCE and PCE are 5 parts per billion (ppb).

During the initial groundwater characterization of the 87 monitoring wells immediately after installation between November 1989 and January 1991, JMM used two different analytical suites. Table 2-1 presents Suite 1 and analytical methods used for North Hollywood VPBs (JMM, 1990a), Crystal Spring VPBs (JMM, 1990b), Pollock VPBs (JMM, 1990c), and Verdugo VPBs (JMM, 1990d), and Table 2-2 presents Suite 2 and analytical methods used for Crystal Springs cluster wells (JMM,

RDD/R10/009.51 2-1

1991a), Pollock cluster wells (JMM, 1991b), and North Hollywood cluster wells (JMM, 1991c). Suite 2 added the analysis for radionuclides and water treatment parameters.

| Table 2-1 JMM Laboratories Analytical Method References for Suite 1 | | | | | | | |
|--|-----------|----------------------|--|--|--|--|--|
| Analyte Water Method Number Methodology | | | | | | | |
| Volatile Organic Chemicals | EPA 524.2 | Purge and Trap GC/MS | | | | | |
| BNAs | EPA 625 | GC/MS | | | | | |
| Pesticides/PCBs | EPA 608 | Gas Chromatography | | | | | |
| Antimony | EPA 204.2 | AAS | | | | | |
| Arsenic | EPA 206.2 | AAS | | | | | |
| Beryllium | EPA 210.1 | AAS | | | | | |
| Cadmium | EPA 213.1 | AAS | | | | | |
| Chromium | EPA 218.1 | AAS | | | | | |
| Copper | EPA 220.1 | AAS | | | | | |
| Lead | EPA 239.2 | AAS | | | | | |
| Mercury | EPA 245.1 | Cold Vapor AAS | | | | | |
| Nickel | EPA 249.1 | AAS | | | | | |
| Selenium | EPA 270.2 | AAS | | | | | |
| Silver | EPA 272.1 | AAS | | | | | |
| Thallium | EPA 279.2 | AAS | | | | | |
| Zinc | EPA 289.1 | AAS | | | | | |

Notes:

- EPA U.S. Environmental Protection Agency, Environmental Monitoring and Support Laboratory. 1983. *Methods for Chemical Analysis of Water and Wastes*. EPA-600/4-79-020. Cincinnati, OH, March 1983 for all EPA methods except EPA 608, EPA 524.2, and EPA 625.
- EPA Federal Register. 1984. Vol 49. No. 290. 26 October. 1984 43234 for EPA 608 and EPA 625.
- EPA U.S. Environmental Protection Agency. 1985. Methods for the Determination of Organic Compounds in Finished Drinking Water and Raw Source Water. (Revised Sept. 1986) for EPA 524.2.

| Table 2-2 JMM Laboratories Analytical Method References for Suite 2 | | | | | | |
|--|---------------------|----------------------|--|--|--|--|
| Analyte | Water Method Number | Methodology | | | | |
| Volatile Organic Chemicals | EPA 524.2 | Purge and Trap GC/MS | | | | |
| BNAs | EPA 625 | GC/MS | | | | |
| Pesticides/PCBs | EPA 608 | Gas Chromatography | | | | |
| Antimony • | EPA 204.2 | AAS | | | | |
| Arsenic | EPA 206.2 | AAS | | | | |
| Beryllium | EPA 210.1 | AAS | | | | |
| Cadmium | EPA 213.1 | AAS | | | | |
| Chromium | EPA 218.1 | AAS | | | | |
| Copper | EPA 220.1 | AAS | | | | |
| Lead . | EPA 239.2 | AAS | | | | |
| Mercury | EPA 245.1 | Cold Vapor AAS | | | | |
| Nickel | EPA 249.1 | AAS | | | | |
| Selenium | EPA 270.2 | AAS | | | | |
| Silver | EPA 272.1 | AAS | | | | |
| Thallium | EPA 279.2 | AAS | | | | |
| Zinc | EPA 289.1 | AAS | | | | |
| Radon | Lucas Cell | | | | | |
| Gross Alpha | EPA 900.0 | | | | | |
| Gross Beta | EPA 900.0 | | | | | |
| Aluminum | EPA 200.7 | | | | | |
| Alkalinity | EPA 310.1 | | | | | |
| Calcium | EPA 200.7 | | | | | |
| Chloride | EPA 300.0 | | | | | |
| Conductance | EPA 120.1 | | | | | |
| Fluoride | EPA 340.2 | | | | | |
| Hardness (Ca + Mg) | EPA 200.7 | | | | | |
| Magnesium | EPA 200.7 | | | | | |
| Nitrate | EPA 300.0 | | | | | |
| Potassium | EPA 200.7 | | | | | |
| Sulfate | EPA 300.0 | | | | | |
| рН | EPA 150.1 | | | | | |

Notes:

- EPA U.S. Environmental Protection Agency, Environmental Monitoring and Support Laboratory. 1983. Methods for Chemical Analysis of Water and Wastes. EPA-600/4-79-020. Cincinnati, OH, March 1983 for all EPA methods except EPA 608, EPA 524.2, and EPA 625.
- EPA Federal Register. 1984. Vol 49. No. 290. 26 October. 1984 43234 for EPA 608 and EPA 625.
- EPA U.S. Environmental Protection Agency. 1985. Methods for the Determination of Organic Compounds in Finished Drinking Water and Raw Source Water. (Revised Sept. 1986) for EPA 524.2.

Results of the initial monitoring well characterization indicated that several water quality parameters were found to be above primary Federal and State MCLs. LADWP, in conjunction with JMM, sampled selected RI wells during two quarterly sampling events (January and April, 1991), and these data have been used to assist in selecting proposed sampling locations. LADWP/JMM's monitoring program originally consisted of quarterly sampling of all 44 cluster wells and 27 of the 42 VPBs (Quarterly Sampling of Cluster Wells and VPB Wells, 1991). Nine VOCs, six metals, and one inorganic have been detected above MCLs (Table 2-3 through Table 2-5). Currently, there are no MCLs for radon; however, detected radon levels are reported in Table 2-4 for information purposes. No pesticides or PCBs have been detected in any of the wells.

RDD/R10/009.51 2-4

| Well Name | Benzene (1.0 μg/l) ⁸ | Carbon Tetrachloride (0.5 µg/l) ⁸ | 1,1-Dichloroethane (5 µg/l) ^a | 1,2-Dichloroethane (0.5 μg/l) ⁸ | 1,1-Dichloroethene (6 μg/l) ^a | 1,1,2,2- Tetrachloroethane (1 μg/l) ^a | Perchloroethene (PCE) (5 μg/l) ^a | Trichloroethene (TCE) (5 μg/l) ⁸ | cis-1-2- Dichloroethene (6 µg/l) ^a |
|------------|------------------------------------|---|---|---|---|--|--|--|---|
| CS-C01-105 | | | | | | _ | 120.0 | 93.0 | |
| CS-C01-285 | | | | | | | 120.0 | 220.0 | |
| CS-C02-062 | | | | | | 8 | 120.0 | 200.0 | |
| CS-C02-180 | | | | | | 2 | 36.0 | 190.0 | |
| CS-C02-250 | | 1.0 | | | • | 2 | 36.0 | 150.0 | |
| CS-C02-335 | | 0.5 | | | | · ··· | 26.0 | 130.0 | |
| CS-C03-100 | | 10.0 | | | 26 | | 6.0 | 1,000.0 | |
| CS-C04-290 | | | | | | | 5.0 | 10.0 | |
| CS-C04-382 | | | | | | | 8.0 | 29.0 | |
| CS-C05-160 | | 1.0 | | | | | | 40.0 | |
| CS-C05-290 | | | | | | | 6.0 | 31.0 | |
| CS-VPB-01 | | | 1 | | | 24 | 120.0 | 120.0 | |
| CS-VPB-02 | | | | | | | | 14.0 | |
| CS-VPB-04 | 2.0 | 69.0 | 49 | 3.0 | 440 | 3 | 81.0 | 5,500.0 | |
| CS-VPB-05 | | 25.0 | 18 | | 170 | 94 | 56.0 | 960.0 | |
| CS-VPB-06 | | | | | | | 7.0 | 45.0 | |
| CS-VPB-07 | 2.0 | 110.0 | 15 | 2.1 | 230 | | 40.0 | 6,000.0 | 14.0 |
| CS-VPB-08 | | 3.0 | | | | | 5.0 | 93.0 | |
| CS-VPB-010 | | 0.7 | | | | | | | |
| CS-VPB-011 | | 1.0 | | | | 3 | 59.0 | 7.0 | |
| NH-C01-325 | | | | | | | 12.0 | | |
| NH-C02-220 | | 2.0 | | | | | | | |
| NH-C02-325 | | 5.0 | | 33.0 | | | 6.0 | 29.0 | |
| NH-C03-580 | | | | | | | | 29.0 | |

| | | | | | | | | | 51.000 2 0 |
|--------------|------------------------------------|---|---|---|---|--|--|--|---|
| Well Name | Benzene (1.0 μg/l) ^a | Carbon Tetrachloride (0.5 µg/l) ^a | 1,1-Dichloroethane (5 μg/l) ⁸ | 1,2-Dichloroethane (0.5 μg/l) ⁸ | 1,1-Dichloroethene (6 µg/l) ^a | 1,1,2,2- Tetrachloroethane (1 µg/l) ^a | Perchloroethene (PCE) (5 μg/l) ⁸ | Trichloroethene (TCE) (5 μg/l) ⁸ | cis-1-2- Dichloroethene (6 µg/l) ⁸ |
| NH-C04-240 | | | | | | | | 6.0 | |
| NH-C06-160 | | | | | | | | 50.0 | |
| NH-VPB-01 | | | | | | 3 | 120.0 | 220.0 | |
| NH-VPB-05 | | | | 4.0 | | | | | |
| NH-VPB-06 | | | | | | | | 10.0 | |
| NH-VPB-07 | | | 19 | 3.0 | | 5 | 75.0 | 38.0 | |
| NH-VPB-08 | | | | | | | | 12.0 | |
| NH-VPB-09 | 0.6 | 1.0 | · | | | | | | |
| NH-VPB-14 | | 3.0 | | 180.0 | | | | 740.0 | |
| PO-C02-052 | | | | 3.0 | | | , | 23.0 | |
| PO-C03-182 | | | | | | | | 6.0 | |
| PO-VPB-01 | | | | | | | 5.0 | 27.0 | |
| PO-VPB-02 | | 1.0 | | 5.0 | 41 | 24 | 140.0 | 820.0 | |
| PO-VPB-03 | | | | | | 6 | 40.0 | 75.0 | |
| PO-VPB-07 | | | | | | _ | 9.0 | 120.0 | |
| PO-VPB-08 | | | 12 | | | | | | |
| a#μg/l = MCI | | | | | · · · · · · · · · · · · · · · · · · · | | | | |

| Table 2-4 Inorganic Analytes Detected Above Primary MCL Sheet 1 of 2 | | | | | | | |
|--|-----------------------------------|---------------------|--|--|--|--|--|
| Well Name | Nitrate (45 mg/l) ^a | Radon () (pci/l) | | | | | |
| CS-C01-105 | 51.5 | 230 | | | | | |
| CS-C01-285 | | 340 | | | | | |
| CS-C01-558 | | 170 | | | | | |
| CS-C02-062 | 70.4 | 485 | | | | | |
| CS-C02-180 | | 240 | | | | | |
| CS-C02-250 | | 410 | | | | | |
| CS-C02-335 | | 250 | | | | | |
| CS-C03-100 | | 145 | | | | | |
| CS-C03-325 | | 290 | | | | | |
| CS-C03-465 | | 145 | | | | | |
| CS-C03-550 | | 160 | | | | | |
| CS-C04-290 | | 700 | | | | | |
| CS-C04-382 | | 260 | | | | | |
| CS-C04-520 | | 400 | | | | | |
| CS-C05-160 | | 90 | | | | | |
| CS-C05-290 | | 110 | | | | | |
| CS-C06-185 | | 35 | | | | | |
| CS-C06-278 | | 175 | | | | | |
| NH-C01-325 | | 180 | | | | | |
| NH-C01-450 | | 590 | | | | | |
| NH-C01-660 | | 530 | | | | | |
| NH-C01-780 | | 235 | | | | | |
| NH-C02-220 | 62.9 | 165 | | | | | |
| NH-C02-325 | | 2.8 | | | | | |
| NH-C02-520 | | 3.6 | | | | | |
| NH-C02-681 | | 195 | | | | | |
| NH-C03-380 | | 550 | | | | | |
| NH-C03-580 | | 230 | | | | | |
| NH-C03-680 | | 88 | | | | | |
| NH-C03-800 | | 220 | | | | | |

RDD/R10/030.51 2-7

Table 2-4
Inorganic Analytes Detected Above Primary MCL

Sheet 2 of 2

| Well Name | Nitrate (45 mg/l) ^a | Radon () (pci/l) |
|------------------------|-----------------------------------|---------------------|
| NH-C04-240 | · | 560 |
| NH-C04-375 | | 270 |
| NH-C04-560 | | 120 |
| NH-C05-320 | 88.0 | 75 |
| NH-C05-460 | | 25 |
| NH-C06-160 | 52.8 | 55 |
| NH-C06-285 | | 200 |
| NH-C06-425 | | 120 |
| PO-C01-354 | | 710 |
| PO-C02-052 | | 110 |
| PO-C03-182 | | 550 |
| PO-C03-235 - | | 380 |
| CS-VPB-04 | 48.4 | 250 |
| CS-VPB-05 | 48.4 | 115 |
| CS-VPB-06 | 53.0 | 245 |
| NH-VPB-04 | 48.4 | |
| NH-VPB-06 | 57.2 | |
| NH-VPB-13 | 74.8 | |
| NH-VPB-14 | 70.4 | 610 |
| PO-VPB-02 | 70.8 | 480 |
| PO-VPB-03 | 52.8 | 290 |
| PO-VPB-10 | 52.8 | |
| VD-VPB-01 | 70.4 | |
| VD-VPB-02 | 70.4 | |
| VD-VPB-06 | . 52.8 | , |
| $a \# \mu g / l = MCL$ | | |

Page 1 of 4

| Well Name | Lead (0.05 mg/l) ^a | Mercury (0.002 mg/l) ^a | Arsenic (0.05 mg/l) ^a | Selenium (0.01 mg/l) ^a | Cadmium (0.005 mg/l) ^a | Chromium (0.05 mg/l) ⁸ | Aluminum (1 mg/l) ^a |
|------------|----------------------------------|--------------------------------------|-------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|-----------------------------------|
| CS-C01-105 | | | | | | | 5.0 |
| CS-C02-062 | | | | | | | 16.0 |
| CS-C02-180 | i | | | | | | 12.0 |
| CS-C02-335 | | | | | | | 5.8 |
| CS-C03-100 | | | | | | | 6.3 |
| CS-C03-325 | | | | | | | 4.2 |
| CS-C03-465 | | | | | | | 7.0 |
| CS-C03-550 | | | | | | | 1.1 |
| CS-C04-290 | | | | | | | 2.6 |
| CS-C04-382 | | | | | | | 6.2 |
| CS-C04-520 | | | | | · | - | 1.6 |
| NH-C01-325 | | | | | | ` | 3.0 |
| NH-C01-450 | | | | | | | 4.4 |
| NH-C01-660 | | | | | | | 6.7 |
| NH-C01-780 | | | | | | | 9.0 |
| NH-C02-220 | | | | | | | 11.0 |
| NH-C02-325 | | | | | | | 6.2 |
| NH-C02-520 | | | | | | | 4.0 |
| NH-C02-681 | | · | | | | | 2.2 |

Page 2 of 4

| Well Name | Lead (0.05 mg/l) ^a | Mercury (0.002 mg/l) ^a | Arsenic (0.05 mg/l) ^a | Selenium (0.01 mg/l) ^a | Cadmium (0.005 mg/l) ^a | Chromium (0.05 mg/l) ^a | Aluminum (1 mg/l) ^a |
|------------|----------------------------------|--------------------------------------|-------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|-----------------------------------|
| NH-C03-380 | | | | | | | 4.3 |
| NH-C03-580 | | | | | | | 4.4 |
| NH-C03-680 | | | | | | | 2.5 |
| NH-C03-800 | | | | | | | 1.7 |
| NH-C04-240 | | | | | | | 4.6 |
| NH-C04-375 | | | | | | | 1.3 |
| NH-C05-320 | | | | | | | 6.0 |
| NH-C05-460 | | | | | | | 16.0 |
| NH-C06-160 | | | | | | | 8.5 |
| NH-C06-285 | | | | | | | 6.3 |
| PO-C01-195 | | | | | | | 3.5 |
| PO-C01-354 | | | | | | | 3.7 |
| PO-C02-052 | | | | | | | 2.9 |
| PO-C02-205 | | | | | | | 4.8 |
| PO-C03-182 | | | | | | | 7.3 |
| PO-C03-235 | | | | | | | 7.4 |
| CS-C02-250 | 0.0910 | 0.0080 | | | | · | |
| CS-VPB-01 | 0.0550 | 0.0034 | 0.0950 | | 0.0060 | 0.0990 | |
| CS-VPB-02 | | | 0.0500 | | | | |

Page 3 of 4

| Well Name | Lead (0.05 mg/l) ^a | Mercury (0.002 mg/l) ^a | Arsenic (0.05 mg/l) ^a | Selenium (0.01 mg/l) ^a | Cadmium (0.005 mg/l) ^a | Chromium (0.05 mg/l) ^a | Aluminum (1 mg/l) ^a |
|------------|----------------------------------|--------------------------------------|-------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|-----------------------------------|
| CV-VPB-04 | | | 0.0890 | | | 0.0700 | 15.0 |
| CS-VPB-05 | | | | | 0.0140 | 0.0600 | |
| CS-VPB-06 | | 0.0034 | | | | | |
| CS-VPB-08 | | 0.0035 | 0.0590 | 0.0190 | | 0.0720 | |
| CS-VPB-09 | | | 0.0850 | | | 0.1200 | - |
| CS-VPB-10 | | | | 0.0180 | 0.0060 | 0.0730 | ¥ - |
| CS-VPB-11 | | | 0.1150 | | | 0.0830 | |
| NH-C04-560 | | | | 0.0140 | | | 1.4 |
| NH-C06-425 | | | | 0.0100 | | | 4.3 |
| NH-VPB-01 | | | 0.0820 | | 0.0230 | 0.0890 | |
| NH-VPB-03 | | | 0.0620 | | | 0.0530 | |
| NH-VPB-06 | | 0.0026 | | | 0.0100 | | |
| NH-VPB-09 | | | | | 0.0300 | | |
| NH-VPB-11 | | | | | 0.0330 | 0.0860 | |
| NH-VPB-12 | | | 0.1300 | | , | 0.1100 | |
| NH-VPB-13 | | | | | | 0.0610 | |
| NH-VPB-14 | 0.0560 | 0.0037 | 0.4400 | 0.0100 | | 0.1600 | 10.0 |
| PO-VPB-01 | | | | | | 0.0680 | |
| PO-VPB-02 | | 0.0470 | | | | 1.2000 | 2.2 |

Page 4 of 4

| Well Name | Lead (0.05 mg/l) ^a | Mercury (0.002 mg/l) ^a | Arsenic (0.05 mg/l) ^a | Selenium (0.01 mg/l) ^a | Cadmium (0.005 mg/l) ^a | Chromium (0.05 mg/l) ^a | Aluminum (1 mg/l) ^a |
|-----------|----------------------------------|--------------------------------------|-------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|-----------------------------------|
| PO-VPB-03 | | | | | | | 2.8 |
| PO-VPB-05 | | | | | | 0.0720 | |
| PO-VPB-07 | | 0.0040 | | | | | |
| VD-VPB-01 | | | 0.0830 | | | | |
| VD-VPB-05 | | | 0.0990 | | | | |
| VD-VPB-06 | | | 0.0800 | | | | |
| VD-VPB-07 | | | | | | 0.0790 | |


Section 3 GROUNDWATER SAMPLING LOCATION MAPS


The maps described below as Figures 3-1 through 3-4 provide an overview of the SFVB study area and the proposed groundwater sampling locations:

- Figure 3-1--Site Location Map--Identifies the geographic location of the SFVB study area.
- Figure 3-2--RI Well Locations--Identifies the 15 cluster well sites (44 monitoring wells) and the 43 VPBs in the SFVB study area.
- Figure 3-3--RI Well Locations for Quarterly Sampling--Identifies the location of the 41 monitoring wells in the SFVB study area that are scheduled for quarterly sampling.
- Figure 3-4--RI Well Locations for Annual Sampling--Identifies the location of 87 monitoring wells in the SFVB study area that are scheduled for annual sampling.

Appendix A contains the Thomas Guide Street Maps of each well location to supplement the figures described above. Appendix A also contains a description of the monitoring well locations according to well location; the nearest street to the well location and nearest major cross street; the specific location of each well, e.g., in the street, parkway, sidewalk, etc.; the city where the well is located; the 1991 Thomas Guide Street Guide map page; and the sampling frequency of each well.

Detailed scaled drawings of each monitoring well location are found in Appendix B.





LEGEND:

- BASIN BOUNDARY

MAJOR FREEWAY


..... NPL SITE BOUNDARY

▲ VPB WELL LOCATION


O CLUSTER WELL LOCATION

◆ VPB AND CLUSTER WELL LOCATION

FIGURE 3-2
RI WELL LOCATIONS
SAN FERNANDO VALLEY BASIN



SFO69114.FI.FQ OCTOBER 1991



SFO69114.FI.FQ OCTOBER 1991

RI WELL LOCATIONS FOR ANNUAL SAMPLING

SAN FERNANDO VALLEY BASIN

Section 4 RATIONALE FOR SAMPLING LOCATIONS, NUMBER OF SAMPLES, AND ANALYTICAL PARAMETERS

SAMPLING LOCATIONS

As part of the development of this recommended monitoring program, available contaminant data, well construction details, water level data, and zones of groundwater contamination maps were compiled and reviewed. VOC contaminant data, well construction information, and water level data were obtained from CH2M HILL's San Fernando Valley Geographical Information System (SFVGIS) data base.

VOC contaminant data have been used to separate RI wells into two categories: those recommended to be sampled quarterly, and those recommended to be sampled annually (CH2M HILL, 1991). A total of 41 RI wells are recommended to be sampled every quarter on the following basis:

• Previous sampling indicate concentrations of TCE, PCE, or other VOCs in excess of Federal and State MCLs.

In addition to the 41 wells that will be sampled on a quarterly basis, an additional 46 will be sampled on an annual basis. These additional 46 RI wells are recommended for the following reasons:

- Previous sampling indicates detectable concentrations of TCE, PCE, or other VOCs, but below MCLs. A total of 20 wells were identified on this basis.
- Previous sampling indicates nondetectable concentrations of VOCS. A total of 26 wells were identified on this basis. These wells are recommended for sampling because only one to four samples have been obtained to date, and additional samples are needed to better characterize groundwater contamination. If future sampling indicates continued nondetectable concentrations of contaminants within these wells, then EPA may decide to remove these wells from the monitoring program after three nondetects have occurred.

Table 4-1 identifies the 41 monitoring wells that will be sampled on a quarterly basis (see Figure 3-3 for locations). Table 4-2 identifies 87 monitoring wells that will be sampled on an annual basis. This includes the 41 wells sampled on a quarterly basis plus 46 additional wells (see Figure 3-4 for locations). The sampling program will need to be periodically reevaluated and revised as new data become available. For example,

Table 4-1 San Fernando Valley Basin Monitoring Wells Included in Quarterly Sampling Events

| Well Site | Well Name | Well Site | Well Name | | |
|-----------------------|------------|----------------------|---------------------------------------|--|--|
| Crystal Spring Wells | | North Hollywood VPBs | | | |
| | CS-C01-105 | | NH-VPB-01 | | |
| | CS-C01-285 | | NH-VPB-05 | | |
| | CS-C02-62 | | NH-VPB-06 | | |
| | CS-C02-180 | | NH-VPB-07 | | |
| | CS-C02-250 | | NH-VPB-08 | | |
| | CS-C02-335 | | NH-VPB-09 | | |
| | CS-C03-100 | | NH-VPB-14 | | |
| | CS-C04-290 | | · · · · · · · · · · · · · · · · · · · | | |
| | CS-C04-382 | | | | |
| | CS-C05-160 | Pollock VPBs | | | |
| | CS-C05-290 | | PO-VPB-01 | | |
| | | | PO-VPB-02 | | |
| North Hollywood Wells | | | PO-VPB-03 | | |
| | NH-C01-325 | | PO-VPB-04 | | |
| | NH-C02-220 | | PO-VPB-07 | | |
| | NH-C02-325 | | PO-VPB-08 | | |
| | NH-C03-580 | Crystal Springs VPB | S | | |
| | NH-C04-240 | | CS-VPB-01 | | |
| | NH-C06-160 | | CS-VPB-02 | | |
| Pollock Wells | | | CS-VPB-04 | | |
| | PO-C02-53 | | CS-VPB-05 | | |
| | PO-C03-182 | | CS-VPB-06 | | |
| | | | CS-VPB-07 | | |
| | | | CS-VPB-08 | | |
| | | | CS-VPB-10 | | |
| | | | CS-VPB-11 | | |

| M | | Table 4-2 nando Valley Basin luded in Annual Sampling E | vent |
|----------------------|------------|---|------------|
| Well Site | Well Name | Well Site | Well Name |
| Crystal Spring Wells | | North Hollywood Wells | |
| | CS-C01-105 | | NH-C01-325 |
| | CS-C01-285 | | NH-C01-450 |
| | CS-C01-558 | | NH-C01-660 |
| | CS-C02-62 | | NH-C01-780 |
| | CS-C02-180 | | NH-C02-220 |
| | CS-C02-250 | | NH-C02-325 |
| | CS-C02-335 | | NH-C02-520 |
| | CS-C03-100 | | NH-C02-681 |
| | CS-C03-325 | | NH-C03-380 |
| | CS-C03-465 | | NH-C03-580 |
| | CS-C03-550 | | NH-C03-680 |
| | CS-C04-290 | | NH-C03-800 |
| | CS-C04-382 | | NH-C04-240 |
| | CS-C04-520 | | NH-C04-375 |
| | CS-C05-160 | | NH-C04-560 |
| | CS-C05-290 | | NH-C05-320 |
| | CS-C06-185 | | NH-C05-460 |
| | CS-C06-278 | | NH-C06-160 |
| | | | NH-C06-285 |
| | | | NH-C06-425 |
| Pollock Wells | | Verdugo VPBs | |
| | PO-C01-195 | | VD-VPB-01 |
| | PO-C01-354 | | VD-VPB-02 |
| • | PO-C02-53 | | VD-VPB-03 |
| | PO-C02-205 | | VD-VPB-04 |
| | PO-C03-182 | | VD-VPB-05 |
| | PO-C03-235 | | VD-VPB-06 |
| | T | <u> </u> | |

VD-VPB-07

 M^{p_1}

RDD/R42/030.51 4-3

Table 4-2
San Fernando Valley Basin
Monitoring Wells Included in Annual Sampling Event

| Well Site | Well Name | Well Site | Well Name | | |
|----------------------|-------------|--------------|-----------|--|--|
| North Hollywood VPBs | | Pollock VPBs | | | |
| · | NH-VPB-01 | | PO-VPB-01 | | |
| | NH-VPB-02 | | PO-VPB-02 | | |
| | NH-VPB-03 | | PO-VPB-03 | | |
| | NH-VPB-04 | | PO-VPB-04 | | |
| | NH-VPB-05 | | PO-VPB-05 | | |
| | NH-VPB-06 | | PO-VPB-06 | | |
| | NH-VPB-07 | | PO-VPB-07 | | |
| | NH-VPB-08 | | PO-VPB-08 | | |
| · | NH-VPB-09 | | PO-VPB-09 | | |
| | NH-VPB-10 | | PO-VPB-10 | | |
| | NH-VPB-11 | • | PO-VPB-11 | | |
| | NH-VPB-12 | | | | |
| | NH-VPB-13 | | | | |
| | NH-VPB-14 | | | | |
| Crystal Springs VPBs | | | | | |
| | CS-VPB-01 | | | | |
| | CS-VPB-02 | | | | |
| | CS-VPB-03 | | · | | |
| | CS-VPB-04 | | | | |
| | CS-VPB-05 | | | | |
| | CS-VPB-06 | | | | |
| | CS-VPB-07 | | | | |
| | CS-VPB-08 | | | | |
| | CS-VPB-09 | | | | |
| | CS-VPB-10 | | | | |
| | CS-VPB-11 | | | | |

RDD/R42/030.51 4-4

quarterly sampling of a well currently recommended to be sampled annually may be warranted if contaminant concentrations increase above MCLs, and wells with nondetectable concentrations of VOCs may be removed from the sampling program.

RATIONALE FOR NUMBER OF SAMPLES

Groundwater samples will be collected quarterly and annually, to monitor water quality. During the quarterly sampling events, 41 field groundwater samples will be collected, and 87 field groundwater samples will be collected during annual sampling events.

In addition to field groundwater samples mentioned above, field QA samples will be collected in the form of field duplicates, field blanks, and lab QC double volume samples. The purpose of the field QA samples is explained in the following paragraphs. The type of field QA samples to be collected are identified by well location and sampling day for quarterly events and annual events in Tables 5-2 and 5-3, respectively.

At a minimum, one field duplicate sample will be collected for each analysis for every 10 wells sampled. The field duplicate will be collected to check the precision of the field and laboratory procedures. A total of 5 field duplicates from 41 wells will be collected for all analytes under investigation during each quarterly sampling event. A total of 9 field duplicates from 87 wells will be collected for all analytes under investigation during the annual sampling event.

Field blank samples will be collected to check for the possible cross contamination of groundwater samples from the point of sample collection to the analysis of the samples by the laboratory. One field blank sample will be collected for all analytes in the field at the first sampling location each day. A total of approximately eight field blank samples (eight sampling days) will be collected during each quarterly sampling event. A total of approximately 16 field blank samples (16 sampling days) will be collected during the annual sampling event.

Lab QC double volume samples will be collected for all analyses during both quarterly and annual events. One lab QC double volume sample will be collected for every 20 samples collected. A total of three lab QC double volume samples will be collected during each quarterly sampling event. A total of five lab QC double volume samples will be collected during each annual sampling event.

With the inclusion of field quality assurance samples, 57 and 118 water samples will be collected during quarterly and annual sampling counts, respectively. The following is a summary of the number of samples that will be submitted to the CLP for laboratory analyses.

Quarterly Sampling Events

- 41 Field groundwater samples
- 5 Duplicate samples
- 8 Field blanks
- 3 Double volume lab QC samples
- 57 Quarterly Event Total

Annual Sampling Event

- Field groundwater samples
- 9 Duplicate samples
- 17 Field blanks
- 5 Double-volume lab QC samples
- 118 Annual Event Total

SELECTION OF ANALYTICAL PARAMETERS

The selection of analytical parameters for groundwater is based on land use and existing groundwater data. VOCs, metals, and nitrates have been detected above MCLs in the groundwater at the SFVB site. Land use in the area includes or has included industry and manufacturing. The potential exists for contamination from chlorinated solvents, fuels, paint solvents, and metals. Several other parameters will be tested for evaluating treatment alternatives. These include chloride, sulfate, fluoride, alkalinity, bicarbonate, carbonate, TDS, TOC, and hardness. Analysis for N-nitrate/nitrite, radon, and gross alpha and beta radioactivity will be performed to assess what degree of blending may be needed to lower the concentration of nitrates and radionuclides to below MCLs such that groundwater from the basin can be delivered as drinking water after VOCs have been removed.

The analytical parameters during quarterly sampling events will consist of VOCs and N-nitrate/nitrite. A lower detection limit will be required for the analysis of samples for VOCs using CLP protocols. A detection limit lower than that described in the CLP statement of work is required since the action levels associated with many of the VOCs in California are lower than the detection limits associated with CLP protocols. Table 4-3 lists the California and Federal Action Levels for the parameters being analyzed. Quarterly information on N-nitrate/nitrite will establish background levels and groundwater treatment objectives.

The analytical parameters during the annual sampling event will consist of VOCs, semivolatiles, metals, radon, gross alpha and beta radioactivity, and the general chemistry water treatment analyses described earlier. The analytical parameters selected will be reviewed periodically and may be modified based on the results obtained from these chemical analyses.

Table 4-3
EPA and California Primary Maximum Contaminant Levels and
California State Action Levels for Selected Organic Compounds,
Metals, and Inorganic Compounds in Drinking Water
(July 1990)

| (July 1990) Environmental Protection | | | | | | |
|---------------------------------------|-------------|-------------------------|--|--------------|-----------------------|--|
| | Age | | California Department of Health Services | | | |
| Constituent | Current MCL | Proposed MCL | Current MCL | Proposed MCL | Action Level (SAL) | |
| VOLATILE ORGANICS (μ | g/l) | | | | | |
| Benzene | 5.0 | | 1.0 | | · <u></u> | |
| Carbon tetrachloride | 5.0 | | 0.5 | | | |
| Chlorobenzene | | 100 | 30 | | | |
| 1,1-Dichloroethane | | | 5.0 | | 5.0 | |
| 1,2-Dichloroethane | 5.0 | | 0.5 | | | |
| 1.1-Dichloroethene | 7.0 | | 6.0 | | | |
| cis-1,2-Dichloroethene | | 70 | 6.0 | | 6.0 | |
| trans-1,2-Dichloroethene | | 100 | 10.0 | | 10 | |
| 1,3-Dichloropropene | | | 0.5 | | | |
| Methylene chloride | | 5 | | | 40 | |
| 1,1,2,2-Tetrachloroethane | | | 1.0 | | | |
| Perchloroethene | | 5.0 | 5.0 | | | |
| Total THMs | 100 | | 100 | | , | |
| Toluene | | 2.000 | | | 100 | |
| 1,1,1-Trichloroethane | 200 | | 200 | | | |
| 1,1,2-Trichloroethane | | 5 | 32 | | | |
| Trichloroethene | 5.0 | | 5.0 | | •• | |
| SEMIVOLATILE ORGANI | CS (μg/l) | | | | | |
| 1,3-Dichlorobenzene | | | | | 130 | |
| 1,4-Dichlorobenzene | 75 | | 5.0 | | | |
| Pentachlorophenol | | 200 | | | 30 | |
| METALS (mg/l) | | | | | | |
| Aluminum | | | | | _ | |
| Antimony | | 0.01/0.005 ^a | | | | |
| Arsenic | 0.05 | | 0.05 | | | |
| Beryllium | | 0.001 | | | ; | |
| Cadmium | 0.01 | 0.005 | 0.01 | | | |
| Chromium | 0.05 | 0.1 | 0.05 | | | |

RDD/R42/030.51 4-7

Table 4-3
EPA and California Primary Maximum Contaminant Levels and
California State Action Levels for Selected Organic Compounds,
Metals, and Inorganic Compounds in Drinking Water
(July 1990)

| | Environmental Protection Agency | | California Department of Health Services | | |
|-------------------------------|------------------------------------|-----------------|--|--------------|-----------------------|
| Constituent | Current MCL | Proposed MCL | Current MCL | Proposed MCL | Action Level (SAL) |
| Copper ^b | 1.0 | 1.3 | 1.0 | | |
| Lead ^C | 0.05 | 0.005/0.01 | 0.05 | | |
| Mercury | 0.002 | 0.002 | 0.002 | | |
| Nickel | | 0.1 | | | |
| Selenium | 0.01 | 0.05 | 0.01 | | |
| Zinc ^b | 5 | | 5 | | |
| INORGANICS (mg/i) | | | | | |
| Nitrate (as NO ₃) | 45 | | 45 | | |

^aTwo options proposed July 25, 1990.

Note: -- Indicates no MCL or state action level has been promulgated or proposed, or the action level has been superseded by a current state MCL.

^bSecondary standard.

^cLead proposed MCL: 0.005 mg/l at the source; ≤0.01 mg/l at the tap.

Section 5 REQUEST FOR ANALYSES

INTRODUCTION

This section presents information necessary to obtain laboratory space through the Contract Laboratory Program (CLP). Described are the analytical parameters and analytical methods to be used, the number of samples to be collected, estimated sampling dates, anticipated sample concentrations, sample containers, methods of preservation, and analytical holding times.

QUARTERLY AND ANNUAL SAMPLING EVENTS

GROUNDWATER SAMPLES

Over the course of each calendar year, four groundwater sampling events will be completed as part of the Basinwide monitoring program: three quarterly sampling events and one annual sampling event. Quarterly sampling events are scheduled to begin during the last weeks of January, July, and October of each year and are anticipated to last for approximately 10 consecutive days. Annual sampling events are scheduled for the last week of April of each year and are anticipated to last approximately 24 consecutive days. The annual sampling event will be composed of two 10-day work shifts with a 4-day break between work shifts.

The analyses requested for the groundwater samples collected during quarterly and annual sampling events differ somewhat based on the data needs of the project. Table 5-1 summarizes the analytical parameters, methods, and requested detection limits for the analyses requested for the Basinwide monitoring program. The analytical and quality control information for parameters not covered under the CLP statements of work for organics or inorganics have been extracted from the Region IX Special Analytical Services (SAS) Compendium and are found in Appendix C. The following is a summary of the requested analyses for quarterly and annual sampling events:

Quarterly Sampling Events

- -- Routine Analytical Services (RAS) plus SAS analyses are requested for the analysis of groundwater samples for VOCs using CLP protocols that have been modified to attain detection limits less than 1 μg/l.
- -- SAS procedures are requested for the analysis of groundwater samples for nitrogen as nitrate/nitrite.

RDD/R10/019.51 5-1

Table 5-1 Groundwater Samples, Analytical Parameters, Methods, and Detection Limits

| Parameter | Method | Target Detection Limit ^a |
|-------------------------------------|--|-------------------------------------|
| TCL Volatiles | CLP ^b /SAS ^c | CLP ^b /SAS ^c |
| TCL Semivolatiles | CLPb | CLPb |
| TAL Metals | CLP ^b | CLPb |
| Chloride | 300.0 ^{d,e} or 325.3 ^{d,e} | 5 mg/l |
| Sulfate | 300.0, 375.4 ^{d,c} or 375.2 ^{d,e} | 5 mg/l |
| Bicarbonate | 403 ^g | 2.20 mg/l |
| Carbonate | 403 ^g | 2.20 mg/l |
| Nitrate+Nitrite | 300.0 ^{d,e} , 353.2 ^{d,e} , or 353.3 ^{d,e} | 0.1 mg/l |
| Fluoride | 340.2 ^{d,e} , or 340.3 ^{d,e} , or 340.1 ^{d,e} | 0.1 mg/l |
| Hardness | 130.2 ^{d,e} | 5 mg/CaCO ₃ /l |
| Total Dissolved Solids | 160.1 ^{d,e} | 3 mg/l |
| Total Organic Carbon | 415.1 ^{d,e} | 2 mg/l |
| Radon | EPA 600/2-87-082 ^f | 100 piC/l |
| Gross Alpha/Beta Radio- activity | EPA 900.0 | |

^aThese are target values; actual limits depend on nature of the specific matrix and will be reported.

• Annual Sampling Events

-- RAS plus SAS procedures are requested for the analysis of groundwater samples for VOCs using CLP protocols capable of attaining detection limits less than 1 µg/l.

^bCLP procedures and QC control limits are defined in EPA contracts 1FBs WA.85.J664/J680 and WP-85-J838/J839 or in the latest EPA contracts.

^cLower detection limits than CLP limits to be requested. Carbon tetrachloride at 0.5 ppb; others at 1 or 2 ppb detection limit as specified in Appendix A.

^dProcedure given in Appendix A; methods listed in order of preference.

^eEPA. 1979. Methods for Chemical Analysis of Water and Wastes, EPA-600/4-79-020, revised March 1983.

^fEPA. September 1987. EPA/600/2-87-082. Appendix B: The Determination of Radon in Drinking Water by Liquid Scintillation, p. 22. Appendix D: Analytical Test Procedure, Radon/Water Concentration Analysis of Grab Samples Using Lucas Scintillation Cell Detection, p. 27.

^gAmerican Public Health Association. 1985. Standard Methods for the Examination of Water and Wastewater. 16th Edition.

- -- RAS procedures are requested for the analysis of groundwater samples for semivolatiles and metals.
- -- SAS procedures are requested for the analysis of groundwater samples for inorganic treatment parameters including nitrate/nitrite, chloride, sulfate, bicarbonate, carbonate, fluoride, hardness, total dissolved solids, and total organic carbon.
- -- SAS procedures are requested for the analysis of groundwater samples for radionuclides including radon, gross alpha, and gross beta.

During quarterly sampling events, approximately 57 water samples including field quality assurance samples will be collected for RAS plus SAS analyses for VOCs, and SAS analyses for nitrogen as nitrate/nitrite.

During annual sampling events, approximately 118 water samples including field quality assurance samples will be collected as follows:

- 118 RAS semivolatile analyses, does not include trip blanks
- 118 RAS metals analyses, does not include trip blanks or double volume lab QC samples
- 118 RAS plus SAS VOC analyses, includes all required field QA samples
- 118 SAS inorganic treatment parameter analyses, does not include trip blanks
- 118 SAS radon analyses, does not include trip blanks and double volume lab QC samples
- 118 SAS gross alpha and gross beta analyses, does not include trip blanks and double volume lab QC samples

Tables 5-2 and 5-3 summarize all of the groundwater samples and field quality assurance samples that will be collected during quarterly and annual sampling events, respectively.

Table 5-2 Request for Analysis--Quarterly Sampling Events (matrix = water)

| | | | | · · · · · · · · · · · · · · · · · · · | | |
|--------------------|------------------------------------|-----------------------|---------------|---|--|-------------------------------|
| CLP Analysis | Requested: | | | RAS and SAS | SAS | |
| Specific Analys | sis Requested: | | | VOCs | Nitrate + Nitrite | |
| Preservatives: | | | | Add two drops 1:1 HCl; chill to 4°C | Cool, 4°C, H ₂ SO ₄ to pH <2 | |
| Analytical Hol | ding Time: | | | Hold <14 days | Hold <28 days | |
| Contract Hold | ing Time: | | | Hold <10 days | Hold to <25 days | |
| Sample Location | Sample Schedule (sample day) | Field QA Sample | Concentration | (No. bottles/analysis) (3x40-ml glass vial) | (No. bottles/analysis) (1x250 ml) polyethylene bottle) | No. Containers per Well |
| NH-C01-325 | 1 | В | Low | 2 | 2 | 8 |
| NH-VPB-07 | 1 | D | Low | 2 | 2 | 8 |
| NH-C03-580 | 1 | | Low | 1 | 1 | 4 |
| NH-VPB-09 | 1 | | Low | 1 | 1 | 4 |
| NH-VPB-06 | 1 | | Low | 1 . | 1 | 4 |
| Subtotal | | | | 7 | 7 | 28 |
| NH-VPB-08 | 2 | В | Low | 2 | 2 | 8 |
| NH-VPB-05 | 2 | | Low | 1 | 1 | 4 |
| NH-C02-325 | 2 | L | Low | 2 | 2 | 8 |
| NH-C02-220 | 2 | | Low | 1 | 1 | 4 |
| NH-C06-160 | 2 | | Low | 1 | 1 | 4 |
| Subtotal | | | | 7 | 7 | 28 |
| NH-VPB-14 | 3 | B,D | Low | 3 | 3 | 12 |
| NH-C04-240 | 3 | | Low | 1 | -1 | 4 |
| NH-VPB-01 | 3 | | Low | 1 | 1 | 4 |
| CS-C01-105 | 3 | : | Low | 1 | 1 | 4 |
| CS-C01-285 | 3 | | Low | 1 | 1 | 4 |
| Subtotal | - | | | 7 | 7 | 28 |
| CS-C02-62 | 4 | L,B | . Low | 3 | 3 | 12 |
| CS-C02-180 | 4 | | Low | 1 | 1 | 4 |
| CS-C02-250 | 4 | | Low | . 1 | - 1 | 4 |
| CS-C02-335 | 4 | | Low | 1 | 1 | 4 |
| CS-VPB-02 | 4 | | Low | 1 | 1 | 4 |
| Subtotal | | | | 7 | 7 | . 28 |
| CS-VPB-01 | 5 | В | Low | 2 | 2 | 8 |
| CS-VPB-08 | 5 | | Low | 1 | 1 | 4 |
| CS-VPB-05 | 5 | D | Low | 2 | 2 | 8 |

Table 5-2 Request for Analysis--Quarterly Sampling Events (matrix = water)

| <u> </u> | | | (1114111) | - "atery | | |
|--------------------|------------------------------------|-----------------------|---------------|---|--|-------------------------------|
| CLP Analysis | Requested: | | | RAS and SAS | SAS | |
| Specific Analys | sis Requested: | | | VOCs | Nitrate + Nitrite | |
| Preservatives: | | | | Add two drops 1:1 HCl; chill to 4°C | Cool, 4°C, H ₂ SO ₄ to pH <2 | |
| Analytical Hole | ding Time: | | | Hold <14 days | Hold <28 days | |
| Contract Hold | ing Time: | | | Hold <10 days | Hold to <25 days | |
| Sample Location | Sample Schedule (sample day) | Field QA Sample | Concentration | (No. bottles/analysis) (3x40-ml glass vial) | (No. bottles/analysis) (1x250 ml) polyethylene bottle) | No. Containers per Well |
| CS-C05-160 | 5 | | Low | 1 | 1 | 4 |
| CS-C05-290 | 5 | | Low | 1 | 1 | 4 |
| Subtotal | | | | 7 | 7 | 28 |
| CS-VPB-07 | 6 | D, B | Low | 3 | 3 | 12 |
| CS-C03-100 | 6 | | Low | 1 | 1 | 4 |
| CS-VPB-04 | 6 | | Low | 1 | 1 | 4 |
| CS-C04-290 | 6 | | Low | 1 | 1 | 4 |
| CS-C04-382 | 6 | | Low | 1 | 1 | 4 |
| Subtotal | | | | 7 | 7 | 28 |
| CS-VPB-11 | 7 | В | Low | 2 | 2 | 8 |
| CS-VPB-06 | 7 | | Low | 1 | 1 | 4 |
| CS-VPB-10 | 7 | | Low | 1 | 1 | 4 |
| PO-VPB-02 | 7 | D | Low | 2 | 2 | 8 |
| PO-C02-53 | 7 | | Low | 1 | 1 | 4 |
| PO-VPB-01 | 7 | | Low | 1 | 1 | 4 |
| Subtotal | | | | 8 | 8 | 32 |
| PO-VPB-03 | 8 | В | Low | 2 | 2 | 8 |
| PO-C03-182 | 8 | | Low | 1 | 1 | 4 |
| PO-VPB-07 | 8 | L | Low | 2 | 2 | 8 |
| PO-VPB-04 | 8 | | Low | 1 | 1 | 4 |
| PO-VPB-08 | 8 | | Low | 1 | 1 | 4 |
| Subtotal | | | | 7 | 7 | 28 |
| | | | | | | |
| Total | | | | 57 | 57 | 228 |
| | | | | | | |

B = Field blank sample: taken at the first sample location every day for all parameters.

D = Field duplicate sample: taken once every 10 samples for all parameters.

L = Laboratory QC sample: taken once every 20 total samples (including blanks and duplicates) for all parameters.

Sheet I of 9

| CLP Analysis R | equested: | | | R.A | <u>us</u> | RAS + SAS | <u> </u> | | | SAS | | | | |
|--------------------|---------------------------------------|--------------------|---------------|--|--|---|-----------------------------------|--|------------------------------|---|---|---|---|-------------------------------|
| Specific Analysi | n Requested: | | | Semivolatiles | Metals | Low Detection LimitVOCs | Chloride, Sulfate, Fluoride | Alkalinity, Bicarbonate, Carbonate | Total Dissolved Solids | Total Organic Carbon ^a Nitrate + Nitrite | Hardness | ļ | Gross Alpha and Beta Radioactivity | |
| Preservatives: | | | | Chill to 4°C | Filter, chili to 4°C, add HNO ₃ to pH <2 | Add two drops 1:1 HCl; chill to 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C, H ₂ SO ₄ to pH <2 | Cool, 4°C, HNO3 to pH <2 | | Cool 4°C, HNO ₃ to pH <2 | |
| Analytical Hold | ing Time: | · | | Hold <7 days prior to extraction; 40 days after extraction | Hold to <6 months (28 days for mercury) | | Hold <28 days | | Hold <7 days | Hold <28 days | Hold <6 months | Hold <2 days | Hold <6 months | |
| Contract Holdiz | ng Time: | | | | Hold to <6 months (26 days for mercury) | | Hold <25 days | Hold <12 days | Hold <5 days | Hold <25 days | Hold <6 months | immediate analysis | | |
| Sample Location | Sample Schedule (sample day) | Field QA Sample | Concentration | (No. bottles/analysis) (2xl-lifer amber glass) | (No. bottles/analysis) (1x1-liter polyethylene bottle) | (No. bottles/ analysis) (3x40-mi glass viai) | | | | (No. bottles/ analysis) (500-ml polyethylene bottle) | (No. bottles/analysis) (250-ml polyethylene bottle) | (No. bottles/ analysis) (2x20-ml vials, prefliled with scintillation mix) | (No. bottles/ analysis) (1x1-liter polyethylene bottle) | No. Containers per Well |
| NH-VPB-13 | 1 | В | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| NH-VPB-11 | 1 | | Low | 1 | 1 | . 1 | | 1 | | 1 | 1 | l | 1 | 12 |
| NH-C05-320 | 1 | | Low | 1 | 1 | 1 | | 1 | | 1 | i | L | 1 | 12 |
| NH-C05-460 | 1 | | Low | 1 | - 1 | 1 | | 1 | | 1 | 1 | 1 | 1 | 12 |
| NH-VPB-06 | 1 | | 1.ow | 1 | 1 | 1 | | 1 | | l l | ı | l | ı | 12 |
| Daily Subtotal | | | | 6 | 6 | 6 | <u> </u> | 6 | | 6 | 6 | 6 | 6 | 72 |
| NH-VPB-09 | 2 | В | Low | 2 | 2 | 2 | <u> </u> | 2 | | 2 | 2 | 2 | 2 | 24 |
| NH-VPB-10 | 2 | | Low | 1 | 1 | 1 | | 1 | • • • | 1 | ı | ı | ı | 12 |
| NH-C01-325 | 2 | D | Low | 2 | 2 . | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| N11-C01-323 | | | Low | 1 | 1 | 1 | | 1 | | ı | l | ı | 1 | .12 |
| NH-C01-450 | 2 | | | | 7 | | | 1 | | 1 | l ï | 1 | 1 | 12 |
| | 2 | | Low | l l | 11 | 1 | I | | | | | | | |
| NH-C01-450 | | | Low Low | 1 1 | 1 | 1 | | 1 | | 1 | 1 | ı | 1 | 12 |

Sheet 2 of

| CLP Analysis R | tequested: | | | R/ | <u> </u> | RAS + SAS | | | | SAS | | | | |
|--------------------|---------------------------------------|--------------------|---------------|---|--|---|-----------------------------------|--|------------------------------|---|---|---|---|-------------------------------|
| Specific Analysi | s Requested: | | | | Metals | Low Detection LimitVOCs | Chioride, Sulfate, Fluoride | Alkelinity, Bicarbonate, Carbonate | Total Dissolved Solids | Total Organic Carbon ^a Nitrate + Nitrite | Hardness | Radon | Gross Alpha and Beta Radioactivity | |
| Preservatives: | | | | Chill to 4°C | Filier, chill to 4°C, add HNO ₃ to pH <2 | Add two drops i:l HCl; chill to 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C, H ₂ SO ₄ to pH <2 | Cool, 4°C, HNO ₃ to pH <2 | | Cool 4°C, HNO ₃ to pH <2 | |
| Analytical Hold | ing Time: | | | Hold <7 days prior to extraction; 40 days after extraction | Hold to <6 months (28 days for mercury) | | Hold < 28 days | Hold <14 days | Hold <7 days | Hold < 28 days | Hold <6 months | Hold <2 days | Hold <6 months | |
| Contract Holdin | ng Time: | | | Hold <5 days prior to extraction; 40 days Hold to <6 months (26 days for mercury) Hold <10 days | | | | | | Hold < 25 days | Hold <6 months | immediate analysis | | |
| Sample Location | Sample Schedule (sample day) | Field QA Sample | Concentration | (No. hottles/analysis) (2xi-lifer amber glass) | (No. bottles/analysis) (1x1-liter polyethylene bottle) | (No. bottles/ analysis) (3x40-mi glass viai) | | (No. bottles/anal | | (No. bottles/ analysis) (500-ml polyethylene bottle) | (No. bottles/analysis) (250-ml polyethylene bottle) | (No. bottles/ analysis) (2x20-ml vials, prefilled with scintillation mix) | (No. bottles/ analysis) (1x1-liter polyethylene bottle) | No. Containers per Well |
| NH-VPB-07 | 3 | В | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| NH-VPB-02 | 3 | | Low | ı i | 1 | 1 | | 1 | | ı | 1 | 1 | l | 12 |
| NH-C03-380 | 3 | | Low | 1 | 1 | 1 | | ı | | 1 | ĩ | ı | ı | 12 |
| NH-C03-580 | 3 | | Low | 1 | 1 . | 1 | | 1 | | 1 | ı | I | i | 12 |
| NH-C03-680 | 3 | | Low | i | 1 | 1 | | 1 | | - 1 | 1 | ı | l | 12 |
| NH-C03-800 | 3 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | l l | 12 |
| Daily Subtotal | | | | 7 | 7 | 7 | | 7 | | 7 | 7 | 7 | 7 | 84 |
| <u> </u> | | | | | | | | | | | · · · · · · · · · · · · · · · · · · · | | | |
| NH-VPB-08 | 4 | В | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| NH-VPB-05 | 4 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | l l | l l | 12 |
| NH-C02-220 | 4 | L | Low | 1 | 11 | 1 | | 1 | | 1 | 1 , | 1 | t | 12 |
| NH-C02-325 | 4 | L | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| NH-C02-520 | 4 | | Low | 1 | 1 | l l | | 1 | | 1 | 2 | 2 | 1 | 12 |
| NH-C02-681 | 4 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | 1 | 12 |
| Daily Subtotal | | | | 8 | 8 | 8 | | 8 | | 8 | 8 | 8 | 8 | 96 |
| | | | | | | | | | | | | | | |

Sheet 3 of 9

| | | | | | | | | | | | | | | DIRECT 3 0, 7 |
|--------------------|---------------------------------------|--------------------|--|---|--|---|-----------------------------------|--|------------------------------|---|---|---|---|-------------------------------|
| CLP Analysis R | | | | R/ | | RAS + SAS | | | | SAS | j | | | |
| Specific Amalysi | s Requested: | | | Semivolatiles | Metala | Low Detection LimitVOCs | Chioride, Sulfate, Finoride | Alkalinity, Bicarbonate, Carbonate | Total Dissolved Solids | Total Organic Carbon ^a Nitrate + Nitrite | Hardness | Radon | Gross Alpha and Beta Radioactivity | |
| Preservatives: | | | | Chill to 4°C | Filter, chill to 4°C, add HNO3 to pH <2 | Add two drops 1:1 HCl; chill to 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C, H ₂ SO ₄ to pH <2 | Cool, 4°C, HNO ₃ to pH <2 | See appended procedure | Cool 4°C, HNO ₃ to pH <2 | } |
| Analytical Holdi | ing Time: | | Hold <7 days prior to extraction; 40 days Hold to <6 months after extraction (28 days for mercury) Hold <14 days Hold <5 days prior to extraction; 40 days Hold to <6 months Hold <5 days Prior to extraction; 40 days Hold to <6 months | | | | | fiold <7 days | Hold < 28 days | Hold <6 months | iloid <2 days | Hold <6 months | | |
| Contract Holdin | ng Time: | | | extraction; 40 days | Hold to <6 months (26 days for mercury) | Hold <10 days | | Hold <12 days | Hold <5 days | Hold < 25 days | Hold <6 months | Immediate analysis | | |
| Sample Location | Sample Schedule (sample day) | Field QA Sample | Concentration | (No. bottles/analysis) (2x1-liter amber glass) | (No. bottles/analysis) (1x1-liter polyethylene bottle) | (No. bottles/ analysis) (3x40-ml glass vial) | | (No. bottles/anal | | (No. bottles/ analysis) (500-ml polyethylene bottle) | (No. bottles/analysis) (250-ml polyethylene bottle) | (No. bottles/ analysis) (2x20-ml vials, prefilled with scintillation mix) | (No. bottles/ nnalysis) (1xt-liter polyethylene bottle) | No. Containers per Weil |
| NH-VPB-03 | 5 | В | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| NH-VPB-04 | 5 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | 1 | 12 |
| NH-C06-160 | 5 | | Low | 1 | 1 | . 1 | | 1 | | 1 | 1 | l | 1 | 12 |
| NH-C06-285 | 5 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | 1 | 12 |
| NH-C06-425 | 5 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | 1 | 12 |
| Daily Subtotal | | | | 6 | 6 | 6 | | 6 | | 6 | 6 | 6 | 6 | 72 |
| | | | | | | | | | | | | | | |
| NH-VPB-12 | 6 | В | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| NH-VPB-14 | 6 | Ð | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| NH-C04-240 | 6 | | Low | 1 | 1 | 1 | | 1 | | 1 | ı | l | 1 | 12 |
| NH-C04-375 | 6 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 . | 1 | 12 |
| NH-C04-560 | 6 | | Low | 1 | 1 | 1 | | 1 | ··· — | 1 | 1 | · 1 | 1 | 12 |
| Daily Subtotal | | | | 7 | 7 | 7 | | 7 | | 7 | 7 | 7 | 7 | 84 |
| | | | · <u>-</u> | | | | | | | | - | | | |

Sheet 4 of

| | | | | | | (- | matrix = w | | | | | | | Sheet 4 of 9 |
|--------------------|---------------------------------------|--------------------|---------------|--|--|---|-----------------------------------|---|------------------------------|---|---|---|---|-------------------------------|
| CLP Analysis R | | | | R/ | | RAS + SAS | | | | SAS | | | | |
| Specific Analysi | is Requested: | | | Semivolatiles | Metaks | Low Detection LimitVOCs | Chloride, Sulfate, Fluoride | | Total Dissolved Solids | Total Organic Carbon ^a Nitrate + Nitrite | Hardness | Radon | Gross Alpha and Beta Radioactivity | |
| Preservatives: | | | | Chill to 4°C | Filter, chill to 4°C, add HNO ₃ to pH <2 | Add two drops I:I HCl; chill to 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C, H ₂ SO ₄ to pH <2 | Cool, 4°C, HNO ₃ to pH <2 | See appended procedure | Cool 4°C, HNO ₃ , to pH <2 | |
| Analytical Hold | ling Time: | | | Hold <7 days prior to extraction; 40 days after extraction | Hold to <6 months (28 days for mercury) | Hold <14 days | Hold < 28 days | Hold <14 days | Hold <7 days | Hold <28 days | Hold <6 months | Hold <2 days | Hold <6 months | |
| Contract Holdin | ng Time: | | | | Hold to <6 months (26 days for mercury) | | Hold <25 days | Hold <12 days | Hold <5 days | Hold <25 days | Hold <6 months | immediate analysis | | |
| Sample Location | Sample Schedule (sample day) | Field QA Sample | Concentration | (No. bottles/analysis) (2xi-lifer amber glass) | (No. bottles/analysis) (1x1-liter polyethylene bottle) | (No. bottles/ analysis) (3x40-ml giasa vial) | | (No. bottles/analysis) (1x1-liter polyethylene bottle) | | (No. bottles/ analysis) (500-ml polyethylene bottle) | (No. bottles/analysis) (250-ml polyethylene bottle) | (No. bottles/ analysis) (2x20-ml vials, prefilled with scintillation mix) | (No. bottles/ analysis) (1x1-liter polyethylene bottle) | No. Containers per Well |
| NH-VPB-01 | 7 | B,D | Low | 3 | 3 | 3 | | 3 | | 3 | 3 | 3 | 3 | 36 |
| CS-C01-105 | 7 | L | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| CS-C01-285 | 7 | D | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| CS-C01-558 | 7 | | Low | 1 | 1 | 1 | | 1 | | 1 | l l | 1 | 1 | 12 |
| CS-VPB-02 | 7 | | Low | 11 | 1 | 1 | | 1 | | 1 | 1 | ı | 1 | 12 |
| Daily Subtotal | | | | 9 | 9 | 9 | | 9 | | 9 | 9 | 9 | 9 | 108 |
| | | | | | | | | | | | | | | |
| CS-VPB-01 | 8 | В | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| CS-C02-62 | 8 | D | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| CS-C02-180 | 8 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 11 | 1 | 12 |
| CS-C02-250 | 8 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | , 1 | 1 | 12 |
| CS-C02-335 | 8 | | Low | 1 | 1 | 1 | <u> </u> | 1 . | | 1 | 1 | l | l . | 12 |
| | y Subtotal | | | 7 | 7 | 7 | | 7 | | 7 | 7 | 7 | 7 | 84 |

Sheet 5 of 9

| CLP Analysis R | lequested: | | | R/ | ıs | RAS + SAS | | | | SAS | - | | | |
|--------------------|---------------------------------------|--------------------|---------------|--|--|---|-----------------------------------|--|------------------------------|---|---|---|---|-------------------------------|
| Specific Analysi | is Requested: | | | Semivolatiles | Metals | Low Detection | Chloride, Sulfate, Fluoride | Alkalinity, Bicarbonate, Carbonate | Total Dissolved Solids | Total Organic Carbon ^a Nitrate + Nitrite | Hardness | Radon | Gross Alpha and Beta Radioactivity | |
| Preservatives: | | | | Chill to 4°C | Filter, chill to 4°C, add HNO ₃ to pH <2 | Add two drops I:i HCl; chill to 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C, H ₂ SO ₄ to pH <2 | Cool, 4°C, HNO ₃ to pH <2 | See appended procedure | Cool 4°C, HNO ₃ to pH <2 | |
| Analytical Hold | ling Time: | · | | Hold <7 days prior to extraction; 40 days after extraction | Hold to <6 months (28 days for mercury) | Hold <14 days | Hold <28 days | Hold <14 days | Hold <7 days | Hold < 28 days | Hold <6 months | Hold <2 days | Hold <6 months | |
| Contract Holdin | ng Time: | | | | Hold to <6 months (26 days for mercury) | Hold <10 days | Hold <25 days | Hold <12 days | Hold <5 days | Hold <25 days | Hold <6 months | lmmediate analysis | | |
| Sample Location | Sample Schedule (sample day) | Field QA Sample | Concentration | (No. bottles/analysis) (2x1-liter amber glass) | (No. bottles/analysis) (Exi-liter polyethylene bottle) | (No. bottles/ analysis) (3x40-mi glass vial) | | (No. bottles/anal | | (No. bottles/ analysis) (500-ml polyethylene bottle) | (No. bottles/analysis) (250-ml polyethylene bottle) | (No. bottles/ analysis) (2x20-ml vials, prefliled with scintillation mix) | (No. bottles/ analysis) (ixi-liter polyethylene buttle) | No. Containers per Well |
| CS-VPB-03 | 9 | В | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| CS-VPB-08 | 9 | L | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| CS-VPB-05 | 9 | D | Low | 2 | . 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| CS-C05-160 | 9 | | Low. | 1 | ı | 1 | | 1 | | 1 | 1 | 1 | 1 | 12 |
| CS-C05-290 | 9 | | Low | ı | ı | 1 | | 1 | | ì | i | ı | l | 12 |
| Daily Subtotal | | | | 8 | 8 | 8 | | 8 | | 8 | 8 | 8 | 8 | 96 |
| | | | | | . <u> </u> | | | | | | | | | |
| CS-VPB-07 | 10 | В | Low | 2 | 2 . | 2 | <u> </u> | 2 | | 2 | 2 | 2 | 2 | 24 |
| CS-C03-100 | 10 | D | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| CS-C03-325 | 10 | | Low | 1 | 1 | 1 | l | 1 | | 1 | 1 | ı i | 1 | 12 |
| CS-C03-465 | 10 | | Low | 1 | 1 | 1 | | 1 | | i | 1 | 1 | 1 | 12 |
| CS-C03-550 | 10 | <u> </u> | Low | 1 | 1 | 1 | L | 1 | | i | 1 | 1 | 1 | 12 |
| Daily Subtotal | | | | 7 | 7 | 7 | <u> </u> | 7 | | 7 | 7 | 7 | 7 | 84 |
| | | | | | | | | | | | | | · | |
| | | | | | | | | | | | | | | |

| | | | | | | (1 | natrix = w | isci j | | | | | | Sheet 6 of |
|--------------------|---------------------------------------|--------------------|---------------|--|--|---|-----------------------------------|--|------------------------------|---|---|---|---|-------------------------------|
| CLP Analysis R | equested: | | | R/ | s | RAS + SAS | | | | SAS | | | | |
| Specific Analysi | s Requested: | | | Semivolatiles | Metaks | Low Detection LimitVOCs | Chloride, Sulfate, Fluoride | Aikalinity, Bicarbonate, Carbonate | Total Dissolved Solids | Total Organic Carbon ^a Nitrate + Nitrite | Hardness | Radon | Gross Alpha and Beta Radioactivity | |
| Preservatives: | | | | Chill to 4°C | Filter, chill to 4°C, add HNO ₃ to pH <2 | Add two drope 1:1 HCl; chill to 4°C | Cool, 4°C | Cool, 4°C | Coot, 4°C | Cool, 4°C, H_2SO_4 to pH <2 | Cool, 4°C, HNO ₃ to pH <2 | | Cool 4°C, HNO ₃ to pH <2 | |
| Analytical Holdi | ing Time: | | | Hold <7 days prior to extraction; 40 days after extraction | Hold to <6 months (28 days for mercury) | | Hold <28 days | Hold <14 days | Hold <7 days | Hold <28 days | Hold <6 months | Hold <2 days | Hold <6 months | |
| Contract Holdin | niract Holding Time: Sample Schedule | | | Hold <5 days prior to extraction; 40 days after extraction | Hold to <6 months (26 days for mercury) | | Hold <25 days | Hold <12 days | Hold <5 days | Hold <25 days | Hold <6 months | lmmediate analysis | | |
| Sample Location | Sample Schedule (sample day) | Field QA Sample | Concentration | (No. bottles/analysis) (2x1-lifer amber glass) | (No. bottles/analysis) (1x1-liter polyethylene bottle) | (No. bottles/ analysis) (3x40-mi glass visi) | | (No. bottles/analysis) | | (No. bottles/ analysis) (500-ml polyethylene bottle) | (No. bottles/analysis) (250-ml polyethylene bottle) | (No. bottles/ analysis) (2x20-ml vials, prefilled with scintillation mix) | (No. bottles/ analysis) (1x1-liter polyethylene bottle) | No. Containers per Well |
| CS-C04-290 | 11 | В | Low | 2 | 2 | 2 | | 2 | | 2 | . 2 | 2 | 2 | 24 |
| CS-C04-382 | 11 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | ı | 12 |
| CS-C04-520 | 11 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | 1 | 12 |
| CS-VPB-04 | 11 | D | Low | 2 | 2 | 2 | | 2 | | 2 . | 2 | 2 | 2 | 24 |
| CS-VPB-09 | 11 | | Low | l | 1 | 1 | | L · | | 1 | 1 | 1 | 1 | 12 |
| Daily Subtotal | | | | 7 | 7 | 7 | <u> </u> | 7 | | 7 | 7 | 7 | 7 | 84 |
| | | | | , | | | | | | | | | | · |
| CS-VPB-11 | 12 | В | Low | 2 | . 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| CS-VPB-10 | 12 | | Low | 11 | 1 | 1 | <u> </u> | 1 | | 1 | 1 | 1 | 1 | 12 |
| CS-VPB-06 | 12 | L | Low | 2 | 2 | 2 | ļ | 2 | | 2 | 2 | 2 | 2 | 24 |
| CS-C06-185 | 12 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | I | 1 | 12 |
| CS-C06-278 | 12 | • | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | - 1 | .12 |
| Daily Subtotal | | | | 1 7 | 7 | 7 | 3 | 7 | | 7 | 7 | 7 | 7 | 84 |

Sheet 7 of 9

| | | | | | | | 7 | | | | | _ | | SLEET / DI |
|--------------------|---------------------------------------|--------------------|--|---------------|--|---|---|---|---|---|--|------------------------|--|-------------|
| CLP Analysis R | equested: | | | R.A | <u>s</u> | RAS + SAS | ـــــــ | | | SAS | <u>; </u> | | . | 1 |
| Specific Analysi | n Requested: | , | | Semivolatiles | | Low Detection LimitVOCs | Chloride, Sulfate, Fluoride | | Total Dissolved Solids | Total Organic Carbon ^a Nitrate + Nitrite | Hardness | Radon | Gross Alpha and Beta Radioactivity | |
| Preservatives: | | | | | Filter, chill to 4°C, add HNO ₃ to pH <2 | Add two drops 1:1 HCl; chill to 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C | | | See appended procedure | Cool 4°C, HNO ₃ to pH <2 | |
| Analytical Holdi | ing Time: | | | | Hold to <6 months (28 days for mercury) | | Hold <28 | Hold <14 days | Hold <7 days | Hold <28 days | Hold <6 months | Hold <2 days | Hold <6 months | |
| Contract Holdin | ng Time: | | | | Hold to <6 months (26 days for mercury) | Hold <10 days | Hold < 25 days | Hold <12 days | Hold <5 days | Hold <25 days | Hold <6 months | Immediate analysis | | |
| Sample Location | Sample Schedule (sample day) | Field QA Sample | cld QA (No. bottles/analysis) | | | (No. bottles/ analysis) (500-ml polyethylene bottle) | (No. bottles/analysis) (250-ml polyethylene bottle) | (No. bottles/ analysis) (2x20-ml vials, prefilled with scintillation mix) | (No. bottles/ analysis) (1x1-liter polyethylene bottle) | No. Containers per Well | | | | |
| VD-VPB-06 | 13 | В | Low | 2 | 2 . | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| VD-VPB-07 | 13 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | l | 12 |
| VD-VPB-01 | 13 | | Low | 1 | ı | 1 | | 1 | | 1 | 1 | ı | 1 | 12 |
| VD-VPB-05 | 13 | | Low | 1 | ı | 1 | | t | | l | 1 | l | 1 | 12 |
| VD-VPB-02 | 13 | | Low | 1 | 1 | 1 | <u> </u> | 11 | | 1 | 1 | 1 | 1 | 12 |
| Daily Subtotal | | | | 6 | 6 | 6 | <u></u> | 6 | | 6 | 6 | 6 | 6 | 72 |
| | | | | | | | , | | | | | | | |
| VD-VPB-04 | 14 | В | Low | 2 | 2 | 2 | <u> </u> | 2 . | | 2 | 2 | 2 | 2 | 24 |
| VD-VPB-03 | 14 | | . Low | 1 | 1 | 1 | <u> </u> | 1 | | 1 | 1 | 1 | 1 | 12 |
| PO-VPB-11 | 14 | | Low | 1 | 1 | 1 | ↓ | 1 | | 1 | 1 | 1 | 1 | 12 |
| PO-VPB-07 | 14 | | Low | 1 | 1 | 1 | 1 | | 1 | 1 | 1 | <u> </u> | 12 | |
| | 14 | 1 1 | Low |] 1 ' | 1 1 | 1 | 1 1 | | |) <u> </u> | 1 | 1 | 1 | 12 |
| PO-VPB-10 | <u> </u> | | | 6 | 6 | 6 | † | 6 | | 6 | 6 | | | |

| | | | · · · · · · · · · · · · · · · · · · · | | | (1 | natrix = w | | | | | | | Sheet 8 of 9 |
|--------------------|---------------------------------------|--------------------|---------------------------------------|---|--|---|-----------------------------------|--|------------------------------|---|---|---|---|-------------------------------|
| CLP Analysis R | equested: | | | R/ | ıs | RAS + SAS | | | | SAS | | | | |
| Specific Analysi | s Requested: | | | Semivolatiles | Metals | Low Detection LimitVOCs | Chloride, Sulfate, Finoride | Alkalinity, Bicarbonate, Carbonate | Total Dissolved Solids | Total Organic Carbon ^a Nitrate + Nitrite | Hardness | Radon | Gross Alpha and Beta Radioactivity | |
| Preservatives: | | | | Сыш ю 4℃ | Filter, chill to 4°C, add HNO ₃ to pH <2 | Add two drops 1:1 HCl; chill to 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C, H ₂ SO ₄ to pH <2 | Cool, 4°C, HNO ₃ to pH <2 | See appended procedure | Cool 4°C, HNO ₃ to pH <2 | |
| Analytical Hold | ing Time: | | | Hold <7 days prior to extraction; 40 days after extraction. | Hold to <6 months (28 days for mercury) | Hold <14 days | Hold < 28 days | Hold < 14 days | Hold <7 days | Hold <28 days | Hold <6 months | Hold <2 days | lioid <6 months | } |
| Contract Holdin | ng Time: | | | Hold <5 days prior to extraction; 40 days after extraction | Hold to <6 months (26 days for mercury) | Hold <10 days | Hold <25 days | Hold <12 days | Hold <5 days | Hold <25 days | Hold <6 months | Immediate analysis | • | |
| Sample Location | Sample Schedule (sample day) | Field QA Sample | Concentration | (No. bottles/analysis) (2xl-lifer amber glass) | (No. bottles/analysis) (1x1-liter polyethylene bottle) | (No. bottles/ analysis) (3x40-mi glass vial) | | (No. bottles/anal -liter polyethyler | | (No. bottles/ analysis) (500-ml polyethylene bottle) | (No. bottles/analysis) (250-mi polyethylene bottle) | (No. bottles/ analysis) (2x20-ml vials, prefilled with scintillation mix) | (No. bottles/ analysis) (1x1-liter polyethylene bottle) | No. Containers per Well |
| PO-VPB-02 | 15 | B, D | Low | 3 | 3 | 3 | | 3 | | 3 | 3 | 3 | 3 | 36 |
| PO-C01-195 | 15 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | i | 12 |
| PO-C01-354 | 15 | | Low | 1 | 1 | 1 | _ | 1 | | 1 | 1 | 1 | 1 | i2 |
| PO-C02-53 | 15 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | 1 | 12 |
| PO-C02-205 | 15 | | Low | 1 | 1 | 1 | | 1 | | l | i | 1 | 1 | 12 |
| Daily Subtotal | | | | 7 | 7 | 7 | <u> </u> | 7 | | 7 | 7 | 7 | 7 | 84 |
| | | | | | | | | | | | | | ···· | |
| PO-VPB-01 | 16 | В | Low | 2 | 1 | 2 | | 2 | | . 2 | 2 | 2 | 2 | 24 |
| PO-VPB-03 | 16 | L | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| PO-C03-182 | -16 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | 1 | 12 |
| PO-C03-235 | 16 | | Low | 11 | 1 | 1 | ļ | 1 | | 11 | 1 | 1 | 1 | 12 |
| | | | | I , | | 1 1 | I | 1 | | l 1 | I 1 | 1 1 | | 12 |
| PO-VPB-05 | 16 | L | Low | <u> </u> | <u>-</u> | <u> </u> | L | <u>.</u> | | | | | | └─ ─ |

Sheet 9 of 9

| CLP Analysis B | lequested: | | | R/ | IS | RAS + SAS | <u> </u> | | | SAS | | | | |
|--------------------|--|--------------------|---------------|---|--|---|-----------------------------------|--|------------------------------|---|---|---|---|-------------------------------|
| Specific Analysi | ls Requested: | 1 | · | Semivolatiles | Metals | Low Detection LimitVOCs | Chloride, Sulfate, Fluoride | Alkalinity, Bicarbonate, Carbonate | Total Dissolved Solids | Total Organic Carbon ⁸ Nitrate + Nitrite | Hardness | | Gross Alpha and Beta Radioactivity | |
| Preservatives: | | | | | Filter, chill to 4°C, add HNO ₃ to pH <2 | Add two drops 1:1 HCl; chill to 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C | Cool, 4°C, H ₂ SO ₄ to pH <2 | Cool, 4°C, HNO ₃ to pH <2 | | Cool 4°C, HNO ₃ to pH <2 | |
| Analytical Hold | Hold <7 days prior to extraction; 40 days Hold to <6 mx Analytical Holding Time: Hold <5 days prior to Hold <5 days Hold to <5 mx Ho | | | | | | Hold < 28 days | | Hold <7 days | Hold <28 days | Hold <6 months | lioid <2 days | Hold <6 months | |
| Contract Holdi | ng Time: | | | extraction; 40 days | Hold to <6 months (26 days for mercury) | | Hold <25 days | Hold <12 days | Hold <5 days | Hold <25 days | Hold <6 months | Immediate analysis | | |
| Sample Location | Sample Schedule (sample day) | Field QA Sample | Concentration | (No. bottles/analysis) (2xi-liter amber glass) | (No. bottles/analysis) (ixi-liter polyethylene bottle) | (No. bottles/ analysis) (3x40-mi giass vial) | | (No. bottles/anal | | (No. bottles/ analysis) (500-ml polyethylene bottle) | (No. bottles/analysis) (250-ml polyethylene bottle) | (No. bottles/ analysis) (2x20-mt vials, prefilled with scintillation mix) | (No. bottles/ analysis) (1x1-liter polyethylene bottle) | No. Containers per Well |
| PO-VPB-04 | 17 | В | Low | 2 | 2 | 2 | | 2 | | 2 | 2 | 2 | 2 | 24 |
| PO-VPB-09 | 17 | | Low. | . 1 | 1 | 1 | | 1 | | 1 | 1 | 1 | ı | 12 |
| PO-VPB-06 | 17 | | Low | ı | 1 | ì | | 1 | | 1 | 1 | 1 | 1 | 12 |
| PO-VPB-08 | 17 | | Low | 1 | 1 | 1 | | 1 | | 1 | 1 | ı | ı | 12 |
| Daily Subtotal | | | | 5 | 5 | 5 | | 5 | | 5 | 5 | 5 | 5 | 60 |
| Total | | | | 118 | 118 | 118 | Ι | 118 | | 118 | 118 | 118 | 118 | 1,416 |

a TOC = Total organic carbon (no head space).

T = Field blank sample: Taken at the first sample location every day for all parameters.

D = Field duplicate sample: Taken once every 10 samples for all parameters.

L = Laboratory QC sample: Taken once every 20 samples for all parameters.

Section 6 METHODS AND PROCEDURES

The procedures for collecting groundwater and potentially hazardous investigation-derived solid waste samples are described in this section. The onsite hydrogeologist or engineer has the authority to modify the following procedures, depending on the particular situation and how, in the individual's best judgment, the most representative sample can be taken. However, any deviations from the procedures outlined in this document will be recorded in the Sample Collection Log. An explanation of when and why these procedures were not followed and what procedures were followed will also be entered.

GROUNDWATER SAMPLING

The following general sampling procedures will be used for the monitoring wells.

- 1. The static water level will be determined.
- 2. Based on the static water level and well construction details, the volume of water in the well casing and gravel pack will be determined. Estimated purge volumes are found in Table 6-1.

The volume of water required to be purged from the well is calculated from the following formula:

$$V = 7.48 \times 5 (\pi r^2 h + n(\pi R^2 h - \pi r^2 h))$$

Where:

V = Volume to be pumped (in gallons)

h = Saturated thickness of groundwater in the well, or the depth of well minus the depth to water (feet)

r = Radius of the well (feet)

R = Radius of the borehole (feet)

n = Porosity

| | | | Table 6-1 | | | |
|----------------|------------|--------------|-------------------|-----------------|--------------|-----------|
| | ······ | Mon | itoring Well Purg | | | |
| | | | | During Sampling | | • |
| | | Total | | Minimum | Maximum | |
| | | Depth | Depth of | Purge | Purge | Sampling |
| Well | Well | of Well (a) | Water (a,c) | Volume (d,c) | Volume (d,c) | Frequency |
| Site | Name | (ft bgs) (b) | (ft bgs) (b) | (gallons) | (gallons) | (Q or A) |
| CRYSTAL SPRING | | | | | | _ |
| CS-C01 | CS-C01-105 | 107 | 93.6 | 86 | 144 | <u> </u> |
| | CS-C01-285 | 287 | 93 | 440 | 733 | Q |
| | CS-C01-558 | 563 | 97.9 | 971 | 1619 | , A |
| CS-C02 | CS-C02-62 | 62 | 39.6 | 104 | 173 | Q |
| | CS-C02-180 | 180 | 39.8 | 335 | 558 | Q |
| | CS-C02-250 | 250 | 39.9 | 472 | 786 | Q |
| | CS-C02-335 | 335 | 40.4 | 637 | 1062 | Q |
| CS-C03 | CS-C03-100 | 100 | 54.6 | 149 | 248 | Q |
| | CS-C03-325 | 325 | 56.2 | 587 | 978 | Α |
| | CS-C03-465 | 465 | 56.7 | 860 | 1433 | Α |
| | CS-C03-550 | 550 | 56.6 | 1027 | 1711 | Α |
| CS-C04 | CS-C04-290 | 290 | 49.4 | 531 | 886 | Q |
| | CS-C04-382 | 382 | 50.2 | 710 | 1183 | Q |
| | CS-C04-520 | 520 | 50.2 | 980 | 1634 | Α |
| CS-C05 | CS-C05-160 | 160 | 34 | 307 | 511 | Q |
| | CS-C05-290 | 290 | 37 | 556 | 926 | , Q |
| CS-C06 | CS-C06-185 | 185 | 36.8 | 350 | 584 | Α |
| <u></u> | CS-C06-278 | 278 | 38.8 | 529 | 881 | Α |
| NORTH HOLLYW | | | , | | | |
| NH-C01 | NH-C01-325 | 330 | 298.6 | 122 | 203 | Q |
| | NH-C01-450 | 453 | 298.7 | 362 | 604 | Α |
| | NH-C01-660 | 662 | 302.7 | 764 | 1273 | Α |
| | NH-C01-780 | 785 | 304.1 | 1002 | 1670 | Α |
| NH-C02 | NH-C02-220 | 225 | 179.9 | 148 | 247 | Q |
| | NH-C02-325 | 325 | 182.1 | 340 | 567 | <u> </u> |
| | NH-C02-520 | 520 | 191.2 | 704 | 1174 | A |

| Table 6-1 | | | | | | | |
|---------------|------------|--------------|-------------------|--------------|--------------|-----------|--|
| | | Mon | itoring Well Purg | e Volumes | | | |
| | | | | | | | |
| | | Total | | Minimum | Maximum | | |
| | | Depth | Depth of | Purge | Purge | Sampling | |
| Well | Well | of Well (a) | Water (a,c) | Volume (d,c) | Volume (d,c) | Frequency | |
| Site | Name | (ft bgs) (b) | (ft bgs) (b) | (gallons) | (gallons) | (Q or A) | |
| | NH-C02-681 | 686 | 191.6 | 1029 | 1714 | Α | |
| NH-C03 | NH-C03-380 | 380 | 246.8 | 321 | 535 | Α | |
| | NH-C03-580 | 580 | 235 | 736 | 1227 | Q | |
| | NH-C03-680 | 680 | 234.7 | 932 | 1554 | Α | |
| | NH-C03-800 | 800 | 249.9 | 1138 | 1896 | Α | |
| NH-C04 | NH-C04-240 | 240 | 94 | 346 | 577 | Q | |
| | NH-C04-375 | 375 | 114.6 | 570 | 950 | Α | |
| | NH-C04-560 | 565 | 86.2 | 998 | 1664 | Α | |
| NH-C05 | NH-C05-320 | 320 | 308.6 | 82 | 137 | A | |
| | NH-C05-460 | 460 | 307.7 | 358 | 597 | Α | |
| NH-C06 | NH-C06-160 | 162 | 120.5 | 141 | 236 | Q | |
| | NH-C06-285 | 290 | 125.8 | 382 | 636 | Α | |
| | NH-C06-425 | 430 | 131.3 | 645 | 1075 | Α | |
| POLLOCK WELLS | 3 | | | | | | |
| PO-C01 | PO-C01-195 | 197 | 41.8 | 364 | 607 | A | |
| | PO-C01-354 | 359 | 40.9 | 683 | 1139 | Α | |
| PO-C02 | PO-C02-53 | 57 | 43.6 | 86 | 144 | Q | |
| | PO-C02-205 | 210 | 43.8 | 386 | 643 | Α | |
| PO-C03 | PO-C03-182 | 185 | 43.8 | 337 | 561 | Q | |
| | PO-C03-235 | 240 | 44 | 444 | 740 | Α | |
| VERDUGO VPB's | | | | 1 | | _ | |
| | VD-VPB-01 | 210 | 202.6 | 74 | 124 | Α | |
| | VD-VPB-02 | 136 | 124 | 84 | 139 | Α | |
| | VD-VPB-03 | 45 | 21.1 | 107 | 178 | A | |
| | VD-VPB-04 | 116 | 89.1 | 113 | 188 | Α | |
| | VD-VPB-05 | 156 | 143.8 | 84 | 140 | Α | |
| | VD-VPB-06 | 96 | 76.4 | 98 | 164 | Α | |

| - | | | Table 6-1 | | | ·· | | |
|--------------|-----------|------------------------|-------------------|--------------|--------------|-----------|--|--|
| | | Mon | itoring Well Purg | | | | | |
| | | During Sampling Events | | | | | | |
| | | Total | | Minimum | Maximum | | | |
| | | Depth | Depth of | Purge | Purge | Sampling | | |
| Well | Well | of Well (a) | Water (a,c) | Volume (d,c) | Volume (d,c) | Frequency | | |
| Site | Name | (ft bgs) (b) | (ft bgs) (b) | (gallons) | (gallons) | (Q or A) | | |
| | VD-VPB-07 | 216 | 202.5 | 86 | 144 | A | | |
| NORTH HOLLYW | OOD VPB's | | | | | | | |
| | NH-VPB-01 | 169 | 103.9 | 188 | 313 | Q | | |
| | NH-VPB-02 | 264 | 231 | 125 | 208 | A | | |
| | NH-VPB-03 | 223 | 125.4 | 251 | 419 | Α | | |
| | NH-VPB-04 | 188 | 154.7 | 125 | 209 | Α | | |
| | NH-VPB-05 | 207 | 180.7 | . 112 | 186 | Q | | |
| | NH-VPB-06 | . 310 | 259.2 | 160 | 266 | Q | | |
| | NH-VPB-07 | 295 | 269.6 | 110 | 183 | Q | | |
| | NH-VPB-08 | 231 | 195.3 | 130 | 217 | Q | | |
| | NH-VPB-09 | 293 | 275.1 | 95 | 158 | Q | | |
| | NH-VPB-10 | 328 | 238.3 | 236 | 393 | Α | | |
| | NH-VPB-11 | 329 | 293.6 | 129 | 216 | Α | | |
| | NH-VPB-12 | . 171 | 134.6 | 131 | 219 | Α | | |
| | NH-VPB-13 | 379 | 352.2 | 113 | 188 | Α | | |
| | NH-VPB-14 | 111 | 93.3 | 95 | 158 | Q | | |
| OLLOCK VPB's | | | | | | | | |
| | PO-VPB-01 | 65 | 27.2 | 134 | 223 | Q | | |
| | PO-VPB-02 | 71 | 39.9 | 121 | 202 | Q | | |
| | PO-VPB-03 | 71 | 37.2 | 126 | 210 | Q | | |
| | PO-VPB-04 | 119 | 30 | 234 | 391 | Q | | |
| | PO-VPB-05 | 69 | 31.6 | 133 | 222 | Α | | |
| | PO-VPB-06 | 55 | 23.9 | 121 | 202 | Α | | |
| | PO-VPB-07 | 93 | 55.5 | 133 | 222 | Q | | |
| | PO-VPB-08 | 49 | 19.8 | 117 | 195 | Q | | |
| | PO-VPB-09 | 58 | 21.6 | 131 | 219 | . A | | |
| | PO-VPB-10 | 93 | 62.9 | 119 | 198 | Α | | |

| | | | Table 6-1 | , | | |
|-----------------|--------------|-----------------------------|--------------------------|---------------------------|---------------------------|-----------------------|
| | | Mon | itoring Well Purg | e Volumes | | <u> </u> |
| | | | | During Sampling | Events | |
| VA7 - II | | Total Depth | Depth of | Minimum Purge | Maximum Purge | Sampling |
| Well Site | Well Name | of Well (a) (ft bgs) (b) | Water (a,c) (ft bgs) (b) | Volume (d,c) (gallons) | Volume (d,c) (gallons) | Frequency (Q or A) |
| | PO-VPB-11 | 110 | | 197 | 328 | Α |
| CRYSTAL SPRIN | IGS VPB's | | | <u> </u> | · | |
| | CS-VPB-01 | 109 | 56.8 | 162 | 270 | Q |
| | CS-VPB-02 | 100 | 67.4 | 124 | 206 | Q |
| | CS-VPB-03 | 100 | 60.6 | 137 | 229 | A |
| | CS-VPB-04 | 81 | 45 | 131 | 218 | Q |
| | CS-VPB-05 | 61 | 30 | 121 | 201 | Q |
| | CS-VPB-06 | 76 | 37.3 | 136 | 226 | Q |
| | CS-VPB-07 | 436 | 57.2 | 802 | 1337 | Q |
| | CS-VPB-08 | 435 | 47.6 | 819 | 1365 | Q |
| | CS-VPB-09 | 80 | 54.7 | 110 | 183 | Α |
| | CS-VPB-10 | 104 | 62.8 | 141 | 235 | Q |
| | CS-VPB-11 | 121 | 81.9 | 137 | 228 | Q |
| TOTAL | | | | 30,083 | 50,140 | |

Notes:

- a) Total depth of well and screen depth from May 1991 Quarterly Sampling Plan, J.M. Montgomery inc.
- b) bgs = below ground surface.
- c) Depth to Water = lowest point during Dec. 1990 through June 1991, except for wells designated with " * " which are July 1990 (J.M. Montgomery, Inc.).
- d) Initial purge volume = (Total depth of well depth to water) x Area of 4-inch diameter casing + 0.3 of gravel pack volume in average of 20-foot screened interval.
- e) Minimum purge volume = $3 \times (lnitial purge volume)$ and Maximum purge volume = $5 \times (lnitial purge volume)$.

It was assumed that the porosity of the gravel pack is approximately 30 percent and 5 well volumes are to be pumped. If the aquifer being sampled has a low permeability and the well is readily pumped dry, the well will be pumped dry three times and the well sampled after it recovers.

- 3. The well will be pumped until three to five well volumes are removed and the pH, temperature, and electrical conductivity of the discharge water have stabilized to within 10 percent between successive well volumes. The well will be sampled without stabilization if stabilization is not reached within 30 minutes after 5 well volumes are removed. Well discharge rate will also be measured intermittently as described in this section.
- 4. Samples will be collected in the appropriate containers (described in Tables 5-2 and 5-3). Samples will be collected from a valve near the wellhead. If required, the sample will be filtered, the proper preservatives added to the sample container, and the sample tested for pH.
- 5. The following general procedures apply to all samples:
 - After purging the well, the outlet valve will be closed sufficiently to only allow 0.5 to 1 gpm of flow.
 - The mixing of air with the groundwater sample will be minimized by tilting the bottle and allowing the water to run down the inside wall of the bottle. A gentle stream of water should enter the bottle.
 - Sample bottles will be kept out of the sun and kept cool prior to sampling. The filled sample bottles will be packaged and placed directly into a cooler with Blue Ice. The Blue Ice packages will be in sealable plastic bags.
 - Plastic bottles without preservatives will be filled completely full to minimize air contact. One-half-liter amber glass bottles will be filled only 7/8 full to allow room for expansion of liquid.
 - When checking the pH of a sample for preservation, the pH probe or pH paper will not be inserted into the sample bottle, as it may contaminate the sample. A small amount of the sample will be poured into a small beaker, and that portion will be tested with the pH probe.
 - If a container other than the sample container is used to extract the sample, a specially cleaned disposable container will be used. The disposable containers will be made of nalgene, stainless steel, or Teflon.

- Precautions will be taken to limit the contamination of samples from outside sources. Hands will be washed with distilled water, and disposal surgical gloves will be used.
- The well number or sample location, analytical parameter, preservatives added, name of sampler, and date and time of sampling will be written directly on the bottle label with a waterproof pen.
- 6. Relevant information will be recorded in the field notebook and in the Sample Collection Log.

Specific procedures are required for some samples and are discussed in the following paragraphs.

When sampling for VOCs, the 40-ml sample vials will have no headspace. The vial will be filled so that no headspace is present to eliminate any air bubbles, and the Teflon-lined cap will be replaced. Three vials will be collected for each sample. The vial will be turned upside-down and tapped to check for air bubbles. If there are any bubbles, the vial will be discarded and another vial will be filled. This procedure will be repeated until an acceptable sample is obtained.

Samples requiring filtration will be filtered through a 0.45-micron millipore disposable in-line filter in the field. A separate disposable filter will be used for each well. Sampling procedures for collecting samples for radon analyses will be as described in Appendix C (in its Appendix B, pages 22 and 23).

FIELD MEASUREMENTS

Water levels will be measured with an electric sounder. There is a 1-inch PVC sounding tube at 73 of the 87 monitoring wells. Measurements will be recorded to the nearest 0.01 foot from the top of the conductor casing. The sounder will be battery-operated and have marks on the sounder line at regular intervals (every 5, 10, or 20 feet). All water levels will be measured with the same sounder. The sounder will be accompanied by a calibration log book which will be used to record the following:

- Date and time of last calibration and name of calibrator
- The point of calibration (either the center of a mark on the sounding line or the extreme of the first mark nearest the probe)

Electrical conductivity, temperature, and pH measurements will be made prior to and during the collection of each groundwater sample using methods recommended by the equipment manufacturer. A conventional pH meter with a combination

gel-filled electrode or equivalent will be used for field pH determinations. A combination electrical conductivity-temperature-salinity meter or equivalent measuring devices will be used for determination of conductivity and temperature. All instruments will be periodically calibrated (according to manufacturer specifications) to maintain accuracy.

The measurements will be made as follows:

- The transfer bottle (a nalgene bottle used solely for this purpose) will be rinsed with sample water prior to filling.
- Instrument probes will be thoroughly rinsed with distilled water, then immediately submerged in the transfer bottle, and measurements will be taken.
- All field measurements will be recorded in a field notebook along with the sample location and time and date of measurement.
- After measurements are recorded, the transfer bottle and the probes will be decontaminated by rinsing with distilled water. If the transfer bottle cannot be cleaned, a new bottle will be used.

Discharge measurements for monitoring wells (flow approximately 4 to 15 gpm) will be made with a calibrated bucket and stopwatch.

TRANSPORT AND DISPOSAL OF DERIVED WASTES

Transport and disposal of potentially hazardous waste will occur during four events --three quarterly sampling events of 41 monitoring wells and one annual sampling event for 87 monitoring wells. Purged well water and potentially hazardous solid wastes will be transported from the monitoring well sites to the LADWP North Hollywood Aeration Facility (NHAF) by a hazardous waste transport and disposal subcontractor. Purged well water will be pumped directly into a 55-gallon drum prior to transfer into the subcontractor's vacuum truck. Groundwater from several wells may be mixed in the vacuum truck during the course of a day's work. The water will then be transferred from the vacuum truck into temporary storage Baker tanks at the NHAF on a daily basis. The water will be characterized and treated in accordance with DHS requirements and disposed of by LADWP.

All protective clothing, field sampling gear, and other miscellaneous items will be collected in 3-mil plastic bags. The contents of each bag, including the plastic liner, will be transported to the NHAF (using U.S. Department of Transportation-approved 55-gallon drums) and contained in 10-cubic-yard rolloff bins. All

protective clothing and sampling waste will be disposed of at an appropriate waste disposal facility by the hazardous waste transport and disposal subcontractor.

It is anticipated that an area within the LADWP NHAF can be used for storage of the Baker tanks, rolloff boxes, and 55-gallon drums until their contents have been analyzed and the appropriate disposal method is decided upon.

EQUIPMENT DECONTAMINATION

Prior to the start of work, all equipment will be washed and cleaned as specified and approved by the site safety officer or field team leader prior to initiation of work at the site. This includes sampling equipment and any other equipment brought onsite. This is especially important to prevent cross-contamination between monitoring wells by any equipment being placed down the well.

For all sampling tools and any other equipment, the following decontamination procedures apply:

- The decontamination area will be covered with plastic liners.
- Sampling equipment, water level sounders, or any equipment placed down the bore of a well will be washed in nonphosphate detergent, rinsed with clean water (tap), rinsed with deionized water, then rinsed with isopropanol (pesticide grade), and finally rinsed with organic-free, deionized water. Rinsates will be containerized and transported to the NHAF by a hazardous waste hauling subcontractor.
- Water sampling, water level measuring, and sample preparation equipment that comes onsite will be cleaned prior to and after each use on this project. Decontamination will consist of combinations of steam cleaning and/or detergent (trisodium phosphate) wash, water rinse, alcohol (or other solvent) rinse, and repeated distilled water rinse.

All equipment that enters or leaves the onsite work area will be decontaminated as if exposed to Level C contaminants. Personnel who leave the onsite work area will be decontaminated as required in the Site Safety Plan (Appendix E). Abovegrade equipment on the onsite work area, all downhole equipment, holding tanks, and other equipment that could transfer contaminants from one well site to another will be decontaminated between well sites.

All decontamination operations will be conducted by subcontractor personnel wearing Level D protective equipment.

SAMPLE CONTAINERS AND PRESERVATION

The sample containers and preservatives will be as specified in Section 5, Request for Analysis, and Tables 5-2 and 5-3. Sample bottles for the groundwater sampling will be procured through the CLP bottle repository. The preservatives will be added in the field prior to sampling (except for metals, which will be added after filtering). Field holding time of samples will be limited to 24 hours.

SAMPLE PACKAGING AND SHIPPING

A sample number, consisting of a CLP sticker for RAS analyses or a SAS number with a sequential extension for SAS analyses, will be placed on all SAS sample containers. The following information will also be written on each sample container (both RAS+SAS and SAS) with a permanent marker, then covered with clear plastic tape.

- Sample location number (if a CLP sticker is used)
- Case number (if applicable)
- Type of analysis requested
- Preservative used
- Date collected

The lid of each container will be wrapped with electrical tape. Custody seals will then be placed over the cap of each sample container. However, custody seals on the VOA vials will be placed around the lid to prevent covering the Teflon septum.

VOA vials (two or three vials per sample) will be wrapped together securely in bubble pack and secured with tape. Sealed samples will be placed in sealable plastic bags labeled with the sample number. Each bubble-wrapped VOA vial pair or triplet will be placed in one sealable plastic bags. All other glass bottles will be bubble-wrapped and placed into sealable plastic bags. Polyethylene bottles will be placed into sealable plastic bags.

Water sample bottles are fragile and should be handled with care. The packaged samples will be placed in coolers with Blue Ice and vermiculite, No. 1 foam liner, or bubble wrap. The Blue Ice may be replaced with double sealable plastic bags filled with cubed ice. Samples should be packaged upright and protected from shipping damage. All appropriate sample documentation will be placed in sealable plastic bags and taped to the inside lid of the cooler. The cooler should be sealed with tape. In addition, tape should be placed over the latch and drain plug of the cooler. At lease two custody seals will be placed on different sides of the cooler in a manner such that they extend from the main body to the lid of the cooler. Clear tape will be placed over the seals to ensure that they are not broken accidently during shipment. Ice chests should be labeled with "Fragile" and "This End Up"

labels on all four sides. Coolers will be shipped to the appropriate CLP laboratory via overnight carrier (e.g., Federal Express Priority 1). All groundwater samples are expected to be low concentration (<10 ppm). Each day's sample shipment will be reported to the EPA Region IX RSCC. For Friday shipments, the Routine Sample Control Coordinator (RSCC) will be contacted prior to 12 noon to coordinate with the laboratories that will receive the sample shipments on Saturday. The laboratory must provide assurances that samples shipped on Fridays will be analyzed prior to exceeding analytical holding times.

SAMPLE DOCUMENTATION

The following sections describe the sampling documentation that will be used. All sampling activities will be recorded in bound, numbered field notebooks. Chain-of-custody procedures will be used to maintain and document sample possession. After sample packaging, the following EPA Region IX paperwork must be completed (Appendix D).

- Organic traffic reports for use when shipping RAS or RAS+SAS samples
- Inorganic traffic reports for use when shipping RAS or RAS+SAS samples
- SAS packing lists for use when shipping SAS samples
- Chain-of-custody records
- Air bills

Instructions for filling out EPA Region IX CLP paperwork and examples of completed forms are included in Appendix D. Completed field QA/QC summary forms will be sent to EPA QAMS at the conclusion of the sampling. Sample shipping information from each day will be relayed to the RSCC at EPA Region IX QAMS as soon as possible after shipping.

FIELD LOGS AND NOTEBOOK

Field data will be recorded on individual log sheets and in bound notebooks. A bound notebook will be maintained whenever samples are being taken.

Examples of the field logs are included in Appendix E. These logs include:

- Daily Field Log (Inspection Diary)
- Groundwater Quality Sampling Diary

Sample Collection Log

These logs will be completed and dated by the individual directly supervising the work.

The Daily Field Log will be maintained by the onsite supervisor. This log will be used to document arrival and departure of visitors, weather, health and safety notes, decontamination procedures, and any other pertinent information essential to reconstruct the day's events. All information entered in this notebook will be recorded in ink.

The Groundwater Quality Sampling Diary will be maintained by the onsite supervisor. Members of the field team will use this notebook to record information taken during sampling. The information should include the name of the sampler, sample designation, date, time, location, field parameter and water level measurements, volume purged, sample containers used, decontamination procedure, and sampling procedure. All information entered in this notebook will be recorded in ink; will be sufficient to correlate the samples taken with information recorded on the Sample Collection Logs; and will provide sufficient information to trace and assess the quality of each sample if the sample collection logs are lost.

SAMPLE CUSTODY

A required part of any sampling and analytical program is maintaining the integrity of the sample from collection to data reporting. This includes the ability to trace the possession and handling of samples from the time of collection, through analysis, and final deposition. This documentation of the sample's history is referred to as "chain of custody." The components of the CLP chain-of-custody requirements (custody seals, a field logbook, chain-of-custody record, and sample labels), and the procedures for their use are described in the following sections. Sample custody procedures will follow EPA contract laboratory guidance and NEIC procedures (EPA, 1986).

A sample is considered to be under a person's custody if it is:

- In a person's physical possession or view
- Retained in a secured area with restricted access
- Placed in a container and secured so the samples(s) cannot be tampered with, i.e., under lock or under official seal

A person who has samples under custody must comply with the procedures described in the following sections.

CHAIN-OF-CUSTODY RECORD

To establish the documentation necessary to trace sample possession from the time of collection, a Chain-of-Custody Record(s) will be filled out and accompany every sample shipment. Instructions for completing a Chain-of-Custody Record are contained in Appendix D.

The record will contain the following minimum information:

- Sampling location (tied to a sampling location)
- Signature of collector(s)
- Date and time of collection
- Sample number
- Number of containers
- Project name and number
- Sample description
- Case number
- Special Analytical Services (SAS) number (when applicable)
- Name of shipper
- Date shipped
- Air bill number
- Signatures of people involved in the chain of possession

In order to maintain chain of custody, each person in custody of the sample will sign, date, and note time on the form, and samples will not be left unattended unless placed in a secure and sealed container (custody seals) with the Chain-of-Custody Record inside the container.

CUSTODY SEALS

Custody seals are used to detect unauthorized tampering of samples from sample collection to the time of analysis. Custody seals will be provided by the EPA Region IX RSCC. A sample of a custody seal is illustrated in Appendix D. The seal will be attached to the sample container and be of the type that must be broken to open the sample container. Seals will be affixed to each sample container before the samples leave the custody of the sampling personnel. Shipping containers will also contain seals to detect possible tampering. A seal will include the following information:

- Sample signature
- Date of collection

QUALITY ASSURANCE

Field duplicate samples will be collected to check the precision of field and laboratory procedures. They will be labeled and packaged in the same manner as other samples so that the lab cannot distinguish between samples and duplicates. Field duplicates will be collected by alternately filling sample and sample duplicate containers at a location of known or suspected contamination. Each duplicate will be taken using the same sampling and preservation method as other samples. The minimum number of field duplicates collected will be approximately 10 percent of the wells sampled.

Field blanks will be collected to check for possible cross contamination during sampling, shipment, and within the laboratory. The blank will be made with organic-free distilled-deionized water for organic analyses and reagent-grade deionized water for inorganic analyses using the same preservation methods and packaging and sealing procedures used during collection of groundwater samples. A field blank for each analysis will be collected each day. They will be labeled and packaged in the same manner as other samples so that the lab cannot distinguish between samples and duplicates.

One of every 20 samples collected (including duplicates and blanks) will be designated for lab quality control (QC). This sample will be twice the normal amount of sample collected and should be from a well with suspected contamination. The label "Lab QC Sample" will appear on the bottles and on the paperwork. The first lab QC sample will be sent with the first or second day's shipment.

Field duplicates, field blanks, and lab quality control samples will be taken from the wells as presented in Tables 5-2 and 5-3. Field QA samples will be labeled according to monitoring well location and a suffix that connotates the type of QA sample being collected:

B = Field Blanks

D = Field Duplicates

L = Lab QC Samples

Example: NH-C01-325 B

This is a field blank sample collected at the North Hollywood Cluster Well Location Number 1 from the well screened from 275 feet to 325 feet.

Section 7 SITE HEALTH AND SAFETY

CH2M HILL subcontractor(s) personnel will follow site safety precautions as described in CH2M HILL's Site Safety Plan (SSP). If the supervising CH2M HILL representative considers the activities of the subcontractor in the field to be unsafe, the subcontractor will be directed to stop work, and the CH2M HILL personnel will leave the site. The Draft SSP for the San Fernando Valley Groundwater Basin site is provided in Appendix F. The SSP will be finalized when CH2M HILL and subcontractor personnel have been selected.

Section 8 REFERENCES

CH2M HILL. August 1991. Recommended RI Well Monitoring Program, San Fernando Valley Basin. Prepared for U.S. EPA.

James M. Montgomery, Consulting Engineers, Inc. March 1989. Remedial Investigation of the San Fernando Valley Groundwater Basin--Sampling and Analysis Plan.

JMM. 1990a. Technical Memorandum for the North Hollywood Vertical Profile Borings. April.

JMM. 1990b. Technical Memorandum for the Phase 1 Crystal Springs Vertical Profile Borings. August.

JMM. 1990c. Technical Memorandum for the Phase 1 Pollock Vertical Profile Borings. October.

JMM. 1990d. Technical Memorandum for the Phase 1 Verdugo Vertical Profile Borings. November.

JMM. 1991a. Technical Memorandum for the Phase 1 Crystal Springs Cluster Wells. May.

JMM. 1991b. Technical Memorandum for the Phase 1 Pollock Cluster Wells. June.

JMM. 1991c. Technical Memorandum for the Phase 1 North Hollywood Cluster Wells. July.

U.S. EPA. 1988a. U.S. EPA Contract Laboratory Program Statement of Work for Organics Analysis; Multi-Media, Multi-Concentration. February.


U.S. EPA. 1988b. U.S. EPA Contract Laboratory Program Statement of Work for Inorganics Analysis, Multi-Media, Multi-Concentration. SOW No. 788. July.


U.S. EPA. 1986. Users Guide to the Contract Lab Program. December.

Appendix A MONITORING WELL DESCRIPTIONS MONITORING WELL DESCRIPTIONS AND COPIES OF 1991 THOMAS GUIDE MAPS

| | DESCRIPTION OF SAN FERNANDO VALLEY B. | ASIN GROUNDWATER MONITO | RING WELL LOC | ATIONS | |
|------------------------|---|------------------------------|---------------|--|------------------------------------|
| MONITORING VÆLL | | SPECIFIC | | THOMAS | SAMPLING FREQUENCY QUARTERLY |
| LOCATION | LOCATION | LOCATION | CITY | GUIDE | OR ANNUALLY |
| CS-C01-106 | PARISH PL @ Verdugo Av | Sidewalk | BURB | | <u> </u> |
| CS-C01-285 | PARISH PL @ Verdugo Av | Sidewalk | BURB | 70.04.00 | <u> </u> |
| CS-C01-658 | PARISH PL @ Verdugo Av | Sidewalk | BURB | PG 24-C2 | A |
| CS-VPB-01 | ALAMEDA AV @ Mein St | Sidewalk | BURB | PG 24-D2 | <u>a</u> |
| CS-VP8-02 | BEACHWOOD DR @ Riverside Dr | Park Lawn | BURB | PG 24-D2 | <u> </u> |
| CS-VPB-03 | VALENCIA AV @ Flower St | Corner Lawn | BURB | PG 24-E2 | A |
| NH-C04-240 | LAKE ST @ Magnolia Av | Burbank PSD | BURB | | |
| NH-C04-375 | LAKE ST @ Magnolia Av | Burbank PSD | BURB | PG 16-D8 | A |
| NH-C04-560 | LAKE ST @ Magnelia Av | Burbank PSD | | PG 16-D6 | A |
| NH-C06-160 | ROSE ST @ Magnolia Av | Sidewalk Sidewalk | BURB | | Q |
| NH-C06-285 | | | BURB | PG 24-A2 | A |
| NH-C06-425 | ROSE ST @ Magnolia Av | Sidewalk Laws | | PG 24-A2 | A |
| NH-VPB-12 NH-VPB-14 | SAN FERNANDO RD @ Burbank B! MAGNOLIA BL @ Lake St | Sidewalk Lawn | BURB | PG 17-D8 | A |
| CS-C03-100 | WESTERN AV @ Flower St | BPSD Lawn City of Glen Prop | GLEN | 7.5 17.00 | a |
| CS-C03-100 | WESTERN AV @ Flower St | City of Glen Prop | GLEN | | A |
| CS-C03-485 | WESTERN AV @ Flower St | City of Glen Prop | GLEN | - | |
| CS-C03-560 | WESTERN AV @ Flower St | | GLEN | PG 24-F2 | Â |
| | FLOWER ST @ Ruberta Av | City of Glen Prop | GLEN | PG 24-F2 | <u> </u> |
| CS-C04-290 | | Grif Mnr Prk Lawn | _ | <u> </u> | |
| CS-C04-382 | FLOWER ST @ Ruberta Av | Grif Mnr Prk Lawn | GLEN | 20 24 52 | <u> </u> |
| CS-C04-520 | FLOWER ST @ Ruberts Av | Grif Mnr Prk Lawn | GLEN | PG 24-F2 | A |
| CS-C05-160 | GRANDVIEW AV @ Flower St | Street | GLEN | 00.05.40 | <u> </u> |
| CS-C05-290 | GRANDVIEW AV @ Flower St | Street | GLEN | PG 25-A2 | <u>a</u> |
| CS-VPB-04 | FLOWER ST @ Ruberta Ave | Grif Mnr Prk Lawn | GLEN | PG 24-F2 PG 25-A2 | |
| CS-VPB-06 | GIARD VIEW AV & Flower St | Street | GLEN | | <u> </u> |
| CS-VPB-07 | DANA ST @ Thompson Av | Street | GLEN | PG 24-F1 | <u> </u> |
| CS-VPB-08 | WINCHESTER AV @ Landell St. | Sidewalk | GLEN | PG 24-E2 | <u> </u> |
| CS-VPB-09 | GRANDVIEW @ Pelanconi Park | Basobali Fid | GLEN | PG 25-A2 | <u> </u> |
| CS-VPB-11 | CALIFORNIA AV @ Chester St KENILWORTH AV @ Freemont Pk | Street | GLEN | PG 26-83 PG 26-83 | <u>a</u> |
| CS-VPB-11 | | Perking | | PG 28-83 | f |
| VD-VPB-01 | MAYFIELD AV @ La Cresenta AV SUNVIEW DR @ Ocean View BI | Street | GLEN | PG 18-E2 | A A |
| VD-VP8-02 VD-VP8-03 | COLINA DR @ Canada BI | Street | GLEN | PG 18-F3 | A |
| VD-VP8-04 | SANTA MARIA AV @ Canada bl. | Street | GLEN | PG 18-E6 | , A |
| VD-VP8-06 | BROADVIEW DR Roselawn Av | Street | GLEN | PG 18-E3 | |
| VD-VPB-06 | FAIRCHILD ST @ Dunamore Av | Street | GLEN | PG 11-C8 | A . |
| CS-C02-062 | MAIN ST @ Riverside Dr | Equestrian Ctr | LA | † | <u> </u> |
| CS-C02-180 | MAIN ST @ Riverside Dr | Equestrian Ctr | LA | | a |
| CS-C02-250 | MAIN ST @ Riverside Dr | Equestrian Ctr | LA | † | a |
| CS-C02-336 | MAIN ST @ Riverside Dr | Equestrian Ctr | LA | PG 24-E2 | <u> </u> |
| | CUTTER ST @ San Fernando Rd | Street | LA | 1 9 27 52 | A . |
| CS-C06-185 | | | LA | PG 25-83 | ^ |
| CS-C08-278 | CUTTER ST @ San Fernando Rd | Street | LA | PG 25-83 | - |
| S-VPB-08 IH-C01-325 | CUTTER ST @ Sen Fernando Rd KESWICK ST @ Tujunga Av | Street Sidewalk Lawn | LA | 7.0 40-03 | a |


| | DESCRIPTION OF SAN FERNANDO VALLEY BAS | IIN GROUNDWATER MONITORI | NG WELL LOC | ATIONS | |
|--------------------------|--|--------------------------|-------------|-----------------|--|
| MONITORING WELL LOCATION | LOCATION | SPECIFIC LOCATION | CITY | THOMAS GUIDE | SAMPLING FREQUENCY QUARTERLY OR ANNUALLY |
| NH-C01-450 | KESWICK ST @ Tujunga Av | Sidewelk Lawn | LA | 00,00 | Î |
| NH-C01-660 | KESWICK ST @ Tujunga Av | Sidewalk Lawn | LA | | A A |
| NH-C01-780 | KESWICK ST @ Tujunga Av | Sidewalk Lawn | LA | PG 16 -D2 | A |
| NH-C02-220 | CAHUENGA BL @ Erwin St | Street | LA | FG 10 -52 | a |
| NH-C02-325 | CAHUENGA BL @ Erwin St | Street | LA | | 9 |
| NH-C02-620 | CAHUENGA BL @ Erwin St | Street | LA | | A . |
| NH-C02-881 | CAHUENGA BL @ Erwin St | Street | LA | PG 18-F6 | A |
| NH-C03-380 | FARMDALE AV S Vanowen St | ROW Trans Line | LA | | A |
| NH-C03-580 | FARMDALE AV ② Vanowen St | ROW Trans Line | LA | | a |
| NH-C03-680 | FARMDALE AV ② Vanowen St | ROW Trans Line | LA | | A |
| NH-C03-800 | FARMDALE AV ② Vanowen St | ROW Trans Line | LA | PG 18-D4 | A |
| NH-C05-320 | GENTRY AV @ Saticoy St | Street | LA | | A |
| NH-C05-460 | GENTRY AV @ Saticoy St | Street | LA | PG 16-C3 | A |
| NH-VPB-01 | CLARK AV @ Keystone St | Sch Lewn | LA | PG 24-C1 | a |
| NH-VPB-02 | ARCHWOOD AV @ Vantge St | Street | LA | PG 18-C4 | A |
| NH-VP8-03 | ERWIN ST @ Lankershim BI | Sidewalk | LA | PG 18-D5 | A |
| NH-VPB-04 | COLLINS ST @ Vineland Av | Street | LA | PG 18-E8 | A |
| NH-VPB-05 | CLYBOURNE AV @ Victory BI | Sidewalk | LA | PG 16-F5 | a |
| NH-VPB-06 | RADFORD ST @ Sherman Rd | ROW Trans Line | LA | PG 16-C3 | a |
| NH-VPB-07 | VALERIO ST @ Backman Av | Sidewalk | LA | PG 16-D3 | a |
| NH-VPB-08 | VINELAND AV @ Erwin St | ROW Trans Line | LA | PG 18-E5 | a |
| NH-VPB-09 | VINELAND AV @ Strathern St | LA Library Pkg | LA | PG 16-E2 | Q |
| NH-VPB-10 | ARMINITA ST @ De Germo Av | Church Lawn | LA | PG 18-F2 | A |
| NH-VP8-11 | BEEMAN AV @ s/o Strathern St | Street | LA | PG 16-82 | А |
| NH-VPB-13 | VENA AVE @ LAC Flood Control | Off Vena | LA | PG 09-85 | A |
| PO-C01-195 | GOODWIN AV @ Brunswick | Street | LA | | A |
| PO-C01-354 | GOODWIN AV @ Brunswick Av | Street | LA | PG 25-85 | A |
| PO-C02-053 | LOS FELIZ RD @ Revere Av | Sidewalk Lewn | LA | | a |
| PO-C02-205 | LOS FELIZ RD @ Revere Av | Sidewalk Lawn | LA | PG 25-C8 | A |
| PO-C03-182 | GARDEN AV @ Garda St | Sidewalk Lawn | LA | | a |
| PO-C03-235 | GARDEN AV @ Garcia St | Sidewalk Lawn | LA | PG 35-C2 | A |
| PO-VPB-01 | BRUNSWICK AV @ Appleton St | Street | LA | PG 35-C1 | Q |
| PO-VP8-02 | GOODWIN AV @ Brunswick Av | Street | LA | PG 25-86 | Q |
| PO-VP8-03 | GARDEN AV @ Gercie St | Sidewalk Lawn | LA | PG 35-C2 | a |
| PO-VPB-04 | AVE 33 @ Eagle Rock BI | Street | LA | PG 35-E2 | a |
| PO-VPB-05 | GILROY ST @ Ripple St | Sidewalk Lewn | LA | PG 35-D2 | Α |
| PO-VPB-06 | QUEEN ST @ Blake Av | Street | LA | PG 35-D3 | Α |
| PO-VPB-07 | ANDRITA ST @ San Fernando Rd | Street | LA | PG 36-D1 | a |
| PO-VPB-08 | CRYSTAL ST @ Doris PI | Street | LA | PG 36-E4 | a |
| PO-VP8-09 | VERDUGO RD @ Eagle Rock 81 | Street | LA | PG 36-E3 | A |
| PO-VPB-10 | PALMER AV @ Maryland Av | Street | LA | PG-25-C5 | A |
| PO-VP8-11 | CRESTMORE PL @ Eagle Rock BI | Sidewalk Lewn | LA | PG 36-E1 | A |
| VD-VPB-07 | ORANGE COVE @ Briggs Av | Street | LAC | PG 11-E6 | Α . |











Appendix B SCALED DRAWINGS OF MONITORING WELL LOCATIONS











THOMAS GUIDE LOCATION: PG 24-F2
CITY OF GLENDALE

AS CONSTRUCTED 04/91


L. A. D. W. P.
CLUSTER WELL LOCATION
CRYSTAL SPRINGS NPL SITE


PREPARED BY:

SUPERFUND GROUP
WATER ENGINEERING DESIGN DIVISION
LOS ANGELES DEP'T OF WATER & POWER


WELL NAME:

CS-C03







CSC04 DRW. 04/91




0 10 20 40 **THOMAS GUIDE LOCATION: PG 25-B3** CS-C06-278 CITY OF LOS ANGELES CS-C06-185 CS-VPB-06 CURB 12" WATER 13' N C.L. CUTTER 406' AS CONSTRUCTED 04/91 PREPARED BY: WELL NAME: L. A. D. W. P. SUPERFUND GROUP CS-C06 **CLUSTER WELL LOCATION** WATER ENGINEERING DESIGN DIVISION LOS ANGELES DEP'T OF WATER & POWER **CRYSTAL SPRINGS NPL SITE** C\$C06.DRW AVA 04/91









NHC02 DRW. 04/91







NHC04 DRW 04/91






NHC06 DRW 04/91







NHCOS DRW AVA 04/91













POC02 DRW AVA 04/91















































AVA 03/83









THOMAS GUIDE LOCATION: PG 35-D2

REVISIONS:

↑10/31/89 AVA

BORING LOCATION

EXCLUSION ZONE

DRILL RIG (8 ft. x 35 ft.)

SERVICE/PIPE TRUCK (8 ft. x 25 ft.)

WASTE BIN, SEALABLE (7 ft. x 15 ft.)

NOTES:

- o VEHICULAR INGRESS/EGRESS WILL BE MAINTAINED DURING ENTIRE DRILLING OPERATION.
- O A STARTER HOLE WILL BE HAND DUG A FEW FEET BELOW GRADE TO ASSURE NO DISRUPTION OF SEWER CONNECTION AND OTHER SUBSTRUCTURES.

L. A. D. W. P.
VERTICAL PROFILE BORING LOCATION
POLLOCK NPL SITE


PREPARED BY:

SUPERFUND GROUP WATER ENGINEERING DESIGN DIVISION LOS ANGELES DEPT OF WATER & POWER


D_W P


DRAWING NO.


PO-VPB-05











THOMAS GUIDE LOCATION: PG 35-E4

BORING LOCATION

EXCLUSION ZONE

1 DRILL RIG (8 ft. x 35 ft.)

SERVICE/PIPE TRUCK (8 ft. x 25 ft.)

WASTE BIN, SEALABLE (7 ft. x 15 ft.)

NOTES:

- VEHICULAR INGRESS/EGRESS WILL BE MAINTAINED DURING ENTIRE DRILLING OPERATION.
- O A STARTER HOLE WILL BE HAND DUG A FEW FEET BELOW GRADE TO ASSURE NO DISRUPTION OF SEWER CONNECTION AND OTHER SUBSTRUCTURES.

L. A. D. W. P.
VERTICAL PROFILE BORING LOCATION
POLLOCK NPL SITE


PREPARED BY:


SUPERFUND GROUP


WATER ENGINEERING DESIGN DIVISION LOS ANGELES DEP'T OF WATER & POWER

DRAWING NO.


PO-VPB-08






















































L.A.D.W.P.


SAN FERNANDO VALLEY R.I.

NORTH HOLLYWOOD NPL SITE

VERTICAL PROFILE BORINGS
PROPOSED LOCATION OF BORING
NH-VPB-12







Appendix C DESCRIPTION OF SAS ANALYTICAL PROCEDURES

Section No.: <u>SM403</u>
Revision No.: <u>1</u>
Date: <u>December 1989</u>
Page: <u>1</u> of <u>2</u>

Analysis of Carbonate, Bicarbonate and Total Alkalinity in Water by Standard Method 403:

Analytes: Carbonate, bicarbonate and total alkalinity

<u>Sample Matrices</u>: Low concentration water samples (specify whether surface water, groundwater, drinking water, waste or leachate).

Analytical Procedure and Detection Limits: Follow "Standard Methods for the Examination of Water and Wastewater", 16th Ed., Method 403, Procedures 4c and 4d. Contract required detection limit (CRDL) is 2.0 mg/L of CaCO₃ or lower for low level samples and 20 mg/L of CaCO₃ for high level samples.

- 1. Samples are to be kept at 4°C until analysis and validation of results are completed.
- 2. Samples will be unfiltered. Report the carbonate, bicarbonate and total alkalinity results for each sample.
- 3. Do not use titrant volumes greater than 50 mL. Dilute and re-analyze any sample aliquots requiring more than 50 mL titrant.

<u>Contract Holding Times</u>: Contract required analysis holding time is 12 days from the date of sample receipt by the laboratory.

Calibration Procedure and Criteria: Not applicable

Internal Quality Control Checks, Control Limits and Corrective Action:

- 1. Standardize the pH meter and the titrant each day. Standardize the pH meter using at least 2 buffers which bracket the end points. Use Na_2CO_3 to standardize titrant, according to Section 3 of Method 403.
- 2. Analyze 1 set of EPA QC Mineral Reference Samples (at 2 concentration levels) at a frequency of one per sample delivery group. Recoveries of 90-110% are required.
- 3. Analyze laboratory blanks at a frequency of one per group of 20 or fewer samples. Laboratory blanks must contain less than 2.0 mg/L of CaCO₃ for low level analyses and less than 10 mg/L of CaCO₃ for high level analyses.
- 4. Analyze laboratory duplicates at a frequency of one per group of 20 or fewer samples. Difference in duplicate sample results must be less than 10% for concentrations exceeding 20 mg/L and less than 2.0 mg/L for concentrations below 20 mg/L.
- 5. If above control limits are exceeded, take appropriate actions to correct the problems and re-analyze the affected samples.

Section No.: SM403
Revision No.: 1
Date: December 1989
Page: 2 of 2

Carbonate, Bicarbonate and Total Alkalinity in Water by Method 403 (Continued):

<u>Data Calculations and Reporting Units</u>: Calculate and report the carbonate, bicarbonate and total alkalinity results according to Section 5 of Method 403. Sample results are to be reported in the concentration unit of milligram per liter (mg/L) of CaCO₃. All records of analysis and calculations must be legible and sufficient to recalculate all sample concentrations and QC results. Include an example of the calculations in the data package.

<u>Documentation</u> and <u>Deliverables</u>: Identify the QC reference sample lot numbers used and the corresponding true values with 95% confidence intervals. Report all bench records tabulating pH meter calibration, titrant standardization, laboratory control samples, titration and indicator blanks, sample volumes and titrant volumes, matrix spikes, laboratory duplicates, etc. Indicate date and time of analysis. Provide all raw data, including copies of instrument readouts and worksheets used to calculate results. Raw data are to be organized systematically and each page is to be numbered.

Section No.: 100 DA
Revision No.: 1
Date: December 1939
Page: 1 of 2

Analysis of Inorganic Anions in Water by Ion Chromatography-EFA Method 300.0:

<u>Analytes</u>: Chloride, fluoride, nitrate-N, nitrite-N, ortho-phosphate-P and sulfate

<u>Sample Matrices</u>: Low concentration water samples (specify whether surface water, groundwater, drinking water, waste or leachate).

Analytical Procedure and Detection Limits: Follow the EPA Method 300.0. Contract required detection limits (CRDL) are 0.10 mg/L for fluoride, nitrate-N and nitrite-N, and 1.0 mg/L or lower for chloride, o-phosphate-P and sulfate.

- 1. Samples are to be kept at 4°C until analysis and validation of results are completed.
- Confirmatory techniques such as sample dilution and spiking must be performed when the identification of a peak in the chromatogram is questionable and for the confirmation of all positive results reported. Spike the sample with an appropriate amount of the relevant standard and re-analyze.
- 3. A laboratory blank is to be analyzed after the analysis of an unusually concentrated sample, to check for contamination by carry-over.

<u>Contract Holding Times</u>: Contract required analysis holding times are 24 hours for nitrate-N, nitrite-N and o-phosphate-P, and 25 days for chloride, fluoride and sulfate, from the date of sample receipt by the laboratory.

<u>Calibration Procedure and Criteria</u>: Calibrate according to Section 9 of EPA Method 300.0, with the following specifications:

- The working standards are to be prepared daily from the stock solutions.

 Stock standards are to be stored at 4°C and replaced after one month.
- 2. Use at least five calibration standards (not including zero standard) to obtain a standard calibration curve. Calculate and report the retention time (RT) window, response factor (RF) and percent relative standard deviation (%RSD) for each analyte.
- 3. Calibration verification standards at the mid-point concentration are to be analyzed at the beginning of each working day, whenever the anion eluent is changed, and after every 20 or fewer samples. Percent differences (%D) in RF of less than ±10% are required. For %D of greater than ±10%, recalibrate as described in Section 9.4 of EPA Method 300.0.

Internal Quality Control Checks, Control Limits and Corrective Action:

.

1. Analyze laboratory control samples (LCS) at a frequency of one per sample delivery group. Recoveries of 85-115% are required.

Section No.: 100.0A Revision No.: 1 Date: December 1989 Page: 2 of 2

Inorganic Anions in Water by Method 300.0 (Continued):

2. Analyze laboratory blanks at a frequency of one per group of 20 or fewer samples and after analysis of unusually concentrated samples.

Laboratory blanks must not contain any anions at concentrations above the CRDL.

3. Samples containing anions at concentrations above the calibration range are to be diluted and re-analyzed. Report the results and documentation

for both analyses.

4. Analyze matrix spikes at a frequency of one per group of 20 or fewer samples. Matrix spike concentrations are to be greater than 30% of the sample concentrations, but spiked samples must not exceed the working range of the standard curve. Recoveries of 85-115% are required.

5. Analyze laboratory duplicates at a frequency of one per group of 20 or fewer samples. The relative percent difference (RPD) of duplicate

sample results must be less than 10%.

6. If above control limits are exceeded, take appropriate actions to correct the problems and re-analyze the affected samples.

Data Calculations and Reporting Units: Calculate the sample results according to Section 12 of EPA Method 300.0. Sample results are to be reported in the concentration unit of milligram per liter (mg/L). All records of analysis and calculations must be legible and sufficient to recalculate all sample concentrations and QC results. Include an example of the calculations in the data package.

<u>Documentation and Deliverables</u>: Identify the laboratory control sample as to source, reference sample lot number and the corresponding true value with 95% confidence interval. Report all bench records tabulating calibration standards (RT window, RF, %RSD and %D), laboratory control samples, laboratory blanks, samples, matrix spikes, laboratory duplicates, etc. Indicate date and time of analysis. Provide all raw data, including copies of instrument readouts and worksheets used to calculate results. Raw data are to be organized systematically and each page is to be numbered.

Revision No.: 1
Date: December 1939
Page: 1 of 2

Analysis of Inorganic Anions in Water by Ion Chromatography-EPA Method 300.0:

<u>Analytes</u>: Chloride, fluoride, total nitrate/nitrite-N, ortho-phosphate-P and sulfate

<u>Sample Matrices</u>: Low concentration water samples (specify whether surface water, groundwater, drinking water, waste or leachate).

Analytical Procedure and Detection Limits: Follow the EPA Method 300.0. Contract required detection limits (CRDL) are 0.10 mg/L for fluoride and total nitrate/nitrite-N, and 1.0 mg/L or lower for chloride, o-phosphate-P and sulfate.

- 1. Samples are to be kept at 4°C until analysis and validation of results are completed.
- Confirmatory techniques such as sample dilution and spiking must be performed when the identification of a peak in the chromatogram is questionable and for the confirmation of all positive results reported. Spike the sample with an appropriate amount of the relevant standard and re-analyze.
- 3. A laboratory blank is to be analyzed after the analysis of an unusually concentrated sample, to check for contamination by carry-over.

Contract Holding Times: Contract required analysis holding times are 5 days for total nitrate/nitrite-N and o-phosphate-P, and 25 days for chloride, fluoride and sulface, from the date of sample receipt by the laboratory.

<u>Calibration Procedure and Criteria</u>: Calibrate according to Section 9 of EPA Method 300.0, with the following specifications:

- The working standards are to be prepared daily from the stock solutions.
 Stock standards are to be stored at 4°C and replaced after one month.
- 2. Use at least five calibration standards (not including zero standard) to obtain a standard calibration curve. Calculate and report the retention time (RT) window, response factor (RF) and percent relative standard deviation (%RSD) for each analyte.
- 3. Calibration verification standards at the mid-point concentration are to be analyzed at the beginning of each working day, whenever the anion eluent is changed, and after every 20 or fewer samples. Percent differences (%D) in RF of less than ±10% are required. For %D of greater than ±10%, recalibrate as described in Section 9.4 of EPA Method 300.0.

Internal Quality Control Checks, Control Limits and Corrective Action:

1. Analyze laboratory control samples (LCS) at a frequency of one per sample delivery group. Recoveries of 85-115% are required.

Section No.: 300.03
Revision No.: 1
Date: December 1939
Page: 2 of 2

Inorganic Anions in Water by Method 300.0 (Continued):

- 2. Analyze laboratory blanks at a frequency of one per group of 20 or fewer samples and after analysis of unusually concentrated samples.

 Laboratory blanks must not contain any anions at concentrations above the CRDL.
- 3. Samples containing anions at concentrations above the calibration range are to be diluted and re-analyzed. Report the results and documentation for both analyses.
- 4. Analyze matrix spikes at a frequency of one per group of 20 or fewer samples. Matrix spike concentrations are to be greater than 30% of the sample concentrations, but spiked samples must not exceed the working range of the standard curve. Recoveries of 85-115% are required.
- 5. Analyze laboratory duplicates at a frequency of one per group of 20 or fewer samples. The relative percent difference (RPD) of duplicate sample results must be less than 10%.
- 6. If above control limits are exceeded, take appropriate actions to correct the problems and re-analyze the affected samples.

Data Calculations and Reporting Units: Calculate the sample results according to Section 12 of EPA Method 300.0. Sample results are to be reported in the concentration unit of milligram per liter (mg/L). All records of analysis and calculations must be legible and sufficient to recalculate all sample concentrations and QC results. Include an example of the calculations in the data package.

<u>Documentation and Deliverables</u>: Identify the laboratory control sample as to source, reference sample lot number and the corresponding true value with 95% confidence interval. Report all bench records tabulating calibration standards (RT window, RF, %RSD and %D), laboratory control samples, laboratory blanks, samples, matrix spikes, laboratory duplicates, etc. Indicate date and time of analysis. Provide all raw data, including copies of instrument readouts and worksheets used to calculate results. Raw data are to be organized systematically and each page is to be numbered.

Section No.: 353,2 5 353 2

Revision No.: 1
Date: December 1989
Page: 1 of 2

Analysis of Nitrate and Nitrite in Water by EPA Method 353.2 or Method 353.3

Analytes: Nitrate and nitrite

<u>Sample Matrices</u>: Low concentration water samples (specify whether surface water, groundwater, drinking water, waste or leachate).

Analytical Procedure and Detection Limits: Follow the EPA Method 353.2 (colorimetric, automated, cadium reduction) or Method 353.3 (colorimetric, manual, cadmium reduction). Contract required detection limit (CRDL) is 0.10 mg/L as nitrogen (N) or lower.

- 1. Samples are to be kept at 4°C until analysis and validation of results are completed.
- 2. Prior to analysis, samples are to be neutralized to pH 5-9. Samples will be unfiltered.
- 3. Samples may be diluted up to ten-fold prior to analysis providing that the final analytical working range does not exceed 0.1 to 10.0 mg/L N.

Contract Holding Times: Contract required analysis holding time is 25 days from the date of sample receipt by the laboratory.

Calibration Procedure and Criteria:

- 1. Use at least five calibration standards (not including a zero standard) to obtain a standard calibration curve. The analytical working range must not exceed 0.1 to 10.0 mg/L N.
- 2. Calibration verification standards at the mid-point concentration are to be analyzed at a frequency of one per group of 10 or fewer samples and at the end of the analysis of a sample delivery group. Recoveries of 90-110% are required.
- 3. If more than one reduction column is used, separate calibrations, laboratory blanks and QC analyses are required for each reduction column. The column used must be identified for each analytical results.

Internal Quality Control Checks, Control Limits and Corrective Action:

- 1. Analyze one set of EPA Nutrient QC Reference Samples (Concentrations 1 and 2) or EPA F/NO₃ QC Samples (WS series, Concentrations 1 and 2) at a frequency of one per sample delivery group. Recoveries of 85-115% are required.
- 2. Analyze laboratory blanks at a frequency of one per group of 20 or fewer samples. Laboratory blanks are prepared by adding 1.0mL of H₂SO, to one liter of reagent water; neutralize prior to analysis. Laboratory blanks must contain less than 0.10 mg/L of nitrogen.
- 3. Samples containing nitrate/nitrite at concentrations above the calibration range are to be diluted and re-analyzed. Report the results and documentation for both analyses.

Section No.: 353.2 & 353.3

Revision No.: 1

Date: December 1989

Page: 2 of 2

Nitrate and Nitrite in Water by Method 353.2 or 353.3 (Continued):

4. Analyze matrix spikes at a frequency of one per group of 20 or fewer samples. Matrix spike concentrations are to be greater than 30% of the sample concentrations, but spiked samples must not exceed working range of the standard curve. Recoveries of 85-115% are required.

5. Analyze laboratory duplicates at a frequency of one per group of 20 or fewer samples. Difference in duplicate sample results must be less than 10% for concentrations exceeding 1.0 mg/L and less than 0.1 mg/L for concentrations below 1.0 mg/L.

6. If above control limits are exceeded, take appropriate actions to correct the problems and re-analyze the affected samples.

<u>Data Calculations and Reporting Units</u>: Calculate the sample results according to Section 8 of EPA Method 353.2 or Method 353.3. Sample results are to be reported to the nearest 0.1 mg/L for concentrations less than 1.0 mg/L N and to 2 significant figures for concentrations exceeding 1.0 mg/L N. All records of analysis and calculations must be legible and sufficient to recalculate all-sample concentrations and QC results. Include an example of the calculations in the data package.

Documentation and Deliverables: The test procedure used must be clearly identified. Identify the QC reference sample lot numbers used and the corresponding true values with 95t confidence intervals. Report all bench records tabulating calibration standards, laboratory control samples, laboratory blanks, samples, matrix spikes, laboratory duplicates, etc. Indicate date and time of analysis. All sample treatment to remove interferences are to be documented. Provide all raw data, including copies of absorbances or concentration read-outs and worksheets used to calculate results. Raw data are to be organized systematically and each page is to be numbered.

Revision No.: 160 1

Revision No.: 1

Date: December 1989

Page: 1 of 2

Analysis of Total Dissolved Solids (TDS) in Water by EPA Method 160.1:

Analytes: Total dissolved solids (TDS, 180°C)

<u>Sample Matrices</u>: Low concentration water samples (specify whether surface water, groundwater, drinking water, waste, or leachate).

Analytical Procedure and Detection Limits: Follow the EPA Method 160.1 (residue, filterable; gravimetric, dried at 180°C). Contract required detection limit (CRDL) is 20 mg/L of dissolved solids or lower.

1. Samples are to be kept at 4°C until analysis and validation of results are completed.

2. If the pH value is less than 4.0, raise the pH of the aliquot (using NaOH titrant) to between pH 4 and 8. Subtract the weight of sodium added from the weight of residue.

3. Residue will be weighed to constant weight pursuant to Section 7.6 of EPA Method 160.1. Constant weight is defined as a) less than 0.5 mg or less than 4% weight loss from the previous weight, whichever is smaller, or b) dried overnight (12 hours drying time) with a single weight used for calculations.

Contract Holding Times: Contract required analysis holding time is 5 days from the date of sample receipt by the laboratory.

Calibration Procedure and Criteria: Not applicable.

Internal Quality Control Checks, Control Limits and Corrective Action:

1. Analyze 1 set of EPA QC Mineral Reference Samples (at 2 concentration levels) at a frequency of one per sample delivery group. Recoveries of 85-115% are required.

2. Analyze laboratory blanks (100 mL of filtered reagent water) at a frequency of one per group of 20 or fewer samples. Laboratory blanks must contain less than 20 mg/L of TDS.

3. Use standard aliquots of 100 mL. If residue in sample is greater than 200 mg, repeat the analysis using a smaller sample aliquot.

4. Analyze sample duplicates at a frequency of one per group of 20 or fewer samples. Difference in duplicate sample results must be less than 10% for concentrations exceeding 200 mg/L and less than 2.0 mg/L for concentrations below 200 mg/L.

5. If above control limits are exceeded, take appropriate actions to correct the problems and re-analyze the affected samples.

Section No.: 160 1 Revision No.: 1 Date: December 1989 Page: 2 of 2

Total Dissolved Solids (TDS) in Water by Method 160.1 (Continued):

li

Data Calculations and Reporting Units: Calculate the sample results according to Section 8 of EPA Method 160.1. Sample results are to be reported in the concentration unit of milligram per liter (mg/L) of dissolved solids. All records of analysis and calculations must be legible and sufficient to recalculate all sample concentrations and QC results. Include an example of the calculations in the data package.

Documentation and Deliverables: Identify the QC reference sample lot numbers used and the corresponding true values with 95% confidence intervals. Report all bench records of tare weights, final weights, additional weights to determine constant weights and volume filtered for laboratory blanks, reference samples, samples, sample duplicates, etc. Indicate date and time of the determination of tare weights, sample filtration and determination of residue weights and constant residue weights. Provide all raw data, including copies of worksheets used to calculate results. Raw data are to be organized systematically and each page is to be numbered.

Section No.: R+S VIAs Revision No.: 1

Date: December 1939
Page: 1 of 1

Analysis of RAS & SAS TCL Volatiles in Water, 25 mL Purge:

Analytes: Routine Analytical Services (RAS) target compound list (TCL) volatiles.

Sample Matrices: Low concentration water samples.

Analytical Procedure and Quantitation Limits: Follow the RAS Statement of Work (SOW) for volatiles analysis. Samples are to be analyzed using a 25 mL purge volume, so that the quantitation limits will be decreased by a factor of 5. Contract required quantitation limits (CRQL) are 1.0 ug/L for compounds with RAS CRQL of 5 ug/L and 2.0 ug/L for compounds with RAS CRQL of 10 ug/L. RAS CRQL of 10 ug/L are acceptable for acetone, 2-butanone, 4-methyl-2-pentanone and 2-hexanone.

- 1. Capillary columns may be used for this analysis, as long as the laboratory uses the instrument parameters in EPA Method 524.2 as guidelines, uses the internal standards and surrogates specified in the RAS SOW and demonstrates that the analysis meets all the performance and QA/QC criteria contained in the RAS SOW and in this contract.
- 2. For foamy samples, fritless sparge tubes are recommended to reduce foaming of the samples. Dilution of the foamy samples is to be avoided.

Contract Holding Times: Contract required analysis holding time is 10 days from the date of sample receipt by the laboratory.

Calibration Procedure and Criteria:

- 1. Follow the calibration procedure specified in the RAS SOW. The 5 mL standards are to be diluted to 25 mL before purging.
- 2. QA/QC criteria in the current RAS SOW must be met, except that the response factor criteria for bromoform and 1,1,2,2-tetrachloroethane are not required.

Internal Quality Control Checks, Control Limits and Corrective Action:

Follow the QC requirements specified in the RAS SOW.

<u>Data Calculations and Reporting Units</u>: Follow the calculations specified in the RAS SOW. The sample results are to be reported in the concentration unit of microgram per litre (ug/L). All records of analysis and calculations must be legible and sufficient to recalculate all sample concentrations and QC results. Include an example of the calculations in the data package.

<u>Documentation and Deliverables</u>: Follow the documentation and deliverables requirements specified in the RAS SOW.

Analysis of Radon by EPA 600/2-87/082 Appendix B

Analyte. Radon

Sample Matrices. Low concentration groundwater samples.

Analytical Procedure and Detection Limits. Follow the liquid scintillation method described in Appendix B attached. Detection limits are affected by matrix interferences and counting times. A target detection limit of 100 pCi/L is desirable at a count rate not to exceed 1,000 minutes.

Contract Holding Time. Two days following sample collection,

24 hrs after receipt at

1 a 6 or a + or

Calibration Procedure and Criteria

- 1. Use traceable NBS radium 226 standard solutions for all Radon 222 analysis.
- 2. Calibrate the instrument according to the manufacturer's specifications, daily.
- 3. Calibrate for Radon 222 analysis according to Appendix B, daily.

Internal Quality Control Checks, Control Limits, and Corrective Action

1. The calibration and counting efficiency must be verified before use by analyzing a QC check sample of a traceable NBS radium 226 standard at a mid-level concentration. This QC check sample must also be run every 20 samples in the analytical batch and after the last sample. The recovery must be 80 to 120 percent of the true value. The laboratory may alternatively establish statistical control limits at 99 percent confidence (average ±3 standard deviations) using a minimum of 20 points. These limits must be updated at least annually.

- 2. Analyze a blank at a frequency of one per analytical batch or one per 20 samples of the same matrix, whichever is more frequent. The blank concentration must be less than the detection limit.
- 3. Analyze a duplicate and a spike at a frequency of one per analytical batch or one per 20 samples of the same matrix, whichever is more frequent. The laboratory must establish appropriate control limits for spike recovery at 99 percent confidence (average ±3 standard deviations) using a minimum of 20 points. These limits must be updated at least annually. The difference between duplicate results must not exceed 25 percent of their average.
- 4. If the above control limits are exceed, appropriate corrective action must be taken, and the affected samples must be reanalyzed.

Data Calculations and Reporting Units. Report results in pCi/L.

Documentation and Deliverables

- 1. Provide all sample and blank results.
- 2. Provide tabular summaries of QC check sample, spike, and duplicate results, showing reference numbers and control limits used.
- 3. Provide raw data of standard concentrations, counts per minute and counting times, sample volumes and dilutions. All raw data must be identified with sample numbers and dates and times of sample collection, dates and times of starting analysis, ingrowth in days, and all radiological calculations.

4. The data package must be systematically organized, with each page sequents numbered.

Other Requirements

Laboratory will provide the appropriate number of liquid scintillation vials (as described on page 25, Note 1 of the attached Appendix B) filled with 10 ml of liquid scintillation mix.

APPENDIX B

ANALYTICAL TEST PROCEDURE "THE DETERMINATION OF RADON IN DRINKING WATER"

(EPA EASTERN ENVIRONMENTAL RESEARCH FACILITY, MONTGOMERY, ALABAMA)

THE DETERMINATION OF RADON IN DRINKING WATER

ルン・エディ (L. 登留)

There are several published methods for the determination of radon (Rn-222). Those include de-emanation into a scintillation flask or Lucas Cell, gamma spectrometry, high volume extraction followed by liquid scintillation counting, and direct low-volume liquid scintillation counting.

Of the aforementioned methods, the last one is probably the most rapid and simplest while other methods may exhibit higher sensitivity. Good precision and accuracy have been shown for samples having radon concentrations of several hundred pCi/L or greater using direct, low-volume liquid scintillation counting. It is especially suited for large numbers of samples over a short period of time. For reasons previously stated, direct low volume scintillation counting is the recommended procedure for determining radon in drinking water, since high sensitivity (e.g., 1 pCi/L or less) is not necessary.

Principle

Samples are collected using the sampling procedure described in EPA/EERF-MANUAL-78-1. Samples are counted by liquid scintillation counting and radon concentration is computed from total count rate due to alpha and beta decay.

Special Apparatus

- 1. Sampling kit which includes a sampling funnel and tube with standard faucet fitting, two 12 mL disposable syringes with 20 gauge 1-1/2 inch hypodermic needles, and glass scintillation vials with 10 mL of liquid scintillation mix. See Note 1.
- Optional mailing tubes.
- 3. Liquid scintillation counter, ambient temperature, with automatic sample changer.

Reagents

1. Mineral oil based liquid scintillation mix PSS-007H or equivalent, if mailing via regular mail. Otherwise, a toluene based liquid scintillation mix is acceptable. See Note 2.

12-11---

Distilled water.

ಎಎ.ಎನ್. ಬಿಕ್ಕರಾ

3. A traceable National Bureau of Standards (NBS) radium-226 standard solution.

Procedure

- 1. Attach the sampling funnel and tube to a faucet with the standard faucet fitting.
- 2. Slowly turn on the water and allow a steady stream to flow out of the funnel for approximately 2 minutes. This purges the tube and assures a fresh sample.
- 3. Reduce the flow of water and invert the funnel. The flow should be adjusted to a level that does not cause turbulence in the pool of water contained in the funnel. Allow excess water to spill over one edge of the funnel.
- 4. Examine the hose connection and tubing for air bubbles or pockets. If these are visible, raise or lower the funnel until they are removed.
- 5. Place the tip of the hypodermic needle approximately 3 cm under the surface of the water in the funnel and withdraw a few mL of water and eject this water. Using this procedure, rinse the syringe and hypodermic needle two or three more times.
- 6. Again, place the tip of the needle approximately 3 cm below the surface of the water and withdraw approximately 12 mL.
 - NOTE: The water should be pulled into the syringe slowly to avoid extreme turbulence and collection of air bubbles. If large air bubbles are noticed in the syringe, the sample should be ejected and redrawn.
- 7. Invert the syrings and slowly eject any small air bubbles and extra water. Retain precisely 10 mL of water in the syrings.
- 8. Remove the cap from a vial and carefully place the tip of the needle into the bottom of the liquid scintillation solution. Slowly eject the water from the syringe into the vial.
 - NOTE: The water is injected under the liquid scintillation solution to prevent loss of radon from the sample. If the water is forced out of the syringe with much pressure, it will cause turbulence in the solution and could result in loss of radon.
- 9. Carefully withdraw the hypodermic needle from the vial and replace the cap. The cap should be tightly secured to prevent leakage.
- 10. Repeat the previous steps to obtain two separate samples from each source. This completes the sample collection.

11. If the vials are to be mailed, the two samples from each source should be individually wrapped with packing material such as newspaper or paper toweling, placed in the mailing tube, and mailed as soon as possible. Due to the short half-life of radon (3.82 days), the quick return of the samples for analysis is of primary importance.

Counting Procedure

1. Scintillation vials are cleaned with alcohol and shaken while allowing 3 hours before counting.

2. A background sample, consisting of 10 mL of distilled water and 10 mL of scintillation solution, and a standard radium-226 solution sample are counted for 50 minutes at the beginning of counting and after every 10 drinking water samples. Drinking water samples are also counted for 50 minutes.

3. An optional second counting of samples is desirable.

Preparation of Standard

1. Add a known quantity of traceable NBS radium-226 standard solution to a known volume of distilled water.

2. Combine a 10 mL aliquot of the radium-226 standard solution with 10 mL of scintillation mix in a 20 mL glass scintillation vial.

3. Allow approximately 21 days for buildup of radon (i.e., secular equilibrium with radium-226).

4. Shake vial to transfer nearly all the radon to the scintillation mix phase (radon is highly soluble in the scintillation mix). The radium-226 remains in the aqueous phase and, therefore, does not contribute significantly to the count rate.

 Allow the buildup of the radon short-lived progeny by waiting 3 hours before counting.

6. Count the standard and background samples for 50 minutes or longer.

7. Subtract the background counts per minute (cpm) from the gross cpm for the standard and divide by the known radon activity (i.e., radon activity equals radium-226 activity at secular equilibrium) to obtain the cpm/pCi conversion factor.

Calculations

Calculate the picocuries per liter of radon in the sample by using the following equation:

$$A = \frac{(C_S - C_B) (1000 \text{ mL})}{(CF) (D) (10 \text{ mL}) (1 \text{ liter})}$$

where: A = picocuries of radon per liter of, sample

Cs = sample cpm
Cs = background cpm

CF = cpm/pCi conversion factor

D = Decay correction.

Decay Correction:

0.693(T)

t1/2

Decay correction (0) = e

Time in days from collection time to midpoint of counting time.

Radiological half-life of raden, 3.82 days. $t_{1/2} =$

Notes

Liquid scintillation vials are standard 20 mL capacity. White caps 1. having polyethylene inner seals are used.

PSS-007H is available from Pilot Chemicals Division, New England 2. Nuclear, Watertown, MA 02172. Do not use a scintillation mix containing emulsifier.

References

Homma, Y. and Murakami, Y., 1977, J. Radioanalyt. Chem. 36, 177. 1.

Horton, T. R., 1983, "Methods and Results of EPA's Study of Radon in-2. Drinking Water, * EPA 520/5-83-027.

Lucas, H. F., 1957, "Improved Low-Level Alpha-Scintillation Counter 3. for Radon," Rev. Sci. Inst. 28, 680.

Lucas, H. F., 1964, "A Fast and Accurate Survey Technique for Both 4. Radon-222 and Radium-226," in The Natural Radiation Environment, U. of Chicago Press, 315.

5.

Noguchi, M., 1964, Radioisotopes 13, 362 (in Japanese).
Prichard, H. M. and Gesell, T. F., 1977, "Rapid Measurements of Rn-222 6. Concentrations in Water with a Commercial Liquid Scintillation Counter," Health Phys. 33, 577.

U.S. Environmental Protection Agency, 1978, "Radon in Water Sampling 7. Program, EPA/EERF-MANUAL-78-1.

Analysis of Gross Alpha/Beta Radioactivity by EPA 900.0

Analyte. Gross Alpha/Beta Radioactivity

Sample Matrices. Low concentration groundwater samples.

Analytical Procedure and Detection Limits. Follow procedure for EPA Metho 900.0, attached. Detection limits are dependent on sample size, counting system characteristics, matrix interferences, and routing times. The National Primary Interim Drinking Water Regulations (NPIDWR) require a gross beta detection limit of 4 pCi/L, and alpha detection limit of 1 pCi/L for compliance with Part 141.15(a) and a gross alpha detection limit of 3 pCi/L for compliance with Part 141.15(b).

Calibration Procedure and Criteria

- 1. Use traceable NBS American-241 standard solutions for all gross alpha calibrations.
- 2. Use strontium-90, equilibrium with ytttrium-90 for gross beta calibrations.
- 3. Calibrate all counting instruments according to manufacturer's specifications, daily.
- 4. For each counting instrument separate alpha and beta self-absorption graphs must be prepared.

Internal Quality Control Checks, Control Limits, and Corrective Action

- 1. The calibration and counting efficiency must be verified before use by analyzing a check samples of americium-241 for alpha and strontium-90 for beta at mid-level concentrations. These QC check samples must also be run every 20 samples in the analytical batch and after the last sample. The recoveries must be 80 to 120 percent of the true value. The laboratory may alternatively establish statistical control limits at 99 percent confidence (average ±3 standard deviations) using a minimum of 20 points for each alpha and beta measurements. These limits must be updated at least annually.
- 2. Analyze a blank at a frequency of one per analytical batch or one per 20 samples of the same matrix, whichever is more frequent. The blank concentrations of alpha and beta must be less than the detection limit.

- 3. Analyze a duplicate and a spike at a frequency of one per analytical batch or one per 20 samples of the same matrix, whichever is more frequent. The laboratory must establish appropriate control limits for spike recovery at 99 percent confidence (average ±3 standard deviations) using a minimum of 20 points. These limits must be updated at least annually. The difference between duplicate results must not exceed 25 percent of their average.
- 4. If the above control limits are exceed, appropriate corrective action must be taken, and the affected samples must be reanalyzed.

Date Calculations and Reporting Units. Report results in pCi/L.

Documentation and Deliverables

- 1. Provide all sample and blank results.
- 2. Provide tabular summaries of QC check sample, spike, and duplicate results, showing reference numbers and control limits used.
- 3. Provide raw data of standard concentrations, counts per minute and counting times, sample volumes and dilutions. All raw data must be identified with sample numbers and dates and times of sample collection, dates and times of starting analysis, ingrowth in days, and all radiological calculations.
- 4. The data package must be systematically organized, with each page sequentially numbered.

Appendix D CLP PAPERWORK INSTRUCTIONS

U.S. EPA Region 9 CLP PAPERWORK INSTRUCTIONS

Paperwork is provided to the sampler by the Region 9 RSCC one week before sampling begins. The samplers must contact the RSCC to obtain paperwork.

ORGANIC AND INORGANIC TRAFFIC REPORTS

Use these forms when shipping RAS or RAS plus SAS samples. Complete one form per laboratory, per shipment. It is not necessary to include a Traffic Report in each cooler.

- Top Right A Case Number is assigned to the sampling project when a SMO coordinator initiates the lab selection process. The Region 9 RSCC will notify the sampler of the case number by phone. This same case number should also appear on the corresponding Chain-of-Custody Record. If the lab will be conducting Special Analytical Service (SAS or RAS+SAS), the SAS number must also be recorded on the form.
 - Box 1 Circle the appropriate Superfund code. If sampling is non-superfund enter the program name, e.g., RCRA.

PA - Preliminary Assessment

SI - Site Investigation

ESI - Expanded Site Investigation

RIFS - Remedial Investigation Feasibility Study

RD - Remedial Design RA - Remedial Action

ER - Emergency Response (Removal)
NPLD - National Priorities List Delete

0&M - Operations and Maintenance

Enter the site name, the city, state, and Superfund site spill ID code (provided by the region) in the designated spaces. This information does not go through to the Lab's copy.

- Box 2 Enter Region No. 9, your sampling company and your name.
- Box 3 Enter the name, address and contact person of the CLP lab contracted to do the analyses. This information is supplied to the sampler by the RSCC after the lab contract has been awarded.
- Box 4 Enter the beginning and ending sampling dates.

Box 5 - Enter the date shipped, the carrier code (e.g., F = Federal Express) and the airbill number.

COLUMNS

- Left edge column Carefully transcribe the CLP Sample Number from the printed sample labels provided. A stack of labels will be provided to the samplers by the RSCC.
- Col. A Enter the appropriate sample description code from Box 6. Note: Item #6 "Oil" and Item #7 "Waste" are for RAS plus SAS projects only.
- Col. B Organic If sample is estimated to be <u>low or medium</u> concentration, enter "L". If sample is high concentration (comprised of more that 15% of a compound), it must be sent to a SAS lab. Notify the Region 9 RSCC if you need a SAS lab for high concentration samples.

Inorganic - Enter the estimated concentration. Low level is less than 10ppm of a for a single compound; medium level is between 10ppm and 15 percent; and high level is above 15 percent.

REMINDER: Ship medium and high concentration organic and inorganic samples in metal cans.

- Col. C Check the appropriate RAS analytical fractions requested for each sample.
- Col. D Special Handling Instructions include information about potential contaminants and SAS requirements. When shipping RAS plus SAS samples, coding the SAS parameters will save space (e.g. A = sulfate, B = low detection limits). Also, designate the Lab QC Sample by writing "Lab QC" in this column.
- Col. E Enter the station location number corresponding to the CLP sample number.

Bottom of Page - In space available list any preservatives used (e.g., VOAs preserved with 2 drops 1:1 HCl).

Back Page - Instruction summarizing CLP sample volumes, packaging and reporting requirements are printed on the back of the Traffic Reports..

SAS PACKING LIST

If samples are shipping samples for Special Analytical Services (i.e., SAS only) then the SAS Packing List replaces both the Organic and Inorganic Traffic Reports.

Complete one form per laboratory, per shipment. It is not necessary to include a SAS Packing List in each cooler.

- Area 1 SAS Number is assigned by SMO when the sample management coordinator initiates the sample project. The SAS Number should also appear on the Custody Record. All Region 9 SAS numbers end in Y; contact the RSCC for your SAS number.
- Area 2 Sampling Office is Region 9 plus the sampler's office, e.g., Rg 9 E&E. The head sampler puts his/her name and office phone number in the provided space.
- Area 3 Sampling Date(s) for the samples shipped.
- Area 4 Date samples shipped to laboratory.
- Area 5 Put the site name or code. This space does not go through to the lab copy.
- Area 6 Shipping address for the laboratory.
- Area 7 Sample numbers are created by the sampler. Each sample must be assigned a <u>unique</u> sample number that included the SAS number as a prefix, followed by a consecutive two or three digit number. For example, if the SAS number is 3441Y for a three sample shipment, the sample numbers would be 3441Y-01, 3441Y-02, and 3441Y-03. This number must also be placed on the chain-of-custody in place of the Traffic Report numbers.
- Area 8 Sample Description must include the following information sequentially: Concentration, Matrix, Analysis (i.e., medium soil for Boron). The sample preservation must also be included on the form; this information can be added to the unused lines at the bottom of the form.

CHAIN-OF-CUSTODY RECORD

Use this form with <u>all</u> sample shipments. Enclose one Chain-of-Custody form in each cooler being shipped.

Project Name: Use the SMO assigned CASE/SAS number. Do not give the actual Project Name!

Samplers: Sampler(s) sign here.

STA. NO.: (Optional) Any number that is appropriate.

Date and Time: Both must be included.

Comp/Grab: Mark if the sample is a composite (a sample composed of more than one discrete sample) or a grab (a discrete sample).

- Station Location: Use the station location abbreviation that was used in the sample plan to designate sampling locations on the maps and tables.
- No. of Containers: Write in the number and size of containers. If necessary, use more than one row for each sample.
- Slanted Lines: Write the analyses requested on the slanted lines and check the boxes below for the analyses requested on each individual sample.
- Remarks: Write in the traffic report or SAS sample numbers corresponding to each station location number.

Write the name of the laboratory in the upper right corner, above the word REMARKS.

Signature Boxes: The person who turns the samples over to the shipper signs and dates in the first relinquished by box.

This persons signature must be included in the "Samplers" box. Write in the airbill number in the first "Received by" box.

FIELD QA/QC SUMMARY FORM

Complete one form per lab, per matrix for each sampling event, or with long-term projects, complete a form(s) after every month of sampling. Complete all appropriate sections.

Section IV duplicate types are defined below:

- a = Composite split: Duplicate samples collected in an intermediate vessel, homogenized, and then split into separate samples.
- b = Consecutive: Duplicate samples collected one after the other from a flowing source, e.g., ground water samples collected with a pump.
- c = Colocated: Duplicate samples collected at the same location from a source that is not flowing, e.g., ambient air or grab samples from ponds.

DISTRIBUTION OF COPIES

The following is a form by form detail of copy distribution:

- 1. Chain-of-Custody Record original accompanies samples, pink copy to QAMS, and a photo copy for sampler's files.
- 2. Traffic Reports original to SMO, second copy (pink) to QAMS, third and fourth copies accompany samples and a photo copy for sampler's files.
- 3. SAS Packing List top copy (white) to SMO, second copy (yellow) to QAMS, third (Pink) and fourth (gold) copies go with the samples, and a photo copy for sampler's files.
- 4. Field QA/QC Summary Form Original to QAMS, and a photo copy for sampler's files.

QAMS address is:

U.S. EPA Region 9
Quality Assurance Mgmt Section
(P-3-2)
215 Fremont St.
San Francisco, CA 94105
Attn: RSCC

SMO address is:

Sample Management Office P.O. Box 818 Alexandria, VA 22313

CALLING IN SHIPPING INFORMATION

Samplers are required to call the RSCC in the Region 9 Quality Assurance Management Section on the day or day after any samples are shipped to a CLP or EPA laboratory. The RSCC's number is 415/974-0925. If the RSCC is unavailable, call the SMO Region 9 Coordinator at (703)557-2490. If you were planning to ship but did not, you must also call in.

The following information must be provided to the RSCC:

- A. Number of samples shipped for each matrix and the date shipped.
- B. Name of lab(s) samples were shipped to.
- C. Airbill number(s).
- D. The next scheduled sampling date.
- E. Any significant changes to the sampling schedule or the sample plan.
- F. If samples will be shipped on a Friday, the above information must be called in before 12:00 noon on Friday.

SAS NU. 1004Y CASE NO: 103771

ORGANIC TRAFFIC REPORT

| | | | 4 | | | | | | | | | | | |
|---|--|---------------------------------|-------------------|----------|-----------|--------------------------|----------------|----------|-------------------|----------------|-------------|-------|--|---|
| • | TYPE OF ACTIVITY (CIR SUPERFUND-PA SI | _ | | RA | ① ER | SHII | 70 | CKY | MTN A | WL ÝTIC | AL | | SAMPLE DESCRIPTION ER IN BOX A) 4. SOIL IRFACE WATER 5. SEDIMENT | ₿ |
| | NON-SUPERFUND | MAO | OTHER | OGR | | | • | • | YARRO A, CC | | | 2. GF | ROUND WATER 6. OIL (SAS) ACHATE 7. WASTE (SAS) | |
| | SITE NAME: Q M | T 6 | DES N | Š | 3H | | | | • | | | | LE VOLUME REQUIRED FOR MATRIX | |
| | ()[] | 7 [| 0 46 | | <u> </u> | ATT | N: | AIH | Y HUTC | HINA | <u> </u> | SPIKI | E/DUPLICATE AQUEOUS SAMPLE | |
| | CITY, STATE: SITE SPILL II HENDERSON NV 32 | | | | | | SAMPLING DATE: | | | | | | MEDIUM AND HIGH CONCENTRATIO | N |
| | REGION NO: SAM | APLING | COMPA | VNY | 0 | | | | | | | | | |
| | SAMPLER: (NAME) | | | | - | | | | 1/13/89CAF | | | | SEE REVERSE FOR ADDITIONAL INSTRUCTIONS | |
| | IRMA DO | OE | | | | AIRBILL NO: 123-123-1234 | | | | | | | | |
| - | | Ø ~ | B 3 | 0 | | | | 0 | | € | | | | |
| | | IPTIO 6 | NO HIGH (\$AS) | | | AS LYSIS | 5 | 1 - | PECIAL INDLING | - | CATION | | · | |
| | · | ESCH (1) | ¥ TIC | | 5 | <u>w</u> | | | | | | | | |
| | CLP SAMPLE | 000 | ENT | VOLATILE | BASE/NEUT | PESTICIDE /PCB's | | | | | | | | |
| | NUMBER (FROM LABELS) | SAMPLE DESCRIPTION (FROM BOX 1) | CONCENTRATION | ğ | BASE | PES | | <u> </u> | | | | | | |
| - | YC. 301. | 2 | L | X | X | | | AB | LABCC | GI | NIC |) | | |
| | YC 302 | 2 | L | X | X | | | AB | | GV | VII | | | |
| | YC. 303 | 3. | L | X | X | | | AB | | GV | V12 | | | |
| _ | YC. 304 | 2 | L | X | X | | | AB | | GI | N 27 | 2 | | |
| | YC 3C5 | 4 | L | X | X | | | B | LABOC | 5 | 301 | | | |
| _ | YC 306 | 4 | L | X | X | | | B | | <u>S</u> | 502 | | | |
| - | YC.307 | 4 | <u>_</u> | X | X | | | B | | 5 | 203 | } | | |
| _ | YC, 308 | 4 | <u></u> | X | X | | | B | <u> </u> | 5 | 304 | | | |
| - | YC.309 | 4 | <u></u> | X | X | | | B | | 55 | ,14 | | | |
| _ | | | | | | | | | | <u> </u> | | | | |
| - | | 1 | ļ | _ | _ | | | | | <u> </u> | | | | |
| _ | | <u> </u> | | | _ | | | | | | | | | |
| _ | | | - | - | | | | | | | | | • | |
| - | | | | - | _ | | | | | ļ | | | | |
| - | A = low | | 0+ | 00 | 1 | | ~ | 1:0 | nits | 100 | | | | |
| - | VOI | h + | 10 | | 1 | ٧ | 1 \ | ur | 1100 | 101 | | | | |
| - | VOI | <u> </u> | ,,, | | | | | | | | | | | |
| | , | | | | | | | 1 | | • | | 1 | | |

EPA Forin 2075-7 (8-87)

<u>B</u> =

WATER VOA ALL

TURNARDUND

SAMPLES PRESERVED WITH HCI

21

DAY

EPA Form 2075-6 (8-87)

SAMPLE MANAGEMENT OFFICE P.O. BOX 818 ALEXANDRÍA, VA 22313 703/557-2490 FTS-557-2490

INORGANIC TRAFFIC REPORT

| TYPE OF ACTIVITY (CIRCLE ONE) | SHIP TO: \/ | SAMPLE DESCRIPTION |
|-----------------------------------|-----------------------------------|---|
| SUPERFUND-PA SI ESI RIFS AD RA ER | VERSAR | (ENTER IN BOX A) 4. SOIL |
| NPLD OAM OTHER | 6850 VERSAR CIR | 1. SURFACE WATER 5. SEDIMENT 2. GROUND WATER 6. OIL (SAS) |
| NON-SUPERFUNDPROGRAM | | 3. LEACHATE 7. WASTE (SAS) |
| | | |
| SITE NAME: CMT | 7 | DOUBLE VOLUME REQUIRED FOR MATRIX |
| 01 11 | ATTN: JANET BECKMAN | SPIKE/DUPLICATE AQUEOUS SAMPLE |
| CITY, STATE. SITE SPILL ID: | | |
| HENDERSON, NV 32 | SAMPLING DATE: | SHIP MEDIUM AND HIGH CONCENTRATION |
| | 11,2100 11,7100 | SAMPLES IN PAINT CANS |
| REGION NO: SAMPLING COMPANY 2 | BEGIN: 1/13/89 END: 1/13/89 | |
| 1 9 NATURE CO | DATE SHIPPED: 1/3189 CARRIER: F 6 | SEE REVERSE FOR ADDITIONAL |
| SAMPLER: (NAME) | DATE SHIPPED: 11210 CARRIER: | INSTRUCTIONS |
| IRMA DOE | AIRBILL NO: 123-123-1244 | |
| | All loice ivo. | <u> </u> |

| | B ~ | B . | 0 | | _ | | | | | О | € |
|--|---------------------------------|---------------|--------------|---------|-----------------------|-------------|----|----------|----------|---------------------|---------------------|
| | | Ser. (See | | | A | RA: NALY | _ | | | SPECIAL HANDLING | STATION LOCATION |
| | SCRIPTIC 1) | ATION H | ETAL S |)E | HIGH ONLY (SAS) | | | | | | |
| CLP SAMPLE NUMBER (FROM LABELS) | SAMPLE DESCRIPTION (FROM BOX 1) | CONCENTRATION | TOTAL METALS | CYANIDE | DISSOLVED | SULTIDE | £. | COMBUC | ORIDAMTS | | |
| MYB 990 | 2 | L | X | | | | | | | AB OC | GWIO |
| MYB 991 | 2 | L | X | | | | | | | AB | GWII |
| MYB 992 | 2 | | X | | | | | | | AB | GW12 |
| mvB 993 | 2 | L | X | | | [| | | | AB | GWZZ |
| MYB 994 | 4 | M | X | | | | | | | BEC | 5501 |
| my8 995 | 7 | M | X | | | | | | | B | 5502 |
| MYR 996 | 4 | M | X | | | | | | | В | 5503 |
| MÝB 997 | 4 | 1/1 | Х | | | | | | | B | 5504 |
| myb 998 | 4 | M | X | | | | | | | В | 5514 |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| A: NITRA | TE / | NI | -R V | TE | | | | | | | |
| | | | | | | | | | | | |
| B: 21 04 | 7 7 | URN | 4R | טט | 70 |) | | | | | |
| | | | | | | | | | | | |
| NITRATE / NITE | πE | PRES | £ | VE | ٧, | ıπ | 1 | H2 | SC | 4 | |
| METALS WAT | ER S | AMP | LE | 5 | PRE | 54 | VE | D | I | HNO3 | |

U.S. ENVIRONMENTAL PROTECTION AGENCY

CLP Sample Management Office

P.O. Box 818 - Alexandria, Virginia 22313

Phone: 703/557-2490 - FTS/557-2490

SAS Number 2525 Y

SPECIAL ANALYTICAL SERVICE PACKING LIST

Sampling Office: Ship To: (6) For Lab Use Only Sampling Date(s): 7/25/38 SILVER VALLEY Date Samples Rec'd: ONE GOVERNMENT GUICH Sampling Contact: Date Shipped: 7125/88 KELLOGG, ID (name) 83837 Received By: Site Name/Code: 5 777 - 7777 OII415 Attn: COLLEEN BRAUN (phone)

| (T | Sample Numbers | Sample Description i.e., Analysis, Matrix, Concentration | Sample Condition on Receipt at Lab |
|----------|-------------------|--|---------------------------------------|
| 1. | 2525Y-01 | low/water for Analyses A | |
| 2. | 25254-02 | 100/water for Analyses A - use for | lab (CC |
| 3. | <u> 2525Y-03</u> | Towlwater for Anatyses A | |
| 4. | 2525Y-04 | lowluster for Analyses A | |
| 5. | 2525Y-05 | 10w/water for Analyses A | <u> </u> |
| 6. | 2525Y-06 | low/water for Analyses A | |
| 7. | 2525Y-07 | med soil for EP TOX METALS | |
| 8 | 2525Y-08 | med Isuil for EP Tax metals | |
| 9. | 2525Y-09 | med/sorl for EP Tox metals | |
| 10 | 2525Y-10 | med soil for EFT or metals-us | se for lab (I.C. |
| 11 | | | |
| 12. | | | |
| 13 | | · · · · · · · · · · · · · · · · · · · | |
| 14. | 1 | | 7 |
| 15 | <u>Analyses</u> | 1 = Chloride, Sulfate, Nitrate, | |
| 16. | | Flouride, TDS, conductivity | 5 , ————— |
| 17. - | Preservati | on: Nitrale/Nitrite preserved | N H2SC4 |
| 18. | | | |
| 19. | | | |
| 20. | | | |
| | | | |

REGION 9 215 Fremont Street

San Francisco, California 94105

| | | | · . | | | | CHAIN | OF CUST | OD' | Y RE | COF | RD | | | | | San Francisco, California 94105 |
|---|-----------|---------------------|---------|------------|--------------|--------------|--|-----------------|-------|--------|-------|----------|--------|----------|---------------------------------------|--------------|---------------------------------|
| PROJ. | NO. | PROJEC [*] | | | 7/1 | 166 | Y' | NO. | | | | <i> </i> | | Τ, | /// | / F | PMAL_ |
| SAMPLE | as: (sign | erure) | | <u>J</u> (| 3ne. |) | | OF CON- | 3/// | | | | | // | | | REMARKS |
| STA. NO. | DATE | TIME | COM | GRAB | | | N LOCATION | TAINERS | | | | | /_ | Sample # | | | |
| 006 | 9/28 | 8:00 | | X | M١ | 11-1 | | 2×18 | X | X | | | | | MÝ | CCC | |
| <u></u> | | | | | · . | | ···· | 1×405 | | | X | | | | · · · · · · · · · · · · · · · · · · · | - <u>-</u> - | |
| F00 | 9/28 | 8:30 | | X | MV | U-2 | | 2x12 | X | X | | | | | MYC | 010 | |
| | ļ | | | | | | | 1×402 | | | X | | | _ | | | • |
| 008 | 9/28 | $n:\infty$ | | X | Mu | 1-3 | | 4x18 | X | X | | | | | MYO | 011 | USE FOR |
| | | | | | | | | 2 × 402 | | | X | | | | | | LAB QC- |
| 009 | 9/28 | 11:30 | | X | MW | !-4 | | ZXIR | X | X | | | | | myc | 012 | |
| | | | | | | | | 1×402 | | | × | | | | | | |
| 010 | 9/28 | 12:00 | | Χ | M۷ | 1-5 | | 2×18 | X | Χ | | | | | myc | 013 | |
| | | | | | | | | 1x402 | | | X | | | | | | |
| | | | | | | | | | | | | | | | | | |
| | | | | | | | · | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | · |
| | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| Relinquist podeer | | | | q | Date / | Time 17:∞ | Received by: (Signature A IRBILL NUIMBER | , | Reli | nquisl | ned b | y: (Sign | eture) | | Da | e / Time | Received by: (Signature) |
| Relinquist | red by: / | Signature) | 1 | | Date / | Time | Received by: (Signature) | , | Relia | nquist | ed by | y: (Sign | | | | e / Time | Received by: (Signature) |
| Relinquished by: (Signature) Date / Time Received for Laboratory (Signature) | | | | ry by: | | Dat | 7Ti | me | Rema | arks | | | | | | | |
| | | Dist | ributii | on Or | iginal Accor | mpanies Si | nipment; Copy to Coordina | tor Field Files | | | | | 1 | | | | |

FIELD GA/GC SUMMARY FORM

| Date: | · · · · · · · · · · · · · · · · · · · | Site: | | _ |
|---|--|----------------------------|------------------------|--|
| Sampler: | | Case/SAS #: | | - |
| | | Laboratory: | | _ |
| Phone #: | <u> </u> | | | |
| Matrix: (check one) | Groundwater Surface Water | Surface Soi | lAir SoilOthe | · r |
| I. BLANKS | | | II. BACKO | ROUND SAMPLES |
| Sample # | . Type (circle one) (| ate Collected | Sample # | Date Collected |
| | Equip/Field/Travel | | | |
| | Equip/Field/fravel | <u>.</u> | | |
| | Equip/Field/Travel | | | |
| | Equip/Field/Travel | | | |
| <u> </u> | Equip/Field/Travel | | | |
| | Equip/Field/Travel | | III. LAB QC | SAMPLES |
| | Equip/field/Travel | | Sample # | Date Collected |
| | Equip/Field/Travel | | | |
| | Equip/field/Trayel | | | |
| | Equip/Field/Travel | | | <u></u> |
| | Equip/Field/Travel | | | |
| | Equip/Field/Travel | | | |
| IV. <u>DUPLICAT</u> Sample # M | ES atches Sample # Date | a/ a/ a/ a/ a/ | b/c/d b = b/c/d c = | composite split consecutive colocated consecutive soil sleeves |
| None Pumping E Sample Fi Less Than | t of Field Problems Eng quipment Problems ltering Problems Required Sample Voluma Recharge Rates | Sample #/ Dat | e(s) of Occur | rrence /Comments |
| Preservat | | | | |
| Sample Sh | ipment Delay | | | |
| Sample Sh | | | | |

Appendix E EXAMPLES OF FIELD LOGBOOKS



GROUNDWATER QUALITY SAMPLING DIARY

| PROJECT: _ | | | |
|------------------|------|---|--|
| | | | |
| - | | | |
| | | | |
| | | · | |
| INCLUSIVE DATES: | | | |
| ED/OM | TO | | |

Capacities of Well Casing

| Diameter of Holes — Inches | Gallons per Linear Foot | Sacks of Cement per Linear Foot | Linear Feet per Sack of Cement | Cubic Yard of Grout to Fill 100' of Hole |
|-------------------------------|----------------------------|------------------------------------|-----------------------------------|---|
| 11/4" | 0.064 | 0.007 | 137.8 | .03 |
| 2" | 0.163 | 0.020 | 50.2 | .08 |
| 3" | 0.367 | 0.031 | 32.1 | .18 |
| 4" | 0.653 | 0.079 | 12.6 | .32 |
| 5″ | 1.020 | 0.124 | 8.0 | .50 |
| 6" | 1.468 | 0.178 | 5.6 | .73 |
| 8" | 2.611 | 0.337 | 3.2 | 1.3 |
| 10" | 4.080 | 0.496 | 2.0 | 2.0 |
| 12" | 5.875 | 0.714 | L4 | 2.9 . |
| 14" | 7.9 96 | .972 | 1.03 | 4.0 |
| 16" | 10.448 | 1.270 | 0.78 | 5.2 |
| 18" | 13.219 | 1.606 | 0.62 | 6.5 |
| 20″ | 16.320 | 1.983 | 0.50 | 8.1 |
| 24" | 23.501 | 2.856 | 0.36 | 11.6 |
| 30″ | 36.720 | 4.462 | 0.22 | 18.2 |
| 36 ″ | 52.877 | 6.426 | 0.15 | 26.2 |

One sack cement = 1.1 foot^3

ORDER OF PREFERRED SAMPLE COLLECTION

- 1. Volatile organics (VOA)
- 2. Purgeable organic carbon (POC)
- 3. Purgeable organic halogens (POX)
- 4. Extractable organics
- 5. Pesticide/Herbicide
- 6. Dibenzofuran/Dioxin
- 7. Total metals
- 8. Dissolved metals
 - 9. Total organic carbon (TOC)
- 10. Total organic halogens (TOX)
- il. Phenois
- 2 12. Cyanide
 - 13. Nitrate and Ammonia
 - 14. Sulfate and chloride
 - 15. Nitrate and ammonia
 - 16. Radionuclides

-

GROUNDWATER SAMPLING FIELD DATA SHEET

| | - | • | | |
|---|--------|-------------|------------------|---------------------------------------|
| FIELD CONDITIONS | | | | |
| FIELD MEASUREMENT/ COLLECTION EQUIP. | • | • | SERIAL/ID NO. | CALIBRATION/ COMMENTS |
| pH METER | | | | |
| CONDUCTIVITY METER | | | | |
| THERMOMETER | | | | |
| WATER LEVEL INDICATOR | | | | · |
| BAILER/PUMP | | | | · · · · · · · · · · · · · · · · · · · |
| DECONTAMINATION | | | | · |
| | | | | |
| · | | | | |
| PURGE INFORMATION | | | | |
| DATE | ST | ART TIME | 8 | END TIME |
| INITIAL DEPTH TO WATER | WEL | L DEPTH | EST. WELL | BORE VOL |
| FINAL DEPTH TO WATER | _TOTAL | VOL. PURGED | DISCH | ARGE RATE |
| METHOD | | PUMP DEPTH | | · |
| VOLUME PURGED TEMPERATURE | рН | CONDUCTIVIT | Υ | APPEARANCE |
| | _ | | | |
| | _ | | | |
| | | | | |
| | | | | |
| | | <u> </u> | | |
| | | | | |
| SAMPLING INFORMATION | | | | |
| | | | | CND TEMP |
| METHOD | | | | END TIME |
| MCINUU | | | | |

| N□, * | TEMP | рŀ | 4 | CONDUCTIV | /ITY | APPERA | NCE/COMM |
|---------------|--------------|------|---------------------------------------|-------------|--------------|---------------------------------------|----------|
| 1 | | | | | | | |
| 2 | | | | | | | |
| 3 | | | | | | | |
| 4 | | | | | | | |
| | | | | | | | |
| SHIPPING INFI | ORMATION . | | | | | | |
| SAMPLE NO. | LABORATOR | Y | C | ARRIER | | SHIPPING DATE | A 1 |
| | | | | | | | |
| | | | | | - | | |
| <u></u> | | | | | - | | |
| | | | | | | | - |
| | | | | | | | |
| | | | | <u> </u> | | | |
| | 1 | I | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| COMMENTS/ | EXCEPTIONS | : TO | SAI | P AND G | PAPP | | |
| COMMENTS/ | 'EXCEPTIONS | т п | SAI | P AND G | PAPP | | |
| COMMENTS/ | 'EXCEPTIONS | : To | SAI | P AND G | APP | | |
| COMMENTS/ | 'EXCEPTIONS | T . | SAI | P AND G | APP | | |
| COMMENTS/ | 'EXCEPTIONS | т. | SAI | P AND G | APP | | |
| | 'EXCEPTIONS | T | SAI | P AND G | APP | | |
| | | TO | | | | | |
| | | | · · · · · · · · · · · · · · · · · · · | | | | |
| | | | | | | | |
| | | | | | | · · · · · · · · · · · · · · · · · · · | |
| | | | | | | · · · · · · · · · · · · · · · · · · · | |

lpha RCRA replicates should be measured following complete purge.

Appendix F CH2M HILL SITE SAFETY PLAN

CH2M HILL HEALTH AND SAFETY PLAN

This plan will be kept onsite during field activities and will be reviewed and updated as necessary. This plan adopts, by reference, the standards of practice (SOP) contained in the CH2M HILL Wasic Management and Industrial Processes Discipline Health and Safety Manual, Volumes 1 and 2, and other applicable CH2M HILL SOPs as appropriate. The Site Safety Coordinator (SSC) is to be familiar with these SOPs. In addition, this plan adopts procedures contained in the work plan for the project.

1.0 PROJECT INFORMATION AND DESCRIPTION

CLIENT:

U.S. EPA

PROJECT NO: SFO69114.FI.SC

OWNER:

National Priority List

OFFICE: SFO

PROJECT MANAGER: Sybil Hatch

SITE NAME:

San Fernando Valley, California

SITE ADDRESS: Four National Priority List (NPL) Sites - North Hollywood, Crystal Springs,

Pollock, and Verdugo

DATE(S) OF INITIAL VISIT: March 1988 through January 1989

DATE(S) OF SITE WORK:

November 1991 through January 1993

SITE ACCESS:

Varies with location. The overall well locations are shown in Figure 2 of the Work Plan. Locations for individual cluster wells and VPBs, including street names and dimensions, are provided in Appendix A.:

SITE SIZE: 122.800-acre area

SITE TOPOGRAPHY: Varies with location.

SITE DESCRIPTION AND HISTORY:

The San Fernando Valley Basin contains four National Priority List (NPL) sites: North Hollywood, Crystal Springs, Pollock, and Verdugo (Figure 1). The primary groundwater contaminants within these areas consist of the volatile organic compounds trichloroethene and perchloroethene. As part of Remedial Investigation work in the basin, 15 cluster well sites containing 44 individual monitoring wells screened at different depths and 43 shallow monitoring wells (VPBs) were installed throughout the basin (Figure 2). The Los Angeles Department of Water and Power conducted two quarterly sampling events in the basin during January and April 1991. Well data are provided in Appendix B.

Land use on the four NPL sites consists primarily of residential and urban areas. The climate is semiarid and typical of Southern California.

THIS PAGE RESERVED FOR MAP

2.0 PROJECT ORGANIZATION AND TASKS TO BE PERFORMED UNDER THIS PLAN

2.1 PROJECT ORGANIZATION

- 2.1.1 Monitoring Well Pump Installations Transporting Purged Well Water
- 2.1.2 Monitoring Well Pump Installations Installing Submersible Pumps

2.2 DESCRIPTIONS OF TASKS

2.2.1 The work to be performed consists of providing a vacuum truck and crew to transport purged well water from 73 monitoring wells during dedicated pump installation and 87 monitoring wells during quarterly and annual sampling events. Purged well water will be transported to the LADWP's North Hollywood Aeration Facility (NHAF), and will be transferred to storage tanks provided by the subcontractor at the NHAF.

The work consists of, but is not limited to, the following:

- a. Providing a 5,000-gallon vacuum truck and crew to obtain purged well water directly from wells.
- b. Transporting and transferring the purged well water and decontaminate rinsate into storage tanks at LADWP's NHAF.
- c. Providing three 21,000-gallon storage tanks at LADWP's NHAF.
- d. Providing these services for others during (1) dedicated pump installation and testing and (2) quarterly well monitoring program.
- 2.2.2 The work to be performed consists of installing dedicated submersible pumps for purging the wells, dedicated bladder pump for sampling the wells, and accessories for 73 existing monitoring wells.

The work consists of, but is not limited to, the following:

- a. Install dedicated submersible pump, associated column piping, and motor leads.
- b. Install dedicated bladder pump and associated tubing.
- c. Install sounding pipe.
- d. Install new top of well casing compression seal.
- e. Conduct a 30-minute performance test of both pumps.
- f. Clean and restore the site.
- 2.2.3 Included in the work is decontamination, cleanup, and other elements as specified.

2.3 NAME AND ROLE OF SUBCONTRACTOR FIRMS

Not known

3.0 HAZARD EVALUATION AND CONTROL

3.1 HEAT AND COLD STRESS (Reference CH2M HILL SOP HS-09)

3.1.1 GUIDELINES FOR WORKING IN TEMPERATURE EXTREMES WHILE WEARING PERSONAL PROTECTIVE EQUIPMENT (PPE)

| Temperature | Work Cycle | Rest Cycle | Control Measures | | | | |
|-------------------------------|------------|------------|--|--|--|--|--|
| <32° F or <55° F & raining | 2 hrs | 15 min | Review cold stress in safety meeting. Rest in a warm are Drink at least 8 ounces of warm non-caffeinated, not alcoholic beverage at each rest break. Schedule a mid-dalunch break of at least 30 minutes in a warm area to beginnt later than 5 hours after startup. | | | | |
| 72° to 77° F | 2 hrs | 5 min | Review heat stress in safety meeting. Take resting pulse rate before beginning work. Drink 8 ounces of cool water before beginning work, and 4 ounces at rest break. Have ice available. | | | | |
| 77° to 82° F | 2 hrs | 5 min | As above, but seated rest break. Monitor pulse rate. (See below.) | | | | |
| 32° to 87° F | 60 min | 15 min | As above, but rest area to be shaded. | | | | |
| 37° to 90° F | 30 min | 15 min | As above. Try to provide a shaded work area. | | | | |
| >90° F | 15 min | 15 min | As above. Provide a shaded area with seats in the work area for team members to use as needed. Try to reschedule work to avoid mid-day heat. | | | | |

PULSE CRITERIA. Take resting radial (wrist) pulse at start of work day; record it. Measure radial pulse for 30 seconds as rest period begins. Pulse not to exceed 110 beats per minute (bpm), or 20 bpm above resting pulse. If pulse exceeds this criteria, reduce work load and/or shorten the work cycle by one third, and observe for signs of heat stress. No team member is to return to work until his/her pulse has returned to <110 bpm, or resting pulse +20 bpm.

| 3.1.2 SYMPTOMS ANI | 3.1.2 SYMPTOMS AND TREATMENT OF HEAT AND COLD STRESS | | | | | | | | | | |
|--|---|--|---|--|--|--|--|--|--|--|--|
| Heat Stroke | Heat Exhaustion | Frostbite | Hypothermia | | | | | | | | |
| Red. hot. dry skin: dizziness: confusion: rapid breathing and pulse: high body temperature. | Pale, clammy, moist skin: profuse sweating; weakness: normal temperature: head- ache: dizzy; vomiting. | Blanched, white, waxy skin, but tissue resilient; tissue cold and pale. | Shivering, apathy, sleepiness: rapid drop in body temper- ature; glassy stare; slow pulse; slow respiration. | | | | | | | | |
| Cool victim rapidly by soaking in cool (not cold) water. Get medical attention immediately!! | Remove victim to a cool. air conditioned place. Loosen clothing, place in head low position. Have victim drink cool (not cold) water. | Remove victim to a warm place. Rewarm area quickly in warm (not hot) water. Have victim drink warm fluidsnot coffee or alcohol. Do not break any blisters. Elevate the injured area and get medical attention. | Remove victim to a warm place. Have victim drink warm fluidsnot coffee or alcohol. Get medical attention. | | | | | | | | |

3.2 PHYSICAL (SAFETY) HAZARDS AND CONTROLS (Reference CH2M HILL SOP HS-03)

| · · · · · · · · · · · · · · · · · · · | |
|--|--|
| Hazard | Engineering or Administrative Controls |
| Flying debris/objects | Provide shielding and PPE. |
| Noise > 85 dBA | Noise protection and monitoring required. |
| Steep terrain/unstable surface | Brace and shore equipment. |
| Build-up of explosive gases | Provide 20 lb A.B.C fire extinguisher and ventilation. |
| Build-up of static electricity | No spark sources within 50 feet of an excavation, heavy equipment, or UST removal. Ground as appropriate: |
| Gas cylinders | Make certain gas cyfinders are properly anchored and chained. Keep cylinders away from ignition sources. |
| High pressure hose rupture | Check to see that fifting and pressurized lines are in good repair before using |
| Electrical shock | Make certain third wire is properly grounded. Do not tamper with electrical wiring unless qualified to do so. |
| Suspended loads | Work not permitted under suspended loads. |
| Moving vehicles | Back-up-alarm required for heavy equipment. Observer remains in contact with operator and signals safe back-up. Personnel to remain outside of turning radius. |
| Overhead electrical wires | Heavy equipment (e.g. drill rig) to remain at least 15 feet from overhead powerline for powerlines of 50 kV or less. For each Kv > 50 increase distance 1/2 foot. |
| Burned utilities, drums, tanks, and so forth | Locate buried utilities, drums, tanks, etc. prior to digging or drilling and mark location. |
| Slip, trip, fall hazards due to muddy work areas | Use wood pallets or similar devices in muddy work areas. |
| Back injury | Use proper lifting techniques, or provide mechanical lifting aids. |
| Confined space entry | Permit and safety plan required (reference CH2M HILL SOP HS-17). |
| Trenches/excavations | Cal/OSHA permit required to trench or excavate. Make certain trench meets Cal/OSHA standard before entering. All excavations > 5 feet deep must be sloped or shored. Excavations > 4 feet deep must have a ladder every 25 feet. If not entering trench, remain 2 feet from edge of trench at all times. |
| Protruding objects | Flag visible objects. |

3.3 LOCATIONS OF BURIED UTILITIES

Because of the urban nature of the setting, utilities may be present at specific investigative sites.

3.4 HAZARDS POSED BY CHEMICALS BROUGHT ONSITE

Refer to CH2M HILL Hazard Communication Program Manual which is available from the Corporate Human Resources Department in Denver. The Project Manager is to request Material Safety Data Sheets (MSDSs) from the client, or contractors and subcontractors for chemicals that CH2M HILL employees are potentially exposed to.

| Chemical | Location | |
|---------------|-----------------------------|--|
| . Isobutylene | Calibration Gas HNU Monitor | |
| Nitric Acid | Water Sampling | |
| Sulfuric Acid | Water Sampling | |

3.5 KNOWN CONTAMINANTS OF CONCERN Location and Highest Concentration PEL, REL, or HJGI Contaminant Symptoms and Effects of Exposure PIP (solid media: mg/kg or TLV (ppm) (ppm) liquid media: ug/l) GW 25/25/50 Trichloroethylene (TCE) 1,000 Headache, vertigo, visual disturbance GW-50/25/50 500 Perchloroethylene (PCE) Irritation-eye, nose, throat GW 350/350/350 1,000 Methyl Chloroform Headache, fassitude, CNS depressant Benzene GW 10/0.1/10 3,500 Irritation--eyes, nose, respiratory system GW Carbon Tetrachloride 5/2/5 300 CNS depressant, nausea, vomiting

| 3.6 POTENTIAL ROUTES OF EXPOSU | RE | |
|---|-------------|---|
| DERMAL: | INHALATION: | OTHER: |
| Secondary for all contaminants of concern | Primary to | r all contaminants of concern ingestion |

Note 1: Note 2:

Note 3:

Note 4:

Lower value of PEL, REL, or TLV listed.

PIP = photoionization potential.

N1. = no limit found in reference materials.

SL (SLUDGE) SW (SURFACE WATER)

Location refers to physical location. Abbreviations specify media;

A (AIR) D (DRUMS) F (FLASH) GW (GROUNDWATER) E (LAGOON) TK (TANK)S (SOIL)

4.0 PERSONNEL

4.1 CH2M HILL EMPLOYEES (Reference CH2M HILL SOP HS-01 and HS-02)

Employees listed below are enrolled in the CH2M HILL chemical protection program (CPP) and meet the medical surveillance, 40-hour initial training, 3-day on-the-job experience, and 8-hour annual refresher training requirements of OSHA 29CFR1910.120. Employees designated "SSC" have received 8 hours of supervisor and 8 hours of instrument training and can serve as site safety coordinator (SSC) for the level of protection indicated. There must be one SSC present during any task performed in exclusion or decontamination zones with the potential for exposure to safety and health hazards. Employees designated "FA-CPR" are currently certified by the American Red Cross, or equivalent, in first aid and CPR. There must be one FA-CPR designated employee present during any task performed in exclusion or decontamination zones with the potential for exposure to safety and health hazards. The "buddy system" requirements of OSHA 29CFR1910.120 are to be met at all times.

| Employee Name | | Office | Responsibility | SSC/FA-CPR |
|---------------|------------------------|--------|--|-------------|
| Ken Starr | | PHS | Field Team Leader | · |
| Loren Krook | | RDD | Site Safety Coordinator | SSC: FA-CPR |
| Jess Brown | | RDD | | FA-CPR |
| Jeff Franklin | | BOI | The state of the s | FA-CPR |
| Bob Treble | _{gr} éja Kasa | ANC | | FA-CPR |
| Willie Paiz | | PHX | | FA-CPR |
| Dan Wendell | | LAO | | FA-CPR |
| Sybil Hatch | the terms | SFO | | FA-CPR |

| 4.2 | HEALTH AND SAFETY AND FIELD TEAM CHAIN OF COMMAND |
|--------|---|
| 4.2.1. | CLIENT |
| | Chris Stubbs - EPA Region IX |
| 4.2.2 | CH2M HILL |
| | Sybil Hatch - SFO |
| 4.3.3 | SUBCONTRACTOR |
| | Unknown |

5.0 PERSONAL PROTECTIVE EQUIPMENT (PPE) SPECIFICATION¹

| | Task | Level | Body | Foot | Head ² | Eye | Hand | Respiratory |
|-----|---|-------|-----------|------------------------|-------------------|----------------------|------------------------|------------------|
| 5.1 | INSTALLING PUMPS AND EQUIPMENT | D | Coveralls | Safety boots/ shoes | Hardbat | Safety glasses or | Supported Polyvinyl | None required |
| 5.2 | TRANSPORTING AND TRANSFERRING PURGED WELL WATER | | | | , | chemical splash | Alcohol gloves | 1 |
| 5.3 | WELL MONITORING | | | | | goggles | | : |

Note 1: Reference CH2M HILL SOP HS-07 and HS-08.

Note 2: The SSC shall specify hardbat areas.

5.1 MODIFICATIONS AND ADDITIONS TO PPE SPECIFICATION

The atmosphere contains no known hazard. Work functions preclude splashes, immersion, or the potential for unexpected inhalation of or contact with hazardous levels of any chemicals.

6.0 AIR MONITORING EQUIPMENT SPECIFICATION⁵

| Instrument | Tasks | Action Levels | Frequency | Calibration |
|--|-------|---|------------------|---|
| CGI: | All | 0-10% L.E.L. No exp. ³ hazard 10-25% L.E.L. Pot. ⁴ exp. hazard >25% L.E.L. Exp. hazard; evacuate/vent | Every 30 minutes | Daily. Record calibration in SSC log book. |
| 0 ₂ meter: | All | >25.0% O_2 Exp. hazard; evacuate/vent 20.9% O_2 Normal O_2 <19.5% O_2 O_2 def.; evacuate/vent | Every 30 minutes | Daily. Record calibration in SSC fog book. |
| Photoionization Detector (PID): 11.7 ev | All | Background ppm ^{ab1} Level 10 > 5 ppm ^{ab} Level C (Continuous for 2-3 minutes) 5-10 ppm ^{ab} f evel 18 > 10 ppm ^{ab} Stop work, re-evaluate | Every 30 minutes | Daily before and after each day's use. Record calibration in SSC log book |

Note 1: ab = above background

Note 2: N/A = not applicable

Note 3: exp. = explosion Note 4: pot. = potential

Note 5: Reference CH2M HILL SOP HS-06

| 6.1 CALIBRATION SPECIFICATION | | | | |
|--------------------------------|------------------------|---------------|----------------------|-------------------------------|
| Instrument | Gas | Span | Reading | Method |
| PID: HNU, 10.2 ev probe | 100 ppm isobutylene | 9.8 ± 2.0 | 55 ppm | 1.5 l/m reg T-tubing |
| | | | | 0.25 1/m reg direct tubing |
| PID: HNU, 11.7 ev probe | 100 ppm isobutylene | 5.0 ± 2.0 | 68 ppm | 1.5 l/m reg T-tubing |
| | | | | 0.25 l/m reg direct tubing |
| FID: OVA-128 | 100 ppm methane | 3.0 ± 1.5 | 100 ppm | 1.5 l/m reg T-tubing |
| CGI: MSA 260, 261, 360, or 361 | 0.75% pentane | N/A | 50% LEL ± 5 % LEL | 1.5 l/m reg direct tubing |

| 6.2 A | IR SAMPLING | | |
|---|--------------------|--|--|
| | d and Description: | | |
| Person | nei: All | | |
| Area: | All | | |
| Results to be interpreted by: Site Safety Coordinator | | | |

| 7.0 DECONTAMINATION SPECIFICATION (Reference CH2M HILL SOP HS-13) | | | | |
|---|---|---|--|--|
| Personnel | Sample Equipment | Heavy Equipment | | |
| Boot wash/rinse | Wash/rinse equipment | Power wash | | |
| Glove wash/rinse | Solvent rinse equipment | Steam clean | | |
| Respirator removal | Solvent disposal method: Contain collected material | Water disposal method: Contain collected material | | |
| Outer glove removal | Final disposal is the responsibility of the SSC | Final disposal is the responsibility of the SSC | | |
| Body suit removal | | | | |
| Inner glove removal | | | | |
| Hand wash/rinse | 144 T | | | |
| Face wash/rinse | | | | |
| Shower ASAP | | | | |

8.0 SPILL CONTAINMENT PROCEDURES

Keep unnecessary people away. Stay upwind; keep out of low areas. Stop leak if you can do it without risk. Small spills - Take up with sand, earth or other noncombustible absorbent material. Large spill - Dike far ahead of liquid spill for later disposal, call for emergency assistance.

9.0 WORK PROCEDURES

9.1 WORK PRACTICES

- No spark sources within exclusion or decontamination zones.
- Avoid visibly contaminated areas.
- No eating, drinking, or smoking in contaminated areas, or exclusion or decontamination zones
- SSC to establish areas for eating, drinking, smoking.
- No contact lenses in exclusion or decontamination zones.
- No facial hair that would interfere with respirator fit if Level C or B is anticipated.
- Site work will be performed during daylight hours whenever possible. Any work conducted during hours of darkness will require enough illumination intensity "to read a newspaper without difficulty."

9.2 SITE CONTROL MEASURES

- Site safety coordinator (SSC) to conduct site safety briefing (see below) before starting field activities, or as tasks and site conditions change:
- SSC records safety briefing attendance in logbook, and documents topics discussed.
- Post Cal/OSHA job site poster in a central and conspicuous location at the site.
- Determine wind direction.
- Establish work zones: support, decontamination, and exclusion zones, and delineate work zones with flagging or cones as appropriate. Support zone upwind of site.
- Establish decontamination procedures, including respirator decontamination procedures, and test.
- Utilize access control at the entry and exit from each work zone.
- Chemicals to be stored in proper containers.
- MSDSs are available for onsite chemicals employees exposed to.
- Establish onsite communications. These should consist of:
 - Line of sight/hand signals
 - Air horn
 - Two-way radio or cellular phone if available
- Establish emergency signals. For example:
 - Grasping throat with hand--EMERGENCY--HELP ME
 - Grasping buddy wrist--LEAVE AREA NOW
 - Thumbs up--OK, UNDERSTOOD
 - Two short blasts on air horn--ALL CLEAR
 - Continuous air horn--EMERGENCY--EVACUATE
- Establish offsite communications.
- Establish "buddv" system.
- Establish procedures for disposal of material generated onsite.
- Initial air monitoring conducted by SSC in appropriate level of protection.
- SSC to conduct periodic inspections of work practices to determine effectiveness of this plan. Deficiencies to be noted, reported to DSO or RSO, and corrected.

10.0 EMERGENCY RESPONSE PLAN (Reference CH2M HILL SOP HS-12)

10.0 PRE-EMERGENCY PLANNING

The SSC performs the applicable pre-emergency planning tasks before starting field activities and coordinates emergency response with the facility and local emergency service providers as appropriate.

- Locate nearest telephone to the site and inspect onsite communications.
- Locate chemical, safety, radiological, biological hazards.
- Confirm and post emergency telephone numbers and route to hospital.
- Post site map marked with location of emergency equipment and supplies.
- Review emergency response plan for applicability to any changed site conditions, alterations in onsite operations, or personnel availability.
- Evaluate capabilities of local response teams.
- Where appropriate and acceptable to the client, inform emergency room/ambulance service and emergency response teams of anticipated types of site emergencies.
- Designate one vehicle as the emergency vehicle; place hospital directions and map inside; keep keys in ignition during field activities.
- Inventory and check site emergency equipment and supplies.
- Review emergency procedures for personnel injury, exposures, fires, explosions, chemical and vapor releases with field personnel.
- Locate onsite emergency equipment and supplies of clean water.
- Verify local emergency contacts, hospital routes, evacuation routes, and assembly points.
- Drive route to hospital.
- Review names of onsite personnel trained in first aid and CPR.
- Review notification procedures for contacting CH2M HILL's medical consultant and team member's occupational physician.
- Rehearse the emergency response plan once prior to site activities.
- Brief new workers on the emergency response plan.

10.2 EMERGENCY EQUIPMENT AND SUPPLIES

The SSC marks the locations of emergency equipment on the site map and posts the map in the support zone.

- 20 lb ABC fire extinguisher
- · Industrial first aid kit

10.3 EMERGENCY MEDICAL TREATMENT

- The SSC will assume charge during a medical emergency until the ambulance arrives, or the injured person is admitted to the emergency room.
- Prevent further injury.
- Initiate first aid and CPR.
- Call the ambulance and hospital.
- Determine if decontamination will make injury worse. Yes--seek medical treatment immediately.
- Make certain that injured person is accompanied to emergency room.
- Notify the Project Manager of the injury.
- Notify the District or Regional Health and Safety Manager.
- Notify the injured person's human resources department:
- Prepare an incident report. Submit this to the Corporate Director Health and Safety (WDC) and Corporate Human Resources Department (DEN) within 48 hours.

10.4 EVACUATION

- Evacuation routes will be designated by SSC prior to beginning of work.
- Onsite and offsite assembly points will be designated prior to beginning of work.
- Personnel will exit the exclusion zone and assemble at the onsite assembly point upon hearing the emergency signal for evacuation of the exclusion zone.
- Personnel will assemble at the offsite point upon hearing the emergency signal for a site evacuation.
- The SSC and a "buddy" will remain onsite after the site has been evacuated (if possible) to assist local responders and advise them of the nature and location of the incident.
- SSC accounts for all personnel in the onsite assembly zone.
- A person designated by the SSC (prior to work) will account for personnel at the offsite assembly area.
- The SSC is to write up the incident as soon as possible after it occurs, and submit a report to the Corporate Director Health and Safety.

10.5 EVACUATION ROUTES AND ASSEMBLY POINTS

Thomas Brothers Map page number(s) are provided for hospital information. Maps will be in the possession of the SSC and in the case of an emergency, an appropriate route will be selected on traffic, distance, and other considerations.

11.0 EMERGENCY RESPONSE TELEPHONE NUMBER

In the event of fire, explosion, or chemical release, evacuate team members to a safe upwind distance and call the fire department. When reporting an incident to the fire department, do not hang up until specifically told to do so by the dispatcher. The SSC should meet the incoming fire responders and answer their questions about the incident. Call the EPA client and project manager as soon as practicable.

Local

Ambulance. Fire and Rescue. Paramedic, Highway Patrol: 911

Hospitals: (Specific site, Phone number, Thomas Bros, Map Page No.) Ex: Valley Hospital Medical Center, North Hollywood Site, 818/997-0101, 15D-3

| Emergency Room Facility | Telephone No. | Thomas Bros. Map Page No. |
|---|-----------------------|------------------------------|
| Valley Hospital Medical Center 14500 Sherman Circle Van Nuys. California (North Hollywood Site) | 818/997-0101 | 15 D-3 |
| Medical Center of North Hollywood 12629 Riverside Drive North Hollywood, California (North Hollywood Site) | 818/ 98 0-9200 | 23 B-2 |
| St. Joseph Medical Center Buena Vista and Alameda Streets Burbank. California (North Hollywood, Crystal Springs Sites) | 818/843-5111 | 24 C-3 |
| Memorial Hospital of Glendale 1320 S. Central Avenue Glendale. California (Crystal Springs, Pollock Sites) | 818/502-1900 | 25 C-6 |
| Verdugo Hills Hospital 1812 Verdugo Boulevard Glendale, Culifornia (Crystal Springs, Verdugo Sites) | 818/790-7100 | 25 F-1 |
| Glendale Adventist Medical Center 1509 Wilson Terrace Glendale, California (Crystal Springs, Pollock, Verdugo Sites) | 818/409-8000 | 25 E-3 |

Poison Control Center.

911

Police/Sheriff: Fire:

911

Electric Co.:

Southern California Edison: 818/674-6060

Gas Co.:

Southern California Edison: 818/674-6060

Water Co.:

City of Los Angeles Department of Water and Power: 818/481-4211

Airport:

Los Angeles International Airport: 818/646-5252

Explosive Unit:

Same as police

| 12.0 EMERGENCY CONTACTS | |
|--|---|
| CH2M HILL Medical Consultant | Occupational Physician (Regional or Local) |
| Dr. Kenneth Chase Washington Occupational Health Associates 202/463-6698 (8 AM to 5 PM EST) 202/463-6440 (after hours answering service; physician will return call within 30 minutes) | |
| Corporate Director Health and Safety | Site Safety Coordinator (SSC) |
| Name: Marty Mathamel/WDC Phone: 703/471-1441 | Name: Phone: |
| District Health and Safety Manager (DHSM) | Regional Manager |
| Name: Allen Macenski/LAO Phone: 714/250-5522, ext. 372 | Name: Phone: |
| Regional Health and Safety Manager (RHSM) | Project Manager |
| Name: Ann Rundle/LAO Phone: 714/250-5522, ext. 370 | Name: Phone: |
| Radiation Health Manager (RHM) | Regional Human Resources Department |
| Name: George Stephens/ORO Phone: 615/483-9032 | Name: Phone: |
| Client | Corporate Human Resources Department |
| | Name: Beth Brown/DEN Phone: 303/771-0952 |
| | If an injury occurs, notify the injured person's personnel office as soon as possible after obtaining medical attention for the injured. Notification must be made within 24 hours of the injury. |

| 13.0 PLAN APPROVAL | | |
|--|------------------|---------------|
| This site safety plan has been written by CH2M HILL. CH2M HILL claims no responsibility for its use by others, unless specified and defined in project or contract documents. The plan is written for the specific site conditions, purposes, dates, and personnel specified and must be amended if these conditions change. | | |
| PLAN WRITTEN BY: | | DATE: |
| PLAN APPROVED BY: Allen Macenski | | DATE: 7/29/91 |
| | | |
| 13.1 PLAN AMENDMENTS | | |
| DATE: | CHANGES MADE BY: | · |
| CHANGES TO PLAN: | | |
| | | |
| APPROVED: | | DATE: |
| | | |
| 13.2 PLAN AMENDMENTS | | |
| DATE: | CHANGES MADE BY: | |
| CHANGES TO PLAN: | | |
| | | |
| | | · |
| APPROVED: | | DATE: |
| | | |
| 14.0 PLAN AMENDMENTS | | |
| Attachment 1: Form 533 | | |
| Attachment 2: Applicable MSDSs | | |