## FRIEDMAN & BRUYA, INC.

### **ENVIRONMENTAL CHEMISTS**

Date of Report: 08/11/03 Date Received: 07/31/03

Project: Metro Self Monitor, PO# M91410, F&BI 307291

Date Extracted: 08/06/03 Date Analyzed: 08/06/03

## RESULTS FROM THE ANALYSIS OF THE WATER SAMPLE FOR TOTAL METALS BY INDUCTIVELY COUPLED PLASMA (ICP) (METHOD 6010)

Results Reported as mg/L (ppm)

Sample ID	<u>Chroi</u>	mium Copp	<u>er</u> <u>Nicke</u>	<u>Zinc</u>
Laboratory ID				
M91410	0.:	21 0.15	0.13	< 0.05
307291-01				
BEARING AND				
Method Blank	<0.0	05 <0.05	< 0.1	< 0.05

## FRIEDMAN & BRUYA, INC.

### **ENVIRONMENTAL CHEMISTS**

Date of Report: 08/11/03 Date Received: 07/31/03

Project: Metro Self Monitor, PO# M91410, F&BI 307291

# QUALITY ASSURANCE RESULTS FROM TOTAL METALS BY INDUCTIVELY COUPLED PLASMA (ICP) (METHOD 6010)

Laboratory Code: 308002-01 (Duplicate)

	Reporting	Sample	Du	plicate	Relativ Percen		ceptan	ce
_Analyte	Units	Result	R	Result	Differen	ce C	riteria	<u>.                                    </u>
Chromium	mg/L (ppm)	< 0.05	<	< 0.05	nm		0-20	
Copper	mg/L (ppm)	2.3		2.3	0		0-20	
Nickel	mg/L (ppm)	< 0.1		<0.1	nm		0-20	
Zinc	mg/L (ppm)	0.79		0.76	4		0-20	

Laboratory Code: 308002-01 (Matrix Spike)

	Reporting	Spike	Sample	% Recov	ery Acceptant	ce
Analyte	Units	Level	Result	MS	Criteria	
Chromium	mg/L (ppm)	2	< 0.05	100	80-120	7
Copper	mg/L (ppm)	2	2.3	87	80-120	
Nickel	mg/L (ppm)	4	<0.1	99	80-120	4
Zinc	mg/L (ppm)	2	0.79	94	80-120	

Laboratory Code: Laboratory Control Sample

	Reporting	Spike	% Recove	ery % Recove	ery Acceptanc	e RPD
Analyte	Units	Level	LCS	LCSD	Criteria	(Limit 20)
Chromium	mg/L (ppm)	2	107	105	80-120	2
Copper	mg/L (ppm)	2	105	105	80-120	0
Nickel	mg/L (ppm)	4	104	105	80-120	1
Zinc	mg/L (ppm)	2	104	106	80-120	2

nm - The analyte was not detected in one or more of the duplicate analyses. Therefore, calculation of the RPD is not applicable.

3072				MPLE CHAI	//		UL	) Y 		•							93 A	
Sand Danuar To (35045)	Thomas	80-2		SAMPLERS	(gnature)	2					$\geq$						ROLIND	
Sena Report 10 <u>Galasas</u>	0	( ) (	_	PROJECT NAME/NO. PO#						TURNAROUND TIME  ☐ Standard (2 Weeks)								
Send Report To GELSCS Company Alaskaw Address 678	Coppea	and a	<u>)</u>	1	METRO SEE MONITUR M9/40					☐ RUSH								
City, State, ZIP SEATCS Phone # 206-382-837	E WA	28023		REMARKS					1						Disp Řetu	ose al irn sa	LE DISP ter 30 da mples with instr	ys
									I	ANA	LYS	ES R	EQU	EST.	ED			
Sample ID	Lab ID	Date	Time	Sample Type	# of containers	TPH-Diesel	TPH-Gasoline	BTEX by 8021B	VOCs by 8260	SVOCs by 8270	HFS	Chan's	/				ľ	Votes
m91410	01	7/3/	9:00	H20	/													
																		t*
West No. of the Control of the Contr																		
										1								
												`						
				ļ								•						
																-		
	1																	
Friedman & Bruya, Inc.	1	SIGNATU	RE		PRINT	NA	ME					CC	)MP.	ANY			DAŢE	TIM

Ph. (206) 285-8282

Fax (206) 283-5044

Seattle, WA 98119-2029

A SIGNITURE	I ICITAL LATINITY	COMITANT	Dajo	1 11/117
Relinguished by	- Joseph	Aew	7/11/03	9130
Recoived by July Mun	TRIC CHOINIERE	FABI	7-31-03	4388
Relinquished by:				
Received by:				

FORMS\COC\COC.DOC

## FRIEDMAN & BRUYA, INC.

#### **ENVIRONMENTAL CHEMISTS**

James E. Bruya, Ph.D. Charlene Morrow, M.S. Yelena Aravkina, M.S. Bradley T. Benson, B.S. Kurt Johnson, B.S. 3012 16th Avenue West Seattle, WA 98119-2029 TEL: (206) 285-8282 FAX: (206) 283-5044 e-mail: fbi@isomedia.com

August 11, 2003

Gerry Thompson, Project Manager Alaskan Copper Works 628 South Hanford Seattle, WA 98134

Dear Mr. Thompson:

Included are the results from the testing of material submitted on July 31, 2003 from the Metro Self Monitor, PO# M91410, F&BI 307291 project. There are 2 pages included in this report. Any samples that may remain are currently scheduled for disposal in 30 days. If you would like us to return your samples or arrange for long term storage at our offices, please contact us as soon as possible.

We appreciate this opportunity to be of service to you and hope you will call if you should have any questions.

Sincerely,

FRIEDMAN & BRUYA, INC.

Charlene Morrow

Charlene Morrow

Chemist

Enclosures ACU0811R.DOC