### **ENVIRONMENTAL CHEMISTS**

Date of Report: November 5, 1996 Date Received: October 31, 1996

Project: Metro Self Monitor, PO #M55101 Date Samples Extracted: November 1, 1996 Date Extracts Analyzed: November 1, 1996

## RESULTS FROM THE ANALYSIS OF THE WATER SAMPLE FOR CHROMIUM, COPPER, NICKEL, AND ZINC USING METHOD 6010

### Samples Processed Using Method 3005A Results Reported as mg/L (ppm)

 Sample ID
 Chromium
 Copper
 Nickel
 Zinc

 M55101
 0.13
 0.08
 0.09
 <0.05</td>

 Method Blank
 <0.05</td>
 <0.05</td>
 <0.05</td>
 <0.05</td>

### **ENVIRONMENTAL CHEMISTS**

Date of Report: November 5, 1996 Date Received: October 31, 1996

Project: Metro Self Monitor, PO #M55101

# QUALITY ASSURANCE RESULTS FOR TOTAL METALS BY INDUCTIVELY COUPLED PLASMA (ICP) (METHOD 6010)

Laboratory Code: 73636 (Duplicate)

Analyte:	Reporting Units	Sample Result	Duplicate Result	Relative Percent Difference	Acceptance <u>Criteria</u>
Chromiur	n mg/L (ppm)	0.13	0.14	7a	0-20
Copper	mg/L (ppm)	0.08	0.08	0a	0-20
Nickel	mg/L (ppm)	0.09	0.08	12a	0-20
Zinc	mg/L (ppm)	< 0.05	< 0.05	nm	0-20

Laboratory Code: 73636 (Matrix Spike)

	Reporting	Spike	Sample		ecovery	Acceptance	
Analyte:	Units	Level	Result	MS	MSD	<u>Criteria</u>	<u>Difference</u>
Chromium	mg/L (ppm)	5	0.13	95	97	80-120	2
Copper	mg/L (ppm)	5	0.08	91	91	80-120	0
Nickel	mg/L (ppm)	10	0.09	95	97	80-120	2
Zinc	mg/L (ppm)	5	< 0.05	98	102	80-120	4

Laboratory Code: Spike Blank

	Reporting	Spike	% R	ecovery	Acceptance	Relative e Percent
Analyte:	Units	Level	MS	MSD	Criteria	Difference
Chromium	mg/L (ppm)	5	102	102	80-120	0
Copper	mg/L (ppm)	5	96	94	80-120	2
Nickel	mg/L (ppm)	10	103	102	80-120	1
Zinc	mg/L (ppm)	5	106	106	80-120	0

nm - The analyte was not detected in one or more of the duplicate analyses. Therefore, calculation of the RPD is not applicable.

a - The analyte was detected at a level less than five times the detection limit. The RPD results may not provide reliable information on the variability of the analysis.

FRESOMAN & BRUYA, INC. 3012 16th Avenue West Seattle, WA 98119-2029 (206, 285-8282

# SAMPLE CHAIN OF CUSTODY

Sent port To: AlAsk	AN Coppen	Works		Contac	or GE	RALD Thom	4D502		
Address 678 A	FIN YOU'LE	98134							
Phone # (206) 38	14 E8 -23			Date	10-3	7-56			
SITE NO.		PROJE	CT NAME			PURCHASE ORDE	ER#		
7238		METRO S	reld n	ron, tore	1	755/01			
SAMPLIARS (signature)						PROJECT LOCAT	ION		
9.4					5200	6th Ave	5		
REN. AAS						LE DISPOSAL INFO			
						Dispose after 30 da Return Samples Call for Instruction	±0.		
Sample #	Date/Time Sampled	Type of Sample	# of Jars	Lab Sample		Analyse Requeste			
m 55101	10/11/86 1:30	1	/	73636		CR CU Y	V' 22		
	The same of the sa			1					
							-		
	<u> </u>								
N. A. CANDARIA				_		<del></del>			
			•						
V.									
	<del>                                     </del>								
2 24 2					1.5				
						•			
SIG TURE	Р	RINT NAME		COMPAN	Y	Date	Time		
Religies shed by:	GERA	40 Thomps	س	ACL	~	195/86	1:45 pm		
Rece by:	ns.	Oborr	F	+B,IV	10.	19/3//96	1245		
Reliminished by:	- 14			an M. San A					
Received by:	2 N G			1					
and the second					1, 1	Maria Maria			

FOR /COC

09/19/94

### **ENVIRONMENTAL CHEMISTS**

James E. Bruya, Ph.D. Beth M. Albertson, M.S. Bradley T. Benson Kelley D. Wilt 3012 16th Avenue West Seattle, WA 98119-2029 TEL: (206) 285-8282 FAX: (206) 283-5044

November 5, 1996

## INVOICE # 96ACU1105-1 DUPLICATE COPY

Accounts Payable Alaskan Copper Works 628 South Hanford Seattle, WA 98134

RE: Project Metro Self Monitor, PO #M55101: Results of testing requested by Gerry Thompson, Project Manager for material submitted on October 31, 1996.

### **ENVIRONMENTAL CHEMISTS**

James E. Bruya, Ph.D. Beth M. Albertson, M.S. Bradley T. Benson Kelley D. Wilt 3012 16th Avenue West Seattle, WA 98119-2029 TEL: (206) 285-8282 FAX: (206) 283-5044

November 5, 1996

Gerry Thompson, Project Manager Alaskan Copper Works 628 South Hanford Seattle, WA 98134

Dear Mr. Thompson:

Included are the results from the testing of material submitted on October 31, 1996 from your Metro Self Monitor, PO #M55101 project.

We appreciate this opportunity to be of service to you and hope you will call if you should have any questions.

Sincerely,

FRIEDMAN & BRUYA, INC.

Kurt Johnson Chemist

keh

Enclosures ACU1105R.DOC