

FRIEDMAN & BRUYA, INC.

ENVIRONMENTAL CHEMISTS

Date of Report: 07/27/05

Date Received: 07/21/05

Project: Metro Self Monitor, PO# M96667, F&BI 507189

Date Extracted: 07/25/05

Date Analyzed: 07/25/05

**RESULTS FROM THE ANALYSIS OF WATER SAMPLES
FOR TOTAL METALS
BY EPA METHOD 6010**

Results Reported as mg/L (ppm)

<u>Sample ID</u> Laboratory ID	<u>Chromium</u>	<u>Copper</u>	<u>Nickel</u>	<u>Zinc</u>
M96667 507189-01	0.23	0.28	0.19	0.05
Method Blank	<0.05	<0.05	<0.10	<0.05

FRIEDMAN & BRUYA, INC.**ENVIRONMENTAL CHEMISTS**

Date of Report: 07/27/05

Date Received: 07/21/05

Project: Metro Self Monitor, PO# M96667, F&BI 507189

**QUALITY ASSURANCE RESULTS
FROM THE ANALYSIS OF WATER SAMPLES FOR TOTAL METALS
BY EPA METHOD 6010**

Laboratory Code: 507145-02 (Duplicate)

Analyte	Reporting Units	Sample Result	Duplicate Result	Relative Percent Difference	RPD (Limit 20)
Chromium	mg/L (ppm)	<0.05	<0.05	nm	0-20
Copper	mg/L (ppm)	0.09	0.09	0	0-20
Nickel	mg/L (ppm)	<0.1	<0.1	nm	0-20
Zinc	mg/L (ppm)	<0.05	<0.05	nm	0-20

Laboratory Code: 507145-02 (Matrix Spike)

Analyte	Reporting Units	Spike Level	Sample Result	Percent Recovery MS	Control Limits
Chromium	mg/L (ppm)	5	<0.05	91	50-150
Copper	mg/L (ppm)	5	0.09	93	50-150
Nickel	mg/L (ppm)	10	<0.1	93	50-150
Zinc	mg/L (ppm)	5	<0.05	95	50-150

Laboratory Code: Laboratory Control Sample

Analyte	Reporting Units	Spike Level	Percent Recovery LCS	Acceptance Criteria
Chromium	mg/L (ppm)	5	103	70-130
Copper	mg/L (ppm)	5	101	70-130
Nickel	mg/L (ppm)	10	102	70-130
Zinc	mg/L (ppm)	5	103	70-130

nm - The analyte was not detected in one or more of the duplicate analyses. Therefore, calculation of the RPD is not applicable.

FRIEDMAN & BRUYA, INC.

ENVIRONMENTAL CHEMISTS

James E. Bruya, Ph.D.
Charlene Morrow, M.S.
Yelena Aravkina, M.S.
Bradley T. Benson, B.S.
Kurt Johnson, B.S.

3012 16th Avenue West
Seattle, WA 98119-2029
TEL: (206) 285-8282
FAX: (206) 283-5044
e-mail: fbi@isomedia.com

July 27, 2005

INVOICE #05ACU0727-1

Accounts Payable
Alaskan Copper Works
628 South Hanford
Seattle, WA 98134

RE: Project Metro Self Monitor, PO# M96667, F&BI 507189 - Results of testing
requested by Gerry Thompson for material submitted on July 21, 2005.

1 sample analyzed for Total Chromium, Copper, Nickel and Zinc by Method 6010B @ \$80 per sample	\$ 80.00
Amount Due	\$ 80.00

FEDERAL TAX ID # (b) (6)

CM 7/21/05 A15

SAMPLE CHAIN OF CUSTODY

507189
 Send Report To Gerard Thompson
 Company 628 S. H. Alaskan Copper
 Address 628 S. Harvard St
 City, State, ZIP Seattle WA 98134
 Phone # 206-302-8379 Fax # 206-302-4309

SAMPLERS (signature)

PROJECT NAME/NO.

Metro Self monitor

PO #

M96667

REMARKS

Page # _____ of _____

TURNAROUND TIME

☐ Standard (2 Weeks)☒ RUSH See Charles

Rush charges authorized by:

SAMPLE DISPOSAL

☐ Dispose after 30 days☐ Return samples☐ Will call with instructions

Sample ID	Lab ID	Date	Time	Sample Type	# of containers	ANALYSES REQUESTED										Notes				
						TPH-Diesel	TPH-Gasoline	BTEX by 8021B	VOCs by 8260	SVOCs by 8270	HFS									
M96667	01	7/2/05	12:30	H2O	1								✓ C6, C7, nC7, nC8							

Friedman & Bruya, Inc.
 3012 16th Avenue West

Seattle, WA 98119-2029

Ph. (206) 285-8282

Fax (206) 283-5044

FORMS\COC\COC.DOC

SIGNATURE	PRINT NAME	COMPANY	DATE	TIME
Relinquished by: <u>[Signature]</u>	Gerard Thompson	ALW	7-21-05	1:20 PM
Received by: <u>[Signature]</u>	HONG NGUYEN	FBI	1	1
Relinquished by:				
Received by:				

FRIEDMAN & BRUYA, INC.

ENVIRONMENTAL CHEMISTS

James E. Bruya, Ph.D.
Charlene Morrow, M.S.
Yelena Aravkina, M.S.
Bradley T. Benson, B.S.
Kurt Johnson, B.S.

3012 16th Avenue West
Seattle, WA 98119-2029
TEL: (206) 285-8282
FAX: (206) 283-5044
e-mail: fbi@isomedia.com

July 27, 2005

Gerry Thompson, Project Manager
Alaskan Copper Works
628 South Hanford
Seattle, WA 98134


Dear Mr. Thompson:

Included are the results from the testing of material submitted on July 21, 2005 from the Metro Self Monitor, PO# M96667, F&BI 507189 project. There are 2 pages included in this report. Any samples that may remain are currently scheduled for disposal in 30 days. If you would like us to return your samples or arrange for long term storage at our offices, please contact us as soon as possible.

We appreciate this opportunity to be of service to you and hope you will call if you should have any questions.

Sincerely,

FRIEDMAN & BRUYA, INC.



Charlene Morrow
Chemist

Enclosures
ACU0727R.DOC