

Development of Dosimetry Model and Response Analyses

Annie M. Jarabek
NCEA-IO *on detail to* NHEERL ETD
U.S. EPA

OU4 Technical Subgroup Meeting
Libby, MT
26 September 2007




1076054

Outline

- Why
- What
- How
- Conceptual considerations
 - Anatomy
 - Physiology
- Role in risk assessment
- Summary



Why: Motivation for Modeling



- External exposure \neq Internal dose (i.e., lung burden)
- Keep up to date with latest biological understanding and testing measures
- Provide insights on important properties
 - Type: Libby amphibole versus others (e.g., chrysotile, ceramic, glass)
 - Size: Distribution of fibers and associated toxicity
 - Persistence: Role of splitting, dissolution and translocation
- Address differences between test species and humans
- Quantify and explore systematically



RESEARCH & DEVELOPMENT

Building a scientific foundation for sound environmental decisions

What: Definition of Dosimetry Modeling


- “Dose”
 - Internal body amount
 - Defined as associated with toxicity to evaluate “dose-response” relationship
- “Metric”
 - Measurement
 - Scale same as observation or response endpoint (e.g., lung region versus local, specific cell type)
- “Model”
 - Mimic or describe important processes
 - Simulate different exposure scenarios




How: Modeling Approach

- Qualitative concept of process: Mode of action
 - Retained dose or lung burden = deposition - clearance
- Mathematical description of process using key determinants as parameters
 - Anatomy
 - Physiology
- Basic biological data in each species to support parameter values
- Verification of model structure against experimental data





Model Structure: Airway Architecture



Illustrations courtesy of Dr. Jack R. Harkema, Professor of Comparative Pathology, Michigan State University.



RESEARCH & DEVELOPMENT


Building a scientific foundation for sound environmental decisions

Model Structure: Physicochemical and Physiological Parameters

- Species-specific
- Inhalability
- Dissolution rates
- Ventilation rate
- Breathing mode
 - Nose only versus mouth
 - Activity patterns
- Mucociliary clearance rates
- Translocation rates




Construction Considerations: Deposition Mechanisms



RESEARCH & DEVELOPMENT

Building a scientific foundation for sound environmental decisions


Construction Considerations: Location of Deposition Mechanisms



RESEARCH & DEVELOPMENT

Building a scientific foundation for sound environmental decisions

Sample Sites to Support Dosimetry Model



- Sample at different times to track movement
- Determine rates to different locations
- Measure particle distribution and burden in each tissue
- Used to verify model structure and predictions



RESEARCH & DEVELOPMENT

Building a scientific foundation for sound environmental decisions

Example of Equations to Describe Deposition by Impaction in the Head

$$\eta (\text{Imp}) = -0.014 + 0.023 \log (C_1 \rho d_{\text{ev}}^2 Q) (\text{g } \mu\text{m}^2 \text{ sec}^{-1})^{-1}$$

$$\text{for } C_1 \rho d_{\text{ev}}^2 Q < 337 \text{ g } \mu\text{m}^2 \text{ sec}^{-1}$$

$$\eta (\text{Imp}) = -0.959 + 0.397 \log (C_1 \rho d_{\text{ev}}^2 Q) (\text{g } \mu\text{m}^2 \text{ sec}^{-1})^{-1}$$

$$\text{for } C_1 \rho d_{\text{ev}}^2 Q < 337 \text{ g } \mu\text{m}^2 \text{ sec}^{-1}$$

Where

$$C_1 = \frac{\left(\frac{3}{2}\right)\beta^{-\frac{2}{3}}}{\frac{0.383}{\ln 2\beta - 0.5} + \frac{1.233}{\ln 2\beta + 0.5}}$$

$$\text{and } d_{\text{ev}} = d_f \beta^{1/3}$$

d_{ev} = Diameter of equivalent vol,

d_f = fiber diameter, and

β = fiber aspect ratio


Accounts for fiber orientation & geometry



RESEARCH & DEVELOPMENT

Building a scientific foundation for sound environmental decisions

Construction Considerations: Clearance Mechanisms




RESEARCH & DEVELOPMENT


Building a scientific foundation for sound environmental decisions



Construction Considerations: Location of Clearance Mechanisms



Mucociliary Escalator
GI Tract
AM-mediated Clearance
Interstitium (via Epithelium)
Lymphat. Circulation
Blood Circulation



Role in Risk Assessment: Putting it All Together



 = air delivery
 = clearance



- Simulate experimental regimen in rats
 - Exposure distribution
 - Duration
- Simulate human exposure scenarios
 - Exposure distribution
 - Activity patterns and duration
- Test hypotheses regarding different dose metrics
 - Size, Number or Mass or specific fraction of fibers, etc.
 - Normalized per respiratory region surface area, number of cells, etc.
 - Response analysis: Evaluate correlations of different dose metrics




RESEARCH & DEVELOPMENT

Building a scientific foundation for sound environmental decisions

LA DRAFT

Conceptual MOA Schematic



Dosimetry Modeling Advantages

- Aids interpretation and use of diverse data
- Predicts complex kinetic behavior
- Capability to “lump” or “split” model structure to predict range from regional to local tissue dose
- Translates laboratory animal data to reconcile with human data
- Flexibility to simulate different human activity patterns
- Explores systematically the factors responsible for potency across fibers
- Facilitates hypothesis generation
- Identifies areas of needed research



Summary

- External exposure \neq internal dose
- Model builds on understanding of biological mechanisms
- Regional to local estimates of internal fiber burden to compare with disease endpoints and measurements
- Aid to comparisons across fibers and between species
- Refines risk assessment predictions

