



CB&I
2700 Chandler Avenue, Building C
Las Vegas, NV 89120
Tel: +1 702 795 0515
Fax: +1 702 795 8210
www.CBI.com

November 15, 2013

Dania Zinner
USEPA; Region 8
1595 Wynkoop Street (8EPR-SR)
Denver, CO 80202-1129

Document ID #: 3019-11152013-4

Dear Ms. Zinner:

EPA CONTRACT NUMBER EP-W-10-033
TASK ORDER NUMBER 3019
QA SUPPORT FOR THE LIBBY ASBESTOS SITE

Enclosed please find the Summary Asbestos On-site Audit Report for the on-site audit performed on October 8, 2013 at EMSL Analytical, Inc. in Cinnaminson, New Jersey. This report and the accompanying checklist are deliverables under Task 5 of the subject Task Order.

If you have any questions, please feel free to contact me.

Sincerely,

Timothy L. Vonnahme
Audit Group Manager, QATS Program
CB&I Federal Services, LLC
Phone: (702) 895-8729
E-Mail Address: timothy.vonnahme@cbifederalservices.com

cc: Administrative Contracting Officer (letter only)
Audit Group Files



The Quality Assurance Technical Support (QATS) contract is operated by Shaw Environmental, Inc., a CB&I Company.
The QATS Program's Quality Management System is certified to the ISO 9001:2008 International Standard

REPORT
FOR
TASK ORDER NUMBER 2019
QUALITY ASSURANCE SUPPORT FOR THE LIBBY ASBESTOS SITE
SUMMARY ASBESTOS ON-SITE AUDIT REPORT

EMSL Analytical, Inc. (Cinnaminson, NJ)

Prepared by:

**The Data Auditing Group
Quality Assurance Technical Support Program
CB&I Federal Services, LLC
2700 Chandler Avenue
Las Vegas, Nevada 89120**

November 14, 2013

QATS Contract Number: EP-W-10-033

Prepared for:

**Dania Zinner
Task Order Manager**

**Region 8
U.S. Environmental Protection Agency
1595 Wynkoop Street
Denver, CO 80202**

TABLE OF CONTENTS

LABORATORY INFORMATION AND AUDIT SCOPE	3
EXECUTIVE SUMMARY	4
AUDIT FINDINGS	5
Sample Receipt, Storage, Log-in, and Chain-of-Custody (COC)	5
Indirect and Direct Preparation of Air Filter and Dust Samples	5
Transmission Electron Microscopy (TEM) Analysis.....	5
Polarized Light Microscopy (PLM) Analysis.....	5
Data Management	6
Quality Control and Quality Assurance (QA/QC)	6
CORRECTIVE ACTION APPLIED FROM THE PREVIOUS AUDIT FINDINGS.....	6
CONCLUSIONS	10

ATTACHMENT

Libby-Specific Asbestos Laboratory On-site Audit Checklist (EPA Only)

LABORATORY INFORMATION AND AUDIT SCOPE

This report summarizes the results of an asbestos on-site laboratory audit of the EMSL Analytical, Inc. in Cinnaminson, New Jersey performed on October 8, 2013. The audit was conducted in support of the United States Environmental Protection Agency (EPA) Region 8 Libby Superfund Site activities. The purpose of the audit was to evaluate corrective actions taken by the laboratory to address deficiencies identified from the last on-site audit conducted on June 26-27, 2012. CB&I Federal Services, LLC Quality Assurance Technical Support (QATS) staff participation in the on-site audit and subsequent preparation of this report was performed under Task 5, Task Order 2019, QATS Contract EP-W-10-033.

Detailed information regarding the subject laboratory is as follows:

Date of On-site: **October 8, 2013**

Laboratory: **EMSL Analytical, Inc.
200 Route 130 North
Cinnaminson, NJ 08077
(800) 220-3675**

Special Projects Manager: **Robyn Denton**

Audit Team

US EPA: **Dania Zinner (by teleconference)**

CB&I QATS: **Michael Lenkauskas, CQA, Senior Auditor**

The Audit Team, comprised of CB&I Federal Services, LLC QATS personnel, performed the technical and evidentiary aspects of the on-site audit. Due to unforeseen circumstances, a representative of the EPA was not able to attend but participated in the debriefing via conference call. The technical and evidentiary parts of the audit involved an evaluation of corrective actions taken by the laboratory to address the deficiencies identified during the previous on-site audit conducted on June 26-27, 2012.

Processes evaluated included sample receipt, sample storage, sample tracking, sample preparation for Transmission Electron Microscopy (TEM) analysis, analysis by Polarized Light Microscopy (PLM), and Quality Assurance/Quality Control (QA/QC). All pertinent laboratory instrumentation and equipment were inspected for proper maintenance and calibration, and laboratory personnel were interviewed to determine their understanding and adherence to laboratory procedures.

During the course of the audit, the applicable sections of the Libby-Specific Asbestos Laboratory On-site Audit Checklist were completed by the Audit Team. Sections of the checklist not completed during the audit are indicated with an "NA." The checklist is provided as an attachment to this report (EPA only).

EXECUTIVE SUMMARY

An asbestos laboratory on-site audit of EMSL Analytical, Inc. in Cinnaminson, New Jersey was performed on October 8, 2013 in support of EPA Region 8 Libby Superfund Site activities. The primary focus of the audit was to evaluate the corrective actions taken by the laboratory to address the deficiencies identified during the previous on-site audit conducted on June 26-27, 2012. The laboratory areas and processes evaluated included sample receipt, sample storage, sample tracking, sample preparation for Transmission Electron Microscopy (TEM) analysis, analysis by Polarized Light Microscopy (PLM), and Quality Assurance/Quality Control (QA/QC).

Corrective actions in response to the previous audit the seven deficiencies identified in the June 2012 on-site audit were evaluated during the current on-site audit. The Audit Team determined that the laboratory had completely addressed all seven, for a corrective action rate of 100%.

The on-site audit identified three new deficiencies which are summarized below by laboratory area:

Indirect and Direct Preparation of Air Filter and Dust Samples – One deficiency was assessed due to a lack of personnel with the training necessary to prepare duff and tree bark samples for analysis by TEM.

Polarized Light Microscopy (PLM) Analysis – Two deficiencies were assessed for failure on one of the PLM microscopes to utilize the correct 550 nm compensator plate specified in the project-specific procedure, and failure to submit completeness checklists with the PLM-VE and PLM-GRAV data packages.

With the exception of the deficiencies noted above, the on-site evaluation revealed EMSL Analytical, Inc. in Cinnaminson, New Jersey to have sufficient facilities, equipment, and staff to analyze samples in accordance with the specified methodologies and Libby-specific protocol. All staff and management were cooperative, readily answered all questions asked by the Audit Team, and appeared to be responsive to the identified deficiencies.

AUDIT FINDINGS

Sample Receipt, Storage, Log-in, and Chain-of-Custody (COC)

The evaluation of this area focused on the one deficiency identified in the previous on-site audit, which was found to have been adequately addressed. No additional deficiencies were observed.

Indirect and Direct Preparation of Air Filter and Dust Samples

The evaluation of this area focused on the one deficiency identified in the previous audit. The deficiency has been addressed as described in the section "Corrective Action Applied from the Previous Audit Deficiencies" on Page 6 of this report. One new deficiency was identified:

1. With the departure of a key staff member, the laboratory no longer has adequate personnel with the training necessary to prepare duff and tree bark samples for analysis by TEM. The training requirements for laboratory personnel are described in Section 4.2.3.3 of the Site-wide Quality Assurance Reference Document (QARD, Rev. 0) and Section 5.2.2 of the laboratory's Quality Assurance Manual (QAM). (Checklist Nos. 6.1 and 10.2.1)

Note: The laboratory has not received tree bark or duff samples since the departure of this key staff member.

Recommended Corrective Action – Ensure that properly trained personnel are available for the preparation of tree bark, duff, and other sample media received from the Libby Superfund site.

Transmission Electron Microscopy (TEM) Analysis

No issues were identified in this area during the previous on-site audit; however, an evaluation of this area was performed during the current audit to assess the knowledge of a newly trained TEM analyst. No new deficiencies were identified.

Polarized Light Microscopy (PLM) Analysis

The evaluation of this area focused on the four (4) deficiencies identified in the previous audit. These deficiencies have been addressed as described in the section "Corrective Action Applied from the Previous Audit Deficiencies" on Page 6 of this report. Two new deficiencies were identified:

2. One of the PLM microscopes used to analyze Libby samples incorrectly utilized a 530 nm compensator plate, rather than a 550 nm compensator plate as specified in the Libby project-specific procedure. Although this deviation is recorded on the bench sheet, it is not described in sufficient detail and is not described in the applicable data package narratives. The requirement to use a 550 nm compensator plate is described in Section 10.3.1.12 of both the PLM-VE (SRC-Libby-03, Rev. 3) and PLM-Grav (SRC-Libby-01, Rev. 3). (Checklist Nos. 8.6.1.12 and 8.15.1)

Recommended Corrective Action – Ensure all deviations from project-specific requirements are described in sufficient detail in the applicable data package narratives.

3. The laboratory was not including the data package completeness checklists with the data deliverables. These checklists are provided with both the PLM-VE and PLM-GRAV EDD templates. The requirement to provide a completed checklist with each PLM-VE, PLM-GRAV, and NIOSH 9002 hardcopy (scanned) data deliverable is described in the "Data Pkg Checklist" tab of each of the applicable EDD templates. (Checklist No. 9.1.2.2)

Recommended Corrective Action – Ensure that data package checklists are provided with each PLM-VE, PLM-GRAV, and NIOSH 9002 hardcopy deliverable.

Data Management

This area was not evaluated since there were no data management issues identified in the June 2012 audit.

Quality Control and Quality Assurance (QA/QC)

The evaluation of this area focused on the one deficiency identified in the previous on-site audit, which has been adequately addressed. No additional deficiencies were observed.

CORRECTIVE ACTION APPLIED FROM THE PREVIOUS AUDIT FINDINGS

The on-site laboratory evaluation included an assessment of the seven (7) deficiencies identified and reported in the previous on-site audit performed on June 26-27, 2012. The Audit Team determined that the laboratory had completely addressed all seven findings (100.0%). The following are the deficiencies identified during the previous on-site audit, the laboratory's verbatim responses to the audit finding comments, and effectiveness checks performed during the current on-site audit.

Sample Receipt, Storage, Log-in, and Chain-of-Custody (COC)

1. Samples prepared or partially prepared at other EMSL facilities (i.e., Libby, MT) and transferred to EMSL in Cinna-minson, NJ (where sample preparation is completed and/or samples are analyzed) are not shipped under proper COC. The identity of the individual relinquishing and receiving the samples and the dates on which samples are relinquished and received at the EMSL laboratory are not recorded on the EMSL internal COC. The requirement that sample custody be maintained from sample collection through analysis is described in Section 5.8.1 of the laboratory's QAM. (Checklist Nos. 4.2.4.1 and 4.2.4.2)

Recommended Corrective Action – Ensure that sample custody, specifically of prepared samples transferred from one EMSL facility to another, is properly maintained.

Laboratory Response (08/13/2012): *The samples that were received at EMSL Cinna-minson were Repreparations of samples that the EMSL-Libby lab had previously submitted. The samples were submitted with a new prep log; however, no documentation of custody was transferred with the samples. The Libby Laboratory was not aware that beyond the original transfer of samples, all re-preparations should also be transferred under the same conditions. Further training was required. Robyn Denton spoke with Ron Mahoney, Lab Manager at EMSL, Libby, about transferring all samples, including re-preparations, under the appropriate Chain of Custody. Both are in agreement of the procedures going forward. Charles LaCerra of Cinna-minson Log In department is monitoring compliance.*

Results of Root Cause Analysis: *The samples that were received at EMNSL Cinnaminson were re-preparations of samples that the EMSL-Libby Lab had previously submitted. The samples were submitted with a new prep log; however, no documentation of custody was transferred with the samples. The Libby Laboratory was not aware that beyond the original transfer of samples, all re-preparations should also be transferred under the same conditions. Further training was required.*

Statement of Action/Proof of Commitment: *Robyn Denton spoke to Ron Mahoney, Lab Manager at EMSL, Libby, about transferring all samples, including re-preparations, under the appropriate Chain of Custody. Both are in agreement of the procedures going forward. Charles LaCerra of Cinnaminson Log In department is monitoring compliance.*

Evidence of Compliance: *Please see attached Inter-Laboratory Sample Transfer Inventory package including internal chain of custody (EMSL Order ID: 271200324) for recently transferred samples.*

Effectiveness Check (10/08/2013): This deficiency has been completely addressed.

Indirect and Direct Preparation of Air Filter and Dust Samples

2. The top loading balance used to weigh duff and tree bark samples is certified annually; however, it is not calibrated daily or when used. Laboratory management explained that they were having a difficult time acquiring a reference weight representative of a typical tree bark or duff sample, which would be approximately 300 grams. The requirement that balances be calibrated (verified) each day before first use is described in Section 8.2 of the laboratory's balance calibration SOP. (Checklist Nos. 6.4.4.1 and 8.4.4.2)

Recommended Corrective Action – Ensure that balances used to weigh samples are calibrated each day before first use.

Laboratory Response (08/13/2012): *The micro analytical balance weights that are currently used in the asbestos bulk preparation lab were too low to be viable verification weights for Duff and Bark samples. These weights are typically 2 g to 20g, while the weight of tree barks and Duff is typically around 300 g. Without having the proper weights to use we could not properly bracket the expected sample weights. Three additional weights have been purchased to bracket the expected weights of Bark and Duff: 30 grams, 200 grams, and 2000 grams. These weights were purchased with NIST traceable certificates. The certificates of the weights are attached in this PDF. The balance verification worksheet used for the pan balance is also attached, showing verifications done on the day that the duff and bark were dried and ashed.*

Effectiveness Check (10/08/2013): This deficiency has been completely addressed.

Transmission Electron Microscopy (TEM) Analysis

No observations concerning TEM were identified.

Polarized Light Microscopy (PLM) Analysis

3. Microscopes that have been moved from or replaced at a PLM work station are not documented in a manner which maintains traceability with the applicable maintenance and calibration logbooks. If equipment is moved or replaced from a work station, the

calibration and/or maintenance records remain at the work station. These logs are subsequently used to record calibration and maintenance activities of the replacement equipment. The requirement that a logbook be maintained for each piece of critical equipment and that all maintenance, repairs and calibrations be recorded along with the identity of the equipment is described in Section 5.5.1 of the laboratory's QAM. (Checklist No. 8.7)

Recommended Corrective Action – Ensure that all instrument maintenance, repairs, and calibrations are recorded and that any equipment moved from a work station is documented.

Laboratory Response (08/13/2012): *Recent scope additions were made to the PLM laboratory. These scopes were added to the Equipment Maintenance Log, however reference to older scopes that were put out of service were not longer represented. Going forward, the records associated with de-activated equipment will be stored in a separate spreadsheet dedicated to inactive equipment. The quality manager retrained our record custodian in the proper way to contend with obsolete electronic records. A current summary of equipment maintenance log for PLM is attached. This shows both active and inactive equipment. In the future the inactive equipment will be moved to a separate spreadsheet.*

Effectiveness Check (10/08/2013): This deficiency has been completely addressed.

4. The laboratory is not currently performing the PLM analysis of fine ground soil samples as described in the Libby-specific SOP. The Libby-specific procedure, as outlined in SOP SRC-Libby-03, requires that suspect fibers be picked out prior to preparing five random slide mounts. The procedure demonstrated by the analyst involved the preparation of five random slides mounts followed by the removal of suspect fibers. The requirement that the laboratory supervisor ensure that all analyses are performed in accordance with the SOP and that the laboratory supervisor identify and take appropriate corrective action to address any deviations is described in Section 3.1 of the Libby-specific SOP for the Analysis of Fibers in Soil by PLM (SRC-Libby-03, Rev. 2). (Checklist Nos. 8.12.1.4 and 8.15.1)

Recommended Corrective Action – Ensure that all analyses are performed in accordance with the procedures described in the Libby-specific SOP for the Analysis of Fibers in Soil by PLM.

Laboratory Response (08/13/2012): *Analyst variability and preference. Re-training of Libby PLM analysts in the correct analysis order for Libby PLM VE samples. A copy of the training records for Nancy Stalter is included as an example of the training performed.*

Effectiveness Check (10/08/2013): This deficiency has been completely addressed.

5. The set of laboratory prepared, permanently mounted, LA reference slides of 0.2% and 1.0% were not prepared "in-house," but by one of the other Libby laboratories. The requirement that laboratories analyzing samples for LA prepare five slide-mounts from both the 0.2% and 1.0% LA reference materials in a permanent medium, such as epoxy or melt-mount, is described in Section 13.7.3.2 of the Libby-specific SOP for the Analysis of Fibers in Soil by PLM (SRC-Libby-03, Rev. 2). (Checklist No. 8.12.6.3)

Recommended Corrective Action – Ensure that a permanent set of laboratory-specific slide-mounts of the 0.2% and 1.0% LA for semi-quantitative estimation of LA in fine ground soil samples are prepared in-house.

Laboratory Response (08/13/2012): *The main PLM VE analysts felt that the permanent preps sent by Reservoirs Environmental, Inc were adequate in loading for our purposes. However, there were some instances, where less material was on the slide prep, in which case we prepared a temporary reference slide from the bulk soil reference standards using 1.625 refractive index liquid. EMSL has ordered Meltmount waxes from Cargille to prepare permanent slides in-house. We have computed that we would need 73% of the 1.605 and 27% of the 1.68 melt mounts to make the slides be at ≈ 1.625 . Packing slip of meltmount waxes. We are in the process of mixing the meltmounts, however, this was not completed at the time the audit report was due. Once it is completed we will forward you evidence that the slides were made and are in use.*

Effectiveness Check (10/08/2013): This deficiency has been completely addressed.

6. The Laboratory Duplicate Cross-check (LDC) analytical observations of optical properties are currently recorded on the same bench sheet as the observations of the original analysis and are, therefore, not “blind.” The requirement that the original results be unknown when the second analysis is performed is described in Section A.5.9.3 of the laboratory’s QAM. (Checklist No. 8.14.1)

Recommended Corrective Action – Record LDC results on a separate bench sheet, other than that used to record the original results. Ensure that the results from the original analyses are unknown to the individual performing the second QC analysis.

Laboratory Response (08/13/2012): *The recording of QC on the same sheet as the original analysis was a training issue. Some of the staff were aware that this needed to be done on a different bench sheet, while others were not. Re-training of Libby PLM analysts in the correct way to perform blind QC on a sample and how to record QC for Libby PLM VE samples. See attached EMSL order ID (041220397) showing the LDC and original analyses on separate analytical worksheets.*

Effectiveness Check (10/08/2013): This deficiency has been completely addressed.

Data Management

No observations concerning data management were identified.

Quality Control and Quality Assurance

7. The laboratory’s process for tracking corrective actions that have either not been closed or that require follow-up is not adequate. Corrective actions are tracked on spreadsheets specific to the calendar quarter in which the corrective action was initiated; however, once a quarter has ended, the QAO does not review previous corrective action spreadsheets to determine the status of corrective actions initiated in previous quarters. The requirement for the QA department to ensure corrective actions are documented, addressed, and evaluated is described in Section 3.0 of the laboratory’s SOP for Non-conformities and Corrective Actions. (Checklist No. 10.4.1)

Recommended Corrective Action – Ensure that corrective actions are tracked in a manner which ensures they are addressed and that follow-up is performed in a timely manner.

Laboratory Response (08/13/2012): *Mis-communication between the QAO and laboratory management lead to a delayed review and follow-up of Corrective actions. We have asked the QAO to prepare a list of outstanding corrective actions to the appropriate supervisor and laboratory management to ensure CARs are addressed and closed out in a timely manner. Completed corrective action reports for the first and second quarter.*

Effectiveness Check (10/08/2013): This deficiency has been completely addressed.

CONCLUSIONS

An asbestos laboratory on-site audit of EMSL Analytical, Inc. in Cinnaaminson, New Jersey was performed on October 8, 2013 in support of EPA Region 8 Libby Superfund Site activities. The primary focus of the audit involved an evaluation of the corrective actions taken by the laboratory to address the deficiencies identified during the previous on-site audit conducted on June 26-27, 2012. The laboratory areas and processes evaluated included sample receipt, sample storage, sample tracking, sample preparation for Transmission Electron Microscopy (TEM) analysis, analysis by Polarized Light Microscopy (PLM), and Quality Assurance/Quality Control (QA/QC).

The Audit Team evaluated the corrective action applied to the seven deficiencies identified in the previous on-site audit, and determined that the laboratory completely addressed all seven, for a corrective action rate of 100%.

The on-site audit identified three new deficiencies:

- Lack of personnel trained to prepare duff and tree bark samples for analysis by TEM.
- Use of an incorrect compensator plate on one of the PLM microscopes used to analyze Libby samples.
- Failure to submit the PLM-VE and PLM-GRAV data package completeness checklists with the data packages.

With the exception of the three deficiencies noted above and in the report, the on-site evaluation revealed EMSL Analytical, Inc. in Cinnaaminson, New Jersey to have sufficient facilities, equipment, and staff to analyze samples in accordance with the specified methodologies and Libby-specific protocol. All staff and management were cooperative, readily answered all questions asked by the Audit Team, and appeared to be responsive to the identified deficiencies.

ATTACHMENT

Libby-Specific Asbestos Laboratory On-site Audit Checklist (EPA Only)

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013Laboratory: EMSL Analytical, Inc.Address: 200 Route 130 NorthCinnaminson, NJ 08077Telephone: (800) 220-3675Laboratory Personnel Contacted

Name	Title
Robert DeMalo	Senior Vice President
Robyn Denton	Special Projects Manager
Charles LaCerra	Special Projects/Sample Receiving Manager
Meghan Smollock	Data Coordinator
Leslie McClusky-Eissing	TEM/PLM Analyst
Melissa Klinedinst	Laboratory QC Group Leader
Garret Vliete	PLM Supervisor

Evaluation Team

Name	Title
Michael Lenkauskas, CQA	CB&I Federal Services, LLC (QATS), Senior Auditor

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

1.0 LABORATORY STATUS & CAPABILITIES	Yes	No	Comments
1.1 Which of the following capabilities does the laboratory possess: 1.1.1 Phase Contrast Microscopy (PCM)? 1.1.2 Polarized Light Microscopy (PLM)? 1.1.3 Transmission Electron Microscopy (TEM)? 1.1.4 Others (list)?	<input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/>	This is a full service laboratory.
1.2 Is the laboratory currently receiving samples from Libby Superfund Site Operable Units?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
If "YES," complete the following table:			
Operable Unit	Matrix/Method(s)		Project/Comments
The EMSL Cinnaminson laboratory has performed PLM and TEM sample analyses, on all sample matrices (i.e., air, water tree bark and duff) from all of the operable units, including OU3.			

2.0 LABORATORY SECURITY	Yes	No	Comments
2.1 Are visitors required to sign in?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
2.2 Are all entrances to the laboratory secured?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Additional Comments:			

3.0 PROJECT INITIATION/PROJECT MANAGEMENT	Yes	No	Comments
3.1 Are there designated project managers or a project management team to ensure samples received are properly processed?	NA	NA	
3.2 Are project-specific requirements and procedures communicated to laboratory staff: 3.2.1 Project-specific SOPs? 3.2.2 Laboratory Modifications? 3.2.3 SAP Analytical Summaries? 3.2.4 Project-specific Electronic Data Deliverables (EDDs)? 3.2.5 Other (list)?	<input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/>	Quality documents reside in the CDM eRoom where all EMSL analysts have access.
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

4.0 SAMPLE RECEIPT, LOG-IN, STORAGE, & TRACKING		Yes	No	Comments
4.1 Is the sample receiving area adequate, clean, and orderly?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Personnel Interviewed				
Name	Title	Experience		
Charles LaCerra	Special Projects/Sample Receiving Manager	13 Years		
4.2 Sample Receipt				
4.2.1 Is there a sample custodian and designated alternate responsible for sample receipt and log-in?		NA	NA	
4.2.2 Is the custodian or alternate available to receive and log-in samples at any time delivery services are operating?		NA	NA	
4.2.3 Are sample shipping containers opened in a HEPA hood (as necessary) to both minimize personal exposure and safeguard against laboratory contamination?		NA	NA	
4.2.4 Does the sample custodian verify and record the following when inspecting shipments and reviewing documentation:				
4.2.4.1 Presence and condition of custody seals?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
4.2.4.2 Presence or absence of Chain-of-Custody (COC) records?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
4.2.4.3 Presence or absence of air bill sticker(s)?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
4.2.4.4 Sample condition?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
4.2.4.5 Presence of packaging or packing material which could compromise samples (i.e., vermiculite & polystyrene)?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
4.2.4.6 Problems/discrepancies between samples, documentation, client requests, etc.?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
4.2.4.7 Bulk and air samples received separately?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
4.2.5 Are COC records signed and dated at the time of sample receipt?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
4.2.6 Is a system in place to ensure laboratory personnel are made aware of project specific requirements?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	All personnel have access to the CDM eRoom.
4.2.7 Is a system in place to contact the client in case of absent documentation, or discrepancies between COCs, client requests, etc.?		NA	NA	
4.2.8 Are subsequent resolutions to problems and discrepancies documented?		NA	NA	
4.3 Sample Identification				
4.3.1 Are sample receipt identification logbooks, or a LIMS, used to log-in samples and assign unique laboratory identification numbers?		NA	NA	
4.3.1.1 Does the logbook or logging system serve as a direct cross-reference between laboratory ID numbers and client ID numbers?		NA	NA	
Additional Comments:				

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

4.0 SAMPLE RECEIPT, LOG-IN, STORAGE, & TRACKING		Yes	No	Comments
4.4 Sample Storage				
4.4.1	Are storage facilities sufficient?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Samples are shipped back to ESAT (TechLaw) in Libby.
4.4.2	Is the sample storage area secured to prevent entry of unauthorized personnel?	NA	NA	
4.4.3	Is a logbook or other means used to record sample locations?	NA	NA	
4.4.4	Are samples easy to locate from logbook references?	NA	NA	
4.5 Sample Tracking				
4.5.1	Is a system in place to keep track of samples entering and leaving the storage, sample preparation, and analysis areas?	NA	NA	
4.5.2	Are the retention and/or disposal of unused portions of samples and prepared samples documented?	NA	NA	
4.5.2.1	Are project-specific retention and/or disposal requirements communicated and followed?	NA	NA	
4.6 Standard Operating Procedures (SOPs)				
4.6.1	Are the applicable laboratory SOPs available and followed by laboratory personnel (list)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	All SOPs are available on the laboratory network.
Document Title		Control No.		Description
QA Manual		Rev. 15		Section 5.4.7.1.1 of Module A
4.7 Document Control:		Yes	No	Comments
4.7.1	Are all logbooks, notebooks, forms, or other laboratory documents legible, accurate, and complete (list)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Document Title		Description/Comments		
Additional Comments:				

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

5.0 PHASE CONTRAST MICROSCOPY (PCM)		Yes	No	Comments
5.1 Does the laboratory perform PCM analyses on samples received from the Libby Superfund site? <i>If answered "No" precede to Section 6.0 of the checklist.</i>		<input type="checkbox"/>	<input checked="" type="checkbox"/>	
5.2 Is the PCM area adequate, clean, and orderly?		<input type="checkbox"/>	<input type="checkbox"/>	
5.3 Are steps taken to prevent the cross-contamination of equipment, supplies, and reagents?		<input type="checkbox"/>	<input type="checkbox"/>	
Personnel Interviewed				
Name		Title		Experience
5.4 Methods and Guidance Documents		Yes	No	Comments
5.4.1 Are the applicable guidance documents available for reference:				
5.4.1.1 NIOSH Method 7400 (Issue 2), 1994?		<input type="checkbox"/>	<input type="checkbox"/>	
5.4.1.2 Other (list)?		<input type="checkbox"/>	<input type="checkbox"/>	
5.4.2 Are project-specific requirements communicated to laboratory personnel and available for reference:				
5.4.2.1 Laboratory Modification LB-000015A?		<input type="checkbox"/>	<input type="checkbox"/>	
5.4.2.2 SOP EPA-Libby-08?		<input type="checkbox"/>	<input type="checkbox"/>	
5.4.2.3 SAP Analytical Summaries?		<input type="checkbox"/>	<input type="checkbox"/>	
5.4.2.4 Project-specific Electronic Data Deliverables (EDDs)?		<input type="checkbox"/>	<input type="checkbox"/>	
5.4.2.5 Other (list)?		<input type="checkbox"/>	<input type="checkbox"/>	
5.5 Equipment				
5.5.1 Ventilation Hoods:				
5.5.1.1 Checked routinely and recorded in a permanent logbook?		<input type="checkbox"/>	<input type="checkbox"/>	
5.5.2 Are the microscopes used to analyze samples equipped with the following:				
5.5.2.1 Positive phase contrast, with green or blue filter?		<input type="checkbox"/>	<input type="checkbox"/>	
5.5.2.2 Adjustable field iris?		<input type="checkbox"/>	<input type="checkbox"/>	
5.5.2.3 Eyepiece (8 to 10X)?		<input type="checkbox"/>	<input type="checkbox"/>	
5.5.2.4 Phase magnification (40 to 45X)?		<input type="checkbox"/>	<input type="checkbox"/>	
5.5.2.5 Walton-Beckett Graticule?		<input type="checkbox"/>	<input type="checkbox"/>	
5.5.2.6 Stage micrometer with 0.01 mm subdivisions?		<input type="checkbox"/>	<input type="checkbox"/>	
5.5.3 Are microscope and phase ring alignment checks conducted daily?		<input type="checkbox"/>	<input type="checkbox"/>	
5.5.4 Is resolution periodically checked using an HSE/NPL slide?		<input type="checkbox"/>	<input type="checkbox"/>	
5.5.5 Are maintenance and calibration activities recorded in microscope-specific logbooks?		<input type="checkbox"/>	<input type="checkbox"/>	
Additional Comments:				

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

5.0 PHASE CONTRAST MICROSCOPY (PCM)		Yes	No	Comments
5.6 Sample Preparation				
5.6.1	Are filters prepared as described in the applicable method(s)?	<input type="checkbox"/>	<input type="checkbox"/>	
5.6.2	Are filters visibly overloaded (>25%) or contain loose debris prepared indirectly as described in SOP EPA-Libby-08?	<input type="checkbox"/>	<input type="checkbox"/>	
5.7 Sample Analysis				
5.7.1	Are the appropriate counting rules used (A or B)?	<input type="checkbox"/>	<input type="checkbox"/>	
5.7.2	How are the fields and fibers tracked and recorded? _____			
5.8 Quality Control				
5.8.1	Is each analyst provided a minimum of one reference slide per work day?	<input type="checkbox"/>	<input type="checkbox"/>	
5.8.2	Are recounts analyzed at a frequency of 1 per 10 samples analyzed?	<input type="checkbox"/>	<input type="checkbox"/>	
5.8.2.1	For count pairs not within acceptance limits are associated samples recounted?	<input type="checkbox"/>	<input type="checkbox"/>	
5.9 Standard Operating Procedures (SOPs)				
5.9.1	Are the applicable laboratory SOPs available and followed by laboratory personnel (list)?	<input type="checkbox"/>	<input type="checkbox"/>	
Document Title		Control No.		Description
5.10 Document Control		Yes	No	Comments
5.10.1	Are all logbooks, notebooks, forms, or other laboratory documents legible, accurate, and complete (list)?	<input type="checkbox"/>	<input type="checkbox"/>	
Document Title		Description/Comments		
Additional Comments:				

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

6.0 TRANSMISSION ELECTRON MICROSCOPY (TEM) GRID PREPARATION		Yes	No	Comments
6.1	Are the grid preparation areas adequate, clean, and orderly?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Refer to Finding No. 1 in the Audit Report
6.2	Are bulk samples prepared in an area separate from that used to prepare air and dust samples?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
6.3	Are steps taken to prevent the cross-contamination of equipment, supplies, and reagents?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Personnel Interviewed				
Name		Title		Experience
Robyn Denton		Special Project Manager		13 Years
6.4	Equipment & Supplies	Yes	No	Comments
6.4.1	Ventilation Hoods:			
6.4.1.1	Checked routinely and recorded in a permanent logbook?	NA	NA	
6.4.2	Drying oven:			
6.4.2.1	Checked routinely and recorded in a permanent logbook?	NA	NA	
	<i>Note: Desiccator is an option for indirect preparation.</i>			
6.4.3	Muffle furnace:			
6.4.3.1	Checked routinely and recorded in a permanent logbook?	NA	NA	
6.4.4	Analytical balances:			
6.4.4.1	Checked routinely and recorded in a permanent logbook?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
6.4.4.2	Calibrated within the last 12 months by a certified technician?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
6.4.5	Plasma Asher:			
6.4.5.1	Calibrated at least quarterly and recorded in a permanent logbook?	NA	NA	
	<i>Refer to Request for Modification LB-000085A</i>			
6.4.6	Sputter Coater (Vacuum evaporator):			
6.4.6.1	Checked routinely and recorded in a permanent logbook?	NA	NA	
6.4.7	Filtration Apparatus (for indirect preparation):			
6.4.7.1	Are disposable or glass funnels used (record catalogue #)?	NA	NA	
6.4.7.2	Has the Effective Filtration Area (EFA) been determined and recorded for each apparatus?	NA	NA	
6.4.8	TEM Grids:			
6.4.8.1	Is documentation for average grid opening determination available?	NA	NA	
Additional Comments:				

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

6.0 TRANSMISSION ELECTRON MICROSCOPY (TEM) GRID PREPARATION	Yes	No	Comments
6.5 Direct and Indirect Preparation Methodology			
6.5.1 What method(s) does the laboratory use to prepare air and dust samples for TEM analysis:			
6.5.1.1 40 CFR, Chapter 1, Part 763, Subpart E - AHERA?	NA	NA	
6.5.1.2 ISO 10312:1195 E - Determination of Asbestos Fibers?	NA	NA	
6.5.1.3 ASTM D 5755-09 - Micro vacuum Sampling and Indirect Analysis of Dust by TEM?	NA	NA	
6.5.1.4 Others (list)?	NA	NA	
6.5.2 Are project-specific requirements communicated to laboratory personnel and available for reference:			
6.5.2.1 Laboratory Modifications?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Quality documents reside in the CDM eRoom, to which all EMSL analysts have access.
6.5.2.2 Project-specific SOPs?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
6.5.2.3 SAP Analytical Summaries?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
6.5.2.4 Other (list)?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
6.6 Sample Inspection			
6.6.1 Are air filter cassettes carefully wet-wiped prior to being transferred to the clean preparation area for inspection?	NA	NA	
6.6.2 Are air filter samples which are visibly overloaded, exhibit uneven loading, or contain loose debris, prepared indirectly? <i>Refer to Laboratory Modifications LB-000016H & LB-000031G</i>	NA	NA	
6.6.3 Are all ambient air samples dried upon receipt at the on-site laboratory (i.e., EMSL-Libby) prior to preparation and analysis? <i>Refer to Laboratory Modification LB-000055A</i>	NA	NA	
6.7 Direct Preparation of MCE and Polycarbonate Filters			
6.7.1 Are MCE filters collapsed using either a Di-Methyl Formamide (DMF) or acetone atmosphere (AA) technique (describe technique)? <i>The use of an acetone vaporizer ("hot block") is not advised due to the formation of wind rows and tilted fibers.</i>	NA	NA	
6.7.2 Is plasma etching performed on collapsed MCE filters?	NA	NA	
6.7.2.1 Is a 5 to 10% layer of the collapsed surface removed during etching?	NA	NA	
6.7.3 Are collapsed MCE filters and secured polycarbonate filters transferred to a vacuum evaporator for carbon coating?	NA	NA	
6.7.4 Are excised filter sections placed on the appropriately labeled TEM grids and cleared using a Jaffe Washer or an equivalent technique (describe)?	NA	NA	
6.7.5 Are samples checked for remaining filter residue after clearing?	NA	NA	
6.7.5.1 If residue remains, is condensation washing or an equivalent technique used (describe technique)?	NA	NA	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

6.0 TRANSMISSION ELECTRON MICROSCOPY (TEM) GRID PREPARATION	Yes	No	Comments
6.8 Indirect Sample Preparation of Air and Dust Samples			
6.8.1 Are the applicable Libby guidance documents available for reference:			
6.8.1.1 SOP EPA-Libby-08 – Indirect Preparation of Air and Dust Sample for TEM Analysis?	NA	NA	
6.8.2 Sample filtration:			
6.8.3 Are the applicable SAP Analytical Summaries reviewed to determine the whether or not filter samples must be ashed?	NA	NA	
6.8.3.1 Are cassettes examined for loose material?	NA	NA	
6.8.3.1.1 If loose material or uneven loading is not evident, is a portion of the air samples retained?	NA	NA	
6.8.3.1.2 If loose material is evident, is the loose material filtered along with the air filter?	NA	NA	
6.8.3.2 Ashing (if applicable):			
6.8.3.2.1 Are filters covered with aluminum foil and placed in a plasma asher?	NA	NA	
6.8.3.2.2 Is the plasma asher operated at minimum power?	NA	NA	
6.8.3.2.3 Is 100% ashing confirmed by visual observation?	NA	NA	
6.8.3.3 Are air filters, loose material, dust, or ash, rinsed into a beaker and brought to a final volume of 100 mL with particle-free water?	NA	NA	
6.8.3.3.1 Adjusted to a pH of 3-4 with a 10% solution of glacial acetic acid?	NA	NA	
6.8.3.3.2 Sonicated for 3 minutes and allowed to settle for 2 minutes prior to filtering?	NA	NA	
6.8.3.4 Are the appropriate aliquots of filtrate passed through a <u>disposable</u> 25 mm filter assembly with a 0.2 µm MCE filter with a 5.0 µm MCE support pad?	NA	NA	
6.8.4 Are serial dilutions performed as necessary?	NA	NA	
6.8.5 Are TEM grids prepared as described in Section 6.7 of this checklist?	NA	NA	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

6.0 TRANSMISSION ELECTRON MICROSCOPY (TEM) GRID PREPARATION	Yes	No	Comments
6.9 Water Sample Preparation			
6.9.1 What method(s) does the laboratory use to prepare water samples for TEM analysis:			
6.9.1.1 EPA Method 100.2 - Determination of Asbestos Structures Over 10 µm in Length in Drinking Water?	NA	NA	
6.9.1.2 EPA Method 100.1 - Determination of Asbestos Fibers Drinking Water?	NA	NA	
6.9.1.3 Others (describe)? _____	NA	NA	
6.9.2 Are samples received and filtered by the laboratory within 48 hours of collection?	NA	NA	
6.9.2.1 If not, are they stored in a refrigerator until filtered?	NA	NA	
6.9.3 Laboratory Modification LB-000020A:			
6.9.3.1 Do samples undergo treatment with ozone/UV light?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
6.9.3.2 Are samples hand-agitated and sonicated?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
<i>Refer to Section 6.2 of EPA Method 100.1</i>			
6.9.4 Are the appropriate aliquots of the original sample poured through a 25 mm or 47 mm MCE filter (0.22 µm or smaller pore size) with an MCE filter (5 µm pore size) backing pad?	NA	NA	
Note: No less than 1 mL must be used as an aliquot.			
6.9.5 Are TEM grids prepared as described in Section 6.7 of this checklist?	NA	NA	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

6.0 TRANSMISSION ELECTRON MICROSCOPY (TEM) GRID PREPARATION	Yes	No	Comments
6.10 OU3 Tree Bark Sample Preparation			
6.10.1 Are the applicable Libby guidance documents available for reference:			
6.10.1.1 EPA-Libby-2012-12 – Sampling and Analysis of Tree Bark for Asbestos?	NA	NA	
6.10.2 Drying and Ashing:			
6.10.2.1 Are the diameter and thickness of the tree bark samples measured and recorded to an accuracy of ± 2 mm?	NA	NA	
6.10.2.2 Is the entire tree bark sample weighed and placed in an oven for drying?	NA	NA	
6.10.2.2.1 Dried at 80° C until the weight stabilizes, a minimum of 6 hours, and weighed?	NA	NA	
6.10.2.3 Is the bark sample then covered and placed in a muffle furnace at 450° C for 18 hours, or until all organic matter has been removed, and weighed?	NA	NA	
6.10.2.3.1 Is the furnace ramped from 0° F to 450° C?	NA	NA	
6.10.3 Acid Treatment:			
6.10.3.1 After adding approximately 1-2 mL of DI water, is 10-20 of concentrated HCL added until no further reaction is visible (approx. 3-5 minutes)?	NA	NA	
6.10.3.2 Are samples diluted, transferred to a 100 mL container (with lid) and brought to a final volume of 100 mL with fiber-free DI water?	NA	NA	
6.10.3.3 Are samples capped, inverted 5-6 times, and sonicated for 2 minutes in preparation for filtering?	NA	NA	
6.10.4 Filtration:			
6.10.4.1 Are 5-20 mLs of solution transferred to a second container and brought to a volume of 100 mL with fiber-free DI water?	NA	NA	
6.10.4.2 Are dilutions agitated (inverted 5-6 times) and filtered through a 47 mm MCE filter (0.45 μ m pore size)?	NA	NA	
6.10.4.2.1 Are additional dilutions prepared if the loading on the filter appears either too heavy (> 20%) or too light?	NA	NA	
6.10.5 Are TEM grids prepared as described in Section 6.7 of this checklist?	NA	NA	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

6.0 TRANSMISSION ELECTRON MICROSCOPY (TEM) GRID PREPARATION	Yes	No	Comments
6.11 OU3 Duff Sample Preparation			
6.11.1 Are the applicable Libby guidance documents available for reference:			
6.11.1.1 EPA-Libby-2012-11 – Sampling and Analysis of Duff for Asbestos?	NA	NA	
6.11.2 Drying and Ashing:			
6.11.2.1 Are the appropriate number of aluminum trays weighed and tared?	NA	NA	
6.11.2.1.1 For tracking purposes, is each tray marked with a unique number?	NA	NA	
6.11.2.2 Are trays filled to approximately $\frac{3}{4}$, dried at 60° C until the weight stabilizes a minimum of 10 hours, and weighed?	NA	NA	
6.11.2.3 Are dried duff samples transferred to covered pans and placed in a muffle furnace at 450° C for 18 hours, or until all organic matter has been removed, and weighed?	NA	NA	
6.11.2.4 Are ashed samples transferred to Zip-lock bags and homogenized?	NA	NA	
6.11.2.4.1 If an individual sample was split between multiple trays, was it combined into one Zip-lock bag?	NA	NA	
6.11.3 Acid Treatment:			
6.11.3.1 After adding approximately 1-2 mL of DI water to 0.25 grams (measured to ± 0.01 g) of ashed sample, is 10-20 mL of concentrated HCL added until no further reaction is visible (approx. 3-5 minutes)?	NA	NA	
6.11.3.2 Are samples diluted, transferred to a 100 mL container (with lid) and brought to a final volume of 100 mL with fiber-free DI water?	NA	NA	
6.11.3.3 Are sample capped, inverted 5-6 times, and sonicated for 2 minutes in preparation for filtering?	NA	NA	
6.11.4 Filtration:			
6.11.4.1 Is 0.1 to 1.0 mL of solution transferred to a second container and brought to a volume of 100 mL with fiber-free DI water?	NA	NA	
6.11.4.2 Are dilutions agitated (inverted 5-6 times) and filtered through a 47 mm MCE filter (0.45 μ m pore size)?	NA	NA	
6.11.4.2.1 Are additional dilutions prepared if the loading on the filter appears either too heavy (> 20%) or too light?	NA	NA	
6.11.5 Are TEM grids prepared as described in Section 6.7 of this checklist?	NA	NA	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

6.0 TRANSMISSION ELECTRON MICROSCOPY (TEM) GRID PREPARATION	Yes	No	Comments
6.12 Grid Preparation/filtrate Storage			
6.12.1 For indirect preparations, are remaining filtrates filtered onto the appropriate filter(s) to be archived?	NA	NA	
6.12.2 Are all remaining filters and filter portions labeled prior to archiving?	NA	NA	
6.12.3 Are grids stored in marked grid storage boxes or other suitable containers and stored in a dust/fiber free environment?	NA	NA	
6.12.4 Is the location of grid preparation recorded in such a manner that they can be retrieved upon request in a timely manner?	NA	NA	
6.13 Quality Control Samples			
6.13.1 Are quality control samples prepared at the described frequency:			
6.13.1.1 Are laboratory blanks (LB) prepared at a frequency of 4% or with each preparation batch, whichever is more frequent?	NA	NA	
6.13.1.2 Are re-preparations prepared at a frequency of 1%?	NA	NA	
6.14 Standard Operating Procedures (SOPs)			
6.14.1 Are the applicable laboratory SOPs available and followed by laboratory personnel (list)?	NA	NA	
Document Title	Control No.	Description	
6.15 Document Control	Yes	No	Comments
6.15.1 Are all logbooks, notebooks, forms, or other laboratory documents legible, accurate, and complete (list)?	NA	NA	
Document Title	Description/Comments		
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

7.0 TEM ANALYSIS		Yes	No	Comments
7.1 Are TEM areas adequate, clean, and orderly?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.2 Are steps taken to prevent the cross-contamination of equipment, supplies, and reagents?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Personnel Interviewed				
Name	Title	Experience		
Leslie McClusky-Eissing	TEM Analyst	1 Year		
7.3 Methods and Guidance Documents		Yes	No	Comments
7.3.1 What method(s) does the laboratory use to analyze samples TEM:				
7.3.1.1	40 CFR, Chapter 1, Part 763, Subpart E (AHERA)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.3.1.2	ISO 10312:1995 E - Determination of Asbestos Fibers?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.3.1.3	ASTM D 5755-09 - Microvacuum Sampling and Indirect Analysis of Dust by TEM?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.3.1.4	EPA Method 100.2 - Determination of Asbestos Structures Over 10 µm in Length in Drinking Water?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.3.1.5	Others (list)? _____	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
7.3.2 Are project-specific requirements communicated to laboratory personnel and available for reference:				
7.3.2.1	Laboratory Modifications?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Quality documents reside in the CDM eRoom, to which all EMSL analysts have access.
7.3.2.2	Project-specific SOPs?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.3.2.3	SAP Analytical Summaries?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.3.2.4	Project-specific Electronic Data Deliverables (EDDs)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.3.2.5	Other (list)? _____	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
7.4 TEM Instrumentation				
7.4.1 Does TEM instrumentation meet the following requirements:				
7.4.1.1	Capable of being operated at between 80 and 120 kV?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.4.1.2	Electron diffraction (ED) and energy dispersive X-ray (EDX) capabilities?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.4.1.3	Fluorescent screen with an inscribed or overlaid calibrated scale?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.4.2 Are the instruments equipped with thin film or beryllium windows (list below if necessary)? <u>Beryllium & Light Element</u>		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.4.3 Are all routine and non-routine maintenance activities recorded in instrument-specific logbooks?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	All maintenance is recorded on an electronic spreadsheet.
Instrument No.	Make	Model	Capabilities	
04-01	JOEL	JEM-100CX II	Digital picture capabilities/Light Element	
04-03	JOEL	JEM-200X	Digital picture capabilities/Beryllium	
04-05	JOEL	JEM-100CX II	Digital picture capabilities/Light Element	
Additional Comments:				

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

7.0 TEM ANALYSIS	Yes	No	Comments
7.5 Instrument Calibration (Laboratory Modification LB-00085A)			
7.5.1 Is microscope alignment performed <u>daily</u> :			
7.5.1.1 Centering of electron beam?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.5.1.2 Electron beam is properly stigmated on either side of crossover?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.5.1.3 Image properly focused?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.5.2 Is the TEM screen magnification calibrated <u>monthly</u> ?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.5.3 Is the camera constant calibrated <u>monthly</u> ?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Weekly
7.5.4 Is the spot size diameter determined to be less than 250 nm <u>quarterly</u> ?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.5.5 Is the low beam dose (≥ 15 seconds for Chrysotile) verified <u>quarterly</u> ?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.5.6 EDXA System:			
7.5.6.1 Is X-ray energy versus channel for two peaks (i.e., Cu/Al) checked <u>daily</u> ?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.5.6.2 Is detector resolution (Mn) checked <u>quarterly</u> ?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.5.6.3 Are K-factors relative to Si determined for Na, Mg, Al, Ca, and Fe <u>quarterly</u> ?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.5.7 Are instrument calibration records maintained in instrument-specific logbooks?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	All calibrations are recorded on an electronic spreadsheet.
7.6 Reference Materials			
7.6.1 Does the laboratory maintain a library of reference materials on asbestos and other fiber types?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.6.2 Are instrument-specific "LA" spectra available, posted near the TEM?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.7 Grid Acceptance/Rejection Criteria			
7.7.1 Grid preparation rejection criteria:			
7.7.1.1 The replica is too dark due to poor dissolution?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.7.1.2 Replica is doubled or folded?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.7.1.3 Replica has $> 25\%$ obscuration rejected?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.7.1.4 Replica has < 50 intact grid openings?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
<i>Refer to Request for Modifications LB-000016H and LB-000031G</i>			
7.7.2 Are samples associated with grids determined to be overloaded ($>25\%$) re-prepped using the indirect-transfer technique described in SOP EPA-Libby-08?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

7.0 TEM ANALYSIS	Yes	No	Comments
7.8 Modifications to AHERA & ASTM D5755:			
7.8.1 Laboratory Modification LB-000031G:			
7.8.1.1 Are structures classified as fibers (F), bundles (B), clusters (C) or matrices (M)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.8.1.2 Are the actual lengths and widths of fibers, bundles, clusters and matrices (M) recorded?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.8.1.3 For disperse matrices and clusters, is the length of the longest protruding structure recorded?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.8.1.4 Unless identified as a "close call" (LB-000066D), are NAMs not recorded?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.8.1.5 Is the designation "ND" used to document when no structures are detected in a grid opening?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.8.1.6 Are fibers, bundles, clusters and matrices only recorded they contain individual constituent fibers meeting the aspect ratio criterion?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.8.1.7 Are non-countable recorded, but not counted, for informational purposes?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.8.1.8 Is the entire length recorded for structures originating in one grid opening and extending to an adjacent grid opening?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.8.2 Laboratory Modification LB-000067:			
7.8.2.1 Are the structure identification codes described in Tables D.1 and D.2 of ISO Method 10312 used?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.9 Modifications to EPA Method 100.2:			
7.9.1 Laboratory Modification LB-000020:			
7.9.1.1 Are all applicable analyte structures, including those comprising the LA complex, $\geq 0.5 \mu$ in length with a \geq AR recorded?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.9.1.2 Are a maximum of 10 grid openings counted?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.9.2 Laboratory Modification LB-000067:			
7.9.2.1 Are the structure identification codes described in Tables D.1 and D.2 of ISO Method 10312 used?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

7.0 TEM ANALYSIS	Yes	No	Comments
7.10 Modifications to ISO Method 10312:			
7.10.1 Laboratory Modification LB-000016H:			
7.10.1.1 Unless identified as a "close call" (LB-000066D), are NAMs recorded?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.10.1.2 Are bundles only recorded if they contain individual constituent fibers meeting the aspect ratio criterion?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.10.1.3 Are bundles, compact clusters, and compact matrices counted regardless of aspect ratio?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.10.1.4 Are structures that intersect non-countable grid bars recorded for informational purposes?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.10.1.5 Are component structures, which do not intersect non-countable grid bars, but are within non-countable structures counted?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.10.1.6 Is the entire length recorded for structures originating in one grid opening and extending to an adjacent grid opening?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.10.1.7 For structures which intersect more than one grid bar is the observed length of the structure recorded?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.10.1.8 Are the recorded rules for partially obscured structures properly applied (i.e., MFO and MBO)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.10.1.9 Are the counting and recording rules for the identification of PCMe structures at "low magnification" applied?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.11 Common TEM Modifications:			
7.11.1 Laboratory Modification LB-000030:			
7.11.1.1 Are highly detailed sketches of up to 50 asbestos structures provided?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.11.2 Laboratory Modification LB-000066D:			
7.11.2.1 Is the presence or absence of sodium and potassium recorded for all LA, OA and NAM particles (NaK, NaX, XK or XX)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.11.2.2 Is probable mineral identification code recorded for all particles?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.11.2.2.1 Are LA particles identified as WRTA, AC, TR or AT?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.11.2.2.2 Are OA particles identified as AM, AN or CR?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.11.2.2.3 Are NAMs indicated as PY, OT or UN?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.11.2.3 Is one SAED pattern recorded for each amphibole asbestos type encountered per samples?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.11.2.4 Are EDS spectrum (a maximum of 5) collected for up to 5 LA and 5 Close-call NAM per sample?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

7.0 TEM ANALYSIS		Yes	No	Comments
7.12 Counting/stopping rules:				
7.12.1 Are the Analytical Summaries reviewed to determine the following:				
7.12.1.1 Analytical Sensitivity?	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7.12.1.2 Recording rules (i.e., AR)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7.12.1.3 Stopping rules (i.e., abundant CH)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7.12.1.4 Applicable Laboratory Modifications?	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7.12.1.5 Investigative or non-investigative?	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7.13 Quality Control Analyses (Laboratory Modification LB-000029C)				
7.13.1 Are quality control samples analyzed at the required frequencies:				
7.13.1.1 Laboratory blanks – Frequency 4%?	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7.13.1.2 Recount Same (RS) - Frequency of 1%?	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7.13.1.3 Recount Different (RD) - Frequency of 2.5%?	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7.13.1.4 Inter-laboratory - Frequency of 0.5%?	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7.13.1.5 Verified Analysis (VA) - Frequency of 1%?	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7.13.1.6 Re-preparations – Frequency of 1%	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7.13.2 Are samples selected for RS, RD and VA analyses in accordance with Laboratory Modification LB-000029C?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.13.3 Is the procedure used to evaluate QC sample analyses in accordance with Laboratory Modification LB-000029C?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
7.14 Standard Operating Procedures (SOPs)				
7.14.1 Are the applicable laboratory SOPs available and followed by laboratory personnel (list)?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	All SOPs are available on the laboratory network.
Document Title	Control No.	Description		
7.15 Document Control		Yes	No	Comments
7.15.1 Are all logbooks, notebooks, forms, or other laboratory documents legible, accurate, and complete (list)?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Document Title	Description/Comments			
Daily Calibration Log	Top loading balance.			
Additional Comments:				

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

8.0 POLARIZED LIGHT MICROSCOPY (PLM)		Yes	No	Comments
8.1 Are PLM areas adequate, clean, and orderly?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.2 Are steps taken to prevent the cross-contamination of equipment, supplies, and reagents?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Personnel Interviewed				
Name	Title	Experience		
Garret Vliete	PLM Supervisor	3 Years		
Melissa Klinedinst	Laboratory QC Group Leader	6 Years		
Leslie McClusky-Eissing	PLM Analyst	3 Years		
8.3 Methods and Guidance Documents		Yes	No	Comments
8.3.1 Are the applicable guidance documents available for reference:				
8.3.1.1 EPA SOP SRC-Libby-01?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.3.1.2 EPA SOP SRC-Libby-03?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.3.1.3 NIOSH 9002, Issue 2 - Asbestos (Bulk) by PLM?		<input type="checkbox"/>	<input checked="" type="checkbox"/>	
8.3.1.4 Others (list)?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	EPA 600
8.3.2 Are project-specific requirements communicated to laboratory personnel and available for reference:				
8.3.2.1 Laboratory Modifications?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.3.2.2 Project-specific SOPs?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.3.2.3 SAP Analytical Summaries?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.3.2.4 Project-specific Electronic Data Deliverables (EDDs)?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.3.2.5 Other (list)?		<input type="checkbox"/>	<input checked="" type="checkbox"/>	Quality documents reside in the CDM eRoom, to which all EMSL analysts have access.
8.4 Equipment				
8.4.1 Ventilation Hoods:				
8.4.1.1 Checked routinely and recorded in a permanent logbook?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.4.2 Drying oven (optional):				
8.4.2.1 Checked routinely and recorded in a permanent logbook?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.4.3 Muffle furnace:				
8.4.3.1 Checked routinely and recorded in a permanent logbook?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Additional Comments:				

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

8.0 POLARIZED LIGHT MICROSCOPY (PLM)		Yes	No	Comments
8.4.4 Analytical balances:				Not necessary, SOP SRC-Libby-01 to be revised.
8.4.4.1 Two balances:				
8.4.4.1.1 Accurate to 0.01 g, range of 0.01 to 1000 g?		<input type="checkbox"/>	<input checked="" type="checkbox"/>	
8.4.4.1.2 Accurate to 1 mg?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.4.4.2 Checked routinely and recorded in a permanent logbook?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.4.4.3 Calibrated within the last 12 months by a certified technician?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.5 Stereomicroscope				
8.5.1 Do stereomicroscopes meet the following requirements:				
8.5.1.1 Magnification range of 10X to 50X?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.5.1.2 Incandescent or fluorescent light source?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6 Polarized Light Microscope				
8.6.1 Are PLMs equipped with the following:				Refer to Finding No. 2 in the Audit Report
8.6.1.1 Light source and replacement bulbs?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.2 Binocular observation tube?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.3 Blue daylight filter?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.4 Oculars (10X)?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.5 Objectives: 10X, 20X and 40X (or similar)?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.6 10X dispersion staining objective?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.7 A 360 degree graduated rotating stage?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.8 Polarizer and analyzer aligned at 90 degrees to one another?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.9 Bertrand lens?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.10 Substage condenser with iris diaphragm?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.11 Accessory slot for compensator plate?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.12 First order red (550 nanometer) compensator plate?		<input type="checkbox"/>	<input checked="" type="checkbox"/>	
8.6.1.13 Crosshair reticle?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.6.1.14 Adjustment tools?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.7 Are microscopes well-maintained, and are all routine and non-routine maintenance activities recorded in instrument-specific logbooks?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Instrument No.	Make	Model	Capabilities	
Station 10	Leica	DM750P		
Thirteen (13) additional PLM stations are available.				
Additional Comments:				

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

8.0 POLARIZED LIGHT MICROSCOPY (PLM)	Yes	No	Comments
8.8 Refractive Index Liquids			
8.8.1 What refractive index liquids are available:			
8.8.1.1 High dispersion RI liquids from 1.620 to 1.640?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1.625
8.8.1.2 1.550 high dispersion RI liquid?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.8.1.3 1.680 to 1.700 RI liquids?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.8.2 Are refractive index liquids checked daily for contamination?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Salt is used to check RIs, tools, etc.
8.8.3 Are refractive index (RI) liquids calibrated monthly using a refractometer or other means (describe)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Quarterly and prior to PLM-VE or PLM-Grav analyses
8.9 Reference Materials			
8.9.1 Does the laboratory maintain a library of asbestos and non-asbestos reference materials:			
8.9.1.1 NIST SRM 1866b (Ch, Am and Cr)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.9.1.2 NIST SRM 1867a (Tr, Ac, and An)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.9.1.3 USGS LA PEs:	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.9.1.3.1 LA 0.2% by mass?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.9.1.3.2 LA 1.0% by mass?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.9.1.3.3 Other (List)?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	2.0 % LA
8.9.1.4 Controlled LA asbestos (USGS)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.9.1.5 NIST testing round M12001 (winchite/richterite)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.9.1.6 Non-asbestos (i.e., gypsum, calcite, and fiberglass)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.10 PLM Calibration	Yes	No	Comments
8.10.1 Is PLM alignment performed daily:			
8.10.1.1 Alignment?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.10.1.2 Stage and objectives centered?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.10.1.3 Optic axis centered?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.10.1.4 Alignment of the upper/lower polars?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.10.1.5 Centered through substage condenser and iris diaphragm?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.10.2 Microscope adjustments verified and recorded prior to sample analyses?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

8.0 POLARIZED LIGHT MICROSCOPY (PLM)	Yes	No	Comments
8.11 PLM Analysis by NIOSH Method 9002:			
8.11.1 Does the laboratory perform PLM analyses on samples received from the Libby Superfund site?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
<i>If answered "No" precede to Section 8.11 of the checklist.</i>			
8.11.2 Are samples visually examined by stereomicroscope for the following:			
8.11.2.1 Color?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.2.2 Homogeneity?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.2.3 Texture?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.3 Which of the following techniques are used to prepare samples for analysis:			
8.11.3.1 Mortar & pestle?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.3.2 Acid washing?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.3.3 Ashing?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.3.4 Solvents?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.3.5 Other (list)?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.4 For non-friable, organically bound samples requiring ashing and/or acid reduction, are all necessary weights and tare weights measured and recorded?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.5 Are slides prepared using the appropriate refractive index liquid(s) and scanned for asbestos fibers using the following optical properties:			
8.11.5.1 Morphology?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.5.2 Color?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.5.3 Refractive indices?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.5.4 Pleochroism?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.5.5 Birefringence?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.5.6 Extinction characteristics?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.5.7 Sign of elongation?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.5.8 Dispersion staining characteristics?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.6 Are the observed optical properties compared to Table 1 (Optical Properties of Asbestos Fibers) to determine the asbestos mineral present?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.7 Is a quantitative assessment of asbestos content made from both the gross and microscopic examinations?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.8 If no fibers are detected in a homogeneous samples are at least two additional slides prepared and analyzed prior to concluding no asbestos is present?	<input type="checkbox"/>	<input type="checkbox"/>	
8.11.9 Is at least one optical property recorded for fibers determined to be non-asbestos fibers?	<input type="checkbox"/>	<input type="checkbox"/>	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

8.0 POLARIZED LIGHT MICROSCOPY (PLM)	Yes	No	Comments
8.12 PLM-VE (SOP SRC-Libby-03)			
8.12.1 Stereomicroscopic Examination:			
8.12.1.1 Are all sample preparation activities performed within a HEPA-filtered hood?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.1.2 Is the entire sample transferred to an asbestos-free substrate for examination?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.1.3 Is the entire sample examined for homogeneity and the presence of suspect fibers?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.1.4 Are suspect fibers removed with fine forceps and mounted in the appropriate RI liquid for PLM analysis?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.1.5 Are the stereomicroscopic findings recorded:			
8.12.1.5.1 Sample appearance?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.1.5.2 Estimated percentage of LA?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.1.5.3 Estimated percentage of other asbestos types?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.2 Determination of Ashing the Sample:			
8.12.2.1 Are soil sample containing a significant amount of artifacts ashed prior to being prepared for random PLM mounts?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.2.1.1 Are samples ashed in a muffle furnace at approximately 480°C?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.2.1.2 Are the necessary gravimetric measurements recorded for the determination of "Pre-ash percent asbestos"?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.3 Slide Preparation for PLM-VE:			
8.12.3.1 Are a minimum of five random sub-samples mounted in the appropriate RI liquid (1.620-1.640) for measurement of LA optical properties?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.4 Supplemental Stereomicroscopic Evaluation:			
8.12.4.1 Following the random slide mount preparation, is the container agitated to cause the particulate to settle and asbestos fibers sort to the surface?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.4.2 Is the sample re-examined and the fiber pick procedure repeated?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

8.0 POLARIZED LIGHT MICROSCOPY (PLM)	Yes	No	Comments
8.12.5 Classification of Asbestos Mineral Type:			
8.12.5.1 Using PLM is entire area of each prepared slide examined for asbestos, non-asbestos and matrix material?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.5.2 Is positive identification determined from the following six optical properties:			
8.12.5.2.1 Habit?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.5.2.2 Color & pleochroism (if present)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.5.2.3 Both alpha and gamma Refractive indices?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.5.2.4 Birefringence?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.5.2.5 Extinction angle?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.5.2.6 Sign of elongation (positive-slow or negative fast)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.5.3 Based on the optical properties, is asbestos classified into one of three categories:			
8.12.5.3.1 Libby Amphibole (LA)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.5.3.2 Other Amphibole (OA)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.5.3.3 Chrysotile (CH)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.5.4 Is at least one optical property recorded for observed non-asbestos fibers?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.6 Quantification of Asbestos Content:			
8.12.6.1 Is asbestos reported as either mass or area percent for LA?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.6.2 Are other, non-LA, asbestos types reported in area percent?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.6.3 Are reference materials used to aid in visual estimation:			
8.12.6.3.1 LA PE reference materials (0.2% or 1.0%)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.6.3.2 Are visual estimates of greater than 1% LA performed using calibration standards made in-house from NIST SRMs and NIST PEs?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.7 Are calibrated visual estimates determined from both the detailed stereomicroscopic observations and examination of the total area for all five random slide mounts?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.8 Are LA results reported in the appropriate bin categories:			
8.12.8.1 Non-detects recorded as Bin A?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.8.2 Less than 0.2% LA recorded as Bin B1?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.8.3 Greater than 0.2%, but less than 1% recorded as Bin B2?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.12.8.4 Equal to or greater than 1% recorded as Bin C, with the percentage recorded as a whole number?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

8.0 POLARIZED LIGHT MICROSCOPY (PLM)	Yes	No	Comments
8.13 PLM-GRAV (SOP SRC-Libby-01)			
8.13.1 Stereomicroscopic Examination:			
8.13.2 Is the entire sample weighed and placed in an appropriate container?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.3 Does the stereomicroscopic examination include:			
8.13.3.1 Examination of multiple fields of view over the entire sample?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.3.2 Probing of the sample and breaking clumps where possible?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.3.3 Manipulation of the sample with the appropriate tools?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.3.4 Observation homogeneity, texture, friability, color and extent of any asbestos content?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.4 Does the analyst refrain from segregating and weighing particles smaller than 2 - 3 mm (1/10 inch)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.5 If no particles larger than 2 – 3 mm or larger are present, are one of the following recorded:			
8.13.5.1 No asbestos detected (ND)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.5.2 Trace levels of asbestos observed, but not quantified (Tr)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.6 Examination by PLM:			
8.13.7 Are tentatively identified asbestos particles examined by PLM as described in SOP SRC-Libby-03 (Section 8.12 of this checklist)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.8 If asbestos particles are determined to be OA, are they further characterized:			
8.13.8.1 Amosite (AMOS)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.8.2 Anthophyllite (ANTH)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.8.3 Crocidolite (CROC)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.8.4 Unknown (UNK)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.9 Is the total weight of each type of positively identified asbestos measured and recorded?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.13.10 Record Keeping:			
8.13.11 Is the data log sheet provided in Attachment 1 of the SOP used to record weights the initial (coarse fraction) and segregated asbestos?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Additional Comments:			

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

8.0 POLARIZED LIGHT MICROSCOPY (PLM)		Yes	No	Comments
8.14 Quality Control Analyses				
8.14.1 Are the following types of QC analyses performed at the required frequencies:				
8.14.1.1 Laboratory duplicate self-check (LDS) at a frequency of 2%?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.14.1.2 Laboratory duplicate cross-check (LDC) at a frequency of 8%?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.14.2 For sample containing LA, are LDS and LDC analyses considered acceptable if:				
8.14.2.1 For LA results, within 1 Bin category?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.14.2.2 For LA results, %LA ≤1%?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Note: For LA results greater than 1%, the laboratory should refer to their internal QA/QC system.				
8.14.3 Is the appropriate correction action taken when LDC or LDS analyses do not meet acceptance criteria (describe)?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
8.15 Standard Operating Procedures (SOPs)				
8.15.1 Are the applicable laboratory SOPs available and followed by laboratory personnel (list)?		<input type="checkbox"/>	<input checked="" type="checkbox"/>	Refer to Finding No. 2 in the Audit Report
Document Title	Control No.	Description		
8.16 Document Control		Yes	No	Comments
8.16.1 Are all logbooks, notebooks, forms, or other laboratory documents legible, accurate, and complete (list)?		<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Document Title	Description/Comments			
Additional Comments:				

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

9.0 DATA MANAGEMENT	PCM	TEM	PLM	Comments
9.1 Data Package Review and Assembly	Yes	Yes	Yes	
9.1.1 Are deliverables reviewed to ensure project-specific requirements are adhered to:				
9.1.1.1 Request for Modifications to Laboratory Activities?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Quality documents reside in the CDM eRoom, to which all EMSL analysts have access.
9.1.1.2 Project-specific SOPs?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
9.1.1.3 SAP Analytical Summaries?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
9.1.1.4 Project-specific Electronic Data Deliverables (EDDs)?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
9.1.1.5 Other (list)? _____	NA	<input type="checkbox"/>	<input type="checkbox"/>	
9.1.2 Are all deliverables reviewed for completeness and accuracy prior to being submitted:				
9.1.2.1 Hard copy deliverables?	NA	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Refer to Finding No. 3 in the Audit Report
9.1.2.2 Electronic deliverables?	NA	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
9.1.3 Are all reviews documented?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
9.2 Data Submission				
9.2.1 Is the submittal of electronic deliverables tracked and recorded:				
9.2.1.1 Date submitted?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
9.2.1.2 Recipient?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
9.2.2 Is the submittal of hard copy deliverables tracked and recorded:				
9.2.2.1 Date submitted?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
9.2.2.2 Recipient?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
9.3 Data Storage and Archiving				
9.2.3 Are electronic files archived onto suitable media on a frequent basis?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
How often? _____				
9.2.4 Are all hardcopy data stored in a secured location with limited access (e.g., locking file cabinet)?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Stored off-site in a secure facility
Additional Comments:				

LIBBY-SPECIFIC ASBESTOS LABORATORY ON-SITE AUDIT CHECKLIST

USEPA

Date(s) of On-site: 10/08/2013

10.0 QUALITY ASSURANCE/QUALITY CONTROL	PCM	TEM	PLM	Comments
10.1 Laboratory Certifications	Yes	Yes	Yes	
10.1.1 Is the laboratory accredited for asbestos analysis under the National Voluntary Laboratory Accreditation Program (NVLAP):				
10.1.1.1 Asbestos Fiber Analysis (TEM Method)?	NA	<input checked="" type="checkbox"/>	NA	2010, expires 10/2012
10.1.1.2 Asbestos Fiber Analysis (PLM Method)?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	2010, expires 10/2012
10.1.2 Is the laboratory accredited for asbestos analysis under the American Industrial Hygiene Association (AIHA), and does it participate in the National Institute for Occupational Safety and Health (NIOSH) Proficiency Analytical Testing (PAT) Program?	<input checked="" type="checkbox"/>	NA	NA	2012, expires 04/2012
10.2 Training				
10.2.1 Have all analysts undergone training on the proper usage of the equipment and instrumentation used in the respective areas?	NA	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Refer to Finding No. 1 in the Audit Report.
10.2.2 Have all analysts demonstrated proficiency through the preparation and/or analysis of standards or samples of known values?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
10.2.3 Are training records maintained in analyst-specific files?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
10.3 Internal Audits				
10.3.1 Are internal audits conducted on an annual basis using an appropriate checklist?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
10.3.1.1 Are internal audit reports available for review?	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
10.4 Corrective/Preventive Action:				
10.4.1 Can the laboratory demonstrate the sequence of problem identification, corrective action, and resumption of duties?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
10.5 Quality Records				
10.5.1 Are SOPs available in the applicable areas for all laboratory-specific procedures?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Network (eLink)
10.5.2 Does the laboratory have a Quality Assurance Manual/Plan?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
10.5.3 Does the laboratory compile monthly quality assurance/quality control reports?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
10.6 Environmental Controls/Laboratory Monitoring				
10.6.1 Does the laboratory conduct an environmental monitoring program?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
10.6.2 Is quarterly air monitoring performed in all laboratory areas?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
10.6.2.1 Are the collected samples analyzed by TEM with a target analytical sensitivity of 0.005 structures/cc?	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
10.6.2.2 If LA is detected, are the affected areas thoroughly cleaned and a new set of samples collected and analyzed? <i>Laboratory Modification LB-000085A</i>	NA	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Additional Comments:				