

POOR LEGIBILITY

**ONE OR MORE PAGES IN THIS DOCUMENT ARE DIFFICULT
TO READ DUE TO THE QUALITY OF THE ORIGINAL**

INLAND EMPIRE ENVIRONMENTAL SERVICES
7291 ASHLEY AVENUE
COLTON, CALIFORNIA 92324
(909) 872-0501 FAX (909) 824-1442

G94-0213
103.0096
EGS

SAN GABRIEL VALLEY
15049

**RESULTS OF THE THIRD AND FORTH PHASE OF
A SOIL GAS SURVEY
CONDUCTED AT THE
CROWN CITY PLATING COMPANY
4350 TEMPLE CITY BLVD.
EL MONTE, CALIFORNIA**

PREPARED FOR

**Mr. Lawrence P. Donovan III
CROWN CITY PLATING COMPANY
4350 Temple City Blvd.
El Monte, California 91731**

SUBMITTED TO :

California Regional Water Quality
Control Board - Los Angeles Region
101 Centre Plaza Drive
Monterey Park, California 91754-2156
Attn: Arthur G. Heath

PREPARED BY :

**INLAND EMPIRE ENVIRONMENTAL SERVICES
7291 Ashley Ave.
Colton, Ca. 92324**

May 15, 1994

TABLE OF CONTENTS

	Page
INTRODUCTION -----	1
FIELD PROCEDURES -----	1
RESULTS -----	3
FIGURE 1 - INDEX MAP	1
APPENDIX A - PLOT PLANS	
APPENDIX B - FID DETECTOR CHROMATOGRAMS	
APPENDIX C - PID DETECTOR CHROMATOGRAMS	
APPENDIX D - PRE-SURVEY CALIBRATIONS AND DAILY CHECKS AND QUALITY CONTROL	

INTRODUCTION

We are pleased to present the results of the third and forth phases of a Soil Gas Survey which was conducted for Crown City Plating located at 4350 Temple City Boulevard, El Monte, California (see Figure #1 INDEX MAP). The study commenced upon approval of Mr. Solomon of the California Regional Water Quality Control Board and was conducted in real time on the site.

The survey was carried out by Inland Empire Environmental Services on May 5 and 6, 1994. Vapor samples were obtained from twenty-six (26) points on the property (see APPENDIX A for - Plot Plans).

FIELD PROCEDURES

This soil gas survey collected and analyzed organic vapors of the subsurface in real time. This survey was conducted using an SRI portable gas chromatograph which detected and characterized these vapors to a field sensitivity as low as 1 part per billion (ppb). The SRI gas chromatograph was equipped with three types of detectors. The first was a PHOTO IONIZATION DETECTOR (PID). The second was a FLAME IONIZATION DETECTOR (FID). The third was an ELECTRO-LYTIC CONDUCTIVITY DETECTOR (ELCD) which is more commonly known as a Hall Detector. The PID is sensitive to products such as benzene while the ELCD is extremely sensitive to chlorinated hydrocarbons. Because the primary compounds of interest in this survey were chlorinated hydrocarbons, the results from the ELCD are of greatest concern to us.

The SRI gas chromatograph was calibrated using a three point curve of 3 μ g/L, 10 μ g/L, and 50 μ g/L mixtures of compounds used for EPA method 8010/8020. Daily checks consisted of an injection of 10 μ g/L of the same compounds used for the construction of the calibration curve. Quality checks were made at the beginning and end of each survey day using an 8010/8020 mixture supplied by a different laboratory. The vapor samples were prepared in VOC bottles with new septums which were placed in an aluminum block that is surrounded by salt. This assemblage was heated inside a closed air circulated oven at 100 °C for one hour. A Hamilton gas tight syringe was then used to




Figure 1 INDEX MAP

INLAND EMPIRE ENVIRONMENTAL SERVICES

7291 Ashley Avenue
Colton, California 92324
(909) 872-0501 FAX (909) 824-1442

94 JUN 13 AM 11:23
CALIFORNIA REGION
QUALITY CONTROL BOARD
LOS ANGELES REGION

inject 10cc of this vapor onto the Tenax trap which had been chilled to 0°C.

The capillary columns used during the survey were a 75 meter megabore supplied by J&W Scientific. The primary column is a DB-VRX with a .45 mm inside diameter and is used with the PID/FID detectors. The second column is a DB-624 with a .53 mm inside diameter and is used with the PID/ELCD detectors. The carrier gas was laboratory grade hydrogen. Filtered air was used to pressurize the n-Propanol which was used as the non-conductive background for the Hall detector. The temperature of the column is controlled by the Peak III software which, in this case, is designed to hold the temperature at 40°C for five (5) minutes and then to ramp to 160° at 5°C per minute.

The system used to extract vapor samples from the subsurface consists of a vapor probe which is connected to a pump by a teflon tube. Vapors are drawn from the subsurface through the teflon tubing to the pump. As the vapors are drawn to the pump, they pass through a glass sampling bulb which contains a sampling port with a septum. The pump is allowed to run for 10 seconds and a sample is obtained from the vapor stream using a Hamilton gas tight syringe. Since the pump is downstream from the sampling port, no cross contamination of samples from the pump is possible.

The vacuum pump used to extract the soil vapor samples is an Air Cadet Vacuum/Pressure Station sold by Cole-Palmer Instrument Company. This instrument pumps at a rate of 1050 cubic inches per minute at 15" Hg and 110 volts. The standard purge time for the survey was 10 seconds which calculates to a volume of 2.87 Liters. The total volume of the system is 700 ml or .7 Liters, which includes the glass gas sampling bulb, hydro-purge cylinder, Teflon tubing and sample probe. Therefore, the system is purged approximately four (4) times before a sample of vapors is taken.

The soil probes used were constructed out of 1/2 inch iron pipe. The pipe is driven five feet below the ground surface with an impact hammer. Once the probe has been installed, it is jacked back out approximately 1 inch. This allows the removable tip to be punched out with a metal rod. The probe is then connected with Teflon tubing to the vacuum pump. The seal between the outside probe pipe and the annulus of the bore hole insures that ambient air from the surface is not drawn into the sample vacuum pump.

Where required, bore holes were drilled through the surfacing material with a three-quarter inch diameter impact drill. A manually operated impact hammer was then used to create the seven-sixteenth inch (7/16") diameter holes to a depth of four feet below ground surface. The probe system was then driven into undisturbed soil and a vapor sample was collected using a sampling pump as described above.

The vapor sample at 10 cc was then injected into the chromatographic column. The individual components present in the soil gas were separated as they were drawn through the column by the carrier gas. As each component (or group of components) exited the column and passed through the detectors, an electronic signal proportional to the amount of material was generated which produced a plot of the detector response versus time. These chromatograms of the soil gas samples are included as Appendix A and B at the end of this report.

INLAND EMPIRE ENVIRONMENTAL SERVICES

7291 Ashley Avenue
Colton, California 92324
(909) 872-0501 FAX (909) 824-1442

RESULTS

Crown City Plating requested that additional soil gas points be made at ccsg 60, 61, 62, and 59.

Point 60 was driven to a depth of 10 feet adjacent to the paint storage area and points 61 and 62 were located east of the paint storage and sampled at depths of 5 feet. Results were non-detectable for these three samples.

Soil gas point ccsg 59 was located at the southeastern corner of the interior fence, east of the guard's station, in order to better define the extent of a possible Trichloroethene plume. The results were non-detectable for this sample.

Soil gas survey points ccsg 50, 51, 52, 53, 54, 55, 63, and 64 were all sampled at depths of fifteen feet in and around the bunker fuel oil storage tanks. The results were non-detectable for the compounds under investigation.

All of the survey points were non-detectable with respect to chlorinated solvents and/or petroleum hydrocarbons. All peaks seen on the chromatograms are either surrogate compounds and/or compounds not specified under the EPA method 502.2 standards.



Lawrence P. Pearce
Project Manager
IEES
CPG #3873
REA #2580

INLAND EMPIRE ENVIRONMENTAL SERVICES


7291 Ashley Avenue
Colton, California 92324
(909) 872-0501 FAX (909) 824-1442

**APPENDIX A
PLOT PLANS**

INLAND EMPIRE ENVIRONMENTAL SERVICES
7291 Ashley Avenue
Colton, California 92324
(909) 872-0501 FAX (909) 824-1442

PLOT PLAN


FIGURE 1



CROWN CITY PLATING

FIGURE 2

PLOT PLAN OF NORTHEASTERN SECTION OF PROPERTY



**APPENDIX B
FID DETECTOR CHROMATOGRAMS**


INLAND EMPIRE ENVIRONMENTAL SERVICES
7291 Ashley Avenue
Colton, California 92324
(909) 872-0501 FAX (909) 824-1442

Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
O Tangents=off
Data file : c3sgf38.chr ()
Operator : PEARCE

-12.800mV

128.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
O Tangents=off
Data file : C3SGF39.CHR ()
Operator : PEARCE

-12.000mV

128.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF40.CHR ()
Operator : PEARCE

-12.800mV

126.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF41.CHR ()
Operator : PEARCE

-12.800mV

128.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
O Tangents=off
Data file : C3SGF42.CHR ()
Operator : PEARCE

-12.800mV

128.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF43.CHR ()
Operator : PEARCE

-12.000mV

128.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF44.CHR ()
Operator : PEARCE

-25.600mV

256.000mV

Retention	Area
0.450	85.69
1.950	104269.84 M
4.900	3212.56 M
14.666	380.54 M
15.533	72.86 M
21.216	141.42 M
22.483	352.59 M



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF45.CHR ()
Operator : PEARCE

-256.600mV

256.000mV

Retention Area
0.183 82.18

1.866 42956.00

3.500 690.80


4.133 2064.73

5.733 1556.19

14.450 387.68

21.100 58.22

22.366 152.73




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF46.CHR ()
Operator : PEARCE

-256.600mV

256.000mV

Retention Area



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF47.CHR ()
Operator : PEARCE

-25.600mV

256.000mV

Retention Area
0.216 99.09

1.900 86707.27 M

3.533 15396.56 M

5.850 190.90 M

10.183 228.62 M

10.733 137.70 M


11.383 68.85 M

14.516 614.67 M

15.400 101.67 M

21.133 105.19 M

22.383 277.69 M




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF48.CHR ()
Operator : PEARCE

-25.600mV

256.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF49.CHR ()
Operator : PEARCE

-256.600mV

256.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF49.CHR ()
Operator : PEARCE

-25.600mV

256.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 50.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF50.CHR ()
Operator : PEARCE

-25.600mV

256.000mV

Retention Area



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
O Tangents=off
Data file : c3sgf51.chr ()
Operator : PEARCE

-25.600mV

256.000mV

Retention 0.250 Area 67.39

1.966 104900.42


4.383 45607.81
4.683 16556.74
5.016 6520.40
5.266 1688.39 M
5.766 45.00 M

14.666 319.88 M

15.533 59.59 M

21.266 122.52 M

22.533 385.54 M



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
Tangents=off
Data file : C3SGF52.CHR ()
Operator : PEARCE

-25.600mV

256.000mV

Retention Area
0.183 41.09

1.950 84017.58 M

4.900 6182.30 M

14.683 270.98 M

15.550 44.44 M

18.800 1099.88 M

19.716 151.60 M

20.566 101.32 M


21.300 206.23 M

21.900 41.22 M

22.550 397.68 M

23.683 14.11 M

24.533 16.06 M



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF53.CHR ()
Operator : PEARCE

-256.600mV

256.000mV

Retention
0.200 Area
73.87

1.933 94779.98 M

4.316 9448.41 M


5.783 52.42 M

14.683 258.61

15.566 45.87

21.300 114.17

22.566 327.82



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
O Tangents=off
Data file : C3SGF54.CHR ()
Operator : PEARCE

-25.600mV

256.000mV

Retention Area
0.216 70.64

1.950 92014.08 M

4.283 5268.85 M
4.416 5356.74 M

5.783 67.03 M


14.700 284.06 M

15.566 56.35 M

18.616 998.82 M

21.266 118.38 M

22.550 343.21



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
O Tangents=off
Data file : C3SGF55.CHR ()
Operator : PEARCE

-25.600mV

256.000mV

Retention Area
0.233 23.14

1.983 107203.52 M

5.050 18158.10 M

11.866 574.25 M


14.683 253.89 M

15.566 46.23 M

18.366 74.20 M
18.650 167.98 M

21.283 119.24 M

22.533 281.64 M
22.900 60.85 M




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF56.CHR ()
Operator : PEARCE

-25.600mV

256.000mV

Retention	Area
0.866	22.11
1.933	79376.83 M
4.166	9443.95 M
5.700	106.05 M
8.133	3560.83 M
10.166	16.30 M
11.866	2074.93 M
14.600	354.04 M
15.466	59.35 M
21.200	102.11 M
22.450	303.03 M
23.166	10.61 M




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF57.CHR ()
Operator : PEARCE

-25.600mV

256.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF58.CHR ()
Operator : PEARCE

-25 .. 600mV

256 .. 000mV

Retention Area



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF59.CHR ()
Operator : PEARCE

-256.600mV

256.000mV

Retention Area
0.183 47.55

2.000 98353.61 M

3.866 15871.99 M


5.816 165.88 M

14.650 426.71 M

15.533 79.58 M

21.250 133.47

22.516 446.54



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF60.CHR ()
Operator : PEARCE

-25 .. 600mV

256 .. 000mV

Retention 0.200 Area 23.14

1.950 80909.98 M

4.166 10084.82 M


5.716 65.48 M

14.616 297.75 M

15.516 67.83 M

21.250 103.74

22.533 303.67



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF61.CHR ()
Operator : PEARCE

-254.600mV

254.000mV

Retention
0.200 Area
23.14

1.950 81323.76

3.450 2066.13
3.733 749.29
4.166 13258.45

5.716 688.14
5.900 2181.78

8.150 240.04
9.166 119.20


10.083 22.52
10.583 22.78
10.966 11.06

14.616 289.78

15.516 59.63

21.250 105.38

22.533 318.75



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF62.CHR ()
Operator : PEARCE

-256.600mV

256.000mV

Retention 0.200 Area 23.14

1.950 83070.27

3.500 1938.49
3.733 874.81
4.200 10599.61 M

5.450 169.01 M


14.616 301.20 M

15.516 72.25 M

21.250 108.84 M

22.533 331.43 M

23.533 13.98 M



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGF63.CHR ()
Operator : PEARCE

-25.600mV

256.000mV

Retention Area
0.183 109.61

1.950 101215.43 M

4.200 11977.63 M

5.783 69.80 M

14.683 283.67 M

15.550 56.45 M


21.300 106.42

22.566 950.13

23.416 299.81

23.966 299.01

24.883 69.42




APPENDIX C
PHOTO-IONIZATION DETECTOR CHROMATOGRAMS

INLAND EMPIRE ENVIRONMENTAL SERVICES
7291 Ashley Avenue
Colton, California 92324
(909) 872-0501 FAX (909) 824-1442

Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
O Tangents=off
Data file : C3SGPF38.CHR ()
Operator : PEARCE

-51.200mV

51.2.000mV




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF39.CHR ()
Operator : PEARCE

-512.200mV

512.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
O Tangents=off
Data file : C3SGPF40.CHR ()
Operator : PEARCE

-51.2 200mV

51.2 000mV


Retention
0.033 Area
13.83



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF41.CHR ()
Operator : PEARCE

-51.200mV


512.000mV



Lab name : IEES
 Client : CROWN CITY
 Column : J&W DB-VRX
 Carrier : NITROGEN
 Temp. prog : SOL10.TEM
 Components : c502e.cpt
 Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
 0 Tangents=off
 Data file : C3SGPF42.CHR ()
 Operator : PEARCE

-512.200mV


512.000mV



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF43.CHR ()
Operator : PEARCE

-512.200mV


512.000mV



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF44.CHR ()
Operator : PEARCE

-512.200mV


512.000mV



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF45.CHR ()
Operator : PEARCE

-51.200mV

512.000mV




Lab name : IEES
 Client : CROWN CITY
 Column : J&W DB-VRX
 Carrier : NITROGEN
 Temp. prog : SOL10.TEM
 Components : c502e.cpt
 Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
 O Tangents=off
 Data file : C3SGPF46.CHR ()
 Operator : PEARCE

-51.200mV

512.000mV


Retention	Area
1.383	26.59
1.800	2045.66 M
2.750	753.23 M
3.383	3306.70 M
4.100	118.64 M
5.100	241.30 M
5.783	638.86 M
6.283	245.00 M
7.666	13.48 M
8.266	230.31 M
10.200	43.06 M
11.950	11.54 M
13.866	20.30 M
14.466	1389.14 M
15.333	68.59 M
16.650	42.26 M
18.616	64.27 M
19.416	46.52 M
20.066	97.08 M
20.566	156.07 M
21.100	155.13 M
22.366	9897.43 M
25.600	609.82 M
26.516	143.07 M
27.183	50.17 M
29.183	226.50 M



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c5O2e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3S6PF47.CHR ()
Operator : PEARCE

-51.200mV

512.000mV




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF48.CHR ()
Operator : PEARCE

-512.200mV

512.000mV


Retention Area



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF49.CHR ()
Operator : PEARCE

-512.200mV


512.000mV



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF50.CHR ()
Operator : PEARCE

-51.200mV

512.000mV




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF51.CHR ()
Operator : PEARCE

-51.200mV

512.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF52.CHR ()
Operator : PEARCE

-512.200mV

512.000mV

Retention Area




Lab name : IEES
Client : ST
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF53.CHR ()
Operator : PEARCE

-51.200mV

51.2.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF54.CHR ()
Operator : PEARCE

-512.200mV

512.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF55.CHR ()
Operator : PEARCE

-51.200mV

512.000mV

Retention Area



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF56.CHR ()
Operator : PEARCE

-51.200mV

512.000mV

Retention
0.083 Area
23.26

2.183 1540.58 M
2.833 633.12 M

3.500 4982.83 M

5.216 352.99 M
5.633 607.13 M
5.900 638.12 M
6.416 348.84 M

8.416 248.45 M
9.133 119.87 M
9.900 274.14 M
10.333 409.94 M

14.000 20.41 M
14.583 1447.37 M
15.450 122.86 M

16.750 101.80 M
17.183 11.34 M


18.733 146.81 M
19.516 72.01 M

20.166 116.05 M
20.566 30.13 M

21.200 148.99 M
22.116 94.73 M
22.433 16208.40 M

25.083 254.18 M
25.550 412.43 M
26.416 2245.62 M
27.150 1236.81 M

28.550 6384.46 M




Lab name : IEES
 Client : CROWN CITY
 Column : J&W DB-VRX
 Carrier : NITROGEN
 Temp. prog : SOL10.TEM
 Components : c502e.cpt
 Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
 0 Tangents=off
 Data file : c3sgpf57.chr ()
 Operator : PEARCE

-51.200mV

512.000mV


Retention Area



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF58.CHR ()
Operator : PEARCE

-51.200mV

512.000mV




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF59.CHR ()
Operator : PEARCE

-512.200mV

512.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF60.CHR ()
Operator : PEARCE

-512.200mV

512.000mV

Retention Area




Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF61.CHR ()
Operator : PEARCE

-512.200mV

512.000mV


Retention Area



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Components : c502e.cpt
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
0 Tangents=off
Data file : C3SGPF62.CHR ()
Operator : PEARCE

-51.200mV


51.2.000mV



Lab name : IEES
Client : CROWN CITY
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
O Tangents=off
Data file : C3SGPF63.CHR ()
Operator : PEARCE

-512.200mV

512.000mV



APPENDIX D
PRE-SURVEY CALIBRATIONS AND DAILY QC CHECKS

INLAND EMPIRE ENVIRONMENTAL SERVICES
7291 Ashley Avenue
Colton, California 92324
(909) 872-0501 FAX (909) 824-1442

Compound	For 3 point initial calibration			For 3 point initial calibration			For 3 point initial calibration						
	1st Conc ug/L or Mass (ng) Injected	2nd Conc ug/L or Mass (ng) Injected	3rd Conc ug/L or Mass (ng) Injected	1st	2nd	3rd	1st	2nd	3rd	Average RF	Std Dev.	%RSD	Pass
Dichlorodifluoromethane	10	15	25	7.55	9.1	15.2	0.8	0.6	0.6	0.7	0	0	0 Pass
Chloromethane	10	15	25	7.1	13.7	18	0.7	0.9	0.7	0.8	0	0	0 Pass
Vinyl chloride	3	10	30	5.79	15.8	30	1.9	1.6	1	1.5	0	0	0 Pass
Bromomethane							ERR	ERR	ERR	ERR	ERR	ERR	ERR
Chloroethane	10	15	25	7.2	7.8	9.34	0.7	0.5	0.4	0.5	0	0	0 Pass
Trichlorofluoromethane	3	10	30	1.9			0.6	0	0	0.2	0	0	0 Pass
1,1-Dichloroethane	3	10	30	139	574	1573	46.3	57.4	52.4	52	5	9.6	Pass
Dichloromethane	3	10	30	1.7	6.1	23	0.6	0.6	0.8	0.7	0	0	0 Pass
trans-1,2-Dichloroethene	3	10	30	372	1251	3673	124	125.1	122.4	123.8	1	0.8	Pass
1,1-Dichloroethane	3	10	30	3	8.77	23	1	0.9	0.8	0.9	0	0	0 Pass
cis-1,2-Dichloroethene	3	10	30	1	4	11.4	0.3	0.4	0.4	0.4	0	0	0 Pass
Chloroform	3	10	30	2.58	7.26	15.5	0.9	0.7	0.5	0.7	0	0	0 Pass
1,1,1-Trichloroethane	3	10	30	1.3	6.1	15.5	0.4	0.6	0.5	0.5	0	0	0 Pass
Carbon tetrachloride	3	10	30	0.55	1.24	4	0.2	0.1	0.1	0.1	0	0	0 Pass
1,2-Dichloroethane	3	10	30	1	3.75	11.2	0.3	0.4	0.4	0.4	0	0	0 Pass
Trichloroethene	3	10	30	274	999.4	2426	91.3	99.9	80.9	90.7	9	9	9.9 Pass
1,2-Dichloropropane	3	10	30	5.64	17	44	1.9	1.7	1.5	1.7	0	0	0 Pass
Dibromomethane							ERR	ERR	ERR	ERR	ERR	ERR	ERR
Bromodichloromethane							ERR	ERR	ERR	ERR	ERR	ERR	ERR
cis-1,3-Dichloropropane	3	10	30	1.32	4	11.5	0.4	0.4	0.4	0.4	0	0	0 Pass
trans-1,3-Dichloropropane	3	10	30	1.57	4.36	13	0.5	0.4	0.4	0.4	0	0	0 Pass
1,1,2-Trichloroethane	3	10	30	6.3	12.1	34.16	2.1	1.2	1.1	1.5	0	0	0 Pass
Tetrachloroethene	3	10	30	212	726.6	1521.7	70.7	72.7	50.7	64.7	12	18.5	Pass
Dibromochloromethane							ERR	ERR	ERR	ERR	ERR	ERR	ERR
1,1,2-Tetrachloroethane	3	10	30	2.62	8.59	26.11	0.9	0.9	0.9	0.9	0	0	0 Pass
Bromoform							ERR	ERR	ERR	ERR	ERR	ERR	ERR
1,1,2,2-Tetrachloroethane	3	10	30	7	23.2	62.67	2.3	2.3	2.1	2.2	0	0	0 Pass
Bromobenzene							ERR	ERR	ERR	ERR	ERR	ERR	ERR
Trichloropropane							ERR	ERR	ERR	ERR	ERR	ERR	ERR
Benzene	3	10	30	500	1489.8	3500	166.7	149	116.7	144.1	25	17.3	Pass
Chlorobenzene	3	10	30	556	1470	2823	185.3	147	94.1	142.1	45	31.6	
1,2-Dichlorobenzene							ERR	ERR	ERR	ERR	ERR	ERR	ERR
1,3-Dichlorobenzene							ERR	ERR	ERR	ERR	ERR	ERR	ERR
1,4-Dichlorobenzene							ERR	ERR	ERR	ERR	ERR	ERR	ERR
Ethylbenzene	3	10	30	360.5	1211	3326.9	120.2	121.1	110.9	117.4	5	4.2	Pass

Compound	Daily 1 point Calibration						Q.C. Check Samples Before analysis of samples						Q.C. Check Samples End of Day															
	Conc ug/L or Mass (ng) injected	Area	RF	% Diff.	Pass	True Value Conc ug/L or Mass (ng)						Area	RF	% Diff.	Pass	True Value Conc ug/L or Mass (ng)						Area	RF	% Diff.	Pass			
						Conc ug/L	or	Mass (ng)	Area	RF	% Diff.					Conc ug/L	or	Mass (ng)	Area	RF	% Diff.							
Dichlorodifluromethane	15	9.1	0.6	-14.2	Pass	10		0																ERR	ERR	ERR		
Chloromethane	15	13.7	0.9	12.5	Pass	10		0																ERR	ERR	ERR		
Vinyl chloride	10	15.8	1.6	6.7	Pass	10		17.3		1.7	13.3	Pass																
Bromomethane	10	0	ERR	ERR																				ERR	ERR	ERR		
Chloroethane	15	7.8	0.5	0	Pass	10		0																ERR	ERR	ERR		
Trichlorofluoromethane		7.8	ERR	ERR																				ERR	ERR	ERR		
1,1-Dichloroethene	10	574	57.4	10.4	Pass	10		424		42.4	-18.4	Pass												0	-99.9			
Dichloromethane	10	6.1	0.6	-14.2	Pass																			ERR	ERR	ERR		
trans-1,2-Dichloroethene	10	1251	125.1	1.1	Pass	10		1283		128.3	3.6	Pass												100	-19.1	Pass		
1,1-Dichloroethane	10	8.77	0.9	0	Pass	10		0																ERR	ERR	ERR		
cis-1,2-Dichloroethene	10	4	0.4	0	Pass	10		0																ERR	ERR	ERR		
Chloroform	10	7.26	0.7	0	Pass	10		4.1		0.4	-19.9	Pass												ERR	ERR	ERR		
1,1,1-Trichloroethane	10	6.1	0.6	20		10																		0.4	-19.9	Pass		
Carbon tetrachloride	10	1.24	0.1	0	Pass	10		0																ERR	ERR	ERR		
1,2-Dichloroethane	10	3.75	0.4	0	Pass	10																		ERR	ERR	ERR		
Trichloroethene	10	999.4	99.9	10.1	Pass	10		874		87.4	-3.5	Pass												100.5	10.8	Pass		
1,2-Dichloropropane	10	17	1.7	0	Pass	10		0																ERR	ERR	ERR		
Dibromomethane	10	0	ERR	ERR																				ERR	ERR	ERR		
Bromodichloromethane			ERR	ERR																				ERR	ERR	ERR		
cis-1,3-Dichloropropane	10	4	0.4	0	Pass	10		0																ERR	ERR	ERR		
trans-1,3-Dichloropropane	10	4.36	0.4	0	Pass	10		0																ERR	ERR	ERR		
1,1,2-Trichloroethane	10	12.1	1.2	-19.9		10		0																ERR	ERR	ERR		
Tetrachloroethene	10	726.6	72.7	12.4	Pass	10		780		78	20.6												10	721	72.1	11.4	Pass	
Dibromochloromethane	10	0	ERR	ERR																				ERR	ERR	ERR		
1,1,1,2-Tetrachloroethane	10	8.59	0.9	0	Pass	10		0																ERR	ERR	ERR		
Bromoform	10	0	ERR	ERR																				ERR	ERR	ERR		
1,1,2,2-Tetrachloroethane	10	23.2	2.3	4.5	Pass	10		0																ERR	ERR	ERR		
Bromobenzene	10	0	ERR	ERR																				ERR	ERR	ERR		
Trichloropropane	10	0	ERR	ERR																				ERR	ERR	ERR		
Benzene	10	1489.8	149	3.4	Pass	10		1633		163.3	13.3	Pass												10	1476	147.6	2.4	Pass
Chlorobenzene	10	1470	147	3.4	Pass	10		0																ERR	ERR	ERR		
1,2-Dichlorobenzene			ERR	ERR																				ERR	ERR	ERR		
1,3-Dichlorobenzene			ERR	ERR																				ERR	ERR	ERR		
1,4-Dichlorobenzene			ERR	ERR																				ERR	ERR	ERR		
Ethylbenzene	10	1211	121.1	3.2	Pass	10		1209		120.9	3	Pass												10	1203	120.3	2.5	Pass


Lab name : IEES
Client : CROWN CITY
Description : CHANNEL 3 - FID
Data file : CC3CAL4C.CHR (C:\PEAK3\CC3)
Sample : 30 NG VOLATILES MIX

SC

-1.562mV

15.625mV

Area




Retention	Area
1.866	346203.25 M
7.516	15.50
8.066	40.33 M -
10.316	68.92
12.550	11.43
13.916	13.20 M
14.116	14.80 M
14.550	28.16 M
14.766	18.82 M
15.300	36.61 M
15.950	29.57 M
16.500	12.21 M
18.216	8.83 M
18.416	24.43 M
19.166	30.09 M
19.783	98.91 M
20.866	62.67 M
21.233	17.94 M
21.000	30.55 M
22.400	38.67 M
23.700	52.03 M
24.383	26.80 M
25.050	30.89
25.483	31.88 M
25.683	25.39 M
25.866	51.21 M
26.283	28.91 M
26.650	36.88 M
27.183	23.79 M
27.633	31.86 M
30.016	46.65
30.383	16.69
30.583	26.51 M
30.683	8.88 M
31.550	22.73 M
32.366	6.39
	5.03

347277.43

Lab name : IEES
Client : CROWN CITY
Description : CHANNEL 3 - FID
Data file : CC3CAL5C.CHR (C:\PEAK3\CC3)
Sample : 10 NG VOLATILES MIX

10



Retention	Area
0.516	7.35
1.816	177760.23
4.466	105.58
5.850	8.77 -
7.333	7.26
7.916	6.10 M
8.400	14.02 M
10.050	16.53 M
10.350	12.09 M
13.933	8.87 M
14.433	18.09 M
15.150	18.54 M
15.850	15.50 M
16.400	15.32 M
18.383	12.05 M
19.133	12.53
19.783	43.10
20.866	26.45 M
21.250	8.05 M
22.016	12.81
22.433	16.93
23.400	22.78
23.733	11.18
24.433	13.43
25.083	11.69
25.516	10.45 M
25.716	21.92 M
25.900	16.15 M
26.300	14.56 M
26.683	10.89 M
27.216	15.40 M
27.683	26.56 M
30.083	8.83
30.416	11.53 M
30.733	15.68 M

178343.76

Lab name : IEES
 Client : CROWN CITY
 Column : J&W DB-VRX 75 METERS
 Carrier : HYDROGEN
 Temp. prog : SOL10-CK.TEM
 Integration : Peak sens=95.0 Base sens=30.0 Min area= 1.00 Dilution= 3.00
 0 Tangents=off
 Data file : cc3cal2c.chr ()
 Operator : PEARCE

3

-0..400mV

4.000mV

Retention	Area
0.316	4.80
0.650	15.26
1.050	1.74
1.283	2.52
1.816	337983.13 M

1/01/01 on exponential scale

11 DCP (2)

7.266 2.58 M

8.366 4.82 M

10.266 7.51 M

11.583 1.53 M

13.850 7.50

14.466 1.80

15.250 6.32

15.866 7.41

16.400 1.91

17.533 1.21

18.383 2.62

19.116 3.67

19.600 14.02

20.200 1.22

20.800 7.02

21.200 2.69

21.950 3.15

22.350 5.75

23.366 5.08

23.683 2.62

24.366 3.35

24.666 2.17

25.000 5.08

25.466 2.21

25.833 2.38


26.250 3.44

26.633 3.12

27.166 3.84

27.633 9.94

28.416 2.86



Retention	Area
0.316	4.80
0.650	15.26
1.050	1.74
1.283	2.52
1.616	337983.13
7.266	2.58
8.166	1.30
8.366	4.82
10.200	4.73
10.266	7.51
11.583	1.53
13.650	7.50
14.466	1.80
15.250	6.32
15.866	7.41
16.400	1.91
17.533	1.21
18.183	1.69
18.383	2.62
19.116	3.67
19.600	14.02
20.200	1.22
20.800	7.02
21.200	6.69
21.950	5.75
22.350	5.08
23.366	6.62
23.683	5.35
24.366	1.17
24.666	1.08
25.000	1.23
25.266	1.21
25.466	3.34
25.650	3.38
25.833	3.44
26.250	3.12
26.633	2.84
27.166	2.94
27.633	2.86
28.416	2.05
30.016	0.04
30.400	3.61
30.666	3.68
31.516	3.33
31.716	3.49
32.133	2.59
32.350	6.09
32.700	

338177.35

Labname : TCEs
Column : J&W DB-VRX
Temp. prog : SOL10-CK.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 1.00
0 Tangents=off
Data file : cc3cal4d.CHR ()
Operator : PEARCE

Temperature program:
Init temp Hold Ramp Final temp


Events:
Time Event

30

-25.600mV

256.000mV

Retention	Area
1.800	524.75
3.216	1573.78 M
4.233	2413.40 M
5.566	2654.76 M
7.983	1528.60 M
8.516	3251.21 M
10.300	2426.44 M
12.500	953.58 M
13.816	1713.33 M
14.550	3517.48 M
15.283	43.41 M
15.883	95.79 M
16.450	1521.70 M
17.216	47.63 M
18.383	2823.31 M
19.133	2326.91 M
19.766	4567.38 M
20.650	1845.41 M
20.850	2653.94 M
21.983	1997.10 M
22.350	3027.61 M
23.350	4218.63 M
23.666	2876.77 M
24.366	2960.18 M
25.033	2043.19 M
25.650	5768.68 M
25.833	2566.81 M
26.266	1773.90 M
26.633	2077.70 M
27.183	2181.59 M
27.833	107.82 M



Retention	Area	External	Units
1.800	524.75		N/A
3.216	1573.76	M	N/A
4.233	2413.40	M	N/A
5.566	2654.76	M	N/A
7.983	1528.60	M	N/A
8.516	3251.21	M	N/A
10.300	2426.44	M	N/A
12.500	953.58	M	N/A
13.816	1713.33	M	N/A
14.550	3517.48	M	N/A
15.283	43.41	M	N/A
15.600	11.71	M	N/A
15.883	95.79	M	N/A
16.450	1521.70	M	N/A
17.216	47.63	M	N/A
18.383	2823.31	M	N/A
19.133	2326.91	M	N/A
19.766	4567.38	M	N/A
20.650	1845.41	M	N/A
20.850	2653.94	M	N/A
21.983	1997.10	M	N/A
22.350	3027.61	M	N/A
23.350	4218.63	M	N/A
23.666	2676.77	M	N/A
24.366	2940.18	M	N/A
25.033	2043.19	M	N/A
25.650	5768.68	M	N/A
25.833	2566.81	M	N/A
26.266	1773.90	M	N/A
26.633	2077.70	M	N/A
27.183	2181.59	M	N/A
27.633	97.51	M	N/A
27.833	107.82	M	N/A
30.016	1488.19	M	N/A
30.346	1686.31	M	N/A
30.666	2256.95	M	N/A
31.563	118.66	M	N/A
31.983	299.49	M	N/A
32.350	33.50	M	N/A
32.533	26.75	M	N/A
32.950	19.15	M	N/A

74321.00

0.00


Lab name : IEES
 Client : CROWN CITY
 Column : J&W DB-VRX
 Carrier : NITROGEN
 Temp. prog : SOL10-CK.TEM
 Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 3.00
 0 Tangents=off
 Data file : cc3cal5d.chr ()
 Operator : PEARCE

10

-25..600mV

256.000mV

Retention	Area
1.766	273.63
2.416	313.80 M
3.133	574.07 M
4.100	1254.20 M
5.366	1074.88 M
5.866	26.61 M
7.833	711.03 M
8.366	1494.12 M
9.883	80.35 M
10.166	999.44 M
10.883	27.29 M
12.283	423.91 M
13.633	809.86 M
14.383	1336.40 M
15.133	13.86 M
15.766	37.84 M
16.366	726.64 M
17.133	19.19 M
18.333	1470.50 M
19.100	1211.12 M
19.750	2375.82 M
20.833	2153.83 M
22.000	965.67 M
22.366	1466.94 M
23.400	2086.18 M
23.700	1400.80 M
24.416	1439.57 M
25.066	955.75 M
25.850	1403.94 M
26.300	780.61 M
26.666	1037.30 M
27.200	1043.68 M
27.666	33.58 M
27.883	14.42 M




Retention	Area
1.766	273.63
2.416	313.80
3.133	574.07
4.100	1254.20
5.366	1074.88
5.866	26.61
7.833	711.03
8.366	1494.12
9.883	80.35
10.166	999.44
10.883	27.29
12.283	423.91
13.633	609.86
14.383	1336.40
15.133	13.86
15.766	37.84
16.366	726.64
17.133	19.19
18.333	1470.50
19.100	1211.12
19.750	2375.82
20.833	2153.83
22.000	965.67
22.366	1466.94
23.400	2086.18
23.700	1400.80
24.416	1439.57
25.066	955.75
25.663	2735.86
25.850	1403.94
26.300	780.61
26.666	1037.30
27.200	1043.68
27.666	33.58
27.883	14.42
30.400	955.46
30.716	1381.90
31.366	80.92
32.066	442.34
32.550	247.56

35880.87

Lab name : IEES
Client : CROWN CITY
Temp. prog : SOL10-CK.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 1.00
0 Tangents=off
Data file : cc3cal2d.CHR ()
Operator : PEARCE

Temperature program:
Init temp Hold Ramp Final temp

Events:
Time Event



Retention	Area
1.850	386.94 M
3.466	138.97 M
4.133	372.57 M
5.566	1162.52 M
6.833	56.86 M
7.866	361.71 M
8.383	613.46 M
10.566	274.11 M
12.383	150.82 M
13.150	17.84 M
13.766	801.95 M
14.433	415.15 M
14.783	15.27 M
15.200	31.05 M
15.833	75.08 M
16.383	212.08 M
17.150	47.76 M
17.516	12.97 M
18.316	556.28 M
19.083	360.50 M
19.716	739.85 M
20.783	407.49 M
21.950	290.79 M
22.300	478.96 M
22.900	17.77 M
23.316	677.11 M
23.600	418.07 M
24.333	420.55 M
25.000	279.98 M
25.616	918.18 M
25.800	417.27 M
26.250	257.40 M
26.616	294.90 M
27.166	306.20 M
29.000	2486.01 M

Retention	Area	External	Units
-----------	------	----------	-------

1.750	79.06	M	N/A
1.850	386.94	M	N/A
3.116	160.06	M	N/A
3.466	138.97	M	N/A
4.133	372.57	M	N/A
5.566	1162.52	M	N/A
6.833	56.86	M	N/A
7.866	361.71	M	N/A
8.383	613.46	M	N/A
10.183	461.48	M	N/A
10.566	274.11	M	N/A
11.950	15.15	M	N/A
12.383	150.82	M	N/A
13.150	117.84	M	N/A
13.766	801.95	M	N/A
14.433	415.15	M	N/A
14.783	15.27	M	N/A
15.200	31.05	M	N/A
15.550	24.69	M	N/A
15.833	75.08	M	N/A
16.150	17.49	M	N/A
16.383	212.08	M	N/A
17.150	47.76	M	N/A
17.516	12.97	M	N/A
18.316	556.28	M	N/A
19.063	360.50	M	N/A
19.716	739.85	M	N/A
20.600	226.65	M	N/A
20.783	407.49	M	N/A
21.950	290.79	M	N/A
22.300	478.96	M	N/A
22.900	17.77	M	N/A
23.316	677.11	M	N/A
23.600	418.07	M	N/A
24.333	420.55	M	N/A
25.000	279.98	M	N/A
25.616	918.18	M	N/A
25.800	417.27	M	N/A
26.250	257.40	M	N/A
26.616	294.90	M	N/A
27.166	306.20	M	N/A
29.000	2486.01	M	N/A
30.000	4459.13	M	N/A
30.350	2599.66	M	N/A
30.650	2277.69	M	N/A
31.616	6348.98	M	N/A
32.050	2405.61	M	N/A
32.600	636.05	M	N/A

34586.30

0.00


Lab name : IEES
 Client : CROWN CITY
 Method : DIRECT COLD ON COLUMN
 Column : J&W DB-VRX
 Carrier : NITROGEN
 Temp. prog : SOL10-CK.TEM
 Integration : Peak sens=95.0 Base sens=30.0 Min area= 1.00 Dilution= 1.00
 0 Tangents=off
 Data file : c3qcpch1.chr ()
 Operator : PEARCE

Temperature program:
 Init temp Hold Ramp Final temp

Events:
 Time Event

-25.600mV

256.000mV



Retention	Area
0.333	15.19
0.833	17.37
1.800	276.62
2.466	423.48
3.150	638.20
4.116	1283.17
5.400	1084.90
5.900	20.21
6.583	3.33
6.766	10.60
7.350	9.60
7.866	744.11
8.400	1632.89
9.916	18.27
10.200	874.37
10.916	42.65
11.866	34.94
12.316	423.73
13.050	17.18
13.383	19.79
13.666	786.90
14.433	1395.62
15.166	31.97
15.333	1.35
15.550	10.60
15.800	82.71
16.416	779.77
16.916	1.97
17.183	32.17
17.566	35.75
18.333	1575.72
19.100	1208.89
19.750	2374.02
20.650	633.67
20.833	1330.07
21.700	5.13
22.000	968.73
22.366	1429.57
23.400	2086.18
23.700	1400.80
24.416	1439.57
25.066	955.75
25.500	883.11
25.683	1897.14
25.850	1419.62
26.300	888.55
26.350	513.25
26.666	1037.30
27.200	1343.84
27.666	316.38
27.883	729.68
30.050	5308.56
30.400	3072.88
30.716	4700.76
31.300	3620.69
31.366	906.01
31.666	3128.65
32.066	2668.36
32.266	697.17
32.550	1080.74
32.966	108.37

60883.61

Lab name : IEES
Client : CROWN CITY
Method : DIRECT COLD ON COLUMN
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10-CK.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 1.00 Dilution= 1.00
0 Tangents=off
Data file : c3qcf1.chr ()
Operator : PEARCE


Temperature program:
Init temp Hold Ramp Final temp

Events:
Time Event

-0..800mV

8..000mV

Retention	Area
0.116	3.04
0.516	7.35
0.866	1.12
1.850	17407.33
2.216	86756.47
4.466	199.04
5.450	35.77
5.883	52.44
7.366	6.75
7.950	3.04
8.433	9.71
10.083	5.39
10.383	2.55
12.433	5.74
13.966	3.31
14.466	15.35
15.183	14.41
15.883	13.09
16.433	4.16
18.416	7.88
19.166	11.88
19.816	42.01
20.900	22.12
21.283	4.19
22.050	12.39
22.450	16.19
23.433	21.57
23.766	9.77
24.750	1.02
25.116	11.62
25.550	5.32
25.733	22.17
26.333	12.44
26.716	7.75
27.250	11.35
27.700	21.49
28.350	16.56
28.650	183.09
29.250	85.17




Retention	Area
0.116	3.04
0.516	7.35
0.866	1.12
1.050	17407.33
2.216	86756.47
4.466	199.04
5.450	35.77
5.883	52.44
7.366	6.75
7.950	3.04
8.433	9.71
10.063	5.39
10.363	2.55
12.433	5.74
13.966	3.31
14.466	15.35
15.183	14.41
15.883	13.09
16.433	4.16
18.200	3.52
18.416	7.88
19.166	11.88
19.816	42.01
20.900	22.12
21.283	4.19
22.050	12.39
22.450	16.19
23.433	21.57
23.766	9.77
24.466	12.78
24.750	1.02
25.116	11.62
25.550	5.32
25.733	22.17
26.333	12.44
26.716	7.75
27.250	11.35
27.700	21.49
28.350	16.56
28.650	185.09
28.866	129.66
28.966	90.88
29.250	85.17
29.916	208.76
30.100	13.71
30.450	14.97
30.750	73.54
32.483	9.97
32.950	5.04

105636.86

Lab name : IEES
Client : CROWN CITY
Method : DIRECT COLD ON COLUMN
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10-CK.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 1.00
0 Tangents=off
Data file : c3gcph2.chr ()
Operator : PEARCE

Temperature program:
Init temp Hold Ramp Final temp

Events:




Retention	Area
0.400	12.62
1.383	14.40
1.800	203.72
2.083	25.82
2.466	424.99
3.133	1000.11
3.800	77.19
4.166	1560.45
5.433	1251.70
5.916	40.54
6.650	71.25
6.833	13.47
7.900	696.38
8.433	1476.83
9.366	27.80
9.950	80.22
10.216	1005.74
10.950	23.36
12.350	421.87
13.316	22.37
13.700	775.55
14.450	1425.33
15.866	36.09
16.466	720.88
17.233	67.96
17.466	185.23
17.933	58.06
18.433	1470.03
19.200	1203.55
19.850	2368.70
20.750	790.25
20.933	1367.45
21.816	125.79
22.066	952.83
22.450	1385.16
23.166	70.30
23.466	2072.77
23.750	1399.02
24.483	1435.92
25.133	942.89
25.750	4135.19
26.350	725.68
26.733	1009.02
27.266	1029.84
27.916	432.10
28.116	200.54
29.016	379.39
30.050	6162.73
30.400	5154.27
30.716	8509.63
31.300	6944.08
31.366	1812.02
31.666	6257.30
32.066	5336.73
32.266	1394.34
32.550	2161.48
32.966	216.74

79165.66

Lab name : IEES
Client : CROWN CITY
Method : DIRECT COLD ON COLUMN
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10-CK.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 1.00 Dilution= 1.00
0 Tangents=off
Data file : c3qaf2.chr ()
Operator : PEARCE

Temperature program:
Init temp Hold Ramp Final temp

Events:
Time Event



Retention	Area
1.666	1.15
2.250	188830.50
5.483	8.71
5.883	93.46
7.050	10.06
7.366	6.54
7.950	3.03
8.433	9.73
9.483	19.88
10.083	5.58
10.383	2.34
12.433	5.74
13.733	1.46
13.933	3.50
14.433	15.03
15.150	14.74
15.850	13.68
16.400	4.58
18.183	3.48
18.400	7.97
19.166	11.92
19.800	42.10
20.883	22.20
21.266	4.41
22.050	12.46
22.450	16.36
23.433	21.84
23.766	10.10
24.450	12.91
24.750	1.07
25.116	11.73
25.533	5.26
25.733	22.48
26.333	12.55
26.716	7.93
27.233	11.38
27.700	21.58
28.350	1.45
29.216	3.19
29.600	1.13
29.816	1.36
30.083	8.83
30.416	7.89
30.733	11.87
32.483	9.97
32.950	5.04

189360.17


Lab name : IEES
Client : CROWN CITY
Method : DIRECT COLD ON COLUMN
Column : J&W DB-VRX
Carrier : NITROGEN
Temp. prog : SOL10-CK.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 10.00 Dilution= 1.00
0 Tangents=off
Data file : c3gaph2.CHR ()
Operator : PEARCE

Temperature program:
Init temp Hold Ramp Final temp

Events:
Time Event

-25.600mV

256.000mV Retention Area




Retention	Area
1.800	252.65
2.083	25.82
3.466	426.00
3.150	1050.42
4.116	1551.26
5.400	1248.96
5.866	36.53
6.583	36.87 M
7.866	701.00
8.400	1593.13
9.916	22.48 M
10.183	876.09 M
10.916	44.63 M
11.600	13.59 M
11.850	33.42 M
12.316	457.65 M
13.000	25.48 M
13.400	47.57 M
13.666	774.57 M
14.416	1321.49 M
15.166	10.63 M
15.800	66.48 M
16.400	771.85 M
17.166	55.42 M
17.550	142.68 M
18.366	1791.07 M
19.133	1206.54 M
19.783	2372.47 M
20.683	798.83 M
20.866	1361.19 M
22.000	968.73 M
22.366	1429.57 M
23.400	2086.18 M
23.700	1400.80 M
24.416	1439.57 M
25.066	955.75 M
25.500	883.11 M
25.683	1897.14 M
25.850	1419.62 M
26.300	888.55 M
26.350	513.25 M
26.666	1037.30 M
27.200	1200.93 M
27.666	121.82 M
27.883	52.80 M
28.066	91.67 M
29.016	1593.52 M
30.050	5271.86 M
30.400	2909.11 M
30.716	4553.45 M
31.300	3571.59 M
31.366	906.01
31.666	3128.65
32.066	2668.36
32.266	697.17
32.550	1080.74
32.966	108.37

61998.37

Lab name : IEES
Client : CROWN CITY
Method : DIRECT COLD ON COLUMN
Column : J&W DB-VRX 75 METERS
Carrier : HYDROGEN
Temp. prog : SOL10-CK.TEM
Integration : Peak sens=95.0 Base sens=30.0 Min area= 1.00 Dilution= 1.00
0 Tangents=off
Data file : c3qcf2.chr ()
Operator : PEARCE

Temperature program:
Init temp Hold Ramp Final temp


Events:
Time Event




Retention	Area
0.266	2.01
0.516	2.96
0.983	2.37
1.816	95213.51
2.350	39639.10
2.783	17223.61
4.966	127.42
5.516	41.35
5.900	60.26
7.333	7.26
7.916	3.46
8.183	1.24
8.400	9.62
10.050	6.73
10.350	4.65
12.466	5.52
13.983	3.13
14.483	15.12
15.200	14.24
15.900	12.89
16.450	4.61
17.416	21.66
18.216	3.19
18.433	7.54
19.183	11.64
19.833	41.78
20.916	22.54
21.300	3.43
22.066	12.23
22.466	15.88
23.450	20.79
23.783	9.20
24.483	14.50
25.166	10.56
25.600	3.92
25.800	19.46
26.400	11.87
26.783	8.47
27.300	11.16
27.733	13.51
28.116	6.79
29.266	2.40
30.083	1.49
30.416	7.89
30.733	11.87
32.483	69.81
32.950	11.28

137276.17


Lab name : IEES
Client : CROWN CITY
Description : CHANNEL 3 - FID
Data file : CC3GASIC.CHR (C:\PEAK3\CC3)
Sample : 25 UL CAL GAS STD



Lab name : IEES
Client : CROWN CITY
Description : CHANNEL 4 - PID
Data file : CC3GAS1D.CHR (C:\PEAK3\CC3)
Sample : 25 UL CAL GAS STD




Lab name : IEES
Client : CROWN CITY PLATING
Description : CHANNEL 2 - PID
Data file : CC3GAS1B.CHR (C:\PEAK3\CC3)
Sample : 25 UL CAL GAS STD




Retention	Area
3.116	63.84
3.700	2.80
	66.64

Lab name : IEES
Client : CROWN CITY
Description : CHANNEL 3 - FID
Data file : CC3GAS2C.CHR (C:\PEAK3\CC3)
Sample : 10 UL CAL GAS STD




Lab name : IEES
Client : CROWN CITY
Description : CHANNEL 4 - PID
Data file : CC3GAS2D.CHR (C:\PEAK3\CC3)
Sample : 10 UL CAL GAS STD




Retention	Area
1.800	467.52 M
2.050	115.93 M

583.46

Lab name : IEES
Client : CROWN CITY
Description : CHANNEL 4 - PID
Data file : CC3GAS3D.CHR (C:\PEAK3\CC3)
Sample : 15 UL CAL GAS STD




Lab name : IEES
Client : CROWN CITY
Description : CHANNEL 3 - FID
Data file : CC3GAS3C.CHR (C:\PEAK3\CC3)
Sample : 15 UL GAS CAL STD



Retention	Area
1.683	7.65 M
1.816	15.42 M
2.066	13.36 M
2.183	14.29 M
3.133	6.55 M

57.27

Lab name : IEES
Client : CROWN CITY
Description : CHANNEL 3 - FID
Data file : CC3GAS3C.CHR (C:\PEAK3\CC3)
Sample : 15 UL GAS CAL STD




Retention Area

0.700	1.56
1.050	1.28
1.366	4.76
1.683	9.10
1.816	13.70
2.066	27.65
2.616	3.97
3.133	7.78
3.683	2.73
4.816	3.32
5.000	2.46
5.616	3.16

90.08


Lab name : IEES
Client : CROWN CITY
Description : CHANNEL 3 - FID
Data file : CC3GAS3C.CHR (C:\PEAK3\CC3)
Sample : 15 UL GAS CAL STD



Retention	Area
0.700	1.56
1.050	1.28
1.366	4.76
1.683	9.10
1.816	13.70
1.966	13.36 M
2.183	14.29 M
2.616	3.97
2.133	7.78
3.500	2.46
3.683	2.73
4.816	3.32
5.083	2.17
5.200	2.48
5.400	1.99
5.616	3.16
6.433	1.97

90.08

Lab name : IEES
Client : CROWN CITY PLATING
Description : CHANNEL 2 - PID
Data file : CC3GAS3B.CHR (C:\PEAK3\CC3)
Sample : 15 UL CAL GAS STD



Retention Area

Retention	Area
3.133	59.14
3.700	2.96


62.10

Lab name : IEES
Client : CROWN CITY
Description : CHANNEL 3 - FID
Data file : CC3SURRC.CHR (C:\PEAK3\CC3)
Sample : 5 uL SURROGATE MIX

-100.000mV

1000.000mV

Area
4.08
3.62
5.78
465696.89 M



Retention	Area
0.016	1.11
0.333	4.08
0.600	3.62
0.966	5.78