

checked by TT
11/20/15

MEMORANDUM

TO: Mr. Addison Rice
Anderson, Mulholland and Associates

DATE: November 15, 2015

FROM: R. Infante 

FILE: 1510223C

RE: Data Validation
Air samples
SDG: 1510223C

SUMMARY

Full validation was performed on the data for several gas samples analyzed for methane by ASTM method D-1946-modified. The samples were collected at the Bristol Myer Squib-Building 6 VI facility, Humacao, PR site on October 09-10, 2015 and submitted to Eurofins Air Toxics, Inc. of Folsom, California that analyzed and reported the results under delivery groups (SDG) 1510223C.

The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: Volatile Organic Analysis of Ambient Air in Canisters by Method TO-15, (SOP # HW-31. Revision #4. October, 2006; and the QC criteria of the ASTM method D-1946-modified. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

In general the data is valid as reported and may be used for decision making purposes. The data results are acceptable for use.

SAMPLES

The samples included in the review are listed below

Client Sample ID	Lab. Sample ID	Collected Date	Matrix	Analysis
B30-1101015	1510223C-01A	10/10/2015	Air	Methane
B30-2100915	1510223C-02A	10/09/2015	Air	Methane
B30-3101015	1510223C-03A	10/10/2015	Air	Methane
B30-4100915	1510223C-04A	10/09/2015	Air	Methane
B30-4D100915	1510223C-05A	10/09/2015	Air	Methane
B30-5100915	1510223C-06A	10/09/2015	Air	Methane
B42-1101015	1510223C-07A	10/10/2015	Air	Methane
B42-2101015	1510223C-08A	10/10/2015	Air	Methane
B42-3101015	1510223C-09A	10/10/2015	Air	Methane
B8SSV-2101015	1510223C-11A	10/10/2015	Air	Methane
B8SSV-2D101015	1510223C-12A	10/10/2015	Air	Methane

REVIEW ELEMENTS

Sample data were reviewed for the following parameters, where applicable to the method

- Agreement of analysis conducted with chain of custody (COC) form
- Holding time and sample preservation
- Gas chromatography/mass spectrometry (GC/MS) tunes
- Initial and continuing calibrations
- Method blanks/trip blanks/field blank
- Canister cleaning certification criteria
- Surrogate spike recovery
- Internal standard performance and retention times
- Field duplicate results
- Laboratory control sample/laboratory control sample duplicate (LCS/LCSD) results
- Quantitation limits and sample results

DISCUSSION

Agreement of Analysis Conducted with COC Request

Sample reports corresponded to the analytical request designated on the chain-of-custody form except for the following:

- Sample B8SSV-2100915 was not analyzed.

Holding Times and Sample Preservation

Sample preservation was acceptable.

Samples analyzed within method recommended holding time.

Initial and Continuing Calibrations

Methane by ASTM method D-1946 (modified)

Initial and continuing calibrations meet method specific requirements. Initial calibration retention times meet method specific requirements.

Method Blank/Trip Blank/Field Blank

Target analytes were not detected in laboratory method blanks.

Summa canister met cleaning certification criteria.

No trip/field blank analyzed with this data package.

Laboratory/Field Duplicate Results

Field/laboratory duplicates were analyzed as part of this data set. Target analytes meet the RPD performance criteria of + 25 % for analytes 5 x SQL.

LCS/LCSD Results

Methane

LCS/LCSD (blank spike) were analyzed by the laboratory associated with this data package. Recoveries and RPD within laboratory control limits.

Quantitation Limits and Sample Results

Dilutions were not performed (see worksheet).

Calculations were spot checked.

Certification

The following samples 1510223C-01A; 1510223C-02A; 1510223C-03A; 1510223C-04A; 1510223C-05A; 1510223C-06A; 1510223C-07A; 1510223C-08A; 1510223C-09A; 1510223C-11A; and 1502113B-12A were analyzed following standard procedures accepted by regulatory agencies. The quality control requirements met the methods criteria except in the occasions described in this document.





Client Sample ID: B30-3101015

Lab ID#: 1510223C-03A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	9101507	Date of Collection: 10/10/15 10:42:00 A
Dil. Factor:	2.35	Date of Analysis: 10/15/15 11:47 AM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00024	0.14

Container Type: 1 Liter Summa Canister (100% Certified)





Client Sample ID: B30-2100915

Lab ID#: 1510223C-02A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	9101506	Date of Collection: 10/9/15 3:40:00 PM
Dil. Factor:	2.30	Date of Analysis: 10/15/15 11:22 AM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00023	0.25

Container Type: 1 Liter Summa Canister (100% Certified)





Client Sample ID: B30-1101015

Lab ID#: 1510223C-01A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	9101505	Date of Collection: 10/10/15 10:22:00 A
Dil. Factor:	2.27	Date of Analysis: 10/15/15 10:35 AM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00023	9.3

Container Type: 1 Liter Summa Canister (100% Certified)





Client Sample ID: B30-4100915

Lab ID#: 1510223C-04A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: 9101508
Dil. Factor: 2.24

Date of Collection: 10/9/15 12:31:00 PM
Date of Analysis: 10/15/15 12:13 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00022	0.00022 J

J = Estimated value.

Container Type: 1 Liter Summa Canister (100% Certified)





Client Sample ID: B30-4D100915

Lab ID#: 1510223C-05A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	9101509	Date of Collection: 10/9/15 12:31:00 PM
Dil. Factor:	2.36	Date of Analysis: 10/15/15 12:37 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00024	0.00021 J

J = Estimated value.

Container Type: 1 Liter Summa Canister (100% Certified)





Client Sample ID: B30-5100915

Lab ID#: 1510223C-06A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	9101510	Date of Collection: 10/9/15 1:36:00 PM
Dil. Factor:	2.38	Date of Analysis: 10/15/15 01:08 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00024	0.00020 J

J = Estimated value.

Container Type: 1 Liter Summa Canister (100% Certified)





Client Sample ID: B42-1101015

Lab ID#: 1510223C-07A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	9101511	Date of Collection: 10/10/15 11:31:00 A
Dil. Factor:	2.30	Date of Analysis: 10/15/15 02:07 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00023	0.00011 J

J = Estimated value.

Container Type: 1 Liter Summa Canister (100% Certified)





Client Sample ID: B42-2101015

Lab ID#: 1510223C-08A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	9101512	Date of Collection: 10/10/15 12:10:00 P
Dil. Factor:	2.28	Date of Analysis: 10/15/15 02:31 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00023	0.00020 J

J = Estimated value.

Container Type: 1 Liter Summa Canister (100% Certified)





Client Sample ID: B42-3101015

Lab ID#: 1510223C-09A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	9101513	Date of Collection: 10/10/15 12:32:00 P
Dil. Factor:	2.38	Date of Analysis: 10/15/15 02:58 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00024	0.00020 J

J = Estimated value.

Container Type: 1 Liter Summa Canister (100% Certified)





Client Sample ID: B8SSV-2101015

Lab ID#: 1510223C-11A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	9101514	Date of Collection: 10/10/15 1:15:00 PM
Dil. Factor:	2.43	Date of Analysis: 10/15/15 03:22 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00024	59

Container Type: 1 Liter Summa Canister (100% Certified)





Client Sample ID: B8SSV-2D101015

Lab ID#: 1510223C-12A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	9101515	Date of Collection: 10/10/15 1:15:00 PM
Dil. Factor:	2.36	Date of Analysis: 10/15/15 03:46 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00024	60

Container Type: 1 Liter Summa Canister (100% Certified)





eurofins

Air Toxics

Sample Transportation Notice

Relinquishing signature on this document indicates that sample is being shipped in compliance with all applicable local, State, Federal, national, and international laws, regulations and ordinances of any kind. Air Toxics Limited assumes no liability with respect to the collection, handling or shipping of these samples. Relinquishing signature also indicates agreement to hold harmless, defend, and indemnify Air Toxics Limited against any claim, demand, or action, of any kind, related to the collection, handling, or shipping of samples. D.O.T. Hotline (800) 467-4922

180 BLUE RAVINE ROAD, SUITE B
FOLSOM, CA 95630-4719
(916) 985-1000 FAX (916) 985-1020

Page 1 of 2

Project Manager Terry Taylor
Collected by: (Print and Sign) Terry Taylor
Company AMAI Email ttaylor@amairesearch.com
Address 2700 Westchase Ave City Purchase State TX Zip 75977
Phone _____ Fax _____

Project Info:

P.O. # _____

Project # _____

Project Name BMS VI

Turn Around Time:

☐ Normal☒ Rush3 day
specify

Lab Use Only

Pressurized by:

Date:

Pressurization Gas:

N₂ He

Lab I.D.	Field Sample I.D. (Location)	Can #	Date of Collection	Time of Collection	Analyses Requested	Canister Pressure/Vacuum			
						Initial	Final	Receipt	Final (psi)
<u>01A</u>	<u>B30-1101015</u>	<u>20780</u>	<u>10/10/15</u>	<u>1022</u>	<u>TO-15, CH₄</u>	<u>30</u>	<u>5</u>		
<u>02A</u>	<u>B30-2100915</u>	<u>31767</u>	<u>10/9/15</u>	<u>1540</u>	<u>TO-15, CH₄</u>	<u>30</u>	<u>5</u>		
<u>03A</u>	<u>B30-3101015</u>	<u>36440</u>	<u>10/10/15</u>	<u>1042</u>	<u>TO-15, CH₄</u>	<u>30</u>	<u>5</u>		
<u>04A</u>	<u>B30-4100915</u>	<u>31788</u>	<u>10/9/15</u>	<u>1231</u>	<u>TO-15, CH₄</u>	<u>30</u>	<u>5</u>		
<u>05A</u>	<u>B30-40100915</u>	<u>37314</u>	<u>10/9/15</u>	<u>1231</u>	<u>TO-15, CH₄</u>	<u>30</u>	<u>5</u>		
<u>06A</u>	<u>B30-5100915</u>	<u>N2056</u>	<u>10/9/15</u>	<u>1336</u>	<u>TO-15, CH₄</u>	<u>30</u>	<u>5</u>		
<u>07A</u>	<u>B42-1101015</u>	<u>11430</u>	<u>10/10/15</u>	<u>1131</u>	<u>TO-15, CH₄</u>	<u>30</u>	<u>5</u>		
<u>08A</u>	<u>B42-2101015</u>	<u>34461</u> → <u>36464</u>	<u>10/10/15</u>	<u>1210</u>	<u>TO-15, CH₄</u>	<u>30</u>	<u>5</u>		
<u>09A</u>	<u>B42-3101015</u>	<u>36464</u>	<u>10/10/15</u>	<u>1232</u>	<u>TO-15, CH₄</u>	<u>30</u>	<u>5</u>		

Relinquished by: (signature) Date/Time

[Signature] 10/12/15 12:00

Received by: (signature) Date/Time

MM EATL 10/13/15 0945

Relinquished by: (signature) Date/Time

Received by: (signature) Date/Time

Relinquished by: (signature) Date/Time

Received by: (signature) Date/Time

Notes:

Report results to MDL

Shipped via FedEx by AMAI

Tracking NO. 7747 14839650

Lab Use Only	Shipper Name	Air Bill #	Temp (°C)	Condition	Custody Seals Intact?	Work Order #
	<u>FEDEX</u>		<u>NA</u>	<u>Good</u>	Yes No <u>None</u>	<u>1510223</u>

Sample Transportation Notice

Relinquishing signature on this document indicates that sample is being shipped in compliance with all applicable local, State, Federal, national, and international laws, regulations and ordinances of any kind. Air Toxics Limited assumes no liability with respect to the collection, handling or shipping of these samples. Relinquishing signature also indicates agreement to hold harmless, defend, and indemnify Air Toxics Limited against any claim, demand, or action, of any kind, related to the collection, handling, or shipping of samples. D.O.T. Hotline (800) 467-4922

180 BLUE RAVINE ROAD, SUITE B
FOLSOM, CA 95630-4719
(916) 985-1000 FAX (916) 985-1020

Page 2 of 2

Project Manager Terry Taylor
Collected by: (Print and Sign) Terry Taylor
Company AMAI Email _____
Address _____ City _____ State _____ Zip _____
Phone _____ Fax _____

Project Info:
P.O. # _____
Project # _____
Project Name BMS VI

Turn Around Time:
☐ Normal
☒ Rush
3-day
specify

Lab Use Only
Pressurized by: _____
Date: _____
Pressurization Gas: _____
N₂ He

Lab I.D.	Field Sample I.D. (Location)	Can #	Date of Collection	Time of Collection	Analyses Requested	Canister Pressure/Vacuum			
						Initial	Final	Receipt	Final (psi)
<u>10A</u>	<u>B85SV-2100915</u>	<u>11427</u>	<u>10/9/15</u>	<u>1623</u>	<u>DO NOT ANALYZE</u>	<u>18</u>	<u>3</u>		
<u>11A</u>	<u>B85SV-2101015</u>	<u>12362</u>	<u>10/10/15</u>	<u>1315</u>	<u>TO-15, CH₄, NAP</u>	<u>30</u>	<u>5.5</u>		
<u>12A</u>	<u>B85SV-2101015</u>	<u>36541</u>	<u>10/10/15</u>	<u>1315</u>	<u>TO-15, CH₄, NAP</u>	<u>30</u>	<u>5</u>		

AC
10-12-15

Relinquished by: (signature) [Signature] Date/Time 10/12/15 12:00
Relinquished by: (signature) _____ Date/Time _____
Relinquished by: (signature) _____ Date/Time _____

Received by: (signature) [Signature] Date/Time 10/13/15 0945
Received by: (signature) _____ Date/Time _____
Received by: (signature) _____ Date/Time _____

Notes:
Shipped via FedEx by AMAI
Tracking no. 774714639650
Dox

Lab Use Only	Shipper Name	Air Bill #	Temp (°C)	Condition	Custody Seals Intact?	Work Order #
	<u>FedEx</u>		<u>N/A</u>	<u>Good</u>	Yes No <u>None</u>	<u>1510223</u>

DATA REVIEW WORKSHEETS

Project Number: 1510223C

Date: 10/09-10/2015

REVIEW OF VOLATILE ORGANIC PACKAGE

The following guidelines for evaluating volatile organics were created to delineate required validation actions. This document will assist the reviewer in using professional judgment to make more informed decision and in better serving the needs of the data users. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: QC criteria from ASTM D-1946 method for measuring permanent gases and light hydrocarbons in refinery and other sources samples using gas chromatography (GC) and a thermal conductivity detector (TCD) and/or flame ionization detection (FID). Validating Air Samples. Volatile Organic Analysis of Ambient Air in Canisters by Method TO-15, (SOP # HW-31. Revision #4. October, 2006). The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

The hardcopied (laboratory name) Eurofins data package received has been reviewed and the quality control and performance data summarized. The data review for VOCs included:

Lab. Project/SDG No.: 1510223C
No. of Samples: 11

Sample matrix: Air

Trip blank No.: -

Field blank No.: -

Equipment blank No.: -

Field duplicate No.: B30-4100915/B30-4D100915, B8SSV-2101015/B8SSV-2D101015

☒ Data Completeness

☒ Holding Times

☐ N/A GC/MS Tuning

☐ N/A Internal Standard Performance

☒ Blanks

☐ N/A Surrogate Recoveries

☐ N/A Matrix Spike/Matrix Spike Duplicate

☒ Laboratory Control Spikes

☒ Field Duplicates

☒ Calibrations

☒ Compound Identifications

☒ Compound Quantitation

☒ Quantitation Limits

Overall Comments: Methane_by_ASTM_method_D-1946_(modified)

Definition of Qualifiers:

J- Estimated results

U- Compound not detected

R- Rejected data

UJ- Estimated nondetect

Reviewer: Rafael Infante

Date: 11/15/2015

DATA REVIEW WORKSHEETS

DATA COMPLETENESS

MISSING INFORMATION

DATE LAB. CONTACTED

DATE RECEIVED

[illegible]

DATA REVIEW WORKSHEETS

All criteria were met X
 Criteria were not met
 and/or see below

HOLDING TIMES

The objective of this parameter is to ascertain the validity of the results based on the holding time of the sample from time of collection to the time of analysis.

Complete table for all samples and note the analysis and/or preservation not within criteria

SAMPLE ID	DATE SAMPLED	DATE ANALYZED	pH	ACTION
All samples analyzed within the recommended method holding time				

Criteria

Aqueous samples – 14 days from sample collection for preserved samples (pH ≤ 2, 4°C), no air bubbles.

Aqueous samples – 7 days from sample collection for unpreserved samples, 4°C, no air bubbles.

Soil samples- 7 days from sample collection.

Cooler temperature (Criteria: 4 ± 2 °C): N/A – summa canisters

Actions

If the VOCs vial(s) have air bubbles, estimate positive results (J) and reject nondetects (R).

If the % solids of soil samples is 10-50%, estimate positive results (J) and nondetects (UJ)

If the % solid of soil samples is < 10%, estimate positive results (J) and reject nondetects (R).

If holding times are exceeded but < 14 days beyond criteria, estimate positive results (J) and nondetects (UJ).

If holding times are exceeded but < 28 days beyond criteria, estimate positive results (J) and reject nondetects (R).

If holding times are grossly exceeded (> 28 days beyond criteria), reject all results (R).

If samples were not iced or if the ice were melted (> 10°C), estimate positive results (J) and nondetects (UJ).

DATA REVIEW WORKSHEETS

All criteria were met __N/A__
Criteria were not met see below _____

GC/MS TUNING

The assessment of the tuning results is to determine if the sample instrumentation is within the standard tuning QC limits

__N/A_ The BFB performance results were reviewed and found to be within the specified criteria.

__N/A_ BFB tuning was performed for every 24 hours of sample analysis.

If no, use professional judgment to determine whether the associated data should be accepted, qualified or rejected.

List _____ the _____ samples _____ affected:

If mass calibration is in error, all associated data are rejected.

Note: Samples analyzed using GC with either TCD or FID detection.

DATA REVIEW WORKSHEETS

All criteria were met X
 Criteria were not met
 and/or see below

CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

Date of initial calibration: 05/15/15

Dates of continuing calibration: 10/15/15

Instrument ID numbers: GC-9

Matrix/Level: Air/low

DATE	LAB ID#	FILE	CRITERIA OUT RFs, %RSD, %D, r	COMPOUND	SAMPLES AFFECTED
Initial and continuing calibrations meet method specific requirements. Initial calibration retention times meet method specific requirements.					

Criteria

All RFs must be > 0.05 regardless of method requirements for SPCC.

All %RSD must be $\leq 15\%$ regardless of method requirements for CCC.

All %Ds must be $\leq 30\%$ regardless of method requirements for CCC.

Method TO-15 does not specify criterion for the curve correlation coefficient (r). A limit for r of ≥ 0.995 has therefore been utilized as professional judgment.

Actions

If any compound has an initial RF or a continuing RF of < 0.05 , estimate positive results (J) and reject nondetects (R), regardless of method requirements.

If any compound has a %RSD $> 15\%$, estimate positive results (J) and use professional judgment to qualify nondetects.

If any compound has a %RSD $> 90\%$, estimate positive results (J) and reject nondetects (R).

If any compound has a % D $> 30\%$, estimate positive results (J) and reject nondetects (R).

If any compound has a % D $> 30\%$, estimate positive results (J) and nondetects (UJ).

If any compound has a % D $> 90\%$, estimate positive results (J) and reject nondetects (R).

If any compound has r < 0.995 , estimate positive results and nondetects.

A separate worksheet should be filled for each initial curve

DATA REVIEW WORKSHEETS

All criteria were met X
Criteria were not met
and/or see below _____

V.A. BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including trip, equipment, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamination in the blanks below. High and low levels blanks must be treated separately.

Laboratory blanks

DATE ANALYZED	LAB ID	LEVEL/ MATRIX	COMPOUND	CONCENTRATION UNITS
All_method_blank_meeth_method_specific_criteria				

Field/Equipment/Trip blank

[illegible]

DATA REVIEW WORKSHEETS

All criteria were met X
 Criteria were not met
 and/or see below

V.B. BLANK ANALYSIS RESULTS (Section 3)

Blank Actions

Action Levels (ALs) should be based upon the highest concentration of contaminant determined in any blank. Do not qualify any blank with another blank. The ALs for samples which have been diluted should be corrected for the sample dilution factor and/or % moisture, where applicable. No positive sample results should be reported unless the concentration of the compound in the samples exceeds the ALs:

ALs = 10x the amount of common contaminants (methylene chloride, acetone, 2-butanone, and toluene)

ALs = 5x for any other compounds

Specific actions are as follows:

If the concentration is < sample quantitation limit (SQL) and \leq AL, report the compound as not detected (U) at the SQL.

If the concentration is \geq SQL but \leq AL, report the compound as not detected (U) at the reported concentration.

If the concentration is \geq SQL and $>$ AL, report the concentration unqualified.

Notes:

High and low level blanks must be treated separately

Compounds qualified "U" for blank contamination are still considered "hits" when qualifying for calibration criteria.

CONTAMINATION SOURCE/LEVEL	COMPOUND	CONC/UNITS	AL/UNITS	SQL	AFFECTED SAMPLES

DATA REVIEW WORKSHEETS

All criteria were met N/A
 Criteria were not met
 and/or see below _____

SURROGATE SPIKE RECOVERIES

Laboratory performance of individual samples is established by evaluation of surrogate spike recoveries. All samples are spiked with surrogate compounds prior to sample analysis. The accuracy of the analysis is measured by the surrogate percent recovery. Since the effects of the sample matrix are frequently outside the control of the laboratory and may present relatively unique problems, the validation of data is frequently subjective and demands analytical experience and professional judgment.

List the percent recoveries (%Rs) which do not meet the criteria for surrogate recovery.

Matrix: solid/aqueous

SAMPLE ID	SURROGATE COMPOUND	ACTION
-----------	--------------------	--------

Surrogate standards not required by the method. _____

QC Limits* (Air)

_____ LL to UL _____ to _____ to _____ to _____

- * QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- * If QC limits are not available, use limits of 80 – 120 % for aqueous and 70 – 130 % for solid samples.

Actions:

QUALITY	%R < 10%	%R = 10% - LL	%R > UL
Positive results	J	J	J
Nondetects results	R	UJ	Accept

Surrogate action should be applied:

If one or more surrogate in the VOC fraction is out of specification, but has a recovery of > 10%.

If any one surrogate in a fraction shows < 10 % recovery.

DATA REVIEW WORKSHEETS

All criteria were met _____
 Criteria were not met _____
 and/or see below ___N/A___

VII. A MATRIX SPIKE/MATRIX SPIKE DUPLICATE (MS/MSD)

This data is generated to determine long term precision and accuracy in the analytical method for various matrices. This data alone cannot be used to evaluate the precision and accuracy of individual samples. If any % R in the MS or MSD falls outside the designated range, the reviewer should determine if there are matrix effects, i.e. LCS data are within the QC limits but MS/MSD data are outside QC limit.

1. MS/MSD Recoveries and Precision Criteria

The laboratory should use one MS and a duplicate analysis of an unspiked field sample if target analytes are expected in the sample. If target analytes are not expected, MS/MSD should be analyzed.

List the %Rs, RPD of the compounds which do not meet the criteria.

Sample ID: _____ - _____ Matrix/Level: _____ - _____

MS OR MSD	COMPOUND	% R	RPD	QC LIMITS	ACTION
_MS/MSD_are_not_required_as_part_of_ASTM-method_D-1946;_blank_spike_used_to_assess_ _accuracy_					

- * QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- * If QC limits are not available, use limits of 70 – 130 %.

Actions:

QUALITY	%R < LL	%R > UL
Positive results	J	J
Nondetects results	R	Accept

MS/MSD criteria apply only to the unspiked sample, its dilutions, and the associated MS/MSD samples:

If the % R for the affected compounds were < LL (or 70 %), qualify positive results (J) and nondetects (JJ).

If the % R for the affected compounds were > UL (or 130 %), only qualify positive results (J).

If 25 % or more of all MS/MSD %R were < LL (or 70 %) or if two or more MS/MSD %Rs were < 10%, qualify all positive results (J) and reject nondetects (R).

A separate worksheet should be used for each MS/MSD pair.

DATA REVIEW WORKSHEETS

All criteria were met _____
Criteria were not met _____
and/or see below N/A

VII. B MATRIX SPIKE/MATRIX SPIKE DUPLICATE

MS/MSD – Unspiked Compounds

It should be noted that Method TO-15 does not specify a MS/MSD criteria for the unspiked compounds in the sample. A %RSD of < 50% has therefore been utilized as professional judgment.

If all target analytes were spiked in the MS/MSD, this review element is not applicable.

List the %RSD of the compounds which do not meet the criteria.

Sample ID: _____ Matrix/Level/Unit: _____

COMPOUND	SAMPLE CONC.	MS CONC.	MSD CONC.	% RSD	ACTION
----------	-----------------	----------	-----------	-------	--------

[illegible]

Actions:

- * If the % RSD > 50, qualify the positive result in the unspiked samples as estimated (J).
* If the % RSD is not calculated (NC) due to nondetected value, use professional judgment to qualify the data.

DATA REVIEW WORKSHEETS

All criteria were met X
 Criteria were not met
 and/or see below

VIII. LABORATORY CONTROL SAMPLE (LCS) ANALYSIS

This data is generated to determine accuracy of the analytical method for various matrices.

1. LCS Recoveries Criteria

Where LCS spiked with the same analyte at the same concentrations as the MS/MSD?
 Yes or No. If no make note in data review memo.

List the %R of compounds which do not meet the criteria

LCS ID	COMPOUND	% R	QC LIMIT
____LCS/LCSD_(Blank_spike)_analyzed_in_this_data_package;_recoveries_and_RPD____			
____within_laboratory_control_limits.____			

- * QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- * If QC limits are not available, use limits of 70 – 130 %.

Actions:

QUALITY	%R < LL	%R > UL
Positive results	J	J
Nondetects results	R	Accept

All analytes in the associated sample results are qualified for the following criteria.

If 25 % of the LCS recoveries were < LL (or 70 %), qualify all positive results (j) and reject nondetects (R).

If two or more LCS were below 10 %, qualify all positive results as (J) and reject nondetects (R).

2. Frequency Criteria:

Where LCS analyzed at the required frequency and for each matrix? Yes or No.

If no, the data may be affected. Use professional judgment to determine the severity of the effect and qualify data accordingly. Discuss any actions below and list the samples affected.

DATA REVIEW WORKSHEETS

All criteria were met X
 Criteria were not met
 and/or see below

IX. FIELD/LABORATORY DUPLICATE PRECISION

Sample ID_ B30-4100915/B30-4D100915_____

Matrix: Air

Sample ID_ B8SSV-2101015/B8SSV-2D101015_____

Matrix: Air

Field/laboratory duplicates samples may be taken and analyzed as an indication of overall precision. These analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples.

The project QAPP should be reviewed for project-specific information.

Suggested criteria: RPD \pm 25% for air samples. If both samples and duplicate are <5 SQL, the RPD criteria is doubled.

COMPOUND	SQL	SAMPLE CONC.	DUPLICATE CONC.	RPD	ACTION
RPD for field duplicates within laboratory control limits. RPD for laboratory duplicate (LCS/LCSD) within laboratory control limits.					

Actions:

Qualify as estimated positive results (J) and nondetects (UJ) for the compound that exceeded the above criteria. For organics, only the sample and duplicate will be qualified.

If an RPD cannot be calculated because one or both of the sample results is not detected, the following actions apply:

If one sample result is not detected and the other is greater than 5x the SQL qualify (J/UJ).

If one sample value is not detected and the other is greater than 5x the SQL and the SQLs for the sample and duplicate are significantly different, use professional judgment to determine if qualification is appropriate.

If one sample value is not detected and the other is less than 5x, use professional judgment to determine if qualification is appropriate.

If both sample and duplicate results are not detected, no action is needed.

DATA REVIEW WORKSHEETS

All criteria were met N/A
 Criteria were not met
 and/or see below _____

X. INTERNAL STANDARD PERFORMANCE

The assessment of the internal standard (IS) parameter is used to assist the data reviewer in determining the condition of the analytical instrumentation.

List the internal standard area of samples which do not meet the criteria.

- * Area of +40% or -40% of the IS area in the associated calibration standard.
- * Retention time (RT) within ± 0.06 seconds of the IS area in the associated calibration standard.

DATE	SAMPLE ID	IS OUT	IS AREA	ACCEPTABLE RANGE	ACTION
------	-----------	--------	---------	------------------	--------

Internal standard not required by the method. Samples quantified by external standard
method

Actions:

1. IS actions should be applied to the compound quantitated with the out-of-control ISs

QUALITY	IS AREA < -40%		IS AREA > + 40%
Positive results	J		J
Nondetected results	R		ACCEPT

2. If a IS retention time varies more than 0.330 seconds, the chromatographic profile for that sample must be examined to determine if any false positive or negative exists. For shifts of a large magnitude, the reviewer may consider partial or total rejection of the data for the sample fraction.

DATA REVIEW WORKSHEETS

All criteria were met X
Criteria were not met
and/or see below

XII. SAMPLE QUANTITATION

The sample quantitation evaluation is to verify laboratory quantitation results. In the space below, please show a minimum of one sample calculation:

1510223C-11A

Methane RF = 157692659

$$[] = (3849285645)/(157692659)$$

$$= 24.41 \% \text{ OK}$$

DATA REVIEW WORKSHEETS

All criteria were met X
 Criteria were not met
 and/or see below

XII. QUANTITATION LIMITS

A. Dilution performed

SAMPLE ID	DILUTION FACTOR	REASONS FOR DILUTION
All samples diluted by a factor of less than 2.4		

B. Percent Solids

List samples which have ≤ 50 % solids

Actions:

If the % solids of a soil sample is 10-50%, estimate positive results (J) and nondetects (UJ)

If the % solids of a soil sample is < 10%, estimate positive results (J) and reject nondetects (R)