Check by 14 11/16/15

MEMORANDUM

TO: M

Mr. Addison Rice

Anderson, Mulholland and Associates

DATE: November 11, 2015

FROM: R. Infante

FILE: 1510351C

RE:

Data Validation **Air samples SDG:** 1510351C

SUMMARY

Full validation was performed on the data for several gas samples analyzed for methane by ASTM method D-1946-modified. The samples were collected at the Bristol Myer Squib-Building 6 VI facility, Humacao, PR site on October 18, 2015 and submitted to Eurofins Air Toxics, Inc. of Folson, California that analyzed and reported the results under delivery groups (SDG) 1510351C.

The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: Volatile Organic Analysis of Ambient Air in Canisters by Method TO-15, (SOP # HW-31. Revision #4. October, 2006; and the QC criteria of the ASTM method D-1946-modified. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

In general the data is valid as reported and may be used for decision making purposes. The data results are acceptable for use.

SAMPLES

The samples included in the review are listed below

Client Sample ID	Lab. Sample ID	Collected Date	Matrix	Analysis
B30IA-1 101715	1510351C-01A	10/18/2015	Air	Methane
B30IA-2 101715	1510351C-02A	10/18/2015	Air	Methane
B30IA-3 101715	1510351C-03A	10/18/2015	Air	Methane
B30IA-4 101715	1510351C-04A	10/18/2015	Air	Methane
B30IA-4D 101715	1510351C-05A	10/18/2015	Air	Methane
B30IA-5 101715	1510351C-06A	10/18/2015	Air	Methane
B42IA-1 101715	1510351C-07A	10/18/2015	Air	Methane
B42IA-2 101715	1510351C-08A	10/18/2015	Air	Methane
B42IA-3 101715	1510351C-09A	10/18/2015	Air	Methane
B3042AA 101715	1510351C-10A	10/18/2015	Air	Methane
B8IA-2 101715	1510351C-11A	10/18/2015	Air	Methane
B8IA-2D 101715	1510351C-12A	10/18/2015	Air	Methane
B8AA-1 101715	1510351C-13A	10/18/2015	Air	Methane

REVIEW ELEMENTS

Sample data were reviewed for the following parameters, where applicable to the method

- o Agreement of analysis conducted with chain of custody (COC) form
- o Holding time and sample preservation
- o Gas chromatography/mass spectrometry (GC/MS) tunes
- o Initial and continuing calibrations
- o Method blanks/trip blanks/field blank
- o Canister cleaning certification criteria
- Surrogate spike recovery
- o Internal standard performance and retention times
- o Field duplicate results
- o Laboratory control sample/laboratory control sample duplicate (LCS/LCSD) results
- o Quantitation limits and sample results

DISCUSSION

Agreement of Analysis Conducted with COC Request

Sample reports corresponded to the analytical request designated on the chain-of-custody form except for the following:

• Sample B30IA-1 101715F was not analyzed.

Holding Times and Sample Preservation

Sample preservation was acceptable.

Samples analyzed within method recommended holding time.

Initial and Continuing Calibrations

Methane by ASTM method D-1946 (modified)

Initial and continuing calibrations meet method specific requirements. Initial calibration retention times meet method specific requirements.

Method Blank/Trip Blank/Field Blank

Target analytes were not detected in laboratory method blanks.

Summa canister met cleaning certification criteria.

No trip/field blank analyzed with this data package.

Laboratory/Field Duplicate Results

Field/laboratory duplicates were analyzed as part of this data set. Target analytes meet the RPD performance criteria of +25 % for analytes $5 \times SQL$.

LCS/LCSD Results

Methane

LCS/LCSD (blank spike) were analyzed by the laboratory associated with this data package. Recoveries and RPD within laboratory control limits.

Quantitation Limits and Sample Results

Dilutions were not performed (see worksheet).

Calculations were spot checked.

Certification

The following samples 1510351C-01A; 1510351C-02A; 1510351C-03A; 1510351C-04A; 1510351C-05A; 1510351C-06A; 1510351C-07A; 1510351C-08A; 1510351C-09A; 1510351C-10A; 1510351C-11A; 1510351C-12A; and 1502113B-13A were analyzed following standard procedures accepted by regulatory agencies. The quality control requirements met the methods criteria except in the occasions described in this document.

Rafael Infante

Chemist License 1888



Client Sample ID: B30IA-1 101715 Lab ID#: 1510351C-01A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

			-	
File Name:	9102205 Date of Colle		ection: 10/18/15 11:00:00 A	
Dil. Factor:	1.66	Date of Analysis: 10/22/15 02:18 PM		
		Rpt. Limit	Amount	
Compound		(%)	(%)	
Methane		0.00017	0.00023	





Client Sample ID: B30IA-2 101715

Lab ID#: 1510351C-02A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102206 1.67		ction: 10/18/15 11:26:00 A sis: 10/22/15 03:16 PM
		Rpt. Limit	Amount
Compound		(%)	(%)
Methane		0.00017	0.00032





Client Sample ID: B30IA-3 101715

Lab ID#: 1510351C-03A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102207 1.72	Date of Collection: 10/18/15 11 Date of Analysis: 10/22/15 03:3	
		Rpt. Limit	Amount
Compound		(%)	(%)
Methane		0.00017	0.00029





Client Sample ID: B30IA-4 101715

Lab ID#: 1510351C-04A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102208 1.60		tion: 10/18/15 11:38:00 A sis: 10/22/15 04:16 PM
		Rpt. Limit	Amount
Compound		(%)	(%)
Methane		0.00016	0.00028





Client Sample ID: B30IA-4D 101715

Lab ID#: 1510351C-05A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102209 1.51		etion: 10/18/15 11:38:00 A sis: 10/22/15 04:45 PM
Compound		Rpt. Limit	Amount (%)
Methane		0.00015	0.00028





Client Sample ID: B30IA-5 101715 Lab ID#: 1510351C-06A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102210 1.69		tion: 10/18/15 11:32:00 A sis: 10/22/15 05:08 PM
		Rpt. Limit	Amount
Compound		(%)	(%)
Methane		0.00017	0.00027





Client Sample ID: B42IA-1 101715 Lab ID#: 1510351C-07A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102211 1.68		ction: 10/18/15 12:38:00 P sis: 10/22/15 06:15 PM
Compound		Rpt. Limit (%)	Amount (%)
Methane		0.00017	0.00020





Client Sample ID: B42IA-2 101715

Lab ID#: 1510351C-08A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102212 1.57		tion: 10/18/15 7:54:00 AM sis: 10/22/15 06:39 PM
Compound		Rpt. Limit (%)	Amount (%)
Methane		0.00016	0.00020





Client Sample ID: B42IA-3 101715

Lab ID#: 1510351C-09A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102213 1.46		tion: 10/18/15 7:52:00 AM sis: 10/22/15 07:19 PM
		Rpt. Limit	Amount
Compound		(%)	(%)
Methane		0.00015	0.00020





Client Sample ID: B3042AA Lab ID#: 1510351C-10A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102214 1.88		tion: 10/18/15 1:45:00 PM sis: 10/22/15 07:49 PM
		Rpt. Limit	Amount
Compound		(%)	(%)
Methane		0.00019	0.00020





Client Sample ID: B8IA-2 101715

Lab ID#: 1510351C-11A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102215 1.57		ction: 10/18/15 11:45:00 A sis: 10/22/15 09:04 PM
		Rpt. Limit	Amount
Compound		(%)	(%)
Methane		0.00016	0.00021





Client Sample ID: B8IA-2D 101715

Lab ID#: 1510351C-12A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102216 1.77	Date of Collection: 10/18/15 11 Date of Analysis: 10/22/16 09:	
	-	Rpt. Limit	Amount
Compound		(%)	(%)
Methane		0.00018	0.00022





Client Sample ID: B8AA-1 101715

Lab ID#: 1510351C-13A

NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: Dil. Factor:	9102217 1.58		ction: 10/18/15 11:45:00 A ysis: 10/22/15 09:51 PM
		Rpt. Limit	Amount
Compound		(%)	(%)
Methane		0.00016	0.00020





Sample Transportation Notice

Relinquishing signature on this document indicates that sample is being shipped in compliance with 180 BLUE RAVINE ROAD, SUITE B all applicable local, State, Federal, national, and international laws, regulations and ordinances of any kind. Air Toxics Limited assumes no liability with respect to the collection, handling or shipping of these samples. Relinquishing signature also indicates agreement to hold harmless, defend, and indemnify Air Toxics Limited against any claim, demand, or action, of any kind, related to the

FOLSOM, CA 95630-4719 (916) 985-1000 FAX (916) 985-1020

collection, handling, or shipping of samples. D.O.T. Hotline (800) 467-4922 Project Manager Terry Taylor Turn Around Lab Use Only Project Info: Time: Pressurized by: □ Normal Company___ Date: Email Address 2700 West chester City Purchase State NY Zip 1057 X Rush Project # Pressurization Gas: 3-Day 914-251-0400 Fax BMS VI Phone Project Name N₂ He specify Date Time Canister Pressure/Vacuum Lab I.D. Field Sample I.D. (Location) Can # of Collection of Collection **Analyses Requested** Initial Final Receipt 1 101715 1100 34753 10-18-15 28 6.5 OUA B301A - 2 101715 6L 1270 1126 10-18-15 29 OSA 1159 30 27 1138 05 29 1138 dol 1132 MG 6 080 30 101715 0752 30 3 70-15 8.5 Date/Time Received by: (signature) Date/Time Notes: 10-19-15 12:00 Report results to MDL 1035 Relinquished by: (signature) Date/Time Received by: (signature) Date/Time Shipped via Fed Ex by AMAI Relinquished by: (slonature) Date/Time Received by: (signature) Date/Time Shipper Name Air Bill # Temp (°C) Condition Custody Seals Intagt? Lab Work Order # Use 1/4 heen Yes No None 1510351 Only

🗱 eurofins

Sample Transportation Notice

Relinquishing signature on this document indicates that sample is being shipped in compliance with 180 BLUE RAVINE ROAD, SUITE B all applicable local, State, Federal, national, and international laws, regulations and ordinances of any kind. Air Toxics Limited assumes no liability with respect to the collection, handling or shipping of these samples. Relinquishing signature also indicates agreement to hold harmless, detend, and indemnity Air Toxics Limited against any claim, demand, or action, of any kind, related to the collection, handling, or shipping of samples. D.O.T. Hotline (800) 487-4922

FOLSOM, CA 95630-4719 (916) 985-1000 FAX (916) 985-1020

Page 2 of 2

Company AMAI Email Project # Project # Project Name BI Address 2700 Westenester City Purchase State NY Zip 10577 Phone 914-251-0400 Fax Project Name BI Lab I.D. Fleld Sample I.D. (Location) Can # of Collection of Collection	Analyses Request To-15, CH4, Naphthal To-15, CH4, Naphthal To-15, CH4, Naphthal	halene 30		urization N₂ H ssure/Vac Receipt	е
Address 2700 Westenester City Purchase State NY Zip 10577 Phone 914-251-0400 Fax Project Name 81 Lab I.D. Fleid Sample I.D. (Location) Can # of Collection of Collection [1A 881A-2101715 GL1334 10-18-15 1145 [1A 881A-2D 101715 31226 10-18-15 1145 [13A 884A-101715 14881 10-18-15 1145	Analyses Request To-15, CH, Naph T0-15, CH, Naphthal	3- Day specify Canisted Initial	ster Pres	N ₂ H	e
Lab I.D. Fleld Sample I.D. (Location) Can # of Collection of Collection I/A B8 IA - 2 10 17 15 GL 1334 10-18-15 1145 IVA B8 IA - 2 D 10 17 15 31 22 G 10-18-15 1145 IVSA B8 AA - 10 17 15 1488 1 10-18-15 1145	TO-15, CH, Naphthal	halene 30	Final		
11A B81A-2101715 GL1334 10-18-15 1145 51A B81A-2D 101715 31226 10-18-15 1145 15A B8 AA-101715 14881 10-18-15 1145	TO-15, CH, Naphthal	Halene 30		Receipt	Final (psi)
12A B81A-2D 101715 31226 10-18-15 1145 13A B8 AA-101715 14881 10-18-15 1145	TO-15, CH4, Naphthal		4.5	Material	1 10
13A B8 AA - 101715 14881 10-18-15 1145	TO-15, CH4, Naphthal				45.
	TO-15, C.H. Nashtha		7		
		leve 30	4		
HA B301A-1 101715 F 5751 10-18-15 0806	Do Not Analyze		0		
Paralis Tables					
			,		310
pat 15					
10-19-15					
后教皇帝皇皇 第58章				-4.5	17.5
Received by: (signature) Date/Time 10-19-15 12:00 15-16 15-	Notes: Report N Shipped Vi Tracking	esulfs to l ia Fed Ex No.: 774	UDL by A 7674	MAI 18 238	7
Lab Shipper Name Air Bill # Temp (°C) Condition	and the same of the same Colorest	als Intact?	Work C	Order #	
Only Oth	Yes No	None	15/03	51	

	Project Number:1510351C
8	Date:10/18/2015
REVIEW OF VOLATILE ORGATINE following guidelines for evaluating volatile organics was actions. This document will assist the reviewer in using predecision and in better serving the needs of the data users. The JSEPA data validation guidance documents in the following D-1946 method for measuring permanent gases and light samples using gas chromatography (GC) and a thermal conducted too (FID). Validating Air Samples. Volatile Organic An TO-15, (SOP # HW-31. Revision #4. October, 2006). The Quidence documents are from the primary guidance documents. The hardcopied (laboratory name) _Eurofins	ANIC PACKAGE vere created to delineate required validation rofessional judgment to make more informed the sample results were assessed according to order of precedence: QC criteria from ASTM hydrocarbons in refinery and other sources ductivity detector (TCD) and/or flame ionization halysis of Ambient Air in Canisters by Method C criteria and data validation actions listed or cument, unless otherwise noted. data package received has beer
_ab. Project/SDG No.:1510351C No. of Samples:13	Sample matrix:Air
Frip blank No.: Field blank No.: Equipment blank No.: Field duplicate No.: _B30IA-4_101715/B30IA-4D_101715; _B	
X Data CompletenessX Holding TimesN/A_ GC/MS TuningN/A_ Internal Standard PerformanceX BlanksN/A_ Surrogate RecoveriesN/A_ Matrix Spike/Matrix Spike Duplicate Overall Comments:_Methane_by_ASTM_method_D-194	X Laboratory Control SpikesX Field DuplicatesX CalibrationsX Compound IdentificationsX Compound QuantitationX Quantitation Limits
Definition of Qualifiers: J- Estimated results J- Compound not detected R- Rejected data JJ- Estimated nondetect	
Reviewer: Reviewer: Reviewer: 11/11/2019	

DATA COMPLETENESS

MISSING INFORMATION	DATE LAB. CONTACTED	DATE RECEIVED

······································		
		<u> </u>
		·
		·
· · · · · · · · · · · · · · · · · · ·		

·		

All criteria were met _	X_
Criteria were not met	
and/or see below	

HOLDING TIMES

The objective of this parameter is to ascertain the validity of the results based on the holding time of the sample from time of collection to the time of analysis.

Complete table for all samples and note the analysis and/or preservation not within criteria

SAMPLE ID	DATE SAMPLED	DATE ANALYZED	pН	ACTION
	All samples analyzed w	! rithin the recommended	l method	holding time
	-		_	
			+	

Criteria

Aqueous samples – 14 days from sample collection for preserved samples (pH \leq 2, 4°C), no air bubbles.

Aqueous samples – 7 days from sample collection for unpreserved samples, 4°C, no air bubbles. Soil samples- 7 days from sample collection.

Cooler temperature (Criteria: 4 ± 2 °C): N/A – summa canisters

Actions

If the VOCs vial(s) have air bubbles, estimate positive results (J) and reject nondetects (R). If the % solids of soil samples is 10-50%, estimates positive results (J) and nondetects (UJ) If the % solid of soil samples is < 10%, estimate positive results (J) and reject nondetects (R). If holding times are exceeded but < 14 days beyond criteria, estimate positive results (J) and nondetects (UJ).

If holding times are exceeded but < 28 days beyond criteria, estimate positive results (J) and reject nondetects (R).

If holding times are grossly exceeded (> 28 days beyond criteria), reject all results (R).

If samples were not iced or if the ice were melted (> 10°C), estimate positive results (J) and nondetects (UJ).

		Cr	ilena were not met see below
GC/MS TUNING			
The assessment of standard tuning Q	•	determine if the sample instru	umentation is within the
N/A_ The BFB	performance results were	reviewed and found to be within	the specified criteria.
N/A_ BFB tunin	g was performed for every	24 hours of sample analysis.	
If no, use profess qualified or rejecte		ine whether the associated da	ta should be accepted,
List	the	samples	affected:
If mass calibration	is in error, all associated of	data are rejected.	•

Note: Samples analyzed using GC with either TCD or FID detection.

All	crite	ria v	were	met	_X	_
Crit	eria	we	re no	t me	et	
and	Vor :	see	belo	W		

CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

				Date of initial calibration:	_05/15/15
				Dates of continuing calibration	on:_10/22/15
				Instrument ID numbers:	GC-9
				Matrix/Level:	Air/low
DATE	LAB	FILE	CRITERIA OUT	COMPOUND	SAMPLES
	ID#		RFs, %RSD, %D, r		AFFECTED
•					
Initial and	continui	ng calib	rations meet method	specific requirements. Initia	calibration retention
times meet	method	specific	requirements.	•	
*					

Criteria

All RFs must be > 0.05 regardless of method requirements for SPCC.

All %RSD must be \leq 15 % regardless of method requirements for CCC.

All %Ds must be ≤ 30% regardless of method requirements for CCC.

Method TO-15 does not specify criterion for the curve correlation coefficient (r). A limit for r of \geq 0.995 has therefore been utilized as professional judgment.

Actions

If any compound has an initial RF or a continuing RF of < 0.05, estimate positive results (J) and reject nondetects (R), regardless of method requirements.

If any compound has a %RSD > 15%, estimate positive results (J) and use professional judgment to qualify nondetects.

If any compound has a %RSD > 90%, estimate positive results (J) and reject nondetects (R).

If any compound has a % D > 30%, estimate positive results (J) and reject nondetects (R).

If any compound has a % D > 30%, estimate positive results (J) and nondetects (UJ).

If any compound has a % D > 90%, estimate positive results (J) and reject nondetects (R).

If any compound has r < 0.995, estimate positive results and nondetects.

A separate worksheet should be filled for each initial curve

All criteria were met _	X_
Criteria were not met	
and/or see below	-21

V A. BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including trip, equipment, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamination in the blanks below. High and low levels blanks must be treated separately.

Laboratory blanks

DATE ANALYZED	LAB ID	LEVEL/ MATRIX	COMPOUND	CONCENTRATION UNITS
All_method				
Field/Equipment				
DATE ANALYZED	LAB ID	LEVEL/ MATRIX	COMPOUND	CONCENTRATION UNITS
_No_field/trip/eq	uipment_blank	s_analyzed_wi	th_this_data_package	

All criteria were metX
Criteria were not met
and/or see below

VB. BLANK ANALYSIS RESULTS (Section 3)

Blank Actions

Action Levels (ALs) should be based upon the highest concentration of contaminant determined in any blank. Do not qualify any blank with another blank. The ALs for samples which have been diluted should be corrected for the sample dilution factor and/or % moisture, where applicable. No positive sample results should be reported unless the concentration of the compound in the samples exceeds the ALs:

ALs = 10x the amount of common contaminants (methylene chloride, acetone, 2-butanone, and toluene)

ALs = 5x for any other compounds

Specific actions are as follows:

If the concentration is < sample quantitation limit (SQL) and \le AL, report the compound as not detected (U) at the SQL.

If the concentration is \geq SQL but \leq AL, report the compound as not detected (U) at the reported concentration.

If the concentration is \geq SQL and > AL, report the concentration unqualified.

Notes:

High and low level blanks must be treated separately

Compounds qualified "U" for blank contamination are still considered "hits" when qualifying for calibration criteria.

CONTAMINATION SOURCE/LEVEL	COMPOUND	CONC/UNITS	AL/UNITS	SQL	AFFECTED SAMPLES

All criteria were metN/A
Criteria were not met
and/or see below

SURROGATE SPIKE RECOVERIES

Laboratory performance of individual samples is established by evaluation of surrogate spike recoveries. All samples are spiked with surrogate compounds prior to sample analysis. The accuracy of the analysis is measured by the surrogate percent recovery. Since the effects of the sample matrix are frequently outside the control of the laboratory and may present relatively unique problems, the validation of data is frequently subjective and demands analytical experience and professional judgment.

List the percent recoveries (%Rs) which do not meet the criteria for surrogate recovery.

Matrix: solid/aqueous

Sa	M	PL	E.		D
----	---	----	----	--	---

SURROGATE COMPOUND

ACTION

38 -5- U-0010101	. 827	073			
Limits* (Air)					
LL_to_UL	to_	to	to	to	

- * QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- * If QC limits are not available, use limits of 80 120 % for aqueous and 70 130 % for solid samples.

Actions:

QUALITY	%R < 10%	%R = 10% - LL	%R > UL
Positive results	J	J	J
Nondetects results	R	UJ	Accept

Surrogate action should be applied:

If one or more surrogate in the VOC fraction is out of specification, but has a recovery of > 10%.

If any one surrogate in a fraction shows < 10 % recovery.

All criteria were me	
Criteria were not m	et
and/or see below _	_N/A

VII. A MATRIX SPIKE/MATRIX SPIKE DUPLICATE (MS/MSD)

This data is generated to determine long term precision and accuracy in the analytical method for various matrices. This data alone cannot be used to evaluate the precision and accuracy of individual samples. If any % R in the MS or MSD falls outside the designated range, the reviewer should determine if there are matrix effects, i.e. LCS data are within the QC limits but MS/MSD data are outside QC limit.

MS/MSD Recoveries and Precision Criteria

The laboratory should use one MS and a duplicate analysis of an unspiked field sample if target analytes are expected in the sample. If target analytes are not expected, MS/MSD should be analyzed.

List the %Rs, RPD of the compounds which do not meet the criteria.

Sample ID:	Sample ID:		Matrix/Level:		
MS OR MSD	COMPOUND	% R	RPD	QC LIMITS	ACTION
	not_required_as_part				k_spike_used_to_assess_

- * QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- * If QC limits are not available, use limits of 70 130 %.

Actions:

QUALITY	%R < LL	%R > UL
Positive results	J	J
Nondetects results	R	Accept

MS/MSD criteria apply only to the unspiked sample, its dilutions, and the associated MS/MSD samples:

If the % R for the affected compounds were < LL (or 70 %), qualify positive results (J) and nondetects (UJ).

If the % R for the affected compounds were > UL (or 130 %), only qualify positive results (J).

If 25 % or more of all MS/MSD %R were < LL (or 70 %) or if two or more MS/MSD %Rs were < 10%, qualify all positive results (J) and reject nondetects (R).

A separate worksheet should be used for each MS/MSD pair.

All criteria were met _____ Criteria were not met and/or see below __N/A__

VII. B MATRIX SPIKE/MATRIX SPIKE DUPLICATE

MS/MSD - Unspiked Compounds

It should be noted that Method TO-15 does not specify a MS/MSD criteria for the unspiked compounds in the sample. A %RSD of < 50% has therefore been utilized as professional judgment.

If all target analytes were spiked in the MS/MSD, this review element is not applicable.

List the %RSD of the compounds which do not meet the criteria.

Sample ID:			Matrix/Level/Unit:		
COMPOUND	SAMPLE CONC.	MS CONC.	MSD CONC.	% RSD	ACTION
				- 12 + 13 <u>- 2</u>	
					·-

Actions:

^{*} If the % RSD > 50, qualify the positive result in the unspiked samples as estimated (J).

^{*} If the % RSD is not calculated (NC) due to nondetected value, use professional judgment to qualify the data.

All criteria were met _	Х_	
Criteria were not met		
and/or see below		

VIII. LABORATORY CONTROL SAMPLE (LCS) ANALYSIS

This data is generated to determine accuracy of the analytical method for various matrices.

LCS Recoveries Criteria

Where LCS spiked with the same analyte at the same concentrations as the MS/MSD? Yes or No. If no make note in data review memo.

List the %R of compounds which do not meet the criteria

LCS ID COMPOUND % R QC LIMIT

D_(Blank_spike)_analyzed_in_this_data_package;_recoveries_and_RPD_____
poratory_control_limits.

10		
	CAR X	

- * QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- * If QC limits are not available, use limits of 70 130 %.

Actions:

QUALITY	%R < LL	%R > UL
Positive results	J	J
Nondetects results	R	Accept

All analytes in the associated sample results are qualified for the following criteria.

If 25 % of the LCS recoveries were < LL (or 70 %), qualify all positive results (j) and reject nondetects (R).

If two or more LCS were below 10 %, qualify all positive results as (J) and reject nondetects (R).

2. Frequency Criteria:

Where LCS analyzed at the required frequency and for each matrix? <u>Yes</u> or No. If no, the data may be affected. Use professional judgment to determine the severity of the effect and qualify data accordingly. Discuss any actions below and list the samples affected.

		All criteria were metX Criteria were not met and/or see below
IX.	FIELD/LABORATORY DUPLICATE PRECISION	
	Sample ID_B30IA-4_101715/B30IA-4D_101715 Sample ID_B8IA-2_101715/B8IA-2D_101715	Matrix:Air Matrix:Air

Field/laboratory duplicates samples may be taken and analyzed as an indication of overall precision. These analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples.

The project QAPP should be reviewed for project-specific information. Suggested criteria: RPD \pm 25% for air samples. If both samples and duplicate are <5 SQL, the RPD criteria is doubled.

COMPOUND	SQL	SAMPLE CONC.	DUPLICATE CONC.	RPD	ACTION
RPD for field duplic	cates within la		atrol limits. RPD		ratory duplicate (LCS/LCSD)

Actions:

Qualify as estimated positive results (J) and nondetects (UJ) for the compound that exceeded the above criteria. For organics, only the sample and duplicate will be qualified.

If an RPD cannot be calculated because one or both of the sample results is not detected, the following actions apply:

If one sample result is not detected and the other is greater than 5x the SQL qualify (J/UJ).

If one sample value is not detected and the other is greater than 5x the SQL and the SQLs for the sample and duplicate are significantly different, use professional judgment to determine if qualification is appropriate.

If one sample value is not detected and the other is less than 5x, use professional judgment to determine if qualification is appropriate.

If both sample and duplicate results are not detected, no action is needed.

All criteria were mel _	N/A
Criteria were not met	
and/or see below	

X. INTERNAL STANDARD PERFORMANCE

The assessment of the internal standard (IS) parameter is used to assist the data reviewer in determining the condition of the analytical instrumentation.

List the internal standard area of samples which do not meet the criteria.

- * Area of +40% or -40% of the IS area in the associated calibration standard.
- * Retention time (RT) within \pm 0.06 seconds of the IS area in the associated calibration standard.

DATE	SAMPLE ID	IS OUT	IS AREA	ACCEPTABLE A RANGE	ACTION
	tandard_not_required			intified_by_external_s	standard
Actions:					

1. IS actions should be applied to the compound quantitated with the out-of-control ISs

QUALITY	IS AREA < -40%	IS AREA > + 40%
Positive results	J	J
Nondetected results	R	ACCEPT

2. If a IS retention time varies more than 0.330 seconds, the chromatographic profile for that sample must be examined to determine if any false positive or negative exists. For shifts of a large magnitude, the reviewer may consider partial or total rejection of the data for the sample fraction.

All criteria were metX	
Criteria were not met	
and/or see below	

XII. SAMPLE QUANTITATION

The sample quantitation evaluation is to verify laboratory quantitation results. In the space below, please show a minimum of one sample calculation:

LCS

Methane

RF = 157692659

[] = (1476338836)/(157692659)

= 9.362 % OK

All criteria were metX
Criteria were not met
and/or see below

XII.	\cap	antit		ИL	TIME	2
AII.	WU.		Δ	ИЬ	JIVII I	u

A. Dilution performed

SAMPLE ID	DILUTION FACTOR	REASONS FOR DILUTION
All samples dilu	ited by a factor of less th	an 1.9
		
		
	1	

B.	Percent Solids		
	List samples which have ≤ 50 % solids		
			_
			_
		 	_

Actions:

If the % solids of a soil sample is 10-50%, estimate positive results (J) and nondetects (UJ)

If the % solids of a soil sample is < 10%, estimate positive results (J) and reject nondetects (R)