

## CERTIFICATION

SDG No:	1701428D	Laboratory:	Eurofins, Folsom, CA
Site:	BMSMC	Matrix:	Air

**SUMMARY:** Air samples (Table 1) were collected on the BMSMC facility. The BMSMC facility is located in Humacao, PR. Samples were taken January 21, 23, 24 and 26, 2017 and were analyzed in Eurofins Laboratory of Folsom, California that reported the data under SDG No.: 1701428D. Results were validated using the validation QC requirements of ASTM D-1946 method for measuring permanent gases and light hydrocarbons in refinery and other sources samples using gas chromatography (GC) and a thermal conductivity detector (TCD) and/or flame ionization detection (FID). The sample integrity and preservation section is validated following the criteria of the following guideline document: USEPA, Validating Air Samples. Volatile Organic Analysis of Ambient Air in Canisters by Method TO-15, (SOP # HW-31. Revision #6. June, 2014). The analyses performed are shown in Table 1. Individual data review worksheets are enclosed for each target analyte group. The data sample summary form shows analyte results that were qualified.

In summary, the results are valid and can be used for decision making purposes.

Table 1. Samples analyzed and analysis performed

SAMPLE ID	SAMPLE DESCRIPTION	MATRIX	ANALYSIS PERFORMED
1701428D-01A	B30IA-1-012117	Air	Methane
1701428D-02A	B30IA-2-012117	Air	Methane
1701428D-03A	B30IA-3-012117	Air	Methane
1701428D-04A	B30IA-4-012117	Air	Methane
1701428D-05A	B30IA-4D-012117	Air	Methane
1701428D-06A	B30IA-5-012117	Air	Methane
1701428D-07A	B1830AA-012117	Air	Methane
1701428D-08A	B18IA-1-012117	Air	Methane
1701428D-09A	B18IA-1D-012117	Air	Methane
1701428D-10A	B18IA-2-012117	Air	Methane
1701428D-11A	B18IA-3-012117	Air	Methane
1701428D-12A	B18IA-4-012117	Air	Methane
1701428D-13A	B8IA-2-012317	Air	Methane
1701428D-14A	B8IA-2D-012317	Air	Methane
1701428D-15A	B8AA-012317	Air	Methane
1701428D-16A	B8SS-2-012417	Air	Methane
1701428D-17A	B8SS-2D-012417	Air	Methane
1701428D-18A	B18SS-1-012617	Air	Methane
1701428D-19A	B18SS-1Dup-012617	Air	Methane

Reviewer Name:

Rafael Infante  
Chemist License 1888

Signature:

*Rafael Infante*

Date:

March 18, 2017





## Air Toxics

Client Sample ID: B30IA-1-012117

Lab ID#: 1701428D-01A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: 10020205  
Dil. Factor: 1.61

Date of Collection: 1/21/17 6:17:00 PM  
Date of Analysis: 2/2/17 09:57 AM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00016	0.0011

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B30IA-2-012117

Lab ID#: 1701428D-02A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020206	Date of Collection: 1/21/17 6:20:00 PM
Dil. Factor:	1.64	Date of Analysis: 2/2/17 10:22 AM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00016	0.00044

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B301A-3-012117

Lab ID#: 1701428D-03A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: 10020207  
Dil. Factor: 1.91

Date of Collection: 1/21/17 6:21:00 PM  
Date of Analysis: 2/2/17 10:59 AM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00019	0.00071

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B301A-4-012117

Lab ID#: 1701428D-04A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020208	Date of Collection: 1/21/17 6:22:00 PM
Dil. Factor:	1.61	Date of Analysis: 2/2/17 11:23 AM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00016	0.00056

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B30IA-4D-012117

Lab ID#: 1701428D-05A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020209	Date of Collection: 1/21/17 6:22:00 PM
Dil. Factor:	1.68	Date of Analysis: 2/2/17 11:53 AM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00017	0.00054

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B301A-5-012117

Lab ID#: 1701428D-06A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020210	Date of Collection: 1/21/17 6:25:00 PM
Dil. Factor:	1.64	Date of Analysis: 2/2/17 12:19 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00016	0.00040

Container Type: 6 Liter Summa Canister (100% Certified)







## Air Toxics

Client Sample ID: B1830AA-012117

Lab ID#: 1701428D-07A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020211	Date of Collection: 1/21/17 6:42:00 PM
Dil. Factor:	1.64	Date of Analysis: 2/2/17 12:42 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00016	0.00018

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B18IA-1-012117

Lab ID#: 1701428D-08A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020212	Date of Collection: 1/21/17 6:07:00 PM
Dil. Factor:	1.79	Date of Analysis: 2/2/17 01:23 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00018	0.00020

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B181A-1D-012117

Lab ID#: 1701428D-09A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: 10020213  
Dil. Factor: 1.68

Date of Collection: 1/21/17 6:07:00 PM  
Date of Analysis: 2/2/17 01:53 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00017	0.00021

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B18IA-2-012117

Lab ID#: 1701428D-10A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name: 10020214  
Dil. Factor: 1.75

Date of Collection: 1/21/17 6:00:00 PM  
Date of Analysis: 2/2/17 02:20 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00018	0.00018

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B18IA-3-012117

Lab ID#: 1701428D-11A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020215	Date of Collection: 1/21/17 6:10:00 PM
Dil. Factor:	1.58	Date of Analysis: 2/2/17 03:14 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00016	0.00022

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B18IA-4-012117

Lab ID#: 1701428D-12A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020216	Date of Collection: 1/21/17 6:12:00 PM
Dil. Factor:	1.41	Date of Analysis: 2/2/17 03:39 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00014	0.00021

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B81A-2-012317

Lab ID#: 1701428D-13A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020217	Date of Collection: 1/23/17 12:23:00 PM
Dil. Factor:	1.75	Date of Analysis: 2/2/17 04:05 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00018	0.00028

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B8IA-2D-012317

Lab ID#: 1701428D-14A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020218	Date of Collection: 1/23/17 12:23:00 PM
Dil. Factor:	1.87	Date of Analysis: 2/2/17 04:32 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00019	0.00024

Container Type: 6 Liter Summa Canister (100% Certified)







## Air Toxics

Client Sample ID: B8AA-012317

Lab ID#: 1701428D-15A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020219	Date of Collection: 1/23/17 9:20:00 AM
Dil. Factor:	1.46	Date of Analysis: 2/2/17 04:55 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00015	0.00024

Container Type: 6 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B8SS-2-012417

Lab ID#: 1701428D-16A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020220	Date of Collection: 1/24/17 3:35:00 PM
Dil. Factor:	2.49	Date of Analysis: 2/2/17 05:40 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00025	34

Container Type: 1 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B8SS-2D-012417

Lab ID#: 1701428D-17A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020221	Date of Collection: 1/24/17 3:35:00 PM
Dil. Factor:	2.42	Date of Analysis: 2/2/17 06:49 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00024	33

Container Type: 1 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B18SS-1-012617

Lab ID#: 1701428D-18A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020222	Date of Collection: 1/26/17 5:30:00 PM
Dil. Factor:	2.50	Date of Analysis: 2/2/17 07:13 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00025	0.00021 J

J = Estimated value.

Container Type: 1 Liter Summa Canister (100% Certified)





## Air Toxics

Client Sample ID: B18SS-1Dup-012617

Lab ID#: 1701428D-19A

### NATURAL GAS ANALYSIS BY MODIFIED ASTM D-1946

File Name:	10020223	Date of Collection: 1/26/17 5:30:00 PM
Dil. Factor:	2.46	Date of Analysis: 2/2/17 07:38 PM

Compound	Rpt. Limit (%)	Amount (%)
Methane	0.00025	Not Detected

Container Type: 1 Liter Summa Canister (100% Certified)





Air Toxics

Sample Transportation Notice

Relinquishing signature on this document indicates that sample is being shipped in compliance with all applicable local, State, Federal, national, and international laws, regulations and ordinances of any kind. Air Toxics Limited assumes no liability with respect to the collection, handling or shipping of these samples. Relinquishing signature also indicates agreement to hold harmless, defend, and indemnify Air Toxics Limited against any claim, demand, or action, of any kind, related to the collection, handling, or shipping of samples. D.O.T. Hotline (800) 467-4922

180 BLUE RAVINE ROAD, SUITE B  
FOLSOM, CA 95630-4719  
(916) 985-1000 FAX (916) 985-1020

Page 1 of 2

Project Manager

Tony Taylor

Collected by: (Print and Sign)

REIT, DL

Company

AMA

Email: rtaylor@amawest.com

Address: 2700 Westchester Ave. City Purchase State NY Zip 10577

Phone 914.251.0400 x309 Fax 914.251.1286

Project Info:

P.O. #

Project # BMS 44

Project Name BMS V1

Turn Around Time:

☒ Normal

☐ Rush

Lab Use Only Pressurized by:

Date:

Pressurization Gas:

N<sub>2</sub> He

Lab I.D.	Field Sample I.D. (Location)	Can #	Date of Collection	Time of Collection	Analyses Requested	Canister Pressure/Vacuum
01#	B301A-1-012117	25336	6/1/17	1817	TO-15, H <sub>2</sub> O, CH <sub>4</sub>	30" 5"
02#	B301A-2-012117	N1755	6/1/17	1820	TO-15, H <sub>2</sub> O, CH <sub>4</sub>	30" 6.5"
03#	B301A-3-012117	9551	6/1/17	1821	TO-15, H <sub>2</sub> O, CH <sub>4</sub>	30" 10.5"
04#	B301A-4-012117	00895	6/1/17	1822	TO-15, H <sub>2</sub> O, CH <sub>4</sub>	30" 5"
05#	B301A-4D-012117	00898	6/1/17	1822	TO-15, H <sub>2</sub> O, CH <sub>4</sub>	30" 6"
06#	B301A-5-012117	33787	6/1/17	1825	TO-15, H <sub>2</sub> O, CH <sub>4</sub>	30" 6"
07#	B1830AA-012117	33585	1/21/17	1842	TO-15, H <sub>2</sub> O, CH <sub>4</sub>	30" 6"
08#	B181A-1-012117	N1735	1/21/17	1807	TO-15, H <sub>2</sub> O, CH <sub>4</sub>	30" 8"
09#	B181A-1D-012117	00138	1/21/17	1807	TO-15, H <sub>2</sub> O, CH <sub>4</sub>	30" 7.5"
10#	B181A-2-012117	061216	1/21/17	1800	TO-15, H <sub>2</sub> O, CH <sub>4</sub>	30" 5"
Relinquished by: (signature) Date/Time		Received by: (signature) Date/Time		Notes: Tag for canister 00898 indicated it is N <sub>2</sub> O <sub>4</sub> . That ID is not on the packing slip. The canister has the serial # 00898, and is listed on the packing slip.		
Relinquished by: (signature) Date/Time		Received by: (signature) Date/Time				
Relinquished by: (signature) Date/Time		Received by: (signature) Date/Time				
Lab Use Only	Shipper Name	Air Bill #	Temp (°C)	Condition	Custody Seals Intact?	Work Order #
	FAA		N/A	good	Yes No (None)	1701428



# Chain-of-Custody Record

Page 2 of 2

<b>Contact Person</b> Terry Taylor <b>Company</b> Anderson Mulholland & Associates, Inc. <b>Address</b> 2700 Winchester, Suite 41 City Purchase State NY Zip 10577 <b>Phone</b> 914-251-0400, x 309 <b>FAX</b> <b>Collected By:</b> (Signature) <i>[Signature]</i>				<b>Project Information:</b> <b>P.O. #</b> <b>Project #</b> BMS VI Invest. <b>Project Name</b> Buildings 8, 13, 5, 18, and 30		<b>Turn Around Time:</b> <input checked="" type="checkbox"/> Normal <input type="checkbox"/> Rush <b>Specify</b>		<b>Pressurized</b> <b>by:</b> <b>Date:</b> <b>Press. Gas:</b> N2 He	
<b>Lab I.D.</b>	<b>Field Sample I.D.</b>	<b>Canister I.D.</b>	<b>Date &amp; Time</b>	<b>Analysis Requested</b>	<b>Canister Pressure/Vacuum</b> <b>Initial</b> <b>Final</b> <b>Receipt</b> <b>Final</b> (psi)				
11A	B18IA-3-012117	34320	1/21/17: 1810	TO-15, MeOH, CH <sub>4</sub>	29 "Hg	6			
12A	B18IA-4-012117	U1591	1/21/17: 1812	TO-15, MeOH, CH <sub>4</sub>	29.5 "Hg	6			
13A	B8IA-2-012317	U1726	1/23/17: 1223	TO-15, MeOH, CH <sub>4</sub>	29 "Hg	8			
14A	B8IA-20-012317	U0416	1/23/17: 1823	TO-15, MeOH, CH <sub>4</sub>	29 "Hg	9			
15A	B8AA-012317	04316	1/23/17: 0930	TO-15, MeOH, CH <sub>4</sub>	29 "Hg	3			
16A	B855-2-012417	1L1603	1/24/17: 1535	TO-15, MeOH, CH <sub>4</sub>	30 "Hg	5			
17A	B855-20-012417	12323	1/24/17: 1535	TO-15, MeOH, CH <sub>4</sub>	29 "Hg	5			
18A	B1855-1-012617	1L1720	1/26/17: 1730	TO-15, MeOH, CH <sub>4</sub>	30 "Hg	5			
19A	B1855-1 DUP-012617								
20A	B1855-1 DUP-012617	U1939	1/26/17: 1730	TO-15, MeOH, CH <sub>4</sub>	30 "Hg	6			
<b>Received By:</b> (Signature) <i>[Signature]</i> <b>Date/Time</b> 1-27-17 1400 <b>Fed EX</b>				<b>Notes:</b> FedEx Tracking No. 7782 9053 0772					
<b>Relinquished By:</b> (Signature) <i>[Signature]</i> <b>Date/Time</b> 1-27-17 1400 <b>Fed EX</b>									
<b>Relinquished By:</b> (Signature) <i>[Signature]</i> <b>Date/Time</b> 1-27-17 1400 <b>Fed EX</b>									
<b>Relinquished By:</b> (Signature) <i>[Signature]</i> <b>Date/Time</b> 1-27-17 1400 <b>Fed EX</b>									
<b>Shipper Name</b> Air Bill # <b>Opened By</b> Temp @ <b>Condition</b> <b>Custody Seals</b> <b>Work Order #</b>									
Fed Ex 1701428									

## EXECUTIVE NARRATIVE

SDG No: **1701428D** Laboratory: **Eurofins, Folsom, CA**  
Analysis: **ASTM D-1946** Number of Samples: **19**  
Location:

**SUMMARY:** Nineteen (19) samples were analyzed for methane in ambient air following ASTM Method D-1946. The sample results were assessed according to the following documents in the order of precedence: QC criteria from ASTM D-1946 method for measuring permanent gases and light hydrocarbons in refinery and other sources samples using gas chromatography (GC) and a thermal conductivity detector (TCD) and/or flame ionization detection (FID). The sample integrity and preservation section is validated following the criteria of the following guideline document: USEPA, Validating Air Samples. Volatile Organic Analysis of Ambient Air in Canisters by Method TO-15, (SOP # HW-31. Revision #6. June, 2014). The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

Results are valid and can be used for decision making purposes.

**Critical issues:** **None**  
**Major:** **None**  
**Minor:** **None**

**Critical findings:** **None**  
**Major findings:** **None**  
**Minor findings:** **1.** Field duplicates analyzed with this data package. RPD within laboratory and generally acceptable control limits except for the cases described in the Data Review Worksheet. No action taken, sample and duplicate concentration < 5 x SQL.

**COMMENTS:** Results are valid and can be used for decision making purposes.

**Reviewers Name:** Rafael Infante  
Chemist License 1888

**Signature:**  
**Date:**



March 17, 2017



# METHANE DATA SAMPLE SUMMARY

METHOD:

ASTM D-1946

## METHANE - ASTM - D-1946

Sample ID	Date	Results	Units	Dilution Factor	Lab Flag	Validation	Reportable
1701428D-01A	1/21/2017	0.0011	%	1.61	-	-	Yes
1701428D-02A	1/21/2017	0.00044	%	1.64	-	-	Yes
1701428D-03A	1/21/2017	0.00071	%	1.91	-	-	Yes
1701428D-04A	1/21/2017	0.00056	%	1.61	-	-	Yes
1701428D-05A	1/21/2017	0.00054	%	1.68	-	-	Yes
1701428D-06A	1/21/2017	0.0004	%	1.64	-	-	Yes
1701428D-07A	1/21/2017	0.0002	%	1.64	-	-	Yes
1701428D-08A	1/21/2017	0.0002	%	1.79	-	-	Yes
1701428D-09A	1/21/2017	0.00021	%	1.68	-	-	Yes
1701428D-10A	1/21/2017	0.00018	%	1.75	-	-	Yes
1701428D-11A	1/21/2017	0.00022	%	1.58	-	-	Yes
1701428D-12A	1/21/2017	0.00021	%	1.41	-	-	Yes
1701428D-13A	1/23/2017	0.00028	%	1.75	-	-	Yes
1701428D-14A	1/23/2017	0.00024	%	1.87	-	-	Yes
1701428D-15A	1/23/2017	0.00024	%	1.46	-	-	Yes
1701428D-16A	1/24/2017	34.00000	%	2.49	-	-	Yes
1701428D-17A	1/24/2017	33.00000	%	2.42	-	-	Yes
1701428D-18A	1/26/2017	0.00021	%	2.50	J	J	Yes
1701428D-19A	1/26/2017	0.00025	%	2.46	-	U	Yes

## DATA REVIEW WORKSHEETS

Project Number: 1701428D

Date: 01/21-23-24-26/2017

### REVIEW OF VOLATILE ORGANIC PACKAGE

The following guidelines for evaluating volatile organics were created to delineate required validation actions. This document will assist the reviewer in using professional judgment to make more informed decision and in better serving the needs of the data users. The sample results were assessed according to the following documents in the order of precedence: QC criteria from ASTM D-1946 method for measuring permanent gases and light hydrocarbons in refinery and other sources samples using gas chromatography (GC) and a thermal conductivity detector (TCD) and/or flame ionization detection (FID). The sample integrity and preservation section is validated following the criteria of the following guideline document: USEPA, Validating Air Samples. Volatile Organic Analysis of Ambient Air in Canisters by Method TO-15, (SOP # HW-31. Revision #6. June, 2014). The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

The hardcopied (laboratory name) Eurofins data package received has been reviewed and the quality control and performance data summarized. The data review for VOCs included:

Lab. Project/SDG No.: 1701428D

Sample matrix: Air

No. of Samples: 19

Trip blank No.: -

Field blank No.: -

Equipment blank No.: -

Field duplicate No.: 1701428D-04A/1701428D-05A; 1701428D-08A/1701428D-09A

1701428D-13A/1701428D-14A; 1701428D-16A/1701428D-17A

1701428D-18A/1701428D-19A

☒ Data Completeness

☒ Holding Times

☒ Calibrations

☒ Blanks

☒ Quantitation Limits

☒ Laboratory Control Spikes

☒ Field Duplicates

☒ Compound Identifications

☒ Compound Quantitation

Overall Comments: Methane\_by ASTM\_method\_D-1946\_(modified)

#### Definition of Qualifiers:

J- Estimated results

U- Compound not detected

R- Rejected data

UJ- Estimated nondetect

Reviewer: Rafael Infante

Date: 03/17/2017

## DATA REVIEW WORKSHEETS

## DATA COMPLETENESS

### MISSING INFORMATION

DATE LAB. CONTACTED

DATE RECEIVED

This image shows a single sheet of white paper with horizontal blue ruling lines. A dashed gray diagonal line runs from the top-left corner towards the bottom-right corner. The lines are evenly spaced and cover the entire page.

All criteria were met   X    
 Criteria were not met  
 and/or see below       

## SAMPLE INTEGRITY AND PRESERVATION

Canister used for sampling of the ambient air must be demonstrated clean, and leak free prior to sample collection. Cleanliness is demonstrated by the analysis of an individual canister or analysis of a representative canister, if only batch cleaning was required. Leak proof testing is performed on individual canisters. Canisters are used in conjunction with gauges, valves and flow controllers. Therefore, canister should be demonstrated clean and leak free inclusive of these components as appropriate.

- a. Leak proof test:
- Was the pressure of each canister measured before shipping? Yes or No
- Was the pressure of each canister measured before sampling? Yes or No
- Did the canister hold vacuum/pressure within +/- 2 psi from the date shipped to the sampling date? Yes or No

Note:

- The laboratory should be notified if the difference between the laboratory and field pressure is greater than 2 psi.

Actions:

Actions for use of canisters with failing leak test criteria are indicated in Table 1 below.

**Table 1. Canister Leak test Actions for TO-15 Analysis\***

Matrix	Difference in initial and 24 hour pressure (psi) Criteria	Action	
		Detected Associated Compounds	Non-Detected Associated Compounds
Air	≤ 5	No qualification	
Air	> 5	J	UJ or R

\*Excessive time period (> 3months) elapsed between leak test and actual use should be considered in evaluation of canister integrity.

- b. Cleanliness
- Integrity of the canister used for sampling of air for analysis should be maintained at all times including time of shipment to the field, sampling, shipping back to the laboratory and time of analysis. Analytical results of canister cleaning verification must be taken into account in the validation of sample results.

Does the canister meet the cleanliness criteria? Yes or No

Is the canister verification included in the data package?

Yes or **No**

Actions:

Canister contamination actions are stated in Table 2 below.

**Note:** Laboratory states that samples were collected on SUMMA canisters 100 % qualified.

**Table 2. Canister Contamination Actions for TO-15 Analyses**

Contamination Type/level	Canister Cleaning Result	Sample Result	Action for Samples
Clean Canister analysis	Detects	Analytes found in clean canister analysis are non-detects	No qualification required
	<CRQL	< CRQL	Report CRQL value with a U
		$\geq$ CRQL and < 2x the CRQL	Report concentration of sample with a U
		$\geq$ 2x the CRQL	No qualification required
	> CRQL	< CRQL	Report CRQL value with a U
		$\geq$ CRQL and $\leq$ clean canister value	Report clean canister value with a U
		$\geq$ CRQL and > clean canister value	No qualification required
	= CRQL	$\leq$ CRQL	Report CRQL value with a U
		> CRQL	No qualification required

c. Holding time and sample integrity

SUMMA canisters are to minimize sample charges or loss for majority of the analyte. Sample integrity is maintained by ensuring the system is closed tight and canister pressure from the time of sampling to the time of analysis is maintained within a difference allowable due to temperature change.

Was the canister pressure measured at the conclusion of the sampling period?

**Yes** or No

Was the canister pressure measured upon arrival to the laboratory? **Yes** or No

Was the canister pressure difference between sampling and analysis less than 5 psi? **Yes** or No

Actions:

Qualify sample results using technical holding time information as stated in Table 3.

## DATA REVIEW WORKSHEETS

Pressure difference between sampling and analysis should be less than 5 psi.  
Qualify samples as per Table 3 requirements.

**Table 3. Holding Time Actions for TO-15 Volatile Analyses**

Matrix	Preserved (Pressure difference between sampling and analysis $\leq 5$ psi)	Criteria	Action	
			Detected Associated Compounds	Non-Detected Associated Compounds
Air	Yes	< 30 days	No qualification	
	Yes	>30 days	J	UJ
Air	No	< 30 days	J	UJ
	No	>30 days	J	R

Complete table for all samples and note the integrity and/or preservation not within criteria

SAMPLE ID	DATE SAMPLED	DATE ANALYZED	Pressure difference < 5 psi	ACTION

The following pressure conversion is used, if necessary

PRESSURE CONVERSION TABLE								
PSI	ATM	kgf/cm <sup>2</sup>	in.H <sub>2</sub> O	mmHg	in.Hg	Kpa	Bar	mm H <sub>2</sub> O
1	0.068046	0.070307	27.7276	51.715	2.03602	6.895	0.6895	704.28104
14.696	1	1.0332	407.484	760	29.921	101.325	1.01325	10350.0936
14.2233	0.96784	1	394.38	735.559	28.959	98.096	0.98067	10000
0.036092	0.002454	0.00253	1	1.8651	0.07343	0.249	0.00249	25.4
0.019336	0.001315	0.001359	0.53616	1	0.03937	0.1333	0.001333	13.618464
0.491154	0.0033421	0.03453	13.6185	25.4	1	3.3864	0.033864	345.9099
0.145	0.00987	0.010197	4.0186	7.5006	0.2953	1	0.01	102.07244
14.5038	0.98692	1.01972	402.156	750.062	29.53	100	1	10214.7624

## DATA REVIEW WORKSHEETS

All criteria were met \_\_N/A\_\_  
Criteria were not met see below \_\_\_\_\_

### GC/MS TUNING

The assessment of the tuning results is to determine if the sample instrumentation is within the standard tuning QC limits

\_\_N/A\_ The BFB performance results were reviewed and found to be within the specified criteria.

\_\_N/A\_ BFB tuning was performed for every 24 hours of sample analysis.

If no, use professional judgment to determine whether the associated data should be accepted, qualified or rejected.

List \_\_\_\_\_ the \_\_\_\_\_ samples \_\_\_\_\_ affected:

If mass calibration is in error, all associated data are rejected.

Note: Samples analyzed using GC with either TCD or FID detection.

## DATA REVIEW WORKSHEETS

All criteria were met ☒ X  
 Criteria were not met  
 and/or see below \_\_\_\_\_

### CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

Date of initial calibration: 01/12/17

Dates of continuing calibration: 02/02/17

Instrument ID numbers: GC-10

Matrix/Level: Air/low

DATE	LAB ID#	FILE	CRITERIA OUT RFs, %RSD, %D, r	COMPOUND	SAMPLES AFFECTED
Initial and continuing calibrations meet method specific requirements with the following modifications: A minimum of 5-point calibration curve is performed. Quantitation is based on the average Response Factor. The standards used by the laboratory are blended to a $\geq 95\%$ accuracy.					

#### General criteria employed for validation

All RFs must be  $> 0.05$  regardless of method requirements.

All %RSD must be  $\leq 15\%$  regardless of method requirements.

All %Ds must be  $\leq 30\%$  regardless of method requirements.

Method ASTM D1946 does not specify criterion for the curve correlation coefficient (r). A limit for r of  $\geq 0.995$  has therefore been utilized as professional judgment.

#### Actions

If any compound has an initial RF or a continuing RF of  $< 0.05$ , estimate positive results (J) and reject nondetects (R), regardless of method requirements.

If any compound has a %RSD  $> 15\%$ , estimate positive results (J) and use professional judgment to qualify nondetects.

If any compound has a % D  $> 30\%$ , estimate positive results (J) and nondetects (UJ).

If any compound has a % D  $> 90\%$ , estimate positive results (J) and reject nondetects (R).

If any compound has  $r < 0.995$ , estimate positive results and nondetects.

A separate worksheet should be filled for each initial curve



## DATA REVIEW WORKSHEETS

All criteria were met ☒ X  
 Criteria were not met  
 and/or see below \_\_\_\_\_

### V A. BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including trip, equipment, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamination in the blanks below. High and low levels blanks must be treated separately.

#### Laboratory blanks

DATE ANALYZED	LAB ID	LEVEL/MATRIX	COMPOUND	CONCENTRATION UNITS
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
All method blank meet method specific criteria				
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____

#### Field/Equipment/Trip blank

DATE ANALYZED	LAB ID	LEVEL/MATRIX	COMPOUND	CONCENTRATION UNITS
_____	_____	_____	_____	_____
No field/trip/equipment blanks analyzed with this data package.				
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below       

### V B. BLANK ANALYSIS RESULTS (Section 3)

#### Blank Actions

Action Levels (ALs) should be based upon the highest concentration of contaminant determined in any blank. Do not qualify any blank with another blank. The ALs for samples which have been diluted should be corrected for the sample dilution factor and/or % moisture, where applicable. No positive sample results should be reported unless the concentration of the compound in the samples exceeds the ALs:

ALs = 10x the amount of common contaminants (methylene chloride, acetone, 2-butanone, and toluene)

ALs = 5x for any other compounds

Specific actions are as follows:

If the concentration is < sample quantitation limit (SQL) and  $\leq$  AL, report the compound as not detected (U) at the SQL.

If the concentration is  $\geq$  SQL but  $\leq$  AL, report the compound as not detected (U) at the reported concentration.

If the concentration is  $\geq$  SQL and > AL, report the concentration unqualified.

Notes:

High and low level blanks must be treated separately

Compounds qualified "U" for blank contamination are still considered "hits" when qualifying for calibration criteria.

CONTAMINATION SOURCE/LEVEL	COMPOUND	CONC/UNITS	AL/UNITS	SQL	AFFECTED SAMPLES

All criteria were met   X    
 Criteria were not met  
 and/or see below           

## VIII. LABORATORY CONTROL SAMPLE (LCS) ANALYSIS

This data is generated to determine accuracy of the analytical method for various matrices.

### 1. LCS Recoveries Criteria

Where LCS spiked with the same analyte at the same concentrations as the MS/MSD?  
 Yes or No. If no make note in data review memo.

List the %R of compounds which do not meet the criteria

LCS ID	COMPOUND	% R	QC LIMIT
____LCS/LCSD_(Blank_spike)_analyzed_in_this_data_package;_recoveries_and_RPD_____			
____within_laboratory_control_limits._____			

\* QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.

\* If QC limits are not available, use limits of 70 – 130 %.

Actions:

QUALITY	%R < LL	%R > UL
Positive results	J	J
Nondetects results	R	Accept

All analytes in the associated sample results are qualified for the following criteria.

If 25 % of the LCS recoveries were < LL (or 70 %), qualify all positive results (j) and reject nondetects (R).

If two or more LCS were below 10 %, qualify all positive results as (J) and reject nondetects (R).

### 2. Frequency Criteria:

Where LCS analyzed at the required frequency and for each matrix? Yes or No.

If no, the data may be affected. Use professional judgment to determine the severity of the effect and qualify data accordingly. Discuss any actions below and list the samples affected.

All criteria were met \_\_\_\_\_  
 Criteria were not met \_\_\_\_\_  
 and/or see below \_\_\_\_X\_\_\_\_

## IX. FIELD/LABORATORY DUPLICATE PRECISION

Sample ID _____ LCS/LCSD_(02/02/17)_____	Matrix: ___Air___
Sample ID _____ 1701428D-04A/1701428D-05A _____	Matrix: ___Air___
Sample ID _____ 1701428D-08A/1701428D-09A _____	Matrix: ___Air___
Sample ID _____ 1701428D-13A/1701428D-14A _____	Matrix: ___Air___
Sample ID _____ 1701428D-16A/1701428D-17A _____	Matrix: ___Air___
Sample ID _____ 1701428D-18A/1701428D-19A _____	Matrix: ___Air___

Field/laboratory duplicates samples may be taken and analyzed as an indication of overall precision. These analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples.

The project QAPP should be reviewed for project-specific information.

Suggested criteria: RPD  $\pm$  25% for air samples. If both samples and duplicate are <5 SQL, the RPD criteria is doubled.

COMPOUND	SQL, %	SAMPLE CONC.	DUPLICATE CONC.	RPD	ACTION
Field/laboratory duplicates analyzed as part of this data package. LCS/LCSD (laboratory) RPD within laboratory control limits. Field duplicate RPD within laboratory control limits except in the cases described in this document.					
1701428D-18A/1701428D-19A					
Methane	0.00025	0.00021	ND	-	No action, professional judgment. Sample/duplicate concentration < 5 x SQL

## Actions:

Qualify as estimated positive results (J) and nondetects (UJ) for the compound that exceeded the above criteria. For organics, only the sample and duplicate will be qualified.

If an RPD cannot be calculated because one or both of the sample results is not detected, the following actions apply:

If one sample result is not detected and the other is greater than 5x the SQL qualify (J/UJ).

If one sample value is not detected and the other is greater than 5x the SQL and the SQLs for the sample and duplicate are significantly different, use professional judgment to determine if qualification is appropriate.

If one sample value is not detected and the other is less than 5x, use professional judgment to determine if qualification is appropriate.

If both sample and duplicate results are not detected, no action is needed.

## DATA REVIEW WORKSHEETS

All criteria were met ☒X\_\_\_\_  
Criteria were not met  
and/or see below \_\_\_\_\_

### XII. SAMPLE QUANTITATION

The sample quantitation evaluation is to verify laboratory quantitation results. In the space below, please show a minimum of one sample calculation:

1701428D-16A

Methane RF = 217680049

$$[ ] = (2972686485)/(217680049)$$

$$= 13.66 \% \text{ OK}$$

## DATA REVIEW WORKSHEETS

All criteria were met ☒X\_\_\_  
 Criteria were not met  
 and/or see below \_\_\_\_\_

### XII. QUANTITATION LIMITS

#### A. Dilution performed

SAMPLE ID	DILUTION FACTOR	REASONS FOR DILUTION
All samples diluted by a factor of less than 2.50		

### System Performance

#### **Action:**

Use professional judgment to qualify the data if it is determined that system performance has degraded during sample analyses. Note, for Laboratory Project Officer (PO) action, any degradation of system performance which significantly affected the data.

#### **Note:**

**Overall Assessment of Data**

**Action:**

1. Use professional judgment to determine if there is any need to qualify data which were not qualified based on the Quality Control (QC) criteria previously discussed.
2. Write a brief narrative to give the user an indication of the analytical limitations of the data. Note, for Laboratory Project Officer (PO) action, any inconsistency of the data with the Sample Delivery Group (SDG) Narrative. If sufficient information on the intended use and required quality of the data is available, the reviewer should include their assessment of the usability of the data within the given context. This may be used as part of a formal Data Quality Assessment (DQA).

**Note:**

Results are valid; the data can be used for decision making purposes.