

FedEx: 770019780857

September 23, 2022

Mr. Dave Cline IDEM Office of Air Quality 100 N. Senate Avenue Indianapolis, IN 46204

RE: REPORT TRANSMITTAL - EQM PN: 050812.0025

TC Energy- ANR Pipeline

Lagrange Compressor Station-TR01

2255 West U.S. 20 LaGrange, IN

IDEM Permit No. 087-42922-00004

Mr. Cline,

On behalf of our client, TC Energy, ANR Pipeline Company, I would like to submit the attached report with the results of the recent emissions testing performed on the Turbine TR01 located in LaGrange, IN.

The test was performed on August 18, 2022, as specified in the testing requirements described in the current operating permit no. 087-42922-00004. Testing procedures were applied as required to meet the testing requirements in the above-mentioned permit under Title 40, Code of Federal Regulations, Part 3, Subpart YYYY (40 CFR 63 (YYYY) for the Turbine TR01.

TC Energy respectfully requests the timely review and approval of this submittal. If you have any questions or concerns regarding this matter, please contact me at your convenience at (219) 661-9900 or kmast@eqm.com.

Respectfully submitted, EQM, Inc.

Karl Mastalski

Manager, Emission Measurement

Attachments: Compliance Test Report -TC Energy - LaGrange Compressor Station -Turbine TR01(1 Copy)

I have reviewed the information being submitted and, based on information and belief formed after reasonable inquiry; I certify that the statements and information contained in this submittal for LaGrange CS-Unit TR01, EQM PN: 050812.0025, are true, accurate and complete.

Signature of Responsible Official: _

Date: 9-21-2022

Printed Name of DAR:

Dustin Enright

Director US Pipelines Operations - Heartland Region

Responsible Official for Emissions & Testing Document Submittals

Electronic copy: Pedro Amieva - Environmental Advisor

DELIVERED

Tuesday

9/27/2022 at 9:54 am

Signed for by: T.LCKETT

DELIVERY STATUS



LAGRANGE TR01 QY REPORT 050812.0025

770019780857 🖉 🏠 📋





FROM

Environmental Quality Mngmt Anova Frasure 1280 Arrowhead Ct., Suite 2 Crown Point, IN US 46307 2196619900

Label Created 9/23/2022 11:07 AM

PACKAGE RECEIVED BY FEDEX

MICHIGAN CITY, IN 9/26/2022 4:51 PM

IN TRANSIT


INDIANAPOLIS, IN 9/27/2022 8:46 AM

OUT FOR DELIVERY

INDIANAPOLIS, IN 9/27/2022 8:46 AM

DELIVERED

David Cline IDEM Office of Air Management 100 N SENATE AVE IGCN1003 INDIANAPOLIS, IN US 46207 3172328443



COMPLIANCE TEST REPORT ANR PIPELINE-LAGRANGE COMPRESSOR STATION TURBINE UNIT TR01

August 18, 2022

Prepared for:



TC Energy's ANR Pipeline Company LaGrange, IN Permit 087-42922-00004

Prepared by:



Environmental Quality Management, Inc. 1280 Arrowhead Court Suite 2 Crown Point, IN 46307 (219) 661-9900 www.eqm.com

PN: 050812.0025

September 2022

PREFACE

I, Karl Mast, do hereby certify that the source emissions testing conducted at TC Energy in LaGrange, Indiana was performed in accordance with the procedures set forth by the United States Environmental Protection Agency, and that the data and results submitted within this report are an exact representation of the testing.

Karl Mast

Test Supervisor

I, Karl Mast, do hereby attest that all work on this project was performed under my direct supervision, and that this report accurately and authentically presents the source emissions testing conducted at ANR Pipeline's LaGrange Compressor Station in LaGrange, IN.

Karl Mast

Test Supervisor

SUMMARY

The compliance testing was performed on the Turbine Unit TR01 in accordance with the requirements of Permit 087-42922-00004, in order to comply with Title 40, Part 63, Subpart YYYY. The results of the testing are detailed in the following tables.

	Turbine Unit TR01- CH2O ppbvd @ 15% O2 Summary Results							
Run 1	Run 2	Run 3	Average	Permit Limit	Pass/Fail			
91	74	70	78	≤91	Pass			

CONTENTS

Pre	face	ii
Sun	nmary	iii
1	Introduction	
2	Test Results Summary	
3	Facility and Process Conditions	4
4	Test Procedures	
5	Quality Assurance Procedures	
6	Conclusions	12
1	TABLES Turbine Unit TR01 Test Results Summary	3
2	Production Data Summary	
	FIGURES	
1	Flow Schematic	6
2	Method 320 Sampling Train	
3	Method 3A Sampling Train	

APPENDICES

- A Field Test Data
- B Process Operating Data
- C Sample Calculations
- D Correspondence

1. INTRODUCTION

This report presents the results of the source emissions testing conducted by Environmental Quality Management, Inc. (EQM) for TC Energy's ANR Pipeline (ANR) at LaGrange compressor station, near LaGrange, IN, which is in LaGrange County.

The primary purpose of this testing program was to conduct emissions testing to determine compliance with Permit 087-42922-00004 for the Turbine Unit TR01 that is subject to 40 CFR Part 63, Subpart YYYY requirement at ANR Pipeline's gas compressor facility. The test plan listed that the turbine is a Mars 90 Turbine. The permit lists the Turbine is a Mars 100.

EQM's responsibility was to conduct the compliance testing for the O2 and CH2O emissions rates, record process operating data per compliance test requirements, and perform data reduction for conformance evaluation. EQM contracted the services of Prism Analytical Technologies to assist in the testing event. ANR Pipeline's responsibility was to maintain process operating parameters and to assist in providing process operating data per compliance test requirements.

The following report provides information pertaining to TC Energy's process operations, and Compliance testing. The Compliance testing conducted on the Mars 100Turbine TR01 was performed on August 18, 2022 from 9:40 A.M. to 1:35 P.M.

The following requirements were specific for the testing program:

- 1. Equipment calibrations were performed and calibration data provided.
- 2. Three (3) sixty (60) -minute, minimum, O₂ and H2CO test runs performed at Turbine Unit TR01 at maximum achievable load and speed according to pipeline conditions pursuant to EPA, Title 40, Code of Federal Regulations, Part 60, Appendix A.
- 3. FTIR data was collected using an MKS MultiGas 2030 FTIR spectrometer configured with a StarBoost system. The StarBoost technology consists of a 5-micron infrared detector, optical filtration and signal amplification. It is designed to optimize signal response and limit instrument noise for low detection limit applications. The FTIR was equipped with a temperature-controlled, 5.11-meter multipass gas cell maintained at 191°C. All data were collected in differential mode with 2 cm-1 resolution sample data and 8 cm-1 resolution background. Each FTIR spectrum was derived from the coaddition of 220 scans, with a new data point generated approximately every 60 seconds.

- 4. Process manufacturing operations maintained at 100 +/- 10 percent peak load condition, or at maximum achievable load according with ambient conditions, and fuel consumption rates recorded during the emissions testing periods.
- 5. All testing and analyses performed in accordance with current EPA test methodologies and analytical procedures for O_2 and CH2O emissions determinations.
- 6. Stratification was found to be less than 5% in the turbine exhausts.
- 7. Diluent corrected stratification test was performed in accordance with Subpart YYYY.

The testing program was approved by and/or coordinated with Pedro Amieva, TC Energy's ANR Pipeline Company. The emission testing was overseen by Karl Mast, Manager, Emission Measurement and Project Manager. The emission testing was conducted by James Carey, Prism analytical Technologies. The emission testing was not observed by regulatory personnel.

2. TEST RESULTS SUMMARY

The compliance testing was performed on the Turbine Unit TR01 in accordance with the requirements of the Title 40, Code of Federal Regulations, Part 63, Subpart YYYY (40 CFR 63, Subpart YYYY. A summary of the test results is given below:

Та	Table 1. Turbine Unit TR01- CH2O ppbvd @ 15% O2 Summary Results							
Run 1	Run 2	Run 3	Average	Permit Limit	Pass/Fail			
91	74	70	78	≤91	Pass			

Based on the information provided above, the Turbine Unit TR01 met the acceptance criteria for CH2O ppbvd @ 15% O2 during the course of the testing. A complete list of performance parameters for each test run that was performed at the stack sampling locations can be found in Appendix A

Additional testing information may be found in Appendix B.

3. PROCESS DESCRIPTION

TC Energy's ANR LaGrange Compressor Station is located at 2255 West U.S. 20, in LaGrange, Indiana and operates a Mars 100 stationary gas turbine using a SoLoNOx (lean premixed) as control. It exhausts to Stack S03.


The Mars 100 gas turbine (TR01) is a simple cycle, natural gas fired, split-shaft turbine. In a simple cycle turbine, filtered atmosphere air is first compressed by the axial flow compressor. The hot compressed air is then fired with natural gas in the combustor. The hot exhaust gases expand through two turbine stages. The gas producer (G.P.) turbine drives the axial flow air while the power turbine (P.T.) drives the centrifugal pipeline compressor. The pipeline gas compressor moves natural gas through the pipeline by compressing it from an initial "suction" state to a more compressed "discharge" state.

The following table provide a summary of the production rates for the Turbine Unit TR01 during the test based on pipeline conditions: Additional process data and information may be found in Appendix B.

Table 2. Turbine Unit TR01- RPM								
Run 1	Run 2	Run 3	Average	% Load				
7934	7785	7717	7,812	97.9				



Figure 1. Flow Schematic



Additional Information pertaining to the Fuel Flows may be found in Appendix B.

4. TEST PROCEDURES

EQM and EQM's affiliates and subcontractors use current U.S. EPA accepted testing methodologies in their Air Quality Programs as listed in the U.S. Code of Federal Regulations, Title 40, Part 60, Appendix A. For this testing program, the following specific methodologies were utilized:

- U.S. EPA Method 3A Determination of Oxygen and Carbon Dioxide Concentrations in Emissions From Stationary Sources (Instrumental Analyzer Procedure)
- ¹U.S. EPA Method 320 Determination of Formaldehyde Concentrations in Emissions From Stationary Sources using StarBoostTM Technology (Instrumental Analyzer Procedure)

USEPA Methods 3A and 320 were performed by using USEPA Method 320, "Measurements of Vapor Phase Organic and Inorganic Emissions by Extractive Fourier Transform Infrared (FTIR) Spectroscopy". Gaseous samples were withdrawn from the stack and transferred to the FTIR spectrometer.

FTIR data were collected using an MKS MultiGas 2030 FTIR spectrometer configured with a StarBoost system. The StarBoost technology consists of a 5-micron infrared detector, optical filtration and signal amplification. It is designed to optimize signal response and limit instrument noise for low detection limit applications. The FTIR was equipped with a temperature-controlled, 5.11-meter multipass gas cell maintained at 191°C. All data were collected in differential mode with 2 cm-1 resolution sample data and 8 cm-1 resolution background. Each FTIR spectrum was derived from the coaddition of 220 scans, with a new data point generated approximately every 60 seconds.

Sample gas continuously flew through the FTIR gas cell via heated head sampling pump. Total sample flow was approximately eight liters per minute. Gas flow and sampling system pressure were monitored using a rotameter and pressure transducer.

Formaldehyde spiking was performed at each source prior to testing to verify the ability of the sampling system to quantitatively deliver a sample containing formaldehyde from the base of the probe to the FTIR. The spike target dilution ratio was 1:10 or less. Analyte spiking assures the ability of the FTIR to quantify formaldehyde in the presence of effluent gas.

As part of the spiking procedure, samples from the source were measured before spiking to determine native concentrations to be used in the spike recovery

calculations. The analyte spiking gas contained nitrous oxide (N2O). The determined N2O concentration in the spiked sample was used to calculate the dilution factor of the spike and thus used to calculate the concentration of the spiked formaldehyde.

Additional information may be found in Appendix A.

Calculations that were used:

Calibration Correction

$$C_{GAS} = (C_R - C_O) \frac{C_{MA}}{C_M - C_O}$$

Where:

CGAS: Corrected flue gas concentration (ppmvd)

CR: Flue gas concentration (ppmvd)

CO: Average of initial and final zero checks (ppmvd) CM: Average of initial and final span checks (ppmvd)

CMA: Actual concentration of span gas (ppmvd)

Outlet Analyzer Drift Correction

$$Cgas = (CAve - CO)(\frac{Cma}{Cm - CO})$$

Where:

CGAS: Average effluent gas concentration adjusted for bias

CAve: Average unadjusted gas concentration indicated by data recorder for the test run

CO: Average of initial and final zero checks (ppmvd)
CM: Actual concentration of the upscale calibration gas

CMA: Average of initial and final system calibration bian check responses for

the upscale calibration gas

EPA F-Factor

$$F_{d} = \frac{\left[(3.64 \cdot H_{WP\%} \cdot 100) + (1.53 \cdot C_{WP\%} \cdot 100) \right]}{\frac{GCV}{\rho_{FuelGas}}} \cdot 10^{6} + \frac{\left[(0.14 \cdot N_{2WP\%} \cdot 100) - (0.46 \cdot O_{2WP\%} \cdot 100) \right]}{\frac{GCV}{\rho_{FuelGas}}} \cdot 10^{6}$$

<u>Where:</u>

 F_d : Fuel specific F-factor, dscf/MMBtu

H_{Wt%}: Hydrogen weight percent C_{Wt%}: Carbon weight percent N_{2Wt%}: Nitrogen weight percent O_{2Wt%}: Oxygen weight percent

GCV: Heating value of the fuel, BTU/dscf $\rho_{Fuel Gas}$: Density of the fuel gas, lb/scf

N₂O Concentration/Dilution Factor

$$DF = \frac{N2O(spk)}{N2O(Direct)}$$

CS = DF * Spike(dir) + Unspike (1-DF) (Sec. 9.3.1 (2) USEPA Method 320)

Where:

DF = Dilution factor of the spike gas

N2O(dir) = N2O concentration measured directly in undiluted spike gas N2O(spk) = Diluted N2O concentration measured in a spiked sample Spikedir = Concentration of the analyte in the spike standard measure by

the FTIR directly

CS = Expected concentration of the spiked samples

Unspike = Native concentration of analytes in unspiked samples



Initial Particulate Filter

Vent

Mass Flow Meter

SF6 or Analyte Spike

Figure 2. USEPA Method 320 Sampling Train



Sample
Sample
Sample
Conditioner

Sample
Conditioner

LWay Valve

Sample Inter

LWay Valve

Calibration Gases

Data Acquisition System

Data Acquisition System

Figure 3. USEPA Method 3A Sampling Train

5. QUALITY ASSURANCE PROCEDURES

Each reference method presented in the U.S. Code of Federal Regulations details the instrument calibration requirements, sample recovery and analysis, data reduction and verification, types of equipment required, and the appropriate sampling and analytical procedures to ensure maximum performance and accuracy. EQM and EQM's affiliates and subcontractors adhere to the guidelines for quality control set forth by the United States Environmental Protection Agency. These procedures are outlined in the following documents:

- Code of Federal Regulations, Title 40, Part 51
- Code of Federal Regulations, Title 40, Part 60
- Quality Assurance Handbook, Volume 1, EPA 600/9-76-005
- Quality Assurance Handbook, Volume 2, EPA 600/4-77-027a
- Quality Assurance Handbook, Volume 3, EPA 600/4-77-027b

6. CONCLUSIONS

An Emissions Test was conducted on the Turbine Unit TR01 at TC Energy's ANR Pipeline Company's LaGrange Compressor Station located in LaGrange, IN. The testing was conducted on August 18, 2022.

During the course of the testing, the Turbine Unit TR01 conformed to the requirements of Code of Federal Regulations, Title 40, Part 63, Subpart YYYY to determine results of H_2CO ppbvd @ 15% O2.

The usefulness and/or significance of the emissions values presented in this document as they relate to the compliance status of the Turbine Unit TR01 emissions shall be determined by others.

For additional information pertaining to the testing program see Appendix D of this report.

A. FIELD TEST DATA



TC Energy ANR Pipeline Co. LaGrange, IN TR01 USEPA Methods 3A & 320 FTIR Emissions Testing August 18th, 2022 PROJ-020063

Scope

Prism Analytical Technologies (Mt. Pleasant, MI) was contracted by Environmental Quality Management, Inc. (Cincinnati, OH) to conduct air emission testing for TC Energy ANR Pipeline Co, LaGrange, IN. Testing was performed August 18th, 2022 to determine concentrations of gaseous formaldehyde (CH₂O), oxygen (O₂), and moisture content (H₂O) from natural gas turbine T01.

US EPA Methods 3A and 320 was performed to quantify the concentration levels of gaseous formaldehyde, oxygen, and moisture content. James Carey (Prism) performed the data collection. Amanda Nilles (Prism) performed report generation and data validation. Phillip Kauppi (Prism) reviewed the FTIR data and report.

Procedures

StarBoostTM FTIR Method 320 Instrumental Configuration & Sample Collection

FTIR data were collected using an MKS MultiGas 2030 FTIR spectrometer configured with a StarBoost system. The StarBoost technology consists of a 5-micron infrared detector, optical filtration and signal amplification. It is designed to optimize signal response and limit instrument noise for low detection limit applications. The FTIR was equipped with a temperature-controlled, 5.11-meter multipass gas cell maintained at 191°C. All data were collected in differential mode with 2 cm-1 resolution sample data and 8 cm-1 resolution background. Each FTIR spectrum was derived from the coaddition of 220 scans, with a new data point generated approximately every 60 seconds.

Sample gas continuously flew through the FTIR gas cell via heated head sampling pump. Total sample flow was approximately eight liters per minute. Gas flow and sampling system pressure were monitored using a rotameter and pressure transducer. See Table 1 below for sampling system details.



Table 1 – FTIR Sampling System

Sou	rce	StarBoost Serial #	Sampling Line	Probe Assembly	Particulate Filter Media	Operating Temperatures
TR	RO1	00244	100', 3/8" dia. Teflon	3', 3/8" dia. Inconel + heated filter element	0.01μ borosilicate	191°C FTIR + 150°C system

StarBoostTM FTIR QA/QC Methodology

QA/QC procedures followed US EPA Method 320. See Tables 2 and 3 below for QA/QC procedure details and list of calibration gas standards. All calibration gases were introduced to the analyzer and sampling system using instrument grade stainless steel rotameters. All QA/QC procedures were within the acceptance criteria allowance of the EPA methodology. QA/QC calculations are presented in detail below.

FTIR diagnostics were performed on the instrument daily to ensure signal intensity and line shape were acceptable to make low-level formaldehyde measurements.

Table 2 – FTIR OA/OC Procedures

	ible 2 - Fill QA/QC Hoccuules				Y	
QAQC Specification	Purpose	Calibration Gas Analyte	Delivery	Frequency	Acceptance Criteria	Result
M320: Zero	Verify that the FTIR is free of contaminants & zero the FTIR	Nitrogen (zero)	Direct to FTIR	pre/post test	< MDL or Noise	Pass
M320: Calibration Transfer Standard (CTS) Direct	Verify FTIR stability, confirm optical path length	Methane	Direct to FTIR	pre-test	+/- 5% cert. value	Pass
M320: Analyte Direct	Verify FTIR calibration	Formaldehyde, N₂O	Direct to FTIR	pre-test	Determine FTIR response to be used for analyte spike calcs	Pass
M320: CTS Response	Verify system stability, recovery, RT	Methane	Sampling System	pre/post test	+/- 5% of Direct Measurement	Pass
M320: Zero Response	Verify system is free of contaminants, system bias	Nitrogen (zero)	Sampling System	pre/post test	Bias correct data	Pass
M320: Analyte Spike	Verify system ability to deliver and quantify analyte of interest in the presence of other effluent gases	Formaldehyde, N₂O	Dynamic Addition to Sampling System, 1:10 effluent	pre-test	+/- 30% theoretical recovery	Pass

Table 3 – Calibration Gas Standards

Components	Concentration (ppm)	Concentration (%)	Vendor	Cylinder #	Standard Type
Formaldehyde, N ₂ O	0.598, 250.1	=	Airgas	EB0116258	Certified Standard-Spec +/- 5%, 2%
Methane	100.2	100.2 -		CC22973	Certified Standard-Spec +/- 2 %
02	=	21.8	Tier 5 Labs	ER0004758	EPA Protocol +/- 0.1% NIST Traceable
02	- 11.8		Tier 5 Labs	CC664614	EPA Protocol +/- 0.2% NIST Traceable
Nitrogen	Zero gas	Zero gas	Airgas	n/a	UHP Grade



StarBoostTM FTIR QA/QC Calculations

Method 320: Analyte Spiking

Formaldehyde spiking was performed at each source prior to testing to verify the ability of the sampling system to quantitatively deliver a sample containing formaldehyde from the base of the probe to the FTIR. The spike target dilution ratio was 1:10 or less. Analyte spiking assures the ability of the FTIR to quantify formaldehyde in the presence of effluent gas.

As part of the spiking procedure, samples from the source were measured before spiking to determine native concentrations to be used in the spike recovery calculations. The analyte spiking gas contained nitrous oxide (N_2O). The determined N_2O concentration in the spiked sample was used to calculate the dilution factor of the spike and thus used to calculate the concentration of the spiked formaldehyde.

$$DF = \frac{N2O(spk)}{N2O(Direct)}$$

CS = DF * Spike(dir) + Unspike(1 - DF) (Sec. 9.3.1 (2) USEPA Method 320)

DF = Dilution factor of the spike gas

 $N_2O_{(dir)} = N_2O$ concentration measured directly in undiluted spike gas

 $N_2O_{(spk)}$ = Diluted N_2O concentration measured in a spiked sample

Spike_{dir} = Concentration of the analyte in the spike standard measure by the FTIR directly

CS = Expected concentration of the spiked samples

Unspike = Native concentration of analytes in unspiked samples

FTIR Post Collection Data Validation

As part of the data validation procedure, reference spectra are manually fit to that of the sample spectra and a concentration is determined. The reference spectra are scaled to match the peak amplitude of the sample, thus providing a scale factor. The scale factor multiplied by the reference spectra concentration is used to determine the concentration value for the sample spectra. Sample pressure and temperature corrections are then applied to compute the final sample concentration. The manually calculated results are then compared with the software-generated results. The data is then validated if the two concentrations are within \pm 20% agreement. If there is a difference greater than \pm 20% the spectra are reviewed for possible spectra interferences or any other potential causes leading to misquantified data.



Oxygen Determination

Oxygen concentrations were determined using a Brand Gaus, Model 4710 Oxygen Analyzer, which utilizes Linear Output Zirconium Oxide Technology. The O_2 analyzer was installed at the exhaust of the FTIR, with all gases passing through the O_2 analyzer. The O_2 analyzer continually measures oxygen as it flows through the system.

QA/QC procedures followed US EPA Method 3A. See Tables 3 and 4 for list of calibration gas standards and QA/QC procedure details. All calibration gases were introduced to the analyzer and the sampling system using an instrument grade stainless steel rotameter. All QA/QC procedures were within the acceptance criteria allowance of the applicable US EPA methodology. See the Oxygen Analyzer Data Appendices for numerical results.

Table 4 – Oxygen QA/QC Procedures

	3 - J 8					
QAQC Specification	Purpose	Calibration Gas Analyte	Delivery	Frequency	Acceptance Criteria	Result
M3A: Zero	Zero the analyzer	Nitrogen (zero)	Direct to O2 Analyzer	pretest	< MDL or Noise	Pass
M3A: Span	Establish the upper range of the analyzer	21.8 % 02	Direct to O2 Analyzer	pretest	+/- 2% cert. value	Pass
M3A: MidPoint	Confirm linear response	11.8 % 02	Direct to O2 Analyzer	pretest	+/- 2% cert. value	Pass
M3A: System Zero	Verify system Bias & Drift / leak check	Nitrogen / Methane (zero)	Sampling System	pre/post test run	< 5% Bias < 3% Drift	Pass
M3A: System MidPoint	Verify system Bias & Drift / leak check	11.8 % 02	Sampling System	pre/post test run	< 5% Bias < 3% Drift	Pass

Results and Discussion

Detection Limit

The StarBoostTM FTIR detection limit for each analyte was calculated following Annex A2 of ASTM D6348-12 procedure using spectra that contained similar amounts of moisture. The minimum detectable concentration of formaldehyde was calculated as three times the standard deviation of the noise in the FTIR system. This minimum concentration can be detected with a probability of 99.7 %. See Table 4 below for determined minimum detectable concentrations.

Table 4 - StarBoostTM FTIR Detection Limits

Analyte	Detection Limit (ppmv wet)	Detection Limit (%v wet)
Formaldehyde	0.02	-
H₂O	-	0.1
O ₂	-	0.1

TR01



Three, sixty-minute test runs were performed on TR01. Testing was performed on August 18th, 2022. All Method 320 FTIR data concentration data were determined on a wet concentration (ppmvw) volume basis. The determined moisture and oxygen levels were used to calculate formaldehyde on a ppb dry, corrected to 15% O2 value.

Analyte spiking was performed to confirm the ability of the measurement system to deliver and quantify formaldehyde. See the FTIR QA/QC Data and Run Results Appendix for all concentration results. See Tables 5 below for a summary of test run results.

Table 5 – TR01 – Run Summary

Condition	Calculation	Formaldehyde (ppmv wet)	H2O (%v)	O2 (%v wet)	Formaldehyde (ppmv dry)	O2 (%v dry)	O2 Corrected (%v dry)	Formaldehyde Corrected (ppbv dry @ 15% O2)
TR01 - Run 1	Minimum	0.045	6.52	14.41	0.048	15.48		
8/18/2022	Maximum	0.096	6.93	14.70	0.103	15.75	15.86	91
9:40 - 9:57, 10:19 - 11:01	Average	0.072	6.70	14.64	0.078	15.69		
TR01 - Run 2	Minimum	0.046	6.41	14.65	0.050	15.70		
8/18/2022	Maximum	0.083	6.74	14.73	0.088	15.75	15.43	74
11:20 - 12:20	Average	0.064	6.56	14.69	0.069	15.72		
TR01 - Run 3	Minimum	0.041	6.28	14.70	0.043	15.70		
8/18/2022	Maximum	0.078	6.46	14.76	0.083	15.77	15.45	70
12:35 - 13:35	Average	0.061	6.39	14.73	0.065	15.74		

The following Appendices are included:

- Test Run Data
- FTIR & O₂ QA/QC Data
- Certificates of Analysis

Amanda Nilles

Field Technician / Chemist

EQM_ANRPipelineCo_LaGrangeIN_2022Aug_PROJ-020063_txt

Date: September 15, 2022

APPENDIX

Test Run Data



TR01 - Test Run 1

TR01 - Test Run 1			Formaldehyde	H2O	FTIR Gas Cell	FTIR Gas Cell	02	Formaldehyde	02
Spectrum	Date	Time	(ppmv wet)	(%v)	Temperature (°C)	Pressure (atm)	(%v wet)	(ppmv dry)	(%v dry)
ENG 0192.LAB	8/18/2022	9:40:53	0.087	6.86	190.9	0.999	14.58	0.094	15.66
ENG_0192.LAB	8/18/2022	9:41:53	0.094	6.88	190.9	0.999	14.56	0.101	15.63
ENG_0193.LAB	8/18/2022	9:42:53	0.096	6.90	190.9	0.999	14.54	0.103	15.62
ENG_0194.LAB	8/18/2022	9:43:52	0.085	6.87	190.9	1.000	14.58	0.103	15.66
ENG_0195.LAB	8/18/2022	9:44:52	0.092	6.91	191.0	0.999	14.53	0.099	15.61
ENG_0193.LAB	8/18/2022	9:45:52	0.080	6.89	190.9	0.998	14.58	0.086	15.65
ENG_0197.LAB	8/18/2022	9:46:52	0.092	6.87	191.0	0.999	14.58	0.099	15.65
ENG_0199.LAB	8/18/2022	9:47:52	0.087	6.89	191.0	0.999	14.58	0.094	15.66
ENG_0193.LAB	8/18/2022	9:48:52	0.083	6.89	191.1	0.999	14.50	0.089	15.58
ENG_0201.LAB	8/18/2022	9:49:51	0.088	6.90	191.0	0.999	14.57	0.094	15.65
ENG 0202.LAB	8/18/2022	9:50:51	0.087	6.88	191.1	0.999	14.58	0.093	15.66
ENG_0203.LAB	8/18/2022	9:51:51	0.085	6.84	191.0	1.000	14.61	0.091	15.68
ENG_0203.LAB	8/18/2022	9:52:51	0.070	6.84	191.0	1.000	14.62	0.075	15.70
ENG 0205.LAB	8/18/2022	9:53:51	0.069	6.82	190.9	0.999	14.63	0.073	15.70
ENG_0205.LAB	8/18/2022	9:54:50	0.084	6.78	190.9	0.999	14.63	0.090	15.69
ENG_0200.LAB	8/18/2022	9:55:50	0.075	6.82	190.9	0.999	14.65	0.080	15.73
ENG_0207.LAB	8/18/2022	9:56:50	0.083	6.76	190.9	1.000	14.65	0.089	15.71
ENG 0209.LAB	8/18/2022	9:57:50	0.067	6.76	190.8	0.999	14.65	0.033	15.72
ENG_0203.LAB	8/18/2022	10:19:46	0.072	6.93	190.8	0.997	14.41	0.072	15.48
ENG_0213.LAB ENG_0214.LAB	8/18/2022	10:13:46	0.069	6.86	190.8	0.999	14.46	0.074	15.53
ENG_0215.LAB	8/18/2022	10:20:46	0.087	6.81	190.8	0.998	14.54	0.094	15.60
ENG_0215.LAB	8/18/2022	10:21:40	0.087	6.77	190.8	0.998	14.55	0.089	15.61
ENG_0210.LAB	8/18/2022	10:22:45	0.083	6.71	190.8	0.998	14.57	0.085	15.62
ENG_0217.LAB	8/18/2022	10:24:45	0.080	6.70	190.8	0.999	14.58	0.086	15.63
ENG_0218.LAB	8/18/2022	10:25:45	0.080	6.68	190.8	0.998	14.61	0.080	15.66
ENG_0220.LAB	8/18/2022	10:26:45	0.078	6.62	190.8	0.998	14.64	0.081	15.67
ENG_0220.LAB	8/18/2022	10:27:44	0.076	6.60	190.8	0.998	14.62	0.082	15.66
ENG_0221.LAB	8/18/2022	10:27:44	0.057	6.61	190.8	0.997	14.66	0.061	15.70
ENG_0223.LAB	8/18/2022	10:29:44	0.063	6.58	190.8	0.998	14.66	0.068	15.69
ENG_0223.LAB	8/18/2022	10:30:44	0.072	6.58	190.8	1.000	14.66	0.008	15.69
ENG_0224.LAB	8/18/2022	10:30:44	0.052	6.62	190.8	0.999	14.67	0.056	15.71
ENG 0226.LAB	8/18/2022	10:31:44	0.080	6.57	190.8	0.998	14.66	0.030	15.69
ENG_0220.LAB	8/18/2022	10:32:44	0.071	6.57	190.8	0.999	14.66	0.076	15.69
ENG_0227.LAB	8/18/2022	10:33:43	0.062	6.58	190.8	0.999	14.69	0.066	15.72
ENG 0229.LAB	8/18/2022	10:34:43	0.078	6.52	190.8	0.999	14.68	0.084	15.72
ENG_0230.LAB	8/18/2022	10:36:43	0.064	6.54	190.8	0.998	14.70	0.068	15.72
ENG 0231.LAB	8/18/2022	10:37:43	0.055	6.54	190.8	1.000	14.69	0.058	15.72
ENG_0231.LAB	8/18/2022	10:37:43	0.070	6.54	190.8	1.000	14.70	0.075	15.72
ENG 0233.LAB	8/18/2022	10:39:42	0.060	6.57	190.8	0.999	14.68	0.065	15.72
ENG 0234.LAB	8/18/2022	10:40:42	0.065	6.58	190.8	0.999	14.69	0.070	15.72
ENG_0235.LAB	8/18/2022	10:41:42	0.058	6.67	190.8	0.999	14.68	0.062	15.73
ENG_0236.LAB	8/18/2022	10:41:42	0.064	6.63	190.8	1.000	14.68	0.069	15.72
ENG_0230.LAB	8/18/2022	10:42:42	0.077	6.58	190.8	0.999	14.69	0.083	15.72
ENG_0237.LAB	8/18/2022	10:44:41	0.068	6.57	190.8	0.999	14.68	0.073	15.72
ENG_0238.LAB	8/18/2022	10:45:41	0.075	6.60	190.8	1.001	14.70	0.073	15.73
ENG_0240.LAB	8/18/2022	10:45:41	0.072	6.59	190.8	1.000	14.67	0.077	15.71
ENG_0240.LAB	8/18/2022	10:47:41	0.072	6.62	190.8	1.000	14.68	0.075	15.72
ENG_0241.LAB	8/18/2022	10:47:41	0.063	6.67	190.8	0.999	14.69	0.068	15.74
ENG_0242.LAB	8/18/2022	10:49:41	0.064	6.64	190.8	0.999	14.69	0.069	15.73
ENG_0244.LAB	8/18/2022	10:50:40	0.078	6.69	190.8	0.999	14.70	0.084	15.75
ENG_0244.LAB	8/18/2022	10:51:40	0.069	6.67	190.8	1.000	14.69	0.074	15.74
ENG_0245.LAB	8/18/2022	10:51:40	0.069	6.67	190.8	0.999	14.69	0.074	15.74
ENG_0247.LAB	8/18/2022	10:53:40	0.056	6.68	190.8	0.999	14.67	0.062	15.72
ENG_0247.LAB ENG_0248.LAB	8/18/2022	10:53:40	0.064	6.68	190.8	1.001	14.67	0.069	15.75
ENG_0248.LAB	8/18/2022	10:54:40	0.058	6.65	190.8	1.001	14.70	0.069	15.73
<u>-</u>	8/18/2022		0.069	6.64	190.8	1.000	14.70	0.062	15.74
ENG_0250.LAB ENG_0251.LAB	8/18/2022	10:56:40 10:57:39	0.069	6.66	190.8	1.000	14.70	0.074	15.74
ENG_UZST.LAB	0/10/2022	10.57.39	0.070	0.00	130.8	1.000	14.09	0.075	15./3



			Formaldehyde	H2O	FTIR Gas Cell	FTIR Gas Cell	02	Formaldehyde	02
Spectrum	Date	Time	(ppmv wet)	(%v)	Temperature (°C)	Pressure (atm)	(%v wet)	(ppmv dry)	(%v dry)
ENG_0252.LAB	8/18/2022	10:58:39	0.059	6.64	190.8	0.998	14.70	0.063	15.74
ENG_0253.LAB	8/18/2022	10:59:39	0.049	6.61	190.8	1.000	14.70	0.052	15.73
ENG_0254.LAB	8/18/2022	11:00:39	0.045	6.59	190.8	1.000	14.69	0.048	15.72
ENG_0255.LAB	8/18/2022	11:01:39	0.081	6.61	190.8	1.000	14.70	0.086	15.74
TR01 - Run 1	Minin	num	0.045	6.52	190.8	0.997	14.41	0.048	15.48
8/18/2022	Maxin	num	0.096	6.93	191.1	1.001	14.70	0.103	15.75
9:40 - 9:57, 10:19 - 11:01	Aver	age	0.072	6.70	190.8	0.999	14.64	0.078	15.69

TR01 - Test Run 2

TR01 - Test Run 2			Formaldehyde	H2O	FTIR Gas Cell	FTIR Gas Cell	02	Formaldehyde	02
Spectrum	Date	Time	(ppmv wet)	(%v)	Temperature (°C)	Pressure (atm)	(%v wet)	(ppmv dry)	(%v dry)
ENG_0289.LAB	8/18/2022	11:20:04	0.056	6.71	190.8	0.996	14.65	0.060	15.70
ENG_0290.LAB	8/18/2022	11:21:04	0.064	6.69	190.8	0.997	14.66	0.069	15.71
ENG_0291.LAB	8/18/2022	11:22:04	0.064	6.69	190.8	0.996	14.66	0.069	15.72
ENG_0292.LAB	8/18/2022	11:23:04	0.070	6.69	190.8	0.996	14.67	0.075	15.72
ENG_0293.LAB	8/18/2022	11:24:04	0.050	6.74	190.8	0.998	14.66	0.054	15.72
ENG_0294.LAB	8/18/2022	11:25:03	0.060	6.70	190.8	0.997	14.66	0.064	15.71
ENG_0295.LAB	8/18/2022	11:26:03	0.081	6.62	190.8	0.998	14.69	0.087	15.73
ENG_0296.LAB	8/18/2022	11:27:03	0.065	6.65	190.8	0.997	14.67	0.069	15.72
ENG_0297.LAB	8/18/2022	11:28:03	0.052	6.65	190.8	0.996	14.68	0.056	15.73
ENG_0298.LAB	8/18/2022	11:29:03	0.067	6.68	190.8	0.997	14.66	0.072	15.71
ENG_0299.LAB	8/18/2022	11:30:03	0.051	6.65	190.8	0.998	14.70	0.054	15.74
ENG_0300.LAB	8/18/2022	11:31:02	0.070	6.66	190.8	0.998	14.67	0.075	15.72
ENG_0301.LAB	8/18/2022	11:32:02	0.083	6.58	190.8	0.997	14.69	0.088	15.72
ENG_0302.LAB	8/18/2022	11:33:02	0.068	6.62	190.9	0.997	14.69	0.072	15.73
ENG_0303.LAB	8/18/2022	11:34:02	0.074	6.61	191.0	0.997	14.67	0.080	15.71
ENG_0304.LAB	8/18/2022	11:35:02	0.059	6.63	191.0	0.997	14.69	0.064	15.73
ENG_0305.LAB	8/18/2022	11:36:02	0.053	6.53	191.0	0.998	14.70	0.057	15.72
ENG_0306.LAB	8/18/2022	11:37:01	0.079	6.50	191.0	0.998	14.70	0.085	15.73
ENG_0307.LAB	8/18/2022	11:38:01	0.069	6.55	191.0	0.999	14.70	0.073	15.73
ENG_0308.LAB	8/18/2022	11:39:01	0.067	6.47	191.0	0.999	14.70	0.072	15.72
ENG_0309.LAB	8/18/2022	11:40:01	0.059	6.54	191.0	0.998	14.70	0.064	15.73
ENG_0310.LAB	8/18/2022	11:41:01	0.068	6.59	191.0	0.999	14.69	0.073	15.72
ENG_0311.LAB	8/18/2022	11:42:00	0.059	6.55	191.0	0.999	14.70	0.063	15.73
ENG_0312.LAB	8/18/2022	11:43:00	0.056	6.51	191.0	0.998	14.70	0.060	15.73
ENG_0313.LAB	8/18/2022	11:44:00	0.057	6.54	191.0	0.998	14.70	0.060	15.73
ENG_0314.LAB	8/18/2022	11:45:00	0.066	6.58	191.0	0.998	14.69	0.071	15.72
ENG_0315.LAB	8/18/2022	11:46:00	0.073	6.54	191.1	0.999	14.70	0.078	15.72
ENG_0316.LAB	8/18/2022	11:47:00	0.060	6.46	191.1	0.999	14.70	0.064	15.72
ENG_0317.LAB	8/18/2022	11:47:59	0.073	6.51	191.0	1.000	14.68	0.078	15.70
ENG_0318.LAB	8/18/2022	11:48:59	0.081	6.58	191.1	0.999	14.69	0.087	15.72
ENG_0319.LAB	8/18/2022	11:49:59	0.061	6.55	191.1	1.000	14.69	0.066	15.72
ENG_0320.LAB	8/18/2022	11:50:59	0.055	6.58	191.1	0.998	14.68	0.059	15.71
ENG_0321.LAB	8/18/2022	11:51:59	0.069	6.52	191.1	0.998	14.70	0.074	15.73
ENG_0322.LAB	8/18/2022	11:52:59	0.066	6.48	191.1	0.999	14.71	0.070	15.73
ENG_0323.LAB	8/18/2022	11:53:58	0.062	6.51	191.1	0.999	14.69	0.066	15.71
ENG_0324.LAB	8/18/2022	11:55:13	0.064	6.58	191.1	0.999	14.70	0.069	15.73
ENG_0325.LAB	8/18/2022	11:56:15	0.068	6.52	191.1	0.998	14.70	0.073	15.73
ENG_0326.LAB	8/18/2022	11:57:15	0.062	6.64	191.1	0.998	14.70	0.067	15.74
ENG_0327.LAB	8/18/2022	11:58:42	0.074	6.56	191.1	0.998	14.70	0.079	15.74
ENG_0328.LAB	8/18/2022	11:59:42	0.066	6.58	191.1	0.999	14.70	0.071	15.74
ENG_0329.LAB	8/18/2022	12:00:42	0.076	6.56	191.0	0.999	14.70	0.082	15.73
ENG_0330.LAB	8/18/2022	12:01:42	0.060	6.60	191.0	0.999	14.71	0.064	15.75
ENG_0331.LAB	8/18/2022	12:02:43	0.073	6.56	191.0	0.999	14.70	0.078	15.73
ENG_0332.LAB	8/18/2022	12:03:43	0.057	6.53	191.0	0.999	14.70	0.061	15.72
ENG_0333.LAB	8/18/2022	12:04:42	0.048	6.57	191.0	0.999	14.71	0.052	15.74
ENG_0334.LAB	8/18/2022	12:05:42	0.047	6.53	191.0	0.998	14.68	0.050	15.70
ENG_0335.LAB	8/18/2022	12:06:42	0.046	6.53	191.1	0.999	14.69	0.050	15.71
ENG_0336.LAB	8/18/2022	12:07:42	0.057	6.45	191.0	0.999	14.71	0.061	15.73
ENG_0337.LAB	8/18/2022	12:08:42	0.058	6.46	191.1	0.998	14.70	0.062	15.72
ENG_0338.LAB	8/18/2022	12:09:42	0.048	6.43	191.0	0.999	14.70	0.052	15.70
ENG_0339.LAB	8/18/2022	12:10:42	0.065	6.48	191.0	0.998	14.72	0.069	15.74
ENG_0340.LAB	8/18/2022	12:11:42	0.075	6.42	191.0	0.997	14.71	0.080	15.72



			Formaldehyde	H2O	FTIR Gas Cell	FTIR Gas Cell	02	Formaldehyde	02
Spectrum	Date	Time	(ppmv wet)	(%v)	Temperature (°C)	Pressure (atm)	(%v wet)	(ppmv dry)	(%v dry)
ENG_0341.LAB	8/18/2022	12:12:41	0.060	6.45	191.0	1.000	14.70	0.064	15.71
ENG_0342.LAB	8/18/2022	12:13:41	0.067	6.52	191.0	0.999	14.73	0.072	15.75
ENG_0343.LAB	8/18/2022	12:14:41	0.057	6.48	191.0	0.999	14.73	0.061	15.75
ENG_0344.LAB	8/18/2022	12:15:41	0.065	6.50	191.0	0.999	14.70	0.070	15.72
ENG_0345.LAB	8/18/2022	12:16:41	0.061	6.50	191.0	0.997	14.70	0.065	15.72
ENG_0346.LAB	8/18/2022	12:17:41	0.069	6.41	191.0	0.999	14.72	0.074	15.73
ENG_0347.LAB	8/18/2022	12:18:40	0.077	6.45	191.1	0.999	14.73	0.082	15.75
ENG_0348.LAB	8/18/2022	12:19:40	0.073	6.48	191.1	0.999	14.72	0.078	15.74
ENG_0349.LAB	8/18/2022	12:20:41	0.064	6.45	191.1	0.999	14.71	0.069	15.73
TR01 - Run 2	Minin	num	0.046	6.41	190.8	0.996	14.65	0.050	15.70
8/18/2022	Maxin	num	0.083	6.74	191.1	1.000	14.73	0.088	15.75
11:20 - 12:20	Avera	age	0.064	6.56	191.0	0.998	14.69	0.069	15.72

TR01 - Test Run 3

			Formaldehyde	H2O	FTIR Gas Cell	FTIR Gas Cell	02	Formaldehyde	02
Spectrum	Date	Time	(ppmv wet)	(%v)	Temperature (°C)	Pressure (atm)	(%v wet)	(ppmv dry)	(%v dry)
ENG_0383.LAB	8/18/2022	12:35:27	0.064	6.42	191.0	0.994	14.73	0.068	15.74
ENG_0384.LAB	8/18/2022	12:36:26	0.059	6.37	191.0	0.996	14.73	0.063	15.73
ENG_0385.LAB	8/18/2022	12:37:26	0.059	6.38	191.0	0.995	14.75	0.063	15.76
ENG_0386.LAB	8/18/2022	12:38:26	0.066	6.38	191.0	0.996	14.73	0.071	15.73
ENG_0387.LAB	8/18/2022	12:39:26	0.064	6.45	191.0	0.995	14.73	0.069	15.74
ENG_0388.LAB	8/18/2022	12:40:26	0.064	6.42	191.0	0.995	14.73	0.068	15.74
ENG_0389.LAB	8/18/2022	12:41:25	0.065	6.42	191.0	0.995	14.73	0.069	15.74
ENG_0390.LAB	8/18/2022	12:42:25	0.043	6.40	191.0	0.995	14.73	0.046	15.74
ENG_0391.LAB	8/18/2022	12:43:25	0.063	6.42	191.0	0.997	14.72	0.067	15.73
ENG_0392.LAB	8/18/2022	12:44:25	0.061	6.46	191.0	0.995	14.72	0.065	15.73
ENG_0393.LAB	8/18/2022	12:45:25	0.066	6.41	191.0	0.996	14.73	0.071	15.74
ENG_0394.LAB	8/18/2022	12:46:25	0.055	6.39	191.0	0.996	14.73	0.058	15.73
ENG_0395.LAB	8/18/2022	12:47:24	0.068	6.35	191.0	0.996	14.74	0.072	15.74
ENG 0396.LAB	8/18/2022	12:48:24	0.059	6.41	191.0	0.997	14.71	0.063	15.72
ENG_0397.LAB	8/18/2022	12:49:24	0.041	6.43	191.0	0.997	14.73	0.043	15.74
ENG_0398.LAB	8/18/2022	12:50:24	0.065	6.43	191.0	0.997	14.72	0.069	15.73
ENG_0399.LAB	8/18/2022	12:51:24	0.051	6.43	191.0	0.997	14.71	0.055	15.72
ENG_0400.LAB	8/18/2022	12:52:24	0.069	6.43	191.0	0.997	14.72	0.074	15.73
ENG 0401.LAB	8/18/2022	12:53:23	0.065	6.39	191.0	0.998	14.73	0.070	15.74
ENG 0402.LAB	8/18/2022	12:54:23	0.058	6.45	191.0	0.996	14.71	0.062	15.72
ENG 0403.LAB	8/18/2022	12:55:23	0.064	6.44	191.0	0.997	14.74	0.069	15.75
ENG 0404.LAB	8/18/2022	12:56:23	0.072	6.38	191.0	0.997	14.72	0.077	15.72
ENG_0405.LAB	8/18/2022	12:57:23	0.070	6.39	191.0	0.996	14.73	0.075	15.74
ENG 0406.LAB	8/18/2022	12:58:23	0.054	6.43	191.0	0.998	14.73	0.057	15.75
ENG 0407.LAB	8/18/2022	12:59:22	0.056	6.44	191.0	0.997	14.73	0.060	15.75
ENG 0408.LAB	8/18/2022	13:00:22	0.058	6.40	191.0	0.996	14.73	0.062	15.74
ENG 0409.LAB	8/18/2022	13:01:22	0.052	6.42	191.0	0.997	14.73	0.055	15.74
ENG 0410.LAB	8/18/2022	13:02:22	0.069	6.38	191.0	0.998	14.74	0.074	15.75
ENG 0411.LAB	8/18/2022	13:03:22	0.061	6.37	191.0	0.997	14.73	0.065	15.74
ENG 0412.LAB	8/18/2022	13:04:21	0.042	6.40	191.0	0.999	14.72	0.045	15.72
ENG 0413.LAB	8/18/2022	13:05:21	0.053	6.43	191.0	0.997	14.73	0.056	15.75
ENG 0414.LAB	8/18/2022	13:06:21	0.057	6.42	191.0	0.998	14.71	0.061	15.72
ENG 0415.LAB	8/18/2022	13:07:21	0.061	6.38	191.0	0.998	14.74	0.065	15.75
ENG 0416.LAB	8/18/2022	13:08:21	0.069	6.38	191.0	0.998	14.73	0.073	15.74
ENG 0417.LAB	8/18/2022	13:09:21	0.071	6.32	191.0	0.998	14.75	0.076	15.75
ENG 0418.LAB	8/18/2022	13:10:20	0.073	6.39	191.0	0.998	14.73	0.078	15.74
ENG 0419.LAB	8/18/2022	13:11:20	0.054	6.35	191.0	0.999	14.75	0.058	15.75
ENG 0420.LAB	8/18/2022	13:12:20	0.065	6.38	191.0	0.998	14.73	0.070	15.74
ENG 0421.LAB	8/18/2022	13:13:20	0.070	6.39	191.0	0.998	14.75	0.075	15.76
ENG 0422.LAB	8/18/2022	13:14:20	0.068	6.43	191.0	0.999	14.73	0.073	15.74
ENG 0423.LAB	8/18/2022	13:15:20	0.073	6.46	191.0	0.998	14.75	0.078	15.77



allytical reciliologies			Formaldehyde	H2O	FTIR Gas Cell	FTIR Gas Cell	02	Formaldehyde	02
Spectrum	Date	Time	(ppmv wet)	(%v)	Temperature (°C)	Pressure (atm)	(%v wet)	(ppmv dry)	(%v dry)
ENG_0424.LAB	8/18/2022	13:16:19	0.055	6.38	191.0	0.999	14.74	0.059	15.74
ENG_0425.LAB	8/18/2022	13:17:19	0.062	6.35	191.0	0.998	14.74	0.066	15.74
ENG_0426.LAB	8/18/2022	13:18:19	0.044	6.37	190.9	0.997	14.75	0.047	15.75
ENG_0427.LAB	8/18/2022	13:19:19	0.060	6.40	191.0	0.999	14.74	0.064	15.75
ENG_0428.LAB	8/18/2022	13:20:19	0.054	6.37	191.0	0.998	14.74	0.058	15.74
ENG_0429.LAB	8/18/2022	13:21:18	0.059	6.36	191.0	0.998	14.76	0.063	15.76
ENG_0430.LAB	8/18/2022	13:22:18	0.054	6.34	190.9	0.999	14.75	0.058	15.75
ENG_0431.LAB	8/18/2022	13:23:18	0.077	6.28	190.9	0.999	14.76	0.082	15.75
ENG_0432.LAB	8/18/2022	13:24:18	0.078	6.30	191.0	0.998	14.74	0.083	15.73
ENG_0433.LAB	8/18/2022	13:25:18	0.055	6.31	191.0	0.998	14.73	0.059	15.72
ENG_0434.LAB	8/18/2022	13:26:17	0.044	6.39	191.0	0.998	14.73	0.047	15.74
ENG_0435.LAB	8/18/2022	13:27:17	0.050	6.34	191.0	0.998	14.73	0.054	15.72
ENG_0436.LAB	8/18/2022	13:28:17	0.060	6.36	191.0	0.997	14.74	0.064	15.74
ENG_0437.LAB	8/18/2022	13:29:17	0.064	6.33	191.0	0.998	14.76	0.068	15.75
ENG_0438.LAB	8/18/2022	13:30:17	0.059	6.33	190.9	0.998	14.75	0.063	15.75
ENG_0439.LAB	8/18/2022	13:31:17	0.060	6.35	190.9	0.998	14.71	0.064	15.71
ENG_0440.LAB	8/18/2022	13:32:16	0.069	6.36	190.9	0.998	14.70	0.074	15.70
ENG_0441.LAB	8/18/2022	13:33:16	0.063	6.38	191.0	0.999	14.72	0.067	15.72
ENG_0442.LAB	8/18/2022	13:34:16	0.059	6.35	191.0	0.998	14.73	0.063	15.73
ENG_0443.LAB	8/18/2022	13:35:16	0.062	6.31	190.99	0.999	14.72	0.066	15.71
TR01 - Run 3	Minin	num	0.041	6.28	190.9	0.994	14.70	0.043	15.70
8/18/2022	Maxin	num	0.078	6.46	191.0	0.999	14.76	0.083	15.77
12:35 - 13:35	Avera	age	0.061	6.39	191.0	0.997	14.73	0.065	15.74

APPENDIX FTIR & O2 QA/QC Data



Nitrogen (Zero) Direct Purge to FTIR

			Methane	Formaldehyde	H2O	Nitrous Oxide	02
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)
N2_DIR_0015.LAB	8/18/2022	8:11:20	0.07	0.032	0.00	0.69	0.05
N2_DIR_0016.LAB	8/18/2022	8:11:35	-0.33	-0.005	-0.01	0.03	0.04
N2_DIR_0017.LAB	8/18/2022	8:11:50	0.07	-0.004	-0.04	0.27	0.05
N2_DIR_0018.LAB	8/18/2022	8:12:05	0.06	0.006	-0.02	0.22	0.04
N2_DIR_0019.LAB	8/18/2022	8:12:20	-0.26	0.010	-0.02	-0.08	0.04
N2_DIR_0020.LAB	8/18/2022	8:12:35	-0.30	0.013	-0.02	0.60	0.04
N2_DIR_0021.LAB	8/18/2022	8:12:50	-0.18	0.030	-0.04	0.20	0.05
N2_DIR_0022.LAB	8/18/2022	8:13:05	-0.54	0.027	-0.02	0.03	0.04
Average					_		0.04

CTS, 100.2 ppm Methane Direct Purge

_			Methane	Formaldehyde	H2O	Nitrous Oxide	02	Methane
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %
CTS_DIR_0023.LAB	8/18/2022	8:14:15	101.57	-0.076	0.54	-1.78	0.05	101.4%
CTS_DIR_0024.LAB	8/18/2022	8:14:30	102.04	-0.074	0.57	-1.40	-2.98	101.8%
CTS_DIR_0025.LAB	8/18/2022	8:14:45	101.79	-0.086	0.53	-2.01	-2.98	101.6%
CTS_DIR_0026.LAB	8/18/2022	8:15:00	102.30	-0.079	0.55	-1.76	-2.98	102.1%
CTS_DIR_0027.LAB	8/18/2022	8:15:15	101.82	-0.088	0.56	-1.85	-2.98	101.6%
CTS_DIR_0028.LAB	8/18/2022	8:15:30	101.02	-0.100	0.53	-1.59	-2.98	100.8%
CTS_DIR_0029.LAB	8/18/2022	8:15:45	101.75	-0.096	0.55	-2.06	-2.98	101.5%
CTS_DIR_0030.LAB	8/18/2022	8:16:00	102.23	-0.103	0.56	-2.16	-2.98	102.0%
Average			101.82			_		_

21.8% O2 Direct Purge

			Methane	Formaldehyde	H2O	Nitrous Oxide	02	O2
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %
O2HIGH_DIR_0091.LAB	8/18/2022	8:34:48	0.23	0.040	-0.03	0.42	21.75	99.8%
O2HIGH_DIR_0092.LAB	8/18/2022	8:35:03	0.14	0.005	-0.04	0.30	21.75	99.8%
O2HIGH_DIR_0093.LAB	8/18/2022	8:35:18	-0.17	0.016	0.00	0.70	21.75	99.8%
O2HIGH_DIR_0094.LAB	8/18/2022	8:35:33	-0.37	0.002	-0.03	0.27	21.75	99.7%
O2HIGH_DIR_0095.LAB	8/18/2022	8:35:48	-0.44	0.011	0.00	0.44	21.74	99.7%
O2HIGH_DIR_0096.LAB	8/18/2022	8:36:03	0.21	0.032	0.00	0.40	21.74	99.7%
O2HIGH_DIR_0097.LAB	8/18/2022	8:36:18	-0.20	0.009	0.02	0.26	21.73	99.7%
O2HIGH_DIR_0098.LAB	8/18/2022	8:36:33	-0.34	0.037	0.00	-0.06	21.73	99.7%
Average				<u> </u>			21.74	

11.8% O2 Direct Purge

<u> </u>			Methane	Formaldehyde	H2O	Nitrous Oxide	02	02
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %
O2MID_DIR_0100.LAB	8/18/2022	8:39:08	0.02	0.022	-0.01	0.20	11.87	100.6%
O2MID_DIR_0101.LAB	8/18/2022	8:39:23	0.00	0.016	0.01	0.21	11.87	100.6%
O2MID_DIR_0102.LAB	8/18/2022	8:39:38	0.28	0.029	0.00	0.26	11.87	100.6%
O2MID_DIR_0103.LAB	8/18/2022	8:39:53	-0.21	0.023	0.03	0.08	11.87	100.6%
O2MID_DIR_0104.LAB	8/18/2022	8:40:08	-0.07	0.009	-0.01	0.04	11.86	100.5%
O2MID_DIR_0105.LAB	8/18/2022	8:40:23	-0.11	0.017	0.01	0.83	11.86	100.5%
O2MID_DIR_0106.LAB	8/18/2022	8:40:38	-0.60	0.004	-0.03	0.32	11.86	100.5%
O2MID_DIR_0107.LAB	8/18/2022	8:40:52	0.66	0.011	0.03	-0.15	11.86	100.5%
Average							11.87	

PROJ-020063 Confidential Proprietary @MAQS 046



0.598 ppm Formaldehyde / 250.1 ppm N2O Direct Purge

			Methane	Formaldehyde	H2O	Nitrous Oxide	02
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)
HCHO_DIR_0067.LAB	8/18/2022	8:25:47	-0.59	0.630	-0.05	240.73	0.06
HCHO_DIR_0068.LAB	8/18/2022	8:26:02	0.06	0.581	-0.05	240.19	0.06
HCHO_DIR_0069.LAB	8/18/2022	8:26:17	-0.19	0.591	-0.08	240.18	0.06
HCHO_DIR_0070.LAB	8/18/2022	8:26:32	-0.59	0.600	-0.05	239.96	0.06
HCHO_DIR_0071.LAB	8/18/2022	8:26:47	-0.23	0.624	-0.04	240.48	0.06
HCHO_DIR_0072.LAB	8/18/2022	8:27:02	-0.25	0.636	-0.09	241.15	0.06
HCHO_DIR_0073.LAB	8/18/2022	8:27:17	0.26	0.608	-0.03	239.84	0.06
HCHO_DIR_0074.LAB	8/18/2022	8:27:32	-0.12	0.598	-0.07	240.41	0.06
Average				0.608		240.37	0.06

100.2 ppm Methane System Purge and Response Time Test

			Methane	Formaldehyde	H2O	Nitrous Oxide	02	Methane	Response
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %	Time (sec)
ENG_CTS_RT_0108.LAB	8/18/2022	8:55:16	-0.54	0.189	6.83	-1.72	14.89	-0.5%	-
ENG_CTS_RT_0109.LAB	8/18/2022	8:55:31	50.79	0.000	3.43	-2.24	0.18	49.9%	15
ENG_CTS_RT_0110.LAB	8/18/2022	8:55:46	101.76	-0.053	0.33	-1.50	0.09	99.9%	30
ENG_CTS_RT_0111.LAB	8/18/2022	8:56:01	102.13	-0.104	0.31	-1.47	0.08	100.3%	
ENG_CTS_RT_0112.LAB	8/18/2022	8:56:16	101.82	-0.097	0.34	-1.51	0.07	100.0%	
ENG_CTS_RT_0113.LAB	8/18/2022	8:56:31	102.44	-0.091	0.36	-1.87	0.07	100.6%	
ENG_CTS_RT_0114.LAB	8/18/2022	8:56:46	102.68	-0.070	0.38	-1.83	0.07	100.8%	
ENG_CTS_RT_0115.LAB	8/18/2022	8:57:01	102.60	-0.077	0.38	-1.88	0.06	100.8%	
ENG_CTS_RT_0116.LAB	8/18/2022	8:57:16	102.39	-0.091	0.36	-2.01	0.06	100.6%	
ENG_CTS_RT_0117.LAB	8/18/2022	8:57:31	101.87	-0.065	0.32	-1.37	0.06	100.1%	
Average			102.28			-			

11.8% O2 System Purge and Response Time Test

11.0% OZ System i urge una respons			Methane	Formaldehyde	H2O	Nitrous Oxide	02	02	Response
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %	Time (sec)
ENG_O2MID_RT_0119.LAB	8/18/2022	8:58:24	101.88	-0.077	0.26	-1.06	0.05	0.4%	-
ENG_O2MID_RT_0120.LAB	8/18/2022	8:58:38	54.49	0.046	1.16	-1.72	10.81	91.1%	15
ENG_O2MID_RT_0121.LAB	8/18/2022	8:58:54	0.25	0.033	0.05	0.23	11.73	98.8%	30
ENG_O2MID_RT_0122.LAB	8/18/2022	8:59:09	0.27	-0.007	0.00	0.51	11.73	98.8%	
ENG_O2MID_RT_0123.LAB	8/18/2022	8:59:24	-0.01	0.035	0.04	-0.35	11.74	98.9%	
ENG_O2MID_RT_0124.LAB	8/18/2022	8:59:39	-0.35	0.031	0.00	0.25	11.74	98.9%	
ENG_O2MID_RT_0125.LAB	8/18/2022	8:59:54	0.13	0.037	-0.04	0.64	11.73	98.8%	
ENG_O2MID_RT_0126.LAB	8/18/2022	9:00:08	-0.20	0.014	0.02	0.07	11.74	98.9%	
ENG_O2MID_RT_0127.LAB	8/18/2022	9:00:23	-0.44	0.003	-0.01	0.89	11.74	98.9%	
ENG_O2MID_RT_0128.LAB	8/18/2022	9:00:38	-0.21	0.055	0.02	0.62	11.74	98.9%	
Average							11.73		

N2 System Purge and Response Time Test

142 System runge and Response Time 1									
			Methane	Formaldehyde	H2O	Nitrous Oxide	02	02	Response
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %	Time (sec)
ENG_N2_RT_0129.LAB	8/18/2022	9:01:15	-0.57	0.050	0.02	0.67	11.74	98.9%	-
ENG_N2_RT_0130.LAB	8/18/2022	9:01:30	0.01	0.048	0.55	-0.80	0.55	0.1%	15
ENG_N2_RT_0131.LAB	8/18/2022	9:01:45	0.07	0.030	0.02	0.03	0.10	0.6%	
ENG_N2_RT_0132.LAB	8/18/2022	9:02:00	-0.26	0.036	-0.01	1.02	0.09	-2.2%	
ENG_N2_RT_0133.LAB	8/18/2022	9:02:15	-0.27	0.025	-0.02	0.38	0.09	-2.3%	
ENG_N2_RT_0134.LAB	8/18/2022	9:02:30	-0.13	0.023	0.00	0.69	0.08	-1.1%	
ENG_N2_RT_0135.LAB	8/18/2022	9:02:45	-0.07	0.042	-0.01	0.06	0.08	-0.6%	
ENG_N2_RT_0136.LAB	8/18/2022	9:03:00	-0.38	0.021	0.02	0.65	0.08	-3.2%	
ENG_N2_RT_0137.LAB	8/18/2022	9:03:15	0.17	0.001	0.01	0.45	0.08	1.4%	
Average						<u> </u>	0.08	_	

PROJ-020063 Confidential Proprietary @MAQS 046



TR01 Prior to Analyte Spike

			Methane	Formaldehyde	H2O	Nitrous Oxide	02
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)
ENG_0141.LAB	8/18/2022	9:06:35	0.00	0.078	6.70	-2.38	14.83
ENG_0142.LAB	8/18/2022	9:07:35	-0.05	0.073	6.71	-2.37	14.81
ENG_0143.LAB	8/18/2022	9:08:35	0.05	0.083	6.69	-2.08	14.80
Average			_	0.078		-2.28	

TR01 Analyte Spike Using 0.598 ppm Formaldehyde / 250.1 ppm N2O

,,,,,,,			Methane	Formaldehyde	H2O	Nitrous Oxide	02	Dilution	Formaldehyde
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Factor	Recovery %
ENG_SPK_0152.LAB	8/18/2022	9:13:45	0.10	0.100	6.14	17.38	13.55	0.082	82.4%
ENG_SPK_0153.LAB	8/18/2022	9:14:00	-0.18	0.128	6.10	17.21	13.60	0.081	105.4%
ENG_SPK_0154.LAB	8/18/2022	9:14:15	0.61	0.106	6.18	17.21	13.57	0.081	87.3%
ENG_SPK_0155.LAB	8/18/2022	9:14:30	0.11	0.121	6.13	17.38	13.60	0.082	99.2%
ENG_SPK_0156.LAB	8/18/2022	9:14:45	-0.24	0.125	6.16	17.29	13.60	0.081	102.9%
ENG_SPK_0157.LAB	8/18/2022	9:15:00	0.03	0.132	6.18	17.77	13.60	0.083	107.7%
ENG_SPK_0158.LAB	8/18/2022	9:15:15	0.75	0.102	6.16	17.21	13.61	0.081	84.6%
ENG_SPK_0159.LAB	8/18/2022	9:15:30	0.30	0.141	6.15	17.28	13.59	0.081	116.5%
Average		_		0.119		17.34		0.08	98.2%

100.2 ppm Methane System Purge

			Methane	Formaldehyde	H2O	Nitrous Oxide	02	Methane
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %
ENG_CTS_SYS_0260.LAB	8/18/2022	11:06:47	100.01	-0.071	0.30	-1.65	0.08	98.2%
ENG_CTS_SYS_0261.LAB	8/18/2022	11:07:02	99.68	-0.079	0.32	-1.77	0.07	97.9%
ENG_CTS_SYS_0262.LAB	8/18/2022	11:07:17	99.90	-0.089	0.31	-1.41	0.07	98.1%
ENG_CTS_SYS_0263.LAB	8/18/2022	11:07:32	100.53	-0.114	0.34	-1.73	0.06	98.7%
ENG_CTS_SYS_0264.LAB	8/18/2022	11:07:47	100.41	-0.110	0.31	-1.64	0.05	98.6%
ENG_CTS_SYS_0265.LAB	8/18/2022	11:08:02	100.22	-0.094	0.30	-1.73	0.03	98.4%
ENG_CTS_SYS_0266.LAB	8/18/2022	11:08:17	100.35	-0.123	0.34	-1.80	0.03	98.6%
ENG_CTS_SYS_0267.LAB	8/18/2022	11:08:32	100.47	-0.083	0.35	-1.77	0.03	98.7%

11.8% O2 System Purge

11.6% OZ System Purge								
			Methane	Formaldehyde	H2O	Nitrous Oxide	O2	02
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %
ENG_O2_SYS_0268.LAB	8/18/2022	11:09:34	0.36	0.056	0.02	0.03	11.65	98.2%
ENG_O2_SYS_0269.LAB	8/18/2022	11:09:49	0.40	0.016	0.04	0.37	11.65	98.2%
ENG_O2_SYS_0270.LAB	8/18/2022	11:10:04	0.38	0.030	0.03	0.88	11.65	98.2%
ENG_O2_SYS_0271.LAB	8/18/2022	11:10:19	0.08	0.022	0.00	0.11	11.66	98.3%
ENG_O2_SYS_0272.LAB	8/18/2022	11:10:34	0.19	0.031	0.00	0.46	11.66	98.3%
ENG_O2_SYS_0273.LAB	8/18/2022	11:10:49	-0.15	0.029	-0.01	0.69	11.66	98.3%
ENG_O2_SYS_0274.LAB	8/18/2022	11:11:04	0.64	0.035	-0.05	0.24	11.66	98.3%
ENG_O2_SYS_0275.LAB	8/18/2022	11:11:19	0.69	-0.007	0.00	0.79	11.66	98.3%
Average			-	<u> </u>		-	11.66	

N2 System Purge

			Methane	Formaldehyde	H2O	Nitrous Oxide	02
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)
ENG_N2_SYS_0276.LAB	8/18/2022	11:12:22	-0.43	0.026	0.02	0.42	0.10
ENG_N2_SYS_0277.LAB	8/18/2022	11:12:37	-0.28	0.040	-0.01	-0.05	0.09
ENG_N2_SYS_0278.LAB	8/18/2022	11:12:53	-0.60	0.023	0.03	0.24	0.09
ENG_N2_SYS_0279.LAB	8/18/2022	11:13:07	-0.03	0.020	0.01	0.59	0.08
ENG_N2_SYS_0280.LAB	8/18/2022	11:13:22	-0.19	0.008	0.06	-0.35	0.08
ENG_N2_SYS_0281.LAB	8/18/2022	11:13:37	-0.03	-0.010	-0.02	-0.27	0.08
ENG_N2_SYS_0282.LAB	8/18/2022	11:13:52	0.28	0.029	0.01	0.80	0.08
ENG_N2_SYS_0283.LAB	8/18/2022	11:14:07	0.08	0.004	0.02	0.45	0.08
Average							0.09



100.2 ppm Methane System Purge

			Methane	Formaldehyde	H2O	Nitrous Oxide	02	Methane
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %
ENG_CTS_SYS_0350.LAB	8/18/2022	12:22:32	99.48	-0.079	0.38	-1.66	0.08	97.7%
ENG_CTS_SYS_0351.LAB	8/18/2022	12:22:47	99.16	-0.082	0.36	-2.16	0.07	97.4%
ENG_CTS_SYS_0352.LAB	8/18/2022	12:23:02	99.50	-0.074	0.34	-1.46	0.06	97.7%
ENG_CTS_SYS_0353.LAB	8/18/2022	12:23:17	99.06	-0.079	0.39	-2.13	0.06	97.3%
ENG_CTS_SYS_0354.LAB	8/18/2022	12:23:32	99.28	-0.075	0.40	-2.17	0.04	97.5%
ENG_CTS_SYS_0355.LAB	8/18/2022	12:23:47	100.48	-0.099	0.38	-1.92	0.03	98.7%
ENG_CTS_SYS_0356.LAB	8/18/2022	12:24:02	99.41	-0.106	0.38	-1.74	0.03	97.6%
ENG_CTS_SYS_0357.LAB	8/18/2022	12:24:16	99.56	-0.087	0.34	-1.69	0.03	97.8%

11.8% O2 System Purge

			Methane	Formaldehyde	H2O	Nitrous Oxide	02	O2
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %
ENG_O2MID_SYS_0364.LAB	8/18/2022	12:27:05	0.27	0.032	-0.01	0.33	11.65	98.2%
ENG_O2MID_SYS_0365.LAB	8/18/2022	12:27:20	0.35	0.035	0.02	0.25	11.65	98.2%
ENG_O2MID_SYS_0366.LAB	8/18/2022	12:27:35	0.21	0.028	-0.01	0.47	11.66	98.3%
ENG_O2MID_SYS_0367.LAB	8/18/2022	12:27:50	0.51	0.026	0.01	0.36	11.65	98.2%
ENG_O2MID_SYS_0368.LAB	8/18/2022	12:28:05	0.19	-0.020	0.00	0.62	11.66	98.3%
ENG_O2MID_SYS_0369.LAB	8/18/2022	12:28:20	0.51	0.040	-0.03	0.84	11.66	98.3%
ENG_O2MID_SYS_0370.LAB	8/18/2022	12:28:35	0.45	-0.011	-0.04	0.59	11.66	98.3%
ENG_O2MID_SYS_0371.LAB	8/18/2022	12:28:50	-0.27	0.028	-0.04	0.54	11.66	98.3%
Average						-	11.66	

N2 System Purge

			Methane	Formaldehyde	H2O	Nitrous Oxide	02
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)
ENG_N2_SYS_0372.LAB	8/18/2022	12:29:42	-0.01	0.028	0.06	0.43	0.10
ENG_N2_SYS_0373.LAB	8/18/2022	12:29:57	-0.60	0.013	0.05	-0.31	0.09
ENG_N2_SYS_0374.LAB	8/18/2022	12:30:11	-0.51	0.037	0.00	-0.31	0.08
ENG_N2_SYS_0375.LAB	8/18/2022	12:30:26	-0.23	0.029	0.02	0.03	0.08
ENG_N2_SYS_0376.LAB	8/18/2022	12:30:41	-0.51	0.011	0.06	-0.24	0.08
ENG_N2_SYS_0377.LAB	8/18/2022	12:30:56	-0.50	0.014	0.04	0.11	0.07
ENG_N2_SYS_0378.LAB	8/18/2022	12:31:11	-0.20	0.024	0.00	0.17	0.07
ENG_N2_SYS_0379.LAB	8/18/2022	12:31:26	0.31	0.025	0.07	0.17	0.07
Average				·			0.08

100.2 ppm Methane System Purge

			Methane	Formaldehyde	H2O	Nitrous Oxide	02	Methane
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %
ENG_CTS_SYS_0458.LAB	8/18/2022	13:42:48	99.32	-0.093	0.36	-1.35	0.08	97.5%
ENG_CTS_SYS_0459.LAB	8/18/2022	13:43:03	99.32	-0.103	0.41	-1.73	0.07	97.5%
ENG_CTS_SYS_0460.LAB	8/18/2022	13:43:18	99.85	-0.117	0.35	-1.77	0.06	98.1%
ENG_CTS_SYS_0461.LAB	8/18/2022	13:43:33	100.40	-0.101	0.35	-2.05	0.05	98.6%
ENG_CTS_SYS_0462.LAB	8/18/2022	13:43:48	100.33	-0.072	0.36	-1.83	0.04	98.5%
ENG_CTS_SYS_0463.LAB	8/18/2022	13:44:03	100.43	-0.121	0.42	-2.09	0.03	98.6%
ENG_CTS_SYS_0464.LAB	8/18/2022	13:44:18	101.02	-0.063	0.41	-1.79	0.03	99.2%
ENG_CTS_SYS_0465.LAB	8/18/2022	13:44:33	101.35	-0.093	0.38	-1.53	0.02	99.5%

11.8% O2 System Purge

			Methane	Formaldehyde	H2O	Nitrous Oxide	02	02
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)	Recovery %
ENG_O2_SYS_0467.LAB	8/18/2022	13:46:00	-0.43	0.015	-0.01	0.06	11.63	98.0%
ENG_O2_SYS_0468.LAB	8/18/2022	13:46:15	-0.17	0.006	0.03	-0.25	11.64	98.1%
ENG_O2_SYS_0469.LAB	8/18/2022	13:46:30	-0.23	0.026	-0.01	0.17	11.64	98.1%
ENG_O2_SYS_0470.LAB	8/18/2022	13:46:45	-0.62	0.011	0.02	-0.23	11.64	98.1%
ENG_O2_SYS_0471.LAB	8/18/2022	13:47:00	0.59	-0.002	0.01	0.51	11.64	98.1%
ENG_O2_SYS_0472.LAB	8/18/2022	13:47:15	0.01	0.011	-0.04	0.34	11.64	98.1%
ENG_O2_SYS_0473.LAB	8/18/2022	13:47:30	-0.06	0.018	0.05	-0.15	11.64	98.1%
ENG_O2_SYS_0474.LAB	8/18/2022	13:47:45	-0.25	0.015	0.00	0.11	11.64	98.1%
Average						_	11.64	



N2 System Purge

			Methane	Formaldehyde	H2O	Nitrous Oxide	02
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)
ENG_N2_SYS_0478.LAB	8/18/2022	13:50:58	0.06	0.020	0.03	0.47	0.10
ENG_N2_SYS_0479.LAB	8/18/2022	13:51:12	-0.07	0.045	0.00	0.05	0.09
ENG_N2_SYS_0480.LAB	8/18/2022	13:51:27	0.02	0.021	0.05	0.39	0.08
ENG_N2_SYS_0481.LAB	8/18/2022	13:51:42	-0.06	0.033	-0.01	-0.01	0.08
ENG_N2_SYS_0482.LAB	8/18/2022	13:51:57	0.20	0.026	0.02	-0.35	0.08
ENG_N2_SYS_0483.LAB	8/18/2022	13:52:12	-0.39	0.048	0.01	0.17	0.07
ENG_N2_SYS_0484.LAB	8/18/2022	13:52:27	-0.92	0.043	0.02	0.40	0.07
ENG_N2_SYS_0485.LAB	8/18/2022	13:52:42	0.26	0.015	0.04	0.20	0.07
Average							0.08

Nitrogen (Zero) Direct Purge to FTIR

			Methane	Formaldehyde	H2O	Nitrous Oxide	02
Spectrum	Date	Time	(ppmv wet)	(ppmv wet)	(%v)	(ppmv wet)	(%v wet)
N2_DIR_0487.LAB	8/18/2022	13:57:09	-0.10	0.025	0.02	0.20	0.05
N2_DIR_0488.LAB	8/18/2022	13:59:09	-0.16	0.014	0.01	-0.03	0.05
N2_DIR_0489.LAB	8/18/2022	14:02:14	0.05	0.022	0.01	0.24	0.05



ANR Pipeline Co, LaGrange, IN EPA Method 3A Data

8/18/2022	Gas	Cylinder ID	Concentration	Value	Initial Response	Error	OK?
		UHPN2	Low	0.00	0.04	0.2%	Υ
	O ₂	CC175513	Bias	11.80	11.87	0.3%	Υ
		SG9167337BAL	Span	21.80	21.74	0.3%	Υ
1						≤2%	

System Bias Checks

Run #	Concentration	Certified Value	Analyzer Response	Bias	Drift
Pre Test	Low	0.00	0.08	0.4%	n/a
	Bias	11.80	11.73	-0.3%	n/a
Run 1	Low	0.00	0.09	0.7%	0.5%
	Bias	11.80	11.66	-1.2%	1.5%
Run 2	Low	0.00	0.08	0.7%	0.5%
	Bias	11.80	11.66	-1.2%	1.5%
Run 3	Low	0.00	0.08	0.7%	0.5%
	Bias	11.80	11.64	-1.4%	1.7%
				≤5%	≤3%

TR01

Run	Run #1		n #2	Run #3				
Calculation	O ₂ (%vd)	Calculation O ₂ (%vd)		Calculation	O ₂ (%vd)			
Average	15.69	Average	15.72	Average	15.74			
Со	0.08	Co	0.08	Co	0.08			
Cm	11.70	Cm	11.66	Cm	11.65			
Cma	11.80	Cma	11.80	Cma	11.80			
Corrected Average:	15.86	Corrected Average:	15.95	Corrected Average:	15.97			

APPENDIXCertificates of Analysis





Airgas USA LLC 1290 Combermere Dr. Troy, MI 48083 Airgas.com

CERTIFICATE OF ANALYSIS

Grade of Product: PRIMARY STANDARD

Customer: MONTROSE AIR QUALITY SERVICES LLC.

Part Number: X02NI99P15A4784

Cylinder Number: CC22973

112 - Troy-32 (SAP) - MI Laboratory:

Analysis Date: Feb 24, 2022

Lot Number: 32-402352595-1 Expiration Date: Feb 24, 2030

Reference Number: 32-402352595-1 Cylinder Volume:

144.3 CF Cylinder Pressure: 2015 PSIG

Valve Outlet:

350

Primary Standard Gas Mixtures are traceable to N.I.S.T. weights and/or N.I.S.T. Gas Mixture reference materials.

ANALYTICAL RESULTS

Component	Req Conc	Actual Concentration (Mole %)	Analytical Uncertainty
METHANE	100.0 PPM	100.2 PPM	+/- 1%
NITROGEN	Balance		





CERTIFICATE OF ANALYSIS

Grade of Product: CERTIFIED STANDARD-SPEC

Customer: MONTROSE AIR QUALITY SERVICES LLC

Part Number: X03NI99C15A02V2

Cylinder Number: EB0116258 Laboratory: 124 - Plumsteadville - PA

Analysis Date: Apr 28, 2022 Lot Number: 160-402387941-1

Expiration Date: Apr 28, 2023

Reference Number: 160-402387941-1 Cylinder Volume: 143.0 CF Cylinder Pressure: 2016 PSIG

Valve Outlet: 350SS

Product composition verified by direct comparison to calibration standards traceable to N.I.S.T. weights and/or N.I.S.T. Gas Mixture reference materials.

ANALYTICAL RESULTS						
Component	Req Conc	Actual Concentration	Analytical			
		(Mole %)	Uncertainty			
FORMALDEHYDE	500.000 PPB	598.181 PPB	+/-5%			
NITROUS OXIDE	250.0 PPM	250.1 PPM	+/-2%			
NITROGEN	Balance					

Permanent Notes:-NA-





Cylinder Number:

Final Pressure:

Mixture Grade: Certificate Number: CC664614

EPA Protocol Calibration Gas 1

PSIG

15422C-02T5-C02

2200

Certification Date:

8/16/2022

Issuance Date:

8/16/2022

Expiration Date: Batch Number:

8/16/2030 15422C-02T5

Part Number:

T5E 4800001-A8-2

Do not use below 100 psi (0.7 megapascals)

EPA Traceability Protocol for Gaseous Calibration Standards Procedure G1, EPA/600/R-12/531 May 2012

Cartified Concentrations

Celulied Collegitations									
Component	Concentration	Analytical Ur	ncertainty	Assay Dates					
Carbon Dioxide	10.0 %	0.1 %	Absolute	7/12/2022					
Oxygen	11.8 %	0.2 %	Absolute	8/16/2022					
Nitrogen	Balance								

Anaytical Instrumentation

	•				
Component	Analytical Principle	Make	Model	Serial	MPC Date
Carbon Dioxide	NDIR	Servomex	4100	900033	7/12/2022
Oxygen	GC-TCD	Shimadzu	GC-8A	C10495021497SA	8/8/2022

Reference Standards

Serial Number	Lot	Expiration	Туре	Component	Salance	Concentration		Uncertainty	Reference
CC466360	°2287A-05T5	1/28/2028	GMIS	CO2	N2	16.17	%	0.156	VSL
CC480398	3308A-05T5	2/19/2028	GMIS	O2	N2	20.91	%	0.113	VSL

The calibration results published in this certificate were obtained using equipment and standards capable of producing results that are traceable to National Institute of Standards and Technology (NIST) and through NIST to the International System of Units (SI). The expanded uncertainties, if included on this certificate, use a coverage factor of k=2 to approximate the 95% confidence level of the measurement, unless otherwise noted. If uncertainties are not included on this certificate, they are available upon request. The nitrogen used as a component or balance gas as well as the oxygen used in air mixtures meets the requirements set forth in 40CFR1065.750. This calibration certificate applies only to the item described and shall not be reproduced other than in full, without written approval from the calibration facility. Calibration certificates without signatures are not valid. This calibration meets the requirements of ISO/IEC 17025-2017.

Analytical Chemist

Carlie Peaceck

Facility Manager

John Schoolcraft

Production Laboratory:

Tier 5 Labs PGVP Vendor ID R12022 5353 W Southern Ave Indianapolis, IN 46241



Cylinder Number:

ER0004758

Mixture Grade:

EPA Protocol Calibration Gas 1

PSIG

Certificate Number: Final Pressure:

08221C-03T5-C01

2015

Certification Date:

3/30/2021

Issuance Date: Expiration Date: 3/31/2021

Batch Number:

3/30/2029

08221C-03T5

Part Number:

T5E 4800001-A8-1

Do not use below 100 psi (0.7 megapascals)

EPA Traceability Protocol for Gaseous Calibration Standards Procedure G1, EPA/600/R-12/531 May 2012

Certified Concentrations

		neu voncentia	UVIIQ			
Component	Concentration	Analytical Toler	ance	Assay Dates		
Carbon Dioxide	17.7 %	0.10 %	Absolute	3/30/2021		
Oxygen	21.8 %	0.10 %	Absolute	3/30/2021		
Nitrogen	Balance					

Anaytical Instrumentation

Component	Analytical Principle	Make	Model	Serial	MPC Date
Carbon Dioxide	GC-TCD	Shimadzu	GC-8A	C10495021497SA	3/23/2021
Oxygen	GC-TCD	Shimadzu	GC-8A	C10495021497SA	3/22/2021

Reference Standards

Serial Number	Lot	Expiration	Type	Component	Balance	Concentration	Units	Uncertainty	Reference
CC462301	1449A-01T5	1/28/2028	GMIS	CO2	N2	17.92	%	0.142	VSL
CC480398	3308A-05T5	2/19/2028	GMIS	02	N2	20.91	%	0.113	VSL

The calibration results published in this certificate were obtained using equipment and standards capable of producing results that are traceable to National Institute of Standards and Technology (NIST) and through NIST to the International System of Units (SI). The expanded uncertainties, if included on this certificate, use a coverage factor of k=2 to approximate the 95% confidence level of the measurement, unless otherwise noted. If uncertainties are not included on this certificate, they are available upon request. Mixture stability is certified according to maximum certification periods set forth by Table 2-3 of EPA 600/R-12/S31 May 2012. The listed expiration date may be extended by special request. The nitrogen used as a component or balance gas as well as the oxygen used in air mixtures meets the requirements set forth in 40CFR1065,750. This calibration certificate applies only to the item described and shall not be reproduced other than in full, without written approval from the calibration facility. Calibration certificates without signatures are not valid. This calibration meets the requirements of ISO/IEC 17025;2017 and ISO/IEC 17034;2016. PJLA accreditation number 170-181.

Analytical Chemist

Carlie Peacock

Quality Manager

Eric Frymier

Production Laboratory:

Tier 5 Labs PGVP Vendor ID R12021 5353 W Southern Ave Indianapolis, IN 46241

B. PROCESS OPERATING DATA


Pipeline	Chromatograph	Date Time	BTU
ANR	LaGrange	08/18/2022 00:00:00	1073.9816

Gravity	Carbon Dioxide	Nitrogen	Methane
0.5996	0.1912	0.3578	91.4731


Ethane	Propane	N Butane	Iso Butane
7.5621	0.3358	0.0276	0.0339


Pentane	Iso Pentane	Neo Pentane	Hexane Plus
0.0025	0.0060	0.0000	0.0101

2 hour 45 minute difference between screenshot time and start time




R1 A Baro 14.32 RH 86 Pause 9:58 Resume 10:18











R2 A 14.32 RH 62










R3 A Baro 14.32 RH 54







C. SAMPLE CALCULATIONS

Test Time 11:20-12:20				H ₂ CO Gaseo	H2CO Gaseous Emissions Example Calculations	mple Calcul	ations		
MWs = 28.01 for CO 528	: le Trai	inergy Lagrange 1 100% ata	Run Test Date	8/18/	Test	Time 11:20	0-12:20		
S28 Tref (°F plus 460) 46.01 fo NOx Reported 6.066 for SOx Example 30.026 H2CO % Difference 30.026 H2CO % Difference 385.3 SV SV SV SV SV SV SV S					MM	,II _s	28.01 for CO		
0.069 C 64.06 for SOX Example 30.026 MWs 30.026 H2CO % Difference 15.43 O2 A53.592 SV SV SV C C C C C C C C C	Reference Temp	perature, °R			us 460)		46.01 fo NOx	Reported	0.074
30.026 MWs 30.026 H2CO % Difference 15.43 Q ₂	Concentraion o	f gaseous species, ppmvd					64.06 for SOx	Example	0.074
33. 34 455. Dpm @ 15% 02	Molecular weig	ht of gaseous species, lb/lb i	nole				30.026 H ₂ CO	% Difference	-0.57
23. 3. 3. 5. 0. 5.	Stack O_2 % dry								
33 bpm @ 15% 02	Grams in a pour	pu		453.592					
(C) (C) (C) (O.069 Ppm @ 15% 02	Specific molar v	olume of an ideal gas at sta	ndard						
(C) 0.069 0.074 ppm @ 15% 02	conditions, ft ³ /l	b mole		ω					
0.069 ppm @ 15% 02	Gaseous Emissi	ons							
= (C) = 0.069 = 0.074 ppm @ 15% O2	a. Concentratio	n, ppm @ 15% O2 dry							
= 0.069 = 0.074 ppm @ 15% O2	<u>ت</u>			(20.9 - 15.0) (20.9 - % O ₂)					
= 0.074	౮		6	(20.9 - 15.0) 5.47	·				
	౮			% 02					

D. CORRESPONDENCE

EMISSION TEST PLAN DOCUMENTATION

Frasure, Anova

From: Frasure, Anova

Sent: Wednesday, June 15, 2022 9:47 AM

To: IDEM Test Protocol

Cc: r5airenforcement@epa.gov

Subject: ANR Pipeline Lagrange CS Test Plan-August 18, 2022

Attachments: Lagrange TR01 test plan 6 11 22.pdf; Lagrange TR01 protocol 5 25 2022 for report.pdf

Mr. Cline,

On behalf of our client, TC Energy, ANR Pipeline, we are submitting the attached compliance test plan and protocol as required by conditions of permit 087-42922-0004. The Air Compliance Team of TC Energy contracted EQM to test the Unit TR01 Turbine at the Lagrange Compressor Station. The testing will be performed in accordance with the requirements of the Code of Federal Regulations, Title 40, Part 60, Subpart A. The testing on the turbine is being tested to comply with regulatory requirement 40 CFR 63, YYYY and will be consistent with USEPA Methods 320 outlined in the attached test plan. Testing is scheduled for August 18, 2022.

TC Energy (ANR) respectfully requests approval of this test date and plan. If you have questions or require additional information, please feel free to contact me via telephone at (219) 661-9900 or email kmast@egm.com. Additional contact information may be found in the test plan.

Anova Frasure | Office Manager

Main: 219.661.9900 | afrasure@egm.com

1280 Arrowhead Ct., Suite 2 | Crown Point, IN 46307

www.eam.com

Email is the best way to communicate to receive immediate assistance.



Please consider the environment before printing this e-mail or attachments. If you do print, please recycle the paper.

Disclaimer:

Electronic Privacy Notice. This e-mail, and any attachments, contains information that is, or may be, covered by the Electronic Communications Privacy Act, 18 U.S.C. 2510-2521, and is also confidential and proprietary in nature. If you are not the intended recipient, please be advised that you are legally prohibited from retaining, using, copying, distributing, or otherwise disclosing, in part or in whole, this information in any manner. Instead, please reply to the sender that you have received this communication in error, and then immediately delete it. Thank you in advance for your cooperation.

Frasure, Anova

From: IDEM Test Protocol <Test_Protocol@idem.IN.gov>

Sent: Wednesday, June 15, 2022 9:51 AM

To: Frasure, Anova

Subject: Automatic Reply: ANR Pipeline Lagrange CS Test Plan-August 18, 2022

Importance: Low

CAUTION: This email originated from outside your organization. Exercise caution when opening attachments or clicking links, especially from unknown senders.

Thank you! Your submittal has been received.

Frasure, Anova

From: Frasure, Anova

Sent: Friday, June 17, 2022 9:19 AM **To:** 'r5airenforcement@epa.gov'

Subject: RE: ANR Pipeline Lagrange CS Test Plan-August 18, 2022

Air Compliance Test Scheduling,

I'm just reaching out to make sure you received the below email and the one for Sulphur Springs that was sent out on Wednesday, June 15, 2022. I usually get a reply back via email, and I have not yet.

Thanks,

Anova Frasure | Office Manager | 219.661.9900 | afrasure@eqm.com

From: Frasure, Anova

Sent: Wednesday, June 15, 2022 9:47 AM

To: IDEM Test Protocol <Test_Protocol@idem.IN.gov>

Cc: r5airenforcement@epa.gov

Subject: ANR Pipeline Lagrange CS Test Plan-August 18, 2022

Mr. Cline,

On behalf of our client, TC Energy, ANR Pipeline, we are submitting the attached compliance test plan and protocol as required by conditions of permit 087-42922-0004. The Air Compliance Team of TC Energy contracted EQM to test the Unit TR01 Turbine at the Lagrange Compressor Station. The testing will be performed in accordance with the requirements of the Code of Federal Regulations, Title 40, Part 60, Subpart A. The testing on the turbine is being tested to comply with regulatory requirement 40 CFR 63, YYYY and will be consistent with USEPA Methods 320 outlined in the attached test plan. Testing is scheduled for August 18, 2022.

TC Energy (ANR) respectfully requests approval of this test date and plan. If you have questions or require additional information, please feel free to contact me via telephone at (219) 661-9900 or email kmast@egm.com. Additional contact information may be found in the test plan.

Anova Frasure | Office Manager

Main: 219.661.9900 | afrasure@eqm.com

1280 Arrowhead Ct., Suite 2 | Crown Point, IN 46307

www.eam.com

Email is the best way to communicate to receive immediate assistance.



Please consider the environment before printing this e-mail or attachments. If you do print, please recycle the paper.

Disclaimer:

Electronic Privacy Notice. This e-mail, and any attachments, contains information that is, or may be, covered by the Electronic Communications Privacy Act, 18 U.S.C. 2510-2521, and is also confidential and proprietary in nature. If you are not the intended recipient, please be advised that you are legally prohibited from retaining, using, copying, distributing, or otherwise disclosing, in part or in whole, this information in any manner. Instead, please reply to the sender that you have received this communication in error, and then immediately delete it. Thank you in advance for your cooperation.



1. Introduction

1.1. The Air Compliance Team of TC Energy's ANR Pipeline Company has scheduled a source emissions testing event at the ANR Lagrange Compressor Station for August 18, 2022 in fulfillment of Indiana Department of Environmental Management (IDEM), permit no. 087-42922-00004. The Turbine TR01 is subject to 40 CFR Part 63, Subpart YYYY requirement. As such, the following parameter will be determined:

1.1.1. Turbine TR01 with an emission limit of ≤91 ppbvd@15%02 Formaldehyde

1.2. Facility Information

1.2.1. Facility Location

ANR Pipeline Lagrange Compressor Station 2255 West U.S. 20 Lagrange, IN 46761

1.2.2. Testing Coordinator

Pedro Amieva 700 Louisiana Street, Suite 700 Houston, TX 77002 (832) 320-5839

Email: Pedro_Amieva@tcenergy.com

1.2.3 Testing Firm

Environmental Quality Management, Inc. 1280 Arrowhead Ct. Ste. 2 Crown Point, IN 46307 Karl Mast, Manager, Emission

Management

(219) 776-6056 Cell kmast@eqm.com Zach Hill, Field Activity Lead (219) 798-5468 zhill@eqm.com

2. Process Description

Unit TR01 is a natural gas fired Mars 90 stationary gas turbine, with ISO rating of 13,220 hp (9.86 MW), using SoLoNOx (lean/premix) as control, exhausts to Stack S03.

Sampling Ports & Traverse Point Locations will be determined on site.

3. Testing Instrumentation and Sampling System

3.1. TC Energy has contracted the services of EQM Inc. (please consult the contractor's web site for

- further information at http://www.eqm.com) to perform the test. EQM Inc. personnel will utilize an emission test platform (ETP) to perform the test.
- 3.2. Exhaust gas enters the system through a stainless-steel probe connected to a sintered filter. The sample is transported via a Teflon sample line through, and into a minimum contact condenser specially designed to dry the sample into a stainless-steel sample pump. The sample is then passed through 3/8" Teflon tubing to the sample manifold. The sample manifold is maintained at a constant pressure by means of an ambient bypass. The stainless-steel internal pumps control the sample flow to O2 analyzer. The flow schematic can be viewed in the attachment.
- 3.3. Formaldehyde emissions will be measured using USEPA Method 320, "Measurements of Vapor Phase Organic and Inorganic Emissions by Extractive Fourier Transform Infrared (FTIR) Spectroscopy". Gaseous samples will be withdrawn from the stack and transferred to the FTIR spectrometer.
- 3.4. An MKS MultiGas 2030 FTIR spectrometer configured with a StarBoost system will be used. The StarBoost technology consists of a 5-micron infrared detector, optical filtration and signal amplification. It is designed to optimize signal response and limit instrument noise for low detection limit applications. The FTIR is equipped with a temperature-controlled, 5.11-meter multipass gas cell maintained at 191°C.

4. General Testing Procedure

- 4.1. Formaldehyde emissions will be measured using USEPA Method 320, "Measurements of Vapor Phase Organic and Inorganic Emissions by Extractive Fourier Transform Infrared (FTIR) Spectroscopy". All data will be collected in differential mode with 2 cm-1 resolution sample data and 8 cm-1 resolution background. Each FTIR spectrum will be derived from the coaddition of 200 scans, with a new data point generated approximately every 60 seconds.
 - 4.1.1. The 0.5 ppm formaldehyde standard for analyte spiking, with 250 ppm N2O tracer gas. Methane will be used as the CTS.
- 4.2. EPA Protocol Gases: EPA protocol 1 calibration gases will be used for analyzer

 $P_{\text{exc}} = 1 \cdot 67$

TC Energy ANR Pipeline Company Lagrange Compressor Station-TR01 Project Number 050812.0025

- calibrations. Certification sheets will be available at the test site.
- 4.2.1. The range of paramagnetic O_2 analyzer will be 0-25%.
- 4.3. Determine of Stratification: Three points on a line passing through the centroidal area will be used, spaced at 16.7, 50.0, and 83.3 percent of the measurement line. The sampling time will be twice the system response time at each traverse point.
- 4.4. Measurement system Preparation: Each analyzer will be set up to the correct response and those responses will be recorded by the data acquisition system. The calibration curve will be then established to convert each analyzer's response to equivalent gas concentrations as introduced to each analyzer. The sample flow rate will remain the same throughout the entire test.
- 4.5. Calibration Error Check: Zero, mid, and high calibration gas will be introduced, without adjustment, to the analyzers and their responses recorded. The response will be considered acceptable if they are within +/- 2 percent of the calibration span.
- 4.6. Sample Line Leak Check: The sample line will be leak checked before the testing by closing the calibration valve assembly while the sample pump is operating. Once the maximum vacuum is reach, the rotameter ball will fall to the bottom. The leak check will be considered acceptable if the ball comes to rest at the bottom of the gas column.
- 4.7. System Bias Check: An upscale gas will first introduce to the analyzer in the direct calibration mode. The analyzer will be allowed to stabilize, and the reading is noted. The same gas will then be introduced at the sample probe, passing through the entire sample system to the analyzer, and the reading noted. The resultant readings will indicate any bias attributed to the sample system. This process will be repeated with the analyzer's zero gas.
- 4.8. The bias check will be considered acceptable if the direct gas reading of the analyzer is within +/- 5 percent of the complete sample train reading of the analyzer. The same procedure will also be conducted for the O₂ analyzer.
- 4.9. Drift Check: Bias checks before and after will be used to determine a zero and upscale drift for NO_x and O_2 analyzers. The drift check will be

- considered acceptable if the zero and the upscale drift for each test run period less than +/- 3 percent of the calibration values.
- 4.10. Response Time Check: Zero gas will be introduced into the sample system at the outlet of the probe until all readings are stable. The calibration valve will then be switched to sample the upscale gas at the outlet of the probe until a stable reading is obtained, within 5 percent of the certified value of the upscale gas. The upscale response time will be recorded. Next, the zero gas will be introduced in the same manner as the upscale gas. Once a stable reading is noted, within 5 percent of the certified value of the upscale gas, the downscale response time will be recorded. The longer interval is the response time.
- Interference Response if required: Vendor instrument data concerning interference in the analyzer will be included in the test report Appendices.
- 4.12. Formaldehyde emissions will be measured using USEPA Method 320, "Measurements of Vapor Phase Organic and Inorganic Emissions by Extractive Fourier Transform Infrared (FTIR) Spectroscopy". Gaseous samples will be withdrawn from the stack and transferred to the FTIR spectrometer. The samples will be directed through a heated probe, heated filter, and heated transfer line connected to the FTIR. The probes, filters, transfer lines, and FTIR will be maintained at approximately 150° C (376° F) during the testing. Concentrations will be measured based on their infrared absorbance compared to reference spectra. The FTIR analyzer scans the sample approximately once per second. A data point consists of the additions of 64 scans, with a data point generated every minute.
 - 4.12.1. FTIR quality assurance procedures will be followed for USEPA Method 320. A calibration transfer standard (CTS) will be analyzed before and after testing. Acetaldehyde spiking will be performed before and after the test. Section 3.29 of the USEPA Method 320 allows the use of a surrogate analyte of spiking. Acetaldehyde may be chosen as a surrogate to formaldehyde for the following reasons.

5. Emissions Testing

Page 2 of 7

- 5.1. Sample Location: The sampling point in the exhaust stack will be at least two stack diameters downstream and at least one-half diameters upstream from any flow disturbance as per 40CFR60 Method 1.
- All Method 320 data will be collected in 5.2. differential mode with 2 cm-1 resolution sample data and 8 cm-1 resolution background. Each FTIR spectrum will be derived from the coaddition of 200 scans, with a new data point generated approximately every 60 seconds. Formaldehyde emissions will be measured using USEPA Method 320, "Measurements of Vapor Phase Organic and Inorganic Emissions by Extractive Fourier Transform Infrared (FTIR) Spectroscopy". Gaseous samples will be withdrawn from the stack and transferred to the FTIR spectrometer.
- Sample Location: A single point probe 5.3. consisting of 3/8-inch stainless steel tubing open at one end will be used to collect the samples if the concentration at each traverse point is within 5 % of the mean concentration; three points will be used if concentration at each traverse point is within 5 to 10% of the mean concentrations. The concentration is considered stratified if the 10% criterion is not met; therefore, twelve traverse points will be used. The sampling point in the exhaust stack will be at least two stack diameters downstream and at least one-half diameters upstream from any flow disturbance as per 40CFR60 Method 1.
- Fuel Gas Analysis: A fuel gas sample will be 5.4. taken during the testing. The sample will be analyzed by the pipeline gas chromatograph. This analysis will give the actual specific gravity, BTU, and mole percentages of fuel gas species (through C6+) so that fuel flow, and mass emissions can be accurately calculated.
- Compliance Test Runs: EPA Reference 5.5. methods, as described in 40 CFR, Part 60, Appendix A, will be followed to conduct this testing. Dilution concentration of exhaust oxygen will be determined by Method 3A. The exhaust gases will be sampled continuously to determine O2 and Formaldehyde (H2CO) concentrations for three 60-minutes test runs at 100% +/-10% for TR01. Moisture will be determined by method 320.
- 5.6. The engine exhaust can vary substantially depending upon air-fuel ratio, load and stack

- geometric considerations, but will generally be at 800-1100 °F, 8-12 % moisture and <100fps stack velocity.
- 5.7. All data will be processed on site and no sample transfer of custody will be required. No CEMS data exists and this is not applicable to these sources. Process conditions during the test will be adjusted to achieve the maximum horsepower possible, up to the engine rating. Process conditions to be monitored and collected during the test will include horsepower, fuel consumption, suction and discharge pressures, heat rates and ambient conditions among others.

6. Test Results

6.1. A copy of the compliance test report will be submitted to the IDEM, Air Quality Division, within 45 days of completion of the test program. The test report will follow the general outline of this test protocol. Data summaries, raw data, calibration sheets, gas analysis, operating parameters and other relevant information will be contained in the test report Appendices.

7. Calculations

7.1. Calibration Correction

$$C_{GAS} = (C_R - C_O) \frac{C_{MA}}{C_M - C_O}$$

Where:

C_{GAS}: Corrected flue gas concentration (bymag)

C_R: Flue gas concentration (ppmvd)

Average of initial and final zero Co: checks (ppmvd)

Average of initial and final span C_M:

checks (ppmvd)

Actual concentration of span gas C_{MA}:

(ppmvd)

7.2. **EPA F-Factor**

TC Energy ANR Pipeline Company Lagrange Compressor Station-TR01 Project Number 050812.0025

 $F_d = \frac{\left[\left(3.64 \cdot H_{W_1\%} \cdot 100 \right) + \left(1.53 \cdot C_{W_1\%} \cdot 100 \right) \right]}{GCV} \cdot 10^6$

 $+\frac{\frac{\rho_{FuelGas}}{\left[\left(0.14\cdot N_{2Wt\%}\cdot 100\right)-\left(0.46\cdot O_{2Wt\%}\cdot 100\right)\right]}{\frac{GCV}{\rho_{FuelGas}}}\cdot 10^{6}$

Where:

 F_d : Fuel specific F-factor, dscf/MMBtu

 $H_{Wt\%}$: Hydrogen weight percent $C_{Wt\%}$: Carbon weight percent $N_{2Wt\%}$: Nitrogen weight percent Oxygen weight percent

GCV: Heating value of the fuel, BTU/dscf $\rho_{Fuel Gas}$: Density of the fuel gas, lb/scf

Where:

C_{d:} Pollutant concentration, lb/scf

F_d: Fuel specific F-factor, dscf/MMBtu

 Q_h : Fuel flow, scf/hr

 $%O_2$: Oxygen concentration in percent,

measured on a dry basis

GCV: Upper dry heating value of fuel,

Btu/dscf

7.3. Inlet Analyzer Drift Correction

$$Cgas = (CAve - CO)(\frac{Cma}{Cm - CO})$$

Where:

C_{GAS}: Average effluent gas concentration adjusted for bias

adjusted for bias

C_{Ave}: Average unadjusted gas concentration indicated by data recorder for the test run

C₀: Average of initial and final zero checks

C_M: Actual concentration of the upscale calibration gas

C_{MA}: Average of initial and final system calibration bias check responses for the upscale calibration gas

7.4. Outlet Analyzer Drift Correction

$$Cgas = (CAve - CO)(\frac{Cma}{Cm - CO})$$

Where:

C_{GAS}: Average effluent gas concentration

adjusted for bias

C_{Ave}: Average unadjusted gas concentration indicated by data

recorder for the test run

 C_0 : Average of initial and final zero

checks (ppmvd)

 C_M : Actual concentration of the upscale

calibration gas

C_{MA}: Average of initial and final system

calibration bian check responses for

the upscale calibration gas

Figure 1. USEPA Method 3A Sampling Train




Figure 2. USEPA Method 320 Sampling Train




Table 1.. USEPA Method 320 System Checks

QAQC Specification	Purpose	Calibration Gas Analyte	Delivery	Frequency	Acceptance Criteria	Result
M320: Zero	Verify that the FTIR is free of contaminants & zero the FTIR	Nitrogen (zero)	Direct to FTIR	pre/post test	< MDL or Noise	Pass
M320: Calibration Transfer Standard (CTS) Direct	Verify FTIR stability, confirm optical path length	Methane	Direct to FTIR	pre-test	+/- 5% cert. value	Pass
M320: Analyte Direct	Verify FTIR calibration	Formaldehyde, N ₂ O	Direct to FTIR	pre-test	Determine FTIR response to be used for analyte spike calcs	Pass
M320: CTS Response	Verify system stability, recovery, RT	Methane	Sampling System	pre/posttest	+/- 5% of Direct Measurement	Pass
M320: Zero Response	Verify system is free of contaminants, system bias	Nitrogen (zero)	Sampling System	pre/posttest	Bias correct data	Pass
M320: Analyte Spike	Verify system ability to deliver and quantify analyte of interest in the presence of other effluent gases	Formaldehyde, N ₂ O	Dynamic Addition to Sampling System, 1:10 effluent	pre-test	+/- 30% theoretical recovery	Pass



State Form 55058 (7-12)

Indiana Department of Environmental Management Office of Air Quality, Compliance Data Section INSTRUCTIONS: Please complete this form and mail it back to: 100 N Senate Avenue, Mail Code 61-53, IGCN 1003, Indianapolis, IN 46204-2251; or fax it to: (317) 233-6865; or e-mail it to: Test_Protocol@idem.IN.gov.

RESET FORM

1. SOURCE INFO: ID/Permit No.: 087-42522-0004 Company: ANR Pipeline Company	֡	220210100		. 20	LIGHT FOR	I laint Forcetton: Fagilatige, IIV	The same of
Company: ANR Pipeline Company			5. Check Applicable Program:	AGENCY USE ONLY:	ne.	:eived:	
TOTAL TOTAL CONTRACT			Trtle V: /	Inspector:	Approval date:	date:	
Mail Address: 700 Louisiana St. Suite 700			SSOA: MSOP:	Reviewer:	Comments:	ıts:	
	TX - XT	77002	Other.				
Company Contact: Pedro Amieva	Telephone: (8	Telephone: (832) 320-5839					
2. TEST COMPANY INFORMATION							
Name: Environmental Quality Manangement,	gement, Inc.						
Address: 1280 Amowhead Ct., Suite 2			٥	CAMBICE	TELOCATION		
11/28	A 46	46307	ó	SHINITES	SAMILLE SITE LOCATION		
Contact Karl Mast	Telephone: (3	Telephone: (219) 776-6056		Disturbance	Does sample port location meet 40 CFR 60, Appx. A	meet 40 CFR 60	Appx. A.
3. PROCESS INFORMATION (Submit a separate form for each unit to test.)	form for each unit t	o test.)	\		Method 1, Sec. 1.2 Requirements	irements:	Oves / NoO
Unit to Test:	TR01		\		If No, explain:		
Maximum Rated Capacity: 13,200	13,200 HP (9.86 MW)		_ <_ <_		77-22-27		
Proposed Operating Speed: =/> 90%	8		*		1.270		nes:
Describe method used to determine operating level:	rel:		_ _ →				
Measure horsebower and or Medawatts					Approximate Stack gas flow (ACFM):	(ACFM):	
Inlet temperatures 4 hour rolling average				Sampling Site	Approximate Stack gas temp (deg. F):	o (deg. F);	
					Approximate Stack gas moisture (%):	ture (%):	1410
Pollution Control Equipment: SoLoNOx (lean/premix)	noc)				7. REAS	REASON FOR TEST:	526
Process Description:			< = = = = = = = = = = = = = = = = = = =		Operating Permit: 087-42922-0004	12922-0004	Oves / NoO
One natural das fired Mars 90 stationary das turbine, with ISO	gas turbine. w	ith ISO		Disturbance	Construction Permit		Oves / No
rating of 13, 220 hp (9.86 MW), using SoLoNOx (lean/premix) as	LoNOx (lean/p	oremix) as		Y	If yes, Unit Start Up Date:	ia.	
control, exhausts to Stack S03	88		>		State Agreed Order: Please Include No.	ase include No.	
List and describe organic raw materials used in process:	rocess:		<i>→</i>	66	Title V:	200	Oves / NoO
				Ŧ	Compliance with 326 IAC NSPS 40 CFR 60 Subpart A	C NSPS 40	Oves / NoO
			Distance A		Other (EPA, CD, State, 114):	1141:	03
Person responsible for recording Process and Control Equipment data:	ontrol Equipment	data:	Distance B		40 C	40 CFR 63 YYYY	
Fuel Type. Natural Gas							
4a. TEST INFORMATION	No. Runs	Time					
Method 1-4					326 IAC 3-6-2(a) requires this completed form to be	es this complete	d form to be
Method 18	300)		4b. Capture Efficiency Testing	Testing	submitted 35 days prior to the proposed test date to	r to the propose	ed test date to
Method 23	3	7	Test Information	No. Runs Time	annicable fest fee to be submitted with the protocol	e submitted with	b) requires any
Method 24	ò	*			(FEE NOT APPLICABLE IF PROGRAM IS FESOP, TITLE	E IF PROGRAM	IS FESOP, TITLE
Method 25			Temporary Enclosure Method:		V OR VE TESTING ONLY.)	.Y.)	
Other: 3A, 320,	6	60.0 mi -	Data Quality Objective Method:			35	





