

5519

SFUND RECORDS CTR
2127595

**Response of RJ Lee Group
to**

**EPA Region 9 (Meer) Letter
dated March 9, 2006**

**Regarding
Evaluation of EPA's Analytical Data
from the
El Dorado Hills Asbestos Evaluation Project**

Exhibit C 1.2
*Preliminary presentation of the El Dorado
data evaluation at the 2005 ASTM Johnson
Conference*

Date: July 2006

Prepared by:
RJ LeeGroup, Inc.
350 Hochberg Rd.
Monroeville, PA 15146
www.rjlg.com

Resuspension of Surface Dusts

RJ Lee Group, Inc.

Johnson 2005

Surface Dust Analyses

- To date, have focused on all (or as much as can be collected) on the surface
 - Typically includes non-respirable particles
- Procedures have involved indirect analyses of samples
 - Indirect preparation increases fiber counts through a combination of liberation and comminution

Surface Dust Analyses


- Target procedure should:
 - Field usable
 - Focus on releasable particles
 - Particles that are respirable
 - Provides information that can be used for risk estimation

Field Sampling

- Unit must be portable
- Results must be correlated with other accepted procedures
- Desirable to study in-place materials
 - Avoids issues related to sample collection and transportation

How Do We Collect Valid Field Samples?

Comparison of Microvac and Wipe Sampling



Field Sampling



El Dorado Hills, CA
Activity-based sampling

The EPA's sampling simulated sports and recreational activities of both children and adults

Field Sampling



El Dorado Hills, CA
Activity-based
sampling

Issue – How
reproducible is the
testing?

Or, as one statistician
said – If they played
the game again, would
the score remain the
same?

The EPA's sampling simulated sports and
recreational activities of both children and adults

What Was Sampled?

- 4726 Primary Structures
- 4901 Total Structures
- 2773 Amphibole Fibers (F, MF, CF)


Parameter	Mean	Median
Length	6.6 μm	5.1 μm
Width	1.1 μm	0.8 μm
Aspect Ratio	7.1	5.8

What Was Sampled?

- 2773 Amphibole Fibers (F, MF, CF)
- 1485 Amphibole Fibers $\geq 5 \mu\text{m}$ long
- 1481 PCME Amphibole Fibers
- 16 Amphibole Fibers $\geq 10 \mu\text{m}$ long and $\leq 0.5 \mu\text{m}$

Parameter	Mean	Median
Length	9.7 μm	8.0 μm
Width	1.6 μm	1.3 μm
Aspect Ratio	7.8	6.2

What Was Sampled?



Prior Processes

Field Sampling




Fig. 2.3-3 HVS3 high-volume small surface sampler (Roberts et al., 1991)

T. Schneider, *Indoor Environ*, Chap 2.3, 2003

Field Sampling




Fig. 2.3-4 Carpettester consisting of a suction nozzle (not visible), radial impactor with collection foil and connector to vacuum cleaner hose, and pressure gauge for adjusting vacuum cleaner flow rate (Schneider et al., 1992)

T. Schneider, *Indoor Environ*, Chap 2.3, 2003

Field Sampling



10 jets @ 45° to surface


Fig 2.3-6 The P-FLEC sampler. The cell is pressed against the surface. Inside the cell a ring supporting and providing pressurized air to a tube with 10 holes rotates. The air jets impact at the surface at an angle of 45°. The removed dust can be collected on a filter or analyzed by a direct reading instrument (Kildeso et al., 2003)

T. Schneider, *Indoor Environ*, Chap 2.3, 2003

Portable Elutriator

- Multiple sample collection
 - Used for multiple analyses (fibers, metals, silica, organics)
- PM 10 sample size
- Loading limited (for fiber counting) to permit direct preparation

Portable Elutriator



Portable Elutriator

- Dust Generator Operation
 - Compressed Nitrogen gas, 25 psi, 8 lpm
 - Injected through four 3.5 mm diameter ports
 - Gas velocity at port – 8 mph
 - Pulsed for 1 second every 30 seconds
 - Remaining 29 seconds used filtered room air

Portable Elutriator

- Elutriator Assembly
 - Cross-section velocity about 0.45 cm/sec
 - Four pre-weighed 0.2 μm PC filters (25 mm) each operating at 1 lpm
- Of the collected particles, 98% were less than 10 μm in diameter.


Portable Elutriator



Portable Elutriator



Portable Elutriator



Comparison with Surface Concentrations

Dust Load Level	Respirable Pb in Air, $\mu\text{g}/\text{m}^3$	Pb on Surface Wipe, $\mu\text{g}/\text{m}^2$	Resuspension Effectiveness, $(\mu\text{g}/\text{m}^3)/(\mu\text{g}/\text{m}^2)$
Light	0.44	1744	2.5×10^{-4}
Medium	1.52	2530	6.0×10^{-4}
Heavy	9.02	9171	9.8×10^{-4}

Average Concentrations

Comparison with Surface Concentrations

Dust Load Level	Respirable Dust in Air, g/m^3	Dust on Surface Wipe, g/m^2	Resuspension Effectiveness, $(\text{g}/\text{m}^3)/(\text{g}/\text{m}^2)$
Light	0.0011	1.99	5.5×10^{-4}
Medium	0.0061	4.04	15.1×10^{-4}
Heavy	0.0387	24.63	15.7×10^{-4}

Average Concentrations

Comparison with Surface Concentrations

Dust Load Level	Respirable Asbestos in Air, s/cm^3	Asbestos on Surface Wipe, s/cm^2	Resuspension Effectiveness, $(\text{s/cm}^3)/(\text{s/cm}^2)$
Light	< 0.019	257,100	$< 1.4 \times 10^{-7}$
Medium	0.40	799,400	5.0×10^{-7}
Heavy	2.69	6,738,000	4.0×10^{-7}

Average Concentrations, Air is Direct Preparation

Comparison with Surface Concentrations

Dust Load Level	Respirable Asbestos in Air, s/cm^3	Asbestos on Surface Wipe, s/cm^2	Resuspension Effectiveness, $(\text{s/cm}^3)/(\text{s/cm}^2)$
Light	0.094	257,100	3.6×10^{-7}
Medium	8.52	799,400	1.1×10^{-5}
Heavy	136.5	6,738,000	2.0×10^{-5}

Average Concentrations, Air is Indirect Preparation

Summary

- A field sampling device was developed with the following characteristics:
 - Multiple sample collection
 - Used for multiple analyses (fibers, metals, silica, organics)
 - PM 10 sample size
 - Loading limited (for fiber counting) to permit direct preparation
- Dust generation (mass) was validated against a real-time monitor

Summary

- Current testing is being conducted to improve the method.