

**LIFENET HEALTH  
REGISTRATION NO. 61713  
COMPLIANCE TEST REPORT  
DETERMINATION  
OF  
ETHYLENE OXIDE REMOVAL EFFICIENCY**

**JANUARY 29 AND 30, 2019**

**Prepared for**

LIFENET HEALTH  
5733 BAYSIDE ROAD, SUITES 103-108  
VIRGINIA BEACH, VIRGINIA 23455

**Prepared by**

AIR MONITORING SPECIALISTS, INC.  
22 RODMAN ROAD  
RICHMOND, VIRGINIA 23224

**Project**

3M MODEL AE ABATORS AB-D AND AB-E

Reviewed by

Initials: JNH

Date: 3/12/19

## REPORT CERTIFICATION

The sampling and analysis performed for this report were carried out under my direction and supervision, and I hereby certify that, to the best of my knowledge, the test report is authentic and accurate.

Signature: 

Date: FEBRUARY 28, 2019

Bruce A. Gerber

President

Air Monitoring Specialists, Inc.



## ***TABLE OF CONTENTS***

---

	EXECUTIVE SUMMARY	1
	Table I-1 Summary of Abator AB-D Ethylene Oxide Removal Efficiency	1
	Table I-2 Summary of Abator AB-E Ethylene Oxide Removal Efficiency	2
1.0	INTRODUCTION	3
1.1	Test Participants	3
	Table1-1	3
1.2	Outline of Test Program	3
	Table1-2	3
2.0	SOURCE DESCRIPTION	4
3.0	SAMPLING AND ANALYTICAL PROCEDURES	5
3.1	Sampling Point Location	5
3.2	Ethylene Oxide	5
4.0	QUALITY ASSURANCE/QUALITY CONTROL	5
4.1	General	5
4.2	Preventive Maintenance	6
4.3	Internal/External System Audit Checks	6
4.4	Data Reduction and Validation	7
4.5	QA/QC Summary	7

## **APPENDICES**

A	Field Data
B	CD With Laboratory Report

## **EXECUTIVE SUMMARY**

Air Monitoring Specialists, Inc. (AMS) was retained by LifeNet Health (Registration NO. 61713), to determine the ethylene oxide removal efficiency for two catalytic abators (AB-D and AB-E). The removal efficiency tests were performed in a series of three one-hour tests. The tests were conducted on January 29 and 30, 2019 at the facility located at 5733 Bayside Road, Suites 103-108 in Virginia Beach, Virginia. The results of the removal efficiency tests are summarized in the following tables:

**TABLE I-1**

**SUMMARY OF ABATOR AB-D ETHYLENE OXIDE REMOVAL EFFICIENCY**

<b>TEST #</b>	<b>ETHYLENE OXIDE / PPM</b>	<b>REMOVAL EFFICIENCY / %</b>
<b>1 - INLET</b>	<b>272</b>	
<b>OUTLET</b>	<b>1.01</b>	<b>99.6</b>
<b>2 - INLET</b>	<b>1,114</b>	
<b>OUTLET</b>	<b>2.45</b>	<b>99.8</b>
<b>3 - INLET</b>	<b>541</b>	
<b>OUTLET</b>	<b>0.559</b>	<b>99.9</b>
<b>AVERAGE INLET</b>	<b>642.3</b>	
<b>AVERAGE OUTLET</b>	<b>1.34</b>	
<b>AVERAGE REMOVAL EFFICIENCY</b>	<b>99.8</b>	

**TABLE I-2****SUMMARY OF ABATOR AB-E ETHYLENE OXIDE REMOVAL EFFICIENCY**

<b>TEST #</b>	<b>ETHYLENE OXIDE / PPM</b>	<b>REMOVAL EFFICIENCY / %</b>
<b>1 - INLET</b>	<b>2,199</b>	
<b>OUTLET</b>	<b>0.496</b>	<b>99.9</b>
<b>2 - INLET</b>	<b>1,806</b>	
<b>OUTLET</b>	<b>1.05</b>	<b>99.9</b>
<b>3 - INLET</b>	<b>2,131</b>	
<b>OUTLET</b>	<b>0.496</b>	<b>99.9</b>
<b>AVERAGE INLET</b>	<b>2,045.3</b>	
<b>AVERAGE OUTLET</b>	<b>0.68</b>	
<b>AVERAGE REMOVAL EFFICIENCY</b>		<b>99.9</b>

## **1.0 INTRODUCTION**

Removal efficiency testing was conducted at LifeNet Health in Virginia Beach, Virginia on January 29 and 30, 2019, to determine the ethylene oxide removal efficiency for two catalytic abators (AB-D and AB-E).

### **1.1 TEST PARTICIPANTS**

Table 1-1 lists the personnel involved in the test program.

**TABLE 1-1**  
**TEST PARTICIPANTS**

LifeNet Health	Jeremy Hirschbeck – Senior Process Engineer
Virginia Department of Environmental Quality	Matthew Slemo – Air Compliance Inspector
Air Monitoring Specialists, Inc.	Phillip Gerber

### **1.2 OUTLINE OF TEST PROGRAM**

Table 1-2 is a test log that presents the sampling locations, primary test methods used, test dates, run numbers and run times for the test program.

**TABLE 1-2**  
**TEST LOG**

<b>Sampling Location</b>	<b>Test Run Methods</b>	<b>Test Run Date</b>	<b>Test Run Numbers and Times</b>
Abator AB-D Inlet	EPA Method 18	January 29, 2019	1 14:03 – 15:03
	EPA Method 18	January 30, 2019	2 09:41 – 10:41
	EPA Method 18	January 30, 2019	3 12:36 – 13:36
Abator AB-D Outlet	EPA Method 18	January 29, 2019	1 14:03 – 15:03
	EPA Method 18	January 30, 2019	2 09:41 – 10:41
	EPA Method 18	January 30, 2019	3 12:36 – 13:36

**TABLE 1-2 (CONT.)****TEST LOG**

<b>Sampling Location</b>	<b>Test Run Methods</b>	<b>Test Run Date</b>	<b>Test Run Numbers and Times</b>
Abator AB-E Inlet	EPA Method 18	January 29, 2019	1 14:44 – 15:44
	EPA Method 18	January 30, 2019	2 09:34 – 10:34
	EPA Method 18	January 30, 2019	3 12:18 – 13:18
Abator AB-E Outlet	EPA Method 18	January 29, 2019	1 14:44 – 15:44
	EPA Method 18	January 30, 2019	2 09:34 – 10:34
	EPA Method 18	January 30, 2019	3 12:18 – 13:18

**2.0 PROCESS DESCRIPTION AND OPERATION**

3M 8XL Steri-Vac EO sterilizers #7 (S/N 350635) and #9 (S/N 350651) and Abators D (S/N 170116) and E (S/N 170133) were used during this efficiency testing. EO sterilizer #7 is connected to Abator D and EO sterilizer #9 is connected to Abator E. The sterilizers were preset to allow only one sterilizer to exhaust at a time. Three cycles were run and one 170 gram EO cartridge was used for each cycle. During the testing, it was verified that the Abator Ready “Green” light was ON before the start of each cycle.

The following cycle operating parameters were used:

- Cycle Description: Custom stored in program 2
- Preheat: 0 minutes
- Vacuum: 160 mBar
- Relative Humidity 60%
- Exposure 3 minutes
- Aeration 0 minutes, no locked aeration

Sampling was started after completion of the Gas Expose Phase. Gas removal to the Abator was indicated on the sterilizer front panel by a drop in chamber pressure. When this occurred, the LNH engineer communicated to the sampler to start collecting the sample from the Abator.

### **3.0 SAMPLING AND ANALYTICAL PROCEDURES**

#### **3.1 SAMPLING POINTS**

Quarter inch tube fittings are located on the catalytic abators inlet and outlet piping.

#### **3.2 ETHYLENE OXIDE**

Ethylene oxide concentrations were determined using U.S. EPA Reference Method 18, "Measurement of Gaseous Organic Compound Emissions by Gas Chromatography." Three one-hour test runs for ethylene oxide removal efficiency were conducted on the inlet and outlet ducts of the three abators utilizing EPA Method 18.

Sample Collection. Samples were withdrawn from the sources at a constant rate using an EPA Method 18 sampling train. The sampling rate was approximately 0.12 liters per minute. The sampling train consists of a Teflon probe line, rotameter, an air tight container containing a ten-liter Tedlar bag, sample/purge valve, rotameter and a metering console with pump and vacuum gauge.

Sample Recovery. The Tedlar bag was removed from the air tight container. The bag was examined for condensation in the bag. No condensation was observed in the sample bags. The bag was then labeled and the information recorded on the chain of custody form, the bag was then stored in an opaque container until delivery to the laboratory.

Sample Analysis. Enthalpy Analytical, Inc. performed the EPA Method 18 analytical procedures. All sample bags were received by the lab in good condition, no condensation observed in the sample bags. Analysis could not be performed if condensation was observed in the sample bags.

### **4.0 QUALITY ASSURANCE/QUALITY CONTROL**

#### **4.1 GENERAL**

Air Monitoring Specialists, Inc. (AMS) is committed to the continued implementation of a Quality Assurance Program to assure the quality of sampling and analytical procedures of environmental measurement data. The Quality Assurance measures taken during this test project equal or exceed the minimum QA/QC recommendations as set forth by the U.S. Environmental Protection Agency (EPA) for a particular method. The following sections outline the QA program implemented by AMS to justify the validity of test

procedures. As applicable, the QA system for the various test programs addresses the following areas:

- Preventive Maintenance
- Internal/External System Checks
- Data Reduction & validation
- QA/QC Summary

#### **4.2 PREVENTIVE MAINTENANCE**

An effective preventive maintenance program decreases downtime and thus increases data completeness and quality. Pretest and posttest equipment calibrations are conducted in a manner and at a frequency, which meets or exceeds U.S. EPA specifications. Each item transported to the field is inspected to detect equipment problems that originate during periods of storage. All equipment returning from the field is cleaned, repaired, reconditioned, and recalibrated as necessary. Routine maintenance on equipment (sampling probes, heated sample lines, flow meters, and valves) is carried out periodically for leaks, corrosion, dents, or any other damage.

#### **4.3 INTERNAL/EXTERNAL SYSTEM AUDIT CHECKS**

System and performance audits are routine elements of all AMS QA/QC programs.

Internal Systems Audit: The following sampling equipment checks were conducted prior to sample collection. All sampling equipment was thoroughly checked to ensure clean and operable components.

- All sampling equipment was thoroughly checked to ensure clean and operable components.
- Equipment was inspected for possible damage from shipment.

External Systems Audits: AMS is subject to a system audit each time a test is conducted for any Air Pollution Control agency. This procedure entails an observer on-site to do qualitative evaluation of performance to demonstrate compliance with the applicable regulations.

#### **4.4 DATA REDUCTION AND VALIDATION**

The test team leader is responsible for reviewing and validating data as they are acquired. Each team leader has extensive knowledge of sampling methodology and the characteristics of the process being measured and is capable of evaluating the accuracy, representativeness, and completeness of raw data on-site. Action to replace inadequate data can be taken immediately.

Data obtained during calibrations and test runs are recorded on standardized forms that are checked twice for completeness and accuracy by the QA Director or his designated representative. Data reduction and consistency are achieved by using the standardized forms and using AMS's in-house computer facilities.

#### **4.5 QA/QC SUMMARY**

EPA Method 18: A recovery study was performed on a bag sample from each test location; the percent recovery met the requirements of section 8.4.2 except for abator AB-D inlet. The results can be found in the laboratory report in Appendix B.



## ***Appendix A***

---

### ***Field Data***

## ***Appendix B***

---

### ***CD With Laboratory Report***

## *Appendix C*

---

### *Process Data*

# Air Monitoring Specialists, Inc.

22 Rodman Rd.  
Richmond, VA 23224

Bayside  
Abator D & E

Analytical Report  
(0119-148)

*EPA Method 18 (Bags)*  
Ethylene oxide

NELAP accredited in the State of Virginia under Laboratory ID # 460155, Certificate # 9984.



**Enthalpy Analytical, LLC**

Phone: (919) 850 - 4392 / Fax: (919) 850 - 9012 / [www.enthalpy.com](http://www.enthalpy.com)  
800-1 Capitola Drive Durham, NC 27713-4385

I certify that to the best of my knowledge all analytical data presented in this report:


- Have been checked for completeness
- Are accurate, error-free, and legible
- Have been conducted in accordance with approved protocol, and that all deviations and analytical problems are summarized in the appropriate narrative(s)

This analytical report was prepared in Portable Document Format (.PDF) and contains 167 pages.


*Michael Steven Schapira*

QA Review Performed by: Michael Steven Schapira

Report Issued: 2/18/19



# Summary of Results



## Enthalpy Analytical

Company: Air Monitoring Specialists, Inc.

Job No.: 0119-148 - EPA Method 18 (Bags)

Client No.: Bayside - Abator D & E

### Summary - Ethylene oxide

Sample ID	Adjusted Sample Concentration (ppmv)
D Outlet 1-1 (01/29/19)	1.01 J
D Inlet 1-2 (01/29/19) **	272 **
E Inlet 2-1 (01/29/19)	2,199
E Outlet 2-2 (01/29/19)	0.496 ND
D Inlet 1-1 BU (01/30/19) **	1,114 **
D Outlet 1-2 (01/30/19)	2.45 J
E Inlet 2-1 (01/30/19)	1,806
E Outlet 2-2 (01/30/19)	1.05 J
D Inlet 3-1 (01/30/19) **	541 **
D Outlet 3-2 (01/30/19)	0.559 ND
E Inlet 4-1 (01/30/19)	2,131
E Outlet 4-2 (01/30/19)	0.496 ND

\*\* Results for these samples have NOT been adjusted as the associated Spike and Recovery did not meet the 70-130% recovery criterion.

# Results



## Enthalpy Analytical

Company: Air Monitoring Specialists, Inc.  
Job No.: 0119-148 - EPA Method 18 (Bags)  
Client No.: Bayside - Abator D & E

Sample Analysis Method Used:  
A = BETTYP957\_EO.M  
B = GUMMOP1536F\_EO.M  
C = BETTYP1042\_EO.M

### Ethylene oxide

Sample ID	Filename #1	Filename #2	Filename #3	Analysis Method	Curve Min	Curve Max	MDL	Ret Time (min)	Ret Time (min)	%dif RT	Conc #1 (ppmv)	Conc #2 (ppmv)	Conc #3 (ppmv)	%dif conc	DF	Avg Conc (ppmv)	Spike Rec. Eff.	Adj. Conc (ppmv)	Flag
D Outlet 1-1 (01/29/19)	002F0101.D	002F0102.D	002F0103.D	B	5.13	243	0.513	3.14	3.14	0.1	0.905	0.812	1.07	15.0	1	0.928	91.8%	1.01	J
D Inlet 1-2 (01/29/19)	002F0602.D	002F0603.D	002F0701.D	B	5.13	243	0.513	3.15	3.15	0.0	13.0	12.9	13.0	0.8	21	272	100%	272	
E Inlet 2-1 (01/29/19)	006F0801.D	006F0901.D	006F0902.D	B	5.13	243	0.513	3.15	3.15	0.1	76.0	75.7	74.6	1.1	21	1,584	72.0%	2,199	
E Outlet 2-2 (01/29/19)	007F0201.D	007F0202.D	007F0203.D	B	5.13	243	0.513	NA	NA	NA	0.513	0.513	0.513	0.0	1	0.513	103%	0.496	ND
D Inlet 1-1 BU (01/30/19)	022B0501.D	022B0502.D	022B0503.D	A	4.85	243	0.485	2.74	2.74	0.0	35.9	35.9	36.0	0.3	31	1,114	100%	1,114	
D Outlet 1-2 (01/30/19)	004F0301.D	004F0302.D	004F0303.D	B	5.13	243	0.513	3.14	3.14	0.0	2.38	2.36	2.00	10.9	1	2.25	91.8%	2.45	J
E Inlet 2-1 (01/30/19)	002F0501.D	002F0601.D	002F0602.D	B	5.13	243	0.513	3.14	3.14	0.1	61.7	61.9	62.3	0.6	21	1,301	72.0%	1,806	
E Outlet 2-2 (01/30/19)	006F0201.D	006F0202.D	006F0203.D	B	5.13	243	0.513	3.14	3.13	0.1	1.37	1.07	0.833	25.2	1	1.09	103%	1.05	J
D Inlet 3-1 (01/30/19)	007F1001.D	007F1002.D	007F1003.D	B	5.13	243	0.513	3.14	3.14	0.0	25.6	25.8	25.9	0.8	21	541	100%	541	
D Outlet 3-2 (01/30/19)	005F0401.D	005F0402.D	005F0403.D	B	5.13	243	0.513	NA	NA	NA	0.513	0.513	0.513	0.0	1	0.513	91.8%	0.559	ND
E Inlet 4-1 (01/30/19)	005F1401.D	005F1402.D	005F1403.D	B	5.13	243	0.513	3.14	3.14	0.0	73.0	73.1	73.2	0.1	21	1,535	72.0%	2,131	
E Outlet 4-2 (01/30/19)	002F0101.D	002F0102.D	002F0103.D	B	5.13	243	0.513	NA	NA	NA	0.513	0.513	0.513	0.0	1	0.513	103%	0.496	ND
D Outlet 1-2 (01/30/19) BL	002F0401.D	002F0402.D	002F0403.D	B	5.13	243	0.513	3.15	3.14	0.1	1.80	1.76	1.79	1.3	1	1.78	100.0%		J
E Inlet 4-1 (01/30/19) BL	007F0201.D	007F0202.D	007F0203.D	B	5.13	243	0.513	3.14	3.14	0.0	27.6	27.6	27.7	0.3	31	857	100.0%		
D Outlet 1-2 (01/30/19) BL SPK	007F0701.D	007F0702.D	007F0703.D	B	5.13	243	0.513	3.15	3.15	0.0	14.8	14.8	14.7	0.6	1	14.8	91.8%		
E Inlet 4-1 (01/30/19) BL SPK	007F0901.D	007F0902.D	007F0903.D	B	5.13	243	0.513	3.15	3.15	0.0	37.2	36.5	36.7	1.0	31	1,141	72.0%		
D Inlet 1-1 BU (01/30/19) SPK	019B1401.D	019B1402.D	019B1403.D	C	5.12	256	0.485	2.73	2.73	0.0	58.7	58.8	57.5	1.4	21	1,225	20.7%		
E Outlet 2-2 (01/30/19) SPK	007F0501.D	007F0502.D	007F0503.D	B	5.13	243	0.513	3.14	3.14	0.0	17.5	17.3	17.0	1.5	1	17.2	103.4%		

## Enthalpy Analytical

Company: Air Monitoring Specialists, Inc.

Job No.: 0119-148 - EPA Method 18 (Bags)

Client No.: Bayside - Abator D & E

### Spiked Bag

D Outlet 1-2 (01/30/19) BL SPK		Ethylene oxide
Before Spiking	Inj1 (ppmv)	1.80
	Inj2 (ppmv)	1.76
	Inj3 (ppmv)	1.79
	Avg ppmv	1.78
	Bag vol L NTP	4.77
Gas Spike	Cylinder	CC122424
	Expires	3/9/19
	Press/Temp	756.7 / 68.5
	Vol (mL)	300
	Cyl Dil Factor	1
	Cyl Conc (ppmv)	243
	Vol (mL NTP)	298
Totals		0.0724
	Sp Bag Vol L NTP	5.07
	Corrected Initial (ppmv)	1.68
	Spike Amount (mL NTP)	0.0724
	Spike Amount (ppmv)	14.3
	Expected (ppmv)	16.0
Result	Inj1 (ppmv)	14.8
	Inj2 (ppmv)	14.8
	Inj3 (ppmv)	14.7
	Avg (ppmv)	14.8
Recovery		91.8%

## Enthalpy Analytical

Company: Air Monitoring Specialists, Inc.

Job No.: 0119-148 - EPA Method 18 (Bags)

Client No.: Bayside - Abator D & E

### Spiked Bag

E Inlet 4-1 (01/30/19) BL SPK		Ethylene oxide
Before Spiking	Inj1 (ppmv)	856
	Inj2 (ppmv)	854
	Inj3 (ppmv)	859
	Avg ppmv	857
	Bag vol L NTP	2.07
Gas Spike	Cylinder	MKBF0692
	Expires	6/5/19
	Press/Temp	757.4 / 71.0
	Vol (mL)	100
	Cyl Dil Factor	101
	Cyl Conc (ppmv)	995,000
	Vol (mL NTP)	99.1 0.976
Totals	Sp Bag Vol L NTP	2.17
	Corrected Initial (ppmv)	817
	Spike Amount (mL NTP)	0.976
	Spike Amount (ppmv)	450
	Expected (ppmv)	1,267
Result	Inj1 (ppmv)	1,153
	Inj2 (ppmv)	1,133
	Inj3 (ppmv)	1,139
	Avg (ppmv)	1,141
Recovery		72.0%

## Enthalpy Analytical

Company: Air Monitoring Specialists, Inc.

Job No.: 0119-148 - EPA Method 18 (Bags)

Client No.: Bayside - Abator D & E

### Spiked Bag

E Outlet 2-2 (01/30/19) SPK		Ethylene oxide
Before Spiking	Inj1 (ppmv)	1.37
	Inj2 (ppmv)	1.07
	Inj3 (ppmv)	0.83
	Avg ppmv	1.09
	Bag vol L NTP	4.35
Gas Spike	Cylinder	CC122424
	Expires	3/9/19
	Press/Temp	764.8 / 70.0
	Vol (mL)	300
	Cyl Dil Factor	1
	Cyl Conc (ppmv)	243
	Vol (mL NTP)	301
Totals	Sp Bag Vol L NTP	4.65
	Corrected Initial (ppmv)	1.02
	Spike Amount (mL NTP)	0.0730
	Spike Amount (ppmv)	15.7
	Expected (ppmv)	16.7
Result	Inj1 (ppmv)	17.5
	Inj2 (ppmv)	17.3
	Inj3 (ppmv)	17.0
	Avg (ppmv)	17.2
Recovery		103%

## Enthalpy Analytical

Company: Air Monitoring Specialists, Inc.

Job No.: 0119-148 - EPA Method 18 (Bags)

Client No.: Bayside - Abator D & E

### Spiked Bag

D Inlet 1-1 BU (01/30/19) SPK		Ethylene oxide
Before Spiking	Inj1 (ppmv)	1,113
	Inj2 (ppmv)	1,112
	Inj3 (ppmv)	1,117
	Avg ppmv	1,114
	Bag vol L NTP	1.94
Gas Spike	Cylinder	MKBF0692
	Expires	6/5/19
	Press/Temp	756.7 / 68.5
	Vol (mL)	40.0
	Cyl Dil Factor	31.0
	Cyl Conc (ppmv)	995,000
	Vol (mL NTP)	39.8
Totals	Sp Bag Vol L NTP	1.98
	Corrected Initial (ppmv)	1,092
	Spike Amount (mL NTP)	1.28
	Spike Amount (ppmv)	644
	Expected (ppmv)	1,736
Result	Inj1 (ppmv)	1,233
	Inj2 (ppmv)	1,234
	Inj3 (ppmv)	1,208
	Avg (ppmv)	1,225
<b>Recovery</b>		<b>20.7%</b>

## Enthalpy Analytical

Company: Air Monitoring Specialists, Inc.

Job No.: 0119-148 - EPA Method 18 (Bags)

Client No.: Bayside - Abator D & E

### Spike Hold Times

Spiked Bag	Time Spiked	Spike Analyzed	Hold Time (Hours)	Related Bag	Related Bag Sampled Date	Bag Analyzed	Hold Time (Hours)
r013119 D Outlet 1-2 BL SP	02-04-2019 09:30	02-05-2019 12:59	27.5	r013019 D Outlet 1-1	01-29-2019 14:03	01-30-2019 10:25	20.4
				r013119 D Outlet 1-2	01-30-2019 09:41	01-31-2019 11:05	25.4
				r013119 D Outlet 3-2	01-30-2019 12:36	01-31-2019 11:53	23.3
r013119 E Inlet 4-1 BL SP	02-04-2019 10:34	02-05-2019 14:32	28.0	r013019 E Inlet 2-1	01-29-2019 14:44	01-30-2019 14:05	23.4
				r013119 E Inlet 2-1	01-30-2019 12:36	01-31-2019 12:30	23.9
				r013119 E Inlet 4-1	01-30-2019 12:18	01-31-2019 15:58	27.7
r013119 E Outlet 2-2 SP	01-31-2019 14:59	02-01-2019 15:46	24.8	r013019 E Outlet 2-2	01-29-2019 14:44	01-30-2019 11:02	20.3
				r013119 E Outlet 2-2	01-30-2019 12:36	01-31-2019 10:18	21.7
				r013119 E Outlet 4-2	01-30-2019 12:18	01-31-2019 09:30	21.2
r013119 IN D 1-1 BU SP	02-07-2019 10:40	02-15-2019 11:13	192.6	r013019 D Inlet 1-2	01-29-2019 14:03	01-30-2019 13:49	23.8
				r013119 D Inlet 3-1	01-30-2019 12:36	01-31-2019 13:45	25.2
				r013119 IN D 1-1 BU	01-30-2019 09:41	02-07-2019 09:31	191.8

# Narrative Summary





## Enthalpy Analytical Narrative Summary

<b>Company</b>	Air Monitoring Specialists, Inc.
<b>Job #</b>	0119-149 - EPA Method 18 (Bags)
<b>Client #</b>	Bayside – Abator D & E

### Custody

David Myers received four samples on 1/30/19 and Matthew St. Lawrence received eight bags on 1/31/19 after being relinquished by Air Monitoring Specialists, Inc. All bags were received at ambient temperature. The back-up bags received on 1/30/19 and all the bags received on 1/31/19 were received with low volume.

Prior to, during, and after analysis, the samples were kept under lock with access only to authorized personnel by Enthalpy Analytical, LLC.

### Analysis

The samples were analyzed for ethylene oxide using the analytical procedures in EPA Method 18, Measurement of Gaseous Organic Compound Emissions by Gas Chromatography (40 CFR Part 60, Appendix A).


All samples and standards were introduced directly to the column using an automated multi-port Valco gas sampling valve equipped with a stainless steel loop. Ethylene oxide was referenced to certified gas phase standards.

The analyses were performed using the Agilent Technologies Model 6890N, Gas Chromatograph “Betty” (S/N US10430048) and the Agilent Technologies Model 6890, Gas Chromatograph “Gummo” (S/N US00028451). Both instruments were equipped with Flame Ionization Detectors (FIDs).

### Calibration

The calibration curves are located in the Raw Data section of this report and referenced in the Analysis Method column on the Detailed Results page.

For each calibration curve used, the first page of the curve contains all method specific parameters (i.e., curve type, origin, weight, etc.) used to quantify the samples. The calibration curve section also includes a table with the Retention Time (RetTime), Level (Lvl), Amount (corresponding units), Area, Response Factor (Amt/Area) and the analyte Name. The calibration table is used to identify (by retention time) and quantify each target compound.





## Enthalpy Analytical Narrative Summary

(continued)

### Chromatographic Conditions

Copies of the acquisition methods (AQ\_GUMMOP1466.M AQ\_GUMMOP1466\_AA.M, GC142P133\_SHORT.M, and GC142P133\_CAL.M) are included in the Raw Data section of this report.

### QC Notes

The analyses of the laboratory method blanks did not contain ethylene oxide at concentrations greater than the detection limit.

As required by the method, a spike and recovery study was performed on one of the samples from each source. Bag **E Outlet 2-2 (01/30/19)** was spiked on 1/31/19 at 2:59 PM, bag **D Outlet 1-2 (01/30/19)** was spiked on 2/4/19 at 9:30 AM, bag **E Inlet 4-1 (01/30/19)** was spiked on 2/4/19 at 10:34AM, and bag **D Inlet 1-1 (01/30/19) BU** was spiked on 2/7/19 at 10:40 AM.. All recovery efficiency values met the method-required limits of 70 to 130%, except for **D Inlet 1-1 (01/30/19) BU**. The passing recovery efficiency values were used to adjust the associated sample results following equation 18-7 of Method 18. The **D Inlet** samples results are reported as measured, without adjustment since their S&R did not meet criteria.

### Reporting Notes


These analyses met the requirements of the TNI Standard. Any deviations from the requirements of the reference method or TNI Standard have been stated above.

The results presented in this report are representative of the samples as provided to the laboratory.

## General Reporting Notes

The following are general reporting notes that are applicable to all Enthalpy Analytical, LLC data reports, unless specifically noted otherwise.


- Any analysis which refers to the method as “**Type**” represents a planned deviation from the reference method. For instance a Hydrogen Sulfide assay from a Tedlar bag would be labeled as “EPA Method 16-Type” because Tedlar bags are not mentioned as one of the collection options in EPA Method 16.
- The acronym **MDL** represents the Minimum Detection Limit. Below this value the laboratory cannot determine the presence of the analyte of interest reliably.
- The acronym **LOQ** represents the Limit of Quantification. Below this value the laboratory cannot quantitate the analyte of interest within the criteria of the method.
- The acronym **ND** following a value indicates a non-detect or analytical result below the MDL.
- The letter **J** in the Qualifier or Flag column in the results indicates that the value is between the MDL and the LOQ. The laboratory can positively identify the analyte of interest as present, but the value should be considered an estimate.
- The letter **E** in the Qualifier or Flag column indicates an analytical result exceeding 100% of the highest calibration point. The associated value should be considered as an estimate.
- Sample results are presented ‘as measured’ for single injection methodologies, or an average value if multiple injections are made. If all injections are below the MDL, the sample is considered non-detect and the ND value is presented. If one, but not all, are below the MDL, the MDL value is used for any injections that are below the MDL. For example, if the MDL is 0.500 and LOQ is 1.00, and the instrument measures 0.355, 0.620, and 0.442 - the result reported is the average of 0.500, 0.620, and 0.500 - - - i.e. 0.540 with a J flag.
- When a spike recovery (Bag Spike, Collocated Spike Train, or liquid matrix spike) is being calculated, the native (unspiked) sample result is used in the calculations, as long as the value is above the MDL. If a sample is ND, then 0 is used as the native amount (not the MDL value).
- The acronym **DF** represents Dilution Factor. This number represents dilution of the sample during the preparation and/or analysis process. The analytical result taken from a laboratory instrument is multiplied by the DF to determine the final undiluted sample results.
- The addition of **MS** to the Sample ID represents a Matrix Spike. An aliquot of an actual sample is spiked with a known amount of analyte so that a percent recovery value can be determined. The MS analysis indicates what effect the sample matrix may have on the target analyte, i.e. whether or not anything in the sample matrix interferes with the analysis of the analyte(s).







## General Reporting Notes (continued)

- The addition of **MSD** to the Sample ID represents a Matrix Spike Duplicate. Prepared in the same manner as a MS, the use of duplicate matrix spikes allows further confirmation of laboratory quality by showing the consistency of results gained by performing the same steps multiple times.
- The addition of **LD** to the Sample ID represents a Laboratory Duplicate. The analyst prepares an additional aliquot of sample for testing and the results of the duplicate analysis are compared to the initial result. The result should have a difference value of within 10% of the initial result (if the results of the original analysis are greater than the LOQ).
- The addition of **AD** to the Sample ID represents an Alternate Dilution. The analyst prepares an additional aliquot at a different dilution factor (usually double the initial factor). This analysis helps confirm that no additional compound is present and coeluting or sharing absorbance with the analyte of interest, as they would have a different response/absorbance than the analyte of interest.
- The Sample ID **LCS** represents a Laboratory Control Sample. Clean matrix, similar to the client sample matrix, prepared and analyzed by the laboratory using the same reagents, spiking standards and procedures used for the client samples. The LCS is used to assess the control of the laboratory's analytical system. Whenever spikes are prepared for our client projects, two spikes are retained as LCSs. The LCSs are labeled with the associated project number and kept in-house at the appropriate temperature conditions. When the project samples are received for analysis, the LCSs are analyzed to confirm that the analyte could be recovered from the media, separate from the samples which were used on the project and which may have been affected by source matrix, sample collection, and/or sample transport.
- **Significant Figures:** Where the reported value is much greater than unity (1.00) in the units expressed, the number is rounded to a whole number of units, rather than to 3 significant figures. For example, a value of 10,456.45 ug catch is rounded to 10,456 ug. There are five significant digits displayed, but no confidence should be placed on more than two significant digits. In the case of small numbers, generally 3 significant figures are presented, but still only 2 should be used with confidence. Many neat materials are only certified to 3 digits, and as the mathematically correct final result is always 1 digit less than all its pre-cursors - 2 significant figures are what are most defensible.
- **Manual Integration:** The data systems used for processing will flag manually integrated peaks with an "M". There are several reasons a peak may be manually integrated. These reasons will be identified by the following two letter designations on sample chromatograms, if provided in the report. The peak was *not integrated* by the software "**NI**", the peak was *integrated incorrectly* by the software "**II**" or the *wrong peak* was integrated by the software "**WP**". These codes will accompany the analyst's manual integration stamp placed next to the compound name on the chromatogram.



# Sample Custody





Page ( ) of

**Special Handling:**

- ☐ Standard Turn Around Time (10 business days)
- ☐ Rush Turn Around Time – Date Needed \_\_\_\_\_
- All TATs Subject to Approval by Enthalpy Analytical, Inc.
- All Bag/Can Samples Disposed of 1 Month from Receipt.
- All Other Samples Disposed of 4 Months from Receipt.

For spiked or duplicate samples: please provide sample volumes for recovery calculations.

For Particulates: please provide tare weights and/or condensed water volumes.

PO#: LFH 0119  
Telephone#: (804) 231-3043  
Email: ams@airmonitoringspecialists.com

Project Number: \_\_\_\_\_  
Site Name: Bay Side  
Location: Ebbetts Pass

**Client Name:** Air Monitoring Specialists, Inc.

**Project Manager:** Bruce Gerber

Report To: Bruce Gerber

**Special Instructions:**

A=Air 1=H<sub>2</sub>SO<sub>4</sub> 2=NaOH 3= 4=

X=XAD C=Charcoal SG=Silica Gel

**X=XAD C=Charcoal SG=Silica Gel**

**X=XAD C=Charcoal SG=Silica Gel**

**G=Grab C=Composite Q=Quality Control**

Sample ID	Date	Time	Sample Volume	Type
1-1	1/29/19	14:03	10L	C
1-2	1/29/19	14:03	10L	C
2-1	1/29/19	14:44	10L	C
2-2	1/29/19	14:44	10L	C
1-1 D	1/29/19	14:03	5L	C
1-2 D	1/29/19	14:03	5L	C
2-1 D	1/29/19	14:44	5L	C
2-2 D	1/29/19	14:44	5L	C

## Sample Containers

### Analyses:

# of VOA Vials

	# of Glass	# of Plastic
1	1	1
2	1	1
3	1	1
4	1	1
5	1	1
6	1	1
7	1	1
8	1	1
9	1	1
10	1	1
11	1	1
12	1	1
13	1	1
14	1	1
15	1	1
16	1	1
17	1	1
18	1	1
19	1	1
20	1	1
21	1	1
22	1	1
23	1	1
24	1	1
25	1	1
26	1	1
27	1	1
28	1	1
29	1	1
30	1	1
31	1	1
32	1	1
33	1	1
34	1	1
35	1	1
36	1	1
37	1	1
38	1	1
39	1	1
40	1	1
41	1	1
42	1	1
43	1	1
44	1	1
45	1	1
46	1	1
47	1	1
48	1	1
49	1	1
50	1	1
51	1	1
52	1	1
53	1	1
54	1	1
55	1	1
56	1	1
57	1	1
58	1	1
59	1	1
60	1	1
61	1	1
62	1	1
63	1	1
64	1	1
65	1	1
66	1	1
67	1	1
68	1	1
69	1	1
70	1	1
71	1	1
72	1	1
73	1	1
74	1	1
75	1	1
76	1	1
77	1	1
78	1	1
79	1	1
80	1	1
81	1	1
82	1	1
83	1	1
84	1	1
85	1	1
86	1	1
87	1	1
88	1	1
89	1	1
90	1	1
91	1	1
92	1	1
93	1	1
94	1	1
95	1	1
96	1	1
97	1	1
98	1	1
99	1	1
100	1	1

# of Bags

# of Canisters

# of Tubes

# Other

**Notes:**

Duplicate  
Duplicate  
Duplicate  
Duplicate

Relinquished By:

Date:

Received By:

Date: \_\_\_\_\_ Time: \_\_\_\_\_

**Sample Condition Upon Receipt:**

Philip Seals

1129114

Don Ward

1-30-19

☐ Iced ☒ Ambient ☐ °C

☐ Iced ☐ Ambient ☐ °C

8800 1 Capital Drive • Durham NC 27713 • (919) 850-4392 • FAX (919) 850-9012 • [www.enthalpy.com](http://www.enthalpy.com)

Ambient temp  
A Received with low volume

DSM 1-30-19

EA Job # 0119-148 Page 18 of 167



Page 1 of 2

**Special Handling:**

- ☐ Standard Turn Around Time (10 business days)  
☐ Rush Turn Around Time – Date Needed

**Client Name:** Air Monitoring Specialists, Inc.

**Project Manager:** Bruce Gerber

Report To: Bruce Gerber

Project Number:

Site Name: Bay Side

Location: 4 Baxter Drive

PO#: LFH 0119

Telephone#: (804) 231-3043

Email: [ams@airmonitoringspecialists.com](mailto:ams@airmonitoringspecialists.com)

For spiked or duplicate samples: please provide sample volumes for recovery calculations.

For Particulates: please provide tare weights and/or condensed water volumes.

**Special Instructions:**

A=Air 1=H<sub>2</sub>SO<sub>4</sub> 2=NaOH 3= 4=

X=XAD C=Charcoal SG=Silica Gel

**G=Grab C=Composite Q=Quality Control**

[illegible]

Relinquished By:

Date:

Received By:

Date:

Time:

Sample Condition Upon Receipt:

Philip Garber

110257

Matt. A. Lawrence

1/31/19

8:00am

☐ Iced ☒ Ambient ☐ °C.


good condition  
Ambient temp

\* = NEA 9888 #0419 at 45m Page 9 of 167  
MS+ 1/31/19

800-1 Capitola Drive • Durham, NC 27713 • (919) 850-4392 • FAX (919) 850-9012 • [www.enthalpy.com](http://www.enthalpy.com)



# Raw Data






# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013019 D Outlet 1-1.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 002F0101.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 10:25 AM  
File Modified 2/18/2019 6:20 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	3.14	0.17186	0.08095	0.90491	1	0.90491	ppm

## Analyst Peak Integration Comments


12:55:14 01/30/19 Justin Guenzler not integrated - EO

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013019 D Outlet 1-1.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 002F0102.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 10:41 AM  
File Modified 2/18/2019 6:20 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	3.14	0.15417	0.06644	0.81177	1	0.81177	ppm

## Analyst Peak Integration Comments


13:26:33 02/01/19 Justin Guenzler not integrated - EO

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013019 D Outlet 1-1.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 002F0103.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 10:53 AM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	3.14	0.20266	0.08337	1.06709	1	1.06709	ppm

## Analyst Peak Integration Comments


13:26:52 02/01/19 Justin Guenzler not integrated - EO

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013019 D Inlet 1-2.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 002F0602.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 1:49 PM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	2.50066	0.91992	13.0463	21	273.972	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013019 D Inlet 1-2.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 002F0603.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 1:54 PM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	2.46476	0.92319	12.8602	21	270.063	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013019 D Inlet 1-2.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 002F0701.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 1:59 PM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 1 of 1  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	2.48541	0.94276	12.9672	21	272.312	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013019 E Inlet 2-1.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 006F0801.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 2:05 PM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 6  
Injection Volume 1000  
Injection 1 of 1  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	14.6385	5.43746	75.9976	21	1595.95	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013019 E Inlet 2-1.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 006F0901.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 2:11 PM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 6  
Injection Volume 1000  
Injection 1 of 2  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	14.5747	5.51740	75.6666	21	1589.00	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013019 E Inlet 2-1.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 006F0902.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 2:27 PM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 6  
Injection Volume 1000  
Injection 2 of 2  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	14.3696	5.26840	74.6032	21	1566.67	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013019 E Outlet 2-2.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 007F0201.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 11:02 AM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

## Chromatogram Report

Sample Name 0119-148.r013019 E Outlet 2-2.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 007F0202.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 11:11 AM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

## Chromatogram Report

Sample Name 0119-148.r013019 E Outlet 2-2.Bag  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 007F0203.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 11:27 AM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 IN D 1-1 BU.Bag  
Sequence Name BETTYP1029 ver.3  
Inj Data File 022B0501.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/7/2019 9:31 AM  
File Modified 2/14/2019 11:18 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 22  
Injection Volume 250  
Injection 1 of 3  
Acquisition Method GC142P133\_CAL\_SHORT.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 2/14/2019 11:18 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	2.74	12.6070	4.69834	35.9046	31	1113.04	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 IN D 1-1 BU.Bag  
Sequence Name BETTYP1029 ver.3  
Inj Data File 022B0502.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/7/2019 9:38 AM  
File Modified 2/14/2019 11:18 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 22  
Injection Volume 250  
Injection 2 of 3  
Acquisition Method GC142P133\_CAL\_SHORT.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 2/14/2019 11:18 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.74	12.5974	4.66886	35.8772	31	1112.19	ppm

## Chromatogram Report

## Enthalpy Analytical

Sample Name 0119-148.r013119 IN D 1-1 BU.Bag  
Sequence Name BETTYP1029 ver.3  
Inj Data File 022B0503.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/7/2019 9:53 AM  
File Modified 2/14/2019 11:18 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 22  
Injection Volume 250  
Injection 3 of 3  
Acquisition Method GC142P133\_CAL\_SHORT.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 2/14/2019 11:18 AM  
Printed 2/18/2019 7:25 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	12.6563	4.70221	36.0447	31	1117.39	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Outlet 1-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 004F0301.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 11:05 AM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 4  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	3.14	0.45199	0.20755	2.37990	1	2.37990	ppm

## Analyst Peak Integration Comments

13:49:09 01/31/19 Justin Guenzler II - Baseline




# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Outlet 1-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 004F0302.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 11:21 AM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 4  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	3.14	0.44768	0.20583	2.35721	1	2.35721	ppm

## Analyst Peak Integration Comments


13:49:29 01/31/19 Justin Guenzler II - Baseline

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Outlet 1-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 004F0303.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 11:37 AM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 4  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	3.14	0.37980	0.17543	1.99979	1	1.99979	ppm

## Analyst Peak Integration Comments


13:49:43 01/31/19 Justin Guenzler II - Baseline

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 2-1.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 002F0501.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 12:30 PM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 1 of 1  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	11.8726	4.54315	61.6524	21	1294.70	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 2-1.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 002F0601.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 12:37 PM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 1 of 2  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	11.9217	4.54206	61.9073	21	1300.05	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 2-1.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 002F0602.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 12:44 PM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 2 of 2  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	12.0037	4.57016	62.3326	21	1308.98	ppm

## Chromatogram Report

Sample Name 0119-148.r013119 E Outlet 2-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 006F0201.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 10:18 AM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 6  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	3.14	0.25955	0.09851	1.36661	1	1.36661	ppm

### Analyst Peak Integration Comments


10:55:26 01/31/19 Justin Guenzler not integrated - Ethylene oxide

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Outlet 2-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 006F0202.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 10:34 AM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 6  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	3.13	0.20398	0.08873	1.07403	1	1.07403	ppm

## Analyst Peak Integration Comments

10:56:00 01/31/19 Justin Guenzler not integrated - Ethylene oxide




# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Outlet 2-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 006F0203.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 10:50 AM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 6  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	3.14	0.15817	0.08186	0.83284	1	0.83284	ppm

## Analyst Peak Integration Comments

11:07:31 01/31/19 Justin Guenzler not integrated - Ethylene oxide




# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Inlet 3-1.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 007F1001.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 1:45 PM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	4.91347	1.85755	25.5601	21	536.761	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Inlet 3-1.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 007F1002.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 1:52 PM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	4.95737	1.86056	25.7877	21	541.542	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Inlet 3-1.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 007F1003.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 1:59 PM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	4.98598	1.89354	25.9361	21	544.659	ppm

## Chromatogram Report

Sample Name 0119-148.r013119 D Outlet 3-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 005F0401.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 11:53 AM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 5  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Outlet 3-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 005F0402.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 12:09 PM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 5  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Outlet 3-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 005F0403.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 12:25 PM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 5  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 4-1.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 005F1401.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 3:58 PM  
File Modified 2/18/2019 6:24 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 5  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	14.0593	5.29047	72.9935	21	1532.86	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 4-1.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 005F1402.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 4:05 PM  
File Modified 2/18/2019 6:24 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 5  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	14.0838	5.34210	73.1206	21	1535.53	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 4-1.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 005F1403.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 4:12 PM  
File Modified 2/18/2019 6:24 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 5  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	14.0951	5.38553	73.1793	21	1536.77	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Outlet 4-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 002F0101.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 9:30 AM  
File Modified 2/18/2019 6:22 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

## Chromatogram Report

Sample Name 0119-148.r013119 E Outlet 4-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 002F0102.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 9:46 AM  
File Modified 2/18/2019 6:22 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

## Chromatogram Report

Sample Name 0119-148.r013119 E Outlet 4-2.Bag  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 002F0103.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 10:02 AM  
File Modified 2/18/2019 6:23 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

## Chromatogram Report

Sample Name 0119-148.r013119 D Outlet 1-2 BL.Bag  
Sequence Name GUMMOP1540A ver.3  
Inj Data File 002F0401.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/4/2019 9:11 AM  
File Modified 2/18/2019 6:29 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	3.15	0.34218	0.13731	1.80169	1	1.80169	ppm

### Analyst Peak Integration Comments


09:23:02 02/04/19 Justin Guenzler not integrated - EO

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Outlet 1-2 BL.Bag  
Sequence Name GUMMOP1540A ver.3  
Inj Data File 002F0402.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/4/2019 9:17 AM  
File Modified 2/18/2019 6:29 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	3.14	0.33441	0.13674	1.76081	1	1.76081	ppm

## Analyst Peak Integration Comments

09:23:14 02/04/19 Justin Guenzler not integrated - EO




# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Outlet 1-2 BL.Bag  
Sequence Name GUMMOP1540A ver.3  
Inj Data File 002F0403.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/4/2019 9:24 AM  
File Modified 2/18/2019 6:29 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 2  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MF	3.14	0.33963	0.13791	1.78828	1	1.78828	ppm

## Analyst Peak Integration Comments


10:16:49 02/04/19 Justin Guenzler not integrated - EO

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 4-1 BL.Bag  
Sequence Name GUMMOP1540A ver.3  
Inj Data File 007F0201.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/4/2019 7:43 AM  
File Modified 2/18/2019 6:29 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	5.31190	2.02289	27.6264	31	856.419	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 4-1 BL.Bag  
Sequence Name GUMMOP1540A ver.3  
Inj Data File 007F0202.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/4/2019 7:50 AM  
File Modified 2/18/2019 6:29 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	5.29899	2.01894	27.5595	31	854.344	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 4-1 BL.Bag  
Sequence Name GUMMOP1540A ver.3  
Inj Data File 007F0203.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/4/2019 7:57 AM  
File Modified 2/18/2019 6:29 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 7  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	5.32740	2.03336	27.7068	31	858.912	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Outlet 1-2 BL SP.Bag  
Sequence Name GUMMOP1542A ver.5  
Inj Data File 007F0701.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/5/2019 12:59 PM  
File Modified 2/18/2019 6:32 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	2.84370	1.06943	14.8255	1	14.8255	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 D Outlet 1-2 BL SP.Bag  
Sequence Name GUMMOP1542A ver.5  
Inj Data File 007F0702.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/5/2019 1:06 PM  
File Modified 2/18/2019 6:32 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	2.84390	1.06152	14.8265	1	14.8265	ppm

## Chromatogram Report

## Enthalpy Analytical

Sample Name 0119-148.r013119 D Outlet 1-2 BL SP.Bag  
Sequence Name GUMMOP1542A ver.5  
Inj Data File 007F0703.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/5/2019 1:13 PM  
File Modified 2/18/2019 6:32 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	2.81802	1.05131	14.6923	1	14.6923	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 4-1 BL SP.Bag  
Sequence Name GUMMOP1542A ver.5  
Inj Data File 007F0901.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/5/2019 2:32 PM  
File Modified 2/18/2019 6:32 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	7.15658	2.72854	37.1936	31	1153.00	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 4-1 BL SP.Bag  
Sequence Name GUMMOP1542A ver.5  
Inj Data File 007F0902.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/5/2019 2:39 PM  
File Modified 2/18/2019 6:32 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	7.03097	2.69512	36.5422	31	1132.81	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Inlet 4-1 BL SP.Bag  
Sequence Name GUMMOP1542A ver.5  
Inj Data File 007F0903.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/5/2019 2:46 PM  
File Modified 2/18/2019 6:32 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	7.06682	2.69909	36.7281	31	1138.57	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 IN D 1-1 BU SP.Bag  
Sequence Name BETTYP1042A ver.2  
Inj Data File 019B1401.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/15/2019 11:13 AM  
File Modified 2/15/2019 1:43 PM  
Instrument Betty  
Operator Jennie Parrish

Sample Type Sample  
Vial Number Vial 19  
Injection Volume 250  
Injection 1 of 3  
Acquisition Method GC142P133\_CAL\_SHORT.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	22.5202	8.13020	58.7302	21	1233.33	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 IN D 1-1 BU SP.Bag  
Sequence Name BETTYP1042A ver.2  
Inj Data File 019B1402.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/15/2019 11:20 AM  
File Modified 2/15/2019 1:44 PM  
Instrument Betty  
Operator Jennie Parrish

Sample Type Sample  
Vial Number Vial 19  
Injection Volume 250  
Injection 2 of 3  
Acquisition Method GC142P133\_CAL\_SHORT.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	22.5407	8.08496	58.7830	21	1234.44	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 IN D 1-1 BU SP.Bag  
Sequence Name BETTYP1042A ver.2  
Inj Data File 019B1403.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/15/2019 11:31 AM  
File Modified 2/15/2019 1:44 PM  
Instrument Betty  
Operator Jennie Parrish

Sample Type Sample  
Vial Number Vial 19  
Injection Volume 250  
Injection 3 of 3  
Acquisition Method GC142P133\_CAL\_SHORT.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	22.0515	7.98737	57.5176	21	1207.87	ppm

## Chromatogram Report

Sample Name 0119-148.r013119 E Outlet 2-2 SP.Bag  
Sequence Name GUMMOP1540 ver.3  
Inj Data File 007F0501.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/1/2019 3:46 PM  
File Modified 2/18/2019 6:26 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 1 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	3.35883	1.26945	17.4971	1	17.4971	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name 0119-148.r013119 E Outlet 2-2 SP.Bag  
Sequence Name GUMMOP1540 ver.3  
Inj Data File 007F0502.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/1/2019 3:53 PM  
File Modified 2/18/2019 6:26 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 7  
Injection Volume 1000  
Injection 2 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	3.31310	1.26852	17.2599	1	17.2599	ppm

## Chromatogram Report

Sample Name 0119-148.r013119 E Outlet 2-2 SP.Bag  
Sequence Name GUMMOP1540 ver.3  
Inj Data File 007F0503.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/1/2019 4:00 PM  
File Modified 2/18/2019 6:26 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 7  
Injection Volume 1000  
Injection 3 of 3  
Acquisition Method AQ\_GUMMOP1466\_AA.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	3.25922	1.25025	16.9805	1	16.9805	ppm

## Enthalpy Analytical

Company: Air Monitoring Specialists, Inc.

Job No.: 0119-148 - EPA Method 18 (Bags)

Client No.: Bayside - Abator D & E

### Ethylene oxide -- Calibration Standards

SAMPLE ID	Filename #1	Filename #2	Filename #3	Analysis Method	Ret Time (min)	Ret Time (min)	Ret Time (min)	%dif RT	Conc. #1 (ppmv)	Conc. #2 (ppmv)	Conc. #3 (ppmv)	%dif conc	Avg. Conc. (ppmv)	Standard Tag	% Tag
BettyP1029 #SC3 ENV(1=636,6=400)	025B0101.D	025B0102.D	025B0103.D	BETTYP957_EO.M	2.73	2.73	2.73	0.0	75.8	76.7	76.9	0.8	76.5	78.8	97.1
BettyP1029 #SC3 ENV(1=636,6=400)	025B1701.D	025B1702.D	025B1703.D	BETTYP957_EO.M	2.74	2.73	2.74	0.0	75.3	73.3	73.5	1.7	74.1	78.8	94.0
BettyP1029 #SC3 ENV(1=636,6=400)	025B0902.D	025B0903.D	025B0904.D	BETTYP1042_EO.M	2.73	2.73	2.73	0.0	77.9	77.8	77.7	0.2	77.8	78.8	98.8
BettyP1029 #SC3 ENV(1=636,6=400)	025B1501.D	025B1502.D	025B1503.D	BETTYP1042_EO.M	2.73	2.73	2.73	0.0	80.5	78.9	77.1	2.2	78.9	78.8	100
gummop1536 #EO3 ENV(1=600,4=410)	016F0702.D	016F0703.D	016F0704.D	GUMMOP1536F_EO.M	3.15	3.15	3.15	0.0	101	101	101	0.4	101	98.5	102
zero air blank #LB	008F0801.D	008F0802.D	008F0803.D	GUMMOP1536F_EO.M	NA	NA	NA	NA	0.513	0.513	0.513	0	0.513	ND	
gummop1536 #EO3 ENV(1=600,4=410)	016F1202.D	016F1203.D	016F1204.D	GUMMOP1536F_EO.M	3.15	3.15	3.16	0.1	106	106	110	2.3	108	98.5	109
gummop1536 #EO3 ENV(1=600,4=410)	016F1302.D	016F1303.D	016F1304.D	GUMMOP1536F_EO.M	3.15	3.15	3.15	0.0	109	107	107	1.1	108	98.5	109
gummop1536 #EO3 ENV(1=600,4=410)	016F2302.D	016F2303.D	016F2304.D	GUMMOP1536F_EO.M	3.15	3.15	3.15	0.0	106	107	106	0.7	107	98.5	108
gummop1536 #EO3 ENV(1=600,4=410)	016F0602.D	016F0603.D	016F0604.D	GUMMOP1536F_EO.M	3.14	3.14	3.14	0.0	106	106	105	0.5	106	98.5	108
gummop1536 #EO3 ENV(1=600,4=410)	016F0902.D	016F0903.D	016F0904.D	GUMMOP1536F_EO.M	3.15	3.15	3.15	0.0	101	101	102	0.4	101	98.5	103
gummop1536 #EO3 ENV(1=600,4=410)	016F0302.D	016F0303.D	016F0304.D	GUMMOP1536F_EO.M	3.14	3.14	3.14	0.0	100	100	100	0.2	100	98.5	102
gummop1536 #EO3 ENV(1=600,4=410)	016F1401.D	016F1402.D	016F1403.D	GUMMOP1536F_EO.M	3.15	3.15	3.14	0.0	97.5	98.3	99.3	0.9	98.4	98.5	99.9

=====  
 Calibration Table  
 =====

Calib. Data Modified : 11/20/2018 11:23:13 AM

Rel. Reference Window : 1.000 %  
 Abs. Reference Window : 0.000 min  
 Rel. Non-ref. Window : 1.000 %  
 Abs. Non-ref. Window : 0.000 min  
 Uncalibrated Peaks : using compound Ethylene oxide  
 Partial Calibration : Yes, identified peaks are recalibrated  
 Correct All Ret. Times: No, only for identified peaks

Curve Type : Linear  
 Origin : Connected  
 Weight : Quadratic (Amnt)

Recalibration Settings:  
 Average Response : Average all calibrations  
 Average Retention Time: Floating Average New 75%

Calibration Report Options :  
 Printout of recalibrations within a sequence:  
   Calibration Table after Recalibration  
   Normal Report after Recalibration  
 If the sequence is done with bracketing:  
   Results of first cycle (ending previous bracket)

Signal 1: FID2 B,

RetTime	Lvl	Amount	Area	Amt/Area	Ref Grp Name
[min]	Sig	[ppm]			
2.731	1	4.85000	1.67100	2.90245	Ethylene oxide
	2	24.26000	9.07357	2.67370	
	3	80.87000	28.53073	2.83449	
	4	242.60000	80.34795	3.01937	

More compound-specific settings:

Compound: Ethylene oxide  
 Time Window : From 2.685 min To 2.750 min

=====  
 Peak Sum Table  
 =====

\*\*\*No Entries in table\*\*\*  
 =====


---

---

### Calibration Curves

---

---



Ethylene oxide at exp. RT: 2.731

FID2 B,

Correlation: 0.99840

Residual Std. Dev.: 3.49505

Formula:  $y = mx + b$

m: 3.51485e-1

b: -1.28762e-2

x: Amount

y: Area

Calibration Level Weights:

Level 1 : 1


Level 2 : 0.039967

Level 3 : 0.003597

Level 4 : 0.0004

=====

Acq. Operator	: Justin Guenzler	Seq. Line	: 3
Acq. Instrument	: Betty	Location	: Vial 25
Injection Date	: 11/16/2018 11:26:24 AM	Inj	: 1
		Inj Volume	: 250 µl
Acq. Method	: C:\GC\2018\BETTY\QUARTER 4\BETTYP957\GC142P133_CAL.M		
Last changed	: 10/18/2017 9:57:08 AM by Justin Guenzler		
Analysis Method	: C:\GC\2018\BETTY\METHODS\BETTYP957_EO.M		
Last changed	: 11/21/2018 12:33:46 PM by Nicholas Traversa		
ECM Server	: http://s022vas01/Enthalpy		
ECM Operator	: Nicole West		
ECM Path	: GC\2018\Betty\Quarter 4\BETTYP957.SC.SSIzip		
ECM Version	: 2 (modified after loading)		



=====

External Standard Report

=====

Sorted By : Signal  
Calib. Data Modified : 11/20/2018 11:23:13 AM  
Multiplier : 1.0000  
Dilution : 1.0000  
Use Multiplier & Dilution Factor with ISTDs

Signal 1: FID2 B,

RetTime [min]	Type	Area [pA*s]	Amt/Area	Amount [ppm]	Grp	Name
2.730	BB	80.43060	2.84553	228.86729		Ethylene oxide

Totals : 228.86729

Uncalibrated Peaks : using compound Ethylene oxide

RetTime [min]	Type	Area [pA*s]	Amt/Area	Amount [ppm]	Grp	Name
7.784	BB	3.49074e-1	2.86672	1.00070	?	

Uncalib. totals : 1.00070

=====

Summed Peaks Report

=====


Signal 1: FID2 B,

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP957 #EO4 ENV(1=0,6=499)  
Sequence Name BETTYP957 ver.2  
Inj Data File 025B0302.D  
File Location GC/2018/Betty/Quarter 4  
Injection Date 11/16/2018 11:51 AM  
File Modified 11/20/2018 9:39 AM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 2 of 4  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 11/19/2018 9:56 AM  
Printed 11/21/2018 12:24 PM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	80.4440	29.9562	228.905	1	228.905	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP957 #EO4 ENV(1=0,6=499)  
Sequence Name BETTYP957 ver.2  
Inj Data File 025B0303.D  
File Location GC/2018/Betty/Quarter 4  
Injection Date 11/16/2018 12:15 PM  
File Modified 11/20/2018 9:39 AM  
Instrument Betty  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 3 of 4  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 11/19/2018 9:56 AM  
Printed 11/21/2018 12:24 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	80.1692	29.8403	228.124	1	228.124	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP957 #EO2 ENV(1=954,6=150)  
Sequence Name BETTYP957 ver.2  
Inj Data File 025B0502.D  
File Location GC/2018/Betty/Quarter 4  
Injection Date 11/16/2018 3:08 PM  
File Modified 11/20/2018 9:39 AM  
Instrument Betty  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 2 of 4  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 11/19/2018 9:56 AM  
Printed 11/21/2018 12:24 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	9.07502	3.29159	25.8557	1	25.8557	ppm

## Chromatogram Report

Sample Name BettyP957 #EO2 ENV(1=954,6=150)  
Sequence Name BETTYP957 ver.2  
Inj Data File 025B0503.D  
File Location GC/2018/Betty/Quarter 4  
Injection Date 11/16/2018 3:33 PM  
File Modified 11/20/2018 9:39 AM  
Instrument Betty  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 3 of 4  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 11/19/2018 9:56 AM  
Printed 11/21/2018 12:24 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	9.12168	3.31035	25.9884	1	25.9884	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP957 #EO2 ENV(1=954,6=150)  
Sequence Name BETTYP957 ver.2  
Inj Data File 025B0504.D  
File Location GC/2018/Betty/Quarter 4  
Injection Date 11/16/2018 3:58 PM  
File Modified 11/20/2018 9:39 AM  
Instrument Betty  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 4 of 4  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 11/19/2018 9:56 AM  
Printed 11/21/2018 12:24 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	9.02403	3.29227	25.7106	1	25.7106	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP957 #EO1 ENV(1=2770.12,6=80)  
Sequence Name BETTYP957 ver.2  
Inj Data File 025B0606.D  
File Location GC/2018/Betty/Quarter 4  
Injection Date 11/16/2018 6:26 PM  
File Modified 11/20/2018 9:40 AM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 6 of 8  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 11/19/2018 9:56 AM  
Printed 11/21/2018 12:24 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.74	1.68674	0.59709	4.83541	1	4.83541	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP957 #EO1 ENV(1=2770.12,6=80)  
Sequence Name BETTYP957 ver.2  
Inj Data File 025B0607.D  
File Location GC/2018/Betty/Quarter 4  
Injection Date 11/16/2018 6:50 PM  
File Modified 11/20/2018 9:40 AM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 7 of 8  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 11/19/2018 9:56 AM  
Printed 11/21/2018 12:24 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.74	1.66064	0.59885	4.76061	1	4.76061	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP957 #EO1 ENV(1=2770.12,6=80)  
Sequence Name BETTYP957 ver.2  
Inj Data File 025B0608.D  
File Location GC/2018/Betty/Quarter 4  
Injection Date 11/16/2018 7:15 PM  
File Modified 11/20/2018 9:40 AM  
Instrument Betty  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 8 of 8  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 11/19/2018 9:56 AM  
Printed 11/21/2018 12:24 PM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.74	1.66563	0.59604	4.77489	1	4.77489	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP957 #EO3 ENV(1=565.33,6=400)  
Sequence Name BETTYP957 ver.2  
Inj Data File 025B1802.D  
File Location GC/2018/Betty/Quarter 4  
Injection Date 11/19/2018 8:45 AM  
File Modified 11/20/2018 9:41 AM  
Instrument Betty  
Operator Nicholas Traversa

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 2 of 4  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 11/19/2018 9:56 AM  
Printed 11/21/2018 12:24 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	2.73	28.6763	10.6097	81.6228	1	81.6228	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP957 #EO3 ENV(1=565.33,6=400)  
Sequence Name BETTYP957 ver.2  
Inj Data File 025B1803.D  
File Location GC/2018/Betty/Quarter 4  
Injection Date 11/19/2018 9:10 AM  
File Modified 11/20/2018 9:41 AM  
Instrument Betty  
Operator Nicholas Traversa

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 3 of 4  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 11/19/2018 9:56 AM  
Printed 11/21/2018 12:24 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	2.73	28.5996	10.5987	81.4045	1	81.4045	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP957 #EO3 ENV(1=565.33,6=400)  
Sequence Name BETTYP957 ver.2  
Inj Data File 025B1804.D  
File Location GC/2018/Betty/Quarter 4  
Injection Date 11/19/2018 9:35 AM  
File Modified 11/20/2018 9:41 AM  
Instrument Betty  
Operator Nicholas Traversa

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 4 of 4  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 11/19/2018 9:56 AM  
Printed 11/21/2018 12:24 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	MM	2.73	28.3162	10.5413	80.5982	1	80.5982	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1029 ver.3  
Inj Data File 025B0101.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/7/2019 7:35 AM  
File Modified 2/14/2019 11:18 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number  
Injection Volume 250  
Injection 1 of 3  
Acquisition Method GC142P133\_CAL\_SHORT.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 2/14/2019 11:18 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	2.73	26.6351	9.85863	75.8154	1	75.8154	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1029 ver.3  
Inj Data File 025B0102.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/7/2019 7:47 AM  
File Modified 2/14/2019 11:18 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 2 of 3  
Acquisition Method GC142P133\_CAL\_SHORT.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 2/14/2019 11:18 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	26.9394	9.94203	76.6811	1	76.6811	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1029 ver.3  
Inj Data File 025B0103.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/7/2019 8:15 AM  
File Modified 2/14/2019 11:18 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 3 of 3  
Acquisition Method GC142P133\_CAL\_SHORT.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 2/14/2019 11:18 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	27.0040	9.95495	76.8648	1	76.8648	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1029 ver.3  
Inj Data File 025B1701.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/7/2019 1:34 PM  
File Modified 2/14/2019 11:20 AM  
Instrument  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 1 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 2/14/2019 11:18 AM  
Printed 2/18/2019 7:25 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.74	26.4582	9.84533	75.3119	1	75.3119	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1029 ver.3  
Inj Data File 025B1702.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/7/2019 1:59 PM  
File Modified 2/14/2019 11:20 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 2 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 2/14/2019 11:18 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	25.7623	9.57694	73.3321	1	73.3321	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1029 ver.3  
Inj Data File 025B1703.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/7/2019 2:24 PM  
File Modified 2/14/2019 11:20 AM  
Instrument  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 3 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP957\_EO.M  
Method Modified 2/14/2019 11:18 AM  
Printed 2/18/2019 7:25 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.74	25.8387	9.56792	73.5495	1	73.5495	ppm

=====  
 Calibration Table  
 =====

Calib. Data Modified : 2/14/2019 11:47:34 AM

Rel. Reference Window : 1.000 %  
 Abs. Reference Window : 0.000 min  
 Rel. Non-ref. Window : 1.000 %  
 Abs. Non-ref. Window : 0.000 min  
 Uncalibrated Peaks : using compound Ethylene oxide  
 Partial Calibration : Yes, identified peaks are recalibrated  
 Correct All Ret. Times: No, only for identified peaks

Curve Type : Linear  
 Origin : Connected  
 Weight : Quadratic (Amnt)

Recalibration Settings:  
 Average Response : Average all calibrations  
 Average Retention Time: Floating Average New 75%

Calibration Report Options :  
 Printout of recalibrations within a sequence:  
 Calibration Table after Recalibration  
 Normal Report after Recalibration  
 If the sequence is done with bracketing:  
 Results of first cycle (ending previous bracket)

Signal 1: FID2 B,

RetTime [min]	Lvl Sig	Amount [ppm]	Area	Amt/Area	Ref Grp Name
2.738	1 1	5.12000	1.79174	2.85756	Ethylene oxide
	2	25.60000	9.77407	2.61917	
	3	78.77000	30.85963	2.55253	
	4	256.00000	96.44357	2.65440	


More compound-specific settings:

Compound: Ethylene oxide  
 Time Window : From 2.691 min To 2.757 min

=====  
 Peak Sum Table  
 =====

\*\*\*No Entries in table\*\*\*  
 =====

Calibration Curves



Ethylene oxide at exp. RT: 2.738

FID2 B,

Correlation: 0.99980

Residual Std. Dev.: 1.70515

Formula:  $y = mx + b$

m:  $3.86577e-1$

b:  $-1.83523e-1$

x: Amount

y: Area

Calibration Level Weights:

Level 1 : 1

Level 2 : 0.04

Level 3 : 0.004225


Level 4 : 0.0004

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC4 ENV(1=0,6=400)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0201.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 7:00 AM  
File Modified 2/14/2019 12:43 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 1 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/14/2019 12:53 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	96.9863	34.4293	251.359	1	251.359	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC4 ENV(1=0,6=400)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0202.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 7:24 AM  
File Modified 2/14/2019 12:43 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 2 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/14/2019 12:53 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	95.6208	34.0494	247.827	1	247.827	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC4 ENV(1=0,6=400)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0203.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 7:49 AM  
File Modified 2/14/2019 12:43 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 3 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/14/2019 12:53 PM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	96.7236	34.4782	250.680	1	250.680	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0301.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 8:13 AM  
File Modified 2/14/2019 12:43 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 1 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/14/2019 12:53 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	31.0879	10.8264	80.8931	1	80.8931	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0302.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 8:38 AM  
File Modified 2/14/2019 12:43 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number  
Injection Volume  
Injection  
Acquisition Method  
Analysis Method  
Method Modified  
Printed  
Calibration  
Vial 25  
250  
2 of 3  
GC142P133\_CAL.M  
BETTYP1042\_EO.M  
2/14/2019 11:47 AM  
2/14/2019 12:53 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	30.7244	10.7262	79.9529	1	79.9529	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0303.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 9:03 AM  
File Modified 2/14/2019 12:43 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 3 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/14/2019 12:53 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	30.7665	10.7125	80.0616	1	80.0616	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC2 ENV(1=636,6=100)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0401.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 9:27 AM  
File Modified 2/14/2019 12:43 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 1 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/14/2019 12:53 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	9.68032	3.28394	25.5158	1	25.5158	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC2 ENV(1=636,6=100)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0402.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 9:52 AM  
File Modified 2/14/2019 12:44 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 2 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/14/2019 12:53 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	9.74881	3.30236	25.6930	1	25.6930	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC2 ENV(1=636,6=100)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0403.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 10:16 AM  
File Modified 2/14/2019 12:44 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number  
Injection Volume  
Injection  
Acquisition Method  
Analysis Method  
Method Modified  
Printed  
Calibration  
Vial 25  
250  
3 of 3  
GC142P133\_CAL.M  
BETTYP1042\_EO.M  
2/14/2019 11:47 AM  
2/14/2019 12:53 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	9.89309	3.35093	26.0662	1	26.0662	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC1 ENV(1=3462.65,6=100)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0501.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 10:41 AM  
File Modified 2/14/2019 12:44 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 1 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/14/2019 12:53 PM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.74	1.78751	0.58006	5.09649	1	5.09649	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC1 ENV(1=3462.65,6=100)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0502.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 11:06 AM  
File Modified 2/14/2019 12:44 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 2 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/14/2019 12:53 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.74	1.80940	0.58006	5.15530	1	5.15530	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC1 ENV(1=3462.65,6=100)  
Sequence Name BETTYP1042 ver.3  
Inj Data File 025B0503.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/14/2019 11:30 AM  
File Modified 2/14/2019 12:44 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 3 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/14/2019 12:53 PM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.74	1.77830	0.56343	5.07025	1	5.07025	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1042A ver.2  
Inj Data File 025B0902.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/15/2019 5:21 AM  
File Modified 2/15/2019 1:42 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 2 of 4  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	29.9468	10.2821	77.9412	1	77.9412	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1042A ver.2  
Inj Data File 025B0903.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/15/2019 5:45 AM  
File Modified 2/15/2019 1:42 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 3 of 4  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	29.8911	10.2110	77.7971	1	77.7971	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1042A ver.2  
Inj Data File 025B0904.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/15/2019 6:10 AM  
File Modified 2/15/2019 1:42 PM  
Instrument Betty  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 4 of 4  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	29.8343	10.2541	77.6502	1	77.6502	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1042A ver.2  
Inj Data File 025B1501.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/15/2019 11:41 AM  
File Modified 2/15/2019 1:44 PM  
Instrument Betty  
Operator Jennie Parrish

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 1 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/18/2019 7:25 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	30.9416	10.7390	80.5145	1	80.5145	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1042A ver.2  
Inj Data File 025B1502.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/15/2019 12:06 PM  
File Modified 2/15/2019 1:44 PM  
Instrument Betty  
Operator Jennie Parrish

Sample Type  
Vial Number Vial 25  
Injection Volume 250  
Injection 2 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/18/2019 7:25 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	30.3319	10.4041	78.9374	1	78.9374	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name BettyP1029 #SC3 ENV(1=636,6=400)  
Sequence Name BETTYP1042A ver.2  
Inj Data File 025B1503.D  
File Location GC/2019/Betty/Quarter 1  
Injection Date 2/15/2019 12:31 PM  
File Modified 2/15/2019 1:44 PM  
Instrument Betty  
Operator Jennie Parrish

Sample Type Calibration  
Vial Number Vial 25  
Injection Volume 250  
Injection 3 of 3  
Acquisition Method GC142P133\_CAL.M  
Analysis Method BETTYP1042\_EO.M  
Method Modified 2/14/2019 11:47 AM  
Printed 2/18/2019 7:25 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	2.73	29.6268	10.2687	77.1134	1	77.1134	ppm

=====

6890 GC METHOD

=====

OVEN

Initial temp:	40 C (On)	Maximum temp:	250 C
Initial time:	6.00 min	Equilibration time:	0.50 min
Ramps:			
#	Rate	Final temp	Final time
1	30.00	220	2.00
2	0 (Off)		
Post temp:	40 C	Cryo:	Off
Post time:	0.00 min	Cryo fault:	On
Run time:	14.00 min	Cryo timeout:	40.00 min (On)
		Quick cryo cool:	Off
		Ambient temp:	30 C

FRONT INLET (SPLIT/SPLITLESS)

Mode: Splitless  
Initial temp: 200 C (On)  
Pressure: 60.0 psi (On)  
Purge flow: 0.0 mL/min  
Purge time: 0.00 min  
Total flow: 12.3 mL/min  
Gas saver: Off  
Gas type: Helium

BACK INLET (SPLIT/SPLITLESS)

Mode: Split  
Initial temp: 200 C (On)  
Pressure: 11.6 psi (On)  
Split ratio: 5:1  
Split flow: 12.3 mL/min  
Total flow: 17.6 mL/min  
Gas saver: Off  
Gas type: Helium

COLUMN 1

Packed Column  
Model Number: 19808  
Description: Rt-ShinCarbon 2m x 1mm I  
Max temperature: 250 C  
Mode: constant pressure  
Pressure: 60.0 psi  
Inlet: Front Inlet  
Outlet: Front Detector  
Outlet pressure: ambient

COLUMN 2

Capillary Column  
Model Number: 10198  
Description: Rtx-1 30m x 0.32mm x 4um  
Max temperature: 250 C  
Nominal length: 30.0 m  
Nominal diameter: 320.00 um  
Nominal film thickness: 4.00 um  
Mode: constant flow  
Initial flow: 2.5 mL/min  
Nominal init pressure: 11.6 psi  
Average velocity: 39 cm/sec  
Inlet: Back Inlet  
Outlet: (other)  
Outlet pressure: ambient

FRONT DETECTOR (TCD)

Temperature: 275 C (On)  
Reference flow: 20.0 mL/min (On)  
Mode: Constant makeup flow  
Makeup flow: 10.0 mL/min (On)  
Makeup Gas Type: Helium  
Filament: On  
Negative polarity: On

BACK DETECTOR (FID)

Temperature: 250 C (On)  
Hydrogen flow: 60.0 mL/min (On)  
Air flow: 450.0 mL/min (On)  
Mode: Constant makeup flow  
Makeup flow: 40.0 mL/min (On)  
Makeup Gas Type: Nitrogen  
Flame: On  
Electrometer: On  
Lit offset: 2.0

SIGNAL 1

Data rate: 20 Hz  
Type: front detector  
Save Data: On

SIGNAL 2

Data rate: 20 Hz  
Type: back detector  
Save Data: On

THERMAL AUX 1

Use: Valve Box Heater  
Initial temp: 130 C (On)

VALVES

Valve 1 Gas Sampling  
Loop Volume: 0.250 mL

POST RUN

Post Time: 0.00 min

dified on: 5/5/2014 at 7:51:02 AM  
 Load Time: 0.10 min  
 Inject Time: 0.50 min  
 Inlet: Front Inlet  
 Valve 2 Gas Sampling  
 Loop Volume: 0.250 mL  
 Load Time: 0.10 min  
 Inject Time: 0.50 min  
 Inlet: Front Inlet

TIME TABLE		
Time(min)	Parameter & Setpoint	
3.00	Front Detector Polarity:	Off

=====

6890 GC METHOD

=====

OVEN

Initial temp: 40 C (On)	Maximum temp: 250 C
Initial time: 3.00 min	Equilibration time: 0.50 min
Ramps:	
# Rate Final temp Final time	CRYO (N2)
1 0 (Off)	Cryo: Off
Post temp: 40 C	Cryo fault: On
Post time: 0.00 min	Cryo timeout: 40.00 min (On)
Run time: 3.00 min	Quick cryo cool: Off
	Ambient temp: 30 C

FRONT INLET (SPLIT/SPLITLESS)	BACK INLET (SPLIT/SPLITLESS)
Mode: Splitless	Mode: Split
Initial temp: 200 C (On)	Initial temp: 200 C (On)
Pressure: 60.0 psi (On)	Pressure: 11.7 psi (On)
Purge flow: 0.0 mL/min	Split ratio: 5:1
Purge time: 0.00 min	Split flow: 12.3 mL/min
Total flow: 12.3 mL/min	Total flow: 17.6 mL/min
Gas saver: Off	Gas saver: Off
Gas type: Helium	Gas type: Helium

COLUMN 1	COLUMN 2
Packed Column	Capillary Column
Model Number: 19808	Model Number: 10198
Description: Rt-ShinCarbon 2m x 1mm I	Description: Rtx-1 30m x 0.32mm x 4um
Max temperature: 250 C	Max temperature: 250 C
Mode: constant pressure	Nominal length: 30.0 m
Pressure: 60.0 psi	Nominal diameter: 320.00 um
Inlet: Front Inlet	Nominal film thickness: 4.00 um
Outlet: Front Detector	Mode: constant flow
Outlet pressure: ambient	Initial flow: 2.5 mL/min
	Nominal init pressure: 11.7 psi
	Average velocity: 39 cm/sec
	Inlet: Back Inlet
	Outlet: (other)
	Outlet pressure: ambient

FRONT DETECTOR (TCD)	BACK DETECTOR (FID)
Temperature: 275 C (On)	Temperature: 250 C (On)
Reference flow: 20.0 mL/min (On)	Hydrogen flow: 60.0 mL/min (On)
Mode: Constant makeup flow	Air flow: 450.0 mL/min (On)
Makeup flow: 10.0 mL/min (On)	Mode: Constant makeup flow
Makeup Gas Type: Helium	Makeup flow: 40.0 mL/min (On)
Filament: On	Makeup Gas Type: Nitrogen
Negative polarity: On	Flame: On
	Electrometer: On
	Lit offset: 2.0

SIGNAL 1	SIGNAL 2
Data rate: 20 Hz	Data rate: 20 Hz
Type: front detector	Type: back detector
Save Data: On	Save Data: On

THERMAL AUX 1

Use: Valve Box Heater

Initial temp: 130 C (On)

VALVES	POST RUN
Valve 1 Gas Sampling	Post Time: 0.00 min
Loop Volume: 0.250 mL	

dified on: 2/17/2014 at 5:52:35 PM

Load Time: 0.10 min

Inject Time: 0.50 min

Inlet: Front Inlet

Valve 2 Gas Sampling

Loop Volume: 0.250 mL

Load Time: 0.10 min

Inject Time: 0.50 min

Inlet: Front Inlet

TIME TABLE

Time (min)	Parameter & Setpoint
------------	----------------------

# Calibration Table

Calib. Data Modified : Friday, February 1, 2019 9:36:29 AM

Rel. Reference Window : 0.000 %  
 Abs. Reference Window : 0.100 min  
 Rel. Non-ref. Window : 0.000 %  
 Abs. Non-ref. Window : 0.050 min  
 Uncalibrated Peaks : not reported  
 Partial Calibration : Yes, identified peaks are recalibrated  
 Correct All Ret. Times: No, only for identified peaks

Curve Type : Linear  
 Origin : Connected  
 Weight : Quadratic (Amnt)

Recalibration Settings:  
 Average Response : Average all calibrations  
 Average Retention Time: Floating Average New 75%

Calibration Report Options :  
 Printout of recalibrations within a sequence:  
 Calibration Table after Recalibration  
 Normal Report after Recalibration  
 If the sequence is done with bracketing:  
 Results of first cycle (ending previous bracket)


Signal 1: FID1 A,  
 Signal 2: FID2 B,

RetTime [min]	Lvl Sig	Amount [ppm]	Area	Amt/Area	Ref Grp Name
3.143	1 1	5.13000	9.75588e-1	5.25837	Ethylene Oxide
	2	44.10000	8.39759	5.25151	
	3	98.50000	18.81007	5.23656	
	4	242.60000	47.61048	5.09552	

## Peak Sum Table

\*\*\*No Entries in table\*\*\*

## Calibration Curves




Ethylene Oxide at exp. RT: 3.143  
 FID1 A,  
 Correlation: 0.99990  
 Residual Std. Dev.: 0.61510  
 Formula:  $y = mx + b$   
 m:  $1.92813e-1$   
 b:  $-1.48438e-2$   
 x: Amount  
 y: Area  
 Calibration Level Weights:  
 Level 1 : 1  
 Level 2 : 0.013532  
 Level 3 : 0.002712  
 Level 4 : 0.000447

## Chromatogram Report

## Enthalpy Analytical

Sample Name gum mop1536 #EO4 ENV(1=0,4=400)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0102.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 1:54 PM  
File Modified 2/1/2019 9:48 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	BB	3.15	48.0857	17.7231	249.467	1	249.467	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO4 ENV(1=0,4=400)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0103.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 2:12 PM  
File Modified 2/1/2019 9:48 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	BB	3.15	47.4155	17.5924	245.991	1	245.991	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO4 ENV(1=0,4=400)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0104.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 2:30 PM  
File Modified 2/1/2019 9:48 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 16  
Injection Volume 1000  
Injection 4 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	BB	3.15	47.3303	17.5278	245.549	1	245.549	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0202.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 3:06 PM  
File Modified 2/1/2019 9:48 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	BB	3.14	18.9348	7.01103	98.2798	1	98.2798	ppm

## Chromatogram Report

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0203.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 3:24 PM  
File Modified 2/1/2019 9:49 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	BB	3.14	18.6583	7.00661	96.8456	1	96.8456	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0204.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 3:42 PM  
File Modified 2/1/2019 9:49 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 4 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	BB	3.14	18.8371	7.00073	97.7733	1	97.7733	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO2 ENV(1=900,4=200)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0302.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 4:18 PM  
File Modified 2/1/2019 9:49 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	BB	3.15	8.43922	3.03728	43.8459	1	43.8459	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO2 ENV(1=900,4=200)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0303.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 4:36 PM  
File Modified 2/1/2019 9:49 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	BB	3.14	8.32955	3.08623	43.2771	1	43.2771	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO2 ENV(1=900,4=200)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0304.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 4:54 PM  
File Modified 2/1/2019 9:49 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 4 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	BB	3.15	8.42400	3.09429	43.7669	1	43.7669	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO1 ENV(1=3700,4=80)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0402.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 5:30 PM  
File Modified 2/1/2019 9:49 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 10  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	BB	3.15	0.97870	0.34003	5.15291	1	5.15291	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gummop1536 #EO1 ENV(1=3700,4=80)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0403.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 5:48 PM  
File Modified 2/1/2019 9:49 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 10  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	MF	3.13	0.99033	0.36870	5.21321	1	5.21321	ppm

## Analyst Peak Integration Comments


09:34:21 02/01/19 Justin Guenzler II - Baseline

## Chromatogram Report

## Enthalpy Analytical

Sample Name gum mop1536 #EO1 ENV(1=3700,4=80)  
Sequence Name GUMMOP1536 ver.2  
Inj Data File 016F0404.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/29/2019 6:06 PM  
File Modified 2/1/2019 9:49 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 4 of 10  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 1/30/2019 6:05 AM  
Printed 2/1/2019 9:55 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene Oxide	BB	3.15	0.95773	0.32835	5.04281	1	5.04281	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gummop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1536 ver.4  
Inj Data File 016F0702.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 3:32 AM  
File Modified 2/18/2019 6:19 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.15	19.4184	7.09083	100.788	1	100.788	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1536 ver.4  
Inj Data File 016F0703.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 3:50 AM  
File Modified 2/18/2019 6:20 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.15	19.5214	7.13197	101.322	1	101.322	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1536 ver.4  
Inj Data File 016F0704.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 4:08 AM  
File Modified 2/18/2019 6:20 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 4 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	19.4121	7.09346	100.755	1	100.755	ppm




## Chromatogram Report

Sample Name zero air blank #LB  
Sequence Name GUMMOP1536 ver.4  
Inj Data File 008F0801.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 4:24 AM  
File Modified 2/18/2019 6:20 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 8  
Injection Volume 1000  
Injection 1 of 5  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

## Chromatogram Report

Sample Name zero air blank #LB  
Sequence Name GUMMOP1536 ver.4  
Inj Data File 008F0802.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 4:41 AM  
File Modified 2/18/2019 6:20 AM  
Instrument  
Operator Justin Guenzler

## Enthalpy Analytical

Sample Type Sample  
Vial Number Vial 8  
Injection Volume 1000  
Injection 2 of 5  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

# Chromatogram Report

# Enthalpy Analytical

Sample Name zero air blank #LB  
Sequence Name GUMMOP1536 ver.4  
Inj Data File 008F0803.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/30/2019 4:57 AM  
File Modified 2/18/2019 6:20 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 8  
Injection Volume 1000  
Injection 3 of 5  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide		(3.15)				1		

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 016F1202.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 3:32 AM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.15	20.5149	7.62871	106.475	1	106.475	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 016F1203.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 3:50 AM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.15	20.4786	7.64183	106.286	1	106.286	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1537 ver.8  
Inj Data File 016F1204.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 6:35 AM  
File Modified 2/18/2019 6:21 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 16  
Injection Volume NA  
Injection 4 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.16	21.2143	7.95609	110.102	1	110.102	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gummop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 016F1302.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 3:06 PM  
File Modified 2/18/2019 6:24 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	20.9506	7.79058	108.734	1	108.734	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 016F1303.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 3:24 PM  
File Modified 2/18/2019 6:24 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	20.5939	7.71506	106.885	1	106.885	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 016F1304.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 1/31/2019 3:42 PM  
File Modified 2/18/2019 6:24 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 4 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	20.6142	7.56283	106.990	1	106.990	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 016F2302.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/1/2019 3:32 AM  
File Modified 2/18/2019 6:25 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.15	20.4678	7.75449	106.231	1	106.231	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 016F2303.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/1/2019 3:50 AM  
File Modified 2/18/2019 6:25 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.15	20.6920	7.78709	107.393	1	107.393	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1538A ver.4  
Inj Data File 016F2304.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/1/2019 4:08 AM  
File Modified 2/18/2019 6:25 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 4 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.15	20.5107	7.77969	106.453	1	106.453	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1540 ver.3  
Inj Data File 016F0602.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/1/2019 4:26 PM  
File Modified 2/18/2019 6:26 AM  
Instrument  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	20.4787	7.72867	106.287	1	106.287	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1540 ver.3  
Inj Data File 016F0603.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/1/2019 4:45 PM  
File Modified 2/18/2019 6:26 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	20.4263	7.65836	106.015	1	106.015	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name gummop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1540 ver.3  
Inj Data File 016F0604.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/1/2019 5:03 PM  
File Modified 2/18/2019 6:26 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 16  
Injection Volume 1000  
Injection 4 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	20.3026	7.60574	105.374	1	105.374	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1540 ver.3  
Inj Data File 016F0902.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/4/2019 3:32 AM  
File Modified 2/18/2019 6:27 AM  
Instrument  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.15	19.4251	7.24232	100.823	1	100.823	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1540 ver.3  
Inj Data File 016F0903.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/4/2019 3:50 AM  
File Modified 2/18/2019 6:27 AM  
Instrument  
Operator Justin Guenzler

Sample Type  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.15	19.4704	7.26195	101.058	1	101.058	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1540 ver.3  
Inj Data File 016F0904.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/4/2019 4:08 AM  
File Modified 2/18/2019 6:27 AM  
Instrument  
Operator Justin Guenzler

Sample Type Calibration  
Vial Number Vial 16  
Injection Volume 1000  
Injection 4 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.15	19.5717	7.31830	101.583	1	101.583	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1542 ver.4  
Inj Data File 016F0302.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/5/2019 3:32 AM  
File Modified 2/18/2019 6:30 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.14	19.2779	7.16754	100.059	1	100.059	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1542 ver.4  
Inj Data File 016F0303.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/5/2019 3:50 AM  
File Modified 2/18/2019 6:30 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.14	19.3623	7.12400	100.497	1	100.497	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1542 ver.4  
Inj Data File 016F0304.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/5/2019 4:08 AM  
File Modified 2/18/2019 6:30 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 4 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	BB	3.14	19.3383	7.21193	100.372	1	100.372	ppm




# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1542A ver.5  
Inj Data File 016F1401.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/6/2019 3:14 AM  
File Modified 2/18/2019 6:32 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 1 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.15	18.7886	6.93803	97.5214	1	97.5214	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1542A ver.5  
Inj Data File 016F1402.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/6/2019 3:32 AM  
File Modified 2/18/2019 6:32 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 2 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM




Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.15	18.9409	7.00738	98.3113	1	98.3113	ppm

# Chromatogram Report

# Enthalpy Analytical

Sample Name gum mop1536 #EO3 ENV(1=600,4=410)  
Sequence Name GUMMOP1542A ver.5  
Inj Data File 016F1403.D  
File Location GC/2019/Gummo/Quarter 1  
Injection Date 2/6/2019 3:50 AM  
File Modified 2/18/2019 6:32 AM  
Instrument  
Operator Justin Guenzler

Sample Type Sample  
Vial Number Vial 16  
Injection Volume 1000  
Injection 3 of 4  
Acquisition Method AQ\_GUMMOP1466.M  
Analysis Method GUMMOP1536F\_EO.M  
Method Modified 2/18/2019 6:19 AM  
Printed 2/18/2019 7:26 AM



Compound	Type	RT	Area	Height	Amount	DF	SampAmt	Unit
Ethylene oxide	VB	3.14	19.1265	7.06071	99.2738	1	99.2738	ppm

6890 GC METHOD

OVEN

Initial temp: 35 C (On)	Maximum temp: 250 C
Initial time: 2.20 min	Equilibration time: 0.20 min

Ramps:

#	Rate	Final temp	Final time
1	15.00	70	0.07
2	30.00	250	1.00
3	0 (Off)		

Post temp: 50 C  
Post time: 0.00 min  
Run time: 11.60 min

FRONT INLET (SPLIT/SPLITLESS)	BACK INLET (SPLIT/SPLITLESS)
Mode: Split	Mode: Split
Initial temp: 160 C (On)	Initial temp: 160 C (On)
Pressure: 4.9 psi (On)	Pressure: 4.7 psi (On)
Split ratio: 2:1	Split ratio: 5.1:1
Split flow: 3.9 mL/min	Split flow: 10.1 mL/min
Total flow: 12.0 mL/min	Total flow: 18.3 mL/min
Gas saver: Off	Gas saver: Off
Gas type: Hydrogen	Gas type: Hydrogen

COLUMN 1	COLUMN 2
Capillary Column	Capillary Column
Model Number: 10198	Model Number: 10970
Description: RTX-1 S/N - 1452472	Description: RTX-624 S/N - 926827
Max temperature: 280 C	Max temperature: 280 C
Nominal length: 30.0 m	Nominal length: 30.0 m
Nominal diameter: 320.00 um	Nominal diameter: 320.00 um
Nominal film thickness: 4.00 um	Nominal film thickness: 1.80 um
Mode: constant flow	Mode: constant flow
Initial flow: 2.0 mL/min	Initial flow: 2.0 mL/min
Nominal init pressure: 4.9 psi	Nominal init pressure: 4.7 psi
Average velocity: 38 cm/sec	Average velocity: 37 cm/sec
Inlet: Front Inlet	Inlet: Back Inlet
Outlet: Front Detector	Outlet: Back Detector
Outlet pressure: ambient	Outlet pressure: ambient

FRONT DETECTOR (FID)	BACK DETECTOR (FID)
Temperature: 250 C (On)	Temperature: 250 C (On)
Hydrogen flow: 40.0 mL/min (On)	Hydrogen flow: 40.0 mL/min (On)
Air flow: 450.0 mL/min (On)	Air flow: 450.0 mL/min (On)
Mode: Constant makeup flow	Mode: Constant makeup flow
Makeup flow: 45.0 mL/min (On)	Makeup flow: 45.0 mL/min (On)
Makeup Gas Type: Nitrogen	Makeup Gas Type: Nitrogen
Flame: On	Flame: On
Electrometer: On	Electrometer: On
Lit offset: 2.0	Lit offset: 2.0

SIGNAL 1	SIGNAL 2
Data rate: 20 Hz	Data rate: 20 Hz
Type: front detector	Type: back detector
Save Data: On	Save Data: On

THERMAL AUX 1

Use: Valve Box Heater

Initial temp: 120 C (On)

VALVES	POST RUN
Valve 1 Gas Sampling	Post Time: 0.00 min

EA Job # 0119-148 Page 161 of 167

modified on: 10/19/2018 at 9:50:33 AM

Loop Volume: 1.000 mL  
Load Time: 0.70 min  
Inject Time: 0.50 min  
Inlet: Front Inlet  
Valve 2 Gas Sampling  
Loop Volume: 1.000 mL  
Load Time: 0.70 min  
Inject Time: 0.50 min  
Inlet: Back Inlet  
Valve 7 Multiposition 16  
BCD input: inverted  
Switch Time: 1.0 sec

TIME TABLE

Time(min)	Parameter & Setpoint	
0.10	Multi-Valve Position:	1

=====

6890 GC METHOD

=====

OVEN

Initial temp:	35 C (On)	Maximum temp:	250 C
Initial time:	2.20 min	Equilibration time:	0.20 min
Ramps:			
#	Rate	Final temp	Final time
1	15.00	70	0.07
2	0 (Off)		
Post temp:	50 C		
Post time:	0.00 min		
Run time:	4.60 min		

FRONT INLET (SPLIT/SPLITLESS)

Mode: Split  
Initial temp: 160 C (On)  
Pressure: 4.9 psi (On)  
Split ratio: 2:1  
Split flow: 3.9 mL/min  
Total flow: 12.0 mL/min  
Gas saver: Off  
Gas type: Hydrogen

BACK INLET (SPLIT/SPLITLESS)

Mode: Split  
Initial temp: 160 C (On)  
Pressure: 4.7 psi (On)  
Split ratio: 5.1:1  
Split flow: 10.1 mL/min  
Total flow: 18.3 mL/min  
Gas saver: Off  
Gas type: Hydrogen

COLUMN 1

Capillary Column  
Model Number: 10198  
Description: RTX-1 S/N - 1452472  
Max temperature: 280 C  
Nominal length: 30.0 m  
Nominal diameter: 320.00 um  
Nominal film thickness: 4.00 um  
Mode: constant flow  
Initial flow: 2.0 mL/min  
Nominal init pressure: 4.9 psi  
Average velocity: 38 cm/sec  
Inlet: Front Inlet  
Outlet: Front Detector  
Outlet pressure: ambient

COLUMN 2

Capillary Column  
Model Number: 10970  
Description: RTX-624 S/N - 926827  
Max temperature: 280 C  
Nominal length: 30.0 m  
Nominal diameter: 320.00 um  
Nominal film thickness: 1.80 um  
Mode: constant flow  
Initial flow: 2.0 mL/min  
Nominal init pressure: 4.7 psi  
Average velocity: 37 cm/sec  
Inlet: Back Inlet  
Outlet: Back Detector  
Outlet pressure: ambient

FRONT DETECTOR (FID)

Temperature: 250 C (On)  
Hydrogen flow: 40.0 mL/min (On)  
Air flow: 450.0 mL/min (On)  
Mode: Constant makeup flow  
Makeup flow: 45.0 mL/min (On)  
Makeup Gas Type: Nitrogen  
Flame: On  
Electrometer: On  
Lit offset: 2.0

BACK DETECTOR (FID)

Temperature: 250 C (On)  
Hydrogen flow: 40.0 mL/min (On)  
Air flow: 450.0 mL/min (On)  
Mode: Constant makeup flow  
Makeup flow: 45.0 mL/min (On)  
Makeup Gas Type: Nitrogen  
Flame: On  
Electrometer: On  
Lit offset: 2.0

SIGNAL 1

Data rate: 20 Hz  
Type: front detector  
Save Data: On

SIGNAL 2

Data rate: 20 Hz  
Type: back detector  
Save Data: On

THERMAL AUX 1

Use: Valve Box Heater  
Initial temp: 120 C (On)

VALVES

Valve 1 Gas Sampling  
Loop Volume: 1.000 mL

POST RUN

Post Time: 0.00 min

dified on: 10/19/2018 at 9:51:39 AM

Load Time: 0.70 min  
Inject Time: 0.50 min  
Inlet: Front Inlet  
Valve 2 Gas Sampling  
Loop Volume: 1.000 mL  
Load Time: 0.70 min  
Inject Time: 0.50 min  
Inlet: Back Inlet  
Valve 7 Multiposition 16  
BCD input: inverted  
Switch Time: 1.0 sec

TIME TABLE

Time(min)	Parameter & Setpoint	
0.10	Multi-Valve Position:	1



THE LINDE GROUP

*Linde*

SHIPPED TO: Enthalpy Analytical Inc.  
3211 Bramer Drive  
Raleigh, NC 27604

PAGE: 1 of 1

## CERTIFICATE OF ANALYSIS

Sales#:	116533174	Cylinder Size:	152 (8" X 47.5")
Production#:	1460819	Cylinder #:	CC-314745
Certification Date:	Jul-13-2018	Cylinder Pressure:	2000 psig
P.O.#:	PO1022200	Cylinder Valve:	CGA 350 / Steel
Blend Type:	CERTIFIED	Cylinder Volume:	29.5 Liter
Material#:	24102763	Cylinder Material:	Aluminum
Traceability:	NIST by weight	Gas Volume:	4000 Liters
Expiration Date:	Jul-13-2019	Blend Tolerance:	5% Relative
Do NOT use under:	150 psig	Analytical Accuracy:	2% Relative

COMPONENT	CAS NUMBER	REQUESTED CONC	CERTIFIED CONC
Acetylene	74-86-2	250 ppm	255 ppm
Chloromethane	74-87-3	250 ppm	255 ppm
Vinyl Chloride	75-01-4	250 ppm	255 ppm
Dimethyl Ether	115-10-6	250 ppm	259 ppm
Ethylene Oxide	75-21-8	250 ppm	256 ppm
Methylene Chloride	75-09-2	250 ppm	256 ppm
Cyclohexane	110-82-7	250 ppm	257 ppm
Isooctane	540-84-1	250 ppm	258 ppm
Nitrogen	7727-37-9	Balance	Balance

ANALYST:

  
Lou Lorenzetti

DATE: Jul-13-2018

## CERTIFICATE OF ANALYSIS

### Grade of Product: CERTIFIED HYDROCARBON

Customer: \*MORRISVILLE, NC\* - MONTROSE ENVIRONMENTAL

GROUP

Part X02NI99C15ACKW8

Number:

Cylinder CC122424

Number:

Laboratory: 124 - LaPorte Mix (SAP) - TX

Analysis Mar 09, 2017

Date:

Lot Number: 126-400875670-1

Reference Number: 126-400875670-1

Cylinder Volume: 114.8 CF

Cylinder Pressure: 1602 PSIG

Valve Outlet: 350

Expiration Date: Mar 09, 2019

Traceability Statement: Hydrocarbon Process standards are NIST traceable either directly by weight or by comparison to Airgas laboratory standards that are directly NIST traceable by weight.

### CERTIFIED CONCENTRATIONS

Component	Requested Concentration	Reported Volume %	Accuracy
ETHYLENE OXIDE	250.0 PPM	242.6 PPM	+/- 2%
NITROGEN	99.98 %	99.97574 %	+/- 2%

Permanent Notes: MONTROSE ENVIRONMENTAL/ENTHALPY ANALYTICAL

Notes:

RECERTIFICATION

PO # 1007021

MONTROSE ENVIRONMENTAL / ENTHALPY ANALYTICAL



  
Approved for Release

**This Is The Last Page  
Of This Report.**



<b>SOP</b>	MP-30-014	<b>REVISION:</b>	.09	<b>PAGE:</b> 1 of 9
<b>TITLE:</b>	SOLID WASTE HANDLING & REMOVAL	<b>EFFECTIVE DATE:</b>	1/14/19	<b>SUPERSEDES:</b> MP-30-014.08

### 1.0 Purpose:

- 1.1 To describe the process for the disposal and tracking of solid waste.

### 2.0 Scope:

- 2.1 This procedure pertains to the discarding and handling of solid waste at all LifeNet Health facilities.

### 3.0 System Owner: Support Services

### 4.0 Approvers:

- 4.1 Director of Quality Systems
- 4.2 Director of Tissue Recovery
- 4.3 Director of Laboratory Sciences
- 4.4 Director of Operations
- 4.5 Director of Logistics
- 4.6 Director OPO Quality Systems
- 4.7 Support Services Manager
- 4.8 Process Engineering

### 5.0 Definitions:

- 5.1 **Non-Regulated Waste (NRW)** - A waste or material that does not contain or is not suspected of containing an infectious substance. This includes Recyclable waste.
- 5.2 **Regulated Medical Waste (RMW) [Red Bag]** - A waste or material known to contain or suspected of containing an infectious substance. This includes but not limited to:
  - 5.2.1 Laboratory wastes- All lab testing materials containing infectious agents.
  - 5.2.2 All Contaminated\* disposable Material, Equipment, and Instruments.
    - 5.2.2.1 \* *Material has to have the ability to release human blood or human body fluids in a liquid or semi- liquid state if compressed. Items that contain or that are caked with dried human blood or human body fluids and are capable of releasing these materials during handling. An item would be considered caked if it could release flakes or particles when handled. (9VAC 20-120-130)*
  - 5.2.3 Blood, Blood Products, Body Fluids.
  - 5.2.4 Sharps- Any items having a point or sharp edge or items that are likely to break during transportation and result in a point or sharp edge. (Examples include: needles, syringes, scalpel blades, blood tubes, slides, culture plates, etc.)
- 5.3 **Pathological Waste (PATH)**—Human or animal body parts, organs, and tissues.



<b>SOP</b>	MP-30-014	<b>REVISION:</b> .09	<b>PAGE:</b> 2 of 9
<b>TITLE:</b>	SOLID WASTE HANDLING & REMOVAL	<b>EFFECTIVE DATE:</b> 1/14/19	<b>SUPERSEDES:</b> MP-30-014.08

5.4 **Primary** - A function (personnel or dept.) that has the foremost responsibility to perform a step in the process, exceptions are permitted.

5.5 **Secondary** - A function (personnel or department) that could be used as consultant for the primary functions for a step in the process. This function may also perform the steps in the process to support primary functions.

### 6.0 Procedure

6.1 Process A: Handling of Non-regulated Waste




6.2 Process B: Handling of Regulated Medical Waste

6.3 Process C: Handling of Pathological Waste

6.4 Process D: Removal & Processing of Regulated/Pathological Waste Containers

6.5 Flowchart: Solid Waste Handling for Virginia Beach Facilities

#### PROCESS A: Non-regulated Waste

Responsibility (Who)	Process A (What)	Notes (How)
<u>Primary:</u> All Departments  <u>Secondary:</u> Contracted Cleaning Crew	 <pre> graph TD     A[Waste is generated] --&gt; B{A-1 Is waste regulated?}     B -- Yes --&gt; C[Process B]     B -- No --&gt; D{A-2 Does the waste contain confidential or proprietary information?}     D -- Yes --&gt; E[Place in appropriate container for shredding]     D -- No --&gt; F[ ]           </pre>	<ol style="list-style-type: none"> <li>All waste must be properly segregated and packaged to prevent leakage, tearing, and/or bursting under normal handling conditions.</li> <li>Safely remove excess air from trash bags to maximize utilization of the container and bins.</li> </ol>
<u>Primary:</u> All Departments  <u>Secondary:</u> Contracted Cleaning Crew		
<u>Primary:</u> All Departments  <u>Secondary:</u>		<ol style="list-style-type: none"> <li>All waste containing a donor name or any other identifier other than a donor number must be shredded.</li> </ol>

## Standard Operating Procedure

<b>SOP</b>	MP-30-014	<b>REVISION:</b>	.09	<b>PAGE:</b>	3 of 9
<b>TITLE:</b>	SOLID WASTE HANDLING & REMOVAL	<b>EFFECTIVE DATE:</b>	1/14/19	<b>SUPERSEDES:</b>	MP-30-014.08

Responsibility (Who)	Process A (What)	Notes (How)
<u>Primary:</u> All Departments  <u>Secondary:</u> Contracted Cleaning Crew	<pre> graph TD     A3{A-3 Is the waste recyclable?} -- Yes --&gt; B1[Place in a clear bag]     B1 --&gt; B2[Place in a blue receptacle]     B2 --&gt; A5_1[A-5]     A3 -- No --&gt; A4[A-4 Place into a clear bag]     A4 --&gt; A5_2([A-5 Move to respective area for transport when full.])           </pre>	
<u>Primary:</u> All Departments  <u>Secondary:</u> Contracted Cleaning Crew	<pre> graph TD     A4[A-4 Place into a clear bag]           </pre>	
<u>Primary:</u> All Departments  <u>Secondary:</u> Contracted Cleaning Crew	<pre> graph TD     A5([A-5 Move to respective area for transport when full.])           </pre>	

<b>SOP</b>	MP-30-014	<b>REVISION:</b>	.09	<b>PAGE:</b>	4 of 9
<b>TITLE:</b>	SOLID WASTE HANDLING & REMOVAL	<b>EFFECTIVE DATE:</b>	1/14/19	<b>SUPERSEDES:</b>	MP-30-014.08






### PROCESS B: Regulated Waste

Responsibility (Who)	Process B (What)	Notes (How)
<u>Primary:</u> All Departments  <u>Secondary:</u>	<div style="border: 1px solid black; padding: 5px; text-align: center;">Regulated Medical Waste generated</div>	1. All waste must be properly segregated and packaged to prevent leakage, tearing, and/or bursting under normal handling conditions. 2. Safely remove excess air from trash bags to maximize utilization of the container and bins.
<u>Primary:</u> All Departments  <u>Secondary:</u>	<div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">(B-1) Is it Pathological Waste?</div> <div style="margin-left: 20px;">Yes</div> <div style="border: 1px solid black; padding: 5px; display: inline-block;">Process C</div> </div>	
<u>Primary:</u> All Departments  <u>Secondary:</u>	<div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">(B-2) Does the waste contain sharps?</div> <div style="margin-left: 20px;">Yes</div> <div style="border: 1px solid black; padding: 5px; display: inline-block;">Place in appropriate puncture-proof container</div> </div>	
<u>Primary:</u> All Departments  <u>Secondary:</u>	<div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">(B-3) Place in Red Biohazard bag</div> <div style="margin-left: 20px;">No</div> <div style="border: 1px solid black; padding: 5px; display: inline-block;">Is the container a Five (5) quart size?</div> <div style="margin-left: 20px;">Yes</div> <div style="border: 1px solid black; padding: 5px; display: inline-block;">Place in transport container</div> </div>	
<u>Primary:</u> All Departments  <u>Secondary:</u>	<div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">(B-4) Place in transport container</div> <div style="margin-left: 20px;">No</div> <div style="border: 1px solid black; padding: 5px; display: inline-block;">Place supplier's barcode on the outside of the container</div> </div>	1. Ensure that all transport containers are completely closed. Do NOT overfill.
<u>Primary:</u> All Departments  <u>Secondary:</u>	<div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">(B-5) Place in designated area for pick up</div> </div>	
<u>Primary:</u> All Departments  <u>Secondary:</u>	<div style="text-align: center;"> <div style="border: 1px solid black; padding: 5px; display: inline-block;">Process D</div> </div>	



<b>SOP</b>	MP-30-014	<b>REVISION:</b>	.09	<b>PAGE:</b>	5 of 9
<b>TITLE:</b>	SOLID WASTE HANDLING & REMOVAL	<b>EFFECTIVE DATE:</b>	1/14/19	<b>SUPERSEDES:</b>	MP-30-014.08


### PROCESS C: Pathological Waste

Responsibility (Who)	Process C (What)	Notes (How)
<u>Primary:</u> All Departments  <u>Secondary:</u>		
<u>Primary:</u> All Departments  <u>Secondary:</u>		
<u>Primary:</u> All Departments  <u>Secondary:</u>		<ol style="list-style-type: none"> <li>Pathological waste must be disposed of in a container labeled as "pathological waste".</li> <li>If a cardboard container is used:               <ol style="list-style-type: none"> <li>The weight must not exceed 40 lbs.</li> <li>Line the container with a red bio-hazard bag.</li> <li>Absorbent material <b>MUST</b> be added to all liquids prior to placing them in the box.</li> <li>Place supplier's barcode on the outside of the box.</li> <li>Properly tie the bag and seal the lid of the box with packaging tape (H-style).</li> <li>Place checkmark in Pathological box on outside of container.</li> <li>If the container has a leak, it <b>MUST</b> be re-packaged.</li> </ol> </li> </ol>
<u>Primary:</u> All Departments  <u>Secondary:</u>		<ol style="list-style-type: none"> <li>Fill in Department and Bar Code information for each form.</li> <li>Place form in a document protector taped to the transport container at all facilities.</li> <li>Complete each line of the form as discard tissue is added to the form. Note: If the list of discarded tissue can be traced in SAP then you may state "Whole or Partial Donor- See SAP".</li> </ol>
<u>Primary:</u> All Departments  <u>Secondary:</u>		

## Standard Operating Procedure








<b>SOP</b>	MP-30-014	<b>REVISION:</b>	.09	<b>PAGE:</b>	6 of 9
<b>TITLE:</b>	SOLID WASTE HANDLING & REMOVAL	<b>EFFECTIVE DATE:</b>	1/14/19	<b>SUPERSEDES:</b>	MP-30-014.08

### PROCESS D: Removal & Processing of Regulated/Pathological Waste Containers

Responsibility (Who)	Process D (What)	Notes (How)
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments	 <pre> graph TD     A[Regulated/Pathological Waste pickup] --&gt; B["(D-1) Inspect containers"]     B --&gt; C{"(D-2) Is the container leaking or missing documentation?"}     C -- Yes --&gt; D[Contact department manager to correct]     C -- No --&gt; E["(D-3) Collect all Pathological Waste Discard Forms"]     D --&gt; E     E --&gt; F{"(D-4) Does your location have a scheduled pickup?"}     F -- No --&gt; G[Call vendor to schedule pickup]     F -- Yes --&gt; H["(D-5) Waste is picked up for disposal"]     G --&gt; H     H --&gt; End[ ]           </pre>	
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments		1. Ensure that each container labeled as pathological waste has a completed Pathological Waste Discard Form with corresponding barcode number and legible disposal entries.
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments		1. The department manager is responsible for correcting any documentation or improper sealing issues.
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments		
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments		1. If your facility does not have a reoccurring pickup schedule then you need to contact the appropriate disposal vendor to schedule a pickup.
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments		

## Standard Operating Procedure

<b>SOP</b>	MP-30-014	<b>REVISION:</b>	.09	<b>PAGE:</b>	7 of 9
<b>TITLE:</b>	SOLID WASTE HANDLING & REMOVAL	<b>EFFECTIVE DATE:</b>	1/14/19	<b>SUPERSEDES:</b>	MP-30-014.08


Responsibility (Who)	Process D (What)	Notes (How)
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments	 <pre>           graph TD             D6{D-6 Did any re-useable containers get picked up?} -- No --&gt; Request[Request a sufficient supply of the one-time use containers]             Request --&gt; D10_1[D-10]             D6 -- Yes --&gt; D10_1           </pre>	
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments		1. Ensure that the vendor delivers a quantity of empty containers that is equal to the amount of containers picked up for each type.
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments		1. Inspect each container for cleanliness, good working condition, properly labeled bio-hazard sticker, no presence of previously used barcode labels and ensure the container is empty.
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments	 <pre>           graph TD             D9{D-9 Are the containers acceptable?} -- No --&gt; Request[Request a replacement for the container]             Request --&gt; D10_2[D-10]             D9 -- Yes --&gt; D10_2           </pre>	
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments		1. Review the vendor's waste disposal manifest for accuracy then sign and date the document.
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments		1. Place supplier's barcode label on all re-usable containers. 2. Place "PATH Only" label on the 96 gallon containers
<u>Primary:</u> Support Services at Virginia Beach facilities <u>Secondary:</u> All Departments		1. Record the manifest document number, your initials and the pickup date in the bottom section of each Pathological waste disposal form (FMP-0019 or FMP-0369 for LNH-NW). 2. The manifest document and all Pathological waste forms for containers that were picked up should be stapled together for filing. 3. Review all Pathological waste forms for any GDP errors or incomplete fields. Notify the department manager for any required corrections.



<b>SOP</b>	MP-30-014	<b>REVISION:</b>	.09	<b>PAGE:</b>	8 of 9
<b>TITLE:</b>	SOLID WASTE HANDLING & REMOVAL	<b>EFFECTIVE DATE:</b>	1/14/19	<b>SUPERSEDES:</b>	MP-30-014.08

## 6.5 Flowchart: Solid Waste Handling for Virginia Beach Facilities

MP-30-014



## Standard Operating Procedure

<b>SOP</b>	MP-30-014	<b>REVISION:</b>	.09	<b>PAGE:</b>	9 of 9
<b>TITLE:</b>	SOLID WASTE HANDLING & REMOVAL	<b>EFFECTIVE DATE:</b>	1/14/19	<b>SUPERSEDES:</b>	MP-30-014.08

<b>Document Revision History</b>			
<i>Contact Document Control for information regarding previous revision levels.</i>			
Revised By	Effective Date	CCO	Summary of Changes
Cecilia Dolan	8/17/07	CC-07-476	Rev.000: PRO-SF-002.001 and PRO-SS-009.009 are obsolete and are being incorporated into MP-30-014 with some changes.
Elizabeth Ferraro	7/25/08	CC-08-532	Rev.001: Updated SOP to reflect all LifeNet Health locations.
Delvin E. Peeks	9/10/08	CC-08-661	Rev.002: Renamed the SOP to cover all solid waste. Added steps on the proper segregation and packaging of waste. Re-defined the difference between regulated and non-regulated waste. Added a flowchart for the transport & removal of waste.
Brandon Anderson/ Charity Holihan	3/31/10	CC-10-258	Rev.003: Converted to process flow format. Revised to reflect change to FMP-0019 Biohazard Waste Discard Form in order to track pathological waste only.
Brandon Anderson	1/12/11	CC-11-004	Rev.04: Added a step for labeling pathological Waste containers with a PATH label.
Brandon Anderson	3/6/17	#34582	Rev.05: Updated the logo
Shanna Mattson	5/25/17	#37061	Rev.06: Removed Virginia Beach from Process C so it would apply to all locations.
Brandon Anderson	9/1/17	#38543	Rev.07: Added FMP-0369 to the SOP for filing.
Brandon Anderson	2/2/18	#41310	Rev.08: Added note for Partial/ Whole donor discards on Step C-3. Added a review of Path forms to step D12.
Brandon Anderson	1/14/19	#47963	Rev.09: Updated A-3 to state clear bag instead of green bag per Audit# 35143