

Data Validation Report

Project #69420

Peoples Gas-Willow Street/Hawthorn Avenue

Water and Soil Vapor Sample Analyses
Performed by

Pace Analytical Services, Green Bay
and
TestAmerica, Inc., Pittsburgh
and
STAT Analysis Corporation Chicago, IL

Prepared for



Prepared by

SHEPHERD TECHNICAL SERVICES

February 10, 2014

Table of Contents

| | Page |
|--|------|
| 1.0 INTRODUCTION | 4 |
| 2.0 Inorganic Data Review | 6 |
| 2.1 Summary | 6 |
| 2.2 Sample Receipt and Methodology | 6 |
| 2.3 Calibration | 6 |
| 2.4 Blanks | 7 |
| 2.5 Laboratory Control Samples | 8 |
| 2.6 Matrix Spike/Matrix Spike Duplicates | 9 |
| 2.7 Internal Standards | 10 |
| 2.8 ICP/MS Serial Dilutions | 10 |
| 2.9 Field Duplicates | 11 |
| 3.0 Organic Data Review | 12 |
| 3.1 SW-846 Method 8260B – Purgeable Volatile Organic Compounds | 12 |
| 3.1.1 Summary | 12 |
| 3.1.2 Trip Blanks | 12 |
| 3.1.3 Method Blanks | 13 |
| 3.1.4 Calibration | 13 |
| 3.1.5 Internal Standard Areas | 14 |
| 3.1.6 Surrogate Compound Recoveries | 15 |
| 3.1.7 Matrix Spike/Matrix Spike Duplicates | 16 |
| 3.1.8 Laboratory Control Samples | 17 |
| 3.1.9 Field Duplicates | 18 |
| 3.2 SW-846 Method 8270C/SIM–PAHs | 19 |
| 3.2.1 Summary | 19 |
| 3.2.2 Method Blanks | 19 |
| 3.2.3 Calibration | 20 |
| 3.2.4 Internal Standard Areas | 20 |
| 3.2.5 Surrogate Compound Recoveries | 21 |
| 3.2.6 Matrix Spike/Matrix Spike Duplicates | 22 |
| 3.2.7 Laboratory Control Samples | 23 |
| 3.2.8 Field Duplicates | 24 |
| 4.0 Vapor Sample Analyses | 25 |
| 4.1 EPA Method TO-15: Volatile Organic Compounds (VOCs) | 25 |
| 4.1.1 Summary | 25 |
| 4.1.2 Method Blanks | 26 |
| 4.1.3 Calibration | 26 |
| 4.1.4 Surrogate Compound Recoveries | 27 |
| 4.1.5 Laboratory Control Samples | 27 |
| 4.1.6 Matrix Spike/Matrix Spike Duplicates | 27 |
| 4.1.7 Field Duplicates | 28 |
| 4.2 EPA Method 3C: Oxygen, Carbon Dioxide, and Methane | 30 |
| 4.2.1 Summary | 30 |
| 4.2.2 Method Blanks | 30 |
| 4.2.3 Calibration | 30 |
| 4.2.4 Surrogate Compound Recoveries | 30 |
| 4.2.5 Laboratory Control Samples | 31 |
| 4.2.6 Matrix Spike/Matrix Spike Duplicates | 31 |
| 4.2.7 Field Duplicates | 32 |

List of Tables

| | Page |
|---|------|
| Table 1-1. Sample/SDG Cross Reference | 5 |
| Table 2-1. Water Inorganic Analytes and Methods Summary | 6 |
| Table 2-2. Water Method 6020 Method Blank Results Summary | 7 |
| Table 2-3. Water EPA Method OIA-1667 Method Blank Results Summary | 8 |
| Table 2-4. Water Method 6020 LCS Results Summary | 8 |
| Table 2-5. Water EPA Method OIA-1667 LCS Results Summary | 8 |
| Table 2-6. Water Method 6020 MS/MSD Sample Recoveries | 9 |
| Table 2-6. Water Method 6020 MS/MSD Sample Recoveries Cont | 9 |
| Table 2-7. Water EPA Method OIA-1667 MS/MSD Sample Recoveries | 9 |
| Table 2-8. Method 6020 Field Dup Recoveries | 11 |
| Table 2-9. Water EPA Method OIA-1667 Field Dup Recoveries | 11 |
| Table 2-9. Water EPA Method OIA-1667 Field Dup Recoveries Cont. | 11 |
| Table 3-1. Organic Analytes and Methods Summary | 12 |
| Table 3-2. Water Method 8260B Method Blank Results Summary | 13 |
| Table 3-3. Water Method 8260B Surrogate Recoveries | 15 |
| Table 3-4. Water Method 8260B MS/MSD Sample Recoveries | 16 |
| Table 3-5. Water Method 8260B LCS Summary | 17 |
| Table 3-6. Water Method 8260B Field Dup Results | 18 |
| Table 3-6. Water Method 8260B Field Dup Results Cont | 18 |
| Table 3-7. Water Method 8270-SIM Method Blank Results Summary | 19 |
| Table 3-8. Water Method 8270-SIM Surrogate Recoveries | 21 |
| Table 3-9. Water Method 8270-SIM MS/MSD Sample Recoveries | 22 |
| Table 3-10. Water Method 8270-SIM LCS Results Summary | 23 |
| Table 3-11. Water Method 8270-SIM Field Dup Results | 24 |
| Table 3-11. Water Method 8270-SIM Field Dup Results Cont | 24 |
| Table 4-1. Vapor Phase Analytes and Methods Summary | 25 |
| Table 4-2. EPA TO-15 Method Blank Summary | 26 |
| Table 4-3. EPA TO-15 Laboratory Control Sample Summary | 27 |
| Table 4-4. EPA TO-15 Field Dup Sample Summary | 28 |
| Table 4-4. EPA TO-15 Field Dup Sample Summary Cont | 29 |
| Table 4-5. EPA Method 3C Method Blank Summary | 30 |
| Table 4-6. EPA Method 3C Laboratory Control Sample Summary | 31 |
| Table 4-7. EPA Method 3C Field Dup Sample Summary | 32 |
| Table 4-7. EPA Method 3C Field Dup Sample Summary Cont | 32 |

1.0 INTRODUCTION

All data validation was performed by Shepherd Technical Services following US EPA National Functional Guidelines (NFG), where applicable, using electronic deliverables. Guidance and requirements appearing in the NRT Multi-Site Quality Assurance Project Plan, Rev. 2, 2007 ("Multi-Site QAPP") were also used in the validation process.

STAT Analysis Corporation performed the sample analyses on the soil vapor samples. The laboratory maintains accreditation under the Illinois EPA Environmental Laboratory Accreditation Program (IEPA ELAP #100445). The laboratory is also accredited under the National Environmental Laboratory Accreditation Program (NELAP) by the Oregon Environmental Laboratory Accreditation Program (ORELAP #IL300001).

Pace Analytical Services, Inc., Green Bay, WI performed the analyses for metals, PAHs, and PVOCs on the groundwater samples. The Pace Green Bay laboratory maintains certification under the Illinois EPA Laboratory Accreditation Program (ID #200050). The Pace laboratory is also accredited under the National Environmental Laboratory Accreditation Program (NELAP) by the Florida Department of Health Environmental Laboratory Certification Program (ID #E87948).

Analyses for Available Cyanide were performed by the TestAmerica Pittsburgh laboratory. TestAmerica Pittsburgh maintains accreditation under the National Environmental Laboratory Accreditation Program (NELAP) by the Pennsylvania Department of Environmental Protection Laboratory Accreditation Program (Certificate Number 008, ID#2-00416) as well as the Illinois EPA Environmental Laboratory Accreditation Program (IEPA ELAP #200005).

The laboratories provided all analytical data, including all internal laboratory QC results in an electronic deliverable format to facilitate the validation process.

A total of 24 aqueous samples including 4 field blanks and 14 soil vapor samples were collected December 17, 2013 to December 20, 2013 at the Peoples Gas-Willow Street/Hawthorne Avenue sites. Samples were organized into 18 sample delivery groups (SDGs, or laboratory lot numbers). Samples were organized into four sample delivery groups (SDG or laboratory lot number) for the analyses by the PACE laboratory and nine SDGs by the

TestAmerica laboratory and five SDGs by STAT laboratory. Samples were analyzed for the indicated parameters using the methods listed in Table 1-1

Table 1-1. Sample/SDG Cross Reference

| Matrix | Field ID | STAT/PACE Sample ID | TestAmerica Sample ID | EPA 3C | EPA TO- 15 | EPA 6020 | EPA 8260 | EPA 8270 by SIM | OIA- 1677 |
|-------------|-----------|------------------------|--------------------------|-----------|---------------|-------------|-------------|--------------------------|--------------|
| Air | 121813007 | 13120429-001 | | X | X | | | | |
| | 121813008 | 13120429-002 | | X | X | | | | |
| | 121813011 | 13120431-001 | | X | X | | | | |
| | 121813014 | 13120429-003 | | X | X | | | | |
| | 121813016 | 13120430-001 | | X | X | | | | |
| | 121913019 | 13120466-001 | | X | X | | | | |
| | 121913021 | 13120466-002 | | X | X | | | | |
| | 121913022 | 13120466-003 | | X | X | | | | |
| | 121913024 | 13120466-004 | | X | X | | | | |
| | 121913025 | 13120466-005 | | X | X | | | | |
| | 121913026 | 13120466-006 | | X | X | | | | |
| | 121913028 | 13120467-003 | | X | X | | | | |
| | 121913030 | 13120467-002 | | X | X | | | | |
| | 121913031 | 13120467-001 | | X | X | | | | |
| GroundWater | 121713001 | 4090191001 | 180-28205-1 | | | X | X | X | X |
| | 121713002 | 4090191002 | 180-28205-2 | | | X | X | X | X |
| | 121713003 | 4090191003 | 180-28205-3 | | | X | X | X | X |
| | 121713004 | 4090191004 | 180-28205-4 | | | X | X | X | X |
| | 121713005 | 4090191005 | | | | | X | | |
| | 121813006 | 4090245001 | 180-28280-1 | | | X | X | X | X |
| | 121813009 | 4090245008 | 180-28276-1 | | | X | X | X | X |
| | 121813010 | 4090245006 | 180-28279-1 | | | X | X | X | X |
| | 121813012 | 4090245002 | 180-28280-2 | | | X | X | X | X |
| | 121813013 | 4090245003 | 180-28280-3 | | | X | X | X | X |
| | 121813015 | 4090245007 | 180-28279-2 | | | X | X | X | X |
| | 121813017 | 4090245004 | 180-28280-4 | | | X | X | X | X |
| | 121813018 | 4090245005 | | | | | X | | |
| | 121913020 | 4090328001 | 180-28336-1 | | | X | X | X | X |
| | 121913023 | 4090328002 | 180-28336-2 | | | X | X | X | X |
| | 121913027 | 4090326001 | 180-28338-1 | | | X | X | X | X |
| | 121913029 | 4090326002 | 180-28338-2 | | | X | X | X | X |
| | 121913032 | 4090325001 | 180-28340-1 | | | X | X | X | X |
| | 121913033 | 4090328003 | | | | | X | | |
| | 122013034 | 4090400001 | 180-28381-1 | | | X | X | X | X |
| | 122013035 | 4090400002 | 180-28381-2 | | | X | X | X | X |

| | | | | | | |
|-----------|------------|-------------|---|---|---|---|
| 122013036 | 4090400003 | 180-28380-1 | X | X | X | X |
| 122013037 | 4090400004 | 180-28380-2 | X | X | X | X |
| 122013038 | 4090400005 | | | X | | |

2.0 INORGANIC DATA REVIEW

2.1 Summary

Blank, spiked, and duplicate results were provided. Overall, QC data indicated acceptable precision and accuracy. The results of the QC review are presented below.

2.2 Sample Receipt and Methodology

The aqueous samples were analyzed for inorganic parameters following the methods cited in the table 2-1.

Table 2-1. Water Inorganic Analytes and Methods Summary

| Analytical Method | Analytes |
|-------------------|-------------------|
| EPA 6020 | Metals |
| EPA OIA-1677 | Available Cyanide |

Generally, the samples arrived at the laboratories properly preserved and in good condition. A few of the available cyanide SDGs were noted for a Saturday delivery but did not arrive until Monday Dec 23. However, no data are qualified based upon this since sample receipt temperatures were still within the required specifications for thermal preservation. All samples were analyzed within the prescribed holding times where holding times have been defined.

2.3 Calibration

Initial instrument calibrations for each of the methods were all within acceptance criteria.

All of the initial calibration verification checks (ICVs) for these analyses met the $\pm 10\%$ acceptance criterion used by the laboratory and required by the methods. No data are qualified as a consequence of the initial calibration verification data.

The laboratory also performed the requisite interference checks (ICS A, ICS AB) with each calibration. All of the interference checks gave acceptable

results. Hence, no data are qualified as a consequence of the interference check sample data.

Continuing calibration verification checks were performed at the required frequencies. All of the continuing calibration verification checks (CCVs) for these analyses met the $\pm 10\%$ acceptance criterion used by the laboratory and required by the methods. No data are qualified as a consequence of the continuing calibration data.

2.4 Blanks

For SDG 4090191 initial and continuing calibration blanks (ICBs/CCBs) for antimony and lead gave values slightly above the limit of detection but below the reporting limit. The effected sample results were detected at greater than ten times the level of contamination, therefore no samples will be qualified based on this.

The initial and continuing calibration blanks (ICBs/CCBs) for available cyanide all gave results below the limit of detection. Therefore no data are qualified as a consequence of the calibration blank data.

Method blanks were prepared for each batch of samples prepared for analysis.

One batch had copper in the method blank. For SDG 4090191 copper gave a value slightly above the limit of detection but below the reporting limit. The effected sample result was detected at greater than ten times the level of contamination; therefore no samples will be qualified based on this.

The method blank for available cyanide all gave results below the limit of detection. Therefore, no data are qualified as a consequence of the method blank data.

The method blank results are summarized in Table 2-2 and 2-3.

Table 2-2. Water Method 6020 Method Blank Results Summary

| <i>Test Batch</i> | <i>Analyte</i> | <i>Units</i> | <i>Result</i> |
|-------------------|----------------|--------------|---------------|
| 150406 | Antimony | µg/L | 1.0 U |
| | Beryllium | µg/L | 1.0 U |
| | Copper | µg/L | 0.27 J |
| | Lead | µg/L | 1.0 U |
| 150917 | Lead | µg/L | 1.0 U |

Table 2-3. Water EPA Method OIA-1667 Method Blank Results Summary

| <i>Test Batch</i> | <i>Analyte</i> | <i>Units</i> | <i>Result</i> |
|-------------------|-------------------|--------------|---------------|
| 180-93124 | Available cyanide | mg/L | 0.0020 U |
| 180-93210 | Available cyanide | mg/L | 0.0020 U |

2.5 Laboratory Control Samples

Laboratory control samples (LCS) were analyzed with each of the data sets.

Laboratory control samples were prepared using commercially available reference materials.

The recovery limits used by the laboratory for LCS results are either those given in the method guidance or are based upon laboratory performance. No results exceeded these criteria; therefore, there is no need to qualify any results based on the LCS results.

Recoveries are given along with the acceptance limits in Tables 2-4 and 2-5.

Table 2-4. Water Method 6020 LCS Results Summary

| <i>QC Batch</i> | <i>Analyte</i> | <i>Recovery Limits (%)</i> | | <i>Spike (µg/L)</i> | <i>Result (µg/L)</i> | <i>Recovery</i> |
|-----------------|----------------|----------------------------|--------------|---------------------|----------------------|-----------------|
| | | <i>Lower</i> | <i>Upper</i> | | | |
| 150406 | Antimony | 80 | 120 | 500 | 514 | 103 |
| | Beryllium | 80 | 120 | 500 | 508 | 102 |
| | Copper | 80 | 120 | 500 | 499 | 100 |
| | Lead | 80 | 120 | 500 | 515 | 103 |
| 150917 | Lead | 80 | 120 | 500 | 508 | 102 |

Table 2-5. Water EPA Method OIA-1667 LCS Results Summary

| <i>QC Batch for OIA-1677</i> | <i>Analyte</i> | <i>Recovery Limits (%)</i> | | <i>Spike (mg/L)</i> | <i>Result (mg/L)</i> | <i>Recovery</i> |
|------------------------------|-------------------|----------------------------|--------------|---------------------|----------------------|-----------------|
| | | <i>Lower</i> | <i>Upper</i> | | | |
| 180-93124 | Available cyanide | 82 | 132 | 0.100 | 0.101 | 101 |
| 180-93210 | Available cyanide | 82 | 132 | 0.100 | 0.0984 | 98 |
| | Available cyanide | 82 | 132 | 0.100 | 0.102 | 102 |

2.6 Matrix Spike/Matrix Spike Duplicates

Matrix spike/matrix spike duplicate (MS/MSD) analyses were evaluated for each of the parameters at appropriate frequencies. On several occasions, the laboratory used non-project specific sample as matrix spike samples to satisfy batch QC requirements. However, only project requested MS/MSD results are included in this report.

No recoveries for 6020 or Available Cyanide fell outside of the limits required by the analytical method. Therefore no data are qualified as a consequence of the MS/MSD data.

The MS/MSD data are given in Tables 2-6 and 2-7.

Table 2-6. Water Method 6020 MS/MSD Sample Recoveries

| <i>Analyte</i> | <i>MS Sample ID: 121713001</i> | | | <i>MSD Sample ID: 121713001</i> | | | <i>RPD</i> | <i>Lab Sample Result (µg/L)</i> | <i>Max RPD</i> |
|----------------|------------------------------------|---------------------------------|--------------------|-------------------------------------|----------------------------------|--------------------|------------|---|--------------------|
| | <i>Spike (µg/L)</i> | <i>MS Result (µg/L)</i> | <i>Rec (%)</i> | <i>Spike (µg/L)</i> | <i>MSD Result (µg/L)</i> | <i>Rec (%)</i> | | | |
| Antimony | 500 | 514 | 103 | 500 | 520 | 104 | 1 | 0.34J | 20 |
| Beryllium | 500 | 488 | 98 | 500 | 489 | 98 | 0 | 0.15 U | 20 |
| Copper | 500 | 459 | 92 | 500 | 462 | 92 | 1 | 0.70 J | 20 |
| Lead | 500 | 520 | 104 | 500 | 527 | 105 | 1 | 0.27J | 20 |

Table 2-6. Water Method 6020 MS/MSD Sample Recoveries Cont

| <i>Analyte</i> | <i>MS Sample ID: 121813015</i> | | | <i>MSD Sample ID: 121813015</i> | | | <i>RPD</i> | <i>Lab Sample Result (µg/L)</i> | <i>Max RPD</i> |
|----------------|------------------------------------|---------------------------------|--------------------|-------------------------------------|----------------------------------|--------------------|------------|---|--------------------|
| | <i>Spike (µg/L)</i> | <i>MS Result (µg/L)</i> | <i>Rec (%)</i> | <i>Spike (µg/L)</i> | <i>MSD Result (µg/L)</i> | <i>Rec (%)</i> | | | |
| Lead | 500 | 509 | 102 | 500 | 503 | 101 | 1 | 0.13 J | 20 |

Table 2-7. Water EPA Method OIA-1667 MS/MSD Sample Recoveries

| <i>Analyte</i> | <i>MS Sample ID: 121813015</i> | | | <i>MSD Sample ID: 121813015</i> | | | <i>RPD</i> | <i>Lab Sample Result (mg/L)</i> | <i>Max RPD</i> |
|-------------------|------------------------------------|---------------------------------|--------------------|-------------------------------------|----------------------------------|--------------------|------------|---|--------------------|
| | <i>Spike (mg/L)</i> | <i>MS Result (mg/L)</i> | <i>Rec (%)</i> | <i>Spike (mg/L)</i> | <i>MSD Result (mg/L)</i> | <i>Rec (%)</i> | | | |
| Available cyanide | 0.100 | 0.0987 | 99 | 0.100 | 0.101 | 100 | 2 | 0.0020 U | 20 |

2.7 Internal Standards

The National Functional Guidelines for Inorganic Data Review, October 2004 requires the relative intensity (%RI) for ICP/MS internal standards to fall within 60-125% for each sample analysis relative to the calibration standards. All internal standards met this requirement so no data will be qualified based on internal standards for ICP/MS.

2.8 ICP/MS Serial Dilutions

Serial dilution tests were performed by the laboratory on an analytical batch basis. However, only one project specific sample from this data set was subject to the serial dilution test.

All serial dilution tests met the acceptance criterion defined in the test method for all of the metals. Consequently no results are qualified due to serial dilution failures.

2.9 Field Duplicates

Field duplicates were collected and analyzed for the inorganic parameters. Field duplicates generally show excellent agreement for all of the analytes where the values are above five times the sample quantitation limit. Precision is only calculated where both the sample and the duplicate sample gave a positive result. Duplicate "NDs", however, are reported with 0% RPDs.

Criteria for evaluating field duplicate precision is provided in the Multi-Site QAPP Addendum dated March 12, 2012. Worksheet #28 of that addendum defines an upper limit, for values greater than five times the quantitation limit, at 30% RPD for precision between field duplicate values for inorganic parameters.

None of the field duplicates gave RPD values exceeding the 30% RPD limit specified in the QAPP Addendum. Therefore no data are qualified as a consequence of the duplicate data.

The results of the duplicate analyses are given in Tables 2-8 and 2-9.

Table 2-8. Method 6020 Field Dup Recoveries

| <i>Analyte</i> | <i>Sample ID: 121813012</i> | | | <i>Sample ID: 121813013</i> | | | <i>RPD</i> | <i>Sample ID: 122013034</i> | | | <i>Sample ID: 122013035</i> | | | <i>RPD</i> |
|----------------|-----------------------------|----------|-----|-----------------------------|----------|-----|------------|-----------------------------|----------|-----|-----------------------------|----------|-----|------------|
| | Result (µg/L) | Lab Flag | LOQ | Result (µg/L) | Lab Flag | LOQ | | Result (µg/L) | Lab Flag | LOQ | Result (µg/L) | Lab Flag | LOQ | |
| Lead | 0.14 | J | 1.0 | 1.3 | | 1.0 | 161.1 | 0.11 | J | 1.0 | 1 | U | 1.0 | NC |

Table 2-9. Water EPA Method OIA-1667 Field Dup Recoveries

| <i>Analyte</i> | <i>Sample ID: 121813012</i> | | | <i>Sample ID: 121813013</i> | | | <i>RPD</i> |
|-------------------|-----------------------------|----------|--------|-----------------------------|----------|--------|------------|
| | Result (mg/L) | Lab Flag | LOQ | Result (mg/L) | Lab Flag | LOQ | |
| Available cyanide | 0.019 | | 0.0020 | 0.021 | | 0.0020 | 10.0 |

Table 2-9. Water EPA Method OIA-1667 Field Dup Recoveries Cont.

| <i>Analyte</i> | <i>Sample ID: 122013034</i> | | | <i>Sample ID: 122013035</i> | | | <i>RPD</i> |
|-------------------|-----------------------------|----------|--------|-----------------------------|----------|--------|------------|
| | Result (mg/L) | Lab Flag | LOQ | Result (mg/L) | Lab Flag | LOQ | |
| Available cyanide | 0.0020 | U | 0.0020 | 0.0020 | U | 0.0020 | 0.0 |

3.0 ORGANIC DATA REVIEW

Blank, spiked, and duplicate results were provided. The results of the QC review are presented below. One method blank was prepared and analyzed with each analytical batch of samples.

Aqueous samples were analyzed for organic compounds following SW-846 Methods as shown in Table 3-1

Table 3-1. Organic Analytes and Methods Summary

| Analytical Method | Analyte |
|-------------------|---|
| EPA 8260B | Purgeable Volatile Organic Compounds (PVOC) |
| EPA 8270 by SIM | Polycyclic Aromatic Hydrocarbons (PAH) |

3.1 SW-846 Method 8260B – Purgeable Volatile Organic Compounds

3.1.1 Summary

SW-846 Method 8260B employs gas chromatographic separation with a mass spectrometer as a detector.

3.1.2 Trip Blanks

Four trip blanks were provided with this sample set. None of the trip blanks associated with these samples gave results above the detection limit.

No data are qualified as a consequence of any of the field quality control blanks.

3.1.3 Method Blanks

The aqueous samples were analyzed in multiple analytical batches. The method blanks, showed no contamination above the detection limit. Hence, no data are qualified as a consequence of the method blank data.

The method blank data are summarized in Table 3-2.

Table 3-2. Water Method 8260B Method Blank Results Summary

| <i>Test Batch</i> | <i>Analyte</i> | <i>Units</i> | <i>Result</i> |
|-------------------|------------------------|--------------|---------------|
| 150514 | 1,2,4-Trimethylbenzene | µg/L | 1.0 U |
| | 1,3,5-Trimethylbenzene | µg/L | 1.0 U |
| | Benzene | µg/L | 1.0 U |
| | Ethylbenzene | µg/L | 1.0 U |
| | Toluene | µg/L | 1.0 U |
| | Xylene (Total) | µg/L | 1.3 U |
| 150684 | 1,2,4-Trimethylbenzene | µg/L | 1.0 U |
| | 1,3,5-Trimethylbenzene | µg/L | 1.0 U |
| | Benzene | µg/L | 1.0 U |
| | Ethylbenzene | µg/L | 1.0 U |
| | Toluene | µg/L | 1.0 U |
| | Xylene (Total) | µg/L | 1.3 U |
| 150857 | 1,2,4-Trimethylbenzene | µg/L | 1.0 U |
| | 1,3,5-Trimethylbenzene | µg/L | 1.0 U |
| | Benzene | µg/L | 1.0 U |
| | Ethylbenzene | µg/L | 1.0 U |
| | Toluene | µg/L | 1.0 U |
| | Xylene (Total) | µg/L | 1.3 U |

3.1.4 Calibration

All initial calibration criteria were met for all compounds. All analytes fit first order linear regression curves and gave average response factors (RFs) with <15% RSD over the average. Therefore average RFs were used in sample quantitation. No data are qualified as a result of the initial calibration data.

For evaluating calibration verifications, the June 2008 CLP National Functional Guidelines have established a \pm 40% drift or difference acceptability criterion for analytes known to exhibit poor response and a \pm 25% drift or difference criterion for all other target analytes. None of the analytes of concern in this investigation are considered to exhibit poor response. The calibration verification associated with this data set did not exceed the \pm 25% difference

criterion in place for all other target analytes. Consequently, no data are qualified as a result of the calibration verification data.

3.1.5 Internal Standard Areas

No sample analyses reported in this data set have internal standard areas less than -50% or greater than +100% of the area response of the corresponding continuing calibration verification. Therefore, no data are qualified.

3.1.6 Surrogate Compound Recoveries

Three surrogate compounds, 4-bromofluorobenzene, toluene-d₈, and dibromofluoromethane, were spiked into each field sample to monitor analyte recovery in the analytical system. The surrogates used by the laboratory are acceptable to measure recovery under EPA SW-846 guidance for this analytical method.

Recoveries for all surrogates for all samples were well within the acceptance limits. No data require qualification based upon surrogate recoveries.

Recoveries for all surrogates for all samples are presented in Table 3-3.

Table 3-3. Water Method 8260B Surrogate Recoveries

| Lab Sample Number | Field ID | Dilution | 4-Bromofluorobenzene | | Dibromofluoromethane | | Toluene-d ₈ | |
|-------------------|-----------|----------|----------------------|-----|----------------------|-----|------------------------|-----|
| | | Limits: | 43 | 137 | 70 | 130 | 55 | 137 |
| 4090191001 | 121713001 | 1 | 79 | | 98 | | 91 | |
| 4090191002 | 121713002 | 1 | 75 | | 97 | | 92 | |
| 4090191003 | 121713003 | 1 | 74 | | 98 | | 93 | |
| 4090191004 | 121713004 | 1 | 70 | | 103 | | 92 | |
| 4090191005 | 121713005 | 1 | 70 | | 104 | | 91 | |
| 4090245001 | 121813006 | 1 | 98 | | 101 | | 104 | |
| 4090245002 | 121813012 | 1 | 96 | | 101 | | 103 | |
| 4090245003 | 121813013 | 1 | 97 | | 101 | | 103 | |
| 4090245004 | 121813017 | 1 | 97 | | 101 | | 103 | |
| 4090245005 | 121813018 | 1 | 98 | | 102 | | 104 | |
| 4090245006 | 121813010 | 4 | 101 | | 101 | | 104 | |
| 4090245007 | 121813015 | 1 | 98 | | 100 | | 104 | |
| 4090245008 | 121813009 | 1 | 97 | | 101 | | 104 | |
| 4090325001 | 121913032 | 1 | 97 | | 101 | | 104 | |
| 4090326001 | 121913027 | 1 | 97 | | 102 | | 105 | |
| 4090326002 | 121913029 | 1 | 99 | | 102 | | 104 | |
| 4090328001 | 121913020 | 1 | 97 | | 100 | | 104 | |
| 4090328002 | 121913023 | 1 | 98 | | 102 | | 104 | |
| 4090328003 | 121913033 | 1 | 98 | | 101 | | 103 | |
| 4090400001 | 122013034 | 1 | 97 | | 99 | | 103 | |
| 4090400002 | 122013035 | 1 | 97 | | 101 | | 103 | |
| 4090400003 | 122013036 | 1 | 98 | | 100 | | 104 | |
| 4090400004 | 122013037 | 1 | 97 | | 102 | | 104 | |
| 4090400005 | 122013038 | 1 | 97 | | 100 | | 103 | |

3.1.7 Matrix Spike/Matrix Spike Duplicates

Matrix spike/matrix spike duplicate (MS/MSD) analyses were performed on one sample as specified by the project team in accordance with the Sampling and Analysis Plan. None of the target compounds recovered outside of the limits established by the laboratory. The spike solution used by the laboratory does not contain 1,2,4-Trimethylbenzene or 1,3,5-Trimethylbenzene. Therefore there are no spike results for the LCS or MS/MSD for these analytes.

No action is defined for flagging data based on the MS/MSD results or RPD values alone. Since all of the reported recoveries were within acceptance limits, no data are qualified as a result of the matrix spike/matrix spike duplicate analyses.

The MS/MSD results are summarized in Table 3-4.

Table 3-4. Water Method 8260B MS/MSD Sample Recoveries

| Analyte | MS Sample ID: 121813015 | | | MSD Sample ID: 121813015 | | | RPD | Lab Sample Result (µg/L) | Max RPD |
|----------------|------------------------------------|---------------------------------|--------------------|-------------------------------------|----------------------------------|--------------------|------------|---|--------------------|
| | Spike (µg/L) | MS Result (µg/L) | Rec (%) | Spike (µg/L) | MSD Result (µg/L) | Rec (%) | | | |
| Benzene | 50 | 57.1 | 114 | 50 | 56 | 112 | 2 | 1.0 U | 20 |
| Ethylbenzene | 50 | 54.6 | 109 | 50 | 53 | 106 | 3 | 1.0 U | 20 |
| Toluene | 50 | 53.9 | 108 | 50 | 52.7 | 105 | 2 | 1.0 U | 20 |
| Xylene (Total) | 150 | 161 | 107 | 150 | 158 | 105 | 2 | 1.3 U | 20 |

3.1.8 Laboratory Control Samples

A Laboratory Control Sample (LCS) analysis was performed for each batch of samples analyzed. None of the analytes recovered outside of the acceptance limits established by the laboratory. No data are qualified due to failed LCS recoveries. The spike solution used by the laboratory does not contain 1,2,4-Trimethylbenzene or 1,3,5-Trimethylbenzene. Therefore there are no spike results for the LCS or MS/MSD for these analytes.

The LCS results are summarized in Table 3-5.

Table 3-5. Water Method 8260B LCS Summary

| QC Batch | Analyte | Recovery Limits (%) | | Spike (µg/L) | Result (µg/L) | Recovery |
|----------|----------------|---------------------|-------|-----------------|------------------|----------|
| | | Lower | Upper | | | |
| 150514 | Benzene | 70 | 137 | 50 | 52.9 | 106 |
| | Ethylbenzene | 70 | 130 | 50 | 51.9 | 104 |
| | Toluene | 70 | 130 | 50 | 54.0 | 108 |
| | Xylene (Total) | 70 | 130 | 150 | 177 | 118 |
| 150684 | Benzene | 70 | 137 | 50 | 57.0 | 114 |
| | Ethylbenzene | 70 | 130 | 50 | 55.0 | 110 |
| | Toluene | 70 | 130 | 50 | 53.9 | 108 |
| | Xylene (Total) | 70 | 130 | 150 | 162 | 108 |
| 150857 | Benzene | 70 | 137 | 50 | 55.4 | 111 |
| | Ethylbenzene | 70 | 130 | 50 | 53.6 | 107 |
| | Toluene | 70 | 130 | 50 | 52.9 | 106 |
| | Xylene (Total) | 70 | 130 | 150 | 160 | 106 |

3.1.9 Field Duplicates

Field duplicates generally have good agreement for all of analytes with all RPD values <30%. Precision is only calculated where both the sample and the duplicate sample gave a positive result. Duplicate “NDs”, however, are reported with 0% RPDs. No results will be qualified based on field duplicate data for 8260.

The results of the field duplicate analyses are given in Table 3-6.

Table 3-6. Water Method 8260B Field Dup Results

| <i>Analyte</i> | <i>Sample ID: 121813012</i> | | | <i>Sample ID: 121813013</i> | | | <i>RPD</i> |
|------------------------|---------------------------------|---------------------|------------|---------------------------------|---------------------|------------|------------|
| | <i>Result (µg/L)</i> | <i>Lab Flag</i> | <i>LOQ</i> | <i>Result (µg/L)</i> | <i>Lab Flag</i> | <i>LOQ</i> | |
| 1,2,4-Trimethylbenzene | 1.0 | U | 1.0 | 1.0 | U | 1.0 | 0.0 |
| 1,3,5-Trimethylbenzene | 1.0 | U | 1.0 | 1.0 | U | 1.0 | 0.0 |
| Benzene | 1.0 | U | 1.0 | 1.0 | U | 1.0 | 0.0 |
| Ethylbenzene | 1.0 | U | 1.0 | 1.0 | U | 1.0 | 0.0 |
| Toluene | 1.0 | U | 1.0 | 1.0 | U | 1.0 | 0.0 |
| Xylene (Total) | 3.0 | U | 3.0 | 3.0 | U | 3.0 | 0.0 |

Table 3-6. Water Method 8260B Field Dup Results Cont

| <i>Analyte</i> | <i>Sample ID: 122013034</i> | | | <i>Sample ID: 122013035</i> | | | <i>RPD</i> |
|------------------------|---------------------------------|---------------------|------------|---------------------------------|---------------------|------------|------------|
| | <i>Result (µg/L)</i> | <i>Lab Flag</i> | <i>LOQ</i> | <i>Result (µg/L)</i> | <i>Lab Flag</i> | <i>LOQ</i> | |
| 1,2,4-Trimethylbenzene | 1.0 | U | 1.0 | 1.0 | U | 1.0 | 0.0 |
| 1,3,5-Trimethylbenzene | 1.0 | U | 1.0 | 1.0 | U | 1.0 | 0.0 |
| Benzene | 1.0 | U | 1.0 | 1.0 | U | 1.0 | 0.0 |
| Ethylbenzene | 1.0 | U | 1.0 | 1.0 | U | 1.0 | 0.0 |
| Toluene | 1.0 | U | 1.0 | 1.0 | U | 1.0 | 0.0 |
| Xylene (Total) | 3.0 | U | 3.0 | 3.0 | U | 3.0 | 0.0 |

3.2 SW-846 Method 8270C/SIM–PAHs

3.2.1 Summary

SW-846 Method 8270C/SIM employs gas chromatographic separation with mass spectroscopic identification using selected ion monitoring (SIM).

3.2.2 Method Blanks

The method blanks, showed contamination above the detection limit but less than the reporting limit for naphthalene and 2-Methylnaphthalene. The effected sample results that are above the detection limit but below the reporting limit will be reported at the reporting limit and qualified with a “U” (not detected). Results that are above the reporting limit, but less than five times the reporting limit, will be qualified as estimated “J”.

The results for the method blanks are summarized in Table 3-7.

Table 3-7. Water Method 8270-SIM Method Blank Results Summary

| <i>Analyte</i> | <i>Units</i> | <i>QC Batch: 150730</i> | <i>QC Batch: 150988</i> |
|------------------------|--------------|-----------------------------|-----------------------------|
| 2-Methylnaphthalene | µg/L | 0.0049 J | |
| Acenaphthene | µg/L | 0.050 U | |
| Acenaphthylene | µg/L | 0.050 U | |
| Anthracene | µg/L | 0.050 U | |
| Benzo(a)anthracene | µg/L | 0.050 U | |
| Benzo(a)pyrene | µg/L | 0.050 U | |
| Benzo(b)fluoranthene | µg/L | 0.050 U | |
| Benzo(g,h,i)perylene | µg/L | 0.050 U | |
| Benzo(k)fluoranthene | µg/L | 0.050 U | |
| Chrysene | µg/L | 0.050 U | |
| Dibenz(a,h)anthracene | µg/L | 0.050 U | |
| Fluoranthene | µg/L | 0.050 U | |
| Fluorene | µg/L | 0.050 U | |
| Indeno(1,2,3-cd)pyrene | µg/L | 0.050 U | |
| Naphthalene | µg/L | 0.010 J | 0.0065 J |
| Phenanthrene | µg/L | 0.050 U | |
| Pyrene | µg/L | 0.050 U | |

3.2.3 Calibration

Instrument tuning checks using decafluorotriphenylphosphine (DFTPP) were performed daily and every 12 hours as described in the methods. However, since this method employs selected ion monitoring, tuning using DFTPP has little value. Consequently, no data are qualified based upon DFTPP tuning criteria.

The initial instrument calibration performed for this method gave satisfactory results with response factors over the calibration range <15% RSD. Therefore an average response factor calibration model was used to quantitate all compounds results.

The initial calibration verifications (ICV) reported with this data set gave percent differences less than the 25% limit defined in the National Functional Guidelines for calibration verification. Therefore, no results are qualified as a consequence of the initial calibration verifications.

All of the continuing calibration verification (CCV) checks for PAH analyses performed gave acceptable results (i.e., <25% D using the CLP National Functional Guidelines) for all of the target analytes. No data are qualified as a consequence of the continuing calibration data.

The peak shapes and chromatographic resolution for the isomers benzo(b)fluoranthene and benzo(k)fluoranthene evident in the sample chromatograms for the samples indicate that the two isomers are not adequately resolved to be quantitated separately as the laboratory attempted to do. The laboratory's report narratives noted this issue but stopped short of reporting the two isomers as a coeluting pair (as is done for m/p-xylene). Consequently all positive results for benzo(b)fluoranthene and benzo(k)fluoranthene in all samples for these two isomers are qualified as estimated ("J").

3.2.4 Internal Standard Areas

One sample analyses reported in this data set yielded internal standard areas less than 50% of the area response of the corresponding continuing calibration verification. In this case the only analyte reported was naphthalene, and the failure was perlene-d₁₂. This internal standard is not associated with naphthalene. Therefore, no data are qualified.

3.2.5 Surrogate Compound Recoveries

Two surrogates, 2-fluorobiphenyl, and terphenyl-d₁₄, were spiked into each field sample to monitor method recovery. Given the focused nature of the compounds of concern (i.e., PAHs), the surrogates reported should be adequate to monitor recovery in the analyses. Two samples had surrogates with 0% recovery due to sample dilution. Under these circumstances qualification of data is not warranted. No data is qualified due to surrogate recoveries.

The surrogate recoveries for all samples are presented in Table 3-8.

Table 3-8. Water Method 8270-SIM Surrogate Recoveries

| <i>Lab Sample Number</i> | <i>Field ID</i> | <i>Dilution</i> | <i>2-Fluorobiphenyl</i> | | <i>Terphenyl-d₁₄</i> | |
|--------------------------|-----------------|-----------------|-------------------------|-----|---------------------------------|-----|
| | | Limits: | 24 | 130 | 44 | 169 |
| 4090191001 | 121713001 | 1 | 58 | | 98 | |
| 4090191002 | 121713002 | 1 | 65 | | 99 | |
| 4090191003 | 121713003 | 1 | 47 | | 92 | |
| 4090191004 | 121713004 | 1 | 53 | | 93 | |
| 4090245001 | 121813006 | 1 | 57 | | 102 | |
| 4090245002 | 121813012 | 1 | 49 | | 105 | |
| 4090245003 | 121813013 | 1 | 50 | | 98 | |
| 4090245004 | 121813017 | 1 | 49 | | 125 | |
| 4090245006 | 121813010 | 100 | 0 | | 0 | |
| 4090245007 | 121813015 | 1 | 50 | | 88 | |
| 4090245008 | 121813009 | 1 | 50 | | 104 | |
| 4090325001 | 121913032 | 1 | 50 | | 97 | |
| 4090326001 | 121913027 | 1 | 41 | | 79 | |
| 4090326002 | 121913029 | 50 | 0 | | 0 | |
| 4090328001 | 121913020 | 1 | 50 | | 83 | |
| 4090328002 | 121913023 | 1 | 46 | | 92 | |
| 4090400001 | 122013034 | 1 | 46 | | 80 | |
| 4090400002 | 122013035 | 1 | 51 | | 91 | |
| 4090400003 | 122013036 | 1 | 49 | | 86 | |
| 4090400004 | 122013037 | 1 | 54 | | 98 | |

3.2.6 Matrix Spike/Matrix Spike Duplicates

Sample 121813015 was used to perform MS/MSD analyses for 8270-SIM. Guidance in the National Functional Guidelines does not call for qualifying data based upon the matrix spike analyses alone. No data are qualified based upon the MS/MSD results.

The MS/MSD recoveries for all samples are presented in Table 3-9.

Table 3-9. Water Method 8270-SIM MS/MSD Sample Recoveries

| <i>Analyte</i> | <i>MS Sample ID: 121813015</i> | | | <i>MSD Sample ID: 121813015</i> | | | <i>RPD</i> | <i>Lab Sample Result (µg/L)</i> | <i>Max RPD</i> |
|----------------|------------------------------------|---------------------------------|--------------------|-------------------------------------|----------------------------------|--------------------|------------|---|--------------------|
| | <i>Spike (µg/L)</i> | <i>MS Result (µg/L)</i> | <i>Rec (%)</i> | <i>Spike (µg/L)</i> | <i>MSD Result (µg/L)</i> | <i>Rec (%)</i> | | | |
| Naphthalene | .19 | 0.11 | 54 | .19 | 0.11 | 54 | 3 | 0.0067 JB | 50 |

3.2.7 Laboratory Control Samples

A laboratory control sample (LCS) was prepared and analyzed with each batch of samples. All of the analytes for the laboratory control samples recovered within the limits used by the laboratory.

The laboratory control sample results are given in Table 3-10.

Table 3-10. Water Method 8270-SIM LCS Results Summary

| <i>Analyte</i> | <i>Spike (Units)</i> | <i>Rec Limits (%)</i> | | <i>QC Batch: 150730</i> | | <i>QC Batch: 150988</i> | |
|------------------------|--------------------------|-----------------------|--------------|--------------------------|--------------------|--------------------------|--------------------|
| | | <i>Lower</i> | <i>Upper</i> | <i>Result (µg/L)</i> | <i>Rec (%)</i> | <i>Result (µg/L)</i> | <i>Rec (%)</i> |
| 2-Methylnaphthalene | .2 | 32 | 130 | 0.17 | 87 | | |
| Acenaphthene | .2 | 30 | 130 | 0.16 | 81 | | |
| Acenaphthylene | .2 | 28 | 130 | 0.16 | 81 | | |
| Anthracene | .2 | 22 | 130 | 0.16 | 82 | | |
| Benzo(a)anthracene | .2 | 40 | 130 | 0.18 | 89 | | |
| Benzo(a)pyrene | .2 | 51 | 130 | 0.18 | 88 | | |
| Benzo(b)fluoranthene | .2 | 45 | 130 | 0.18 | 91 | | |
| Benzo(g,h,i)perylene | .2 | 59 | 130 | 0.20 | 99 | | |
| Benzo(k)fluoranthene | .2 | 60 | 130 | 0.23 | 113 | | |
| Chrysene | .2 | 62 | 130 | 0.21 | 105 | | |
| Dibenz(a,h)anthracene | .2 | 51 | 130 | 0.16 | 78 | | |
| Fluoranthene | .2 | 43 | 130 | 0.17 | 85 | | |
| Fluorene | .2 | 29 | 130 | 0.17 | 85 | | |
| Indeno(1,2,3-cd)pyrene | .2 | 56 | 130 | 0.17 | 86 | | |
| Naphthalene | .2 | 30 | 130 | 0.17 | 86 | 0.17 | 87 |
| Phenanthrene | .2 | 29 | 130 | 0.16 | 81 | | |
| Pyrene | .2 | 38 | 130 | 0.19 | 97 | | |

3.2.8 Field Duplicates

Field duplicates generally show good agreement for all of the analytes. Precision is only calculated where both the sample and the duplicate sample gave a positive result (NC=Not Calculated). Duplicate “NDs”, however, are reported with 0% RPDs. The National Functional Guidelines do not provide any guidance for qualifying data associated with field or sample duplicates for semivolatiles analyses. However, requirements that appear in the Multi-Site QAPP Addendum governing this project place a 30% limit on the RPD values where the results are >2x the limit of quantitation. No results for any field samples associated with these duplicate pairs are qualified based upon field duplicate data.

The results of the duplicate analyses are given in Table 3-11.

Table 3-11. Water Method 8270-SIM Field Dup Results

| <i>Analyte</i> | <i>Sample ID: 121813012</i> | | | <i>Sample ID: 121813013</i> | | | <i>RPD</i> |
|----------------|---------------------------------|---------------------|------------|---------------------------------|---------------------|------------|------------|
| | <i>Result (µg/L)</i> | <i>Lab Flag</i> | <i>LOQ</i> | <i>Result (µg/L)</i> | <i>Lab Flag</i> | <i>LOQ</i> | |
| Naphthalene | 0.016 | JB | 0.050 | 0.070 | B | 0.049 | 125.6 |

Table 3-11. Water Method 8270-SIM Field Dup Results Cont

| <i>Analyte</i> | <i>Sample ID: 122013034</i> | | | <i>Sample ID: 122013035</i> | | | <i>RPD</i> |
|----------------|---------------------------------|---------------------|------------|---------------------------------|---------------------|------------|------------|
| | <i>Result (µg/L)</i> | <i>Lab Flag</i> | <i>LOQ</i> | <i>Result (µg/L)</i> | <i>Lab Flag</i> | <i>LOQ</i> | |
| Naphthalene | 0.0067 | JB | 0.054 | 0.005 | U | 0.049 | NC |

4.0 VAPOR SAMPLE ANALYSES

Soil vapor phase samples were collected as part of this investigation. Blank, laboratory control sample, and duplicate results were provided. The results of the QC review are presented below.

Vapor phase samples were analyzed for organic compounds following the methods as shown in Table 4-1.

Table 4-1. Vapor Phase Analytes and Methods Summary

| Analytical Method | Analyte |
|--------------------------|-----------------------------------|
| EPA Method TO-15 | Volatile Organic Compounds (VOCs) |
| ASTM D1946/EPA Method 3C | Oxygen, Carbon Dioxide, Methane |

All samples were collected in SUMMA polished canisters and received by the laboratory in good condition and intact. No data are qualified based upon sample receipt conditions.

All sample analyses were performed within the EPA-established holding times. No data are qualified based upon sample holding times.

STAT laboratory noted on their case narrative that the methylene chloride reported in sample 121913031 is a possible lab artifact. Based on this the sample will be qualified as unusable "R" for methylene chloride.

4.1 EPA Method TO-15: Volatile Organic Compounds (VOCs)

4.1.1 Summary

EPA Method TO-15 employs gas chromatographic separation with a mass spectrometer as a detector. One method blank was prepared and analyzed with each analytical batch of samples. Ultra High Purity nitrogen was used as the matrix for VOC method blank analysis.

4.1.2 Method Blanks

The samples were analyzed in two analytical batches. Methylene chloride and naphthalene were detected in the method blanks above the limit of detection but below the reporting limit. All positive results for methylene chloride and naphthalene in the associated batches will be qualified as estimated "J".

The results for the method blanks are summarized in Table 4-2.

Table 4-2. EPA TO-15 Method Blank Summary

| <i>Analyte</i> | <i>Units</i> | <i>QC Batch: R95580</i> | <i>QC Batch: R95604</i> |
|--------------------------|-------------------|-----------------------------|-----------------------------|
| 1,1,1-Trichloroethane | µg/m ³ | 1.1 U | 1.1 U |
| 1,1-Dichloroethane | µg/m ³ | 0.8 U | 0.8 U |
| 1,2,4-Trimethylbenzene | µg/m ³ | 1 U | 1 U |
| 2-Butanone | µg/m ³ | 1.5 U | 1.5 U |
| Acetone | µg/m ³ | 4.8 U | 4.8 U |
| Benzene | µg/m ³ | 0.6 U | 0.6 U |
| Carbon disulfide | µg/m ³ | 0.62 U | 0.62 U |
| cis-1,2-Dichloroethene | µg/m ³ | 0.8 U | 0.8 U |
| Ethylbenzene | µg/m ³ | 0.9 U | 0.9 U |
| Methylene chloride | µg/m ³ | 0.6947 J | 0.59 U |
| Naphthalene | µg/m ³ | 0.26 U | 0.05242 J |
| Styrene | µg/m ³ | 0.9 U | 0.9 U |
| Tetrachloroethene | µg/m ³ | 1.4 U | 1.4 U |
| Toluene | µg/m ³ | 0.8 U | 0.8 U |
| trans-1,2-Dichloroethene | µg/m ³ | 0.8 U | 0.8 U |
| Vinyl chloride | µg/m ³ | 0.5 U | 0.5 U |
| Xylenes, Total | µg/m ³ | 2.6 U | 2.6 U |

4.1.3 Calibration

The initial instrument calibration performed for this method gave satisfactory results with response factors over the calibration range <30% RSD. Therefore an average response factor calibration model was used to quantitate all target analyte results.

All of the initial calibration verification (ICV) and continuing calibration verification (CCV) checks for Method TO-15 performed gave acceptable results (i.e., <30%D) for all of the target analytes.

No data are qualified as a consequence of the calibration data.

4.1.4 Surrogate Compound Recoveries

Surrogate Compound analysis is not included as part of EPA Method TO-15.

4.1.5 Laboratory Control Samples

A laboratory control sample (LCS) was prepared and analyzed with each batch of samples.

All of the target analytes for all of the laboratory control samples recovered within the limits used by the laboratory. No data are qualified due to failed LCS recoveries.

The laboratory control sample results are given in Table 4-3.

Table 4-3. EPA TO-15 Laboratory Control Sample Summary

| <i>Analyte</i> | <i>Spike ($\mu\text{g}/\text{m}^3$)</i> | <i>Rec Limits (%)</i> | | <i>QC Batch: R95580</i> | | <i>QC Batch: R95604</i> | |
|--------------------------|--|-----------------------|--------------|---|-------------------------|---|-------------------------|
| | | <i>Lower</i> | <i>Upper</i> | <i>Result ($\mu\text{g}/\text{m}^3$)</i> | <i>Recovery (%)</i> | <i>Result ($\mu\text{g}/\text{m}^3$)</i> | <i>Recovery (%)</i> |
| 1,1,1-Trichloroethane | 27.28 | 70 | 130 | 27.23 | 99.8 | 26.63 | 97.6 |
| 1,1-Dichloroethane | 20.24 | 70 | 130 | 21.05 | 104 | 18.78 | 92.8 |
| 1,2,4-Trimethylbenzene | 24.58 | 70 | 130 | 25.56 | 104 | 25.61 | 104 |
| 2-Butanone | 14.75 | 70 | 130 | 15.69 | 106 | 14.6 | 99 |
| Acetone | 11.88 | 70 | 130 | 12.33 | 104 | 11.05 | 93 |
| Benzene | 15.97 | 70 | 130 | 13.96 | 87.4 | 13.99 | 87.6 |
| Carbon disulfide | 15.57 | 70 | 130 | 16.32 | 105 | 14.29 | 91.8 |
| cis-1,2-Dichloroethene | 19.82 | 70 | 130 | 20.97 | 106 | 18.99 | 95.8 |
| Ethylbenzene | 21.71 | 70 | 130 | 20.8 | 95.8 | 20.75 | 95.6 |
| Methylene chloride | 17.37 | 70 | 130 | 18.41 | 102 | 16.22 | 93.4 |
| Naphthalene | 26.21 | 70 | 130 | 30.82 | 118 | 31.92 | 122 |
| Styrene | 21.3 | 70 | 130 | 22.58 | 106 | 22.83 | 107 |
| Tetrachloroethene | 33.91 | 70 | 130 | 34.86 | 103 | 33.44 | 98.6 |
| Toluene | 18.84 | 70 | 130 | 18.46 | 98 | 18.28 | 97 |
| trans-1,2-Dichloroethene | 19.82 | 70 | 130 | 21.69 | 109 | 19.15 | 96.6 |
| Vinyl chloride | 12.78 | 70 | 130 | 13.5 | 106 | 11.66 | 91.2 |
| Xylenes, Total | 65.13 | 70 | 130 | 65.22 | 100 | 65.82 | 101 |

4.1.6 Matrix Spike/Matrix Spike Duplicates

Matrix spike/matrix spike duplicate (MS/MSD) analyses are not performed for EPA Method TO-15 analyses.

4.1.7 Field Duplicates

Field duplicates generally show good agreement with RPD <30% for all analytes. Precision is only calculated where both the sample and the duplicate sample gave a positive result (NC=Not Calculated). Duplicate “NDs”, however, are reported with 0% RPDs.

The National Functional Guidelines do not provide any guidance for qualifying data associated with field or sample duplicates for semivolatiles analyses. However, requirements that appear in the Multi-Site QAPP Addendum governing this project place a 30% limit on the RPD values where the results are >2x the limit of quantitation. No results will be qualified based on field duplicate data.

The results of the duplicate analyses are given in Table 4-4.

Table 4-4. EPA TO-15 Field Dup Sample Summary

| Analyte | Sample ID: 121913024 | | | Sample ID: 121913025 | | | RPD |
|--------------------------|--------------------------------------|---------------------|------------|--------------------------------------|---------------------|------------|------------|
| | Result (µg/m³) | Lab Flag | LOQ | Result (µg/m³) | Lab Flag | LOQ | |
| 1,1,1-Trichloroethane | 2 | U | 2 | 2 | U | 2 | 0.0 |
| 1,1-Dichloroethane | 1.5 | U | 1.5 | 1.5 | U | 1.5 | 0.0 |
| 1,2,4-Trimethylbenzene | 1.9 | U | 1.9 | 1.8 | U | 1.8 | 0.0 |
| 2-Butanone | 2.8 | U | 2.8 | 2.7 | U | 2.7 | 0.0 |
| Acetone | 8.9 | U | 8.9 | 8.7 | U | 8.7 | 0.0 |
| Benzene | 1.1 | U | 1.1 | 1.1 | U | 1.1 | 0.0 |
| Carbon disulfide | 1.2 | U | 1.2 | 1.1 | U | 1.1 | 0.0 |
| cis-1,2-Dichloroethene | 1.5 | U | 1.5 | 1.5 | U | 1.5 | 0.0 |
| Ethylbenzene | 1.7 | U | 1.7 | 1.6 | U | 1.6 | 0.0 |
| Methylene chloride | 13 | U | 13 | 13 | U | 13 | 0.0 |
| Naphthalene | 0.48 | U | 0.48 | 0.47 | U | 0.47 | 0.0 |
| Styrene | 1.7 | U | 1.7 | 1.6 | U | 1.6 | 0.0 |
| Tetrachloroethene | 2.6 | U | 2.6 | 2.6 | U | 2.6 | 0.0 |
| Toluene | 1.5 | U | 1.5 | 1.5 | U | 1.5 | 0.0 |
| trans-1,2-Dichloroethene | 1.5 | U | 1.5 | 1.5 | U | 1.5 | 0.0 |
| Vinyl chloride | 0.93 | U | 0.93 | 0.91 | U | 0.91 | 0.0 |
| Xylenes, Total | 4.8 | U | 4.8 | 4.7 | U | 4.7 | 0.0 |

Table 4-4. EPA TO-15 Field Dup Sample Summary Cont

| Analyte | Sample ID: 121913030 | | | Sample ID: 121913031 | | | RPD |
|--------------------------|--------------------------------------|---------------------|------------|--------------------------------------|---------------------|------------|------------|
| | Result (µg/m³) | Lab Flag | LOQ | Result (µg/m³) | Lab Flag | LOQ | |
| 1,1,1-Trichloroethane | 2 | U | 2 | 1.9 | U | 1.9 | 0.0 |
| 1,1-Dichloroethane | 1.5 | U | 1.5 | 1.4 | U | 1.4 | 0.0 |
| 1,2,4-Trimethylbenzene | 1.8 | U | 1.8 | 1.8 | U | 1.8 | 0.0 |
| 2-Butanone | 2.7 | U | 2.7 | 2.6 | U | 2.6 | 0.0 |
| Acetone | 8.8 | U | 8.8 | 8.5 | U | 8.5 | 0.0 |
| Benzene | 1.1 | U | 1.1 | 1.1 | U | 1.1 | 0.0 |
| Carbon disulfide | 1.1 | U | 1.1 | 1.1 | U | 1.1 | 0.0 |
| cis-1,2-Dichloroethene | 1.5 | U | 1.5 | 1.4 | U | 1.4 | 0.0 |
| Ethylbenzene | 1.6 | U | 1.6 | 1.6 | U | 1.6 | 0.0 |
| Methylene chloride | 13 | U | 13 | 28 | | 12 | NC |
| Naphthalene | 0.48 | U | 0.48 | 0.46 | U | 0.46 | 0.0 |
| Styrene | 1.6 | U | 1.6 | 1.6 | U | 1.6 | 0.0 |
| Tetrachloroethene | 2.6 | U | 2.6 | 2.5 | U | 2.5 | 0.0 |
| Toluene | 1.5 | U | 1.5 | 1.4 | U | 1.4 | 0.0 |
| trans-1,2-Dichloroethene | 1.5 | U | 1.5 | 1.4 | U | 1.4 | 0.0 |
| Vinyl chloride | 0.91 | U | 0.91 | 0.88 | U | 0.88 | 0.0 |
| Xylenes, Total | 4.8 | U | 4.8 | 4.6 | U | 4.6 | 0.0 |

4.2 EPA Method 3C: Oxygen, Carbon Dioxide, and Methane

4.2.1 Summary

EPA Method 3C employs gas chromatographic separation with thermal conductivity detector.

4.2.2 Method Blanks

The samples were analyzed in several analytical batches. None of the target compounds were detected in the method blanks.

No data are qualified due to the blank contamination.

The results for the method blanks are summarized in Table 4-5.

Table 4-5. EPA Method 3C Method Blank Summary

| <i>Parameter</i> | <i>Batch</i> | <i>Units</i> | <i>Result</i> |
|------------------|--------------|--------------|---------------|
| Carbon Dioxide | R95544 | mol % | 0.08 U |
| | R95570 | mol % | 0.08 U |
| Methane | R95544 | mol % | 0.1 U |
| | R95570 | mol % | 0.1 U |
| Oxygen | R95544 | mol % | 0.8 U |
| | R95570 | mol % | 0.8 U |

4.2.3 Calibration

The initial instrument calibration performed for this method gave satisfactory results with response factors over the calibration range <10% RSD. Therefore an average response factor calibration model was used to quantitate all target analyte results.

All of the initial calibration verification (ICV) and continuing calibration verification (CCV) checks for Method 3C performed gave acceptable results (i.e., <10%D) for all of the target analytes.

No data are qualified as a consequence of the calibration data.

4.2.4 Surrogate Compound Recoveries

Surrogate Compound analysis is not included as part of EPA Method 3C.

4.2.5 Laboratory Control Samples

A laboratory control sample (LCS) was prepared and analyzed with each batch of samples.

All of the target analytes for each of the laboratory control samples recovered within the limits used by the laboratory. Based upon the acceptable recoveries, there is no need to qualify data based upon the LCS recovery results.

The laboratory control sample results are given in Table 4-6.

Table 4-6. EPA Method 3C Laboratory Control Sample Summary

| <i>Analyte</i> | <i>Spike (mol %)</i> | <i>Rec Limits (%)</i> | | <i>QC Batch: R95544</i> | | <i>QC Batch: R95570</i> | |
|----------------|--------------------------|-----------------------|--------------|---------------------------|-------------------------|---------------------------|-------------------------|
| | | <i>Lower</i> | <i>Upper</i> | <i>Result (mol %)</i> | <i>Recovery (%)</i> | <i>Result (mol %)</i> | <i>Recovery (%)</i> |
| Carbon Dioxide | 0.6 | 80 | 120 | 0.676 | 113 | 0.654 | 109 |
| Methane | 1 | 80 | 120 | 0.992 | 99.2 | 0.988 | 98.8 |
| Oxygen | 0.8 | 80 | 120 | 0.806 | 101 | 0.812 | 102 |

4.2.6 Matrix Spike/Matrix Spike Duplicates

Matrix spike/matrix spike duplicate (MS/MSD) analyses are not performed for EPA Method 3C analyses.

4.2.7 Field Duplicates

Field duplicates show excellent agreement with RPD <30% for all the analytes. Precision is only calculated where both the sample and the duplicate sample gave a positive result (NC=Not Calculated). Duplicate “NDs”, however, are reported with 0% RPDs.

Based upon these observations, no results for any field samples associated with these duplicate pairs are qualified based upon field duplicate data.

The results of the duplicate analyses are given in Table 4-7.

Table 4-7. EPA Method 3C Field Dup Sample Summary

| <i>Analyte</i> | <i>Sample ID: 121913024</i> | | | <i>Sample ID: 121913025</i> | | | <i>RPD</i> |
|----------------|---------------------------------|---------------------|------------|---------------------------------|---------------------|------------|------------|
| | <i>Result (mol %)</i> | <i>Lab Flag</i> | <i>LOQ</i> | <i>Result (mol %)</i> | <i>Lab Flag</i> | <i>LOQ</i> | |
| Carbon Dioxide | 0.402 | | 0.08 | 0.408 | | 0.08 | 1.5 |
| Methane | 0.1 | U | 0.1 | 0.1 | U | 0.1 | 0.0 |
| Oxygen | 17 | | 0.8 | 17.2 | | 0.8 | 1.2 |

Table 4-7. EPA Method 3C Field Dup Sample Summary Cont

| <i>Analyte</i> | <i>Sample ID: 121913030</i> | | | <i>Sample ID: 121913031</i> | | | <i>RPD</i> |
|----------------|---------------------------------|---------------------|------------|---------------------------------|---------------------|------------|------------|
| | <i>Result (mol %)</i> | <i>Lab Flag</i> | <i>LOQ</i> | <i>Result (mol %)</i> | <i>Lab Flag</i> | <i>LOQ</i> | |
| Carbon Dioxide | 0.096 | | 0.08 | 0.098 | | 0.08 | 2.1 |
| Methane | 0.1 | U | 0.1 | 0.1 | U | 0.1 | 0.0 |
| Oxygen | 17.6 | | 0.8 | 17.6 | | 0.8 | 0.0 |