

7950285 110.0622 AV

SFUND RECORDS CTR 2166-07941

> SFUND RECORDS CTR 88137361 ITX 2166-07941

SUBSURFACE SOIL-GAS INVESTIGATION REPORT

K&L ANODIZING CORPORATION 1200 SOUTH VICTORY BLVD. BURBANK, CALIFORNIA

OCTOBER, 1995

PREPARED FOR:

Jan Phillips
K&L ANODIZING CORPORATION
1200 South Victory Blvd.
Burbank, California 91502

TRG Number 4685-K&L

TABLE OF CONTENTS

SUBSURFACE SOIL-GAS INVESTIGATION REPORT

| 1.0 | EXECUTIVE SUMMARY | 1 |
|-----|---|--------|
| 2.0 | INTRODUCTION | 1 |
| 3.0 | OBJECTIVE | 1 |
| 4.0 | SCOPE OF WORK | 1 |
| 5.0 | FIELD INVESTIGATION | 2 |
| | 5.1 Soil-Gas Survey5.2 Soil Vapor Acquisition and Handling5.3 Quality Assurance/Quality Control, (QA/QC) Procedures | 2 3 |
| 6.0 | RESULTS AND FINDINGS | 6 |
| 7.0 | CONCLUSIONS | 6 |
| 8.0 | LIMITATIONS | 7 |

TABLE

TABLE 1 - List of 25 Calibration Compounds

TABLE 2 - List of 15 Laboratory Check Sample Compounds

FIGURES

FIGURE 1 - Site Location Map

FIGURE 2 - Site Plot Plan and Sample Locations

APPENDICES

APPENDIX A- Laboratory Report

SUBSURFACE SOIL-GAS INVESTIGATION REPORT

K&L ANODIZING CORPORATION 1200 SOUTH VICTORY BLVD. BURBANK, CALIFORNIA

1.0 EXECUTIVE SUMMARY

This report presents soil-gas investigation results for work conducted on October 26, 1995 at 1200 South Victory Blvd., City of Burbank, State of California. The soil-gas investigation included collection of 5 vapor samples from 3 sampling locations (SG-1 through SG-3). During the soil-gas investigation, detectable levels of two halogenated compounds, 1,1,1-trichloroethane (111-TCA), and tetrachloroethene (PCE), were identified in trace ($<5.0 \,\mu\text{g/L}$) to low levels ($<50 \,\mu\text{g/L}$). Based on the results that only small amounts of 111-TCA and PCE exist in the soils in the area investigated, it appears no further action is required with respect to VOC's at this Site.

2.0 INTRODUCTION

This report summarizes the soil-gas investigation conducted by The Reynolds Group (TRG) at 1200 South Victory Boulavard, Burbank, California (the Site). The work was conducted on behalf of Ms. Jan Phillips and in accordance with the TRG work plan proposal dated September 13, 1995. Sample collection and analysis were conducted by Optimal Technology Inc. of Summerland, California.

3.0 OBJECTIVE

The objective of the soil-gas investigation was to screen the near surface soils at the Site for possible volatile organic compounds (VOCs).

4.0 SCOPE OF WORK

To fulfill the objectives of the subsurface investigation, the following scope of work was conducted by TRG as approved by the Regional Water Quality Control Board:

Task 1: Collected five soil-gas samples from three sampling locations.

Task 2: Completed laboratory analyses of collected soil vapor samples in accordance with LA-RWQCB guidelines ("Workplan Requirements for Active Soil Gas Investigation, Well Investigation Program": March, 1994).

Task 3: Prepared this report documenting the methodology, findings, field and analytical test results, and conclusions of this investigation.

A detailed description of the work performed during the investigation is presented in the following sections of this report.

5.0 FIELD INVESTIGATION

TRG performed the soil-gas survey field investigation on October 26, 1995. Ms. Ana Veloz of the Regional Water Quality Control Board was present during part of the field work. The investigation included one area inside the building, adjacent to an existing clarifier, one area outside side of the building, adjacent to the former degreaser, and one area adjacent to the chemical storage room (Figure 2). The sampling and analytical testing were performed by Optimal Technology Inc. of Summerland, California. For the field investigation, all work was conducted according to the standards of the California Regional Water Quality Control Board, Los Angeles Section as outlined in "Workplan Requirements for Active Soil Gas Investigation, Well Investigation Program": dated March, 1994.

5.1 Soil-Gas Survey

TRG collected five soil-gas samples from three locations during the course of the soil-gas investigation (Figure 2). Gas samples were collected at approximately five ft bgs for three sampling locations and 15 ft bgs for two locations. Location SG-1 (located adjacent to the chemical storage room), and location SG-2 (located near the former degreaser) were sampled at both five and 15 ft bgs. Location SG-3, located next to the clarifier inside the building, was sampled at five ft bgs. Soil to approximately fifteen ft bgs consisted of silty sand.

5.2 Soil Vapor Acquisition and Handling

At each sample location, probes were advanced to designated depths, soil vapor samples were extracted, and samples were immediately analyzed by the on-site laboratory. Sampling was performed by advancing 1/2 inch diameter galvanized hollow steel gas probes with an electric hammer. An electric rotary hammer drill was used to drill a one inch in diameter hole through the overlying concrete to allow probe placement.

At each sampling location, an electric vacuum pump (set to draw 2 liters/minute of soil vapors at a maximum vacuum of 100 inches of water) was attached to the probe and purged vapors for 45 seconds (approximately 1500 milliliters) at an average vacuum of 10 inches of water, extracting approximately two purge volumes of air prior to sample collection. A 3-point purge vs. concentration study was performed on October 26, 1995. This investigation determined that no significant change in concentration vs. purge volume occurred. Based on these results, approximately 2 purge volumes were used at subsequent sampling locations.

Samples were obtained in Hamilton gas-tight syringes by puncturing silicone tubing that connected the sampling probe and the vacuum pump. New silicone tubing was used at each sampling point to prevent cross contamination. After collection, samples were immediately injected into the gas chromatograph. New sampling probes were used after each sample collection, eliminating decontamination procedures between samples. In addition, equipment blanks were analyzed between each sample by passing ambient air through the sampling apparatus.

All analyses were performed on a laboratory grade Hewlett Packard model 5890 Series II gas chromatograph (GC) equipped with a Phote Ionization Detector (PID) and an Electron Capture Detector (ECD). Restec wide bore capillary columns, using hydrogen as the carrier gas, were used to perform all analysis. All data generated by the GC was collected on an IBM compatible personal computer and a specially designed software package converted GC data to concentrations expressed as micrograms/liter (µg/L).

5.3 Quality Assurance/Quality Control, (QA/QC) Procedures

Calibrations

On October 19, 1995, an initial 3-point calibration was performed prior to sampling by preparing a calibration solution from a pre-mixed standard supplied by Supelco, Inc. The standard solution contained 19 common halogenated solvents and 6 aromatic hydrocarbons. The individual compound concentrations in the standard ranged from 0.025 nanograms per micrograms ($ng/\mu g$) to 0.25 $ng/\mu g$.

The initial three point calibration consisted of 20, 50, and 100 microliter (µl) injections of the calibration solution. An average response factor (RF) was calculated for each analyte and used to determine concentrations. In addition, the percent relative standard deviation (%RSD) between the three calibration levels was determined to assure the instrument was operating properly. The %RSD must be less than 15% or an additional calibration is performed.

Method detection limits were calculated to $1.0 \,\mu\text{g/L}$ for both the halogenated solvents and the aromatic hydrocarbons.

TABLE 1

| Dichlorofluoromethane | Carbon Tetrachloride | Benzene |
|--------------------------|---------------------------|----------------|
| Trichlorofluoromethane | 1,2-Dichloroethane | Toluene |
| 1,1-Dichloroethene | Trichloroethene | Freon 113 |
| Methylene Chloride | 1,1.2-Trichloroethane | Ethylbenzene |
| trans-1,2-Dichloroethene | Tetrachloroethene | m\p-Xylene |
| 1,1-Dichloroethane | Chloroform | o-Xylene |
| cis-1,2-Dichloroethene | 1,1,1,2-Tetrachloroethane | Vinyl Chloride |
| 1,1,1-Trichloroethane | 1,1,2.2-Tetrachloroethane | Freon 113 |

Laboratory Check Sample

An independent laboratory check sample containing the 25 compounds listed in Table 1 was run as the first sample after the initial 3-point calibration on October 19, 1995. This sample was prepared independent (with different lot numbers) of the sample used in the 3-

point calibration. This assured that the standard used during the initial calibration had not degraded. These laboratory check samples must agree within 15% of the true concentration injected.

Continuing Calibrations

A one-point continuing calibration (mid-point) check using the compounds listed in Table 2 was run at the beginning of the work day (October 26, 1995) to verify the integrity of the existing 3-point calibration. This continuing calibrations must agree within 15% of the most recent three-point calibration or an additional three-point calibration would be performed and the new calibration factor used for the subsequent samples. This standard is also run at the end of the work day to assure that the instrument response had not changed.

TABLE 2

Methylene Chloride Trichloroethene

1,2-Dichloroethane 1,1,2-Trichloroethane

1,1-Dichloroethene Tetrachloroethene

trans-1,2-Dichloroethene Benzene
1,1-Dichloroethane Toluene
cis-1,2-Dichloroethene Ethylbenzene

1,1,1-Trichloroethane m/o-Xylene

Sample Replicates

A duplicate analysis was run when concentrations exceeded the calibration range of the instrument/detector being used. The duplicate sample was dilute using a smaller injection volume to assure that the instrument response was within 50% of the calibrated range. In addition, a duplicate analysis was run a minimum of once each day to evaluate the reproducibility of both the sampling system and the instrument. If the difference between samples collected varies more than 20%, the entire system was evaluated and the cause of the inconsistency was determined and corrected.

Equipment Blanks

Equipment blanks were run at the beginning of each work day, after calibrations, and at a minimum of once every five samples analyzed. New vapor probes were used following each sample with positive results or when probes were damaged during installation. The blanks were collected by hooking up the entire sampling system above ground and collecting an ambient air sample. These blanks checked the probes, fittings, septum, syringe, GC column, GC detector and the ambient air. If contamination was found to exist, the procedure was repeated until the source was determined and corrected. Blank results are given along with the sample results (Appendix B).

6.0 RESULTS AND FINDINGS

Subsurface soil conditions at this Site were predominantly a relatively high permeability silty sand. This silty sand appeared to be homogeneous throughout the study area. Depth to ground water was unknown at the time of the investigation.

During the soil-gas investigation, detectable levels of two halogenated compounds, 1,1,1-trichloroethane (111-TCA), and tetrachloroethene (PCE), were identified in trace (<5.0 μ g/L) to low levels (<50 μ g/L). 111-TCA was detected in all five samples at concentrations ranging from 4.7 μ g/L to 10.6 μ g/L. PCE was detected at all five samples at concentrations ranging from 1.1 μ g/L to 1.8 μ g/L. Multiple depth samples collected at locations SG-1 and SG-2 showed a decrease in concentration with depth.

During the course of the field investigation, TRG reviewed the QA/QC data performed by Optimal Technology to assess the impact of sampling equipment, laboratory equipment and laboratory procedures on analytical results. The review consisted of identifying analyte concentrations in sampling or test equipment, duplicate sample variances, and calibration shifts that would affect the analytical results. No results were outside of the QA/QC acceptable limits.

A complete table of analytical results, equipment blanks, duplicate results and calibration check samples are included with this report.

7.0 CONCLUSIONS

Based on the results of this investigation, low levels of 111-TCA and PCE were detected. The maximum contamination levels (MCL's) allowed by the U.S. Environmental Protection Agency are 200 μ g/L for 111-TCA and 5 μ g/L for PCE. Based on the results that only small amounts of 111-TCA and PCE exist in the soils in the area investigated, it appears no further action is required with respect to VOC's at this Site.

8.0 LIMITATIONS

The findings and conclusions presented above are based upon the agreed upon scope of work outlined in the above report. Soil vapor testing is only a subsurface screening tool and does not represent actual contaminant concentrations in either the soil and/or ground water. Consultant makes no warranties or guarantees as to the accuracy or completeness of information obtained from information provided or compiled by others. It is possible that information which was not found exists beyond the scope of this investigation. Additional information which was not found or available to Consultant at the time of writing of this report, may result in a modification of the findings and conclusions presented. This report is not a legal opinion.

Douglas S. Hodge, Ph.D.

Project Manager

F Edward Reynolds, Jr., P.J. California RCE #38677



FIGURE 1 SITE LOCATION MAP





FIGURE 2 SITE PLOT PLAN AND SAMPLING LOCATIONS



APPENDIX A LABORATORY REPORT

SOIL GAS SAMPLE RESULTS

SITE NAME: 1200 S. Victory Blvd. - Burbank, CA

LAB NAME: Optimal Technology Inc.

ANALYST: Timothy L. Theisen

COLLECTOR: Timothy L. Theisen

DATE: Oct. 26, 1995

INSTRUMENT ID: HP5890-2

NORMAL INJECTION VOLUME: ECD = 500 ul / PID = 500 ul

PAGE: 1 of 2

| SAMPLE ID: | BLANK-1 | SG-1-5-A | \$G-1-5-B | SG-1-5-C | SG-1-15 | SG-2-5 |
|------------------------|---------|----------|-----------|----------|---------|--------|
| | | | | 80-1-8-0 | 33-1-10 | 30.2.5 |
| Sampling Depth (ft): | N/A | 5.0 | 5.0 | 5.0_ | 15.0 | 5.0 |
| Purge Volume (mi): | N/A ı | 500 | 1000 | 1500 | 2000 | 1000 |
| Vacuum (in. of water): | N/A | 0 | 0 | 0 | 0 | 0 |
| Sampling Time: | N/A | N/A | N/A | N/A | N/A | N/A |
| Injection Time: | N/A | N/A | N/A | N/A | N/A | N/A |
| Injection Volume: | 500/500 | 500/500 | 100/500 | 100/500 | 50/500 | 50/500 |
| Dilution Factor ECD: | 2 | 2 | 10 | 10 | 20 | 20 |
| Dilution Factor PID: | 2 | 2 | 2 | 2 | 2 | 2 |

| COMPOUND | DET | AREA | CONC | AREA | CONC | AREA | CONC | AREA | CONC | AREA | CONC | AREA | CONC |
|---------------------------|-----|------|-------|---------|-------|--------|-------|---------|-------|--------|-------|--------|-------|
| Dichlorofluoromethane | ECD | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | <1.0 | 0 | < 1.0 |
| Chloroethane | ECD | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | <1.0 | 0 | < 1.0 | 0 | < 1.0 |
| Trichlorofluoromethane | ECD | 0 | <1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | <1.0 | 0 | <1.0 | 0 | <1.0 |
| Trichlorotrifluoromethane | ECD | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | <1.0 | 0 | < 1.0 |
| Methylene Chloride | ECD | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | ol | < 1.0 |
| 1,1-Dichloroethane | ECD | 0 | < 1.0 | O | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | ol | < 1.0 |
| Chloroform | ECD | 0 | <1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 |
| 1,1,1-Trichloroethane | ECD | 0 | <1.0 | 5908119 | 12.5 | 996607 | 10.5 | 1010526 | 10.6 | 369395 | 7.B. | 223125 | 4.7 |
| Carbon Tetrachloride | ECD | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | o | < 1.0 |
| 1,2-Dichloroethane | ECD | 0 | <1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 |
| Trichloroethene | ECD | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 |
| 1,1,2-Trichloroethane | ECD | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | <1.0 |
| Tetrachloroethene | ECD | 0 | < 1.0 | 1181900 | 1.4 | 243315 | 1.5 | 223778 | 1.4 | 121977 | 1.5 | 0 | < 1.0 |
| 1,1,1,2-Tetrachloroethane | ECD | 0 | <1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 |
| 1,1,2,2-Tetrachloroethane | ECD | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 |
| Vinyl Chloride | PID | 0 | <1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | ol | < 1.0 |
| 1,1-Dichloroethene | PID | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | <1.0 |
| trans-1,2-Dichloroethene | PID | U. | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | <1.0 | 0 | < 1.0 | 0 | < 1.0 |
| cis-1,2-Dichloroethene | PID | 0 | <1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 |
| Benzene | PID | 0 | <1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | <1.0 |
| Toluene | PID | 0 | <1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 |
| Ethylbenzene | PID | 0 | <1.0 | 0 | < 1.0 | 0 | < 1.0 | 0 | < 1.0 | 0. | < 1.0 | 0 | < 1.0 |
| m/p/o-Xylene | PID | 0 | <1.0 | 0 | <1.0 | 0 | < 1.0 | 0 | <1.0 | 0 | <1.0 | 0 | <1.0 |

| Unidentified Peaks (ECD): | 0 | 0 | 0 | 0 | 0 |
|---------------------------|---|---|---|---|---|
| Unidentified Peaks (PID): | 0 | 0 | 0 | 0 | 0 |

COMMENTS:

All results are reported in ug/L

SOIL GAS SAMPLE RESULTS

SITE NAME: 1200 S. Victory Blvd. - Burbank, CA

LAB NAME: Optimal Technology Inc.

DATE: Oct. 26, 1995

ANALYST: Timothy L. Theisen

COLLECTOR: Timothy L. Theisen

INSTRUMENT ID: HP5890-2

NORMAL INJECTION VOLUME: ECD = 500 ul / PID = 500 ul

PAGE: 2 of 2

| SAMPLE ID: | SG-2-15 | SG-3-5 | |
|------------------------|---------|---------|--|
| Sampling Depth (ft): | 15.0 | 5.0 | |
| Purge Volume (ml): | 2000 • | 1000 | |
| Vacuum (in. of water): | 0 | 0 | |
| Sampling Time: | N/A | N/A | |
| Injection Time: | N/A | N/A | |
| Injection Volume: | 100/500 | 100/500 | |
| Dilution Factor ECD: | 10 | 10 | |
| Dilution Factor PID: | 2 | 2 | |

| COMPOUND | DET | AREA | CONC | AREA | CONC | | | | | | |
|---------------------------|-----|--------|-------|--------|-------|---|----------|---|------|----------|---------|
| Dichlorofluoromethane | ECD | 0 | <1.0 | 0 | < 1.0 | | | | | | |
| Chloroethane | ECD | 0 | <1.0 | 0 | < 1.0 | | | | | <u> </u> | |
| Trichlorofluoromethane | ECD | 0 | < 1.0 | 0 | < 1.0 | | | | | | |
| Trichlorotrifluoromethane | ECD | 0 | <1.0 | 0 | < 1.0 | | | | | | |
| Methylene Chloride | ECD | 0 | <1.0 | 0 | < 1.0 | | | | | | |
| 1,1-Dichloroethane | ECD | 0 | < 1.0 | 0 | < 1.0 | | | | | | |
| Chloroform | ECD | 0 | <1.0 | 0 | < 1.0 | | <u> </u> | | | | |
| 1,1,1-Trichloroethane | ECD | 484267 | 5.1 | 457856 | 4.8 | 1 | | | | | |
| Carbon Tetrachloride | ECD | 0 | <1.0 | 0 | < 1.0 | | | | | | |
| 1,2-Dichloroethane | ECD | 0 | < 1.0 | 0 | < 1.0 | | | | | | |
| Trichloroethene | ECD | 0 | < 1.0 | 0 | < 1.0 | | 1 | 1 | | | |
| 1,1,2-Trichloroethane | ECD | 0 | < 1.0 | 0 | < 1.0 | | | | | | |
| Tetrachloroethene | ECD | 181334 | 1.1 | 292807 | 1.8 | | | | | | |
| 1,1,1,2-Tetrachloroethane | ECD | 0 | < 1.0 | 0 | < 1.0 | | | | | | |
| 1,1,2,2-Tetrachloroethane | ECD | 0 | <1.0 | 0 | < 1.0 | | i | | | | |
| Vinyl Chloride | PID | 0 | < 1.0 | 0 | < 1.0 | | | | | | |
| 1,1-Dichloroethene | PID | 0 | <1.0 | 0 | < 1.0 | | | | | | |
| trans-1,2-Dichloroethene | PID | ر | < 1.0 | 0 | < 1.0 | | | | | | |
| cis-1,2-Dichloroethene | PID | 0 | <1.0 | 0 | < 1.0 | | | | | | |
| Benzene | PID | 0 | <1.0 | 0 | < 1.0 | | | | | | |
| Toluene | PID | 0 | < 1.0 | 0 | < 1.0 | | | | | | |
| Ethylbenzene | PID | 0 | <1.0 | 0 | < 1.0 | | | | | | |
| m/p/o-Xylene | PID | 0 | <1.0 | 0 | < 1.0 | | | | | | |

| Unidentified Peaks (ECD): | 0 | 0 |
|---------------------------|---|---|
| Unidentified Peaks (PID): | 0 | 0 |

COMMENTS: All results are reported in ug/L

SOIL GAS INITIAL CALIBRATION STANDARD REPORT

SITE NAME: 1200 S. Victory Blvd. - Burbank, CA

LAB NAME: Optimal Technology Inc.

DATE: Oct. 19, 1995

ANALYST: Timothy L. Theisen

STD LOT ID NO.: LA-48322/LA-48327

INSTRUMENT ID: HP5890-2

NORMAL INJECTION VOLUME: 20, 50 and 100 ul

INJECTION TIME: 4:30 - 5:30 am

| COMPOUND | DET | | 181 | CONC | | | 2nd | CONC | | | 3rd | CONC |] | RF AVE | SD | %RSD | |
|---------------------------|-----|-------|------|---------|---------|-------|------|---------|---------|-------|------|----------|---------|---------|--------|-------|-----|
| | | RT | MASS | AREA | RF | RT | MASS | AREA | RF | RT | MASS | AREA | RF | | | | |
| Dichlorodifluoromethane | ECD | 0.871 | 0.5 | 200262 | 400523 | 0.871 | 1.25 | 478267 | 382613 | 0.871 | 2.5 | 897461 | 358984 | 380707 | 20835 | 5.47% | |
| Chloroethane | ECD | 1.532 | 2.5 | 1519 | 608 | 1.040 | 6.25 | 3574 | 572 | 1.040 | 12.5 | 6877 | 550 | 577 | 29 | 5.04% | |
| Trichlorofluoromethane | ECD | 1.228 | 0.5 | 2235808 | 4471615 | 1.228 | 1.25 | 5590037 | 4472030 | 1.228 | 2.5 | 11109792 | 4443917 | 4462521 | 16113 | 0.36% | |
| Trichlorotrifluoromethane | ECD | 1.394 | 0.5 | 345254 | 690508 | 1.394 | 1.25 | 836711 | 669368 | 1.394 | 2.5 | 1632983 | 653193 | 671023 | 18712 | 2.79% | |
| Methylene Chloride | ECD | 1.577 | 2.5 | 16039 | 6416 | 1.577 | 6.25 | 44103 | 7056 | 1.577 | 12.5 | 82109 | 6569 | 6680 | 335 | 5.01% | |
| 1, 1-Dichloroethane | ECD | 1.869 | 2.5 | 5998 | 2399 | 1.869 | 6.25 | 14747 | 2360 | 1.869 | 12.5 | 29153 | 2332 | | 34 | 1.43% | |
| Chloroform | ECD | 2.284 | 0.5 | 163551 | 327103 | 2.284 | 1.25 | 437936 | 350349 | 2.284 | 2.5 | 855013 | 342005 | 339819 | 11776 | 3.47% | |
| 1,1,1-Trichloroethane | ECD | 2.401 | 0.5 | 472482 | 944964 | 2.401 | 1.25 | 1187694 | 950155 | 2.401 | 2.5 | 2379412 | 951765 | 948962 | 3554 | 0.37% | |
| Carbon Tetrachloride | ECD | 2.497 | 0.5 | 1497349 | 2994698 | 2.497 | 1.25 | 3438417 | 2750734 | 2.497 | 2.5 | 6594218 | 2637687 | 2794373 | 182462 | 6.53% | , , |
| 1,2-Dichloroethane | ECD | 2.642 | 2.5 | 20525 | 8210 | 2.642 | 6.25 | 55380 | 8861 | 2.642 | 12.5 | 108887 | 8711 | 8594 | 341 | 3.96% | |
| Trichloroethene | ECD | 2.993 | 0.5 | 201540 | 403080 | 2.993 | 1.25 | 558828 | 447063 | 2.993 | 2.5 | 1053521 | 421408 | 423850 | 22093 | 5.21% | |
| 1,1,2-Trichloroethane | ECD | 4.228 | 2.5 | 107991 | 43197 | 4.228 | 6.25 | 275751 | 44120 | 4.228 | 12.5 | 510160 | 40813 | 42710 | 1707 | 4.00% | |
| Tetrachloroethene | ECD | 4.363 | 0.5 | 819954 | 1639909 | 4.363 | 1.25 | 2112248 | 1689798 | 4.363 | 2.5 | 4037593 | 1615037 | 1648248 | 38072 | 2.31% | ~ |
| 1,1,1,2-Tetrachioroethane | ECD | 5.195 | 0.5 | 548384 | 1096768 | 5.195 | 1.25 | 1411862 | 1129490 | 5,195 | 2.5 | 2961489 | 1184596 | 1136951 | 44387 | 3.90% | |
| 1,1,2,2-Tetrachloroethane | ECD | 6.414 | 0.5 | 93759 | 187519 | 6.414 | 1.25 | 214415 | 171532 | 6.414 | 2.5 | 459907 | 183983 | 181004 | 8394 | 4.64% | |
| Vinyl Chloride | PID | 2.034 | 2.5 | 14398 | 5759 | 2.034 | 6.25 | 40623 | 6500 | 2.034 | 12.5 | 79724 | 6378 | 6212 | 397 | 6.39% | |
| 1, 1-Dichloroethene | PID | 2.746 | 2.5 | 21640 | 8656 | 2.746 | 6.25 | 57235 | 9168 | 2.746 | 12.5 | 116746 | 9340 | 9051 | 354 | 3.91% | |
| trans-1,2-Dichloroethene | PID | 3.195 | 2.5 | 39249 | 15700 | 3.195 | 6.25 | 99725 | 15956 | 3.195 | 12.5 | 183264 | 14661 | 15439 | 686 | 4.44% | |
| cis-1, 2-Dichloroethene | PID | 3.866 | 2.5 | 19346 | 7738 | 3.866 | 6.25 | 51545 | 8247 | 3.866 | 12.5 | 98882 | 7911 | 7985 | 259 | 3.25% | |
| Benzene | PID | 4.633 | 2.5 | 40264 | 16106 | 4.633 | 6.25 | 103268 | 16523 | 4.633 | 12.5 | 192348 | 15388 | 16005 | 574 | 3.59% | |
| Toluene | PID | 6.316 | 2.5 | 30136 | 12054 | 6.316 | 6.25 | 76622 | 12260 | 6.316 | 12.5 | 153210 | 12257 | 12190 | 118 | 0.96% | |
| Ethylbenzene | PID | 7.867 | 2.5 | 18133 | 7253 | 7.867 | 6.25 | 48136 | 7702 | 7.867 | 12.5 | 95213 | 7617 | 7524 | 238 | 3.17% | |
| m/p-Xylene | PID | 7.955 | 5 | 41370 | 8274 | 7.955 | 12.5 | 113219 | 9058 | 7.955 | 25 | 203479 | 8139 | 8490 | 496 | 5.84% | |
| o-Xylene | PID | 8.430 | 2.5 | 21327 | 8531 | 8.430 | 6.25 | 53727 | 8596 | 8.430 | 12.5 | 119321 | 9546 | 8891 | 568 | 6.39% | _ |

LABORATORY CONTROL CHECK STANDARD

SITE NAME: 1200 S. Victory Blvd. - Burbank, CA LAB NAME: Optimal Technology Inc. DATE: Oct. 19, 1995

ANALYST: Timothy L. Theisen STD LOT ID NO.: LA-42967/LA-42996 INSTRUMENT ID: HP5890-

NORMAL INJECTION VOLUME: ECD = 50 ul / PID = 50 ul INJECTION TIME: 5:17 am File: E/PEN-04.D

| COMPOUND | DET | RT | MASS | AREA | RF | %DIFF | ACC RGE |
|---------------------------|-----|-------|------|---------|---------|--------|---------|
| Dichlorodifluoromethane | ECD | 0.910 | 1.25 | 456192 | 364954 | 4.14% | ±15% |
| Chloroethane | ECD | 1.147 | 6.25 | 3836 | 614 | -6.45% | ± 15% |
| Trichlorofluoromethane | ECD | 1.382 | 1.25 | 4984629 | 3987703 | 10.64% | ±15% |
| Trichlorotrifluoromethane | ECD | 1.648 | 1.25 | 732656 | 586125 | 12.65% | ±15% |
| Methylene Chloride | ECD | 1.933 | 6.25 | 38265 | 6122 | 8.35% | ±15% |
| 1,1-Dichloroethane | ECD | 2.409 | 6.25 | 13987 | 2238 | 5.32% | ± 15% |
| Chloroform | ECD | 3.080 | 1.25 | 387599 | 310079 | 8.75% | ± 15% |
| 1, 1, 1-Trichloroethane | ECD | 3.230 | 1.25 | 1039879 | 831903 | 12.34% | ±15% |
| Carbon Tetrachloride | ECD | 3.369 | 1.25 | 3292456 | 2633965 | 5.74% | ±15% |
| 1,2-Dichloroethane | ECD | 3.549 | 6.25 | 52323 | 8372 | 2.59% | ± 15% |
| Trichloroethene | ECD | 4.097 | 1.25 | 508782 | 407026 | 3.97% | ± 15% |
| 1,1,2-Trichloroethane | ECD | 5.695 | 6.25 | 233874 | 37420 | 12.39% | ± 15% |
| Tetrachloroethene | ECD | 5.836 | 1.25 | 1973427 | 1578742 | 4.22% | ±15% |
| 1,1,1,2-Tetrachioroethane | ECD | 6.802 | 1.25 | 1283291 | 1026633 | 9.70% | ±15% |
| 1,1,2,2-Tetrachloroethane | ECD | 8.142 | 1.25 | 202879 | 162303 | 10.33% | ±15% |
| Vinyl Chloride | PID | 2.039 | 6.25 | 38790 | 6206 | 0.09% | ± 30% |
| 1,1-Dichloroethene | PID | 2.748 | 6.25 | 54751 | 8760 | 3.21% | ± 15% |
| trans-1,2-Dichloroethene | PID | 3.195 | 6.25 | 88243 | 14119 | 8.55% | ±15% |
| cis-1, 2-Dichloroethene | PID | 3.862 | 6.25 | 46155 | 7385 | 7.29% | ± 15% |
| Benzene | PID | 4.625 | 6.25 | 87959 | 14073 | 12.07% | ± 15% |
| Toluene | PID | 6.304 | 6.25 | 68230 | 10917 | 10.45% | ±15% |
| Ethylbenzene | PID | 7.851 | 6.25 | 43166 | 6907 | 8.21% | ± 15% |
| m/p-Xylene | PID | 7.940 | 12.5 | 90296 | 7224 | 14.92% | ±15% |
| o-Xylene | PID | 8.415 | 6.25 | 48481 | 7757 | 12.75% | ± 15% |

DAILY MID-POINT CHECK STANDARD

SITE NAME: 1200 S. Victory - Burbank, CA LAB NAME: Optimal Technology Inc. DATE: Oct. 26, 1995

ANALYST: Timothy L. Theisen

STD LOT ID NO.: LA-42995 INSTRUMENT ID: HP5890-

NORMAL INJECTION VOLUME: ECD = 50 ul / PID = 50 ul

INJECTION TIME: 7:53 am File: E/PCER-01.D

| COMPOUND | DET | RT | MASS | AREA | RF | %DIFF | ACC RGE |
|---------------------------|-----|-------|------|---------|---------|--------|---------|
| Dichlorodifluoromethane | ECD | | | | | | ±15% |
| Chloroethane | ECD | | | | | | ±15% |
| Trichlorofluoromethane | ECD | | | | | | ± 15% |
| Trichlorotnfluoromethane | ECD | | | | | | ±15% |
| Methylene Chloride | ECD | 1.989 | 6.25 | 38373 | 6140 | 8.09% | ±15% |
| 1,1-Dichloroethane | ECD | 2.474 | 6.25 | 13912 | 2226 | 5.83% | ±15% |
| Chloroform | ECD | | | | | | £15% |
| 1,1,1-Trichloroethane | ECD | 3.307 | 1.25 | 1078723 | 862978 | 9.06% | ± 15% |
| Carbon Tetrachloride | ECD | | | | | | ± 15% |
| 1,2-Dichloroethane | ECD | 3.628 | 6.25 | 51249 | 8200 | 4.59% | ±15% |
| Trichloroethene | ECD | 4.179 | 1.25 | 474332 | 379466 | 10.47% | ± 15% |
| 1,1,2-Trichloroethane | ECD | 5.781 | 6.25 | 234398 | 37504 | 12.19% | ± 15% |
| Tetrachloroethene | ECD | 5.923 | 1.25 | 1874327 | 1499462 | 9.03% | ±15% |
| 1,1,1,2-Tetrachloroethane | ECD | | | | | | ±15% |
| 1,1,2,2-Tetrachloroethane | ECD | | | | | | ± 15% |
| Vinyl Chlonde | PID | | | | | | ± 30% |
| 1,,1-Dichloroethene | PID | 2.872 | 6.25 | 52324 | B372 | 7 50% | ±15% |
| trans-1,2-Dichloroethene | PID | 3.335 | 6.25 | 90213 | 14434 | 6.51% | ±15% |
| cis-1,2-Dichloroethene | PID | 4.020 | 6.25 | 46322 | 7412 | 6.95% | ±15% |
| Benzene | PID | 4.797 | 6.25 | 93213 | 14914 | 6.82% | ± 15% |
| Toluene | PID | 6.492 | 6.25 | 72431 | 11589 | 4.93% | ± 15% |
| Ethylbenzene | PID | 8.047 | 6.25 | 44321 | 7091 | 5.75% | ± 15% |
| m/p-Xylene | PID | 8.136 | 6.25 | 47453 | 7592 | 10.57% | ±15% |
| o-Xylene | PID | 8.588 | 6.25 | 51328 | 8212 | 7.63% | ±15% |

LABORATORY CONTROL CHECK STANDARD

SITE NAME: 1200 S. Victory - Burbank, CA LAB NAME: Optimal Technology Inc. DATE: Oct. 26, 1995

ANALYST: Timothy L. Theisen


STD LOT ID NO.: LA-42995

INSTRUMENT ID: HP5890-

NORMAL INJECTION VOLUME: ECD = 50 ul / PID = 50 ul

INJECTION TIME: 1:47 pm File: E/PCER-2017.D

| COMPOUND | DET | RT | MASS | AREA | RF | %D0FF | ACC RGE |
|---------------------------|-----|-------|------|---------|---------|--------|---------|
| Dichlorodifluoromethane | ECD | | | | | | ±15% |
| Chloroethane | ECD | | | | | | ±15% |
| Trichlorofluoromethane | ECD | | | | | | ±15% |
| Trichlorotrifluoromethane | ECD | | | | | | ± 15% |
| Methylene Chloride | ECD | 1.989 | 6.25 | 37656 | 6025 | 9.81% | ±15% |
| 1,1-Dichloroethane | ECD | 2.474 | 6.25 | 12999 | 2080 | 12.01% | ±15% |
| Chloroform | ECD | | | | | | ± 15% |
| 1,1,1-Trichloroethane | ECD | 3.307 | 1.25 | 1073242 | 858594 | 9.52% | ± 15% |
| Carbon Tetrachloride | ECD | | | | | | ±15% |
| 1,2-Dichloroethane | ECD | 3.628 | 6.25 | 47544 | 7607 | 11.48% | ±15% |
| Trichloroethene | ECD | 4.179 | 1.25 | 459546 | 367637 | 13.26% | ±15% |
| 1,1,2-Trichloroethane | ECD | 5.781 | 6.25 | 231298 | 37008 | 13.35% | ±15% |
| Tetrachloroethene | ECD | 5.923 | 1.25 | 1821437 | 1457150 | 11.59% | ±15% |
| 1,1,1,2-Tetrachloroethane | ECD | | | | | | ±15% |
| 1,1,2,2-Tetrachloroethane | ECD | | | | | | ±15% |
| Vinyl Chloride | PID | | | | | | ± 30% |
| 1,1-Dichloroethene | PID | 2.872 | 6.25 | 49298 | 7888 | 12.85% | ±15% |
| trans-1,2-Dichloroethene | PID | 3.335 | 6.25 | 85476 | 13676 | 11.42% | ± 15% |
| cis-1,2-Dichloroethene | PID | 4.020 | 6.25 | 43987 | 7038 | 11.64% | ± 15% |
| Benzene | PID | 4.797 | 6.25 | 86907 | 13905 | 13.12% | ± 15% |
| Toluene | PID | 6.492 | 6.25 | 58843 | 11015 | 9.64% | ± 15% |
| Ethylbenzene | PID | 8.047 | 6.25 | 41987 | 6718 | 10.71% | ±15% |
| m/p-Xylene | PID | 8.136 | 6.25 | 47367 | 7579 | 10.74% | ±15% |
| o-Xylene | PID | 8.588 | 6.25 | 48897 | 7824 | 12.01% | ±15% |



ALLEY

EXPLANATION

Soil Vapor Sampling Locations

NOT TO SCALE

Optimal Technology Inc.

P.O. Box 547 Summerland, CA 93067

Tel: (805) 969-2444 * Fax: (805) 969-6597

DATE: Oct. 26, 1995

PROJECT NO: OTI-100695

APPROVED BY: TLT

FIGURE

COMPANY:

THE REYNOLDS GROUP

TITLE:

SOIL VAPOR SAMPLING LOCATIONS 1200 S. VICTORY BLVD. - BURBANK, CA