ANALYTICAL RESULTS OF SURFACE WATER SAMPLES COLLECTED FROM RACCOON CREEK October 27, 1998 Sampling Event

Prepared for

ARCO CHEMICAL COMPANY/BEAZER EAST INC.

Prepared by

Applied Hydrology Associates, Inc. Denver, Colorado

December 15, 1998



ANALYTICAL RESULTS OF SURFACE WATER SAMPLES COLLECTED FROM RACCOON CREEK October 27, 1998 Sampling Event

Prepared for

ARCO CHEMICAL COMPANY/BEAZER EAST INC.

Prepared by

Applied Hydrology Associates, Inc. Denver, Colorado

December 15, 1998

ARCO CHEMICAL COMPANY Monaca, Pennsylvania

TABLE OF CONTENTS

Section	Page
1.0	INTRODUCTION1
2.0	SAMPLING1
3.0	RESULTS2
Tables	Summary of Analytical Results for Samples Collected from Raccoon Creek
2 Figure:	Historical Benzene Concentrations at Transect E
1 2	Transect Location Map Surface Water Benzene Concentrations at Transect E
Annen	dices

Groundwater Elevations, East and West Sides of Raccoon Creek Appendix A Data Validation Report Appendix B

Monaca, Pennsylvania

1.0 INTRODUCTION

This report presents the results of surface water samples collected from Raccoon Creek at the ARCO Chemical Company (ACC) / Beazer East Inc. (BEI) Monaca, PA site during the October 1998 quarterly monitoring event. The samples were collected in compliance with Appendix D of the Consent Order and Agreement (CO&A) between ARCO Chemical Company, BEI and the Pennsylvania Department of Environmental Protection (PADEP) dated October 20, 1997.

2.0 SAMPLING

Surface water samples were collected at Transect E as defined in the 1997 CO&A. The locations of Transect E is shown in Figure 1. In addition, water elevations were measured in nearby monitoring wells and the results are presented in Appendix A.

A total of nine surface water samples, including two duplicates were collected from Raccoon Creek on October 27, 1998. These samples were collected at the same three locations along Transect E as in previous sampling events. The locations are shown in Figure 2 and are at the center of the stream, and approximately 30 feet from the east and west banks. At the center location, samples were collected at three depths: 6 inches below surface, 2 inches above the bottom, and midway between the surface and bottom. Samples from the east and west sides of the transect were collected at two depths: 1 to 2 inches above the bottom, and midway between the surface and bottom.

During sampling the boat was anchored at Transect E and the anchors were laid away from the sampling location so sediment would not be introduced into the water sample. The samples were collected by using a peristaltic pump to pump water from the desired depth into three 40-milliliter vials preserved with hydrochloric acid. The depth of sample collection was controlled by securing tubing to a probe long enough to reach the bottom of the creek. The tubing was secured at the desired depth from the bottom of the probe, and the probe was set on the bottom of the creek. Care was taken not to disturb the sediments at the sampling location and the water was closely monitored to ensure sediment was not included in the sample. After the sample had been collected, the tubing was moved to the correct depth for the next sample, reattached to the probe, and the next sample was collected after again lowering the probe. One length of tubing was used for all sampling depths at each location. Tubing was discarded and replaced between sampling locations.

The samples were uniquely numbered as follows to identify the location, depth and date of sampling:

RC-EC-00-1098

Where:

RC indicates Raccoon Creek;

EC indicates Transect E and location (C = center, L = left bank, R = right bank

([facing downstream]);

indicates sample depth in feet and tenths of a foot (0.0 feet); and

1098 indicates the month and year collected (October 1998)

Analytical Results of Surface Water Samples Collected from Raccoon Creek

ARCO CHEMICAL COMPANY
Monaca, Pennsylvania

Samples were logged onto a chain of custody form (included as part of the data validation report in Appendix B) and stored on ice until receipt by Reliance Laboratories Inc. in Edison, NJ. Reliance analyzed the samples using USEPA Method 524.2 for BTEXS.

3.0 RESULTS

The analytical results are presented in Table 1, which is the Certificate of Analysis from Reliance Laboratories. Benzene was detected in six of the nine samples and concentrations in samples where benzene was detected ranged from 0.20 µg/L in Sample RC-EC-27-1098 to 1.63 µg/L in sample RC-EL-20-1098A. Sampling locations and depths are shown on Figure 2, along with the concentration of benzene at each location. Water levels in wells near Raccoon Creek are presented in Appendix A.

The analytical data were validated upon receipt and found to be acceptable. A Data Validation Report is included as Appendix B. Table 2 presents the historical concentration of benzene in Raccoon Creek at Transect E during all monitoring events to date.

TABLE 1

R E L I A N C E LABORATORIES INC.



175 MAY STREET, EDISON, NJ 08837 PH (732) 738-5454 FAX (732) 738-5841 EMAIL: 74201.3501@COMPUSERVE.COM

LABORATORY ID NJ DEP 12687 PA DER 68437

CERTIFICATE OF ANALYSIS

Customer:

Arco / Beazer

Sample:

Water Samples

Lab ID:

R-6122

Reference:

Arco Beaver Valley

11 November 1998

Units: μg/L

Sample ID	Benzene	Toluene	Ethylbenzene	Xylene	Styrene
RC-EL-20-1098	1.50	6.80	2.59	11.02	< 0.58
RC-EL-20-1098A	1.63	7.25	2.71	11.69	< 0.58
RC-EL-38-1098	0.42	1.60	0.59	2.58	< 0.58
RC-EL-38-1098A	0.79	4.90	2.52	10.62	< 0.58
RC-EC-00-1098	< 0.13	< 0.6	< 0.22	< 0.22	< 0.58
RC-EC-27-1098	0.20	< 0.6	< 0.22	0.56	< 0.58
RC-EC-57-1098	< 0.13	< 0.6	< 0.22	< 0.22	< 0.58
RC-ER-66-1098	< 0.13	< 0.6	< 0.22	< 0.22	< 0.58
RC-ER-35-1098	0.52	0.83	0.26	1.86	< 0.58

G. P. Kirpalani Manager


Epkerselani


Monaca, Pennsylvania

Table 2
Historic Benzene Concentrations at Transect E (ug/L)

Sampling Location	Sampling Depth	7/23/97	10/28/97	2/25/98	5/21/98	7/29/98	10/27/98
30 Feet off West Bank	Mid-depth	0.28	<0.13	<0.13	0.70	<0.13	1.57 ⁽¹⁾
30 Feet off West Bank	Deep	0.81	<0.13	<0.13	0.70	<0.13	0.61(1)
Center of Creek	Shallow	0.24	<0.13	0.38	0.70	<0.13	<0.13
Center of Creek	Mid-Depth	0.18	<0.13	0.49	0.64	<0.13	0.2
Center of Creek	Deep	0.46	<0.13	0.30	0.60	<0.13	<0.13
30 Feet off East Bank	Mid-depth	0.16	<0.13	<0.13	<0.13	0.13	0.52
30 Feet off East Bank	Deep	<0.13	<0.13	0.14	0.22	0.22	<0.13

⁽¹⁾ Results shown area average of blind duplicate samples.





Appendix A

Groundwater Elevations, East and West Sides of Raccoon Creek

GROUNDWATER LEVELS ON THE EAST AND WEST SIDES OF RACCOON CREEK October 27, 1998

				OTH AREA		
Well Number	Top of Casing		Depth to Water	Calculated Water	Calculated SPL	Comments
	(TOC)	from TOC (2)	from TOC (2)	Level Elevation (1)	Thickness (3)	
	(ft. amsl)	(ft. amsl)	(ft. amsl)	(ft. amsl)	(ft. amsl)	
MW - 360	685,84	ND	2.16	683.68	N/A	
MW - 170	706.70	ND	22.45	684.25	N/A	
MW 362	689.43	ND	5.72	683.71	N/A	
			RAC	COON CREEK AR	REA	
Well Number	Top of Casing	Depth to SPL	Depth to Water	Calculated Water	Calculated SPL	Comments
	(TOC)	from TOC (2)	from TOC (2)	Level Elevation (1)	Thickness (3)	
	(ft. amsl)	(ft. amsl)	(ft. amsl)	(ft. amsl)	(ft. amsl)	
MW- 118	690,39	ND	6.83	683.56	N/A	
MW - 502	701.86	ND	18.40	683.46	N/A	
MW - 119	705.59	ND	22.10	683.49	N/A	
MW - 120	709.42	ND	25.86	683.56	N/A	
MW - 121	713.90	ND	30.33	683.57	N/A	
MW - 152	696.35	ND	12.85	683.50	N/A	
Note: see figure						
Mater can transm	1		1			

GROUNDWATER LEVELS ON THE EAST AND WEST SIDES OF RACCOON CREEK October 27, 1998

				OTH AREA		
Well Number		Depth to SPL from TOC (2) (ft. amsl)	Depth to Water from TOC (2) (ft. amsl)	Calculated Water Level Elevation (1) (ft. amsl)	Calculated SPL Thickness (3) (ft. amsl)	Comments
MW - 344	709.42	ND	25.49	683,93	N/A	
MW - 359S	692.93	ND	9.33	683.60	N/A	
MW - 361S	689.40	ND	5.86	683.54	N/A	
MW - 169	707.93	ND	24.30	683,63	N/A	
MW - 167	707.36	ND	23.81	683.55	N/A	
Note: see figur	e 2					

GROUNDWATER LEVELS ON THE EAST AND WEST SIDES OF RACCOON CREEK October 27, 1998

RACCOON CREEK AREA									
Vell Number	Top of Casing (TOC) (ft. amsl)	Depth to SPL from TOC (2) (ft. amsl)	-	Calculated Water Level Elevation (1) (ft. amsl)		Comments			
MW - 163S	690.87	ND	7.31	683.56	N/A				
MW - 501S	701.30	ND	18.08	683.22	N/A				
MW - 162S	706.05	ND	22.55	683.50	N/A				
MW - 159	708.99	ND	25.47	683.52	N/A				
MW - 160	701.00	ND	17.46	683.54	N/A				
MW - 158S	713.60	ND	30.10	683.50	N/A				
MW - 122	692.78	ND	9.29	683.49	N/A				
lote: see figure	2								

⁽⁴⁾ Could not determine interface between SPL and groundwater. SPL elevation shown.

GROUNDWATER LEVELS ON THE EAST AND WEST SIDES OF RACCOON CREEK October 27, 1998

			RACCOON CREEK A	1 Creek and Ohio River REA STAFF GAUGE	
Time of observation	Staff Gauge Elevation (a) (ft. amsl)	Staff Gauge reading	Calculated Water Level Elevation (ft. amsl)	Comments	
12:05	685.00	1.47	683.47		
13:41	685.00	1.49	683.49		
			OHIO RIVER.		
Time of observation	Staff Gauge Elevation (b) (ft. amsl)	Staff Gauge reading	Calculated Water Level Elevation (ft. amsl)	Comments	
11:54	685.96	3.46	683.42	*	
13:20	685.96	3.50	683.46		
				9	
				3.	
				Y	
				3	
				9	
				4	

GROUNDWATER LEVELS ON THE EAST AND WEST SIDES OF RACCOON CREEK October 27, 1998

		IVAUIII IUE	, vicus bele	OTH AREA	Sand and Gravel	
Well Number	Top of Casing	_	Depth to Water		Calculated SPL	Comments
	(TOC)	from TOC (2)	from TOC (2)	Level Elevation (1)	Thickness (3)	
	(ft. amsl)	(ft. amsl)	(ft. amsl)	(ft. amsl)	(ft. amsl)	
MW 345	708.91	ND	25.41	683.50	N/A	
MW 361D	689.35	ND	5.79	683.56	N/A	
MW 359D	692.80	ND	9.30	683.50	N/A	
			RAC	CCOON CREEK AR	EA	
Well Number	Top of Casing	Depth to SPL	Depth to Water	Calculated Water	Calculated SPL	Comments
	(TOC)	from TOC (2)	from TOC (2)	Level Elevation (1)	Thickness (3)	
	(ft. amsl)	(ft. amsl)	(ft. amsl)	(ft. amsl)	(ft. amsl)	
MW 163D	689.62	ND	6.00	683.62	N/A	
MW 501D	701.44	ND	17.99	683.45	N/A	
MW 166D	703.95	ND	20.51	683.44	N/A	
MW 158D	712.04	ND	28.68	683.36	N/A	
Note: see figure	4					
		Elevation of To	OC minus Depth	to Water from TOC.		
				e. ND means no SPL	was detected	

AHA FilenameRaccwtrl.xls 5 OF 5 12/15/9812:36 PM

Appendix B Data Validation Report



1200 South Parker Road, Suite 100

Denver, CO 80231

Tel: (303) 873-0164

Fax: (303) 873-6110

MEMORANDUM

TO:

Skip Meier, Applied Hydrology Associates

FROM:

Adam Bedard, Applied Hydrology Associates

DATE:

December 9, 1998

SUBJECT:

Data Validation Results, Lyondell Petrochemical Company Beaver Valley

Property

Data validation was performed on the volatile organic analytical data from nine surface water samples obtained from Raccoon Creek on October 27, 1998. The validation was performed in accordance with the "USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review". Reliance Laboratories Inc. performed the analysis using EPA Method 524.2. The samples reviewed included:

Field Sample ID	Lab Sample ID
EL-20-1098	R-6075.1
EL-20-1098A	R-6075.2
EL-38-1098	R-6075.3
EL-38-1098A	R-6075.4
EC-00-1098	R-6075.5
EC-27-1098	R-6075.6
EC-57-1098	R-6075.7
EC-66-1098	R-6075.8
EC-35-1098	R-6075.9

Items reviewed and actions taken were as follows:

√ Method:

The nine samples were analyzed for BTEXS by method USEPA 524.2 on October 29, 1998.

Holding Time:

All Samples were analyzed within the 14-day holding time.

√ Blanks:

No target compounds were detected in the associated method blank.

V System Monitoring Compounds:

The "USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review" indicate that "Recoveries for system monitoring compounds in volatile samples and blanks must be within the limits specified in the Method." However, Method 524.2 does not specify a required recovery. However, 4-bromofluorobenzene and 1,2-dichlorobenzene-d4 surrogate recoveries were within 78-94 percent and this is acceptable.

√ Internal Standards:

All fluorobenzene internal standards were within the established criteria for area internal standard and retention time.

√ GC/MS Instrument Performance Check:

All bromofluorobenzene (BFB) tunes met the ion abundance criteria. Analysis of the instrument performance check solution was performed at the beginning of each 12-hr period during which the samples were analyzed.

√ <u>Initial Calibrations:</u>

The initial calibration performed on October 7, 1998 for Instrument HP5971A met the 30 percent relative standard deviation (RSD) and 0.05 minimum relative response factor criteria for all compounds.

√ Continuing Calibrations:

Continuing calibration was run and compared to the correct initial calibration. All continuing calibrations met the 25 percent difference and minimum relative response factor criteria for all compounds.

√ Matrix Spike/Duplicate:

The matrix spike/duplicate results for recovery and RPD were within the advisory limits.

Target Compound Indentification/Quantitation:

No problems were identified with compound identification or quantities.

√ Field Duplicate:

Two pairs of field duplicates were collected during this sampling event. Duplicate samples are denoted by an "A" at the end of the sample name. The pairs are: RC-EL-20-1098 and duplicate RC-EL-20-1098A, and RC-EL-38-1098 and duplicate RC-EL-38-1098A. Table 1 below summarizes the RPD for the two sample/duplicate pairs.

Table 1: Relative Percent Difference (RFD)

Sample Name	Benzene (ppb)	RPD (%)	Toluene (ppb)	RPD (%)	Ethyl- Benzene (ppb)	RPD (%)	Xylene (ppb)	RPD (%)	Styrene (ppb)	RPD (%)
RC-EL-20-1098 RC-EL-20-1098A	1.50 1.63	8.3	6.80 7.25	6.4	2.59 2.71	4.5	11.02 11.69	5.9	ND ND	NA NA
RC-EL-38-1098 RC-EL-38-1098A	0.42	61.2	1.60 4.90	101.5	0.59 2.52	124.1	2.58 10.62	121.8	ND ND	NA NA

ND = Non Detect

NA = Not Applicable

√ Summary:

The overall quality of the data was good, although there was poor agreement between duplicate sample pair RC-EL-38-1098/RC-EL-38-1098A (See Table 1). Also no trip blank was included with the samples sent to the lab. This oversight will be remedied in subsequent sampling events.

RELIANCE LABORATORIES, INC.



175 MAY STREET, EDISON, NJ 08837 PH (732) 738-5454 FAX (732) 738-5841 EMAIL: 74201.3501@COMPUSERVE.COM

ANALYTICAL REPORT

For Arco Chemical Co. Pittsburg, PA 15219

Project: Raccoon Creek

RELIANCE LABORATORIES, INC.



175 MAY STREET, EDISON, NJ 08837 PH (732) 738-5454 FAX (732) 738-5841 EMAIL: 74201.3501@COMPUSERVE.COM

ANALYTICAL DATA REPORT

for

Arco Chemical Co. Pittsburg, PA 15219 Project: Raccoon Creek

Date Received: 10/28/98

Sample ID	Lab ID #
2 16-11	
EL-20-1098	R-6122.1
EL-20-1098A	R-6122.2
EL-38-1098	R-6122.3
EL-38-1098A	R-6122.4
EC-00-1098	R-6122.5
EC-27-1098	R-6122.6
EC-57-1098	R-6122.7
ER-66-1098	R-6122.8
ER-35-1098	R-6122.9

These samples have been analyzed by EPA method 524.2 for a selected compound list. The results are not designed for use for drinking water purposes.

G. P. Kirpalani

Manager

GPK/vb

R E L I A N C E LABORATORIES INC.



3090 WOODBRIDGE AVENUE, EDISON NJ 08837 PH (908) 738-5454 FAX (908) 738-5841

REDUCED LABORATORY DATA DELIVERABLES

Check if Complete

I.	Cover Page, Format, and Laboratory Certification (Include Cross Reference Table of Field I.D. and Lab I.D)	
П.	Chain of Custody	
Ш.	Summary Sheets listing analytical results Including QA Data Information	
IV.	Laboratory Chronicle and Methodology	
\mathbf{v} .	Initial Calibration and Continuing Calibration	V
VI.	Tune Summary (MS)	
VII.	Blank Summary	
VIII.	Surrogate Recovery Summary	
IX.	Chromatograms / IR Spectra	
X.	Internal Standard Summary (MS)	
XI.	Matrix Spike / Spike Duplicate Summary	_V
XII.	Non-Conformance Summary	
<u>.</u> 1	Laboratory Manager Date	<u> </u>

Signature

RELIANCE LABORATORIES INC.



175 MAY STREET, EDISON, NJ 08837 PH (732) 738-5454 FAX (732) 738-5841 EMAIL: 74201.3501@COMPUSERVE.COM

TABLE OF CONTENTS

Laboratory Chronicle	page	1
Non-Conformance Summary	page	2
Methodology Summary	page	3
Analytical Results	page	5
QA/QC Data	page	6
Laboratory Certificate	page	37
Chain of Custody	page	38

RELIANCE LABORATORIES, INC.



175 MAY STREET, EDISON, NJ 08837 PH (732) 738-5454 FAX (732) 738-5841 EMAIL: 74201.3501@COMPUSERVE.COM

LABORATORY CHRONICLE

Customer Name Arco Chemical Co. Date Received: 10/28/98 Date Sampled: 10/27/98 Sample ID: As per chain of custody	
Organic Extraction:	
1 Acids	
O Destinidad/DODIa	
Analysis:	
1 Volatiles	10/28/98
2 Acids	
	INVIDENCE OF THE CONTRACT OF T
Inorganics:	
1 Metals	
2 Cyanides	
3 Phenols	
Other Analysis:	
	2
Supervisor Review & Approval	li P Kuralani

RELIANCE LABORATORIES INC.



3090 WOODBRIDGE AVENUE, EDISON NJ 08837 PH (908) 738-5454 FAX (908) 738-5841

NON-CONFORMANCE SUMMARY

Reliance Labs received 9 water sample for BTEXS (EPA 524.2) from Arco/Beazer on 28 October 1998. Samples consisted of 9 vials.

Matrix spike recovery analysis was performed on previous samples and results are attached.

All analyses were performed within the required holding time.

STANDARD OPERATING PROCEDURE **METHOD 524.2**

Scope 1.

This is the general method for the procedure used to identify purgeable volatile organics in portable water. The sample is purged with ultra high purity helium and concentrated into a trap. The volatiles are then thermally desorbed onto a megabore column and identified using a mass spectrometer detector.

- Equipment and Apparatus 2.
- Sample containers- 40ml screw caps amber vials. A.
- Purge and Trap System. B.
 - 1. 25cm VOCARB 3000 trap.
- C. Glassware
 - 20 ml fritted purging vessels. 1.
 - 25 ml teflon sealed syringe with lever lock assembly. 2.
 - 3. 10 μL syringes.
- Gas Chromographic / Mass Spectrometer. D.
 - Column type J&W 1.

75 m, 0.53 mm ID, DB624 3 microns

- Apparatus Conditions E.
 - Tekmar (purge and trap) 1.

2 min. Purge time

250° for 2 min. Desorb time and temp.: b.

260° for 12 min. Bake time and temp. : C.

15 cc/min. Flow rate

GC Conditions 2.

a.	Column flow	15 cc/min.
b.	Initial temp.	35° C
c.	Ramping Rate	6° C/min.
d.	Final temp.	200° C
e.	Run time	47.25 min.
f	Initial time	6 min.

- Stock Standards 3.
- Internal Standard Α.
 - Flourobenzene

f.

- Surrogates B.
 - 1,2-dichlorobenzene-d4 1.
 - 4-bromoflurobenzene
- Prepare standard solutions for all target compounds and surrogates at 20 ppm. C.
- Prepare internal standard at 20 ppm in methanol. D.

Initial time

Prepare all standards and store in teflon sealed 1 ml vials.

4. Run Sequence

- A. Tune Instrument
- 1. Inject 1μL of 25 ppm BFB into GC.
 - a. Tune must pass against criteria.
 - b. Tune must be run before any samples, blank or calibrations can be run.
 - c. From time to tune 12 hours are available to run all QC data and samples.

B. Three Point Calibration Curve

- 1. Purge five (3) concentrations of standard solutions containing all the target analysis at 1 ppb, 2 ppb, 5 ppb.
- 2. The above standard must be run within 12 hours of injecting the BFB tune.
- 3. Created a calibration curve with the above standard runs.
 - a. If the 30% RSD deviation is exceeded the standards must be run again (still within 12 hours)
- 4. Create an identification file from this calibration curve for automated quantification.
- C. If time remains in the 12-hour run period go to step F.
- D. If the 12-hour period has expired, a new tune must be injected and a new sequence must be started.
- E. Once an initial calibration curve is established a continuing calibrations check may be run. A continuing calibration check is required every time the mass spectrometer is tuned.
 - 1. 2 ppb concentration of all target compounds is purged and quanted against current ID file.
 - 2. Check the response factors of this run against the average RF of the calibration file. The RF of the continuing calibration must be within \pm 50% D (difference) of the 5 point for all compounds.
 - The area counts of internal standard and surrogates must not be decreased by >30% from the most recent continuing calibration standard nor decrease by >50% from the initial calibration standard.

F. Daily Blank

- 1. Purge 20 ml of laboratory reagent water (nanopure) with 5 ppb internal standard and 5 ppb each surrogate.
- 2. Run this blank and quant against current ID file.
- 3. If blank does not meet criteria, it must be rerun before analyzing any samples.

G. Samples

- 1. Fill 25 ml syringe until it overflows with sample. Then adjust the volume to 20 ml exactly.
- 2. Inject 5 µl each 25 ppm internal standard and surrogate standard solution into each sample.
- 3. Run and quant against the current 5 point calibration curves.
- 4. Any sample with target compound over 5 ppb must be rerun at the appropriate dilution.
- 5. Any sample not injected in 12-hour period must be rerun.

H. Quality Control Sample (QCS)

1. Analyze a QCS from an external source at least quarterly.

TABLE 1

RELIANCE LABORATORIES INC.



175 MAY STREET, EDISON, NJ 08837 PH (732) 738-5454 FAX (732) 738-5841 EMAIL: 74201.3501@COMPUSERVE.COM

LABORATORY ID NJ DEP 12687 PA DER 68437

CERTIFICATE OF ANALYSIS

Customer:

Arco / Beazer

Sample:

Water Samples

Lab ID:

R-6122

Reference:

Arco Beaver Valley

11 November 1998

Units: μg/L

Sample ID	Benzene	Toluene	Ethylbenzene	Xylene	Styrene
RC-EL-20-1098	1.50	6.80	2.59	11.02	< 0.58
RC-EL-20-1098A	1.63	7.25	2.71	11.69	< 0.58
RC-EL-38-1098	0.42	1.60	0.59	2.58	< 0.58
RC-EL-38-1098A	0.79	4.90	2.52	10.62	< 0.58
RC-EC-00-1098	< 0.13	< 0.6	< 0.22	< 0.22	< 0.58
RC-EC-27-1098	0.20	< 0.6	< 0.22	0.56	< 0.58
RC-EC-57-1098	< 0.13	< 0.6	< 0.22	< 0.22	< 0.58
RC-ER-66-1098	< 0.13	< 0.6	< 0.22	< 0.22	< 0.58
RC-ER-35-1098	0.52	0.83	0.26	1.86	< 0.58

Apkirtelani G. P. Kirpalani

Manager

Data File : C:\HPCHEM\1\DATA\V5783.D Acq On : 28 Oct 98 2:37 pm

Vial: 7

Operator: vb Inst : 5971 - In

: R-6122.1 Sample

Multiplr: 1.00

Misc : Arco - RC-EL-20-1098

Quant Time: Oct 29 9:33 1998

: C:\HPCHEM\1\METHODS\RUN524.M Method

: 524.2 Purgable Organics Title Last Update : Thu Oct 08 09:10:03 1998 Response via : Multiple Level Calibration

Internal Standards	R.T.	QIon	Response	Conc Units	Dev(Min)
1) Fluorobenzene	12.88	96	1557949	5.00 ug/L	0.00
System Monitoring Compounds	25 07	95	551387	%] 4.69 ug/L	Recovery 93.76%
43) 4-bromofluorobenzene 55) 1,2-dichlorobenzene-d4	25.97 31.13	152	337652	4.40 ug/L	
Target Compounds					Qvalue
19) Benzene	12.05	78	468786	1.50 ug/L	99
26) Toluene	17.73	91	2637091	6.80 ug/L	99
35) Ethylbenzene	22.56	91	903002	2.59 ug/L	96
36) m&p-xylenes	22.97	106	1265459	5.09 ug/L	98
37) o-xylene	24.24	91	1400961	5.93 ug/L	97
40) Isopropylbenzene	25.52	105	165451	0.51 ug/L	
45) n-propylbenzene	26.92	91	659413	1.48 ug/L	
48) 1,3,5-trimethylbenzene	27.56	105	631022	2.65 ug/L	
50) 1,2,4-trimethylbenzene	28.81	105	2511377	11.19 ug/L	
61) Naphthalene	37.64	128	43769	0.52 ug/L	93

^{(#) =} qualifier out of range (m) = manual integration V5783.D RUN524.M Thu Oct 29 09:33:43 1998

Data File : C:\HPCHEM\1\DATA\V5783.D


Acq On : 28 Oct 98 2:37 pm

Sample : R-6122.1

Misc : Arco - RC-EL-20-1098 Quant Time: Oct 29 9:33 1998

Method : C:\HPCHEM\1\METHODS\RUN524.M

Title : 524.2 Purgable Organics
Last Update : Thu Oct 08 09:10:03 1998
Response via : Multiple Level Calibration



Vial: 7

Multiplr: 1.00

: 5971 - In

Operator: vb

Inst

Data File: C:\HPCHEM\1\DATA\V5784.D Acq On

Vial: 8 : 28 Oct 98 3:24 pm Operator: vb

: R-6122.2 Inst : 5971 - In Sample Misc : Arco - RC-EL-20-1098A Multiplr: 1.00

Quant Time: Oct 29 9:21 1998

: C:\HPCHEM\1\METHODS\RUN524.M Method

: 524.2 Purgable Organics Title Last Update : Thu Oct 08 09:10:03 1998 Response via : Multiple Level Calibration

Internal Standards	R.T.	QIon	Response	Conc Units	Dev(Min)
1) Fluorobenzene	12.87	96	1639515	5.00 ug/L	0.00
System Monitoring Compounds				%R	ecovery
43) 4-bromofluorobenzene	25.97	95	564298	4.56 ug/L	91.18%
55) 1,2-dichlorobenzene-d4	31.13	152	354794	4.39 ug/L	87.79%
Target Compounds					Qvalue
19) Benzene	12.06	78	537678	1.63 ug/L	99
26) Toluene	17.74	91	2957316	7.25 ug/L	98
35) Ethylbenzene	22.56	91	995716	2.71 ug/L	96
36) m&p-xylenes	22.96	106	1444393	5.52 ug/L	98
37) o-xylene	24.24	91	1532378	6.17 ug/L	98
40) Isopropylbenzene	25.53	105	170743	0.50 ug/L	98
45) n-propylbenzene	26.91	91	701923	1.49 ug/L	99
48) 1,3,5-trimethylbenzene	27.56	105	680182	2.72 ug/L	95
50) 1,2,4-trimethylbenzene	28.80	105	2682557	11.36 ug/L	94
61) Naphthalene	37.65	128	198770	2.24 ug/L	98

^{(#) =} qualifier out of range (m) = manual integration V5784.D RUN524.M Thu Oct 29 09:21:39 1998

Data File : C:\HPCHEM\1\DATA\V5784.D

Acq On : 28 Oct 98 3:24 pm


Sample : R-6122.2

Misc : Arco - RC-EL-20-1098A

Quant Time: Oct 29 9:21 1998

Method : C:\HPCHEM\1\METHODS\RUN524.M

Title : 524.2 Purgable Organics
Last Update : Thu Oct 08 09:10:03 1998
Response via : Multiple Level Calibration



Vial: 8

Multiplr: 1.00

: 5971 - In

Operator: vb

Inst

Data File : C:\HPCHEM\1\DATA\V5785.D

Acq On : 28 Oct 98 4:10 pm

Sample : R-6122.3 Misc : Arco - RC-EL-38-1098

Quant Time: Oct 29 8:51 1998

: C:\HPCHEM\1\METHODS\RUN524.M Method

: 524.2 Purgable Organics Title Last Update : Thu Oct 08 09:10:03 1998 Response via : Multiple Level Calibration

Internal Standards	R.T.	QIon	Response	Conc Units	Dev(Min)
1) Fluorobenzene	12.87	96	1557842	5.00 ug/L	0.00
System Monitoring Compounds	25.97	- 95	540403	%F 4.60 ug/L	Recovery 91.90%
43) 4-bromofluorobenzene 55) 1,2-dichlorobenzene-d4	31.13	152	333812	4.35 ug/L	
Target Compounds					Qvalue
19) Benzene	12.05	78	132567	0.42 ug/L	99
26) Toluene	17.73	91	619884	1.60 ug/L	100
35) Ethylbenzene	22.56	91	204439	0.59 ug/L	95
36) m&p-xylenes	22.95	106	292646	1.18 ug/L	90
37) o-xylene	24.25	91	329957	1.40 ug/L	97
48) 1,3,5-trimethylbenzene	27.56	105	153626	0.65 ug/L	92
50) 1,2,4-trimethylbenzene	28.80	105	572358	2.55 ug/L	99
61) Naphthalene	37.65	128	180269	2.13 ug/L	97

Vial: 9

Multiplr: 1.00

: 5971 - In

Operator: vb

Inst

^{(#) =} qualifier out of range (m) = manual integration Thu Oct 29 09:20:06 1998 V5785.D RUN524.M

Data File : C:\HPCHEM\1\DATA\V5785.D


Acq On : 28 Oct 98 4:10 pm

Sample : R-6122.3

Misc : Arco - RC-EL-38-1098 Quant Time: Oct 29 8:51 1998

Method : C:\HPCHEM\1\METHODS\RUN524.M

Title : 524.2 Purgable Organics
Last Update : Thu Oct 08 09:10:03 1998
Response via : Multiple Level Calibration



Vial: 9
Operator: vb

Multiplr: 1.00

Inst

: 5971 - In

Data File : C:\HPCHEM\1\DATA\V5786.D

Acq On : 28 Oct 98 5:13 pm

: R-6122.4

Sample Misc : Arco - RC-EL-38-1098A

Quant Time: Oct 29 9:18 1998

: C:\HPCHEM\1\METHODS\RUN524.M Method

: 524.2 Purgable Organics Title Last Update : Thu Oct 08 09:10:03 1998 Response via : Multiple Level Calibration

Internal Standards	R.T.	QIon	Response	Conc Units	Dev(Min)
1) Fluorobenzene	12.88	96	1599877	5.00 ug/L	0.00
System Monitoring Compounds					Recovery
43) 4-bromofluorobenzene	25.97	95	553083	4.58 ug/L	
55) 1,2-dichlorobenzene-d4	31.13	152	338191	4.29 ug/L	85.75%
Target Compounds 19) Benzene	12.04	78	254827	0.79 ug/L	Qvalue 99
19) Benzene 26) Toluene	17.72	91	1951173	4.90 ug/L	100
35) Ethylbenzene	22.55	91	905348	2.52 ug/L	95
36) m&p-xylenes	22.96	106	1284545	5.03 ug/L	96
37) o-xylene	24.23	91	1356030	5.59 ug/L	97
45) n-propylbenzene	26.91	91	677106	1.48 ug/L	98
48) 1,3,5-trimethylbenzene	27.56	105	678643	2.78 ug/L	98
50) 1,2,4-trimethylbenzene	28.80	105	2691751	11.68 ug/L	
61) Naphthalene	37.64	128	112214	1.29 ug/L	96

Vial: 10

Inst : 5971 - In

Operator: vb

Multiplr: 1.00

^{(#) =} qualifier out of range (m) = manual integration Thu Oct 29 09:18:12 1998 V5786.D RUN524.M

Data File : C:\HPCHEM\1\DATA\V5786.D

Acq On : 28 Oct 98 5:13 pm


Sample : R-6122.4

Misc : Arco - RC-EL-38-1098A

Quant Time: Oct 29 9:18 1998

Method : C:\HPCHEM\1\METHODS\RUN524.M

Title : 524.2 Purgable Organics
Last Update : Thu Oct 08 09:10:03 1998
Response via : Multiple Level Calibration



Vial: 10

: 5971 - In

Operator: vb

Multiplr: 1.00

Inst

Data File : C:\HPCHEM\1\DATA\V5787.D

Vial: 11 Operator: vb

Acq On : 28 Oct 98 6:00 pm Sample : R-6122.5 Misc : Arco - RC-EC-00-1098

Inst : 5971 - In

Multiplr: 1.00

Quant Time: Oct 29 8:51 1998

Method : C:\HPCHEM\1\METHODS\RUN524.M
Title : 524.2 Purgable Communication

Last Update : Thu Oct 08 09:10:03 1998 Response via : Multiple Level Calibration

Internal Standards	R.T.	QIon	Response	Conc Units	Dev(Min)
1) Fluorobenzene	12.88	96	1548516	5.00 ug/L	0.00
System Monitoring Compounds 43) 4-bromofluorobenzene 55) 1,2-dichlorobenzene-d4	25.98 31.13	95 152	552905 334892	4.73 ug/L	ecovery 94.59% 87.73%
Target Compounds					Qvalue

^{(#) =} qualifier out of range (m) = manual integration Thu Oct 29 09:16:04 1998 V5787.D RUN524.M

Data File : C:\HPCHEM\1\DATA\V5787.D

Acq On : 28 Oct 98 6:00 pm


: R-6122.5 Sample

: Arco - RC-EC-00-1098

Misc Quant Time: Oct 29 8:51 1998

: C:\HPCHEM\1\METHODS\RUN524.M Method

: 524.2 Purgable Organics Title Last Update : Thu Oct 08 09:10:03 1998 Response via : Multiple Level Calibration



Vial: 11

: 5971 - In

Operator: vb

Multiplr: 1.00

Inst

Data File: C:\HPCHEM\1\DATA\V5788.D Vial: 12
Acq On: 28 Oct 98 6:46 pm Operator: vb

Sample : R-6122.6 Inst : 5971 - In

Misc : Arco - RC-EC-27-1098 Multiplr: 1.00

Quant Time: Oct 29 9:14 1998

Method : C:\HPCHEM\1\METHODS\RUN524.M

Title : 524.2 Purgable Organics
Last Update : Thu Oct 08 09:10:03 1998
Response via : Multiple Level Calibration

Internal Standards	R.T.	QIon	Response	Conc Units	Dev(Min)
1) Fluorobenzene	12.88	96	1518426	5.00 ug/L	0.00
System Monitoring Compounds 43) 4-bromofluorobenzene 55) 1,2-dichlorobenzene-d4	25.98 31.13	95 152	503030 314613	%I 4.39 ug/L 4.20 ug/L	Recovery 87.77% 84.05%
Target Compounds 19) Benzene 26) Toluene 36) m&p-xylenes 37) o-xylene	12.06 17.73 22.96 24.25	78 91 106 91	60617 110140 53881 78257	0.20 ug/L 0.29 ug/L 0.22 ug/L 0.34 ug/L	Qvalue 94 94 97 97

^{(#) =} qualifier out of range (m) = manual integration V5788.D RUN524.M Thu Oct 29 09:14:59 1998

Data File : C:\HPCHEM\1\DATA\V5788.D

Acq On : 28 Oct 98 6:46 pm


Sample : R-6122.6 Misc : Arco - RO

: Arco - RC-EC-27-1098

Quant Time: Oct 29 9:14 1998

Method : C:\HPCHEM\1\METHODS\RUN524.M

Title : 524.2 Purgable Organics
Last Update : Thu Oct 08 09:10:03 1998
Response via : Multiple Level Calibration



Vial: 12

: 5971 - In

Operator: vb

Multiplr: 1.00

Inst

Data File : C:\HPCHEM\1\DATA\V5789.D

\(\1\DATA\V5789.D\)
7:33 pm Vial: 13
Operator: vb

Acq On : 28 Oct 98 7:33 p

Inst : 5971 - In

Sample : R-6122.7 Misc : Arco - RC-EC-57-1098

Multiplr: 1.00

Quant Time: Oct 29 9:12 1998

Method : C:\HPCHEM\1\METHODS\RUN524.M

Title : 524.2 Purgable Organics
Last Update : Thu Oct 08 09:10:03 1998
Response via : Multiple Level Calibration

Internal Standards	R.T.	QIon	Response	Conc Units	Dev(Min)
1) Fluorobenzene	12.88	96	1558932	5.00 ug/L	0.00
System Monitoring Compounds 43) 4-bromofluorobenzene 55) 1,2-dichlorobenzene-d4	25.97 31.13	95 152	514953 314091	%R 4.38 ug/L 4.09 ug/L	87.51% 81.74%
Target Compounds					Qvalue

^{(#) =} qualifier out of range (m) = manual integration V5789.D RUN524.M Thu Oct 29 09:13:06 1998

Data File : C:\HPCHEM\1\DATA\V5789.D

Acq On : 28 Oct 98 7:33 pm


: R-6122.7 Sample

: Arco - RC-EC-57-1098 Misc Quant Time: Oct 29 9:12 1998

Inst Multiplr: 1.00

: C:\HPCHEM\1\METHODS\RUN524.M Method

: 524.2 Purgable Organics Title Last Update : Thu Oct 08 09:10:03 1998 Response via : Multiple Level Calibration



Vial: 13

: 5971 - In

Operator: vb

Data File : C:\HPCHEM\1\DATA\V5790.D Acq On : 28 Oct 98 8:19 pm

Vial: 14

Operator: vb

: R-6122.8 Sample

Inst : 5971 - In Multiplr: 1.00

Misc : Arco - RC-ER-66-1098

Quant Time: Oct 29 8:52 1998

: C:\HPCHEM\1\METHODS\RUN524.M

Method : 524.2 Purgable Organics Title Last Update : Thu Oct 08 09:10:03 1998 Response via : Multiple Level Calibration

Internal Standards	R.T.	QIon	Response	Conc (Jnits	Dev(Min)
1) Fluorobenzene	12.88	96	1656337	5.00	ug/L	0.00
System Monitoring Compounds 43) 4-bromofluorobenzene 55) 1,2-dichlorobenzene-d4	25.98 31.13	95 152	552556 342587		%I ug/L ug/L	Recovery 88.38% 83.91%
Target Compounds						Qvalue

^{(#) =} qualifier out of range (m) = manual integration V5790.D RUN524.M Thu Oct 29 09:12:07 1998

Data File : C:\HPCHEM\1\DATA\V5790.D

Acq On : 28 Oct 98 8:19 pm


Sample : R-6122.8

: Arco - RC-ER-66-1098 Misc

Quant Time: Oct 29 8:52 1998

: C:\HPCHEM\1\METHODS\RUN524.M Method

: 524.2 Purgable Organics Title Last Update : Thu Oct 08 09:10:03 1998 Response via : Multiple Level Calibration



Vial: 14 Operator: vb

Multiplr: 1.00

Inst

: 5971 - In

Data File : C:\HPCHEM\1\DATA\V5791.D

Acq On : 28 Oct 98 9:06 pm

Sample : R-6122.9 Misc : Arco - RC-ER-35-1098 Inst : 5971 - In Multiplr: 1.00

Vial: 15

Operator: vb

Quant Time: Oct 29 9:11 1998

: C:\HPCHEM\1\METHODS\RUN524.M Method

: 524.2 Purgable Organics Title Last Update : Thu Oct 08 09:10:03 1998 Response via : Multiple Level Calibration

Internal Standards	R.T.	QIon	Response	Conc Units I	Dev(Min)
1) Fluorobenzene	12.88	96	1480994	5.00 ug/L	0.00
System Monitoring Compounds 43) 4-bromofluorobenzene 55) 1,2-dichlorobenzene-d4	25.97 31.14	95 152	510317 306347	%R0 4.56 ug/L 4.20 ug/L	ecovery 91.29% 83.92%
Target Compounds 19) Benzene 26) Toluene 35) Ethylbenzene 36) m&p-xylenes 37) o-xylene 48) 1,3,5-trimethylbenzene 50) 1,2,4-trimethylbenzene	12.04 17.73 22.56 22.96 24.24 27.57 28.80	78 91 91 106 91 105 105	154572 305008 84827 174468 252065 75373 218585	0.52 ug/L 0.83 ug/L 0.26 ug/L 0.74 ug/L 1.12 ug/L 0.33 ug/L 1.02 ug/L	Qvalue 98 98 99 95 96 88 95

^{(#) =} qualifier out of range (m) = manual integration Thu Oct 29 09:11:38 1998 V5791.D RUN524.M

Data File : C:\HPCHEM\1\DATA\V5791.D

Acq On : 28 Oct 98 9:06 pm

Sample : R-6122.9


Misc : Arco - RC-ER-35-1098 Quant Time: Oct 29 9:11 1998 Vial: 15 Operator: vb

Inst : 5971 - In

Multiplr: 1.00

Method : C:\HPCHEM\1\METHODS\RUN524.M

Title : 524.2 Purgable Organics
Last Update : Thu Oct 08 09:10:03 1998
Response via : Multiple Level Calibration



WATER VOLATILE SYSTEM MONITORING COMPOUND RECOVERY

Customer : Arco

		SMC1	SMC2		OTHER		TOT
1	SAMPLE NO.	#	#	#		#	OUT
01	VBLK01	87	78				
02	R-6122.1	94	88				
03	R-6122.2	91	88				
04	R-6122.3	92	87				
05	R-6122.4	92	86				
06	R-6122.5	95	88				
07	R-6122.6	88	84			_	
08	R-6122.7	88	82				
09	R-6122.8	88	84				
10	R-6122.9	91	84			_	
11	R-6122.6	94	90				-
12					ļ	_	
13					<u> </u>	-	
14							-
15						_	-
16						_	-
17							
18					-		-
19						_	-
20						_	-
21						-	<u> </u>
22							-
23[-
24						-	-
25[-	-
26						_	-
27					-	-	
28[_	
29[-	-
30						_	

QC LIMITS (75-115) (75-115)

SMC1 = 4-Bromofluorobenzene SMC2 = 1,2-dichlorobenzene-d4

- # Column to be used to flag recovery values
- * Values outside of contract required QC limits
- D System Monitoring Compound diluted out

FORM II VOA-1

WATER VOLATILE MATRIX SPIKE/MATRIX SPIKE DUPLICATE RECOVERY

Matrix Spike - Sample No.: R-6109.2

COMPOUND	SPIKE ADDED (ug/L)	SAMPLE CONCENTRATION (ug/L)	MS CONCENTRATION (ug/L)	MS % REC	QC. LIMITS # REC.
	2.00	0.00	2.15	108	(80-120)
Benzene Toluene	2.00	0.00	1.79	90	(80-120)
	2.00	0.00	1.95	98	(80-120)
Ethylbenzene	2.00	0.00	2.03	102	(80-120)
m&p-xylenes	2.00	0.00	2.15	108	(80-120)
o-xylene Styrene	2.00	0.00	1.79	90	(80-120)

· · · · · · · · · · · · · · · · · · ·	SPIKE	MSD	MS			
	ADDED	CONCENTRATION	%	%	QC L	IMITS
COMPOUND	(ug/L)	(ug/L)	REC #	RPD #	RPD	REC.
	2.00	1.99	100	8	20	(80-120)
Benzene Toluene	2.00	1.63	82	9	20	(80-120)
	2.00	1.78	89	9	20	(80-120)
Ethylbenzene	2.00	1.88	94	8	20	(80-120)
m&p-xylenes	2.00	1.98	99	8	20	(80-120)
o-xylene Styrene	2.00	1.62	81	10	20	(80-120)

- # Column to be used to flag recovery and RPD values with an asterisk
- Values outside of QC limits

Comments:	

VOLATILE METHOD BLANK SUMMARY

VBLKO

Customer: Arco	
Lab File ID: V5782.D	Lab Sample ID: BLANK1
	Time Analyzed: 1351
Date Analyzed: 10/28/98	Time Analyzed:
GC Column: DB-624 ID: 0.53 (mm)	
Instrument ID: HP5971A	

THIS METHOD BLANK APPLIES TO THE FOLLOWING SAMPLES, MS AND MSD:

	LAB	LAB	TIME
SAMPLE NO.	SAMPLE ID	FILE ID	ANALYZED
01 R-6122.1	EL-20	V5783.D	1437
02 R-6122.2	EL-20A	V5784.D	1524
03 R-6122.3	EL-38	V5785.D	1610
04 R-6122.4	EL-38A	V5786.D	1713
05 R-6122.5	EC-00	V5787.D	1800
06 R-6122.6	EC-27	V5788.D	1846
07 R-6122.7	EC-57	V5789.D	1933
08 R-6122.8	ER-66	V5790.D	2019
09 R-6122.9	ER-35	V5791.D	2106
10 R-6122.6	EC-27DUP	V5792.D	2152
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			

COMMENTS:			

Page 1 of 1

VOLATILE ORGANIC ANALYSIS DATA SHEET

Client Arco - Method blank

Sample ID: blank

Sample ID: blank

Sample Amount: 20 mL Matrix: Water Analyst: vb Lab File ID: v5782.d

Units: ug/L Date Analyzed: 10/28/98

CAS No Compound		Concentration	MDL
71-43-2	Benzene	< 0.13	0.13
108-88-3	Toluene	< 0.60	0.60
100-41-4	Ethylbenzene	< 0.22	0.22
1330-20-7	m+p-Xylenes	< 0.22	0.22
1330-20-7	o-Xylene	< 0.58	0.58

ND = Not detected

B = Compound found in blank and sample

J = Detected below MDL

E = Out of calibration range

Data File : C:\HPCHEM\1\DATA\V5782.D

Vial: 6

Acq On : 28 Oct 98 1:51 pm Sample : blank Misc : blank

Operator: vb Inst : 5971 - In

Multiplr: 1.00

Quant Time: Oct 29 8:51 1998

: C:\HPCHEM\1\METHODS\RUN524.M Method

: 524.2 Purgable Organics Title Last Update : Mon Nov 09 15:27:45 1998 Response via : Multiple Level Calibration

Internal Standards	R.T.	QIon	Response	Conc Units	Dev(Min)
1) Fluorobenzene	12.87	96	1672566	5.00 ug/L	0.00
System Monitoring Compounds 43) 4-bromofluorobenzene 55) 1,2-dichlorobenzene-d4	25.98 31.13	95 152	546294 321040	%R 4.33 ug/L 3.89 ug/L	ecovery 86.53% 77.87%
Target Compounds					Qvalue

^{(#) =} qualifier out of range (m) = manual integration Mon Nov 09 15:28:29 1998 V5782.D RUN524.M

Data File : C:\HPCHEM\1\DATA\V5782.D

Acq On : 28 Oct 98 1:51 pm

Sample : blank
Misc : blank

Quant Time: Oct 29 8:51 1998


: C:\HPCHEM\1\METHODS\RUN524.M

Method : C:\HPCHEM\1\METHODS\RUN524.

Title : 524.2 Purgable Organics

Last Update : Mon Nov 09 15:27:45 1998

Response via : Multiple Level Calibration



Vial: 6

Multiplr: 1.00

: 5971 - In

Operator: vb

Inst

VOLATILE ORGANIC INSTRUMENT PERFORMANCE CHECK BROMOFLUOROBENZENE (BFB)

Custon	ner:	
Lab File ID: V5729.D		BFB Injection Date: 10/7/98
Instrument ID: HP5971A		BFB Injection Time: 0852
GC Column: DB-624	ID: <u>0.53</u> (mm)	

Г		%RELATIVE	
m/e	ION ABUNDANCE CRITERIA	ABUNDANCE	
50	8.0 - 40.0% of mass 95	17.1	
75	30.0 - 66.0% of mass 95	41.4	
95	Base peak, 100% relative abundance	100.0	
96	5.0 - 9.0% of mass 95	6.5	
173	Less than 2.0% of mass 174		0.0)1
174	50.0 - 120.0% of mass 95	72.0	
175	4.0 - 9.0% of mass 174		7.5)1
176	93.0 - 101.0% of mass 174		9.5)1
177	5.0 - 9.0% of mass 176	4.3 (6.0)2

1-Value is % mass 174

2-Value is % mass 176

This check applies to the following SAMPLES, MS, MSD, BLANKS and STANDARDS:

	LAB	LAB	DATE	TIME
SAMPLE NO.	SAMPLE ID	FILE ID	ANALYZED	ANALYZED
VSTD001	ICC001	V5730.D	10/7/98	0928
VSTD002	ICC002	V5731.D	10/7/98	1017
VSTD005	ICC005	V5732.D	10/7/98	1106
701000				

11

Data File: C:\HPCHEM\1\DATA\V100798\V5729.D

: 7 Oct 98 8:52 am Acq On

: bfb Sample

Misc


Operator: vb : 5971 - In Inst

Multiplr: 1.00

Vial: 1

: C:\HPCHEM\1\METHODS\RUN524.M Method

: 524.2 Purgable Organics Title



Peak Apex is scan: 334

Target	Rel. to	Lower	Upper	Rel.	Raw	Result
Mass	Mass	Limit%	Limit%	Abn%	Abn	Pass/Fail
50 75 95 96 173 174 175 176	95 95 95 95 174 95 174 174	15 30 100 5 0 50 59 95	40 80 100 9 2 100 9	17.2 41.5 100.0 6.4 0.0 74.0 8.0 98.1 6.6	49328 119256 287040 18368 0 212480 17104 208448 13768	PASS PASS PASS PASS PASS PASS PASS PASS

VOLATILE ORGANIC INSTRUMENT PERFORMANCE CHECK **BROMOFLUOROBENZENE (BFB)**

	Customer : Arco	
File ID:	V5780.D	BFB Injection Date: 10/28/98
ument II	D: HP5971A	BFB Injection Time: 1134

GC Column: DB-624 ID: 0.53 (mm)

Lab

Instrument ID: HP5971A

		%RELATIVE
m/e	ION ABUNDANCE CRITERIA	ABUNDANCE
50	8.0 - 40.0% of mass 95	17.4
75	30.0 - 66.0% of mass 95	40.2
95	Base peak, 100% relative abundance	100.0
96	5.0 - 9.0% of mass 95	5.9
173	Less than 2.0% of mass 174	0.0 (0.0)1
174	50.0 - 120.0% of mass 95	71.8
175	4.0 - 9.0% of mass 174	5.4 (7.6)1
176	93.0 - 101.0% of mass 174	71.6 (99.7)1
177	5.0 - 9.0% of mass 176	4.1 (5.8)2
	1-Value is % mass 174	2-Value is % mass 176

This check applies to the following SAMPLES, MS, MSD, BLANKS and STANDARDS:

	LAB	LAB	DATE	TIME
SAMPLE NO.	SAMPLE ID	FILE ID	ANALYZED	ANALYZED
1 VSTD050	CC002	V5781.D	10/28/98	1301
2 VBLK01	BLANK1	V5782.D	10/28/98	1351
3 R-6122.1	EL-20	V5783.D	10/28/98	1437
4 R-6122.2	EL-20A	V5784.D	10/28/98	1524
5 R-6122.3	EL-38	V5785.D	10/28/98	1610
6 R-6122.4	EL-38A	V5786.D	10/28/98	1713
7 R-6122.5	EC-00	V5787.D	10/28/98	1800
8 R-6122.6	EC-27	V5788.D	10/28/98	1846
9 R-6122.7	EC-57	V5789.D	10/28/98	1933
0 R-6122.8	ER-66	V5790.D	10/28/98	2019
1 R-6122.9	ER-35	V5791.D	10/28/98	2106
2 R-6122.6	EC-27DUP	V5792.D	10/28/98	2152
3				
4				
5				
6				
7				
8				
9				
0				
1				
2				

Data File : C:\HPCHEM\1\DATA\V5780.D

Acq On : 28 Oct 98 11:34 am

Sample : bfb

Misc :


Vial: 1 Operator: vb

Inst : 5971 - In

Multiplr: 1.00

Method : C:\HPCHEM\1\METHODS\RUN524.M

Title : 524.2 Purgable Organics



Peak Apex is scan: 328

Target Mass	Rel. to Mass	Lower Limit%	Upper Limit%	Rel. Abn%	Raw Abn	Result Pass/Fail
50	95	15	40	17.4	39464	PASS
75	95	30	80	40.2	91408	PASS
95	95	100	100	100.0	227328	PASS
96	95	5	9	5.9	13431	PASS
173	174	0	2	0.0	0	PASS
174	95	50	100	71.8	163328	PASS
175	174	5	9	7.6	12332	PASS
176	174	95	101	99.7	162880	PASS
177	176	5	9	5.8	9431	PASS

VOLATILE ORGANICS INITIAL CALIBRATION DATA

 Instrument ID:
 HP5971A
 Calibration Date(s):
 10/7/98
 10/7/98

 Calibration Times:
 0928
 1106

GC Column: DB-624 ID: 0.53 (mm)

GC Column: DB-624	^{ID:} .	0.53	(mm)				i:
Lab File ID:	RRF01 =	V5730.D		RRF02 =	V5731.D		
RRF05 = V5732.D							
							%
COMPOUND	RRF05	RRF02	RRF01			RRF	RSI
Benzene	0.962	0.957	1.144			1.021	10.4
Toluene	0.878	0.874	1.041			0.931	10.2
Ethylbenzene	1.048	1.045	1.209			1.101	8.5
m&p-xylenes	0.716	0.704	0.849			0.756	10.6
o-xylene	0.738	0.712	0.813			0.754	7.0
Styrene	0.551	0.516	0.575			0.547	5.4
							<u> </u>
4-Bromofluorobenzene	0.393	0.388	0.382			0.388	1.4
1,2-dichlorobenzene-d4	0.262	0.260	0.242			0.255	4.3

^{*} Compounds with required minimum RRF and maximum %RSD values. All other compounds must meet a minimum RRF of 0.010.

Page 1 of 1

FORM VI VOA

VOLATILE CONTINUING CALIBRATION CHECK

Customer: Arco

Instrument ID:

HP5971A

Calibration Date: 10/28/98

Time: <u>1301</u>

Init. Calib. Date(s): 10/7/98 10/7/98

Lab File ID: V5781.D

Init. Calib. Times: 0928

1106

GC Column:

DB-624

ID: <u>0.53</u> (mm)

	l		MIN		MA:
COMPOUND	RRF	RRF20	RRF	%D	%E
Benzene	1.021	0.997		2.4	
Toluene	0.931	0.915		1.7	
Ethylbenzene	1.101	1.128		-2.5	
m&p-xylenes	0.756	0.768		-1.6	
o-xylene	0.754	0.736		2.4	
Styrene	0.547	0.509		6.9	
		u .			
			- 3		
					\top
THE STATE OF THE S					
4-Bromofluorobenzene	0.388	0.334		13.9	
1,2-dichlorobenzene-d4	0.255	0.219		14.1	

All other compounds must meet a minimum RRF of 0.010.

VOLATILE INTERNAL STANDARD AREA AND RT SUMMARY

Customer : Arco

Lab File ID (Standard): V5781.D Date Analyzed: 10/28/98

Instrument ID: HP5971A

Time Analyzed: 1301

GC Column:

DB-624

ID: 0.53 (mm)

-		IS1									
		AREA #	RT #	AREA	#	RT	#	AREA	#	RT	#
	12 HOUR STD	1570687	12.90								
	UPPER LIMIT	3141374	13.40								
	LOWER LIMIT	785344	12.40								
	SAMPLE										
	NO.										
01	VBLK01	1672566	12.87								
02	R-6122.1	1557949	12.88								
03	R-6122.2	1639515	12.87								
04	R-6122.3	1557842	12.87								
05	R-6122.4	1599877	12.88								
06	R-6122.5	1548516	12.88								
07	R-6122.6	1518426	12.88								
08	R-6122.7	1558932	12.88								
09	R-6122.8	1656337	12.88								
10	R-6122.9	1480994	12.88								
11	R-6122.6	1425478	12.87								
12											
13											
14											
15											
16											_
17										ļ	
18								L			
19											-
20											
21										<u> </u>	
22								l	_		

IS1 = Fluorobenzene

AREA UPPER LIMIT = +100% of internal standard area AREA LOWER LIMIT = -50% of internal standard area RT UPPER LIMIT = +0.50 minutes of internal standard RT RT LOWER LIMIT = -0.50 minutes of internal standard RT

Column used to flag values outside QC limits with an asterisk

* Values outside of QC limits.

Page 1 of 1

FORM VIII VOA



SIAIE OF NEW JERSEY

DEPARTMENT OF ENVIRONMENTAL PROTECTION

Certifies That
Reliance Laboratories, Inc.
3090 Wood Bridge Avenue
Edison, NJ 08837



having duly met the requirements of the

Regulations Governing Laboratory Certification

And Standards Of Performance N.J.A.C. 7:18 et. seq.


is hereby approved as a

State Certified Water Laboratory

To perform the analyses as indicated on the Annual Certified Parameter List which must accompany this certificate to be valid

12687
PERMANENT CERTIFICATION NUMBER

LIANUARY 11 1989
DATE



DEPARTMENT OF ENVIRONMENTAL PROTECTION

N.J.A.C. 7:18-2.11(d) and agreed to by the Laboratory Manager on filing the application This certification is subject to unannounced laboratory inspections as specified by

TO BE CONSPICUOUSLY DISPLAYED AT THE LABORATORY WITH THE ANNUAL CERTIFIED PARAMETER 1 IST.