

Appendix A

Auxier & Associates Radiological Sampling Procedures

PROCEDURE 2.8

PREPARING SAMPLES FOR TRANSPORTATION

1.0 PURPOSE

- 1.1 To provide guidance for preparing samples for transportation to assure regulatory compliance.

2.0 RESPONSIBILITIES

- 2.1 The Site Survey Manager is responsible for assuring this procedure is implemented.
- 2.2 Survey team members are responsible for following this procedure.
- 2.3 The Health and Safety Committee will assist in preparing appropriate criteria for potential shipments, including specific radiation action levels at appropriate distances from the container's surface.

3.0 PROCEDURE

- 3.1 Overview of regulations: Regulations for transportation of samples containing small quantities of radioactivity are set forth in 49 CFR 173, Subpart I. The regulations take a graded approach, and shipments containing greater radioactivity will generally be required to follow more stringent shipping requirements

For transportation purposes, radioactive material is defined in 49 CFR 173.403 as "... any material containing radionuclides where both the activity concentration and the total activity in the consignment exceed the values specified in the table in §173.436 or values derived according to the instructions in §173.433." These activities are reproduced in Table 2.8-1 for a subset of radionuclides.

It is important to note that 49 CFR 173.401(b)(4) states that Subpart I does not apply to "... (n)atural material and ores containing naturally occurring radionuclides which are not intended to be processed for use of these radionuclides, provided the activity concentration of the material does not exceed 10 times the values specified in §173.436."

- 3.2 Applicability and Additional Considerations: For the purpose of shipping, most samples collected from environmental media, are expected to be either excepted, or classified as non-radioactive for shipping purposes. If the sample shipment

exceeds the limits specified in Table 2.8-1, this procedure does not apply, and special handling will be required.

In addition to requirements imposed by transportation regulations, the analytical laboratory or other receiver of the shipped samples may have further restrictions or requirements which must be considered in preparation of the shipment.

The Health and Safety Committee will assist in preparing appropriate criteria for potential shipments, including specific radiation action levels at the container surface, at 30 cm from the surface, and at 1 m from the surface. Special packaging and labeling instructions will also be developed. This information will be incorporated into the Survey Work Plan.

- 3.3 The following is the process for preparing samples for transportation:
- 3.3.1 Select an appropriate outer container for the samples. The container must be strong and capable of retaining contents during conditions normally incident to transportation. A typical container used by A&A is a 48 quart plastic cooler.
 - 3.3.2 Place a plastic liner inside the container. A plastic garbage bag works well.
 - 3.3.3 Place the samples into the lined container. Do not exceed a net sample weight (including the individual sample containers) of 29 kg.
 - 3.3.4 Scan the outside of the loaded container with a gamma detector (Procedure 2.2) to determine the location of the maximum radiation level.
 - 3.3.5 Measure the radiation level (see Procedure 2.4) at a distance of 30 cm from the location on the container identified in Step 3.3. Record the results on the sample chain of custody form.
 - 3.3.6 Compare the measurement obtained with the exposure rate action levels provided in the Survey Work Plan. If the radiation levels satisfy the criteria, the shipment is excepted from all manifesting and labeling requirements.² Contact the HSC Chairperson or the project manager if the package still does not meet the specified action levels.
 - 3.3.7 Mark the outside of the inner lining with the UN identification number UN2910. This can be hand written using a black marker.
 - 3.3.8 Fill spaces in the container liner with packing material to restrict sample movement during transport. If the container includes any freestanding

² For certain radionuclides, this concentration limit can be demonstrated by measurement of the direct radiation level associated with the package. For example, if the contaminant is oil-field NORM, calculations and experience have shown that the activity concentration limit will be satisfied if the direct radiation level at 30 cm from the package exterior (assuming a typical 48 quart cooler, used by A&A for sample shipping) is less than 20 μ R/h (or 20 μ rem/h), above background. For other radionuclides, the relationship between concentration and direct radiation level may differ from that of Ra-226, and appropriate decision levels must therefore be established for each project.

liquids, include twice the sufficient absorbent material to absorb the liquid contents, in case of leakage.

- 3.3.9 Seal the inner plastic liner in a manner that leaves the UN number clearly visible.
- 3.3.10 Place the Chain-of-Custody form and other paperwork on top of the inner liner.
- 3.3.11 Close and seal the outer container.
- 3.3.12 Complete shipping papers. If the package is "Exempt", shipping papers are the same as if the shipment did not contain radioactive material.
- 3.3.13 Attach the shipping papers and initiate the shipment.

Table 2.8-1 Table of Exempt Material Activity Concentrations and Exempt Consignment Activity Limits Found in 49 CFR 173

Symbol of radionuclide ²	Activity concentration for exempt material (pCi/g)	Parent radionuclide's average activity concentration in exempt package (pCi/g) ^{3,4}	Activity limit for exempt consignment (pCi)	Activity limit of parent radionuclide for exempt consignment (pCi) ^{3,4}
Am-241	27	27	2.7E+5	2.7E+5
C-14	2.7E+5	270000	2.7E+8	2.7E+8
Co-60	270	270	2.7E+6	2.7E+6
Cs-137 (b)	270	135	2.7E+5	1.4E+5
K-40	2700	2700 (27000)	2.7E+7	3E+7 (3E+8)
Pb-210 (b)	270	90 (900)	2.7E+5	9E+4 (9E+5)
NORM scale	270	30 (300)	2.7E+5	2E+4 (2E+5)
Ra-224 (b)	270	45 (450)	2.7E+6	5E+5 (5E+6)
Ra-226 (b)	270	30 (300)	2.7E+5	3E+4 (3E+5)
Ra-228 (b)	270	135 (1350)	2.7E+6	1E+6 (1E+7)
Rb(nat)	2.7E+5	3E+5 (3E+6)	2.7E+8	3E+8 (3E+9)
Sr-90 (b)	2700	1350	2.7E+5	1.4E+5
Th-228 (b)	27	4 (39)	2.7E+5	4E+4 (4E+5)
Th-230	27	27 (270)	2.7E+5	3E+5 (3E+6)
Th-232	270	135 (1350)	2.7E+5	1E+5 (1E+6)
Th (nat) (b)	27	3 (27)	2.7E+4	3E+3 (3E+4)
U (nat) (b)	27	2 (19)	2.7E+4	2E+3 (2E+4)
U (enriched to 20% or less)(g)	27	27	2.7E+4	2.7E+4
U (dep)	27	27	2.7E+4	2.7E+4

¹ 69 FR 3685, Jan 26, 2004

² +D indicates the sum of the activities of the parent and specified daughters should be compared to exempt values

³ Derived values account for presence of daughters and incorporate 10x modifier for natural origin, if applicable.

PROCEDURE 3.7

ENVIRONMENTAL SAMPLE IDENTIFICATION

1.0 PURPOSE

- 1.1 To assure consistent sample identification.

2.0 RESPONSIBILITIES

- 2.1 The Corporate Secretary (or designated agent) is responsible for maintaining a list of site identification codes that have been used in the past or are in current use.
- 2.2 The Project Manager is responsible for selecting site identification code(s) appropriate for new site(s) and assuring that the site identification codes are unique.
- 2.3 The Site Survey Manager is responsible for selecting grid identification numbers, and developing a system for relating the grid identification numbers to an appropriate land survey convention.
- 2.4 The Site Survey Manager is responsible for assuring that this procedure is implemented.
- 2.5 Survey team personnel are responsible for following this procedure.

Note: The Site Survey Manager may modify any part of this identification system as needed in order to facilitate field work in a given situation, provided that no ambiguous sample numbers are produced in the process. The Site Survey Manager should keep departures from the standard format to a minimum, and is responsible for overseeing all consequent modifications to data handling/processing software and procedures that may be required by such modifications.

3.0 PROCEDURE

- 3.1 Field samples shall be identified by an alphanumeric code. This code shall be used on the sample container, on the chain-of-custody forms, and in the field records.

3.2 The general format of the code is typically: XXXXXY123. Where:

3.2.1 **XXXXXX**= Four to six letter site identification code identified in Step 2.2, above.

3.2.2 **Y**= A one-digit code indicating the medium protocol.

A: Air
D: Sediment
R: Smears
S: Soil (including amorphous materials found in the soil, earthen or not)
V: Vegetation
W: Water
X: Misc. Not covered above

3.2.4 **123**= alphanumeric characters (usually 3) indicating the particular number of a particular sample type or general category for the site. Each number will correspond to a location designation on a map or grid area. Additional characters may be included to further identify location such as depth of sampling.

3.2.5 Examples of some sample codes are:

RFYCTGS143-the 143rd soil sample collected for project RFY/CTG

RFYCTGS187.090-a soil sample from the 90 cm depth at location 187 for the project RFYCTG

GIBONMW001-the first water sample collected for project GIB/ONM

3.3 At a minimum, sampling date, sampler initials and the sample identification are placed on the sample.

3.4 The identification method for the project should be described in the project records.

3.5 Marking is performed using an indelible pen.

3.5 All samples known or suspected of containing levels of radioactivity, which could present a contamination or exposure problem, are to be placed in clean outer

containers and clearly marked with descriptive information, as appropriate, according to the sample screening requirements.

PROCEDURE 3.8

SAMPLE CHAIN-OF-CUSTODY

1.0 PURPOSE

To provide a method for sample chain-of-custody.

2.0 RESPONSIBILITIES

2.1 The Site Survey Manager is responsible for assuring that this procedure is implemented.

2.2 Survey team members are responsible for following this procedure.

3.0 PROCEDURE

Chain-of-custody is initiated upon collection (or receipt) of samples and continues until samples are transferred to another organization or are disposed. An acceptable chain-of-custody is maintained when the sample is under direct surveillance by the assigned individual; the sample is maintained in a tamper-free container; or the sample is within a controlled-access facility. The chain-of-custody is recorded on a standardized A&A form (see Appendix A) or a form provided by another organization, such as an analytical laboratory or another sampling agency.

3.1 Field Procedures

3.1.1 An individual present during sample collection is designated as the sample custodian and is responsible for maintaining surveillance of the sample until the custody of that sample is transferred to another party. Samples must, at all times, be in the possession and under the direct surveillance of the sample custodian, or secured in a locked vehicle, building, or container. The sample custodian initiates a chain-of-custody form, daily, for all samples collected or received on that day.

3.1.2 Samples may be listed on the form as an individual entry or group of samples having common characteristics and originating from the same site may be recorded as a single entry, provided information describing each sample in the group (e.g. a completed field data form) is attached to or referenced on the custody form.

- 3.1.3 If sample custody is to be transferred (relinquished), the container and its contents are inspected by the individual accepting custody to assure that tampering has not occurred and custody has therefore been maintained. If evidence of tampering is observed or if any deviations or problems are noted, a notation must be provided on the form by the individual accepting custody. The sample collector must sign the first "Relinquished by" block and the receiver must complete the first "Received by" block.
- 3.1.4 If sample custody will not be assured under one of the conditions in item 3.0 above, a security seal is placed on the container of the samples. A security seal is a wire, tape, or other such item, which is uniquely identified (numbered), and can be affixed to a package in a manner as to require damaging the seal if the package is opened. Damage to the seal thereby alerts the recipient of a package to the possibility of tampering with the contents. The number of the seal is entered onto the Chain-of-Custody form. Samples, which are under security seals, do not have to be maintained in a secure area; however, precautions should be taken to restrict sample access to authorized individuals.
- 3.1.5 The original of the chain-of-custody form must contain all signatures and other pertinent records regarding custody. Therefore the original is retained in the possession of the individual who has custody.
- 3.1.6 As long as samples remain in custody of the sampler, both copies of the chain-of-custody form are to accompany the samples. If custody is transferred to another individual and the control requirements in item 3.0 above are not satisfied, the duplicate copy of the form is packaged with the samples and the original remains with the individual having custody.
- 3.1.7 Samples collected by other organizations and provided to A&A personnel will have chain-of-custody initiated for them by the individual receiving the samples. When the organization has an established chain-of-custody in place, a copy of the form will be attached to the A&A form.

3.2 Sample Transport

- 3.2.1 Samples must comply with regulations of the Department of Transportation, if they are to be transported over or through publicly accessible transport routes. The Health and Safety Plan describes the procedure for assuring compliance with this requirement.

- 3.2.2 Unsealed samples may be transported by a vehicle controlled by the person having custody of the samples, or in that person's hand carried baggage.
- 3.2.3 Transport by mail, checked baggage, common carrier, or other mode not controlled by the sample custodian of record, requires that security seals be used.
- 3.2.3 The method of transport is to be identified on the original chain-of-custody record. If inner containers are sealed, additional seals on outer packaging are not required.
- 3.3 Samples sent to other organizations
 - 3.3.1 The custodian will sign the "Relinquished by" space and the original form will be packed with the samples.
 - 3.3.2 Receiving organizations will be requested to check the container and its contents for signs of tampering and note any deficiencies in the "Comments" portion of the form.
 - 3.3.3 When samples will not be returned to A&A, the receiving organization will be asked to return the original of the form. The form will be provided to the Project Manager, for inclusion with the project records.
 - 3.3.4 If samples will be returned to A&A, the receiving organization will be asked to sign the "Relinquished by" space and pack the form with the samples for return shipment. Upon receipt, the samples and form will be provided to the Project Manager, who will sign the "Received" space and place a copy in the project file.

PROCEDURE 3.9 AIR SAMPLING

1.0 PURPOSE

This procedure establishes the basis and methodology for the placement and use of air monitoring equipment, as well as the collection, analysis, and documentation of air samples. Radiological air sampling and analysis is performed to monitor concentrations of radionuclides in the air for purposes of tracking internal radiation exposure to occupational radiation workers, determining appropriate respiratory protection devices, establishing radiological posting boundaries, verifying effluent airborne radioactivity concentrations, providing information on radiological conditions in the work area, and environmental monitoring.

2.0 RESPONSIBILITIES

2.1 Radiation Safety Officer (RSO)

- Manages the implementation of this procedure.
- Ensures technicians performing activities under this procedure are competent and have sufficient experience to perform assigned tasks.
- Ensures all activities performed within this procedure conform to the requirements of the SSHP.

2.2 Senior Radiation Protection Technician (SRPT)

- Initiates, collects, submits, counts, and documents air samples according to the requirements of this procedure, and the SSHP.
- Ensures that junior level technicians have sufficient experience and / or knowledge to perform assigned duties under this procedure.

3.0 MATERIALS

- Filters
- Envelopes or folders
- Chain of Custody
- Checklist (Attachment 3)

NOTE: Assembly, installation and calibration of sampling stations are performed according to manufacturer instructions and specifications.

4.0 DEFINITIONS

Airborne Radioactivity: Radioactive material in any chemical or physical form that is dissolved, misted, suspended, or otherwise entrained in air.

Breathing Zone (BZ): A uniform description of the volume of air around the worker's upper body and head which may be drawn into the lungs during the course of breathing.

Derived Air Concentration (DAC): The concentration of a given radioactive nuclide in air which, if breathed by the reference man for a working year of 2000 hours under conditions of light work (1.2 m³ of air per hour), would result in an intake of one (1) ALI.

DAC-hour (DAC-hr): The product of the concentration of radioactive material in air (expressed as a fraction or multiple of the DAC for each radionuclide) and the time of exposure to that radionuclide in hours. A facility may take 2000 DAC-hr to represent 1 ALI.

Grab Sample: A single sample of ambient air collected over a short time.

Monitoring: The measurement of radiation levels, airborne radioactivity concentrations, radioactive contamination levels, quantities of radioactive material, or individual doses and the use of the results of these measurements to evaluate radiological hazards or potential and actual doses resulting from exposures to ionizing radiation.

Representative: Sampling in such a manner that the sample closely approximates both the amount of activity and the physical and chemical properties of the material (e.g., particle size and solubility in the case of aerosol to which workers are exposed). Air sampling performed within the Breathing Zone (BZ) is considered representative of the airborne radioactive material concentration inhaled by the worker.

SSHP: Site specific health plan.

5.0 PRECAUTIONS AND LIMITATIONS

- Running air samplers for extended periods may cause excessive dust loading of the filter media. The frequency of filter change-out should be increased if excessive dust loading is observed.
- Air samplers shall not be used in combustible / explosive atmospheres.
- Air sampling and sample counting equipment shall not be operated beyond their respective calibration periods.
- Air samples shall be taken in such a manner as to not contaminate the filter with materials that were not airborne during the sample interval or by re-suspension of loose contamination from surfaces near the sampling head.
- Sampler exhaust may cause the re-suspension of loose surface contamination if the sampler is positioned improperly.
- Consider higher volume air samplers when covering short duration tasks.
- The decision to provide individual monitoring devices to workers is influenced by the expected levels of intake, likely variations in dose among workers, and the complexity of measurement and interpretation of results.

- Operating instructions for air sampling equipment and calibration functions are addressed in separate instrument-specific procedures.
- Use only those supplies, attachments, replacement parts, or accessories recommended for use with the particular air sampler with which you are working.
- Turn air sampler OFF when loading, unloading, attaching or removing filters or accessories.
- Do not operate air sampler without a filter or other recommended sampling accessory. Make certain that filters do not become overly saturated to restrict air flow or break up during operation.
- Unplug from outlet when not in use and before cleaning or servicing. Grasp plug, no cord when disconnecting air sampler from outlet.
- Do not operate an air sampler with a damaged cord or plug or after the sampler malfunctions or has been damaged in any manner.

6.0 PROCEDURE

6.1 Air Monitoring Methods

6.1.1 Utilize the following monitoring methods to implement the radiological air monitoring program:

- General Area (GA) Air Monitoring
- Breathing Zone (BZ) Air Monitoring
- Passive Radon Monitoring
- Particulate Radon Grab Samples
- Perimeter Monitoring, frequently referred to as Air Environmental (AE)

6.1.2 Air sampling equipment should be placed so as to:

- Not directly contact a contaminated (transferable) surface.
- Minimize interference with the performance of work.
- Be easily accessible for changing filters and servicing.
- Be downstream of potential release points.
- Minimize the influence of supply airflow.

6.1.3 An airflow study of any indoor area to be monitored should be performed prior to placement of the sampler (other than BZ samplers). Additional studies should be performed after changes in the work area setup, ventilation systems, or seasons, if seasonal changes may affect airflow patterns.

6.1.4 Perform BZ air sampling in occupied areas where, under typical conditions, a worker is likely to be exposed to an air concentration of 10 % or more of the DAC.

6.2 General Area (GA) Air Sampling

- 6.2.1 GA samples are typically taken with low volume samplers such as LV-1 or equivalent.
- 6.2.2 GA sampling shall be performed with instrumentation operating at volumes capable of meeting the analytical Minimum Detectable Concentration (MDC).
- 6.2.3 GA samples should be collected:
 - During work activities as a supplement to Breathing Zone (BZ) sampling as deemed appropriate.
 - At site boundaries to confirm effluent air discharge concentrations. These are the Air Environmental (AE) type samples.
 - At discharge points to determine the worst case airborne radiological conditions.
- 6.2.4 Document airflow studies, if performed in the appropriate project logbook or as directed by the RSO.
- 6.2.5 Select a calibrated low / high volume sampler with the appropriate glass fiber air filter and place the sample head into position. The fuzzy side of the filter should face outwards.
- 6.2.6 Turn the sampler ON. At a minimum, document the following information on the air filter envelope and checklist (record NA for any items on the checklist that do not apply, Attachment 3):
 - Sampling Location
 - Date / time on
 - Sampler model
 - Serial number
 - Filter ID number
 - Sample Purpose (eg GA or AE)
 - RWP if applicable
 - Flow rate
 - On by (individual starting sampler)
- 6.2.7 When air monitoring is complete, observe the sampler flow rate and turn the sampler off. At a minimum, document the following information on the air filter envelope and checklist (Attachment 3):
 - Date / time off
 - Flow rate
 - Total Run Time (if available)

- Total Volume Sampled
- Off by (individual terminating sample)

6.2.8 Remove and / or replace the sample head and filter using caution to prevent cross contamination.

6.2.9 Store the filter in a protective container to minimize the loss of collected material.

6.2.10 Submit sample and associated sample specific information to the counting lab for analysis.

6.3 Breathing Zone (BZ) Air Sampling

6.3.1 Collect BZ samples during entries into posted airborne radioactivity areas and during activities which have a reasonable potential of producing airborne radioactivity (e.g., excavating contaminated soils, surface destructive activities on surfaces with fixed contamination) as determined by the RSO.

6.3.2 Position the sampler on the individual representative of the worst-case exposure for the group if a single lapel sampler is used for multiple members of a work group. In micro environments such as the interior of an operator cab, the placement of the sampler may be in any representative location that does not interfere with the safe operation of the equipment. Base this selection on operating experience and consultation with the RSO. A single lapel sampler should be used for a group of no more than four workers spending greater than one hour in the work area under the same RWP.

6.3.3 Ensure the sample head is positioned as close to the breathing zone as practical without interfering with the work or the worker.

6.3.4 Operate sampler(s) according to the appropriate instrument use procedure. At a minimum, document the following information on the air filter envelope or log sheet:

- Primary Wearer's name(s) and/or site badge number
- Sample Purpose (eg BZ)
- (RWP) number
- Sampler model / serial numbers
- Date / time On
- Flow rate (sampler must be running)
- On by (individual starting sampler)

- 6.3.5 Upon exit from the work area, note the flow rate, turn the sampler OFF and detach from the worker / object. Note that unless otherwise authorized by the RSO. BZ sampling should be suspended / restarted during the workday to facilitate break period when no one is in the work area. Accurate volume tracking is crucial during these periods of non-operation.
 - 6.3.6 Perform necessary post-operation sampler checks according to the specific instrument use procedure
 - 6.3.7 Carefully, remove the air filter from the sample head and place in air filter envelope. Complete the pre-printed air filter envelope or sample log sheet:
 - Date / time off
 - Flow rate
 - Total Run Time (if available)
 - Total Volume (if available)
 - Off by (individual stopping sampler)
 - 6.3.8 Submit sample to Counting Room for analysis.
- 6.4 Radon and Thoron Progeny
- 6.4.1 High volume or low volume grab samplers such as HV-1, LV-1, or RAS 1 (typically in the 35-75 lpm range) should be used for collecting radon and thoron samples.
 - 6.4.2 Radon and thoron samples should be collected:
 - During work activities as deemed appropriate by the RSO or designee.
 - At restricted area boundaries as deemed appropriate by the RSO or designee.
 - Each frequently occupied work location should have its own samplers.
 - Airflow patterns should be considered in placing samplers so that the sampler is likely to be in the airflow downstream of the source.
 - A simultaneous background sample shall be taken upwind of all activities when radon and thoron sampling is performed. This sample is critically important.
 - When collecting a radon and thoron breathing zone sample, the sampler should be located in the breathing zone for the worker. Preferably it should be held immediately downwind of the worker and moved around with the worker.

- 6.4.3 Select a calibrated high volume sampler with a 47 mm filter and place the sample head into position. The preferred filter is a membrane filter. The approved membrane filter is the F&J Specialty Products, Inc. model number A020A047A. Alternatively, a glass fiber filter is the F&J Specialty Products, Inc. model number FP-47.
- 6.4.4 Turn the sampler ON and complete the required information on the air filter envelope to include:
- HWP number, if appropriate
 - Sampler model and serial number
 - On date, time, and flow rate
 - On by (site worker initials)
 - Sample location
- 6.4.5 Collect a sample for exactly 5 minutes, with no more than a 5-second uncertainty. Exercise caution when handling sample head so as not to cross contaminate the air filter.
- 6.4.6 Remove air filter from sample head and place in air filter envelope. Complete the required information on the air filter envelope including:
- Off date, time, and flow rate
 - Site worker stopping the sampler
- 6.4.7 Submit the sample to the counting room within 30 minutes after collection. Samples must be counted between 40 and 90 minutes, or they will be void.
- 6.4.8 Analyze the sample in accordance with Sections 8.1 or 8.2, whichever is appropriate
- 6.4.9 Alternate industry-accepted methods for radon-thoron monitoring may be used at the discretion of the RSO with concurrence from the Project Certified Health Physicist.
- 6.5 Perimeter/ Environmental Air (AE) Sampling
- 6.5.1 Perimeter Environmental Air samples are taken with high volume samplers such as the Staplex TFIA, Radeco H809v or equivalent. Low volume air samplers such as the LV-1 may be used at the discretion of the RSO
- 6.5.2 AE samples are collected to verify compliance with off-site release criteria.

- 6.5.3 AE samples are collected at locations designated by the RSO. At least four perimeter air-sampling stations are positioned along excavation boundaries and one sampler is to be placed at a designated background reference location. One air sampling station will be established at the most likely downwind perimeter boundary, as determined by evaluation of local meteorological data, and / or the nearest perimeter boundary from active work areas.
 - 6.5.4 Filters from operating perimeter air samplers are normally changed out after one to four weeks of operation depending on the dust loading and associated sampler performance capabilities. Filter change-out of perimeter air samplers will be performed at a frequency long enough to ensure acceptable counting statistics and short enough to maintain consistent sampler flow rates.
 - 6.5.5 Perimeter sampler operation shall be verified on a daily basis around locations when airborne generating activities are in progress. This requirement may be relaxed by the RSO for samplers with data logging capability.
 - 6.5.6 Document daily verification (i.e., flow rate) and notify the RSO of any discrepancies. Replace filter and investigate pump operation if daily flow rates vary by greater than 20%.
 - 6.5.7 Any sampler that is out of service due to malfunction for more than 1 hour and any invalid samples should be brought to the attention of the RSO.
 - 6.5.8 Samples are to be collected in accordance with Section 6.2, Steps 5-10.
- 6.6 Passive Radon Monitoring
- 6.6.1 Passive radon monitoring methods include the use of either alpha track etch detectors or electrets.
 - 6.6.2 Detectors should be placed for a length of time, so that the minimum detectable concentration is 0.1pCi/l or less, following manufacturer guidelines. The length of placement is generally 1 month or greater. Locations selected should be representative of the breathing zone, when practical. A simultaneous background sample should always be taken at a location unaffected by site activities. This sample is critically important.
 - 6.6.3 Open the bag containing the detector and place the detector in a protective container to allow for air circulation. Follow manufacturer guidelines to activate the detector, as necessary.

6.6.4 Record in the logbook:

- Sample location
- Date and time of placement
- Serial number of the detector
- Initials of the worker placing the detectors

6.6.5 Ship the detector to the manufacturer's processing center for analysis.

7.0 ANALYSIS OF AIR SAMPLES

General Area (GA), Breathing Zone (BZ), and Air Environmental (AE) samples should be submitted to the counting room for gross alpha analysis. Samples may be analyzed for gross alpha/ beta activity onsite or sent offsite for isotopic analysis as deemed appropriate by the RSO.

7.1 Analysis for Radon and Thoron Progeny from a 5-Minute Low Volume Grab Sample

7.1.1 Count the sample twice (5 minutes each) for alpha activity using a Ludlum 2929, Ludlum 2000, or Equivalent.

1. The first count should start at least 40 minutes after the end of the sample, but not greater than 90 minutes at the end of sample collection.
2. The second count should start at least 5 hours after the end of the count, but not greater than 17 hours after the end of the first count.

NOTE

It is not recommended to use a gas flow proportional counter for this analysis if there is a reasonably high probability of contaminating the instrument with radon and / or thoron progeny.

8.1.2 Calculate the thoron progeny (TDC) in working levels from the delayed (second) count as follows:

$$\text{cpmnet} = (\text{gross counts/count time}) - \text{background cpm of counting instrument}$$

V = Volume of air in liters

E = efficiency of counting instrument

CE = Filter collection efficiency (normally 0.998)

SAF = Self absorption factor (normally 0.7 for glass fiber filters and 1.0 for membrane filters)

FTh = Working level factor from Graph 1 (Attachment 1).

8.1.3 Calculate the radon progeny (RDC) in working levels from the first count as follows:

$$RDC = \frac{\left(\frac{cpm_{net}}{E \cdot V \cdot CE \cdot SAF} - TDC \times 16.5 \right)}{F_{Rn}}$$

where,

cpmnet = (gross counts/count time) - background cpm of counting instrument

V = Volume of air in liters

E = efficiency of counting instrument

CE = Filter collection efficiency (normally 0.998)

SAF = Self absorption factor (normally 0.7 for glass fiber filters and 1.0 for membrane filters)

FRn = Radon working level factor from Graph 2 (Attachment 2).

TDC = Thoron progeny determined from second count

8.2 Alternate Method for the Analysis of Radon Progeny from a 5 Minute Low Volume Grab Sample

This section only applies to the determination of radon and not the determination of thoron.

8.2.1 Count the sample once for alpha activity using a Ludlum 2929, Ludlum 2000, or Equivalent. The count should start at least 40 minutes after the end of the sample, but not greater than 90 minutes at the end of the count. Count the sample for 5 minutes.

NOTE

It is not recommended to use a gas flow proportional counter for this analysis if there is a reasonably high probability of contaminating the instrument with radon and / or thoron progeny.

8.2.2 Calculate the radon progeny (RDC) in working levels from the first count as follows:

$$RDC = \frac{cpm_{net}}{E \cdot V \cdot CE \cdot SAF \cdot F_{Rn}}$$

where,

cpmnet = (gross counts/count time) - background cpm of counting instrument

V = Volume of air in liters
E = efficiency of counting instrument
CE = Filter collection efficiency (normally 0.998)
SAF = Self absorption factor (normally 0.7 for glass fiber filters and 1.0 for membrane filters)
FRn = Radon working level factor from Graph 2 (Attachment 2).

8.0 REPORTS

Maintain air monitoring instrument data, sampling data, and analysis results as a quality record.

9.0 ATTACHMENTS


Attachment 1 Graph 1, Thoron Working Level Factors

Attachment 2 Graph 2, Radon Working Level Factors

10.0 REFERENCES


- 10 CFR 20, "Standards for Protection Against Radiation."
- Rock, R.L., Sampling Mine Atmospheres for Potential Alpha Energy Due to the Presence of Radon-220 (Thoron) Daughters, Informational Report No. 1015, United States Department of the Interior, Mining Enforcement and Safety Administration, 1975.
- Kusnetz, H.L., Radon Daughters in Mine Atmospheres, A Field Method for Determining Concentrations, Am. Ind. Hyg. Assoc. Quat., Vol. 17, No. 87, 1956.
- ANSI N13.1, Guide to Sampling Airborne Radioactive Materials in Nuclear Facilities.
- Regulatory Guide 8.25, Air Sampling in the Workplace.
- 29 CFR 1910.1096, United States Occupational Health & Safety, Ionizing Radiation.

ATTACHMENT 1
GRAPH 1, THORON WORKING LEVEL FACTORS



Time factors versus time after sampling for thoron daughter samples.

ATTACHMENT 2
GRAPH 2, RADON WORKING LEVEL FACTORS



Time factors versus time after sampling for radon daughter samples.

Air Sampling Checklist

Location: _____ Filter #: _____

Sampler ID: _____ Sample Start Date/Time: _____

Sampler SN: _____ Sample End Date/Time: _____

Flow Rate: _____ Elapsed Time: _____

Technician: _____

Instrument Inspection Checklist

Supplies and Materials

Filters (Inspect filters with a back light to look for pin holes)	Yes	No	
Envelopes or folders for filters	Yes	No	
Media fluid	Yes	No	
Calibration Kit and procedure	Yes	No	
Log book	Yes	No	
Chain of Custody	Yes	No	

Comments

Sampler Operation

Is the sampler running?	Yes	No	
If sampler is not running, contact management.			
Is the filter loading heavy?	Yes	No	

Visual Check

Is the sampler level and securely mounted?	Yes	No	
Any visible damage to sampler or shelter?	Yes	No	
If yes, contact management.			
Power cords and connections in good condition?	Yes	No	
Tubing and connections in good condition?	Yes	No	
Filter holder assembly in good condition?	Yes	No	
PM 2.5 filter cartridge in good condition?	Yes	No	
Inspect and clean filter screen?	Yes	No	
Do gaskets need to be replaced?	Yes	No	
Constant flow controller operational?	Yes	No	
Elapsed time meter operational?	Yes	No	
Telemetry unit powered up and operational?	Yes	No	

Appendix B
Eberline Analytical Oak Ridge
Laboratory Quality Assurance
Program Manual

Eberline Analytical Oak Ridge Laboratory Quality Assurance Program Manual

AUTHORIZATION AND APPROVAL STATEMENT

This **Eberline Analytical** - Oak Ridge Laboratory,
Quality Assurance Program Manual+
is authorized and approved in its entirety by:



Saba Arnold Seaver
Quality Assurance Manager

Date: August 1, 2013



Michael R. McDougall
Laboratory Manager

Date: August 1, 2013

Eberline Services – Oak Ridge Laboratory
601 Scarboro Road
Oak Ridge, TN 37830
Phone: (865) 481 - 0683, Fax: (865) 83 - 4621

Table of Contents

MISSION STATEMENT	5
STATEMENT OF COMPLIANCE AND MATRIX COMPARISON	6
1.0 INTRODUCTION AND DESCRIPTION	15
1.1 PREFACE	15
1.2 PURPOSE	15
1.3 SCOPE	15
1.4 INTRODUCTION	16
1.5 DESCRIPTION	17
1.6 CONFIDENTIAL AND PROPRIETARY INFORMATION	17
1.7 TECHNICAL COMPLAINTS	17
1.8 ETHICAL AND LEGAL RESPONSIBILITIES	17
1.9 ACCREDITATIONS	17
2.0 ORGANIZATION AND RESPONSIBILITY	19
2.1 ORGANIZATIONAL STRUCTURE	19
2.2 RESPONSIBILITY	19
2.3 ASSESSMENT	21
2.4 ORGANIZATION CHARTS	21
3.0 QUALITY ASSURANCE OBJECTIVES	23
3.1 OBJECTIVES	23
3.2 QUALITY IMPROVEMENT	23
3.3 RESPONSIBILITIES	23
3.4 CORRECTIONS	24
4.0 PERSONNEL QUALIFICATION AND TRAINING	25
4.1 QUALIFIED PERSONNEL	25
4.2 RESPONSIBILITY	25
5.0 INSTRUCTIONS AND PROCEDURES	27
5.1 POLICY	27
5.2 ANALYTICAL PROCEDURES	27
5.3 PROCEDURE MANUALS	27
5.4 FORMAT AND DISTRIBUTION	27
5.5 REVIEW	28

5.6	REVISION	28
6.0	<i>PROCUREMENT DOCUMENT CONTROL</i>	29
6.1	PURCHASING	29
6.2	PURCHASE REQUISITION REVIEW	29
6.3	CERTIFICATION/CERTIFICATE OF CONFORMANCE	29
6.4	SUBCONTRACTS	29
6.5	VENDORS	29
6.6	QUALITY RELATED SERVICES	29
7.0	<i>MATERIAL RECEIPT AND CONTROL</i>	29
7.1	POLICY	30
7.2	RESPONSIBILITY	30
7.3	MATERIAL CONTROL	30
7.4	NON-CONFORMING MATERIAL	30
8.0	<i>MATERIAL STORAGE AND CONTROL</i>	31
8.1	POLICY	31
8.2	RESPONSIBILITY	31
9.0	<i>CONTROL OF PROCESS</i>	32
9.1	STANDARD PRACTICES	32
9.2	DOCUMENTED PROCEDURES	32
9.3	RESPONSIBILITY	32
9.4	WORK POLICY	33
10.0	<i>PREVENTIVE MAINTENANCE</i>	34
10.1	POLICY	34
10.2	MAINTENANCE	34
10.3	SPARE PARTS	34
11.0	<i>CONTROL OF MEASUREMENT AND TEST EQUIPMENT</i>	35
11.1	MEASUREMENT AND TEST EQUIPMENT CALIBRATION POLICY	35
11.2	RESPONSIBILITY	35
11.3	PROCEDURES	35
11.4	CERTIFICATION AND CERTIFICATES OF CALIBRATION	36
11.5	RADIOACTIVE SOURCE CALIBRATION	36
11.6	CALIBRATION RECORDS	36
11.7	REPORTS GENERATED FROM USE OF A DEFICIENT INSTRUMENT	36

11.8	PERFORMANCE CHECKS OF RADIATION SCREENING INSTRUMENTS	36
12.0	DATA REDUCTION, VERIFICATION, AND REPORTING	37
12.1	USE OF COMPUTER HARDWARE AND SOFTWARE	37
12.2	DATA REDUCTION AND VERIFICATION	37
12.3	REPORTING	37
13.0	DOCUMENT CONTROL	38
13.1	POLICY	38
13.2	RESPONSIBILITY	38
14.0	INTERNAL QUALITY CONTROL	39
14.1	LABORATORY ANALYTICAL SERVICES	39
14.2	QUALITY CONTROL AND DATA REPORTS	40
14.3	DATA VERIFICATION	40
14.4	SAMPLE CUSTODY	Error! Bookmark not defined.
15.0	AUDITS	42
15.1	POLICY	42
15.2	RESPONSIBILITY	42
15.3	DOCUMENTATION	42
15.4	DEFICIENT AREAS	43
15.5	FREQUENCY OF AUDITS	43
16.0	QUALITY ASSURANCE AND INSPECTION RECORDS	43
16.1	POLICY	43
16.2	RESPONSIBILITY	43
16.3	RECORDS	43
16.4	STORAGE OF RECORDS	43
17.0	CORRECTIVE ACTION	44
17.1	POLICY	44
17.2	CORRECTIONS	44
17.3	NON-CONFORMANCE REPORT (NCR)	45
17.4	RESPONSIBILITY	45
17.5	CLIENT NOTIFICATION	45
18.0	QUALITY ASSURANCE REPORTS TO MANAGEMENT	45
18.1	POLICY	45
18.2	QUALITY ASSURANCE REPORTS	45

MISSION STATEMENT

Our mission is to ensure that all of The Eberline Services, Oak Ridge Laboratory's systems, services, processes, and deliverables are of a quality that meets or exceeds client requirements; and to foster a Laboratory culture in which there is a commitment to a rising standard of quality. This culture demands that the quality of those systems, services, processes, and deliverables and the methods used to achieve that quality be continuously improved.

Quality Assurance is a spirit that pervades all aspects of an organization. It is the quality attitude developed by a quality culture in an organization. It is the spirit in which any organization, procedure or activity is documented, implemented and performed. This spirit produces empowerment and motivation in all employees to achieve the highest level of quality. The result of this attitude is **"Quality Assurance."**

The policy guidelines are presented in this Oak Ridge Laboratory Quality Assurance Program Manual, and are based on the philosophy and premises that:

- People are our greatest asset and are ultimately responsible for the quality of the items and services we provide. Therefore, each person is treated with the greatest possible respect and consideration.
- Employees are inherently proud and want to produce top quality and on time services and deliverables. In order to do this they must be made aware of the quality requirements that are expected and must be provided appropriate facilities, equipment, and proper training.
- A culture of quality embodied within the entire Oak Ridge Laboratory organization is the most effective way to provide support for the employee's commitment to quality.
- Management support is paramount, and organizational responsibilities must ensure integration of quality requirements in the day-to-day operations.
- All systems, services, processes, and deliverables can be planned, performed, assessed, and improved.
- Improvements allow operations to become more efficient and result in contractual requirements performed "on time" and done "right the first time."
- Quality improvements lead to reduced costs and allow the ultimate objective of providing the highest quality items and services to be a viable goal.

Quality is our clients' perception of us. Our actions must assure our clients that the Oak Ridge Laboratory organization provides for quality systems, services, processes, and deliverables that will meet or exceed their requirements. To this end, each employee must understand and exercise the highest standards of ethics in the performance of their duties and ensure the integrity of the data they report.



STATEMENT OF COMPLIANCE AND MATRIX COMPARISON

This Quality Assurance Program Manual addresses the basic requirements outlined in several regulatory manuals, standards, regulations, and national laboratory programs. Matrix comparison to some of these documents is included in the following pages. Additional regulatory requirements are listed in Section 1.0.

NQA-Quality Assurance Requirements for Nuclear Facility Application
National Environmental Laboratory Accreditation Conference (NELAC), USEPA; 2003, the NELAC Institute (TNI), 2009
USEPA Requirements for the Certification of Laboratories Analyzing Drinking Water; 2005
ISO/IEC 17025 for the General Requirements for the Competence of Calibration and Testing
DOE Quality Systems for Analytical Services (QSAS) Document
DoD Quality Systems Manual for Environmental Laboratories (DoD QSM)
PJLA Accreditation Compliance Requirements

This manual is organized as follows:

±
Name, Title, Authorization and Approval
Table of Contents
Mission Statement
Statement of Compliance and Matrix Comparison
Introduction and Description
Organization and Responsibility
Quality Assurance Objectives
Personnel Qualification and Training
Instructions and Procedures
Procurement Document Control
Material Receipt and Control
Material Storage and Control
Control of Process
Preventative Maintenance
Control of Measurement and Test Equipment
Data Reduction, Verification, and Reporting
Document Control
Internal Quality Control
Audits
Quality Assurance and Inspection Records
Corrective Action
Quality Assurance Reports to Management

MATRIX COMPARISON

NQA-1, Cross Reference to - Oak Ridge Laboratory Q.A. Program Manual

NQA-1- Quality Assurance Requirements for Nuclear Facility Applications (<i>Basic Requirements</i>)		Oak Ridge, TN laboratory Quality Assurance Program Manual	
BASIC RQMT	TITLE	QAM SECT	TITLE
1.	Organization	2.0	Organization and Responsibility
2.	Quality Assurance Program	3.0 4.0	Quality Assurance Objectives Personnel Indoctrination and Training
3.	Design Control	N/A	Does not apply
4.	Procurement Document Control	6.0	Procurement Document Control
5.	Instructions, Procedures, and Drawings	5.0	Instructions and Procedures
6.	Document Control	13.0	Document Control
7.	Control of Purchased Items and Services	7.0	Material Receipt and Control
8.	Identification and Control of Items	8.0	Material Storage and Control
9.	Control of Process	9.0	Control of Process
10.	Inspection	14.0	Internal Quality Control
11.	Test Control	14.0	Internal Quality Control
12.	Control of Measurement and Test Equipment	11.0	Control of Measurement and Test Equipment
13.	Handling, Storage, and Shipping	8.0	Material Storage and Control
14.	Inspection, Test, and Operating Status	14.0	Internal Quality Control
15.	Control of Nonconforming Items	8.0	Material Storage and Control
16.	Corrective Actions	17.0	Corrective Actions
17.	Quality Assurance Records	16.0	Quality Assurance and Inspection Records
18.	Audits	15.0	Audits
	N/A	N/A	Title Page
	N/A	N/A	Authorization and Approval Statement
	N/A	1.0	Introduction and Description
	N/A	10.0	Preventive Maintenance
	N/A	12.0	Data Reduction, Verification, and Reporting
	N/A	18.0	Quality Assurance Reports to Management

MATRIX COMPARISON

10 CFR Part 50, Appendix B Cross Reference to Oak Ridge Laboratory Q.A. Program Manual

NRC 10 CFR Part 50 Appendix B, "Quality Assurance Criteria for Nuclear Power Plants and Fuel Reprocessing Plants."		Oak Ridge, TN Laboratory Quality Assurance Program Manual	
Criterion No.	TITLE	QAM SECT	TITLE
I	Organization	2.0	Organization and Responsibility
II	Quality Assurance Program	3.0	Quality Assurance Objectives
III	Design Control	N/A	Does not apply
IV	Procurement Document Control	6.0	Procurement Document Control
V	Instructions Procedures, and Drawings	5.0	Instructions and Procedures
VI	Document Control	13.0	Document Control
VII	Control of Purchased Material, Equipment, and Deliverables	7.0	Material Receipt and Control
VIII	Identification and Control of Materials, Parts, and Components	8.0	Material Storage and Control
IX	Control of Special Process	9.0	Control of Process
X	Inspections	14.0	Internal Quality Control
XI	Test Control	14.0	Internal Quality Control
XII	Control of Measuring and Test Equipment	11.0	Control of Measurement and Test Equipment
XIII	Handling, Storage, and Shipping	8.0	Material Storage and Control
XIV	Inspection, Tests, and Operating Status	14.0	Internal Quality Control
XV	Nonconforming Materials, Parts or Components	7.0	Material Receipt and Control
XVI	Corrective Actions	17.0	Corrective Actions
XVII	Quality Assurance Records	16.0	Quality Assurance Inspection Records
XVIII	Audits	15.0	Audits
		N/A	Title Page
		1.0	Introduction and Description
		10.0	Preventative Maintenance
		12.0	Data Reduction, Verification, and Reporting
		18.0	Quality Assurance Reports to Management

MATRIX COMPARISON

DOE Order 414.1C Cross Reference to Oak Ridge Laboratory Q.A. Program Manual

DOE Order 414.1 C "Quality Assurance"			Oak Ridge, TN Laboratory Quality Assurance Program Manual
Criterion No.	TITLE	QAM SECT	TITLE
1.	Program	1.0 2.0 3.0 12.0 13.0	Introduction Organization and Responsibility Quality Assurance Objectives Data Reduction, Verification, and Reporting Document Control
2.	Personnel Training and Qualification	4.0	Personnel Indoctrination and Training
3.	Quality Improvement	17.0	Corrective Actions
4.	Documents and Records	16.0 18.0	Quality Assurance Records Quality Assurance Reports to Management
5.	Work Process	5.0 9.0 10.0 14.0	Instructions and Procedures Control of Process Preventive Maintenance Internal Quality Control
6.	Design	N/A	Does not apply
7.	Procurement	6.0 7.0 8.0	Procurement Document Control Material Receipt and Control Material Storage and Control
8.	Inspection and Acceptance Testing	11.0 14.0 15.0	Control of Measurement and Test Equipment Internal Quality Control Audits
9.	Management Assessment	2.0	Organization and Responsibility
10.	Independent Assessment	15.0	Audits
N/A		N/A	Title Page
N/A		N/A	Authorization and Approval Statement

MATRIX COMPARISON

DOE Quality Systems (QSAS). And DoD Quality Systems (QSM) Cross Reference to Oak Ridge Laboratory QA Program Manual.

This cross reference applies also to NELAC Chapter 5.4.2.3

NELAC Chapter 5 "Quality Systems"		Oak Ridge, TN Laboratory Quality Assurance Program Manual	
4.2.6 RQMT	TITLE	QAM SECT	TITLE
	Title Page		Title Page
(a)	Policy statement, objectives, commitment by top management	1.0 3.0	Introduction and Description Quality Assurance Objectives
(b)	Organization and Management structure, Org Charts	2.0	Organization and Responsibility
(c)	Relationship between management, technical operations, support services and the quality system	2.0	Organization and Responsibility
(d)	Document control and records retention	16.0	Quality Assurance & Inspection Records
(e)	Job Descriptions	4.0	Personnel Indoctrination and Training
(f)	Approval signatories, signed concurrences	A&A	Authorization and Approval Statement
(g)	Traceability of measurements	14.0	Internal Quality Control
(h)	List of test methods	9.0	Control of Process
(i)	Review for facility and resource availability	9.0	Control of Process
(j)	Calibration or verification test procedures	5.0	Instructions and Procedures
(k)	Procedures for handling submitted samples	9.0	Control of Process
(l)	Major equipment and measurement standards	9.0 11.0	Control of Process Control of Measurement & Test Equipment
(m)	Calibration, verification, & maintenance	11.0	Control of Measurement & Test Equipment
(n)	Inter laboratory comparison, proficiency testing, reference material, internal Q.C.	14.0	Internal Quality Control
(o)	Corrective actions	17.0	Corrective Actions
(p)	Departures from policy/procedures	5.0	Instructions and Procedures
(q)	Complaints	1.0	Introduction and Description
(r)	Confidentiality and Proprietary rights	1.0	Introduction and Description
(s)	Audits and Data reviews	12.0 15.0	Data Reduction, Verification, and Reporting Audits
(t)	Personnel experience and training	4.0	Personnel Indoctrination and Training
(u)	Ethical and legal responsibilities	1.0	Introduction and Description
(v)	Analytical results reporting	12.0	Data Reduction, Verification, and Reporting
(w)	Table of Contents	TOC	Table of Contents

MATRIX COMPARISON

10 CFR Part 830.122 Cross Reference to Oak Ridge Laboratory Q.A. Program Manual

10CFR 830.122 "Quality Assurance Criteria"			Oak Ridge, TN Laboratory Quality Assurance Program Manual
Criterion No.	TITLE	QAM SECT	TITLE
830.122 (a)	Management/Program	1.0 2.0	Introduction Organization and Responsibility
(b)	Management/Personnel Training and Qualification	4.0	Personnel Indoctrination and Training
(c)	Management/Quality Improvement	3.0 14.0 17.0	Quality Assurance Objectives Internal Quality Control Corrective Actions
(d)	Management/Documents and Records	5.0 9.0 12.0 13.0 16.0 18.0	Instructions and Procedures Control of Process Data Reduction, Verification, and Reporting Document Control Quality Assurance Records Quality Assurance Reports to Management
(e)	Performance/Work Process	7.0 8.0 10.0 14.0	Material Receipt and Control Material Storage and Control Preventive Maintenance Internal Quality Control
(f)	Performance/Design	N/A	Does not apply
(g)	Performance/Procurement	6.0	Procurement Document Control
(h)	Performance/Inspection and Acceptance Testing	11.0 14.0 15.0	Control of Measurement and Test Equipment Internal Quality Control Audits
(i)	Assessment/Management Assessment	2.0	Organization and Responsibility
(j)	Assessment/Independent Assessment	2.0 15.0	Organization and Responsibility Audits
N/A		N/A	Title Page
N/A		N/A	Authorization and Approval Statement

MATRIX COMPARISON

EPA SW-846 Cross Reference to - Oak Ridge Laboratory Q.A. Program Manual

EPA SW-846 (Essential Elements)		Oak Ridge, TN Laboratory Quality Assurance Program Manual	
BASIC RQMT	TITLE	QAM SECT	TITLE
1.	Title Page	N/A	Title Page
2.	Table of Contents	N/A	Table of Contents
3.	Project Description	1.0	Introduction and Description
4.	Project Organization and Responsibility	2.0	Organization and Responsibility
5.	Q.A. Objectives	3.0	Quality Assurance Objectives
6.	Sampling Procedures	N/A	Does not apply to laboratory
7.	Sample Custody	9.0	Control of Process
8.	Calibration Procedures and Frequency	11.0	Control of Measurement and Test Equipment
9.	Analytical Procedures	5.0 9.0	Instructions and Procedures Control of Process
10.	Data Reduction, Validation, and Reporting	12.0	Data Reduction, Verification, and Reporting
11.	Internal Quality Control Checks	14.0	Internal Quality Control
12.	Performance and System Audits	15.0	Audits
13.	Preventive Maintenance	10.0	Preventive Maintenance
14.	Specific Routine Procedures Used to Assess Data Precision, Accuracy, and Completion	14.0	Internal Quality Control
15.	Corrective Action	17.0	Corrective Actions
16.	Quality Assurance Reports to Management	18.0	Quality Assurance Reports to Management
N/A		N/A	Authorization and Approval Statement
N/A		4.0	Personnel Indoctrination and Training
N/A		6.0	Procurement Document Control
N/A		7.0	Material Receipt and Control
N/A		8.0	Material Storage and Control
N/A		13.0	Document Control
N/A		16.0	Quality Assurance and Inspection Records

MATRIX COMPARISON

EPA QA/R-5 %EPA Requirements for Quality Assurance Project Plans+

EPA QA/R-5, "EPA Requirements for Quality Assurance Project Plans"		Oak Ridge, TN Laboratory Quality Assurance Program Manual	
RQMT	TITLE	SECT	TITLE
A	Project Management		
A1	Title and Approval Sheet		Title Page Authorization and Approval (A&A) Statement
A2	Table of Contents		Table of Contents Page Headers (document control)
A3	Distribution List		Title Page
A4	Project/Task Organization	1.4 2.1 2.2 2.5	Introduction Organizational Structure Responsibility Organization Charts
A5	Problem Definition/Background	3.0 9.0 14.0	Quality Assurance Objectives Control of Process Internal Quality Control
A6	Project/Task Description	9.0	Control of Process
A7	Quality Objectives and Criteria	3.0	Quality Assurance Objectives
A8	Special Training/Certification	4.0	Personnel Indoctrination and Training
A9	Documents and Records	5.0 9.2 13.0 16.0	Instructions and Procedures Documented Procedures Document Control Quality Assurance and Inspection Records
B	Data Generation and Acquisition		
B1	Sampling Process Design (Experimental Design)	N/A	
B2	Sampling Methods	N/A	
B3	Sample Handling and Custody	14.4	Sample Custody
B4	Analytical Methods	5.0 9.0	Instructions and Procedures Control of Process
B5	Quality Control	14.0	Internal Quality Control
B6	Instrument/Equipment Testing, Inspection, and Maintenance	10.0 11.0	Preventive Maintenance Control of Measurement and Test Equipment
B7	Instrument/Equipment Calibration and Frequency	11.0	Control of Measurement and Test Equipment
B8	Inspection/Acceptance of Supplies and Consumables	7.0 8.0	Material Receipt and Control Material Storage and Control
B9	Non-direct Measurements	10.0	Data Reduction, Verification, and Reporting
B10	Data Management	10.0	Data Reduction, Verification, and Reporting
C	Assessment and Oversight		
C1	Assessments and Response Actions	15.0 17.0	Audits Corrective Action
C2	Reports to Management	18.0	Quality Assurance Reports to Management
D	Data Validation and Usability		
	Data Review, Verification, and Validation	12.0	Data Reduction, Verification, and Reporting



QUALITY ASSURANCE PROGRAM

Rev. 7
Effective: 8/1/13
Page 14 of 46

EPA QA/R-5, "EPA Requirements for Quality Assurance Project Plans"		Oak Ridge, TN Laboratory Quality Assurance Program Manual	
RQMT	TITLE	SECT	TITLE
D1		14.3	Data Verification
D2	Verification and Validation Methods	12.0	Data Reduction, Verification, and Reporting
D3	Reconciliation with User Requirements	12.0	Data Reduction, Verification, and Reporting

1.0 INTRODUCTION AND DESCRIPTION

1.1 PREFACE

Eberline Services . Oak Ridge Laboratory is a radiochemistry laboratory that specializes in providing services for radiological assays to the environmental industry. Radionuclides are quantified within materials such as surface water, ground water, drinking water, wastewater, soil, sediment, sludge, vegetation, and hazardous waste. Bioassay (urine) analysis is performed for total uranium. The objective of the laboratory is to produce the highest quality data that are accurate, precise, legally defensible, and meet our clients data needs and requirements in a timely and cost effective manner.

The management of Eberline Services, Oak Ridge Laboratory is committed to a rigorous Quality Assurance (Q.A.) Program. While this commitment is necessary for the normal conduct of business, our basic policies dictate the highest standards of ethics and integrity in the conduct of our affairs. This philosophy and the specific procedures to attain policy objectives from the framework of our Q.A. Program. We will provide only those services that are within our qualifications and with confidence that our Q.A. Program and all related operating procedures dictate reliable performance of those services.

1.2 PURPOSE

This manual outlines management's Q.A. policy and establishes a requirement that procedures be promulgated and implemented to accomplish all of the quality assurance elements necessary to fulfill our responsibility to meet or exceed client or regulatory specifications. It also provides a means for creating mutual understanding regarding our Q.A. program and reliability techniques with our subcontractors, suppliers, and clients. This Eberline Services-Oak Ridge Laboratory Quality Assurance Program provides the structure, policies and responsibilities for the execution of quality control and quality assessment operations to assure that the laboratory meets defined standards of quality.

1.3 SCOPE

This Quality Assurance Program Manual provides guidance to meet operational Q.A. requirements.

In addition to the documents identified in the Cross Reference Section, this Manual complies with applicable requirements of the following the latest revisions of regulations below:

- 1.3.1 NRC 10 CFR Part 21, "Reporting of Defects and Non-compliance."
- 1.3.2 ANSI/ANS-10.3-, "Documentation of Computer Software."
- 1.3.3 NRC Regulatory Guide 4.15, Rev. 1, "Quality Assurance for Radiological Monitoring Programs - Effluent Streams and the Environment."
- 1.3.4 U.S. EPA QA/R-5, "EPA Requirements for Quality Assurance Program Plans."
- 1.3.5 DOE Order 414.1C Quality Assurance.+
- 1.3.6 ISO/IEC 17025, "General Requirements for the Competence of Calibration and Testing Laboratories."
- 1.3.7 USEPA Directive 2185, %Good Automated Laboratory Practices+(GALP).

- 1.3.8 DOE Quality Systems for Analytical Services (QSAS)
- 1.3.9 DoD Quality Systems Manual for Environmental Laboratories (DoD QSM)
- 1.3.10 A National Environmental Laboratory Accreditation Conference (NELAC) Chapter 5 Quality Systems+, July 2003.
- 1.3.11 USEPA Manual for the Certification of Laboratories Analyzing Drinking Water, EPA 815-R-004, January 2005.

1.4 INTRODUCTION

Quality assurance, as outlined herein, is a tool that allows management to utilize the expertise and experience of all personnel on the job. It requires each worker to be aware of his/her work environment and to continually evaluate methods and processes to ensure that the best and correct operation is being performed. It requests each employee to identify and suggest any improvement to the processes while performing an operation. Improvements or changes shall be coordinated with management who will validate improvement and disseminate the information to all affected personnel. Management shall also, as needed, change procedures and provide additional training. This program also requires that all personnel be qualified, and trained on a continuing basis to maintain that qualification and be assimilated into the Oak Ridge Laboratory quality culture.

Management will provide resources, tools, equipment, scheduling, and training to ensure personnel can perform their duties effectively.

- 1.4.1 Management will also ensure that internal assessments are performed annually to evaluate management and processes with feedback for review with a goal of improving all areas of operations.
- 1.4.2 It is only by having a quality assurance culture, with all personnel involved, that a system, service, or product can be provided with full assurance that the best possible work, the best possible product, or the best possible service has been provided.
- 1.4.3 In order to ensure that this manual is an effective management tool, subjects that are not normally considered quality assurance, i.e. safety, security, etc., are addressed in other management documents.
- 1.4.4 The following titled designations of positions are used within the Oak Ridge, TN Laboratory:

Laboratory Manager: Refers to the General Manager of the Oak Ridge Laboratory.

Radiation Safety Officer (RSO): Refers to the RSO of the Oak Ridge Laboratory.

Emergency Coordinator: Refers to the individual who is responsible for overseeing and directing activities and protocols associated with emergencies and disasters..

Project Manager: Refers to an individual who is responsible for client service activities and is the single point of contact with a client for the laboratory.

Supervisor: Refers to individuals within the laboratory who are responsible for the operational functions of a group of personnel.

Q.A. Manager: Refers to the individual who is responsible for the Laboratory's Q.A.

Program.

1.5 DESCRIPTION

This document outlines the organization of the Q.A. functions within the laboratory. It depicts the lines of authority, and lists the duties and responsibilities within the organization. It provides direction for the preparation of Procedures Manuals, which provide the detailed methods of processes and analyses that accomplish the goal of quality data in terms of precision, accuracy and reproducibility.

1.6 CONFIDENTIAL AND PROPRIETARY INFORMATION

Oak Ridge Laboratory employees are exposed to confidential and/or proprietary information pertaining to the company and its clients. Information concerning the report of analysis, radiation dosimetry records, audit reports, calibration reports, and other documents relating to a project are considered confidential. This information is to be released only to the client or to the client's authorized representative. Each employee will sign an agreement with the Oak Ridge, TN Laboratory concerning the security of proprietary and confidential information. A copy of the agreement will be retained in the employee's personnel file (at the corporate office in Albuquerque, NM).

1.7 TECHNICAL COMPLAINTS

Technical complaints will be addressed by the Laboratory Manager, Project Manager, Quality Assurance Manager, or staff member with expertise in the area of complaint. If the complaint is not valid, every attempt will be made to satisfy the client. If the complaint is determined to be valid, the cause of the complaint shall be identified and corrected as soon as feasible. Verification that the cause for a valid complaint has been corrected is the responsibility of the individual addressing the complaint. Details of all technical complaints shall be recorded and maintained in the customer's project file. Clients are also encouraged to provide feedback on the Eberline Analytical website via a statement on each client report.

1.8 ETHICAL AND LEGAL RESPONSIBILITIES

Eberline Services-Oak Ridge Laboratory utilizes a clearly stated ethics policy that is discussed with all new employees during orientation. Each employee is required to understand the high standards of ethics and integrity required in order to perform their duties and to ensure the integrity of the data reported in connection with their employment at the Oak Ridge Laboratory. Each employee will understand that intentionally reporting data that are not the actual values obtained, intentionally reporting dates and/or times or data analyses that are not the actual dates and/or times of analyses, intentionally representing another individual's work as their own; or any other action that may affect the integrity of the data reported by the laboratory; will be the cause for dismissal.

1.9 ACCREDITATIONS

Through applications, pre-qualification, performance testing, and external auditing programs; the laboratory has been granted certification by different agencies, organizations, and states. The Laboratory maintains proficiency as required by the clients and regulatory certifying agency. The Quality Assurance Manager maintains credentials and lists of certifying agencies. The list of certifications maintained by the Oak Ridge Laboratory includes:

State of Tennessee, Department of Health . Laboratory Division

State of California, Department of Public Health . ELAP Branch

State of South Carolina, Dept of Health & Environmental Control, Environmental Lab Certification Program



QUALITY ASSURANCE PROGRAM

Rev. 7
Effective: 8/1/13
Page 18 of 46

State of Utah, Department of Health Bureau of Laboratory Improvement
State of New Jersey, Department of Environmental Protection, Office of Quality Assurance
State of New York, Department of Health, Environmental Lab Approval Program
State of North Dakota, Dept. of Health Environ. Lab. Certification Program - Chemistry Division
State of Nevada, Dept. of Conservation Bureau of water Quality Environmental Lab Services
State of Louisiana, Department of Environmental Quality
State of Texas, Texas Commission of Environmental Quality
State of Alabama, Department of Environmental Management
Commonwealth of Virginia, Dept. of General Services Division of Consolidated Lab Services
State of Washington, Department of Ecology
Perry Johnson Laboratory Accreditation, Inc.
Department of Energy (DOE)
Department of Defense (DoD)

2.0 ORGANIZATION AND RESPONSIBILITY

2.1 ORGANIZATIONAL STRUCTURE

The Laboratory Manager has overall responsibility for this Quality Assurance Program (hereafter referred to as the Program). In this capacity, he has delegated the responsibility for formulation, implementation, and execution of the Program to the Laboratory Q.A. Manager.

Current organizational charts, identifying key individuals and the structure of the laboratory, are included in the "Statement of Qualifications." Additional organizational structure, functional responsibilities, levels of authority, and lines of communication for management, direction, and execution of the Program are documented below.

2.2 RESPONSIBILITY

Laboratory Management will periodically assess the integrated quality assurance program, its performance, and its effectiveness. Problems that hinder the organization from achieving its objectives will be identified and corrected.

Management will provide training and qualification to ensure quality products and services. Every employee is responsible for supporting the QA program policies, procedures, and guidance with each employee being responsible for their work. Professional qualifications and experience of all individuals and positions are maintained. Position descriptions and resumes are kept on file in the QA office. The specific duties of selected personnel are described below. Other job descriptions are located within an employee's training file in the QA office.

2.2.1 Laboratory Manager

The Laboratory Manager, under the authority of the President of Eberline Analytical Corporation, is responsible for the overall laboratory productivity and optimization of the efforts of the analytical staff and those who directly support the analytical effort. Staff interacts with the Lab Manager throughout the day. The Laboratory Manager is responsible for the implementation of regulatory standards, and national program requirements (NELAP, TNI, DOE, and DoD). The Laboratory Manager is responsible for the all safety aspects of the laboratory operations.

The duties of the Laboratory Manager include the following.

- Overall direction and general administration.
- Daily operation of the laboratory.
- Review of analytical procedures and practices.
- Recruitment, hiring, assignment, evaluation and termination of personnel.
- Training and professional development of staff.
- Review of proposals, bids, pricing and quotations.
- Perform an annual assessment of the laboratory operation.

2.2.2 Quality Assurance Manager

The Quality Assurance Manager operates independently from line management while reporting to the Laboratory Manager. The QA Manager has sufficient authority and organizational freedom to identify quality problems, to initiate, recommend or provide solutions; to verify implementation of solutions, and if necessary, to stop work until the problem is resolved. The QA Manager has independence from cost scheduling, and production considerations. In his capacity, he has the authority to control processing, delivery, installation, or use of items or services until proper disposition of an identified non-conformance, deficiency, or condition adverse to quality. The QA

Manager has a direct line of communication to the President of Eberline Analytical Corporation for matters of quality.

The duties and responsibilities of the QA Manager are as follows.

- Develop QA procedures, instructions and plans.
- Maintain surveillance over all applications of the QA Program; make recommendations for resolution of problems, or further evaluation by management.
- Monitor external audits, write responses, and ensure corrective actions.
- Issue non-conformances and formal corrective action(s).
- Issue stop-work orders for work that is not in compliance with requirements.
- Direct, and maintain records of analytical performance evaluation programs to ensure full and prompt participation and evaluation of results and derivation of all benefits relating there from.
- Direct, and maintain records of laboratory certification programs.
- Authorized to sign and designate other personnel to sign client related Certificates of conformance and/or non-conformance.
- Ensures compliance with Regulatory Standards and National Program requirements (e.g. NELAP, TNI, DOE, DoD, . . .)

2.2.3 Health and Safety Manager

The Health and Safety Manager reports directly to the Laboratory Manager and oversees the daily implementation of the laboratory's health and safety program. The program includes an integrated chemical hygiene plan, safety orientation and training, radiation safety plans and training, sample disposal and shipment, and safety checks and audits.

- The duties and responsibilities of the Health and Safety Manager are as follows.
- Administer chemical hygiene, safety, fire extinguisher, etc. training.
- Management of sample disposal in conformance with the waste disposal policy.
- Packaging and shipment of samples, or designation thereof, following DOT regulations.
- Maintain Material Safety Data Sheet (MSDS) documentation.
- Direct spill response.
- Direct safety checks and audits.
- Ensures compliance with regulatory standards and national program requirements (NELAP, TNI, DoD, DOE, . . .)

2.2.4 Technical Director

The Technical Director reports directly to the Laboratory Manager and provides technical direction or advice for the laboratory operations and/or special programs, projects, or activities.

- The duties and responsibilities of the Technical Director are as follows.
- Perform technical analysis for specific projects.
- Make recommendations for research and development.
- Write technical manuals.
- Design systems, procedures, and documentation as necessary.
- Assist chemistry supervisors and technicians in technical interpretation of program requirements.
- Consult with clients, make recommendations regarding analytical schemes.

2.2.5 Data Review Department Staff

The Data Review Department has been structured to handle the specific project requirements of

our clients. The Department is responsible for producing quality control (QC) reports, for ensuring proper assembly of data packages and production of electronic data deliverables (EDDs) that meet the requests of the clients. Data Review personnel, in concert with the QA Manager, will assess the requirements of the various programs and client specific requirements, then interact with the appropriate laboratory personnel to ensure compliance with the client's statement of work. These efforts improve the accuracy and efficiency with which QC reports and data packages are prepared and forwarded to the client. Data deliverables are those items associated with the analyses of samples that are provided to the client.

Data Review staff responsibilities include the following.

- Assuring that analytical data have been correctly entered in the final report.
- Assuring that data are not released without reviews.
- Assuring that all data are released to the correct contact person.
- Producing QC reports.
- Assembling Data Packages.
- Ensuring that submitted EDD are complete, verified and in appropriate format.


2.3 ASSESSMENT

- 2.3.1 The Laboratory Manager will perform routine and continuous assessment of the management system to identify, correct, and prevent management problems that hinder achievement of the organization's objective. The assessment will focus on broad categories of management issues to determine the effectiveness of the integrated management system.
- 2.3.2 Laboratory Manager's assessments will not be conducted to verify conformance to regulations, product standards, or established procedures, but will evaluate customer and employee perceptions relative to the following key issues.
- Mission and strategic objectives of the organization.
 - Employee's role in the organization.
 - Customer's expectations and degree to which expectations are being met.
 - Opportunities for improving quality and cost effectiveness.
 - Recognizing and enhancing human resource capabilities.
- 2.3.3 Results of the Laboratory Manager's management assessment and recommendations will be documented annually. Decisions and related actions resulting from the recommendations will be properly followed up and evaluated for their effectiveness. Moreover, the opportunity for customer feedback is afforded by means of an on-line customer feedback/satisfaction survey on the laboratory website.

2.4 ORGANIZATION CHARTS

- 2.4.1 The Oak Ridge Laboratory Organization is illustrated in Figure 2.1

Figure 2.1
Oak Ridge, TN Laboratory Organization



3.0 QUALITY ASSURANCE OBJECTIVES

3.1 OBJECTIVES

The Oak Ridge Laboratory Q.A. Program is organized to meet the following objectives.

- 3.1.1 To ensure performance of those actions that provide confidence that quality is achieved.
- 3.1.2 To provide an effective control for the verification of characteristics of all systems, services, and processes that produce data of the required quality.
- 3.1.3 To ensure that systems, services, processes, and deliverables meet the rigid quality and reliability standards of the Oak Ridge Laboratory. Also, to ensure that individual client criteria pursuant to these standards are met.
- 3.1.4 To provide a continuing monitoring service for review of operating procedures, and for overall effectiveness and evaluation of the Q.A. Program. Also, to provide observations and recommendations for improvement in all areas of laboratory operations where quality may be affected.
- 3.1.5 To ensure the program provides valid records of the control measures applied to all factors bearing on the result of investigations.
- 3.1.6 To ensure the assessment of results provides feedback to improve the process.
- 3.1.7 To foster a culture of commitment to achieve a rising standard of quality that demands that the methods utilized to achieve the quality systems, services, processes, and deliverables be continuously monitored and improved.

3.2 QUALITY IMPROVEMENT

Operational processes will be reviewed continually by management and employees to detect and prevent problems and to ensure quality improvement. Any item or process that does not meet established requirements will be identified, controlled, and corrected. The cause of problems will be identified with corrections made to prevent recurrence. Item reliability, process implementation, and quality-related information will be reviewed and the data analyzed to identify items and processes needing improvement.

3.3 RESPONSIBILITIES

Employees are an integral part of the organization and are responsible to be aware of their work environment, to review operational processes and materials utilized, to identify any problems, and to make suggestions and recommendations for improvement. Employees are empowered to make and/or recommend corrections to improve operations and to prevent recurrence of the problems. Employees are also empowered, through their supervisor, to stop work where detrimental ethical, contractual, quality, safety, or health conditions exist. Management will immediately be made aware of any situations requiring work stoppage.

All employees are responsible for supporting the Program in principle and in detail and shall retain responsibility for the quality of their work.

Management is responsible to be actively involved in the quality improvement process to ensure

proper focus is maintained and for resolution of difficult issues. Management will maintain a no fault attitude to encourage employees to identify problems that compromise safety and reliability. Management will consider all recommendations for quality improvement and will recognize employee contributions.

3.4 CORRECTIONS

Items and processes that do not meet established requirements must be identified, documented, analyzed, and resolved. Corrective actions will be implemented and followed up to ensure effectiveness.

No laboratory analytical data will be revised or corrected after reporting to clients without full documentation of the process. The documentation must show: a) what necessitated the change; b) details of the change in terms of re-run records or recalculation; c) approval process for the change; d) formal client notification.

4.0 PERSONNEL QUALIFICATION AND TRAINING

4.1 QUALIFIED PERSONNEL

- 4.1.1 The Oak Ridge Laboratory personnel who perform activities that affect quality will have education, experience and training to ensure that suitable proficiency is achieved and maintained. A job description, identifying position qualification and duty requirements, will be included in each individual's training records.
- 4.1.2 All personnel will have training outlining their ethical and legal responsibilities, including the potential punishment and penalties for improper, unethical, or illegal actions.
- 4.1.3 Personnel performing technical functions or processes will have known and documented related work experience and minimum qualifications of education.

4.2 RESPONSIBILITY

- 4.2.1 Supervisors are responsible for initial evaluation of capabilities and qualifications of assigned personnel and will assign those personnel to perform functions based on the individual's qualifications and abilities.
- 4.2.2 Supervisors and managers are responsible for the day-to-day monitoring of assigned personnel for evidence of unethical, improper, or illegal activities.
- 4.2.3 Appropriate training is the responsibility of the supervisors with support from management. Training will address specific needs and will vary according to each job's requirements and previous experience of the employee, and will ensure:
 - 4.2.3.1 Understanding of the fundamentals of the work and its context,
 - 4.2.3.2 Understanding of the processes and tools being used, the extent and sources of variability in those processes and tools, and the degree to which control over the variability is maintained,
 - 4.2.3.3 Emphasis on correct performance of the work, understanding why quality requirements exist, and potential consequences of improper work, and
 - 4.2.3.4 Emphasis on "doing it right the first time.+ A particular emphasis is placed on employee safety.
- 4.2.4 Management will provide ALL employees the resources, tools, equipment, scheduling, and structured training to ensure personnel can perform their duties effectively. New employees will receive detailed information concerning the general corporate policies and the specific laboratory safety practices, and security policies. Training shall be conducted on an individual basis to achieve and maintain suitable proficiencies. The training will include, but will not be limited to:
 - Ethical and Legal responsibilities
 - Health and Safety
 - Radiation Protection
 - Waste Management
 - Quality Assurance
 - Laboratory Procedures
 - LIMS Operation

- 4.2.5 Access to all laboratory documents and procedures will be available at all times to all employees who will be expected to familiarize themselves with these documents.
- 4.2.6 Milestone achievements or unique training will be noted by the supervisors via entry in the training records. Available certificates of training, education, or awards will also be maintained with the individual's training records.
- 4.2.7 Supervisors will monitor individual work habits to ensure proficiency is maintained, to note progressive improvement, and to identify any needed supportive training. Additional training requirements will be developed by the individual's supervisor.
- 4.2.8 As needed, employees will be informed of the requirements of special clients/programs necessary to achieve their duties and responsibilities. Familiarization will be made a matter of record.
- 4.2.9 All personnel training records will be maintained in the QA office. The details for maintenance of training requirements and records are outlined in the Oak Ridge Laboratory Management Procedure, MP-042 ~~Personnel Training~~ "Personnel Training."

5.0 INSTRUCTIONS AND PROCEDURES

5.1 POLICY

The Oak Ridge Laboratory policy uses written and approved procedures for routine activities and for analytical and operational processes. Applicable Laboratory procedures are available to all personnel. The most current revision of the appropriate procedure will be maintained and documented on the laboratory computer server. Departures from routine procedures due to non-standard situations or specific requests from clients will be approved by management and fully documented.

In addition to analytical procedures (AP) the laboratory maintains Management Procedures (MP) that describe the policy and approach for performing quality functions. Separate procedures for Health and Safety, Radiation Protection and Waste Management, are also maintained.

5.1.1 ANALYTICAL PROCEDURES

Analytical procedures are descriptions of particular protocols for testing or operations. Analytical procedures will be developed based on published reference procedures for each test or process, and authorized for use by the Laboratory Manager.

5.1.2 Qualification requirements for personnel performing operations and criteria used to determine the proficiency of the operator will be documented.

5.1.3 Each technical procedure will include a list of Personal Protective Equipment (PPE) required for the operation being performed. Training for the identification, operation, use, limitations, and disposal of the PPE will be conducted.

5.1.4 Each technical procedure will identify any chemicals/reagents required for completion of the operation. Material Safety Data Sheets (MSDSs) for those chemicals/reagents will be readily available, and training applicable to the MSDSs will be conducted.

5.1.5 Training will be conducted to the procedures used for processing wastes generated within the appropriate chemistry laboratory.

5.2 PROCEDURE MANUALS

Procedure manuals consist of the individual analytical procedures for a laboratory area or for an operation combined into one document. The procedures within the manual define all parameters of the operations being performed to include required accuracy and completeness of specific measurement parameters involved. Procedures will be incorporated into procedure manuals. Signature on the Authorization and Approval page applies to all procedures in the manual.

5.3 FORMAT AND DISTRIBUTION

5.3.1 Procedures will comply with the format prescribed in the laboratory management procedure (MP-021, Preparation of Technical and Project QA Documents) and will be approved by the QA Manager and the Laboratory Manager.

5.3.2 Employee access to the most current revision of procedures and manuals will be through the Laboratory computer server. Any distribution of controlled copies of any Laboratory procedure will be in accordance with the laboratory's document control protocol.

5.3.3 The Laboratory Manager is responsible for the maintenance and security of the original electronic version of all laboratory procedures and manuals and for ensuring that the most current revision of the procedures and manuals are promptly posted and accessible to all employees.

5.4 REVIEW

Laboratory technical procedure, manuals and Quality Assurance Plan will be reviewed annually and whenever program or procedural changes occur with updates as appropriate. Such reviews will be documented. All effected laboratory personnel and document holders will be made aware of any changes. Training of laboratory personnel on new changes will be conducted as necessary.

5.5 REVISION

- 5.5.1 The appropriate supervisor, or designated representative, is responsible for revisions or changes to the applicable procedure manuals.
- 5.5.2 Revisions are reviewed and approved by the organization(s) and personnel responsible for the original document. When possible, revisions or changes will be accomplished on a page replacement basis.
- 5.5.3 The Q.A. Manager will be advised of any changes in procedures required to satisfy specifications of the client.
- 5.5.4 The final revision shall be reviewed, approved, and authorized by the laboratory manager and QA manager. The electronic copy is placed on the laboratory server for access.
- 5.5.5 The Q.A. Manager will be responsible for the electronic retention of past revised and superseded procedures. The Q.A. Manager will also be responsible for maintaining the server location where current revisions are stored for employee reference.

6.0 PROCUREMENT DOCUMENT CONTROL

6.1 PURCHASING

Procurement of material, components, supplies, reagents, equipment, and services necessary to carry on the business interests of the Oak Ridge Laboratory is initiated by purchase requisition and controlled by the use of an authorized purchase order number. To the extent necessary, purchase orders will require suppliers to have a Q.A. program consistent with the requirements of this document. Detailed information on procurement is outlined in the laboratory's Purchasing Procedure.

6.2 PURCHASE REQUISITION REVIEW

Purchase requisitions or change orders are reviewed by purchasing department personnel to ensure conformance to the procurement requirements. As applicable, quality related requisitions are reviewed by Q.A. personnel prior to being processed. Change orders undergo the same review process.

6.3 CERTIFICATION/CERTIFICATE OF CONFORMANCE

All materials and processes requiring certification and certificates of conformance are identified on the face of the purchase requisition. Adequate information is provided to ensure supplier compliance to the required specifications. The Q.A. Manager is responsible for the retention, filing, and recall of material certification or certificates of conformance.

6.4 SUBCONTRACTS

When subcontracting analytical work, Oak Ridge Laboratory Management will ensure that the subcontractor can meet all the technical specification, maintain the appropriate certification (NELAP, DOE, DoD, State, . . .) and that the prospective subcontractor has a QA program consistent with the requirements of this document. The Oak Ridge Management will secure the client approval for subcontracting their analytical work prior to commencement of the subcontract. The Q.A. Manager is responsible for evaluation and acceptance of the subcontractor's Q.A. program.

6.5 VENDORS

- 6.5.1 For procurement of quality-related items or services, the Q.A. Manager is responsible for vendor evaluation and approval. Analytical service vendor evaluation and qualification will be through accreditation as a secondary standard calibration laboratory (NVLAP, NIST); an audit by Oak Ridge Laboratory personnel or an acceptable audit agency; or facility inspection, test reports, or receipt inspections, when the quality of the materials or service can be verified by these methods. Documentary evidence that products and services conform to procurement requirements will be provided and retained. A list of approved vendors will be maintained by the Procurement Office.
- 6.5.2 The effectiveness of the control of quality by contractors and subcontractors will be assessed at intervals consistent with the importance, complexity, and quantity of the product or services.
- 6.5.3 The purchasing department is responsible for maintaining a record of quality related materials received from vendors including any reports for non-conforming material.

6.6 QUALITY RELATED SERVICES

Q.A. personnel will review the purchase requisitions for quality related services. Those services that are determined to be quality related will include, as applicable, a statement, or wording, in the body of the purchase order or by attachment identifying the applicable requirement.

7.0 MATERIAL RECEIPT AND CONTROL

7.1 POLICY

Only material components, supplies, reagents or standards with acceptable quality characteristics and from qualified vendors will be allowed into the laboratory.

7.2 RESPONSIBILITY

Receipt and initial verification of all materials and equipment received by the Oak Ridge Laboratory, either purchased or contract (client) supplied, is the responsibility of the receiving or designated individual. Technical verification for materials and equipment will be performed by the requisitioner or Q.A. Manager, whichever is applicable. Quality related purchase order items will be receipt inspected by Q.A. personnel.

7.3 MATERIAL CONTROL

Purchased material is controlled by the Laboratory Supervisor or designated individual.

7.3.1 The receiving and stock control clerk, or designated individual, is responsible for the expedient and correct routing of all initially accepted received materials to stock, or to the requisitioner.

7.3.2 Purchasing department personnel are responsible for maintaining a record of materials received from vendors, including Rejected Material Report or equivalent form, for any non-conforming material.

7.4 NON-CONFORMING MATERIAL

When received material, affecting quality, has been determined to be non-conforming, the requisitioner will work with the purchasing agent and will be responsible for proper processing.

7.5 RECORDS

Records of receipt of services and supplies that affect the quality of laboratory operation will be identified with date of receipt, expiration date, source, lot or serial identifier, and calibration or certification records as appropriate.

8.0 MATERIAL STORAGE AND CONTROL

8.1 POLICY

All materials and supplies in storage will have the necessary protection to preclude deterioration, corrosion, or damage during storage life and will carry identification sufficiently clear to ensure that only those materials specified by process instructions will be withdrawn from material storage and issued for processing.

Only analytical grade chemicals and reagents, bearing such grade identification will be utilized by the Laboratory. Each container will be assigned a unique identification number upon receipt. The date of receipt will be posted on each container. The use and the retention (shelf life) of such chemical will be monitored by the Laboratory Supervisor.

All standards used by the Laboratory must be NIST certified. Each standard must be accompanied with a certificate showing the name, composition, concentration, reference number and NIST Certification. The use and distribution of these standards will be monitored by the LIMS. The certificate and certification documents of standards will be controlled by the QA department.

8.2 RESPONSIBILITY

Only authorized personnel will have access to, and the responsibility for, control and issue of materials or supplies. Materials and supplies will be stored to allow for ready identification. Care will be taken to preclude mixing of rejected material and supplies with those that are qualified for issue.

9.0 CONTROL OF PROCESS

9.1 STANDARD PRACTICES

Standard practices applicable to services provided by the Oak Ridge Laboratory are contained in documented procedures and this Q.A. Program Manual. Every effort is made to implement and fulfill the requirements of Federal and local laws, rules, guidance(s), and directives as may be applicable to the operational practices within the Oak Ridge Laboratory. These may include but are not limited to:

- 9.1.1 Federal and State rules and regulations.
- 9.1.2 Consensus standards related to the services performed (e.g., American National Standards Institute).
- 9.1.3 Regulatory Guides published by the Nuclear Regulatory Commission, Department of Energy, the Environmental Protection Agency, and the Department of Defense.
- 9.1.4 Specific contractual agreements with clients.
- 9.1.5 Where conflicts may occur among any of the above items, the client will be notified and requested to specify the practice to be followed.

9.2 DOCUMENTED PROCEDURES

Routine analytical operating procedures are documented. Each laboratory procedure includes quality control criteria that are applicable to that process. The laboratory management will develop, promulgate, and implement procedures that document the operations performed in the laboratory. Additionally, the following general procedures or documents, as applicable, will be developed:

- 9.2.1 Quality Assurance Procedures
- 9.2.2 Radiation Safety Manual and Procedures
- 9.2.3 Sample Control Procedures
- 9.2.4 Purchasing Policies and Procedures
- 9.2.5 Data Review Procedures
- 9.2.6 Environmental Compliance Procedures
- 9.2.7 Safety Procedures
- 9.2.8 Chemical Hygiene Plan
- 9.2.9 Hazard Communications Program
- 9.2.10 LIMS Procedures
- 9.2.11 Management Procedures
- 9.2.12 Analytical Procedures

9.3 RESPONSIBILITY

The Laboratory Manager, or designated representative, determines which instructions or procedures require quantitative or qualitative acceptance criteria and specify the appropriate criteria on special contracts or projects.

9.4 WORK POLICY

All work to be performed by the Oak Ridge Laboratory on client samples is authorized by the client and controlled through a Laboratory Information Management System (LIMS) work order document which incorporates the client's requirements. (Or by some other document deemed necessary by the Laboratory Manager or Project Manager as directed by the customer)

- 9.4.1 The work order specifies those analyses necessary to assure compliance with contractual obligations.
- 9.4.2 The Project Manager or designated personnel . under the authority of the Laboratory Manager, are responsible for notifying the Q.A. Manager and performing laboratory departments, through the appropriate supervisor, of all contract requirements including reporting format and quality control criteria. This may be done by reference to other documents (e.g., Purchase Order, statement of work, technical specifications, etc.) that delineates the contract requirements.
- 9.4.3 The Project Manager or designee . under the authority of the Laboratory Manager-, will ensure planning, scheduling, and resources are considered when contracting for or accepting work.
- 9.4.4 When subcontracting analytical services, the Project Manager or designated individual under the authority of the Laboratory manager-, will assure that:
 - The client is notified in writing of the intention to subcontract any portion of the testing to another party.
 - If the work is covered under NELAP, the work will be placed with a laboratory accredited under NELAP for the tests to be performed.
 - Records, demonstrating that the above requirements have been met, are retained in the project folder.

10.0 PREVENTIVE MAINTENANCE**10.1 POLICY**

Preventive maintenance is performed as required on instrumentation and equipment to prevent down time and to ensure reliable performance. The laboratories maintain instrument redundancy that precludes the requirement for a repair and maintenance capability for instrumentation. Maintenance and/or repair of equipment are performed by the equipment manufacturer or authorized representative under contract or purchase order.

10.2 MAINTENANCE

Preventive maintenance procedures will be developed for use where instructions are not provided in the manufacturer supplied operator's manual. As applicable, each department will maintain a major equipment and measurement standards list. A record of instrument maintenance, calibration, and repair, if applicable, will also be maintained. The supervisors and operating personnel are responsible for complying with the department maintenance schedule.

10.3 SPARE PARTS

Supervisors will ensure that an adequate inventory of spare parts and consumables is requisitioned and maintained for instrumentation in their area in order to prevent down time or compromise operating conditions.

11.0 CONTROL OF MEASUREMENT AND TEST EQUIPMENT**11.1 MEASUREMENT AND TEST EQUIPMENT CALIBRATION POLICY**

This section establishes the controls and calibration requirements for all analytical and nuclear measurement equipment. An equipment list will be maintained indicating calibration status.

- 11.1.1 All equipment whose operation and function directly affect the quality of service will be inspected/calibrated at established intervals. As applicable, equipment will be suitably identified to reflect calibration status. If an instrument is determined to be out-of-tolerance, it will be segregated, or otherwise clearly identified as inoperable. Records of each calibration will be kept in appropriate logbooks or files. Instruments whose calibrations are performed during method operations are calibrated and controlled in accordance with the method requirements. Run logs will be maintained for this category of instrumentation.
- 11.1.2 The equipment used to determine the quality characteristics and accuracy of instruments will be checked and verified either internally (dependent upon capability), or by qualified calibration services.
- 11.1.3 Frequency of inspection/calibration will be based on use of the equipment or instrument, environmental conditions in which it is used, its inherent stability, manufacturer's recommendation, and the wear or deterioration resulting from its use.
- 11.1.4 Certified standards are used for all primary calibrations. National Institute of Standards and Technology (NIST) or NIST traceable, Environmental Protection Agency (EPA), New Brunswick Laboratory (NBL), or Department of Energy (DOE) standards are used, when available, for the primary calibrations or verification of primary calibrations.
- 11.1.5 All preparations of standard solutions are recorded in a standards preparation logbook or file. Identities of standards are such that a secondary standard or dilution can be traced, through subsequent actions, back to the initial certification. Records of these reference standards are organized in a secure location in the QA office.
- 11.1.6 Quality control check standards are used to record instrument sensitivity and linearity and to verify proper response. Methods and calibration entries are dated, initialed, and documented by the analyst.
- 11.1.7 Measuring and test equipment are tagged as to calibration or operating status for periodic processes performed on a scheduled interval of greater than one month. For processes performed more frequently, separate documentation will be available for verification of operational status. Instruments that are too small to be tagged or are subject to a wide variety of calibrations shall have separate documentation of status available.

11.2 RESPONSIBILITY

Testing and/or calibration of equipment and instruments will be performed under the direction of the supervisor, the department manager, or the operations manager and performed under suitable environmental conditions.

11.3 PROCEDURES

All tests and calibrations will be performed in accordance with written procedures that contain provisions for ensuring that all prerequisites for the given test have been met, including appropriate equipment to be used.

11.4 CERTIFICATION AND CERTIFICATES OF CALIBRATION

11.4.1 To the extent possible, calibration will be traceable to NIST. Records of traceability will be maintained along with records of routine calibrations of each instrument or measurement system. Where no NIST traceability exists, the basis used for calibration will be documented.

11.4.2 Equipment records will be maintained to indicate past and current status, and to provide reproducibility and traceability of results.

11.5 RADIOACTIVE SOURCE CALIBRATION

Radioactive sources used as calibration standards will be periodically calibrated and controlled. Current calibration certificates will be kept on file.

11.6 CALIBRATION RECORDS

Supervisors will ensure that calibration data for instruments and radioactive sources is recorded in the instrument logbook, on data work sheets, on computer files and/or control charts. When required, new calibration charts will be prepared when there is measurable change in calibration effect on instruments that have been calibrated. If an instrument is determined to be out of tolerance, it will be segregated or otherwise clearly tagged as inoperable and not used until repaired.

11.7 REPORTS GENERATED FROM USE OF A DEFICIENT INSTRUMENT

If a major deficiency in an instrument or device is detected during periodic calibration procedures, the technician will immediately notify the supervisor, the operations manager, and the Q.A. Manager. A conference will immediately be scheduled to investigate and decide what corrective action is to be taken on past data and reports resulting from the use of the deficient instrument or device. A record of corrective actions will be maintained.

11.8 PERFORMANCE CHECKS OF RADIATION SCREENING INSTRUMENTS

Performance checks will be made to ensure the continuing capability of radiation screening instruments. Procedures will include efficiency checks and background determinations. The procedure and frequency of each check is optimized for each detector system to provide assurance of the detector's performance. Documentation of the checks and the results are kept for all operations.

12.0 DATA REDUCTION, VERIFICATION, AND REPORTING**12.1 USE OF COMPUTER HARDWARE AND SOFTWARE**

Computer programs used in the production or support of client data are either purchased, or developed using approved development methodology. Such programs are independently validated, verified, and documented. Changes are controlled to assess the potential impact of the change on the performance of the program.

12.2 DATA REDUCTION AND VERIFICATION

Sample receipt and distribution through the laboratory is documented by the sample receiving technician. Sample handling, subsampling, and preparation for counting measurement are documented by the laboratory technicians.

12.2.1 The successful completion of an analysis is monitored by the Counting Room staff. The Laboratory Manager, or designated individual, performs the final review and approves the data.

12.2.2 Calculation methods, transcriptions, and data flow, plus times and locations of the various tiers of review are detailed in the specific procedure.

12.3 REPORTING

The Project Manager or designated individual is responsible for providing the client with the required analytical results. Reports to clients will be reviewed for accuracy and completeness and, where required, analytical methods and minimum/method detection limits (MDL) will be reported. Laboratory reports of analyses will be signed by an authorized individual who, along with the person who signed the data sheets, can attest to the fact that the data was generated in accordance with established procedures.

13.0 DOCUMENT CONTROL**13.1 POLICY**

The primary formal communication methods within the Oak Ridge Laboratory departments are documents that inform or direct activities affecting purchasing, sample analyses and reporting, instrument calibration and/or testing, radiation controls, proper handling of wastes, radiation safety, and Health and Safety. These documents are controlled by the Q.A. Program Manual, Operating Procedure Manuals, other documented procedures, or by interoffice memoranda. Drawings and specifications are not controlled as separate documents but are included in controlled procedures where applicable. The QA Office controls logbooks used to document the analysis of samples (see MP-023, Documentation of Analytical Laboratory Notebooks).

13.2 RESPONSIBILITY

13.2.1 The Q.A. Manager is primarily responsible for maintaining files of all controlled documents and will:

- Review the Quality Assurance Program Manual and provide recommendations for updating.
- Ensure that all holders of controlled documents receive updates to the documents.
- Maintain files of controlled document distribution indicating document title, number, revision number, assigned date, and the name of the individual to whom the document is assigned.
- Forward revisions of controlled documents to assigned individuals. An acknowledgment form will accompany each document revision for verification of receipt and to provide disposition instructions for the superseded pages
- Maintain a Master List of current procedures which includes procedure number, procedure title, current revision number, and date on which the current revision became effective. The list will be continually updated to reflect all new revisions or new procedures issued. An electronic copy of this list shall be available for employee reference at all times.

13.2.2 Uncontrolled copies of controlled documents will be distributed only if marked "Uncontrolled."

13.2.3 Superseded and/or obsolete documents are isolated from use or destroyed. Upon training to new revisions, employees sign to verify the destruction of all uncontrolled copies of obsolete revisions.

13.2.4 Each employee is responsible for requesting revisions or changes to operating procedures for their area of responsibility.

13.2.5 The Q.A. Manager will be advised of any changes in procedures required to satisfy client specific requirements.

13.2.6 Client information and records such as contract requirements, project descriptions, analytical data and results submitted to the client; and all laboratory records associated with such submittal will be maintained by the laboratory for a minimum of 5 (Five) years. Clients will be contacted and queried for disposition instructions for their related documentation.

13.2.7 If or when the laboratory may transfer ownership, is decommissioned, or goes out of business, ALL clients will be notified and asked to provide specific direction regarding the transfer or disposition of documents and records related to their project(s).

14.0 INTERNAL QUALITY CONTROL

14.1 LABORATORY ANALYTICAL SERVICES

Precautions are taken in the chemistry laboratories to avoid cross-contamination of samples and to ensure the reporting of accurate results. Quality control samples are analyzed along with routine samples to indicate when results may be in error due to improper operation or calibration of equipment, inadequate training of personnel, a deficiency in the procedure, or cross-contamination from other samples.

- 14.1.1 Laboratory Precision - Laboratory management personnel are responsible to ensure that analytical results are reproduced internally within acceptable limits.
- 14.1.2 Precision and Accuracy - Replicate standards and/or samples are used to estimate the precision of each analytical test procedure for a known matrix. Data control limits are established to satisfy the requirements of specific measurements based on prior knowledge of the measurement system and method validation studies. Certified standards and/or spiked samples are used to estimate chemical recovery and accuracy for these procedures for known matrices.
- 14.1.3 Calibration and Performance Checks of Nuclear Measurement Systems - Reference standards are used for calibrating nuclear measurement systems. In addition to calibration of all instrumentation, routine monitoring is performed to ensure the continuing integrity of the instrument performance. The monitoring parameters performed include efficiency checks, background determinations, and energy calibrations. The procedure and frequency of each check is optimized for each detector system to provide assurance of the detector's performance. Documentation of the checks and the results are kept for all systems. The supervisor is responsible for these calibration and performance checks.
- 14.1.4 Duplicate Analysis - Duplicate aliquots of randomly selected samples will be processed on a routine basis. The analyst will always process samples in accordance within approved operating procedures. The evaluation of the duplicate analysis will be based on examination of the difference between the duplicates. A statistical analysis of the data may be performed when a cursory evaluation indicates problems with the results. If the two results agree within the three standard deviation limits, a more detailed evaluation will generally not be necessary. Results of duplicate analyses will be included in the monthly Q.C./Q.A. report.
- 14.1.5 Detection and Elimination of Bias - Where possible, calibration will be with standards that are traceable to NIST. However, traceability to NIST is not always possible and reliance on other suppliers may be necessary (e.g., International Atomic Energy Agency, U.S. Department of Energy, U.S. Environmental Protection Agency, or commercial supplier such as Analytics, Amersham Biosciences, AEA Technology, etc.). Standards in the appropriate geometry or form will be used to determine efficiency of instruments on a periodic basis. In the calibration process, the ideal standard will be a known quantity of the radionuclide to be measured, prepared in exactly the same geometry as the samples and counted under the same conditions. In this way, factors such as self-absorption, backscatter, sample geometry, and detector efficiency will be accounted for empirically.
- 14.1.6 Spiked Samples - A known quantity of calibrated radioactive standard solution will be added to an aliquot of the sample or to a "blank" sample for replicate analysis. When the entire analytical system is operating properly, the laboratory record will demonstrate the accuracy and precision of the data. Divergent data from the spiked sample will point out

- problem areas. If the data is consistently higher or lower than the known value, bias in the analytical procedure is indicated. This may require a search for personnel errors, re-standardization of carriers or tracers, and/or recalibration of counting equipment. .
- 14.1.7 Background Determination - The type of equipment and environmental factors contribute to variation in the counting rate of instrument background. The background of each system instrument will be determined and recorded with sufficient frequency to provide a firm statistical basis for that measurement and to ensure response to potential instrument problems or other artifacts such as controlled contamination.
 - 14.1.8 These background determinations will include use of the items that most closely duplicate the analytical configuration in type, geometry, and with any associated fixtures. In some cases, true blanks are not available, but the closest practicable analog is used.
 - 14.1.9 Some systems are sufficiently stable to require no change in backgrounds used for data reduction (e.g., uranium daughter gamma-rays found in gamma spectra due to adjacent building materials and earth). In this case, backgrounds will be compared to historical data to insure sufficient stability. Other systems experience enough variability to require computed backgrounds based upon running averages.
 - 14.1.10 Background data will be recorded in the logbook or computer file for that specific instrument along with calibration data and instrument maintenance records.
 - 14.1.11 Blanks - Blank samples are routinely analyzed to verify control of contamination and process. Results of processed blanks will be included in the monthly Q.C./Q.A. report.
 - 14.1.12 Collaborative Testing - The Oak Ridge Laboratory participates in collaborative testing or inter-laboratory comparison programs. Natural or synthetic samples prepared to contain known concentrations of certain radionuclides are sent to participating laboratories by an independent referee group such as the DOE Radiological and Environmental Sciences Laboratory DOE, Idaho Falls, Idaho (MAPEP); by a NELAC approved provider such as the Environmental Resources Agency (ERA), Environmental Measurements Laboratory (EML), or by customer(s).

These programs enable Oak Ridge Laboratory personnel to document the precision and accuracy of radioactivity measurements, identify instrumental and procedural problems, and compare performance with other laboratories.

14.2 QUALITY CONTROL AND DATA REPORTS

14.2.1 Quality Control Reports

Quality control results will be summarized, and include with every sample/group of samples.

14.2.2 Data Reports

Routine performance requires documentation of all pertinent information with the basic documents dated and initialed or signed. Required documentation will be the initial work order, Chain-of-Custody (CoC), or document that records all pertinent information such as the identity of the sample and analyses to be performed. The data report will include technical analysis notes, logbooks, work sheets all raw data and other information used in performing the analysis. The report of analysis will be the final report of the data to the client and is issued in accordance with the laboratory's procedure for review and processing, as well as any client specific requirements.

14.3 DATA VERIFICATION

Routine performance requires inclusion of all pertinent information with basic documents dated and initialed or signed. The work order has recorded such information as the identity of the samples and analyses to be performed. All raw data and other information used in performing the

analyses are documented.

14.3.1 Electronic Deliverables Verification - Project managers, or designated individuals, are responsible for ensuring that electronic deliverables are complete and accurate.

14.4 Sample Custody

Samples are assigned a unique laboratory identification number, marked on a label that is applied directly to the container and which identifies the work order and laboratory fraction. Sample control personnel are designated sample custodians for strict (legally defensible) CoC samples. Locked buildings, refrigerators, freezers, and cabinets are available for CoC samples. Sample custody forms or technician analysis notes are used for tracking all samples through the analytical process. Details for radiological survey of samples, sample security, sample disposal, etc. are outlined in approved Sample Control Procedures. Sample chemistry and nuclear counting requirements are assigned by the laboratory manager, or designated individuals.

15.0 AUDITS**15.1 POLICY**

The Oak Ridge Laboratory has established a comprehensive system of planned and documented audits to verify compliance with all aspects of the Q.A. Program. An audit is defined as a documented activity performed in accordance with written procedures or checklists to verify, by examination and evaluation of objective evidence, that applicable elements of the Q.A. Program have been developed and effectively implemented in accordance with specific requirements. Audits will be performed by persons not having direct responsibility for those areas being audited.

15.1.1 Customer Access to the Oak Ridge Laboratory Facilities and Personnel - The client is frequently responsible for auditing the Oak Ridge Laboratory's performance relative to contractual requirements. The exact nature of this responsibility is relative to the nature of the regulatory or licensing requirements, the significance of the services, and the technical expertise available or inherent within the client's organization. The need for, and frequency of, client audits is dependent upon the above factors. A client may authorize an independent agency to perform an audit on its behalf. When possible, the facilities, equipment, and records (proprietary information excluded) of the Oak Ridge Laboratory will be made available for client inspection along with the necessary personnel to permit verification of quality characteristics.

15.1.2 The Q.A. Manager will coordinate and participate in audits conducted by the client or the client's representative.

15.1.3 Internal Audits - The Q.A. Manager will audit the laboratory operations to verify compliance with established procedures and requirements set forth in the Q.A. Program Manual. Use of a checklist will insure items in compliance are noted as well as any requirements for improvement.

15.1.4 External Audits - External audits of organizations providing services to the Analytical Services Group are scheduled at a frequency commensurate with the status and importance of the activity.

15.2 RESPONSIBILITY

Audits will be directed by the Q.A. Manager with assistance from designated personnel.

15.2.1 The Q.A. Manager will be responsible for an independent quality assurance audit of each department.

15.2.2 The Q.A. Manager will be responsible for assuring that audits are performed by knowledgeable professionals.

15.2.3 An independent qualified auditor will audit areas of responsibility assigned to the Q.A. Manager.

15.3 DOCUMENTATION

Audit results will be documented by the Q.A. Manager.

15.3.1 The Laboratory Manager shall be provided a copy of the audit report.

15.3.2 The QA Manager will determine if there are any corrective actions required and the individual responsible for implementing the corrective action

15.4 DEFICIENT AREAS

- 15.4.1 The responsible Manager will ensure correction of the identified deficiencies.
- 15.4.2 The Q.A. Manager will verify that action is taken to correct any deficiency and will take follow-up action to ensure that corrections have been completed.
- 15.4.3 The Q.A. Manager will ensure close out, with documentation, of the audit after corrective actions have been completed.
- 15.4.4 For uncorrected or unresolved deficiencies, after due diligence, the Q.A. Manager will petition the Laboratory Manager to bring to bear his authority for resolution of the deficiencies.

15.5 FREQUENCY OF AUDITS

The Q.A. Manager will ensure internal audits are conducted on an annual basis. Additional selective audits will be conducted when one or more of the following conditions exist:

- 15.5.1 When significant changes are made in functional areas of the Q.A. Program, including significant reorganization or procedure revisions.
- 15.5.2 When assessment of the Program's effectiveness is considered necessary.

16.0 QUALITY ASSURANCE AND INSPECTION RECORDS**16.1 POLICY**

Records that provide objective evidence of the quality of work are generated and maintained. These records include controlled logbooks, customer instructions, sample analyses data sheets, and results of reviews, inspections, tests, audits, corrective actions, reports, and training records. Also included are related data such as personnel qualifications, procedures, and equipment records.

16.2 RESPONSIBILITY

The responsibility for initiation, completeness, and reliability of Q.A. records is vested in the appropriate supervisor, with periodic verification checks by the Q.A. Manager. All Oak Ridge Laboratory personnel performing processes or services associated with the work being performed will assist in the efforts.

16.3 RECORDS

- 16.3.1 Inspection and test records will, at a minimum, identify the inspector or data recorder, the type of observation, the results, the action taken in connection with any deficiencies noted, and the date of the inspection or test.
- 16.3.2 All required records will be legible and of a quality that can be copied. Records shall be completed using reproducible ink. Errors or incorrect entries will be lined through with a single line, dated, and initialed by the recorder.
- 16.3.3 Correspondence from clients may be made available for inspection at the discretion of client representatives and authorization from the originating organization.
- 16.3.4 Q.A. records will be identified and controlled by customer number and/or client identification as applicable.

16.4 STORAGE OF RECORDS

- 16.4.1 Quality assurance records will be firmly attached in binders, placed in folders or

envelopes, and, if applicable, cross referenced by client identification and stored in a secure area.

16.4.2 Q.A. records will be properly stored and made available to the client upon request.

16.4.3 Records will be maintained in a secured and protective storage area.

16.4.4 Records will be identified and be retrievable.

16.4.5 CoC records are included with the sample set records.

16.4.6 Longer retention or duplication of records is available at the specific direction from the client.

16.4.7 Laboratory management will be responsible for governing access to, and controlling the records.

16.4.8 Analytical reports and source calibration data will be retained for a minimum of five years after results are reported to the client.

16.4.9 Procurement records will be retained for a minimum of five years or as required by the contract.

16.4.10 All records and analyses performed pertaining to (NELAC) accreditation will be kept for a minimum of 5 years and would be available for inspection by the accrediting authorities during this period even without prior notification to the laboratory.

17.0 CORRECTIVE ACTION

17.1 POLICY

The Oak Ridge Laboratory policy is to ensure continuous acceptable quality levels for services provided. Conditions adverse to quality will be identified and corrected as soon as practical.

17.2 CORRECTIONS

17.2.1 CORRECTIVE ACTION REPORT (CAR)

In the case of a significant condition adverse to quality, the cause of the condition shall be determined and corrective action taken to preclude recurrence. The identification, cause, and corrective action shall be documented and reported to appropriate levels of management. Follow-up action shall be taken to verify implementation of this corrective action and documented via a Corrective Action Follow-Up form. The Corrective Action Report (CAR) Form shall be used to document this condition. Typically, the Q.A. Manager will initiate investigation and corrective action by issuing a Corrective Action Report (CAR) in any of the following situations:

- When an audit reveals circumstances that will adversely affect quality (Audit Finding) as determined by the Q.A. Manager.
- When any results of an inter-comparison study are out of control, or for non-participation.
- When procedural or technical problems arise and the Q.A. Manager determines that they will significantly affect quality.

17.3 NON-CONFORMANCE REPORT (NCR)

A non-conformance is a deficiency in a characteristic, procedure, or documentation that renders the quality of an item unacceptable, however, is not considered a significant condition that would require an investigation by use of a CAR. In the laboratory, non-conformances can include physical defects, incorrect or inadequate documentation, and deviations from an established protocol, plan, or documented technical requirement. This condition is documented using a Non-Conformance Report (NCR) Form.

17.4 RESPONSIBILITY

All laboratory personnel are responsible to communicate any evidence of unacceptable quality performance to their supervisor, the responsible manager, and/or the Q.A. Manager.

17.4.1 The responsible manager will ensure investigation of a condition adverse to quality, determine assignable cause, and provide recommendation(s) for corrective action.

17.4.2 The responsible manager will ensure action is initiated to correct the assignable cause of the adverse condition and to determine and initiate the specific corrective action(s) necessary to preclude recurrence.

17.4.3 The Q.A. Manager will review CARs, NCRs, and routine Q.C. reports for evidence of unacceptable quality.

17.4.4 Copies of the completed CARs and NCRs will be kept on file by the Q.A. Manager.

17.5 CLIENT NOTIFICATION

The client will be notified when any Corrective Action is initiated due to evidence of unacceptable quality that is related to their contract.

18.0 QUALITY ASSURANCE REPORTS TO MANAGEMENT**18.1 POLICY**

The Oak Ridge Laboratory policy is to keep management apprised of all quality assurance problems, actions taken to correct them, and any actions taken to prevent recurrence.

18.2 QUALITY ASSURANCE REPORTS

18.2.1 Quality Assurance Reports are prepared quarterly by the QA Manager and submitted to upper management. The reports shall include discussion of inter-comparison studies, status of corrective actions, and quarterly QA objectives.

18.2.2 The Q.A. Manager will report all general or system audit results, problems, corrective actions, and replies.

Document Revision History

Revision	Effective Date	Changes From Previous Revision
7	8/1/13	<ul style="list-style-type: none">• Document Revision History table implemented• Added Emergency Coordinator to title designations of positions in Section 1.4.4• Updated list of accreditations in section 1.9 to reflect all current certifications• Updated Laboratory Organization Chart• Removed requirement for employees to maintain hard copies of procedures in work area.



PERRY JOHNSON LABORATORY ACCREDITATION, INC.

Certificate of Accreditation

Perry Johnson Laboratory Accreditation, Inc. has assessed the Laboratory of:

Eberline Analytical – Oak Ridge Laboratory
601 Scarboro Road, Oak Ridge, TN 37830-7371

(Hereinafter called the Organization) and hereby declares that Organization has met the requirements of ISO/IEC 17025:2005 “General Requirements for the competence of Testing and Calibration Laboratories” and the DoD Quality Systems Manual for Environmental Laboratories Version 4.2 10/26/2010 and is accredited in accordance with the:

**United States Department of Defense
Environmental Laboratory Accreditation Program
(DoD-ELAP)**

This accreditation demonstrates technical competence for the defined scope:
Environmental Testing
(As detailed in the supplement)

Accreditation claims for such testing and/or calibration services shall only be made from addresses referenced within this certificate. This Accreditation is granted subject to the system rules governing the Accreditation referred to above, and the Organization hereby covenants with the Accreditation body's duty to observe and comply with the said rules.

For PJLA:

Tracy Szeszen
President/Operations Manager

Perry Johnson Laboratory
Accreditation, Inc. (PJLA)
755 W. Big Beaver, Suite 1325
Troy, Michigan 48084

<i>Initial Accreditation Date:</i>	<i>Issue Date:</i>	<i>Accreditation No.:</i>	<i>Certificate No.:</i>
December 18, 2012	December 18, 2012	70747	L12-194

The validity of this certificate is maintained through ongoing assessments based on a continuous accreditation cycle. The validity of this certificate should be confirmed through the PJLA website: www.pjilabs.com



Certificate of Accreditation: Supplement

ISO/IEC 17025:2005 and DoD-ELAP

Eberline Analytical – Oak Ridge Laboratory

601 Scarboro Road, Oak Ridge, TN 37830-7371

Michael McDougall Phone: 865-481-0683

Accreditation is granted to the facility to perform the following testing:

Matrix	Standard/Method	Technology	Analyte
Air/Aqueous	Eberline SOP EiChroM AM-01	Alpha Spectroscopy	Isotopic Curium
Air/Aqueous/Solid	AP-016	Beta GPC	Chlorine-36
Air/Aqueous/Solid	AP-026	Beta LSC	Carbon-14
Air/Aqueous/Solid	ASTM D-5174	KPA	Total Uranium
Air/Aqueous/Solid	Eberline SOP EiChroM Ni-01	Beta LSC	Nickel-63
Air/Aqueous/Solid	Eberline SOP EML Pu-01	Alpha Spectroscopy	Isotopic Plutonium
Air/Aqueous/Solid	Eberline SOP EML Th-01	Alpha Spectroscopy	Isotopic Thorium
Air/Aqueous/Solid	Eberline SOP EPA 903.0	Alpha Spectroscopy	Radium-226
Air/Aqueous/Solid	EiChroM Np-01	Alpha Spectroscopy	Neptunium-237
Air/Aqueous/Solid	EiChroM Sr-01	Beta GPC	Strontium-90
Air/Aqueous/Solid	EiChroM Sr-01	Beta GPC	Total Strontium
Air/Aqueous/Solid	EiChroM Tc-01	Beta LSC	Technetium-99
Air/Solid	Eberline SOP EiChroM AM-01	Alpha Spectroscopy	Americium-241
Air/Solid	Eberline SOP EML Pb-01	Beta GPC	Lead-210
Air/Solid	Eberline SOP EML Po-01	Alpha Spectroscopy	Polonium-210
Air/Solid	Eberline SOP EML U-02	Alpha Spectroscopy	Isotopic Uranium
Air/Solid	Eberline SOP EPA 903.0	Alpha GPC	Total Radium
Air/Solid	Eberline SOP EPA 904.0	Beta GPC	Radium-228
Air/Solid	LANL ER-130	Gamma Spectroscopy	Gamma Emitting Radionuclides
Aqueous	EPA 900.0	Alpha Beta GPC	Gross Alpha & Beta
Aqueous	EPA 901.1	Gamma Spectroscopy	Gamma Emitting Radionuclides
Aqueous	EPA 903.0	Alpha GPC	Total Radium
Aqueous	EPA 904.0	Beta GPC	Radium-228
Aqueous	EPA 906.0	Beta LSC	Tritium
Aqueous	EPA 908.0	Alpha Spectroscopy	Isotopic Uranium
Aqueous/Solid	EiChromM Am-01	Alpha Spectroscopy	Americium-241
Solid	EiChromM Am-01	Alpha Spectroscopy	Isotopic Curium



Perry Johnson Laboratory Accreditation, Inc.



October 1, 2012

Mr. Michael McDougall
Eberline Analytical – Oak Ridge Laboratory
601 Scarboro Road
Oak Ridge, TN 37830-7371

Dear Mr. McDougall:

This letter is to confirm that you have successfully completed your accreditation assessment. A certificate has now been granted and posted on our website. As you are aware, PJLA will no longer be issuing expiration dates on our certificates. Your certificate # **L12-194** will remain valid as long as you continue to maintain your annual assessments and reaccreditation assessments as stated in your customer agreement with PJLA. At this time, we have confirmed that your annual assessments will be conducted during the month of **June** each calendar year. This will include an interim surveillance assessment and a full system reassessment to be completed by **June 2014**. Once your reassessment is conducted and approved by our accreditation committee a revised status letter will be provided to you. Please allow PJLA at least 120 days from your assessment due date to issue this letter.

Please feel free to release this letter to any interested parties as confirmation of your certificate validity. Also, please remind them that your certificate is posted on our website at all times. Any changes in regards to your accreditation status will be reflected on our website.

We would like to thank you for your patronage and we look forward to continuously serving your accreditation needs in the future. If we can assist you any further, please feel free to contact us at any time.

Sincerely,

Tracy Szerszen
President/Operations Manager

State of New Jersey
Department of Environmental Protection



Certifies That

Eberline Services - Oak Ridge

Laboratory Certification ID # TN004

is hereby approved as a

Nationally Accredited Environmental Laboratory
to perform the analyses as indicated on the Annual Certified Parameter List
which must accompany this certificate to be valid


having duly met the requirements of the
Regulations Governing The Certification Of
Laboratories And Environmental Measurements N.J.A.C. 7:18 et. seq.
and

having been found compliant with the 2009 TNI Standard approved by the
The NELAC Institute

Expiration Date June 30, 2014



NJDEP is a NELAP Recognized Accreditation Body



Joseph F. Aiello, Manager
Office of Quality Assurance

New Jersey Department of Environmental Protection
Environmental Laboratory Certification Program
LABORATORY PERSONNEL LIST
Effective as of: 07/01/2013

Laboratory Name: EBERLINE SERVICES - OAK RIDGE Laboratory Number: TN004 Activity ID: NLC130001
601 SCARBORO RD
OAK RIDGE, TN 37830

Position: Lead Tech. Director		Start Date	End Date	Documentation Status	Complete Date	Comments
Employee	Category/Instrument					
AHMED HALOUMA		7/1/2005	7/31/2012	Complete/Qualified		
MIKE McDOUGALL		7/31/2012		Complete/Qualified		
Position: QA Officer		Start Date	End Date	Documentation Status	Complete Date	Comments
Employee	Category/Instrument					
SABA ARNOLD		7/31/2012		Complete/Qualified		
AHMED HALOUMA		4/16/2002	7/31/2012	Complete/Qualified		
Position: Supervisor/Tech Dir		Start Date	End Date	Documentation Status	Complete Date	Comments
Employee	Category/Instrument					
AHMED HALOUMA	SDW07, 08, WPP09 or 10	7/1/2005	7/31/2012	Complete/Qualified		
MARY TURNER	SDW07, 08, WPP09 or 10	7/31/2012		Complete/Qualified		

New Jersey Department of Environmental Protection
National Environmental Laboratory Accreditation Program
ANNUAL CERTIFIED PARAMETER LIST AND CURRENT STATUS
 Effective as of 07/01/2013 until 06/30/2014



Laboratory Name: EBERLINE SERVICES - OAK RIDGE Laboratory Number: TN004 Activity ID: NL130001
 601 SCARBORO RD
 OAK RIDGE, TN 37830

Category: SDW07 -- Radiochem.: Radioactivity / Radionuclide

Eligible to Report		NJ Data		State		Code		Matrix		Technique Description		Approved Method		Parameter Description	
Status	Report	NJ Data	State	Code	Matrix	Technique Description	Approved Method	Parameter Description							
Certified	Yes	UT	UT	SDW07.01000	DW	Proportional or Scintillation	[EPA 900.0]	Gross - alpha-beta							
Certified	Yes	UT	UT	SDW07.03100	DW	Gamma Spectrometry	[EPA 901.1]	Gamma emitters							
Certified	Yes	UT	UT	SDW07.03900	DW	Radiochemical	[EPA 903.0]	Radium - 226							
Certified	Yes	UT	UT	SDW07.04100	DW	Precipitation	[EPA 904.0]	Radium - 228							
Certified	Yes	UT	UT	SDW07.05000	DW	Precipitation	[EPA 903.0]	Radium - total							
Certified	Yes	UT	UT	SDW07.06000	DW	Total Sr & Strontium 90	[EPA 905.0]	Strontium - 89, 90							
Certified	Yes	UT	UT	SDW07.06010	DW	Strontium 90	[EPA 905.0]	Strontium - 90							
Certified	Yes	UT	UT	SDW07.07000	DW	Distillation/Liquid Scintillation	[EPA 906.0]	Tritium							
Certified	Yes	UT	UT	SDW07.08100	DW	Co-Precipitation	[EPA 908.0]	Uranium							
Certified	Yes	UT	UT	SDW07.08400	DW	Radiochemical / Alpha Counting	[EPA 907.0]	Uranium							
Certified	Yes	UT	UT	SDW07.09000	DW	Radiochemical / Alpha Counting	[EPA 907.0]	Plutonium							

Category: WPP09 -- Radiochem.: Radioactivity / Radionuclide

Eligible to Report		NJ Data		State		Code		Matrix		Technique Description		Approved Method		Parameter Description	
Status	Report	NJ Data	State	Code	Matrix	Technique Description	Approved Method	Parameter Description							
Certified	Yes	UT	UT	WPP09.01000	NPW	Proportional or Scintillation	[EPA 900.0]	Gross - alpha							
Certified	Yes	UT	UT	WPP09.03000	NPW	Proportional Counter	[EPA 900.0]	Gross - beta							
Certified	Yes	UT	UT	WPP09.05000	NPW	Precipitation	[EPA 903.0]	Radium - total							
Certified	Yes	UT	UT	WPP09.05010	NPW	Proportional	[EPA 903.0]	Radium - 226							
Certified	Yes	UT	UT	WPP09.06020	NPW	Co-Precipitation / Beta Counting	[EPA 904.0]	Radium - 228							
Certified	Yes	UT	UT	WPP09.07000	NPW	Gamma Spectrometry	[EPA 901.1]	Photon Emitters							
Certified	Yes	UT	UT	WPP09.08000	NPW	Precipitation / Beta Counting	[EPA 905.0]	Strontium - 89, 90							
Certified	Yes	UT	UT	WPP09.08100	NPW	Precipitation / Beta Counting	[EPA 905.0]	Strontium - 90							

Category: SHW09 -- Miscellaneous Parameters

Eligible to Report		NJ Data		State		Code		Matrix		Technique Description		Approved Method		Parameter Description	
Status	Report	NJ Data	State	Code	Matrix	Technique Description	Approved Method	Parameter Description							
Certified	Yes	UT	UT	SHW09.60000	NPW, SCM	Proportional Counter	[SW-846 9310]	Gross - alpha-beta							
Certified	Yes	UT	UT	SHW09.60100	NPW, SCM	Precipitation	[SW-846 9315]	Alpha Emitting Radium Isotopes							

KEY: AE = Air and Emissions, BT = Biological Tissues, DW = Drinking Water, NPW = Non-Portable Water, SCM = Solid and Chemical Materials



State of New Jersey

DEPARTMENT OF ENVIRONMENTAL PROTECTION

CHRIS CHRISTIE
Governor

KIM GUADAGNO
Lt. Governor

Office of Quality Assurance
401 East State Street
P.O. Box 420, Mail Code 401-02D
Trenton, New Jersey 08625-0420
Telephone: (609) 292-3950
Facsimile: (609) 777-1774

BOB MARTIN
Commissioner

Dear Laboratory Manager:

A Certificate and an Annual Certified Parameter List (ACPL) that reflects the current status of your facility are enclosed. If there are any discrepancies, please contact your Laboratory Certification Officer to verify information and make arrangements for a new ACPL. Effective with the receipt of this letter, your facility's certification status is valid through June 30, 2014. Both the ACPL and Certificate should be conspicuously displayed at your facility in a location on the premises that is visible to the public.


As always, we are available to discuss any comments or questions. Please do not hesitate to contact your Laboratory Certification Officer or me.

Sincerely,

Joseph F. Aiello, Manager

Enclosure(s)

New Jersey Department of Environmental Protection
National Environmental Laboratory Accreditation Program
ANNUAL CERTIFIED PARAMETER LIST AND CURRENT STATUS
Effective as of 07/01/2013 until 06/30/2014




Laboratory Name: EBERLINE SERVICES - OAK RIDGE Laboratory Number: TN004 Activity ID: NLC130001
601 SCARBORO RD
OAK RIDGE, TN 37830

Category: SHW09 -- Miscellaneous Parameters

Eligible to Report

Status	NJ Data	State	Code	Matrix	Technique Description	Approved Method	Parameter Description
Certified	Yes	UT	SHW09,60110	NPW, SCM	Precipitation	[SW-846 9320]	Radium - 228


Joseph F. Aiello, Manager

KEY: AE = Air and Emissions, BT = Biological Tissues, DW = Drinking Water, NPW = Non-Potable Water, SCM = Solid and Chemical Materials



Catherine B. Templeton, Director

Promoting and protecting the health of the public and the environment

September 19, 2012

MICHAEL MCDUGALL
EBERLINE SERVICES OAK RIDGE LAB
601 SCARBORO RD
OAK RIDGE, TENNESSEE 37830

Laboratory I. D. 84013

Dear Michael Mcdougall:

Your amended certificate and associated parameter list(s) are enclosed. These documents now represent the certificate of record for your laboratory. Any certificate(s) and associated parameter list(s) received prior to your receipt of these documents are now null and void and should be destroyed. Please be reminded that all environmental data submitted to the Department is reviewed to ensure that the reporting laboratory possesses the necessary certification. Data reported by laboratories without the proper certification will be addressed by the affected enforcement programs.

If you have any questions, or problems are detected concerning your certificate, please contact this office within ten (10) working days.

Sincerely,

Carol F. Smith, Director
Office of Environmental Laboratory Certification
Bureau of Environmental Services

Enclosures



South Carolina Department of Health
and Environmental Control

Environmental Laboratory Certification Program

In accordance with the provisions of Regulation 61-81, entitled
"State Environmental Laboratory Certification Regulations"

EBERLINE SERVICES OAK RIDGE LAB
601 SCARBORO RD
OAK RIDGE, TENNESSEE 37830

is hereby certified to perform analyses as documented on the attached parameter list(s). This certification does not guarantee validity of data generated, but indicates the laboratory's adherence to prescribed methodology, quality control, records keeping, and reporting procedures. This certificate is the property of S.C. DHEC and must be surrendered upon demand. This certificate is non-transferable and is valid only for the parameters and methodology listed on the attached parameter list(s).

Laboratory Director: MICHAEL MCDOUGALL
Certifying Authority: TN
Date of Issue: September 19, 2012
Date of Expiration: December 15, 2014
Certificate Number: 84013001

Director

Office of Environmental Laboratory Certification

**SOUTH CAROLINA DEPARTMENT OF HEALTH AND ENVIRONMENTAL CONTROL
ENVIRONMENTAL LABORATORY CERTIFICATION PROGRAM**

EBERLINE SERVICES OAK RIDGE LAB (Laboratory ID 84013)
Laboratory Director: MICHAEL MCDOUGALL
Certifying Authority: TN
Certificate Number: 84013001

Date of Issue: September 19, 2012
Expiration Date: December 15, 2014

SAFE DRINKING WATER ACT

INORGANIC - RADIOLOGICAL

GROSS ALPHA	EPA 900.0 (1980)
GROSS BETA	EPA 900.0 (1980)
RADIUM 226	EPA 903.0 (1980)
RADIUM 228	EPA 904.0 (1980)
STRONTIUM 90	EPA 905.0 (1980)
TRITIUM	EPA 906.0 (1980)



State of Tennessee

Department of Environment & Conservation

Division of Water Supply

Certifies That

Eberline Services Laboratory

*Having Met the Requirements of the Regulations for the
Certification of Laboratories Analyzing Drinking Water
is hereby Approved as a*

State Certified Laboratory in Radiochemistry

*To perform the Analyses as Indicated on the Certified Parameter List
For the Public Water Systems of Tennessee*

Laboratory ID Number TN02042 - Effective through December 15, 2014

A handwritten signature in cursive script, reading "A. Craig LaFever".

A. Craig LaFever

Laboratory Certification Manager

Division of Water Supply

*This certification is subject to performance on E.P.A. Performance
Evaluation Samples, laboratory inspections
and payment of annual fees*

Certified Parameters - 2011

TENNESSEE

Eberline Services

TN02042

EPA # TN01067

12/16/2011

Attn: Ahmed Halouma
601 Scarboro Road
Oak Ridge, TN 37830-7371

<u>Parameter</u>	<u>EPA Parameter #</u>	<u>Approved Method</u>	<u>Study Type</u>	<u>Date Complete</u>	<u>PT Provider / WS #</u>	
Radiological						
Cesium-134 (Radioactive)	4270	EPA - 901.1	Proficiency Test	5/19/2011	ERA /	RAD-85
Cesium-137 (Radioactive)	4276	EPA - 901.1	Proficiency Test	5/19/2011	ERA /	RAD-85
Cobalt-60 (Radioactive)	4142	EPA - 901.1	Proficiency Test	5/19/2011	ERA /	RAD-85
Gross Alpha	4000	EPA - 900.0	Proficiency Test	5/19/2011	ERA /	RAD-85
Gross Beta	4100	EPA - 900.0	Proficiency Test	5/19/2011	ERA /	RAD-85
Radium-226	4020	EPA - 903.0	Proficiency Test	5/19/2011	ERA /	RAD-85
Radium-228	4030	EPA - 904.0	Proficiency Test	5/19/2011	ERA /	RAD-85
Strontium 89 (Radioactive)	4172	EPA - 905.0	Proficiency Test	5/19/2011	ERA /	RAD-85
Strontium 90 (Radioactive)	4174	EPA - 905.0	Proficiency Test	5/19/2011	ERA /	RAD-85
Tritium (Radioactive)	4102	EPA - 906.0	Proficiency Test	5/19/2011	ERA /	RAD-85
Uranium (Natural)	4006	EPA - 908.0	Proficiency Test	5/19/2011	ERA /	RAD-85
Uranium (Radioactive)	4400	ASTM - D 5174-02	Proficiency Test	5/19/2011	ERA /	RAD-85



STATE OF TENNESSEE
DEPARTMENT OF ENVIRONMENT AND CONSERVATION
DIVISION OF WATER SUPPLY
6th Floor, L & C TOWER, 401 Church Street
Nashville, Tennessee 37243-1549

December 27, 2011

Mr. Ahmed Halouma, QA Mgr
Eberline Analytical Corporation
601 Scarboro Road
Oak Ridge, TN 37830-7371

Re: Audit Report
Lab # TN02042

Dear Mr. Halouma:

Division of Water Supply personnel visited your laboratory and performed an audit on December 12 and December 13, 2011. We would like to thank you and your staff for your courtesy during the audit.

I. Certification Status

The certification for Radiochemistry analyses shall be valid until December 15, 2015. Continued compliance with the State of Tennessee certification criteria is subject to the USEPA laboratory certification criteria and procedures for quality assurance (*Manual for the Certification of Laboratories Analyzing Drinking Water, Fifth Edition, 2005*).

Eberline Analytical Corporation Laboratory (TN02042) is granted Certification for the Radiochemistry methods and parameters listed on the enclosed Certified parameter list.

II. List of Deviations

No Deviations noted.

III. Remarks

We appreciate the willingness to share detailed explanations of the methodology and quality control. As discussed, please forward us the completed SOPs for Uranium 234 and 238 analysis by alpha spectrometry and the SOPs for Strontium-89 and Strontium-90.

IV. Personnel

<u>Name</u>	<u>Specialty</u>
Michael R. McDougall	Laboratory Manager
Ahmed Halouma	Quality Assurance Manager

If you have any questions please do not hesitate to contact the Laboratory Certification Officers Craig LaFever (615-532-0181) Craig.LaFever@tn.gov or Prasad Subbanna (865-594-5557) Prasad.Subbanna@tn.gov.

Sincerely,



A. Craig LaFever
Laboratory Certification Officer
Tennessee Division of Water Supply

cc: file

Enclosure



NELAP - RECOGNIZED



CALIFORNIA STATE

ENVIRONMENTAL LABORATORY ACCREDITATION PROGRAM BRANCH

CERTIFICATE OF NELAP ACCREDITATION

Is hereby granted to

Eberline Analytical Corporation (EPA# TN01067)

601 Scarboro Road
Oak Ridge, TN 37830

Scope of the Certificate is limited to the
"NELAP Fields of Accreditation"
which accompany this Certificate.

Continued accredited status depends on successful
ongoing participation in the program.


This Certificate is granted in accordance with provisions of
Section 100825, et seq. of the Health and Safety Code.

Certificate No.: **08261CA**

Expiration Date: **7/31/2014**

Effective Date: **8/1/2013**

Richmond, California
subject to forfeiture or revocation


David Mazzer, Ph.D., Assistant Division Chief
Division of Drinking Water and Environmental Management



NELAP RECOGNIZED

CALIFORNIA DEPARTMENT OF PUBLIC HEALTH
ENVIRONMENTAL LABORATORY ACCREDITATION PROGRAM BRANCH
NELAP Fields of Accreditation



Eberline Analytical Corporation (EPA# TN01067)

601 Scarboro Road
Oak Ridge, TN 37830
Phone: (865) 481-0683

Certificate No. 08261CA
Renew Date: 7/31/2014

Primary AA: UT TN010672012-2

106 - Radiochemistry of Drinking Water

106.010	001	EPA 900.0	Gross Alpha
106.010	002	EPA 900.0	Gross Beta
106.030	003	EPA 901.1	Gamma Emitters
106.050	001	EPA 903.0	Total Alpha Radium
106.050	002	EPA 903.0	Radium-226
106.060	001	EPA 904.0	Radium-228
106.070	001	EPA 905.0	Strontium-89, 90
106.070	002	EPA 905.0	Strontium-89
106.070	003	EPA 905.0	Strontium-90
106.080	001	EPA 906.0	Tritium
106.090	001	EPA 908.0	Uranium
106.480	001	ASTM D5174-97	Uranium

112 - Radiochemistry of Wastewater

112.010	001	EPA 900.0	Gross Alpha
112.010	002	EPA 900.0	Gross Beta
112.140	002	EPA 901.1	Gamma
112.160	001	EPA 904.0	Radium-228
112.180	001	EPA 906.0	Tritium
112.190	001	EPA 908.0	Uranium

118 - Radiochemistry of Hazardous Waste

118.010	001	EPA 9310	Gross Alpha
118.010	002	EPA 9310	Gross Beta
118.020	001	EPA 9315	Radium, Total
118.030	001	EPA 9320	Radium-228



State of Louisiana
DEPARTMENT OF ENVIRONMENTAL QUALITY
ENVIRONMENTAL SERVICES

July 1, 2013

LELAP Lab ID # 05005
AI No. 168684
Accreditation Year FY2014
Renewal due FY 2016

Ms. Saba Arnold Seaver
Eberline Services - Oak Ridge Lab
601 Scarboro Rd
Oak Ridge, Tennessee 37830-7371

Re: Scope of Accreditation

Dear Ms. Arnold Seaver:

The Louisiana Department of Environmental Quality's laboratory accreditation program, in accordance with Louisiana Administrative Code, Title 33, Part I, Subpart 3, Laboratory Accreditation, accredits this laboratory for Fiscal Year 2014. This accreditation does not constitute an endorsement of the suitability of the listed methods for any specific purpose. The laboratory is accredited for the method as identified on the application for accreditation; if the method is partially identified on the application for accreditation, the laboratory is accredited for the versions listed on the current application or referenced in the laboratory standard operating procedure.

National Environmental Laboratory Accreditation Program (NELAP) accreditation is granted **only** for those methods/analytes for which "NELAP" is indicated as the type of accreditation. "STATE" is indicated as the type of accreditation for those methods/analytes for which accreditation by the Louisiana Environmental Laboratory Accreditation Program (LELAP) is granted. Accreditation is dependent on the laboratory's successful ongoing compliance with regulations as outlined in the Louisiana Administrative Code, Title 33, Part I, Subpart 3, Laboratory Accreditation, and with the standards adopted by the NELAP Accreditation Council.

The accreditation certificate is the property of the State of Louisiana. Should your accreditation be suspended or revoked, your laboratory must return the certificate of accreditation to the department and delete any electronic copies until your accreditation status is restored.

LAC 33:I.5313.A and/or NELAC 5.5.10.1 require that the laboratory report include all relevant information. Therefore, the certificate number shall be placed in the upper right corner of all laboratory reports. If the test report includes results of any test for which the laboratory is not accredited, the unaccredited results must be clearly identified as such.

Ms. Saba Arnold Seaver
Eberline Services - Oak Ridge Lab
July 1, 2013
Page 2 of 2

We request that you examine the scope of accreditation attachment for accuracy and completeness. If you find that an analyte for which you expected to be accredited is not listed, please examine your records to ensure that:

1. You have met the requirements for successful participation in proficiency test studies as outlined in LAC 33:I.4711 and in the NELAC Standard 2.7.2.
2. In the case of accreditation by recognition, the requested analyte must be listed for the requested method and matrix on both the certificate issued by the Primary Accreditation Body ***and*** on the Louisiana application form.

If after reviewing this information, the scope and/or certificate are inaccurate, please notify us immediately.

If you have any questions, please contact your assigned assessor Dr. Alicia B. Ryan, Environmental Scientist at (225) 219-1352.

Sincerely,



Lourdes Iturralde
Administrator
Notifications and Accreditations Section
OES, Public Participation & Permit Support Services Division

LI:PB:abr



**STATE OF LOUISIANA
DEPARTMENT OF ENVIRONMENTAL QUALITY**

Is hereby granting a Louisiana Environmental Laboratory Accreditation to



**Eberline Services - Oak Ridge Lab
601 Scarboro Rd
Oak Ridge, Tennessee 37830-7371**

Agency Interest No. 168684

According to the Louisiana Administrative Code, Title 33, Part I, Subpart 3, LABORATORY ACCREDITATION, the State of Louisiana formally recognizes that this laboratory is technically competent to perform the environmental analyses listed on the scope of accreditation detailed in the attachment.

The laboratory agrees to perform all analyses listed on this scope of accreditation according to the Part I, Subpart 3 requirements and acknowledges that continued accreditation is dependent on successful ongoing compliance with the applicable requirements of Part I. Please contact the Department of Environmental Quality, Louisiana Environmental Laboratory Accreditation Program (LELAP) to verify the laboratory's scope of accreditation and accreditation status.

Accreditation by the State of Louisiana is not an endorsement or a guarantee of validity of the data generated by the laboratory. To be accredited initially and maintain accreditation, the laboratory agrees to participate in two single-blind, single-concentration PT studies, where available, per year for each field of testing for which it seeks accreditation or maintains accreditation as required in LAC 33:I.4711.

Lourdes Iturralde, Administrator
Notifications and Accreditations Section
Public Participation & Permit Support Services Division

Certificate Number: 05005

**Expiration Date: June 30, 2014
Issued On: July 1, 2013**



STATE OF LOUISIANA
DEPARTMENT OF ENVIRONMENTAL QUALITY
Issue Date: July 1, 2013

Eberline Services - Oak Ridge Lab
AI Number: 168684
Expiration Date: June 30, 2014

601 Scarboro Rd, Oak Ridge, Tennessee 37830-7371

Certificate Number: 05005

Air Emissions

Analyte	Method Name	Method Code	Type	AB
NONE	NONE	NONE	NONE	NONE

Non Potable Water

Analyte	Method Name	Method Code	Type	AB
2830 - Gross-alpha	EPA 900	10112400	NELAP	UT
2840 - Gross-beta	EPA 900	10112400	NELAP	UT
2826 - Gamma Emitters	EPA 901.1	10112808	NELAP	UT
1128 - Radium-223	EPA 903	10113209	NELAP	UT
2960 - Radium-224	EPA 903	10113209	NELAP	UT
2965 - Radium-226	EPA 903	10113209	NELAP	UT
2750 - Total alpha radium	EPA 903	10113209	NELAP	UT
2970 - Radium-228	EPA 904	10113607	NELAP	UT
2995 - Strontium-89	EPA 905	10113801	NELAP	UT
3010 - Strontium-89, 90	EPA 905	10113801	NELAP	UT
3005 - Strontium-90	EPA 905	10113801	NELAP	UT
3030 - Tritium	EPA 906	10114008	NELAP	UT
3035 - Uranium	EPA 908	10114202	NELAP	UT
2830 - Gross-alpha	EPA 9310	10208205	NELAP	UT
2840 - Gross-beta	EPA 9310	10208205	NELAP	UT
100210 - Alpha Emitting Radium Isotopes	EPA 9315	10208409	NELAP	UT
2970 - Radium-228	EPA 9320	10208603	NELAP	UT

Solid Chemical Materials

Analyte	Method Name	Method Code	Type	AB
2830 - Gross-alpha	EPA 9310	10208205	NELAP	UT
2840 - Gross-beta	EPA 9310	10208205	NELAP	UT
100210 - Alpha Emitting Radium Isotopes	EPA 9315	10208409	NELAP	UT
2970 - Radium-228	EPA 9320	10208603	NELAP	UT

Biological Tissue

Analyte	Method Name	Method Code	Type	AB
NONE	NONE	NONE	NONE	NONE

NEW YORK

state department of

HEALTH

Nirav R. Shah, M.D., M.P.H.
Commissioner

Sue Kelly
Executive Deputy Commissioner

LAB ID: 11798

April 01, 2013

MS. MARY L. TURNER
EBERLINE SERVICES-OAK RIDGE LAB
601 SCARBORO ROAD
OAK RIDGE, TN 37830

Certificate Expiration Date:
April 01, 2014

Dear Ms. Turner,

Enclosed are Certificate(s) of Approval issued to your environmental laboratory for the current permit year. The Certificate(s) supersede(s) any previously issued one(s) and is(are) in effect through the expiration date listed. Please carefully examine the Certificate(s) to insure that the categories, subcategories, analytes, and methods for which your laboratory is approved are correct. In addition, verify that your laboratory's name, address, lead technical director, and identification number are accurate.

Pursuant to NYCRR Subpart 55-2.2, original certificates must be posted conspicuously in the laboratory and copies shall be made available to any client of the laboratory upon request.

Pursuant to NYCRR Subpart 55-2.6, any misrepresentation of the Fields of Accreditation (Matrix - Method - Analyte) for which your laboratory is approved may result in denial, suspension, or revocation of your certification. Any use of the Environmental Laboratory Approval Program (ELAP) or National Environmental Laboratory Accreditation Program (NELAP) name, reference to the laboratory's approval status, and/or using the NELAP logo in any catalogs, advertising, business solicitations, proposals, quotations, laboratory analytical reports, or other materials must include the laboratory's ELAP identification number and distinguish between testing for which the laboratory is approved and testing for which the laboratory is not approved.

If you have any questions, please contact ELAP at the New York State Department of Health (NYS DOH), Wadsworth Center, PO Box 509, Albany NY, 12201-0509; by phone at (518) 485-5570; by facsimile at (518) 485-5568; and by email at elap@health.state.ny.us.

Sincerely,



STEPHANIE OSTROWSKI, PH.D.
Program Director
Environmental Laboratory Approval Program

NEW YORK STATE DEPARTMENT OF HEALTH
WADSWORTH CENTER



Expires 12:01 AM April 01, 2014
Issued April 01, 2013

CERTIFICATE OF APPROVAL FOR LABORATORY SERVICE

Issued in accordance with and pursuant to section 502 Public Health Law of New York State

MS. MARY L. TURNER
EBERLINE SERVICES-OAK RIDGE LAB
601 SCARBORO ROAD
OAK RIDGE, TN 37830

NY Lab Id No: 11798

is hereby APPROVED as an Environmental Laboratory in conformance with the
National Environmental Laboratory Accreditation Conference Standards (2003) for the category
ENVIRONMENTAL ANALYSES POTABLE WATER
All approved analytes are listed below:

Drinking Water Metals III

Uranium (Mass) ASTM D5174-97 02 07

Radiological Analytes

Gross Alpha	EPA 900.0
Gross Beta	EPA 900.0
Photon Emitters	EPA 901.1
Radium-226	EPA 903.0
Radium-228	EPA 904.0
Strontium-89	EPA 905.0
Strontium-90	EPA 905.0
Tritium	EPA 906.0
Uranium (Activity)	EPA 908.0

Serial No.: 48873

Property of the New York State Department of Health. Certificates are valid only at the address shown, must be conspicuously posted, and are printed on secure paper. Continued accreditation depends on successful ongoing participation in the Program. Consumers are urged to call (518) 485-5570 to verify the laboratory's accreditation status.



NEW YORK STATE DEPARTMENT OF HEALTH
WADSWORTH CENTER



Expires 12:01 AM April 01, 2014
Issued April 01, 2013

CERTIFICATE OF APPROVAL FOR LABORATORY SERVICE

Issued in accordance with and pursuant to section 502 Public Health Law of New York State

MS. MARY L. TURNER
EBERLINE SERVICES-OAK RIDGE LAB
601 SCARBORO ROAD
OAK RIDGE, TN 37830

NY Lab Id No: 11798

is hereby **APPROVED** as an Environmental Laboratory in conformance with the
National Environmental Laboratory Accreditation Conference Standards (2003) for the category
ENVIRONMENTAL ANALYSES NON POTABLE WATER
All approved analytes are listed below:


Radiological Analytes

Gross Alpha	EPA 900.0
Gross Beta	EPA 900.0
Photon Emitters	EPA 901.1
Radium-226	EPA 903.0
Radium-228	EPA 904.0
Strontium-89	EPA 905.0
Strontium-90	EPA 905.0
Tritium	EPA 906.0
Uranium (Activity)	EPA 908.0

Serial No.: 48874


Property of the New York State Department of Health. Certificates are valid only at the address shown, must be conspicuously posted, and are printed on secure paper. Continued accreditation depends on successful ongoing participation in the Program. Consumers are urged to call (516) 485-5570 to verify the laboratory's accreditation status.





Texas Commission on Environmental Quality

NELAP-Recognized Laboratory Accreditation is hereby awarded to



Eberline Services - Oak Ridge Laboratory

601 Scarboro Road

Oak Ridge, TN 37830-7371

in accordance with Texas Water Code Chapter 5, Subchapter R, Title 30 Texas Administrative Code Chapter 25, and the National Environmental Laboratory Accreditation Program.


The laboratory's scope of accreditation includes the fields of accreditation that accompany this certificate. Continued accreditation depends upon successful ongoing participation in the program. The Texas Commission on Environmental Quality urges customers to verify the laboratory's current location(s) and accreditation status for particular methods and analyses (www.tceq.texas.gov/goto/lab). Accreditation does not imply that a product, process, system or person is approved by the Texas Commission on Environmental Quality.

Certificate Number: T104704443-13-5

Effective Date: 10/1/2013

Expiration Date: 9/30/2014


Executive Director Texas Commission on
Environmental Quality



Texas Commission on Environmental Quality

NELAP - Recognized Laboratory Fields of Accreditation



Eberline Services - Oak Ridge Laboratory

601 Scarboro Road
Oak Ridge, TN 37830-7371

Certificate: T104704443-13-5

Expiration Date: 9/30/2014

Issue Date: 10/1/2013

These fields of accreditation supercede all previous fields. The Texas Commission on Environmental Quality urges customers to verify the laboratory's current accreditation status for particular methods and analyses.

Matrix: *Drinking Water*

Method EPA 900.0

Analyte	AB	Analyte ID	Method ID
Gross-alpha	UT	2830	10112400
Gross-beta	UT	2840	10112400

Method EPA 901.1

Analyte	AB	Analyte ID	Method ID
Gross gamma	UT	2855	10112808
Radioactive cesium	UT	2955	10112808

Method EPA 903.0

Analyte	AB	Analyte ID	Method ID
Radium-226	UT	2965	10113209

Method EPA 904.0

Analyte	AB	Analyte ID	Method ID
Radium-228	UT	2970	10113607

Method EPA 905.0


Analyte	AB	Analyte ID	Method ID
Strontium-89	UT	2995	10113801
Strontium-90	UT	3005	10113801

Method EPA 906.0

Analyte	AB	Analyte ID	Method ID
Tritium	UT	3030	10114008

Method EPA 908.0

Analyte	AB	Analyte ID	Method ID
Uranium	UT	3035	10114202



Texas Commission on Environmental Quality

NELAP - Recognized Laboratory Fields of Accreditation



Eberline Services - Oak Ridge Laboratory

601 Scarboro Road
Oak Ridge, TN 37830-7371

Certificate: T104704443-13-5

Expiration Date: 9/30/2014

Issue Date: 10/1/2013

These fields of accreditation supercede all previous fields. The Texas Commission on Environmental Quality urges customers to verify the laboratory's current accreditation status for particular methods and analyses.

Matrix: *Non-Potable Water*

Method EPA 900.0

Analyte	AB	Analyte ID	Method ID
Gross-alpha	UT	2830	10112400
Gross-beta	UT	2840	10112400

Method EPA 903.0

Analyte	AB	Analyte ID	Method ID
Total radium	UT	2975	10113209

Method EPA 908.0

Analyte	AB	Analyte ID	Method ID
Uranium	UT	3035	10114202



Texas Commission on Environmental Quality

NELAP - Recognized Laboratory Fields of Accreditation



Eberline Services - Oak Ridge Laboratory

601 Scarboro Road
Oak Ridge, TN 37830-7371

Certificate:

T104704443-13-5

Expiration Date:

9/30/2014

Issue Date:

10/1/2013

These fields of accreditation supercede all previous fields. The Texas Commission on Environmental Quality urges customers to verify the laboratory's current accreditation status for particular methods and analyses.

Matrix: Solid & Chemical Materials

Method EPA 9310

Analyte

Gross-alpha

Gross-beta

AB

UT

UT

Analyte ID

2830

2840

Method ID

10208205

10208205

State of Utah

Department of Health

Environmental Laboratory Certification Program

Certification is hereby granted to

Eberline Services - Oak Ridge Laboratory

601 Scarboro Road
Oak Ridge, TN 37830


*Has conformed with the
2009 TNI Standard*

*Scope of accreditation is limited to the
State of Utah Accredited Fields of Accreditation
Which accompanies this Certificate*

EPA Number: TN01067

Expiration Date: 9/30/2014

Certificate Number: TN010672013-3



Robyn M. Atkinson, Ph.D, HCCLD
Director, Utah Public Health Laboratory

Continued accredited status depends on successful ongoing participation in the program.





State of Utah
 Gary R Herbert
 Governor
 Gregory S Bell
 Lieutenant Governor

Utah Department of Health

W. David Patton Ph.D

Executive Director

Division of Disease Control and Prevention

Robyn M. Atkinson, Ph.D, HCLD

Director, Utah Public Health Laboratory



EPA Number: **TN01067**

Attachment to Certificate Number: **TN010672013-3**

Page 1 of 4

Eberline Services - Oak Ridge Laboratory

Start Date Expires AB

Program/Matrix: CWA (Non Potable Water)

Method EPA 900

Gross-alpha	10/1/2013	9/30/2014	UT
Gross-beta	10/1/2013	9/30/2014	UT

Method EPA 901.1

Cesium-134	10/1/2013	9/30/2014	UT
Cesium-137	10/1/2013	9/30/2014	UT
Gamma Emitters	10/1/2013	9/30/2014	UT

Method EPA 903

Radium-223	10/1/2013	9/30/2014	UT
Radium-224	10/1/2013	9/30/2014	UT
Radium-226	10/1/2013	9/30/2014	UT

Method EPA 904

Radium-228	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Method EPA 905

Strontium-89	10/1/2013	9/30/2014	UT
Strontium-89, 90	10/1/2013	9/30/2014	UT
Strontium-90	10/1/2013	9/30/2014	UT

Method EPA 906.0

Tritium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Method EPA 908

Uranium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Eberline Services - Oak Ridge Laboratory

Start Date

Expires

AB

Program/Matrix: RCRA (Non Potable Water)**Method EPA 9310**

Gross alpha-beta

10/1/2013 9/30/2014 UT

Method EPA 9315

Total alpha radium

10/1/2013 9/30/2014 UT

Method EPA 9320

Radium-228

10/1/2013 9/30/2014 UT

Eberline Services - Oak Ridge Laboratory

Start Date Expires

AB

Program/Matrix: RCRA (Solid & Hazardous Material)**Method EPA 9310**

Gross alpha-beta

10/1/2013 9/30/2014 UT

Method EPA 9315

Total alpha radium

10/1/2013 9/30/2014 UT

Method EPA 9320

Radium-228

10/1/2013 9/30/2014 UT

Eberline Services - Oak Ridge Laboratory

Start Date	Expires	AB
------------	---------	----

Program/Matrix: SDWA (Potable Water)**Method ASTM D5174-02**

Uranium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Method EPA 00- 02

Gross-alpha	10/1/2013	9/30/2014	UT
-------------	-----------	-----------	----

Method EPA 900.0

Gross-alpha	10/1/2013	9/30/2014	UT
-------------	-----------	-----------	----

Gross-beta	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Method EPA 901.1

Cesium-134	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Gamma Emitters	10/1/2013	9/30/2014	UT
----------------	-----------	-----------	----

Iodine-131	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Method EPA 903

Radium-223	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Radium-224	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Radium-226	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Total radium	10/1/2013	9/30/2014	UT
--------------	-----------	-----------	----

Method EPA 904

Radium-228	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Method EPA 905

Strontium	10/1/2013	9/30/2014	UT
-----------	-----------	-----------	----

Strontium-89	10/1/2013	9/30/2014	UT
--------------	-----------	-----------	----

Strontium-90	10/1/2013	9/30/2014	UT
--------------	-----------	-----------	----

Method EPA 906

Tritium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Method EPA 907.0

Americium-241	10/1/2013	9/30/2014	UT
---------------	-----------	-----------	----

Curium-242	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Curium-243	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Curium-244	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Neptunium-237	10/1/2013	9/30/2014	UT
---------------	-----------	-----------	----

Plutonium-238	10/1/2013	9/30/2014	UT
---------------	-----------	-----------	----

Plutonium-239	10/1/2013	9/30/2014	UT
---------------	-----------	-----------	----

Plutonium-240	10/1/2013	9/30/2014	UT
---------------	-----------	-----------	----

Thorium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Uranium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Method EPA 908

Uranium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.

The analytes by method which a laboratory is authorized to perform at any given time will be those indicated in the most recent certificate letter. The most recent certification letter supersedes all previous certification or authorization letters. It is the certified laboratory's responsibility to review this letter for discrepancies. The certified laboratory must document any discrepancies in this letter and send notice to this bureau within 15 days of receipt. This certificate letter will be recalled in the event your laboratory's certification is revoked.



State of Utah
 Gary R Herbert
Governor
 Gregory S Bell
Lieutenant Governor

Utah Department of Health

W. David Patton Ph.D

Executive Director

Division of Disease Control and Prevention

Robyn M. Atkinson, Ph.D, HCLD

Director, Utah Public Health Laboratory



EPA Number: TN01067

Attachment to Certificate Number: TN010672013-3

Page 1 of 4

Eberline Services - Oak Ridge Laboratory

Start Date Expires AB

Program/Matrix: CWA (Non Potable Water)

Method EPA 900

Gross-alpha	10/1/2013	9/30/2014	UT
Gross-beta	10/1/2013	9/30/2014	UT

Method EPA 901.1

Cesium-134	10/1/2013	9/30/2014	UT
Cesium-137	10/1/2013	9/30/2014	UT
Gamma Emitters	10/1/2013	9/30/2014	UT

Method EPA 903

Radium-223	10/1/2013	9/30/2014	UT
Radium-224	10/1/2013	9/30/2014	UT
Radium-226	10/1/2013	9/30/2014	UT

Method EPA 904

Radium-228	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Method EPA 905

Strontium-89	10/1/2013	9/30/2014	UT
Strontium-89, 90	10/1/2013	9/30/2014	UT
Strontium-90	10/1/2013	9/30/2014	UT

Method EPA 906.0

Tritium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Method EPA 908

Uranium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Eberline Services - Oak Ridge Laboratory

Start Date	Expires	AB
------------	---------	----

Program/Matrix: RCRA (Non Potable Water)**Method EPA 9310**

Gross alpha-beta

10/1/2013	9/30/2014	UT
-----------	-----------	----

Method EPA 9315

Total alpha radium

10/1/2013	9/30/2014	UT
-----------	-----------	----

Method EPA 9320

Radium-228

10/1/2013	9/30/2014	UT
-----------	-----------	----

Eberline Services - Oak Ridge Laboratory

Start Date	Expires	AB
------------	---------	----

Program/Matrix: RCRA (Solid & Hazardous Material)**Method EPA 9310**

Gross alpha-beta

10/1/2013	9/30/2014	UT
-----------	-----------	----

Method EPA 9315

Total alpha radium

10/1/2013	9/30/2014	UT
-----------	-----------	----

Method EPA 9320

Radium-228

10/1/2013	9/30/2014	UT
-----------	-----------	----

Eberline Services - Oak Ridge Laboratory

Start Date	Expires	AB
------------	---------	----

Program/Matrix: SDWA (Potable Water)**Method ASTM D5174-02**

Uranium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Method EPA 00- 02

Gross-alpha	10/1/2013	9/30/2014	UT
-------------	-----------	-----------	----

Method EPA 900.0

Gross-alpha	10/1/2013	9/30/2014	UT
-------------	-----------	-----------	----

Gross-beta	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Method EPA 901.1

Cesium-134	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Gamma Emitters	10/1/2013	9/30/2014	UT
----------------	-----------	-----------	----

Iodine-131	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Method EPA 903

Radium-223	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Radium-224	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Radium-226	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Total radium	10/1/2013	9/30/2014	UT
--------------	-----------	-----------	----

Method EPA 904

Radium-228	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Method EPA 905

Strontium	10/1/2013	9/30/2014	UT
-----------	-----------	-----------	----

Strontium-89	10/1/2013	9/30/2014	UT
--------------	-----------	-----------	----

Strontium-90	10/1/2013	9/30/2014	UT
--------------	-----------	-----------	----

Method EPA 906

Tritium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Method EPA 907.0

Americium-241	10/1/2013	9/30/2014	UT
---------------	-----------	-----------	----

Curium-242	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Curium-243	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Curium-244	10/1/2013	9/30/2014	UT
------------	-----------	-----------	----

Neptunium-237	10/1/2013	9/30/2014	UT
---------------	-----------	-----------	----

Plutonium-238	10/1/2013	9/30/2014	UT
---------------	-----------	-----------	----

Plutonium-239	10/1/2013	9/30/2014	UT
---------------	-----------	-----------	----

Plutonium-240	10/1/2013	9/30/2014	UT
---------------	-----------	-----------	----

Thorium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Uranium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

Method EPA 908

Uranium	10/1/2013	9/30/2014	UT
---------	-----------	-----------	----

The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.

The analytes by method which a laboratory is authorized to perform at any given time will be those indicated in the most recent certificate letter. The most recent certification letter supersedes all previous certification or authorization letters. It is the certified laboratory's responsibility to review this letter for discrepancies. The certified laboratory must document any discrepancies in this letter and send notice to this bureau within 15 days of receipt. This certificate letter will be recalled in the event your laboratory's certification is revoked.



COMMONWEALTH of VIRGINIA

Department of General Services

Division of Consolidated Laboratory Services

*600 North 5th Street
Richmond, Virginia 23219-3691
(804) 648-4480
FAX (804) 692-0416*

12/10/2013

Michael R Mcdougall
EBERLINE SERVICES OAK RIDGE LABORATORY
601 Scarboro Road
Oak Ridge TN 37830

VELAP ID: 460218

Dear Michael R Mcdougall:

EBERLINE SERVICES OAK RIDGE LABORATORY has been granted secondary accreditation pursuant to the provisions of 1VAC30-46 and the National Environmental Laboratory Accreditation Program (NELAP) by the Division of Consolidated Laboratory Services (DCLS). Enclosed please find Certificate 2544 and the corresponding Scope of Accreditation which are valid until 12/14/2014. The certificate must be conspicuously displayed in the laboratory along with the associated Scope of Accreditation.

Your laboratory is required to notify the DCLS Virginia Environmental Laboratory Accreditation Program (VELAP) in writing of any changes in key accreditation criteria within 30 calendar days of the change per 1VAC30-46-90 A. This requirement includes changes in ownership, location, key personnel, and major instrumentation.

If your laboratory wishes to change its scope of accreditation an application must be submitted in accordance with the provisions of 1VAC30-46-90 B. These changes are subject to fees as outlined in 1VAC30-46-150 F 1.

Additionally, a laboratory holding secondary accreditation with DCLS is responsible for assuring that DCLS has current information regarding the laboratory's primary accreditation. Upon any change in the status of any field of accreditation, a secondary laboratory must notify DCLS of the exact nature of the change and provide a copy of the laboratory's new primary certificate.

If you have any questions, please contact the VELAP program office at (804)648-4480.

Sincerely yours,

A handwritten signature in black ink, appearing to read 'Cathy Westerman', with a long horizontal line extending to the right.

Cathy Westerman

Manager, Virginia Environmental Laboratory Accreditation Program

Enclosures



COMMONWEALTH OF VIRGINIA
DEPARTMENT OF GENERAL SERVICES
DIVISION OF CONSOLIDATED LABORATORY SERVICES



Certifies that

VA Laboratory ID#: 460218
EBERLINE SERVICES OAK RIDGE LABORATORY

601 SCARBORO ROAD
OAK RIDGE, TN 37830

Owner: GLENROSE INSTRUMENT INC, DR. SHELTON CLARK - PRESIDENT
Operator: EBERLINE SERVICES - OAK RIDGE LABORATORY
Responsible Official: MICHAEL R MCDUGALL

Having met the requirements of 1 VAC 30-46
and the National Environmental Laboratory Accreditation Conference 2003 Standard
is hereby approved as an

Accredited Laboratory

As more fully described in the attached Scope of Accreditation

Effective Date: **December 15, 2013**
Expiration Date: **December 14, 2014**
Certificate # 2544

Continued accreditation status depends on successful ongoing participation in the program.
Certificate to be conspicuously displayed at the laboratory.
Not valid unless accompanied by a valid Virginia Environmental Laboratory Accreditation Program (VELAP)
Scope of Accreditation.
Customers are urged to verify the laboratory's current accreditation status.

Certificate Not Transferable

Thomas L. York, Ph.D., HCLD
DGS Deputy Director for Laboratories

Surrender Upon Revocation



Commonwealth of Virginia
Department of General Services
Division of Consolidated Laboratory Services



Scope of Accreditation

VELAP Certificate No.: 2544

EBERLINE SERVICES OAK RIDGE LABORATORY
601 SCARBORO ROAD
OAK RIDGE, TN 37830

Virginia Laboratory ID: 460218
Effective Date: December 15, 2013
Expiration Date: December 14, 2014

DRINKING WATER

<u>METHOD</u>	<u>ANALYTE</u>	<u>PRIMARY</u>	<u>METHOD</u>	<u>ANALYTE</u>	<u>PRIMARY</u>
EPA 900.0 1980	GROSS ALPHA	UT	EPA 900.0 1980	GROSS BETA	UT
EPA 901.1	CESIUM-134	UT	EPA 901.1	GAMMA EMITTERS	UT
EPA 903.0	RADIUM-226	UT	EPA 903.0	TOTAL ALPHA RADIUM	UT
EPA 904.0	RADIUM-228	UT	EPA 905.0 1980	STRONTIUM-89	UT
EPA 905.0 1980	STRONTIUM-90	UT	EPA 906.0	TRITIUM	UT
EPA 908.0	URANIUM	UT			

NON-POTABLE WATER

<u>METHOD</u>	<u>ANALYTE</u>	<u>PRIMARY</u>	<u>METHOD</u>	<u>ANALYTE</u>	<u>PRIMARY</u>
EPA 900.0 1980	GROSS ALPHA	UT	EPA 900.0 1980	GROSS BETA	UT
EPA 901.1	GAMMA EMITTERS	UT	EPA 903.0	RADIUM-226	UT
EPA 904.0	RADIUM-228	UT	EPA 905.0 1980	STRONTIUM-89	UT
EPA 905.0 1980	STRONTIUM-90	UT	EPA 906.0	TRITIUM	UT
EPA 908.0	URANIUM	UT	EPA 9310 (9/86)	GROSS ALPHA	UT
EPA 9310 (9/86)	GROSS BETA	UT	EPA 9315 (9/86)	TOTAL ALPHA RADIUM	UT
EPA 9320 (9/86)	RADIUM-228	UT			

The State of
Department



Washington
of Ecology

Eberline Services - Oak Ridge Lab
Oak Ridge, TN

has complied with provisions set forth in Chapter 173-50 WAC and is hereby recognized by the Department of Ecology as an ACCREDITED LABORATORY for the analytical parameters listed on the accompanying Scope of Accreditation. This certificate is effective June 15, 2013 and shall expire June 14, 2014.

Witnessed under my hand on June 20, 2013

Alan D. Rue
Lab Accreditation Unit Supervisor

Laboratory ID
C887

WASHINGTON STATE DEPARTMENT OF ECOLOGY

ENVIRONMENTAL LABORATORY ACCREDITATION PROGRAM

SCOPE OF ACCREDITATION

Eberline Services - Oak Ridge Lab

Oak Ridge, TN

is accredited for the analytes listed below using the methods indicated. Full accreditation is granted unless stated otherwise in a note. Accreditation for U.S. Environmental Protection Agency (EPA) "Test Methods for Evaluating Solid Waste, Physical/Chemical Methods" (SW-846) is for the latest version of the method. SM refers to EPA approved editions of "Standard Methods for the Examination of Water and Wastewater." ASTM is the American Society for Testing and Materials. Other references are described in notes.

Matrix/Analyte	Method	Notes
Drinking Water		
Gross Alpha	EPA 900.0-80	1
Gross Beta	EPA 900.0-80	1
Gamma Emitters	EPA 901.1-80	1
Radium-226	EPA 903.0-80	1
Radium-228	EPA 904.0-80	1
Strontium-90	EPA 905.0-80	1
Tritium	EPA 906.0-80	1
Total Uranium	EPA 908.0-80	1
Non-Potable Water		
Gross Alpha	EPA 900.0-80	1
Gross Beta	EPA 900.0-80	1
Gamma Emitters	EPA 901.1-80	1
Radium-226	EPA 903.0-80	1
Radium-228	EPA 904.0-80	1
Strontium-90	EPA 905.0-80	1
Tritium	EPA 906.0-80	1
Total Uranium	EPA 908.0-80	1
Solid and Chemical Materials		
Gross Alpha	EPA 9310_(9/86)	1
Gross Beta	EPA 9310_(9/86)	1
Radium-226	EPA 9315_(9/86)	1

Eberline Services - Oak Ridge Lab

Matrix/Analyte	Method	Notes
Radium-228	EPA 9320_(9/86)	1

Accredited Parameter Note Detail

(1) Accreditation based in part on recognition of Utah NELAP accreditation.



Authentication Signature
Alan D. Rue, Lab Accreditation Unit Supervisor

06/20/2013

Date

The Alabama Department of Environmental Management

certifies that

Eberline Services Laboratory

Having met Department laboratory certification criteria, is approved to conduct Drinking
Water analyses for the following:

Radionuclides

Effective January 1, 2014 through December 31, 2014



Alabama Department of Environmental Management

Laboratory Number 41620

QA/QC RECEIVED

DATE 1/23/14 BY J. M. ST

Eberline Services Laboratory
Expires December 31, 2014

Analyte	Method
Gross Alpha	900.0
Gross Beta	900.0
Radium-226	903.0
Radium-228	904.0
Strontium-89	905.0
Strontium-90	905.0
Tritium	906.0
Uranium	908.0
Uranium	ASTM-D 5174-02

NEW YORK

state department of

HEALTH

Nirav R. Shah, M.D., M.P.H.
Commissioner

Sue Kelly
Executive Deputy Commissioner

LAB ID: 11798

April 01, 2014

MS. MARY L. TURNER
EBERLINE SERVICES-OAK RIDGE LAB
601 SCARBORO ROAD
OAK RIDGE, TN 37830

Certificate Expiration Date:
April 01, 2015

Dear Ms. Turner,

Enclosed are Certificate(s) of Approval issued to your environmental laboratory for the current permit year. The Certificate(s) supersede(s) any previously issued one(s) and is(are) in effect through the expiration date listed. Please carefully examine the Certificate(s) to insure that the categories, subcategories, analytes, and methods for which your laboratory is approved are correct. In addition, verify that your laboratory's name, address, lead technical director, and identification number are accurate.

Pursuant to NYCRR Subpart 55-2.2, original certificates must be posted conspicuously in the laboratory and copies shall be made available to any client of the laboratory upon request.

Pursuant to NYCRR Subpart 55-2.6, any misrepresentation of the Fields of Accreditation (Matrix - Method - Analyte) for which your laboratory is approved may result in denial, suspension, or revocation of your certification. Any use of the Environmental Laboratory Approval Program (ELAP) or National Environmental Laboratory Accreditation Program (NELAP) name, reference to the laboratory's approval status, and/or using the NELAP logo in any catalogs, advertising, business solicitations, proposals, quotations, laboratory analytical reports, or other materials must include the laboratory's ELAP identification number and distinguish between testing for which the laboratory is approved and testing for which the laboratory is not approved.

If you have any questions, please contact ELAP at the New York State Department of Health (NYS DOH), Wadsworth Center, PO Box 509, Albany NY, 12201-0509; by phone at (518) 485-5570; by facsimile at (518) 485-5568; and by email at elap@health.state.ny.us.

Sincerely,



STEPHANIE OSTROWSKI, PH.D.
Program Director
Environmental Laboratory Approval Program

NEW YORK STATE DEPARTMENT OF HEALTH
WADSWORTH CENTER



Expires 12:01 AM April 01, 2015
Issued April 01, 2014

CERTIFICATE OF APPROVAL FOR LABORATORY SERVICE

Issued in accordance with and pursuant to section 502 Public Health Law of New York State

MS. MARY L. TURNER
EBERLINE SERVICES-OAK RIDGE LAB
601 SCARBORO ROAD
OAK RIDGE, TN 37830

NY Lab Id No: 11798

is hereby APPROVED as an Environmental Laboratory in conformance with the
National Environmental Laboratory Accreditation Conference Standards (2003) for the category
ENVIRONMENTAL ANALYSES NON POTABLE WATER


All approved analytes are listed below:

Radiological Analytes

Gross Alpha	EPA 900.0
Gross Beta	EPA 900.0
Photon Emitters	EPA 901.1
Radium-226	EPA 903.0
Radium-228	EPA 904.0
Strontium-89	EPA 905.0
Strontium-90	EPA 905.0
Tritium	EPA 906.0
Uranium (Activity)	EPA 908.0

Serial No.: 50856

Property of the New York State Department of Health. Certificates are valid only at the address shown, must be conspicuously posted, and are printed on secure paper. Continued accreditation depends on successful ongoing participation in the Program. Consumers are urged to call (518) 485-5570 to verify the laboratory's accreditation status.



NEW YORK STATE DEPARTMENT OF HEALTH
WADSWORTH CENTER



Expires 12:01 AM April 01, 2015
Issued April 01, 2014

CERTIFICATE OF APPROVAL FOR LABORATORY SERVICE

Issued in accordance with and pursuant to section 502 Public Health Law of New York State

MS. MARY L. TURNER
EBERLINE SERVICES-OAK RIDGE LAB
601 SCARBORO ROAD
OAK RIDGE, TN 37830

NY Lab Id No: 11798

is hereby APPROVED as an Environmental Laboratory in conformance with the
National Environmental Laboratory Accreditation Conference Standards (2003) for the category
ENVIRONMENTAL ANALYSES POTABLE WATER
All approved analytes are listed below:

Drinking Water Metals III

Uranium (Mass) ASTM D5174-97 02 07

Radiological Analytes

Gross Alpha	EPA 900.0
Gross Beta	EPA 900.0
Photon Emitters	EPA 901.1
Radium-226	EPA 903.0
Radium-228	EPA 904.0
Strontium-89	EPA 905.0
Strontium-90	EPA 905.0
Tritium	EPA 906.0
Uranium (Activity)	EPA 908.0

Serial No.: 50855

Property of the New York State Department of Health. Certificates are valid only at the address shown, must be conspicuously posted, and are printed on secure paper. Continued accreditation depends on successful ongoing participation in the Program. Consumers are urged to call (518) 485-5570 to verify the laboratory's accreditation status.

