

Ballast Water Management System

Application for AMS determination and US Type Approval

PROPRIETARY INFORMATION

This document includes proprietary and confidential information which is to be maintained in strict confidence.

PROPERTY OF AQUA Eng. Co., Ltd. BUSAN, KOREA

Reproduction, use or disclosure without express authorization is prohibited.



GENERAL DISCLAIMER

AQUA Eng. Co., Ltd. reserves all rights to the copyright for AquaStar™ BWMS. All information presented in this document must don't change without the approval of AQUA Eng. Co., Ltd. Also, all parts or sections of this document must be not reproduced and transmitted in any formations by any objectives without the approval of AQUA Eng. Co., Ltd.

Model	Treatment rated capacity (m ³ /hr)	
AquaStar™ BWMS H-200	200	
AquaStar [™] BWMS H-200S/H-200S-Ex ¹	350	
AquaStar™ BWMS H-250	500	
AquaStar™ BWMS H-300/H-300-Ex	800	
AquaStar™ BWMS H-350/H-350-Ex	1,100	
AquaStar™ BWMS H-450	1,800	
AquaStar™ BWMS H-550	2,600	
AquaStar™ BWMS H-650/H-650-Ex	3,000	
AquaStar™ BWMS H-700	4,000	
AquaStar™ BWMS H-750	5,000	

¹ Explosion-proof type

Type Approval Certificate of BWMS from Republic of Korea

AQUA Eng. Co., Ltd.			
Address	#2-62,Sandan-4-ro, Jeonggwan-myeon, Gijang-gun, Busan, Korea		
Telephone	+82-51-728-1270~2		
Facsimile	+82-51-728-1273		
Homepage	www.aquaeng.kr		

WRI	WRITTEN BY REVIEWED BY		APPROVED BY		
DIVISION	RRD conter	DIVISION	RED Certer	DIVISION	GE0
NAME	Chungil kim	NAME	Lee, gh	NAME	2004
SIGN	Je Kily	SIGN	0/2/2	SIGN	Q65
DATE	13.5.8	DATE	13.5.6	DATE	13. 5.8

¹⁴ Models = 10 Standard models + 4 Explosion-proof models

ABBREVIATION LIST

	REVIATION	FULL NAME	
Α	AAV	Auto Air Vent	
	AB	Air Blower	
	AC	Alternating Current	
	AMS	Alternate Management System	
	AS	Active Substances	
	ASS	Air Supply System	
	AV	Air Ventury	
В	BP	Ballast Pump	
	BR	Bus Rod	
	ВТ	Ballast Tank	
	BWMS	Ballast Water Management System	
С	CL2D	Chlorine gas Detector	
	CM	Conductivity Meter	
	СОС	Cargo Oil Control (=Deck office)	
	CRO	Combined Residual Oxidants	
	CSU	Control System Unit	
D	DC	Direct Current	
	DPD	N,N-Diethyl-P-Phenylenediamine	
E	EL	Electrolyzer Unit	
	Ex	Explosion-proof type	
F	FRO	Free Residual Oxidants	
	FS	Flow Switch	
	FWSS	Fresh Water Supply System	
G	GS	Gas Separator Unit	
Н	H2D	Hydrogen gas Detector	
I	IGBT	Insulated Gate Bipolar Transistor	
	IMO	International Maritime Organization	
L	LCP	Local Control Panel	
	LEL	Lower Explosion Limit	
	LG	Level Gauge	

	LT	Level Transmitter
М	МСР	Master Control Panel
	MFM	Main Flow Meter
	MLTM	Ministry of Land, Transport and Maritime Affairs
	MSBD	Main Switch Board
N	NAP	Neutralizing Agent Pump
	NCP	Neutralizer Control Panel
	NIP	Neutralization Injection Port Unit
	NSPP	Neutralization Sampling Port Unit
	NTP	Neutralizing Transfer Pump
	NT	Neutralizing agent storage tank
	NU	Neutralization Unit
P	PID	Proportional/Integral/Differential
	P&ID	Piping and Instrument Diagram
	PI	Pressure Indicator
	PFD	Process Flow Diagram
	PLC	Programmable Logic Control
	PSU	Practical Salinity Unit
	PT	Pressure Transmitter
	PTS	Pressure Transmitter Set
	PWD	Power Distributor
R	RCP	Rectifier Control Panel
S	SCR	Silicon Controlled Rectifier
	SIP	Sampling with Injection Port Unit
	SP	Smart Pipe Unit
	SPP	Sampling Port Unit
Т	TBS	Thermal Bimetal Switch
	TRO	Total Residual Oxidants
		TRO_1: ballasting/TRO_2: in-tank/TRO_3: de-ballasting
	TT	Temperature Transmitter
U	USCG	United States Coast Guard



Contents

1. Introduction

2. System Description

- 2.1. General
- 2.2. Control system
- 2.3. Main components
- 2.4. Pre-start check list
- 2.5. Operation procedure
- 2.6. Emergency operation

3. Application of AMS and US Type Approval

- 3.1. Authority information for foreign Type Approval
- 3.2. Evaluation of existing data and Type Approval requirements
- 3.3. AMS review checklist

APPENDICES

Data or information related to application of AMS determination and US Type Approval

Appendix A. Type Approval certificate for BWMS

- A-1. Type Approval certificate for standard model of AquaStarTM BWMS_Republic of Korea
- A-2. Type Approval certificate for Ex-model of AquaStarTM BWMS_Republic of Korea

Appendix B. Drawing Package

Appendix C. Operation Manual

Page Number: 5 / 106

Application for AMS determination and US Type Approval

Contents

- C-1. Operation Manual
- C-2. Operation program user's manual
- C-3. Data logging
- C-4. Drawing for maintenance of BWMS

Appendix D. Land-based test

- D-1. Certificate of Land-based test
- D-2. P&ID
- D-3. Tank specifications
- D-4. Sampling port
- D-5. Operation data
- D-6. Augmentation facility
- D-7. Washing check list

Appendix E. Environmental test

- E-1. Certificate of Environmental test_H-300
- E-2. Certificate of Environmental test_H-650
- E-3. Certificate of Environmental test_sensors

Appendix F. Shipboard test

- F-1. Certificate of Shipboard test
- F-2. Volume and location of uptake & discharge
- F-3. Operation data

Page Number: 6 / 106

F-4. Check list of maintenance

Appendix G. MEPC documents

- G-1. 19th GESAMP (MEPC63-2-11)
- G-2. Application for Basic Approval (MEPC61-2-1)
- G-3. Application for Final Approval (MEPC63-2-3)

Appendix H. Calibration Procedure

Appendix I. QMP and QAPP for tests

- I-1. QMP and QAPP of Land-based test
- I-2. QMP and QAPP of Shipboard test



1. Information

1. Information

Page Number: 7 / 106

The transportation of ballast water on the oceans amounts to 10 billion tons per year, and aquatic organisms more than 7,000 individuals are unavoidably transported. Non-indigenous aquatic species of animals, plants, and bacteria have been introduced into new environments through discharge of ballast water with severe impact on native ecosystems. In 2004, IMO adopted "the International Convention for the Control and Management of Ship's Ballast Water and Sediments" and prepared a quality standard for discharge of ballast water. In 2009, USCG published a notice of proposed rulemaking entitled "Standards for Living Organisms in Ship's Ballast Water Discharged in US Waters" in the Federal Register.

Ballast water treatment technologies (filtration, ultraviolet, ozone and electrolysis etc.) had developed and are developing all over the world until now.

AquaStarTM BWMS developed by AQUA Eng. Co., Ltd. (website: www.aquaeng.kr) is the electrolytic system. In AquaStarTM BWMS, TRO (including AS) is produced in-situ by electrolyzing the natural seawater and brackish water. AquaStarTM BWMS is composed of SP, EL, NU and CSU. The design of these components is very simple, and these components would be easy to directly install the main ballast pipe line. AquaStarTM BWMS that is directly set up a ballast line of a ship is working more efficiently and economically than general disinfection equipment. The aim of AquaStarTM BWMS is that harmful aquatic organisms in the ballast water are simply treated.

2.1. General

Specification of AquaStar™ BWMS

Division	Division Specification		
Model	H-200 ~ H-750		
Flow rate	200 ~ 5,000 m ³ /h		
Electrolyzer system unit			
Power consumption	12 ~ 400 kW (10 mg/L as Cl ₂)		
TRO concentration	$8 \sim 10$ mg/L as Cl_2		
Operation performance	Less than 10 mg/L as Cl ₂		
Neutralization system unit			
Neutralizing performance	Less than 0.2 mg/L as Cl ₂		
Neutralizing agent	Sodium thiosulfate (Na ₂ S ₂ O ₃ ·5H ₂ O)		
CSU			
Control method	Dual control system / Automatic operation		
Installation location	MCP (COC) / LCP (Engine room)		
Display	LCD, Touch screen, Graphical user interface		
Others			
Allowable operating salinity	More than 10 PSU		
Designed pressure	5 kg/cm ² (Test pressure: Max. 7.5 kg/cm ²)		

2.1.1. System boundary

Main components of AquaStarTM BWMS are composed of SP, EL, NU and CSU.


SP and EL installed in ballasting process line is used to disinfect.

NU installed in de-ballasting process line is used to discharge treated water similar to TRO concentration of the natural seawater.

CSU is possible to automatically or manually control and store or monitor the operation data of AquaStar[™] BWMS. The overall diagram of AquaStar[™] BWMS is shown in a below figure.

During ballasting, equipment operated in AquaStar™ BWMS : SP and EL

During de-ballasting, equipment operated in AquaStar™ BWMS : NU




Page Number: 10 / 106

2.1.1.1. Ballasting process

Ballasting process of AquaStar[™] BWMS is measured TRO value generated by EL. If the initial target TRO value set at CSU differs in a measured TRO value, the current of rectifier by CSU is controlled to maintain the target TRO value.

During ballasting process, in the first step, SP is removing and weakening most aquatic organisms larger than 50 µm in the ballast water and is increasing the disinfectant efficiency of electrolysis. In the second step, harmful aquatic organisms are disinfected by TRO generated EL with seawater or brackish water.




2.1.1.2. De-ballasting process

De-ballasting process of AquaStar[™] BWMS is as follows; Before de-ballasting the treated water in BT,

- 1) TRO value of treated water is measured by TRO sensor.
- 2) The measured value of TRO is transferred to CSU.
- 3) Numerical calculation related to neutralization is conducted by PLC stored at CSU.
- 4) Then, CSU determines the suitable flow rate of NAP.

* In case of no measured TRO concentration of treated water in BT before deballasting, the default value of TRO concentration supplied AQUA Eng. Co., Ltd. should be used.

During de-ballasting process, Neutralization system unit of AquaStarTM BWMS is removed TRO of treated water, and then treated water similar to TRO of natural seawater is discharging (< 0.2 mg/L as Cl_2).



2.1.2. Principle of the system

2.1.2.1. Principle of electrolysis in seawater

AS act to disinfect viable organisms in ballast water. In AquaStar™ BWMS, AS are produced in-situ by electrolysis of natural seawater. During electrolysis of seawater, NaOCl is formed by the reaction with Cl₂ produced at the anode and NaOH produced at the cathode. Also, a part of Cl₂ dissolves immediately into H₂O to produce HOCl/OCl⁻ which exists in equilibrium in the seawater. And some portion of HOCl reacts with bromine ion in seawater and generates HOBr/OBr⁻ in equilibrium in the seawater. These compounds are FRO. Chloramines and bromamines are also produced by the electrolytic process and are here referred to as CRO. FRO and CRO together are referred to as TRO. All TRO compounds may have disinfectant effects; hence they are here regarded as AS.

During electrolysis of seawater, NaOCl is formed by the reaction to Cl_2 produced at the anode and NaOH produced at the cathode (reaction 5). Also, Cl_2 reacts immediately with H_2O to produce HOCl (reactions 6).

At the anode, both H_2O and Cl^- are oxidized to produce O_2 (reaction 1) and Cl_2 (reaction 2), respectively.

```
(reaction 1) 2H_2O \rightarrow O_2 + 4H^+ + 4e^-
(reaction 2) 2Cl^- \rightarrow Cl_2 + 2e^-
```

At the cathode, NaOH and H₂ are formed according to reaction 3.

(reaction 3)
$$2H_2O + 2Na^+ + 2e^- \rightarrow 2NaOH + H_2$$

The overall reaction of the seawater electrolysis is described in the reaction 4.

(reaction 4)
$$2NaCl (2Na^+ + 2Cl^-) + 2H_2O \rightarrow 2Na^+ + 2OH^- + Cl_2 + H_2$$

NaOCl is formed by the reaction to Cl_2 produced at the anode and NaOH produced at the cathode (reaction 5).

(reaction 5)
$$Cl_2 + NaOH \rightarrow NaOCI + H^+ + Cl^-$$

Page Number: 12 / 106



Simultaneously with reaction 5, Cl_2 formed at the anode reacts immediately with H_2O to form HOCl according to reaction 6.

(reaction 6)
$$Cl_2 + H_2O \rightarrow HOCl + H^+ + Cl^-$$

HOCl dissociates to OCl⁻ and H⁺ in the bulk solution reaction 7; dissociation depends on several factors, mainly pH.

The disinfecting effect of hypochlorous acid and hypochlorite is due to the release of atomic oxygen which is highly reactive, according to reaction 8 and 9, respectively.

(reaction 8)
$$HOCI \rightarrow O + CI^{-} + H^{+}$$

(reaction 9) $OCI^{-} \rightarrow O + CI^{-}$

Natural seawater contains approximately $60 \sim 70$ mg/L of Br, existing as Br⁻. Under alkaline conditions, Br⁻ also is oxidized by HOCl to HOBr according to the following reaction 10.

HOBr dissociates in water in a similar reaction to HOCl (reaction 11), and also acts as an effective disinfectant.

Page Number: 14 / 106

2.1.2.2. Principle of neutralization

During de-ballasting, the treated water is neutralized to keep below 0.2 mg/L as Cl_2 without any risk to the marine environment. The neutralizing agent is sodium thiosulfate ($Na_2S_2O_3$).

The neutralizing reactions of $Na_2S_2O_3$ and NaOCI are described in reactions 1 and 2.

(reaction 1) Na₂S₂O₃ + 3NaOCl
$$\rightarrow$$
 3NaCl + Na₂S₂O₆ (reaction 2) Na₂S₂O₃ + 4NaOCl + 2NaOH \rightarrow 4NaCl + 2Na₂SO₄ + H₂O

The neutralizing reactions of $Na_2S_2O_3$ and HOCl/HOBr are described in reactions 3 and 4.


(reaction 3) Na₂S₂O₃ + 4OCl⁻ + H₂O
$$\rightarrow$$
 2NaCl + 2SO₄²⁻ + 2HCl (reaction 4) Na₂S₂O₃ + 4OBr⁻ + H₂O \rightarrow 2NaCl + 2SO₄²⁻ + 2HBr



2.1.3. Sampling facility

Page Number: 15 / 106

According to the paper of "Analysis of Ballast water sampling port designs using Computational Fluid Dynamics (See the Appendix D-4)", in order to gain representative samples from the sampling ports, the sampling port is installed in the center of pipe and in the opposite direction of the water flow, and is used to sampling of the efficacious, chemical and toxicity test.



< Drawing of sampling port using AquaStar™ BWMS >

2.2. Control system

During ballasting and de-ballasting, CSU automatically monitors and controls the operation of AquaStarTM BWMS. CSU of AquaStarTM BWMS is based on PLC and is designed as available equipment at ship.


Functions of CSU are as follows;

Page Number: 16 / 106


- Automatic and manual operation of AquaStarTM BWMS is possible during ballasting and de-ballasting (to adjust necessary treatment dosage for ballasting/de-ballasting mode).
- During the operation of AquaStar[™] BWMS, when an unexpected problem occurs, alarm system operates, and then AquaStar[™] BWMS should be shut down.
- Various operation data and instruments (equipment) can be stored and displayed.
- Alarm of operation for cleaning, calibration or repair can be stored and displayed.
- The status for emergency and by-pass operation can be stored and displayed.
- CSU can show whether all instruments of AquaStar[™] BWMS are normally functioning or failure of the BWMS.
- CSU stores data on monitored functions and conditions for at 24 months and the operation data can be displayed or printed for inspection.

2.2.1. Control flow chart of system

2.2.1.1. Automatic selection mode for ballasting and de-ballasting operation



2.2.1.2. Automatic ballasting process of AquaStar™ BWMS



Numerical calculation of ballasting process;

Current of rectifier = P1 x P2 x P3 x F1 x T_{TRO1}/P_{ele}

F1 = Main flow rate of BP (m³/hr)

 T_{TRO1} = Target TRO value at ballasting process (Setting value)

TRO1 = Measuring TRO value of TRO sensor during ballasting process

P1 = Parameter (Theoretical value)

P2 = Experimental efficiency (Setting value)

Application for AMS determination and US Type Approval


2. System Description

P_{ele} = factor, connecting EL (Default=4)
 P3 = Estimated between measuring TRO1 and Target TRO
 Control variable in program (Default=1)

If $(T_{TRO1} - TRO1) > 0$ or positive (+) \Rightarrow Current increase (Calculating with TRO1 and T_{TRO1} value) If $(T_{TRO1} - TRO1) < 0$ or negative (-) \Rightarrow Current decrease (Calculating with TRO1 and T_{TRO1} value)



2.2.1.3. Automatic de-ballasting process of AquaStar™ BWMS



Numerical calculation of de-ballasting process;

Flow rate of NAP (L/hr) = N1 x N2 x N3 x F2 x (TRO2 – T_{TRO3}) / C1

F2 = Main flow rate of BP (m³/hr)

C1 = Neutralizing agent concentration (g/L)

TRO2 = Initial TRO value with water treated EL before de-ballasting process (Refer to 2.2.4. to check detail information for setting method of TRO2)

 T_{TRO3} = Target TRO value at de-ballasting process (Setting value)

Application for AMS determination and US Type Approval

2. System Description

N1 = Parameter (Calculated ideal)

N2 = Experimental efficiency (Setting value)

N3 = Estimated between Measuring TRO2 and T_{TRO3}

Control variable in program (Default=1)

TRO3 = Measuring TRO value TRO sensor during de-ballasting process

If $(T_{TRO3} - TRO3) > 0$ or positive (+) \Rightarrow NAP flow rate increase (Calculating with TRO3 and T_{TRO3} value)

If $(T_{TRO3} - TRO3) < 0$ or negative (-) \Rightarrow NAP flow rate decrease (Calculating with TRO3 and T_{TRO3} value)



Page Number: 21 / 106 AquaStarTM Ballast Water Management System

2.2.1.4. Setting method of TRO2 value (Initial TRO value for de-ballasting operation)



1) De Initial TRO (A)

- A new TRO sensor which measures TRO concentration with water before neutralization is added at existing model of AquaStarTM BWMS.
- This method is used to reduce the initial consumption of a neutralizing agent.
- This method is upgraded at interval measuring and cycle measuring.
- ① Before de-ballasting operation, touch A button in the screen of "navigation process (Above picture)".
- ② Set a target TRO3 value in the screen of "deballast set".
- ③ Stat BP and de-ballasting operation is automatically started.
- 4 De-ballasting operation is conducted on condition that target TRO1 setting at ballasting operation is applied as the initial TRO2 at neutralization equation during setting period.

- (5) During setting period, TRO concentration with water before neutralization is measured by new added TRO sensor.
- (6) After setting period, the average value of measured values (5) step) is applied as the initial TRO2 at neutralization equation.
- The suitable volume of a neutralizing agent is injected during de-ballasting operation.

2) Manual Set (B)

- The initial TRO2 is directly or manually setting by the operator.
- Source of a initial TRO2
 - a. Default supplied AQUA Eng. Co., Ltd
 - b. Actual measured value by TRO portable at site (Sampling water before neutralization)
- ① Before de-ballasting operation, touch B button in the screen of "navigation process (Above picture)".
- ② The operator directly sets the initial TRO2.
- 3 Set a target TRO3 value in the screen of "deballast set".
- (4) Stat BP and de-ballasting operation is automatically started.
- (5) If the measured TRO > target TRO, the flow rate of NAP is increased. If the measured TRO < target TRO, the flow rate of NAP is decreased.
 - → This process is automatically controlled and monitored.

3) Interval Measuring (C)

- After stopped ballasting operation, the power of AquaStar™ BWMS is shut off.
- To check the initial TRO2 before de-ballasting operation, turn on the power of AquaStar™ BWMS.
- Such as below picture, the operator sets the setting time to measure TRO concentration with water before neutralization.

AOUA



- Ex) Power on the system
 - → Measure TRO concentration per 2 minutes during 2 hours after 4 hours

4) Cycle Measuring (D)

- The situation of power on for AquaStarTM BWMS all the time
- This method is used to check the initial TRO2 before de-ballasting operation or monitor the change of TRO concentration after ballasting operation.
- Such as below picture, the operator sets the setting time to measure TRO concentration with water before neutralization.



Ex) Measure TRO concentration per 2 minutes during 2 hours per 4 hours

2.2.2. PID control

PID control is applied to control the TRO value in the system.

In the method of PID control, the control method by the continuous analog value is not suitable for a measuring method or a control method in the system. Thus, the system is applied to PID control of the sampling method (the discrete value).

First, the basic equation for PID control of the sampling method is described in the reaction 1.

(Reaction 1)

Manipulated variable = $K_p \times a$ deviation (Proportional) + $K_i \times a$ cumulative value of a deviation (Integral) + $K_d \times a$ differential value with the last deviation (Differential)

When expressing by symbols

$$TCn = TC_{n-1} + \Delta TC_n$$

$$\Delta TC_n = K_p(DT_n-DT_{n-1}) + K_i DT_n + K_d\{(DT_n-DT_{n-1})-(DT_{n-1}-DT_{n-2})\}$$


TC_n, TC_{n-1}: n, n-1 th control variable

Page Number: 25 / 106

 ΔTC_n : n th control variable differentiation


 DT_n , DT_{n-1} , DT_{n-2} : n, n-1, n-2 th deviation

2.2.2.1. Ballasting control



- RC_n, RC_{n-1}: n, n-1 th control variable of Rectifier
- dRC_n: n th control variable differentiation of Rectifier
- DT_n, DT_{n-1}, DT_{n-2}: n, n-1, n-2 th deviation

2.2.2.2. De-ballasting control



- NP_n, NPC_{n-1}: n, n-1 th control variable of NAP
- dNP_n: n th control variable differentiation of NAP
- DT_n, DT_{n-1}, DT_{n-2}: n, n-1, n-2 th deviation

Page Number: 27 / 106


2.2.3. Continuous self-monitoring

By controlling and monitoring the ballasting and de-ballasting control of CSU, the operation of AquaStarTM BWMS is to continuous self-monitoring.

In ballasting and de-ballast process screen of MCP or LCP, each unit is touched, the measured value for this unit is appeared (Real-time monitoring=History graph).

History graphs of each unit;

- Main flow-rate of ballasting de-ballasting process
- Voltage/ampere and temperature of rectifier
- Voltage/temperature of EL
- TRO sensor
- Pressure_SP / Pressure_NU
- CL2D, H2D
- NT level





2.2.4. Data storage

When touch the data management button of data save set screen in configure screen, the data management screen appears as shown.

All operation data (ballasting/de-ballasting process) are automatically stored at the memory card (CF card) in touch panel of CSU, while CSU is power on.

Also, alarm list and instrument state are stored in touch panel of CSU.



Please, refer to Appendix C-3 (Data logging) to check the storage form for operation, alarm and instrument data.

<The method to check the data stored in CSU>

- ① Touch the words (CF card) in above screen.
- ② Some folders is appears as SAMP 01 (alarm), SAMP 02 (operation data) and SAMP 03 (instrument state).
- 3 When touch the name of folder that want to the check, every file is appears in order created.
- 4) When touch the name of file that want to the check, operation data is appears in right table.
- 5 Using up, down, left and right button, detailed data value can be verified.
- *When touch the button (file name reset), number of new file's name is relisted from "0".
- * When touch the button (alarm save), save the list of alarm that occurred until now.

<The method of download the data from CF card in touch panel to USB memory>

- 1) Put the USB memory into the touch panel.
- ② In the file list of CF card, select and touch the file that want to the download.
- 3 Touch the COPY button in lower left of the table. And, select the YES about question of program.
- 4 Touch the PASTE button in lower left of the table. And, select the YES about question of program.
- (5) After download the file, touch the button (USB open) before pull the USB memory.
- 6 Pull the USB memory from the touch screen.
- 7 Check the operation data of the USB memory.



Application for AMS determination and US Type Approval

2. System Description

- X Check procedure of previous operation data, after MCP replacement
 - ① After new MCP replacement same as model, remove the storage media put the predecessor, and then put at new MCP
 - ② MCP power on
 - 3 Check the previous operation data at MCP display
 - ④ To print the previous operation data, do the method indicated "The method to check the data stored in MCP"

※ Operation data capacity

Total data capacity for operation (ballasting and de-ballasting), alarm and instrument state: 28~30KB/h

As calculating for years,

Page Number: 31 / 106

 \rightarrow 478~512MB/2years

Because the data capacity of a storage media supplied from AquaStar™ BWMS is 4GB, the data storage is enough for 2 years.



2.2.5. Safety function

Page Number: 32 / 106

In AquaStar[™] BWMS, various sensors (such as MFM, CM, TT, PI, TBS, TRO sensor, H2D, CL2D, LT and LG) are installed for the effective operation of AquaStar[™] BWMS. During AquaStar[™] BWMS operation, these sensors can be detected any risk factors. Depending on the level of a sensed risk, CSU is programmed to be able to conduct the proper response.

In the maintenance for AquaStar[™] BWMS, audible and visual alarm signals are activated whenever the BWMS is in the operation for purposes of management (cleaning, calibration and repair) and ballasting or de-ballasting; such events recorded by CSU.

All components of AquaStarTM BWMS can't be installed in the explosive hazardous area. If you want to install in the explosive hazardous area, AquaStarTM BWMS certified Explosion-proof must be used.



Alarm and Interlock list

Units	Installation	Alarm	Interlock
MFM			
1) Ballasting process (m³/hr)	0	Low/High	Low Low/High High
2) De-ballasting process (m³/hr)	Ο	Low/High	Low Low/High High
SP			. (
1) PI	0	X	X
2) PT (kg/cm ²)	0	High	High High
Electrolyzer system unit			
1) EL temp. (°C)	0	High	High High
2) EL voltage (V)	0	High	High High
3) Rectifier voltage (V)	0	High	High High
4) Rectifier ampere (A)	O	High	High High
5) Rectifier temp. (°C)	О	High	High High
6) TRO value (ppm)	~ ()		
Ballasting process	O	Low/High	Low Low/High High
De-ballasting process	0	High	High High
Neutralization system unit			
1) NT level (%)	0	Low	Low Low
2) Flow rate	0	Low	Low Low
3) NU			
PI	0	X	X
PT (kg/cm²)	0	High	High High
Others			
1) CM (mS/cm)	0	Low	Low Low
2) H2D (%)	Ο	High	High High
3) CL2D (ppm)	Ο	High	High High

Page Number: 34 / 106

2.3. Main components

2.3.1. CSU

During ballasting and de-ballasting, the operation of the AquaStar[™] BWMS is automatically monitored and controlled by CSU. CSU of the AquaStar[™] BWMS is based on PLC and is designed as available equipment at vessel type.

CSU is used the operation of AquaStar™ BWMS and is composed of MCP and LCP.


MCP is installed at COC (Control room=Deck office) and takes over all unit operation and overall operation of AquaStarTM BWMS.

LCP is installed at the engine room and takes over emergency and local operation. In order to protect, control and maintain the operation data or the soft program for CSU, the engineer of AQUA Eng. Co., Ltd. installed the security label (the breaking of a seal; see the below picture) at important parts (Cover, CF card and communication connecter etc.) of MCP and LCP, respectively.



< Seal sticker >

Configuration of CSU



2.3.1.1. MCP

MCP is applied to the control program designed AQUA Eng. Co., Ltd. Functions of MCP are as follows;

- Auto and manual operation for ballasting and de-ballasting
- The display and storage of operation data communicated with LCP
- The display and storage of parameter operation
- The setting of safety conditions (Alarm and Interlock)
- Check operation state of all instruments and equipment



Please, refer to Appendix C-1 (Operation Manual) to check detailed information for the specification of this unit.

2.3.1.2. LCP

LCP is applied to the control program designed AQUA Eng. Co., Ltd. Functions of LCP are as follows;

- Auto and manual operation for ballasting and de-ballasting
- The display and storage of operation data communicated with all instruments and equipment
- Transfer the operation data into MCP
- The display and storage of parameter operation
- The setting of safety conditions (Alarm and Interlock)
- Check operation state of all instruments and equipment
- Directly handle to equipment and instruments



Please, refer to Appendix C-1 (Operation Manual) to check detailed information for the specification of this unit.

AQUA

2.3.2. SP

SP is constructed with a number of half-baffle compartments with 50 μ m mesh. When seawater and brackish water flow through SP, diverse flow types occur. When ballast water flows through SP, aquatic organisms larger than 50 μ m are removed or damaged cell structures (such as membranes, appendages etc.).

Although some filters have clogged, the entire SP does not completely clog. If meshes are partially clogged, clog reducing mechanism is occurred by the backflow of running fluid in an inside of SP.



2.3.3. Electrolyzer system unit

Components of Electrolyzer system unit are as following;

- Rectifier
- EL
- GS (including AB, AAV etc.)


During ballasting operation, EL electrolyzes the natural seawater and brackish water based on electrolysis method. EL disinfects harmful aquatic organism including the seawater and is suitable to IMO D-2 Regulation.

When EL is operated, AQUA Eng. Co., Ltd. designed that TRO concentration is generated below 10 mg/L as Cl₂. Dependent on TRO value and ballast flow rate, the current supplied from rectifier is automatically controlled.

AQUA

2.3.3.1. Configuration of Electrolyzer system unit

Rectifier is directly connected to LCP. The current supplied from rectifier is controlled by LCP. The amount of current is controlled by the change of generated TRO value. Based on this information transferred from CSU, the current of rectifier is controlled. Also, rectifier is connected with EL and supplies the current of the specified value to EL.



2.3.3.2. Rectifier

Rectifier (including RCP) is installed near EL at engine room and transfers from 440V AC supplied at MSBD to DC, and DC is supplied to EL. The generated heat during transferring form AC to DC is refrigerated by air flowing from the cooling fan. Dependent on the location of rectifier, the location of the BR using the electric wire connection is possible to design the installation of diverse parts (top/bottom, front/back) in ship.

Rectifier type applied AquaStar[™] BWMS is IGBT rectifier and SCR rectifier. The type selection of these rectifiers is determined by site of vessel.




Please, refer to Appendix C-1 (Operation Manual) to check detailed information for the specification of this unit.

AQUA

2.3.3.3. EL

EL as an important part of AquaStar[™] BWMS is installed in main stream of ballast pipe line and electrolyzed to form TRO of regular concentration. When EL operates using seawater or brackish water, TRO is generated. TRO concentration of the treated water is automatically monitored by CSU with a feed-back system for control of the rectifier in order to regulate TRO, and in turn the TRO concentration.






Page Number: 43 / 106


EL serial connecting method

In AquaStarTM BWMS, being considered to low current operation and flexibility of installation, EL more than two set can be connected serially. Positive (+) BR of EL is connected with negative (-) BR of the neighbor EL. See the picture below.



2.3.3.4. GS


In the ballasting process, hydrogen gas is generated during the operation of EL. GS is safely vented on hydrogen gas to the outside. AAV is installed the top of GS. When the air pressure increases over fixed extent, hydrogen gas is automatically vented.



- 1: GS
- 2: AAV
- 3: By-pass line
- 4: AB
- 5: AV

2.3.4. Neutralization system unit

In the de-ballasting operation, Neutralization system unit removes TRO of treated water in the BT. TRO concentration of seawater treated by Neutralization system unit is similar to that of the natural seawater. Neutralization system unit is composed of NU, NT (1st and 2nd), NAP, NTP, NIP, NSPP and NCP.



AQUA

2.3.4.1. NU

NU is installed in main stream of de-ballasting pipe line (Discharge pipe).

During de-ballasting, NU reduces TRO concentration of the treated water (Similar to TRO concentration of the natural seawater). TRO concentration is continuously monitored during de-ballasting operation and a feed-back system controls the injected amount of the neutralizing agent.



2.3.4.2. NT

The air bubbling system using to solve the neutralizing agent is placed to the bottom inside NT.

NT is composed of 1st NT and 2nd NT.



- 1st NT
- : Mixing a neutralizing agent (Solid type → Solution type)
- 2nd NT
- : Supplying to a injector for a neutralizing agent

Also, LT and LG is installed in NT and is transferred the amount of neutralizing agent to CSU.



2.3.5. Instruments

2.3.5.1. H2D/CL2D

During ballasting process, hydrogen (H₂) and chlorine (Cl₂) gas are generated by electrolysis. H2D and CL2D are installed to detect the leakage of hydrogen and chlorine gas.

- Installation location of gas detector
 - 1) H2D (installed two points)
 - End part of air vent line connected GS and above part of near EL
 - 2) CL2D (installed one point)
 - Below part of near EL



 $<TS-4000 (H_2)>$

Page Number: 48 / 106



<GTD-1000Ex (H₂)>



<GTD-1000Tx (Cl₂)>

2.3.5.2. MFM

MFM is directly installed at the main ballast pipe in the engine room and measures the flow rate of BP.

In ballasting process, MFM measures the normal direction flow. The measured flow value transfers to CSU and is utilized the current calculation of the rectifier. In de-ballasting process, MFM measures the reverse direction flow. The measured flow value is transferred to CSU and is utilized the flow rate calculation of NAP.





2.3.5.3. TRO sensor

AquaStarTM BWMS controls and measures TRO concentration using on-line type equipment (CLX-XT) adopted DPD method. Also, TRO sensor is installed at the engine room and connected with LCP. The measurement range for TRO sensor is designed as $0 \sim 10$ mg/L as Cl₂, but TRO sensor is upgraded up to 15 mg/L as Cl₂.

1) Ballasting process

: Alarm and interlock setting value is setting for low and high TRO value.

- Setting for low TRO value

- ① When it is continuously two occurrences for less than 8 mg/L as Cl_2 , alarm is operated at CSU.
- ② When it is continuously three occurrences for less than 8 mg/L as Cl₂, AquaStar™ BWMS is shutdown.

- Setting for high TRO value

- ① When it is continuously two occurrences for over than 10 mg/L as Cl_2 , alarm is operated at CSU.
- ② When it is continuously three occurrences for over than 10 mg/L as Cl₂, AquaStar™ BWMS is shutdown.

2) De-ballasting process

: Alarm and interlock setting value is setting for high TRO value.

- Setting for high TRO value
- ① When it is to pass 240 seconds (Possible to set) for over than 0.15 mg/L as Cl₂, alarm is operated at CSU.
- ② When it is to pass 240 seconds (Possible to set) for over than 0.2 mg/L as Cl_2 , AquaStarTM BWMS is shutdown.





Please, refer to Appendix C-1 (Operation Manual) to check detailed information for the specification of this unit.

AQUA

2.3.6. Installation condition of main components

No.	Units	Installation location	Site	Remark
1	МСР	COC=Deck office	- Easily accessible place for ensuring safe operation	
2	LCP	Engine room	- Easily accessible place for ensuring safe operation	
3	SP	Engine room	- Ballast pipe forward 1st EL - Considered flow direction of BP	>
4	Rectifier	Engine room	- Near EL - Security area from electric hazard	
5	RCP	Engine room	Near Rectifier or LCPEasily accessible place for ensuring safe operation	
6	EL	Engine room	 Ballast pipe between SP and GS at security area Variable installation structure depending on the ship pipe line Considered polar of EL 	
7	GS	Engine room	- Ballast pipe backward 4 th EL - Considered flow direction of BP	
8	SPP	Engine room	- Ballast pipe backward GS - Considered flow direction of BP	
9	NIP	Engine room	Forepart of de-ballast pipedischarged from BTConsidered flow direction of BP	

Application for AMS determination and US Type Approval

10	SIP	Engine room	Unit combined SPP and NIPBallast pipe backward GSConsidered flow direction of BP
11	NU	Engine room	 Variable installation structure depending on the ship pipe line De-ballast pipe backward NIP Considered flow direction of BP
12	NT	Engine room	- Wide and easily accessible place
13	NCP	Engine room	- Near NT - Easily accessible place for ensuring safe operation
14	NAP	Engine room	- Near NT (2 nd)
15	NTP	Engine room	- Between 1 st NT and 2 nd NT
16	NSPP	Engine room	- De-ballast pipe near overboard - Considered flow direction of BP
17	MFM	Engine room	- Ballast pipe of back end of BP
18	H2D	Over A or B deck	- End part of air vent line connected GS (Over A or B deck)
19	CL2D	Engine room	- Below part near EL
20	TRO sensor	Engine room	- Near LCP - Easily accessible place for ensuring safe operation
21	СМ	Engine room	- Near SP - Easily accessible place for ensuring safe operation

- Considering the site of ship, all units of AquaStar™ BWMS should be installed to normally operate at safety area.
- Before installation at ship, the optimum installation location for all units of AquaStarTM BWMS should be selected by several inspections.
- **X** Please, refer to below drawings to check installation and composition for each unit of AquaStar™ BWMS.




AOUA

Composition for each unit of AquaStar™ BWMS SP E/R E/R E/R GS E/R Sampling port NTP E/R E/R NU E/R E/R NSPP E/R Rectifier E/R LCP coc MCP coc NT **NSPP** coc TRO Sensor LCP MCP TRO Sensor GAS EMISSION SYSTEM RCP Rectifier Sampling port GS **MFM** EL SIP AQUASTAR" COMPOSITION - 1 NOTE Considering the site of ship, all units of AquaStar™ BWMS should be installed to normally operate at safety area. NONE SHEET NO. 1 OF 1



Page Number: 55 / 106

AquaStarTM Ballast Water Management System



AOUA

2.4. Pre-start check list

2.4.1. General hazard

2.4.1.1. Basic information

	INSPECTI	ON INFORMATION
Project Name	:	
Division	:	
Inspector Name	:	
Inspection Date	:	

The function of this section is to determine the suitability whether design, construction, operation and function of BWMS is suitable for the standard of international convention and ship's voyage.

This section can be used as guidance for manufactures and ship's operator (crew) on the evaluation procedure that equipment will undergo and the requirements placed on BWMS.

Also, this section is used to maintenance for system including electric instruments. All check lists of AquaStar[™] BWMS indicated this document must be carried out by engineer of AQUA Eng. Co., Ltd.

2.	System	Desc	rip	tion

2.4.1.2. Information for hazard substances

Please, list the surrounding hazard substances.

:					
•					
:					
:			-		
alth	:		7		
roblem	:				
problem	:				
-				tivity, sus	sceptibility to
	special ha	roblem : problem : special hazards suc	roblem : problem : special hazards such as chemi	roblem : problem :	roblem : problem : special hazards such as chemical reactivity, sus

Page Number: 59 / 106

2.4.2. Installation of main components

Division	Check item	Result	
CSU			
	Check the overall installation (No upper water leak or faller)		
MCP	2) Check a fixing status		
	3) Check a power connecting status		
	1) Check the overall installation (No upper water leak or faller)		
LCP	2) Check a fixing status		
	3) Check a power connecting status		
SP			
	1) Check the overall installation		
	2) Check the water leakage (body, cover, flange and pipe line)		
	3) Check the welding status for socket		
CD.	4) Check the installation direction (as same to ballast flow) as contrasted with drawing		
SP	5) Check a status of bolt fastened at cover, flange and bed		
	6) Check the assembly status and the welding with bed		
	7) Check the assembly and operation status of PTS related PI and PT		
	8) Check operation status for all valves		
Electrolyzer system unit			
Rectifier	1) Check the overall installation		

	(No upper water leak or faller)
	2) Check a fixing status
	3) Check a power connecting status
	4) Check connection status of each rectifier and RCP
	5) Check connection and communication status with PWD
	1) Check the overall installation
	2) Check the water leakage (body, cover and flange)
	3) Check the assembly status for insulation bolt
	4) Check the installation direction (as same to ballast flow) as contrasted with drawing
	5) Check the assembly status for EL and bed
	6) Check the insulted status between EL and bed
	7) Check the assembly status for sealing device
EL	8) Check the assembly status for EL and cover
	9) Check the insulted status between 4ea EL
	10) Check the assembly location of 4ea EL
	: Check positive and negative connecting of each EL
	11) Check a status of flange assembly of each EL
	12) Check a connecting status for cable between each EL
	13) Check a connecting status for cable between rectifier and EL
	14) Check a status related to applying the electric current for positive and negative of each EL
GS	1) Check the overall installation

	2) Check the installation direction as contrasted with drawing	
	3) Check the water leakage (body, cover, flange and pipe line)	
	4) Check the assembly status for valves and flanges related to gas vent line	
	5) Check the assembly status and location for AB	
	6) Check the assembly status and location for AV	
	7) Check the assembly status and location for AAV	
	8) Check a status of flange assembly of GS	
	9) Check the outlet status of gas vent line installed higher than upper deck in the safety area	
	10) Check operation status for all valves	
Neutraliza	tion system unit	
	1) Check the overall installation	
	2) Check the water leakage (body, flange and pipe line)	
	3) Check the welding status for socket	
NII .	4) Check the installation direction (as same to flow) as contrasted with drawing	
NU	5) Check a status of bolt fastened of flange	
	6) Check the assembly status for socket and ball valve	
	7) Check operation status for all valves	
	8) Check the assembly and operation status of PTS related PI and PT	
NIT	1) Check the overall installation	
NT	2) Check the water leakage of NT	Λ

	3) Check the water leakage of pipe line related to NT	
	4) Check the installation status of LG and LT	
	5) Check the installation status of FWSS	
	6) Check the installation status of ASS	
	7) Check the installation status of NAP	
	8) Check the installation status of NTP	
	9) Check the installation and operation status of PI for NAP	
	10) Check operation status for all valves	
	1) Check the overall installation	
	(No upper water leak or faller)	
NCP	2) Check a fixing status	
	3) Check a power connecting status	
	1) Check the overall installation	
	2) Check the water leakage (body, flange and pipe line)	
NIP	3) Check a status of bolt fastened at flange	
	4) Check the installation direction (as same to flow) as contrasted with drawing	
	5) Check operation status for all valves	
	1) Check the overall installation	
	2) Check the water leakage (body, flange and pipe line)	
SIP	3) Check a status of bolt fastened at flange	
	4) Check the installation direction (as same to flow) as contrasted with drawing	
	5) Check operation status for all valves	
		A

	1) Check the overall installation	
	2) Check the water leakage (body, flange and pipe line)	
SPP	3) Check a status of bolt fastened at flange	
	4) Check the installation direction (as same to flow) as contrasted with drawing	
	5) Check operation status for all valves	
	1) Check the overall installation	
	2) Check the water leakage (body, flange and pipe line)	
NSPP	3) Check a status of bolt fastened at flange	
	4) Check the installation direction (as same to flow) as contrasted with drawing	
	5) Check assemble and operation status for all valves	
Instrumer	nts	
	1) Check the overall installation	
	(No upper water leak or faller)	
	2) Check the water leakage (body and flange)	
	3) Check a status of bolt fastened at flange	
MFM	4) Check the installation direction (as same to ballast pump flow) as contrasted with marker manual	
	5) Check the installation and fixing status of transmitter	
	6) Check cable connection status of transmitter and body	
	7) Check ground connection status	

H2D /CL2D	Check the overall installation (No upper water leak or faller)	
	2) Check the installation and fixing status	
	3) Check ground connection status	
	Check the overall installation (No upper water leak or faller)	
	2) Check the water leakage (TRO sensor and pipe line)	
TRO	3) Check a fixing status	
sensor	4) Check a connecting status of pipe lines (sampling)	
	5) Check assemble and operation status for all valves	
	6) Check volume and condition state for reagent and buffer bottle	
Butterfly	Check the overall installation (No upper water leak or faller)	
valve	2) Check the installation and fixing status	
(Main and by-	3) Check the water leakage	
pass	4) Check a status of bolt fastened at flange	
valves)	5) Check the installation direction (as same to ballast pump flow) as contrasted with marker manual	
	Check the overall installation (No upper water leak or faller)	
СМ	2) Check the installation and fixing status	
	3) Check the water leakage	

Application for AMS determination and US Type Approval

2. System Description

FS	1) Check the overall installation	
(Option;	(No upper water leak or faller)	
Explosio n-proof	2) Check the installation and fixing status	
type)	3) Check the water leakage	
_		

Remark (Describe, if the inadequate state exists, except inspection items)



2.4.3. Check list for electrical operation state

Division	Check points	Result
CSU		
	State of power supply	
	Operation state of button/switch/lamp/touch screen of ballasting	
	Operation state of button/switch/lamp/touch screen of de-ballasting	
МСР	Operation state of button/switch/lamp/touch screen of navigation	
	Operation state of emergency switch	
	Operation state of emergency operation switch	
	Communication state with LCP	
	State of power supply	
	Operation state of button/switch/lamp/touch screen of ballasting	
LCP	Operation state of button/switch/lamp/touch screen of de-ballasting	
LCP	Operation state of button/switch/lamp/touch screen of navigation	
	Operation state of emergency switch	
	Communication state with MCP/instruments/equipment	



SP		
SP	Communication state of PT_4~20 mA	
Electrolyzer system unit		
Rectifier	State of power supply	
	Operation and communication state of RCP	
	Operation state of TT	
	Operation state of voltage and current	
	Operation state of emergency switch	
	Communication state with LCP	
EL	Operation state of TT	
	Operation state of TBS	
	Operation state of voltage	
GS	Operation state of AB	
	Operation state of solenoid valve	

Neutralization system unit		
NU	Communication state of PT_4~20 mA	
NCP	State of power supply	
	Operation state of button/switch/lamp	
	Communication state of LT_4~20 mA	
	Communication state with LCP/instruments	
NT	Operation state of ASS	
	Operation state of FWSS	
	Operation state of solenoid valve	
NAP	State of power supply	
	Operation state of output (flow rate)	
	Operation state of button	
NTP	State of power supply	
	Operation state of this device (flow)	

Instruments	
	State of power supply
	Communication state with LCP
MFM	Communication state for 4~20 mA
	Operation state of button
H2D	Communication state with LCP
	Communication state for 4~20 mA
4125	Communication state with LCP
CL2D	Communication state for 4~20 mA
	State of power supply
	Communication state with LCP
	Communication state for 4~20 mA
TRO sensor	Operation state of this device
	Operation state for cooling system
	Operation state of solenoid valve
	Operation state for suction pump
Butterfly valve (Main and by-	Communication state with LCP

Application for AMS determination and US Type Approval

2. System Description

pass valves)	Operation state of this device
СМ	State of power supply
	Communication state with LCP
	Operation state of this device
	Communication state for 4~20 mA
FS	Communication state with LCP
(Option; Explosion-proof	Operation state of this device
type)	Communication state for 4~20 mA or contact status indication signal



Page Number: 70 / 106

AquaStarTM Ballast Water Management System

2.4.4. Equipment test

Equipment list for work procedure

- SP
- EL and GS
- NU, NT, NIP and NSPP

Test report of manufacture

Equipment Name	:	
Model No.	:	
Drawing No.	:	
Inspector	:	Date :

Inspection items	Test equipment	Result
Size inspection	Visual inspection/Digital level	
Welding inspection	UT tester	
Flange angular test	Digital level/Goniometer	
Painting inspection	Thickness gauge	
Assembling inspection	Visual inspection	
Insulation test	Multimeter	
Hydraulic test	Hydraulic pressure measuring device	

Remark (Describe, if the inadequate state exists, except inspection items)

AOUA

2.4.5. Emergency operation test

Abnormal operation test

Division	Performance checks	Result
Emergency switch test of MCP / LCP		
Check rectifier po	ower off	
Check BP stop (Option)		
Check ON state of instruments and equipment		
Alarm/Shut-down		
Check alarm/interlock range of each instrument		
Refer to 2.5.4 (Ala	arm and interlock list)	
Remark (Describe, if the inadequate state exists, except inspection items)		

By-pass/Override test


Page Number: 72 / 106

Division	Performance checks	Result	
By-pass procedure	By-pass procedure		
By-pass valve ope	en		
Main valves close			
Push emergency operation button of MCP			
BP start			
Check list for by-pass operation			
Indication of valv	es position		
Rectifier power off			
Operation data st	torage		
Remark (Describe, if the inadequate state exists, except inspection items)			

2.4.6. Test run for the system



A: Ballasting process



B: De-ballasting process



C: Sensor status



D: Measuring value screen

2. System Description

2.4.6.1. Automatic ballasting operation

Division	Performance checks			Result
Preparation for operation	eparation for operation 1) Check reagents preparation for TRO sensor			
	1) Check normal operation state of MCP/LCP (Figure A)			
	2) Check communication with MCP, check each instruments (Figure C)			
	3) Che	ck normal operation state	of MFM (Figure C)	
Condition for normal operation	4) Che	ck TRO sensor communica	ate with LCP (Figure C)	
	5) Che	ck normal operation state	of rectifier power on (Figure C)	
	6) Check state of main valves open (Figure A)			
	7) Che	ck state of by-pass valve o	close (Figure A)	
	1) MSE	BD Power On		
Check operation procedure	2) MCP/LCP Power On			
	3) BP start			
	No Instrument Normal operation range			
Check normal condition for	1	MFM	10 % ~ 110 % of Max. capacity	
ballasting operation	2	SP pressure	< 5 kg/cm ²	
	3 EL temp. < 70 °C			

AQUA

2. System Description

	4	EL voltage	< 6 V
	5	Rectifier voltage	< 24 V
	6	Rectifier current	< 80 % of Max. capacity
	7	Rectifier temp.	< 80 ℃
	8	H2D	< 25 % of LEL
	9	CL2D	< 0.5 ppm
	10	TRO	8 ~ 10 ppm
	11	СМ	> 10 mS/cm
	Check	above items using figure	A or D (Display of MCP/LCP)
	1) BP stop		
Ending procedure	2) MCP/LCP Power Off		
3) MSBD Power Off			



Page Number: 75 / 106

AquaStarTM Ballast Water Management System

2. System Description

2.4.6.2. Automatic de-ballasting operation

Division	Performance checks	
Preparation for operation	1) Check preparation for neutralizing agent	
	1) Check normal operation state of MCP, LCP and NCP (Figure B)	
	2) Check communication with MCP, check each instruments (Figure C)	
	3) Check normal operation state of MFM (Figure C)	
Condition for normal operation	4) Check TRO sensor communicate with LCP (Figure C)	
	5) Check normal operation state of NAP (Figure B)	
	6) Check state of main valves close (Figure B)	
	7) Check state of by-pass valve open (Figure B)	
	1) MSBD Power On	
Check operation procedure	2) MCP/LCP/NCP Power On	
	3) Push de-ballasting button of MCP	
	4) BP start	



2. System Description

	No	Instrument	Normal operation range	
	1	MFM	10 % ~ 110 % of Max. capacity	
Check normal condition for de-	2	NU pressure	< 5 kg/cm ²	
ballasting operation	3	NT level	> 30 %	
	4	TRO	< 0.15 ppm	
	Check	above items using figure I	B or D (Display of MCP/LCP)	
	1) BP	1) BP stop		
Ending procedure	2) MCP/LCP/NCP Power Off			
	3) M	3) MSBD Power Off		



Page Number: 77 / 106

AquaStarTM Ballast Water Management System

2. System Description

2.4.6.3. Check items of ballasting/de-ballasting operation data

Division	Performance checks	Result	
Check data storage after operation			
	1) Ballasting/De-ballasting/Navigation operation data		
MCP Data	2) Alarm list		
	3) Operation state of instruments		
	1) Ballasting/De-ballasting/Navigation operation data		
LCP Data	2) Alarm list		
	3) Operation state of instruments		
	1) Check the capacity size of a memory card		
Other control device test	2) Test to print the storage data transfer to USB memory card at		
	field PC		
Remark (Describe, if the inadequ	uate state exists, except inspection items)		

AQUA

Page Number: 78 / 106

AquaStarTM Ballast Water Management System

2.4.7. Safety program and training

Result
items)


2.4.8. Personnel safety

Check point	Result		
1) Check the operation ability (skill) for an operator			
- Normal operation of ballasting/de-ballasting			
- Emergency operation			
2) Check to wear and store the protective device	P		
- Safety shoes, safety helmet and safety gloves etc.			
3) Check the maintenance approach for an operator			
4) Check the emergency exit			
5) Check arrangement and operation for safety equipment			
Remark (Describe, if the inadequate state exists, except inspection items)			

2.5. Operation Procedure


2.5.1. **General**

Page Number: 81 / 106




MCP/LCP display of AquaStar™ BWMS

A: Ballasting process



B: De-ballasting process



C: Navigation process

Page Number: 83 / 106



Number	Equipment	Unit	Description
Α	Ballasting process s	tatus	
1	MFM	m³/hr	Ballasting flow rate
2	SP	kg/cm ²	SP pressure
3	Rectifier	V	Rectifier voltage
4	Rectifier	А	Rectifier ampere
5	Rectifier	°C	Rectifier temperature
6	EL	EA	Name of EL
7	EL	V	Individual EL voltage
8	EL	°C	Cathode cable temperature
9	EL	°C	Anode cable temperature
10	CL2D	mg/L (ppm)	Chlorine gas concentration
11	H2D	%	Hydrogen gas concentration
12	TRO sensor	mg/L (ppm)	Ballasting TRO concentration
13	АВ		AB On/Off status

2. System Description

В	De-ballasting process status			
14	MFM	m³/hr	De-ballasting flow rate	
15	NU	kg/cm ²	NU pressure	
16	TRO sensor	mg/L (ppm)	De-ballasting TRO concentration	
17	NT		NT status	
18	NT level	%	NT level status	
19	NAP		NAP On/Off	
С	Navigation process status			
20	TRO sensor	mg/L (ppm)	Average measuring TRO value	
21	TRO sensor	mg/L (ppm)	Manual measured TRO value	
22	TRO sensor	mg/L (ppm)	Interval measuring TRO value	
23	TRO sensor	mg/L (ppm)	Cycle measuring TRO value	

2.5.2. Preparation for operation

1) Preparation of neutralizing agent (Sodium thiosulfate)

 \times The Na₂S₂O₃ in the actual neutralization process is used as Na₂S₂O₃·5H₂O (248g/mol).



Please put on the protective clothing, gloves, masks and goggles when you prepare the neutralizing agent solution.









- * The concentration of a neutralizing agent is 1 M (mole/L).
- ① Put 248 kg of a neutralizing agent into 1st NT.
- 2) Fill with 1,000 L of fresh water into 1st NT.
- (3) Check the level of 1st NT.
- 4 Operate the air bubbling system installed 1st NT to solve a neutralizing agent.
- ⑤ Operate NTP installed 1st NT to move a neutralizing agent of a solution type into 2nd NT.



Operate the air bubbling system again if a neutralizing agent is not dissolved completely due to the surrounding environment.



Page Number: 85 / 106

A neutralizing agent storage: Keep in a tightly closed container, stored in a cool less than 38°C, dry, ventilated area. Protect against physical damage. Isolate from incompatible substances.



2. System Description

2) Preparation of TRO sensor reagent

There are two reagents required, for the instrument to operate; the buffer and the indicator. The reagents are provided "wet" and the buffer is ready to use and will last up to one year.



Left: indicator reagent (with DPD powder), Right: buffer solution

The smaller indicator reagent does require the addition of the DPD power to activate it.



Page Number: 86 / 106

Use caution while preparing. These reagents are caustic and can burn skin and stain clothing. The use of protective gloves, clothing and eye protection is highly recommended.

2. System Description

3) Preparation of indicator reagent

- 1) Remove the cap of the small liquid indicator reagent.
- 2 Add the contents of the DPD powder bottle (small brown bottle).
- 3 Cover the cap and shake to fully dissolve the powder.






Page Number: 87 / 106

Once mixed the indicator has an expected life of 90 days if kept in the powered cooling chamber. Write the mixing date on the reagent bottle labels in the area provided. Dispose of expired reagents correctly.

4) Installation of reagents in TRO sensor

- ① To replace the reagents, press the "SERVICE" button; this will empty the cuvette and stop any flow of water.
- ② Remove the cap on both bottles replace with the cap supplied with TRO sensor. The buffer is installed on the left and the indicator is installed in the cooling chamber. The suction tube for both reagents will reach the bottom of the bottles.
- ③ To complete the replacement procedure, press the "PRIME" button and then the ← button. This will draw enough of each reagent to completely prime the tubes and replace any old solution. The system will automatically return to normal operation after it has primed.



Buffer solution

Indicator reagent (added DPD powder)



Page Number: 88 / 106

Use caution when changing the reagents as they are caustic. These reagents will stain clothing and anything they contact. After changing the reagents, operators should wash their hands.

2.5.3. Operation method of AquaStar™ BWMS

2.5.3.1. Automatic (Normal) ballasting operation

Start-up procedure

- 1) Turn on MSBD power
- 2) Check the state of system
 - : MCP, LCP and rectifier power on
 - : Auto position in manual/auto selector switch of MCP
 - : Remote position in selector switch of LCP and rectifier
- 3) Check the state of valve
 - : Main valves open and by-pass valve close
- 4) Check the target TRO concentration including setting values
- 5) Turn on BP
- 6) Automatically start ballasting operation
- 7) Check the operating condition

Stop procedure

- 1) Turn off BP
- 2) Automatically stop ballasting operation
- 3) Turn off MSBD power
- 4) Check MCP, LCP and rectifier off

AQUA

2.5.3.2. Automatic (Normal) de-ballasting operation

Start-up procedure

- 1) Turn on MSBD power
- 2) Check the state of system
 - : MCP, LCP and NCP power on
 - : Auto position in manual/auto selector switch of MCP
 - : Remote position in selector switch of LCP, NCP and NAP
- 3) Check the state of valve
 - : Main valve close and by-pass valve open
- 4) Check the target TRO concentration including setting values
- 5) Push de-ballast process button/lamp (Pre-operation: NAP on state)
- 6) After 3 minutes, turn on BP
- 7) Automatically start de-ballasting operation
- 8) Check the operating condition

Stop procedure

- 1) Turn off BP
- 2) Automatically stop de-ballasting operation
- 3) Turn off MSBD power
- 4) Check MCP, LCP, NCP and NAP off



2.5.4. Alarm and Interlock setting for system

Unit	Alarm	Interlock	Remark
MFM			
1) Ballasting process (m³/hr)	10~110%	5~115%	
2) De-ballasting process (m³/hr)	10~110%	5~115%	
SP			
1) PI	X	X	
2) PT (kg/cm ²)	over 5	over 7	
Electrolyzer system unit		7	>
1) EL temp. (°C)	over 70	over 85	
2) EL voltage (V)	over 6	over 7	
3) Rectifier voltage (V)	over 24	over 28	
4) Rectifier ampere (A)	80% of Max. cap.	90% of Max. cap.	
5) Rectifier temp. (°C)	over 80	over 90	
Neutralization system unit			
1) NT level (%)	under 30	under 10	
2) Flow rate	X	0	
3) NU			
PI	X	X	
PT (kg/cm²)	over 5	over 7	
Others			
1) CM (mS/cm)	under 10	under 5	
2) H2D (%)	over 25 of LEL	over 50 of LEL	
3) CL2D (ppm)	over 0.5	over 1	
4) TRO concentration (ppm)			
Ballasting process	under 8 / over 10	under 8 / over 10	
	(continuously	(continuously	
	2times)	3times)	
De-ballasting process	over 0.15	over 0.2	

2.6. Emergency Operation

2.6.1. Emergency switch

Emergency switch used at emergency situation is installed at MCP and LCP, respectively.

When the operator pushes the emergency switch, AquaStar[™] BWMS and BP are stopped at once. After solving the emergency situation, AquaStar[™] BWMS should be restarted.



If an emergency occurs, please contact directly AQUA Eng. Co., Ltd.

Operation condition of emergency switch

- 1) In case of, exist the risk of ship and crew
- 2) In case of, abnormal operation of MCP, LCP, rectifier and BP etc.
- ③ In case of, do not work Interlock of MCP
- 4 In case of, the alarm operation of LCP/MCP or do not search for the long time cause
- 5 In case of, generate the errors H2D/CL2D or do not work H2D/CL2D
- 6 In case of, the gas leakage or water leak generate
- ⑦ In case of, need to quickly stop AquaStar[™] BWMS by diverse risk of ship
- In case of, fire and short circuit generate

Page Number: 92 / 106

- (9) In case of, TRO is abnormally high and low
- 10 In case of, the pressure of SP rapidly increase
- ① In case of, the pressure of NU rapidly increase



Location of emergency switch







LCP emergency switch

Check item during emergency switch

- ① Check the operation condition of H2D/CL2D
- 2 Check the rectifier power off
- 3 Check the pressure of SP
- 4 Check the pressure of NU
- (5) Check the power off of NAP
- 6 Check the operation condition of TRO sensor
- ⑦ Check the power on of MCP and LCP
- (8) Check BP off

2.6.2. Emergency operation switch

AquaStarTM BWMS is designed to conduct the ballasting operation or deballasting operation at the same time with BP working. When the operator pushes the emergency operation switch, the operation of BP will be continued but the operation of AquaStarTM BWMS will be stopped. At this time, the data related to emergency state is stored.



Before emergency operation switch uses, please contact directly AQUA Eng. Co., Ltd.



AQUA Eng. Co., Ltd. is not liable for any troubles caused by using of emergency operation switch without the approval of AQUA Eng. Co., Ltd.



Page Number: 94 / 106


Emergency operation switch

AQUA


2.6.3. By-pass operation

Please, use only in case of by-pass operation should be needed. By-pass operation activates an alarm and the event can be stored and displayed. The operator must record the information for by-pass operation.

Flow diagram of normal operation



Flow diagram of abnormal operation



1) Valve-N close: Normal operation valve

2) Valve-B open: By-pass valve

AQUA

3. Application of AMS and US Type Approval

3.1. Authority information for foreign Type Approval

Model	Treatment rated capacity (m ³ /hr)	
AquaStar [™] BWMS H-200	200	
AquaStar TM BWMS H-200S/H-200S-Ex ¹	350	
AquaStar [™] BWMS H-250	500	
AquaStar TM BWMS H-300/H-300-Ex	800	
AquaStar [™] BWMS H-350/H-350-Ex	1,100	
AquaStar [™] BWMS H-450	1,800	
AquaStar [™] BWMS H-550	2,600	
AquaStar [™] BWMS H-650/H-650-Ex	3,000	
AquaStar [™] BWMS H-700	4,000	
AquaStar [™] BWMS H-750	5,000	

¹ Explosion-proof type

- 14 models (10 standard models and 4 Explosion-proof models)
- Type Approval Certificate of BWMS from Republic of Korea
- Refer to Appendix A (Type Approval certificate for BWMS) for Type Approval Certificate of AquaStarTM BWMS.

Foreign Type Approval MLTM		MLTM / Republic of Korea		
Address		#88, Gwanmun-ro, Gwacheon-si, Gyeonggi-do,		
		Korea		
Phone numb	er	+82-44-201-4108		
Name (Point of contact)		Hae Kwang, Kim		
Email		miraepa7@mltm.go.kr		

3.2. Evaluation of existing data and Type Approval requirements

In accordance with 33 CFR Part 151 / 46 CFR Part 162 of "Standards for Living Organisms in Ship's Ballast Water Discharged in U.S. Waters", data or information included the application for USCG AMS determination and US Type Approval are attached to appendices (Appendix A \sim I) of this document.



Page Number: 97 / 106 AquaStar™ Ballast Water Management System

3.3. AMS review checklist

Alternate Management System Review Checklist			
А	В	С	D
Guideline (G8) Specification	Cross Reference	Adequacy	Comments
(G8 section noted in brackets)	(Applicant to identify page,	(USCG to note	(Applicant-black; USCG-red)
	paragraph and/or table where	Y/N/NA)	
	this information is located)		
1. BWMS documentation [5]			
1.1 BWMS description, including diagrammatic drawing(s) showing typical	Chapter 2 (8~95 pages) of this		
pumping and piping arrangements (including a Bill of Materials and the	document and Appendix B		
specifications and standard/s which it meets), sampling facilities for	(Drawing Package)		
control and monitoring systems, operational outlets for treated water and			
waste streams [5.1]			
1.1.1 Control equipment automatically monitors and adjusts necessary	Chapter 2.2 (16~33 pages) of this		
treatment dosages, intensities or other aspects of the BWMS necessary	document and Appendix C-2		
for proper administration of necessary treatment [4.10]	(Operation program user's manual)		
1.1.2 Control equipment incorporates a continuous self-monitoring function	Chapter 2.2 (16~33 pages) of this		
when BWMS is in operation [4.11]	document and Appendix C-2		
	(Operation program user's		
	manual)		
1.1.3 Monitoring equipment record the proper functioning or failure of the	Chapter 2.2 (16~33 pages) of this		
BWMS [4.12]	document and Appendix C-2		
	(Operation program user's manual)		
1.1.4 Control equipment stores data on monitored functions and conditions	Chapter 2.2 (16~33 pages) of this		<u> </u>

AQU

Page Number: 98 / 106

AquaStar™ Ballast Water Management System

3. Application of AMS and US Type Approval

for at least 24 months; stored data can be displayed or printed for	document and Appendix C-2
inspection [4.13]	(Operation program user's manual)
1.2 Protections against interference [4.5]	
1.2.1 Every access beyond requirements of 4.4 requires breaking a seal [4.5.1]	Chapter 2.3.1 (34 page) of this
	document
1.2.2 Visual alarm is activated whenever the BWMS is in operation for	Chapter 2.2.5 (32~33 pages) of this
purpose of cleaning, calibration, or repair; such events recorded by	document and Appendix C-2
control equipment [4.5.2]	(Operation program user's manual)
1.2.3 Suitable emergency over-rides/by-passes to protect ship and crew	Chapter 2.6 (92~95 pages) of this
[4.5.3]	document
1.2.4 By-passes activate an alarm and the event is recorded by the control	Chapter 2.6 (92~95 pages) of this
equipment [4.5.4]	document
1.3 Audible and visual alarm signals in stations from which ballast water	Chapter 2.2.5 (32~33 pages) of this
operations and ballast water management are controlled [4.3]	document and Appendix C-2
	(Operation program user's manual)
1.4 Manufacture's equipment manuals containing details of major components	Chapter 2.3 (34~56 pages) of this
of the BWMS and their operation and maintenance [5.1.2]	document and Chapter 2 (23~61
	pages), 3 (62~90 pages) and 6
	(111~122 pages) of Appendix C-1
	(Operation Manual)
1.5 Operation and technical manual for complete BWMS covering	Chapter 2.3 (34~56 pages) of this
arrangements, operation, and maintenance of the BWMS as a whole, and	document and Chapter 2 (23~61
specifically describing any parts not covered by manufacturers equipment	pages), 3 (62~90 pages) and 6
manuals [5.1.3]	(111~122 pages) of Appendix C-1
	(Operation Manual)
1.5.1 Operations section of the manual includes normal operational	Chapter 2.5 (81~91 pages) of this
procedures [5.1.4]	document and Chapter 3 (62~90

Page Number: 99 / 106

3. Application of AMS and US Type Approval

	pages) of Appendix C-1 (Operation	
	Manual)	
1.5.2 Documentation of simple and effective means for operation and control	Chapter 2.5 (81~91 pages) of this	
[4.8]	document and Chapter 3 (62~90	
	pages) of Appendix C-1 (Operation	
	Manual)	
1.5.3 Operations manual includes procedures in the event of a malfunction of	Chapter 2.6 (92~95 pages) of this	
the BWMS, including emergency actions necessary for securing the ship	document and Chapter 4 (91~96	
[5.1.4]	pages) of Appendix C-1 (Operation	
	Manual)	
1.5.4 Operations manual contains maintenance procedures [5.1.3]	Chapter 6 (111~122 pages) of	
	Appendix C-1 (Operation Manual)	
1.6 All working parts of the BWMS liable to wear or damage easily accessible	Appendix C-4 (Drawing for	
for maintenance [4.4]	maintenance of BWMS) and	
	Chapter 6 (111~122 pages) of	
	Appendix C-1 (Operation Manual)	
1.6.1 Means provided to check in drift of, repeatability by, measuring devices	Appendix H (Calibration	
that are part of control equipment, and for re-zeroing control equipment	Procedure)	
meters [4.14]		
1.6.2 Facilities incorporated for checking the performance/calibration of	Appendix H (Calibration	
components of BWMS that take measurements [4.6]	Procedure)	
1.7 Operations manual describes methods for conditioning of treated water	Chapter 2.2 (16~33 pages) and	
	chapter 2.5.3.2 (90 page) of this	
prior to discharge to control residual treatment chemicals, disinfection by	document	
products, and the general suitability of the treated water for discharge		
[5.1.5]		
1.8 Technical section of the manual includes adequate information (including	Chapter 2.4.1, 2.4.2 and 2.4.3	
description and diagrammatic drawings of monitoring and	(57~70 pages) of this document	٨
	1 1	00(1/1

Page Number: 100 / 106

AquaStarTM Ballast Water Management System

3. Application of AMS and US Type Approval

electrical/electronic wiring) to enable faultfinding [5.1.7]		
1.9 Technical section of the manual includes specifications defining, inter alia,	Chapter 2.3.6 (52~56 pages) of this	
requirements for location and mounting of components, arrangements for	document	
sampling by control and monitoring equipment, and arrangements for	4	
ensuring safe operation [5.1.8]		
1.9.1 BWMS components, if intended for fitting in locations where flammable	Chapter 2.2.5 (32 page) of this	
atmospheres may be present, comply with relevant safety regulations;	document and Appendix A (Type	
certified by Administration as safe for use in a hazardous area [4.9]	Approval certificate for BWMS)	
1.10 Operations and technical manual contains a recommended test and	Chapter 2.4 (57~80 pages) of this	
checkout procedure, specifying all the checks to be carried out in a	document	
functional test following installation and a test by a surveyor when		
carrying out an onboard survey to confirm the installation meets the		
manufacturer's specific installation criteria [5.1.9]		
1.11 BWMS is robust and suitable for working in the shipboard environment,	Appendix B (Drawing Package) and	
with design, construction and materials, including electronic and electrical	Appendix E-1, E-2 and E-3	
components (including a Bill of Materials and the specifications and	(Certificate of Environmental	
standard/s which it meets), adequate for intended service [4.7.1]	test_H-300, H-650 and sensors)	
2. Type approval certificate		
2.1 Type approval certificate issued by, or on behalf of, the Administration [6.1]	Appendix A (Type Approval	
	certificate for BWMS)	
2.1.1 Specification of any limiting conditions on the usage of the BWMS,	Appendix A (Type Approval	
including but not limited to ballast water volumes, flow rates, salinity,	certificate for BWMS) and	
temperature, etc. [6.1 and 6.2]	Appendix G-1 (19th GESAMP)	
2.1.2 Specification of the type and model of the BWMS, including	Appendix A (Type Approval	
identification of duly dated equipment assembly drawings bearing	certificate for BWMS)	
model specification numbers or equivalent identification details [6.5]		nou!

Page Number: 101 / 106

AquaStar™ Ballast Water Management System

3. Application of AMS and US Type Approval

3. Environmental and public health impacts assessment documentation	
3.1 Protections reduce to minimum danger to persons (i.e., hot surfaces, moving parts, exposure to chemicals, UV, etc) [4.7]	Appendix G-2 (Application for Basic Approval) and G-3 (Application for Final Approval)
3.2 Complete application dossiers for IMO active substance basic and final approvals [Annex part 1, 1.6.4]	Appendix G-2 (Application for Basic Approval) and G-3 (Application for Final Approval)
3.3 Adequate arrangements for storage, application, mitigation, and safe handling of any substances of a dangerous nature [4.2]	Appendix G-2 (Application for Basic Approval) and G-3 (Application for Final Approval)
4. Quality Assurance (QA) and Quality Control (QC) [Annex Part 1, 2.1]	
4.1 Quality Management Plan (QMP) addressing the quality control management structure and policies of the testing body, including all subcontractors and outside laboratories [Annex Part 2, 2.1.2.2]	Appendix I (QMP and QAPP for tests)
4.2 Quality Assurance Project Plan (QAPP) describing the specifies of the BWMS, the test facility, and other conditions affecting the design and implementation of the test procedures [Annex Part 2, 2.1.2.3]	Appendix I (QMP and QAPP for tests)
4.3 Shipboard Test Plan and Report [Annex Part 2, 2.2.2.1]	Appendix F-1 (Certificate of Shipboard test)
4.3.1 Documentation that treatment rated capacity of BWMS was appropriate for ship [Annex Part 2, 2.2.2.2]	Appendix F-3 (Operation data)
4.3.2 Documentation that the volume and pumping rate of ballast water during test was consistent with normal ballast operations of ship [Annex Part 2, 2.2.2.3]	Appendix F-3 (Operation data)
4.3.3 Documentation of all test cycles, demonstrating three valid consecutive test cycles showing discharge of treated ballast water meeting regulation	Chapter 1.7 (7~8 pages) of Appendix F-1 (Certificate of Shipboard test)

Page Number: 102 / 106

AquaStar™ Ballast Water Management System

3. Application of AMS and US Type Approval

D-2 standard [Annex Part 2, 2.2.2.4 and 2.2.2.8]		
4.3.4 Tests meet minimum organism concentrations during uptake of more	Chapter 1.7 (7~8 pages) of	
than 10 times the maximum permitted values in regulation D-2.1 [Annex	Appendix F-1 (Certificate of	
Part 2, 2.2.2.5]	Shipboard test)	
4.3.5 Documentation that sampling regime was appropriate, either by	Chapter 1.5 (6 pag <mark>e) of A</mark> ppendix	
meeting G8 recommendations for control and treated ballast water	F-1 (Certificate of Shipboard test)	
including:		
1) Control tank replicates;		
2) Treatment tank replicates		
3) Sample sizes; or		
4) By documenting appropriate validation of sample volumes and		
numbers, per EPA ETV [Annex Part 2, 2.2.2.6]		
4.3.6 Documentation that test cycles completed over at least six months	Chapter 1.6 (6 page) of Appendix	
[Annex Part 2, 2.2.2.7]	F-1 (Certificate of Shipboard test)	
4.3.7 Documentation of source water characterization for salinity,	ATTACHMENT Ⅲ (11~16 pages) of	
temperature, POC and TSS [Annex Part 2, 2.2.2.9]	Appendix F-1 (Certificate of	
	Shipboard test)	
4.3.8 Documentation of system operations, including:	1): Appendix F-2 (Volume and	
1) Volume and locations of uptake & discharge volume;	location of uptake & discharge)	
2) Possible reasons for unsuccessful test cycle or failure of a cycle to	2): N/A (Not Applicable) 3): Appendix F-4 (Check list of	
meet D-2 standard;	maintenance)	
3) Scheduled maintenance	4): N/A (Not Applicable)	
4) Unscheduled maintenance and repair	5): Appendix F-3 (Operation data)	
5) Appropriate engineering parameters; and	6): Appendix C-2 (Operation	
6) Proper functioning of control & monitoring equipment [Annex Part 2,	program user's manual)	
2.2.2.10]		2001

Page Number: 103 / 106

3. Application of AMS and US Type Approval

4.4 Land-based Test Plan and Report [Annex Part 2, 2.4]	Appendix D-1 (Certificate of Land-	
	based test)	
4.4.1 Description of test set-up, including:	1): Appendix D-2 (P&ID)	
1) Arrangement of BWMS [Annex Part 2, 2.3.9]	2): Appendix D-2 (P&ID)	
2) Piping and pumping arrangements [Annex Part 2, 2.3.9]	3): Appendix D-3 (Tank	
3) Tank specifications (treatment and control) [Annex Part 2, 2.3.10]	specifications)	
4) Facilities for representative sampling [Annex Part 2, 2.3.12]	4): Appendix D-4 (Sampling port)	
5) Augmentation facilities for DOC, POC, TSS and standard test	5): Appendix D-6 (Augmentation	
organisms if used [Annex Part 2, 2.3.12]; and	facility)	
6) Monitoring facilities for environmental parameters including pH,	6): Appendix D-4 (Sampling port) and chapter 1.1 ~ 1.7 (5~10	
temperature, salinity, dissolved oxygen, TSS, DOC, POC and turbidity	pages) of Appendix D-1	
[Annex Part 2, 2.3.12]	(Certificate of Land-based test)	
4.4.2 Documentation system was operated at treatment rated capacity, or	Appendix D-5 (Operation data)	
	Appendix D-3 (Operation data)	
scaled as follow:		
1) 200 M3/hr <trc<1,000 1:5;<="" downscaled="" hr="" m3="" more="" no="" td="" than="" –=""><td></td><td></td></trc<1,000>		
2) TRC > 1,000 M3/hr – downscaled no more than 1:100; and		
3) Documentation of mathematical modeling and/or calculations		
demonstrating downscaling used would not affect functioning and		
effectiveness onboard ship at full scale for which certification is intended		
[Annex Part 2, 2.3.13]		
4.4.3 Description of cleaning procedures for test set-up before starting	Appendix D-7 (Washing check list)	
testing, and between test cycles [Annex Part 2, 2.3.11]		
4.4.4 Description of sampling and analysis procedures for organisms and	1), 2) and 3): Appendix I-1 (QMP	
environmental/water quality parameters, including:	and QAPP of Land-based test)	
1) Identification of standard methods [Annex Part 2, 4.2]	4): Appendix D-4 (Sampling port)	
2) Validation of non-standard methods [Annex Part 2, 4.3]	and Appendix D-6 (Augmentation	

Page Number: 104 / 106

3. Application of AMS and US Type Approval

3) Validation of appropriateness of sample processing times [Annex Part	facility)	
2, 2.3.34]; and		
4) Description and validation of facilities and procedures for collecting		
representative samples [Annex Part 2, 2.3.31; 2.3.32; 2.2.23; 2.3.28]		
4.4.5 Results of all analyses for organisms, challenge conditions and BWMS	Chapter 1.7 (8~10 pages) of	
performance indicators [Annex Part 2, 2.3.23; 2.3.25]	Appendix D-1 (Certificate of Land-	
	based test)	
4.4.6 Documentation the BWMS was operated and performed as designed	Appendix D-5 (Operation data)	
within its specified parameters including power consumption, flow rate,		
etc. [Annex Part 2, 2.3.4; 2.3.24]		
4.4.7 Documentation of all test cycles, demonstrating 5 valid tests with	Chapter 1.7 (8~10 pages) of	
treated water meeting the D-2 discharge standard for each salinity	Appendix D-1 (Certificate of Land-	
regime for which testing was conducted [Annex Part 2, 2.3.1; 2.3.17;	based test)	
2.3.18; 2.3.19; 2.3.20; 2.3.36]		
4.5 Environmental Testing [Annex Part 3]		
4.5.1. Documentation of vibration tests [Annex Part 3, 3.4-3.7]	Appendix E-1, E-2 and E-3	
	(Certificate of Environmental	
	test_H-300, H-650 and sensors)	
4.5.2 Documentation of temperature tests [Annex Part 3, 3.8-3.10]	Appendix E-1, E-2 and E-3	
	(Certificate of Environmental	
	test_H-300, H-650 and sensors)	
4.5.3 Documentation of humidity tests [Annex Part 3, 3.11]	Appendix E-1, E-2 and E-3	
	(Certificate of Environmental	
	test_H-300, H-650 and sensors)	
4.5.4 Documentation of heavy seas protection tests [Annex Part 3, 3.12]	Appendix E-1, E-2 and E-3	
	(Certificate of Environmental	
	test_H-300, H-650 and sensors)	

3. Application of AMS and US Type Approval

4.5.5 Documentation of power supply fluctuation tests [Annex Part 3, 3.13]	Appendix E-1, E-2 and E-3	
	(Certificate of Environmental	
	test_H-300, H-650 and sensors)	
4.5.6 Documentation of inclination tests [Annex Part 3, 3.14]	Appendix E-1, E-2 and E-3	
	(Certificate of Environmental	
	test_H-300, H-650 and sensors)	



Page Number: 106 / 106

AquaStar™ Ballast Water Management System