

32/95

55

Kennedy/Jenks Consultants

GROUNDWATER MONITORING
DATA SUMMARY REPORT
THIRD QUARTER 1995

DOUGLAS AIRCRAFT COMPANY C-6 FACILITY
TORRANCE, CALIFORNIA

KJ 944016.01

OCTOBER 1995

GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER, 1995

DOUGLAS AIRCRAFT COMPANY C-6 FACILITY
TORRANCE, CALIFORNIA

K/J 944016.01

TABLE OF CONTENTS

<u>SECTION</u>	<u>TITLE</u>	<u>PAGE</u>
1.0	INTRODUCTION	1
2.0	QUARTERLY MONITORING PROGRAM	1
	2.1 Groundwater Sampling Procedures	1
	2.2 Field QA/QC Procedures	2
3.0	EVALUATION OF ANALYTICAL RESULTS	2
	3.1 Groundwater Gradient	2
	3.2 Analytical Data	3

LIST OF TABLES

<u>TABLE</u>	<u>TITLE</u>
1	Observation Well Construction Details
2	Cumulative Summary of Observation Well Data (EPA Method 8240/8260)
3	Cumulative Summary of Observation Well Data (EPA Method 8240/8260), Minor Constituents
4	Summary of Groundwater Elevation Data

TABLE OF CONTENTS
(continued)

LIST OF FIGURES

<u>FIGURE</u>	<u>TITLE</u>
1	Site Vicinity Map
2	Groundwater Observation Well Locations
3	Observation Well Detected Chemical Concentrations, September 1995 Sampling Event
4	Estimated Groundwater Elevation Contour Map, Shallow Zone, September 1995 Sampling Event
5	Chemical Concentration Profiles November 1991 to September 1995

APPENDICES

<u>APPENDIX</u>	<u>TITLE</u>
A	Laboratory Data Sheets
B	Laboratory/Field Quality Control Data Sheets
C	Groundwater Purge and Sample Forms
D	Chain-of-Custody Records

1.0 INTRODUCTION

The Douglas Aircraft Company (DAC) C-6 Facility is located at 19503 South Normandie Avenue, Torrance, California (Figure 1). Quarterly groundwater sampling is being conducted in response to the California Regional Water Quality Control Board - Los Angeles Region correspondence to DAC, dated 7 April 1992. This report summarizes laboratory analytical data generated through the chemical analysis of groundwater samples collected during the period of 6 and 7 September 1995, Third Quarter 1995.

2.0 QUARTERLY MONITORING PROGRAM

Third Quarter 1995 groundwater sampling was performed in accordance with standard sampling procedures. Static water level depths were measured on 6 September 1995 prior to initiating purging of groundwater from any observation wells and again on 20 September 1995 to confirm the measured depths. Static water depths on monitoring wells (MW-9, MW-18 and MW-19) located in the southern portion of the DAC property installed for the Montrose Chemical Corporation Remedial Investigation were not measured for this quarter.

Groundwater samples were collected from the following fifteen wells (Figure 2) and chemically analyzed for volatile organic compounds (VOCs) by EPA Method 8240/8260 for the Third Quarter 1995.

WCC-1S, WCC-2S, WCC-3S, WCC-4S, WCC-5S, WCC-6S, WCC-7S,
WCC-8S, WCC-9S, WCC-10S, WCC-11S, WCC-12S, WCC-1D, WCC-3D,
and DAC-P1.

Table 1 summarizes observation well construction details. Tables 2 and 3 summarize the results of chemical analysis of groundwater samples and duplicates for major and minor constituents at the C-6 facility, respectively. Chemicals detected in samples from each observation well are shown in Figure 3. Table 4 summarizes available measured groundwater elevations to date. Estimated groundwater elevation contours for the Third Quarter are presented in Figure 4. Historical chemical concentration profiles for the indicator chemicals trichloroethene and 1,1-dichloroethene are shown in Figure 5. Copies of laboratory data sheets, laboratory/field Quality Control data sheets, groundwater purge and sample forms, and Chain-of-Custody records are included in Appendices A, B, C, and D respectively.

2.1 Groundwater Sampling Procedures

Prior to collecting groundwater samples from each well, groundwater was purged using an electrical submersible pump that was temporarily installed in the observation well. After lowering the pump to the approximate mid-point of the saturated well screen, approximately three to five wetted casing volumes of groundwater were purged from the well until the following groundwater monitoring parameters had stabilized to within 10% of preceding values: pH, electrical conductivity, and temperature. Purged groundwater was stored onsite in DOT approved 55 gallon barrels pending the results of laboratory analysis of samples.

Following groundwater purging, the submersible pump was removed from the well and a representative groundwater sample was collected using a steam-cleaned stainless steel point-source bailer equipped with top and bottom ball-check valves. The bailer was lowered to the approximate mid-point of the saturated well screen interval and retrieved to ground surface. The contents of the bailer were drained into three labeled 40-ml capacity vials, preserved with HCl.

2.2 Field QA/QC Procedures

Duplicate groundwater samples were collected for the sampling rounds on 6 and 7 September 1995 for quality control purposes. The duplicates were collected in three HCl-preserved vials each and identified by inserting the collection date after "DW-" (DW-090695 and DW-090795). No further sample identification was provided to the laboratory. Samples DW-090695 and DW-090795 were taken from observation wells WCC-11S and WCC-6S, respectively.

Following decontamination of the bailer by steam-cleaning, and prior to collection of groundwater samples from the successive well, an equipment rinsate blank was prepared for laboratory analysis. The equipment rinsate blank was prepared by pouring Reagent Grade II water, prepared by the analytical laboratory, through the bailer and discharge spigot and collecting the rinsate in two 40-ml vial preserved with HCl. The blank was identified following a similar protocol to that used for duplicate water samples and is identified as "EB090795". The wells sampled before and after rinsate blank preparation were recorded. EB090795 was collected after sampling well DAC P-1, the last well sampled that day. A trip blank was also analyzed for the second day of sampling and shipping and is identified as TB-090795.

All groundwater, duplicate, and field blank samples were transported in ice-cooled chests to Curtis & Tompkins, Ltd., General Analytical Laboratory, Irvine, California using U.S. EPA-recommended Chain-of-Custody procedures.

3.0 EVALUATION OF ANALYTICAL RESULTS

3.1 Groundwater Gradient

Groundwater levels were measured prior to sampling on 6 September 1995, and again on 20 September 1995 to confirm the measurements (Table 4 and Appendix C). The shallow zone groundwater elevations measured on 20 September 1995 range from 15.59 feet below mean sea level (MSL) to 16.82 feet below MSL. An estimated potentiometric surface map for the shallow zone as measured on this day is presented as Figure 4. The groundwater gradient in the shallow zone was generally south-southeast with a southerly directed trough-like depression between observation wells WCC-10S and WCC-12S.

Insufficient data (two wells) are available to define the groundwater gradient in the deeper zone. Groundwater elevation in the two wells (WCC-1D and WCC-3D) is approximately 16.60 and 16.47 feet below MSL, respectively.

3.2 Analytical Data

The results of chemical analysis of groundwater and duplicate samples are summarized in Tables 2 and 3. Table 2 lists major constituents and Table 3 lists additional minor constituents of samples tested. The duplicate groundwater samples are indicated by an asterisk and are presented with the "original" groundwater samples. These tables include cumulative analytical data for all monitoring wells and detection limits (where available) for the listed chemicals.

The following observations are noted:

- Data for groundwater samples collected from well DAC-P1, located at the upgradient property boundary, indicate a TCE concentration of 13,000 micrograms per liter ($\mu\text{g}/\text{L}$) coming onto DAC's property. This test result shows a decrease relative to prior sampling events, but is within the historical range. Other chemicals detected in well DAC-P1 include 1,1-DCE, cis-1,2-DCE, chloroform and toluene. These chemicals were detected at concentrations less than 100 $\mu\text{g}/\text{L}$. DAC-P1 is screened in the shallow zone.
- Background concentrations of TCE and 1,1-DCE in the shallow zone upgradient or cross gradient wells WCC-10S, WCC-2S, and WCC-11S increased slightly, but remain in the range of 100 to 200 $\mu\text{g}/\text{L}$ of TCE and tens of $\mu\text{g}/\text{L}$ of 1,1-DCE.
- Groundwater elevation data (Figure 4) and chemical concentration data (Figure 3) indicate that chemical transport in the shallow zone is in a generally southerly to southeasterly direction in the vicinity of buildings 36 and 41. Most chemical concentration data from the eastern boundary observation wells (WCC-5S, and WCC-9S) are within the same range or lower than upgradient or cross gradient "background level" wells (WCC-10S, WCC-2S and WCC-11S).
- WCC-3S data showed a significant decrease in 1,1-DCE and toluene over recent historical data.
- WCC-6S data showed significant decrease in 1,1-DCE, 1,1,1-TCA, MIBK, cis-1,2-DCE, and toluene over the previous sampling event.
- Decreases in 1,1-DCE and TCE were also observed in wells WCC-1S and WCC-8S.
- WCC-3D data showed significant increases in 1,1-DCA, 1,1,1-TCA, TCE and toluene compared to concentrations observed last quarter. However, last quarter's data was relatively low, and this quarter's data is more consistent with other historical data.
- Chemical concentration variances within all observation wells (other than WCC-3D discussed above) were typical of historical ranges.
- Analytical data from the equipment rinsate blanks, sample duplicates, trip blanks, and laboratory spikes and duplicates are indicative of reliable data.

TABLES

OBSERVATION WELL CONSTRUCTION DETAILS
GROUNDWATER MONITORING DATA SUMMARY REPORT

THIRD QUARTER, 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CALIFORNIA

KJ 944016.01

Well	Date Constructed	Well Diameter (inches)	Total Depth of Borehole (Feet)	Depth of Screened Interval (Feet)	Depth to top of Sand Filter Pack (Feet)	Well Casing Material and Slot Size		Hydrogeologic Unit Screened
WCC-1S ¹	3/26/87	2	91	78-88	72	Schedule 40 PVC	0.020-inch Slots	Shallow
WCC-2S ¹	10/28/87	4	90.5	70-90	63	Schedule 40 PVC	0.010-inch Slots	Shallow
WCC-3S ¹	10/26/87	4	92	69-89	64	Schedule 40 PVC	0.010-inch Slots	Shallow
WCC-4S ¹	10/27/87	4	91.5	70.5-90.5	65	Schedule 40 PVC	0.010-inch Slots	Shallow
WCC-5S ¹	11/24/87	4	91	60.5-91	58.5	Schedule 40 PVC	0.010-inch Slots	Shallow
WCC-6S ²	9/22/89	4	91	60-90	N/A ³	Schedule 40 PVC	0.010-inch Slots	Shallow
WCC-7S ²	6/8/89	4	90.5	60-90	54	Schedule 40 PVC	0.010-inch Slots	Shallow
WCC-8S ²	6/12/89	4	90	59.5-89.5	54	Schedule 40 PVC	0.010-inch Slots	Shallow
WCC-9S ²	9/21/89	4	91.5	60-90	55	Schedule 40 PVC	0.010-inch Slots	Shallow
WCC-10S	6/7/89	4	90.8	60-90	54	Schedule 40 PVC	0.010-inch Slots	Shallow
WCC-11S	N/A	4	N/A	60-90(?)	N/A	Schedule 40 PVC	0.010-inch Slots	Shallow
WCC-12S	N/A	4	N/A	60-90(?)	N/A	Schedule 40 PVC	0.010-inch Slots	Shallow
DAC-P ¹	9/25/89	4	N/A	60-90(?)	N/A	Schedule 40 PVC	0.010-inch Slots	Shallow
WCC-1D ²	6/30/89	4	140	120-140	115	Schedule 40 PVC	0.010-inch Slots	Deeper
WCC-3D ²	6/27/89	4	140	120-140	114	Schedule 40 PVC	0.010-inch Slots	Deeper
MW-8 ⁴	5/10/89	4	85	65-80	62	PVC blank and 316 Stainless Steel	0.020-inch Slot Screen	Shallow
MW-9 ⁴	5/9/89	4	85	66-81	61	PVC blank and 316 Stainless Steel	0.020-inch Slot Screen	Shallow
MW-18 ⁴	3/29/90	4	84	68-83	67	PVC blank and 316 Stainless Steel	0.020-inch Slot Screen	Shallow
MW-19 ⁴	3/30/90	4	80	63-79	62	PVC blank and 316 Stainless Steel	0.020-inch Slot Screen	Shallow

NOTES:

1. Data from Woodward-Clyde Consultants Phase II Report, May 1988
2. Data from Woodward-Clyde Consultants Phase III Report, March 1990
3. N/A = Not Available
4. Data from Hargis + Associates, Final Draft, Remedial Investigation, Montrose Site, Torrance, Ca, October 1992

TABLE 2
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MAJOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

1 - Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 2
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MAJOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

COMPOUNDS DETECTED BY EPA METHOD 8240 OR EPA METHOD 8240/8260 - All results in ug/l.

WELL I.D.	SAMPLE DATE	1,1-DCE	1,1-DCA	1,1,1-TCA	TCE	MIBK	cis-1,2-DCE	trans-1,2-DCE	CHLOROFORM	BENZENE	TOLUENE	MEK
WCC-3S	11/02/87	38,000	-	110,000	10,000	54,000	-	-	-	80,000	-	-
	11/12/87	88,000	1,000	54,000	11,000	70,000	<500	1,000	<500	140,000	32,000	-
	07/13/89	18,000	<500	56,000	7,700	<3000	<500	660	<1,000	56,000	-	-
	08/23/89	56,000	<1,000	78,000	6,000	<5000	<1,000	<1,000	250	27,000	12,000	<10,000
	11/14/91	12,000	400	6,900	7,900	70,000	550	550	<5,000	51,000	52,000	<3,000
	06/17/92	25,000	<5,000	13,000	13,000	100,000	<5,000	<5,000	<500	44,000	4,000	<500
	09/23/92	22,000	<500	7,800	12,000	82,000	<500	<500	<500	42,000/42,000	<2,000	<50/(<50)
	12/09/92	21,000	<500	5,800	11,000	90,000	700	600	640/670	210	37,000	<8,000/660
'03/18/93	20,000/20,000	650/510	21,000/22,000	8,800/8,800	44,000/45,000	650/640	<100	<100	<400/10	280	50,000	<4,000
06/08/93	16,000	420	5,900	8,600	79,000	520	480	<200	<200	220	25,000	<4,000
*08/25/93	21,000/20,000	500/560	10,000/9,500	11,000/9,700	50,000/49,000	670/700	680/710	<200	<200	<400/250	23,000	<4000
11/19/93	26,000	690	19,000	10,000	47,000	1,100	840	<200	<200	200	35,000	<10000/(<10000)
2/24/94	15,000	310	9,600	2,500	15,000	2,500	360	<200	<200	200	40,000	<4,000
6/13/94	13,000	310	6,200	820	9,900	4,100	360	<200	<200	230	39,000	<8000
*9/9/94	23,000/25,000	520/560	9,000/9,800	<500/(<500)	3,400	6,000/640	530	<200	<500/(<500)	220	40,000	<4,000
12/22/94	20,000	440	6,700	390	4,600	6,200	670	<200	<200	200	31,000	<200
3/14/95	24,000	570	8,700	2,300	4,600	6,200	500	<400	<400	220	-	-
6/13/95	22,000	450	4,800	1,200	6,600	6,300	520	76	76	-	-	-
9/7/95	13,000	480	4,100	910	4,600	6,000	-	-	-	-	-	-
WCC-4S	11/02/87	360	-	14	700	-	-	2	2	-	-	-
	11/12/87	1,200	-	35	690	-	-	-	-	-	-	-
	7/13/89	170	<3	11	270	-	10	<3	<3	<3	<3	<5
	03/23/89	360	<5	7	410	<20	15	<5	<5	<5	<5	<5
	11/18/91	1,000	<25	20	2,200	<30	-	-	<25	<25	<25	<50
06/17/92	920	<10	20	1,500	<50	<10	<10	10	10	<10	<10	<50
09/23/92	1,400	<10	20	1,900	<50	10	<10	10	<10	<10	<10	<50
12/08/92	1,000	<10	20	1,600	<50	6	<4	4	4	9	<80	<80
03/17/93	810	8	14	1,200	<5	8	5	5	6	<2	<2	<10
06/08/93	1,300	<10	12	1,800	<100	10	<10	<10	<10	<10	<10	<200
08/25/93	1,100	<10	10	1,400	<100	6	5	5	5	<10	<10	<200
11/19/93	610	17	8	700	<40	8.7	7.2	5.1	6.4	<4	<4	<80
2/24/94	1,100	5.8	8.8	980	<40	7.1	5.2	4.4	4.4	<40	<40	<60
6/4/94	800	<4	5	940	<40	20	<20	<20	<20	<20	<20	<400
9/9/94	1,000	<20	<20	1,300	<200	750	<10	<10	<10	<10	<10	<200
12/22/94	670	<10	4.9	450	<40	4.9	<4	<4	<4	<4	<4	<80
3/14/95	400	9.8	4.9	1,100	<6.6	7.9	<6.6	7	7	<6.6	<6.6	<130
6/13/95	1,100	8.6	6	1,200	<10	9	7	7	7	<5	<5	<10
9/7/95	910	8	-	-	-	-	-	-	-	-	-	-

1 • Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 2
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MAJOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

WELL I.D.	SAMPLE DATE	COMPOUNDS DETECTED BY EPA METHOD 8240 OR EPA METHOD 8240/8260 - All results in ug/l.						BENZENE	TOLUENE	MEK	
		1,1-DCE	1,1-DCA	1,1-TCA	TCE	MBK	cis-1,2-DCE	trans-1,2-DCE	CHLOROFORM		
WCC-5S	11/30/87	7	-	1	-	-	-	-	-	1	
	01/08/88	4	<1	10	-	<1/<1	-	<1/<1	-	-	
	*07/13/89	3/3	<1	13/12	<5	<1	6/6	<1	<1	<1/<1	
	08/23/89	<1	<1	12	<5	<1	4	<1	<1	-	
	11/19/91	20	-	-	8	-	-	-	-	-	
	06/15/92	28	<5	-	7	<10	-	<5	<5	<10	
	09/21/92	21	<1	<1	5	<5	<1	<1	<1	<5	
	12/07/92	21	<1	<1	5	<5	<1	<1	<1	<5	
	03/16/93	18	<2	<2	4	<5	<2	<2	<2	<10	
	06/07/93	22	<2	<2	4	<20	<2	<2	<2	<40	
	08/24/93	23	<2	<2	5	<20	<2	<2	<2	<40	
	11/18/93	21	<2	<2	3	<20	<2	<2	<2	<40	
	2/23/94	20	<2	<2	4	<20	<2	<2	<2	<40	
	*6/10/94	25/25	<2/<2	<2/<2	3.4/3.4	<20/<20	<2/<2	<2/<2	<2/<2	<40/<40	
	9/8/94	18	<2	<2	3.3	<20	<2	<2	<2	<40	
	12/21/94	18	<2	<2	2.9	<20	<2	<2	<2	<40	
	3/13/95	14	<2	<2	2.8	<20	<2	<2	<2	<40	
	6/12/95	19	<2	<2	3.2	<20	<2	<2	<2	<40	
	9/6/95	18	<5	<5	<5	<10	<5	<5	<5	<10	
WCC-6S	10/06/89	210	4	130	140	<5	12	7	<1	<1	
	11/16/91	5,800	5,000	5,000	17,000	-	-	-	35,000	21,000	
	06/17/92	5,400	<500	2,100	3,000	7,600	<500	<500	15,000	6,300	
	09/23/92	5,900	94	1,300	3,100	7,500	200	170	10,000	3,600	
	*12/09/92	3,700/5,600	80/<100	680/1,400	2,700/3,200	3,400/<500	200/200	100/200	5,000/10,000	3,000/5,000	
	03/17/93	3,200	50	1,200	1,400	13,000	<10	80	15	3,800	
	06/08/93	5,500	<100	1,900	2,100	13,000	260	120	<100	21,000	
	08/25/93	5,400	<100	2,100	1,900	11,000	630	130	<100	19,000	
	11/19/93	2,200	42	440	670	4,700	480	<10	24	7,600	
	2/24/94	11,000	91	2,200	1,800	13,000	1,400	140	21	4,900	
	*6/13/94	5,800/6,300	87/<100	1,900/1,500	1,400/1,300	4,400/5,200	1,600/1,400	130/100	52/<100	20,000	4,400
	9/9/94	Not sampled; well head obstructed	<200	1,300	1,900	4,800	2,500	<200	<200	12,000/<13,000	<4,000
	12/22/94	3,000	38	200	930	390	850	<20	25	2,300	<400
	3/14/95	9,800	130	810	510	450	4,200	180	82	8,400	<400
	6/13/95	4,300/3,800	55/70	370/310	620/520	240/180	2,400/2,200	83/99	14/19	50/56	2,900/2,500
	9/7/95										12/11

1 * Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 2
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MAJOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

COMPOUNDS DETECTED BY EPA METHOD 8240 OR EPA METHOD 8240/8260 - All results in ug/L.

WELL ID.	SAMPLE DATE	1,1-DCE	1,1-DCA	1,1,1-TCA	TCE	MIBK	cis-1,2-DCE	trans-1,2-DCE	CHLOROFORM	BENZENE	TOLUENE	MEK
WCC-7S	07/13/89	850	<10	110	1,300	<50	26	11	<10	<10	<10	-
	08/23/89	1,100	<30	66	1,400	<100	31	<30	<30	<30	<30	-
	11/18/91	390	-	-	1,200	-	-	-	-	-	-	-
	06/17/92	230	<5	<5	560	<10	<5	<5	<5	<5	<5	<10
	09/23/92	140	<5	<5	570	<30	<5	<5	<5	<5	<5	<30
	12/08/92	140	<5	<5	430	<30	<5	<5	<5	<5	<5	<30
	03/17/93	77	<2	<2	200	<5	4	<2	<2	<2	<2	<10
	06/07/93	120	<2	<2	330	<20	4	<2	<2	<2	<2	<40
	08/25/93	70	<4	<4	210	<40	4	<4	<4	<4	<4	<80
	11/19/93	56	<2	<2	130	<20	<2	<2	<2	<2	<2	<40
	2/24/94	75	<2	<2	140	<20	2.5	<2	<2	<2	<2	<40
	6/13/94	58	<2	<2	110	<20	2.5	<2	<2	<2	<2	<40
	9/8/94	50	13	<2	250	<20	<2	<2	<2	<2	<2	<40
	12/22/94	94	<2	<2	94	<20	<2	<2	<2	<2	<2	<40
	3/14/95	53	<2	<2	84	<20	<2	<2	<2	<2	<2	<40
	*6/13/95	110/98	<2/<2	<2/<2	230/220	<20/<20	<2/<2	<2/<2	<2/<2	<2/<2	<2/<2	<40/<40
	9/7/95	150	<5	<5	200	<10	<5	<5	<5	<5	<5	<10
WCC-8S	07/13/89	430	<5	160	240	<30	7	9	<5	<5	<5	-
	08/23/89	820	<5	130	430	<30	7	5	<5	<5	<5	-
	11/15/91	2,600	-	400	3,000	<50/100	40	40	25	25	25	-
	*06/17/92	2,200/2,300	<25/<50	180/180	2,400/2,600	<25/<50	<25/<50	<25/<50	<25/<50	<25/<50	<25/<50	<50/<100
	09/23/92	2,800	<20	200	3,100	<100	<20	20	20	20	<20	<100
	12/08/92	2,000	<20	100	2,500	<100	20	30	20	20	<20	<100
	03/17/93	1,800	11	180	1,500	<5	15	26	10	15	<2	<10
	06/08/93	3,000	<20	300	2,000	<200	<20	40	<20	<20	<20	<400
	08/25/93	3,100	<20	330	2,200	<200	<20	45	<20	<20	<20	<400
	11/19/93	3,300	<20	330	2,000	<200	<20	50	<20	24	<20	<400
	2/24/94	3,400	<20	300	1,200	<200	<20	35	<20	<20	<20	<400
	6/13/94	4,000	<40	290	2,200	<400	<40	44	<40	<40	<40	<800
	9/9/94	4,600	<50	280	3,100	<500	<50	<50	<50	<50	<50	<1000
	12/22/94	4,000	<20	230	2,100	<200	<20	43	<20	25	<20	<400
	3/14/95	4,500	<40	220	2,600	<400	<40	41	<40	<40	<40	<800
	6/13/95	4,200	<40	150	2,400	<400	<40	<40	<40	<40	<40	<800
	9/7/95	2,200	10	110	1,700	<10	15	28	9	22	<5	<10

1 • Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 2
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MAJOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

1 - Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 2
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MAJOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

1 * Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 2
 SUMMARY OF GROUNDWATER ANALYTICAL DATA - MAJOR CONSTITUENTS
 GROUNDWATER MONITORING DATA SUMMARY REPORT
 THIRD QUARTER 1995
 DOUGLAS AIRCRAFT C-6 FACILITY
 TORRANCE, CA

COMPOUNDS DETECTED BY EPA METHOD 8240 OR EPA METHOD 8240/8260 - All results in ug/l.

WELL ID.	SAMPLE DATE	COMPOUNDS DETECTED BY EPA METHOD 8240 OR EPA METHOD 8240/8260 - All results in ug/l.						MEK				
		1,1-DCE	1,1-DCA	1,1,1-TCA	TCE	MBK	cis-1,2-DCE	trans-1,2-DCE	CHLOROFORM	BENZENE	TOLUENE	
DAC-P1	10/09/89	<200	<200	<200	17,000	<1,000	<200	<200	<200	<200	<200	<1,000
	06/17/92	<5	<5	<1/<1	21,000	<10	13	5	5	5	<5	<10
	*06/23/92	4/4			28,000/28,000	<5/<5	71/70	1/2	5/51	5/5		<5/<5
	12/09/92	<300	<500	<500	29,000	<3,000	<500	<500	<500	<500	<500	<3,000
	03/18/93	21	<2	44	21,000	7	68	2	44	5	5	<10
	06/08/93	<200	<100	<100	28,000	<1,000	<100	<100	<100	<100	130	<2,000
	08/25/93	<400	<200	<200	27,000	<2,000	<200	<200	<200	<200	300	<4,000
	11/19/93	<40	<20	<20	24,000	<200	81	<20	52	<20	<20	<400
	2/24/94	<40	<20	<20	20,000	<200	89	<20	47	<20	<20	<400
	6/13/94	<40	<20	<20	20,000	<200	92	<20	46	<20	<20	<400
	9/9/94	<400	<200	<200	18,000	<2,000	<200	<200	<200	<200	<200	<4,000
	12/22/94	<400	<200	<200	11,000	<2,000	<200	<200	<200	<200	<200	<4,000
	3/14/95	<400	<200	<200	21,000	<2,000	<200	<200	<200	<200	<200	<4,000
	6/13/95	<400	<200	<200	18,000	<2000	<200	<200	<200	<200	<200	<4,000
	9/7/95	12	<5	<5	13,000	<10	89	<5	33	<5	53	<10
WCC-1D	07/25/89	<1	<1	<1	2	<5	1	<1	<1	<1	<1	-
	08/23/89	<1	<1	<1	8	<5	<1	<1	<1	<1	<1	-
	1/15/91	90	-	8	40	230/210	<25/<25	<25/<25	<25/<25	<25/<25	<25/<25	<50/<80
	*06/15/92	1,500/1,300	<25/<25	63/64	8	<50/<65	<5	2	<1	<1	<1	<5
	09/22/92	180	<1	1	44	<5	<5/<5	2/<1	<1/<1	1/1	<1/1	<5/<5
	*12/07/92	160/150	<1/<1	8/160	41/6	<5/<5	3	<2	<2	<2	<2	<10
	03/16/93	200	<2	19	23	<5	<100/<40	<10/<4	<10/<4	<10/<4	<10/<4	<200/<80
	*06/08/93	500/480	<10/<4	14/17	71/72	<20	3	2	<2	<2	<2	<40
	08/24/93	540	<2	16	67	<20	3	3	<2	<2	<2	<40
	11/18/93	880	<2	16	110	<20	3	3	<2	<2	<2	<40
	2/23/94	140	<2	3	14	<20	<2	<2	<2	<2	<2	<40
	6/10/94	230	<2	37	24	<20	<2	<2	<2	<2	<2	<40
	9/8/94	210	<2	36	37	<20	<2	<2	<2	<2	<2	<40
	12/22/94	600	<2	10	71	<20	2,3	2,2	<2	<2	<2	<80
	3/13/95	240	<4	44	38	<40	<4	<4	<4	<4	<4	<40
	6/13/95	170	<2	21	<2	<20	2	<2	<2	<2	<2	<40
	9/6/95	150	<5	29	<5	<10	<5	<5	<5	<5	<5	<10

1 • Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 2
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MAJOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

COMPOUNDS DETECTED BY EPA METHOD 8240 OR EPA METHOD 8240/8260 - All results in ug/l.

WELL I.D.	SAMPLE DATE	1,1-DCE	1,1-DCA	1,1,1-TCA	TCE	MIBK	clis-1,2-DCE	trans-1,2-DCE	CHLOROFORM	BENZENE	TOLUENE	MEK
WCC-3D	07/25/89	<1	<10	49	4	<5	<10	<10	<1	<1	3	-
	08/23/89	<10	-	32	-	<50	-	-	<10	<10	<10	-
	11/14/91	20	-	60	-	-	-	-	-	-	-	-
	06/16/92	510	<5	880	23	<10	<5	<5	<5	<5	8	<10
	09/22/92	21	<1	27	2	<5	<1	<1	<1	<1	<1	<5
	12/07/92	120	<1	130	5	<5	<1	<1	1	<1	3	<5
	*03/16/93	950/1,000	6/6	2,000/2,000	50/47	<5/<5	2/2	9/9	<2/<2	<2/<2	6/6	<10/<10
	06/08/93	110	<2	110	6	<20	<2	<2	<2	<2	<2	<40
	08/24/93	120	<2	100	5	<20	<2	<2	<2	<2	3	<40
	*11/18/93	610/840	<2/<4	410/640	17/23	<20/<40	<2/4	<2/4	<4/<4	<4/<4	6/8	<40/<80
	2/23/94	370/420	<4/<4	530/590	23/25	<40/<40	<4/<4	<4/<4	<4/<4	<4/<4	12/13	<80/<80
	6/13/94	720	<10	1,300	96	<100	<10	<10	<10	<10	<10	<200
	9/9/94	3,700	<50	5,600	490	<500	<50	<50	<50	<50	<50	<1,000
	12/21/94	5,200	10	6,300	540	<40	15	22	<4	8.6	5,100	<80
	*3/14/95	3,300/3,200	<40/<20	4,000/3,900	370/380	<400/<200	<40/<20	<40/<20	<40/<20	<40/<20	3,200/3,400	<800/<400
	6/13/95	1,800	<10	2,100	200	<100	<10	<10	<10	<10	1,700	<200
	9/7/95	3,400	13	4,100	520	170	60	30	<5	13	4,700	<10

Notes:

ug/l = micrograms per liter
 1,1-DCE = Dichloroethene
 1,1-DCA = Dichloroethane

1,1,1-TCA = 1,1,1-Trichloroethane
 TCE = Trichloroethene

MIBK = Methyl Isobutyl ketone
 clis-1,2-DCE = clis-1,2-Dichloroethene

trans-1,2-DCE = trans-1,2-Dichloroethene
 MEK = Methyl ethyl ketone

1 • Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 3
 SUMMARY OF GROUNDWATER ANALYTICAL DATA - MINOR CONSTITUENTS
 GROUNDWATER MONITORING DATA SUMMARY REPORT
 THIRD QUARTER 1995
 DOUGLAS AIRCRAFT C-6 FACILITY
 TORRANCE, CA

WELL I.D.	SAMPLE DATE	COMPOUNDS DETECTED BY EPA METHOD 8240 OR EPA METHOD 8240/8260 - All results in ug/l.							Carbon Disulfide	Ethyl-Benzene	1,2-DCA
		Total Xylenes	Acetone	Trichloro-fluoromethane	Methylene Chloride	Carbon Tetrachloride	1,1,2-TCA	PCE			
WCC-1S	03/27/87	-	-	-	-	-	-	-	-	-	-
	04/13/87	-	-	-	-	-	-	-	-	-	-
	11/12/87	-	-	-	-	-	-	-	-	-	-
	07/13/89	-	-	-	-	-	-	-	-	-	-
	08/23/89	-	-	-	-	-	-	-	-	-	-
	11/18/91	-	-	-	-	-	-	-	-	-	-
	06/17/92	<300	-	-	-	-	-	-	-	-	-
	09/23/92	<5	<1	<1	4	<1	<1	<1	22	<1	<1
	12/09/92	<100	<30	<30	40	<30	<30	<30	<30	<30	<30
	03/18/93	<10	<2	<5	<10	<5	<2	<2	<5	<2	<2
	06/08/93	<400	<20	<20	<100	<20	<20	<20	<20	<20	<20
	08/25/93	<400	<20	<20	<40	<20	<40	<20	<20	<20	<20
	11/19/93	<400	<20	<20	<100	<20	<40	<20	<20	<20	<20
	2/24/94	<400	<20	<20	<100	<20	<40	<20	<20	<20	<20
	6/13/94	<200	<30	<10	<50	<10	<20	<10	<10	<10	<10
	9/9/94	<800	<120	<40	<200	<40	<80	<40	<40	<40	<40
	12/22/94	<400	<40	<20	<100	<20	<40	<20	<20	<20	<20
	3/14/95	<400	<40	<20	<100	<20	<40	<20	<20	<20	<20
	6/13/95	<400	<20	<20	<100	<20	<40	<20	<20	<20	<20
	9/7/95	<10	<5	<5	<5	<5	<5	<5	<5	<5	<5

1 * Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 3
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MINOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

1 : Duplicate sample also analyzed. 2 : Not Detected (Detection Limit not specified)

TABLE 3
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MINOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

1 * Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 3
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MINOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

1 * Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 3
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MINOR CONSTITUENTS
GROUNDWATER MONITORING DATA, SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

1 - Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 3
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MINOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

1 • Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 3
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MINOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

1 - Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

TABLE 3
SUMMARY OF GROUNDWATER ANALYTICAL DATA - MINOR CONSTITUENTS
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CA

COMPOUNDS DETECTED BY EPA METHOD 8240 OR EPA METHOD 8240/8260 - All results in ug/l.

WELL I.D.	SAMPLE DATE	Acetone	Total Xylenes	Trichloro-fluoromethane	Methylene Chloride	Carbon Tetrachloride	1,1,2-TCA	PCE	Carbon Disulfide	Ethyl-Benzene	1,2-DCA
WCC-1D	07/25/89	-	-	-	-	-	-	-	-	-	-
	08/23/89	-	-	-	-	-	-	-	-	-	-
	11/15/91	<50/<50	<1	4	11	<1	<1/<1	<1	<1	<1	<1
	*06/15/92	<5/<5	<1/<1	<1/<1	22	<1/<1	<1/<1	<1	<1/<1	<1	<1/<1
	09/22/92	<5/<5	<2	<5	<10	<5	<2	<2	<2	<2	<2
	*12/07/92	<10	<10/<4	<10/<4	<20/<10	<10/<4	<20/<8	<10/<4	<10/<4	<10/<4	<10/<4
	03/16/93	<200/<80	<40	<4	<4	<4	<4	<4	<2	<2	<2
	*06/08/93	<200/<80	<40	<2	<2	<2	<2	<2	<2	<2	<2
	08/24/93	<40	<2	<2	<10	<2	<2	<2	<2	<2	<2
	11/18/93	<40	<2	<2	<10	<2	<2	<2	<2	<2	<2
	2/23/94	<40	<2	<2	<20	<2	<2	<2	<2	<2	<2
	6/10/94	<40	<6	<2	<10	<2	<4	<2	<2	<2	<2
	9/8/94	<40	<2	<2	<10	<2	<4	<2	<2	<2	<2
	12/22/94	<40	<4	<2	<10	<2	<4	<4	<4	<4	<4
	3/13/95	<80	<8	<4	<20	<4	<8	<4	<4	<4	<4
	6/13/95	<40	<2	<2	<10	<2	<4	<2	<2	<2	<2
	9/6/95	<10	<5	<5	<5	<5	<5	<5	<5	<5	<5
WCC-3D	07/25/89	-	-	-	-	-	-	-	-	-	-
	08/23/89	-	-	-	-	-	-	-	-	-	-
	11/14/91	<30	<1	1	8	<1	<1	<1	<1	<1	<1
	06/16/92	<5	<1	<1	1	<1	<1	<1	<1	<1	<1
	09/22/92	<5	<2	<2	<5/<5	<10/<10	<5/<5	<2/<2	<2/<2	<2/<2	<2/<2
	*12/07/92	<5	<2	<2	<4	<4	<4	<4	<2	<2	<2
	*03/16/93	<10/<10	<2	<2	<2	<2	<2	<2	<2	<2	<2
	<40	<2	<2	<2	<4	<4	<4	<4	<2	<2	<2
	06/08/93	<40	<2	<2	<2	<4	<4	<4	<2	<2	<2
	08/24/93	<40	<2	<2	<4	<10/<20	<2/<4	<4/<8	<2/<4	<2/<4	<2/<4
	*11/18/93	<40/<80	<2/<4	<4	<20	<4	<8	<4	<4	<4	<4
	2/23/94	<80	<4	<4	<50	<10	<20	<10	<10	<10	<10
	6/13/94	<200	<30	<10	<50	<50	<100	<50	<50	<50	<50
	9/9/94	<1000	<150	<8	<4	<20	<4	<4	<4	<4	<4
	12/21/94	<80	<80	<40/<40	<40/<20	<200/<100	<80/<40	<40/<20	<40/<20	<40/<20	<40/<20
	*3/14/95	<800/<400	<200	<10	<10	<50	<10	<10	<10	<10	<10
	6/13/95	<200	<8	<10	<5	<5	<5	<5	<5	<5	<5
	9/7/95	<10	-	-	-	-	-	-	-	-	-

Notes:
 ug/l = micrograms per liter
 PCE = Tetrachloroethane
 1,1,2-TCA=1,1,2-Trichloroethane
 1,2-DCA = 1,2-Dichloroethane

1 • Duplicate sample also analyzed. 2 - Not Detected (Detection Limit not specified)

SUMMARY OF GROUNDWATER ELEVATION DATA

THIRD QUARTER 1995

DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CALIFORNIA

KJ 944016.01

Observation Well	Reference Point ¹ Elevation (Feet Above MSL) ²	Water Level Elevation (Feet Above Mean Sea Level)										
		4/9/93	6/7/93	8/24/93	11/18/93	2/23/94	6/10/94	9/8/94	12/21/94	3/13/95	6/12/95	9/20/95
WCC-1S	50.7	-18.79	-18.75	-18.25	-18	-17.61	-17.23	-17.25	-17.12	-17.12	-16.53	-16.27
WCC-2S	50.59	-18.64	-18.63	-18.15	-17.87	-17.49	-17.07	-17.2	-17.17	-17.08	-16.37	-16.19
WCC-3S	51.19	-18.83	-18.82	-18.36	-18.01	-17.67	-17.19	-17.31	-17.28	-17.22	-16.58	-16.37
WCC-4S	49.69	-18.86	-18.78	-18.37	-18.16	-17.77	-17.32	-17.37	-17.31	-17.23	-16.61	-16.38
WCC-5S	48.22	-18.83	-18.78	-18.38	-18.13	-17.78	-17.33	-17.33	-17.25	-17.19	-16.56	-16.35
WCC-6S	50.95	-19.03	-18.97	-18.55	-18.32	-17.92	-17.48	NM*	-17.45	-17.36	-16.75	-16.64
WCC-7S	48.29	-19.3	-19.23	-18.83	-18.6	-18.22	-17.82	-17.8	-17.74	-17.54	-17.03	-16.82
WCC-8S	50.56	-18.69	-18.61	-18.19	-17.89	-17.49	-17.11	-17.14	-17.12	-17.29	-16.42	-16.16
WCC-9S	47.01	-19.09	-19.09	-18.69	-18.42	-18.09	-18.63	-19.08	-17.51	-17.41	-16.79	-16.64
WCC-10S	51.12	-18.42	-18.33	-17.83	-17.54	-17.07	-16.67	-17.03	-16.97	-16.56	-16.05	-15.89
WCC-11S	49.97	-18.13	-18.04	-17.6	-17.36	-16.96	-16.45	-16.58	-16.63	-16.48	-15.83	-15.59
WCC-12S	46.92	-19.26	-19.2	-18.78	-18.58	-18.13	-17.74	-17.79	-17.67	-17.63	-17.00	-16.79
DAC-P1	52.44	-17.46	-17.38	-17.03	-16.76	-16.74	-16.6	-16.48	-16.26	-16.41	-15.94	-15.66
WCC-1D	50.45	-19.1	-19	-18.53	-18.34	-17.83	-17.47	-17.66	-17.55	-17.36	-16.79	-16.60
WCC-3D	51.18	-18.87	-18.85	-18.4	-18.18	-18	-17.39	-17.47	-17.42	-17.27	-16.67	-16.47
MW-8 ⁶	49.09	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
MW-9 ⁶	48.67	NA	-20.58	NA	NA	NA	NA	NA	NA	NA	NA	NA
MW-18 ⁶	50.29	NA	-20.88	NA	NA	NA	NA	NA	NA	NA	-18.91	NA
MW-19 ⁶	46.55	NA	-20.13	NA	NA	NA	NA	NA	NA	NA	-18.06	NA

Notes:

1. Reference point is north side, top of well casing
 2. Reference point elevation measured by Hargis + Associates, Inc.
 3. Data taken from Woodward-Clyde Consultants Phase II Report, May 1988.
 4. Data taken from Woodward-Clyde Consultants Phase III Report, March 1990.
 5. NA - Not Available - No access to offsite wells.
 6. Installed by Hargis + Associates, Inc. for Montrose Chemical Corporation
 7. Well WCC-6S could not be opened on 20 September 1995. The water level elevation shown was measured on 6 September 1995.
- * Water Level Elevation not measured due to wellhead obstructions.


**SUMMARY OF GROUNDWATER ELEVATION DATA
GROUNDWATER MONITORING DATA SUMMARY REPORT
THIRD QUARTER 1995
DOUGLAS AIRCRAFT C-6 FACILITY
TORRANCE, CALIFORNIA
KJ 944016.01**

Observation Well	Reference Point ¹ Elevation (Feet Above MSL) ²	Water Level Elevation (Feet Above Mean Sea Level)				
		11/13/87 ³	10/18/89 ⁴	6/15/92	9/21/92	1/5/93
WCC-1S	50.7	-21.63	-19.48	-19.2	-19.42	-19.34
WCC-2S	50.59	-19.72	-19.06	-19.15	-19.41	-19.51
WCC-3S	51.19	-21.56	-19.42	-19.24	-19.52	-19.73
WCC-4S	49.69	-21.77	-19.59	-19.22	-19.49	-19.34
WCC-5S	48.22	NA ⁵	-19.7	-19.13	-19.42	-19.32
WCC-6S	50.95	NA	-19.7	-19.4	-19.64	-19.5
WCC-7S	48.29	NA	-20.07	-19.63	-19.93	-19.76
WCC-8S	50.56	NA	-19.35	-19.11	-19.34	-19.19
WCC-9S	47.01	NA	-20.07	-19.44	-19.66	-19.56
WCC-10S	51.12	NA	-18.42	-18.94	-19.33	-19.1
WCC-11S	49.97	NA	NA	-17.62	-18.81	-18.69
WCC-12S	46.92	NA	NA	-19.6	-19.9	-19.74
DAC-P1	52.44	NA	NA	-17.76	-17.88	-18.02
WCC-1D	50.45	NA	-19.51	-19.55	-19.92	-19.61
WCC-3D	51.18	NA	-19.38	-19.39	-19.71	-20.52
MW-8 ⁶	49.09	NA	NA	NA	NA	NA ⁵
MW-9 ⁶	48.67	NA	NA	NA	NA	NA
MW-18 ⁶	50.29	NA	NA	NA	NA	NA
MW-19 ⁶	46.55	NA	NA	NA	NA	NA

Notes:

1. Reference point is north side, top of well casing
2. Reference point elevation measured by Hargis + Associates, Inc.
3. Data taken from Woodward-Clyde Consultants Phase II Report, May 1988.
4. Data taken from Woodward-Clyde Consultants Phase III Report, March 1990.
5. NA - Not Available - No access to offsite wells.
6. Installed by Hargis + Associates, Inc. for Montrose Chemical Corporation
7. Well WCC-6S could not be opened on 20 September 1995. The water level elevation shown was measured on 6 September 1995.
- * Water Level Elevation not measured due to wellhead obstructions.

FIGURES



Kennedy/Jenks Consultants
Douglas Aircraft Company
C6 Facility

Site Vicinity Map

October 1995
K/J 944016.01

Figure 1

0 1,000 2,000 FEET

Base Map: U.S.G.S. 7.5 Minute Topographic Map,
Torrance, California Quadrangle, 1981.

190 TH. ST.


Observation Well Locations
October 1995
K/J 944016.01
Figure 2

NOTE: 1) Wells MW-8,-9,-10,-18, and -19 installed by Montrose Chemical Corporation

LEGEND


WCC-1S Observation Well Location, Designation

Scale in Feet



BOE-C6-0137606

190 TH. ST.



Kennedy/Jenks Consultants
Douglas Aircraft Company
C6 Facility

Estimated Groundwater Elevation
Contour Map, Shallow Zone,
September 1995


October 1995
K/J 944016.01
Figure

- NOTE: 1) Wells MW-8, -9, -10, -18, and -19 Installed by Montrose Chemical Corporation
 2) Contour Interval = 0.2 feet
 3) Wells WCC-3D and WCC-1D are screened across the deeper zone. Therefore, their water elevations are not included.

NORMANDIE AVE.

LEGEND

- WCC-1S Observation Well Location, Designation and groundwater elevation, feet MSL, measured 9/20/95.
- 18.00
- 18.00
- 0 200 Scale in Feet



APPENDIX A

LABORATORY DATA SHEETS



Since 1878

Curtis & Tompkins, Ltd. General Analytical Laboratories

2495 Da Vinci, Irvine CA 92714

Phone 714-252-9700 Fax 714-252-9701

LABORATORY REPORT

Laboratory Number: 212809

Page 1 of 23

Date Received: 09/07/95

Date Reported: 09/19/95

Date Amended: 09/28/95

Issued To: KENNEDY/JENKS
2151 MICHELSON DR.
SUITE 100
IRVINE, CA 92715
ATTN: SARAH BARTLING

Project I.D.: 944016.00

Location: DAC

Report On: ELEVEN LIQUID SAMPLES ANALYZED AS SPECIFIED ON ATTACHED CHAIN OF CUSTODY

This report certifies that the samples were received in good condition (i.e. intact, chilled, and/or preserved appropriately) and that strict chain of custody procedures were adhered to at all times. It further certifies that the methods of analysis used are in fact those listed within this report and that Curtis & Tompkins, Ltd. has current certification for all work performed in the laboratory. Exceptions to this statement are specifically noted in the analytical report or on the attached chain of custody.

Reviewed By:

M. J. Kite

G. J. McI.

Berkeley

Irvine

Since 1878

Curtis & Tompkins, Ltd. General Analytical Laboratories

2495 Da Vinci, Irvine CA 92714

Phone 714-252-9700

Fax 714-252-9701

LABORATORY REPORT

Laboratory Number: 212803

Page 1 of 17

Date Received: 09/06/95

Date Reported: 09/19/95

Date Amended: 09/28/95

Issued To: KENNEDY/JENKS
2151 MICHELSON DR.
SUITE 100
IRVINE, CA 92715
ATTN: SARAH BARTLING


Project I.D.: 944016.00


Location: DAC

Report On: EIGHT LIQUID SAMPLES ANALYZED AS SPECIFIED ON ATTACHED CHAIN OF CUSTODY

This report certifies that the samples were received in good condition (i.e. intact, chilled, and/or preserved appropriately) and that strict chain of custody procedures were adhered to at all times. It further certifies that the methods of analysis used are in fact those listed within this report and that Curtis & Tompkins, Ltd. has current certification for all work performed in the laboratory. Exceptions to this statement are specifically noted in the analytical report or on the attached chain of custody.

Reviewed By:





Berkeley

Irvine

VOLATILE ORGANICS

Client I.D.: WCC1S-12
 Laboratory I.D.: 212809-004
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 8 of 23

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
Acetone	ND	10		ND	10	a - Result from 1:50 dilution.
Benzene	51	5		ND	5	
Bromobenzene	ND	5		ND	5	
Bromochloromethane	ND	5		ND	5	
Bromodichloromethane	ND	5		ND	5	
Chloroform	ND	5		ND	5	
Bromomethane	ND	10		ND	10	
Butanone	ND	10		ND	10	
Butylbenzene	ND	5		ND	5	
sec-Butylbenzene	ND	5		ND	5	
tert-Butylbenzene	ND	5		ND	5	
Carbon disulfide	ND	5		ND	5	
Carbon tetrachloride	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Chloroethane	ND	10		ND	10	
Chloroform	16	5		ND	5	
Chloromethane	ND	10		ND	10	
2-Chlorotoluene	ND	5		ND	5	
Chlorotoluene	ND	5		ND	5	
Bromochloromethane	ND	5		ND	5	
1,2-Dibromo-3-chloropropane	ND	5		ND	5	
1,2-Dibromoethane	ND	5		ND	5	
Bromomethane	ND	5		ND	5	
1,2-Dichlorobenzene	ND	5		ND	5	
1,3-Dichlorobenzene	ND	5		ND	5	
1,4-Dichlorobenzene	ND	5		ND	5	
1-Chlorodifluoromethane	ND	10		ND	10	
1,1-Dichloroethane	22	5		ND	5	
1,1-Dichloroethane	ND	5		ND	5	
1,1-Dichloroethene	1800	250	a	ND	5	
cis-1,2-Dichloroethene	37	5		ND	5	
trans-1,2-Dichloroethene	37	5		ND	5	
1,2-Dichloropropane	ND	5		ND	5	
1,3-Dichloropropane	ND	5		ND	5	
2,2-Dichloropropane	ND	5		ND	5	
1,4-Dichloropropene	ND	5		ND	5	
1,1,3-Dichloropropene	ND	5		ND	5	
trans-1,3-Dichloropropene	ND	5		ND	5	
Ethylbenzene	ND	5		ND	5	
Ion 113	ND	5		ND	5	
Isobutylchlorobutadiene	ND	5		ND	5	
2-Hexanone	ND	10		ND	10	
Methylpropylbenzene	ND	5		ND	5	
Methylpropyltoluene	ND	5		ND	5	
Methylene chloride	ND	5		ND	5	
4-Methyl-2-pentanone	ND	10		ND	10	
Phthalene	ND	5		ND	5	
Methylpropylbenzene	ND	5		ND	5	
Styrene	ND	5		ND	5	

(continued on next page)

Sample	Method Blank
Date Sampled:	9/07/95
Date Analyzed:	9/13/95

OLATILE ORGANICS

Client I.D.: WCC1S-12
Laboratory I.D.: 212809-004
Client: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

Page
9 of 23

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method	Detection Limit	Analytical Notes	
						Blank	
1,1,2-Tetrachloroethane	ND	5		ND	5		
1,1,2,2-Tetrachloroethane	ND	5		ND	5		
Tetrachloroethene	ND	5		ND	5		
Urene	ND	5		ND	5		
1,3-Trichlorobenzene	ND	5		ND	5		
1,2,4-Trichlorobenzene	ND	5		ND	5		
1,1-Trichloroethane	22	5		ND	5		
1,2-Trichloroethane	ND	5		ND	5		
Trichloroethene	2600	250	a	ND	5		
Trichlorofluoromethane	ND	5		ND	5		
3-Trichloropropane	ND	5		ND	5		
4-Trimethylbenzene	ND	5		ND	5		
3,5-Trimethylbenzene	ND	5		ND	5		
Methyl acetate	ND	10		ND	10		
Methyl Chloride	ND	10		ND	10		
m-Xylene	ND	5		ND	5		
n,p-Xylenes	ND	5		ND	5		

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike	Percent	QC	Batch I.D.: 8758AIC					Sample I.D.: 212768-009				
	Amount (ug/L)	Recovery	Limits	Compounds	Spike Amt.	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
Urene-d8	50	96	80-120	1,1-Dichloroethene	25	90	80-120	85	87	61-145	2	14	
Trifluorobenzene	50	86	81-117	Benzene	25	109	80-120	105	105	76-127	<1	11	
Trifluoromethane	50	116	74-121	Trichloroethene	25	87	80-120	87	86	71-120	1	14	
				Toluene	25	103	80-120	101	102	76-125	1	13	
				Chlorobenzene	25	104	80-120	107	104	75-130	3	13	

VOLATILE ORGANICS

ct

nt I.D.: WCC2S-12
oratory I.D.: 212803-005
lient: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

Page
10 of 17

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
Acetone	ND	10		ND	10	
Azene	ND	5		ND	5	
Chromobenzene	ND	5		ND	5	
Chlorochloromethane	ND	5		ND	5	
Chlorodichloromethane	ND	5		ND	5	
Formalform	ND	5		ND	5	
Chloromethane	ND	10		ND	10	
Isobutane	ND	10		ND	10	
Methylbenzene	ND	5		ND	5	
o-Butylbenzene	ND	5		ND	5	
p-Butylbenzene	ND	5		ND	5	
Thion disulfide	ND	5		ND	5	
Silicon tetrachloride	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Propane	ND	10		ND	10	
Formalform	ND	5		ND	5	
Chloromethane	ND	10		ND	10	
Chlorotoluene	ND	5		ND	5	
Bromotoluene	ND	5		ND	5	
Chlorochloromethane	ND	5		ND	5	
2-Dibromo-3-chloropropane	ND	5		ND	5	
Bromomoethane	ND	5		ND	5	
Trimethane	ND	5		ND	5	
2-Dichlorobenzene	ND	5		ND	5	
3-Dichlorobenzene	ND	5		ND	5	
Dichlorobenzene	ND	5		ND	5	
Chlorodifluoromethane	ND	10		ND	10	
-Dichloroethane	ND	5		ND	5	
1-Chloroethane	ND	5		ND	5	
1-Chloroethylene	ND	5		ND	5	
-1,2-Dichloroethene	ND	5		ND	5	
trans-1,2-Dichloroethene	ND	5		ND	5	
1-Chloropropane	ND	5		ND	5	
1-Chloropropane	ND	5		ND	5	
2-Dichloropropane	ND	5		ND	5	
1-Chloropropene	ND	5		ND	5	
3-Dichloropropene	ND	5		ND	5	
trans-1,3-Dichloropropene	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
1113	ND	5		ND	5	
Chlorobutadiene	ND	5		ND	5	
Hexanone	ND	10		ND	10	
Propylbenzene	ND	5		ND	5	
Propyltoluene	ND	5		ND	5	
Ethylene chloride	ND	5		ND	5	
Methyl-2-pentanone	ND	10		ND	10	
Phthalene	ND	5		ND	5	
Propylbenzene	ND	5		ND	5	
Toluene	ND	5		ND	5	

(continued on next page)

Sample Method Blank

Date Sampled: 9/06/95 N/A

Date Analyzed: 9/12/95 9/11/95

VOLATILE ORGANICS

Client I.D.: WCC2S-12
 Laboratory I.D.: 212803-005
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 11 of 17

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method	Detection Limit	Analytical Notes	
						Blank	
1,1,2-Tetrachloroethane	ND	5		ND	5		
1,1,2,2-Tetrachloroethane	ND	5		ND	5		
Tetrachloroethene	ND	5		ND	5		
Toluene	ND	5		ND	5		
1,3-Trichlorobenzene	ND	5		ND	5		
1,2,4-Trichlorobenzene	ND	5		ND	5		
1,1-Trichloroethane	ND	5		ND	5		
1,2-Trichloroethane	ND	5		ND	5		
Trichloroethene	200	5		ND	5		
Trichlorofluoromethane	ND	5		ND	5		
1,3-Trichloropropane	ND	5		ND	5		
1,4-Trimethylbenzene	ND	5		ND	5		
1,3,5-Trimethylbenzene	ND	5		ND	5		
Methyl acetate	ND	10		ND	10		
Methyl Chloride	ND	10		ND	10		
p-Xylene	ND	5		ND	5		
m,p-Xylenes	ND	5		ND	5		

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8734AIA				Sample I.D.: 212803-001					
				Compounds	Spike Amt. (ug/L)	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
Toluene-d8	50	97	80-120	1,1-Dichloroethene	25	106	80-120	93	92	61-145	1	14	
Bromotefluorobenzene	50	95	81-117	Benzene	25	99	80-120	98	96	76-127	2	11	
Chlorotefluoromethane	50	126-a	74-121	Trichloroethene	25	103	80-120	111	104	71-120	6	14	
				Toluene	25	94	80-120	90	92	76-125	2	13	
				Chlorobenzene	25	103	80-120	96	100	75-130	4	13	

VOLATILE ORGANICS

Client I.D.: WCC3S-12
 Laboratory I.D.: 212809-006
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 12 of 23

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
Cetone	39	10		ND	10	a - Result from 1:20 dilution.
Benzene	220	100	a	ND	5	
Bromobenzene	ND	5		ND	5	b - Result from 1:100 dilution.
Bromoform	ND	5		ND	5	c - Result from 1:250 dilution.
Bromochloromethane	ND	5		ND	5	
Bromodichloromethane	ND	5		ND	5	
Bromoform	ND	5		ND	5	
Bromomethane	ND	10		ND	10	
Butanone	ND	200	a	ND	10	
Butylbenzene	ND	5		ND	5	
sec-Butylbenzene	ND	5		ND	5	
tert-Butylbenzene	ND	5		ND	5	
Carbon disulfide	ND	5		ND	5	
Carbon tetrachloride	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Chloroethane	ND	10		ND	10	
Chloroform	76	5		ND	5	
Chloromethane	ND	10		ND	10	
2-Chlorotoluene	ND	5		ND	5	
Chlorotoluene	ND	5		ND	5	
Bromochloromethane	ND	5		ND	5	
1,2-Dibromo-3-chloropropane	ND	5		ND	5	
2-Dibromoethane	ND	5		ND	5	
Bromomethane	ND	5		ND	5	
1,2-Dichlorobenzene	ND	5		ND	5	
1,3-Dichlorobenzene	ND	5		ND	5	
4-Dichlorobenzene	ND	5		ND	5	
Chlorodifluoromethane	ND	10		ND	10	
1,1-Dichloroethane	480	100	a	ND	5	
1,2-Dichloroethane	99	5		ND	5	
1,3-Dichloroethene	13000	500	b	ND	5	
cis-1,2-Dichloroethene	6000	500	b	ND	5	
trans-1,2-Dichloroethene	520	100	a	ND	5	
1,2-Dichloropropane	ND	5		ND	5	
1,3-Dichloropropane	ND	5		ND	5	
2,2-Dichloropropane	ND	5		ND	5	
1,1-Dichloropropene	ND	5		ND	5	
1,3-Dichloropropene	ND	5		ND	5	
trans-1,3-Dichloropropene	ND	5		ND	5	
Ethylbenzene	18	5		ND	5	
non 113	ND	5		ND	5	
transchlorobutadiene	ND	5		ND	5	
2-Hexanone	200	10		ND	10	
Propylbenzene	ND	5		ND	5	
Sopropyltoluene	ND	5		ND	5	
Methylene chloride	23	5		ND	5	
4-Methyl-2-pentanone	4600	1000	b	ND	10	
Phthalene	ND	5		ND	5	
Propylbenzene	ND	5		ND	5	
Styrene	ND	5		ND	5	

(continued on next page)

Sample Method Blank

Date Sampled: 9/07/95 N/A

Date Analyzed: 9/13/95 9/13/95

VOLATILE ORGANICS

Sample I.D.: WCC3S-12
Laboratory I.D.: 212809-006
Client: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

Page
13 of 23

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,2-Tetrachloroethane	ND	5		ND	5	a - Result from 1:20 dilution.
1,1,2,2-Tetrachloroethane	ND	5		ND	5	
Trichloroethene	ND	5		ND	5	b - Result from 1:100 dilution.
Toluene	31000	1250	c	ND	5	
1,2,3-Trichlorobenzene	ND	5		ND	5	c - Result from 1:250 dilution.
2,4-Trichlorobenzene	ND	5		ND	5	
1-Trichloroethane	4100	500	b	ND	5	d - High surrogate recovery due to suspected sample matrix effect.
2-Trichloroethane	64	5		ND	5	
Trichloroethylene	910	100	a	ND	5	
Chlorofluoromethane	ND	5		ND	5	
3-Trichloropropane	ND	5		ND	5	
2,4-Trimethylbenzene	ND	5		ND	5	
3,5-Trimethylbenzene	ND	5		ND	5	
Methyl acetate	100	10		ND	10	
M Chloride	ND	10		ND	10	
Xylene	44	5		ND	5	
-Xylenes-	93	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data								
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8758AIC			Sample I.D.: 212768-009					
				Compounds	Spike Amt. (ug/L)	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits
Styrene-d8	50	123-d	80-120	1,1-Dichloroethene	25	90	80-120	85	87	61-145	2	14
Chlorofluorobenzene	50	129-d	81-117	Benzene	25	109	80-120	105	105	76-127	<1	11
Chlorofluoromethane	50	95	74-121	Trichloroethene	25	87	80-120	87	86	71-120	1	14
				Toluene	25	103	80-120	101	102	76-125	1	13
				Chlorobenzene	25	104	80-120	107	104	75-130	3	13

VOLATILE ORGANICS

nt I.D.: WCC4S-12
Laboratory I.D.: 212809-003
lient: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

Page
6 of 23

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
Acetone	ND	10		ND	10	a - Result from 1:20 dilution.
Benzene	13	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Chlorochloromethane	ND	5		ND	5	
Chlorodichloromethane	ND	5		ND	5	
Chloroform	ND	5		ND	5	
Chloromethane	ND	10		ND	10	
Cyclohexanone	ND	10		ND	10	
Ethylbenzene	ND	5		ND	5	
p-Butylbenzene	ND	5		ND	5	
m-Butylbenzene	ND	5		ND	5	
Carbon disulfide	ND	5		ND	5	
Carbon tetrachloride	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Chloroethane	ND	10		ND	10	
Chloroform	6	5		ND	5	
Chloromethane	ND	10		ND	10	
Chlorotoluene	ND	5		ND	5	
Methylchlorotoluene	ND	5		ND	5	
Chlorochloromethane	ND	5		ND	5	
2-Dibromo-3-chloropropane	ND	5		ND	5	
Dibromoethane	ND	5		ND	5	
Bromomethane	ND	5		ND	5	
2-Dichlorobenzene	ND	5		ND	5	
3-Dichlorobenzene	ND	5		ND	5	
Dichlorobenzene	ND	5		ND	5	
Bromodifluoromethane	ND	10		ND	10	
1-Dichloroethane	8	5		ND	5	
Dichloroethane	ND	5		ND	5	
Dichloroethene	910	100	a	ND	5	
trans-1,2-Dichloroethene	10	5		ND	5	
cis-1,2-Dichloroethene	9	5		ND	5	
Dichloropropane	ND	5		ND	5	
Dichloropropene	ND	5		ND	5	
2-Dichloropropane	ND	5		ND	5	
Dichloropropene	ND	5		ND	5	
trans-3-Dichloropropene	ND	5		ND	5	
cis-1,3-Dichloropropene	ND	5		ND	5	
Hydrobenzene	ND	5		ND	5	
n 113	ND	5		ND	5	
Chlorobutadiene	ND	5		ND	5	
Hexanone	ND	10		ND	10	
Propylbenzene	ND	5		ND	5	
Propyltoluene	ND	5		ND	5	
Ethylene chloride	ND	5		ND	5	
Methyl-2-pentanone	ND	10		ND	10	
Phthalene	ND	5		ND	5	
Propylbenzene	ND	5		ND	5	
Styrene	ND	5		ND	5	

(continued on next page)

Sample	Method Blank	
Date Sampled:	9/07/95	N/A
Date Analyzed:	9/13/95	9/13/95

VOLATILE ORGANICS

Sample I.D.: WCC4S-12
Laboratory I.D.: 212809-003
Client: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

Page
7 of 23

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,2-Tetrachloroethane	ND	5		ND	5	a - Result from 1:20 dilution.
1,2,2-Tetrachloroethane	ND	5		ND	5	
tetrachloroethene	ND	5		ND	5	
ene	ND	5		ND	5	
,2-Trichlorobenzene	ND	5		ND	5	
,2,4-Trichlorobenzene	ND	5		ND	5	
1-Trichloroethane	6	5		ND	5	
2-Trichloroethane	ND	5		ND	5	
richloroethene	1200	100	a	ND	5	
richlorofluoromethane	ND	5		ND	5	
3-Trichloropropane	ND	5		ND	5	
,4-Trimethylbenzene	ND	5		ND	5	
,3,5-Trimethylbenzene	ND	5		ND	5	
acetate	ND	10		ND	10	
Chloride	ND	10		ND	10	
-Xylene	ND	5		ND	5	
n-Xylenes	ND	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount	Percent Recovery	QC Limits (ug/L)	Batch I.D.: 8758AIC		Sample I.D.: 212768-009							
	LCS Amt.	%Rec.	QC Limits	Compounds	Spike Amt.	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
Toluene-d8	50	97	80-120	1,1-Dichloroethene	25	90	80-120	85	87	61-145	2	14	
Bromofluorobenzene	50	93	81-117	Benzene	25	109	80-120	105	105	76-127	<1	11	
Difluoromethane	50	110	74-121	Trichloroethene	25	87	80-120	87	86	71-120	1	14	
				Toluene	25	103	80-120	101	102	76-125	1	13	
				Chlorobenzene	25	104	80-120	107	104	75-130	3	13	

VOLATILE ORGANICS

Client I.D.: WCC5S-12
 Laboratory I.D.: 212803-001
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 2 of 17

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
Cetone	ND	10		ND	10	
Benzene	ND	5		ND	5	
Bromobenzene	ND	5		ND	5	
Bromoform	ND	5		ND	5	
Bromomethane	ND	10		ND	10	
Butanone	ND	10		ND	10	
Butylbenzene	ND	5		ND	5	
sec-Butylbenzene	ND	5		ND	5	
tert-Butylbenzene	ND	5		ND	5	
Carbon disulfide	ND	5		ND	5	
Carbon tetrachloride	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Chloroethane	ND	10		ND	10	
Chloroform	ND	5		ND	5	
Chloromethane	ND	10		ND	10	
2-Chlorotoluene	ND	5		ND	5	
Chlorotoluene	ND	5		ND	5	
Dibromochloromethane	ND	5		ND	5	
1,2-Dibromo-3-chloropropane	ND	5		ND	5	
1,2-Dibromoethane	ND	5		ND	5	
bromomethane	ND	5		ND	5	
1,2-Dichlorobenzene	ND	5		ND	5	
1,3-Dichlorobenzene	ND	5		ND	5	
1,4-Dichlorobenzene	ND	5		ND	5	
chlorodifluoromethane	ND	10		ND	10	
1,1-Dichloroethane	ND	5		ND	5	
1,2-Dichloroethane	ND	5		ND	5	
1,1-Dichloroethene	18	5		ND	5	
cis-1,2-Dichloroethene	ND	5		ND	5	
trans-1,2-Dichloroethene	ND	5		ND	5	
2-Dichloropropane	ND	5		ND	5	
3-Dichloropropane	ND	5		ND	5	
2,2-Dichloropropane	ND	5		ND	5	
1,1-Dichloropropene	ND	5		ND	5	
1,3-Dichloropropene	ND	5		ND	5	
trans-1,3-Dichloropropene	ND	5		ND	5	
Ethylbenzene	ND	5		ND	5	
benzene	ND	5		ND	5	
hexachlorobutadiene	ND	5		ND	5	
2-Hexanone	ND	10		ND	10	
Propylbenzene	ND	5		ND	5	Sample
Isopropyltoluene	ND	5		ND	5	Method Blank
Methylene chloride	ND	5		ND	5	Date Sampled: 9/06/95 N/A
4-Methyl-2-pentanone	ND	10		ND	10	Date Analyzed: 9/11/95 9/11/95
Phthalene	ND	5		ND	5	
Propylbenzene	ND	5		ND	5	
Styrene	ND	5		ND	5	

(continued on next page)

VOLATILE ORGANICS

Client I.D.: WCC5S-12
Laboratory I.D.: 212803-001
Client: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

Page
3 of 17

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,2-Tetrachloroethane	ND	5		ND	5	
1,1,2,2-Tetrachloroethane	ND	5		ND	5	
Tetrachloroethene	ND	5		ND	5	
luene	ND	5		ND	5	
1,3-Trichlorobenzene	ND	5		ND	5	
1,2,4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	ND	5		ND	5	
1,2-Trichloroethane	ND	5		ND	5	
Trichloroethene	ND	5		ND	5	
Trichlorofluoromethane	ND	5		ND	5	
1,3-Trichloropropane	ND	5		ND	5	
4-Trimethylbenzene	ND	5		ND	5	
1,3,5-Trimethylbenzene	ND	5		ND	5	
Vinyl acetate	ND	10		ND	10	
Vinyl Chloride	ND	10		ND	10	
c-Xylene	ND	5		ND	5	
m,p-Xylenes	ND	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8734AIA				Sample I.D.: 212803-001					
				Compounds	Spike Amt. (ug/L)	LCs %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
Toluene-d8	50	88	80-120	1,1-Dichloroethene	25	106	80-120	93	92	61-145	1	14	
Bromofluorobenzene	50	90	81-117	Benzene	25	99	80-120	98	96	76-127	2	11	
Dichlorofluoromethane	50	111	74-121	Trichloroethene	25	103	80-120	111	104	71-120	6	14	
				Toluene	25	94	80-120	90	92	76-125	2	13	
				Chlorobenzene	25	103	80-120	96	100	75-130	4	13	

VOLATILE ORGANICS

Client I.D.: WCC6S-12
 Laboratory I.D.: 212809-007
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 14 of 23

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
Acetone	ND	10		ND	10	a - Result from 1:10 dilution.
Benzene	50	5		ND	5	b - Result from 1:50 dilution.
Bromobenzene	ND	5		ND	5	
Bromochloromethane	ND	5		ND	5	
Bromoform	ND	5		ND	5	
Bromomethane	ND	10		ND	10	
2-Butanone	12	10		ND	10	
Butylbenzene	ND	5		ND	5	
Sec-Butylbenzene	ND	5		ND	5	
tert-Butylbenzene	ND	5		ND	5	
Carbon disulfide	ND	5		ND	5	
Carbon tetrachloride	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Chloroethane	ND	10		ND	10	
Chloroform	14	5		ND	5	
Chloromethane	ND	10		ND	10	
2-Chlorotoluene	ND	5		ND	5	
Chlorotoluene	ND	5		ND	5	
Bromochloromethane	ND	5		ND	5	
1,2-Dibromo-3-chloropropane	ND	5		ND	5	
1,2-Dibromoethane	ND	5		ND	5	
Bromomethane	ND	5		ND	5	
1,2-Dichlorobenzene	ND	5		ND	5	
1,3-Dichlorobenzene	ND	5		ND	5	
1,4-Dichlorobenzene	ND	5		ND	5	
Chlorodifluoromethane	ND	10		ND	10	
1,1-Dichloroethane	55	5		ND	5	
1,2-Dichloroethane	39	5		ND	5	
trans-Dichloroethene	4300	250	b	ND	5	
cis-1,2-Dichloroethene	2400	250	b	ND	5	
trans-1,2-Dichloroethene	83	5		ND	5	
1,1-Dichloropropane	ND	5		ND	5	
1,3-Dichloropropane	ND	5		ND	5	
2,2-Dichloropropane	ND	5		ND	5	
1,1-Dichloropropene	ND	5		ND	5	
1,1,3-Dichloropropene	ND	5		ND	5	
trans-1,3-Dichloropropene	ND	5		ND	5	
Ethylbenzene	ND	5		ND	5	
Styrene 113	ND	5		ND	5	
trans-Chlorobutadiene	ND	5		ND	5	
2-Hexanone	ND	10		ND	10	
Isopropylbenzene	ND	5		ND	5	
Isopropyttoluene	ND	5		ND	5	
Methylene chloride	ND	5		ND	5	
4-Methyl-2-pentanone	240	100	a	ND	10	
Phthalene	ND	5		ND	5	
Tropylibenzene	ND	5		ND	5	
Styrene	ND	5		ND	5	

(continued on next page)

Date Sampled:	9/07/95	Method Blank
Date Analyzed:	9/13/95	9/13/95

OLATILE ORGANICS

ent I.D.: WCC6S-12
boratory I.D.: 212809-007
Client: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

Page
15 of 23

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,2-Tetrachloroethane	ND	5		ND	5	a - Result from 1:10 dilution.
1,1,2,2-Tetrachloroethane	ND	5		ND	5	b - Result from 1:50 dilution.
Tetrachloroethene	ND	5		ND	5	
luene	2900	250	b	ND	5	
1,3-Trichlorobenzene	ND	5		ND	5	
1,2,4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	370	50	a	ND	5	
1,2-Trichloroethane	48	5		ND	5	
Trichloroethene	620	50	a	ND	5	
Trichlorofluoromethane	ND	5		ND	5	
1,3-Trichloropropane	ND	5		ND	5	
2,4-Trimethylbenzene	ND	5		ND	5	
1,3,5-Trimethylbenzene	ND	5		ND	5	
yl acetate	14	10		ND	10	
yl Chloride	ND	10		ND	10	
o-Xylene	6	5		ND	5	
m,p-Xylenes	15	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8758AIC		Sample I.D.: 212768-009							
				Compounds	Spike Amt. (ug/L)	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
luene-d8	50	100	80-120	1,1-Dichloroethene	25	90	80-120	85	87	61-145	2	14	
Bromofluorobenzene	50	91	81-117	Benzene	25	109	80-120	105	105	76-127	<1	11	
Bromofluoromethane	50	87	74-121	Trichloroethene	25	87	80-120	87	86	71-120	1	14	
				Toluene	25	103	80-120	101	102	76-125	1	13	
				Chlorobenzene	25	104	80-120	107	104	75-130	3	13	

VOLATILE ORGANICS

ct

Sample I.D.: DW090795
 Laboratory I.D.: 212809-011
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 22 of 23

WCC-6S

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method	Detection Limit	Analytical Notes	
						Blank	
Toluene	ND	10		ND	10		a - Result from 1:10 dilution.
o-xylene	56	5		ND	5		b - Result from 1:50 dilution.
p-xylene	ND	5		ND	5		
m-xylene	ND	5		ND	5		
Chloromethane	ND	5		ND	5		
Dichloromethane	ND	5		ND	5		
Trichloromethane	ND	5		ND	5		
Tetrachloromethane	ND	5		ND	5		
Formaldehyde	ND	5		ND	5		
Acetone	ND	10		ND	10		
Propanone	11	10		ND	10		
Isobutylbenzene	ND	5		ND	5		
sec-Butylbenzene	ND	5		ND	5		
tert-Butylbenzene	ND	5		ND	5		
Carbon disulfide	ND	5		ND	5		
Carbon tetrachloride	ND	5		ND	5		
Chlorobenzene	ND	5		ND	5		
Chloroethane	ND	10		ND	10		
Chloropropane	19	5		ND	5		
Chloromethane	ND	10		ND	10		
1,2-Chlorotoluene	ND	5		ND	5		
1,4-Chlorotoluene	ND	5		ND	5		
1,2-Dibromo-3-chloropropane	ND	5		ND	5		
1,2-Dibromoethane	ND	5		ND	5		
Dibromomethane	ND	5		ND	5		
1,2-Dichlorobenzene	ND	5		ND	5		
1,3-Dichlorobenzene	ND	5		ND	5		
1,4-Dichlorobenzene	ND	5		ND	5		
1,1-Difluorodichloromethane	ND	10		ND	10		
1,1-Dichloroethane	70	5		ND	5		
1,2-Dichloroethane	55	5		ND	5		
1,1-Dichloroethene	3800	250	b	ND	5		
cis-1,2-Dichloroethene	2200	250	b	ND	5		
trans-1,2-Dichloroethene	99	5		ND	5		
1,1-Dichloropropene	ND	5		ND	5		
1,2-Dichloropropene	ND	5		ND	5		
2,2-Dichloropropene	ND	5		ND	5		
1,1-Dichloropropene	ND	5		ND	5		
cis-1,3-Dichloropropene	ND	5		ND	5		
trans-1,3-Dichloropropene	ND	5		ND	5		
Ethylbenzene	ND	5		ND	5		
Furan 113	ND	5		ND	5		
1,4-Hexachlorobutadiene	ND	5		ND	5		
2-Hexanone	ND	10		ND	10		
Isopropylbenzene	ND	5		ND	5		
p-Isopropyltoluene	ND	5		ND	5		
Methylene chloride	ND	5		ND	5		
4-Methyl-2-pentanone	180	100	a	ND	10		
Naphthalene	ND	5		ND	5		
m-Isopropylbenzene	ND	5		ND	5		
Styrene	ND	5		ND	5		

(continued on next page)

VOLATILE ORGANICS

Client I.D.: DW090795
 Laboratory I.D.: 212809-011
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 23 of 23

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method	Blank	Detection Limit	Analytical Notes	
1,1,2-Tetrachloroethane	ND	5		ND		5	a - Result from 1:10 dilution.	
1,1,2,2-Tetrachloroethane	ND	5		ND		5		
Tetrachloroethene	ND	5		ND		5	b - Result from 1:50 dilution.	
Toluene	2500	250	b	ND		5		
2,3-Trichlorobenzene	ND	5		ND		5		
1,2,4-Trichlorobenzene	ND	5		ND		5		
1,1,1-Trichloroethane	310	50	a	ND		5		
1,2-Trichloroethane	52	5		ND		5		
Trichloroethene	520	50	a	ND		5		
Trichlorofluoromethane	ND	5		ND		5		
2,3-Trichloropropane	ND	5		ND		5		
2,4-Trimethylbenzene	ND	5		ND		5		
1,3,5-Trimethylbenzene	ND	5		ND		5		
Vinyl acetate	17	10		ND		10		
Chloro Chloride	ND	10		ND		10		
c-Xylene	6	5		ND		5		
m,p-Xylenes	17	5		ND		5		

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data								
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8758AID			Sample I.D.: 212768-009					
				Compounds	Spike Amt. (ug/L)	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits
Toluene-d8	50	103	80-120	1,1-Dichloroethene	25	88	80-120	85	87	61-145	2	14
Bromofluorobenzene	50	92	81-117	Benzene	25	112	80-120	105	105	76-127	<1	11
Dichromofluoromethane	50	102	74-121	Trichloroethene	25	88	80-120	87	86	71-120	1	14
				Toluene	25	112	80-120	101	102	76-125	1	13
				Chlorobenzene	25	108	80-120	107	104	75-130	3	13

VOLATILE ORGANICS

Sample I.D.: WCC7S-12
Laboratory I.D.: 212809-001
Client: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

Page
2 of 23

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method	Detection Limit	Analytical Notes
				Blank		
Acetone	ND	10		ND	10	
Benzene	ND	5		ND	5	
Bromobenzene	ND	5		ND	5	
Bromo-chloromethane	ND	5		ND	5	
Chlorodichloromethane	ND	5		ND	5	
Chloroform	ND	5		ND	5	
Bromomethane	ND	10		ND	10	
Butanone	ND	10		ND	10	
Butylbenzene	ND	5		ND	5	
sec-Butylbenzene	ND	5		ND	5	
tert-Butylbenzene	ND	5		ND	5	
Carbon disulfide	ND	5		ND	5	
Carbon tetrachloride	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Chloroethane	ND	10		ND	10	
Chloroform	ND	5		ND	5	
Chloromethane	ND	10		ND	10	
2-Chlorotoluene	ND	5		ND	5	
4-Chlorotoluene	ND	5		ND	5	
Dibromochloromethane	ND	5		ND	5	
1,2-Dibromo-3-chloropropane	ND	5		ND	5	
1,1-Dibromoethane	ND	5		ND	5	
Dibromomethane	ND	5		ND	5	
1,2-Dichlorobenzene	ND	5		ND	5	
1,3-Dichlorobenzene	ND	5		ND	5	
1,1-Dichlorobenzene	ND	5		ND	5	
Dichlorodifluoromethane	ND	10		ND	10	
1,1-Dichloroethane	ND	5		ND	5	
1,1-Dichloroethane	ND	5		ND	5	
1,1-Dichloroethene	150	5		ND	5	
cis-1,2-Dichloroethene	ND	5		ND	5	
trans-1,2-Dichloroethene	ND	5		ND	5	
1,1-Dichloropropane	ND	5		ND	5	
1,1-Dichloropropane	ND	5		ND	5	
2,2-Dichloropropane	ND	5		ND	5	
1,1-Dichloropropene	ND	5		ND	5	
cis-1,3-Dichloropropene	ND	5		ND	5	
trans-1,3-Dichloropropene	ND	5		ND	5	
Ethylbenzene	ND	5		ND	5	
Fluorin 113	ND	5		ND	5	
Hexachlorobutadiene	ND	5		ND	5	
2-Hexanone	ND	10		ND	10	
1-Methylbenzene	ND	5		ND	5	
p,p'-Oxydipropyltoluene	ND	5		ND	5	
Methylene chloride	ND	5		ND	5	
4-Methyl-2-pentanone	ND	10		ND	10	
Naphthalene	ND	5		ND	5	
n,p'-Oxydiphenylbenzene	ND	5		ND	5	
Styrene	ND	5		ND	5	

(continued on next page)

Sample	Method Blank	
Date Sampled:	9/07/95	N/A
Date Analyzed:	9/13/95	9/13/95

VOLATILE ORGANICS



Client I.D.: WCC7S-12
Laboratory I.D.: 212809-001
Client: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

Page
3 of 23

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,2-Tetrachloroethane	ND	5		ND	5	
1,1,2,2-Tetrachloroethane	ND	5		ND	5	
Tetrachloroethene	ND	5		ND	5	
luene	ND	5		ND	5	
1,3-Trichlorobenzene	ND	5		ND	5	
1,2,4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	ND	5		ND	5	
1,2-Trichloroethane	ND	5		ND	5	
Trichloroethene	200	5		ND	5	
Trichlorofluoromethane	ND	5		ND	5	
1,3-Trichloropropane	ND	5		ND	5	
1,4-Trimethylbenzene	ND	5		ND	5	
1,3,5-Trimethylbenzene	ND	5		ND	5	
Vinyl acetate	ND	10		ND	10	
Methyl Chloride	ND	10		ND	10	
c-Xylene	ND	5		ND	5	
m,p-Xylenes.	ND	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8758AIC				Sample I.D.: 212768-009					
				Compounds	Spike Amt. (ug/L)	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
luene-d8	50	98	80-120	1,1-Dichloroethene	25	90	80-120	85	87	61-145	2	14	
Bromofluorobenzene	50	89	81-117	Benzene	25	109	80-120	105	105	76-127	<1	11	
Bromofluoromethane	50	115	74-121	Trichloroethene	25	87	80-120	87	86	71-120	1	14	
				Toluene	25	103	80-120	101	102	76-125	1	13	
				Chlorobenzene	25	104	80-120	107	104	75-130	3	13	

VOLATILE ORGANICS

ct

Client I.D.: WCC8S-12
 Laboratory I.D.: 212809-002
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 4 of 23

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
Acetone	ND	10		ND	10	
Toluene	22	5		ND	5	
Bromobenzene	ND	5		ND	5	
Bromoform	ND	5		ND	5	
Bromochloromethane	ND	5		ND	5	
Chlorodichloromethane	ND	5		ND	5	
Chloroform	ND	5		ND	5	
Bromomethane	ND	10		ND	10	
2-Butanone	ND	10		ND	10	
Isobutylbenzene	ND	5		ND	5	
Sec-Butylbenzene	ND	5		ND	5	
tert-Butylbenzene	ND	5		ND	5	
Carbon disulfide	ND	5		ND	5	
Carbon tetrachloride	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Chloroethane	ND	10		ND	10	
Chloroform	9	5		ND	5	
Chloromethane	ND	10		ND	10	
2-Chlorotoluene	ND	5		ND	5	
Chlorotoluene	ND	5		ND	5	
Bromochloromethane	ND	5		ND	5	
1,2-Dibromo-3-chloropropane	ND	5		ND	5	
1,2-Dibromoethane	ND	5		ND	5	
Bromomethane	ND	5		ND	5	
1,2-Dichlorobenzene	ND	5		ND	5	
1,3-Dichlorobenzene	ND	5		ND	5	
1,4-Dichlorobenzene	ND	5		ND	5	
Chlorodifluoromethane	ND	10		ND	10	
1,1-Dichloroethane	10	5		ND	5	
1,2-Dichloroethane	ND	5		ND	5	
trans-Dichloroethene	2200	250	a	ND	5	
cis-1,2-Dichloroethene	15	5		ND	5	
trans-1,2-Dichloroethene	28	5		ND	5	
1,1-Dichloropropane	ND	5		ND	5	
1,2-Dichloropropane	ND	5		ND	5	
2,2-Dichloropropane	ND	5		ND	5	
1,1-Dichloropropene	ND	5		ND	5	
1,2-Dichloropropene	ND	5		ND	5	
trans-1,3-Dichloropropene	ND	5		ND	5	
Ethylbenzene	ND	5		ND	5	
1,1,1-Trifluoroethane	ND	5		ND	5	
1,1,2-Trifluoroethane	ND	5		ND	5	
1,1,1,2-Tetrafluoroethane	ND	5		ND	5	
2-Hexanone	ND	10		ND	10	
Isopropylbenzene	ND	5		ND	5	
Isopropyltoluene	ND	5		ND	5	
Methylene chloride	ND	5		ND	5	
4-Methyl-2-pentanone	ND	10		ND	10	
Phthalene	ND	5		ND	5	
Propylbenzene	ND	5		ND	5	
Styrene	ND	5		ND	5	

(continued on next page)

VOLATILE ORGANICS

Sample I.D.: WCC8S-12
 Laboratory I.D.: 212809-002
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 5 of 23

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,2-Tetrachloroethane	ND	5		ND	5	a - Result from 1:50 dilution.
1,1,2,2-Tetrachloroethane	ND	5		ND	5	
Tetrachloroethene	ND	5		ND	5	
Toluene	ND	5		ND	5	
1,3-Trichlorobenzene	ND	5		ND	5	
1,2,4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	110	5		ND	5	
1,2-Trichloroethane	ND	5		ND	5	
Trichloroethene	1700	250	a	ND	5	
Trichlorofluoromethane	ND	5		ND	5	
1,3-Trichloropropane	ND	5		ND	5	
4-Trimethylbenzene	ND	5		ND	5	
1,3,5-Trimethylbenzene	ND	5		ND	5	
Methyl acetate	ND	10		ND	10	
Methyl Chloride	ND	10		ND	10	
p-Xylene	ND	5		ND	5	
m,p-Xylenes	ND	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8758AIC		Sample I.D.: 212768-009							
				Compounds	Spike Amt. (ug/L)	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
Styrene-d8	50	94	80-120	1,1-Dichloroethene	25	90	80-120	85	87	61-145	2	14	
Chloromfluorobenzene	50	90	81-117	Benzene	25	109	80-120	105	105	76-127	<1	11	
Chloromfluoromethane	50	109	74-121	Trichloroethene	25	87	80-120	87	86	71-120	1	14	
				Toluene	25	103	80-120	101	102	76-125	1	13	
				Chlorobenzene	25	104	80-120	107	104	75-130	3	13	

VOLATILE ORGANICS

Client I.D.: WCC9S-12
Laboratory I.D.: 212803-002
Client: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

Page
4 of 17

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes	
Acetone	ND	10		ND	10		
Benzene	ND	5		ND	5		
Bromobenzene	ND	5		ND	5		
Bromoform	ND	5		ND	5		
Bromomethane	ND	10		ND	10		
Butanone	ND	10		ND	10		
Butylbenzene	ND	5		ND	5		
sec-Butylbenzene	ND	5		ND	5		
tert-Butylbenzene	ND	5		ND	5		
Carbon disulfide	ND	5		ND	5		
Carbon tetrachloride	ND	5		ND	5		
Chlorobenzene	ND	5		ND	5		
Chloroethane	ND	10		ND	10		
Chloroform	19	5		ND	5		
Chloromethane	ND	10		ND	10		
2-Chlorotoluene	ND	5		ND	5		
Chlorotoluene	ND	5		ND	5		
Dichlorochloromethane	ND	5		ND	5		
1,2-Dibromo-3-chloropropane	ND	5		ND	5		
Dibromoethane	ND	5		ND	5		
Bromomethane	ND	5		ND	5		
1,2-Dichlorobenzene	ND	5		ND	5		
2,2-Dichlorobenzene	ND	5		ND	5		
Dichlorobenzene	ND	5		ND	5		
Chlorodifluoromethane	ND	10		ND	10		
1,1-Dichloroethane	ND	5		ND	5		
Dichloroethane	ND	5		ND	5		
Dichloroethylene	11	5		ND	5		
trans-1,2-Dichloroethylene	ND	5		ND	5		
Dichloropropane	ND	5		ND	5		
1,2-Dichloropropane	ND	5		ND	5		
Dichloropropene	ND	5		ND	5		
1,3-Dichloropropene	ND	5		ND	5		
trans-1,3-Dichloropropene	ND	5		ND	5		
Thylbenzene	ND	5		ND	5		
in 113	ND	5		ND	5		
exachlorobutadiene	ND	5		ND	5		
-Hexanone	ND	10		ND	10		
Propylbenzene	ND	5		ND	5	Sample	Method Blank
Propyltoluene	ND	5		ND	5	Date Sampled:	9/06/95 N/A
Methylene chloride	ND	5		ND	5	Date Analyzed:	9/11/95 9/11/95
Methyl-2-pentanone	ND	10		ND	10		
Phthalene	ND	5		ND	5		
Propylbenzene	ND	5		ND	5		
Tyrene	ND	5		ND	5		

(continued on next page)

VOLATILE ORGANICS

Client I.D.: WCC9S-12
 Laboratory I.D.: 212803-002
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 5 of 17

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,2-Tetrachloroethane	ND	5		ND	5	
1,1,2,2-Tetrachloroethane	ND	5		ND	5	
Tetrachloroethene	ND	5		ND	5	
Toluene	ND	5		ND	5	
1,2,3-Trichlorobenzene	ND	5		ND	5	
1,2,4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	ND	5		ND	5	
1,2-Trichloroethane	ND	5		ND	5	
Trichloroethene	64	5		ND	5	
Trichlorofluoromethane	ND	5		ND	5	
2,3-Trichloropropane	ND	5		ND	5	
1,2,4-Trimethylbenzene	ND	5		ND	5	
1,3,5-Trimethylbenzene	ND	5		ND	5	
Methyl acetate	ND	10		ND	10	
Methyl Chloride	ND	10		ND	10	
o-Xylene	ND	5		ND	5	
m,p-Xylenes	ND	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8734AIA		Sample I.D.: 212803-001							
				Compounds	Spike Amt (ug/L)	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
Toluene-d8	50	100	80-120	1,1-Dichloroethene	25	106	80-120	93	92	61-145	1	14	
Bromofluorobenzene	50	96	81-117	Benzene	25	99	80-120	98	96	76-127	2	11	
Chlorotefluoromethane	50	117	74-121	Trichloroethene	25	103	80-120	111	104	71-120	6	14	
				Toluene	25	94	80-120	90	92	76-125	2	13	
				Chlorobenzene	25	103	80-120	96	100	75-130	4	13	

VOLATILE ORGANICS

Plant I.D.: WCC10S-12
Laboratory I.D.: 212803-004
Client: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

ctb

Page
8 of 17

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes		
Stone	ND	10		ND	10			
Benzene	ND	5		ND	5			
Bromobenzene	ND	5		ND	5			
2-Bromo-1-chloromethane	ND	5		ND	5			
1,1-Dichloromethane	ND	5		ND	5			
Chloroform	ND	5		ND	5			
Bromomethane	ND	10		ND	10			
Butanone	ND	10		ND	10			
2-Ethylbenzene	ND	5		ND	5			
2-Ec-Butylbenzene	ND	5		ND	5			
2-Et-Butylbenzene	ND	5		ND	5			
Carbon disulfide	14	5		ND	5			
Carbon tetrachloride	ND	5		ND	5			
Chlorobenzene	ND	5		ND	5			
Propane	ND	10		ND	10			
Proform	ND	5		ND	5			
Chloromethane	ND	10		ND	10			
1-Chlorotoluene	ND	5		ND	5			
Chlorotoluene	ND	5		ND	5			
1,1-Dibromo-2-chloromethane	ND	5		ND	5			
2,2-Dibromo-3-chloropropane	ND	5		ND	5			
Dibromoethane	ND	5		ND	5			
Homomethane	ND	5		ND	5			
2-Dichlorobenzene	ND	5		ND	5			
3-Dichlorobenzene	ND	5		ND	5			
Dichlorobenzene	ND	5		ND	5			
1,1-Difluoromethane	ND	10		ND	10			
1,1-Dichloroethane	ND	5		ND	5			
1,1-Dichloroethane	ND	5		ND	5			
Dichloroethene	27	5		ND	5			
trans-1,2-Dichloroethene	ND	5		ND	5			
trans-1,2-Dichloroethene	ND	5		ND	5			
Dichloropropane	ND	5		ND	5			
Dichloropropane	ND	5		ND	5			
2-Dichloropropane	ND	5		ND	5			
Dichloropropene	ND	5		ND	5			
1,3-Dichloropropene	ND	5		ND	5			
trans-1,3-Dichloropropene	ND	5		ND	5			
Phenylbenzene	ND	5		ND	5			
1,1,1-Trichloroethane	ND	5		ND	5			
Hexanone	ND	10		ND	10			
Methylpropylbenzene	ND	5		ND	5			
Propyltoluene	ND	5		ND	5			
Ethylene chloride	ND	5		ND	5			
Methyl-2-pentanone	ND	10		ND	10			
Phthalene	ND	5		ND	5			
Propylbenzene	ND	5		ND	5			
Tyrene	ND	5		ND	5			

(continued on next page)

VOLATILE ORGANICS

Client I.D.: WCC10S-12
 Laboratory I.D.: 212803-004
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 9 of 17

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,2-Tetrachloroethane	ND	5		ND	5	a - High surrogate recovery due to matrix effect (confirmed by reanalysis 09/12/95).
1,1,2,2-Tetrachloroethane	ND	5		ND	5	
Tetrachloroethene	ND	5		ND	5	
Toluene	ND	5		ND	5	
1,2,3-Trichlorobenzene	ND	5		ND	5	
1,2,4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	ND	5		ND	5	
1,2-Trichloroethane	ND	5		ND	5	
Trichloroethene	160	5		ND	5	
Trichlorofluoromethane	ND	5		ND	5	
2,3-Trichloropropane	ND	5		ND	5	
1,2,4-Trimethylbenzene	ND	5		ND	5	
1,3,5-Trimethylbenzene	ND	5		ND	5	
Methyl acetate	ND	10		ND	10	
Methyl Chloride	ND	10		ND	10	
o-Xylene	ND	5		ND	5	
m,p-Xylenes	ND	5		ND	5	

Quality Control Data Summary

Compound	Surrogate Recovery Data			Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8734AIA			Sample I.D.: 212803-001						
				Compounds	Spike Amt.	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
Toluene-d8	50	96	80-120	1,1-Dichloroethene	25	106	80-120	93	92	61-145	1	14	
Bromotefluorobenzene	50	91	81-117	Benzene	25	99	80-120	98	96	76-127	2	11	
Chlorotefluoromethane	50	132-a	74-121	Trichloroethene	25	103	80-120	111	104	71-120	6	14	
				Toluene	25	94	80-120	90	92	76-125	2	13	
				Chlorobenzene	25	103	80-120	96	100	75-130	4	13	

VOLATILE ORGANICS

Client I.D.: WCC11S-12
 Laboratory I.D.: 212803-006
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 12 of 17

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method	Detection Limit	Analytical Notes	
cetone	ND	10		ND	10		
benzene	ND	5		ND	5		
Bromobenzene	ND	5		ND	5		
Bromo-chloromethane	ND	5		ND	5		
Bromo-dichloromethane	ND	5		ND	5		
Bromoform	ND	5		ND	5		
Bromomethane	ND	10		ND	10		
Butanone	ND	10		ND	10		
Butylbenzene	ND	5		ND	5		
sec-Butylbenzene	ND	5		ND	5		
tert-Butylbenzene	ND	5		ND	5		
carbon disulfide	ND	5		ND	5		
Carbon tetrachloride	ND	5		ND	5		
Chlorobenzene	ND	5		ND	5		
chloroethane	ND	10		ND	10		
chloroform	ND	5		ND	5		
Chloromethane	ND	10		ND	10		
2-Chlorotoluene	ND	5		ND	5		
Chlorotoluene	ND	5		ND	5		
1-Bromochloromethane	ND	5		ND	5		
1,2-Dibromo-3-chloropropane	ND	5		ND	5		
2-Dibromoethane	ND	5		ND	5		
bromomethane	ND	5		ND	5		
1,2-Dichlorobenzene	ND	5		ND	5		
1,3-Dichlorobenzene	ND	5		ND	5		
4-Dichlorobenzene	ND	5		ND	5		
Dichlorodifluoromethane	ND	10		ND	10		
1,1-Dichloroethane	ND	5		ND	5		
1,2-Dichloroethane	ND	5		ND	5		
1,1-Dichloroethene	31	5		ND	5		
cis-1,2-Dichloroethene	ND	5		ND	5		
trans-1,2-Dichloroethene	ND	5		ND	5		
1,2-Dichloropropane	ND	5		ND	5		
1,3-Dichloropropane	ND	5		ND	5		
2,2-Dichloropropane	ND	5		ND	5		
1,1-Dichloropropene	ND	5		ND	5		
1,3-Dichloropropene	ND	5		ND	5		
trans-1,3-Dichloropropene	ND	5		ND	5		
Ethylbenzene	ND	5		ND	5		
eon 113	ND	5		ND	5		
hexachlorobutadiene	ND	5		ND	5		
2-Hexanone	ND	10		ND	10		
Isopropylbenzene	ND	5		ND	5		
Sopropyltoluene	ND	5		ND	5		
Methylene chloride	ND	5		ND	5		
1-Methyl-2-pentanone	ND	10		ND	10		
Phthalene	ND	5		ND	5		
Propylbenzene	ND	5		ND	5		
Styrene	ND	5		ND	5		

(continued on next page)

Sample	Method Blank	
Date Sampled:	9/06/95	N/A
Date Analyzed:	9/12/95	9/11/95

VOLATILE ORGANICS

Plant I.D.: WCC11S-12
 Laboratory I.D.: 212803-006
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 13 of 17

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,2-Tetrachloroethane	ND	5		ND	5	a - High surrogate recovery due to matrix effect (confirmed by reanalysis 09/12/95).
1,2-Tetrachloroethane	ND	5		ND	5	
1,1-Chloroethene	ND	5		ND	5	
Toluene	ND	5		ND	5	
2,3-Trichlorobenzene	ND	5		ND	5	
4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	ND	5		ND	5	
1,2-Trichloroethane	ND	5		ND	5	
Chloroethene	190	5		ND	5	
Chlorofluoromethane	ND	5		ND	5	
2,3-Trichloropropane	ND	5		ND	5	
2,4-Trimethylbenzene	ND	5		ND	5	
3,5-Trimethylbenzene	ND	5		ND	5	
Acetate	ND	10		ND	10	
Methyl Chloride	ND	10		ND	10	
Ethene	ND	5		ND	5	
Xylenes	ND	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8734AIA		Sample I.D.: 212803-001							
				Compounds	Spike Amt.	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
Toluene-d8	50	97	80-120	1,1-Dichloroethene	25	106	80-120	93	92	61-145	1	14	
Chlorofluorobenzene	50	91	81-117	Benzene	25	99	80-120	98	96	76-127	2	11	
Chlorotefluoromethane	50	125-a	74-121	Trichloroethene	25	103	80-120	111	104	71-120	6	14	
				Toluene	25	94	80-120	90	92	76-125	2	13	
				Chlorobenzene	25	103	80-120	96	100	75-130	4	13	

VOLATILE ORGANICS

ct

Client I.D.: DW090695
Laboratory I.D.: 212803-008
Client: KENNEDY/JENKS

Matrix: Liquid
Method: EPA 8260
Extraction: EPA 5030 Purge & Trap

Page
16 of 17

WCC-115

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes	
Methone	ND	10		ND	10		
Benzene	ND	5		ND	5		
m-nitrobenzene	ND	5		ND	5		
1,1-dichloromethane	ND	5		ND	5		
Bromodichloromethane	ND	5		ND	5		
Isomeric form	ND	5		ND	5		
Isobutane	ND	10		ND	10		
2-Butanone	ND	10		ND	10		
n-Butylbenzene	ND	5		ND	5		
o-Butylbenzene	ND	5		ND	5		
Carbon disulfide	ND	5		ND	5		
Carbon tetrachloride	ND	5		ND	5		
p-Chlorobenzene	ND	5		ND	5		
Chloroethane	ND	10		ND	10		
Chloroform	ND	5		ND	5		
Dibromomethane	ND	10		ND	10		
1,1-Dichlorotoluene	ND	5		ND	5		
1,4-Chlorotoluene	ND	5		ND	5		
Chlorochloromethane	ND	5		ND	5		
1,1-Dibromo-3-chloropropane	ND	5		ND	5		
1,1-Dibromoethane	ND	5		ND	5		
Dibromomethane	ND	5		ND	5		
1,1-Dichlorobenzene	ND	5		ND	5		
1,1-Dichlorobenzene	ND	5		ND	5		
1,4-Dichlorobenzene	ND	5		ND	5		
Dichlorodifluoromethane	ND	10		ND	10		
Dichloroethane	ND	5		ND	5		
1,1-Dichloroethane	ND	5		ND	5		
1,1,2-Dichloroethene	ND	5		ND	5		
cis-1,2-Dichloroethene	ND	5		ND	5		
1,2-Dichloropropane	ND	5		ND	5		
1,3-Dichloropropane	ND	5		ND	5		
1,1-Dichloropropene	ND	5		ND	5		
1,1-Dichloropropene	ND	5		ND	5		
cis-1,3-Dichloropropene	ND	5		ND	5		
trans-1,3-Dichloropropene	ND	5		ND	5		
p-Chlorobenzene	ND	5		ND	5		
Freon 113	ND	5		ND	5		
Hexachlorobutadiene	ND	5		ND	5		
Heptanone	ND	10		ND	10		
Isopropylbenzene	ND	5		ND	5		
p-isopropyltoluene	ND	5		ND	5		
1,1-Methylene chloride	ND	5		ND	5		
2-Ethyl-2-pentanone	ND	10		ND	10		
Naphthalene	ND	5		ND	5		
n-Propylbenzene	ND	5		ND	5		
Styrene	ND	5		ND	5		

(continued on next page)

Sample	Method Blank	
Date Sampled:	9/06/95	N/A
Date Analyzed:	9/12/95	9/11/95



VOLATILE ORGANICS

Client I.D.: DW090695

Laboratory I.D.: 212803-008

Client: KENNEDY/JENKS

Matrix: Liquid

Method: EPA 8260

Extraction: EPA 5030 Purge & Trap

Page

17 of 17

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,1,2-Tetrachloroethane	ND	5		ND	5	a - High surrogate recovery due to matrix effect (confirmed by reanalysis 09/12/95).
1,1,2,2-Tetrachloroethane	ND	5		ND	5	
Trichloroethene	ND	5		ND	5	
Toluene	ND	5		ND	5	b - Result from a 1:2 dilution run on 09/12/95.
1,2,3-Trichlorobenzene	ND	5		ND	5	
2,4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	ND	5		ND	5	
1,1,2-Trichloroethane	ND	5		ND	5	
Trichloroethene	200	10	b	ND	5	
Bromofluoromethane	ND	5		ND	5	
1,2,3-Trichloropropane	ND	5		ND	5	
1,2,4-Trimethylbenzene	ND	5		ND	5	
3,5-Trimethylbenzene	ND	5		ND	5	
Methyl acetate	ND	10		ND	10	
Vinyl Chloride	ND	10		ND	10	
Xylene	ND	5		ND	5	
p-Xylenes	ND	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount	Percent Recovery	QC Limits	Batch I.D.: 8734AIA				Sample I.D.: 212803-001					
	(ug/L)	(ug/L)	(ug/L)	LCS Amt.	QC %Rec.	Spike Limits	Spk Dup %Rec.	QC Limits	RPD	QC Limits			
Toluene-d8	50	98	80-120	1,1-Dichloroethene	25	106	80-120	93	92	61-145	1	14	
Bromofluorobenzene	50	94	81-117	Benzene	25	99	80-120	98	96	76-127	2	11	
Bromofluoromethane	50	127-a	74-121	Trichloroethene	25	103	80-120	111	104	71-120	6	14	
				Toluene	25	94	80-120	90	92	76-125	2	13	
				Chlorobenzene	25	103	80-120	96	100	75-130	4	13	

VOLATILE ORGANICS

Client I.D.: WCC12S-12
 Laboratory I.D.: 212803-007
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 14 of 17

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
cetone	ND	10		ND	10	
Benzene	ND	5		ND	5	
Bromobenzene	ND	5		ND	5	
Bromochloromethane	ND	5		ND	5	
Bromodichloromethane	ND	5		ND	5	
Bromoform	ND	5		ND	5	
Bromomethane	ND	10		ND	10	
Butanone	ND	10		ND	10	
n-Butylbenzene	ND	5		ND	5	
sec-Butylbenzene	ND	5		ND	5	
tert-Butylbenzene	ND	5		ND	5	
Carbon disulfide	33	5		ND	5	
Carbon tetrachloride	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Chloroethane	ND	10		ND	10	
Chloroform	ND	5		ND	5	
Chloromethane	ND	10		ND	10	
Chlorotoluene	ND	5		ND	5	
Chlorotoluene	ND	5		ND	5	
Dibromochloromethane	ND	5		ND	5	
2-Dibromo-3-chloropropane	ND	5		ND	5	
2-Dibromoethane	ND	5		ND	5	
Dibromomethane	ND	5		ND	5	
1,2-Dichlorobenzene	ND	5		ND	5	
3-Dichlorobenzene	ND	5		ND	5	
4-Dichlorobenzene	ND	5		ND	5	
Dichlorodifluoromethane	ND	10		ND	10	
1,1-Dichloroethane	32	5		ND	5	
2-Dichloroethane	ND	5		ND	5	
1,1-Dichloroethene	60	5		ND	5	
cis-1,2-Dichloroethene	ND	5		ND	5	
trans-1,2-Dichloroethene	ND	5		ND	5	
1,2-Dichloropropane	ND	5		ND	5	
1,3-Dichloropropane	ND	5		ND	5	
2-Dichloropropane	ND	5		ND	5	
1,1-Dichloropropene	ND	5		ND	5	
cis-1,3-Dichloropropene	ND	5		ND	5	
trans-1,3-Dichloropropene	ND	5		ND	5	
Phenylbenzene	ND	5		ND	5	
Freon 113	ND	5		ND	5	
Hexachlorobutadiene	ND	5		ND	5	
-Hexanone	ND	10		ND	10	
Isopropylbenzene	ND	5		ND	5	
p-isopropyltoluene	ND	5		ND	5	
Methylene chloride	ND	5		ND	5	
-Methyl-2-pentanone	ND	10		ND	10	
Naphthalene	ND	5		ND	5	
n-Propylbenzene	ND	5		ND	5	
Styrene	ND	5		ND	5	

(continued on next page)

Sample	Method Blank	
Date Sampled:	9/06/95	N/A
Date Analyzed:	9/12/95	9/11/95

VOLATILE ORGANICS

Client I.D.: WCC12S-12
 Laboratory I.D.: 212803-007
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 15 of 17

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,1,2-Tetrachloroethane	ND	5		ND	5	a - High surrogate recovery due to matrix effect (confirmed by reanalysis 09/12/95).
1,1,2,2-Tetrachloroethane	ND	5		ND	5	
Trichloroethene	ND	5		ND	5	
Toluene	ND	5		ND	5	b - Result from a 1:2.5 dilution run on 09/12/95.
1,2,3-Trichlorobenzene	ND	5		ND	5	
1,4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	ND	5		ND	5	
1,1,2-Trichloroethane	ND	5		ND	5	
Trichloroethylene	300	12.5	b	ND	5	
chlorofluoromethane	ND	5		ND	5	
1,2,3-Trichloropropane	ND	5		ND	5	
1,2,4-Trimethylbenzene	ND	5		ND	5	
1,5-Trimethylbenzene	ND	5		ND	5	
Methyl acetate	ND	10		ND	10	
Vinyl Chloride	ND	10		ND	10	
c-Xylene	ND	5		ND	5	
m-Xylenes	ND	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8734AIA				Sample I.D.: 212803-001					
				Compounds	Spike Amt. (ug/L)	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
Toluene-d8	50	99	80-120	1,1-Dichloroethene	25	106	80-120	93	92	61-145	1	14	
Bromofluorobenzene	50	98	81-117	Benzene	25	99	80-120	98	96	76-127	2	11	
Chloromethylfluoromethane	50	131-a	74-121	Trichloroethene	25	103	80-120	111	104	71-120	6	14	
				Toluene	25	94	80-120	90	92	76-125	2	13	
				Chlorobenzene	25	103	80-120	96	100	75-130	4	13	

VOLATILE ORGANICS

Client I.D.: DACP1-12
 Laboratory I.D.: 212809-008
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 16 of 23

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
Acetone	ND	10		ND	10	
Benzene	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Chlorochloromethane	ND	5		ND	5	
Chlorodichloromethane	ND	5		ND	5	
Chloroform	ND	5		ND	5	
Chloromethane	ND	10		ND	10	
2-Methylpropane	ND	10		ND	10	
2-Butylbenzene	ND	5		ND	5	
3-Butylbenzene	ND	5		ND	5	
Carbon disulfide	ND	5		ND	5	
Carbon tetrachloride	ND	5		ND	5	
Cyclohexene	ND	5		ND	5	
Ethane	ND	10		ND	10	
Chloroform	33	5		ND	5	
Chloromethane	ND	10		ND	10	
Chlorotoluene	ND	5		ND	5	
4-Chlorotoluene	ND	5		ND	5	
Dibromochloromethane	ND	5		ND	5	
1,1-Dibromo-3-chloropropane	ND	5		ND	5	
1,1-Dibromoethane	ND	5		ND	5	
Dibromomethane	ND	5		ND	5	
1,2-Dichlorobenzene	ND	5		ND	5	
1,3-Dichlorobenzene	ND	5		ND	5	
1,4-Dichlorobenzene	ND	5		ND	5	
Dichlorodifluoromethane	ND	10		ND	10	
1,1-Dichloroethane	ND	5		ND	5	
1,1-Dichloroethane	ND	5		ND	5	
1,1-Dichloroethene	12	5		ND	5	
1,1,1,2-Dichloroethene	89	5		ND	5	
cis-1,2-Dichloroethene	ND	5		ND	5	
1,2-Dichloropropane	ND	5		ND	5	
1,3-Dichloropropane	ND	5		ND	5	
1,4-Dichloropropane	ND	5		ND	5	
Dichloropropene	ND	5		ND	5	
cis-1,3-Dichloropropene	ND	5		ND	5	
trans-1,3-Dichloropropene	ND	5		ND	5	
Methylbenzene	ND	5		ND	5	
Freon 113	ND	5		ND	5	
Hexachlorobutadiene	ND	5		ND	5	
2-Hexanone	ND	10		ND	10	
2-Propylbenzene	ND	5		ND	5	
p-isopropyltoluene	ND	5		ND	5	
1,2-Ethylene chloride	ND	5		ND	5	
2-Ethyl-2-pentanone	ND	10		ND	10	
Naphthalene	ND	5		ND	5	
n-Propylbenzene	ND	5		ND	5	
Styrene	ND	5		ND	5	

(continued on next page)

	Sample	Method Blank
Date Sampled:	9/07/95	N/A
Date Analyzed:	9/14/95	9/13/95

VOLATILE ORGANICS

Client I.D.: DACP1-12
 Laboratory I.D.: 212809-008
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 17 of 23

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,1,2-Tetrachloroethane	ND	5		ND	5	a - Result from 1:100 dilution.
1,1,2-Tetrachloroethane	ND	5		ND	5	
Trichloroethene	17	5		ND	5	
Toluene	53	5		ND	5	
1,2,3-Trichlorobenzene	ND	5		ND	5	
1,2,4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	ND	5		ND	5	
1,1,2-Trichloroethane	ND	5		ND	5	
Trichloroethene	13000	500	a	ND	5	
Trichlorofluoromethane	ND	5		ND	5	
1,2,3-Trichloropropane	ND	5		ND	5	
1,2,4-Trimethylbenzene	ND	5		ND	5	
3,5-Trimethylbenzene	ND	5		ND	5	
Methyl acetate	ND	10		ND	10	
Vinyl Chloride	ND	10		ND	10	
Xylene	ND	5		ND	5	
p-Xylenes	ND	5		ND	5	

Quality Control Data Summary

Compound	Surrogate Recovery Data			Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8758AIC				Sample I.D.: 212768-009					
				Compounds	Spike Amt. (ug/L)	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
Toluene-d8	50	95	80-120	1,1-Dichloroethene	25	90	80-120	85	87	61-145	2	14	
Bromofluorobenzene	50	89	81-117	Benzene	25	109	80-120	105	105	76-127	<1	11	
Bromofluoromethane	50	106	74-121	Trichloroethene	25	87	80-120	87	86	71-120	1	14	
				Toluene	25	103	80-120	101	102	76-125	1	13	
				Chlorobenzene	25	104	80-120	107	104	75-130	3	13	

VOLATILE ORGANICS

Client I.D.: WCC1D-12
 Laboratory I.D.: 212803-003
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 6 of 17

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method	Detection Limit	Analytical Notes	
						Blank	
Cetone	ND	10		ND	10		
Benzene	ND	5		ND	5		
m-benzeno	ND	5		ND	5		
p-chloromethane	ND	5		ND	5		
Bromodichloromethane	ND	5		ND	5		
Chloroform	ND	5		ND	5		
Dichloromethane	ND	10		ND	10		
2-Butanone	ND	10		ND	10		
n-Butylbenzene	ND	5		ND	5		
s-Butylbenzene	ND	5		ND	5		
Carbon disulfide	ND	5		ND	5		
Carbon tetrachloride	ND	5		ND	5		
Chlorobenzene	ND	5		ND	5		
Chloroethane	ND	10		ND	10		
Chloroform	ND	5		ND	5		
Dibromochloromethane	ND	10		ND	10		
Dibromo-3-chloropropane	ND	5		ND	5		
1,2-Dibromoethane	ND	5		ND	5		
Dibromomethane	ND	5		ND	5		
-Dichlorobenzene	ND	5		ND	5		
-Dichlorobenzene	ND	5		ND	5		
1,4-Dichlorobenzene	ND	5		ND	5		
Dichlorodifluoromethane	ND	10		ND	10		
-Dichloroethane	ND	5		ND	5		
1,2-Dichloroethane	ND	5		ND	5		
1,1-Dichloroethene	150	5		ND	5		
1,1,2-Dichloroethene	ND	5		ND	5		
trans-1,2-Dichloroethene	ND	5		ND	5		
1,2-Dichloropropane	ND	5		ND	5		
1,1-Dichloropropane	ND	5		ND	5		
1,1-Dichloropropene	ND	5		ND	5		
cis-1,3-Dichloropropene	ND	5		ND	5		
trans-1,3-Dichloropropene	ND	5		ND	5		
Methylbenzene	ND	5		ND	5		
Freon 113	ND	5		ND	5		
Hexachlorobutadiene	ND	5		ND	5		
Heptanone	ND	10		ND	10		
Isopropylbenzene	ND	5		ND	5		
p-isopropyltoluene	ND	5		ND	5		
ethylene chloride	ND	5		ND	5		
2-methyl-2-pentanone	ND	10		ND	10		
Naphthalene	ND	5		ND	5		
Propylbenzene	ND	5		ND	5		
Toluene	ND	5		ND	5		

(continued on next page)

	Sample	Method Blank
Date Sampled:	9/06/95	N/A
Date Analyzed:	9/12/95	9/11/95

VOLATILE ORGANICS

Sample I.D.: WCC1D-12
 Laboratory I.D.: 212803-003
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 7 of 17

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method	Detection Blank	Detection Limit	Analytical Notes
1,1,2-Tetrachloroethane	ND	5		ND	5		
1,2,2-Tetrachloroethane	ND	5		ND	5		
Trichloroethene	ND	5		ND	5		
Clorene	ND	5		ND	5		
2,3-Trichlorobenzene	ND	5		ND	5		
4-Trichlorobenzene	ND	5		ND	5		
1-Trichloroethane	ND	5		ND	5		
1,2-Trichloroethane	ND	5		ND	5		
Trichloroethene	29	5		ND	5		
Chlorofluoromethane	ND	5		ND	5		
1,2,3-Trichloropropane	ND	5		ND	5		
2,4-Trimethylbenzene	ND	5		ND	5		
5-Trimethylbenzene	ND	5		ND	5		
Methyl acetate	ND	10		ND	10		
Vinyl Chloride	ND	10		ND	10		
Xylyne	ND	5		ND	5		
Xylenes	ND	5		ND	5		

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike	Percent	QC	Batch I.D.: 8734AIA		Sample I.D.: 212803-001		RPD	QC				
	Amount	Recovery	QC Limits	Compounds	Spike Amt.	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits			
Toluene-d8	50	98	80-120	1,1-Dichloroethene	25	106	80-120	93	92	61-145	1	14	
Chlorofluorobenzene	50	97	81-117	Benzene	25	99	80-120	98	96	76-127	2	11	
Dichlorofluoromethane	50	122-a	74-121	Trichloroethene	25	103	80-120	111	104	71-120	6	14	
				Toluene	25	94	80-120	90	92	76-125	2	13	
				Chlorobenzene	25	103	80-120	96	100	75-130	4	13	

VOLATILE ORGANICS

Sample I.D.: WCC3D-12
 Laboratory I.D.: 212809-005
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 10 of 23

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method	Blank	Detection Limit	Analytical Notes	
Betone	ND	10		ND		10	a - Result from 1:20 dilution.	
Benzene	13	5		ND		5		
m-Bromobenzene	ND	5		ND		5	b - Result from 1:100 dilution.	
p-Bromochloromethane	ND	5		ND		5		
Bromodichloromethane	ND	5		ND		5		
Bromoform	ND	5		ND		5		
Bromomethane	ND	10		ND		10		
Butanone	ND	10		ND		10		
n-Butylbenzene	ND	5		ND		5		
p-Butylbenzene	ND	5		ND		5		
Carbon disulfide	ND	5		ND		5		
Carbon tetrachloride	ND	5		ND		5		
Chlorobenzene	ND	5		ND		5		
Chloroethane	ND	10		ND		10		
Chloroform	ND	5		ND		5		
Chloromethane	ND	10		ND		10		
Chlorotoluene	ND	5		ND		5		
4-Chlorotoluene	ND	5		ND		5		
Dibromochloromethane	ND	5		ND		5		
1,1-Dibromo-3-chloropropane	ND	5		ND		5		
1,2-Dibromoethane	ND	5		ND		5		
Dibromomethane	ND	5		ND		5		
1,2-Dichlorobenzene	ND	5		ND		5		
1,1-Dichlorobenzene	ND	5		ND		5		
1,4-Dichlorobenzene	ND	5		ND		5		
Dichlorodifluoromethane	ND	10		ND		10		
1,1-Dichloroethane	13	5		ND		5		
1,1-Dichloroethane	6	5		ND		5		
1,1-Dichloroethene	3400	500	b	ND		5		
1,1,2-Dichloroethene	60	5		ND		5		
1,1,2-Dichloroethene	30	5		ND		5		
1,2-Dichloropropane	ND	5		ND		5		
1,3-Dichloropropane	ND	5		ND		5		
1,2-Dichloropropene	ND	5		ND		5		
cis-1,3-Dichloropropene	ND	5		ND		5		
trans-1,3-Dichloropropene	ND	5		ND		5		
Chlorobenzene	ND	5		ND		5		
Freon 113	ND	5		ND		5		
Hexachlorobutadiene	ND	5		ND		5		
Heptanone	ND	10		ND		10		
Isopropylbenzene	ND	5		ND		5		
p-isopropyltoluene	ND	5		ND		5		
Methylene chloride	ND	5		ND		5		
Methyl-2-pentanone	170	10		ND		10		
Naphthalene	ND	5		ND		5		
p-Propylbenzene	ND	5		ND		5		
Toluene	ND	5		ND		5		

(continued on next page)

Sample	Method Blank	
Date Sampled:	9/07/95	N/A
Date Analyzed:	9/13/95	9/13/95

VOLATILE ORGANICS

Client I.D.: WCC3D-12

Matrix: Liquid

Laboratory I.D.: 212809-005

Method: EPA 8260

Client: KENNEDY/JENKS

Extraction: EPA 5030 Purge & Trap

Page

11 of 23

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method	Detection Limit	Analytical Notes
				Blank		
1,1,1,2-Tetrachloroethane	ND	5		ND	5	a - Result from 1:20 dilution.
1,1,2,2-Tetrachloroethane	ND	5		ND	5	
1,1,2-Tetrachloroethene	ND	5		ND	5	b - Result from 1:100 dilution.
Toluene	4700	500	b	ND	5	
1,2,3-Trichlorobenzene	ND	5		ND	5	
1,2,4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	4100	500	b	ND	5	
1,1,2-Trichloroethane	35	5		ND	5	
Trichloroethylene	520	100	a	ND	5	
1,1-Dichlorofluoromethane	ND	5		ND	5	
2,3-Trichloropropane	ND	5		ND	5	
1,2,4-Trimethylbenzene	ND	5		ND	5	
3,5-Trimethylbenzene	ND	5		ND	5	
Methyl acetate	ND	10		ND	10	
Vinyl Chloride	ND	10		ND	10	
o-Xylene	ND	5		ND	5	
p-Xylenes	8	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data											
Compound	Spike	Percent	QC	Batch I.D.: 8758AIC				Sample I.D.: 212768-009							
	Amount (ug/L)	Recovery	Limits	Compounds	Spike Amt.	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits			
Toluene-d8	50	104	80-120	1,1-Dichloroethene	25	90	80-120	85	87	61-145	2	14			
Bromofluorobenzene	50	93	81-117	Benzene	25	109	80-120	105	105	76-127	<1	11			
Dichromofluoromethane	50	119	74-121	Trichloroethylene	25	87	80-120	87	86	71-120	1	14			
				Toluene	25	103	80-120	101	102	76-125	1	13			
				Chlorobenzene	25	104	80-120	107	104	75-130	3	13			

APPENDIX B

LABORATORY/FIELD QUALITY CONTROL

DATA SHEETS



VOLATILE ORGANICS

Client I.D.: EB090795

Laboratory I.D.: 212809-009

Client: KENNEDY/JENKS

Matrix: Liquid

Method: EPA 8260

Extraction: EPA 5030 Purge & Trap

Page
18 of 23

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
Acetone	ND	10		ND	10	
Benzene	ND	5		ND	5	
Bromobenzene	ND	5		ND	5	
Bromochloromethane	ND	5		ND	5	
Bromodichloromethane	ND	5		ND	5	
Bromoform	ND	5		ND	5	
Bromomethane	ND	10		ND	10	
Butanone	ND	10		ND	10	
n-Butylbenzene	ND	5		ND	5	
m-Butylbenzene	ND	5		ND	5	
t-Butylbenzene	ND	5		ND	5	
Carbon disulfide	ND	5		ND	5	
Carbon tetrachloride	ND	5		ND	5	
Chlorobenzene	ND	5		ND	5	
Chloroethane	ND	10		ND	10	
Chloroform	ND	5		ND	5	
Chloromethane	ND	10		ND	10	
Chlorotoluene	ND	5		ND	5	
4-Chlorotoluene	ND	5		ND	5	
Dibromochloromethane	ND	5		ND	5	
1-Dibromo-3-chloropropane	ND	5		ND	5	
1-Dibromoethane	ND	5		ND	5	
Dibromomethane	ND	5		ND	5	
1,2-Dichlorobenzene	ND	5		ND	5	
1,3-Dichlorobenzene	ND	5		ND	5	
1,4-Dichlorobenzene	ND	5		ND	5	
Dichlorodifluoromethane	ND	10		ND	10	
1,1-Dichloroethane	ND	5		ND	5	
1,1-Dichloroethane	ND	5		ND	5	
1,1-Dichloroethene	ND	5		ND	5	
1,1,2-Dichloroethene	ND	5		ND	5	
1,1s-1,2-Dichloroethene	ND	5		ND	5	
1,2-Dichloropropane	ND	5		ND	5	
1,3-Dichloropropane	ND	5		ND	5	
1,4-Dichloropropane	ND	5		ND	5	
cis-1,3-Dichloropropene	ND	5		ND	5	
trans-1,3-Dichloropropene	ND	5		ND	5	
/benzene	ND	5		ND	5	
Freon 113	ND	5		ND	5	
Hexachlorobutadiene	ND	5		ND	5	
Heptanone	ND	10		ND	10	
Propylbenzene	ND	5		ND	5	
p-isopropyltoluene	ND	5		ND	5	
ethylene chloride	ND	5		ND	5	
Methyl-2-pentanone	ND	10		ND	10	
Naphthalene	ND	5		ND	5	
p-Propylbenzene	ND	5		ND	5	
Trene	ND	5		ND	5	

(continued on next page)

VOLATILE ORGANICS

Client I.D.: EB090795
 Laboratory I.D.: 212609-009
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 19 of 23

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,1,2-Tetrachloroethane	ND	5		ND	5	
1,1,2,2-Tetrachloroethane	ND	5		ND	5	
Trichloroethene	ND	5		ND	5	
Toluene	ND	5		ND	5	
1,2,3-Trichlorobenzene	ND	5		ND	5	
2,4-Trichlorobenzene	ND	5		ND	5	
1,1-Trichloroethane	ND	5		ND	5	
1,1,2-Trichloroethane	ND	5		ND	5	
Trichloroethylene	ND	5		ND	5	
Chlorofluoromethane	ND	5		ND	5	
1,2,3-Trichloropropane	ND	5		ND	5	
1,2,4-Trimethylbenzene	ND	5		ND	5	
3,5-Trimethylbenzene	ND	5		ND	5	
Methyl acetate	ND	10		ND	10	
Vinyl Chloride	ND	10		ND	10	
m-Xylene	ND	5		ND	5	
p-Xylenes	ND	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8758AID		Sample I.D.: 212768-009							
				Compounds	Spike Amt. (ug/L)	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits	RPD	QC Limits	
Toluene-d8	50	95	80-120	1,1-Dichloroethene	25	88	80-120	85	87	61-145	2	14	
bromofluorobenzene	50	90	81-117	Benzene	25	112	80-120	105	105	76-127	<1	11	
bromofluoromethane	50	117	74-121	Trichloroethene	25	88	80-120	87	86	71-120	1	14	
				Toluene	25	112	80-120	101	102	76-125	1	13	
				Chlorobenzene	25	108	80-120	107	104	75-130	3	13	

VOLATILE ORGANICS

Sample I.D.: TB090795
 Laboratory I.D.: 212809-010
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 20 of 23

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method	Detection Limit	Analytical Notes	
						Blank	Limit
Acetone	ND	10		ND	10		
Benzene	ND	5		ND	5		
Chlorobenzene	ND	5		ND	5		
Dibromochloromethane	ND	5		ND	5		
Dibromodichloromethane	ND	5		ND	5		
Bromoform	ND	5		ND	5		
Chloromethane	ND	10		ND	10		
2-Butanone	ND	10		ND	10		
m-Butylbenzene	ND	5		ND	5		
p-Butylbenzene	ND	5		ND	5		
Carbon disulfide	ND	5		ND	5		
Carbon tetrachloride	ND	5		ND	5		
Chlorobenzene	ND	5		ND	5		
Chloroethane	ND	10		ND	10		
Chloroform	ND	5		ND	5		
Chloromethane	ND	10		ND	10		
Chlorotoluene	ND	5		ND	5		
+Chlorotoluene	ND	5		ND	5		
Dibromochloromethane	ND	5		ND	5		
-Dibromo-3-chloropropane	ND	5		ND	5		
+Dibromoethane	ND	5		ND	5		
Dibromomethane	ND	5		ND	5		
+Dichlorobenzene	ND	5		ND	5		
-Dichlorobenzene	ND	5		ND	5		
1,4-Dichlorobenzene	ND	5		ND	5		
Dichlorodifluoromethane	ND	10		ND	10		
-Dichloroethane	ND	5		ND	5		
-Dichloroethane	ND	5		ND	5		
1,1-Dichloroethene	ND	5		ND	5		
cis-1,2-Dichloroethene	ND	5		ND	5		
trans-1,2-Dichloroethene	ND	5		ND	5		
1,2-Dichloropropane	ND	5		ND	5		
1,3-Dichloropropane	ND	5		ND	5		
-Dichloropropene	ND	5		ND	5		
-Dichloropropene	ND	5		ND	5		
cis-1,3-Dichloropropene	ND	5		ND	5		
trans-1,3-Dichloropropene	ND	5		ND	5		
Methylbenzene	ND	5		ND	5		
Freon 113	ND	5		ND	5		
Hexachlorobutadiene	ND	5		ND	5		
Heptanone	ND	10		ND	10		
Isopropylbenzene	ND	5		ND	5		
p-isopropyltoluene	ND	5		ND	5		
Methylene chloride	ND	5		ND	5		
Methyl-2-pentanone	ND	10		ND	10		
Naphthalene	ND	5		ND	5		
n-Propylbenzene	ND	5		ND	5		
Tyrene	ND	5		ND	5		

(continued on next page)

Sample	Method Blank	
Date Sampled:	9/07/95	N/A
Date Analyzed:	9/14/95	9/14/95

VOLATILE ORGANICS

Sample I.D.: TB090795
 Laboratory I.D.: 212809-010
 Client: KENNEDY/JENKS

Matrix: Liquid
 Method: EPA 8260
 Extraction: EPA 5030 Purge & Trap

Page
 21 of 23

(continued from previous page)

Compound	Result (ug/L)	Detection Limit	Analytical Notes	Method Blank	Detection Limit	Analytical Notes
1,1,2-Tetrachloroethane	ND	5		ND	5	
1,2,2-Tetrachloroethane	ND	5		ND	5	
Trichloroethylene	ND	5		ND	5	
Styrene	ND	5		ND	5	
2,3-Trichlorobenzene	ND	5		ND	5	
4-Trichlorobenzene	ND	5		ND	5	
1-Trichloroethane	ND	5		ND	5	
1,2-Trichloroethane	ND	5		ND	5	
Chloroethylene	ND	5		ND	5	
Chlorofluoromethane	ND	5		ND	5	
2,3-Trichloropropane	ND	5		ND	5	
2,4-Trimethylbenzene	ND	5		ND	5	
5-Trimethylbenzene	ND	5		ND	5	
Acetate	ND	10		ND	10	
Methyl Chloride	ND	10		ND	10	
Styrene	ND	5		ND	5	
Xylenes	ND	5		ND	5	

Quality Control Data Summary

Surrogate Recovery Data				Laboratory Control Sample, Matrix Spike/Matrix Spike Duplicate Data									
Compound	Spike Amount (ug/L)	Percent Recovery	QC Limits	Batch I.D.: 8758AID		Sample I.D.: 212768-009		RPD	QC Limits				
	Compounds	Spike Amt. (ug/L)	LCS %Rec.	QC Limits	Spike %Rec.	Spk Dup %Rec.	QC Limits						
Toluene-d8	50	94	80-120	1,1-Dichloroethene	25	88	80-120	85	87	61-145	2	14	
Chlorofluorobenzene	50	92	81-117	Benzene	25	112	80-120	105	105	76-127	<1	11	
Chloromfluoromethane	50	118	74-121	Trichloroethylene	25	88	80-120	87	86	71-120	1	14	
				Toluene	25	112	80-120	101	102	76-125	1	13	
				Chlorobenzene	25	108	80-120	107	104	75-130	3	13	

APPENDIX C

GROUNDWATER PURGE AND SAMPLE FORMS

Groundwater Purge and Sample Form

Date: 9/7/95

Kennedy/Jenks Consultants

PROJECT NAME:	DAC		WELL NUMBER:	WCC-15			
PROJECT NUMBER:	944016.00		PERSONNEL:	RAP			
STATIC WATER LEVEL (FT):	67.00		MEASURING POINT DESCRIPTION:	Top of Casing			
WATER LEVEL MEASUREMENT METHOD:	Elec. Probe		PURGE METHOD:	Reel-Flow			
TIME START PURGE:	0957		PURGE DEPTH (FT)	70 feet			
TIME END PURGE:	1115						
TIME SAMPLED:	1120						
COMMENTS:							
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	MULTIPLIER FOR CASING DIAMETER (IN)		CASING VOLUME (GAL)	
				2	4		6
91	-	67	-	0.16	0.64	1.44	96 11.52
TIME	1022	1045	1057		1105	1115	
VOLUME PURGED (GAL)	2	4	6		9	11	
PURGE RATE (GPM)							
TEMPERATURE (°F)	76.0	74.4	75.5		75.7	75.0	
pH	7.39	7.34	7.50		7.52	7.51	
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected)	1752	1753	1741		1734	1737	
DISSOLVED OXYGEN (mg/L)	-	-	-		-	-	
eH(MV)Pt-AgCl ref.	-	-	-		-	-	
TURBIDITY/COLOR	Brown	Brown	Brown		Brown	Brown	
ODOR	No	No	No		No	No	
DEPTH OF PURGE INTAKE (FT)							
DEPTH TO WATER DURING PURGE (FT)							
NUMBER OF CASING VOLUMES REMOVED							
DEWATERED?							

Groundwater Purge and Sample Form

Date: 7/6/95

Kennedy/Jenks Consultants

PROJECT NAME:	<u>DAC</u>		WELL NUMBER:	<u>WCC-2S</u>			
PROJECT NUMBER:	<u>944016</u>		PERSONNEL:	<u>RAT</u>			
STATIC WATER LEVEL (FT):	<u>67.85</u>		MEASURING POINT DESCRIPTION:	<u>Top of casing</u>			
WATER LEVEL MEASUREMENT METHOD:	<u>Elec. Probe</u>		PURGE METHOD:	<u>Redi Flow</u>			
TIME START PURGE:	<u>1237</u>		PURGE DEPTH (FT)				
TIME END PURGE:	<u>1248</u>						
TIME SAMPLED:	<u>1300</u>						
COMMENTS:							
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	MULTIPLIER FOR CASING DIAMETER (IN)		3 X CASING VOLUME (GAL)	
				2	4		6
	<u>88.80</u>	<u>87.85</u>	<u>20.95</u>	<u>0.16</u>	<u>0.64</u>	<u>1.44</u>	<u>40.2</u>
TIME	<u>1240</u>	<u>1242</u>	<u>1244</u>	<u>1246</u>	<u>1247</u>	<u>1248</u>	
VOLUME PURGED (GAL)	<u>10</u>	<u>20</u>	<u>30</u>	<u>40</u>	<u>45</u>	<u>50</u>	
PURGE RATE (GPM)	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>	
TEMPERATURE (°F)	<u>77.0</u>	<u>75.4</u>	<u>75.3</u>	<u>75.5</u>	<u>75.6</u>	<u>75.5</u>	
pH	<u>7.54</u>	<u>7.46</u>	<u>7.51</u>	<u>7.42</u>	<u>7.43</u>	<u>7.44</u>	
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected) cm	<u>1178</u>	<u>1078</u>	<u>1030</u>	<u>1020</u>	<u>1012</u>	<u>1004</u>	
DISSOLVED OXYGEN (mg/L)	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	
eH(MV)Pt-AgCl ref.	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	
TURBIDITY/COLOR	<u>Slight</u>	<u>brown</u>	<u>slight</u>	<u>slt/clear</u>	<u>clr</u>	<u>clear</u>	
ODOR	<u>N</u>	<u>N</u>	<u>N</u>	<u>N</u>	<u>N</u>	<u>N</u>	
DEPTH OF PURGE INTAKE (FT)	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>	
DEPTH TO WATER DURING PURGE (FT)							
NUMBER OF CASING VOLUMES REMOVED							
DEWATERED?							

Groundwater Purge and Sample Form

Date: 9/7/95

Kennedy/Jenks Consultants

PROJECT NAME:	DAC		WELL NUMBER:	WCC-3S					
PROJECT NUMBER:	944016 CR		PERSONNEL:	RAB					
STATIC WATER LEVEL (FT):	67.65		MEASURING POINT DESCRIPTION:	Top of casing					
WATER LEVEL MEASUREMENT METHOD:	Elec. probe		PURGE METHOD:	Rod flow					
TIME START PURGE:	1329		PURGE DEPTH (FT)	75					
TIME END PURGE:	1339								
TIME SAMPLED:	1350								
COMMENTS:									
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	MULTIPLIER FOR CASING DIAMETER (IN)		3 X CASING VOLUME (GAL)			
				2	4		6		
	92	67.65	24.35	x	0.16	0.64	1.44	-	47
TIME	1331	1333	1335	1337	1338	1339			
VOLUME PURGED (GAL)	10	20	30	40	45	50			
PURGE RATE (GPM)	5	5	5	5	5	5			
TEMPERATURE (°C)	78.2	77.9	77.8	77.6	78.0	77.5			
pH	6.39	6.41	6.39	6.44	6.45	6.45			
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected) cm	3360	3330	2980	2680	2590	2530			
DISSOLVED OXYGEN (mg/L)	—	—	—	—	—	—			
eH(MV)Pt-AgCl ref.	—	—	—	—	—	—			
TURBIDITY/COLOR	clear	clear	clear	clear	clear	clear			
ODOR	y	y	y, slight	y	y	y			
DEPTH OF PURGE INTAKE (FT)	75	75	75	75	75	75			
DEPTH TO WATER DURING PURGE (FT)									
NUMBER OF CASING VOLUMES REMOVED									
DEWATERED?									

Groundwater Purge and Sample Form

Date: 9/7/95

Kennedy/Jenks Consultants

PROJECT NAME:	DAC		WELL NUMBER:	ACC-45					
PROJECT NUMBER:	1000248 0 944060		PERSONNEL:	RAP					
STATIC WATER LEVEL (FT):	66.16		MEASURING POINT DESCRIPTION:	Top of casing					
WATER LEVEL MEASUREMENT METHOD:	Elec. Probe		PURGE METHOD:	Radio flow					
TIME START PURGE:	0920		PURGE DEPTH (FT)	75					
TIME END PURGE:	0931								
TIME SAMPLED:	0945								
COMMENTS:									
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	MULTIPLIER FOR CASING DIAMETER (IN)		3 X CASING VOLUME (GAL)			
				X	2		4	6	
	91.5	66.16	25.34		0.16	0.64	1.44	-	49
TIME	0922	0924	0926	0928	0929	0931			
VOLUME PURGED (GAL)	10	20	30	40	45	50			
PURGE RATE (GPM)	5	5	5	5	5	5			
TEMPERATURE (°F)	73.9	74.2	74.3	74.1	74.2	74.2			
pH	7.53	7.31	7.32	7.28	7.30	7.27			
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected) cm	1635	1560	1501	1408	1374	1358			
DISSOLVED OXYGEN (mg/L)	-	-	-	-	-	-			
eH(MV)Pt-AgCl ref.	-	-	-	-	-	-			
TURBIDITY/COLOR	CLEAR/ YELLOW	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR			
ODOR	No	No	No	No	No	No			
DEPTH OF PURGE INTAKE (FT)	75	75	75	75	75	75			
DEPTH TO WATER DURING PURGE (FT)									
NUMBER OF CASING VOLUMES REMOVED									
DEWATERED?									

Groundwater Purge and Sample Form

Date: 9/6/95

Kennedy/Jenks Consultants

PROJECT NAME:	DQ			WELL NUMBER:	WCC-55			
PROJECT NUMBER:	9044016.00			PERSONNEL:	RNP			
STATIC WATER LEVEL (FT):	64.63			MEASURING POINT DESCRIPTION:	Top of casing			
WATER LEVEL MEASUREMENT METHOD:	Elec. Probe			PURGE METHOD:	Reduced flow			
TIME START PURGE:	908			PURGE DEPTH (FT)	75			
TIME END PURGE:	919							
TIME SAMPLED:	933							
COMMENTS:								
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	X	MULTIPLIER FOR CASING DIAMETER (IN)			3 X CASING VOLUME (GAL)
					2	4	6	
	89.35	64.63	24.72		0.16	0.64	1.44	47
TIME	911	913	915	917	918	919		
VOLUME PURGED (GAL)	10	20	30	40	45	50		
PURGE RATE (GPM)	5	5	5	5	5	5		
TEMPERATURE (°C)	77.9	74.1	74.0	74.2	73.9	73.8		
pH	6.74	7.29	7.27	7.22	7.20	7.18		
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected) cm	1515	1430	1441	1455	1455	1464		
DISSOLVED OXYGEN (mg/L)	—	—	—	—	—	—		
eH(MV)Pt-AgCl ref.	—	—	—	—	—	—		
TURBIDITY/COLOR	slight	slight	slight	slight	slight	slight		
ODOR	N	N	N	N	N	N		
DEPTH OF PURGE INTAKE (FT)	75	75	75	75	75	75		
DEPTH TO WATER DURING PURGE (FT)								
NUMBER OF CASING VOLUMES REMOVED								
DEWATERED?								

Groundwater Purge and Sample Form

Date: 9/7/95

Kennedy/Jenks Consultants

PROJECT NAME: <u>DAC</u>	WELL NUMBER: <u>WCC-65</u>						
PROJECT NUMBER: <u>944016-002</u>	PERSONNEL: <u>RAP</u>						
STATIC WATER LEVEL (FT): <u>67.59</u>	MEASURING POINT DESCRIPTION: <u>Top of casing</u>						
WATER LEVEL MEASUREMENT METHOD: <u>Elec Probe</u>	PURGE METHOD: <u>Rediflo</u>						
TIME START PURGE: <u>1422</u>	PURGE DEPTH (FT) <u>75</u>						
TIME END PURGE: <u>1432</u>							
TIME SAMPLED: <u>1445</u>							
COMMENTS:							
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	MULTIPLIER FOR CASING DIAMETER (IN)			3 X CASING VOLUME (GAL)
				2	4	6	
	<u>91</u>	<u>67</u>	<u>24</u>	<u>0.16</u>	<u>0.64</u>	<u>1.44</u>	<u>46.08</u>
TIME	<u>1424</u>	<u>1426</u>	<u>1428</u>	<u>1430</u>	<u>1431</u>	<u>1432</u>	
VOLUME PURGED (GAL)	<u>10</u>	<u>20</u>	<u>30</u>	<u>40</u>	<u>45</u>	<u>50</u>	
PURGE RATE (GPM)	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>		
TEMPERATURE (°C)	<u>78.0</u>	<u>77.8</u>	<u>78.0</u>	<u>77.7</u>	<u>77.5</u>	<u>77.1</u>	
pH	<u>6.80</u>	<u>6.76</u>	<u>6.78</u>	<u>6.84</u>	<u>6.79</u>	<u>6.78</u>	
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected) cm	<u>1931</u>	<u>1841</u>	<u>1772</u>	<u>1718</u>	<u>1684</u>	<u>1665</u>	
DISSOLVED OXYGEN (mg/L)	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>	
eH(MV)Pt-AgCl ref.	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>	
TURBIDITY/COLOR	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>	
ODOR	<u>Y</u>	<u>Y</u>	<u>Y</u>	<u>Y</u>	<u>Y</u>	<u>Y</u>	
DEPTH OF PURGE INTAKE (FT)	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>	
DEPTH TO WATER DURING PURGE (FT)							
NUMBER OF CASING VOLUMES REMOVED							
DEWATERED?							

Groundwater Purge and Sample Form

Date: 9/7/95

Kennedy/Jenks Consultants

PROJECT NAME:	DAC			WELL NUMBER:	WCC - 75			
PROJECT NUMBER:	94 4016 CC			PERSONNEL:	RAP			
STATIC WATER LEVEL (FT):	15.20			MEASURING POINT DESCRIPTION:	Top of Casing			
WATER LEVEL MEASUREMENT METHOD:	U.L.C. probe			PURGE METHOD:	Red. flow			
TIME START PURGE:	747			PURGE DEPTH (FT)	75			
TIME END PURGE:	0800							
TIME SAMPLED:	0812							
COMMENTS:								
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	MULTIPLIER FOR CASING DIAMETER (IN)			CASING VOLUME (GAL)	
				2	4	6		
	90.5	65.2	25.3	X	0.16	0.64	1.44	49
TIME	= 49	- - -	- - -	757	759	800		
VOLUME PURGED (GAL)	10	20	30	40	45	50		
PURGE RATE (GPM)	5	5	5	5	5			
TEMPERATURE (°F)	72.4	72.7	73.0	73.5	73.6	73.5		
pH	7.40	7.40	7.39	7.31	7.29	7.25		
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected) cm	1366	1256	1155	1098	1077	1064		
DISSOLVED OXYGEN (mg/L)	—	—	—	—	—	—		
eH(MV)Pt-AgCl ref.	—	—	--	—	—	—		
TURBIDITY/COLOR	clear	clear	clear	clear	clear	clear		
ODOR	N	N	N	N	N	N		
DEPTH OF PURGE INTAKE (FT)								
DEPTH TO WATER DURING PURGE (FT)								
NUMBER OF CASING VOLUMES REMOVED								
DEWATERED?								

Groundwater Purge and Sample Form

Date: 9/7/95

Kennedy/Jenks Consultants

PROJECT NAME: <u>DAC</u>	WELL NUMBER: <u>WCC - 85</u>								
PROJECT NUMBER: <u>944016.00</u>	PERSONNEL: <u>RAP</u>								
STATIC WATER LEVEL (FT): <u>67.83</u>	MEASURING POINT DESCRIPTION: <u>Top of Casing</u>								
WATER LEVEL MEASUREMENT METHOD: <u>Elec. Probe</u>	PURGE METHOD: <u>Reel flow</u>								
TIME START PURGE: <u>0833</u>	PURGE DEPTH (FT) <u>75</u>								
TIME END PURGE: <u>0843</u>									
TIME SAMPLED: <u>0855</u>									
COMMENTS:									
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	-	WATER COLUMN (FT)	MULTIPLIER FOR CASING DIAMETER (IN)			3 X CASING VOLUME (GAL)	
					2	4	6		
	<u>90</u>	<u>67.83</u>	-	<u>22.17</u>	X	0.16	0.64	1.44	<u>43</u>
TIME	<u>0835</u>	<u>0837</u>	<u>0839</u>	<u>0841</u>	<u>0842</u>	<u>0843</u>			
VOLUME PURGED (GAL)	<u>10</u>	<u>20</u>	<u>30</u>	<u>40</u>	<u>45</u>	<u>50</u>			
PURGE RATE (GPM)	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>			
TEMPERATURE (°F)	<u>73.4</u>	<u>74.1</u>	<u>74.3</u>	<u>74.3</u>	<u>74.3</u>	<u>74.4</u>			
pH	<u>6.98</u>	<u>6.97</u>	<u>7.00</u>	<u>6.94</u>	<u>6.93</u>	<u>6.92</u>			
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected) cm	<u>1780</u>	<u>1770</u>	<u>1770</u>	<u>1767</u>	<u>1764</u>	<u>1764</u>			
DISSOLVED OXYGEN (mg/L)	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>			
eH(MV)Pt-AgCl ref.	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>			
TURBIDITY/COLOR	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>			
ODOR	<u>No</u>	<u>No</u>	<u>No</u>	<u>No</u>	<u>No</u>	<u>No</u>			
DEPTH OF PURGE INTAKE (FT)	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>			
DEPTH TO WATER DURING PURGE (FT)									
NUMBER OF CASING VOLUMES REMOVED									
DEWATERED?									

Groundwater Purge and Sample Form

Date: 9/6/95

Kennedy/Jenks Consultants

PROJECT NAME:	<u>DAC</u>			WELL NUMBER:	<u>WCC-95</u>			
PROJECT NUMBER:	<u>1000000 944016.00</u>			PERSONNEL:	<u>RAP</u>			
STATIC WATER LEVEL (FT):	<u>63.68</u>			MEASURING POINT DESCRIPTION:	<u>Top of Casing</u>			
WATER LEVEL MEASUREMENT METHOD:	<u>Elec. Probe</u>			PURGE METHOD:	<u>Redi-Flow</u>			
TIME START PURGE:	<u>953</u>			PURGE DEPTH (FT)	<u>75</u>			
TIME END PURGE:	<u>1004</u>							
TIME SAMPLED:	<u>1016</u>							
COMMENTS:								
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	MULTIPLIER FOR CASING DIAMETER (IN)			CASING VOLUME (GAL)	
				X	2	4		6
	<u>89.20</u>	<u>63.68</u>	<u>25.52</u>		<u>0.16</u>	<u>0.64</u>	<u>1.44</u>	<u>49</u>
TIME	<u>955</u>	<u>957</u>	<u>959</u>	<u>961</u>	<u>962</u>	<u>1003</u>		
VOLUME PURGED (GAL)	<u>10</u>	<u>20</u>	<u>30</u>	<u>40</u>	<u>45</u>	<u>50</u>		
PURGE RATE (GPM)	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>		
TEMPERATURE (°F)	<u>75.1</u>	<u>76.1</u>	<u>75.0</u>	<u>75.4</u>	<u>75.1</u>	<u>74.9</u>		
pH	<u>7.26</u>	<u>7.44</u>	<u>7.40</u>	<u>7.36</u>	<u>7.34</u>	<u>7.31</u>		
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected)	<u>1507</u>	<u>1197</u>	<u>1152</u>	<u>1132</u>	<u>1125</u>	<u>1119</u>		
DISSOLVED OXYGEN (mg/L)	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>		
eh(MV)Pt-AgCl ref.	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>	<u>—</u>		
TURBIDITY/COLOR	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>	<u>CLEAR</u>		
ODOR	<u>N</u>	<u>N</u>	<u>N</u>	<u>N</u>	<u>N</u>	<u>N</u>		
DEPTH OF PURGE INTAKE (FT)	<u>75</u>	<u>75</u>	<u>25</u>	<u>75</u>	<u>75</u>	<u>25</u>		
DEPTH TO WATER DURING PURGE (FT)								
NUMBER OF CASING VOLUMES REMOVED								
DEWATERED?								

Groundwater Purge and Sample Form

Date: 9/6/95

Kennedy/Jenks Consultants

PROJECT NAME:	DAC			WELL NUMBER:	WCC - 105			
PROJECT NUMBER:	944016.00			PERSONNEL:	R.A.P.			
STATIC WATER LEVEL (FT):	67.10			MEASURING POINT DESCRIPTION:	Top of casing			
WATER LEVEL MEASUREMENT METHOD:	Elec.			PURGE METHOD:	Reduction			
TIME START PURGE:	1149			PURGE DEPTH (FT)				
TIME END PURGE:	1200							
TIME SAMPLED:	1215							
COMMENTS:								
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	MULTIPLIER FOR CASTING DIAMETER (IN)			3 X CASING VOLUME (GAL)	
				X	2	4		6
					0.16	0.64		1.44
89.60	67.10	22.5					43.2	
TIME	1151	1153	1155	1157	1158	1159		
VOLUME PURGED (GAL)	10	20	30	76	45	50		
PURGE RATE (GPM)	5	5	5	5	5	5		
TEMPERATURE (°C)	18.7	16.3	14.6	14.8	14.9	15.1		
pH	7.31	7.43	7.23	7.23	7.18	7.17		
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected) cm	972	954	951	949	950	952		
DISSOLVED OXYGEN (mg/L)	—	—	—	—	—	—		
eH(MV)Pt-AgCl ref.	—	—	—	—	—	—		
TURBIDITY/COLOR	Clear	Clear	Clear	Clear	Clear	Clear		
ODOR	N	N	N	N	N	N		
DEPTH OF PURGE INTAKE (FT)	75	75	75	75	75	75		
DEPTH TO WATER DURING PURGE (FT)								
NUMBER OF CASING VOLUMES REMOVED								
DEWATERED?								

PROJECT NAME:	<u>DAC</u>			WELL NUMBER:	<u>WCC - 113</u>			
PROJECT NUMBER:	<u>G44016.00</u>			PERSONNEL:	<u>RAP</u>			
STATIC WATER LEVEL (FT):	<u>65.66</u>			MEASURING POINT DESCRIPTION:	<u>Top of casing</u>			
WATER LEVEL MEASUREMENT METHOD:	<u>Elec. probe</u>			PURGE METHOD:	<u>Rediflow</u>			
TIME START PURGE:	<u>1326</u>			PURGE DEPTH (FT)				
TIME END PURGE:	<u>1338</u>							
TIME SAMPLED:	<u>1350</u>							
COMMENTS:								
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	X	MULTIPLIER FOR CASING DIAMETER (IN)			3 X CASING VOLUME (GAL)
					2	4	6	
	<u>89.30</u>	<u>65.66</u>	<u>23.64</u>		0.16	0.64	1.44	<u>45</u>
TIME	<u>1326</u>	<u>1331</u>	<u>1334</u>	<u>1336</u>	<u>1337</u>	<u>1338</u>		
VOLUME PURGED (GAL)	<u>10</u>	<u>20</u>	<u>30</u>	<u>40</u>	<u>45</u>	<u>50</u>		
PURGE RATE (GPM)	<u>4</u>	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>	<u>5</u>		
TEMPERATURE (°C)	<u>73.9</u>	<u>73.6</u>	<u>74.5</u>	<u>74.9</u>	<u>74.5</u>	<u>74.2</u>		
pH	<u>7.24</u>	<u>7.25</u>	<u>7.20</u>	<u>7.22</u>	<u>7.20</u>	<u>7.21</u>		
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected) cm	<u>1382</u>	<u>1366</u>	<u>1390</u>	<u>1380</u>	<u>1375</u>	<u>1370</u>		
DISSOLVED OXYGEN (mg/L)	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>		
eH(MV)Pt-AgCl ref.	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>	<u>-</u>		
TURBIDITY/COLOR	<u>slight</u>	<u>slight</u>	<u>clear</u>	<u>clear</u>	<u>clear</u>	<u>clear</u>		
ODOR	<u>N</u>	<u>N</u>	<u>N</u>	<u>N</u>	<u>N</u>	<u>N</u>		
DEPTH OF PURGE INTAKE (FT)	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>	<u>75</u>		
DEPTH TO WATER DURING PURGE (FT)								
NUMBER OF CASING VOLUMES REMOVED								
DEWATERED?								

PROJECT NAME:	DAC		WELL NUMBER:	WCC-125		
PROJECT NUMBER:	944016.00		PERSONNEL:	ZAP		
STATIC WATER LEVEL (FT):	63.78		MEASURING POINT DESCRIPTION:	Top of casing		
WATER LEVEL MEASUREMENT METHOD:	Elec. Probe		PURGE METHOD:	Revol-Flood		
TIME START PURGE:	1416		PURGE DEPTH (FT)	75'		
TIME END PURGE:	1425					
TIME SAMPLED:	1423					
COMMENTS:						
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	MULTIPLIER FOR CASING DIAMETER (IN)		CASING VOLUME (GAL)
				2	4	
	90.25	63.78	26.47	0.16	0.64	1.44
TIME	1418	1420	1422	1424	1425	1426
VOLUME PURGED (GAL)	10	20	30	40	45	50
PURGE RATE (GPM)	5	5	5	5	5	5
TEMPERATURE (°F)	75.0	75.6	75.7	75.7	75.6	75.5
pH	7.63	7.44	7.39	7.34	7.36	7.31
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected)	1257	1183	1168	1159	1169	1166
DISSOLVED OXYGEN (mg/L)	-	-	-	-	-	-
eH(MV)Pt-AgCl ref.	-	-	-	-	-	-
TURBIDITY/COLOR	slt brown	slt brown	slt brown	slt brown	slt/clear	slight/ clear
ODOR	N	N	N	N	N	N
DEPTH OF PURGE INTAKE (FT)	75	75	75	75	75	75
DEPTH TO WATER DURING PURGE (FT)						
NUMBER OF CASING VOLUMES REMOVED						
DEWATERED?						

Groundwater Purge and Sample Form

Date: 9/7/85

Kennedy/Jenks Consultants

PROJECT NAME: DRC

WELL NUMBER: DAEP-1

PROJECT NUMBER: 944016.02

PERSONNEL: RAP

STATIC WATER LEVEL (FT): 68.20

MEASURING POINT DESCRIPTION: Top of casing

WATER LEVEL MEASUREMENT METHOD: Elec Probe

PURGE METHOD: Redi flow

TIME START PURGE: 1508

PURGE DEPTH (FT)

TIME END PURGE: 1519

TIME SAMPLED: 1530

COMMENTS:

WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	=	WATER COLUMN (FT)	MULTIPLIER FOR CASING DIAMETER (IN)			3 X CASING VOLUME (GAL)
					2	4	6	
					0.16	0.64	1.44	
	90	68	=	22				42

TIME	1510	1512	1514	1516	1517	1518	
VOLUME PURGED (GAL)	10	20	30	40	45	50	
PURGE RATE (GPM)	5	5	5	5	5	5	
TEMPERATURE (°C)	78.0	76.5	75.8	75.0	75.1	74.9	
pH	7.23	7.21	7.09	7.01	7.06	7.12	
SPECIFIC CONDUCTIVITY (micromhos/cm) (uncorrected)	2450	2280	2330	2320	2310	2300	
DISSOLVED OXYGEN (mg/L)	—	—	—	—	—	—	
eH(MV)Pt-AgCl ref.	—	—	—	—	—	—	
TURBIDITY/COLOR	Some Silt	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR	
ODOR	N	N	N	N	N	N	
DEPTH OF PURGE INTAKE (FT)	75	75	75	75	75	75	
DEPTH TO WATER DURING PURGE (FT)							
NUMBER OF CASING VOLUMES REMOVED				1			
DEWATERED?							

Groundwater Purge and Sample Form

Date: 9/6/95

Kennedy/Jenks Consultants

PROJECT NAME: Dac

WELL NUMBER: WCC-1D

PROJECT NUMBER: 944016.00

PERSONNEL: RAP

STATIC WATER LEVEL (FT): 67.15

MEASURING POINT DESCRIPTION: Top of Casing

WATER LEVEL MEASUREMENT METHOD: ELEC. PROBE

PURGE METHOD: Bed flush

TIME START PURGE: 1037

PURGE DEPTH (FT) 90

TIME END PURGE: 1102

TIME SAMPLED: 1135

COMMENTS:

WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	DEPTH TO WATER (FT)	WATER COLUMN (FT)	X	MULTIPLIER FOR CASING DIAMETER (IN)			3 X CASING VOLUME (GAL)
					2	4	6	
					0.16	0.64	1.44	
	135.50	67.15						131

TIME	1039	1055	1104	1106	1108	1110	1112
VOLUME PURGED (GAL)	10	50	100	110	120	130	140
PURGE RATE (GPM)	5	4	5	5	5	5	5
TEMPERATURE (°C)	29.5	25.7	25.6	25.3	24.9	24.8	24.6
pH	7.55	7.82	7.66	7.65	7.70	7.69	7.69
SPECIFIC CONDUCTIVITY (micromhos/cm) (uncorrected)	759	148	726	723	719	716	715
DISSOLVED OXYGEN (mg/L)	—	—	—	—	—	—	—
eH(MV)Pt-AgCl ref.	—	—	—	—	—	—	—
TURBIDITY/COLOR	clear						
ODOR	N	N	N	N	N	N	N
DEPTH OF PURGE INTAKE (FT)	90	90	90	90	90	90	90
DEPTH TO WATER DURING PURGE (FT)							
NUMBER OF CASING VOLUMES REMOVED							
DEWATERED?							

Groundwater Purge and Sample Form

Date: 9/7/95

Kennedy/Jenks Consultants

PROJECT NAME:	DAC			WELL NUMBER:	WCC-3D			
PROJECT NUMBER:	944016.00			PERSONNEL:	RAP			
STATIC WATER LEVEL (FT):	67.74			MEASURING POINT DESCRIPTION:	Top of Casing			
WATER LEVEL MEASUREMENT METHOD:	Elec. probe			PURGE METHOD:	Rapid Flow			
TIME START PURGE:	1207			PURGE DEPTH (FT)	120			
TIME END PURGE:	1239							
TIME SAMPLED:	1255							
COMMENTS:								
WELL VOLUME CALCULATION (FILL IN BEFORE PURGING)	TOTAL DEPTH (FT)	-	DEPTH TO WATER (FT)	-	WATER COLUMN (FT)	X	MULTIPLIER FOR CASING DIAMETER (IN)	3 X CASING VOLUME (GAL)
							2	
	140	-	67.74	-	72.26	X	0.16 0.64 1.44	- 139
TIME	1209	1223	1233	1235	1237	1239		
VOLUME PURGED (GAL)	10	60	10	120	130	140		
PURGE RATE (GPM)	5	5	5	5	5	5		
TEMPERATURE (°C)	75.7	75.9	75.1	75.0	74.7	74.5		
pH	7.72	7.76	7.84	7.54	7.59	7.61		
SPECIFIC CONDUCTIVITY (micromhos) (uncorrected) cm	755	740	728	726	724	725		
DISSOLVED OXYGEN (mg/L)	—	—	—	—	—	—		
eH(MV)Pt-AgCl ref.	—	—	—	—	—	—		
TURBIDITY/COLOR	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR		
ODOR	Y	Y	N	N	N	N		
DEPTH OF PURGE INTAKE (FT)	120	120	120	120	120	120		
DEPTH TO WATER DURING PURGE (FT)								
NUMBER OF CASING VOLUMES REMOVED								
DEWATERED?								

WATER LEVEL DATA SHEET

Job No. 944016.01

Facility DAe

WATER LEVEL DATA SHEET

Well No.	Date Mo/Day/Yr	Time	Well Elevation	Depth To Water	Water Elevation	Initials	Comments
WCC-5S	9/20/95	1145		64.57	-16.35	KKP	
WCC-9S		1155		63.65	-16.64	KKP	
WCC-12S		1205		63.71	-16.79	KKP	
WCC-2S		1225		66.78	-16.19	KKP	
WCC-7S		1245		65.11	-16.82	KKP	
WCC-11S		1255		65.56	-15.59	KKP	
WCC-4S		1305		66.07	-16.38	KKP	
WCC-8S		1310		66.72	-16.16	KKP	
WCC-1S		1320		66.97	-16.27	KKP	
WCC-1D		1327		67.05	-16.60	KKP	
WCC-3S		1335		67.56	-16.34	KKP	
WCC-3D		1340		67.65	-16.75 -16.47	XKD	
WCC-6S		— CAN'T OPEN —				KKP	
WCC-10S		1405		67.01	-15.89	XKP	
DAC-PI	▼	1415		68.10	-15.66	KKP	

Job No. 944016.01

Facility DAC

APPENDIX D

CHAIN-OF-CUSTODY RECORDS

CHAINS OF SECURITY INC.

DULUTH, GA

JULY, 2001

2495 Da Vinci, Irvine, CA 92714

Phone (714)252-9700

Fax (714)252-9701

CJ

Sample ID	Depth	Date	Time	Sample Type	Container Type	Total Number of Containers	CF Contaminants	ANALYSES	601/8010	602/8020	BTEX	8015 UVIH	8015 UTEH	4132	4181	4131	PCBS OHL	6248080	6258270	TITLE 26 Metals	ZHE Extraction	8260	RCRA Materials	TCLP Extraction	WEF Extraction	8260	Field Notes:		
WCC75-12	10ft	0852	11Q	VQA	3																								
WCC85-12		0855																											
WCC45-12		0945																											
WCC15-12		1120																											
WCC3D-12		1220																											
WCC3S-12		1330																											
WCC6S-12		1445																											
DAC-P1-12		1545																											
EP2090795		-																											
1P2070775		-																											
DR2070755		-																											

WCC75-12	10ft	0852	11Q	VQA	3																							
WCC85-12		0855																										
WCC45-12		0945																										
WCC15-12		1120																										
WCC3D-12		1220																										
WCC3S-12		1330																										
WCC6S-12		1445																										
DAC-P1-12		1545																										
EP2090795		-																										
1P2070775		-																										
DR2070755		-																										

RElinquished By: (Signature) RICK PARKER	Date/Time 11/9/01 - 17:55	Received By: (Signature) DANIELLE	Date/Time 11/9/01 - 17:55	LABORATORY NOTES:	DATE DATA NEEDED BY:
RElinquished By: (Signature)	Date/Time	Received By: (Signature)	Date/Time	All samples will be disposed of 30 days after invoice unless specified on chain of custody - write 'archive' for _____ days - by any sample to be archived.	
RElinquished By: (Signature)	Date/Time	Received By: (Signature)	Date/Time	\$5 / sample / month will be charged	
SEND ANALYTICAL REPORT TO: RICK PARKER				CLIENT JOB I.D.: DAC	C&T QUOTE NO.:
COMPANY: CCI				SAMPLING LOCATION: DAC	
ADDRESS: CITY: IRVINE STATE: ZIP CODE: 92610				COLLECTOR: R PARKER	
PHONE NUMBER: 714-2577 FAX NUMBER: 261-2131				PROJECT MANAGER: SARAH PARKER	WHITE COPY - Original (Accompanies Sample) PINK COPY - Collector
					Form # COCO293