

adcoat, inc.

172 East La Jolla Road, Placentia, California 92670 - (714) 630-7311

AC-830 STRIPPER

PRODUCT DESCRIPTION

AC-830 Stripper has been specially formulated to facilitate the removal of chemical milling masks after the etch process is completed. The immersion of masked parts in AC-830 Stripper results in sharply reduced mask to metal adhesion and subsequent easier hand removal of the mask.

PRODUCT CHARACTERISTICS

APPEARANCE	Colorless Liquid
SPECIFIC GRAVITY @ 20° C.	0.820 ± 0.030
FLASH POINT, T.O.C.	None to 180° F.
STORAGE LIFE (Closed Container)	1 Year
SOLVENT SYSTEM	Meets Reg. 3, Rule 66

PRODUCT PRECAUTIONS

Contains chlorinated hydrocarbons and petroleum distillates. Keep out of reach of children. Warning! Vapor is harmful if inhaled. Use with adequate ventilation. Avoid prolonged or repeated contact with skin. Do not take internally. First Aid: If inhaled, remove to fresh air. If not breathing give artificial respiration. Give oxygen if breathing is difficult. If swallowed, induce vomiting by having patient drink mustard water, luke warm salt water, or warm soapy water. If necessary induce vomiting by inserting a finger down patients throat. Repeat procedure at least five times then have patient drink a tablespoon of epsom salts dissolved in a glass of water. Call physician immediately.

Store containers, tightly closed, in a cool place. Open container carefully to avoid spurting.

PRODUCT PACKAGING

AC-830 Stripper and AC-830 Stripper Additive, are furnished in 5 gallon pails and 55 gallon drums.

PRODUCT USE INSTRUCTIONS

GENERAL - The directions and recommendations given below are intended to serve as a guide only and may need modification to meet local conditions.

MIXING/THINNING - Use AC-830 Stripper as received. No mixing or thinning is necessary.

DEMASKING -

1. Immerse parts to be demasked in AC-830 Stripper for 10 to 20 minutes.
2. Treated parts are then removed from the stripper and allowed to drain over the stripper tank.

"service is part of our formula"

DEMASKING (cont.) -

3. Allow treated parts to air dry for 10 to 30 minutes before removing mask.
4. Hand strip loose mask from parts. Solvent wipe parts to remove any mask stains or residue.

SOLUTION CONTROL

1. AC-830 Stripper is controlled by maintaining its specific gravity between 0.800 and 0.840.
2. Add AC-830 Stripper as required to maintain solution level.
3. Add AC-830 Stripper Additive to increase specific gravity when required. An addition of 1% by volume of AC-830 Stripper Additive should raise the specific gravity of the AC-830 Stripper solution by 0.005.

EQUIPMENT RECOMMENDATIONS

AC-830 Stripper may be stored in a mild steel tank. Tank should be placed in a well ventilated area.

Seller makes no warranty, express or implied, concerning the use of this product. Since conditions of use are beyond our control, buyer assumes all risk of use of this product. Sellers sole obligation shall be to replace the product if found to be defective. Seller shall not be liable for any loss, damage, or injury, direct or consequential, arising out of the use of this product.