

Ethylene Oxide Treatment

Ethylene Oxide Treatment		In this sheet, air emissions and the quantity treated on site is calculated for ethylene oxide. Catalytic oxidizer: Emissions from catalytic oxidizers are estimated based on 2016 testing that indicates 0.162 pounds per hour of emissions for 2015-2018. Emissions for 2019 are based on the 1 ppm figure from NESHAP Subpart O standard for aeration room vents. This is a change from 2018 RY based on indication of potential higher emissions in 2019 vs. 2016 emissions testing data, but without readily available data to calculate. Scrubber: Emissions from the scrubber are estimated based on assuming all ethylene oxide is fed the						
Ethylene Oxide Use	2016	Comments	2017	Comments	2018	Comments	2019	Comments
Ethylene Oxide Use	354,000 lb		356,800 lb		378,000 lb		395,600 lb	
SN-116 and SN-117 Catalytic Oxidizers		Comments	Comments	Comments	Comments	Comments	Comments	Comments
Hours of Operation	8,784 hr/yr		8,760 hr/yr		8,760 hr/yr		8,760 hr/yr	
Oxidizer A - Ethylene Oxide Emissions		Note: no change from reported emissions from the catalytic oxidizers. Calculations taken from file "PlantVOCHAPnew_v1.0"		Note: no change from reported emissions from the catalytic oxidizers. Calculations taken from file "PlantVOCHAPnew_v1.0"		Note: no change from reported emissions from the catalytic oxidizers. Calculations taken from file "PlantVOCHAPnew_v1.0"	1 ppm	1 ppm figure from NESHAP Subpart O standard for aeration room vents. Change from 2018 RY based on indication of potential higher emissions in 2019 vs. 2016 emissions testing data, but without readily available data to calculate.
Oxidizer B - Ethylene Oxide Emissions							25,828 scfm	
							0.177 lb/hr Ethylene Oxide Emissions	
							1 ppm	
							25,351 scfm	
							0.174 lb/hr Ethylene Oxide Emissions	
							0.351 lb/hr Ethylene Oxide Emissions	
Ethylene Oxide Treated in Oxidizers & Scrubbers	337,341 lb Ethylene Oxide		341,355 lb Ethylene Oxide		360,966 lb Ethylene Oxide		376,085 lb Ethylene Oxide	
Total Oxidizer Emissions	1,423 lb/yr Ethylene Oxide Emissions, total both oxidizers		1,419 lb/yr Ethylene Oxide Emissions, total both oxidizers		1,419 lb/yr Ethylene Oxide Emissions, total both oxidizers		3,077 lb/yr Ethylene Oxide Emissions, total both oxidizers	
SN-101 Scrubber		Comments	Comments	Comments	Comments	Comments	Comments	Comments
Pre-Scrubber Ethylene Oxide	354,000 lb Ethylene Oxide	99% figure from NESHAP Subpart O standard for sterilization chamber vents. Same factor as used for 2018 RY.	356,800 lb Ethylene Oxide	99% figure from NESHAP Subpart O standard for sterilization chamber vents. Same factor as used for previous year importing.	378,000 lb Ethylene Oxide	99% figure from NESHAP Subpart O standard for sterilization chamber vents. Same factor as used for previous year importing.	395,600 lb Ethylene Oxide	99% figure from NESHAP Subpart O standard for sterilization chamber vents. Same factor as used for 2018 RY.
Scrubber Control	99.00%		99.00%		99.00%			
Scrubber Emissions	3,540 lb Ethylene Oxide		3,568 lb Ethylene Oxide		3,780 lb Ethylene Oxide		3,956 lb Ethylene Oxide	
General Fugitive Emissions		Comments	Comments	Comments	Comments	Comments	Comments	Comments
Ethylene Oxide Use	354,000 lb	EPA factor from Federal Register, 12/12/2019. Different factor used in previous years. This is a change from prior calculations that used an emission factor of 1% of emissions.	356,800 lb	EPA factor from Federal Register, 12/12/2019. Different factor used in previous years. This is a change from prior calculations that used an emission factor of 1% of emissions.	378,000 lb	EPA factor from Federal Register, 12/12/2019. Different factor used in previous years. This is a change from prior calculations that used an emission factor of 1% of emissions.	395,600 lb	EPA factor from Federal Register, 12/12/2019. Different factor used in previous years. This is a change from prior calculations that used an emission factor of 1% of emissions.
General Fugitive Emissions	0.5%		0.5%		0.5%			
	1,770 lb		1,784 lb		1,890 lb		1,978 lb	
SN-119 Sterilization Chamber #7 Rear Chamber Exhaust		Comments	Comments	Comments	Comments	Comments	Comments	Comments
Ethylene Oxide Vented Per Batch	2.23 lb	From 2014 ERM calculations	2.23 lb	From 2014 ERM calculations	2.23 lb	From 2014 ERM calculations	2.23 lb	From 2014 ERM calculations
2019 Batches	1 batches		51 batches		195 batches		181 batches	
Ethylene Oxide Emissions	2 lb	From K. Steelman 6/24/2020 data	114 lb	From K. Steelman 6/24/2020 data	435 lb	From K. Steelman 6/24/2020 data	404 lb	From K. Steelman 6/24/2020 data
Total Ethylene Oxide Emissions		Comments	Comments	Comments	Comments	Comments	Comments	Comments
SN-101 Scrubber	3,540 lb		3,568 lb		3,780 lb		3,956 lb	
SN-116 and SN-117 CO	1,423 lb		1,419 lb		1,419 lb		3,077 lb	
SN-119 Sterilization Chamber #7	2 lb		114 lb		435 lb		404 lb	
General Fugitives	1,770 lb		1,784 lb		1,890 lb		1,978 lb	
Total Ethylene Oxide Emissions	6,735 lb		6,885 lb		7,524 lb		9,415 lb	

	A	B	C	D	E	F	G	H	I	J	K	L	M
1	Inputs & Summary							Ethylene Oxide Emissions (lbs)		2019	2020 Period 1	2020 Pd. 2-7	2020
2								SN-101 Scrubber		3,795	505	654	1,159
3								SN-116 and SN-117 CO		3,077	4,244	268	4,511
4								SN-119 Sterilization Chamber #7		404	75	4	78
5								General Fugitives		1,897	327	1,725	2,052
6								Total Ethylene Oxide Emissions		9,173	5,151	2,650	7,801
7													
8	Ethylene Oxide Use from Dave Miller											Quantity Treated on-Site (lbs)	402,677
9	Period	EO Use (lbs)											
10	1	65,487						Period 1 (1/1-2/13) operated with high emissions from Cat Ox units					
11	2	59,570						Period 2 (2/25-4/22) operated with TOs after the CatOx and dry beds after chamber #7 and after the scrubber					
12	3	73,574						Period 3 (4/23-6/24) operated with one TO after one CatOx and dry beds after the other CatOx, scrubber, and chamber #7					
13	4	29,193						Period 4 (6/25-7/12) operated with dry beds after CatOx and chamber 7 and dry beds after the scrubber					
14	5	36,294						Period 5 (7/13-8/4) operated with dry beds after CatOx and chamber 7 and a TO after the scrubber					
15	6	23,670						Period 6 (8/5-8/24) operated as period 5 did but with new catalyst in the north oxidizer					
16	7	122,690						Period 7 (8/25-12/31) operated as period 6 did but with new catalyst in the south oxidizer as well					
17	2020 Total	410,477											
18													
19	EO use calculated from JDE system. Each tank used contains 400 pounds of ethylene oxide. Only 394.5 pounds of each is used per EO supplier.												
20													
21	Timeline from Kevin Beckham & Dave Miller												
22	Operation shut down – 2/11/20												
23	Operation started up – 2/25/20												
24	TOs added post CatOx units for polishing												
25	Dry beds added post Scrubber for polishing												
26	Dry beds added for Vessel 7 rear chamber exhaust												
27	South TO replaced with South dry bed chain (14) for polishing – 4/23/20												
28	North TO replaced with North dry bed chain (14) for polishing – 6/25/20												
29	Dry beds post scrubber replaced by TO unit for polishing – 7/13/20												
30	Catalyst in CatOx replaced - 8/5/20 (north) & 8/25/20 (south)												
31													
32													
33													
34													
35													
36													
37													
38													
39													
40													
41													
42													
43													
44													
45													
46													
47													
48													
49													
50	ETO Emissions - Previous Estimate		2020	2021									
51	SN-101 Scrubber		759	63									
52	SN-116 and SN-117 CO		4,564	461									
53	SN-119 Sterilization Chamber #7		80	203									
54	General Fugitives		2,029	1,539									
55	Total Ethylene Oxide Emissions		7,432	2,266									
56													
57													
58	ETO Emissions - Current Estimate		2020	2021	2022								
59	SN-101 Scrubber		1,159	64	64								
60	SN-116 and SN-117 CO		4,511	11	11								
61	SN-119 Sterilization Chamber #7		78	0	0								
62	General Fugitives		2,052	1,557	0								
63	Total Ethylene Oxide Emissions		7,801	1,632	75								

Assumptions

For whole year, assumed 77.1% EO to scrubber and 22.9% to catalytic oxidizers per Tim Stafford
 Dry bed efficiencies are based on EO concentrations per text box below.
 Thermal oxidizers (TOs) are 98% efficient per manufacturer

Efficiencies estimated by Dry Bed Supplier

99% at > 10 ppmv inlet
 98% at 5-10 ppmv inlet
 95% at 1-4 ppmv inlet
 90% at 0.5-0.9 ppmv inlet
 75% at 0.2-0.4 ppmv inlet
 50% at 0.05-0.1 ppmv inlet

Supplier contact:
 Randal Nicolli, P.E.
 Engineering Manager
 Advanced Air Technologies, Inc.
 300 Slesseman Drive
 Corunna, MI 48817
 (989) 743-5544
micolli@advairtech.com

	A	B	C	D	E	F	G	H	I	J	K
1											
2	Baxter Healthcare Toxic Release Inventory					Period 1 (1/1-2/13) operated with high emissions from Cat Ox units					
3						start	1/1/20 0:00		Days	43.99999	
4	Site Specific Factors		2020 - Period 1			end	2/13/20 23:59		Hours	1056	
5											
6	Ethylene Oxide Data					Comments					
7	Ethylene Oxide Used		65,487 lb/period								
8	Ethylene Oxide Mol. Wt.		44.05 lb/lbmol								
9											
10	SN-116 and SN-117 Catalytic Oxidizers					Comments					
11	Hours of Operation		1,056 hr/period								
12											
13											
14											
15	So. Oxidizer - Ethylene Oxide Emissions		12.47 ppm								
16			28,400 scfm								
17			2.431 lb/hr Ethylene Oxide Emissions								
18			Source for the concentrations and flowrates is data provided by LCH.								
19	No. Oxidizer - Ethylene Oxide Emissions		7.5 ppm								
20			30,850 scfm								
21			1.588 lb/hr Ethylene Oxide Emissions								
22											
23	Total Oxidizer Emissions		4.019 lb/hr Ethylene Oxide Emissions								
24	Total Oxidizer Emissions		4,244 lb/period Ethylene Oxide								
25											
26	SN-101 Scrubber					Comments					
27	Pre-Scrubber Ethylene Oxide		50,490 lb Ethylene Oxide								
28	Scrubber Control		99.00%								
29											
30	Scrubber Emissions		505 lb/period Ethylene Oxide								
31											
32	General Fugitive Emissions					Comments					
33	Ethylene Oxide Used		65,487 lb								
34	General Fugitive Emissions		0.5%								
35			327 lb								
36											
37	SN-119 Sterilization Chamber #7 Rear Chamber Exhaust					Comments					
38	Ethylene Oxide Vented Per Batch		2.23 lb								
39	Batches		34 batches								
40	Ethylene Oxide Emissions		75 lb								
41											
42	Total Ethylene Oxide Emissions					Comments					
43	SN-101 Scrubber		505 lb								
44	SN-116 and SN-117 CO		4,244 lb								
45	SN-119 Sterilization Chamber #7		75 lb								
46	General Fugitives		327 lb								
47	Total Ethylene Oxide Emissions		5,151 lb								
48											

	A	B	C	D	E	F	G	H	I	J
1	<div>Baxter Healthcare Toxic Release Inventory</div> <div>Period 2 (2/25-4/22) operated with TOs after the CatOx and dry beds after chamber #7 and after the scrubber.</div> <div>start2/25/20 0:00Days58</div> <div>end4/22/20 23:59Hours1392</div>									
2										
3										
4										
5	Site Specific Factors					2020 - Period 2				
6	Ethylene Oxide Data					Comments				
7	Ethylene Oxide Used			59,570 lb/period						
8	Ethylene Oxide Mol. Wt.			44.05 lb/lbmol						
9										
10	SN-116 and SN-117 Catalytic Oxidizers					Comments				
11	Hours of Operation1,392 hr/period					Source for the concentrations emitted from the oxidizers is the testing summarized in the pdf on the Period 1 sheet.				
12										
13										
14										
15	So. Oxidizer - Ethylene Oxide Emissions			12.47 ppm						
16				28,400 scfm						
17				2.431 lb/hr Ethylene Oxide Emissions						
18										
19										
20	No. Oxidizer - Ethylene Oxide Emissions			7.5 ppm						
21				30,850 scfm						
22				1.588 lb/hr Ethylene Oxide Emissions						
23										
24	Total Catalytic Oxidizer Emissions to Thermal Oxidiz			4.019 lb/hr Ethylene Oxide Emissions						
25	Thermal Oxidizer Emissions			0.080 lb/hr Ethylene Oxide Emissions						
26										
27	Total Thermal Oxidizer Emissions			112 lb/period Ethylene Oxide Emissions, total						
28										
29	SN-101 Scrubber					Comments				
30	Pre-Scrubber Ethylene Oxide			45,928 lb Ethylene Oxide		99% figure from NESHAP Subpart O standard for sterilization chamber vents. Same factor as used for 2018 RY.				
31	Scrubber Control			99.00%						
32										
33	Emissions from Scrubber			459 lb Ethylene Oxide		Efficiency estimated based on low EO conc. fed to the beds b/c high scrubber efficiency.				
34	Emissions from dry beds (50% efficiency)			230 lb Ethylene Oxide						
35										
36	General Fugitive Emissions					Comments				
37	Ethylene Oxide Used			59,570 lb		EPA factor from Federal Register, 12/12/2019. Different factor used in previous years.				
38	General Fugitive Emissions			0.5%						
39				298 lb						
40										
41	SN-119 Sterilization Chamber #7 Rear Chamber Exhaust					Comments				
42	Ethylene Oxide Vented Per Batch			2.23 lb		From 2014 ERM calculations Estimated 1 every 2 days per 2019 operation Efficiency based on info from supplier (text box) with conc. assumed >10 ppm (no upstream control).				
43	Batches			29 batches						
44	Emissions from dry beds (99% efficiency)			1 lb						
45										
46	Total Ethylene Oxide Emissions					Comments				
47	SN-101 Scrubber			230 lb						
48	SN-116 and SN-117 CO			112 lb						
49	SN-119 Sterilization Chamber #7			1 lb						
50	General Fugitives			298 lb						
51	Total Ethylene Oxide Emissions			640 lb						

	A	B	C	D	E	F	G	H	I	J
1	Baxter Healthcare Toxic Release Inventory					Period 3 (4/23-6/25) operated with a TO after No. CatOx and dry beds after So. CatOx, scrubber, and chamber #7				
2										
3										
4										
5	Site Specific Factors					2020 - Period 3				
6	Ethylene Oxide Data					Comments				
7	Ethylene Oxide Used		73,574 lb/period							
8	Ethylene Oxide Mol. Wt.		44.05 lb/lbmol							
9										
10	SN-116 and SN-117 Catalytic Oxidizers					Comments				
11	Hours of Operation		1,536 hr/period			Source for the concentrations emitted from the oxidizers is the testing summarized in the pdf on the Period 1 sheet.				
12										
13	So. Oxidizer - Ethylene Oxide Emissions		12.47 ppm							
14			28,400 scfm							
15			2.431 lb/hr Ethylene Oxide Emissions							
16	Dry Bed Emissions		0.024 lb/hr Ethylene Oxide Emissions							
17										
18	No. Oxidizer - Ethylene Oxide Emissions		7.5 ppm							
19			30,850 scfm							
20			1.588 lb/hr Ethylene Oxide Emissions							
21	Thermal Oxidizer Emissions		0.032 lb/hr Ethylene Oxide Emissions							
22										
23	Total Emissions		0.056 lb/hr Ethylene Oxide Emissions							
24	Total Emissions		86 lb/period Ethylene Oxide Emissions, total							
25										
26	SN-101 Scrubber					Comments				
27	Pre-Scrubber Ethylene Oxide		56,726 lb Ethylene Oxide			99% figure from NESHAP Subpart O standard for sterilization chamber vents. Same factor as used for 2018 RY.				
28	Scrubber Control		99.00%							
29										
30	Emissions from Scrubber		567 lb Ethylene Oxide							
31	Emissions from dry beds (50% efficiency)		284 lb Ethylene Oxide			Efficiency estimated based on low EO conc. fed to the beds b/c high scrubber efficiency.				
32										
33	General Fugitive Emissions					Comments				
34	Ethylene Oxide Used		73,574 lb			EPA factor from Federal Register, 12/12/2019. Different factor used in previous years.				
35	General Fugitive Emissions		0.5%							
36			368 lb							
37										
38	SN-119 Sterilization Chamber #7 Rear Chamber Exhaust					Comments				
39	Ethylene Oxide Vented Per Batch		2.23 lb			From 2014 ERM calculations Estimated 1 every 2 days per 2019 operation Efficiency based on info from supplier (text box) with conc. assumed >10 ppm (no upstream control).				
40	Batches		32 batches							
41	Emissions from dry beds (99% efficiency)		1 lb							
42										
43	Total Ethylene Oxide Emissions					Comments				
44	SN-101 Scrubber		284 lb							
45	SN-116 and SN-117 CO		86 lb							
46	SN-119 Sterilization Chamber #7		1 lb							
47	General Fugitives		368 lb							
48	Total Ethylene Oxide Emissions		738 lb							

	A	B	C	D	E	F	G	H	I	J
1	Baxter Healthcare Toxic Release Inventory					Period 4 (6/26-7/12) operated with dry beds after CatOx and chamber 7 and dry beds after the scrubber				
2										
3										
4										
5	Site Specific Factors					2020 - Period 4				
6	Ethylene Oxide Data					Comments				
7	Ethylene Oxide Used		29,193 lb/period							
8	Ethylene Oxide Mol. Wt.		44.05 lb/lbmol							
9										
10	SN-116 and SN-117 Catalytic Oxidizers					Comments				
11	Hours of Operation		408 hr/period			Source for the concentrations emitted from the oxidizers is the testing summarized in the pdf on the Period 1 sheet.				
12										
13	So. Oxidizer - Ethylene Oxide Emissions		12.47 ppm							
14			28,400 scfm							
15			2.431 lb/hr Ethylene Oxide Emissions							
16	Dry Bed Emissions		0.024 lb/hr Ethylene Oxide Emissions							
17										
18	No. Oxidizer - Ethylene Oxide Emissions		7.5 ppm							
19			30,850 scfm							
20			1.588 lb/hr Ethylene Oxide Emissions							
21	Dry Bed Emissions		0.032 lb/hr Ethylene Oxide Emissions							
22										
23	Total Emissions		0.056 lb/hr Ethylene Oxide Emissions							
24	Total Emissions		23 lb/period Ethylene Oxide Emissions, total							
25										
26	SN-101 Scrubber					Comments				
27	Pre-Scrubber Ethylene Oxide		22,508 lb Ethylene Oxide			99% figure from NESHAP Subpart O standard for sterilization chamber vents. Same factor as used for 2018 RY.				
28	Scrubber Control		99.00%							
29										
30	Emissions from Scrubber		225 lb Ethylene Oxide							
31	Emissions from dry beds (50% efficiency)		113 lb Ethylene Oxide			Efficiency estimated based on low EO conc. fed to the beds b/c high scrubber efficiency.				
32										
33	General Fugitive Emissions					Comments				
34	Ethylene Oxide Used		29,193 lb			EPA factor from Federal Register, 12/12/2019. Different factor used in previous years.				
35	General Fugitive Emissions		0.5%							
36			146 lb							
37										
38	SN-119 Sterilization Chamber #7 Rear Chamber Exhaust					Comments				
39	Ethylene Oxide Vented Per Batch		2.23 lb			From 2014 ERM calculations Estimated 1 every 2 days per 2019 operation Efficiency based on info from supplier (text box) with conc. assumed >10 ppm (no upstream control).				
40	Batches		9 batches							
41	Emissions from dry beds (99% efficiency)		0.2 lb							
42										
43	Total Ethylene Oxide Emissions					Comments				
44	SN-101 Scrubber		113 lb							
45	SN-116 and SN-117 CO		23 lb							
46	SN-119 Sterilization Chamber #7		0 lb							
47	General Fugitives		146 lb							
48	Total Ethylene Oxide Emissions		282 lb							

	A	B	C	D	E	F	G	H	I	J
1										
2	Baxter Healthcare Toxic Release Inventory					Period 5 (7/13-8/4) operated with dry beds after CatOx and chamber 7 and a TO after the scrubber				
3						start	7/13/20 0:00	Days	22.99999	
4	Site Specific Factors					end	8/4/20 23:59	Hours	551.9997	
5										
6	Ethylene Oxide Data					Comments				
7	Ethylene Oxide Used			36,294 lb/period						
8	Ethylene Oxide Mol. Wt.			44.05 lb/lbmol						
9										
10	SN-116 and SN-117 Catalytic Oxidizers					Comments				
11	Hours of Operation			552 hr/period						
12										
13	So. Oxidizer - Ethylene Oxide Emissions			12.47 ppm						
14				28,400 scfm						
15				2.431 lb/hr Ethylene Oxide Emissions						
16	Dry Bed Emissions			0.024 lb/hr Ethylene Oxide Emissions						
17										
18	No. Oxidizer - Ethylene Oxide Emissions			7.5 ppm						
19				30,850 scfm						
20				1.588 lb/hr Ethylene Oxide Emissions						
21	Dry Bed Emissions			0.032 lb/hr Ethylene Oxide Emissions						
22										
23	Total Emissions			0.056 lb/hr Ethylene Oxide Emissions						
24	Total Emissions			31 lb/period Ethylene Oxide Emissions, total						
25										
26	SN-101 Scrubber					Comments				
27	Pre-Scrubber Ethylene Oxide			27,983 lb Ethylene Oxide						
28	Scrubber Control			99.00%						
29										
30	Emissions from Scrubber			280 lb Ethylene Oxide						
31	Emissions from thermal oxidizer (98% efficiency)			6 lb Ethylene Oxide						
32										
33	General Fugitive Emissions					Comments				
34	Ethylene Oxide Used			36,294 lb						
35	General Fugitive Emissions			0.5%						
36				181 lb						
37										
38	SN-119 Sterilization Chamber #7 Rear Chamber Exhaust					Comments				
39	Ethylene Oxide Vented Per Batch			2.23 lb						
40	Batches			12 batches						
41	Emissions from dry beds (99% efficiency)			0.3 lb						
42										
43	Total Ethylene Oxide Emissions					Comments				
44	SN-101 Scrubber			6 lb						
45	SN-116 and SN-117 CO			31 lb						
46	SN-119 Sterilization Chamber #7			0 lb						
47	General Fugitives			181 lb						
48	Total Ethylene Oxide Emissions			218 lb						

	A	B	C	D	E	F	G	H	I	J					
1															
2	Baxter Healthcare Toxic Release Inventory					Period 6 (8/5-8/24) operated as period 5 did but with new catalyst in the north oxidizer									
3						start	8/5/20 0:00	Days	19.99999						
4	Site Specific Factors		2020 - Period 6			end	8/24/20 23:59	Hours	479.9997						
5															
6	Ethylene Oxide Data					Comments									
7	Ethylene Oxide Used		23,670 lb/period												
8	Ethylene Oxide Mol. Wt.		44.05 lb/lbmol												
9															
10	SN-116 and SN-117 Catalytic Oxidizers					Comments									
11	Hours of Operation		480 hr/period			<div>Source for the concentrations emitted from the south oxidizers is the testing summarized in the pdf on the Period 1 sheet.</div> <div>Dave Miller indicated that Montrose sampled the stack from the North Cat Ox & Dry Bed train in April 2021 and found ethylene oxide to be non-detect. The detection limit was 6 ppb. We use half the detection limit.</div>									
12															
13	So. Oxidizer - Ethylene Oxide Emissions		12.47 ppm												
14			28,400 scfm												
15			2.431 lb/hr Ethylene Oxide Emissions												
16	Dry Bed Emissions		0.024 lb/hr Ethylene Oxide Emissions												
17															
18	No. Oxidizer/Dry Bed Ethylene Oxide Emissions		0.003 ppm												
19			30,850 scfm												
20			0.001 lb/hr Ethylene Oxide Emissions												
21															
22															
23	Total Emissions		0.025 lb/hr Ethylene Oxide Emissions												
24	Total Emissions		12 lb/period Ethylene Oxide Emissions, total												
25															
26	SN-101 Scrubber					Comments									
27	Pre-Scrubber Ethylene Oxide		18,250 lb Ethylene Oxide			99% figure from NESHAP Subpart O standard for sterilization chamber vents. Same factor as used for 2018 RY.									
28	Scrubber Control		99.00%												
29															
30	Emissions from Scrubber		182 lb Ethylene Oxide												
31	Emissions from thermal oxidizer (98% efficiency)		4 lb Ethylene Oxide			Efficiency estimated based on low EO conc. fed to the beds b/c high scrubber efficiency.									
32															
33	General Fugitive Emissions					Comments									
34	Ethylene Oxide Used		23,670 lb			EPA factor from Federal Register, 12/12/2019. Different factor used in previous years.									
35	General Fugitive Emissions		0.5%												
36			118 lb												
37															
38	SN-119 Sterilization Chamber #7 Rear Chamber Exhaust					Comments									
39	Ethylene Oxide Vented Per Batch		2.23 lb			From 2014 ERM calculations Estimated 1 every 2 days per 2019 operation Efficiency based on info from supplier (text box) with conc. assumed >10 ppm (no upstream control).									
40	Batches		10 batches												
41	Emissions from dry beds (99% efficiency)		0.2 lb												
42															
43	Total Ethylene Oxide Emissions					Comments									
44	SN-101 Scrubber		4 lb												
45	SN-116 and SN-117 CO		12 lb												
46	SN-119 Sterilization Chamber #7		0 lb												
47	General Fugitives		118 lb												
48	Total Ethylene Oxide Emissions		134 lb												

	A	B	C	D	E	F	G	H	I	J
1						Period 7 (8/25-12/31) operated as period 6 did but with new catalyst in the south oxidizer as well				
2	Baxter Healthcare Toxic Release Inventory									
3						start	8/25/20 0:00	Days	129	
4	Site Specific Factors 2020 - Period 7					end	12/31/20 23:59	Hours	3096	
5										
6	Ethylene Oxide and Ethylene Glycol Data					Comments				
7	Ethylene Oxide Used		122,690 lb/period							
8	Ethylene Oxide Mol. Wt.		44.05 lb/lbmol							
9										
10	SN-116 and SN-117 Catalytic Oxidizers					Comments				
11	Hours of Operation		3,096 hr/period							
12										
13	so. Oxidizer/Dry Bed Ethylene Oxide Emissions		0.003 ppm							
14			28,400 scfm							
15			0.001 lb/hr Ethylene Oxide Emissions							
16						<div>Dave Miller indicated that Montrose sampled the stack from both the Cat Ox & Dry Bed trains in April 2021 and found ethylene oxide to be non-detect. The detection limit was 6 ppb. We use half the detection limit.</div>				
17										
18	No. Oxidizer/Dry Bed Ethylene Oxide Emissions		0.003 ppm							
19			30,850 scfm							
20			0.001 lb/hr Ethylene Oxide Emissions							
21										
22										
23	Total Emissions		0.001 lb/hr Ethylene Oxide Emissions							
24	Total Emissions		4 lb/period Ethylene Oxide Emissions, total							
25										
26	SN-101 Scrubber					Comments				
27	Pre-Scrubber Ethylene Oxide		94,594 lb Ethylene Oxide							
28	Scrubber Control		99.00%			99% figure from NESHAP Subpart O standard for sterilization chamber vents. Same factor as used for 2018 RY.				
29										
30	Emissions from Scrubber		946 lb Ethylene Oxide			Efficiency estimated based on low EO conc. fed to the beds b/c high scrubber efficiency.				
31	Emissions from thermal oxidizer (98% efficiency)		19 lb Ethylene Oxide							
32										
33	General Fugitive Emissions					Comments				
34	Ethylene Oxide Used		122,690 lb							
35	General Fugitive Emissions		0.5%			EPA factor from Federal Register, 12/12/2019. Different factor used in previous years.				
36			613 lb							
37										
38	SN-119 Sterilization Chamber #7 Rear Chamber Exhaust					Comments				
39	Ethylene Oxide Vented Per Batch		2.23 lb			From 2014 ERM calculations				
40	Batches		65 batches			Estimated 1 every 2 days per 2019 operation				
41	Emissions from dry beds (99% efficiency)		1 lb			Efficiency based on info from supplier (text box) with conc. assumed >10 ppm (no upstream control).				
42										
43	Total Ethylene Oxide Emissions					Comments				
44	SN-101 Scrubber		19 lb							
45	SN-116 and SN-117 CO		4 lb							
46	SN-119 Sterilization Chamber #7		1 lb							
47	General Fugitives		613 lb							
48	Total Ethylene Oxide Emissions		638 lb							

Dave Miller indicated that Montrose sampled the stack from both the Cat Ox & Dry Bed trains in April 2021 and found ethylene oxide to be non-detect. The detection limit was 6 ppb. We use half the detection limit.