U.S.ENVIRONMENTAL PROTECTION AGENCY NATIONAL AIR AND RADIATION ENVIRONMENTAL LABORATORY 540 S. MORRIS AVE., MONTGOMERY, AL 36115 RA226 ANALYSES

REPORT OF SAMPLE DELIVERY GROUP #1100248

Project:

Dimock Residential GW Site, Dimock, PA

Analysis method:

Radium-226 in Water: Rapid Method for High-Activity Samples

Report ID:

1100248-RA226

Report type:

Original 04/10/2012

Date reported:
Total pages in report:

30

SAMPLES

NAREL Sample #	Client Sample ID	Location	Matrix	Date Collected	Date Received
B2.01731G	HW49	PA:DIMOCK	WATER-DRINKING	02/09/2012	02/13/2012
B2.01732H	FB14	PA:DIMOCK	WATER-DRINKING	02/09/2012	02/13/2012
B2.01733J	HW21Z	PA:DIMOCK	WATER-DRINKING	02/09/2012	02/13/2012
B2.01734K	HW22	PA:DIMOCK	WATER-DRINKING	02/09/2012	02/13/2012
B2.01735L	HW44	PA:DIMOCK	WATER-DRINKING	02/09/2012	02/13/2012
B2.01736M	HW36N	PA:DIMOCK	WATER-DRINKING	02/10/2012	02/13/2012
B2.01737N	HW54	PA:DIMOCK	WATER-DRINKING	02/10/2012	02/13/2012
B2.01761N	HW55	PA:DIMOCK	WATER-DRINKING	02/13/2012	02/14/2012
B2.01762P	FB16	PA:DIMOCK	WATER-DRINKING	02/13/2012	02/14/2012
B2.01763Q	HW27	PA:DIMOCK	WATER-DRINKING	02/13/2012	02/14/2012
B2.01777X	FB17	PA:DIMOCK	WATER-DRINKING	02/14/2012	02/15/2012
B2.01778Y	HW57	PA:DIMOCK	WATER-DRINKING	02/14/2012	02/15/2012
B2.01779Z	HW03	PA:DIMOCK	WATER-DRINKING	02/14/2012	02/15/2012
B2.01780R	HW03Z	PA:DIMOCK	WATER-DRINKING	02/14/2012	02/15/2012
B2.01781T	HW58	PA:DIMOCK	WATER-DRINKING	02/14/2012	02/15/2012
B2.01782U	HW11	PA:DIMOCK	WATER-DRINKING	02/13/2012	02/15/2012
B2.01783V	HW27Z	PA:DIMOCK	WATER-DRINKING	02/13/2012	02/15/2012
B2.01784W	HW53	PA:DIMOCK	WATER-DRINKING	02/13/2012	02/15/2012
B2.01785X	HW59	PA:DIMOCK	WATER-DRINKING	02/14/2012	02/15/2012
B2.01877A	HW07	PA:DIMOCK	WATER-DRINKING	02/15/2012	02/16/2012

EXCEPTIONS

- 1. Packaging and shipping No problems were observed.
- 2. Documentation NAREL originally agreed to analyze 71 samples for this project, but sample collectors collected and shipped more samples than expected. NAREL then agreed to analyze 100 samples, which would make five batches of 20 for QC purposes. Actually 101 samples were received. With the client's permission, NAREL did not analyze the field blank received in the last shipment thus making the agreed upon total of 100 samples for analysis.
- 3. Sample preparation No problems were encountered.
- 4. Analysis No problems were encountered.
- 5. Holding times No holding times were specified.

QUALITY CONTROL

- 1. QC samples All QC analysis results met NAREL acceptance criteria.
- 2. Yields All chemical yields were within acceptance limits.
- 3. Instruments Response and background checks for all instruments used in these analyses met NAREL acceptance criteria.

CERTIFICATION

I certify that this data report complies with the terms and conditions of the Quality Assurance Project Plan, except as noted above. Release of the data contained in this report has been authorized by the Director of the Center for Environmental Radioanalytical Laboratory Science and the NAREL Quality Assurance Manager, or their designees, as verified by the following signatures.

Mary F. Wisdom Quality Assurance Manager, NAREL

Director, Center for Environmental Radioanalytical

Laboratory Science

GENERAL INFORMATION

SAMPLE TYPES

BLD Blind sample FBK Field blank SAM Normal sample

ANALYSIS QC TYPES

ANA Normal analysis
DUP Laboratory duplicate

LCS Laboratory control sample (blank spike)

MS Matrix spike

MSD Matrix spike duplicate

RBK Method blank

QUALITY INDICATORS

RPD Relative Percent Difference

%R Percent Recovery

Z Number of standard deviations by which a QC measurement differs from the expected value

EVALUATION OF QC ANALYSES

A method blank result is considered unacceptable if it is more than 3 standard deviations below zero or more than 3 standard deviations above a predetermined upper control limit. For some analyses NAREL has set the upper control limit at zero. For others the control limit is a small positive number.

NAREL evaluates the results of duplicate and spike analyses using "Z scores." A Z score is the number of standard deviations by which the QC result differs from its ideal value. The score is considered acceptable if its absolute value is not greater than 3.

The Z score for a spiked sample is computed by dividing the difference between the measured value and the target value by the combined standard uncertainty of the difference.

The Z score for a duplicate analysis is computed by dividing the difference between the two measured values by the combined standard uncertainty of the difference. When the precision of paired MS/MSD analyses is evaluated, the native sample activity is subtracted from each measured value and the net concentrations are then converted to total activities before the Z score is computed.

Each standard uncertainty used to compute a Z score includes an additional fixed term to represent sources of measurement error other than counting error. This additional term is not used in the evaluation of reagent blanks.

NAREL reports the "relative percent difference," or RPD, between duplicate results and the "percent recovery," or %R, for spiked analyses, but does not use these values for evaluation.

SDG #1100248

ANALYSIS SUMMARY

Analysis Procedure:

NAREL RA226-EICHROM

Title:

Radium-226 in Water: Rapid Method for High-Activity Samples

	QC		Date	Assay	QC
NAREL Sample #	Туре	Preparation Procedure	Completed	Batch #	Batch #
B2.01731G		N/A	04/05/2012	0015862U	0008615C
B2.01732H	1	N/A	04/06/2012	0015862U	0008615C
B2.01733J		N/A	04/05/2012	0015862U	0008615C
B2.01734K		N/A	04/05/2012	0015862U	0008615C
B2.01735L		N/A	04/05/2012	0015862U	0008615C
B2.01736M		N/A	04/05/2012	0015862U	0008615C
B2.01737N		N/A	04/05/2012	0015862U	0008615C
B2.01761N		N/A	04/06/2012	0015868A	0008615C
B2.01762P		N/A	04/06/2012	0015868A	0008615C
B2.01763Q		N/A	04/06/2012	0015868A	0008615C
B2.01763Q	DUP	N/A	04/06/2012	0015868A	0008615C
B2.01777X		N/A	04/06/2012	0015868A	0008615C
B2.01778Y		N/A	04/06/2012	0015868A	0008615C
B2.01779Z		N/A	04/06/2012	0015868A	0008615C
B2.01780R		N/A	04/06/2012	0015868A	0008615C
B2.01781T		N/A	04/07/2012	0015872W	0008615C
B2.01782U		N/A	04/07/2012	0015872W	0008615C
B2.01783V		N/A	04/07/2012	0015872W	0008615C
B2.01784W		N/A	04/07/2012	0015872W	0008615C
B2.01785X		N/A	04/07/2012	0015872W	0008615C
B2.01877A		N/A	04/07/2012	0015872W	0008615C
LCS-00634903F *	LCS	N/A	04/07/2012	0015872W	0008615C
RBK-00634902E *	RBK	N/A	04/05/2012	0015862U	0008615C

^{*} Samples marked with an asterisk are not in this sample delivery group but were analyzed with it for QC purposes.

PREPARATION METHOD(S) USED

Procedure ID	Title	

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01731G

QC batch #:

0008615C

Matrix:

WATER-DRINKING

Assay batch #:

0015862U

Sample type:

SAM

Prep procedure:

N/A

Amount analyzed:

2.000e-01 L

Analysis procedure:
Analyst:

NAREL RA226-EICHRO

Dry/wet weight:

N/A

QC type:

ANA

Ash/dry weight:

N/A N/A

Sample description: Comment:

N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/04/2012 16:13	1000.0	AS105	RCL

		±2 σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	1.06e-01	8.6e-02	6.5e-02	PCI/L	04/03/2012 14:45 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

 Sample #:
 B2.01732H
 QC batch #:
 0008615C

 Matrix:
 WATER-DRINKING
 Assay batch #:
 0015862U

Sample type: SAM Prep procedure: N/A

Amount analyzed: 2.000e-01 L Analysis procedure: NAREL RA226-EICHRO

Dry/wet weight: N/A Analyst: PH
Ash/dry weight: N/A QC type: ANA

Sample description: N/A
Comment: Aqueous

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/05/2012 14:59	1000.0	AS107	RCL

		±2σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	4.59e-02	6.2e-02	6.6e-02	PCI/L	04/03/2012 14:34 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #: Matrix: B2.01733J

WATER-DRINKING

QC batch #:

0008615C

Sample type:

SAM

Assay batch #: Prep procedure:

0015862U

Amount analyzed:

2.000e-01 L

Analysis procedure:

N/A NAREL RA226-EICHRO

Dry/wet weight:

N/A

Analyst: QC type:

PH ANA

Ash/dry weight:

N/A N/A

Sample description: Comment:

N/A N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/04/2012 16:13	1000.0	AS107	RCL

		±2 σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	7.77e-02	7.7e-02	6.7e-02	PCI/L	04/03/2012 14:46 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01734K

WATER-DRINKING

QC batch #:

0008615C

Matrix:

Assay batch #:

0015862U N/A

Sample type:

SAM 2.000e-01 L Prep procedure: Analysis procedure:

NAREL RA226-EICHRO

Amount analyzed: Dry/wet weight:

N/A

Analyst:

PH

Ash/dry weight:

N/A N/A

QC type: ANA

Sample description:

Comment: N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/04/2012 16:13	1000.0	AS108	RCL

		±2 σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	5.94e-01	2.1e-01	6.9e-02	PCI/L	04/03/2012 15:55 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01735L

WATER-DRINKING

QC batch #:

0008615C

Matrix:

Assay batch #:

0015862U N/A

Sample type: Amount analyzed:

SAM 2.000e-01 L Prep procedure:

NAREL RA226-EICHRO

Dry/wet weight:

N/A

Analysis procedure: Analyst:

PH

Ash/dry weight:

N/A N/A

QC type:

ANA

Sample description: Comment:

N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/04/2012 16:13	1000.0	AS109	RCL

		±2σ) MDG	TT *.	D .,
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	1.29e-01	9.6e-02	8.5e-02	PCI/L	04/03/2012 14:38 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01736M

WATER-DRINKING

QC batch #: Assay batch #: 0008615C

Matrix: Sample type:

SAM

0015862U N/A

Amount analyzed:

2.000e-01 L

Prep procedure: Analysis procedure:

NAREL RA226-EICHRO

Dry/wet weight:

N/A

Analyst: QC type: PH ANA

Ash/dry weight: Sample description:

N/A N/A

Comment:

N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/04/2012 16:13	1000.0	AS110	RCL

		±2σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	1.77e-01	1.1e-01	8.7e-02	PCI/L	04/03/2012 14:48 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01737N

QC batch #:

0008615C

Matrix:

WATER-DRINKING

Assay batch #:

0015862U

Sample type:

SAM 2.000e-01 L Prep procedure: Analysis procedure: N/A NAREL RA226-EICHRO

Amount analyzed: Dry/wet weight:

N/A

Analyst: QC type: PH **ANA**

Ash/dry weight: Sample description:

N/A N/A

Comment:

N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/04/2012 16:13	1000.0	AS111	RCL

		±2 σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	1.26e-01	1.0e-01	7.8e-02	PCI/L	04/03/2012 14:55 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #: Matrix:

B2.01761N

WATER-DRINKING

QC batch #: Assay batch #: 0008615C

Sample type:

SAM

Prep procedure:

0015868A N/A

Amount analyzed:

2.000e-01 L

Analysis procedure:

NAREL RA226-EICHRO

Dry/wet weight: Ash/dry weight: N/A N/A

Analyst: QC type: PH ANA

Sample description: Comment:

N/A N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/05/2012 14:59	1000.0	AS97	RCL

		±2σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226 *	1.96e-01	1.2e-01	9.6e-02	PCI/L	04/04/2012 13:42 CDT

^{*} An asterisk indicates a result that may be significantly under or overestimated

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01762P

Matrix:

Sample type: Amount analyzed:

Dry/wet weight:

Ash/dry weight: Sample description:

Comment:

WATER-DRINKING

SAM

2.000e-01 L

N/A N/A N/A

Aqueous

QC batch #:

Assay batch #: Prep procedure:

Analysis procedure:

Analyst:

QC type:

0008615C

0015868A N/A

NAREL RA226-EICHRO PH

ANA

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/05/2012 14:59	1000.0	AS98	RCL

		±2 σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	6.18e-02	7.0e-02	6.7e-02	PCI/L	04/04/2012 13:42 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #: B2.01763Q Matrix: WATER-DRINKING

Assay batch #:

0008615C 0015868A

ANA

Sample type:

SAM

Prep procedure: N/A NAREL RA226-EICHRO

Amount analyzed: Dry/wet weight:

2.000e-01 L

Analysis procedure: Analyst:

QC batch #:

QC type:

Ash/dry weight:

N/A N/A N/A

Sample description: Comment: N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/05/2012 14:59	1000.0	AS101	RCL

		±2σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	3.93e-02	7.0e-02	1.1e-01	PCI/L	04/04/2012 13:41 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01763Q

QC batch #:

0008615C

Matrix:

WATER-DRINKING

Assay batch #:

0015868A

Sample type:

SAM

Prep procedure:

N/A

Amount analyzed:

2.000e-01 L

Analysis procedure:

NAREL RA226-EICHRO

Dry/wet weight:

N/A

Analyst: QC type: PH DUP

Ash/dry weight:

N/A N/A

Sample description: Comment: N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/05/2012 14:59	1000.0	AS100	RCL

		±2σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	1.28e-01	1.1e-01	1.1e-01	PCI/L	04/04/2012 13:46 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01777X

WATER-DRINKING

QC batch #:

0008615C

Matrix:

Assay batch #:

0015868A N/A

Sample type:

SAM 2.000e-01 L Prep procedure: Analysis procedure:

NAREL RA226-EICHRO

Amount analyzed: Dry/wet weight:

N/A

Analyst:

PH

Ash/dry weight:

N/A N/A

QC type:

ANA

Sample description:

Comment: Aqueous

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/05/2012 14:59	1000.0	AS102	RCL

		±2σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	8.11e-02	8.0e-02	7.0e-02	PCI/L	04/04/2012 13:44 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01778Y

Matrix:

Sample type: Amount analyzed:

Dry/wet weight:

Ash/dry weight: Sample description:

Comment:

WATER-DRINKING

SAM

2.000e-01 L N/A

N/A N/A N/A QC batch #:

Assay batch #:

Prep procedure: Analysis procedure:

Analyst:

QC type:

N/A NAREL RA226-EICHRO

PH ANA

0008615C

0015868A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/05/2012 14:59	1000.0	AS103	RCL

		±2σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	3.33e-01	1.5e-01	6.9e-02	PCI/L	04/04/2012 14:58 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

 Sample #:
 B2.01779Z
 QC batch #:
 0008615C

 Matrix:
 WATER-DRINKING
 Assay batch #:
 0015868A

Sample type: SAM Prep procedure: N/A
Amount analyzed: 2.000e-01 L Analysis procedure: NAREL RA226-EICHRO

Dry/wet weight: N/A Analyst: PH
Ash/dry weight: N/A QC type: ANA

Sample description: N/A Comment: N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/05/2012 14:59	1000.0	AS104	RCL

		± 2 σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226 *	8.29e-01	2.5e-01	1.3e-01	PCI/L	04/04/2012 13:42 CDT

^{*} An asterisk indicates a result that may be significantly under or overestimated

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #: Matrix:

B2.01780R

WATER-DRINKING

QC batch #:

0008615C

Sample type:

SAM

Assay batch #:

0015868A N/A

Amount analyzed:

2.000e-01 L

Prep procedure:

NAREL RA226-EICHRO

Dry/wet weight:

N/A

Analysis procedure: Analyst: QC type:

PH ANA

Ash/dry weight: Sample description: N/A N/A

Comment:

N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/05/2012 14:59	1000.0	AS105	RCL

		±2σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	8.05e-01	2.4e-01	6.8e-02	PCI/L	04/04/2012 13:42 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01781T

QC batch #:

0008615C

Matrix:

WATER-DRINKING

Assay batch #:

0015872W

Sample type:

SAM 2.000e-01 L Prep procedure:

N/A NAREL RA226-EICHRO

Amount analyzed: Dry/wet weight:

N/A

Analysis procedure:
Analyst:

PH

Ash/dry weight:

N/A N/A

QC type:

ANA

Sample description:
Comment:

N/A N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/06/2012 11:52	1000.0	AS121	RCL

		±2σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	1.48e-01	1.1e-01	1.2e-01	PCI/L	04/05/2012 11:50 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01782U

QC batch #:

0008615C

NAREL RA226-EICHRO

Matrix:

WATER-DRINKING

Assay batch #:

0015872W

Sample type:

SAM

Prep procedure:

N/A

Amount analyzed: Dry/wet weight:

2.000e-01 L N/A Analysis procedure: Analyst: QC type:

PH ANA

Ash/dry weight:

N/A

N/A

Sample description:
Comment:

N/A N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/06/2012 11:52	1000.0	AS122	RCL

Amalata	Activity	±2σ	MDC	Unit	Date
Analyte Ra226	2.07e-01	Uncertainty 1.2e-01	9.4e-02	PCI/L	04/05/2012 11:20 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

Sample type:

Matrix:

B2.01783V

WATER-DRINKING

2.000e-01 L

Amount analyzed: Dry/wet weight:

Ash/dry weight: Sample description:

Comment:

SAM

N/A

N/A N/A N/A QC batch #:

Assay batch #: Prep procedure:

Analysis procedure:

Analyst: QC type: NAREL RA226-EICHRO PH

ANA

N/A

0008615C

0015872W

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/06/2012 11:52	1000.0	AS123	RCL

		±2 σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	1.34e-01	1.0e-01	8.8e-02	PCI/L	04/05/2012 11:44 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01784W

...

QC batch #:

0008615C

Matrix:

WATER-DRINKING

Assay batch #:

0015872W

Sample type:

SAM

Prep procedure:

N/A NAREL RA226-EICHRO

Amount analyzed: Dry/wet weight:

2.000e-01 L N/A Analysis procedure:
Analyst:

PH

Ash/dry weight:

N/A N/A

QC type:

ANA

Sample description: Comment:

n: N/A N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/06/2012 11:52	04/06/2012 11:52 1000.0		RCL

		±2σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	1.40e-01	1.0e-01	9.2e-02	PCI/L	04/05/2012 11:43 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01785X

WATER-DRINKING

QC batch #: Assay batch #: 0008615C

Matrix:

Comment:

SAM

0015872W N/A

Sample type: Amount analyzed:

2.000e-01 L

Prep procedure: Analysis procedure:

NAREL RA226-EICHRO

Dry/wet weight:

N/A

Analyst: QC type: PH **ANA**

Ash/dry weight: Sample description:

N/A N/A N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/06/2012 11:52	1000.0	AS125	RCL

		±2 σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	1.36e-01	1.0e-01	9.0e-02	PCI/L	04/05/2012 11:11 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

B2.01877A

WATER-DRINKING

QC batch #:

0008615C

Matrix: Sample type:

SAM

Assay batch #:

0015872W N/A

Amount analyzed:

2.000e-01 L

Prep procedure:
Analysis procedure:

NAREL RA226-EICHRO

Dry/wet weight:

N/A

Analyst: QC type:

PH ANA

Ash/dry weight:

N/A N/A

N/A N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/06/2012 11:52	1000.0	AS127	RCL

Analyte	Activity	±2 σ Uncertainty	MDC	Unit	Date
Ra226	2.07e-01	1.2e-01	8.6e-02	PCI/L	04/05/2012 11:30 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

LCS-00634903F

QC batch #:

0008615C

Matrix:

Comment:

N/A

Assay batch #:

0015872W

Sample type:

N/A

Prep procedure:

N/A

Amount analyzed: Dry/wet weight:

1.000e+00 SAMP N/A

Analysis procedure: Analyst:

NAREL RA226-EICHRO

Ash/dry weight:

N/A

QC type:

PH LCS

Sample description:

N/A N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/06/2012 11:52	1000.0	AS128	RCL

		±2σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	3.46e+00	3.7e-01	1.3e-02	PCI	04/05/2012 11:18 CDT

SDG #1100248

SAMPLE ANALYSIS REPORT

Sample #:

RBK-00634902E

QC batch #:

0008615C

Matrix:

N/A

Assay batch #:

0015862U

Sample type:

N/A

Prep procedure:

N/A

Amount analyzed:

1.000e+00 SAMP

Analysis procedure:

NAREL RA226-EICHRO

Dry/wet weight:

N/A

Analyst: QC type:

PH RBK

Ash/dry weight: Sample description: N/A N/A

Sample descript Comment:

N/A

COUNTING INFORMATION

Date and time	Duration (min)	Detector ID	Operator
04/04/2012 16:13	1000.0	AS112	RCL

		±2 σ			
Analyte	Activity	Uncertainty	MDC	Unit	Date
Ra226	3.41e-03	9.9e-03	1.5e-02	PCI	04/03/2012 14:50 CDT

SDG 1100248

QC BATCH SUMMARY

QC batch #:

0008615C

Preparation procedure:

N/A

Analysis procedure:

NAREL RA226-EICHROM

		·		
NAREL Sample #	QC Type	Yield (%)	±2 σ Uncertainty (%)	Analyst
B2.01731G		91.28 %	8.29 %	PH
B2.01732H		91.05 %	7.21 %	PH
B2.01733J		89.76 %	8.23 %	PH
B2.01734K		88.01 %	8.26 %	PH
B2.01735L		92.89 %	8.39 %	PH
B2.01736M		96.34 %	8.78 %	PH
B2.01737N		79.73 %	7.71 %	PH
B2.01761N		84.36 %	8.08 %	PH
B2.01762P]	91.02 %	8.47 %	PH
B2.01763Q		84.98 %	8.16 %	PH
B2.01763Q	DUP	74.75 %	7.52 %	PH
B2.01777X		89.84 %	8.51 %	PH
B2.01778Y		89.81 %	8.56 %	PH
B2.01779Z		86.17 %	8.18 %	PH
B2.01780R		87.16 %	8.17 %	PH
B2.01781T		85.97 %	8.40 %	PH
B2.01782U		84.24 %	8.18 %	PH
B2.01783V		89.44 %	8.55 %	PH
B2.01784W		89.05 %	8.65 %	PH
B2.01785X		90.34 %	8.63 %	PH
B2.01877A		93.06 %	8.80 %	PH
LCS-00634903F *	LCS	88.29 %	8.41 %	PH
RBK-00634902E *	RBK	83.23 %	7.89 %	PH

^{*} Samples marked with an asterisk are not in this sample delivery group but were analyzed with it for QC purposes.

DIM0273709

National Air and Radiation Environmental Laboratory QC Batch Report

QC Batch #: 0008615C Analytical Method: NAREL RA226-EICHROM

METHOD BLANKS (PCI)

Sample ID	Nuclide	Activity ± 2σ	Prep Date	Flags
00634902E	RA226	3.41e-03 ± 9.9e-03	2012-04-03	OK


LABORATORY DUPLICATES (PCI/L)

Sample ID	Nuclide	Original ± 20	Duplicate ± 2σ	RPD	Z
B2.01763Q	RA226	3.93e-02 ± 7.0e-02	1.28e-01 ± 1.1e-01	105.75	1.35 OK

LAB CONTROL SAMPLES (PCI)

Sample ID	Nuclide	Amt Added ± 2σ	Measured ± 2σ	%R	Z -
00634903F	RA226	3.37e+00 ± 3.4%	3.46e+00 ± 3.7e-01	102.88	0.50 OK

Analyst:



Method Blanks

Analyte: RA226

Method: NAREL RA226-EICHROM

Analyst: Honsa, Patricia

PH IOAPTEDE