

## SECTION 9

### SAMPLE HANDLING AND CUSTODY REQUIREMENTS

Similar sample custody procedures are followed for all monitoring programs. However, program-specific differences exist because the analytical requirements for the programs vary. Because these activities are conducted under one EPA contract, United Parcel Service of America (UPS) with Overnight Delivery will handle all shipping to and from the sites. Unless specified below, samples taken in the field should not require any extra special precautions for shipping.


The Shipping and Receiving Task Leader will ensure that sample media that leaves and field samples that are received in the laboratory follow all procedures listed in this QAPP and the individual SOPs. The Task Leader will also advise the Project Manager of any issues or obstacles regarding sample shipping, receipt, login and storage. The sample custodian working under the Shipping and Receiving Task Leader will ship sample media to the field and receive custody of samples, complete COC receipt information, document sample receipt, and enter COC information into LIMS to create a work order.

#### 9.1 Canister Sample Custody

##### 9.1.1 Canister Custody

A color-coded, three-copy canister sample COC form (Figures 9-1 and 9-2) is shipped with each 6-liter canister for the NMOC, SNMOC, UATMP, NATTS, CSATAM, or PAMS sites. If duplicate or collocated samples are to be taken, two canisters and two COC forms are sent in the shipping container(s) to the site. When a sample is collected, the site operator fills out the form per the instructions in the on-site notebook. The site operator detaches the pink copy to be retained on-site and sends the remaining copies with the canister in the shipping container to ERG's laboratory.

Project No. 0344.00  
 Element No. Section 9 - B3  
 Revision No. 3  
 Date January 2017  
 Page 2 of 16

		ERG Lab ID # _____		
601 Keystone Park Drive, Suite 700, Morrisville, NC 27560				
<b>NMOC SAMPLE CHAIN OF CUSTODY</b>				
Lab Pre-Sampling	Site Code: _____ City/State: _____ AQS Code: _____ Collection Date: _____		Canister Number: _____ Lab Initial Can. Press. ("Hg): _____ Date Can. Cleaned: _____ Cleaning Batch #: _____	
	<b>Options</b> NMOC (Y/N): _____ SNMOC (Y/N): _____ TOXICS (Y/N): _____		Duplicate Event (Y/N): _____ Duplicate Can #: _____	
	Field Setup	Operator: _____ Sys. #: _____ Setup Date: _____ Field Initial Can. Press. ("Hg): _____		Rotameter Setting: _____ Elapsed Timer Reset (Y/N): _____ Canister Valve Opened (Y/N): _____
		Field Recovery	Recovery Date: _____ Field Final Can. Press. (psig): _____	
Lab Recovery	Received by: _____ Date: _____ Status: Valid Void (Circle one) If void, why: _____		Lab Final Can. Press. (psig): _____	
	NMOC	Analyst: _____ Database entry by: _____ Date: _____ Date: _____ Batch ID: _____ NMOC Instrument: _____		
Inj. 1 (AC): _____ (ppmC): _____ Inj. 2 (AC): _____ (ppmC): _____ Inj. 3 (AC): _____ (ppmC): _____				
Average AC: _____ Standard Dev. (AC): _____ Average Conc. (ppmC): _____ Standard Dev. (ppmC): _____				
SNMOC Option		Analyst: _____ Date: _____ Batch ID: _____		
		Toxics Option	Analyst: _____ Date: _____ Batch ID: _____	


Comments: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

White: Sample Traveler

Canary: Lab Copy

Pink: Field Copy

Figure 9-1. Example NMOC COC

		ERG Lab ID # _____	
801 Keystone Park Drive, Suite 700, Morrisville, NC 27560			
<b>AIR TOXICS SAMPLE CHAIN OF CUSTODY</b>			
<b>Lab Pre-Sampling</b>	Site Code: _____		Canister Number: _____
	City/State: _____		Lab Initial Can. Press. ("Hg): _____
	AQS Code: _____		Cleaning Batch #: _____
	Collection Date: _____		Date Can. Cleaned: _____
	Options:		
	SNMOC (Y/N): _____		Duplicate Event (Y/N): _____
	TOXICS (Y/N): _____		Duplicate Can #: _____
	METHANE (Y/N): _____		
Relinquished by: _____		Date: _____	
<b>Field Setup</b>	Received by: _____		Date: _____
	Operator: _____		MFC Setting: _____
	System #: _____		Elapsed Timer Reset (Y/N): _____
	Setup Date: _____		Canister Valve Opened (Y/N): _____
	Field Initial Can. Press.: _____ psig psia "Hg (Circle one)		
<b>Field Recovery</b>	Recovery Date: _____		Sample Duration (3 or 24 hr): _____
	Operator: _____		Elapsed Time: _____
	Field Final Can. Press.: _____ psig psia "Hg (Circle one)		
	Status: <b>VALID</b> <b>VOID</b> (Circle one)		Canister Valve Closed (Y/N): _____
	Relinquished by: _____		Date: _____
<b>Lab Recovery</b>	Received by: _____		Date: _____
	Lab Final Can. Press.: _____ psig "Hg (Circle one) Converted to psia: _____		
	Status: <b>VALID</b> <b>VOID</b> (Circle one)		Gauge: <b>1</b> <b>2</b> (Circle one)
	If void, why: _____		
Samples stored in Air Tox Lab (Room 130)			

Comments: \_\_\_\_\_

 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

White: Sample Traveler

Canary: Lab Copy

Pink: Field Copy

Figure 9-2. Example Air Toxics COC

Upon receipt, the measured sample canister vacuum/pressure is compared against the field documented vacuum/pressure to ensure the canister remained airtight during transport. If the receiving vacuum differs from the field vacuum more than 3" Hg, the program manager is notified and sample canister may be voided. Because there are potential differences in barometric pressures and temperatures between the sampling site (such as those at high altitudes) and the receiving laboratory and different accuracies for different types of pressure gauges, there can be a difference in final field pressure and lab receipt pressure for canister samples. This difference and other parameters are considered to determine the validity of the canister samples and these are monitored daily by logging the pressures in an Excel spreadsheet. This allows the laboratory the ability to determine if the difference is due to gauges or if the canister leaked en route. A sample of the spreadsheet is presented in Table 9-1.

**Table 9-1**  
**Example of Canister Pressure Check Spreadsheet**

Date Received	Site	Field Pressure Reading	Lab Pressure Reading	Difference
8/30/16	NBIL	2 " Hg	6 " Hg	4 " Hg
9/7/16	NBIL	1 " Hg	4 " Hg	3 " Hg
9/14/16	NBIL	3 " Hg	7 " Hg	4 " Hg
9/16/16	NBIL	4 " Hg	7 " Hg	3 " Hg
8/30/16	BLKY	5 " Hg	5 " Hg	0 " Hg
9/7/16	BLKY	5 " Hg	3.5 " Hg	1.5 " Hg
9/13/16	BLKY	5 " Hg	5 " Hg	0 " Hg
9/16/16	BLKY	5 " Hg	4 " Hg	1 " Hg

The canister should be cleaned no more than 30 days before sampling. If the canister is older than 30 days, a note will be made in LIMS. More detailed sample receipt procedures and sample acceptance policies are presented in the *SOP for Sample Receipt at the ERG Chemistry Laboratory*, ERG-MOR-045 in Appendix C. The sample specific information from the COC is then entered into LIMS (example login page is shown in Figure 9-3) following the *SOP for Sample Login to the Laboratory Information Management System*, ERG-MOR-079 found in Appendix C. The sample is given a unique LIMS identification (ID) number and tagged (see Figure 9-4), noting the site location and the sample collection date.

The screenshot displays the ERG LIMS interface. On the left, a sidebar shows a list of samples under '3341 Items', with '6012904-02' and '6012904-03' selected. The main area is titled 'Sample Information' and includes tabs for 'Containers' and 'Qualifiers'. The 'Sample' tab is active, showing fields for Name (PNSS), Alias, Regulatory ID, Comments, and QC Source. To the right, there are sections for 'Field Data', 'Field Info', 'Field Info', and 'Memos'. The 'Sample' section includes 'Lab Matrix' (Air), 'Report Matrix' (Air), 'Sample Type' (Field Sample), and 'Sampled By'. The 'Field Info' section shows 'Sampled [Eastern]' and 'Sampled Begin'. Below these, a table lists 'Analyses included for this sample' with columns for Analysis, Subanalysis, Comments, TAT, Due, Hold, and Subcontract. The table contains one entry: 'TO-15 2016' with TAT 45, Due 03/13/16 12:00, and Hold 30. At the bottom, there are buttons for 'Add', 'Edit', 'Copy', 'Delete', 'Group Edit', 'Field Data', '<< Work Orders', and 'Done'.

**Figure 9-3. Example ERG LIMS Login Page**

The diagram shows a canister tag with a rectangular label area. The label contains the following fields with lines for text entry:

- Analysis: \_\_\_\_\_
- Sample ID: \_\_\_\_\_
- Laboratory ID: \_\_\_\_\_
- Date Sampled: \_\_\_\_\_
- Canister #: \_\_\_\_\_ Press/Vac: \_\_\_\_\_
- Site: \_\_\_\_\_ Dup/Rep: \_\_\_\_\_
- Comment: \_\_\_\_\_

A circular hole is visible on the right side of the tag.

**Figure 9-4. Canister Tag**

The LIMS ID number is recorded on the canister tag and on all ERG copies of the COC. The remaining copies of the canister sample COC are separated. The white copy is scanned (the PDF is stored in the LIMS system) and is kept with the canister sample until analysis is complete. After sample analysis, the white copy goes into the data package with the sample

data. The yellow copy is stored chronologically in a designated file cabinet for one year. The file cabinet is in Room 102 in the Laboratory building.

#### 9.1.2 Canister Analytical Routing Schedule

The canister samples received from the monitoring sites are assigned a unique LIMS ID number. This number is recorded on the individual Toxics/SNMOC COCs upon receipt at the laboratory for use during sample analysis. Each canister has a unique canister identification number inscribed on the canister. This number is used during can cleaning, field collection, laboratory receipt, and laboratory sample analysis and is included on the individual Toxics/SNMOC COCs and entered into the LIMS.

The canister sample analysis hold time is 30 days from the sampling date. The samples are sent to the ERG Air Toxics Laboratory for VOC and SNMOC/PAMS GC/Flame Ionization Detector/Mass Spectrometer (FID/MS) analysis. The canister sample is analyzed and kept in the laboratory until after the analyst and the Task Leader reviews the relevant analytical data.

#### 9.1.3 Canister Cleanup

All canisters are cleaned prior to reuse using SOP ERG-MOR-105 (*SOP for Sample Canister Cleaning using Wasson TO-Clean Automated System*) as shown in Appendix C. The canisters are cleaned using the procedure described in Section 10.1.1. The unheated system (following SOP ERG-MOR-062, *SOP for Sample Canister Cleaning*) is maintained as a backup and is described in Section 10.1.2. The canisters are cleaned to <3x MDL or 0.2 parts per billion by volume (ppbV), whichever is lower, and 20 parts per billion as Carbon (ppbC) for Total SNMOC. If the canister fails the Blank criteria, it is returned to the cleaning system bank with the other canisters that were cleaned along with it and all canisters are put through an additional Vacuum and Pressure cycle. The same canister then undergoes Blank analysis again. All canisters, whether used for NMOC, SNMOC, UATMP, NATTS, CSATAM, or PAMS, are cleaned by the same procedure and are entered into the canister cleanup log, shown in Figure 9-5 for the heated systems and in Figure 9-6 for the unheated systems.

Heated Canister Cleaning Systems Logbook 2016-2									
<b>Heated System 1</b>									
Upper		Rear		Front		Batch ID		Pass	Fail
Lower		Rear		Front		Cleaning Date		Extra Cycle Date	
						Initials		Program	
						Oven Temperature (°C)		Final Evac Date	
						Leak Check			
<b>Heated System 2</b>									
Upper		Rear		Front		Batch ID		Pass	Fail
Lower		Rear		Front		Cleaning Date		Extra Cycle Date	
						Initials		Program	
						Oven Temperature (°C)		Final Evac Date	
						Leak Check			
							Review Initials & Date		

L:\Forms\Canister cleaning\Wasson Can Cleaning system log v2.xlsx

Figure 9-5. Canister Cleanup Log for the ERG Heated Cleaning System

Canister Cleaning Logbook 2016-1

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								

Batch ID _____ Date _____		Upper				Lower			
P1	P5								
P2	P6								
P3	P7								
P4	P8								