

6.6.4 Recommended Spare Parts

The following table shows spare parts and consumables. For the complete list of manufacturer's spare parts, refer to the Instruction Manual.

PART NUMBER	DESCRIPTION
4121	Capillary - ozone - 10 mil
4113	Capillary - sample - 5 mil
4126	Capillary - bypass - 20 mil
4157	Charcoal
6998	Desiccant
4510	Fuse
8138	Solenoid
4800	O-ring capillary
9464	Twin Head Pump Repair Kit
5013	Bypass Pump Repair Kit

6.7. NO_x reports

6.7.1 Daily NO_x reports

Two styles of daily reports for NO_x are available for printing on the printer. The first report prints the average value for every minute in any calendar day. The second report is a line graph of one minute values. The first report included other status information such as fault conditions and calibration status. A sample of each report is included in Appendix C of this document.

6.7.2. Quarterly NO_x reports

A sample quarterly NO_x report as required by US EPA and Pennsylvania Department of Environmental Resources (DER) is included in Appendix C of this document.

6.8. Parameters monitored by SNIFFER

Allen Bradley PLC (RDCN) monitors a signal from the Thermo Environmental Instruments, Inc. NO_x analyzer corresponding to NOx ppm. It also monitors two digital lines which indicate when the NOx analyzer is performing calibration and if the unit has failed calibration. The final signal being monitored by the remote data collection unit is an analyzer fault line. The SNIFFER data acquisition units saves to the hard disk the following data once each minute;

- NO_x ppm
- NO_x corrected to 7% oxygen.

- Analyzer calibration status

6.9. Rate of data collection for analyzer

The remote data collection unit takes a reading from the Thermo Environmental Instruments, Inc. NO_x analyzer once every few seconds. The SNIFFER data acquisition system requests the latest data value from the remote data collection unit four or more times each minute. These readings are averaged together in the data acquisition system to construct a one minute average. The actual analyzer reading and analyzer status information (calibration and fault status) are transmitted from the remote data collection unit to the data acquisition computer.

6.10. Schematic of monitoring system

See Appendix D of this document.

6.11. NO_x Calibration drift

The acceptable zero drift for this analyzer is ± 0.2 ppm per day and the acceptable span drift for this analyzer is ± 1 percent of full scale per day. These conform to the requirements defined in 40CFR60 Appendix B (Spec. 2).

As per 40CFR60 Appendix F, the analyzer must be calibrated whenever its reading drifts from the reference gas by two times the amount specified in Appendix B.

During calibration the system compares the known concentration of the span gas to the reading from the analyzer. If the reading is different, the system automatically adjusts the reading in software.

If this drift is more than twice the acceptable drift specified in 40CFR60 Appendix B, then the system warns the operator of calibration failure.

At this point the analyzer may be manually calibrated and or repaired.

6.12. Equations to Compute Corrected NO_x Emissions.

The equations used to compute the emissions follow:

Correction of NO_x to 7.0 % Oxygen on a dry basis

$$\text{NO}_x \text{ corrected} = \frac{(20.95\% - 7.0\%)}{(20.95\% - \text{O}_2\% \text{ dry})} * \text{NO}_x(\text{PPMVD})$$

6.13. Equations to Compute NO_x Mass Emissions.

The NO_x emission is recorded in three units.

They are:

- NO_x analyzer readings.
- NO_x analyzer readings corrected to 7.0% oxygen.
- NO_x emissions rate in pounds per hour.

$$\text{NO}_x(\text{lbs/hr}) = \text{NO}_x(\text{lbs/MMBtu}) * (\text{fuel consumption MMBtu/hr})$$

The equation used to compute NO_x emissions in (lbs per MMBtu) is defined in 40CFR60 Method 19 and is as follows:

$$E = C * F (20.9 / (20.9 - O_2\%))$$

E = emissions in lbs/MMBtu

C = NO_x in lb/scf = NO_x(ppm) * (1.194 * 10⁻⁷)

F = Fuel factor in dscf/MMBtu

7. Calibration of CEMS analyzers

Daily calibration is accomplished by routing certified calibration gases up through the sample line to the probe and back down the normal extraction gas sample path to the analyzer.

Each analyzer is first fed a zero gas to establish the base line and then fed a span gas. These two readings determine the slope and offset values used to correct the analyzer readings.

Although each analyzer may be calibrated individually, the normal, automatic calibration performed daily by the CEMS system calibrates all of the analyzers together as quickly as possible.

This is accomplished by calibrating one or more analyzers simultaneously. For example, several analyzers may be zero calibrated at the same time or one analyzers span gas may also be used as the zero gas for a second analyzer. This therefore reduces the overall time the CEMS is in calibration.

The calibration sequence described below represents the actual calibration of all analyzers in this CEMS.

The steps below do not mention the "wait" times which permit the calibration gases to purge the sample lines sufficiently. These delay times may be altered to match the length of the sample lines.

In addition to this fixed time delay, the CEMS also takes multiple readings during the sample time to insure the analyzer reading has stabilized. This helps verify the line has been completely purged and only pure calibration gas is being sampled.

7.1. Calibration Timing Sequence Chart

Note that the CEMS system for each boiler is calibrated independently. Further all timing constants are set independently for each system.

Step	Time seconds	Operation			Gas flowing		Comments
		Purge	Zero	Span	O ₂ Span	NO _x Span	
1	120	x				x	
2	30		NO _x			x	
3	120	x					
4	30		O ₂				
6	120	x				x	
7	30			O ₂	x		
8	120	x					x
9	30			NO _x		x	
10	180	x					Purge Sample Line
11							Resume Sampling

8. Monitored Data Points

The following signals are collected from various instruments either in the CEM analyzer cabinet or other sources at the site. One set of signals is collected for each boiler.

- O_2 Oxygen
- O_2 Analyzer fault
- NO_x Nitrogen-oxides
- NO_x Analyzer fault
- Fuel Flow Signals for each fuel
- Opacity
- Fuel Factor (Fd) for Coke Oven Gas

9. Calculated Data Points

The following values are calculated in the CEM system for each boiler.

- NO_x corrected to 7.0% O_2
- NO_x Lbs/mmBTU

10. Process Status Input

The following digital signal is read by the RDCN and recorded on the hard disk. It is used to determine number of hours of operation for the industrial boiler. The emission limit episodes are discounted while the process signal indicates the process is off.

- industrial boiler on/off Digital input

11. Alarms

The following alarms are output by the RDCN when high emissions or analyzer failure is detected. Also refer to the "Lockout" section for further specific control points.

- CEMS calibration failure Digital output
- CEMS high emissions alarm Digital output
- CEMS trouble alarm Digital output

12. Lockout Control

This system has no lockout requirements.

13. Emission Limits

This system determines if the process is operating by a digital input to the CEM system. This input is provided by the plant DCS and is on only during the period in which the CEM system is to test for emissions exceedances.

While in operation, the CEM system will be taking readings of all pollutants, correcting them to 7 percent O₂ and generating a rolling hourly average. The rolling hourly average is based on minute average calculated by the DCN. The rolling hourly average will be valid if there are a minimum of 45 valid minute averages during the last 60 minutes.

The air permit is an installation permit. It is our assumption that PADER will establish concentration limits for each of the emissions. This CEM system will contain emission limit software in the event a NOx emission limit is placed on the boilers.

The pollutants that will be measured are:

Pollutant	Units
• NOx corrected to 7.0% O ₂ Limit: (Undetermined at this time)	ppm dry
• NOx lb/MMBTU Limit: (Undetermined at this time)	lb./MMBTU
• NOx lb/hr Limit: (Undetermined at this time)	lb./hr

Opacity will be monitored in the stack. The instantaneous readings will be collected in real time by the RDCN. From these values both one minute and six minute averages will be calculated and stored on the DAS. For a one minute average to be valid at least 6 readings will be required. For a six minute average to be valid at least 5 minute averages must be valid.

14. Quality control / Quality Assurance

The primary guidelines for this section are those outlined in 40CFR60 Appendix F.

The quality control plan is made up of six items.

- Calibration of the CEMS analyzers on a daily basis
- Determination of calibration drift and adjustment
- Preventative maintenance of the CEMS
- Recording the data and calculation of emissions rates, and reporting the results
- Accuracy audit procedures
- Corrective actions for CEMS components which do not meet the above criteria

If the CEMS has two consecutive quarters of excessive inaccuracies then this current QA/QC plan must be re-written to correct the deficiencies.

14.1. Calibration Drift

All analyzers are calibrated using the criteria set forth in 40CFR60 Appendix F and Appendix B.

Refer to the "Calibration Drift" section for each analyzer for specific details.

If the analyzer fails the drift calibration for five consecutive days, the analyzer is considered out-of-control. In addition, if the calibration drift error is four times the applicable drift specification at any time, the analyzer is considered out-of-control.

The analyzer remains out-of-control until the completion of a calibration drift test which results in a calibration drift within the corresponding allowable calibration drift limit.

The data during the out-of-control period is marked as invalid data. All data collected from the CEMS is kept for two years.

14.2. Data Accuracy

Data accuracy is verified by performing a set of quarterly audits. There are three types of quarterly audits;

- Relative Accuracy Test Audit (RATA)
- Cylinder Gas Audit (CGA)
- Relative Accuracy Audit (RAA)

14.2.1. Relative Accuracy Test Audit (RATA)

When the CEMS is first certified this audit is one of the audits performed by the

stack testing firm in accordance with the performance specifications outlined in 40CFR60 Appendix B. The relative accuracy specifications are listed below:

- **Performance Specification 2**

Performance Specification 2 (NO_x , SO_2) twenty (20) percent of the mean value of the reference method (RM) test data in units of emissions standard or five (5) percent of applicable emissions standard.

If the limits defined in performance specification 2 are less than 2.5 ppm NO_x , then the minimum accuracy of 2.5 ppm NO_x will be used as outlined in the NESCAUM guide.

- **Performance Specification 3**

Performance Specification 3 (O_2 , CO_2) twenty (20) percent of the mean value of the reference method (RM) test data or one (1) percent O_2 or CO_2 .

- **Performance Specification 4**

Performance Specification 4 (CO) ten (10) percent of the mean value of the reference method (RM) test data in units of emissions standard or five (5) percent of applicable emissions standard.

If the limits defined in performance specification 4 are less than five (5) ppm then performance specification 4A will be used.

- **Performance Specification 4A**

Performance Specification 4 (CO) ten (10) percent of the mean value of the reference method (RM) test data in units of emissions standard or five (5) ppm, whichever is higher.

- **Equations and calculations**

The equations specified in

Arithmetic Mean: EPA 40CFR60 App. B PS2 eq. 2-1

Standard Deviation: EPA 40CFR60 App. B PS2 eq. 2-2

Confidence Coefficient: EPA 40CFR60 App. B PS2 eq. 2-3

RA: EPA 40CFR60 App. B PS2 eq. 2-4

All span and zero gases used for these audits must be "EPA Protocol I".

The required audit gases are found in Appendix B of this document.

14.2.2. Cylinder Gas Audits (CGA)

This audit is performed in three out of four quarters. This audit challenges the CEMS with cylinder gases of known concentration at two points for each monitored pollutant.

Each pollutant is monitored at a mid range which is calculated as between 20 to 30 percent of the monitors span value.

The high range is calculated as being between 50 to 60 percent of span.

The cylinder gas audit routes the audit cylinder gas through the entire CEMS; (i.e. up to stack probe and back through the sample conditioning system to the analyzers).

The cylinder gases must be introduced three times for each range, for each analyzer. In other words, to audit one analyzer six data points must be recorded. The cylinder gases must be EPA protocol I gases.

The difference between the cylinder gas known value and the CEMS result is used to assess the accuracy of the CEMS.

The required audit gases are found in Appendix B of this document.

14.2.3. Relative Accuracy Audit (RAA)

The relative accuracy audit is similar to the Relative Accuracy Test Audit (RATA) except less data is recorded. The relative accuracy audit can be performed in three out of four quarters. It requires three sets of data in contrast to the RATA which requires nine sets of data. The relative difference between the mean of the reference method (RM) values and the mean of the CEMS values is used to assess the accuracy of the CEMS.

14.3. Excessive Inaccuracies

If the relative accuracy of the RATA exceeds twenty (20) percent then the CEMS is out-of-control. If the relative accuracy exceeds fifteen (15) percent of the CGA or the RAA then the CEMS is out-of-control. The CEMS remains out-of-control from the time that the system fails the RATA, CGA or RAA until the system passes the RATA, CGA or RAA. If the system fails a RATA then only a RATA is used to certify that the CEMS is no longer out-of-control.

The data during the out-of-control period is marked as invalid data.

14.4. Calculation for CEMS data accuracy

The RATA relative accuracy calculations are outlined in the performance specification section of 40CFR60 Appendix B.

The RAA relative accuracy calculations are calculated in the emissions standard units (for instance lbs/hr or lbs/MMBTU).

The CGA relative accuracy calculations are calculated in the units of the concentration appropriate for the analyzer (for instance O₂ in percent, and CO in ppm).

The equation used to compute relative accuracy for CGA or RAA is:

$$A = \frac{C_{\text{meas}} - C_{\text{audit}}}{C_{\text{audit}}} * 100$$

A = accuracy in percent

C_{meas} = Average CEMS response during the audit in units of applicable standard or appropriate concentration

C_{audit} = Average audit value (CGA certified value or three run average for RAA) in units of applicable standard or appropriate concentration

14.5. Reporting Requirements

Samples of the required reports are found in Appendix C of this document.

Depending on the type of report, they can be produced on a daily or quarterly basis.

Certain reports such as the calibration summary report will prompt the user for a start and stop date. The report will determine if there is data present for the specified days and if so will compile the requested report period into the report.

Refer to Appendix C of this document for the list of reports.

APPENDIX A Project personnel

The following is a list of key project personnel and their corresponding responsibilities.

Overall Project Management	<u>Manager of Environmental Control</u>
Overall Quality Assurance	<u>Manager of Environmental Control</u>
Performance Auditing	<u>Manager of Environmental Control</u>
Data Processing	<u>Manager of Operations</u>
Sampling Quality Control	<u>Manager of Operations</u>
Sampling Operations	<u>Manager of Operations</u>

In case of incomplete personnel list, be advised U. S. Steel Corp. is presently organizing the staffing and will furnish the names and duties prior to operation of the CEMS equipment.

Definitions of project responsibilities:

Overall Project Management - Responsible individual who assures the system conforms to all state and federal regulations and that all reports are submitted promptly.

Overall Quality Assurance - Manages the CEMS system. Responsible for ensuring all sampling operations, sampling quality control and data processing activities are performed.

Performance Auditing - Ensures the required quarterly audits are performed. Provides tracking of performance information.

Data Processing - Examines daily backup logs. Assures all daily reports are printed and distributed. Performs regular full backups.

Sampling Quality Control - Inspect daily calibration information. Assures all daily automatic checks were performed. Maintains spare parts inventory.

Sampling Operation - Performs daily maintenance.

APPENDIX B Specialty Gases Required

Daily Operation

- Oxygen zero gas CO span gas, which contains 0% O₂
- Oxygen span gas 22.0% Oxygen in Nitrogen base EPA Protocol 1
- NO_x Range one Zero Gas 0 ppm NOx, using Oxygen analyzer span gas
- NO_x Range one Span Gas 400-450 ppm EPA Protocol 1

Note:

The span and zero gases may be "Certified Masters" for normal operation but must be "EPA Protocol I" for all audits (i.e. CGA).

CGA audit gases

- * Oxygen Range one mid range audit gas 5.0% Oxygen EPA Protocol 1
- * Oxygen Range one hi range audit gas 10.0% Oxygen EPA Protocol 1
- * NO_x Range one mid range audit gas 125 ppm NOx in Nitrogen base EPA Protocol 1
- * NO_x Range one hi range audit gas 275 ppm NOx in Nitrogen base EPA Protocol 1

Note:

These specified span and audit gases are desired values. The supplier attempts to meet the desired concentrations as best as possible using industry standard gas mixing methods.

The actual concentration of the gases are determined by measurement of the bottle contents and may vary slightly, as long as the concentration is within 80 to 90 percent of full scale for the chosen operating range of the analyzers.

Each piece of equipment permits the span gas concentration value to be set to the actual bottle concentration.

When received, each bottle of protocol gas will be labeled with the exact concentration. This equipment setting must be set to the actual bottle contents when the bottles are changed.

APPENDIX C Sample Reports

Sample Analyzer Performance Report.

INSTRUMENT UP/DOWN REPORT
PRINTED: 02-Jun-91 11:50
Enertec Industrial, Inc.
811 West 5th St.
NOx-1 lbs/hr
BEGINNING Apr. 1, 1991 AND ENDING Jun. 2, 1991

Date	CEM Outage Began	CEM Outage Ended	Total CEM downtime	Reason for Downtime	Corrective Action Taken
04/01	00:01	00:07	0:07	Calibration	Scheduled cal.
05/29	10:52	13:29	2:38	Monitor Down.	Replace battery.
05/29	13:33	13:34	0:02	Monitor Down.	Clean hoses.
05/29	13:43	16:54	3:12	Monitor Down.	Hardware failure.
05/30	08:52	09:02	0:11	Monitor Down.	none at this time.
05/30	11:25	13:27	2:03	DAS Down.	Preventive Maintenance.
05/30	13:31	13:31	0:01	Monitor Down.	Call service.
05/30	14:10	14:10	0:01	Monitor Down.	none at this time.
06/01	12:05	12:08	0:04	Monitor Down.	Call service
06/01	12:10	12:10	0:01	Monitor Down.	none at this time.

CEM protocol for U. S. Steel Corp.
Revision: 1.0

Daily CO report

ACEMS Pollution Monitor Daily Report V4.1 01/12/1993 Page # 1
 Company: ABC CORP. Location : Somewhere, USA
 Source : Boiler Pollutant: CO Units: ppm

00:00	19.0	19.0	19.0	20.0	19.0	19.0	21.0	22.0	19.0	18.0		
00:10	18.0	20.0	20.0	20.0	20.0	22.0	20.0	20.0	20.0	26.0	44.0	
00:20	50.0	29.0	34.0	46.0	47.0	55.0	60.0	56.0	79.0	81.0		
00:30	85.0	88.0	64.0	46.0	35.0	22.0	22.0	21.0	21.0	22.0		
00:40	21.0	23.0	24.0	35.0	26.0	24.0	24.0	24.0	26.0	26.0		
00:50	28.0	27.0	25.0	28.0	26.0	24.0	31.0	56.0	29.0	26.0	Avg:	32.3 60
01:00	25.0	26.0	28.0	31.0	28.0	47.0	31.0	26.0	26.0	26.0		
01:10	25.0	25.0	26.0	25.0	27.0	27.0	27.0	26.0	27.0	38.0		
01:20	39.0	36.0	27.0	28.0	35.0	30.0	26.0	26.0	38.0	37.0		
01:30	34.0	28.0	28.0	27.0	26.0	26.0	30.0	28.0	25.0	27.0		
01:40	27.0	25.0	24.0	24.0	23.0	23.0	25.0	26.0	41.0	37.0		
01:50	25.0	27.0	38.0	25.0	25.0	30.0	34.0	28.0	25.0	Avg:	37.9 60	
02:00	24.0	25.0	31.0	24.0	24.0	24.0	27.0	28.0	25.0	24.0		
02:10	25.0	30.0	31.0	31.0	27.0	24.0	27.0	31.0	33.0	29.0		
02:20	30.0	32.0	30.0	28.0	28.0	31.0	33.0	32.0	33.0	32.0		
02:30	32.0	31.0	31.0	32.0	34.0	36.0	34.0	34.0	39.0	38.0		
02:40	37.0	33.0	31.0	29.0	34.0	48.0	39.0	36.0	31.0	31.0		
02:50	36.0	40.0	39.0	42.0	51.0	41.0	46.0	44.0	44.0	41.0	Avg:	32.6 60
03:00	45.0	43.0	51.0	60.0	75.0	57.0	65.0	47.0	46.0	51.0		
03:10	53.0	56.0	52.0	48.0	52.0	52.0	56.0	57.0	56.0	60.0		
03:20	58.0	65.0	78.0	71.0	67.0	66.0	57.0	74.0	69.0	69.0		
03:30	63.0	60.0	53.0	62.0	56.0	52.0	65.0	53.0	64.0	157.0		
03:40	69.0	68.0	53.0	55.0	48.0	59.0	70.0	59.0	47.0	52.0		
03:50	51.0	46.0	52.0	49.0	49.0	49.0	51.0	60.0	81.0	82.0	Avg:	60.3 60
04:00	58.0	87.0	88.0	53.0	62.0	82.0	94.0	100.0	122.0	61.0		
04:10	42.0	39.0	40.0	41.0	39.0	47.0	41.0	38.0	36.0	40.0		
04:20	40.0	45.0	70.0	47.0	42.0	42.0	41.0	37.0	45.0	46.0		
04:30	37.0	37.0	41.0	37.0	34.0	34.0	34.0	35.0	34.0	34.0		
04:40	49.0	35.0	31.0	43.0	36.0	32.0	31.0	31.0	32.0	32.0		
04:50	35.0	31.0	47.0	36.0	36.0	39.0	62.0	28.0	28.0	28.0	Avg:	45.6 60
05:00	28.0IC	68.0IC	2.0IC	0.0ZC	171.0IC	188.0SC	101.0IC	2.0IC	0.0ZC	2607.0IC		
05:10	2829.0SC	3828.0SC	93.0IC	49.0IC	32.0	31.0	31.0	29.0	28.0	59.0		
05:20	94.0	37.0	34.0	27.0	26.0	26.0	35.0	30.0	26.0	25.0		
05:30	24.0	24.0	26.0	27.0	29.0	35.0	28.0	26.0	26.0	38.0		
05:40	65.0	76.0	73.0	56.0	48.0	53.0	53.0	51.0	51.0	52.0		
05:50	58.0	57.0	56.0	57.0	48.0	29.0	30.0	33.0	36.0	33.0	Avg:	40.5 46
06:00	31.0	34.0	35.0	36.0	38.0	38.0	36.0	44.0	174.0	43.0		
06:10	37.0	34.0	35.0	40.0	36.0	36.0	36.0	36.0	37.0	33.0		
06:20	38.0	33.0	40.0	38.0	37.0	39.0	41.0	45.0	39.0	41.0		
06:30	40.0	36.0	39.0	44.0	40.0	43.0	41.0	39.0	50.0	41.0		
06:40	40.0	39.0	38.0	51.0	54.0	40.0	46.0	48.0	47.0	44.0		
06:50	45.0	48.0	43.0	44.0	42.0	56.0	64.0	46.0	43.0	42.0	Avg:	43.3 60

CEM protocol for U. S. Steel Corp.
Revision: 1.0

ACEMS Pollution Monitor Daily Report V4.1 01/12/1993 Page # 2
 Company: ABC CORP. Location : Somewhere, USA
 Source : Boiler Pollutant: CO Units: ppm

07:00	48.0	50.0	44.0	46.0	50.0	45.0	57.0	49.0	48.0	49.0	49.0
07:10	66.0	89.0	41.0	37.0	43.0	41.0	43.0	39.0	43.0	44.0	44.0
07:20	38.0	40.0	40.0	36.0	37.0	41.0	63.0	46.0	117.0	42.0	
07:30	32.0	33.0	36.0	34.0	34.0	40.0	32.0	29.0	30.0	33.0	
07:40	27.0	26.0	29.0	32.0	29.0	28.0	30.0	29.0	29.0	28.0	
07:50	32.0	26.0	25.0	25.0	30.0	28.0	27.0	28.0	28.0	28.0	Avg: 39.3 60
08:00	33.0	37.0	28.0	25.0	24.0	25.0	27.0	26.0	31.0	48.0	
08:10	40.0	37.0	33.0	118.0	62.0	28.0	25.0	27.0	35.0	37.0	
08:20	27.0	26.0	28.0	23.0	24.0	23.0	37.0	23.0	34.0	29.0	
08:30	30.0	25.0	25.0	25.0	26.0	28.0	28.0	34.0	34.0	23.0	
08:40	24.0	22.0	20.0	21.0	32.0	37.0	34.0	22.0	20.0	20.0	
08:50	22.0	22.0	26.0	31.0	26.0	37.0	24.0	24.0	31.0	22.0	Avg: 29.4 60
09:00	22.0	25.0	29.0	37.0	23.0	23.0	25.0	22.0	23.0	27.0	
09:10	22.0	23.0	24.0	31.0	27.0	27.0	28.0	27.0	23.0	29.0	
09:20	25.0	26.0	31.0	29.0	24.0	25.0	29.0	27.0	25.0	24.0	
09:30	28.0	27.0	26.0	24.0	25.0	24.0	23.0	24.0	29.0	26.0	
09:40	24.0	23.0	25.0	24.0	26.0	21.0	18.0	25.0	33.0	27.0	
09:50	23.0	33.0	27.0	26.0	30.0	36.0	23.0	22.0	23.0	35.0	Avg: 25.7 60
10:00	24.0	33.0	34.0	24.0	26.0	27.0	27.0	24.0	23.0	33.0	
10:10	25.0	24.0	36.0	28.0	33.0	36.0	39.0	37.0	37.0	45.0	
10:20	51.0	39.0	36.0	29.0	26.0	27.0	29.0	34.0	25.0	25.0	
10:30	24.0	26.0	33.0	31.0	31.0	36.0	28.0	28.0	25.0	27.0	
10:40	28.0	30.0	33.0	39.0	52.0	28.0	33.0	33.0	30.0	38.0	
10:50	34.0	32.0	36.0	32.0	30.0	36.0	38.0	34.0	34.0	32.0	Avg: 31.5 60
11:00	40.0	39.0	47.0	29.0	38.0	36.0	32.0	34.0	33.0	37.0	
11:10	43.0	41.0	31.0	32.0	32.0	33.0	38.0	38.0	34.0	71.0	
11:20	58.0	36.0	43.0	40.0	37.0	36.0	37.0	36.0	42.0	36.0	
11:30	37.0	35.0	33.0	33.0	35.0	50.0	99.0	43.0	39.0	35.0	
11:40	36.0	38.0	36.0	38.0	45.0	38.0	40.0	40.0	44.0	45.0	
11:50	63.0	52.0	57.0	51.0	61.0	41.0	36.0	39.0	43.0	43.0	Avg: 41.1 60
12:00	38.0	37.0	38.0	39.0	48.0	47.0	41.0	43.0	45.0	42.0	
12:10	67.0	69.0	40.0	50.0	48.0	38.0	47.0	54.0	39.0	38.0	
12:20	41.0	38.0	38.0	39.0	32.0	32.0	31.0	43.0	40.0	35.0	
12:30	32.0	29.0	27.0	39.0	32.0	33.0	34.0	28.0	28.0	33.0	
12:40	28.0	26.0	31.0	27.0	31.0	27.0	27.0	29.0	27.0	26.0	
12:50	26.0	27.0	26.0	25.0	31.0	36.0	26.0	27.0	27.0	29.0	Avg: 35.4 60
13:00	30.0	23.0	46.0	30.0	38.0	29.0	28.0	39.0	31.0	30.0	
13:10	30.0	27.0	26.0	27.0	26.0	26.0	32.0	26.0	31.0	27.0	
13:20	26.0	27.0	28.0	38.0	38.0	30.0	31.0	26.0	25.0	32.0	
13:30	27.0	32.0	26.0	34.0	27.0	40.0	42.0	42.0	52.0	33.0	
13:40	27.0	32.0	28.0	29.0	40.0	44.0	44.0	49.0	51.0	48.0	
13:50	39.0	30.0	22.0	28.0	41.0	44.0	46.0	36.0	27.0	24.0	Avg: 32.9 60

CEM protocol for U. S. Steel Corp.
Revision: 1.0

ACEMS Pollution Monitor Daily Report V4.1 01/12/1993 Page # 3
 Company: ABC CORP. Location : Somewhere, USA
 Source : Boiler Pollutant: CO Units: ppm

14:00	26.0	34.0	36.0	33.0	22.0	31.0	31.0	23.0	26.0	23.0		
14:10	21.0	21.0	21.0	24.0	23.0	31.0	31.0	20.0	24.0	23.0		
14:20	23.0	22.0	22.0	21.0	31.0	31.0	20.0	23.0	21.0	37.0		
14:30	26.0	22.0	23.0	23.0	23.0	23.0	23.0	25.0	23.0	22.0		
14:40	25.0	25.0	26.0	28.0	27.0	27.0	26.0	26.0	31.0	30.0		
14:50	27.0	28.0	119.0	75.0	51.0	26.0	27.0	29.0	37.0	30.0	Avg:	27.8 60
15:00	30.0	30.0	39.0	38.0	34.0	36.0	41.0	39.0	33.0	36.0		
15:10	45.0	42.0	40.0	38.0	37.0	37.0	54.0	37.0	37.0	38.0		
15:20	37.0	39.0	45.0	64.0	34.0	35.0	38.0	39.0	54.0	44.0		
15:30	42.0	48.0	58.0	68.0	52.0	54.0	53.0	47.0	60.0	63.0		
15:40	52.0	48.0	48.0	43.0	49.0	45.0	41.0	35.0	38.0			
15:50	34.0	39.0	42.0	41.0	45.0	74.0	61.0	49.0	62.0	47.0	Avg:	44.2 60
16:00	57.0	47.0	47.0	54.0	43.0	60.0	56.0	61.0	47.0	39.0		
16:10	38.0	43.0	42.0	33.0	31.0	61.0	48.0	38.0	34.0	35.0		
16:20	31.0	31.0	27.0	58.0	42.0	31.0	30.0	30.0	27.0	34.0		
16:30	36.0	31.0	30.0	28.0	31.0	33.0	37.0	30.0	28.0	29.0		
16:40	28.0	28.0	31.0	30.0	29.0	28.0	29.0	30.0	24.0	23.0		
16:50	24.0	25.0	28.0	30.0	26.0	22.0	32.0	22.0	26.0	24.0	Avg:	34.8 60
17:00	23.0	23.0	24.0	25.0	23.0	31.0	32.0	31.0	30.0	27.0		
17:10	25.0	23.0	22.0	22.0	22.0	22.0	39.0	51.0	40.0	40.0		
17:20	28.0	22.0	35.0	41.0	45.0	33.0	42.0	46.0	48.0	39.0		
17:30	28.0	27.0	27.0	33.0	26.0	22.0	22.0	21.0	21.0	22.0		
17:40	22.0	22.0	22.0	26.0	29.0	28.0	24.0	23.0	31.0	29.0		
17:50	30.0	30.0	27.0	27.0	27.0	28.0	27.0	29.0	29.0	30.0	Avg:	29.0 60
18:00	33.0	33.0	32.0	30.0	34.0	34.0	38.0	39.0	35.0	30.0		
18:10	30.0	38.0	36.0	32.0	47.0	35.0	34.0	36.0	32.0	31.0		
18:20	32.0	32.0	35.0	53.0	25.0	36.0	35.0	34.0	36.0	35.0		
18:30	37.0	45.0	43.0	42.0	40.0	40.0	35.0	39.0	41.0	38.0		
18:40	37.0	39.0	56.0	46.0	45.0	37.0	35.0	39.0	37.0	46.0		
18:50	37.0	34.0	32.0	45.0	38.0	38.0	44.0	33.0	115.0	43.0	Avg:	38.8 60
19:00	34.0	34.0	33.0	35.0	36.0	35.0	39.0	47.0	53.0	36.0		
19:10	31.0	32.0	34.0	36.0	38.0	39.0	43.0	39.0	35.0	38.0		
19:20	41.0	44.0	42.0	44.0	48.0	41.0	53.0	48.0	37.0	34.0		
19:30	43.0	41.0	56.0	45.0	46.0	39.0	37.0	37.0	37.0	77.0		
19:40	43.0	32.0	28.0	32.0	40.0	43.0	33.0	38.0	41.0	32.0		
19:50	34.0	36.0	32.0	35.0	32.0	30.0	32.0	32.0	36.0	34.0	Avg:	38.8 60
20:00	30.0	31.0	31.0	33.0	31.0	33.0	29.0	29.0	32.0	30.0		
20:10	28.0	28.0	29.0	43.0	27.0	33.0	26.0	25.0	23.0	23.0		
20:20	25.0	25.0	25.0	26.0	36.0	28.0	23.0	23.0	25.0	35.0		
20:30	27.0	32.0	28.0	24.0	25.0	24.0	23.0	23.0	25.0	25.0		
20:40	23.0	23.0	24.0	27.0	24.0	23.0	23.0	22.0	23.0	23.0		
20:50	22.0	22.0	22.0	23.0	26.0	67.0	37.0	30.0	23.0	36.0	Avg:	27.5 60

CEM protocol for U. S. Steel Corp.
Revision: 1.0

ACEMS Pollution Monitor Daily Report V4.1 01/12/1993 Page # 4
Company: ABC CORP. Location : Somewhere, USA
Source : Boiler Pollutant: CO Units: ppm

21:00	28.0	24.0	21.0	23.0	25.0	24.0	28.0	40.0	26.0	23.0	
21:10	24.0	23.0	23.0	25.0	23.0	22.0	24.0	23.0	23.0	21.0	
21:20	21.0	22.0	40.0	49.0	44.0	55.0	57.0	43.0	29.0	26.0	
21:30	39.0	48.0	48.0	35.0	22.0	25.0	37.0	40.0	43.0	45.0	
21:40	25.0	26.0	21.0	25.0	23.0	24.0	28.0	37.0	35.0	39.0	
21:50	35.0	45.0	60.0	31.0	29.0	31.0	26.0	23.0	23.0	23.0	Avg: 31.0 60
22:00	22.0	23.0	22.0	22.0	24.0	24.0	24.0	24.0	31.0	37.0	
22:10	29.0	22.0	29.0	24.0	30.0	23.0	24.0	25.0	28.0	24.0	
22:20	24.0	25.0	26.0	33.0	34.0	24.0	27.0	24.0	26.0	24.0	
22:30	24.0	52.0	37.0	23.0	23.0	23.0	25.0	28.0	23.0	24.0	
22:40	23.0	26.0	30.0	35.0	30.0	26.0	24.0	24.0	27.0	31.0	
22:50	27.0	24.0	40.0	31.0	25.0	27.0	26.0	24.0	26.0	27.0	Avg: 27.1 60
23:00	28.0	25.0	25.0	22.0	30.0	32.0	33.0	29.0	23.0	24.0	
23:10	29.0	31.0	34.0	30.0	37.0	28.0	34.0	32.0	28.0	35.0	
23:20	31.0	28.0	26.0	25.0	29.0	37.0	38.0	45.0	31.0	25.0	
23:30	32.0	51.0	46.0	34.0	38.0	38.0	37.0	40.0	35.0	39.0	
23:40	34.0	40.0	43.0	41.0	31.0	35.0	36.0	31.0	38.0	37.0	
23:50	34.0	37.0	38.0	39.0	49.0	55.0	46.0	43.0	50.0	45.0	Avg: 34.6 60

Daily Average: 35.4 Count: 1426

Calibration Codes	Status Codes
IC - In calibration	CD - CEMSPEAK data error
SC - Span Calibration PASS	CT - CEMSPEAK task error
MC - Midrange Calibration PASS	DE - Data error
ZC - Zero Calibration PASS	HW - Hardware fault
CF - Calibration Fail	IG - Ignore Data
SF - Span Calibration Fail	LF - Communication Link Failure
MF - Midrange Calibration Fail	ND - No Data
ZF - Zero Calibration Fail	OD - Old Data
	DN - Process Down

End of Daily Report.

CEM protocol for U. S. Steel Corp.
Revision: 1.0

Daily O2 report

ACSMG Pollution Monitor Daily Report V4.1 01/12/1993 Page # 1
 Company: Some company Location : Yourtown, Yourstate
 Source : Boiler Pollutant: O2 Units: *

00:00	8.5	8.4	8.6	8.7	8.8	8.8	8.5	8.0	8.4	8.7	
00:10	8.8	8.8	8.9	8.8	8.8	8.4	8.5	8.6	8.2	8.7	
00:20	9.6	8.8	9.3	9.8	10.0	8.6	8.1	9.6	10.4	10.6	
00:30	10.7	10.6	10.1	9.3	8.4	8.5	8.6	8.4	8.5	8.5	
00:40	8.5	8.6	8.4	7.2	7.9	8.3	8.2	8.3	8.1	8.0	
00:50	8.0	8.0	8.0	7.9	7.7	8.0	7.8	8.3	7.4	8.1	Avg: 8.6
<hr/>											
01:00	8.3	8.5	8.3	8.2	8.3	8.6	7.4	8.1	8.1	8.3	
01:10	8.2	8.3	8.3	8.2	8.3	8.0	8.0	8.1	8.0	7.4	
01:20	8.1	8.4	8.3	8.2	7.3	8.3	8.4	8.2	8.1	7.7	
01:30	7.8	8.2	8.0	8.0	8.2	8.3	8.0	8.2	8.3	8.2	
01:40	8.0	8.1	8.1	8.0	8.1	8.4	7.9	8.0	7.1	7.9	
01:50	8.1	8.0	8.0	8.1	8.1	8.1	7.9	7.4	8.0	8.2	Avg: 8.0
<hr/>											
02:00	8.1	8.1	7.7	8.0	8.0	8.0	7.9	7.8	8.1	8.0	
02:10	8.0	8.0	8.1	8.0	8.0	8.4	8.3	8.3	7.8	8.2	
02:20	8.0	7.8	8.3	8.3	8.2	8.4	8.0	8.1	8.2	8.1	
02:30	8.3	8.0	8.0	8.1	7.9	8.0	8.1	8.1	8.0	8.0	
02:40	7.8	8.0	8.0	8.0	8.0	7.5	7.8	7.7	7.7	7.7	
02:50	7.6	7.7	7.8	7.7	7.4	7.7	7.7	7.7	7.6	7.6	Avg: 8.0
<hr/>											
03:00	7.8	7.7	7.6	6.9	7.1	7.9	7.8	8.1	8.3	8.3	
03:10	8.3	8.2	8.0	7.9	7.9	8.0	7.9	7.9	7.9	7.7	
03:20	7.8	7.9	7.8	7.8	7.7	7.8	7.8	7.6	7.6	7.5	
03:30	7.5	7.7	7.8	7.8	7.7	7.7	7.7	7.6	7.5	7.7	
03:40	6.8	6.7	7.9	7.8	8.1	8.0	7.8	7.7	7.9	7.9	
03:50	7.6	7.9	7.6	7.6	8.0	7.7	7.6	8.1	8.5	8.5	Avg: 7.7
<hr/>											
04:00	8.1	8.7	8.7	8.3	8.0	9.3	9.2	9.6	9.9	8.3	
04:10	8.0	8.0	8.1	8.0	8.1	7.5	8.1	8.2	8.2	8.1	
04:20	8.0	8.0	6.5	7.1	8.0	8.0	8.1	8.2	7.6	7.9	
04:30	8.1	8.2	8.0	7.9	7.9	7.9	8.0	7.9	7.9	7.9	
04:40	7.0	7.9	8.4	7.7	7.9	8.6	8.7	8.5	8.4	8.3	
04:50	8.3	8.3	7.3	7.4	7.7	7.2	6.0	8.4	8.8	8.8	Avg: 8.1
<hr/>											
05:00	8.8IC	15.4IC	21.1IC	19.7IC	1.5IC	0.0EC	0.6ZC	31.0IC	31.1SC	1.2IC	
05:10	9.8IC	3.1IC	7.2IC	7.3IC	8.0	7.9	7.9	7.7	7.8	6.2	
05:20	4.8	6.9	7.0	8.0	8.5	8.5	7.9	7.9	8.7	8.6	
05:30	8.5	8.4	8.3	8.3	8.1	7.4	8.2	8.2	8.3	8.4	
05:40	10.3	10.3	9.6	9.4	9.8	9.8	9.9	9.9	9.8	9.8	
05:50	9.4	9.9	9.9	9.9	9.5	8.3	8.3	8.3	8.2	8.2	Avg: 8.6
<hr/>											
06:00	8.3	8.3	8.3	8.4	8.3	8.2	8.3	8.1	8.3	8.4	
06:10	7.3	7.8	8.3	8.1	8.8	9.0	8.8	8.6	8.6	8.6	
06:20	8.6	8.3	8.1	8.4	8.3	8.2	8.3	7.5	7.8	8.3	
06:30	8.2	8.1	7.9	7.6	8.0	8.1	7.6	7.5	7.3	8.0	
06:40	8.1	8.0	7.9	7.7	7.3	8.0	7.7	7.6	7.9	8.0	
06:50	7.9	7.4	8.0	7.9	7.9	7.8	7.9	7.8	7.9	7.7	Avg: 8.0
<hr/>											

CEM protocol for U. S. Steel Corp.
Revision: 1.0

ACEMS Pollution Monitor Daily Report V4.1 01/12/1993 Page # 2
Company: Some company Location : Yourtown, Yourstate
Source : Boiler Pollutant: O2 Units: *

	07:00	7.8	7.6	7.9	7.9	7.7	7.7	7.4	7.6	7.7	7.6	
	07:10	7.2	8.0	7.6	8.0	7.6	7.9	8.0	8.0	7.9	7.9	
	07:20	8.1	8.0	8.1	7.9	8.0	7.9	8.4	7.8	8.7	7.3	
	07:30	8.3	8.5	8.5	8.3	8.3	7.7	8.0	8.1	8.0	7.6	
	07:40	7.6	8.0	7.9	7.5	7.6	7.6	7.5	7.5	7.6	7.7	
60	07:50	7.2	7.5	7.6	7.6	7.2	7.6	7.6	7.4	7.6	7.5	Avg: 7.7
	08:00	7.1	7.3	7.2	7.6	7.6	7.6	7.6	7.5	7.4	6.2	
	08:10	6.7	6.6	6.9	5.8	6.4	6.1	6.1	7.9	7.3	7.0	
	08:20	7.8	7.8	7.6	7.8	7.7	7.3	7.4	7.7	7.6	7.1	
	08:30	7.3	7.6	7.7	7.8	7.5	7.5	7.5	7.6	7.7	7.8	
	08:40	7.8	7.8	7.8	7.8	7.4	6.4	7.9	8.2	8.1	7.4	
60	08:50	7.8	8.1	7.8	7.0	7.6	7.6	8.0	7.9	7.1	7.9	Avg: 7.5
	09:00	7.8	7.4	7.1	6.7	7.7	7.9	7.8	7.9	7.8	7.4	
	09:10	7.7	7.8	7.7	7.2	7.8	7.8	7.7	7.4	7.8	7.8	
	09:20	7.8	7.7	7.2	7.7	7.7	7.7	7.1	7.7	7.6	7.8	
	09:30	7.8	8.0	7.8	7.8	7.8	7.9	7.9	7.8	7.9	7.9	
	09:40	6.0	8.1	7.9	7.8	7.5	7.7	7.5	7.5	6.8	7.5	
60	09:50	8.0	7.5	7.6	8.0	7.7	7.7	8.0	8.1	8.1	8.1	Avg: 7.7
	10:00	8.1	7.4	6.8	8.0	8.0	7.7	7.5	7.8	7.8	7.7	
	10:10	7.7	7.6	7.6	7.4	7.3	7.3	7.4	7.3	7.3	7.0	
	10:20	6.0	7.3	7.3	7.7	7.7	7.7	7.7	6.9	7.9	7.8	
	10:30	7.8	7.9	7.7	7.7	7.6	6.9	7.4	7.7	7.7	7.6	
	10:40	7.8	7.7	7.6	7.3	6.0	7.6	7.4	7.9	7.8	7.7	
60	10:50	8.1	8.1	7.9	8.1	8.1	8.0	8.0	7.9	7.8	7.7	Avg: 7.6
	11:00	7.4	7.6	6.6	7.7	8.0	8.2	8.1	7.9	8.0	7.6	
	11:10	6.7	7.7	7.9	8.1	7.9	7.9	7.7	7.4	7.7	7.6	
	11:20	6.2	7.6	7.4	8.0	8.3	8.2	8.2	8.1	8.0	8.1	
	11:30	8.0	8.0	8.0	7.9	7.8	7.1	6.4	7.8	8.3	8.0	
	11:40	8.0	7.7	8.1	8.0	7.8	7.7	7.3	7.4	7.6	7.5	
60	11:50	6.9	7.6	7.3	7.2	7.4	7.6	7.6	7.6	7.5	7.7	Avg: 7.7
	12:00	7.5	7.7	7.7	7.8	7.8	7.8	7.8	7.8	7.7	7.7	
	12:10	7.4	6.7	7.8	7.6	7.6	7.9	7.6	6.4	7.6	7.7	
	12:20	7.2	7.4	7.6	7.6	7.5	7.4	7.5	7.0	7.1	7.7	
	12:30	7.6	7.8	7.9	7.4	7.8	7.8	7.7	7.9	7.9	7.4	
	12:40	7.8	8.0	7.6	8.1	7.7	8.0	8.1	7.6	7.9	8.0	
60	12:50	8.0	7.9	7.9	7.9	7.4	7.9	8.0	8.0	7.9	8.0	Avg: 7.7
	13:00	8.0	8.0	6.7	7.9	8.3	8.2	8.1	7.4	7.9	8.1	
	13:10	8.1	8.1	8.1	8.0	8.1	8.0	7.4	7.9	7.2	7.5	
	13:20	7.9	7.6	7.9	6.7	7.9	7.9	7.6	7.9	7.9	7.0	
	13:30	7.8	7.5	8.0	7.6	7.8	8.1	8.0	9.7	9.0	8.1	
	13:40	8.3	7.9	8.5	8.7	9.4	9.5	9.5	9.4	8.9	9.5	
60	13:50	8.9	8.7	7.9	9.1	9.5	9.5	9.6	8.9	8.2	8.1	Avg: 8.2

CEM protocol for U. S. Steel Corp.
Revision: 1.0

ACEMS Pollution Monitor Daily Report V4.1 01/12/1993 Page # 3
 Company: Some company Location : Yourtown, Yourstate
 Source : Boiler Pollutant: O2 Units: ppm

14:00	8.1	7.9	8.7	8.8	8.4	8.4	8.5	8.4	8.3	8.1	
14:10	8.4	8.4	8.5	8.3	8.2	8.3	8.4	8.4	8.0	7.9	
14:20	8.0	7.9	7.8	7.9	7.7	7.8	7.7	7.6	7.9	8.3	
14:30	7.5	8.2	8.1	8.2	8.1	8.0	7.9	7.7	7.9	7.9	
14:40	7.8	7.7	7.5	7.8	7.6	7.5	7.4	7.5	7.4	7.5	
14:50	7.5	7.4	8.0	8.5	5.9	7.8	7.8	7.9	7.4	7.8	Avg: 7.8
60											
15:00	8.0	7.9	7.9	7.8	7.7	7.6	7.8	7.2	7.6	7.3	
15:10	8.8	7.4	7.3	7.3	7.3	7.1	6.4	7.1	7.3	7.3	
15:20	7.3	7.3	7.1	6.5	6.9	7.3	7.1	7.1	6.9	7.1	
15:30	7.3	7.3	7.0	7.0	7.0	6.8	6.7	7.0	7.0	7.0	
15:40	7.1	6.9	6.9	7.2	7.1	7.0	7.0	7.1	7.1	7.0	
15:50	6.9	6.9	7.0	7.1	7.1	6.3	6.8	7.1	6.5	6.8	Avg: 7.1
60											
16:00	7.1	7.1	7.0	7.2	7.2	6.9	6.9	7.0	7.1	7.1	
16:10	7.1	7.1	7.1	7.2	7.2	6.3	6.2	7.3	7.4	7.4	
16:20	7.3	7.4	7.4	6.8	7.0	7.6	7.6	7.6	7.5	7.5	
16:30	7.4	7.5	7.5	7.5	7.4	7.4	7.4	7.6	7.5	7.5	
16:40	7.6	7.6	7.3	7.6	7.6	7.6	7.5	7.6	7.6	7.6	
16:50	7.8	7.5	7.7	7.8	7.9	7.9	7.9	7.9	7.9	7.9	Avg: 7.4
60											
17:00	7.9	7.7	7.7	7.7	7.7	7.6	7.5	7.6	7.7	8.0	
17:10	8.2	8.4	8.6	8.7	8.6	8.6	8.4	8.1	8.7	8.8	
17:20	8.9	8.6	9.3	9.9	9.8	8.3	8.5	8.8	9.4	9.4	
17:30	8.6	8.4	8.5	7.9	8.1	8.4	8.7	8.7	8.7	8.6	
17:40	8.6	8.5	8.4	8.3	7.8	7.6	8.3	8.5	8.1	8.1	
17:50	8.2	8.3	8.3	8.1	8.0	8.1	8.1	8.0	8.0	8.3	Avg: 8.4
60											
18:00	7.7	7.6	7.5	7.8	7.5	7.4	7.2	7.4	7.2	8.0	
18:10	8.0	7.5	7.9	8.1	7.0	7.6	8.1	7.8	7.9	8.0	
18:20	7.9	8.0	8.0	8.1	7.7	8.0	8.3	8.4	8.4	8.3	
18:30	8.2	8.0	8.2	8.0	8.0	7.8	8.1	8.1	8.0	7.9	
18:40	7.8	7.9	7.2	7.7	7.7	7.9	7.8	7.8	7.4	7.2	
18:50	7.9	7.9	8.1	7.5	8.1	8.3	7.9	8.2	8.4	7.4	Avg: 7.8
60											
19:00	8.4	8.8	8.8	8.3	8.6	8.6	8.3	7.5	7.2	7.8	
19:10	8.8	8.6	8.5	8.4	8.2	8.2	7.7	8.3	8.2	8.1	
19:20	8.0	7.9	7.9	7.7	7.6	7.7	7.0	7.6	7.8	7.6	
19:30	7.1	7.6	7.3	7.4	7.2	8.1	8.1	8.3	8.0	8.4	
19:40	7.6	8.2	8.2	8.1	8.1	7.5	8.1	7.9	7.4	8.0	
19:50	8.0	8.0	8.0	7.5	8.0	8.0	8.0	7.9	7.5	7.4	Avg: 7.9
60											
20:00	8.0	7.9	7.9	8.0	8.0	7.7	7.8	8.0	8.3	8.2	
20:10	8.2	8.1	8.0	8.7	7.7	6.9	7.7	8.1	8.3	8.3	
20:20	8.3	8.3	8.3	8.0	7.3	7.6	8.3	8.3	8.1	8.0	
20:30	7.8	7.2	7.8	8.0	7.9	7.9	7.8	7.0	7.8	8.0	
20:40	8.0	7.9	8.0	7.8	7.8	7.8	8.1	7.8	7.8	7.9	
20:50	7.9	7.9	7.8	7.8	7.6	5.7	6.8	6.9	7.4	7.4	Avg: 7.8

CEM protocol for U. S. Steel Corp.
Revision: 1.0

ACEMS Pollution Monitor Daily Report V4.1 01/12/1993 Page # 4
 Company: Some company Location : Yourtown, Yourstate
 Source : Boiler Pollutant: O₂ Units: %

21:00	7.0	7.8	8.6	8.5	8.3	8.1	7.7	6.5	7.9	7.9	
21:10	7.9	7.9	7.9	8.0	8.0	7.9	7.8	7.7	7.7	7.9	
21:20	7.8	7.8	7.1	6.8	8.0	9.0	9.3	9.1	8.8	8.0	
21:30	9.1	9.2	9.4	8.8	7.6	8.0	9.1	9.3	9.3	9.3	
21:40	7.8	7.4	7.2	7.1	7.2	6.9	6.9	7.0	6.8	6.5	
21:50	6.9	6.7	6.3	7.7	7.8	7.3	8.1	8.1	7.9	7.9	Avg: 7.8
60											
22:00	7.9	7.8	7.6	7.6	7.5	7.5	7.6	7.4	7.0	8.7	
22:10	6.8	7.5	7.1	7.6	7.0	7.7	7.7	7.6	7.1	7.5	
22:20	7.5	7.5	7.4	7.0	7.4	7.3	7.2	7.3	7.2	7.1	
22:30	7.2	5.9	6.6	7.5	7.5	7.4	7.2	7.0	7.5	7.5	
22:40	7.5	7.5	7.4	7.0	7.4	7.4	7.5	7.5	7.5	7.5	
22:50	7.5	7.5	6.4	6.8	7.5	7.6	7.5	7.6	7.6	7.6	Avg: 7.3
60											
23:00	7.4	7.5	7.5	7.4	6.9	7.4	7.5	7.4	7.6	7.6	
23:10	7.4	7.4	7.3	7.2	6.7	7.3	7.2	7.3	7.4	7.3	
23:20	7.4	7.5	7.6	7.6	7.5	7.5	7.3	6.6	7.3	7.6	
23:30	7.5	6.8	6.2	7.3	7.1	7.2	7.5	7.6	7.3	7.5	
23:40	7.4	7.2	7.0	7.4	7.4	7.3	7.3	7.4	7.3	7.1	
23:50	7.2	7.5	7.6	7.4	7.2	7.2	7.2	7.2	7.3	7.4	Avg: 7.3
60											

Daily Average: 7.8 Count: 1426

Calibration Codes	Status Codes
IC - In calibration	CD - CEMSPEAK data error
SC - Span Calibration PASS	CT - CEMSPEAK task error
MC - Midrange Calibration PASS	DE - Data error
ZC - Zero Calibration PASS	HW - Hardware fault
CP - Calibration Fail	IS - Ignore Data
SP - Span Calibration Fail	LF - Communication Link Failure
MP - Midrange Calibration Fail	ND - No Data
ZP - Zero Calibration Fail	OD - Old Data
	DN - Process Down

End of report.

Daily Stack Calibration Summary

COMPANY: Your Company

PERIOD START: August 22, 1993

PLANT:

PERIOD END: September 03, 1993

STACK: Turbine 1 on Node turbine_1

Created: 09/03/93 Page 1

Ranges of Analyzers:

CO: 0.0 - 50.0 ppm

O2: 0.0 - 25.0 %

NOX_INLET: 0.0 - 200.0 ppm

NOX_OUT: 0.0 - 50.0 ppm

NH3: 0.0 - 50.0 ppm

COLO: 0.0 - 20.0 ppm

ALLOWANCE

Date	Time	ANALYZER	TYPE	EXPECTED	ACTUAL	ABS	%	RANGE	Units	%
------	------	----------	------	----------	--------	-----	---	-------	-------	---

09/03/93	05:29	NH3	SPAN	38.7	39.8	1.1	2.20%	2.5	5.0%	P
09/03/93	05:29	NH3	ZERO	0.0	0.0	0.0	0.00%	2.5	5.0%	P

09/03/93	05:29	NOX_OUT	SPAN	38.7	41.4	2.7	5.40%	2.5	5.0%	F
09/03/93	05:29	NOX_OUT	ZERO	0.0	-0.1	0.1	0.20%	2.5	5.0%	P

09/03/93	05:29	NOX_INLE	SPAN	182.0	177.0	5.0	2.50%	10.0	5.0%	P
09/03/93	05:29	NOX_INLE	ZERO	0.0	0.0	0.0	0.00%	10.0	5.0%	P

09/03/93	05:29	O2	SPAN	22.0	22.0	0.0	0.04%	0.5	2.0%	P
09/03/93	05:29	O2	ZERO	0.0	-0.1	0.1	0.24%	0.5	2.0%	P

09/03/93	05:29	COLO	SPAN	39.8	37.7	2.1	4.20%	2.5	5.0%	P
09/03/93	05:29	COLO	ZERO	0.0	-0.8	0.8	1.60%	2.5	5.0%	P

09/02/93	09:15	NH3	SPAN	38.7	39.0	0.3	0.60%	2.5	5.0%	P
09/02/93	09:15	NH3	ZERO	0.0	0.0	0.0	0.00%	2.5	5.0%	P

09/02/93	09:15	NOX_OUT	SPAN	38.7	38.7	0.0	0.00%	2.5	5.0%	P
09/02/93	09:15	NOX_OUT	ZERO	0.0	0.0	0.0	0.00%	2.5	5.0%	P

09/02/93	09:15	NOX_INLE	SPAN	182.0	181.2	0.8	0.40%	10.0	5.0%	P
09/02/93	09:15	NOX_INLE	ZERO	0.0	0.0	0.0	0.00%	10.0	5.0%	P

09/02/93	09:15	O2	SPAN	22.0	22.4	0.4	1.48%	0.5	2.0%	P
09/02/93	09:15	O2	ZERO	0.0	0.1	0.1	0.52%	0.5	2.0%	P

09/02/93	09:15	COLO	SPAN	39.8	38.0	1.8	3.60%	2.5	5.0%	P
09/02/93	09:15	COLO	ZERO	0.0	-0.7	0.7	1.40%	2.5	5.0%	P

CO	O2	NOX_INLET	NOX_OUT	NH3	COLO
P - Pass	< 5.0%	< 2.0%	< 5.0%	< 5.0%	< 5.0%
F - Fail	> 5.0%	> 2.0%	> 5.0%	> 5.0%	> 5.0%

CEM protocol for U. S. Steel Corp.
Revision: 1.0

Sample Source Operation Report.

Page # 1

Source Operation Report
Quarter: 2 Year: 1991
Enerotec Industrial, Inc.
811 West 5th St.
Source: CUB 101
CEMS id no.: _____

Operation Outage Began	Operation Outage Ended	Source Downtime dd:hh:mm	Reasons for Downtime	Corrective Action
04/01 00:00	05/23 10:06	52/09:07	Process down	system off line.
05/23 10:18	05/23 10:18	00:05	Data Acquisition down	None at this time.
05/23 10:38	05/23 10:35	00:01	Process down	None at this time.
05/23 10:43	05/23 10:44	00:01	Process down	None at this time.
05/23 10:59	05/23 13:59	03:01	Routine Maintenance	Scheduled maintenance.
05/23 14:04	05/28 09:16	4/19:13	Routine Maintenance	Scheduled maintenance.
05/28 10:12	05/28 10:12	00:01	Data Acquisition down	None at this time.
05/28 10:50	05/28 10:57	00:08	Data Acquisition down	None at this time.
05/28 10:59	05/28 11:03	00:04	Process down	None at this time.
05/29 10:53	05/29 13:29	02:36	Process down	Preventive maintenance.
05/29 13:33	05/29 13:34	00:02	Data Acquisition down	None at this time.
05/29 13:43	05/28 16:54	03:12	Preventive Maintenance	Scheduled maintenance.
05/30 08:52	05/30 09:02	00:11	Process down	None at this time.
05/30 11:25	05/30 13:27	02:02	Process down	None at this time.
05/30 13:31	05/30 13:31	00:01	Routine Maintenance	Scheduled maintenance.
05/30 14:09	05/30 14:10	00:02	Data Acquisition down	None at this time.
06/01 12:05	06/01 12:10	00:05	Process down	None at this time.
06/02 09:37	06/02 09:56	00:20	Process down	None at this time.
06/02 10:09	06/02 10:11	00:02	Data Acquisition down	None at this time.
06/02 11:37	06/02 11:44	00:07	Routine Maintenance	Scheduled maintenance.
06/02 12:22	06/02 13:23	00:01	Process down	None at this time.

CEM protocol for U. S. Steel Corp.
Revision: 1.0

Source Operation Report
Quarter: 2 Year: 1991
Enertec Industrial, Inc.
811 West 5th St.
Source: CUB 101
CEMS id no.: _____

Page # 2

Outage Summary

Total Times	DAYS/HRS:MINs
Process Up Time	4/18:53
Process Down Time	00:00
Data Acquisition Down Time	57/16:39
Total Time in Quarter	62/11:23

Time percentages

Per cent process up time	7.7%	Process Uptime / Time in Quarter
Per cent process down time	0.0%	Process Downtime / Time in Quarter
Per cent DA down time	92.3%	DA Downtime / Time in Quarter
Total time	100.0%	

Process availability 7.7% Process Uptime / (Process Uptime + DA Downtime)

Calculate maximum additional DA downtime permitted for rest of quarter.

Availability base = cess uptime + DA downtime + time remaining in quarter	90/23:00
.90 * availability base	81/20:42
Max DA downtime permitted for quarter	9/02:18
Less time that DA already down for quarter	57/16:30
Max DA downtime permitted in remainder of quarter	00:00

CEM protocol for U. S. Steel Corp.
Revision: 1.0

Sample of a PA Excess Emissions Report.

STANDARD EMISSIONS REPORT PAGE 1
COMPANY NAME: U. S. Steel Corp.
LOCATION: Clairton, PA.
SOURCE: Boiler
CEMS ID NO. (+SOURCE ID+ANALYZER ID): 0068910
PARAMETER: NOX#MBTU
QUARTER: 4
YEAR: 92
UNITS: lbs

HOUR	1	2	3	4	5	6	7	8
	9	10	11	12	13	14	15	16
	17	18	19	20	21	22	23	24
	XXXX,PC	XXXX,PC	XXXX,PC	XXXX,PC	XXXX,PC	XXXX,PC	XXXX,PC	XXXX,PC
DAY								
01	0006.08	0006.08	0007.08	0007.08	0006.08	0006.08	0007.08	
	0007.08	0005.08	0005.08	0005.08	0005.08	0005.08	0005.08	0006.08
	0005.08	0005.08	0006.08	0006.08	0006.08	0005.08	0005.08	0006.08
02	0005.08	0005.08	0005.08	0005.08	0005.08	0005.08	0005.08	0006.08
	0007.08	0005.08	0005.08	0008.08	0005.08	0005.08	0006.08	
	0005.08	0005.08	0005.08	0005.08	0005.08	0005.08	0005.08	0005.08
03	0004.08	0004.08	0004.08	0004.08	0004.08	0004.08	0004.08	0006.08
	0005.08	0004.08	0004.08	0004.08	0004.08	0004.08	0004.08	0005.08
	0004.08	0004.08	0004.08	0004.08	0004.08	0004.08	0004.08	0004.08
04	0004.08	0004.08	0004.08	0003.08	0003.08	0003.08	0003.08	0005.08
	0005.08	0003.08	0003.08	0003.08	0003.08	0003.08	0004.08	0004.08
	0003.08	0003.08	0003.08	0003.08	0003.08	0002.08	0002.08	0002.08
05	0001.08	0002.08	0002.08	0002.08	0001.08	0001.08	0001.08	0003.08
	0003.08	0001.08	0001.08	0001.08	0002.08	0002.08	0002.08	0003.08
	0002.08	0002.08	0002.08	0002.08	0002.08	0002.08	0002.08	0002.08
06	0001.08	0001.08	0001.08	0001.08	0001.08	0001.08	0001.08	0003.08
	0002.08	0000.08	0000.08	0001.08	0001.08	II21.08	0007.08	0006.08
	0006.08	0007.08	0007.08	0007.08	0007.08	0007.08	0007.08	0007.08
07	0007.08	0007.08	0007.08	0007.08	0007.08	0007.08	0007.08	0007.08
	II21.08	II21.08	0010.08	0008.08	0007.08	0007.08	0007.08	0007.08
	0008.08	0007.08	0008.08	0007.08	0007.08	0007.08	0007.08	0007.08
08	0007.08	0008.08	0008.08	0007.08	0007.08	0008.08	0008.08	0008.08
	III18.08	III18.08	0008.08	II21.08	II21.08	II21.08	0010.08	0011.08
	0010.08	0010.08	0010.08	0011.08	0010.08	0010.08	0010.08	0010.08
09	0009.08	0010.08	0011.08	0012.08	0012.08	0014.08	0016.08	0016.08
	0015.08	0013.08	0012.08	0011.08	II21.08	0011.08	0011.08	0011.08
	0010.08	0010.08	0010.08	0010.08	0010.08	0010.08	0010.08	0011.08
10	0011.08	0010.08	0011.08	0011.08	0010.08	0010.08	0011.08	0011.08
	0014.08	0012.08	0011.08	0011.08	0011.08	0011.08	0011.08	0011.08
	0011.08	0010.08	0011.08	0011.08	0011.08	0011.08	0011.08	0012.08
11	0011.08	0011.08	0010.08	0010.08	0010.08	0010.08	0010.08	0010.08

CEM protocol for U. S. Steel Corp.
Revision: 1.0

STANDARD EMISSIONS REPORT PAGE 2
CEMS ID NO. (+SOURCE ID+ANALYZER ID): 0068910
QUARTER: 4
YEAR: 92

HOUR	1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16	
17	18	19	20	21	22	23	24	

XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC

DAY

0012.08	0010.08	0010.08	0012.08	0011.08	0009.08	0009.08	0010.08	
0010.08	0010.08	0011.08	0011.08	0011.08	0012.08	0012.08	0013.08	
12	0012.08	0012.08	0012.08	0012.08	0011.08	0010.08	0011.08	0012.08
	0012.08	0011.08	0011.08	0013.08	0010.08	0010.08	0010.08	0011.08
	0010.08	0010.08	0010.08	0010.08	0010.08	0010.08	0010.08	0010.08
13	0010.08	0009.08	0009.08	0010.08	0009.08	0009.08	0009.08	0010.08
	0011.08	0010.08	0010.08	II21.08	0010.08	0010.08	0010.08	0011.08
	0010.08	0010.08	0010.08	0011.08	0011.08	0011.08	0011.08	0011.08
14	0011.08	0010.08	0010.08	0011.08	0011.08	0011.08	0011.08	0011.08
	II21.08	II21.08	0010.08	0010.08	0010.08	0010.08	0010.08	0010.08
	0010.08	0010.08	0011.08	0013.08	0013.08	0013.08	0012.08	0013.08
15	0012.08	0013.08	0013.08	0011.08	0011.08	0010.08	0011.08	0011.08
	0012.08	0010.08	0011.08	0011.08	0011.08	0010.08	0010.08	0011.08
	0011.08	0011.08	0010.08	0010.08	0010.08	0010.08	0010.08	0010.08
16	0010.08	0010.08	0010.08	0010.08	0010.08	0010.08	0011.08	0011.08
	0011.08	0010.08	0010.08	0010.08	0010.08	0010.08	0011.08	0011.08
	0010.08	0010.08	0011.08	0011.08	0011.08	0011.08	0011.08	0012.08
17	0011.08	0011.08	0011.08	0010.08	0009.08	0007.08	0007.08	0008.08
	0011.08	0010.08	0009.08	0010.08	0009.08	0010.08	0010.08	0010.08
	0010.08	0011.08	0012.08	0012.08	0012.08	0012.08	0012.08	0012.08
18	0012.08	0012.08	0012.08	0012.08	0011.08	0011.08	0011.08	
	0012.08	0010.08	0010.08	0011.08	0011.08	0009.08	0012.08	0014.08
	0013.08	0010.08	0014.08	0011.08	0010.08	0010.08	0010.08	0010.08
19	0010.08	0012.08	0009.08	0010.08	0010.08	0010.08	0010.08	0011.08
	0011.08	0009.08	0010.08	0010.08	0009.08	0009.08	0010.08	0010.08
	0010.08	0010.08	0010.08	0010.08	0009.08	0009.08	0009.08	0009.08
20	0008.08	0008.08	0008.08	0008.08	0008.08	0007.08	0010.08	III16.08
	II21.08	II21.08	II16.08	II21.08	II21.08	II21.08	II21.08	II20.08
	II20.08	0010.08	0011.08	0012.08	0011.08	0011.08	0011.08	0011.08
21	0010.08	0010.08	0010.08	0010.08	0008.08	0008.08	0011.08	II21.08
	II21.08	II21.08	II21.08	0010.08	0011.08	II21.08	II21.08	0009.08
	0009.08	0009.08	0010.08	0011.08	0010.08	0009.08	0010.08	0011.08
22	0011.08	0010.08	0009.08	0009.08	0009.08	0010.08	0011.08	0011.08
	0011.08	0010.08	0010.08	0010.08	II21.08	II21.08	0010.08	0011.08
	0011.08	0010.08	0008.08	0009.08	0009.08	0009.08	0010.08	0011.08
23	0012.08	0012.08	0012.08	0012.08	0011.08	0011.08	0012.08	0012.08
	0012.08	II18.08	II21.08	0011.08	0011.08	0011.08	0011.08	0011.08

CEM protocol for U. S. Steel Corp.
Revision: 1.0

STANDARD EMISSIONS REPORT PAGE 3
CEMS ID NO. (+SOURCE ID+ANALYZER ID): 0068910

QUARTER: 4
YEAR: 92

HOUR	1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16	
17	18	19	20	21	22	23	24	

XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC

DAY

0011.08	0010.08	0009.08	0010.08	0009.08	0009.08	0009.08	0010.08	
24	0010.08	0009.08	0008.08	0007.08	0008.08	0008.08	0008.08	0008.08
	0009.08	0009.08	0007.08	0008.08	0009.08	0009.08	0010.08	
	0009.08	0010.08	0011.08	0011.08	0011.08	0012.08	0011.08	
25	0011.08	0011.08	0011.08	0011.08	0011.08	0012.08	0012.08	0012.08
	0012.08	II18.08	II18.08	II21.08	0012.08	0012.08	0012.08	0012.08
	0012.08	0012.08	0013.08	0012.08	0012.08	0011.08	0012.08	0012.08
26	0011.08	0012.08	0012.08	0013.08	0012.08	0011.08	0012.08	0012.08
	0011.08	II18.08	0014.08	0012.08	0011.08	0011.08	0011.08	0012.08
	0012.08	0011.08	0011.08	0013.08	0012.08	0012.08	0012.08	0012.08
27	0012.08	0012.08	0012.08	0013.08	0012.08	0012.08	0013.08	0012.08
	II21.08	II21.08	II21.08	II21.08	II21.08	0010.08	0010.08	
	0010.08	0010.08	0011.08	0011.08	0012.08	0012.08	0011.08	0011.08
28	0011.08	0012.08	0012.08	0012.08	0011.08	0012.08	0011.08	0011.08
	II18.08	0014.08	0013.08	0012.08	0011.08	0012.08	0010.08	0010.08
	0010.08	0011.08	0012.08	0012.08	0012.08	0012.08	0012.08	0012.08
29	0012.08	0012.08	0012.08	0012.08	0012.08	0013.08	0012.08	0012.08
	II18.08							
	II18.08							
30	II18.08	0012.08						
	0012.08	0011.08	0011.08	0012.08	0012.08	0012.08	0011.08	0011.08
	0011.08	0012.08	0011.08	0010.08	0011.08	0011.08	0011.08	0012.08
31	0012.08	0011.08	0011.08	0012.08	0012.08	0012.08	0012.08	0013.08
	0017.08	0017.08	0017.08	0016.08	0014.08	0012.08	0012.08	0011.08
	0012.08	0011.08	0012.08	0014.08	0015.08	0014.08	0013.08	0013.08
32	0011.08	0011.08	0012.08	0011.08	0011.08	0012.08	0013.08	0013.08
	0013.08	0012.08	0012.08	0012.08	0012.08	0012.08	0013.08	0013.08
	0011.08	0011.08	0012.08	0012.08	0012.08	0012.08	0012.08	0012.08
33	0013.08	0013.08	0014.08	0013.08	0013.08	0013.08	0013.08	0012.08
	0013.08	0011.08	0010.08	0010.08	0008.08	0000.08	0000.08	0000.08
	0000.08	0000.08	0000.08	0000.08	0000.08	0000.08	0000.08	0000.08
34	0000.08	0000.08	0000.08	0000.08	0000.08	II13.08	II13.08	II13.08
	II13.08							
	II13.08							
35	II13.08	II13.08	II13.08	II13.08	II13.08	II13.08	0000.08	0000.08
	0000.08	0000.08	0002.08	0001.08	0000.08	0000.08	0000.08	0000.08
	0000.08	0000.08	0000.08	0000.08	0000.08	0000.08	0000.08	0000.08

CEM protocol for U. S. Steel Corp.
Revision: 1.0

STANDARD EMISSIONS REPORT PAGE 4
CEMS ID NO. (+SOURCE ID+ANALYZER ID): 0068910

QUARTER: 4

YEAR: 92

HOUR	1	2	3	4	5	6	7	8
9		10	11	12	13	14	15	16
17		18	19	20	21	22	23	24

XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC

DAY

36	0000.08	0000.08	0000.08	0000.08	0000.08	0000.08	0000.08	II21.08
	III16.08							
	0008.08	0007.08	0008.08	0008.08	0008.08	0009.08	0009.08	0009.08
37	0009.08	0010.08	0010.08	0011.08	0011.08	0011.08	0011.08	0011.08
	III16.08	III16.08	0012.08	0012.08	0011.08	0011.08	0012.08	0013.08
	0012.08	0013.08	0012.08	0012.08	0012.08	0011.08	0011.08	0011.08
38	0012.08	0011.08	0010.08	0010.08	0011.08	0011.08	0011.08	0012.08
	0013.08	0012.08	0011.08	0011.08	III18.08	0011.08	0011.08	0011.08
	0012.08	0013.08	0013.08	0013.08	0013.08	0013.08	0012.08	0011.08
39	0011.08	0011.08	0011.08	0011.08	0009.08	0010.08	0009.08	0010.08
	0011.08	0011.08	0010.08	0009.08	0008.08	0009.08	0008.08	0010.08
	0011.08	0011.08	0012.08	0011.08	0011.08	0011.08	0010.08	0009.08
40	0010.08	0012.08	0011.08	0010.08	0010.08	0010.08	0009.08	0010.08
	0011.08	0009.08	0009.08	0009.08	0009.08	0009.08	0009.08	0009.08
	0010.08	0011.08	0010.08	0010.08	0011.08	0011.08	0011.08	0012.08
41	0012.08	0011.08	0010.08	0011.08	0011.08	0011.08	0011.08	0012.08
	0012.08	0010.08	0010.08	0011.08	0011.08	0011.08	0010.08	0011.08
	0011.08	0011.08	0012.08	0012.08	0012.08	0012.08	0011.08	0010.08
42	0010.08	0010.08	0010.08	0010.08	0011.08	0011.08	0011.08	0011.08
	0012.08	0011.08	0012.08	0011.08	0011.08	0010.08	0011.08	0011.08
	0010.08	0011.08	0011.08	0011.08	0011.08	0011.08	0010.08	0009.08
43	0010.08	0011.08	0011.08	0011.08	0012.08	0012.08	0013.08	0014.08
	II21.08	0013.08	0012.08	0011.08	0011.08	0011.08	0010.08	0011.08
	0013.08	0013.08	0013.08	0013.08	0012.08	0012.08	0012.08	0013.08
44	0014.08	0014.08	0014.08	0013.08	0014.08	0014.08	0014.08	0013.08
	III16.08	III16.08	III16.08	III16.08	0015.08	0015.08	0014.08	0014.08
	0014.08	0016.08	0015.08	0014.08	0014.08	0012.08	0012.08	0012.08
45	0012.08	0013.08	0014.08	0013.08	0014.08	0014.08	0013.08	0013.08
	II21.08	0013.08	0012.08	0012.08	0013.08	0014.08	0014.08	0013.08
	0013.08	0013.08	0013.08	0012.08	0012.08	0012.08	0012.08	0012.08
46	0012.08	0012.08	0013.08	0012.08	0012.08	0012.08	0012.08	0012.08
	II21.08	II21.08	0013.08	0012.08	0012.08	0012.08	0013.08	0012.08
	0012.08	0012.08	0013.08	0012.08	0012.08	0011.08	0012.08	0012.08
47	0011.08	0011.08	0012.08	0011.08	0011.08	0012.08	0013.08	0012.08
	III16.08	III16.08	III16.08	III16.08	0011.08	0011.08	0011.08	0011.08
	0011.08	0012.08	0012.08	0011.08	0010.08	0011.08	0011.08	0011.08
48	0011.08	0011.08	0011.08	0011.08	0011.08	0011.08	0011.08	0011.08

CEM protocol for U. S. Steel Corp.
Revision: 1.0

STANDARD EMISSIONS REPORT PAGE 5

CEMS ID NO. (+SOURCE ID+ANALYZER ID): 0068910

QUARTER: 4

YEAR: 92

HOUR	1	2	3	4	5	6	7	8
	9	10	11	12	13	14	15	16
	17	18	19	20	21	22	23	24

XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC

DAY

III16.08	II16.08	0014.08	0012.08	0011.08	0011.08	0011.08	0011.08	0011.08
0011.08	0011.08	0011.08	0010.08	0010.08	0011.08	0011.08	0011.08	0010.08
49	0010.08	0010.08	0011.08	0010.08	0010.08	0011.08	0010.08	0011.08
	0012.08	0011.08	0011.08	0011.08	0011.08	0011.08	0011.08	0011.08
	0011.08	0012.08	0012.08	0011.08	0011.08	0012.08	II16.08	0011.08
50	0011.08	0012.08	0012.08	0011.08	0011.08	0011.08	0012.08	0011.08
	II21.08	0012.08	0012.08	0011.08	0011.08	0012.08	0012.08	0011.08
	0011.08	0012.08	0012.08	0012.08	0012.08	0011.08	0011.08	0010.08
51	0010.08	0010.08	0011.08	0011.08	0010.08	0010.08	0011.08	II21.08
	0009.08	0010.08	0011.08	0010.08	0011.08	0010.08	0010.08	0011.08
	0011.08	0011.08	0011.08	0011.08	0011.08	0011.08	0011.08	0011.08
52	0012.08	0011.08	0010.08	0011.08	0011.08	0011.08	0011.08	0012.08
	II21.08	0011.08	0011.08	0012.08	0011.08	0011.08	0011.08	0012.08
	0011.08	0011.08	0011.08	0011.08	0011.08	0011.08	0011.08	0012.08
53	0011.08	0011.08	0011.08	0011.08	0012.08	0011.08	0010.08	0011.08
	0012.08	0011.08	0011.08	0011.08	0011.08	0010.08	0011.08	0011.08
	0011.08	0010.08	0011.08	0011.08	0012.08	0011.08	0011.08	0011.08
54	0011.08	0011.08	0012.08	0014.08	0015.08	0015.08	0014.08	0013.08
	0014.08	0013.08	0013.08	0013.08	0014.08	0013.08	0012.08	0012.08
	0013.08	0013.08	0012.08	0013.08	0014.08	0013.08	0012.08	0013.08
55	0014.08	0012.08	0013.08	0014.08	0015.08	0014.08	0013.08	0014.08
	III12.08	III12.08	0012.08	0013.08	0012.08	0012.08	0012.08	0013.08
	0013.08	0012.08	0012.08	0012.08	0012.08	0012.08	0011.08	0012.08
56	0011.08	0011.08	0011.08	0012.08	0012.08	0012.08	0012.08	0012.08
	II21.08	II21.08	0012.08	0012.08	0011.08	0012.08	0012.08	0013.08
	0013.08	0013.08	0013.08	0013.08	0012.08	0011.08	0011.08	0011.08
57	0011.08	0012.08	0012.08	0011.08	0011.08	0011.08	0011.08	0011.08
	0011.08	0012.08	0013.08	0014.08	0013.08	0013.08	0013.08	0013.08
	0013.08	0013.08	0012.08	0012.08	0013.08	0012.08	0012.08	0013.08
58	0013.08	0012.08	0009.08	0008.08	0007.08	0008.08	0010.08	0014.08
	0014.08	0012.08	0012.08	0012.08	0012.08	0012.08	0012.08	0013.08
	0012.08	0012.08	0012.08	0013.08	0013.08	0012.08	0011.08	0012.08
59	0012.08	0011.08	0012.08	0012.08	0012.08	0011.08	0011.08	0012.08
	0011.08	0011.08	0011.08	0012.08	0011.08	0011.08	0010.08	0011.08
	0005.08	0005.08	0007.08	0010.08	0014.08	0015.08	0014.08	0014.08
60	0013.08	0012.08	0012.08	0013.08	0013.08	0012.08	0012.08	0013.08
	0014.08	0013.08	0013.08	0013.08	0013.08	0012.08	0013.08	0013.08

CEM protocol for U. S. Steel Corp.
Revision: 1.0

STANDARD EMISSIONS REPORT PAGE 6
CEMS ID NO. (+SOURCE ID+ANALYZER ID): 0068910

QUARTER: 4

YEAR: 92

HOUR	1	2	3	4	5	6	7	8
	9	10	11	12	13	14	15	16
	17	18	19	20	21	22	23	24

XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC

DAY

0010.08	0010.08	0010.08	0011.08	0011.08	0010.08	0004.08	0007.08
61	0017.08	0011.08	0010.08	0012.08	0012.08	0011.08	0011.08
	0011.08	0011.08	0011.08	0011.08	0011.08	II21.08	0011.08
	0011.08	0011.08	0011.08	0011.08	0012.08	0012.08	0011.08
62	0011.08	0012.08	0011.08	0011.08	0011.08	0012.08	0014.08
	0012.08	0011.08	0012.08	0013.08	0011.08	0011.08	II21.08
	0012.08	0012.08	0014.08	0014.08	0011.08	0013.08	0012.08
63	0013.08	0012.08	0013.08	0013.08	0013.08	0012.08	0013.08
	0013.08	0013.08	0014.08	0014.08	0012.08	0012.08	0012.08
	0012.08	0012.08	0013.08	0013.08	0012.08	0011.08	0012.08
64	0013.08	0013.08	0013.08	0013.08	0012.08	0012.08	0011.08
	0010.08	0011.08	0012.08	0013.08	0012.08	0012.08	0012.08
	0011.08	0012.08	0012.08	0013.08	0012.08	0011.08	0012.08
65	0011.08	0010.08	0011.08	0012.08	0012.08	0012.08	0013.08
	0013.08	0012.08	0013.08	II21.08	0012.08	0012.08	0013.08
	0013.08	0014.08	0014.08	0013.08	0012.08	0013.08	0014.08
66	0013.08	0013.08	0013.08	0014.08	0013.08	0014.08	0017.08
	0014.08	0013.08	0014.08	0015.08	0013.08	0014.08	0015.08
	0012.08	0012.08	0013.08	0014.08	0014.08	0014.08	0013.08
67	0014.08	0014.08	0015.08	0014.08	0014.08	0014.08	0014.08
	0013.08	0013.08	0014.08	II21.08	0015.08	0014.08	0013.08
	0014.08	0014.08	0015.08	0014.08	0014.08	0014.08	0014.08
68	0014.08	0014.08	0014.08	0014.08	0014.08	0014.08	0015.08
	0014.08	0014.08	0014.08	0016.08	0015.08	0014.08	0014.08
	0014.08	0014.08	0014.08	0015.08	0014.08	0014.08	0016.08
69	0014.08	0013.08	0013.08	0014.08	0014.08	0014.08	0015.08
	0014.08	0013.08	0014.08	0014.08	0014.08	0013.08	0014.08
	0013.08	0012.08	II18.08	II18.08	III18.08	III18.08	III18.08
70	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08
	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08
	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08
71	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08
	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08
	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08
72	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08
	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08
	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08	II18.08

CEM protocol for U. S. Steel Corp.
Revision: 1.0

STANDARD EMISSIONS REPORT PAGE 7
CEMS ID NO. (+SOURCE ID+ANALYZER ID): 0068910

QUARTER: 4

YEAR: 92

HOUR	1	2	3	4	5	6	7	8
9		10	11	12	13	14	15	16
17		18	19	20	21	22	23	24

XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC

DAY

73	III18.08							
	III18.08							
	III18.08							
74	III18.08							
	III18.08							
	III18.08							
75	III18.08							
	III18.08							
	III18.08							
76	III18.08							
	III18.08							
	III18.08							
77	III18.08							
	III18.08							
	III18.08							
78	III18.08							
	III18.08							
	III18.08							
79	III18.08							
	III18.08							
	III18.08							
80	III18.08							
	III18.08							
	III18.08							
81	III18.08							
	III18.08							
	III18.08							
82	III18.08							
	III18.08							
	III18.08							
83	III18.08							
	III18.08							
	III18.08							
84	III18.08							
	III18.08							
	III18.08							
85	III18.08							

STANDARD EMISSIONS REPORT PAGE 8

CEMS ID NO. (+SOURCE ID+ANALYZER ID): 0068910

QUARTER: 4

YEAR: 92

HOUR	1	2	3	4	5	6	7	8
	9	10	11	12	13	14	15	16
	17	18	19	20	21	22	23	24

XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC XXXX.PC

DAY

III18.08								
III18.08								
86	III18.08							
III18.08								
III18.08								
87	III18.08							
III18.08								
III18.08								
88	III18.08							
III18.08								
III18.08								
89	III18.08							
III18.08								
III18.08								
90	III18.08							
III18.08								
III18.08								
91	III18.08							
III18.08								
III18.08								
92	III18.08							
III18.08								
III18.08								
III18.08								

CALIBRATION ERROR CHECK RESULTS (%):

ID

LO

MD

HI

PROCESS CODES (PC):

01= CHANGING FUELS	04= SHUTDOWN	07= CLEAN CONTROL EQUIP.
02= CONTROL EQUIP. MALF.	05= CHANGING OPERATING LEVEL	08= NORMAL OPERATION
03= STARTUP	06= CLEAN PROCESS EQUIP.	09= OTHER

MONITORING CODES (MC) (XXXX=IIMC if invalid):

10= REQUIRED ADJUSTMENT NOT MADE	16= PRIMARY ANALYZER MALFUNCTION
11= EXCESS DRIFT PRIMARY ANALYZER	17= ANCILLARY ANALYZER MALFUNCTION
12= EXCESS DRIFT ANCILLARY ANALYZER	18= DATA HANDLING SYSTEM MALFUNCTION
13= PROCESS DOWN	19= SAMPLE INTERFACE MALFUNCTION
14= RECALIBRATION	20= CORRECTIVE MAINTENANCE
15= PREVENTIVE MAINTENANCE	21= OTHER

TO THE BEST OF MY KNOWLEDGE, THE INFORMATION IN THIS REPORT REPRESENTS TRUE AND ACCURATE DATA.

XXXX = PPM FOR HCL, SO₂, CO, NO_x


%X100 FOR O₂, C.E., SO₂R SIGNED _____

HCLR, OPACITY



DEG FOR TEMPERATURE TITLE _____

APPENDIX D System Design & Flow Diagrams

C.1. Distance Between Stacks = 53'-6"



T. O. S. EL. 950'-0




3' SAMPLE LINE MUST BE SUPPORTED
HORIZONTAL RUNS MUST HAVE A MINIMUM
OF A 5:1 DROP RATIO TO PREVENT LOW
SPOTS WHERE MOISTURE CAN COLLECT.
REFER TO INSTALLATION INSTRUCTIONS.

STACK PROBE AND TEST PORTS MUST BE MOUNTED
A MINIMUM OF 1/2 STACK DIAMETERS FROM THE
FLUE GAS INTRODUCTION POINT.

(9'-0 i.d.)

T.O. Inlet
EL. 927'-0

FLUE GAS




EL. 879'-0


Boiler No. 1 Stack

Ener tec, Inc.	SL ROUTE
811 West Fifth St.	
Lansdale, Pa. 19446	
(215) 362-0966	
Cust : U.S. Steel - Clairton Works	
Date : 09/21/94 Proj : P901-P12	
TITLE Analyzer Cabinet to Stack	
SAMPLE LINE ROUTING	
Rev II 9/27/94 Rev	
Rev	Rev

T. O. S. EL. 950'-0



Energetec, Inc.	St. Route
811 West Fifth St.	
Lorsdale, Pa. 19446	
(215) 362-0966	
Cost : U. S. Steel	Clifton Works
Date : 09/21/94	Proj : 190-p12
TITLE Analyzer Cabinet to Stack	
SAMPLE LINE ROUTING	
Rev. 11 09/27/94	Rev
Rev	Rev



APPENDIX E Equations and calculations

F Calculations for Emissions

1. Mass Emission Calculations

Method 19 & 20 are used to calculate the mass emission output for CO (lb/MMBTU), CO (lb/hr), NOx (lb/MMBTU) and NOx (lb/hr).

This document contains several calcuations needed to calculate a quantitative measurement of an emission.

The references for these calcuations are found in 40CFR60 Appendix A. Method 19 and 20.

2. Conversion factor(s) used to determine Concentration (C_e)

From	To	Multiply by
ppm NOx	lb/scf	1.194×10^{-7}

3. Dry Fuel factor(s) F_d (Method 19, table 19-1) :

Fuel (F_d)	dscf per MMBTU
Natural gas	8,710
Number 2 oil	9,190
Coke oven Gas	Determined on a real time basis from gas analysis
Bituminous	9,780

G Thermal input:

Using the fuel input flow rate and the fuel heat content factor, the "Thermal Input" TI (MMBTU/hr) factor can be calculated.

The units are Standard Cubic Feet (SCF), Million Btu's (MMBtu's) and Heating Value measured as MMBtu's per SCF of fuel (HHV).

The two fuels used are natural gas and #2 fuel oil. Their high heating values (HHV) are:

Fuel	HHV
Natural gas	1,040 Btu/SCF
Number 2 oil	140,000 Btu/Gallon
Coke Oven Gas	(to be supplied)
Bituminous	9,780

The equations are as follows.

example for natural gas:

$$\begin{aligned} \text{TI (MMBTU/hr)} &= (\text{Fuel flow (dscf/hr)} * \text{HHV}) * 10^6 \text{ MMBTU/BTU} \\ 420 \text{ MMBtu/hr} &= (403,846 \text{ (dscf/hr)} * 1,040) * 10^6 \end{aligned}$$

CEM protocol for U. S. Steel Corp.
Revision: 1.0

1. Calculation from E (lbs/MMBTU) with O₂ diluent:

The references for this calculation are found in 40CFR60 Appendix A, Method 19 equation 19-1 and Method 20 equation 20-6.

example:

$$E \text{ (lbs/MMBTU)} = (C_a * F_a) * [20.9 / (20.9 - O_2)]$$

Assume current O₂ value is 14.0% and NOX value is 18ppm (not corrected for O₂). Also assume the fuel burned is natural gas with a fuel factor of 8710.

$$E \text{ (lbs/MMBTU)} = C_a \quad F_a \quad O_2 \text{ comp.}$$

$$0.05700 \quad (\text{lbs/MMBTU}) = (18\text{ppm} * 1.194 * 10^{-7}) * 8710 * [20.9 / (20.9 - 14.0)]$$

Where:

E (lbs/MMBTU) = Calculated emission rate in lbs/MMBTU

C_a = Pollutant reading in lbs/scf

C_a (for NOx) = [NOx (ppm) * 1.194 * 10⁻⁷]

F_a = Fuel factor (from table)

2. Calculation for E (lbs/hr):

$$E \text{ (lbs/hr)} = E \text{ (lbs/MMBTU)} * TI \text{ (MMBTU/hr)}$$

3. Combination of two fuels:

Using the previously defined TI calculation on two or more different fuels. A combined fuel factor can be determined.


$$F_{comb} = \frac{(TI(\text{Fuel 1}) * (\text{Fuel 1 factor}) + TI(\text{Fuel 2}) * (\text{Fuel 2 factor}) + \dots)}{(TI(\text{Fuel 1}) + TI(\text{Fuel 2}) + \dots)}$$

CEM protocol for U. S. Steel Corp.
Revision: 1.0

APPENDIX H Oxygen Analyzer Manufacturer Specifications

SERVOMEX 1400B LIGHT INDUSTRIAL GAS ANALYSER

Servomex
LEADERS IN GAS ANALYSIS



FEATURES

- Paramagnetic Oxygen and Infrared Transducers
- 19" Rack, Panel Mount and Bench-Top Cases
- Voltage and Current Outputs

BENEFITS

- Suitable for a wide range of applications
- Meets User's configuration requirements
- Interfaces with the user's data recording device

Introduction to 1400B Series

The Servomex 1400B Series meets the light industrial market's requirement for a moderately priced, high performance, general purpose analyser.


Servomex offers the 1400B in three user selected case configurations: 19" rack mounting, panel mounting and bench-top. The above picture shows a dual unit 1400B in a 19" rack mounting case.

The 1400B Series features high visibility LED displays, dual linear electrical outputs: 0-1VDC

non-isolated, and 4-20mA isolated, dual concentration alarms and (for non flammable samples) flow alarm all as standard.

A back pressure regulator option is available on standard 1400B analysers to reduce the effects of barometric or sample vent pressure changes when the 1400B is used for measuring high concentrations of oxygen or other gases.

The 1400B Series now offers three types of transducers, each meeting a requirement of the light industrial market:




Magneto-dynamic Paramagnetic Oxygen Transducer

A magneto-dynamic paramagnetic oxygen transducer (shown above) provides excellent accuracy between 0.1 and 100% oxygen, fast response and the capability of measuring oxygen in the presence of hydrocarbons.

Unlike fuel cell oxygen sensors, the Servomex sensor is unaffected by acid gases, cannot be poisoned and has an unlimited life. Since oxygen is one of only a few gases that exhibit paramagnetism (attraction by a magnetic field) this sensor is highly specific to oxygen when measured in a wide variety of background gases.

The paramagnetic oxygen transducer is maintained above ambient temperature to increase temperature stability.


The 1400B is also available in a version suitable for the analysis of oxygen in flammable samples.



providing increased reliability and reduced maintenance by elimination of moving parts.

For increased measurement stability, the cell is heated and temperature controlled to 60°C.

Single-Beam, Dual Wavelength Infrared Transducer



New Single-Beam, Single Wavelength Infrared Transducer

Servomex offers a full range of new single-beam, single wavelength IR transducers for CO₂ analysis in non-flammable gases (See diagram).


The wide choice of full scale ranges ensures that an IR transducer can be chosen which gives maximum sensitivity and accuracy for the user's application. Other gases will be added to this new transducer's capabilities.

A sealed, pulsed, infrared source and narrow bandpass filter replace the traditional chopper motor and dual filters used in most conventional IR benches. This reduces the unit's cost while

A single-beam, dual wavelength IR transducer (shown above) is offered for the analysis of gases other than CO₂ and for CO₂ in flammable and toxic samples. Common measurements with this transducer include CH₄, CO, solvents, and SF₆. The transducer has excellent long term stability and high rejection of common mode errors introduced by obscuration of the cell end windows.

The user may select a full scale range that fits his application.

Options offered with this bench are dual ranges and hard piping for flammable gas analysis.



Magneto-dynamic Paramagnetic Oxygen Transducer

A magneto-dynamic paramagnetic oxygen transducer (shown above) provides excellent accuracy between 0.1 and 100% oxygen, fast response and the capability of measuring oxygen in the presence of hydrocarbons.

Unlike fuel cell oxygen sensors, the Servomex sensor is unaffected by acid gases, cannot be poisoned and has an unlimited life. Since oxygen is one of only a few gases that exhibit paramagnetism (attraction by a magnetic field) this sensor is highly specific to oxygen when measured in a wide variety of background gases.

The paramagnetic oxygen transducer is maintained above ambient temperature to increase temperature stability.


The 1400B is also available in a version suitable for the analysis of oxygen in flammable samples.

New Single-Beam, Single Wavelength Infrared Transducer

Servomex offers a full range of new single-beam, single wavelength IR transducers for CO₂ analysis in non-flammable gases (See diagram).

The wide choice of full scale ranges ensures that an IR transducer can be chosen which gives maximum sensitivity and accuracy for the user's application. Other gases will be added to this new transducer's capabilities.


A sealed, pulsed, infrared source and narrow bandpass filter replace the traditional chopper motor and dual filters used in most conventional IR benches. This reduces the unit's cost while



providing increased reliability and reduced maintenance by elimination of moving parts.

For increased measurement stability, the cell is heated and temperature controlled to 60°C.

Single-Beam, Dual Wavelength Infrared Transducer



A single-beam, dual wavelength IR transducer (shown above) is offered for the analysis of gases other than CO₂ and for CO₂ in flammable and toxic samples. Common measurements with this transducer include CH₄, CO, solvents, and SF₆. The transducer has excellent long term stability and high rejection of common mode errors introduced by obscuration of the cell end windows.

The user may select a full scale range that fits his application.

Options offered with this bench are dual ranges and hard piping for flammable gas analysis.

TYPICAL APPLICATIONS

	O ₂	CO ₂	CO	CH ₄	FREONS	SOLVENTS AND HYDROCARBONS	SF ₆
Respiratory Physiology	●	●					
Exercise Machines	●	●					
Lung Function Research	●	●					
Diving Bells	●	●					
Decompression Chambers	●	●					
Agriculture/Horticulture	●	●			●		
Food/Plant Growing	●	●			●		
Green Houses	●	●			●		
Fruit Stores	●	●					
Mushroom Farms	●	●					
Animal Husbandry	●	●					
Off Gases in Silos/ Storage Chambers	●	●					
Food Industry	●	●					
Food Packaging	●	●					
Food Manufacture	●	●					
Fermentation Processes	●	●					
Others							
Synthetic Fibres						●	
Plastic Films						●	
Landfill Gas		●					
Ventilation Control	●	●			●		
Refrigeration							
Exhaust Emission Testing	●	●	●		●		
Heat Treatment	●	●	●		●		
Gas Manufacture/Mixing	●	●	●		●		
Pharmaceutical/ Fine Chemicals	●	●	●		●		
Bio-Engineering	●	●	●				
Switchgear Manufacture	●	●	●				
Combustion Processes	●	●	●				
Research Laboratories	●	●	●	●	●		●


SPECIFICATIONS				INFRARED			
Parameter	Conditions / Comments	O ₂ FLS	O ₂ , STD	CO, STD	NonFlam, NonTox	SPX	Flam/Tox
Performance							
Measurement Principle		Magno-dynamic	Paramagnetic	Single beam, single wavelength IR	Single beam, dual wavelength IR		
Repeatability	at the 1V output, constant conditions for 10°C change within the specified ambient temperature range	±0.1% O ₂	±0.1% O ₂	±1% FS	±1% FS		
Temperature Coefficient	a) inlet pressure & flow in specified range b) at point when flow alarm trips	±0.05% O ₂	±0.3% reading typically less than 10 sec	±1% FS	±2% FS	±4% reading	
Response Time (90%)	maximum error from best straight line	approximately 50 sec	±3% reading	typically 30 sec	typically 30 sec		
Linearity		±0.1% O ₂	directly proportional	0.15% reading/lat	±1% FS		
Effects of Atmospheric Pressure	a) direct vent to atmosphere b) nominal with back pressure regulation typical at 20°C ambient temperature	0.02% reading/lat	0.03% reading/lat	0.03% reading/lat	0.03% reading/lat	0.03% reading/lat	
Warm-up Time				1 hour			
Outputs							
Digital Reading	3½ digit green LED display + overrange	0.0 to 100.0% O ₂		display resolution optimised for specified range			
1V Output		non-isolated, nominal o/p impedance 470 ohms		isolated o/p impedance < 1 ohm			
4-20mA (Isolated)		maximum load 600 ohms		maximum load 500 ohms			
Ranges		2 ranges from 5, 10, 20, 25, 50, 100% User Configurable		dual range (optional)			
Alarms				Specified at time of order			
Flow Fail	change over relay contacts rated 1A/110VAC or 1A/28VDC non-inductive	none	dedicated SPCO relay	See below	none		
Concentration Level	change over relay contacts rated 1A/110VAC or 1A/28VDC non-inductive	2 SPCO relays can be configured to high or low alarms, operating over the full scale of the unit		a 4-pole changeover relay configurable to one or more of: flow, concentration or instrument failure alarms			
Local Indication	red LED lamps flash when alarm active	individual concentration level & flow alarm indication					
Materials Exposed to Sample		stainless steel					
	Viton/fluorocarbon rubber						
	platinum, nickel, borosilicate glass	sapphire					
	bonded glass fibre, nylon, neoprene, gold on silver, brass, monel, polypropylene, ruby, acetyl resin	epoxy resin					
	copper, PVC, PVDF, berillium copper	CaF ₂ or sapphire	silicone rubber				

Additional with Back Pressure Option

Parameter	Conditions / Comments	O ₂ FLS	O ₂ STD	CO ₂ STD	SPX	SPX
<u>Environmental</u>						
Operating Ambient Temperature	a) Single or dual case b) Fitted into bench-top case	-0.45°C (32-113°F) -0.40°C (32-104°F)	-0.45°C (32-113°F) -0.40°C (32-104°F)		0-40°C (32-104°F) 0-35°C (32-95°F)	
Sensor / Transducer Temperature	nominal control temperature	50°C	50°C	60°C		
Storage Temperature			-20°C to +70°C (-4°F to 158°F)			
Relative Humidity		0-100% non-condensing			5 to 85% non-condensing	
AC Power Supply		88-264V 47-63Hz, 45VA max.			120 or 240VAC±10% 48 to 62Hz 30VAmax	
EMC	Designed for compliance with:	EN 50022 (1987) CLASS A for conducted interference and radiated electric field				
<u>Sample Requirements</u>	Vibration Condition	'		Protect from excessive vibration		
Inlet Pressure / Flow Rate	Refer to flow schematics overleaf.		Clear, dry gas with dew point at least 5°C below ambient temperature			
Flammable Gases	See schematic a groups B, C, D T3 group IIIC, T3		See schematics b & c		See schematic d groups C and D, T4 groups II and IIIB, T4	
Filtering	ISA-S12.12 (1984) BS5345, Part 1 (1976)			Not Applicable		
SPX & FLS require external 0.6 micron filter	located at the rear of the unit	3.2mm ^{1/8} " O.D. stub	0.6 micron replaceable	0.6 micron		
<u>Physical Characteristics</u>	Gas Connection Case	6.4mm (1/4 inch) O.D. tube stub suitable for 1/4 inch compression fittings				
Overall Dimensions	a) Description b) Classification a) Double case 4U b) Single case 4U c) Bench-top case d) Back pressure option single unit double unit bench unit	Steel and aluminum, finished in epoxy powder paint IP20 (IEC 529) when fitted in the 19 inch rack case 178mm high x 483mm wide x 380mm deep 182mm high x 256mm wide x 420mm deep 228mm high x 520mm wide x 400mm deep depth becomes 460mm approx.				
Weight		5.5kg (12lb) typical 12kg (26lb) typical 20kg (44lb) typical				
Unit Identification	Rear panel serial no.	1421B NNN	1420B NNN	1415B NNN	1410B NNN	1411B NNN
	The Company reserves the right to alter the specification without prior notice.					

FLOW SCHEMATICS

(a) Sample Vent Direct to Atmosphere (FLS)



Flow:

User limited/controlled to 250ml min⁻¹ max.

Flow Effect:

Less than 0.5% of O₂ reading change for flow change from 50 to 250 ml min⁻¹


Inlet pressure:

Typically 0.3kPag (3cmWG) at 200ml min⁻¹

Atmospheric pressure effect:

Oxygen reading is directly proportional to barometric pressure

(b) Sample Vent Direct to Atmosphere (STD)



Flow:

Typically 1 to 6l min⁻¹, dependent upon inlet pressure

Inlet pressure:

7 to 70kPag (1 to 10psig)

Inlet pressure effects:

Pressure changes over the entire inlet pressure range will cause the reading to change by less than 0.2% O₂ or 1% of CO₂ reading


Barometric pressure effects:

O₂ reading is directly proportional to barometric pressure; CO₂ changes by 1.5% reading per kPa

Atmospheric (vent) pressure range:

CO₂ units 90 to 110kPa(0.9 to 1.1 bara); O₂ units 80 to 110kPa(0.8 to 1.1 bara)

(c) Sample Vent Via Back Pressure Regulator (STD)



Inlet pressure:

Typically 120 to 140kPa (to achieve inlet flow within the range 1 to 2 l min⁻¹)

Flow effects:

Flow changes over the specified range will change the O₂ reading by less than 0.2%O₂ and the CO₂ by less than 1% of the CO₂ reading


Barometric pressure effects:

Reading changes by typically 0.25% of reading per kPa (0.025% of reading per mbar)

Atmospheric (vent) pressure:

108kPa max.

(d) SPX Vent Direct to Atmosphere (SPX)



Flow:

User regulated within the range 0.1 to 1.0 lmin⁻¹

Atmospheric (vent) pressure:


90 to 110kPa

Atmospheric pressure effect:


Approx. 1.5% reading per kPa

MOUNTING DETAILS

Double Unit Case



Single Unit Case (supplied with handles and rubber feet)




ALL DIMENSIONS IN $\frac{inches}{mm}$

1400 ORDERING CODE

Analyser 1400B4

Type Specification	Special Applications			SPX
	Flammable Sample		FLS	
	Standard	STD		
F1 Left hand unit	O ₂ unit (standard) O ₂ unit (flammable) CO ₂ unit 1% FS CO ₂ unit 2% FS CO ₂ unit 5% FS CO ₂ unit 10% FS CO ₂ unit 25% FS CO ₂ unit 50% FS CO ₂ unit 100% FS Special IR Non Flammable/Non Toxic Sample Special IR Flammable/Toxic Sample Blank panel	10 11 23 24 25 26 27 28 29 99	-11 91 92	
F2 Right hand unit	Single unit O ₂ unit (standard) O ₂ unit (flammable) CO ₂ unit 1% FS CO ₂ unit 2% FS CO ₂ unit 5% FS CO ₂ unit 10% FS CO ₂ unit 25% FS CO ₂ unit 50% FS CO ₂ unit 100% FS Special IR Non Flammable/Non Toxic Sample Special IR Flammable/Toxic Sample Blank panel	00 10 23 24 25 26 27 28 29 99	00 10 11 91 92 99	00 10 11
F3 Back pressure regulator	None Left hand and single units Right hand unit Right and left hand units	0 1 2 3	0 0	0
F4 Instrument case	Double unit case Single unit case Double bench-top case	1 2 3	1 2 3	1 2 3
F5 Manual (operator)	English French } German Reserved	1 2 3	1 2 3	1 2 3
F6 Manual (service)	None English French } German Reserved	0 1 2 3	0 1 2 3	0 1 2 3
F7 Supply voltage	240 VAC ±10%, 48 to 62 Hz 120 VAC ±10%, 48 to 62 Hz	+	+	1 2

Example:



Notes: 1) SPX units must be approved by Servomex applications. Refer to Servomex for details of gases and ranges measurable with SPX units.
 2) Flammable and non-flammable sample units may not be paired in the same SPX analyser.



Certified to ISO 9001 (1987)

Servomex
LEADERS IN GAS ANALYSIS

Servomex plc, Jarvis Brook, Crowborough, East Sussex, TN6 3QJ, England
 Servomex Company, Inc., 90 Kenny Place, Norwood, MA 02062, USA

Servomex S.A.R.L., 8 Rue Proudhon, B.P. 50, 93012 La Plaine St Denis, France

Servomex B.V., PO Box 406, 2700 AK Zoetermeer, Stephensstraat 20, 2723 RN Zoetermeer, Netherlands

Servomex Asia/Pacific Ltd, 5F-4, No. 328 Chang Chun Road, Taipei, Taiwan, R.O.C.

CNTIC-Servomex Technical Centre, No 2 Sheng Gu Zhuang, Chaoyang Area Beijing, China, PO Box 1432, Beijing, Post Code 100029

Scottish Anglo Environmental Protection Ltd, Tees Offshore Base, Dockside Road, South Bank, Middlesbrough, Cleveland TS6 6UZ, England

□ (44) 893 652181	Fax (44) 893 652293
□ (01) 617-769-7710	Fax (01) 617-769-2824
□ (33) 1-48 20 82 22	Fax (33) 1-48 20 82 38
□ (31) 79-41 71 41	Fax (31) 79-42 88 18
□ (886) 2-712 6831	Fax (886) 2-712 0852
□ (85) 1-426-8911, 2101	Fax (85) 1-426-8894
□ (44) 842 457771	Fax (44) 842 458183


CEM protocol for U. S. Steel Corp.
Revision: 1.0

APPENDIX I NOx Analyzer Manufacturer Specifications

MODEL 42 H

CHEMILUMINESCENCE NO-NO₂-NO_x ANALYZER



For Continuous
Source Gas Monitoring



PERFORMANCE IS DESIGNED IN!

- MICROPROCESSOR BASED
- NINE (9) FIELD SELECTABLE RANGES
- CONTINUOUS OUTPUTS ON EACH CHANNEL
- EXTERNAL (OIL-LESS) VACUUM PUMP
- COMPACT SIZE
- PUSH BUTTON CALIBRATION
- USER FRIENDLY DIAGNOSTICS
- MANUAL AND AUTOMATIC MODES
- FRONT PANEL DISPLAY
- SELECTABLE TIME CONSTANTS

MODEL 42H NO-NO₂-NO_x ANALYZER



MODEL 42H SPECIFICATIONS

Ranges:	0-10, 20, 50, 100, 200, 500, 1000, 2000, 5000ppm	Linearity:	$\pm 1\%$ Full Scale
Noise:	25ppb	Sample Flow Rate:	25 cc/min./with Bypass 2 SCFH
Detection Limit:	50ppb	Vacuum:	28.5" Hg
Zero Drift (24-Hours):	50ppb	Power Requirements:	500 watts, 115 \pm 10 volts, 220 \pm 20 volts, 50/60 Hz
Span Drift (24-Hours)	$\pm 1\%$ Full Scale	Physical Dimensions:	17" (W) x 8 $\frac{3}{4}$ " (H) X 23" (D)
Rise Fall Times: (0-90%)	2.5 seconds NO Mode 5.0 seconds NO _x Mode	Weight:	70 pounds, including pump
		Outputs:	Selectable 0-10mv, 100mv, 1v, 5v, 10v, (optional) 4-20MA Isolated or RS-232

The Model 42H is Thermo Environmental Instruments' latest addition to its line of microprocessor based instrumentation. The Model 42H is a high level, fast response chemiluminescence instrument for NO, NO₂, and/or NO_x. Typical applications range from automotive exhaust analysis to source or stack measurements.

The Model 42H has full scale outputs from 10ppm to 5000ppm while using only dry air as the ozonator feed. Response times from 0.5 seconds to 300 seconds are available at the user's option.

A twin-headed diaphragm pump eliminates the need for oil changes typical of older analyzers. The unique two-piece reaction chamber construction offers ease in maintenance and service.

As always, Thermo Environmental Instruments is eager to offer assistance with its new Model 42H Chemiluminescence Analyzer. The Model 42H is expected to maintain TEI's position as the industry standard in high level NO_x measurements and applications.


— Easy to Read Display

OPTIONS

- 42-002 — Rack Mounts
- 42-004 — Regulated Bypass System
- 42-005 — 4-20MA Isolated Output
- 42-006 — Pressure Transducer
- 42-007 — Ozone Particulate Filter
- 42-008 — RS-232 Interface
- 42-009 — Permeation Dryer

— Push Button Calibration,
Diagnostics, Ranges
and More

MODEL 42H FLOW DIAGRAM





MODEL 42H: STANDARD CONFIGURATION


The Model 42H standard plumbing configuration is used in applications where ample amount of sample is present. The sample should be at a continuous stable flow. The analyzer is allowed to extract the sample as needed by use of a vented manifold system (atmospheric dump).

MODEL 42H: REGULATED BYPASS SYSTEM OPTION

The regulated bypass system is used when the sample must be transported over a long distance. It is also used when an unstable flow is being provided. The regulated bypass system provides make-up air thru the sample regulator in case of lack of sample to the reaction chamber. This unique feature avoids instrument drift due to pressure changes.



**Installation Drawing.
Including Rack Mount
Slides (Optional)**



**Thermo Environmental
Instruments Inc.**

8 West Forge Parkway
Franklin, MA 02038

Tel: (508) 520-0430
Telex: 200205 THEMO UR

FAX: (508) 520-1460

Printed in the U.S.A. — 6/93 5M

ATTACHMENT

to

"CONTINUOUS EMISSIONS MONITORING PLAN"

"U. S. STEEL CLAIRTON WORKS
NOS. 1 AND 2 BOILERS
FUEL MONITORING STRATEGY"

PREPARED BY

U. S. STEEL CLAIRTON WORKS
CLAIRTON, PA
SEPTEMBER 30, 1994

INTRODUCTION

This report is submitted as an attachment to the Phase I Application submittal for the installation of NOx Continuous Emissions Monitors for the Nos. 1 and 2 Boiler stacks at U. S. Steel Clairton Works. It is the intent of this report to advise the Pennsylvania Department of Environmental Resources (PaDER) of our proposed fuel monitoring strategy for the various fuels burned or may potentially be burned.

IDENTIFICATION OF FUELS:

1. Clean Coke Oven Gas

Clean (desulfurized) coke oven gas is the primary fuel burned on both subject boilers at Clairton Works. Its usage comprises approximately 99% of the total fuel burned on an annual basis on the boilers.

2. Natural Gas

On an intermittent basis or under extreme adverse conditions natural gas is injected into the fuel stream fed to the boilers. This percentage of addition does not exceed 10% of the fuel gas flow at any given time.

3. Coal

Previous conditions existed at both boilers where pulverized coal was the predominant or major source of fuel. This condition has since been modified where coal is only utilized as a fuel under adverse or emergency conditions.

4. Fuel Oil

Under extreme adverse weather and conditions, Clairton Works and U. S. Steel have in the past been subjected to restrictions on usage of the previously mentioned fuels. As a safeguard against this measure Clairton Works would utilize fuel oils as a supplementary fuel fed to the boilers.

FUEL MONITORING STRATEGY

The Clairton Boilers use clean by-product coke oven gas as a primary fuel. Historically, over the past several years, coke oven gas has been used better than 99% of the time. There were some exceptions where natural gas was used as a supplemental fuel. The supplement typically was less than 10% of the fuel volume going to the boilers. These exceptions were due to unusual business or weather conditions.

The 1993-1994 recent severe winter under scored the necessity to have the flexibility of using alternate fuels. The sub-zero temperatures forced the Natural Gas Suppliers to consider curtailing gas supplies to the United States Steel Monongahela Valley steel making complex. If this scenario took place, the Clairton boilers would supplement with a liquid fuel or coal.

It is Clairton's intent to certify the NOx CEM with coke oven gas. However, we wish to maintain the flexibility to use alternate fuels so that if circumstances mandate use of an alternate fuel, we would not be in violation.

COKE OVEN GAS

The fuel factor for coke oven gas is calculated from a process gas chromatographic measurement of 13 coke oven gas components.

Hydrogen	Oxygen
Nitrogen	Methane
Carbon Monoxide	Carbon Dioxide
Ethylene	Ethane
Propylene	Propane
C 4 Hydrocarbons	Benzene
Hydrogen Sulfide	

The analysis is updated twice per hour. The chromatograph is calibrated daily with a certified gas standard.

Coke oven gas flow is measured across an orifice plate with a differential pressure transmitter. The 4 to 20 MA flow signal is transmitted to a continuous recorder and 24 hour integrator panel meter. The flow measurement output is also sent to the CEM process logic controller which uses the information to calculate NOx values. The system is calibrated semi-annually.

NATURAL GAS

The published F Factor for Natural Gas will be used.

Natural gas flow is measured across an orifice plate with a differential pressure transmitter. The 4 to 20 MA flow signal is transmitted to a continuous recorder and 24 hour integrator panel meter. The flow measurement output is also sent to the CEM process logic controller which uses the information to calculate NOx values. The system is calibrated semi-annually.

FUEL OIL

The published F factor for fuel will be used.

Fuel flow is measured by a positive displacement flow meter. The 4-20 MA flow signal is continuously recorded and sent to the CEM PLC for use in calculation of NOx values.

COAL

The published F factor for bitumerous coal will be used.

Coal samples will be stopped belt cross cut. Coal flow is measured by a Merrick weigh belt.

NOx.CEM
WCG/kb-94336

SE

WEDD
DOOR
WICK
WORX

SPECIALIZED ENVIRONMENTAL SERVICES
607 Freedlander Road Wooster, Ohio 44691 (216)262-8877 Fax (216)262-7777

FAX COVER SHEET

Date: _____

To: JACK Withrow / JEFF FADDIS

Company: _____

Fax Phone Number: 412 233 1054

From: Cal Lowe^t

Message: SURPRISE, SURPRISE, SURPRISE

TOTAL NUMBER OF PAGES 4 (INCLUDES COVER SHEET)

If you do not receive this fax in its entirety, please call:

Allegheny County Health Department

COUNTY COMMISSIONERS

Tom Foerster
Chairman

Pete Flaherty

Larry Dunn

Bruce W. Dixon, M.D.
Director



BOARD OF HEALTH

Roy L. Titchworth, M.D.
Chairman
Martin Krauss, O.D.
Vice Chairman

Robert Engel, Esq.
Susanne M. Gallin, Ph.D
Azizi Powell
Msgr. Charles Owen Rice
Frederick Ruben, M.D.
Anthony D. Stagno, Sr.

BUREAU OF ENVIRONMENTAL QUALITY
DIVISION OF AIR QUALITY
301 39th Street
Pittsburgh, Pennsylvania 15201

September 21, 1994

Mr. Gary F. Platek
7-7, Inc.
607 Freedlander Road
Wooster OH 44691

PERMIT NO.: 94-I-0058-P
EQUIPMENT : USS Clairton Works
Peter's Creek Lagoon Remediation
LOCATION : Clairton, PA
ANNUAL OPERATING PERMIT FEE: \$375

NOTICE OF INSTALLATION PERMIT APPROVAL

The subject installation permit has been conditionally approved for the installation of equipment associated with the remediation of the Peter's Creek Lagoon. The installation shall be made in conformity with the plans and specifications which are a part of your application. The installation must be inspected and approved by the Bureau before it is placed into operation (contact W. G. Gilson 578 8135).

The documents that are considered to be part of this installation permit include, but are not necessarily limited to, the following:

- ACHD, DAQ Form AP352 Process permit application, dated 8-3-94
- 7-7, Inc. Permit Submittal Package including:
letter dated August 5, 1994
- 7-7, Inc. Fax dated 8-25-94 - A revision to the August 5, 1994 letter.

Additional conditions of approval are:

1. All equipment actually exposed to the lagoon contents (e.g. roll-off boxes, backhoe bucket, screens, etc.) shall be kept tarped when not in use for a period in excess of two hours.
2. Lagoon material shall not be transferred from container to container on the site.
3. All spillage shall be cleaned up promptly and kept placed in

closed containers until properly disposed of. Proper precautions shall be observed to prevent tracking of lagoon material off the site due to vehicular traffic.

4. The excavation rate shall not exceed any of the following:

10 Tons/hour
40 Tons/day
140 Tons/Week

5. The operating hours shall not exceed six(6) hours on any given day.

6. All excavation operations shall be performed between the hours of 7:00 am and 7:00 pm.

A complete operating permit application shall be submitted within sixty (60) days of achieving full production or one hundred twenty (120) days of start-up, whichever is earlier. When it is determined by the Bureau that the installation complies with all regulations, limitations, and approved installation permit conditions, an operating permit will be issued.

This installation permit shall be kept at the site during the construction period and be made available to Bureau personnel upon request.

Permit Issued by:

DIVISION OF AIR QUALITY

Roger C. Westman
Roger C. Westman
Engineering Section Head

APC USE ONLY

Permit 94-I-505X-? Check No. 597A
 Receipt No. 8-3-94
 Issued _____
 Expires _____
 Fee \$430.00
 Basis

ALLEGHENY COUNTY HEALTH DEPARTMENT

AIR POLLUTION CONTROL

PERMIT - PROCESS

COMPLETION DATE

DATE INSTALLED

INSTALLATION 8/5/94OPERATING

BUSINESS

NAME	ADDRESS
U.S. STEEL	400 STATE STREET CLAIRTON, PA 15025 TAR RECYCLING

OWNER	ADDRESS	PHONE
7-7, INC.	607 FREEDLANDER ROAD WOOSTER, OH 44691 (216) 262-8877	

INSTALLER OR CONTRACTOR	ADDRESS	PHONE
7-7, INC.	607 FREEDLANDER ROAD, WOOSTER, OH 44691 (216) 262-8877	

AUTHORIZED REPRESENTATIVE	TITLE	SIGNATURE	PHONE
GARY P. PLATEK	DIRECTOR OF ENGINEERING	<i>Gary P. Platek</i>	(216) 262-8877

PROCESS	YOUR IDENTIFICATION	PRODUCTION RATE <input checked="" type="checkbox"/>	PEE
TAR EXCAVATION	5084	CHARGING RATE <input type="checkbox"/> 2 1/2-10 TONS/HR.	\$ 430.00

OPERATING TIME	4 HOURS/DAY	7 DAYS/WK.	52 WEEKS/YR.	CONTINUOUS <input type="checkbox"/>	BATCH TIME	
				<input checked="" type="checkbox"/>	1-2	HR.

RAW MATERIALS	TOTAL					
---------------	-------	--	--	--	--	--

MATERIALS PRODUCED	TOTAL					
--------------------	-------	--	--	--	--	--

TAR MATERIALS CONTAINED IN COVERED 20 YD. ROLL-OFF BOXES/100% 10-40 TONS/DAY						
--	--	--	--	--	--	--

FUEL	AMT./HR.	BTU	% ASH	% SULFUR	FUEL	AMT./HR.	BTU	% ASH	% SULFUR
------	----------	-----	-------	----------	------	----------	-----	-------	----------

FUEL	AMT./HR.	BTU	% ASH	% SULFUR	FUEL	AMT./HR.	BTU	% ASH	% SULFUR
------	----------	-----	-------	----------	------	----------	-----	-------	----------

GAS CLEANER	GAS FLOW	SCFM	INLET TEMP.	* F	DUST LOADING	EFFICIENCY	PRESSURE DROP
-------------	----------	------	-------------	-----	--------------	------------	---------------

N/A					GR./SCF.	%	"W.G.
-----	--	--	--	--	----------	---	-------

GAS CLEANER	GAS FLOW	SCFM	INLET TEMP.	* F	DUST LOADING	EFFICIENCY	PRESSURE DROP
-------------	----------	------	-------------	-----	--------------	------------	---------------

N/A					GR./SCF.	%	"W.G.
-----	--	--	--	--	----------	---	-------

EMISSION ANALYSIS	PARTICULATE	SO ₂	CO	NO _x	HC	OTHER
-------------------	-------------	-----------------	----	-----------------	----	-------

POTENTIAL					0.61 LBS/HR	
-----------	--	--	--	--	-------------	--

FINAL					0.18 LBS/HR	
-------	--	--	--	--	-------------	--

STACK HEIGHT	STACK AREA	EXHAUST FLOW	TEMPERATURE	DUST LOADING
--------------	------------	--------------	-------------	--------------

N/A	FT.	N/A	SQ. FT.	N/A	ACFM	AMBIENT	* F	N/A	GR./SCF.
-----	-----	-----	---------	-----	------	---------	-----	-----	----------

EMISSION BASIS	MFG. DATA <input type="checkbox"/>	EMISSION FACTORS <input type="checkbox"/>	STACK TEST <input type="checkbox"/>	COMPANY ESTIMATE <input type="checkbox"/>	SUBMIT SUPPORTING DATA FOR METHOD USED.			
----------------	------------------------------------	---	-------------------------------------	---	---	--	--	--

NEAREST SEE1) HEIGHT	DISTANCE	COST OF EQUIPMENT			COST OF GAS CLEANING			
----------------------	----------	-------------------	--	--	----------------------	--	--	--

BUILDING: AT 18	30 FT. ABOUT 2000 FT.	\$ 5,000.			SYSTEM \$ N/A			
-----------------	-----------------------	-----------	--	--	---------------	--	--	--

DRAWING NO'S.	FIG. 1, REGIONAL LOCATION PLAN - 8/5/94, FIG. 2, LAGOON AREA 8/5/94							
---------------	---	--	--	--	--	--	--	--

AND TITLES	REMARKS							
------------	---------	--	--	--	--	--	--	--

1) MUNICIPAL WASTE WATER TREATMENT BLDG.								
--	--	--	--	--	--	--	--	--

2) SEE ATTACHED COMMENTS OF 8/5/94								
------------------------------------	--	--	--	--	--	--	--	--

REVIEWED BY	TITLE	DATE	REVIEWED BY	TITLE	DATE
<i>Gary P. Platek</i>	100-5084	9/20/94	<i>Gary P. Platek</i>	PERMIT APPROVED BY	9-21-94

REVIEWED BY	TITLE	DATE	REVIEWED BY	TITLE	DATE
			<i>Jerry L. Washington, Eng. Sc., P.E.</i>		9-21-94