



WESTON SOLUTIONS, INC.  
205 CAMPUS DRIVE  
EDISON, NEW JERSEY 08837  
732-417-5800 • FAX: 732-417-5801

*The Trusted Integrator for Sustainable Solutions*

May 13, 2014

Mr. Andrew Fessler, Work Assignment Manager  
U.S. Environmental Protection Agency  
290 Broadway - 18th Floor  
New York, NY 10007-1866

**Document Control No.: 2222-2F-BLWR**

**Subject: QAPP Addendum**  
**Work Assignment No. 2222, Canadian Radium & Uranium Corp. SR**  
**Contract No.: EP-S5-06-04, TDD No.: S05-0013-1307-009**

Dear Mr. Fessler:

Weston Solutions, Inc. (WESTON®) is pleased to submit the Quality Assurance Project Plan (QAPP) Addendum for the sediment sampling associated with the Canadian Radium & Uranium Corp. site. WESTON personnel plan to collect sediment samples on May 15, 2013. If you have any questions, please contact me at (732) 417-5814.

Very truly yours,

WESTON SOLUTIONS, INC.

A handwritten signature in black ink that reads "Denise Breen". The signature is written in a cursive, flowing style.

Denise Breen  
Assistant Project Scientist

enclosure

cc:

C. Romano, EPA (w/o enclosure)  
G. Gilliland, WESTON (w/o enclosure)  
Site file

**Site Name/Project Name:** Canadian Radium & Uranium Corp.  
**Site Location:** 103-105 Kisco Avenue, Mt. Kisco, Westchester County, NY 10549  
**Operable Unit:** 00  
**Title:** Site-Specific UFP QAPP  
**Revision Number:** 01  
**Revision Date:** May 13, 2014

## **TASK SUMMARY**

In order to characterize the surface water pathway, Region 2 Site Assessment Team (SAT) will collect sediment samples along the surface water pathway. Sediment sampling will include the collection of six sediment samples, including one field duplicate sample. Sediment sample collection depth will be 0-6 inch intervals below sediment surface. Sediment samples will be collected in an upstream direction, beginning with the furthest downstream location. Background samples will be collected from locations suspected to not have been impacted by the historic on-site activities. One rinsate blank will be collected to document adequate decontamination of non-dedicated sampling equipment.

Sediment will be collected using a petite ponar dredge or hand augers and homogenized in dedicated, disposable aluminum trays with disposable polyethylene scoops prior to insertion into the sample containers. The sediment samples will be analyzed by an off-site laboratory for Target Analyte List (TAL) metals analysis including mercury; Isotopic Thorium and Isotopic Uranium by alpha spectroscopy; radioisotopes including Radium-226 and Radium-228 by gamma spectroscopy; and stable isotopic lead.

Region 2 SAT will collect locational data using Global Positioning System (GPS) technology and collect photo documentation of the sampling activities.

The site work is scheduled for May 15, 2014.

### **Decontamination:**


Decontamination of non-disposable sampling equipment, including petite ponar dredge and/ hand augers, will be performed before and after the sampling event and between sample locations, and will consist of the following steps:

1. Soap and water scrub.
2. Tap water or deionized (DI) water rinse.
3. Steam-clean with DI water.
4. Air dry.
5. Screen with radiation meter for residual contamination.
6. Foil wrap if not immediately re-used.

### **Quality Control Tasks:**

The sediment samples will be collected for definitive data QA objective. One field duplicate will be collected, and one sediment sample will be designated for MS/MSD analysis, as applicable.


Figure 1  
Proposed Sample Location Map



LEGEND:	
	Proposed Sediment Sample Location
	Approximate Footprint of the Former Canadian Radium & Uranium Corp. Property
PROJECT:	
Canadian Radium & Uranium Corp.	
CLIENT NAME:	
EPA	

TITLE:	
Proposed Sediment Sample Location Map Canadian Radium & Uranium Corp. 103/105 Kisco Avenue Mount Kisco, NY 10549	
DRAWING NUMBER:	15064
FIGURE #:	1

DRAWN BY:	J. Lynes
REVIEWED BY:	D. Breen
PROJECT MANAGER:	D. Breen
SCALE:	1" = 150'
DATE:	May 2014



**TABLE 1**  
**ANALYTICAL SERVICES**  
**CANADIAN RADIUM & URANIUM CORP. SITE SR SEDIMENT SAMPLING**

Sample Type	Number of Samples	Matrix	Sampling Device	Sample Container <sup>(1)</sup>	Sample Preservation	Technical Holding Time <sup>(2)</sup>	Laboratory Analyses <sup>(3)</sup>
Sediment Soil	5 (includes one duplicate and one MS/MSD)	Sediment (Low/Med Concentration)	Dedicated aluminum tray/plastic scoop;  Petite Ponar dredge/sediment hand auger	2-oz. glass jar	Cool to 4° C	6 months	TAL Metals incl. Hg SW846 6010C/ 7471B ST-MT-0003, ST-MT-0007
				4-oz. glass jar	None	6 months	Isotopic Thorium and Isotopic Uranium by alpha spectroscopy HASL 300 ST-RD-0210
				16-oz. plastic jar	None	6 months	Radioisotopes by gamma spectroscopy (includes Radium-226 and Radium-228) HASL 300 ST-RD-0102
				4-oz. glass jar	Cool to 4°C	6 months	Stable Isotopic Lead ICP-MS
Rinsate Blanks <sup>(4)</sup>	1	Aqueous (Low/Med Concentration)	Spigot	250 mL Plastic	HNO <sub>3</sub> , Cool to 4° C	6 months	TAL Metals incl. Hg SW846 6010C/ 7470A ST-MT-0003, ST-MT-0005
				2 L Plastic	HNO <sub>3</sub>	6 months	Isotopic Thorium and Isotopic Uranium by alpha spectroscopy HASL 300 ST-RD-0210
				2 L Plastic	HNO <sub>3</sub>	6 months	Radioisotopes by gamma spectroscopy (includes Radium-226 and Radium-228) HASL 300 ST-RD-0210
				1 L Plastic	HNO <sub>3</sub>	6 months	Radium-226/228 SW846 9315/9320 ST-RD-0403

**TABLE 1 (CONTINUED)**  
**ANALYTICAL SERVICES**  
**CANADIAN RADIUM & URANIUM CORP. SITE SR SEDIMENT SAMPLING**

Sample Type	Number of Samples	Matrix	Sampling Device	Sample Container <sup>(1)</sup>	Sample Preservation	Technical Holding Time <sup>(2)</sup>	Laboratory Analyses <sup>(3)</sup>
				500 mL Plastic	HNO <sub>3</sub> , Cool to 4° C	6 months	Stable Isotopic Lead ICP-MS

<sup>(1)</sup> = Sample containers are certified clean by the supplier.

<sup>(2)</sup> = Technical holding times are calculated from the date of sample collection.



**TABLE 2**  
**SAMPLE DESCRIPTIONS/RATIONALE**  
**CANADIAN RADIUM & URANIUM CORP. SITE SR SEDIMENT SAMPLING**

SAMPLE NUMBER	DESCRIPTION/RATIONALE
2222-SD01 (MS/MSD)	Sediment sample to be collected from sample location SD01, for waste source characterization, depth: 0 to 6 inches; Matrix Spike/Matrix Spike Duplicate (MS/MSD) for Quality Assurance/Quality Control (QA/QC) purposes.
2222-SD02	Sediment sample to be collected from sample location SD02, located downstream, for waste source characterization, depth: 0 to 6 inches.
2222-SD03	Sediment sample to be collected from sample location SD03, located downstream for waste source characterization, depth: 0 to 6 inches
2222-SD04	Sediment sample to be collected from sample location SD04, located at the PPE, for waste source characterization, depth: 0 to 6 inches
2222-SD05	Sediment sample to be collected from sample location SD05, located upstream for waste source characterization, depth: 0 to 6 inches
2222-SD06	Duplicate sediment sample for QA/QC purposes, from a sample location to be determined in the field.
2222-RIN01	Rinsate blank (Petite) for QA/QC purposes.

Temperature Blanks will be placed in each cooler with samples shipped to the laboratory.

**TABLE 3**  
**SAMPLE ANALYSES, BOTTLE TYPES, AND PRESERVATIVES**  
**CANADIAN RADIUM & URANIUM CORP. SITE SR SEDIMENT SAMPLING**

SAMPLE NUMBER	SAMPLE BOTTLES	ANALYSIS	PRESERVATION
2222-SD01 (MS/MSD)	1 4oz glass jar	Isotopic Thorium and Isotopic Uranium by alpha spectroscopy	Ice – cool to 4°C
	1 16oz plastic jar	Radioisotopes by gamma spectroscopy (includes Radium-226 and Radium-228)	
	1 2oz glass	TAL Metals	
	1 4oz glass jar	Stable Isotopic Lead	
2222-SD02	1 4oz glass jar	Isotopic Thorium and Isotopic Uranium by alpha spectroscopy	Ice – cool to 4°C
	1 16oz plastic jar	Radioisotopes by gamma spectroscopy (includes Radium-226 and Radium-228)	
	1 2oz glass	TAL Metals	
	1 4oz glass jar	Stable Isotopic Lead	
2222-SD03	1 4oz glass jar	Isotopic Thorium and Isotopic Uranium by alpha spectroscopy	Ice – cool to 4°C
	1 16oz plastic jar	Radioisotopes by gamma spectroscopy (includes Radium-226 and Radium-228)	
	1 2oz glass	TAL Metals	
	1 4oz glass jar	Stable Isotopic Lead	
2222-SD04	1 4oz glass jar	Isotopic Thorium and Isotopic Uranium by alpha spectroscopy	Ice – cool to 4°C
	1 16oz plastic jar	Radioisotopes by gamma spectroscopy (includes Radium-226 and Radium-228)	
	1 2oz glass	TAL Metals	
	1 4oz glass jar	Stable Isotopic Lead	
2222-SD05	1 4oz glass jar	Isotopic Thorium and Isotopic Uranium by alpha spectroscopy	Ice – cool to 4°C
	1 16oz plastic jar	Radioisotopes by gamma spectroscopy (includes Radium-226 and Radium-228)	
	1 2oz glass	TAL Metals	
	1 4oz glass jar	Stable Isotopic Lead	



**TABLE 3 (CONTINUED)**  
**SAMPLE ANALYSES, BOTTLE TYPES, AND PRESERVATIVES**  
**CANADIAN RADIUM & URANIUM CORP. SITE SR SEDIMENT SAMPLING**

SAMPLE NUMBER	SAMPLE BOTTLES	ANALYSIS	PRESERVATION
2222-SD06	1 4oz glass jar	Isotopic Thorium and Isotopic Uranium by alpha spectroscopy	Ice – cool to 4°C
	1 16oz plastic jar	Radioisotopes by gamma spectroscopy (includes Radium-226 and Radium-228)	
	1 2oz glass	TAL Metals	
	1 4oz glass jar	Stable Isotopic Lead	
2222-RIN01	5 1-Liter plastic	Isotopic Thorium and Isotopic Uranium by alpha spectroscopy	HNO <sub>3</sub> , Cool to 4 <sup>0</sup> C
		Radioisotopes by gamma spectroscopy (includes Radium-226 and Radium-228)	
	1 250-mL plastic	TAL Metals	
	1 500-ml plastic	Stable Isotopic Lead	

**Addendum Title and Approval Page****Title:** Site-Specific UFP Quality Assurance Project Plan (QAPP)**Site Name/Project Name:** Canadian Radium & Uranium Corp.**Site Location:** 103-105 Kisco Avenue, Mt. Kisco, Westchester County, NY 10549**Revision Number:** 01**Revision Date:** Not Applicable

EPA Region 2

**Lead Organization**

Denise Breen

Weston Solutions, Inc.

205 Campus Dr., Edison, NJ 08837

Email: [Denise.Breen@westonsolutions.com](mailto:Denise.Breen@westonsolutions.com)**Preparer's Name and Organizational Affiliation**

November 19, 2013

**Preparation Date (Day/Month/Year)**

Site Project Manager:



Signature

Denise Breen/Weston Solutions, Inc.

**Printed Name/Organization/Date**

QA/Technical Reviewer:



Signature

Gerald V. Gilliland/Weston Solutions, Inc.

**Printed Name/Organization/Date**EPA Region 2 Work Assignment Manager  
(WAM):

Signature

Andrew Fessler/EPA Region 2

**Printed Name/Organization/Date**

Other EPA Approval Signature:

Signature

**Printed Name/Organization/Date**