















Attachment 1

Carbon Injection Daily Log

July 28, 2008 0900 hours to August 13, 2008 0525 hours



8 days  
900 pounds

4.6875 pounds per hour

8.5 days  
900 pounds

4.411765 pounds per hour

## Carbon Injection Daily Log

COPY

<u>Date</u>	<u>Time</u>	<u>Crew</u>	<u>Bag Wt.</u>	<u>Comments</u>
7-28	09:00	D	900	new Bag
7-28	1720	B	822	
7-29	5	D	803	
7-30	1630	B	781	
7-30	05:00	A	704	
	17:15	C	670	
7-31	05:00	A	695	
	17:15	C	595	
8-1	5	D	549	
8-1	1715	B	468	
8-2	5	D	409	
8-3	17:15	B	180	
8-4	05:30	C	194	
L	17:00	A	747	
8-5	05:30	C	59	
L	09:30	C	1001	New bag
L	17:00	A	942	
8-6	5	D	897	
8-7	5	D	805	
8-7	17:20	B	700	
8-8	05:30	C	689	
8-8	16:15	A	633	
		A	651	

32-9612

**SCOPY**

[illegible]

## Attachment 2

### Veolia's Mercury Spikes Solution Methods

Mercury Test Solution trace number 2101-59-17 (see Log 2101 page 59 lines 17-20)

Using a 2 liter graduated cylinder, added 10 liter of di water to a clean Nalgene Carboy.

Added 2.5 liters of Nitric Acid (trace metal grade) to the Carboy.

Tared a 100 ml beaker. And Into the tared beaker, weighed 26.200 grams of 98% mercury II nitrate hydrate.

Placed the 26.200g mercury into the carboy containing the nitric acid solution.

Filled a 2 liter graduated flask with DI water to the 2000 ml mark.

Rinsed the 100ml beaker 5-6 times with water and added the rinsate to the carboy.

Poured the remaining water into the carboy.

Added another 10.5 liter to the carboy for a final volume of 25 L

Mixed the solution several times though out the day.

Pulled 2 aliquot of 50 ml each to be tested for concentration at outside lab.

After the concentration of the solution was determined by the outside Lab, Jeff Mueller told me the volume to place in 50 ml cent tubes.

A 10 ml repipet dispenser was used to place the required number of mls into the centrifuge tubes.

Chris

Hope This is what you wanted.

Jeff

1101-1193

High Mercury Solution  
 Reagent # 2101-60-13  
 Vial prep 8/20/08 FHF / JS

MERCURY NITRATE SPIKE VIALS - Target Volume: 23 milliliters

Personnel

*Tracy Fennel*

*Jim Smallwood*

Date *8-20-08*

Shift *1st*

Pump calibrated *Yea*

VIAL #	VOLUME (ml)	VIAL #	VOLUME (ml)	VIAL #	VOLUME (ml)	VIAL #	VOLUME (ml)
1101	23	1126	23	1151	23	1176	23
1102	23	1127	23	1152	23	1177	23
1103	23	1128	23	1153	23	1178	23
1104	23	1129	23	1154	23	1179	23
1105	23	1130	23	1155	23	1180	23
1106	23	1131	23	1156	23	1181	23
1107	23	1132	23	1157	23	1182	23
1108	23	1133	23	1158	23	1183	23
1109	23	1134	23	1159	23	1184	23
1110	23	1135	23	1160	23	1185	23
1111	23	1136	23	1161	23	1186	23
1112	23	1137	23	1162	23	1187	23
1113	23	1138	23	1163	23	1188	23
1114	23	1139	23 <i>FHF 8/20/08</i>	1164	23	1189	23
1115	23	1140	23	1165	23	1190	23
1116	23	1141	23	1166	23	1191	23
1117	23	1142	23	1167	23	1192	23
1118	23	1143	23	1168	23	1193	23
1119	23	1144	23	1169	23	1194	
1120	23	1145	23	1170	23	1195	
1121	23	1146	23	1171	23	1196	
1122	23	1147	23	1172	23	1197	
1123	23	1148	23	1173	23	1198	
1124	23	1149	23	1174	23	1199	
1125	23	1150	23	1175	23	1200	

Metals- Standard Preparation

Concentration(ug/ml) / Name	Conc / Starting Material	Trace Number	Amount	Final Volume(ml)	Prep Date	Exp. Date	Analyst
1 ICP ICU STD	5000 ug/ml As, Cd, Cr, Pb 2000 ug/ml Ba	2032-49-20	50 uL	100 ml	6-19-08	6-19-08	JS
2	Conc HNO <sub>3</sub>	2032-44-29	6 ml	↓	↓	↓	↓
3	Conc HCL	2032-32-6	2 ml	↓	↓	↓	↓
4	D. H <sub>2</sub> O	-	SQ	↓	↓	↓	↓
5 0.109 ug/ml Hg	1,000 ug/ml Mercury	2032-49-18	100 ml	100 ml	6/23/08	6/23/09	KS
6	37% Conc HCL	2032-32-6	10 ml	↓	↓	↓	↓
7	D. H <sub>2</sub> O	-	SQ	↓	↓	↓	↓
8 1.0 ug/ml Hg	1,000 ug/ml Hg	2032-49-18	0.1 ml	100 ml	6/23/08	6/23/09	KS
9	37% Conc HCL	2032-32-6	10 ml	↓	↓	↓	↓
10	D. H <sub>2</sub> O	-	SQ	↓	↓	↓	↓
11 10 ug/ml Hg	1,000 ug/ml Hg	2032-49-18	1.0 ml	100	6/23/08	6/23/09	KS
12	37% Conc HCL	2032-32-6	10 ml	↓	↓	↓	↓
13	D. H <sub>2</sub> O	-	SQ	↓	↓	↓	↓
14 0.109 ug/ml Hg	10 ug/ml	2101-59-11 2032-	1.0 ml	100	6/23/08	6/23/09	KS
15	37% Conc HCL	2032-32-6	10 ml	↓	↓	↓	↓
16	D. H <sub>2</sub> O	-	SQ	↓	↓	↓	↓
17 ~0.058 % Hg Sol	98% H <sub>2</sub> (NO <sub>3</sub> ) <sub>2</sub> ·H <sub>2</sub> O	2184-2-28	26.200 g	25 L	6/23/09	6-23-09	FHF
18 Conc To Be Confirmed	37% Conc Nitric	2032-45-1	2.5 L	↓	↓	↓	↓
19 By Instruction	D. H <sub>2</sub> O	-	SQ	↓	↓	↓	↓
20 Analysis	-	-	-	-	-	-	-
21 ~1.76% Hg Sol	98% H <sub>2</sub> (NO <sub>3</sub> ) <sub>2</sub> ·H <sub>2</sub> O	2184-2-29 2184-2-30	91.00 g	3 L	6/23/09	6/23/09	FHF
22	37% Conc Nitric	2032-32-13 H <sub>2</sub> SO <sub>4</sub> 32-13	300 ml	↓	↓	↓	↓
23	D. H <sub>2</sub> O	-	SQ	↓	↓	↓	↓
24 ICP ICU	SAME AS LINE 1-4	-	100 ml	100 ml	7-10-08	7-11-08	JS
25 ICP ICU	SAME AS LINE 1-4	-	100	100	7-23-08	7-23-08	JS
26 ICP ICU	SAME AS LINE 1-4	-	100	100	7-30-08	7-31-08	JS
27 0.002 ug/ml Hg	0.209 ug/ml Hg	2101-58-29	1 ml	100 ml	7/30/07	9/13/07	KS
28	Conc HNO <sub>3</sub>	2032-49-20	3 ml	↓	↓	↓	↓
29	Conc HCL	2032-44-29	1 ml	↓	↓	↓	↓
30	D. H <sub>2</sub> O	-	SQ	↓	↓	↓	↓

Metals- Standard Preparation

Concentration(ug/ml) / Name	Conc / Starting Material	Trace Number	Amount	Final Volume(ml)	Prep Date	Exp. Date	Analyst
0.02 ug/ml Hg	0.2 ug/ml Hg	2101-58-29	5 ml	50 ml	7/30/08	9/13/08	KS
I	Conc H <sub>2</sub> O <sub>2</sub>	2032-44-29	3 ml	I	I	I	I
I	Conc HCL	2032-32-6	1 ml	I	I	I	I
I	D. H <sub>2</sub> O		SQ	I	I	I	I
High Conc Hg Solution	98% Mercury Nitrate hydrate	2184-3-11 2184-3-12 2184-2-30	121.004 g	7 L	8/5/08	—	FHF
I For MALT TESTING	Nitric Acid	2032-44-28	800 ml	I	I	I	I
I	DI H <sub>2</sub> O	—	SQ	I	I	I	I
ICP ICV STD	5000 ug/ml As, Cd, Cr, Pb, 2000 ug/ml Br	2032-49-20	50 ul / 50	100 ul	8-6-08	8-6-08	JS
I	Conc HNO <sub>3</sub>	2032-44-29	6 ml	I	I	I	I
I	Conc HCL	2032-32-6	2 ml	I	I	I	I
I	DI H <sub>2</sub> O	—	SQ	I	I	I	I
ICP ICV STD	SAME AS LINES 8-11	8-11	—	100 ul	8-8-08	8-8-08	JS
High Conc Hg Solution	98% Mercury Nitrate hydrate	2184-3-13	43.004 g	2.5 L	8-11-08	—	FHF
BATCH 2 For	Nitric Acid	2032-44-28	250 ml	I	I	I	I
MALT TESTING	D. H <sub>2</sub> O	—	SQ	I	I	I	I
ICP ICV STD	5000 ug/ml As, Cd, Cr, Pb, 2000 ug/ml Br	2032-49-20	50 ul	100 ml	8/13/08	8/13/08	KS
I	Conc Nitric Acid	2032-44-29 2032-49-20	6 ml	I	I	I	I
I	Conc HCL	2032-32-6 2032-44-28	2 ml	I	I	I	I
I	D. H <sub>2</sub> O	—	SQ	I	I	I	I
ICP ICV STD	same as Lines 16-19	16-19	KS	8/13/08	8/13/08	8/13/08	KS
ICP ICV STD	SAME AS LINES 16-19	16-19	—	100 ml	8-21-08	8-21-08	JS
22							
23							
24							
25							
26							
27							
28							
29							
30							



# Standards/Reagents Receipt

Trace Number	Material	Source	Lot#	Date Received	Exp. Date	Use	Received By
2184-2-1	P-Xylene	Fisher	073181	4/21/08	—	LAB	RWH
2184-2-2					—		
2184-2-3					—		
2184-2-4	Methanol		076559		—		
2184-2-5					—		
2184-2-6					—		
2184-2-7					—		
2184-2-8					—		
2184-2-9					—		
2184-2-10					—		
2184-2-11					—		
2184-2-12	Mineral Oil, Light	Fisher	072798	5/5/08	—	Lab	RWH
2184-2-13	Hexanes		080013	5/5/08	—	Lab	RWH
2184-2-14					—		
2184-2-15					—		
2184-2-16					—		
2184-2-17					—		
2184-2-18					—		
2184-2-19					—		
2184-2-20					—		
2184-2-21	PHI Buffer	Fisher	074117	6/3/08	02/2009	LAB	RWH
2184-2-22	Sodium Hydroxide	Fisher	076254	6/10/08	—	LAB	
2184-2-23					—		
2184-2-24					—		
2184-2-25					—		
2184-2-26					—		
2184-2-27					—		
2184-2-28	Mercury II Nitrate	AIFA Aesar	E 225010	6/23/07	—	MACR Testing	RWH
2184-2-29					—		
2184-2-30					—		

Reviewed By:

Date:

### Standards/Reagents Receipt

Trace Number	Material	Source	Lot#	Date Received	Exp. Date	Use	Received By
1 2184-3-1	Hexanes	Fischer	080013	7-3-08	—	LAB	RWH
2 2184-3-2	I	I	I	I	—	I	I
3 2184-3-3	I	I	I	I	—	I	I
4 2184-3-4	I	I	I	I	—	I	I
5 2184-3-5	I	I	I	I	—	I	I
6 2184-3-6	I	I	I	I	—	I	I
7 2184-3-7	I	I	I	I	—	I	I
8 2184-3-8	I	I	I	I	—	I	I
9 2184-3-9	30% Hydrogen Peroxide	Fisher	082548	8/4/08	—	Lab-Metals	RWH
10 2184-3-10	I	I	I	I	—	I	I
11 2184-3-11	Mercury II Nitrate hydrate ACS 98% Stock # 14497	AIFA Aesar	E225010	8/5/08	—	MULT TESTING Hg Sol	FHF
12 2184-3-12	I	I	I	I	—	SHIPPED DATE 7/8/08	I
13 2184-3-13	Mercury (II) Nitrate hydrate ACS 98% Stock 14497	AIFA Aesar	E225010	8/8/08	—	MULT TESTING	FHF
14 2184-3-14	Hexanes	Fisher	083197	8/19/08	—	Lab-PCB'S	RWH/mt
15 2184-3-15	I	I	I	I	—	I	I
16 2184-3-16	I	I	I	I	—	I	I
17 2184-3-17	I	I	I	I	—	I	I
18							
19							
20							
21							
22							
23							
24							
25							
26							
27							
28							
29							
30							

Reviewed By:

Date:

## Fisherbrand\* 50mL Graduated Polypropylene Tube

Skirt extends beyond the bottom of the tube so it can stand without support

- ▶ Freestanding with conical bottom
- ▶ Made from durable polypropylene for excellent chemical resistance
- ▶ Features molded graduations in 2.5mL increments up to 10mL, and 5mL increments from 10 to 50mL
- ▶ Sterile
- ▶ Supplied with blue plastic plug-seal caps



O.D. x L	Capacity	Cat. No.	Case of 500
29.5 x 113.8mm	50mL	14-375-150	188.66



### LOOKING FOR RACKS?

Fisherbrand\* Vinyl-Coated Wire Racks are made of heavy-gauge steel for excellent chemical resistance. For details and ordering information, see the Racks section.

## Corning\* 15mL Graduated Tubes

Available with leakproof ergonomic, leak-resistant caps

- ▶ With conical bottoms
- ▶ Available with your choice of clear polypropylene (PP) or polyethylene terephthalate (PET)
- ▶ Sterile, certified RNase-/DNase-free and nonpyrogenic
- ▶ High speed RCF rating up to 12,000xG
- ▶ CentriStar\* caps provide a revolutionary plug feature, wider knurls, and roll-over edge design to improve grip; easy-on, easy-off thread design; and a flat top with matte finish for easy marking
- ▶ Original plug-seal caps also available
- ▶ Large white marking spot and black printed graduations



05-538-51

### ORDERING INFORMATION:

Tubes are packaged in a bulk pack resealable zip lock (sleeve) or a convenient polyfoam rack (07-200-611, also available separately).

O.D. x L	Max. RCF	Material	Packaging	Mfr. No.	Cat. No.	Case of 500
<b>Tubes with CentriStar Caps</b>						
17 x 119mm	12,000xG	Clear PP	50/rack	430790	05-538-59A	198.72
17 x 119mm	12,000xG	Clear PP	25/sleeve	430791	05-538-59B	191.73
<b>Tubes with Plug-Seal Caps</b>						
17 x 119mm	12,000xG	Clear PP	50/rack	430052	05-538-53D	208.36
17 x 119mm	12,000xG	Clear PP	25/sleeve	430766	05-538-53F	199.10
17 x 119mm	3600xG	PET	50/rack	430055	05-538-51	212.38
17 x 119mm	3600xG	PET	25/sleeve	430053	05-538-51A	199.10


## Corning\* 50mL Graduated Plastic Tubes

Available with leakproof CentriStar\* caps

- ▶ With conical bottoms
- ▶ Available in your choice of clear polypropylene (PP) or polyethylene terephthalate (PET)
- ▶ Sterile, certified RNase-/DNase-free and nonpyrogenic
- ▶ High speed RCF rating up to 15,500xG
- ▶ CentriStar caps provide a revolutionary plug feature, wider knurls, and roll-over edge design to improve grip; easy-on, easy-off thread design; and a flat top with matte finish for easy marking
- ▶ Original plug-seal caps also available
- ▶ Large white marking spot and black printed graduations

### ORDERING INFORMATION:

Tubes are packaged in a bulk pack resealable zip lock (sleeve) or a convenient polyfoam rack (available separately, 07-202-531)  
Universal rack for holding both 15mL and 50mL tubes is also available (07-200-610)



05-538-55

O.D. x L	Max. RCF	Material	Packaging	Mfr. No.	Cat. No.	Case of
<b>Tubes w/CentriStar Caps</b>						
28 x 115mm	15,500xG	PP	25/sleeve	430829	05-538-60	500/258.34
28 x 115mm	15,500xG	PP	25/rack	430828	05-5268	500/272.14
28 x 115mm	15,500xG	PP	25/rack	4558	07-203-510†	300/168.00
<b>Tubes w/Plug-Seal Caps</b>						
28 x 115mm	15,500xG†	PP	25/rack	430290	05-538-55†	500/282.61
28 x 115mm	15,500xG†	PP	25/sleeve	430291	05-538-55A†	500/268.28
30 x 114mm	3600xG	PET	25/rack	430304	05-538-49	500/322.55

† Thermo Scientific® IEC BR50 (05-375-79) rotor supports these tubes to 25,000xG.

## Thermo Scientific\* Universal and Low-Profile Repipet\* Dispensers

Handy, accurate Pyrex\* glass reagent diluters

Safely handle most any reagent, including concentrated acids (except hydrofluoric) and alkalis, chlorinated hydrocarbons. Only glass and fluorocarbon resin come in contact with reagent. Repipet dispensers dispense 20 times/min.

- ▶ Lift plunger to fill, depress to deliver
- ▶ Accuracy: 1%
- ▶ Reproducibility: 0.1%

### Universal Diluters


- ▶ Fit common screw-cap reagent bottles with openings greater than 3/4" I.D. (19mm)
- ▶ Ideal for blood chemistries and biological and microbiological analyses
- ▶ Come with three sets of caps and washers to fit 28-430, 33-430, and 38-430 bottle threads (other sizes available on request)
- ▶ Features magnifying indicator, integral air filter, and 24" (61cm) of PTFE resin tubing (metal indicator for diluters available on special order)
- ▶ Without bottle

### Low-Profile Diluters

- ▶ Wide-mouth, 1000mL reservoir containers have Halar\* fluorocarbon resin caps with two openings: one for dispenser; other to allow refilling (no need to remove dispenser)
- ▶ Bottle designed for solid support, less chance of breakage
- ▶ Low profile allows easy fit into shelf space and refrigerators
- ▶ Amberized glass
- ▶ PTFE resin outlet tip
- ▶ With air intake tubulation

### NOTE:

PTFE resin caps may distort with autoclaving or use of strong solvents.



13-687-22

## Brinkmann\* Bottle-Top Dispensers

With a broad array of adapters and accessories available, dispensers are designed to fit almost any size reagent bottle for almost any application

Brinkmann fixed- and adjustable-volume bottle-top dispensers shown with reservoirs (not supplied); some with accessory extended discharge tube or drying tube.



Fixed- and adjustable-volume dispensers cover a volume range of 0.1 to 100mL. Deliver even the harshest reagents safely. Choose standard models or ChemSaver models, which recirculate the reagent used during the priming step. Accuracy  $\pm 0.5\%$ , precision  $\leq 0.1\%$ .

- ▶ Clear plastic sleeve surrounds the glass cylinder to protect the user from chemical hazards should the cylinder break
- ▶ Support sleeve surrounds the discharge tubing to restrict its movement and provide an additional safety barrier during dispensing
- ▶ Entire assembly rotates 360° to allow the user to obtain the safest dispensing position and reach the volume adjustment at all times
- ▶ Autoclavable without having to loosen valves or remove individual parts
- ▶ Easy to use and maintain
- ▶ Unique "wiping" piston seal of PTFE resin eliminates the problems of piston swelling/freezing common to conventional floating-piston dispensers
- ▶ Reagent is wiped out of the cylinder with each stroke to prevent the buildup of residue that can lead to malfunction
- ▶ Grooved, positive-lock volume adjustment ensures precision and prevents accidental setting changes during use
- ▶ Unique telescoping filling tube adjusts to fit the reagent bottle, without cutting
- ▶ Filling valve, tubing, and even the piston can be individually replaced, to minimize repairs and downtime
- ▶ ChemSaver models eliminate reagent waste through the use of a recirculating safety valve that diverts reagent used in priming back into the reservoir bottle
- ▶ ChemSaver valve can be closed to prevent unintended flow of reagent
- ▶ ChemSaver models can be user-calibrated for fine adjustment of volume when working with viscous or high-density solutions

### INCLUDES:

All dispensers are supplied with a certificate of calibration to aid in GLP compliance. Standard dispensers come in fixed- as well as adjustable-volume styles, ChemSaver dispensers, in adjustable-volume style only.

Volume	Grad.	Mfr. No.	Cat. No.	Each
<b>Repipet Dispensers</b>				
<b>Universal</b>				
1mL	0.01mL	3001AU	13-687-18	377.00
5mL	0.05mL	3005AU	13-687-19	387.00
10mL	0.10mL	3010AU	13-687-20	380.00
20mL	0.25mL	3020AU	13-687-21	410.00
50mL	0.50mL	3050AU	13-687-22	494.00
100mL	1.00mL	3100AU	13-687-23	617.00
<b>Low-Profile</b>				
1mL	0.01mL	3001AL	13-687-31	389.00
5mL	0.05mL	3005AL	13-687-33	390.00
10mL	0.10mL	3010AL	13-687-35	390.00
20mL	0.25mL	3020AL	13-687-37	406.00
50mL	0.50mL	3050AL	13-687-39	497.00

Ordering Table Contd. on next page.

## Pyrex® Vista® Reusable Glass Tubes with Phenolic Screw Caps

Supplied with deep-form phenolic caps to facilitate handling and sealing after autoclaving

- ▶ Blue enamel marking spot provides excellent surface for pencil notations
- ▶ Pencil marks are easily erased

### ORDERING INFORMATION:

Replacement caps available.

07-250-130 Series

Capacity	O.D. x L	Mfr. No.	Cat. No.	Pack of 50	Case of 4 Pk.
9mL	13 x 100mm	70825-13	07-250-133	54.06	157.81
11mL	16 x 100mm	70825-16	07-250-134	74.45	217.37
15mL	16 x 125mm	70825-16X	07-250-135	74.45	217.37
20mL	16 x 150mm	70825-16XX	07-250-136	74.45	217.37
25mL	20 x 125mm	70825-20	07-250-137	91.05	265.83
34mL	20 x 150mm	70825-20X	07-250-138	102.75	299.99
55mL	25 x 150mm	70825-25	07-250-139	114.95	335.62

## Kimax® Reusable Tube with Brown Graduations

With permanently fused brown scale

- ▶ 10mL tube is graduated every 0.1mL from 0.5 to 10mL
- ▶ Reinforced bead

10-310-200

O.D. x L	Mfr. No.	Cat. No.	Each
16 x 125mm	46350-10	10-310-200	35.63

## Kimax® Reusable Borosilicate Glass Tubes

Feature fire-polished top rim and uniform wall thickness for maximum heat transfer and chemical resistance

- ▶ Culture tubes made from KG-33 glass

### COMPLIANCE:

Designed from ASTM\* specification E982, Type IV requirements

### With Plain End

Without marking spot

14-925 Series

O.D. x L	Mfr. No.	Cat. No.	Pack off
6 x 50mm	45060 650	14-925B	72/19.08
13 x 100mm	45060 13100	14-925E	72/35.14
16 x 150mm	45060 16150	14-925J	72/44.18
19 x 150mm	45060 19150	14-925K	72/44.18
25 x 150mm	45060 25150	14-925M	72/82.34
25 x 200mm	45060 25200	14-925N	24/30.12

\* Also available in alternate quantity. Contact your Fisher Scientific Customer Service Representative for details. Or visit our Web site.

### With Plain End and Marking Spot

With durable white ceramic marking spot on each tube

14-923 Series

O.D. x L	Mfr. No.	Cat. No.	Pack off
10 x 75mm	45048-1075	14-923B	72/35.14
12 x 75mm	45048-1275	14-923C	72/35.14
13 x 100mm	45048-13100	14-923D	72/37.16
15 x 125mm	45048-15125	14-923F	72/44.18
16 x 100mm	45048-16100	14-923H	72/46.19
16 x 125mm	45048-16125	14-923J	72/44.18
16 x 150mm	45048-16150	14-923K	72/53.22
18 x 150mm	45048-18150	14-923L	72/59.25
20 x 150mm	45048-20150	14-923W	576/392.87
25 x 150mm	45048-25150	14-923P	72/113.47
25 x 250mm	45048-25250	14-923R	144/398.73

\* Also available in alternate quantity. Contact your Fisher Scientific Customer Service Representative for details. Or visit our Web site.

We use 14-950-B

A 25ml Tube unable to locate quickly

### Attachment 3

#### Rotary Kiln Incinerator Unit 4 Waste Profile and Analytical Data for Test Feeds

**UNIT 4 TEST CONDITIONS**  
**August, 2008**

Chlorine – lbs/hr	<u>250 – 300</u>
Hexachloroethane (6.9 lbs/bag in solids)	
Drum Solids – lbs/hr — Zexel	<u>900 -1000 (23 – 24 lbs/charge)</u>
Lead Nitrate (2.6 lbs/bag)	
Mercuric Nitrate (23 ml/bag)	
Bulk Solids — Zexel + Sand	<u>4000 - 5000</u>
High Btu Liquids (Tank 312) – lbs/hr	<u>300 -600</u>
Low Btu Liquids (Direct Inject) – lbs/hr	<u>300 -600</u>
Chromic Acid (250 lbs/hr)	

Containerized Solids – Zexel Carveout Area	pages 2-4
Bulk Solids – Zexel Carveout Area + sand (ash content)	pages 2-4
Low Btu Liquids (DI) – PQ Corp	page 5
High Btu Liquids – Bayer Crop Science, Veolia, Cambrex Charles City	page 7      pages 8-9      pages 10-11
Metal Feeds (Spike + Waste Feeds)	
Mercury – 0.025 lbs/hr	
Lead – 66 lbs/hr	
Chromium – 45 lbs/hr	

Biochem 312  
page 6

One Condition, Three Runs Only

Report: R7008  
DATE: 07/03/08

ONYX ENVIRONMENTAL SERVICES, LLC  
WASTE PROFILE SUMMARY

Version 06.04

TWI-032206

SELLING REGION LAB - MRL

BUSINESS: ZEXEL CARVEOUT AREA  
DEPT.....  
ADDRESS 1: 2121 S IMBODEN COURT  
ADDRESS 2:  
CITY/ST.: DECATUR IL 62521  
CONTACT...: RONALD W. ELDER

NUMBER.....: 143-8-669  
PHONE.....: 314/682-1540  
EXPIRES.....: 02/08/10  
STATUS.....: APPR FOR SERV  
FEDERAL EPA ID: ILR000150359  
STATE EPA ID...: 1150155433  
EPA STATUS.....: CHK RESTRICT  
SALES OFFICE...: TWI

WASTE NAME: SOLIDIFIED SLUDGE  
PROCESS GENERATING WASTE: SITE REMEDIATION  
SHIP. NAME: HAZARDOUS WASTE, SOLID, N.O.S  
ADDL. DESC: (TRICHLOROETHYLENE, TETRACHLOROETHENE, CIS-1,2-DICHLOROETHEN

CHEMICAL COMPOSITION

CIS-1,2-DICHLOROETHENE  
STYRENE  
TETRACHLOROETHANE  
TRICHLOROETHENE  
WATER  
SOIL  
NON-TRI CHEMICALS  
CORN COB ABSORBANT

MIN	- MAX	UNIT DESCRIPTION
		110000 UG/KG
		360000 UG/KG
		417000 UG/KG
		115000 UG/KG
0	10	%
70	80	%
0	20	%

METALS	EP TOX/TCLP
Arsenic as As	< 5.0 mg/l
Cadmium as Cd	< 1.0 mg/l
Lead as Pb	< 5.0 mg/l
Mercury as Hg	< .2 mg/l
Selenium as Se	< 1.0 mg/l
Chromium Hex	
Nickel as Ni	
Thallium as Tl	

PHYSICAL CHARACTERISTICS

Physical State....: Solid  
Flash Point.....: N/A CL  
pH.....: 05.0 - 09.0  
Color.....: BROWN  
Odor.....: NONE  
Layers.....: Single Layer  
Specific Gravity..: 0.000  
Free Liquids.....: 0 - 10  
Cyanides.....: < 5 PPM TOTAL  
Sulfides.....: > 3 PPM TOTAL  
PCB's.....: ppm, Regulated by 40 CFR 761:  
Phenolics.....: < 10 PPM  
% Taxable.....: DOT UN/NA NBR: NA3077  
Treatment Codes...: T07  
CRQ RPT QTY.....: Material Class:  
EPA Permit.....: EXP:  
Hazard Class.....: 9  
State Codes.....: 090001  
Benzene .....: NESHAP:  
Packing Group.....: III  
Process Codes.....: BSH  
Cert of Distrct Rq:

Federal Codes: D039 D040

HANDLING

NEO. GREY GLOVES

SARANEX

TYPE C RESPIR CONST FLOW

INDEX/BLUE NITRILE (INNER GLOVE)

DOT PROPERTIES

Inhalation: 2

Dermal: 2

Oral: 2

Flammable: 0

Health: 0

SUMMARY

Waste Type  
Form Code

B519  
1



# Waste Tracking System

File Inventory Print Approvals Chemist Receiving Laboratory Tank Farm Process Planning Window Billing Help

## Profile Approvals

Profile

Number  
032206

Retrieve

Edit Mode

Update

Cancel

Exit

Last Updated By:

meredith

Incoming Analysis Required

Process Code(s)

BSH

DOT Hazard Class

9

☐ PCB Analysis Required

☐ Lab: Run metals as specified below.

☐ Dioxin Precursor Analysis Required

☐ Visual Inspection Only

☐ Visual Inspection: Glove Box / Hooded Feeder

☐ Inspect Outer Drum Only - Do Not Open - Comments Below

☐ Receiving: Verify Original Consumer Label and Write Label Info on PDW

☐ Decant Sample Required

☒ Sample Required

Analytical Comments

Reference Tracking # / Sample # for analysis:

☐ Dioxin Precursor analysis results below site action levels

☐ No additional analysis required

☐ Run on each load

☐ Analysis supplied by generator - See Tech. Manager File

☐ PCB analysis to be determined upon visual inspection of waste

Additional Comments: 12 samples were pulled from 4 rolloff boxes, and the average nu

Sample Characteristics

Viscosity

☐ L ☐ M ☐ H ☒ N/A

pH Screen

☐ <2 ☒ 2-12.5 ☐ >12.5

Spec. Gravity

BTU/lb

% Chloride

Flashpoint

☐ <73 ☐ <140 ☐ >140 ☒ N/A

Metals

ppm

AS 3.4

BE 0.1

CD 198

CR 1193

HG 1.03

K 0

NA 0

PB 206

ASH 36.68

Profile and Handling Comments

Profile Review for Appendix WAP-C Constituents by: KMERDITH on 2/11/2008

☐ Water Reactive - avoid contact with moisture

☐ Contains Cyanides - DO NOT mix with pH < 6

☐ Benzene NESHAP controls required

☐ Poison Inhalation Hazard ☐ Contains Acrylonitrile ☐ Contains Hydrofluoric Acid

☐ Reactive Category

4.

### Sample Required

Date: 7/17/2008

Profile #: 032206

Generator: ZEXEL CARVEOUT AREA

Descript: SOLIDIFIED SLUDGE

Process Code(s): BSH

**Drum Storage Compatibility**

Profiled DOT Hazard Class 9

***P = Pass F = Fail***

8A \_\_\_\_\_ 8B \_\_\_\_\_ 4/5 \_\_\_\_\_

Sample Number	284638	000231228VES
---------------	--------	--------------



284638

Drum Rep / Comp		BULK/0		284638		Profile		Conform		Date	Initials
Free Liquid (%)		0						Yes	No	07/17/08	AJ
Pumpable		NO									
Layers/Phases -% Ea.		100									
Color		brown - dark									
Turbidity		N/A									
Viscosity		N/A				N/A			X		
Physical State		solid									
Water Miscibility		Part Floats Sinks									
Add. Description		sludge									
Water Reactivity		No RXN									
Radiation Screen		=BKG				=BKG			X		
Flam. Pot. Screen		NEGATIVE				See Flashpoint			X		
pH Screen		6 at 10 pcnt				2-12.5			X		
Oxidizer Screen		NEGATIVE		As	3.4	Hg 206 1.03					
Paint Filter Test		N/A		Be	0.1	K 1.02					
Cyanide Screen		NEGATIVE CYANTESMO		Cd	198	Na 0					
Sulfide Screen		POSITIVE		Cr	1193	Pb 206					
Incidental Odor		No		ASH 36.68							
Specific Gravity						0.000 - 0.000				01/01/00	
BTU/Lb		2340				2000 - 10000				07/17/08	MT
% Chloride		<0.5				1 - 5				07/17/08	TD
Flash Point - Deg F						N/A				01/01/00	
PCBs By GC - mg/kg						<50ppm				07/17/08	
PCBs-Screen - ppm						<50ppm				01/01/00	
2,4,5-T/Silvex - ppm		/								01/01/00	
PCP Screen - ppm										01/01/00	
pH by Meter										01/01/00	

Additional Comments: 12 samples were pulled from 4 rolloff boxes, and the average number was used for metals.  
Profile Review for Appendix WAP-C Constituents by: KMEREDITH  
Date: 2/11/2008

DATE: 08/20/08

## WASTE PROFILE SUMMARY

SELLING REGION LAB - MRL

BUSINESS: PQ CORP

DEPT.....

ADDRESS 1: 1700 KANSAS AVE

ADDRESS 2:

CITY/ST...: KANSAS CITY

KS 66105-1198

CONTACT...:

NUMBER.....: 141-6-444

PHONE.....:

EXPIRES.....: 03/07/10

STATUS.....: APPR FOR SERV

FEDERAL EPA ID: KSD000203711

STATE EPA ID...: 9200019999

EPA STATUS.....: CHK RESTRICT

SALES OFFICE...: PTA

WASTE NAME: MONOISOBUTYLAMINE &amp; WATER MIX

PROCESS GENERATING WASTE: FLASH CONDENSATE FROM ZEOLITE MANUFACTURING

SHIP. NAME: WASTE FLAMMABLE LIQUIDS, CORROSIVE, N.O.S

ADDL. DESC: (CONTAINS MONOISOBUTYLAMINE)

CHEMICAL COMPOSITION

WATER

NON-TRI CHEMICALS

MONOISOBUTYLAMINE

TRIETHYLAMINE

MIN - MAX UNIT DESCRIPTION

60 70 %

0 40 %

0 40 %

PHYSICAL CHARACTERISTICSMETALS TCA OR TOTAL

Nickel as Ni 2.5 ppm

Thallium as Tl 10 ppm

Barium as Ba 2.5 ppm

Cadmium as Cd 2.5 ppm

Chromium tot Cr 2.5 ppm

Lead as Pb 2.5 ppm

Silver as Ag 2.5 ppm

Antimony 2.5 ppm

Vanadium 2.5 ppm

Arsenic as As 2.0 ppm

Mercury as Hg 0.05 ppm

Beryllium 2.5 ppm

Potassium 12.5 ppm

Sodium 5.0 ppm

Selenium as Se 2.5 ppm

Zinc 2.5 ppm

Aluminum 20.0 ppm

Physical State...: Liquid

Flash Point.....: 100 - 140 CL

pH.....: 12.5 - 14.0

Color.....: VARIES

Odor.....: AMINE - LIKE

Layers.....: Single Layer

Specific Gravity.: 0.800 - 1.200

Free Liquids.....: 99 - 100

Cyanides.....: &lt; 5 PPM TOTAL

Sulfides.....: &lt; 3 PPM TOTAL

PCB's.....: N/A ppm, Regulated by 40 CFR 761:

Phenolics.....: None

% Taxable.....: DOT UN/NA NBR: UN2924

Treatment Codes...: T07

CRQ RPT QTY.....: Material Class:

EPA Permit.....: EXP:

Hazard Class.....: 3

State Codes.....: 090001

Benzene .....: NESHAP: Not Benzene NESHAP

Packing Group....: II

Process Codes....: DI1

Cert of Distrct Rq:

Federal Codes: D001 D002HANDLING

NEO. GREY GLOVES

CPF 3

TYPE C RESPIR CONST FLOW

PVC YELLOW OVR BOOT COVER

INDEX/BLUE NITRILE (INNER GLOVES)

DI-CAUSTIC LIQUID; PH &gt;10

DOT PROPERTIES

Inhalation: 3

Dermal: 3

Oral: 3

Flammable: 0

Health: 0

SUMMARY

Waste Type

B219

Form Code

1

COMMENTS

CHARGE CODE: CORL

REVIEWED FOR MACT METALS

PE UNTIL 3-31-09

PO 100271 for 8/15/08

6

Process Code(s):

8A \_\_\_\_\_ 8B \_\_\_\_\_ 4/5 \_\_\_\_\_

pH by Meter



01/01/00

Add. Comments: The data in the sample information section(6/29/2001)is date profile ZZZZZZ was created.

Report: R7008  
DATE: 08/18/08

ONYX ENVIRONMENTAL SERVICES, LLC  
WASTE PROFILE SUMMARY

Version 06.04  
TWI-388522  
SELLING REGION LAB - MRL

BUSINESS: BAYER CROP SCIENCE  
DEPT.....  
ADDRESS 1: 1740 WHITEHALL RD  
ADDRESS 2:  
CITY/ST.: MUSKEGAN MI 49445  
CONTACT..:

NUMBER.....: 103-9-594  
PHONE.....:  
EXPIRES.....: 01/05/10  
STATUS.....: APPR FOR SERV  
FEDERAL EPA ID: MID080358351  
STATE EPA ID..: 9260019999  
EPA STATUS....: CHK RESTRICT  
SALES OFFICE...: TWI

WASTE NAME: MOTHER LIQUOR RESIDUE  
PROCESS GENERATING WASTE: PROCESS WASTE FROM MANUFACTURING OF INTERMEDIATE H IDE  
SHIP. NAME: HAZARDOUS WASTE, LIQUID, N.O.S  
ADDL. DESC: (METHANOL, GLUFOSINATE AMMONIUM)

CHEMICAL COMPOSITION

NON-TRI CHEMICALS  
GLUFOSINATE AMMONIUM  
AMMONIUM CHLORIDE  
METHANOL  
WATER  
NON-TRI CHEMICALS  
OTHER RELATED COMPOUNDS

MIN	- MAX	UNIT DESCRIPTION
0	30 %	
0	20 %	
0	5.8 %	
20	70 %	
8	8 %	

METALS	EP TOX/TCLP
Arsenic as As	< 5.0 mg/l
Cadmium as Cd	< 1.0 mg/l
Lead as Pb	< 5.0 mg/l
Mercury as Hg	< .2 mg/l
Selenium as Se	< 1.0 mg/l
Chromium Hex	
Nickel as Ni	
Thallium as Tl	

PHYSICAL CHARACTERISTICS

Physical State...: Liquid  
Flash Point.....: 100 - 200 CL  
pH.....: 04.0 - 06.0  
Color.....: BROWN/VARIES  
Odor.....: NONE  
Layers.....: Multi Layer  
Specific Gravity.: 0.950 - 1.150  
Free Liquids.....: 99 - 100  
Cyanides.....: < 5 PPM TOTAL  
Sulfides.....: < 3 PPM TOTAL  
PCB's.....: ppm, Regulated by 40 CFR 761:  
Phenolics.....: < 10 PPM  
% Taxable.....: DOT UN/NA NBR: NA3082  
Treatment Codes..: T07  
CRQ RPT QTY.....: Material Class:  
EPA Permit.....: EXP:  
Hazard Class.....: 9  
State Codes.....: 090001  
Benzene .....: NESHA:  
Packing Group....: III  
Process Codes....: BLL  
Cert of Distrct Rq:

Federal Codes: F003

HANDLING

NEO. GREY GLOVES  
TYPE C RESPIR CONST FLOW

N-DEX INNER GLOVE

SARANEX

DOT PROPERTIES

Inhalation: 2 Dermal: 2 Oral: 2 Flammable: 0 Health: 0

SUMMARY

Waste Type B219  
Form Code 1

Report: R7008  
DATE: 08/18/08

ONYX ENVIRONMENTAL SERVICES, LLC  
WASTE PROFILE SUMMARY

Version 06.04  
TWI-351071  
SELLING REGION LAB - MRL

BUSINESS: VEOLIA ES TECHNICAL SOLUTIONS  
DEPT.....ATTN SUSAN SCHNEIDER 479  
ADDRESS 1: W124N9451 BOUNDARY RD  
ADDRESS 2:  
CITY/ST... MENOMONEE FALLS WI 53051-1603  
CONTACT..:

NUMBER..... 139-1-232  
PHONE.....  
EXPIRES..... 09/19/09  
STATUS..... APPR FOR SERV  
FEDERAL EPA ID: N/A  
STATE EPA ID... 9550019999  
EPA STATUS..... CHK RESTRICT  
SALES OFFICE... DEN

WASTE NAME: BULKED LIQUID HIGH BTU >3000  
PROCESS GENERATING WASTE: ACCUMULATION OF WASTE FROM SOLVENT RECOVERY PROCES  
SHIP. NAME: RQ, HAZARDOUS WASTE, LIQUID, N.O.S  
ADDL. DESC: (TECHNICAL DESCRIPTIONS, RQ'S VALUES ILL VARY)

CHEMICAL COMPOSITION

OIL  
NON-HALOGENATED SOLVENTS  
ACETONE  
METHYL ETHYL KETONE  
XYLENE  
ETHANOL  
ISOPROPANOL  
GLYCOL  
TOLUENE  
HEXANE  
METHANOL  
METHYL ISOBUTYL KETONE

MIN - MAX UNIT DESCRIPTION  
0 60 %  
40 60 %

Underlying Hazardous Constituents exist, Print Landban form and Underlying Hazardous Constituent form.

METALS	TCA OR TOTAL	
Arsenic as As	< 500	mg/l
Barium as Ba		
Cadmium as Cd	< 100	mg/l
Chromium tot Cr		
Lead as Pb	< 500	mg/l
Mercury as Hg	< 20	mg/l
Selenium as Se	< 100	mg/l
Silver as Ag		
Nickel as Ni	< 134	mg/l
Thallium as Tl	< 130	mg/l
Chromium Hex	< 500	mg/l

PHYSICAL CHARACTERISTICS

Physical State... Liquid  
Flash Point..... 70 - 200 CL  
pH..... 06.0 - 12.5  
Color..... VARIES, BROWN  
Odor..... NONE  
Layers..... Single Layer  
Specific Gravity.. 0.800 - 1.100  
Free Liquids..... 95 - 100  
Cyanides..... < 50 PPM TOTAL  
Sulfides..... < 3 PPM TOTAL  
PCB's..... N/A ppm, Regulated by 40 CFR 761:  
Phenolics..... < 10 PPM  
% Taxable..... DOT UN/NA NBR: NA3082  
Treatment Codes... T07  
CRQ RPT QTY..... Material Class:  
EPA Permit..... EXP:  
Hazard Class..... 9  
State Codes..... 090001  
Benzene ..... < 1000 NESHA: Not Benzene NESHA  
Packing Group.... III  
Process Codes.... BLH  
Cert of Dstrct Rq: Y

Federal Codes: D004 D005 D006 D007 D008 D010 D011 F001 F002 F003 F005 D003 D012 D015 D018 D019 +

HANDLING

NBR GREEN GLOVES N-DEX INNER GLOVE CPF 4  
FULLFACE RESPIRATOR TYPE C RESPIR CONST FLOW

CANCER SUSPECT AGENTS: CADMIUM, LEAD, BENZENE, VINYL CHLORIDE,  
FORMALDEHYDE, ARSENIC  
yellow over boot cover

DOT PROPERTIES

Inhalation: Dermal: 3 Oral: 3 Flammable: 0 Health: 0

SUMMARY

Waste Type B201  
Form Code 1

Report: R7008  
DATE: 06/18/08  
PROFILE: 351071

ONYX ENVIRONMENTAL SERVICES, LLC  
WASTE PROFILE SUMMARY ADDENDUM

Version 01.00  
APPENDIX  
PAGE: 01

(9)

CHEMICAL COMPOSITION: Additional Constituents  
Not included on Waste Profile Summary Report

Chemical Composition

MIN - MAX UNIT DESCRIPTION

ETHYL ACETATE			
HEPTANE			
BUTYL ACETATE			
GLYCOL ETHER	0	60	%
WATER	0	12	%
HALOGENATED SOLVENTS			
METHYLENE CHLORIDE			
CHLOROFORM			
CARBON TETRACHLORIDE			
1,1,1-TRICHLOROETHANE			
TRICHLOROETHYLENE			
TETRACHLOROETHYLENE			
1,1,2-TRICHLORO-1,2,2-TRIFLUOROETHANE			
TRICHLOROETHYLENE			
INERTS	0	5	%
DIRT, SLUDGE			
MAY ALSO INCLUDE SURFACTANS, STAINS, AND VARNISHES THAT WILL BE			
COMPATED PRIOR TO ADDITION.			
COMMENTS			
TOTAL SODIUM AND POTASSIUM	1000	10000	PPM

Report: R7008  
Date: 08/18/08

ONYX ENVIRONMENTAL SERVICES, LLC  
WASTE PROFILE SUMMARY

Version 06.04  
TWI-CG6944  
SELLING REGION LAB - MRL

BUSINESS: CAMBREX CHARLES CITY INC  
DEPT.....  
ADDRESS 1: 1205 11TH ST  
ADDRESS 2: A CAMBREX CO  
CITY/ST.: CHARLES CITY  
CONTACT: JEFF ROSS

IA 50616-3466

NUMBER.....: 105-1-142  
PHONE.....: 641/257-1059  
EXPIRES.....: 11/17/08  
STATUS.....: APPR FOR SERV  
FEDERAL EPA ID: IAD984591891  
STATE EPA ID.: 9190019999  
EPA STATUS....: CHK RESTRICT  
SALES OFFICE...: TWI

WASTE NAME: PILOT PLANT SOLVENTS  
PROCESS GENERATING WASTE: R & D ACTIVITY IN PHARMACEUTICAL PILOT PLANT  
SHIP. NAME: WASTE FLAMMABLE LIQUIDS, N.O.S  
ADDL. DESC: (METHANOL, ETHANOL)

CHEMICAL COMPOSITION

ISOPROPYL ACETATE  
HEPTANE  
TOLUENE  
OCTANE  
ORGANICS

MIN	- MAX	UNIT DESCRIPTION
0	100 %	
0	100 %	
0	100 %	
0	100 %	
50	100 %	

BUTANOL  
ETHANOL  
METHANOL  
ISOPROPANOL

0 50 %

ORGANICS  
METHYL ETHYL KETONE  
ACETONE

Underlying Hazardous Constituents exist, Print Landban form and Underlying Hazardous Constituent form.

PHYSICAL CHARACTERISTICS

METALS	EP TOX/TCLP		mg/l
Arsenic as As	< 5.0		mg/l
Cadmium as Cd	< 1.0		mg/l
Lead as Pb	< 5.0		mg/l
Mercury as Hg	< .2		mg/l
Selenium as Se	< 1.0		mg/l
Chromium Hex			
Nickel as Ni			
Thallium as Tl			

Physical State....: Liquid  
Flash Point.....: < 73 CL  
pH.....: 04.0 - 09.0  
Color.....: CLEAR  
Odor.....: ORGANIC  
Layers.....: Single Layer  
Specific Gravity.: 0.700 - 0.950  
Free Liquids.....: 95 - 100  
Cyanides.....: < 5 PPM TOTAL  
Sulfides.....: < 3 PPM TOTAL  
PCB's.....: ppm, Regulated by 40 CFR 761:  
Phenolics.....: < 10 PPM  
% Taxable.....: DOT UN/NA NBR: UN1993  
Treatment Codes...: T07  
CRQ RPT QTY.....: 100 Material Class:  
EPA Permit.....: EXP:  
Hazard Class.....: 3  
State Codes.....: 090001  
Benzene .....: NESHA:  
Packing Group....: II  
Process Codes....: DLF BF  
Cert of Distrct Rq: Y

Federal Codes: D001 F003 F005

HANDLING

N-Dex Inner Glove  
TYPE C RESPIR CONST FLOW

NBR GREEN GLOVES  
FULLFACE RESPIRATOR

CPF 4

INDEX/BLUE NITRILE (INNER GLOVE)

DOT PROPERTIES

Inhalation: 2

Dermal: 2

Oral: 2

Flammable: 0

Health: 0

SUMMARY

Waste Type  
Form Code

B203  
1



Report: R7008  
DATE: 08/18/08  
PROFILE: CG6944

ONYX ENVIRONMENTAL SERVICES, LLC  
WASTE PROFILE SUMMARY ADDENDUM

Version 01.00  
APPENDIX  
PAGE: 01

(11)

CHEMICAL COMPOSITION: Additional Constituents  
Not included on Waste Profile Summary Report

<u>Chemical Composition</u>		<u>MIN</u>	<u>-</u>	<u>MAX</u>	<u>UNIT DESCRIPTION</u>
METHYL ISOBUTYL KETONE		0		50	%
ORGANICS					
XYLENE		0		50	%
ORGANICS					
ETHYL ACETATE					
BUTYL ACETATE		0		100	%
PROPYL ACETATE		0		50	%
ORGANICS					
TERT-BUTYL METHYL ETHER					
ETHYL ETHER					
TETRAHYDROFURAN					
INERTS					
ORGANIC SETTLED SOLIDS FROM SYNTHESIS OF		0		2	%
INTERMEDIATE PHARMACEUTICAL PRODUCTS		0		100	%
ACETONITRILE					

Report: R7008  
DATE: 07/16/08

ONYX ENVIRONMENTAL SERVICES, LLC  
WASTE PROFILE SUMMARY

Version 06.04  
TWI-346595  
SELLING REGION LAB - MRL

BUSINESS: TORAY CARBON FIBERS AMERICA  
DEPT.....: ..  
ADDRESS 1: 2030 HIGHWAY 20 WEST  
ADDRESS 2:  
CITY/ST...: DECATUR AL 35601  
CONTACT...: JOHN CONLON

NUMBER.....: 143-5-585  
PHONE.....: 256/260-1010  
EXPIRES.....: 12/29/09  
STATUS.....: APPR FOR SERV  
FEDERAL EPA ID: ALR000036822  
STATE EPA ID...: 9010019999  
EPA STATUS.....: CHK RESTRICT  
SALES OFFICE...: TWI

WASTE NAME: ACRYLONITRILE  
PROCESS GENERATING WASTE: SPINNING  
SHIP. NAME: RQ, WASTE ACRYLONITRILE, STABILIZED  
ADDL. DESC:

CHEMICAL COMPOSITION

	MIN	- MAX	UNIT DESCRIPTION
WATER	0	3	%
ACRYLONITRILE		97	%
CUPFERRON	0	1	%

METALS	EP TOX/TCLP
Arsenic as As	< 5.0
Cadmium as Cd	< 1.0
Lead as Pb	< 5.0
Mercury as Hg	< .2
Selenium as Se	< 1.0
Chromium Hex	
Nickel as Ni	
Thallium as Tl	

mg/l  
mg/l  
mg/l  
mg/l  
mg/l

PHYSICAL CHARACTERISTICS

Physical State....: Liquid  
Flash Point.....: < 73 CL  
pH.....: 05.0 - 09.0  
Color.....: CLEAR, COLORLESS  
Odor.....: MILD PUNGENT  
Layers.....: Single Layer  
Specific Gravity.: 0.750 - 0.950  
Free Liquids.....: 95 - 100  
Cyanides.....: < 5 PPM TOTAL  
Sulfides.....: < 3 PPM TOTAL  
PCB's.....: ppm, Regulated by 40 CFR 761:  
Phenolics.....: < 10 PPM  
% Taxable.....: DOT UN/NA NBR: UN1093  
Treatment Codes...: T07  
CRQ RPT QTY.....: 100 Material Class:  
EPA Permit.....: EXP:  
Hazard Class.....: 3  
State Codes.....: 090001  
Benzene .....: NESHAP:  
Packing Group.....: I  
Process Codes.....: DI1  
Cert of Distrct Rq:

Federal Codes: D001

HANDLING

BUTYL RUBBER GLOVE  
NOMEX

N-DEX INNER GLOVE  
TYPE C RESPIR CONST FLOW

SARANEX  
PVC YELLOW OVR BOOT COVER

REACTIVE CATEGORY: B--RMP  
DI - ACRYLONITRILE, POLYMERIZABLE MATERIAL  
CANCER SUSPECT AGENT: ACRYLONITRILE

DOT PROPERTIES

Inhalation: 3 Dermal: 3 Oral: 3 Flammable: 0 Health: 0

SUMMARY

Waste Type B210  
Form Code 1

COMMENTS

REVIEWED FOR MACT METALS  
RMP CHEMICAL: 20,000 LB THRESHOLD LIMIT  
COMMITTED TO SPLIT LOAD UPON ARRIVAL  
NEED WEIGHT  
INVOICE TO ATTN: MIKE CONLON

REACTIVE CATEGORY: B--RMP CHEMICAL  
DO NOT SCHEDULE MORE THAN 20,000/SHIPMENT  
KAPPLER'S CHEM TAPE 2  
PE UNTIL 2-7-09



**FAX TO :** Tom RAMALY

**COMPANY :** USEPA

**PHONE :** \_\_\_\_\_

**FAX :** 312-353-4788

**DATE:** 8/15/08

**PAGES ATTACHED INCLUDING COVER PAGE:** \_\_\_\_\_

( ) CONFIDENTIAL    ( ) FOR YOUR REVIEW    (✓) REQUESTED INFORMATION

**FROM:** Dennis J. Warchol, EHS Mgr.

Veolia ES Technical Solutions, L.L.C.  
7 Mobile Ave  
Sauget, Illinois 62201-1069  
618 271 2804 x 231  
Dennis.Warchol@veoliaes.com

**Visual Inspection: Glove Box / Hooded Feeder**

Process Code(s):

285174

Profile		Conform		Date	Initials
		Yes	No	08/01/08	AJ
L			X		
BKG			X		
See Flashpoint			X		
2-12.5			X		
Hg	65				
K	0.02				
Na	0				
Pb	0				
				08/01/08	AJ
				08/01/08	MT
				08/01/08	JF
				01/01/00	
<50ppm				08/01/08	
<50ppm				01/01/00	
				01/01/00	
				01/01/00	
				01/01/00	

Date:   
Add. Comments: blend analysis

THE DATE 6/29/2001 IS THE DATE THAT PROFILE 222222 WAS CREATED. PROFILE 222222 WAS CREATED TO ALLOW US TO ENTER DATA IN THE SYSTEM. ALL TRACIC BLENDS AND PIT



Attachment 4

Rotary Kiln Incinerator Unit 4  
Solid Feed Charges Log – August 20, 2008

SOLID FEED CHARGES - Target Rate: 40 charges/hour

Date 8/20/08

Incinerator No. 4

Test Run 1

Operator Wheeler, Ed Asch

ID # - CHARGE #	LEAD #	HEX #	MERCURY #	ID # - CHARGE #	LEAD #	HEX #	MERCURY #
<del>20080801</del> -1066	508	931	737	20080801-1039	981	847	701
1054	509	936	765	2 1034	914	848	721
1062	502	934	724	1030	988	843	732
1058	507	935	764	1026	991	840	710
1057	503	939	736	1025	995	845	743
1052	501	937	730	1029	974	844	733
1056	513	933	731	1033	1000	846	702
1050	505	863	738	1028	998	839	745
1053	514	865	707	1024	999	842	725
1049	510	864	726	1032	952	838	708
1048	522	861	709	1023	962	835	703
1055	504	860	744	1031	986	836	706
1051	512	866	723	1027	959	841	734
1047	523	858	728	1021	982	833	716
1046	506	857	705	1022	983	834	746
1042	520	855	712	1020	979	837	720
1035	528	859	739	1013	992	832	767
1036	516	862	711	1018	994	830	741
1045	521	856	704	1019	961	831	718
1041	524	852	714	1017	990	812	719
1037	976	850	715	1012	987	829	722
1044	912	849	740	1016	966	813	717
1040	977	854	742	1015	964	826	729
1043	977	853	763	1011	975	828	866
1038	984	851	727	1014	968	823	855

< SAMPLE

START  
5:35

SOLID FEED CHARGES - Target Rate: 40 charges/hour

Date 8/20/08

Incinerator No. 4

Test Run 1

Operator W. Miller, Ed Lasick

ID # - CHARGE #	LEAD #	HEX #	MERCURY #	ID # - CHARGE #	LEAD #	HEX #	MERCURY #
<del>20080801</del> -1001	989	827	850	<del>20080801</del> -983	956	1032	873
1004	973	820	880	980	951	1030	849
1007	989	819	853	975	944	1027	865
1010	996	824	879	985	946	1033	881
1009	932	822	867	982	967	1031	875
1000	921	825	852	979	947	1025	863
1006	923	821	871	974	948	1020	841
1003	950	1050	848	981	933	1029	884
1008	934	1048	844	984	978	1026	862
1005	993	1049	859	973	945	1024	870
1002	971	1046	858	976	941	1014	883
999	960	1044	874	963	917	1023	869
998	957	1047	845	972	938	1021	872
995	970	1042	857	969	924	1022	878
992	963	1043	838	966	920	1017	886
989	955	1039	876	965	919	1018	882
997	954	1041	842	968	935	1015	861
994	980	1045	840	971	943	1012	860
991	958	1040	847	962	940	1004	856
988	927	1038	868	961	931	1016	854
996	969	1037	864	964	929	1009	794
993	972	1036	851	967	930	1013	817
990	942	1028	877	<del>970</del>	<del>937</del>	<del>1007</del>	<del>797</del>
987	985	1035	846				
986	953	1034	885				

\*\*819 - Merc

\*843 - Merc



Attachment 5

Rotary Kiln Incinerator Unit 4  
Solid Feed Charges Log – August 21, 2008

SOLID FEED CHARGES - Target Rate: 40 charges/hour

Date 8/21/08

Incinerator No. 4

Test Run 2

Operator W. Muller Ed Lasch

ID # - CHARGE #	LEAD #	HEX #	MERCURY #	ID # - CHARGE #	LEAD #	HEX #	MERCURY #
20080801-970	909	1007	797	20080801-927	1111	1097	807
960	907	1010	830	936	1116	1095	823
957	911	1011	816	933	1162	1088	809
954	905	1019	828	930	1109	1093	805
951	901	1003	833	935	1114	1090	806
959	915	1008	827	932	1171	1087	802
956	910	1006	811	929	1163	1083	801
953	908	999	836	926	1157	1092	798
950	936	1001	834	934	1164	1086	800
958	903	1000	839	925	1106	1091	818
955	909	1005	831	928	1177	1089	820
949	913	1002	835	931	1159	1085	796
952	916	997	815	924	1117	1082	795
948	922	995	810	921	1191	1084	804
945	926	998	812	918	1166	1080	803
942	949	992	799	915	1161	1073	813
939	928	993	837	923	1113	1081	962
947	902	991	832	920	1195	1079	963
944	906	996	814	917	1178	1074	966
941	965	994	825	914	1176	1077	959
938	925	1099	826	922	1115	1069	964
946	918	1100	829	919	1175	1075	950
943	937	1094	822	913	<del>1174</del>	1076	955
940	1105	1098	808	916	1173	1072	967
937	1112	1096	821	912	1110	1078	968

START >  
25

SAMP >

SOLID FEED CHARGES - Target Rate: 40 charges/hour

Date 8/21/08

Incinerator No. 4

Test Run 2

Operator W. J. Jaskuch

START  
2:37

SAMP\*

ID # - CHARGE #	LEAD #	HEX #	MERCURY #	ID # - CHARGE #	LEAD #	HEX #	MERCURY #
20080801-909	1167	1070	969	20080801-1121	1190	1446	952
906	1172	1071	970	1122	1118	1444	953
903	1160	1066	944	1123	1189	1442	954
901	1167	1068	960	1124	1186	1441	948
905	1169	1065	961	1125	1150	1438	936
908	1170	1061	958	1126	1197	1443	928
911	1180	1067	956	1128	1184	1437	923
910	1147	1063	934 965	1127	1179	1439	924
907	1183	1064	947	1129	1158	1435	914
904	1141	1062	945	1130	1194	1436	911
902	1198	1059	940	1110	1193	1428	913
1131	1149	1066	936	1107	1151	1433	893
1132	1153	1058	935	1108	1152	1425	922
1133	1168	1055	957	1111	1196	1431	905
1134	1188	1054	946	1112	1155	1432	897
1135	1187	1057	933	1113	1124	1434	912
1136	1186	1051	938	1109	1138	1440	931 904
1137	1121	1053	949				
1138	1135	1056	941				
1142	1165	1052	942				
1141	1185	1450	939				
1140	1130	1448	943				
1139	1145	1445	932				
1119	1182	1449	937				
1120	1181	1447	951				

SAMP\*\*  
15:37

**Attachment 6**

**TWI Instrument Calibration Records  
Carbon Injection System**

# TWI INSTRUMENT CALIBRATION RECORD

UNIT #4  
QUARTERLY

TAG: 483	
LOOP: C-17	
DESCRIPON: INJECTOR	MANUFACT: K-TRON
SERVICE: CARBON INJECTION	MODEL: K2V-T35
LOCATION: FLD	SCALE:
LP-SHT:	CALIB-IN:
P&ID:	CALIB-OUT:
REMARKS:	PROCESS-SP:
INSTL-RMKS:	INST-SP:
SPEC-RMKS:	ACTION:
S/N:	I/O NUMBER: F26:127

## CALIBRATION NOTES

Set control system set point to an appropriate flow rate. Flow Carbon into a container for one minutes, and compare the measured weight of the container, minus it's empty weight, multiplied by 60, to get the actual flow rate. Divide measured weight by indicated weight, to get a percent of error. To correct an error multiply this number by the number in Main PLC, F26:127 and enter new number.

## CALIBRATION REPORT

INPUT VALUE	INSTRUMENT READING
Before Calibration	
0	0
6 lbs/hr	1086.096 min
After Calibration	

## CALIBRATION SOURCE REFERENCE

Starting value of F26:127 \_\_\_\_\_

Corrected Value of F26:127 \_\_\_\_\_

Comments: No Calibration needed

Performed by: D.W. Date: 8-8-07 Time: 1:00 AM PM

JB  
CALSHEET.WDB

Place: (Field or Shop)

TWI INSTRUMENT CALIBRATION RECORD  
UNIT #4  
QUARTERLY

TAG: 483  
LOOP: C-17  
DESCRIPON: INJECTOR  
SERVICE: CARBON INJECTION  
LOCATION: FLD  
LP-SHT:  
P&ID:  
REMARKS:  
INSTL-RMKS:  
SPEC-RMKS:  
S/N:

MANUFACT: K-TRON  
MODEL: K2V-T35  
SCALE:  
CALIB-IN:  
CALIB-OUT:  
PROCESS-SP:  
INST-SP:  
ACTION:  
I/O NUMBER: F26:127

CALIBRATION NOTES

Set control system set point to an appropriate flow rate.  
Flow Carbon into a container for one minutes, and compare  
the measured weight of the container, minus it's empty  
weight, multiplied by 60, to get the actual flow rate.  
Divide measured weight by indicated weight, to get a  
percent of error. To correct an error multiply this number  
by the number in Main PLC, F26:127 and enter new number.

CALIBRATION REPORT

INPUT VALUE	INSTRUMENT READING
<u>Set at 6 lbs. per.</u>	<u>Before Calibration</u>
<u>hr. for 1 minute</u>	<u>.1 lbs.</u>
<u>-</u>	<u>After Calibration</u>
<u>-</u>	<u>-</u>
<u>-</u>	<u>-</u>

CALIBRATION SOURCE REFERENCE

Starting value of F26:127 \_\_\_\_\_  
Corrected Value of F26:127 \_\_\_\_\_

Comments: No calibration needed.

Performed by: B. T. B. [Signature] Date: 11-12-07 Time: 2:15 AM PM

JB  
CALSHEET.WDB

Place: (Field or Shop)

TWI INSTRUMENT CALIBRATION RECORD  
UNIT #4  
QUARTERLY

TAG: 483	
LOOP: C-17	
DESCRIPON: INJECTOR	MANUFACT: K-TRON
SERVICE: CARBON INJECTION	MODEL: K2V-T35
LOCATION: FLD	SCALE:
LP-SHT:	CALIB-IN:
P&ID:	CALIB-OUT:
REMARKS:	PROCESS-SP:
INSTL-RMKS:	INST-SP:
SPEC-RMKS:	ACTION:
S/N:	I/O NUMBER: F26:127

CALIBRATION NOTES

Set control system set point to an appropriate flow rate. Flow Carbon into a container for one minutes, and compare the measured weight of the container, minus it's empty weight, multiplied by 60, to get the actual flow rate.

Divide measured weight by indicated weight, to get a percent of error. To correct an error multiply this number by the number in Main PLC, F26:127 and enter new number.

CALIBRATION REPORT

INPUT VALUE	INSTRUMENT READING
<u>-6 lbs. per hr.</u>	<u>Before Calibration</u>
<u>for 1 minute</u>	<u>.095 lbs</u>
<u> </u>	<u> </u>
<u> </u>	<u>After Calibration</u>
<u> </u>	<u> </u>
<u> </u>	<u> </u>

CALIBRATION SOURCE REFERENCE

Starting value of F26:127  

Corrected Value of F26:127  

Comments: No calibration needed.

Performed by: BB/CE Date: 2-13-08 Time: 2:45 AM PM

JB  
CALSHEET.WDB Place: (Field) or Shop

TWI INSTRUMENT CALIBRATION RECORD  
UNIT #4  
QUARTERLY

TAG: 483  
LOOP: C-17  
DESCRIPON: INJECTOR  
SERVICE: CARBON INJECTION  
LOCATION: FLD  
LP-SHT:  
P&ID:  
REMARKS:  
INSTL-RMKS:  
SPEC-RMKS:  
S/N:

MANUFACT: K-TRON  
MODEL: K2V-T35  
SCALE:  
CALIB-IN:  
CALIB-OUT:  
PROCESS-SP:  
INST-SP:  
ACTION:  
I/O NUMBER: F26:127

CALIBRATION NOTES

Set control system set point to an appropriate flow rate.  
Flow Carbon into a container for one minutes, and compare  
the measured weight of the container, minus it's empty  
weight, multiplied by 60, to get the actual flow rate.

Divide measured weight by indicated weight, to get a  
percent of error. To correct an error multiply this number  
by the number in Main PLC, F26:127 and enter new number.

CALIBRATION REPORT

INPUT VALUE	INSTRUMENT READING
Before Calibration	
6 lbs. per hr. for	.096 lbs.
1 minute	
After Calibration	

CALIBRATION SOURCE REFERENCE

Starting value of F26:127 \_\_\_\_\_

Corrected Value of F26:127 \_\_\_\_\_

Comments: No calibration needed.

Performed by: BB/DO Date: 5-15-08 Time: 12:45 AM PM  
Place: (Field) or Shop  
JB  
CALSHEET.WDB



Attachment 7

Chain of Custody Record



Attachment 8

Certificate of Analysis – Glassware



Scientific Products LLC

Where clean is critical

36 East B.J. Tunnell Blvd.

Miami, OK 74354

QC-B-001

Rev. 4

9/23/05

# Certificate of Analysis

BOTTLE TYPE GLASS QA LEVEL 1 LOT NO 027852

DESCRIPTION 131-08C; 250ml. Short Clear Wide Mouth Jar

EP Scientific Products Level 1 products have been tested and found to comply with or to be lower than the EPA detection limits as stated in OSWER Directive # 9240.0-05A, "Specifications And Guidance For Contaminant-Free Sample Containers 12/92". EP Scientific Products pass/fail criteria considers all significant non-target compounds.

Glass and HDPE Sample containers for use in the analysis of Metals							
Analyte	Detection Limit (µg/L)	Analyte	Detection Limit (µg/L)	Analyte	Detection Limit (µg/L)	Analyte	Detection Limit (µg/L)
Aluminum	<80	Calcium (all HDPE)	<100	Magnesium	<100	Selenium	<2
Antimony	<5	Chromium	<10	Manganese	<10	Silver	<5
Arsenic	<2	Cobalt	<10	Mercury	<0.2	Sodium	<5000
Barium	<20	Copper	<10	Nickel	<20	Sodium (all HDPE)	<100
Beryllium	<0.5	Iron	<50	Potassium	<750	Thallium	<5
Cadmium	<1	Lead	<2	Potassium (all HDPE)	<100	Vanadium	<10
Calcium	<500					Zinc	<10

In addition to the above analytes, NALGENE® containers are certified for these analytes:

Analyte	Detection Limit (µg/L)	Analyte	Detection Limit (µg/L)	Analyte	Detection Limit (µg/L)	Analyte	Detection Limit (µg/L)
Chloride	<100	Fluoride	<20	Nitrite	<50	Sulfate	<100
Cyanide	<10	Nitrate	<20	Paraquat (amber only)	<0.4	Sulfide	<30
Diquat (amber only)	<1.0					Sulfite	<1000

Glass Sample Containers for use in the analysis of Semivolatiles and Pesticides/PCBs

Compound	Quantitation Limit (µg/L)	Compound	Quantitation Limit (µg/L)	Compound	Quantitation Limit (µg/L)
Acenaphthene	<5	Acenaphthylene	<5	Anthracene	<5
Benzo(a)anthracene	<5	Benzo(a)pyrene	<5	Benzo(b)fluoranthene	<5
Benzo(k)fluoranthene	<5	Benzo(a,h,i)perylene	<5	Benzoic Acid	<20
Benzyl Alcohol	<5	4-Bromophenyl-phenylether	<5	Butylbenzylphthalate	<5
4-Chloroaniline	<5	4-Chloro-3-methylphenol	<5	bis-(2-chloroethoxy)methane	<5
bis-(2-Chloroethyl)ether	<5	bis-(2-Chloroisopropyl)ether	<5	2-Chloronaphthalene	<5
2-Chlorophenol	<5	4-Chlorophenyl-phenylether	<5	Chrysene	<5
Di-n-butylphthalate	<5	Di-n-octylphthalate	<5	Dibenz(a,h)anthracene	<5
Dibenzofuran	<5	1,2-Dichlorobenzene	<5	1,4-Dichlorobenzene	<5
1,3-Dichlorobenzene	<5	3,3'-Dichlorobenzidine	<5	2,4-Dichlorophenol	<5
Diethylphthalate	<5	Dimethylphthalate	<5	2,4-Dinitrophenol	<5
4,6-Dinitro-2-methylphenol	<20	2,4-Dinitrophenol	<20	2,4-Dinitrotoluene	<5
2,6-Dinitrotoluene	<5	bis-(2-Ethylhexyl)phthalate	<5	Fluoranthene	<5
Fluorene	<5	Hexachlorobenzene	<5	Hexachlorobutadiene	<5
Hexachlorocyclopentadiene	<5	Hexachloroethane	<5	Indeno(1,2,3-cd)pyrene	<5
Isophorone	<5	2-Methylnaphthalene	<5	2-Methylphenol	<5
4-Methylphenol	<5	2-Nitroaniline	<20	3-Nitroaniline	<20
4-Nitroaniline	<20	N-Nitroso-di-n-propylamine	<5	N-Nitrosodimethylamine	<5
N-Nitrosodiphenylamine	<5	Naphthalene	<5	Nitrobenzene	<5
2-Nitrophenol	<5	4-Nitrophenol	<20	Pentachlorophenol	<20
Phenanthrene	<5	Phenol	<5	Pyrene	<5
1,2,4-Trichlorobenzene	<5	2,4,5-Trichlorophenol	<20	2,4,6-Trichlorophenol	<5
Azobenzene	<5	Carbazole	<5	Aldrin	<0.01
4,4-DDD	<0.02	Endosulfan II	<0.02	Alpha-BHC	<0.01
4,4-DDE	<0.02	Endosulfan Sulfate	<0.02	Beta-BHC	<0.01
4,4-DDT	<0.02	Erdrin	<0.02	Delta-BHC	<0.01
Dieldrin	<0.02	Endrin Aldehyde	<0.02	Gamma-BHC	<0.01
Endosulfan I	<0.01	Heptachlor	<0.01	Heptachlor Epoxide	<0.01
Methoxychlor	<0.10	Endrin Ketone	<0.02	Alpha-Chlordane	<0.01
Gamma-Chlordane	<0.01	Toxaphene	<0.30	Aroclor-1016	<0.20
Aroclor-1221	<0.20	Aroclor-1232	<0.20	Aroclor-1242	<0.20
Aroclor-1248	<0.20	Aroclor-1254	<0.20	Aroclor-1260	<0.20
Aroclor-1262	<0.20	Aroclor-1268	<0.20		

Glass Sample Containers for use in the analysis of Volatiles

Compound	Quantitation Limit (µg/L)	Compound	Quantitation Limit (µg/L)	Compound	Quantitation Limit (µg/L)
Acetone	<5	1,3-Dichloropropane	<1	Benzene	<1
2,2-Dichloropropane	<1	Bromobenzene	<1	1,2-Dichloropropane	<1
Bromodichloromethane	<1	trans-1,3-Dichloropropene	<1	Bromoform	<1
cis-1,3-Dichloropropene	<1	Bromomethane	<1	1,1-Dichloropropene	<1
2-Butanone	<5	Ethylbenzene	<1	tert-Butylbenzene	<1
Hexachlorobutadiene	<1	sec-Butylbenzene	<1	2-Hexanone	<5
n-Butylbenzene	<1	Isopropylbenzene	<1	Carbon Disulfide	<1
p-Isopropyltoluene	<1	Carbon Tetrachloride	<1	4-Methyl-2-pentanone	<5
Chloromethane	<1	Methylene Chloride	<2	Chloroethane	<1
1,1,2,2-Tetrachloroethane	<1	Chloroform	<1	n-Propylbenzene	<1
Dibromochloromethane	<1	Styrene	<1	2 & 4 Chlorotoluene	<1
1,2,3-Trichloropropane	<1	1,2-Dibromo-3-chloropropane	<1	Tetrachloroethene	<1
1,4-Dichlorobenzene	<1	Toluene	<1	1,2-Dibromoethane (EDB)	<1
1,1,1-Trichloroethane	<1	Dibromomethane	<1	1,2,4-Trichlorobenzene	<1
Dichlorodifluoromethane	<1	1,1,2-Trichloroethane	<1	1,3-Dichlorobenzene	<1
1,2,3-Trichloropropane	<1	1,2-Dichlorobenzene	<1	Trichloroethene	<1
trans-1,2-Dichloroethene	<1	Trichlorofluoromethane	<1	1,2-Dichloroethene	<1
Vinyl Acetate	<5	1,1-Dichloroethane	<1	Bromochloromethane	<1
Xylenes (total)	<1	1,3,5-Trimethylbenzene	<1		
Vinyl Chloride	<1	1,1-Dichloroethene	<1		
		1,2,4-Trimethylbenzene	<1		
		cis-1,2-Dichloroethene	<1		

In addition to the above analytes, 40 mL and 60 mL vials are certified for:

Compound	Quantitation Limit (µg/L)
Total Organic Carbon	<600

If EP Scientific Products can be of any further assistance, please call 800-331-7425 and ask for our Technical Service Department.

Approved By: James L. Riner - Quality Assurance

*James L. Riner*