

# CETIFICATION

SDG No: FA33668 Laboratory: Accutest, Florida  
Site: BMS, Building 5 Area, PR Matrix: Groundwater/Soil

Humacao, PR

**SUMMARY:** Groundwater and soil samples (Table 1) were collected on the BMSMC facility – Building 5 Area. The BMSMC facility is located in Humacao, PR. Samples were taken May 03-04, 2016 and were analyzed in Accutest Laboratory of Orlando, Florida that reported the data under SDG No.: FA33668. Results were validated using the latest validation guidelines (July, 2015) of the EPA Hazardous Waste Support Section. The analyses performed are shown in Table 1. Individual data review worksheets are enclosed for each target analyte group. The data sample organic data samples summary form shows for analytes results that were qualified.

In summary the results are valid and can be used for decision taking purposes.

Table 1. Samples analyzed and analysis performed

| SAMPLE ID | SAMPLE DESCRIPTION | MATRIX               | ANALYSIS PERFORMED |
|-----------|--------------------|----------------------|--------------------|
| FA33668-1 | RA-16 GWD          | Groundwater          | VOCs TCL List      |
| FA33668-2 | EB 030316D         | AQ- Equipment Blank  | VOCs TCL List      |
| FA33668-3 | S-42S              | Groundwater          | VOCs TCL List      |
| FA33668-4 | RA-11 GWS          | Groundwater          | VOCs TCL List      |
| FA33668-5 | BPEB-12            | AQ- Equipment Blank  | VOCs TCL List      |
| FA33668-6 | RA-11 (10-11)      | Soil                 | VOCs TCL List      |
| FA33668-7 | S-43S              | Groundwater          | VOCs TCL List      |
| FA33668-8 | RA-10 (5.5-6.5)    | Soil                 | VOCs TCL List      |
| FA33668-9 | TB 050416          | AQ- Trip Blank water | VOCs TCL List      |

Reviewer Name: Rafael Infante  
Chemist License 1888

Signature:

Date:

May 23, 2016



SGS Accutest

## Report of Analysis

Page 1 of 2

Client Sample ID: RA-16 GWD  
 Lab Sample ID: FA33668-1  
 Matrix: AQ - Ground Water  
 Method: SW846 8260C  
 Project: BMSMC, Building 5 Area, Humacao, PR

Date Sampled: 05/03/16  
 Date Received: 05/05/16  
 Percent Solids: n/a

| Run #  | File ID    | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|----|-----------|------------|------------------|
| Run #1 | J0976339.D | 1  | 05/06/16 | DP | n/a       | n/a        | VJ5288           |
| Run #2 |            |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

## VOA TCL List (SOM02.0)

| CAS No.    | Compound                                | Result | RL  | MDL  | Units | Q |
|------------|---|--------|-----|------|-------|---|
| 67-64-1    | Acetone                                 | ND     | 25  | 10   | ug/l  |   |
| 71-43-2    | Benzene                                 | ND     | 1.0 | 0.20 | ug/l  |   |
| 100-44-7   | Benzyl Chloride                         | ND     | 2.0 | 0.44 | ug/l  |   |
| 74-97-5    | Bromochloromethane                      | ND     | 1.0 | 0.42 | ug/l  |   |
| 75-27-4    | Bromodichloromethane                    | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-25-2    | Bromoform                               | ND     | 1.0 | 0.46 | ug/l  |   |
| 78-93-3    | 2-Butanone (MEK)                        | ND     | 5.0 | 2.6  | ug/l  |   |
| 75-15-0    | Carbon Disulfide                        | ND     | 2.0 | 0.23 | ug/l  |   |
| 56-23-5    | Carbon Tetrachloride                    | ND     | 1.0 | 0.30 | ug/l  |   |
| 108-90-7   | Chlorobenzene                           | ND     | 1.0 | 0.20 | ug/l  |   |
| 75-00-3    | Chloroethane                            | ND     | 2.0 | 0.63 | ug/l  |   |
| 67-66-3    | Chloroform                              | ND     | 1.0 | 0.30 | ug/l  |   |
| 110-82-7   | Cyclohexane                             | ND     | 1.0 | 0.26 | ug/l  |   |
| 124-48-1   | Dibromochloromethane                    | ND     | 1.0 | 0.26 | ug/l  |   |
| 96-12-8    | 1,2-Dibromo-3-chloropropane             | ND     | 5.0 | 0.81 | ug/l  |   |
| 106-93-4   | 1,2-Dibromoethane                       | ND     | 2.0 | 0.33 | ug/l  |   |
| 75-71-8    | Dichlorodifluoromethane                 | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-50-1    | 1,2-Dichlorobenzene                     | ND     | 1.0 | 0.27 | ug/l  |   |
| 541-73-1   | 1,3-Dichlorobenzene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 106-46-7   | 1,4-Dichlorobenzene                     | ND     | 1.0 | 0.39 | ug/l  |   |
| 75-34-3    | 1,1-Dichloroethane                      | ND     | 1.0 | 0.26 | ug/l  |   |
| 107-06-2   | 1,2-Dichloroethane                      | ND     | 1.0 | 0.28 | ug/l  |   |
| 75-35-4    | 1,1-Dichloroethylene                    | ND     | 1.0 | 0.22 | ug/l  |   |
| 156-59-2   | cis-1,2-Dichloroethylene                | ND     | 1.0 | 0.31 | ug/l  |   |
| 156-60-5   | trans-1,2-Dichloroethylene <sup>a</sup> | ND     | 1.0 | 0.33 | ug/l  |   |
| 78-87-5    | 1,2-Dichloropropane                     | ND     | 1.0 | 0.34 | ug/l  |   |
| 10061-01-5 | cis-1,3-Dichloropropene                 | ND     | 1.0 | 0.26 | ug/l  |   |
| 10061-02-6 | trans-1,3-Dichloropropene               | ND     | 1.0 | 0.25 | ug/l  |   |
| 100-41-4   | Ethylbenzene                            | ND     | 1.0 | 0.25 | ug/l  |   |
| 76-13-1    | Freon 113                               | ND     | 1.0 | 0.32 | ug/l  |   |
| 591-78-6   | 2-Hexanone                              | ND     | 10  | 2.0  | ug/l  |   |
| 98-82-8    | Isopropylbenzene                        | ND     | 1.0 | 0.33 | ug/l  |   |

ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



## Report of Analysis

Client Sample ID: RA-16 GWD  
 Lab Sample ID: FA33668-1  
 Matrix: AQ - Ground Water  
 Method: SW846 8260C  
 Project: BSMC, Building 5 Area, Humacao, PR

Date Sampled: 05/03/16  
 Date Received: 05/05/16  
 Percent Solids: n/a

## VOA TCL List (SOM02.0)

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 99-87-6   | p-Isopropyltoluene          | ND     | 1.0 | 0.28 | ug/l  |   |
| 79-20-9   | Methyl Acetate              | ND     | 20  | 5.0  | ug/l  |   |
| 74-83-9   | Methyl Bromide              | ND     | 2.0 | 0.50 | ug/l  |   |
| 74-87-3   | Methyl Chloride             | ND     | 2.0 | 0.50 | ug/l  |   |
| 108-87-2  | Methylcyclohexane           | ND     | 1.0 | 0.23 | ug/l  |   |
| 75-09-2   | Methylene Chloride          | ND     | 5.0 | 2.0  | ug/l  |   |
| 108-10-1  | 4-Methyl-2-pentanone (MIBK) | ND     | 5.0 | 1.4  | ug/l  |   |
| 1634-04-4 | Methyl Tert Butyl Ether     | 0.75   | 1.0 | 0.20 | ug/l  | J |
| 100-42-5  | Styrene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-85-4   | Tert-Amyl Alcohol           | ND     | 20  | 6.0  | ug/l  |   |
| 75-65-0   | Tert-Butyl Alcohol          | ND     | 20  | 9.1  | ug/l  |   |
| 79-34-5   | 1,1,2,2-Tetrachloroethane   | ND     | 1.0 | 0.33 | ug/l  |   |
| 127-18-4  | Tetrachloroethylene         | ND     | 1.0 | 0.30 | ug/l  |   |
| 109-99-9  | Tetrahydrofuran             | ND     | 5.0 | 1.4  | ug/l  |   |
| 108-88-3  | Toluene                     | ND     | 1.0 | 0.20 | ug/l  |   |
| 87-61-6   | 1,2,3-Trichlorobenzene      | ND     | 2.0 | 0.51 | ug/l  |   |
| 120-82-1  | 1,2,4-Trichlorobenzene      | ND     | 2.0 | 0.50 | ug/l  |   |
| 71-55-6   | 1,1,1-Trichloroethane       | ND     | 1.0 | 0.20 | ug/l  |   |
| 79-00-5   | 1,1,2-Trichloroethane       | ND     | 1.0 | 0.37 | ug/l  |   |
| 79-01-6   | Trichloroethylene           | ND     | 1.0 | 0.27 | ug/l  |   |
| 75-69-4   | Trichlorofluoromethane      | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-63-6   | 1,2,4-Trimethylbenzene      | ND     | 1.0 | 0.20 | ug/l  |   |
| 75-01-4   | Vinyl Chloride              | ND     | 1.0 | 0.31 | ug/l  |   |
|           | m,p-Xylene                  | ND     | 2.0 | 0.30 | ug/l  |   |
| 95-47-6   | o-Xylene                    | ND     | 1.0 | 0.26 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 102%   |        | 83-118% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 98%    |        | 79-125% |
| 2037-26-5  | Toluene-D8            | 101%   |        | 85-112% |
| 460-00-4   | 4-Bromofluorobenzene  | 102%   |        | 83-118% |

(a) Associated BS recovery outside control limits.



ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 2

|                   |                                     |                 |          |
|-------------------|-------------------------------------|-----------------|----------|
| Client Sample ID: | EB 050316D                          | Date Sampled:   | 05/03/16 |
| Lab Sample ID:    | FA33668-2                           | Date Received:  | 05/05/16 |
| Matrix:           | AQ - Equipment Blank                | Percent Solids: | n/a      |
| Method:           | SW846 8260C                         |                 |          |
| Project:          | BMSMC, Building 5 Area, Humacao, PR |                 |          |

| Run #  | File ID    | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|----|-----------|------------|------------------|
| Run #1 | J0976340.D | 1  | 05/06/16 | DP | n/a       | n/a        | VJ5288           |
| Run #2 |            |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

## VOA TCL List (SOM02.0)

| CAS No.    | Compound                                | Result | RL  | MDL  | Units | Q |
|------------|---|--------|-----|------|-------|---|
| 67-64-1    | Acetone                                 | ND     | 25  | 10   | ug/l  |   |
| 71-43-2    | Benzene                                 | ND     | 1.0 | 0.20 | ug/l  |   |
| 100-44-7   | Benzyl Chloride                         | ND     | 2.0 | 0.44 | ug/l  |   |
| 74-97-5    | Bromochloromethane                      | ND     | 1.0 | 0.42 | ug/l  |   |
| 75-27-4    | Bromodichloromethane                    | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-25-2    | Bromoform                               | ND     | 1.0 | 0.46 | ug/l  |   |
| 78-93-3    | 2-Butanone (MEK)                        | ND     | 5.0 | 2.6  | ug/l  |   |
| 75-15-0    | Carbon Disulfide                        | ND     | 2.0 | 0.23 | ug/l  |   |
| 56-23-5    | Carbon Tetrachloride                    | ND     | 1.0 | 0.30 | ug/l  |   |
| 108-90-7   | Chlorobenzene                           | ND     | 1.0 | 0.20 | ug/l  |   |
| 75-00-3    | Chloroethane                            | ND     | 2.0 | 0.63 | ug/l  |   |
| 67-66-3    | Chloroform                              | ND     | 1.0 | 0.30 | ug/l  |   |
| 110-82-7   | Cyclohexane                             | ND     | 1.0 | 0.26 | ug/l  |   |
| 124-48-1   | Dibromochloromethane                    | ND     | 1.0 | 0.26 | ug/l  |   |
| 96-12-8    | 1,2-Dibromo-3-chloropropane             | ND     | 5.0 | 0.81 | ug/l  |   |
| 106-93-4   | 1,2-Dibromoethane                       | ND     | 2.0 | 0.33 | ug/l  |   |
| 75-71-8    | Dichlorodifluoromethane                 | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-50-1    | 1,2-Dichlorobenzene                     | ND     | 1.0 | 0.27 | ug/l  |   |
| 541-73-1   | 1,3-Dichlorobenzene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 106-46-7   | 1,4-Dichlorobenzene                     | ND     | 1.0 | 0.39 | ug/l  |   |
| 75-34-3    | 1,1-Dichloroethane                      | ND     | 1.0 | 0.26 | ug/l  |   |
| 107-06-2   | 1,2-Dichloroethane                      | ND     | 1.0 | 0.28 | ug/l  |   |
| 75-35-4    | 1,1-Dichloroethylene                    | ND     | 1.0 | 0.22 | ug/l  |   |
| 156-59-2   | cis-1,2-Dichloroethylene                | ND     | 1.0 | 0.31 | ug/l  |   |
| 156-60-5   | trans-1,2-Dichloroethylene <sup>a</sup> | ND     | 1.0 | 0.33 | ug/l  |   |
| 78-87-5    | 1,2-Dichloropropane                     | ND     | 1.0 | 0.34 | ug/l  |   |
| 10061-01-5 | cis-1,3-Dichloropropene                 | ND     | 1.0 | 0.26 | ug/l  |   |
| 10061-02-6 | trans-1,3-Dichloropropene               | ND     | 1.0 | 0.25 | ug/l  |   |
| 100-41-4   | Ethylbenzene                            | ND     | 1.0 | 0.25 | ug/l  |   |
| 76-13-1    | Freon 113                               | ND     | 1.0 | 0.32 | ug/l  |   |
| 591-78-6   | 2-Hexanone                              | ND     | 10  | 2.0  | ug/l  |   |
| 98-82-8    | Isopropylbenzene                        | ND     | 1.0 | 0.33 | ug/l  |   |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

Client Sample ID: EB 050316D  
 Lab Sample ID: FA33668-2  
 Matrix: AQ - Equipment Blank  
 Method: SW846 8260C  
 Project: BSMC, Building 5 Area, Humacao, PR

Date Sampled: 05/03/16  
 Date Received: 05/05/16  
 Percent Solids: n/a

## VOA TCL List (SOM02.0)

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 99-87-6   | p-Isopropyltoluene          | ND     | 1.0 | 0.28 | ug/l  |   |
| 79-20-9   | Methyl Acetate              | ND     | 20  | 5.0  | ug/l  |   |
| 74-83-9   | Methyl Bromide              | ND     | 2.0 | 0.50 | ug/l  |   |
| 74-87-3   | Methyl Chloride             | ND     | 2.0 | 0.50 | ug/l  |   |
| 108-87-2  | Methylcyclohexane           | ND     | 1.0 | 0.23 | ug/l  |   |
| 75-09-2   | Methylene Chloride          | ND     | 5.0 | 2.0  | ug/l  |   |
| 108-10-1  | 4-Methyl-2-pentanone (MIBK) | ND     | 5.0 | 1.4  | ug/l  |   |
| 1634-04-4 | Methyl Tert Butyl Ether     | ND     | 1.0 | 0.20 | ug/l  |   |
| 100-42-5  | Styrene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-85-4   | Tert-Amyl Alcohol           | ND     | 20  | 6.0  | ug/l  |   |
| 75-65-0   | Tert-Butyl Alcohol          | ND     | 20  | 9.1  | ug/l  |   |
| 79-34-5   | 1,1,2,2-Tetrachloroethane   | ND     | 1.0 | 0.33 | ug/l  |   |
| 127-18-4  | Tetrachloroethylene         | ND     | 1.0 | 0.30 | ug/l  |   |
| 109-99-9  | Tetrahydrofuran             | ND     | 5.0 | 1.4  | ug/l  |   |
| 108-88-3  | Toluene                     | ND     | 1.0 | 0.20 | ug/l  |   |
| 87-61-6   | 1,2,3-Trichlorobenzene      | ND     | 2.0 | 0.51 | ug/l  |   |
| 120-82-1  | 1,2,4-Trichlorobenzene      | ND     | 2.0 | 0.50 | ug/l  |   |
| 71-55-6   | 1,1,1-Trichloroethane       | ND     | 1.0 | 0.20 | ug/l  |   |
| 79-00-5   | 1,1,2-Trichloroethane       | ND     | 1.0 | 0.37 | ug/l  |   |
| 79-01-6   | Trichloroethylene           | ND     | 1.0 | 0.27 | ug/l  |   |
| 75-69-4   | Trichlorofluoromethane      | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-63-6   | 1,2,4-Trimethylbenzene      | ND     | 1.0 | 0.20 | ug/l  |   |
| 75-01-4   | Vinyl Chloride              | ND     | 1.0 | 0.31 | ug/l  |   |
|           | m,p-Xylene                  | ND     | 2.0 | 0.30 | ug/l  |   |
| 95-47-6   | o-Xylene                    | ND     | 1.0 | 0.26 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 103%   |        | 83-118% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 96%    |        | 79-125% |
| 2037-26-5  | Toluene-D8            | 101%   |        | 85-112% |
| 460-00-4   | 4-Bromofluorobenzene  | 105%   |        | 83-118% |

(a) Associated BS recovery outside control limits.



ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 2

Client Sample ID: S-42S  
 Lab Sample ID: FA33668-3  
 Matrix: AQ - Ground Water  
 Method: SW846 8260C  
 Project: BSMC, Building 5 Area, Humacao, PR

Date Sampled: 05/03/16  
 Date Received: 05/05/16  
 Percent Solids: n/a

| Run #  | File ID    | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|----|-----------|------------|------------------|
| Run #1 | J0976341.D | 1  | 05/06/16 | DP | n/a       | n/a        | VJ5288           |
| Run #2 |            |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

## VOA TCL List (SOM02.0)

| CAS No.    | Compound                    | Result | RL  | MDL  | Units | Q |
|------------|-----------------------------|--------|-----|------|-------|---|
| 67-64-1    | Acetone                     | ND     | 25  | 10   | ug/l  |   |
| 71-43-2    | Benzene                     | ND     | 1.0 | 0.20 | ug/l  |   |
| 100-44-7   | Benzyl Chloride             | ND     | 2.0 | 0.44 | ug/l  |   |
| 74-97-5    | Bromochloromethane          | ND     | 1.0 | 0.42 | ug/l  |   |
| 75-27-4    | Bromodichloromethane        | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-25-2    | Bromoform                   | ND     | 1.0 | 0.46 | ug/l  |   |
| 78-93-3    | 2-Butanone (MEK)            | ND     | 5.0 | 2.6  | ug/l  |   |
| 75-15-0    | Carbon Disulfide            | ND     | 2.0 | 0.23 | ug/l  |   |
| 56-23-5    | Carbon Tetrachloride        | ND     | 1.0 | 0.30 | ug/l  |   |
| 108-90-7   | Chlorobenzene               | 0.44   | 1.0 | 0.20 | ug/l  | J |
| 75-00-3    | Chloroethane                | ND     | 2.0 | 0.63 | ug/l  |   |
| 67-66-3    | Chloroform                  | ND     | 1.0 | 0.30 | ug/l  |   |
| 110-82-7   | Cyclohexane                 | 0.86   | 1.0 | 0.26 | ug/l  | J |
| 124-48-1   | Dibromochloromethane        | ND     | 1.0 | 0.26 | ug/l  |   |
| 96-12-8    | 1,2-Dibromo-3-chloropropane | ND     | 5.0 | 0.81 | ug/l  |   |
| 106-93-4   | 1,2-Dibromoethane           | ND     | 2.0 | 0.33 | ug/l  |   |
| 75-71-8    | Dichlorodifluoromethane     | 0.68   | 2.0 | 0.50 | ug/l  | J |
| 95-50-1    | 1,2-Dichlorobenzene         | ND     | 1.0 | 0.27 | ug/l  |   |
| 541-73-1   | 1,3-Dichlorobenzene         | ND     | 1.0 | 0.24 | ug/l  |   |
| 106-46-7   | 1,4-Dichlorobenzene         | ND     | 1.0 | 0.39 | ug/l  |   |
| 75-34-3    | 1,1-Dichloroethane          | ND     | 1.0 | 0.26 | ug/l  |   |
| 107-06-2   | 1,2-Dichloroethane          | ND     | 1.0 | 0.28 | ug/l  |   |
| 75-35-4    | 1,1-Dichloroethylene        | ND     | 1.0 | 0.22 | ug/l  |   |
| 156-59-2   | cis-1,2-Dichloroethylene    | ND     | 1.0 | 0.31 | ug/l  |   |
| 156-60-5   | trans-1,2-Dichloroethylene  | ND     | 1.0 | 0.33 | ug/l  |   |
| 78-87-5    | 1,2-Dichloropropane         | ND     | 1.0 | 0.34 | ug/l  |   |
| 10061-01-5 | cis-1,3-Dichloropropene     | ND     | 1.0 | 0.26 | ug/l  |   |
| 10061-02-6 | trans-1,3-Dichloropropene   | ND     | 1.0 | 0.25 | ug/l  |   |
| 100-41-4   | Ethylbenzene                | ND     | 1.0 | 0.25 | ug/l  |   |
| 76-13-1    | Freon 113                   | 8.7    | 1.0 | 0.32 | ug/l  |   |
| 591-78-6   | 2-Hexanone                  | ND     | 10  | 2.0  | ug/l  |   |
| 98-82-8    | Isopropylbenzene            | ND     | 1.0 | 0.33 | ug/l  |   |



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

**Client Sample ID:** S-42S  
**Lab Sample ID:** FA33668-3  
**Matrix:** AQ - Ground Water  
**Method:** SW846 8260C  
**Project:** BSMC, Building 5 Area, Humacao, PR

**Date Sampled:** 05/03/16  
**Date Received:** 05/05/16  
**Percent Solids:** n/a

## VOA TCL List (SOM02.0)

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 99-87-6   | p-Isopropyltoluene          | ND     | 1.0 | 0.28 | ug/l  |   |
| 79-20-9   | Methyl Acetate              | ND     | 20  | 5.0  | ug/l  |   |
| 74-83-9   | Methyl Bromide              | ND     | 2.0 | 0.50 | ug/l  |   |
| 74-87-3   | Methyl Chloride             | ND     | 2.0 | 0.50 | ug/l  |   |
| 108-87-2  | Methylcyclohexane           | ND     | 1.0 | 0.23 | ug/l  |   |
| 75-09-2   | Methylene Chloride          | ND     | 5.0 | 2.0  | ug/l  |   |
| 108-10-1  | 4-Methyl-2-pentanone (MIBK) | ND     | 5.0 | 1.4  | ug/l  |   |
| 1634-04-4 | Methyl Tert Butyl Ether     | 1.6    | 1.0 | 0.20 | ug/l  |   |
| 100-42-5  | Styrene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-85-4   | Tert-Amyl Alcohol           | ND     | 20  | 6.0  | ug/l  |   |
| 75-65-0   | Tert-Butyl Alcohol          | ND     | 20  | 9.1  | ug/l  |   |
| 79-34-5   | 1,1,2,2-Tetrachloroethane   | ND     | 1.0 | 0.33 | ug/l  |   |
| 127-18-4  | Tetrachloroethylene         | ND     | 1.0 | 0.30 | ug/l  |   |
| 109-99-9  | Tetrahydrofuran             | ND     | 5.0 | 1.4  | ug/l  |   |
| 108-88-3  | Toluene                     | ND     | 1.0 | 0.20 | ug/l  |   |
| 87-61-6   | 1,2,3-Trichlorobenzene      | ND     | 2.0 | 0.51 | ug/l  |   |
| 120-82-1  | 1,2,4-Trichlorobenzene      | ND     | 2.0 | 0.50 | ug/l  |   |
| 71-55-6   | 1,1,1-Trichloroethane       | ND     | 1.0 | 0.20 | ug/l  |   |
| 79-00-5   | 1,1,2-Trichloroethane       | ND     | 1.0 | 0.37 | ug/l  |   |
| 79-01-6   | Trichloroethylene           | ND     | 1.0 | 0.27 | ug/l  |   |
| 75-69-4   | Trichlorofluoromethane      | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-63-6   | 1,2,4-Trimethylbenzene      | ND     | 1.0 | 0.20 | ug/l  |   |
| 75-01-4   | Vinyl Chloride              | ND     | 1.0 | 0.31 | ug/l  |   |
|           | m,p-Xylene                  | ND     | 2.0 | 0.30 | ug/l  |   |
| 95-47-6   | o-Xylene                    | ND     | 1.0 | 0.26 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 102%   |        | 83-118% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 98%    |        | 79-125% |
| 2037-26-5  | Toluene-D8            | 102%   |        | 85-112% |
| 460-00-4   | 4-Bromofluorobenzene  | 107%   |        | 83-118% |

(a) Associated BS recovery outside control limits.



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 2

|                   |                                     |                 |          |
|-------------------|-------------------------------------|-----------------|----------|
| Client Sample ID: | RA-11 GWS                           | Date Sampled:   | 05/03/16 |
| Lab Sample ID:    | FA33668-4                           | Date Received:  | 05/05/16 |
| Matrix:           | AQ - Ground Water                   | Percent Solids: | n/a      |
| Method:           | SW846 8260C                         |                 |          |
| Project:          | BMSMC, Building 5 Area, Humacao, PR |                 |          |

| Run #  | File ID    | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|----|-----------|------------|------------------|
| Run #1 | J0976342.D | 1  | 05/06/16 | DP | n/a       | n/a        | VJ5288           |
| Run #2 |            |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

## VOA TCL List (SOM02.0)

| CAS No.    | Compound                                | Result | RL  | MDL  | Units | Q |
|------------|---|--------|-----|------|-------|---|
| 67-64-1    | Acetone                                 | ND     | 25  | 10   | ug/l  |   |
| 71-43-2    | Benzene                                 | ND     | 1.0 | 0.20 | ug/l  |   |
| 100-44-7   | Benzyl Chloride                         | ND     | 2.0 | 0.44 | ug/l  |   |
| 74-97-5    | Bromochloromethane                      | ND     | 1.0 | 0.42 | ug/l  |   |
| 75-27-4    | Bromodichloromethane                    | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-25-2    | Bromoform                               | ND     | 1.0 | 0.46 | ug/l  |   |
| 78-93-3    | 2-Butanone (MEK)                        | ND     | 5.0 | 2.6  | ug/l  |   |
| 75-15-0    | Carbon Disulfide                        | ND     | 2.0 | 0.23 | ug/l  |   |
| 56-23-5    | Carbon Tetrachloride                    | ND     | 1.0 | 0.30 | ug/l  |   |
| 108-90-7   | Chlorobenzene                           | 0.76   | 1.0 | 0.20 | ug/l  | J |
| 75-00-3    | Chloroethane                            | ND     | 2.0 | 0.63 | ug/l  |   |
| 67-66-3    | Chloroform                              | ND     | 1.0 | 0.30 | ug/l  |   |
| 110-82-7   | Cyclohexane                             | ND     | 1.0 | 0.26 | ug/l  |   |
| 124-48-1   | Dibromochloromethane                    | ND     | 1.0 | 0.26 | ug/l  |   |
| 96-12-8    | 1,2-Dibromo-3-chloropropane             | ND     | 5.0 | 0.81 | ug/l  |   |
| 106-93-4   | 1,2-Dibromoethane                       | ND     | 2.0 | 0.33 | ug/l  |   |
| 75-71-8    | Dichlorodifluoromethane                 | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-50-1    | 1,2-Dichlorobenzene                     | ND     | 1.0 | 0.27 | ug/l  |   |
| 541-73-1   | 1,3-Dichlorobenzene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 106-46-7   | 1,4-Dichlorobenzene                     | ND     | 1.0 | 0.39 | ug/l  |   |
| 75-34-3    | 1,1-Dichloroethane                      | ND     | 1.0 | 0.26 | ug/l  |   |
| 107-06-2   | 1,2-Dichloroethane                      | ND     | 1.0 | 0.28 | ug/l  |   |
| 75-35-4    | 1,1-Dichloroethylene                    | ND     | 1.0 | 0.22 | ug/l  |   |
| 156-59-2   | cis-1,2-Dichloroethylene                | ND     | 1.0 | 0.31 | ug/l  |   |
| 156-60-5   | trans-1,2-Dichloroethylene <sup>a</sup> | ND     | 1.0 | 0.33 | ug/l  |   |
| 78-87-5    | 1,2-Dichloropropane                     | ND     | 1.0 | 0.34 | ug/l  |   |
| 10061-01-5 | cis-1,3-Dichloropropene                 | ND     | 1.0 | 0.26 | ug/l  |   |
| 10061-02-6 | trans-1,3-Dichloropropene               | ND     | 1.0 | 0.25 | ug/l  |   |
| 100-41-4   | Ethylbenzene                            | ND     | 1.0 | 0.25 | ug/l  |   |
| 76-13-1    | Freon 113                               | ND     | 1.0 | 0.32 | ug/l  |   |
| 591-78-6   | 2-Hexanone                              | ND     | 10  | 2.0  | ug/l  |   |
| 98-82-8    | Isopropylbenzene                        | ND     | 1.0 | 0.33 | ug/l  |   |

ND = Not detected MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound





## Report of Analysis

Client Sample ID: RA-11 GWS  
 Lab Sample ID: FA33668-4  
 Matrix: AQ - Ground Water  
 Method: SW846 8260C  
 Project: BSMC, Building 5 Area, Humacao, PR

Date Sampled: 05/03/16  
 Date Received: 05/05/16  
 Percent Solids: n/a

## VOA TCL List (SOM02.0)

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 99-87-6   | p-Isopropyltoluene          | ND     | 1.0 | 0.28 | ug/l  |   |
| 79-20-9   | Methyl Acetate              | ND     | 20  | 5.0  | ug/l  |   |
| 74-83-9   | Methyl Bromide              | ND     | 2.0 | 0.50 | ug/l  |   |
| 74-87-3   | Methyl Chloride             | ND     | 2.0 | 0.50 | ug/l  |   |
| 108-87-2  | Methylcyclohexane           | ND     | 1.0 | 0.23 | ug/l  |   |
| 75-09-2   | Methylene Chloride          | ND     | 5.0 | 2.0  | ug/l  |   |
| 108-10-1  | 4-Methyl-2-pentanone (MIBK) | ND     | 5.0 | 1.4  | ug/l  |   |
| 1634-04-4 | Methyl Tert Butyl Ether     | 1.7    | 1.0 | 0.20 | ug/l  |   |
| 100-42-5  | Styrene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-85-4   | Tert-Amyl Alcohol           | ND     | 20  | 6.0  | ug/l  |   |
| 75-65-0   | Tert-Butyl Alcohol          | 41.1   | 20  | 9.1  | ug/l  |   |
| 79-34-5   | 1,1,2,2-Tetrachloroethane   | ND     | 1.0 | 0.33 | ug/l  |   |
| 127-18-4  | Tetrachloroethylene         | ND     | 1.0 | 0.30 | ug/l  |   |
| 109-99-9  | Tetrahydrofuran             | ND     | 5.0 | 1.4  | ug/l  |   |
| 108-88-3  | Toluene                     | ND     | 1.0 | 0.20 | ug/l  |   |
| 87-61-6   | 1,2,3-Trichlorobenzene      | ND     | 2.0 | 0.51 | ug/l  |   |
| 120-82-1  | 1,2,4-Trichlorobenzene      | ND     | 2.0 | 0.50 | ug/l  |   |
| 71-55-6   | 1,1,1-Trichloroethane       | ND     | 1.0 | 0.20 | ug/l  |   |
| 79-00-5   | 1,1,2-Trichloroethane       | ND     | 1.0 | 0.37 | ug/l  |   |
| 79-01-6   | Trichloroethylene           | ND     | 1.0 | 0.27 | ug/l  |   |
| 75-69-4   | Trichlorofluoromethane      | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-63-6   | 1,2,4-Trimethylbenzene      | ND     | 1.0 | 0.20 | ug/l  |   |
| 75-01-4   | Vinyl Chloride              | ND     | 1.0 | 0.31 | ug/l  |   |
|           | m,p-Xylene                  | ND     | 2.0 | 0.30 | ug/l  |   |
| 95-47-6   | o-Xylene                    | ND     | 1.0 | 0.26 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 103%   |        | 83-118% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 97%    |        | 79-125% |
| 2037-26-5  | Toluene-D8            | 101%   |        | 85-112% |
| 460-00-4   | 4-Bromofluorobenzene  | 104%   |        | 83-118% |

(a) Associated BS recovery outside control limits.



ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 2

Client Sample ID: BPEB-12  
 Lab Sample ID: FA33668-5  
 Matrix: AQ - Equipment Blank  
 Method: SW846 8260C  
 Project: BSMC, Building 5 Area, Humacao, PR

Date Sampled: 05/03/16  
 Date Received: 05/05/16  
 Percent Solids: n/a

| Run #  | File ID    | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|----|-----------|------------|------------------|
| Run #1 | J0976343.D | 1  | 05/06/16 | DP | n/a       | n/a        | VJ5288           |
| Run #2 |            |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

## VOA TCL List (SOM02.0)

| CAS No.    | Compound                    | Result | RL  | MDL  | Units | Q |
|------------|-----------------------------|--------|-----|------|-------|---|
| 67-64-1    | Acetone                     | ND     | 25  | 10   | ug/l  |   |
| 71-43-2    | Benzene                     | ND     | 1.0 | 0.20 | ug/l  |   |
| 100-44-7   | Benzyl Chloride             | ND     | 2.0 | 0.44 | ug/l  |   |
| 74-97-5    | Bromochloromethane          | ND     | 1.0 | 0.42 | ug/l  |   |
| 75-27-4    | Bromodichloromethane        | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-25-2    | Bromoform                   | ND     | 1.0 | 0.46 | ug/l  |   |
| 78-93-3    | 2-Butanone (MEK)            | ND     | 5.0 | 2.6  | ug/l  |   |
| 75-15-0    | Carbon Disulfide            | ND     | 2.0 | 0.23 | ug/l  |   |
| 56-23-5    | Carbon Tetrachloride        | ND     | 1.0 | 0.30 | ug/l  |   |
| 108-90-7   | Chlorobenzene               | ND     | 1.0 | 0.20 | ug/l  |   |
| 75-00-3    | Chloroethane                | ND     | 2.0 | 0.63 | ug/l  |   |
| 67-66-3    | Chloroform                  | ND     | 1.0 | 0.30 | ug/l  |   |
| 110-82-7   | Cyclohexane                 | ND     | 1.0 | 0.26 | ug/l  |   |
| 124-48-1   | Dibromochloromethane        | ND     | 1.0 | 0.26 | ug/l  |   |
| 96-12-8    | 1,2-Dibromo-3-chloropropane | ND     | 5.0 | 0.81 | ug/l  |   |
| 106-93-4   | 1,2-Dibromoethane           | ND     | 2.0 | 0.33 | ug/l  |   |
| 75-71-8    | Dichlorodifluoromethane     | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-50-1    | 1,2-Dichlorobenzene         | ND     | 1.0 | 0.27 | ug/l  |   |
| 541-73-1   | 1,3-Dichlorobenzene         | ND     | 1.0 | 0.24 | ug/l  |   |
| 106-46-7   | 1,4-Dichlorobenzene         | ND     | 1.0 | 0.39 | ug/l  |   |
| 75-34-3    | 1,1-Dichloroethane          | ND     | 1.0 | 0.26 | ug/l  |   |
| 107-06-2   | 1,2-Dichloroethane          | ND     | 1.0 | 0.28 | ug/l  |   |
| 75-35-4    | 1,1-Dichloroethylene        | ND     | 1.0 | 0.22 | ug/l  |   |
| 156-59-2   | cis-1,2-Dichloroethylene    | ND     | 1.0 | 0.31 | ug/l  |   |
| 156-60-5   | trans-1,2-Dichloroethylene  | ND     | 1.0 | 0.33 | ug/l  |   |
| 78-87-5    | 1,2-Dichloropropane         | ND     | 1.0 | 0.34 | ug/l  |   |
| 10061-01-5 | cis-1,3-Dichloropropene     | ND     | 1.0 | 0.26 | ug/l  |   |
| 10061-02-6 | trans-1,3-Dichloropropene   | ND     | 1.0 | 0.25 | ug/l  |   |
| 100-41-4   | Ethylbenzene                | ND     | 1.0 | 0.25 | ug/l  |   |
| 76-13-1    | Freon 113                   | ND     | 1.0 | 0.32 | ug/l  |   |
| 591-78-6   | 2-Hexanone                  | ND     | 10  | 2.0  | ug/l  |   |
| 98-82-8    | Isopropylbenzene            | ND     | 1.0 | 0.33 | ug/l  |   |

ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



## Report of Analysis

Client Sample ID: BPEB-12  
 Lab Sample ID: FA33668-5  
 Matrix: AQ - Equipment Blank  
 Method: SW846 8260C  
 Project: BSMC, Building 5 Area, Humacao, PR

Date Sampled: 05/03/16  
 Date Received: 05/05/16  
 Percent Solids: n/a

## VOA TCL List (SOM02.0)

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 99-87-6   | p-Isopropyltoluene          | ND     | 1.0 | 0.28 | ug/l  |   |
| 79-20-9   | Methyl Acetate              | ND     | 20  | 5.0  | ug/l  |   |
| 74-83-9   | Methyl Bromide              | ND     | 2.0 | 0.50 | ug/l  |   |
| 74-87-3   | Methyl Chloride             | ND     | 2.0 | 0.50 | ug/l  |   |
| 108-87-2  | Methylcyclohexane           | ND     | 1.0 | 0.23 | ug/l  |   |
| 75-09-2   | Methylene Chloride          | ND     | 5.0 | 2.0  | ug/l  |   |
| 108-10-1  | 4-Methyl-2-pentanone (MIBK) | ND     | 5.0 | 1.4  | ug/l  |   |
| 1634-04-4 | Methyl Tert Butyl Ether     | ND     | 1.0 | 0.20 | ug/l  |   |
| 100-42-5  | Styrene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-85-4   | Tert-Amyl Alcohol           | ND     | 20  | 6.0  | ug/l  |   |
| 75-65-0   | Tert-Butyl Alcohol          | ND     | 20  | 9.1  | ug/l  |   |
| 79-34-5   | 1,1,2,2-Tetrachloroethane   | ND     | 1.0 | 0.33 | ug/l  |   |
| 127-18-4  | Tetrachloroethylene         | ND     | 1.0 | 0.30 | ug/l  |   |
| 109-99-9  | Tetrahydrofuran             | ND     | 5.0 | 1.4  | ug/l  |   |
| 108-88-3  | Toluene                     | ND     | 1.0 | 0.20 | ug/l  |   |
| 87-61-6   | 1,2,3-Trichlorobenzene      | ND     | 2.0 | 0.51 | ug/l  |   |
| 120-82-1  | 1,2,4-Trichlorobenzene      | ND     | 2.0 | 0.50 | ug/l  |   |
| 71-55-6   | 1,1,1-Trichloroethane       | ND     | 1.0 | 0.20 | ug/l  |   |
| 79-00-5   | 1,1,2-Trichloroethane       | ND     | 1.0 | 0.37 | ug/l  |   |
| 79-01-6   | Trichloroethylene           | ND     | 1.0 | 0.27 | ug/l  |   |
| 75-69-4   | Trichlorofluoromethane      | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-63-6   | 1,2,4-Trimethylbenzene      | ND     | 1.0 | 0.20 | ug/l  |   |
| 75-01-4   | Vinyl Chloride              | ND     | 1.0 | 0.31 | ug/l  |   |
|           | m,p-Xylene                  | ND     | 2.0 | 0.30 | ug/l  |   |
| 95-47-6   | o-Xylene                    | ND     | 1.0 | 0.26 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 101%   |        | 83-118% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 98%    |        | 79-125% |
| 2037-26-5  | Toluene-D8            | 96%    |        | 85-112% |
| 460-00-4   | 4-Bromofluorobenzene  | 104%   |        | 83-118% |

(a) Associated BS recovery outside control limits.



ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 2

|                   |                                     |                 |          |
|-------------------|-------------------------------------|-----------------|----------|
| Client Sample ID: | RA-11 (10-11)                       | Date Sampled:   | 05/04/16 |
| Lab Sample ID:    | FA33668-6                           | Date Received:  | 05/05/16 |
| Matrix:           | SO - Soil                           | Percent Solids: | 75.1     |
| Method:           | SW846 8260C                         |                 |          |
| Project:          | BMSMC, Building 5 Area, Humacao, PR |                 |          |

| Run #  | File ID  | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|----------|----|----------|----|-----------|------------|------------------|
| Run #1 | Y28348.D | 1  | 05/05/16 | AD | n/a       | n/a        | VY1148           |
| Run #2 |          |    |          |    |           |            |                  |

| Run #  | Initial Weight | Final Volume |
|--------|----------------|--------------|
| Run #1 | 5.39 g         | 5.0 ml       |
| Run #2 |                |              |

## VOA TCL List (SOM02.0)

| CAS No.    | Compound                    | Result | RL  | MDL | Units | Q |
|------------|-----------------------------|--------|-----|-----|-------|---|
| 67-64-1    | Acetone                     | ND     | 62  | 13  | ug/kg |   |
| 71-43-2    | Benzene                     | ND     | 6.2 | 1.6 | ug/kg |   |
| 100-44-7   | Benzyl Chloride             | ND     | 6.2 | 1.7 | ug/kg |   |
| 74-97-5    | Bromochloromethane          | ND     | 6.2 | 1.4 | ug/kg |   |
| 75-27-4    | Bromodichloromethane        | ND     | 6.2 | 1.2 | ug/kg |   |
| 75-25-2    | Bromoform                   | ND     | 6.2 | 1.2 | ug/kg |   |
| 78-93-3    | 2-Butanone (MEK)            | ND     | 31  | 11  | ug/kg |   |
| 75-15-0    | Carbon Disulfide            | ND     | 6.2 | 1.2 | ug/kg |   |
| 56-23-5    | Carbon Tetrachloride        | ND     | 6.2 | 2.2 | ug/kg |   |
| 108-90-7   | Chlorobenzene               | ND     | 6.2 | 1.2 | ug/kg |   |
| 75-00-3    | Chloroethane                | ND     | 6.2 | 2.5 | ug/kg |   |
| 67-66-3    | Chloroform                  | ND     | 6.2 | 1.5 | ug/kg |   |
| 110-82-7   | Cyclohexane                 | ND     | 6.2 | 1.5 | ug/kg |   |
| 124-48-1   | Dibromochloromethane        | ND     | 6.2 | 1.2 | ug/kg |   |
| 96-12-8    | 1,2-Dibromo-3-chloropropane | ND     | 6.2 | 2.7 | ug/kg |   |
| 106-93-4   | 1,2-Dibromoethane           | ND     | 6.2 | 1.2 | ug/kg |   |
| 75-71-8    | Dichlorodifluoromethane     | ND     | 6.2 | 3.1 | ug/kg |   |
| 95-50-1    | 1,2-Dichlorobenzene         | ND     | 6.2 | 1.2 | ug/kg |   |
| 541-73-1   | 1,3-Dichlorobenzene         | ND     | 6.2 | 1.2 | ug/kg |   |
| 106-46-7   | 1,4-Dichlorobenzene         | ND     | 6.2 | 1.3 | ug/kg |   |
| 75-34-3    | 1,1-Dichloroethane          | ND     | 6.2 | 2.1 | ug/kg |   |
| 107-06-2   | 1,2-Dichloroethane          | ND     | 6.2 | 1.2 | ug/kg |   |
| 75-35-4    | 1,1-Dichloroethylene        | ND     | 6.2 | 1.2 | ug/kg |   |
| 156-59-2   | cis-1,2-Dichloroethylene    | ND     | 6.2 | 1.5 | ug/kg |   |
| 156-60-5   | trans-1,2-Dichloroethylene  | ND     | 6.2 | 1.9 | ug/kg |   |
| 78-87-5    | 1,2-Dichloropropane         | ND     | 6.2 | 2.0 | ug/kg |   |
| 10061-01-5 | cis-1,3-Dichloropropene     | ND     | 6.2 | 2.3 | ug/kg |   |
| 10061-02-6 | trans-1,3-Dichloropropene   | ND     | 6.2 | 1.2 | ug/kg |   |
| 100-41-4   | Ethylbenzene                | ND     | 6.2 | 1.3 | ug/kg |   |
| 76-13-1    | Freon 113                   | ND     | 6.2 | 1.4 | ug/kg |   |
| 591-78-6   | 2-Hexanone                  | ND     | 31  | 11  | ug/kg |   |
| 98-82-8    | Isopropylbenzene            | ND     | 6.2 | 1.7 | ug/kg |   |

ND = Not detected MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound



## Report of Analysis

Client Sample ID: RA-11 (10-11)  
 Lab Sample ID: FA33668-6  
 Matrix: SO - Soil  
 Method: SW846 8260C  
 Project: BSMC, Building 5 Area, Humacao, PR

Date Sampled: 05/04/16  
 Date Received: 05/05/16  
 Percent Solids: 75.1

## VOA TCL List (SOM02.0)

| CAS No.   | Compound                    | Result | RL  | MDL | Units | Q |
|-----------|-----------------------------|--------|-----|-----|-------|---|
| 99-87-6   | p-Isopropyltoluene          | ND     | 6.2 | 1.2 | ug/kg |   |
| 79-20-9   | Methyl Acetate              | ND     | 31  | 11  | ug/kg |   |
| 74-83-9   | Methyl Bromide              | ND     | 6.2 | 3.2 | ug/kg |   |
| 74-87-3   | Methyl Chloride             | ND     | 6.2 | 3.0 | ug/kg |   |
| 108-87-2  | Methylcyclohexane           | ND     | 6.2 | 1.2 | ug/kg |   |
| 75-09-2   | Methylene Chloride          | 5.0    | 12  | 4.9 | ug/kg | J |
| 108-10-1  | 4-Methyl-2-pentanone (MIBK) | ND     | 31  | 13  | ug/kg |   |
| 1634-04-4 | Methyl Tert Butyl Ether     | ND     | 6.2 | 1.4 | ug/kg |   |
| 100-42-5  | Styrene                     | ND     | 6.2 | 1.2 | ug/kg |   |
| 75-85-4   | Tert-Amyl Alcohol           | ND     | 62  | 17  | ug/kg |   |
| 75-65-0   | Tert-Butyl Alcohol          | ND     | 62  | 17  | ug/kg |   |
| 79-34-5   | 1,1,2,2-Tetrachloroethane   | ND     | 6.2 | 2.7 | ug/kg |   |
| 127-18-4  | Tetrachloroethylene         | ND     | 6.2 | 1.6 | ug/kg |   |
| 109-99-9  | Tetrahydrofuran             | ND     | 12  | 4.5 | ug/kg |   |
| 108-88-3  | Toluene                     | ND     | 6.2 | 1.4 | ug/kg |   |
| 87-61-6   | 1,2,3-Trichlorobenzene      | ND     | 6.2 | 2.4 | ug/kg |   |
| 120-82-1  | 1,2,4-Trichlorobenzene      | ND     | 6.2 | 1.8 | ug/kg |   |
| 71-55-6   | 1,1,1-Trichloroethane       | ND     | 6.2 | 1.2 | ug/kg |   |
| 79-00-5   | 1,1,2-Trichloroethane       | ND     | 6.2 | 2.2 | ug/kg |   |
| 79-01-6   | Trichloroethylene           | ND     | 6.2 | 1.4 | ug/kg |   |
| 75-69-4   | Trichlorofluoromethane      | ND     | 6.2 | 2.3 | ug/kg |   |
| 95-63-6   | 1,2,4-Trimethylbenzene      | ND     | 6.2 | 1.2 | ug/kg |   |
| 75-01-4   | Vinyl Chloride              | ND     | 6.2 | 2.1 | ug/kg |   |
|           | m,p-Xylene                  | ND     | 12  | 2.2 | ug/kg |   |
| 95-47-6   | o-Xylene                    | ND     | 6.2 | 1.4 | ug/kg |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 107%   |        | 75-124% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 110%   |        | 72-135% |
| 2037-26-5  | Toluene-D8            | 100%   |        | 75-126% |
| 460-00-4   | 4-Bromofluorobenzene  | 100%   |        | 71-133% |



SGS Accutest

## Report of Analysis

Page 1 of 2

|                   |                                     |                 |          |
|-------------------|-------------------------------------|-----------------|----------|
| Client Sample ID: | S-43S                               | Date Sampled:   | 05/04/16 |
| Lab Sample ID:    | FA33668-7                           | Date Received:  | 05/05/16 |
| Matrix:           | AQ - Ground Water                   | Percent Solids: | n/a      |
| Method:           | SW846 8260C                         |                 |          |
| Project:          | BMSMC, Building 5 Area, Humacao, PR |                 |          |

| Run #  | File ID    | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|----|-----------|------------|------------------|
| Run #1 | J0976344.D | 1  | 05/06/16 | DP | n/a       | n/a        | VJ5288           |
| Run #2 |            |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

## VOA TCL List (SOM02.0)

| CAS No.    | Compound                                | Result | RL  | MDL  | Units | Q |
|------------|---|--------|-----|------|-------|---|
| 67-64-1    | Acetone                                 | ND     | 25  | 10   | ug/l  |   |
| 71-43-2    | Benzene                                 | 0.46   | 1.0 | 0.20 | ug/l  | J |
| 100-44-7   | Benzyl Chloride                         | ND     | 2.0 | 0.44 | ug/l  |   |
| 74-97-5    | Bromochloromethane                      | ND     | 1.0 | 0.42 | ug/l  |   |
| 75-27-4    | Bromodichloromethane                    | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-25-2    | Bromoform                               | ND     | 1.0 | 0.46 | ug/l  |   |
| 78-93-3    | 2-Butanone (MEK)                        | ND     | 5.0 | 2.6  | ug/l  |   |
| 75-15-0    | Carbon Disulfide                        | ND     | 2.0 | 0.23 | ug/l  |   |
| 56-23-5    | Carbon Tetrachloride                    | ND     | 1.0 | 0.30 | ug/l  |   |
| 108-90-7   | Chlorobenzene                           | 12.9   | 1.0 | 0.20 | ug/l  |   |
| 75-00-3    | Chloroethane                            | ND     | 2.0 | 0.63 | ug/l  |   |
| 67-66-3    | Chloroform                              | ND     | 1.0 | 0.30 | ug/l  |   |
| 110-82-7   | Cyclohexane                             | 6.3    | 1.0 | 0.26 | ug/l  |   |
| 124-48-1   | Dibromochloromethane                    | ND     | 1.0 | 0.26 | ug/l  |   |
| 96-12-8    | 1,2-Dibromo-3-chloropropane             | ND     | 5.0 | 0.81 | ug/l  |   |
| 106-93-4   | 1,2-Dibromoethane                       | ND     | 2.0 | 0.33 | ug/l  |   |
| 75-71-8    | Dichlorodifluoromethane                 | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-50-1    | 1,2-Dichlorobenzene                     | ND     | 1.0 | 0.27 | ug/l  |   |
| 541-73-1   | 1,3-Dichlorobenzene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 106-46-7   | 1,4-Dichlorobenzene                     | ND     | 1.0 | 0.39 | ug/l  |   |
| 75-34-3    | 1,1-Dichloroethane                      | ND     | 1.0 | 0.26 | ug/l  |   |
| 107-06-2   | 1,2-Dichloroethane                      | ND     | 1.0 | 0.28 | ug/l  |   |
| 75-35-4    | 1,1-Dichloroethylene                    | ND     | 1.0 | 0.22 | ug/l  |   |
| 156-59-2   | cis-1,2-Dichloroethylene                | ND     | 1.0 | 0.31 | ug/l  |   |
| 156-60-5   | trans-1,2-Dichloroethylene <sup>a</sup> | ND     | 1.0 | 0.33 | ug/l  |   |
| 78-87-5    | 1,2-Dichloropropane                     | ND     | 1.0 | 0.34 | ug/l  |   |
| 10061-01-5 | cis-1,3-Dichloropropene                 | ND     | 1.0 | 0.26 | ug/l  |   |
| 10061-02-6 | trans-1,3-Dichloropropene               | ND     | 1.0 | 0.25 | ug/l  |   |
| 100-41-4   | Ethylbenzene                            | ND     | 1.0 | 0.25 | ug/l  |   |
| 76-13-1    | Freon 113                               | ND     | 1.0 | 0.32 | ug/l  |   |
| 591-78-6   | 2-Hexanone                              | ND     | 10  | 2.0  | ug/l  |   |
| 98-82-8    | Isopropylbenzene                        | 10.1   | 1.0 | 0.33 | ug/l  |   |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

## Report of Analysis

Client Sample ID: S-43S  
 Lab Sample ID: FA33668-7  
 Matrix: AQ - Ground Water  
 Method: SW846 8260C  
 Project: BSMC, Building 5 Area, Humacao, PR

Date Sampled: 05/04/16  
 Date Received: 05/05/16  
 Percent Solids: n/a

## VOA TCL List (SOM02.0)

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 99-87-6   | p-Isopropyltoluene          | ND     | 1.0 | 0.28 | ug/l  |   |
| 79-20-9   | Methyl Acetate              | ND     | 20  | 5.0  | ug/l  |   |
| 74-83-9   | Methyl Bromide              | ND     | 2.0 | 0.50 | ug/l  |   |
| 74-87-3   | Methyl Chloride             | ND     | 2.0 | 0.50 | ug/l  |   |
| 108-87-2  | Methylcyclohexane           | ND     | 1.0 | 0.23 | ug/l  |   |
| 75-09-2   | Methylene Chloride          | ND     | 5.0 | 2.0  | ug/l  |   |
| 108-10-1  | 4-Methyl-2-pentanone (MIBK) | ND     | 5.0 | 1.4  | ug/l  |   |
| 1634-04-4 | Methyl Tert Butyl Ether     | 11.0   | 1.0 | 0.20 | ug/l  |   |
| 100-42-5  | Styrene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-85-4   | Tert-Amyl Alcohol           | 12.8   | 20  | 6.0  | ug/l  | J |
| 75-65-0   | Tert-Butyl Alcohol          | 223    | 20  | 9.1  | ug/l  |   |
| 79-34-5   | 1,1,2,2-Tetrachloroethane   | ND     | 1.0 | 0.33 | ug/l  |   |
| 127-18-4  | Tetrachloroethylene         | ND     | 1.0 | 0.30 | ug/l  |   |
| 109-99-9  | Tetrahydrofuran             | 1.7    | 5.0 | 1.4  | ug/l  | J |
| 108-88-3  | Toluene                     | 0.27   | 1.0 | 0.20 | ug/l  | J |
| 87-61-6   | 1,2,3-Trichlorobenzene      | ND     | 2.0 | 0.51 | ug/l  |   |
| 120-82-1  | 1,2,4-Trichlorobenzene      | ND     | 2.0 | 0.50 | ug/l  |   |
| 71-55-6   | 1,1,1-Trichloroethane       | ND     | 1.0 | 0.20 | ug/l  |   |
| 79-00-5   | 1,1,2-Trichloroethane       | ND     | 1.0 | 0.37 | ug/l  |   |
| 79-01-6   | Trichloroethylene           | ND     | 1.0 | 0.27 | ug/l  |   |
| 75-69-4   | Trichlorofluoromethane      | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-63-6   | 1,2,4-Trimethylbenzene      | ND     | 1.0 | 0.20 | ug/l  |   |
| 75-01-4   | Vinyl Chloride              | ND     | 1.0 | 0.31 | ug/l  |   |
|           | m,p-Xylene                  | ND     | 2.0 | 0.30 | ug/l  |   |
| 95-47-6   | o-Xylene                    | ND     | 1.0 | 0.26 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 101%   |        | 83-118% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 100%   |        | 79-125% |
| 2037-26-5  | Toluene-D8            | 98%    |        | 85-112% |
| 460-00-4   | 4-Bromofluorobenzene  | 107%   |        | 83-118% |

(a) Associated BS recovery outside control limits.



ND = Not detected    MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 2

|                   |                                     |                 |          |
|-------------------|-------------------------------------|-----------------|----------|
| Client Sample ID: | RA-10 (5.5-6.5)                     | Date Sampled:   | 05/04/16 |
| Lab Sample ID:    | FA33668-8                           | Date Received:  | 05/05/16 |
| Matrix:           | SO - Soil                           | Percent Solids: | 80.7     |
| Method:           | SW846 8260C                         |                 |          |
| Project:          | BMSMC, Building 5 Area, Humacao, PR |                 |          |

| Run #  | File ID  | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|----------|----|----------|----|-----------|------------|------------------|
| Run #1 | Y28349.D | 1  | 05/05/16 | AD | n/a       | n/a        | VY1148           |
| Run #2 |          |    |          |    |           |            |                  |

| Run #  | Initial Weight | Final Volume |
|--------|----------------|--------------|
| Run #1 | 5.73 g         | 5.0 ml       |
| Run #2 |                |              |

## VOA TCL List (SOM02.0)

| CAS No.    | Compound                    | Result | RL  | MDL | Units | Q |
|------------|-----------------------------|--------|-----|-----|-------|---|
| 67-64-1    | Acetone                     | ND     | 54  | 11  | ug/kg |   |
| 71-43-2    | Benzene                     | ND     | 5.4 | 1.4 | ug/kg |   |
| 100-44-7   | Benzyl Chloride             | ND     | 5.4 | 1.5 | ug/kg |   |
| 74-97-5    | Bromochloromethane          | ND     | 5.4 | 1.2 | ug/kg |   |
| 75-27-4    | Bromodichloromethane        | ND     | 5.4 | 1.1 | ug/kg |   |
| 75-25-2    | Bromoform                   | ND     | 5.4 | 1.1 | ug/kg |   |
| 78-93-3    | 2-Butanone (MEK)            | ND     | 27  | 9.8 | ug/kg |   |
| 75-15-0    | Carbon Disulfide            | ND     | 5.4 | 1.1 | ug/kg |   |
| 56-23-5    | Carbon Tetrachloride        | ND     | 5.4 | 1.9 | ug/kg |   |
| 108-90-7   | Chlorobenzene               | ND     | 5.4 | 1.1 | ug/kg |   |
| 75-00-3    | Chloroethane                | ND     | 5.4 | 2.2 | ug/kg |   |
| 67-66-3    | Chloroform                  | ND     | 5.4 | 1.3 | ug/kg |   |
| 110-82-7   | Cyclohexane                 | ND     | 5.4 | 1.3 | ug/kg |   |
| 124-48-1   | Dibromochloromethane        | ND     | 5.4 | 1.1 | ug/kg |   |
| 96-12-8    | 1,2-Dibromo-3-chloropropane | ND     | 5.4 | 2.4 | ug/kg |   |
| 106-93-4   | 1,2-Dibromoethane           | ND     | 5.4 | 1.1 | ug/kg |   |
| 75-71-8    | Dichlorodifluoromethane     | ND     | 5.4 | 2.7 | ug/kg |   |
| 95-50-1    | 1,2-Dichlorobenzene         | ND     | 5.4 | 1.1 | ug/kg |   |
| 541-73-1   | 1,3-Dichlorobenzene         | ND     | 5.4 | 1.1 | ug/kg |   |
| 106-46-7   | 1,4-Dichlorobenzene         | ND     | 5.4 | 1.1 | ug/kg |   |
| 75-34-3    | 1,1-Dichloroethane          | ND     | 5.4 | 1.8 | ug/kg |   |
| 107-06-2   | 1,2-Dichloroethane          | ND     | 5.4 | 1.1 | ug/kg |   |
| 75-35-4    | 1,1-Dichloroethylene        | ND     | 5.4 | 1.1 | ug/kg |   |
| 156-59-2   | cis-1,2-Dichloroethylene    | ND     | 5.4 | 1.3 | ug/kg |   |
| 156-60-5   | trans-1,2-Dichloroethylene  | ND     | 5.4 | 1.6 | ug/kg |   |
| 78-87-5    | 1,2-Dichloropropane         | ND     | 5.4 | 1.7 | ug/kg |   |
| 10061-01-5 | cis-1,3-Dichloropropene     | ND     | 5.4 | 2.1 | ug/kg |   |
| 10061-02-6 | trans-1,3-Dichloropropene   | ND     | 5.4 | 1.1 | ug/kg |   |
| 100-41-4   | Ethylbenzene                | ND     | 5.4 | 1.2 | ug/kg |   |
| 76-13-1    | Freon 113                   | ND     | 5.4 | 1.3 | ug/kg |   |
| 591-78-6   | 2-Hexanone                  | ND     | 27  | 9.4 | ug/kg |   |
| 98-82-8    | Isopropylbenzene            | ND     | 5.4 | 1.5 | ug/kg |   |



ND = Not detected      MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



## Report of Analysis

Client Sample ID: RA-10 (5.5-6.5)  
 Lab Sample ID: FA33668-8  
 Matrix: SO - Soil  
 Method: SW846 8260C  
 Project: BSMC, Building 5 Area, Humacao, PR

Date Sampled: 05/04/16  
 Date Received: 05/05/16  
 Percent Solids: 80.7

## VOA TCL List (SOM02.0)

| CAS No.   | Compound                    | Result | RL  | MDL | Units | Q |
|-----------|-----------------------------|--------|-----|-----|-------|---|
| 99-87-6   | p-Isopropyltoluene          | ND     | 5.4 | 1.1 | ug/kg |   |
| 79-20-9   | Methyl Acetate              | ND     | 27  | 9.3 | ug/kg |   |
| 74-83-9   | Methyl Bromide              | ND     | 5.4 | 2.8 | ug/kg |   |
| 74-87-3   | Methyl Chloride             | ND     | 5.4 | 2.6 | ug/kg |   |
| 108-87-2  | Methylcyclohexane           | ND     | 5.4 | 1.1 | ug/kg |   |
| 75-09-2   | Methylene Chloride          | ND     | 11  | 4.3 | ug/kg |   |
| 108-10-1  | 4-Methyl-2-pentanone (MIBK) | ND     | 27  | 12  | ug/kg |   |
| 1634-04-4 | Methyl Tert Butyl Ether     | ND     | 5.4 | 1.2 | ug/kg |   |
| 100-42-5  | Styrene                     | ND     | 5.4 | 1.1 | ug/kg |   |
| 75-85-4   | Tert-Amyl Alcohol           | ND     | 54  | 15  | ug/kg |   |
| 75-65-0   | Tert-Butyl Alcohol          | ND     | 54  | 15  | ug/kg |   |
| 79-34-5   | 1,1,2,2-Tetrachloroethane   | ND     | 5.4 | 2.4 | ug/kg |   |
| 127-18-4  | Tetrachloroethylene         | ND     | 5.4 | 1.4 | ug/kg |   |
| 109-99-9  | Tetrahydrofuran             | ND     | 11  | 3.9 | ug/kg |   |
| 108-88-3  | Toluene                     | ND     | 5.4 | 1.2 | ug/kg |   |
| 87-61-6   | 1,2,3-Trichlorobenzene      | ND     | 5.4 | 2.1 | ug/kg |   |
| 120-82-1  | 1,2,4-Trichlorobenzene      | ND     | 5.4 | 1.6 | ug/kg |   |
| 71-55-6   | 1,1,1-Trichloroethane       | ND     | 5.4 | 1.1 | ug/kg |   |
| 79-00-5   | 1,1,2-Trichloroethane       | ND     | 5.4 | 2.0 | ug/kg |   |
| 79-01-6   | Trichloroethylene           | ND     | 5.4 | 1.3 | ug/kg |   |
| 75-69-4   | Trichlorofluoromethane      | ND     | 5.4 | 2.0 | ug/kg |   |
| 95-63-6   | 1,2,4-Trimethylbenzene      | ND     | 5.4 | 1.1 | ug/kg |   |
| 75-01-4   | Vinyl Chloride              | ND     | 5.4 | 1.8 | ug/kg |   |
|           | m,p-Xylene                  | ND     | 11  | 1.9 | ug/kg |   |
| 95-47-6   | o-Xylene                    | ND     | 5.4 | 1.2 | ug/kg |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 107%   |        | 75-124% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 111%   |        | 72-135% |
| 2037-26-5  | Toluene-D8            | 101%   |        | 75-126% |
| 460-00-4   | 4-Bromofluorobenzene  | 98%    |        | 71-133% |



ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

SGS Accutest

## Report of Analysis

Page 1 of 2

|                   |                                     |                 |          |
|-------------------|-------------------------------------|-----------------|----------|
| Client Sample ID: | TB 050416                           | Date Sampled:   | 04/11/16 |
| Lab Sample ID:    | FA33668-9                           | Date Received:  | 05/05/16 |
| Matrix:           | AQ - Trip Blank Water               | Percent Solids: | n/a      |
| Method:           | SW846 8260C                         |                 |          |
| Project:          | BMSMC, Building 5 Area, Humacao, PR |                 |          |

| Run #  | File ID    | DF | Analyzed | By | Prep Date | Prep Batch | Analytical Batch |
|--------|------------|----|----------|----|-----------|------------|------------------|
| Run #1 | J0976345.D | 1  | 05/06/16 | DP | n/a       | n/a        | VJ5288           |
| Run #2 |            |    |          |    |           |            |                  |

| Run #  | Purge Volume |
|--------|--------------|
| Run #1 | 5.0 ml       |
| Run #2 |              |

## VOA TCL List (SOM02.0)

| CAS No.    | Compound                                | Result | RL  | MDL  | Units | Q |
|------------|---|--------|-----|------|-------|---|
| 67-64-1    | Acetone                                 | ND     | 25  | 10   | ug/l  |   |
| 71-43-2    | Benzene                                 | ND     | 1.0 | 0.20 | ug/l  |   |
| 100-44-7   | Benzyl Chloride                         | ND     | 2.0 | 0.44 | ug/l  |   |
| 74-97-5    | Bromochloromethane                      | ND     | 1.0 | 0.42 | ug/l  |   |
| 75-27-4    | Bromodichloromethane                    | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-25-2    | Bromoform                               | ND     | 1.0 | 0.46 | ug/l  |   |
| 78-93-3    | 2-Butanone (MEK)                        | ND     | 5.0 | 2.6  | ug/l  |   |
| 75-15-0    | Carbon Disulfide                        | ND     | 2.0 | 0.23 | ug/l  |   |
| 56-23-5    | Carbon Tetrachloride                    | ND     | 1.0 | 0.30 | ug/l  |   |
| 108-90-7   | Chlorobenzene                           | ND     | 1.0 | 0.20 | ug/l  |   |
| 75-00-3    | Chloroethane                            | ND     | 2.0 | 0.63 | ug/l  |   |
| 67-66-3    | Chloroform                              | ND     | 1.0 | 0.30 | ug/l  |   |
| 110-82-7   | Cyclohexane                             | ND     | 1.0 | 0.26 | ug/l  |   |
| 124-48-1   | Dibromochloromethane                    | ND     | 1.0 | 0.26 | ug/l  |   |
| 96-12-8    | 1,2-Dibromo-3-chloropropane             | ND     | 5.0 | 0.81 | ug/l  |   |
| 106-93-4   | 1,2-Dibromoethane                       | ND     | 2.0 | 0.33 | ug/l  |   |
| 75-71-8    | Dichlorodifluoromethane                 | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-50-1    | 1,2-Dichlorobenzene                     | ND     | 1.0 | 0.27 | ug/l  |   |
| 541-73-1   | 1,3-Dichlorobenzene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 106-46-7   | 1,4-Dichlorobenzene                     | ND     | 1.0 | 0.39 | ug/l  |   |
| 75-34-3    | 1,1-Dichloroethane                      | ND     | 1.0 | 0.26 | ug/l  |   |
| 107-06-2   | 1,2-Dichloroethane                      | ND     | 1.0 | 0.28 | ug/l  |   |
| 75-35-4    | 1,1-Dichloroethylene                    | ND     | 1.0 | 0.22 | ug/l  |   |
| 156-59-2   | cis-1,2-Dichloroethylene                | ND     | 1.0 | 0.31 | ug/l  |   |
| 156-60-5   | trans-1,2-Dichloroethylene <sup>b</sup> | ND     | 1.0 | 0.33 | ug/l  |   |
| 78-87-5    | 1,2-Dichloropropane                     | ND     | 1.0 | 0.34 | ug/l  |   |
| 10061-01-5 | cis-1,3-Dichloropropene                 | ND     | 1.0 | 0.26 | ug/l  |   |
| 10061-02-6 | trans-1,3-Dichloropropene               | ND     | 1.0 | 0.25 | ug/l  |   |
| 100-41-4   | Ethylbenzene                            | ND     | 1.0 | 0.25 | ug/l  |   |
| 76-13-1    | Freon 113                               | ND     | 1.0 | 0.32 | ug/l  |   |
| 591-78-6   | 2-Hexanone                              | ND     | 10  | 2.0  | ug/l  |   |
| 98-82-8    | Isopropylbenzene                        | ND     | 1.0 | 0.33 | ug/l  |   |

ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound



## Report of Analysis

Client Sample ID: TB 050416  
 Lab Sample ID: FA33668-9  
 Matrix: AQ - Trip Blank Water  
 Method: SW846 8260C  
 Project: BMSMC, Building 5 Area, Humacao, PR

Date Sampled: 04/11/16  
 Date Received: 05/05/16  
 Percent Solids: n/a

## VOA TCL List (SOM02.0)

| CAS No.   | Compound                    | Result | RL  | MDL  | Units | Q |
|-----------|-----------------------------|--------|-----|------|-------|---|
| 99-87-6   | p-Isopropyltoluene          | ND     | 1.0 | 0.28 | ug/l  |   |
| 79-20-9   | Methyl Acetate              | ND     | 20  | 5.0  | ug/l  |   |
| 74-83-9   | Methyl Bromide              | ND     | 2.0 | 0.50 | ug/l  |   |
| 74-87-3   | Methyl Chloride             | ND     | 2.0 | 0.50 | ug/l  |   |
| 108-87-2  | Methylcyclohexane           | ND     | 1.0 | 0.23 | ug/l  |   |
| 75-09-2   | Methylene Chloride          | ND     | 5.0 | 2.0  | ug/l  |   |
| 108-10-1  | 4-Methyl-2-pentanone (MIBK) | ND     | 5.0 | 1.4  | ug/l  |   |
| 1634-04-4 | Methyl Tert Butyl Ether     | ND     | 1.0 | 0.20 | ug/l  |   |
| 100-42-5  | Styrene                     | ND     | 1.0 | 0.24 | ug/l  |   |
| 75-85-4   | Tert-Amyl Alcohol           | ND     | 20  | 6.0  | ug/l  |   |
| 75-65-0   | Tert-Butyl Alcohol          | ND     | 20  | 9.1  | ug/l  |   |
| 79-34-5   | 1,1,2,2-Tetrachloroethane   | ND     | 1.0 | 0.33 | ug/l  |   |
| 127-18-4  | Tetrachloroethylene         | ND     | 1.0 | 0.30 | ug/l  |   |
| 109-99-9  | Tetrahydrofuran             | ND     | 5.0 | 1.4  | ug/l  |   |
| 108-88-3  | Toluene                     | ND     | 1.0 | 0.20 | ug/l  |   |
| 87-61-6   | 1,2,3-Trichlorobenzene      | ND     | 2.0 | 0.51 | ug/l  |   |
| 120-82-1  | 1,2,4-Trichlorobenzene      | ND     | 2.0 | 0.50 | ug/l  |   |
| 71-55-6   | 1,1,1-Trichloroethane       | ND     | 1.0 | 0.20 | ug/l  |   |
| 79-00-5   | 1,1,2-Trichloroethane       | ND     | 1.0 | 0.37 | ug/l  |   |
| 79-01-6   | Trichloroethylene           | ND     | 1.0 | 0.27 | ug/l  |   |
| 75-69-4   | Trichlorofluoromethane      | ND     | 2.0 | 0.50 | ug/l  |   |
| 95-63-6   | 1,2,4-Trimethylbenzene      | ND     | 1.0 | 0.20 | ug/l  |   |
| 75-01-4   | Vinyl Chloride              | ND     | 1.0 | 0.31 | ug/l  |   |
|           | m,p-Xylene                  | ND     | 2.0 | 0.30 | ug/l  |   |
| 95-47-6   | o-Xylene                    | ND     | 1.0 | 0.26 | ug/l  |   |

| CAS No.    | Surrogate Recoveries  | Run# 1 | Run# 2 | Limits  |
|------------|-----------------------|--------|--------|---------|
| 1868-53-7  | Dibromofluoromethane  | 102%   |        | 83-118% |
| 17060-07-0 | 1,2-Dichloroethane-D4 | 96%    |        | 79-125% |
| 2037-26-5  | Toluene-D8            | 101%   |        | 85-112% |
| 460-00-4   | 4-Bromofluorobenzene  | 105%   |        | 83-118% |

(a) Sample received outside the holding time.

(b) Associated BS recovery outside control limits.



ND = Not detected MDL = Method Detection Limit  
 RL = Reporting Limit  
 E = Indicates value exceeds calibration range

J = Indicates an estimated value  
 B = Indicates analyte found in associated method blank  
 N = Indicates presumptive evidence of a compound

**Misc. Forms**

---

**Custody Documents and Other Forms**

---

**Includes the following where applicable:**

- Chain of Custody

SGS

ACCUTEST-FL

## CHAIN OF CUSTODY

SGS Accredited "Daytest" Florida  
 7333 Route 950, Boynton, FL 33420  
 TEL: 732-329-0280 FAX: 732-329-3499/3480  
 www.accutest.com

FA33668

PAGE 1 OF 1

802591276584

Date Chain Custody

6/21/16 From NJ

|  |  |  |  |   |  |
|--|--|--|--|---|--|
| Company Name<br><b>Anderson Mulholland Assoc. Inc.</b>   |  | Project Name<br><b>BMS Release Assessment</b>  |  | Billing Information (if different from Report to)   |  |
| Street Address<br><b>2700 Westchester</b>  |  | City<br><b>HUMACAO</b>   |  | Company Name  |  |
| State<br><b>Purchase NY</b>  |  | Zip<br><b>PR</b>   |  | Street Address  |  |
| Project Contact<br><b>Terry Taylor</b>   |  | Project #  |  | City  |  |
| Phone #<br><b>914-251-0400</b>   |  | Client Purchase Order #  |  | State   |  |
| Demographic Name(s)<br><b>N. Rivera, T. Taylor, D. Lindstrom</b>   |  | Project Manager  |  | Zip   |  |
| Field ID / Point of Collection   |  | Date   |  | Time  |  |
| All Chain Custody  |  | Sample by  |  | Number of samples   |  |
| 1 RA-16 GWD  |  | 5/3/16   |  | 1100 TT GW 3 3  |  |
| 2 EB050316   |  | 5/3/16   |  | 1112 NR EB 3 3  |  |
| 3 S-425  |  | 5/3/16   |  | 1535 NR GW 3 3  |  |
| 4 RA-11 GWS  |  | 5/3/16   |  | 1645 TT GW 3 3  |  |
| 5 BPER-12  |  | 5/3/16   |  | 1730 TT EB 3 3  |  |
| 6 RA-11 (10-11)  |  | 5/4/16   |  | 1110 TT SO 4 1 3  |  |
| 7 S-435  |  | 5/4/16   |  | 1210 JV GW 3 3  |  |
| 8 RA-10 (S.S.-G.S)   |  | 5/4/16   |  | 1235 NR SO 4 1 3  |  |
| 9 TB 050416  |  | 4/11/16  |  | 630 TB 2 2  |  |
| Turnaround Time (Business days)  |  | Date Deliverable Information   |  | Comments / Special Instructions   |  |
| <input checked="" type="checkbox"/> 10 Business Days for soil samples<br><input type="checkbox"/> 5 Day RUSH<br><input type="checkbox"/> 3 Day RUSH<br><input type="checkbox"/> 2 Day RUSH<br><input checked="" type="checkbox"/> 1 Day RUSH For expedited samples<br><input type="checkbox"/> other |  | <input type="checkbox"/> Commercial "A" (Level 1)<br><input type="checkbox"/> Commercial "B" (Level 2)<br><input checked="" type="checkbox"/> FULL11 (Level 3+4)<br><input type="checkbox"/> NJ Reduced<br><input type="checkbox"/> Commercial "C"<br><input type="checkbox"/> NJ Date of Known Quality Protocol Reporting<br><input type="checkbox"/> Commercial "A" - Results Only, Commercial "B" - Results + QC Summary<br><input type="checkbox"/> NJ Reduced - Results + QC Summary + Partial Raw data |  | <input type="checkbox"/> NYASP Category A<br><input type="checkbox"/> NYASP Category B<br><input type="checkbox"/> State Forms<br><input type="checkbox"/> EDD Format<br><input type="checkbox"/> Other |  |
| Add to Report: Tetrahydrofuran,<br>p-Isopropyl toluene,<br>1,2,4-Trimethyl benzene, Benzyl chloride,<br>Tetra amyl chloride<br>Sample inventory is verified upon receipt in the Laboratory   |  |  |  |   |  |
| Sample Custody must be documented below each time samples change possession, including courier delivery.   |  |  |  |   |  |
| Received By: <b>John W. W. W.</b>  |  | Received By: <b>Fed EX</b>   |  | Date Time: <b>5/5/16 145</b>  |  |
| Subsampled By:   |  | Subsampled By:   |  | Date Time:  |  |
| 3  |  | 4  |  | 4   |  |
| 5  |  | 610  |  | 610   |  |
| Date Time:   |  | Date Time:   |  | Date Time:  |  |
| 3  |  | 4  |  | 4   |  |
| 5  |  | 610  |  | 610   |  |
| Date Time:   |  | Date Time:   |  | Date Time:  |  |
| 3  |  | 4  |  | 4   |  |
| 5  |  | 610  |  | 610   |  |

FA33668: Chain of Custody

Page 1 of 3

SGS

28 of 349

ACCUTEST  
FA33668

## EXECUTIVE NARRATIVE

SDG No: **FA33668** Laboratory: **Accutest, Florida**  
Analysis: **SW846-8260C** Number of Samples: **9**  
Location: **BMSMC, Building 5 Area**  
**Humacao, PR**

**SUMMARY:** Eight (8) samples and one (1) trip blank were analyzed for VOAs TCL list by method SW846-8260C. Samples were validated following USEPA Hazardous Waste Support Section SOP No. HW-33A Revision 0 SOM02.2. Low/Medium Volatile Data Validation. July, 2015. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

Results are valid and can be used for decision making purposes.

**Critical issues:** **None**  
**Major:** **None**  
**Minor:** **None**

**Critical findings:** **None**  
**Major findings:** **None**  
**Minor findings:**

1. The following sample was analyzed outside of holding time for method SW846 8260C: FA33668-9. Sample was received and analyzed outside the holding time. No action taken, this sample is a Trip Blank.
2. Initial calibration, initial calibration verification, and continuing calibration verification within the validation guidance document required criteria. 1,2,4-trichlorobenzene %D was outside the method performance criteria but within the guidance document criteria. No action taken on affected samples. Closing calibration check verification included in data package.
3. MS/MSD % recovery for tetrachloroethylene outside the laboratory control limit (> UL) in sample FA33668-8MS/-8MSD. Tetrachloroethylene not detected in the samples, results are accepted.
4. MSD % recovery for tert-butyl alcohol outside the laboratory control limit (> UL) in sample FA33668-1MS/-1MSD. Tert-butyl alcohol not detected in the samples, results are accepted.
5. Blank spike (aqueous) % recovery for trans-1,2-dichloroethylene outside the laboratory control limit (> UL) in sample FA33668-8MS/-8MSD. trans-1,2-dichloroethylene not detected in the samples, results are accepted.

**COMMENTS:** Results are valid and can be used for decision making purposes.

**Reviewers Name:** **Rafael Infante**  
**Chemist License 1888**

**Signature:**



**Date:** **May 23, 2016**

**SAMPLE ORGANIC DATA SAMPLE SUMMARY**

Sample ID: FA33668-1

Sample location: BMSMC Building 5 Area

Sampling date: 5/3/2016

Matrix: Groundwater

METHOD: 8260C

| Analyte Name                | Result | Units | Dilution | Factor | Lab Flag | Validation | Reportable |
|-----------------------------|--------|-------|----------|--------|----------|------------|------------|
| Acetone                     | 25     | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzene                     | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzyl Chloride             | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromochloromethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromodichloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromoform                   | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 2-Butanone (MEK)            | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon disulfide            | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon tetrachloride        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chlorobenzene               | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chloroethane                | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chloroform                  | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Cyclohexane                 | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dibromochloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromo-3-chloropropane | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromoethane           | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dichlorodifluoromethane     | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,3-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,4-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethene          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| cis-1,2-Dichloroethene      | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |

|                            |      |      |     |   |    |     |
|----------------------------|------|------|-----|---|----|-----|
| trans-1,2-Dichloroethene   | 1.0  | ug/L | 1.0 | - | U  | Yes |
| 1,2-Dichloropropane        | 1.0  | ug/L | 1.0 | - | U  | Yes |
| cis-1,3-Dichloropropene    | 1.0  | ug/L | 1.0 | - | U  | Yes |
| trans-1,3-Dichloropropene  | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Ethylbenzene               | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Freon 113                  | 1.0  | ug/L | 1.0 | - | U  | Yes |
| 2-Hexanone                 | 10   | ug/L | 1.0 | - | U  | Yes |
| Isopropylbenzene           | 1.0  | ug/L | 1.0 | - | U  | Yes |
| p-Isopropyltoluene         | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Methyl Acetate             | 20   | ug/L | 1.0 | - | U  | Yes |
| Methyl Bromide             | 2.0  | ug/L | 1.0 | - | U  | Yes |
| Methyl Chloride            | 2.0  | ug/L | 1.0 | - | U  | Yes |
| Methylcyclohexane          | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Methylene chloride         | 5.0  | ug/L | 1.0 | - | U  | Yes |
| 4-Methyl-2-pentanone(MIBK) | 5.0  | ug/L | 1.0 | - | U  | Yes |
| Methyl Tert Butyl Ether    | 0.75 | ug/L | 1.0 | J | UJ | Yes |
| Styrene                    | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Tert-Amyl Alcohol          | 20   | ug/L | 1.0 | - | U  | Yes |
| Tert-Butyl Alcohol         | 20   | ug/L | 1.0 | - | U  | Yes |
| 1,1,2,2-Tetrachloroethane  | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Tetrachloroethene          | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Tetrahydrofuran            | 5.0  | ug/L | 1.0 | - | U  | Yes |
| Toluene                    | 1.0  | ug/L | 1.0 | - | U  | Yes |
| 1,2,3-Trichlorobenzene     | 2.0  | ug/L | 1.0 | - | U  | Yes |
| 1,2,4-Trichlorobenzene     | 2.0  | ug/L | 1.0 | - | U  | Yes |
| 1,1,1-Trichloroethane      | 1.0  | ug/L | 1.0 | - | U  | Yes |
| 1,1,2-Trichloroethane      | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Trichloroethene            | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Trichlorofluoromethane     | 2.0  | ug/L | 1.0 | - | U  | Yes |
| 1,2,4-Trimethylbenzene     | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Vinyl chloride             | 1.0  | ug/L | 1.0 | - | U  | Yes |
| m,p-Xylene                 | 2.0  | ug/L | 1.0 | - | U  | Yes |
| o-Xylene                   | 1.0  | ug/L | 1.0 | - | U  | Yes |



Sample ID: FA33668-2

Sample location: BMSMC Building 5 Area

Sampling date: 5/3/2016

Matrix: AQ - Equipment Blank

METHOD: 8260C

| Analyte Name                | Result | Units | Dilution | Factor | Lab Flag | Validation | Reportable |
|-----------------------------|--------|-------|----------|--------|----------|------------|------------|
| Acetone                     | 25     | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzene                     | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzyl Chloride             | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromochloromethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromodichloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromoform                   | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 2-Butanone (MEK)            | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon disulfide            | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon tetrachloride        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chlorobenzene               | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chloroethane                | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chloroform                  | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Cyclohexane                 | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dibromochloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromo-3-chloropropane | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromoethane           | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dichlorodifluoromethane     | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,3-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,4-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethene          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| cis-1,2-Dichloroethene      | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| trans-1,2-Dichloroethene    | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloropropane         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |

|                            |     |      |     |   |   |     |
|----------------------------|-----|------|-----|---|---|-----|
| cis-1,3-Dichloropropene    | 1.0 | ug/L | 1.0 | - | U | Yes |
| trans-1,3-Dichloropropene  | 1.0 | ug/L | 1.0 | - | U | Yes |
| Ethylbenzene               | 1.0 | ug/L | 1.0 | - | U | Yes |
| Freon 113                  | 1.0 | ug/L | 1.0 | - | U | Yes |
| 2-Hexanone                 | 10  | ug/L | 1.0 | - | U | Yes |
| Isopropylbenzene           | 1.0 | ug/L | 1.0 | - | U | Yes |
| p-Isopropyltoluene         | 1.0 | ug/L | 1.0 | - | U | Yes |
| Methyl Acetate             | 20  | ug/L | 1.0 | - | U | Yes |
| Methyl Bromide             | 2.0 | ug/L | 1.0 | - | U | Yes |
| Methyl Chloride            | 2.0 | ug/L | 1.0 | - | U | Yes |
| Methylcyclohexane          | 1.0 | ug/L | 1.0 | - | U | Yes |
| Methylene chloride         | 5.0 | ug/L | 1.0 | - | U | Yes |
| 4-Methyl-2-pentanone(MIBK) | 5.0 | ug/L | 1.0 | - | U | Yes |
| Methyl Tert Butyl Ether    | 1.0 | ug/L | 1.0 | - | U | Yes |
| Styrene                    | 1.0 | ug/L | 1.0 | - | U | Yes |
| Tert-Amyl Alcohol          | 20  | ug/L | 1.0 | - | U | Yes |
| Tert-Butyl Alcohol         | 20  | ug/L | 1.0 | - | U | Yes |
| 1,1,2,2-Tetrachloroethane  | 1.0 | ug/L | 1.0 | - | U | Yes |
| Tetrachloroethene          | 1.0 | ug/L | 1.0 | - | U | Yes |
| Tetrahydrofuran            | 5.0 | ug/L | 1.0 | - | U | Yes |
| Toluene                    | 1.0 | ug/L | 1.0 | - | U | Yes |
| 1,2,3-Trichlorobenzene     | 2.0 | ug/L | 1.0 | - | U | Yes |
| 1,2,4-Trichlorobenzene     | 2.0 | ug/L | 1.0 | - | U | Yes |
| 1,1,1-Trichloroethane      | 1.0 | ug/L | 1.0 | - | U | Yes |
| 1,1,2-Trichloroethane      | 1.0 | ug/L | 1.0 | - | U | Yes |
| Trichloroethene            | 1.0 | ug/L | 1.0 | - | U | Yes |
| Trichlorofluoromethane     | 2.0 | ug/L | 1.0 | - | U | Yes |
| 1,2,4-Trimethylbenzene     | 1.0 | ug/L | 1.0 | - | U | Yes |
| Vinyl chloride             | 1.0 | ug/L | 1.0 | - | U | Yes |
| m,p-Xylene                 | 2.0 | ug/L | 1.0 | - | U | Yes |
| o-Xylene                   | 1.0 | ug/L | 1.0 | - | U | Yes |

Sample ID: FA33668-3

Sample location: BMSMC Building 5 Area

Sampling date: 5/3/2016

Matrix: Groundwater

METHOD: 8260C

| Analyte Name                | Result | Units | Dilution | Factor | Lab Flag | Validation | Reportable |
|-----------------------------|--------|-------|----------|--------|----------|------------|------------|
| Acetone                     | 25     | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzene                     | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzyl Chloride             | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromochloromethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromodichloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromoform                   | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 2-Butanone (MEK)            | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon disulfide            | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon tetrachloride        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chlorobenzene               | 0.44   | ug/L  | 1.0      | J      | -        | UJ         | Yes        |
| Chloroethane                | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chloroform                  | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Cyclohexane                 | 0.86   | ug/L  | 1.0      | J      | -        | UJ         | Yes        |
| Dibromochloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromo-3-chloropropane | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromoethane           | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dichlorodifluoromethane     | 0.68   | ug/L  | 1.0      | J      | -        | UJ         | Yes        |
| 1,2-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,3-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,4-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethene          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| cis-1,2-Dichloroethene      | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| trans-1,2-Dichloroethene    | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloropropane         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |

|                            |     |      |     |   |   |     |
|----------------------------|-----|------|-----|---|---|-----|
| cis-1,3-Dichloropropene    | 1.0 | ug/L | 1.0 | - | U | Yes |
| trans-1,3-Dichloropropene  | 1.0 | ug/L | 1.0 | - | U | Yes |
| Ethylbenzene               | 1.0 | ug/L | 1.0 | - | U | Yes |
| Freon 113                  | 8.7 | ug/L | 1.0 | - | - | Yes |
| 2-Hexanone                 | 10  | ug/L | 1.0 | - | U | Yes |
| Isopropylbenzene           | 1.0 | ug/L | 1.0 | - | U | Yes |
| p-Isopropyltoluene         | 1.0 | ug/L | 1.0 | - | U | Yes |
| Methyl Acetate             | 20  | ug/L | 1.0 | - | U | Yes |
| Methyl Bromide             | 2.0 | ug/L | 1.0 | - | U | Yes |
| Methyl Chloride            | 2.0 | ug/L | 1.0 | - | U | Yes |
| Methylcyclohexane          | 1.0 | ug/L | 1.0 | - | U | Yes |
| Methylene chloride         | 5.0 | ug/L | 1.0 | - | U | Yes |
| 4-Methyl-2-pentanone(MIBK) | 5.0 | ug/L | 1.0 | - | U | Yes |
| Methyl Tert Butyl Ether    | 1.6 | ug/L | 1.0 | - | - | Yes |
| Styrene                    | 1.0 | ug/L | 1.0 | - | U | Yes |
| Tert-Amyl Alcohol          | 20  | ug/L | 1.0 | - | U | Yes |
| Tert-Butyl Alcohol         | 20  | ug/L | 1.0 | - | U | Yes |
| 1,1,2,2-Tetrachloroethane  | 1.0 | ug/L | 1.0 | - | U | Yes |
| Tetrachloroethene          | 1.0 | ug/L | 1.0 | - | U | Yes |
| Tetrahydrofuran            | 5.0 | ug/L | 1.0 | - | U | Yes |
| Toluene                    | 1.0 | ug/L | 1.0 | - | U | Yes |
| 1,2,3-Trichlorobenzene     | 2.0 | ug/L | 1.0 | - | U | Yes |
| 1,2,4-Trichlorobenzene     | 2.0 | ug/L | 1.0 | - | U | Yes |
| 1,1,1-Trichloroethane      | 1.0 | ug/L | 1.0 | - | U | Yes |
| 1,1,2-Trichloroethane      | 1.0 | ug/L | 1.0 | - | U | Yes |
| Trichloroethene            | 1.0 | ug/L | 1.0 | - | U | Yes |
| Trichlorofluoromethane     | 2.0 | ug/L | 1.0 | - | U | Yes |
| 1,2,4-Trimethylbenzene     | 1.0 | ug/L | 1.0 | - | U | Yes |
| Vinyl chloride             | 1.0 | ug/L | 1.0 | - | U | Yes |
| m,p-Xylene                 | 2.0 | ug/L | 1.0 | - | U | Yes |
| o-Xylene                   | 1.0 | ug/L | 1.0 | - | U | Yes |

Sample ID: FA33668-4

Sample location: BMSMC Building 5 Area

Sampling date: 5/3/2016

Matrix: Groundwater

METHOD: 8260C

| Analyte Name                | Result | Units | Dilution | Factor | Lab Flag | Validation | Reportable |
|-----------------------------|--------|-------|----------|--------|----------|------------|------------|
| Acetone                     | 25     | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzene                     | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzyl Chloride             | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromochloromethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromodichloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromoform                   | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 2-Butanone (MEK)            | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon disulfide            | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon tetrachloride        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chlorobenzene               | 0.76   | ug/L  | 1.0      | J      | -        | UJ         | Yes        |
| Chloroethane                | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chloroform                  | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Cyclohexane                 | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dibromochloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromo-3-chloropropane | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromoethane           | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dichlorodifluoromethane     | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,3-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,4-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethene          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| cis-1,2-Dichloroethene      | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| trans-1,2-Dichloroethene    | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloropropane         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |

|                            |      |      |     |   |   |     |
|----------------------------|------|------|-----|---|---|-----|
| cis-1,3-Dichloropropene    | 1.0  | ug/L | 1.0 | - | U | Yes |
| trans-1,3-Dichloropropene  | 1.0  | ug/L | 1.0 | - | U | Yes |
| Ethylbenzene               | 1.0  | ug/L | 1.0 | - | U | Yes |
| Freon 113                  | 1.0  | ug/L | 1.0 | - | U | Yes |
| 2-Hexanone                 | 10   | ug/L | 1.0 | - | U | Yes |
| Isopropylbenzene           | 1.0  | ug/L | 1.0 | - | U | Yes |
| p-Isopropyltoluene         | 1.0  | ug/L | 1.0 | - | U | Yes |
| Methyl Acetate             | 20   | ug/L | 1.0 | - | U | Yes |
| Methyl Bromide             | 2.0  | ug/L | 1.0 | - | U | Yes |
| Methyl Chloride            | 2.0  | ug/L | 1.0 | - | U | Yes |
| Methylcyclohexane          | 1.0  | ug/L | 1.0 | - | U | Yes |
| Methylene chloride         | 5.0  | ug/L | 1.0 | - | U | Yes |
| 4-Methyl-2-pentanone(MIBK) | 5.0  | ug/L | 1.0 | - | U | Yes |
| Methyl Tert Butyl Ether    | 1.7  | ug/L | 1.0 | - | - | Yes |
| Styrene                    | 1.0  | ug/L | 1.0 | - | U | Yes |
| Tert-Amyl Alcohol          | 20   | ug/L | 1.0 | - | U | Yes |
| Tert-Butyl Alcohol         | 41.1 | ug/L | 1.0 | - | - | Yes |
| 1,1,2,2-Tetrachloroethane  | 1.0  | ug/L | 1.0 | - | U | Yes |
| Tetrachloroethene          | 1.0  | ug/L | 1.0 | - | U | Yes |
| Tetrahydrofuran            | 5.0  | ug/L | 1.0 | - | U | Yes |
| Toluene                    | 1.0  | ug/L | 1.0 | - | U | Yes |
| 1,2,3-Trichlorobenzene     | 2.0  | ug/L | 1.0 | - | U | Yes |
| 1,2,4-Trichlorobenzene     | 2.0  | ug/L | 1.0 | - | U | Yes |
| 1,1,1-Trichloroethane      | 1.0  | ug/L | 1.0 | - | U | Yes |
| 1,1,2-Trichloroethane      | 1.0  | ug/L | 1.0 | - | U | Yes |
| Trichloroethene            | 1.0  | ug/L | 1.0 | - | U | Yes |
| Trichlorofluoromethane     | 2.0  | ug/L | 1.0 | - | U | Yes |
| 1,2,4-Trimethylbenzene     | 1.0  | ug/L | 1.0 | - | U | Yes |
| Vinyl chloride             | 1.0  | ug/L | 1.0 | - | U | Yes |
| m,p-Xylene                 | 2.0  | ug/L | 1.0 | - | U | Yes |
| o-Xylene                   | 1.0  | ug/L | 1.0 | - | U | Yes |

Sample ID: FA33668-5

Sample location: BMSMC Building 5 Area

Sampling date: 5/3/2016

Matrix: AQ - Equipment Blank

METHOD: 8260C

| Analyte Name                | Result | Units | Dilution | Factor | Lab Flag | Validation | Reportable |
|-----------------------------|--------|-------|----------|--------|----------|------------|------------|
| Acetone                     | 25     | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzene                     | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzyl Chloride             | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromochloromethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromodichloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromoform                   | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 2-Butanone (MEK)            | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon disulfide            | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon tetrachloride        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chlorobenzene               | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chloroethane                | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chloroform                  | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Cyclohexane                 | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dibromochloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromo-3-chloropropane | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromoethane           | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dichlorodifluoromethane     | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,3-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,4-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethene          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| cis-1,2-Dichloroethene      | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| trans-1,2-Dichloroethene    | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloropropane         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |

|                            |     |      |     |   |   |     |
|----------------------------|-----|------|-----|---|---|-----|
| cis-1,3-Dichloropropene    | 1.0 | ug/L | 1.0 | - | U | Yes |
| trans-1,3-Dichloropropene  | 1.0 | ug/L | 1.0 | - | U | Yes |
| Ethylbenzene               | 1.0 | ug/L | 1.0 | - | U | Yes |
| Freon 113                  | 1.0 | ug/L | 1.0 | - | U | Yes |
| 2-Hexanone                 | 10  | ug/L | 1.0 | - | U | Yes |
| Isopropylbenzene           | 1.0 | ug/L | 1.0 | - | U | Yes |
| p-Isopropyltoluene         | 1.0 | ug/L | 1.0 | - | U | Yes |
| Methyl Acetate             | 20  | ug/L | 1.0 | - | U | Yes |
| Methyl Bromide             | 2.0 | ug/L | 1.0 | - | U | Yes |
| Methyl Chloride            | 2.0 | ug/L | 1.0 | - | U | Yes |
| Methylcyclohexane          | 1.0 | ug/L | 1.0 | - | U | Yes |
| Methylene chloride         | 5.0 | ug/L | 1.0 | - | U | Yes |
| 4-Methyl-2-pentanone(MIBK) | 5.0 | ug/L | 1.0 | - | U | Yes |
| Methyl Tert Butyl Ether    | 1.0 | ug/L | 1.0 | - | U | Yes |
| Styrene                    | 1.0 | ug/L | 1.0 | - | U | Yes |
| Tert-Amyl Alcohol          | 20  | ug/L | 1.0 | - | U | Yes |
| Tert-Butyl Alcohol         | 20  | ug/L | 1.0 | - | U | Yes |
| 1,1,2,2-Tetrachloroethane  | 1.0 | ug/L | 1.0 | - | U | Yes |
| Tetrachloroethene          | 1.0 | ug/L | 1.0 | - | U | Yes |
| Tetrahydrofuran            | 5.0 | ug/L | 1.0 | - | U | Yes |
| Toluene                    | 1.0 | ug/L | 1.0 | - | U | Yes |
| 1,2,3-Trichlorobenzene     | 2.0 | ug/L | 1.0 | - | U | Yes |
| 1,2,4-Trichlorobenzene     | 2.0 | ug/L | 1.0 | - | U | Yes |
| 1,1,1-Trichloroethane      | 1.0 | ug/L | 1.0 | - | U | Yes |
| 1,1,2-Trichloroethane      | 1.0 | ug/L | 1.0 | - | U | Yes |
| Trichloroethene            | 1.0 | ug/L | 1.0 | - | U | Yes |
| Trichlorofluoromethane     | 2.0 | ug/L | 1.0 | - | U | Yes |
| 1,2,4-Trimethylbenzene     | 1.0 | ug/L | 1.0 | - | U | Yes |
| Vinyl chloride             | 1.0 | ug/L | 1.0 | - | U | Yes |
| m,p-Xylene                 | 2.0 | ug/L | 1.0 | - | U | Yes |
| o-Xylene                   | 1.0 | ug/L | 1.0 | - | U | Yes |



Sample ID: FA33668-6

Sample location: BMSMC Building 5 Area

Sampling date: 5/4/2016

Matrix: Soil

METHOD: 8260C

| Analyte Name                | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-----------------------------|--------|-------|-----------------|----------|------------|------------|
| Acetone                     | 62     | ug/Kg | 1.0             | -        | U          | Yes        |
| Benzene                     | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| Benzyl Chloride             | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| Bromochloromethane          | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| Bromodichloromethane        | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| Bromoform                   | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| 2-Butanone (MEK)            | 31     | ug/Kg | 1.0             | -        | U          | Yes        |
| Carbon disulfide            | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| Carbon tetrachloride        | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| Chlorobenzene               | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| Chloroethane                | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| Chloroform                  | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| Cyclohexane                 | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| Dibromochloromethane        | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,2-Dibromo-3-chloropropane | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,2-Dibromoethane           | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| Dichlorodifluoromethane     | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,2-Dichlorobenzene         | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,3-Dichlorobenzene         | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,4-Dichlorobenzene         | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,1-Dichloroethane          | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,2-Dichloroethane          | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,1-Dichloroethene          | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| cis-1,2-Dichloroethene      | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| trans-1,2-Dichloroethene    | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,2-Dichloropropane         | 6.2    | ug/Kg | 1.0             | -        | U          | Yes        |

|                            |     |       |     |   |    |     |
|----------------------------|-----|-------|-----|---|----|-----|
| cis-1,3-Dichloropropene    | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| trans-1,3-Dichloropropene  | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Ethylbenzene               | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Freon 113                  | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| 2-Hexanone                 | 31  | ug/Kg | 1.0 | - | U  | Yes |
| Isopropylbenzene           | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| p-Isopropyltoluene         | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Methyl Acetate             | 31  | ug/Kg | 1.0 | - | U  | Yes |
| Methyl Bromide             | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Methyl Chloride            | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Methylcyclohexane          | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Methylene chloride         | 5.0 | ug/Kg | 1.0 | J | UJ | Yes |
| 4-Methyl-2-pentanone(MIBK) | 31  | ug/Kg | 1.0 | - | U  | Yes |
| Methyl Tert Butyl Ether    | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Styrene                    | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Tert-Amyl Alcohol          | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Tert-Butyl Alcohol         | 62  | ug/Kg | 1.0 | - | U  | Yes |
| 1,1,2,2-Tetrachloroethane  | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Tetrachloroethene          | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Tetrahydrofuran            | 12  | ug/Kg | 1.0 | - | U  | Yes |
| Toluene                    | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| 1,2,3-Trichlorobenzene     | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| 1,2,4-Trichlorobenzene     | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| 1,1,1-Trichloroethane      | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| 1,1,2-Trichloroethane      | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Trichloroethene            | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Trichlorofluoromethane     | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| 1,2,4-Trimethylbenzene     | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| Vinyl chloride             | 6.2 | ug/Kg | 1.0 | - | U  | Yes |
| m,p-Xylene                 | 12  | ug/Kg | 1.0 | - | U  | Yes |
| o-Xylene                   | 6.2 | ug/Kg | 1.0 | - | U  | Yes |

Sample ID: FA33668-7

Sample location: BMSMC Building 5 Area

Sampling date: 5/4/2016

Matrix: Groundwater

METHOD: 8260C

| Analyte Name                | Result | Units | Dilution | Factor | Lab Flag | Validation | Reportable |
|-----------------------------|--------|-------|----------|--------|----------|------------|------------|
| Acetone                     | 25     | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzene                     | 0.46   | ug/L  | 1.0      | J      | -        | UJ         | Yes        |
| Benzyl Chloride             | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromochloromethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromodichloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromoform                   | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 2-Butanone (MEK)            | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon disulfide            | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon tetrachloride        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chlorobenzene               | 12.9   | ug/L  | 1.0      | -      | -        | -          | Yes        |
| Chloroethane                | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chloroform                  | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Cyclohexane                 | 6.3    | ug/L  | 1.0      | -      | -        | -          | Yes        |
| Dibromochloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromo-3-chloropropane | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromoethane           | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dichlorodifluoromethane     | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,3-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,4-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethene          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| cis-1,2-Dichloroethene      | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| trans-1,2-Dichloroethene    | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloropropane         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |

|                            |      |      |     |   |    |     |
|----------------------------|------|------|-----|---|----|-----|
| cis-1,3-Dichloropropene    | 1.0  | ug/L | 1.0 | - | U  | Yes |
| trans-1,3-Dichloropropene  | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Ethylbenzene               | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Freon 113                  | 1.0  | ug/L | 1.0 | - | U  | Yes |
| 2-Hexanone                 | 10   | ug/L | 1.0 | - | U  | Yes |
| Isopropylbenzene           | 10.1 | ug/L | 1.0 | - | -  | Yes |
| p-Isopropyltoluene         | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Methyl Acetate             | 20   | ug/L | 1.0 | - | U  | Yes |
| Methyl Bromide             | 2.0  | ug/L | 1.0 | - | U  | Yes |
| Methyl Chloride            | 2.0  | ug/L | 1.0 | - | U  | Yes |
| Methylcyclohexane          | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Methylene chloride         | 5.0  | ug/L | 1.0 | - | U  | Yes |
| 4-Methyl-2-pentanone(MIBK) | 5.0  | ug/L | 1.0 | - | U  | Yes |
| Methyl Tert Butyl Ether    | 11.0 | ug/L | 1.0 | - | -  | Yes |
| Styrene                    | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Tert-Amyl Alcohol          | 12.8 | ug/L | 1.0 | J | UJ | Yes |
| Tert-Butyl Alcohol         | 223  | ug/L | 1.0 | - | -  | Yes |
| 1,1,2,2-Tetrachloroethane  | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Tetrachloroethene          | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Tetrahydrofuran            | 1.7  | ug/L | 1.0 | J | UJ | Yes |
| Toluene                    | 0.27 | ug/L | 1.0 | J | UJ | Yes |
| 1,2,3-Trichlorobenzene     | 2.0  | ug/L | 1.0 | - | U  | Yes |
| 1,2,4-Trichlorobenzene     | 2.0  | ug/L | 1.0 | - | U  | Yes |
| 1,1,1-Trichloroethane      | 1.0  | ug/L | 1.0 | - | U  | Yes |
| 1,1,2-Trichloroethane      | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Trichloroethene            | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Trichlorofluoromethane     | 2.0  | ug/L | 1.0 | - | U  | Yes |
| 1,2,4-Trimethylbenzene     | 1.0  | ug/L | 1.0 | - | U  | Yes |
| Vinyl chloride             | 1.0  | ug/L | 1.0 | - | U  | Yes |
| m,p-Xylene                 | 2.0  | ug/L | 1.0 | - | U  | Yes |
| o-Xylene                   | 1.0  | ug/L | 1.0 | - | U  | Yes |

Sample ID: FA33668-8

Sample location: BMSMC Building 5 Area

Sampling date: 5/4/2016

Matrix: Soil

METHOD: 8260C

| Analyte Name                | Result | Units | Dilution Factor | Lab Flag | Validation | Reportable |
|-----------------------------|--------|-------|-----------------|----------|------------|------------|
| Acetone                     | 54     | ug/Kg | 1.0             | -        | U          | Yes        |
| Benzene                     | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| Benzyl Chloride             | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| Bromochloromethane          | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| Bromodichloromethane        | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| Bromoform                   | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| 2-Butanone (MEK)            | 27     | ug/Kg | 1.0             | -        | U          | Yes        |
| Carbon disulfide            | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| Carbon tetrachloride        | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| Chlorobenzene               | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| Chloroethane                | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| Chloroform                  | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| Cyclohexane                 | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| Dibromochloromethane        | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,2-Dibromo-3-chloropropane | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,2-Dibromoethane           | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| Dichlorodifluoromethane     | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,2-Dichlorobenzene         | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,3-Dichlorobenzene         | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,4-Dichlorobenzene         | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,1-Dichloroethane          | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,2-Dichloroethane          | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,1-Dichloroethene          | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| cis-1,2-Dichloroethene      | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| trans-1,2-Dichloroethene    | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |
| 1,2-Dichloropropane         | 5.4    | ug/Kg | 1.0             | -        | U          | Yes        |

|                            |     |       |     |   |   |     |
|----------------------------|-----|-------|-----|---|---|-----|
| cis-1,3-Dichloropropene    | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| trans-1,3-Dichloropropene  | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Ethylbenzene               | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Freon 113                  | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| 2-Hexanone                 | 27  | ug/Kg | 1.0 | - | U | Yes |
| Isopropylbenzene           | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| p-Isopropyltoluene         | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Methyl Acetate             | 27  | ug/Kg | 1.0 | - | U | Yes |
| Methyl Bromide             | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Methyl Chloride            | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Methylcyclohexane          | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Methylene chloride         | 11  | ug/Kg | 1.0 | - | U | Yes |
| 4-Methyl-2-pentanone(MIBK) | 27  | ug/Kg | 1.0 | - | U | Yes |
| Methyl Tert Butyl Ether    | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Styrene                    | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Tert-Amyl Alcohol          | 54  | ug/Kg | 1.0 | - | U | Yes |
| Tert-Butyl Alcohol         | 54  | ug/Kg | 1.0 | - | U | Yes |
| 1,1,2,2-Tetrachloroethane  | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Tetrachloroethene          | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Tetrahydrofuran            | 11  | ug/Kg | 1.0 | - | U | Yes |
| Toluene                    | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| 1,2,3-Trichlorobenzene     | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| 1,2,4-Trichlorobenzene     | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| 1,1,1-Trichloroethane      | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| 1,1,2-Trichloroethane      | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Trichloroethene            | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Trichlorofluoromethane     | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| 1,2,4-Trimethylbenzene     | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| Vinyl chloride             | 5.4 | ug/Kg | 1.0 | - | U | Yes |
| m,p-Xylene                 | 11  | ug/Kg | 1.0 | - | U | Yes |
| o-Xylene                   | 5.4 | ug/Kg | 1.0 | - | U | Yes |

Sample ID: FA33668-9

Sample location: BMSMC Building 5 Area

Sampling date: 4/11/2016

Matrix: AQ - Trip Blank Water

METHOD: 8260C

| Analyte Name                | Result | Units | Dilution | Factor | Lab Flag | Validation | Reportable |
|-----------------------------|--------|-------|----------|--------|----------|------------|------------|
| Acetone                     | 25     | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzene                     | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Benzyl Chloride             | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromochloromethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromodichloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Bromoform                   | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 2-Butanone (MEK)            | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon disulfide            | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Carbon tetrachloride        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chlorobenzene               | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chloroethane                | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Chloroform                  | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Cyclohexane                 | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dibromochloromethane        | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromo-3-chloropropane | 5.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dibromoethane           | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| Dichlorodifluoromethane     | 2.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,3-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,4-Dichlorobenzene         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloroethane          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,1-Dichloroethene          | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| cis-1,2-Dichloroethene      | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| trans-1,2-Dichloroethene    | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |
| 1,2-Dichloropropane         | 1.0    | ug/L  | 1.0      | -      | -        | U          | Yes        |

|                            |      |      |     |   |   |     |
|----------------------------|------|------|-----|---|---|-----|
| cis-1,3-Dichloropropene    | 1.0  | ug/L | 1.0 | - | U | Yes |
| trans-1,3-Dichloropropene  | 1.0  | ug/L | 1.0 | - | U | Yes |
| Ethylbenzene               | 1.0  | ug/L | 1.0 | - | U | Yes |
| Freon 113                  | 1.0  | ug/L | 1.0 | - | U | Yes |
| 2-Hexanone                 | 10   | ug/L | 1.0 | - | U | Yes |
| Isopropylbenzene           | 1.0  | ug/L | 1.0 | - | U | Yes |
| p-Isopropyltoluene         | 1.0  | ug/L | 1.0 | - | U | Yes |
| Methyl Acetate             | 20   | ug/L | 1.0 | - | U | Yes |
| Methyl Bromide             | 2.0  | ug/L | 1.0 | - | U | Yes |
| Methyl Chloride            | 2.0  | ug/L | 1.0 | - | U | Yes |
| Methylcyclohexane          | 1.0  | ug/L | 1.0 | - | U | Yes |
| Methylene chloride         | 5.0  | ug/L | 1.0 | - | U | Yes |
| 4-Methyl-2-pentanone(MIBK) | 5.0  | ug/L | 1.0 | - | U | Yes |
| Methyl Tert Butyl Ether    | 0.75 | ug/L | 1.0 | - | U | Yes |
| Styrene                    | 1.0  | ug/L | 1.0 | - | U | Yes |
| Tert-Amyl Alcohol          | 20   | ug/L | 1.0 | - | U | Yes |
| Tert-Butyl Alcohol         | 20   | ug/L | 1.0 | - | U | Yes |
| 1,1,2,2-Tetrachloroethane  | 1.0  | ug/L | 1.0 | - | U | Yes |
| Tetrachloroethene          | 1.0  | ug/L | 1.0 | - | U | Yes |
| Tetrahydrofuran            | 5.0  | ug/L | 1.0 | - | U | Yes |
| Toluene                    | 1.0  | ug/L | 1.0 | - | U | Yes |
| 1,2,3-Trichlorobenzene     | 2.0  | ug/L | 1.0 | - | U | Yes |
| 1,2,4-Trichlorobenzene     | 2.0  | ug/L | 1.0 | - | U | Yes |
| 1,1,1-Trichloroethane      | 1.0  | ug/L | 1.0 | - | U | Yes |
| 1,1,2-Trichloroethane      | 1.0  | ug/L | 1.0 | - | U | Yes |
| Trichloroethene            | 1.0  | ug/L | 1.0 | - | U | Yes |
| Trichlorofluoromethane     | 2.0  | ug/L | 1.0 | - | U | Yes |
| 1,2,4-Trimethylbenzene     | 1.0  | ug/L | 1.0 | - | U | Yes |
| Vinyl chloride             | 1.0  | ug/L | 1.0 | - | U | Yes |
| m,p-Xylene                 | 2.0  | ug/L | 1.0 | - | U | Yes |
| o-Xylene                   | 1.0  | ug/L | 1.0 | - | U | Yes |



# DATA REVIEW WORKSHEETS

Project Number: FA33668  
 Date: May 03-04, 2016  
 Shipping date: May 04, 2016  
 EPA Region: 2

## REVIEW OF VOLATILE ORGANIC PACKAGE Low/Medium Volatile Data Validation

The following guidelines for evaluating volatile organics were created to delineate required validation actions. This document will assist the reviewer in using professional judgment to make more informed decision and in better serving the needs of the data users. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: **USEPA Hazardous Waste Support Section SOP No. HW-33A Revision 0 SOM02.2. Low/Medium Volatile Data Validation**. July, 2015. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

The hardcopied (laboratory name) Accutest data package received has been reviewed and the quality control and performance data summarized. The data review for VOCs included:

Lab. Project/SDG No.: FA33668 Sample matrix: Soil/Groundwater  
 No. of Samples: 9  
 Trip blank No.: FA33668-9  
 Field blank No.: -  
 Equipment blank No.: FA33668-2; FA33668-5  
 Field duplicate No.: -

|   |   |
|---|---|
| <input checked="" type="checkbox"/> Data Completeness                   | <input checked="" type="checkbox"/> Laboratory Control Spikes |
| <input checked="" type="checkbox"/> Holding Times                       | <input checked="" type="checkbox"/> Field Duplicates          |
| <input checked="" type="checkbox"/> GC/MS Tuning                        | <input checked="" type="checkbox"/> Calibrations              |
| <input checked="" type="checkbox"/> Internal Standard Performance       | <input checked="" type="checkbox"/> Compound Identifications  |
| <input checked="" type="checkbox"/> Blanks                              | <input checked="" type="checkbox"/> Compound Quantitation     |
| <input checked="" type="checkbox"/> Surrogate Recoveries                | <input checked="" type="checkbox"/> Quantitation Limits       |
| <input checked="" type="checkbox"/> Matrix Spike/Matrix Spike Duplicate |   |

Overall Comments: VOA\_TCL\_list (SW846\_8260C)

### Definition of Qualifiers:

J- Estimated results  
 U- Compound not detected  
 R- Rejected data  
 UJ- Estimated nondetect

Reviewer: Rafael Infante  
 Date: May 23, 2016

10

4

1. **Introduction**  
 2. **Background**  
 3. **Methodology**  
 4. **Results**  
 5. **Discussion**  
 6. **Conclusion**  
 7. **References**  
 8. **Appendix**  
 9. **Figure 1**  
 10. **Figure 2**  
 11. **Figure 3**  
 12. **Figure 4**  
 13. **Figure 5**  
 14. **Figure 6**  
 15. **Figure 7**  
 16. **Figure 8**  
 17. **Figure 9**  
 18. **Figure 10**  
 19. **Figure 11**  
 20. **Figure 12**  
 21. **Figure 13**  
 22. **Figure 14**  
 23. **Figure 15**  
 24. **Figure 16**  
 25. **Figure 17**  
 26. **Figure 18**  
 27. **Figure 19**  
 28. **Figure 20**  
 29. **Figure 21**  
 30. **Figure 22**  
 31. **Figure 23**  
 32. **Figure 24**  
 33. **Figure 25**  
 34. **Figure 26**  
 35. **Figure 27**  
 36. **Figure 28**  
 37. **Figure 29**  
 38. **Figure 30**  
 39. **Figure 31**  
 40. **Figure 32**  
 41. **Figure 33**  
 42. **Figure 34**  
 43. **Figure 35**  
 44. **Figure 36**  
 45. **Figure 37**  
 46. **Figure 38**  
 47. **Figure 39**  
 48. **Figure 40**  
 49. **Figure 41**  
 50. **Figure 42**  
 51. **Figure 43**  
 52. **Figure 44**  
 53. **Figure 45**  
 54. **Figure 46**  
 55. **Figure 47**  
 56. **Figure 48**  
 57. **Figure 49**  
 58. **Figure 50**  
 59. **Figure 51**  
 60. **Figure 52**  
 61. **Figure 53**  
 62. **Figure 54**  
 63. **Figure 55**  
 64. **Figure 56**  
 65. **Figure 57**  
 66. **Figure 58**  
 67. **Figure 59**  
 68. **Figure 60**  
 69. **Figure 61**  
 70. **Figure 62**  
 71. **Figure 63**  
 72. **Figure 64**  
 73. **Figure 65**  
 74. **Figure 66**  
 75. **Figure 67**  
 76. **Figure 68**  
 77. **Figure 69**  
 78. **Figure 70**  
 79. **Figure 71**  
 80. **Figure 72**  
 81. **Figure 73**  
 82. **Figure 74**  
 83. **Figure 75**  
 84. **Figure 76**  
 85. **Figure 77**  
 86. **Figure 78**  
 87. **Figure 79**  
 88. **Figure 80**  
 89. **Figure 81**  
 90. **Figure 82**  
 91. **Figure 83**  
 92. **Figure 84**  
 93. **Figure 85**  
 94. **Figure 86**  
 95. **Figure 87**  
 96. **Figure 88**  
 97. **Figure 89**  
 98. **Figure 90**  
 99. **Figure 91**  
 100. **Figure 92**  
 101. **Figure 93**  
 102. **Figure 94**  
 103. **Figure 95**  
 104. **Figure 96**  
 105. **Figure 97**  
 106. **Figure 98**  
 107. **Figure 99**  
 108. **Figure 100**  
 109. **Figure 101**  
 110. **Figure 102**  
 111. **Figure 103**  
 112. **Figure 104**  
 113. **Figure 105**  
 114. **Figure 106**  
 115. **Figure 107**  
 116. **Figure 108**  
 117. **Figure 109**  
 118. **Figure 110**  
 119. **Figure 111**  
 120. **Figure 112**  
 121. **Figure 113**  
 122. **Figure 114**  
 123. **Figure 115**  
 124. **Figure 116**  
 125. **Figure 117**  
 126. **Figure 118**  
 127. **Figure 119**  
 128. **Figure 120**  
 129. **Figure 121**  
 130. **Figure 122**  
 131. **Figure 123**  
 132. **Figure 124**  
 133. **Figure 125**  
 134. **Figure 126**  
 135. **Figure 127**  
 136. **Figure 128**  
 137. **Figure 129**  
 138. **Figure 130**  
 139. **Figure 131**  
 140. **Figure 132**  
 141. **Figure 133**  
 142. **Figure 134**  
 143. **Figure 135**  
 144. **Figure 136**  
 145. **Figure 137**  
 146. **Figure 138**  
 147. **Figure 139**  
 148. **Figure 140**  
 149. **Figure 141**  
 150. **Figure 142**  
 151. **Figure 143**  
 152. **Figure 144**  
 153. **Figure 145**  
 154. **Figure 146**  
 155. **Figure 147**  
 156. **Figure 148**  
 157. **Figure 149**  
 158. **Figure 150**  
 159. **Figure 151**  
 160. **Figure 152**  
 161. **Figure 153**  
 162. **Figure 154**  
 163. **Figure 155**  
 164. **Figure 156**  
 165. **Figure 157**  
 166. **Figure 158**  
 167. **Figure 159**  
 168. **Figure 160**  
 169. **Figure 161**  
 170. **Figure 162**  
 171. **Figure 163**  
 172. **Figure 164**  
 173. **Figure 165**  
 174. **Figure 166**  
 175. **Figure 167**  
 176. **Figure 168**  
 177. **Figure 169**  
 178. **Figure 170**  
 179. **Figure 171**  
 180. **Figure 172**  
 181. **Figure 173**  
 182. **Figure 174**  
 183. **Figure 175**  
 184. **Figure 176**  
 185. **Figure 177**  
 186. **Figure 178**  
 187. **Figure 179**  
 188. **Figure 180**  
 189. **Figure 181**  
 190. **Figure 182**  
 191. **Figure 183**  
 192. **Figure 184**  
 193. **Figure 185**  
 194. **Figure 186**  
 195. **Figure 187**  
 196. **Figure 188**  
 197. **Figure 189**  
 198. **Figure 190**  
 199. **Figure 191**  
 200. **Figure 192**  
 201. **Figure 193**  
 202. **Figure 194**  
 203. **Figure 195**  
 204. **Figure 196**  
 205. **Figure 197**  
 206. **Figure 198**  
 207. **Figure 199**  
 208. **Figure 200**  
 209. **Figure 201**  
 210. **Figure 202**  
 211. **Figure 203**  
 212. **Figure 204**  
 213. **Figure 205**  
 214. **Figure 206**  
 215. **Figure 207**  
 216. **Figure 208**  
 217. **Figure 209**

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below       

### HOLDING TIMES

The objective of this parameter is to ascertain the validity of the results based on the holding time of the sample from time of collection to the time of analysis.

Complete table for all samples and note the analysis and/or preservation not within criteria

| SAMPLE ID   | DATE SAMPLED | DATE ANALYZED | pH | ACTION |
|---|--------------|---------------|----|--------|
|   |              |               |    |        |
|   |              |               |    |        |
| Samples analyzed within method recommended holding time. Sample preservation within required criteria. The following samples were run outside of holding time for method SW846 8260C: FA33668-9. Sample was received and analyzed outside the holding time. No action taken, this sample is a Trip Blank. |              |               |    |        |
|   |              |               |    |        |
|   |              |               |    |        |
|   |              |               |    |        |

### Criteria

Aqueous samples – 14 days from sample collection for preserved samples ( $\text{pH} \leq 2$ ,  $4 \pm 2^\circ\text{C}$ ), no air bubbles.

Aqueous samples – 7 days from sample collection for unpreserved samples,  $4^\circ\text{C}$ , no air bubbles.

Soil samples- 14 days from sample collection.

Cooler temperature (Criteria:  $4 \pm 2^\circ\text{C}$ ):  $2.8^\circ\text{C}$  - OK

### Actions

#### **Aqueous samples**

- If there is no evidence that the samples were properly preserved ( $\text{pH} < 2$ ,  $T = 4^\circ\text{C} \pm 2^\circ\text{C}$ ), but the samples were analyzed within the technical holding time [7 days from sample collection], no qualification of the data is necessary.
- If there is no evidence that the samples were properly preserved, and the samples were analyzed outside of the technical holding time [7 days from sample collection], qualify detects for all volatile compounds as estimated (J) and non-detects as unusable (R).
- If the samples were properly preserved, and the samples were analyzed within the technical holding time [14 days from sample collection], no qualification of the data is necessary.
- If the samples were properly preserved, but were analyzed outside of the technical holding time [14 days from sample collection], qualify detects as estimated (J) and non-detects as unusable (R).
- If air bubbles were present in the sample vial used for analysis, qualify detected compounds as estimated (J-) and non-detected compounds as estimated (UJ).

**Non-aqueous samples**

- a. If there is no evidence that the samples were properly preserved ( $T < -7^{\circ}\text{C}$  or  $T = 4^{\circ}\text{C} \pm 2^{\circ}\text{C}$  and preserved with  $\text{NaHSO}_4$ ), but the samples were analyzed within the technical holding time [14 days from sample collection], qualify detects for all volatile compounds as estimated (J) and non-detects as (UJ) or unusable (R) using professional judgment.
- b. If the samples were properly preserved, and the samples were analyzed within the technical holding time [14 days from sample collection], no qualification of the data is necessary.
- c. If there is no evidence that the samples were properly preserved, and the samples were analyzed outside of the technical holding time [14 days from sample collection], qualify detects for all volatile compounds as estimated (J) and non-detects as unusable (R).
- d. If the samples were properly preserved, but were analyzed outside of the technical holding time [14 days from sample collection], qualify detects as estimated (J) and non-detects as unusable (R).

**Qualify TCLP/SPLP samples**

- a. If the TCLP/SPLP ZHE procedure is performed within the extraction technical holding time of 14 days, detects and non-detects should not be qualified.
- b. If the TCLP/SPLP ZHE procedure is performed outside the extraction technical holding time of 14 days, qualify detects as estimated (J) and non-detects as unusable (R).
- c. If TCLP/SPLP aqueous samples and TCLP/SPLP leachate samples are analyzed within the technical holding time of 7 days, detects and non-detects should not be qualified.
- d. If TCLP/SPLP aqueous samples and TCLP/SPLP leachate samples are analyzed outside of the technical holding time of 7 days, qualify detects as estimated (J) and non-detects as unusable (R).

Table 1. Holding Time Actions for Low/Medium Volatile Analyses - Summary

| Matrix      | Preserved | Criteria  | Action                        |                                   |
|-------------|-----------|-----------|-------------------------------|-----------------------------------|
|             |           |           | Detected Associated Compounds | Non-Detected Associated Compounds |
|             |           |           |                               |                                   |
| Aqueous     | No        | ≤ 7 days  | No qualification              |                                   |
|             | No        | > 7 days  | J                             | R                                 |
|             | Yes       | ≤ 14 days | No qualification              |                                   |
|             | Yes       | > 14 days | J                             | R                                 |
| Non-Aqueous | No        | ≤ 14 days | J                             | Professional judgment, UJ or R    |
|             | Yes       | ≤ 14 days | No qualification              |                                   |
|             | Yes/No    | > 14 days | J                             | R                                 |
| TCLP/SPLP   | Yes       | ≤ 14 days | No qualification              |                                   |
| TCLP/SPLP   | No        | > 14 days | J                             | R                                 |

|   |   |                           |   |
|---|---|---------------------------|---|
| TCLP/SPLP   | ZHE performed within the 14-day technical holding time  | No qualification          |   |
| TCLP/SPLP   | ZHE performed outside the 14-day technical holding time | J                         | R |
| TCLP/SPLP aqueous & TCLP/SPLP leachate                              | Analyzed within 7 days                                  | No qualification          |   |
| TCLP/SPLP aqueous & TCLP/SPLP leachate                              | Analyzed outside 7 days                                 | J                         | R |
| Sample temperature outside 4°C ± 2°C upon receipt at the laboratory |   | Use professional judgment |   |
| Holding times grossly exceeded                                      |   | J                         | R |

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met see below       

### GC/MS TUNING

The assessment of the tuning results is to determine if the sample instrumentation is within the standard tuning QC limits

  X   The BFB performance results were reviewed and found to be within the specified criteria.

  X   BFB tuning was performed for every 12 hours of sample analysis.

**NOTES:** All mass spectrometer instrument conditions must be identical to those used during the sample analysis. Background subtraction actions resulting in spectral distortions for the sole purpose of meeting the method specifications are contrary to the Quality Assurance (QA) objectives, and are therefore unacceptable.

**NOTES:** No data should be qualified based on BFB failure. Instances of this should be noted in the narrative.

All ion abundance ratios must be normalized to m/z 95, the nominal base peak, even though the ion abundance of m/z 174 may be up to 120% that of m/z 95.

#### Actions:

If samples are analyzed without a preceding valid instrument performance check, qualify all data in those samples as unusable (R).

If ion abundance criteria are not met, professional judgment may be applied to determine to what extent the data may be utilized. When applying professional judgment to this topic, the most important factors to consider are the empirical results that are relatively insensitive to location on the chromatographic profile and the type of instrumentation. Therefore, the critical ion abundance criteria for BFB are the m/z 95/96, 174/175, 174/176, and 176/177 ratios. The relative abundances of m/z 50 and 75 are of lower importance. This issue is more critical for Tentatively Identified Compounds (TICs) than for target analytes.

**Note:** State in the Data Review Narrative, decisions to use analytical data associated with BFB instrument performance checks not meeting contract requirements.

**Note:** Verify that that instrument instrument performance check criteria were achieved using techniques described in Low/Medium Volatiles Organic Analysis, Section II.D.5 of the SOM02.2 NFG, obtain additional information on the instrument performance checks. Make sure that background subtraction was performed from the BFB peak and not from background subtracting from the solvent front or from another region of the chromatogram.

## DATA REVIEW WORKSHEETS

Use professional judgment to determine whether associated data should be qualified based on the spectrum of the mass calibration compound.

List the samples affected:

---

---

---

---

---

---

---

If mass calibration is in error, all associated data are rejected.

# DATA REVIEW WORKSHEETS

All criteria were met ☒ X  
 Criteria were not met  
 and/or see below \_\_\_\_\_

## CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

Date of initial calibration: 04/25/16 03/15/16  
 Dates of continuing (initial) calibration: 04/25/16 03/15/16  
 Dates of continuing calibration: 05/05/16 05/06/16  
 Date of ending calibration verification: 05/05/16 05/05/16  
 Instrument ID numbers: GCMSY GCMSJ  
 Matrix/Level: Aqueous/low Aqueous/low

| DATE     | LAB FILE ID# | CRITERIA OUT RFs, %RSD, %D, r | COMPOUND                | SAMPLES AFFECTED   |
|----------|--------------|-------------------------------|-------------------------|--|
| GCMSY    |              |                               |                         |  |
| 04/25/16 | icc1133-4    | -21.3                         | 1,2,4-trichlorobenzene* | FA33668-6; -8; -8MS/8MSD; FA33661-1; -1MS/1MSD (QC sample) |
|          |              |                               |                         |  |
|          |              |                               |                         |  |
|          |              |                               |                         |  |
|          |              |                               |                         |  |
|          |              |                               |                         |  |

Note: Initial calibration, initial calibration verification, and continuing calibration verification within the validation guidance document required criteria. 1,2,4-trichlorobenzene %D was outside the method performance criteria but within the guidance document criteria. No action taken on affected samples. Closing calibration check verification included in data package.

### Criteria

The analyte calibration criteria in the following Table must be obtained. Analytes not meeting the criteria are qualified.

A separate worksheet should be filled for each initial curve



**Initial Calibration - Table 2. RRF, %RSD, and %D Acceptance Criteria for Initial Calibration and CCV for Low/Medium Volatile Analysis**

| Analyte                               | Minimum RRF | Maximum %RSD | Opening Maximum %D <sup>1</sup> | Closing Maximum %D |
|---------------------------------------|-------------|--------------|---------------------------------|--------------------|
| Dichlorodifluoromethane               | 0.010       | 25.0         | ±40.0                           | ±50.0              |
| Chloromethane                         | 0.010       | 20.0         | ±30.0                           | ±50.0              |
| Vinyl chloride                        | 0.010       | 20.0         | ±25.0                           | ±50.0              |
| Bromomethane                          | 0.010       | 40.0         | ±30.0                           | ±50.0              |
| Chloroethane                          | 0.010       | 40.0         | ±25.0                           | ±50.0              |
| Trichlorofluoromethane                | 0.010       | 40.0         | ±30.0                           | ±50.0              |
| 1,1-Dichloroethene                    | 0.060       | 20.0         | ±20.0                           | ±25.0              |
| 1,1,2-Trichloro-1,2,2-trifluoroethane | 0.050       | 25.0         | ±25.0                           | ±50.0              |
| Acetone                               | 0.010       | 40.0         | ±40.0                           | ±50.0              |
| Carbon disulfide                      | 0.100       | 20.0         | ±25.0                           | ±25.0              |
| Methyl acetate                        | 0.010       | 40.0         | ±40.0                           | ±50.0              |
| Methylene chloride                    | 0.010       | 40.0         | ±30.0                           | ±50.0              |
| trans-1,2-Dichloroethene              | 0.100       | 20.0         | ±20.0                           | ±25.0              |
| Methyl tert-butyl ether               | 0.100       | 40.0         | ±25.0                           | ±50.0              |
| 1,1-Dichloroethane                    | 0.300       | 20.0         | ±20.0                           | ±25.0              |
| cis-1,2-Dichloroethene                | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| 2-Butanone                            | 0.010       | 40.0         | ±40.0                           | ±50.0              |
| Bromochloromethane                    | 0.100       | 20.0         | ±20.0                           | ±25.0              |
| Chloroform                            | 0.300       | 20.0         | ±20.0                           | ±25.0              |
| 1,1,1-Trichloroethane                 | 0.050       | 20.0         | ±25.0                           | ±25.0              |
| Cyclohexane                           | 0.010       | 40.0         | ±25.0                           | ±50.0              |
| Carbon tetrachloride                  | 0.100       | 20.0         | ±25.0                           | ±25.0              |
| Benzene                               | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| 1,2-Dichloroethane                    | 0.070       | 20.0         | ±20.0                           | ±25.0              |
| Trichloroethene                       | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| Methylcyclohexane                     | 0.050       | 40.0         | ±25.0                           | ±50.0              |
| 1,2-Dichloropropane                   | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| Bromodichloromethane                  | 0.300       | 20.0         | ±20.0                           | ±25.0              |
| cis-1,3-Dichloropropene               | 0.300       | 20.0         | ±20.0                           | ±25.0              |
| 4-Methyl-2-pentanone                  | 0.030       | 25.0         | ±30.0                           | ±50.0              |
| Toluene                               | 0.300       | 20.0         | ±20.0                           | ±25.0              |
| trans-1,3-Dichloropropene             | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| 1,1,2-Trichloroethane                 | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| Tetrachloroethene                     | 0.100       | 20.0         | ±20.0                           | ±25.0              |
| 2-Hexanone                            | 0.010       | 40.0         | ±40.0                           | ±50.0              |
| Dibromochloromethane                  | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| 1,2-Dibromoethane                     | 0.200       | 20.0         | ±20.0                           | ±25.0              |
| Chlorobenzene                         | 0.400       | 20.0         | ±20.0                           | ±25.0              |
| Ethylbenzene                          | 0.400       | 20.0         | ±20.0                           | ±25.0              |

# DATA REVIEW WORKSHEETS

| Analyte                                  | Minimum RRF | Maximum %RSD | Opening Maximum %D <sup>1</sup> | Closing Maximum |
|--|-------------|--------------|---------------------------------|-----------------|
| m,p-Xylene                               | 0.200       | 20.0         | ±20.0                           | ±25.0           |
| o-Xylene                                 | 0.200       | 20.0         | ±20.0                           | ±25.0           |
| Styrene                                  | 0.200       | 20.0         | ±20.0                           | ±25.0           |
| Bromoform                                | 0.100       | 20.0         | ±25.0                           | ±50.0           |
| Isopropylbenzene                         | 0.400       | 20.0         | ±25.0                           | ±25.0           |
| 1,1,2,2-Tetrachloroethane                | 0.200       | 20.0         | ±25.0                           | ±25.0           |
| 1,3-Dichlorobenzene                      | 0.500       | 20.0         | ±20.0                           | ±25.0           |
| 1,4-Dichlorobenzene                      | 0.600       | 20.0         | ±20.0                           | ±25.0           |
| 1,2-Dichlorobenzene                      | 0.600       | 20.0         | ±20.0                           | ±25.0           |
| 1,2-Dibromo-3-chloropropane              | 0.010       | 25.0         | ±30.0                           | ±50.0           |
| 1,2,4-Trichlorobenzene                   | 0.400       | 20.0         | ±30.0                           | ±50.0           |
| 1,2,3-Trichlorobenzene                   | 0.400       | 25.0         | ±30.0                           | ±50.0           |
| <b>Deuterated Monitoring Compound</b>    |             |              |                                 |                 |
| Vinyl chloride-d <sub>3</sub>            | 0.010       | 20.0         | ±30.0                           | ±50.0           |
| Chloroethane-d <sub>5</sub>              | 0.010       | 40.0         | ±30.0                           | ±50.0           |
| 1,1-Dichloroethene-d <sub>2</sub>        | 0.050       | 20.0         | ±25.0                           | ±25.0           |
| 2-Butanone-d <sub>6</sub>                | 0.010       | 40.0         | ±40.0                           | ±50.0           |
| Chloroform-d                             | 0.300       | 20.0         | ±20.0                           | ±25.0           |
| 1,2-Dichloroethane-d <sub>4</sub>        | 0.060       | 20.0         | ±25.0                           | ±25.0           |
| Benzene-d <sub>6</sub>                   | 0.300       | 20.0         | ±20.0                           | ±25.0           |
| 1,2-Dichloropropane-d <sub>6</sub>       | 0.200       | 20.0         | ±20.0                           | ±25.0           |
| Toluene-d <sub>8</sub>                   | 0.300       | 20.0         | ±20.0                           | ±25.0           |
| trans-1,3-Dichloropropene-d <sub>4</sub> | 0.200       | 20.0         | ±20.0                           | ±25.0           |
| 2-Hexanone-d <sub>8</sub>                | 0.010       | 40.0         | ±40.0                           | ±50.0           |
| 1,1,2,2-Tetrachloroethane-d <sub>2</sub> | 0.200       | 20.0         | ±25.0                           | ±25.0           |
| 1,2-Dichlorobenzene-d <sub>3</sub>       | 0.400       | 20.0         | ±20.0                           | ±25.0           |

- <sup>1</sup> If a closing CCV is acting as an opening CCV, all target analytes and DMCs must meet the requirements for an opening CCV.

## Actions:

1. If any volatile target compound has an RRF value less than the minimum in the table, use professional judgment for detects, based on mass spectral identification, to qualify the data as estimated (J+ or R).
  - a. If any volatile target compound has an RRF value less than the minimum criterion, qualify non-detected compounds as unusable (R).
  - b. If any of the volatile target compounds listed in the Table has %RSD greater than the criteria, qualify detects as estimated (J), and non-detected compounds using professional judgment.
  - c. If the volatile target compounds meet the acceptance criteria for RRF and the %RSD, no qualification of the data is necessary.

- d. No qualification of the data is necessary on the DMC RRF and %RSD data alone. Use professional judgment and follow the guidelines in Action 2 to evaluate the DMC RRF and %RSD data in conjunction with the DMC recoveries to determine the need for qualification of data.
2. At the reviewer's discretion, and based on the project-specific Data Quality Objectives (DQOs), a more in-depth review may be considered using the following guidelines:
    - a. If any volatile target compound has a %RSD greater than the maximum criterion in the Table, and if eliminating either the high or the low-point of the curve does not restore the %RSD to less than or equal to the required maximum:
      - i. Qualify detects for that compound(s) as estimated (J).
      - ii. Qualify non-detected volatile target compounds using professional judgment.
    - b. If the high-point of the curve is outside of the linearity criteria (e.g., due to saturation):
      - i. Qualify detects outside of the linear portion of the curve as estimated (J).
      - ii. No qualifiers are required for detects in the linear portion of the curve.
      - iii. No qualifiers are required for volatile target compounds that were not detected.
    - c. If the low-point of the curve is outside of the linearity criteria:
      - i. Qualify low-level detects in the area of non-linearity as estimated (J).
      - ii. No qualifiers are required for detects in the linear portion of the curve.
      - iii. For non-detected volatile compounds, use the lowest point of the linear portion of the curve to determine the new quantitation limit.

**Note:** If the laboratory has failed to provide adequate calibration information, inform the Region's designated representative to contact the laboratory and request the necessary information. If the information is not available, the reviewer must use professional judgment to assess the data.

State in the Data Review Narrative, if possible, the potential effects on the data due to calibration criteria exceedance.

Note, for the Laboratory COR action, if calibration criteria are grossly exceeded.

Table. Initial Calibration Actions for Low/Medium Volatile Analysis – Summary

| Criteria  | Action                               |                                |
|---|--------------------------------------|--------------------------------|
|   | Detect                               | Non-detect                     |
| Initial Calibration not performed at specified frequency and sequence | Use professional judgment<br>R       | Use professional judgment<br>R |
| Initial Calibration not performed at the specified concentrations     | J                                    | UJ                             |
| RRF < Minimum RRF in Table for target analyte                         | Use professional judgment<br>J- or R | R                              |
| RRF > Minimum RRF in Table for target analyte                         | No qualification                     | No qualification               |
| %RSD > Maximum %RSD in Table for target analyte                       | J                                    | Use professional judgment      |
| %RSD ≤ Maximum %RSD in Table for target analyte                       | No qualification                     | No qualification               |

All criteria were met   X    
Criteria were not met  
and/or see below           

### Continuing Calibration Verification (CCV)

**NOTE:** Verify that the CCV was run at the required frequency (an opening and closing CCV must be run within 12-hour period) and the CCV was compared to the correct initial calibration. If the mid-point standard from the initial calibration is used as an opening CCV, verify that the result (RRF) of the mid-point standard was compared to the average RRF from the correct initial calibration.

The closing CCV used to bracket the end of a 12-hour analytical sequence may be used as the opening CCV for the new 12-hour analytical sequence, provided that all the technical acceptance criteria are met for an opening CCV (see criteria show before in the Table) . If the closing CCV does not meet the technical acceptance criteria for an opening CCV, then a BFB tune followed by an opening CCV is required and the next 12-hour time period begins with the BFB tune.

All DMCs must meet RRF criteria. No qualification of the data is necessary on the DMCs RRF and %RSD/%D data alone. However, use professional judgment to evaluate the DMC and %RSD/%D data in conjunction with the DMC recoveries to determine the need of qualification the data.

#### Action:

1. If a CCV (opening and closing) was not run at the appropriate frequency, qualify data using professional judgment.
2. Qualify all volatile target compounds in Table shown before using the following criteria:
  - a. For an opening CCV, if any volatile target compound has an RRF value less than the minimum criterion, use professional judgment for detects, based on mass spectral identification, to qualify the data as estimated (J) and qualify non-detected compounds as unusable (R).
  - b. For a closing CCV, if any volatile target compound has an RRF value less than the criteria, use professional judgment for detects based on mass spectral identification to qualify the data as estimated (J), and qualify non-detected compounds as unusable (R).
  - c. For an opening CCV, if the Percent Difference value for any of the volatile target compounds is outside the limits in calibration criteria Table shown before, qualify detects as estimated (J) and non-detected compounds as estimated (UJ).
  - d. For a closing CCV, if the Percent Difference value for any volatile target compound is outside the limits in calibration criteria table, qualify detects as estimated (J) and non-detected compounds as estimated (UJ).
  - e. If the volatile target compounds meet the acceptable criteria for RRF and the Percent Difference, no qualification of the data is necessary.

## DATA REVIEW WORKSHEETS

- f. No qualification of the data is necessary on the DMC RRF and the Percent Difference data alone. Use professional judgment to evaluate the DMC RRF and Percent Difference data in conjunction with the DMC recoveries to determine the need for qualification of data.

**Notes:** If the laboratory has failed to provide adequate calibration information, inform the Region's designated representative to contact the laboratory and request the necessary information. If the information is not available, the reviewer must use professional judgment to assess the data.

State in the Data Review Narrative, if possible, the potential effects on the data due to calibration criteria exceedance.

Note, for Contract Laboratory COR action, if calibration criteria are grossly exceeded.

Table. Continuing Calibration Actions for Low/Medium Volatile Analysis – Summary

| Criteria for Opening CCV  | Criteria for Closing CCV  | Action                              |                                |
|---|---|-------------------------------------|--------------------------------|
|   |   | Detect                              | Non-detect                     |
| CCV not performed at required frequency   | CCV not performed at required frequency   | Use professional judgment<br>R      | Use professional judgment<br>R |
| CCV not performed at specified concentration                                    | CCV not performed at specified concentration                                    | Use professional judgment           | Use professional judgment      |
| RRF < Minimum RRF in Table 2 for target analyte                                 | RRF < Minimum RRF in Table 2 for target analyte                                 | Use professional judgment<br>J or R | R                              |
| RRF ≥ Minimum RRF in Table 2 for target analyte                                 | RRF ≥ Minimum RRF in Table 2 for target analyte                                 | No qualification                    | No qualification               |
| %D outside the Opening Maximum %D limits in Table 2 for target analyte          | %D outside the Closing Maximum %D limits in Table 2 for target analyte          | J                                   | UJ                             |
| %D within the inclusive Opening Maximum %D limits in Table 2 for target analyte | %D within the inclusive Closing Maximum %D limits in Table 2 for target analyte | No qualification                    | No qualification               |

# DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

## BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including trip, equipment, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamination in the blanks below. High and low levels blanks must be treated separately.

The concentration of a target analyte in any blank must not exceed its Contract Required Quantitation Limit (CRQL) (2x CRQLs for Methylene chloride, Acetone, and 2-Butanone). TIC concentration in any blanks must be  $\leq 5.0 \mu\text{g/L}$  for water ( $0.0050 \text{ mg/L}$  for TCLP leachate) and  $\leq 5.0 \mu\text{g/kg}$  for soil matrices.

### Laboratory blanks

The method blank, like any other sample in the SDG, must meet the technical acceptance criteria for sample analysis.

| DATE<br>ANALYZED                               | LAB ID | LEVEL/<br>MATRIX | COMPOUND | CONCENTRATION<br>UNITS |
|--|--------|------------------|----------|------------------------|
| _____  | _____  | _____            | _____    | _____                  |
| _____  | _____  | _____            | _____    | _____                  |
| _____  | _____  | _____            | _____    | _____                  |
| _No_target_analyte_detected_in_method_blanks._ |        |                  |          |                        |

### Field/Equipment/Trip blank

If field or trip blanks are present, the data reviewer should evaluate this data in a similar fashion as the method blanks.

| DATE<br>ANALYZED | LAB ID | LEVEL/<br>MATRIX | COMPOUND | CONCENTRATION<br>UNITS |
|------------------|--------|------------------|----------|------------------------|
| _____            | _____  | _____            | _____    | _____                  |
| _____            | _____  | _____            | _____    | _____                  |
| _____            | _____  | _____            | _____    | _____                  |
| _____            | _____  | _____            | _____    | _____                  |
| _____            | _____  | _____            | _____    | _____                  |
| _____            | _____  | _____            | _____    | _____                  |
| _____            | _____  | _____            | _____    | _____                  |
| _____            | _____  | _____            | _____    | _____                  |

\_No\_target\_analytes\_detected\_in\_the\_trip/equipment\_blanks\_analyzed\_for\_this\_data\_package.\_  
 \_No\_field\_blank\_analyzed\_included\_in\_this\_data\_package.\_

## DATA REVIEW WORKSHEETS

All criteria were met ☒ X  
 Criteria were not met  
 and/or see below \_\_\_\_\_

### BLANK ANALYSIS RESULTS (Section 3)

#### Blank Actions

**Note:** All fields blank results associated with a particular group of samples (may exceed one per case) must be used to qualify data. Trip blanks are used to qualify only those samples with which they were shipped. Blanks may not be qualified because of contamination in another blank. Field blanks and trip blanks must be qualified for system monitoring compounds, instrument performance criteria, and spectral or calibration QC problems.

Samples taken from a drinking water tap do not have associated field blanks.

When applied as described in the Table below, the contaminant concentration in the blank is multiplied by the sample dilution factor.

**Table. Blank and TCLP/SPLP LEB Actions for Low/Medium Volatile Analysis**

| Blank Type   | Blank Result           | Sample Result                         | Action for Samples                                      |
|--|------------------------|---------------------------------------|---|
| Method,<br>Storage, Field,<br>Trip,<br>TCLP/SPLP<br>LEB,<br>Instrument** | Detects                | Not detected                          | No qualification required                               |
|  | < CRQL *               | < CRQL *                              | Report CRQL value with a U                              |
|  |                        | ≥ CRQL *                              | No qualification required                               |
|  | > CRQL *               | < CRQL *                              | Report CRQL value with a U                              |
|  |                        | ≥ CRQL * and ≤<br>blank concentration | Report blank value for sample<br>concentration with a U |
|  |                        | ≥ CRQL * and ><br>blank concentration | No qualification required                               |
|  | = CRQL *               | ≤ CRQL *                              | Report CRQL value with a U                              |
|  |                        | > CRQL *                              | No qualification required                               |
|  | Gross<br>contamination | Detects                               | Report blank value for sample<br>concentration with a U |

\* 2x the CRQL for methylene chloride, 2-butanone and acetone.

\*\* Qualifications based on instrument blank results affect only the sample analyzed immediately after the sample that has target compounds that exceed the calibration range or non-target compounds that exceed 100 µg/L.

Action Levels (ALs) should be based upon the highest concentration of contaminant determined in any blank. Do not qualify any blank with another blank. The ALs for samples which have been diluted should be corrected for the sample dilution factor and/or % moisture, where applicable. No positive sample results should be reported unless the concentration of the compound in the samples exceeds the ALs:

## DATA REVIEW WORKSHEETS

### Notes:

High and low level blanks must be treated separately

Compounds qualified "U" for blank contamination are still considered "hits" when qualifying for calibration criteria.

| CONTAMINATION<br>SOURCE/LEVEL | COMPOUND | CONC/UNITS | AL/UNITS | SQL | AFFECTED<br>SAMPLES |
|-------------------------------|----------|------------|----------|-----|---------------------|
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |
|                               |          |            |          |     |                     |



All criteria were met   X    
 Criteria were not met  
 and/or see below       

### DEUTERATED MONITORING COMPOUNDS (DMCs)

Laboratory performance of individual samples is established by evaluation of surrogate spike (DMCs) recoveries. All samples are spiked with surrogate compounds prior to sample analysis. The accuracy of the analysis is measured by the surrogate percent recovery. Since the effects of the sample matrix are frequently outside the control of the laboratory and may present relatively unique problems, the validation of data is frequently subjective and demands analytical experience and professional judgment.

**Table. Volatile Deuterated Monitoring Compounds (DMCs) and Recovery Limits**

| DMC                          | %R for Water Sample | %R for Soil Sample |
|------------------------------|---------------------|--------------------|
| Vinyl chloride-d3            | 60-135              | 30-150             |
| Chloroethane-d5              | 70-130              | 30-150             |
| 1,1-Dichloroethene-d2        | 60-125              | 45-110             |
| 2-Butanone-d5                | 40-130              | 20-135             |
| Chloroform-d                 | 70-125              | 40-150             |
| 1,2-Dichloroethane-d4        | 70-125              | 70-130             |
| Benzene-d6                   | 70-125              | 20-135             |
| 1,2-Dichloropropane-d6       | 70-120              | 70-120             |
| Toluene-d8                   | 80-120              | 30-130             |
| trans-1,3-Dichloropropene-d4 | 60-125              | 30-135             |
| 2-Hexanone-d5                | 45-130              | 20-135             |
| 1,1,2,2-Tetrachloroethane-d2 | 65-120              | 45-120             |
| 1,2-Dichlorobenzene-d4       | 80-120              | 75-120             |

**NOTE:** The recovery limits for any of the compounds listed in the above Table may be expanded at any time during the period of performance if the United States Environmental Protection Agency (EPA) determines that the limits are too restrictive.

#### Action:

Are recoveries for DMCs in volatile samples and blanks must be within the limits specified in the Table above. Yes? or No?

**NOTE:** The recovery limits for any of the compounds listed in the Table above may be expanded at any time during the period of performance if USEPA determines that the limits are too restrictive.

## DATA REVIEW WORKSHEETS

List the DMCs that may fail to meet the recovery limits

| Sample ID | Date | DMCs | % Recovery | Action |
|-----------|------|------|------------|--------|
|-----------|------|------|------------|--------|

DMCs recoveries within the required limits. Other non-deuterated surrogates added to the samples within laboratory control limits.

Note: Any sample which has more than 3 DMCs outside the limits must be reanalyzed.

Action:

1. For any recovery greater than the upper acceptance limit:
  - a. Qualify detected associated volatile target compounds as estimated high (J+).
  - b. Do not qualify non-detected associated volatile target compounds.
2. For any recovery greater than or equal to 10%, and less than the lower acceptance limit:
  - a. Qualify detected associated volatile target compounds as estimated low (J-).
  - b. Qualify non-detected associated volatile target compounds as estimated (UJ).
3. For any recovery less than 10%:
  - a. Qualify detected associated volatile target compounds as estimated low (J-).
  - b. Qualify non-detected associated volatile target compounds as unusable (R).
4. For any recovery within acceptance limits, no qualification of the data is necessary.
5. In the special case of a blank analysis having DMCs out of specification, the reviewer must give special consideration to the validity of associated sample data. The basic concern is whether the blank problems represent an isolated problem with the blank alone, or whether there is a fundamental problem with the analytical process. For example, if one or more samples in the batch show acceptable DMC recoveries, the reviewer may choose to consider the blank problem to be an isolated occurrence. However, even if this judgment allows some use of the affected data, note analytical problems for Contract Laboratory COR action.
6. If more than three DMCs are outside of the recovery limits for Low/Medium volatiles analysis and the sample was not reanalyzed, note under Contract Problems/Non-Compliance.

Table. Deuterated Monitoring Compound (DMC) Recovery Actions for Low/Medium Volatiles Analyses – Summary

| Criteria  | Action                      |                                   |
|---|-----------------------------|-----------------------------------|
|   | Detect Associated Compounds | Non-detected Associated Compounds |
| $\%R < 10\%$  | J-                          | R                                 |
| $10\% \leq \%R < \text{Lower Acceptance Limit}$                             | J-                          | UJ                                |
| $\text{Lower Acceptance Limit} \leq \%R \leq \text{Upper Acceptance Limit}$ | No qualification            | No qualification                  |
| $\%R > \text{Upper Acceptance Limit}$                                       | J+                          | No qualification                  |

TABLE. VOLATILE DEUTERATED MONITORING COMPOUNDS (DMCs) AND THE ASSOCIATED TARGET COMPOUNDS

|  |  |  |
|--|--|--|
| <b>Vinyl chloride-d<sub>1</sub> (DMC-1)</b>  | <b>Chloroethane-d<sub>5</sub> (DMC-2)</b>  | <b>1,1-Dichloroethene-d<sub>2</sub> (DMC-3)</b>  |
| Vinyl chloride   | Dichlorodifluoromethane<br>Chloromethane<br>Bromomethane<br>Chloroethane<br>Carbon disulfide | trans-1,2-Dichloroethene<br>cis-1,2-Dichloroethene<br>1,1-Dichloroethene   |
| <b>2-Butanone-d<sub>6</sub> (DMC-4)</b>  | <b>Chloroform-d (DMC-5)</b>  | <b>1,2-Dichloroethane-d<sub>4</sub> (DMC-6)</b>  |
| Acetone<br>2-Butanone  | 1,1-Dichloroethane<br>Bromochloromethane<br>Chloroform<br>Dibromochloromethane<br>Bromoform  | Trichlorofluoromethane<br>1,1,2-Trichloro-1,2,2-trifluoroethane<br>Methyl acetate<br>Methylene chloride<br>Methyl-tert-butyl ether<br>1,1,1-Trichloroethane<br>Carbon tetrachloride<br>1,2-Dibromoethane<br>1,2-Dichloroethane |
| <b>Benzene-d<sub>6</sub> (DMC-7)</b>   | <b>1,2-Dichloropropane-d<sub>6</sub> (DMC-8)</b>   | <b>Toluene-d<sub>8</sub> (DMC-9)</b>   |
| Benzene  | Cyclohexane<br>Methylcyclohexane<br>1,2-Dichloropropane<br>Bromodichloromethane              | Trichloroethene<br>Toluene<br>Tetrachloroethene<br>Ethylbenzene<br>o-Xylene<br>m,p-Xylene<br>Styrene<br>Isopropylbenzene   |
| <b>trans-1,3-Dichloropropene-d<sub>4</sub> (DMC-10)</b>  | <b>2-Hexanone-d<sub>8</sub> (DMC-11)</b>   | <b>1,1,2,2-Tetrachloroethane-d<sub>2</sub> (DMC-12)</b>  |
| cis-1,3-Dichloropropene<br>trans-1,3-Dichloropropene<br>1,1,2-Trichloroethane  | 4-Methyl-2-pentanone<br>2-Hexanone   | 1,1,2,2-Tetrachloroethane<br>1,2-Dibromo-3-chloropropane   |
| <b>1,2-Dichlorobenzene-d<sub>4</sub> (DMC-13)</b>  |  |  |
| Chlorobenzene<br>1,3-Dichlorobenzene<br>1,4-Dichlorobenzene<br>1,2-Dichlorobenzene<br>1,2,4-Trichlorobenzene<br>1,2,3-Trichlorobenzene |  |  |

# DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below           

## MATRIX SPIKE/MATRIX SPIKE DUPLICATE (MS/MSD)

This data is generated to determine long term precision and accuracy in the analytical method for various matrices. This data alone cannot be used to evaluate the precision and accuracy of individual samples. If any % R in the MS or MSD falls outside the designated range, the reviewer should determine if there are matrix effects, i.e. LCS data are within the QC limits but MS/MSD data are outside QC limit.

**NOTES:** Data for MS and MSDs will not be present unless requested by the Region.  
 Notify the Contract Laboratory COR if a field or trip blank was used for the MS and MSD.

For a Matrix Spike that does not meet criteria, apply the action to only the field sample used to prepare the Matrix Spike sample. If it is clearly stated in the data validation materials that the samples were taken through incremental sampling or some other method guaranteeing the homogeneity of the sample group, then the entire sample group may be qualified.

### 1. MS/MSD Recoveries and Precision Criteria

The laboratory should use one MS and a duplicate analysis of an unspiked field sample if target analytes are expected in the sample. If target analytes are not expected, MS/MSD should be analyzed.

List the %Rs, RPD of the compounds which do not meet the criteria.

Sample ID:   FA33668-8MS/8MSD   Matrix/Level:   Soil    
 Sample ID:   FA33668-1MS/1MSD   Matrix/Level:   Aqueous  

| MS OR MSD         | COMPOUND                       | % R                | RPD          | QC LIMITS           | ACTION   |
|-------------------|--------------------------------|--------------------|--------------|---------------------|--|
| FA33668-8MS/8MSD  |                                |                    |              |                     |  |
| <u>  MS/MSD  </u> | <u>  Tetrachloroethylene  </u> | <u>  147/174  </u> | <u>  %  </u> | <u>  79 - 130  </u> | <u>  No qualification needed; analyte not detected in sample  </u> |
| FA33668-1MS/1MSD  |                                |                    |              |                     |  |
| <u>  MSD  </u>    | <u>  Tert-Butyl Alcohol  </u>  | <u>  133  </u>     | <u>  %  </u> | <u>  63 - 129  </u> | <u>  No qualification needed; analyte not detected in sample  </u> |

- \* QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- \* If QC limits are not available, use limits of 70 – 130 %.

## DATA REVIEW WORKSHEETS

### Actions:

1. No qualification of the data is necessary on MS and MSD data alone. However, using professional judgment, the validator may use the MS and MSD results in conjunction with other QC criteria and determine the need for some qualification of the data.

| QUALITY            | %R < LL | %R > UL |
|--------------------|---------|---------|
| Positive results   | J       | J       |
| Nondetects results | R       | Accept  |

MS/MSD criteria apply only to the unspiked sample, its dilutions, and the associated MS/MSD samples:

If the % R for the affected compounds were < LL (or 70 %), qualify positive results (J) and nondetects (UJ).

If the % R for the affected compounds were > UL (or 130 %), only qualify positive results (J).

If 25 % or more of all MS/MSD %R were < LL (or 70 %) or if two or more MS/MSD %Rs were < 10%, qualify all positive results (J) and reject nondetects (R).

A separate worksheet should be used for each MS/MSD pair.

All criteria were met   X    
 Criteria were not met  
 and/or see below           

## LABORATORY CONTROL SAMPLE (LCS) ANALYSIS

This data is generated to determine accuracy of the analytical method for various matrices.

## 1. LCS Recoveries Criteria

Where LCS spiked with the same analyte at the same concentrations as the MS/MSD? Yes or No. If no make note in data review memo. – LCS solid concentration lower than matrix spike concentration.

List the %R of compounds which do not meet the criteria

| LCS ID   | COMPOUND                          | % R          | QC LIMIT        |
|--|-----------------------------------|--------------|-----------------|
| <u>Recoveries (blank spike) within laboratory control limits except for the following:</u> |                                   |              |                 |
| <u>VJ5288-BS (Aqueous)</u>   | <u>trans-1,2-dichloroethylene</u> | <u>130 %</u> | <u>76 - 127</u> |
|  |                                   |              |                 |
|  |                                   |              |                 |
|  |                                   |              |                 |

**Note:** Analyte not detected in affected sample, results are accepted.

- \* QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- \* If QC limits are not available, use limits of 70 – 130 %.

Actions:

| QUALITY            | %R < LL | %R > UL |
|--------------------|---------|---------|
| Positive results   | J       | J       |
| Nondetects results | R       | Accept  |

All analytes in the associated sample results are qualified for the following criteria.

If 25 % of the LCS recoveries were < LL (or 70 %), qualify all positive results (J) and reject nondetects (R).

If two or more LCS were below 10 %, qualify all positive results as (J) and reject nondetects (R).

## 2. Frequency Criteria:

Where LCS analyzed at the required frequency and for each matrix? Yes or No.

If no, the data may be affected. Use professional judgment to determine the severity of the effect and qualify data accordingly. Discuss any actions below and list the samples affected.

All criteria were met   X    
 Criteria were not met  
 and/or see below           

## IX. FIELD/LABORATORY DUPLICATE PRECISION

Sample IDs:                    -                   

Matrix:                    -                   

Field/laboratory duplicate samples may be taken and analyzed as an indication of overall precision. These analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples.

The project QAPP should be reviewed for project-specific information.

**NOTE:** In the absence of QAPP guidance for validating data from field duplicates, the following action will be taken.

Identify which samples within the data package are field duplicates. Estimate the relative percent difference (RPD) between the values for each compound. Use professional judgment to note large RPDs (> 50%) in the narrative.

| COMPOUND   | SQL | SAMPLE CONC. | DUPLICATE CONC. | RPD | ACTION |
|--|-----|--------------|-----------------|-----|--------|
|  |     |              |                 |     |        |
|  |     |              |                 |     |        |
| No field/laboratory duplicate analyzed for this data package. MS/MSD RPD used to assess precision. RPD within required criteria, < 50 % for target analytes. |     |              |                 |     |        |
|  |     |              |                 |     |        |
|  |     |              |                 |     |        |

### Actions:

Qualify as estimated positive results (J) and nondetects (UJ) for the compound that exceeded the above criteria. For organics, only the sample and duplicate will be qualified.

If an RPD cannot be calculated because one or both of the sample results is not detected, the following actions are suggested based on professional judgment:

If one sample result is not detected and the other is greater than 5x the SQL qualify (J/UJ).

If one sample value is not detected and the other is greater than 5x the SQL and the SQLs for the sample and duplicate are significantly different, use professional judgment to determine if qualification is appropriate.

If one sample value is not detected and the other is less than 5x, use professional judgment to determine if qualification is appropriate.

If both sample and duplicate results are not detected, no action is needed.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
Criteria were not met  
and/or see below       

### X. INTERNAL STANDARD PERFORMANCE

The assessment of the internal standard (IS) parameter is used to assist the data reviewer in determining the condition of the analytical instrumentation.

| DATE | SAMPLE ID | IS OUT | IS AREA | ACCEPTABLE RANGE | ACTION |
|------|-----------|--------|---------|------------------|--------|
|------|-----------|--------|---------|------------------|--------|

Internal standard area counts within the required criteria.

#### Action:

1. If an internal standard area count for a sample or blank is greater than 200.0% of the area for the associated standard (opening CCV or mid-point standard from initial calibration) (see Table below):
  - a. Qualify detects for compounds quantitated using that internal standard as estimated low (J-).
  - b. Do not qualify non-detected associated compounds.
2. If an internal standard area count for a sample or blank is less than 20.0% of the area for the associated standard (opening CCV or mid-point standard from initial calibration):
  - a. Qualify detects for compounds quantitated using that internal standard as estimated high (J+).
  - b. Qualify non-detected associated compounds as unusable (R).
3. If an internal standard area count for a sample or blank is greater than or equal to 20.0%, and less than or equal to 200% of the area for the associated standard opening CCV or mid-point standard from initial calibration, no qualification of the data is necessary.
4. If an internal standard RT varies by more than 30.0 seconds: Examine the chromatographic profile for that sample to determine if any false positives or negatives exist. For shifts of a large magnitude, the reviewer may consider partial or total rejection of the data for that sample fraction. Detects should not need to be qualified as unusable (R) if the mass spectral criteria are met.
5. If an internal standard RT varies by less than or equal to 30.0 seconds, no qualification of the data is necessary.

**Note:** Inform the Contract Laboratory Program Project Officer (CLP PO) if the internal standard performance criteria are grossly exceeded. Note in the Data Review Narrative potential effects on the data resulting from unacceptable internal standard performance.



## DATA REVIEW WORKSHEETS

6. If required internal standard compounds are not added to a sample or blank, qualify detects and non-detects as unusable (R).
7. If the required internal standard compound is not analyzed at the specified concentration in a sample or blank, use professional judgment to qualify detects and non-detects.

**Table. Internal Standard Actions for Low/Medium Volatiles Analyses - Summary**

| Criteria   | Action                         |                                    |
|--|--------------------------------|------------------------------------|
|  | Detected Associated Compounds* | Non-detected Associated Compounds* |
| Area counts > 200% of 12-hour standard (opening CCV or mid-point standard from initial calibration)                            | J-                             | No qualification                   |
| Area counts < 20% of 12-hour standard (opening CCV or mid-point standard from initial calibration)                             | J+                             | R                                  |
| Area counts ≥ 50% but ≤ 200% of 12-hour standard (opening CCV or mid-point standard from initial calibration)                  | No qualification               |                                    |
| RT difference > 30.0 seconds between samples and 12-hour standard (opening CCV or mid-point standard from initial calibration) | R **                           | R                                  |
| RT difference ≤ 30.0 seconds between samples and 12-hour standard (opening CCV or mid-point standard from initial calibration) | No qualification               |                                    |

\* For volatile compounds associated to each internal standard, see TABLE - VOLATILE TARGET ANALYTES, DEUTERATED MONITORING COMPOUNDS WITH ASSOCIATED INTERNAL STANDARDS FOR QUANTITATION in SOM02.2, Exhibit D, available at: <http://www.epa.gov/superfund/programs/clp/download/som/som22d.pdf>

\*\* Detects should not need to be qualified as unusable (R) if the mass spectral criteria are met.

## DATA REVIEW WORKSHEETS

All criteria were met   X    
 Criteria were not met  
 and/or see below       

### TARGET COMPOUND IDENTIFICATION

#### Criteria:

Is the Relative Retention Times (RRTs) of reported compounds within  $\pm 0.06$  RRT units of the standard RRT [opening Continuing Calibration Verification (CCV) or mid-point standard from the initial calibration]. Yes? or No?

List compounds not meeting the criteria described above:

| Sample ID | Compounds | Actions |
|-----------|-----------|---------|
| =====     | =====     | =====   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |

Mass spectra of the sample compound and a current laboratory-generated standard [i.e., the mass spectrum from the associated calibration standard (opening CCV or mid-point standard from initial calibration)] must match according to the following criteria:

- All ions present in the standard mass spectrum at a relative intensity greater than 10% must be present in the sample spectrum.
- The relative intensities of these ions must agree within  $\pm 20\%$  between the standard and sample spectra (e.g., for an ion with an abundance of 50% in the standard spectrum, the corresponding sample ion abundance must be between 30-70%).
- Ions present at greater than 10% in the sample mass spectrum, but not present in the standard spectrum, must be evaluated by a reviewer experienced in mass spectral interpretation.

List compounds not meeting the criteria described above:

| Sample ID | Compounds | Actions |
|-----------|-----------|---------|
| =====     | =====     | =====   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |
| _____     | _____     | _____   |

## DATA REVIEW WORKSHEETS

### Action:

1. The application of qualitative criteria for GC/MS analysis of target compounds requires professional judgment. It is up to the reviewer's discretion to obtain additional information from the laboratory. If it is determined that incorrect identifications were made, qualify all such data as unusable (R).
2. Use professional judgment to qualify the data if it is determined that cross-contamination has occurred.
3. Note in the Data Review Narrative any changes made to the reported compounds or concerns regarding target compound identifications. Note, for Contract Laboratory COR action, the necessity for numerous or significant changes.

### TENTATIVELY IDENTIFIED COMPOUNDS (TICS)

NOTE: Tentatively identified compounds should only be evaluated when requested by a party from outside of the Hazardous Waste Support Section (HWSS).

#### List TICs

| Sample ID | Compound | Sample ID | Compound |
|-----------|----------|-----------|----------|
| =====     |          |           |          |
| _____     |          |           |          |
| _____     |          |           |          |
| _____     |          |           |          |
| _____     |          |           |          |
| _____     |          |           |          |

### Action:

1. Qualify all TIC results for which there is presumptive evidence of a match (e.g. greater than or equal to 85% match) as tentatively identified (NJ), with approximated concentrations. TICs labeled "unknown" are qualified as estimated (J).
2. General actions related to the review of TIC results are as follows:
  - a. If it is determined that a tentative identification of a non-target compound is unacceptable, change the tentative identification to "unknown" or another appropriate identification, and qualify the result as estimated (J).
  - b. If all contractually-required peaks were not library searched and quantitated, the Region's designated representative may request these data from the laboratory.
3. In deciding whether a library search result for a TIC represents a reasonable identification, use professional judgment. If there is more than one possible match, report the result as "either compound X or compound Y". If there is a lack of isomer specificity, change the TIC result to a nonspecific isomer result (e.g., 1,3,5-trimethyl benzene to trimethyl benzene).

## DATA REVIEW WORKSHEETS

isomer) or to a compound class (e.g., 2-methyl, 3-ethyl benzene to a substituted aromatic compound).

4. The reviewer may elect to report all similar compounds as a total (e.g., all alkanes may be summarized and reported as total hydrocarbons).
5. Target compounds from other fractions and suspected laboratory contaminants should be marked as "non-reportable".
6. Other Case factors may influence TIC judgments. If a sample TIC match is poor, but other samples have a TIC with a valid library match, similar RRT, and the same ions, infer identification information from the other sample TIC results.
7. Note in the Data Review Narrative any changes made to the reported data or any concerns regarding TIC identifications.
8. Note, for Contract Laboratory COR action, failure to properly evaluate and report TICs

# DATA REVIEW WORKSHEETS

All criteria were met ☒   
 Criteria were not met   
 and/or see below \_\_\_\_\_

## SAMPLE QUANTITATION AND REPORTED CONTRACT REQUIRED QUANTITATION LIMITS (CRQLS)

### Action:

1. If any discrepancies are found, the Region's designated representative may contact the laboratory to obtain additional information that could resolve any differences. If a discrepancy remains unresolved, the reviewer must use professional judgment to decide which value is the most accurate. Under these circumstances, the reviewer may determine that qualification of data is warranted. Note in the Data Review Narrative a description of the reasons for data qualification and the qualification that is applied to the data.
2. For non-aqueous samples, in the percent moisture is less than 70.0%, no qualification of the data is necessary. If the percent moisture is greater than or equal to 70.0% and less than 90.0%, qualify detects as estimated (J) and non-detects as approximated (UJ). If the percent moisture is greater than or equal to 90.0%, qualify detects as estimated (J) and non-detects as unusable (R) (see Table below).
3. Note, for Contract Laboratory COR action, numerous or significant failures to accurately quantify the target compounds or to properly evaluate and adjust CRQLs.
4. Results between MDL and CRQL should be qualified as estimated "J".
5. Results < MDL should be reported at the CRQL and qualified "U". MDLs themselves are not reported.

Table. Percent Moisture Actions for Low/Medium Volatiles Analysis for Non-Aqueous Samples

| Criteria                 | Action                        |                                   |
|--------------------------|-------------------------------|-----------------------------------|
|                          | Detected Associated Compounds | Non-detected Associated Compounds |
| % Moisture < 70.0        | No qualification              |                                   |
| 70.0 < % Moisture < 90.0 | J                             | UJ                                |
| % Moisture > 90.0        | J                             | R                                 |

The sample quantitation evaluation is to verify laboratory quantitation results. In the space below, please show a minimum of one sample calculation:

Sample ID

FA33668-3

Freon 113

RF = 0.250

[ ] = (47635)(50)/(0.250)(1090332) = 8.74 ppb Ok

## DATA REVIEW WORKSHEETS

### B. Percent Solids

List samples which have  $\geq 70\%$  solids

---

---

---

---

---

---

## DATA REVIEW WORKSHEETS

All criteria were met X  
Criteria were not met  
and/or see below \_\_\_\_\_

## QUANTITATION LIMITS

**A. Dilution performed**

[illegible]

All criteria were met X  
Criteria were not met  
and/or see below \_\_\_\_\_

## OTHER ISSUES

### A. System Performance

List samples qualified based on the degradation of system performance during simple analysis:

| Sample ID | Comments                                       | Actions |
|-----------|--|---------|
|           |  |         |
|           | No degradation of system performance observed. |         |
|           |  |         |

**Action:**

Use professional judgment to qualify the data if it is determined that system performance has degraded during sample analyses. Inform the Contract Laboratory Program COR any action as a result of degradation of system performance which significantly affected the data.

## B. Overall Assessment of Data

**List samples qualified based on other issues:**

| Sample ID | Comments   | Actions |
|-----------|--|---------|
|           |  |         |
|           | No additional issues observed that require qualification of the data. Results are valid and can be used for decision purposes. |         |
|           |  |         |

**Action:**

1. Use professional judgment to determine if there is any need to qualify data which were not qualified based on the Quality Control (QC) criteria previously discussed.
2. Write a brief narrative to give the user an indication of the analytical limitations of the data. Inform the Contract Laboratory COR the action, any inconsistency of the data with the Sample Delivery Group (SDG) Narrative. If sufficient information on the intended use and required quality of the data is available, the reviewer should include their assessment of the usability of the data within the given context. This may be used as part of a formal Data Quality Assessment (DQA).