


Interpreting In Vivo Effects of Thyroid Synthesis Inhibitors Through the Lens of Ex Vivo Assays

**Michael Hornung
Sigmund J. Degitz, Joseph E. Tietge**

US Environmental Protection Agency
Office of Research and Development, National Health and Environmental Research Laboratory,
Mid-Continent Ecology Division, Duluth MN, USA

35th Aquatic Toxicity Workshop
October 6-8, 2008
Saskatoon, Saskatchewan


Potential Endpoints for Thyroid Hormone Disruption



RESEARCH & DEVELOPMENT

Building a scientific foundation for sound environmental decisions

Amphibian Metamorphosis Assay



Metamorphosis is a Thyroid Hormone-Dependent Process




Amphibian Metamorphosis Assay

- Initiated with tadpoles at onset of thyroid function
- 14-21 days exposure
- Apical Endpoints
 - Developmental stage
 - Thyroid histology




Amphibian Metamorphosis Assay

Methimazole



Perchlorate




Are there effects that occur earlier than changes in histology or development that can be used as diagnostic indicators of thyroid disruption ?




In Vivo Gene Expression Following Exposure

Sodium Iodide Symporter (NIS)




Pituitary Proteins Following Exposure




Thyroid Gland Explant Cultures

Dissect thyroid glands from pro-metamorphic tadpoles

- Culture in 96-well plates in L-15 media (BSA, antibiotic, 1 μ M KI)
- Stimulate with TSH and treat with graded concentrations of test chemical
- Measure T4 released to media by RIA
- Measure TSH responsive gene expression by QPCR.




Paired thyroid glands in
NF stage 59 *X. laevis* tadpole




Thyroid Gland Explant Culture:

TSH Dose-Response




Thyroid Gland Explant Culture:

Time & dose relationship of T4 release inhibition




Thyroid Gland Explant Cultures:


Gene Expression Response to TSH




Explant Thyroid Gene Expression: *Response to Inhibitors*




In Vivo Thyroid Gland TH



Serum T4 Following Exposure to Inhibitors



HPT Compensation Summary



Thyroid Explant Culture

Interpretation of compensatory and direct effects

In vitro...

- Release T4 in response to TSH is dose related
- T4 reserves must be depleted before synthesis inhibition significantly affects T4 release

In vivo...

- Early stages are more sensitive to arrested metamorphosis by T4 inhibitors than late stages
- At late prometamorphosis, thyroid glands are larger and reserve T4 is sufficient to complete metamorphosis
- Exposure time 0 does not equal effect time 0 for circulating T4: NEED TO UNDERSTAND DOSIMETRY / PK & PD
- Need to measure circulating hormone levels (T4, TSH) to interpret gene expression and protein responses in vivo



MED Thyroid Project Team

Mike Hornung

Sig Degitz

Joe Tietge

John Nichols

Jose Serrano

Joe Korte

Gary Holcombe

Pat Kosian

Dean Hammermeister

Jon Haselman

Brian Butterworth

Sherri Batterman

Post Docs

Kara Thoemke

Jasim Chowdhury

Robin Sternberg

Student Contractors

Hollie Kerr

Megan Bugge

Lisa Korte

Jessica Olson

Emily Burgess

Scott Moen



Thyroid Gland Cell Number: Normal Development

