

**Chiccine, Catherine**

---

**From:** Madonia, Joseph <Joseph.Madonia@btlaw.com>  
**Sent:** Monday, December 12, 2022 9:54 AM  
**To:** Chiccine, Catherine  
**Cc:** Madonia, Joseph; Susan Knowles  
**Subject:** Ameren - On site work plan  
**Attachments:** Huster - Work Plan for On-site ISCO with attachments.pdf

Cathy - here is the work plan we sent to Tonya and Clint. Thanks for helping us meet our schedule.

Sent from my iPhone

CONFIDENTIALITY NOTICE: This email and any attachments are for the exclusive and confidential use of the intended recipient. If you are not the intended recipient, please do not read, distribute or take action in reliance upon this message. If you have received this in error, please notify us immediately by return email and promptly delete this message and its attachments from your computer system. We do not waive attorney-client or work product privilege by the transmission of this message.

# Pilot ISCO Work Plan for Huster Rd. Substation

## Huster Road Substation

St. Charles, MO 63301

December 2022

Prepared for

Ameren Missouri

1901 Chouteau Avenue

St. Louis, MO 63103



**Loureiro Engineering Associates, Inc.**

112 Corporate Drive, Suite 2 • Portsmouth, NH 03801 • 603.778.1100 • [www.Loureiro.com](http://www.Loureiro.com)

An Employee-Owned Company

**Affirmative Action / Equal Opportunity Employer**

---

**Pilot ISCO Work Plan for  
Huster Rd. Substation**

**Huster Road Substation  
St. Charles, MO 63301**

**December 9, 2022**

**Prepared for**

**Ameren Missouri  
1901 Chouteau Avenue  
St. Louis, MO 63103**

**Prepared by**

**LOUREIRO ENGINEERING ASSOCIATES, INC.  
112 Corporate Drive, Suite #2  
Portsmouth, NH 03801**

***An Employee Owned Company***

---

---

## Table of Contents

	Page
<b>1. INTRODUCTION</b>	<b>5-1</b>
<b>2. SITE CONCEPTUAL MODEL</b>	<b>5-1</b>
2.1 Site Background	5-1
<b>3. ISCO OBJECTIVES</b>	<b>5-2</b>
<b>4. REMEDIAL DESIGN OVERVIEW</b>	<b>5-2</b>
4.1 Proposed ISCO Application	5-2
4.2 ISCO Application – Process Monitoring	5-4
4.3 Post-ISCO Application – Performance Monitoring	5-4
4.4 Coordination with EPA Site Investigation	5-4
4.5 Re-Establishment of Bioremediation	5-4
<b>5. PILOT TEST SCHEDULE</b>	<b>5-5</b>

Figure

Appendices

## 1. INTRODUCTION

Loureiro Engineering Associates (LEA) has prepared this Pilot In Situ Chemical Oxidation (ISCO) Work Plan for remedial evaluation in the Huster Road Substation (work plan) on behalf of Ameren Missouri (Ameren). The work plan presents a summary of the proposed remedial approach to treat residual groundwater impacts within the Huster Road Substation on Huster Road in St. Charles, Missouri (Site) (**Figure 1**). The primary contaminants of concern (COCs) to be treated at the site are 1,2-cis-dichloroethene (cis-1,2-DCE) and vinyl chloride.

## 2. SITE CONCEPTUAL MODEL

The geology of the site consists of a silty clay/silt material 25 to 30 feet in thickness. The lower two to three feet transitions to a primarily silt composition. Underlying the cohesive unit is a medium grained sand material that extends from approximately 30 feet below ground surface (ft bgs) to the top of bedrock observed at approximately 110 ft bgs. The depth to groundwater at the site varies, dependent on the Mississippi River located approximately 2 miles north, but is typically encountered at approximately 20 feet bgs.

### 2.1 Site Background

Previous bench scale treatability studies performed by XDD Environmental (XDD) were used to determine the treatment effectiveness of several in situ chemical oxidation (ISCO) technologies. Refer to the *Plume Containment Pilot Study Work Plan (September 2014)* and the *Plume Containment Pilot Test Work Plan Addendum (December 2014)* for a detailed summary of the various technologies that were evaluated to treat site soils and groundwater.

Results of the treatability studies indicated alkaline activated sodium persulfate (AAP) was an effective technology to address the COCs in both site soils and groundwater. ISCO pilot tests were performed in 2014 (Phase 1) and 2015 (Phase II), targeting groundwater impacts north of the substation property in the vicinity of City Well W-5 and south of Highway 370. The impacted interval was approximately 15 feet and based on vertical impacts in groundwater, measured from approximately 32 ft bgs to 45 ft bgs. The pilot tests successfully reduced COCs in the treatment area without observing any adverse impact in City Well 5. The persulfate induces a chemical reaction upon contact with COCs and residence time in groundwater is limited. COC concentration levels in the off-site treatment area declined within a short time frame, a matter of weeks.

In order to supplement the success of multiple bioremediation applications at the site combined with the operation of a groundwater extraction treatment system (GETS), a larger-scale injection of AAP was chosen to aggressively target the existing COC mass on soils and groundwater within

the substation in the uppermost groundwater zone. Several factors were considered when developing the proposed remedial approach to prevent any negative impacts to the continued operation of the GETS and city wells that may become operational before, during, or after the ISCO application:

- groundwater dilution of AAP solution,
- total oxidant demand in subsurface soils and groundwater due to anaerobic conditions created by previous bioremediation applications,
- pH reduction over distance traveled (subsurface).

### **3. ISCO OBJECTIVES**

The GETS was designed to contain and treat groundwater from the substation as it flows naturally to the north/northwest and influenced by City of St. Charles (City) production wells located upgradient. Ameren's primary objective of the ISCO application is to address the last remaining COC impacts within the substation. (**Figure 1**). The GETS was designed to contain and treat groundwater from the substation as it flows naturally to the north/northwest and influenced by City of St. Charles (City) production wells located upgradient. Ameren's primary objective of the ISCO application is to address the last remaining COC impacts within the substation. (**Figure 1**). The estimated remaining mass of contaminated material trapped in the subsurface soils and clays on the 8 -acre Site is approximately 4 lbs. (The estimated mass prior to remediation efforts was approximately 400 lbs.)

### **4. REMEDIAL DESIGN OVERVIEW**

Fourteen temporary injection points will be installed prior to injection activities. Proposed injection locations are shown on **Figure 1** and are intended to focus treatment in areas with known residual COC impacts or areas directly in pathway of a potential extraction point used as a drinking water source. The ISCO application will consist of sodium persulfate (persulfate) and sodium hydroxide (NaOH) delivered to the site in 5,500-gallon stainless steel tankers. A mixture of persulfate, NaOH, and water will be injected simultaneously and mixed in-line to create an AAP solution concentration of approximately 95 grams per liter (g/L).

#### **4.1 Proposed ISCO Application**

The proposed AAP ISCO application is described in detail below.

- ISCO will be used to target soil and groundwater in the substation. The target interval is approximately 32 to 42 ft below ground surface (bgs) and may vary depending on the thickness of the overlying silty clay layer.

- Approximately 189,544 pounds (lb) of sodium persulfate will be applied during injection activities.
- Approximately 238,000 gallons, or the equivalent to one pore volume, will be injected during the ISCO application at a concentration of approximately 95 grams per liter (g/L) into an estimated 14 temporary injection locations. Each location is expected to receive approximately 17,000 gallons.
- Temporary injection points will be installed using a direct-push drill rig using 1-inch Sch 40 PVC with a 10-foot slotted screen.
- The anticipated radius of influence per injection location is approximately 15 ft. If evenly distributed, the injections will cover approximately 10,500 ft<sup>2</sup>.
- Sodium persulfate will be received as a solid powder in 2,204-lb super sacks at an off-site facility and batched with potable water into a concentrated solution of approximately 317 g/L. The concentrated batch solution will be transferred into stainless steel tanker truck and delivered to the site. The concentrated solution will be diluted during injection with NaOH and water to achieve the target injection concentration of 95 g/L.
- Using the 2:1 molar ratio of sodium hydroxide to sodium persulfate for alkaline activation, approximately 63,686 lbs of sodium hydroxide will be injected with the persulfate. The sodium hydroxide will be purchased as a 25% solution (approximately 23,897 gallons required). The use of sodium hydroxide will elevate the pH in the contact zone to level greater than 10.
- A manifold skid will be used to inject the solution into 7-10 locations simultaneously with an anticipated flow rate of 5-10 gpm in each location.
- Assuming the anticipated flow rates can be sustained throughout the application, the ISCO injections are estimated to be completed in 10 days (not including mobilization or demobilization).

Currently, very low levels of COCs exist on the west side of the substation. However, to facilitate effectiveness of the application of the treatment, operation of City Wells 4 and 5 should be coordinated to create groundwater "stagnant zones" within the substation to maximize persulfate residence time. Alternatively, if coordination of City Well 5 and 4 pumping rates is not feasible, operation of City Well 4 should be deferred for 30 days post ISCO application to maximize persulfate residence time.

Following the installation of the temporary injection points, each temporary location will be developed/purged until groundwater quality parameters of temp, pH, conductivity, ORP, and turbidity stabilize. Following stabilization, samples will be collected and analyzed by USEPA Method 8260. The data collected will be used to define areas of primary need for the greatest mass reduction and volumes injected into these locations may be adjusted so as ensure contact of the oxidant with the impact present. Upon completion of the injection, the temporary injection wells will be removed in accordance with state regulations.

#### **4.2 ISCO Application – Process Monitoring**

Periodic monitoring for persulfate or elevated pH, which indicate distribution of the oxidant will be conducted at existing monitoring wells within the substation during the ISCO application. Chemetrics test kits will be used to test the persulfate concentration and pH paper will be used for a general reading on alkalinity. Adjacent wells will be monitored for pH to confirm continuing persulfate reaction with COCs. This information will be used to adjust location volume and flow rate to better ensure contact of solution with the impact that is present.

#### **4.3 Post-ISCO Application – Performance Monitoring**

Groundwater monitoring post-application is required to evaluate the overall treatment effectiveness and determine if rebound is occurring. The post-application monitoring plan will be conducted monthly for a minimum of 5 months, starting 1 month after the ISCO application is complete. The monitoring duration may change based on the results of the ISCO application monitoring.

#### **4.4 Coordination with EPA Site Investigation**

The United States Environmental Protection Agency (USEPA) plans on conducting direct push site investigation activities north of both the substation property and Highway 370. The ISCO application cannot impact or interfere with such activities because the on-site persulfate injection will induce a chemical reaction that will occur only within substation boundaries and that will result in limited residual residence time. The previously installed ZVI barriers remain in place and are operational as will be the GETS. Monitoring will ensure that any discharges from the Site comply with National Pollutant Discharge Elimination System (NPDES) pH permit conditions.

#### **4.5 Re-Establishment of Bioremediation**

From 2014 through 2022, several in situ bioaugmentation/bioremediation applications have been performed in the substation. Each application was designed to target within the vertical interval to be treated in the proposed ISCO application (45 feet to 55 feet below ground surface [bgs]). During each bioaugmentation/bioremediation application, groundwater was



amended to create ideal subsurface conditions for chlorinated solvent-degrading bacteria, dehalococcoides (DHC), to degrade site COCs into innocuous end products, ethene and ethane.


The proposed ISCO application will eliminate the DHC population that has been built up over the past 8 years. After post-injection performance monitoring is complete, and the effectiveness of the ISCO applications has been determined, additional bioaugmentation/bioremediation injections will be performed at the site to re-establish the DHC population and bioaugmentation treatment zone in the subsurface. The scale and scope of those injections will be provided at a later date, in a separate document.

## 5. PILOT TEST SCHEDULE

The schedule and estimated task duration is presented below. LEA can be prepared to start the mobilization portion of the ISCO pilot test the week of January 23, 2023.

Task	Date (duration)
AAP ISCO Pilot Test Application	
Preparations and Procurement	December 2022
Temporary Injection Well Installation and Baseline Sampling	January 2023
On-Site Mobilization (3 days)	January 23 - 25, 2023
Chemical Delivery	January 24 - 25, 2023
ISCO Application	January 26 through February 17, 2023
Site Demobilization	February 20 and February 21, 2022
Post-ISCO Application Performance Monitoring	March/April 2023 through July 2023 (Minimum 5 months)
Re-establish Bioremediation	June/July 2023

**FIGURE**



LEGEND

- PROPOSED TEMPORARY INJECTION LOCATION (ASSUMED 15 FT ROI)
- PZ-11 MONITORING WELL
- CW-6 CITY WELL

NOTES:

1. Radius of influence (ROI) per injection location is assumed at 15 feet based on proposed injection volumes and assumed soil porosity.



SCALE: AS SHOWN
DATE: DECEMBER 2022
PROJECT No.: 088UE2.08
CLIENT: AMEREN
DRAWN BY: PC
CHECKED BY: DI
APPROVED BY: DI



TITLE: SITE PLAN ISCO TREATMENT AREA - SUBSTATION HUSTER RD. ST. CHARLES, MO		
DRAWING NO.	FIGURE 1	REV.

## **APPENDICES**



## Project Health and Safety Plan

Ameren Missouri - Huster Road Substation

Project Name: Huster Road Substation Commission or Project #: 088UE2.01  
Client Name: Ameren Missouri Project Location: St. Charles, Missouri  
Field Work Start Date: 1/1/2022 Anticipated Duration: 3 years

Project Description (include anticipated work tasks): Operation and maintenance of the groundwater extraction system (GETS), in situ bioremediation / bioaugmentation injections (as needed), associated groundwater monitoring, and soil sampling / air monitoring during site construction activities (not associated with remedial activities) and waste characterization.

This Project Health and Safety Plan (HASP) was prepared for Loureiro employees performing a specific scope of work. It was prepared based on the best available information regarding the physical and chemical hazards known or suspected to be present on the project site. While it is not possible to discover, evaluate, and protect in advance against all possible hazards, which may be encountered during the completion of this project, adherence to the requirements of the HASP will significantly reduce the potential for occupational injury or illness. This HASP must be completed by a competent person, approved by the Project Manager or Superintendent, and reviewed and signed by the project team.

Job Hazard Analyses (JHAs) for the primary work tasks identified for this project shall be attached to this HASP. The sections below identify the hazards of the project and minimum safe work practices to be used by the project team while on-site.

This HASP was completed by: Karen O'Shaughnessy Date: 1/13/2022  
Project Manager or Superintendent: Derek Ingram Date: 1/13/2022

### Project Team & Emergency Contacts


Company / Entity	Role	Name	Primary Contact Number
Loureiro	Project Manager / Superintendent	Derek Ingram	314-609-3065
	Safety Lead	Reginald Gardner	618-567-4703
	Field Personnel	Troy Eppinger	618-407-2347
Ameren	Project Manager	Barbara Miller	314-223-4655
	Director Substation Maintenance & Construction	Joe Fitzgerald	314-288-9539
	Substation Supervisor	Jay Pidcock	314-608-6146
	Substation Emergency Response	Ameren Distribution Dispatch	573-681-7567
		Ameren Transmission Dispatch	314-554-2262
Local Fire Department	Emergency Response	St. Charles Fire Department	911
Local Police		St. Charles Police Department	911
Sedgwick	Injury Management	Clinical Consultation	1-855-811-5702
Poison Control	Poison Emergency	U.S Poison Control Centers	800-222-1222
DigSafe	Utility Clearance	National DigSafe Call Center	811
Missouri Department of Natural Resources (MDNR)	Project Manager	Feyi Ilesanmi	
MDNR Environmental Emergency Response	Discharge, Spill, and/or Release Notification	NA	573-634-2436
<b>Stop Work Authority</b> - Any employee or subcontractor may halt a job or task when a hazardous situation appears imminent. Work may resume once the hazard is eliminated or controlled.			



## Emergency Medical Facility Information

Medical Center Name: **Barnes-Jewish St. Peters Hospital Location**

Address: **10 Hospital Drive; St. Peters, MO 63376**



### Additional Emergency Information

In addition to any client or work location requirements, follow this basic emergency protocol in the event of an emergency:

1. In the event of a fire or other emergency, evacuate as soon as possible to a safe assembly location upwind of the incident.
2. If fire extinguishers are available, they may only be used by trained personnel against a fire still in its beginning stage.
3. In the event of an injury or illness:
  - a. For life-threatening incidents, initiate emergency response (911 or local contact number) and notify Manager.
  - b. If the injury is not life threatening, but may require clinical attention or advice, the employee notifies his or her Manager then contact Health & Safety.
  - c. A first-aid kit should be available for minor injuries, by an employee who is first aid trained.
4. If chemicals are handled on-site, ensure proper spill prevention and containment is immediately available for use, spill response can only be handled by trained personnel, otherwise evacuate and contact the local fire department or designated responder.
5. All workplace injuries and illnesses must be reported to Loureiro H&S as soon as possible. For workplace injury or illness incidents, the Manager must complete an Incident Investigation Form (available in Appendix A of the [Incident Reporting Program](#)) within 24 hours of the incident and submit it electronically to Loureiro H&S department.

#### Evacuation Assembly Area:

Site layout showing assembly area is attached

#### Emergency Communication:

- |  |  |                                   |
|--|--|-----------------------------------|
| <input checked="" type="checkbox"/> Cell Phone | <input checked="" type="checkbox"/> Hand Signals | <input type="checkbox"/> Air Horn |
| <input type="checkbox"/> Radio                 | <input checked="" type="checkbox"/> Verbal       | <input type="checkbox"/> Other:   |

☒ Client specific safety procedures or protocols included on page 7 or attached to this HASP.

Project Hazard Assessment (Check all that apply)			
<b>General Hazards</b> <input type="checkbox"/> N/A	<input checked="" type="checkbox"/> Aerial Lift Work (Operator training required) <input checked="" type="checkbox"/> Compressed Gases Storage/Use <input type="checkbox"/> Confined Spaces (CSE Training Required for Permit Entry) <input checked="" type="checkbox"/> Construction Exposure <input checked="" type="checkbox"/> Drilling/Test Pitting <input checked="" type="checkbox"/> Energized Equipment or Circuits <input type="checkbox"/> Excavation/trenching Work	<input type="checkbox"/> Falls from Elevated Work (>4 feet) <input type="checkbox"/> Flammable Liquids Storage/Use <input checked="" type="checkbox"/> Forklifts/Lulls (Operator training required) <input type="checkbox"/> Heavy Equipment Use <input type="checkbox"/> Hot Work – Cutting, welding, or grinding generated sparks or heat sources. (Hot work permit required) <input type="checkbox"/> Manufacturing Area Exposure <input type="checkbox"/> Pinch Points	<input type="checkbox"/> Rotating Equipment <input checked="" type="checkbox"/> Slips and Trips <input checked="" type="checkbox"/> Utilities – Overhead or Underground <input checked="" type="checkbox"/> Vehicular Traffic <input type="checkbox"/> Working In, Over, or Adjacent to Water <input type="checkbox"/> Falling/Overhead Objects <input checked="" type="checkbox"/> Power Equipment/Tool
<b>Biological / Environmental Hazards</b> <input type="checkbox"/> N/A	<input checked="" type="checkbox"/> Excessive Cold (<32°F) <input checked="" type="checkbox"/> Excessive Heat (>91°F) <input type="checkbox"/> Microbiological (bacterial/viral) such as in wastewater or research labs <input checked="" type="checkbox"/> Mosquitoes	<input checked="" type="checkbox"/> Poisonous Plants (Ivy, oak, sumac, ragweed, hogweed, etc.) <input checked="" type="checkbox"/> Ticks <input checked="" type="checkbox"/> Venomous animals (Spiders, wasps, bees, snakes, etc.)	<input type="checkbox"/> Wild/Dangerous Animals <input checked="" type="checkbox"/> Wet Conditions <input type="checkbox"/> Other:
<b>Chemical Hazards</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Acid and Alkaline Substances <input checked="" type="checkbox"/> Contaminated Soil/Particulate <input type="checkbox"/> Flammable/Explosive <input type="checkbox"/> Organic Solvents	<input checked="" type="checkbox"/> Oxidizers <input type="checkbox"/> Radiological ( <b>Contact H&amp;S</b> ) <input type="checkbox"/> Reactive <input checked="" type="checkbox"/> Volatiles/Semi Volatiles	<input checked="" type="checkbox"/> <i>List site-specific constituents (or attach to HASP):</i> 1. Chlorinated VOCs (PCE, TCE, 1,1-DCE, trans-1,2-DCE, cis-1,2-DCE, and VC) 2. Sodium permanganate (residual oxidant in groundwater from previous remedial activities)
<b>Ergonomic Hazards</b> <input type="checkbox"/> N/A	<input checked="" type="checkbox"/> Bending/Twisting <input type="checkbox"/> Climbing	<input checked="" type="checkbox"/> Pulling/Tugging <input checked="" type="checkbox"/> Lifting	<input type="checkbox"/> Repetitive Motion
<b>Eye/Face Hazards</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Acid and Alkaline Substances <input type="checkbox"/> Laser Operations <input checked="" type="checkbox"/> Liquid Splashes	<input type="checkbox"/> Particulates <input type="checkbox"/> Sharps/Punctures <input type="checkbox"/> Ultraviolet Radiation	<input type="checkbox"/> Welding Arc <input type="checkbox"/> Other:
<b>Foot Hazards</b> <input type="checkbox"/> N/A	<input checked="" type="checkbox"/> Crush <input checked="" type="checkbox"/> Sharps/Puncture	<input type="checkbox"/> Conductive Hazards <input type="checkbox"/> Chemical Hazards	<input type="checkbox"/> Other:
<b>Hand Hazards</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Acid and Alkaline Substances <input checked="" type="checkbox"/> Excessive Cold (Surface <40°F) <input checked="" type="checkbox"/> Excessive Heat (Surface >100°F)	<input checked="" type="checkbox"/> Handling Contaminated Media <input type="checkbox"/> High Vibration <input type="checkbox"/> Organic Solvents	<input type="checkbox"/> Sharps/Punctures <input type="checkbox"/> Other:
<b>Hearing Hazards</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Impact Noise	<input checked="" type="checkbox"/> High Ambient Noise	<input type="checkbox"/> Other:
<b>Respiratory Hazards</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Acid Gases <input type="checkbox"/> Asbestos ( <b>Contact H&amp;S</b> ) <input type="checkbox"/> Asbestos/Particles <input type="checkbox"/> Ammonia <input type="checkbox"/> Chromium	<input type="checkbox"/> Lead ( <b>Contact H&amp;S</b> ) <input type="checkbox"/> Mercury Vapor <input type="checkbox"/> Methylamine <input type="checkbox"/> Mold <input checked="" type="checkbox"/> Organic Vapors	<input type="checkbox"/> Oxygen Deficient <input type="checkbox"/> Particulate (respirable) <input type="checkbox"/> Silica (respirable, crystalline) <input type="checkbox"/> Welding Fumes <input type="checkbox"/> Other:

Personal Protective Equipment Requirements (Check all that apply)			
Completion of this section also serves as a certified personal protective equipment (PPE) hazard assessment.			
<b>Level D Work Gear</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Cotton Coveralls <input checked="" type="checkbox"/> Hard Hat <input checked="" type="checkbox"/> Hi-Visibility Vest or Equivalent	<input checked="" type="checkbox"/> Long Pants <input type="checkbox"/> Rubber Boots <input checked="" type="checkbox"/> Sleeved shirts (short or long, as appropriate)	<input checked="" type="checkbox"/> Safety Glasses <input checked="" type="checkbox"/> Safety-Toed Boots
<b>Body Protection</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Fire Resistant Clothing <input type="checkbox"/> Fully Encapsulating Suit <input type="checkbox"/> Tyvek Coveralls or Equivalent	<input type="checkbox"/> Lab Coat <input checked="" type="checkbox"/> Tyvek® QC Coveralls or Equivalent <input type="checkbox"/> Tyvek® SL Coveralls or Equivalent	<input type="checkbox"/> Insulated Coveralls <input type="checkbox"/> Personal Fall Arrest System (appropriate harness, lanyard, anchor point) <input type="checkbox"/> Other:
<b>Electrical Clothing / Equipment</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Arc-Flash Hazard Clothing: (qualified electrical workers only) <input type="checkbox"/> PPE Category 1 <input type="checkbox"/> PPE Category 2 <input type="checkbox"/> PPE Category 3 or 4 (Not allowed by Loureiro, must be subcontracted)	<input type="checkbox"/> High Visibility Vest (arc rated) <input type="checkbox"/> Personal Fall Arrest System (arc rated) <input type="checkbox"/> Insulated Tools <input type="checkbox"/> Multi-meter	<input checked="" type="checkbox"/> GFCI <input type="checkbox"/> Other:
<b>Eye / Face Protection</b> <input type="checkbox"/> N/A	<input checked="" type="checkbox"/> Chemical Goggles <input checked="" type="checkbox"/> Face Shield	<input type="checkbox"/> Welding Goggles <input type="checkbox"/> Welding Helmet	<input type="checkbox"/> Welding Screens
<b>Hand Protection</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Anti-Vibration Gloves <input type="checkbox"/> Butyl Gloves <input type="checkbox"/> Cotton Gloves <input type="checkbox"/> Insulated Gloves or Glove Liners	<input checked="" type="checkbox"/> Cut-Resistant Gloves <input type="checkbox"/> Leather Gloves <input type="checkbox"/> Neoprene Gloves	<input type="checkbox"/> Rubber Gloves <input checked="" type="checkbox"/> Nitrile Gloves <input type="checkbox"/> Other:
<b>Head Protection</b> <input checked="" type="checkbox"/> N/A	<input type="checkbox"/> Bump/Miners Helmet	<input type="checkbox"/> Head Lamp	<input type="checkbox"/> Other:
<b>Hearing Protection</b> <input type="checkbox"/> N/A	<input checked="" type="checkbox"/> Ear Plugs* *For noise levels exceeding 85dBA. Check the Noise Reduction Rating of plugs to ensure adequate protection.	<input checked="" type="checkbox"/> Ear Muffs*	<input type="checkbox"/> Ear plugs and muffs** **Dual protection is recommended by NIOSH for noise levels exceeding 100 dBA.
<b>Respiratory Protection</b> <input checked="" type="checkbox"/> N/A	<b>Respiratory Protection (If respiratory protection is required, refer to the <a href="#">Respiratory Protection Program</a> of the Corporate H&amp;S Program Manual. <i>Every employee shall ensure that facial hair does not interfere with the effectiveness of their respirator.</i> Each employee voluntarily wearing a respirator must have prior approval from H&amp;S department)</b>		
	<b>Respirator Type</b> <input type="checkbox"/> Dust Mask (nuisance dust) <input type="checkbox"/> Half Face <input type="checkbox"/> Full Face <input type="checkbox"/> Powered APR <input type="checkbox"/> Airline Respirator or SCBA (Contact H&S)	<b>Cartridge Types</b> <input type="checkbox"/> Particulate P100 <input type="checkbox"/> Organic Vapor <input type="checkbox"/> Mercury Vapor <input type="checkbox"/> Acid Gas <input type="checkbox"/> Ammonia / Methylamine <input type="checkbox"/> Other:	
<b>Additional PPE</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Insect gaiters <input checked="" type="checkbox"/> Insect Repellent (DEET, permethrin)	<input type="checkbox"/> Personal Flotation Device <input checked="" type="checkbox"/> Sunscreen (broad spectrum)	<input type="checkbox"/> Waders <input type="checkbox"/> Other:



Air Monitoring Protocol (Check all that Apply, if Required)			
<b>Task(s) Requiring Monitoring</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Confined Space Entry <input checked="" type="checkbox"/> Excavation	<input type="checkbox"/> Exclusion Zone Monitoring <input type="checkbox"/> Worksite Perimeter Monitoring	<input type="checkbox"/> Other:
<b>Air Hazards</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Asbestos ( <b>Contact H&amp;S</b> ) <input type="checkbox"/> Carbon Monoxide <input type="checkbox"/> Dioxins <input type="checkbox"/> Hexavalent Chromium <input type="checkbox"/> Respirable Crystalline Silica (air monitoring not required if Table 1 is followed. See page 6 for more silica controls)	<input type="checkbox"/> Hydrogen Sulfide (H <sub>2</sub> S) <input type="checkbox"/> Lead ( <b>Contact H&amp;S</b> ) <input type="checkbox"/> Particulate <input type="checkbox"/> PCBs	<input checked="" type="checkbox"/> Volatile Organics <input type="checkbox"/> Oxygen <input type="checkbox"/> Other: <input type="checkbox"/> Hydrocarbons
<b>Air Monitoring Equipment / Device</b> <input type="checkbox"/> N/A	<input type="checkbox"/> Aerosol/Dust Meter <input type="checkbox"/> Colorimetric Tubes <input type="checkbox"/> Heat monitoring equipment <input type="checkbox"/> Multi-gas meter	<input type="checkbox"/> Noise Meter <input type="checkbox"/> Personal Sampling Badges <input type="checkbox"/> Personal Sampling Pumps <input checked="" type="checkbox"/> Photoionization Detector	<input type="checkbox"/> Other:
Equipment	Chemical of Concern	Action Levels	Safety Action
<input type="checkbox"/> Aerosol Dust Meter	Nuisance Dust or Particulates	Any visual observation of uncontrolled dust or >5 mg/m <sup>3</sup> in work zone; or >0.150 mg/m <sup>3</sup> above background at work zone perimeter.	Stop work, apply wet controls to reduce dust generation, other controls such as HEPA vacuum units for power tools may also be evaluated as applicable.
<input type="checkbox"/> Multi-Gas Meter	Hazardous Atmosphere	Oxygen >19.5%-<23.5% LEL < 10% H <sub>2</sub> S < 10 ppm CO < 35 ppm	Stop work, apply ventilation controls to bring the atmosphere within safe limits. Monitor continuously if atmosphere does not improve, stop work, and <b>contact H&amp;S</b> .
<input checked="" type="checkbox"/> PID	Volatile Organics	> 5 ppm sustained for >1 minute or any reading > 10 ppm in breathing zone.	Stop work; apply ventilation to reduce concentrations. If concentrations cannot be reduced, stop work, move to safe locations, and <b>contact H&amp;S</b> .
<input type="checkbox"/> Other			

Additional Planning Considerations and Controls			
<b>Work Area / Traffic Controls</b>	<input checked="" type="checkbox"/> Caution/Warning Tape	<input type="checkbox"/> Police Detail/Escort	<input checked="" type="checkbox"/> Work Zone Signage
	<input checked="" type="checkbox"/> Fencing	<input checked="" type="checkbox"/> Traffic Cones	<input type="checkbox"/> Other:
	<input type="checkbox"/> Low Visibility/Evening Work	<input type="checkbox"/> Traffic Control Plan Required (refer to plan)	
	<input type="checkbox"/> Flaggers	<input type="checkbox"/> Vehicle Barriers	
<b>Heat Stress Controls</b>	<input checked="" type="checkbox"/> Water and rest breaks provided	<input checked="" type="checkbox"/> Potable water onsite	<input type="checkbox"/> Other:
	<input checked="" type="checkbox"/> Employees trained in recognition of heat-related illnesses	<input checked="" type="checkbox"/> Access to AC in vehicle, office, trailer, nearby building, etc.	
<b>Sanitation</b>	<input checked="" type="checkbox"/> Portable toilet (1 per 20 workers – Doesn't apply to mobile crews with transportation readily available to nearby toilet facilities) <input type="checkbox"/> Showers/Changing Rooms – Needed when project is greater than 6 months or if decontamination procedures indicate a need		
Hazard Communication			
Which hazardous chemicals will be used or maintained at the jobsite by Loureiro personnel?			
<input type="checkbox"/> None. No further action needed. <input checked="" type="checkbox"/> Attach inventory list and Safety Data Sheets (SDSs). Refer to the SharePoint Site for database of current SDSs, or contact the chemical manufacturer directly for SDS. <i>All SDSs for this project must be saved to the project folder, in the Health &amp; Safety folder.</i>			
Crystalline Silica Exposure Control Plan			
Any tasks involving sanding, drilling, jackhammering, sawing, or mixing of asphalt, brick, concrete products, rock, sand, or stone?			
<input checked="" type="checkbox"/> None. No further action needed.	<input type="checkbox"/> Employees Avoid All Respirable Silica-Generating Areas <input type="checkbox"/> Follow All Controls in OSHA Silica Table 1 (located in the Construction Safety Program in the Corporate H&S Program Manual)		<input type="checkbox"/> Exposure Determination Needed (required if employees have exposure and OSHA Silica Table 1 is not followed – <b>contact H&amp;S</b> ) <input type="checkbox"/> Routine Observations by Competent Person (required for construction projects generating silica above 25 µg/m3). The Competent Person for this project is:
Permit Required Activities			
Any Loureiro required permits and Client required permits should be included with this HASP.			
Activity		Permit Process	
<input checked="" type="checkbox"/> None. No further action needed.	<input type="checkbox"/> <b>Confined Space Entry.</b> Will the work include a permit required entry of a confined space by employees following this HASP?	CSE Planning Checklist and Entry permit(s) must be attached to this HASP and completed as applicable. They are available in the <a href="#">Confined Space Entry Program</a> of the Corporate H&S Program Manual.	
	<input type="checkbox"/> <b>Lock Out / Tag Out.</b> Will hazardous energies need to be controlled to conduct work tasks?	Equipment-specific energy control procedures will be developed and attached to this HASP.	
	<input type="checkbox"/> <b>Hot Work.</b> Will hot work be performed by employees following this HASP?	Hot work permit(s) must be attached to this HASP and completed as applicable. Permit is available in the <a href="#">Construction Safety Program</a> of the Corporate H&S Program Manual.	
	<input type="checkbox"/> <b>Groundbreaking.</b> Will groundbreaking be performed by employees following this HASP?	Pre-Groundbreaking Checklist and Groundbreaking Permit(s) must be attached to this HASP and completed as applicable. Checklist and Permit are available in the <a href="#">Utility Location Program</a> of the Corporate H&S Program Manual.	
	<input type="checkbox"/> <b>Client required permit:</b>		

## Specialized Requirements

(Please check if any of the following is required for work on the Site. Contact H&S for further guidance)

<input type="checkbox"/> None. No further action needed.	<input type="checkbox"/> Confined Space Entry	<input type="checkbox"/> OSHA 10 Hour General Industry Safety Training
	<input type="checkbox"/> First Aid/CPR ( <i>Required if emergency care is more than 3-4 minutes from project location</i> )	<input type="checkbox"/> OSHA 30 Hour Construction Safety Training
	<input checked="" type="checkbox"/> HAZWOPER 40 Hour Training & Annual Refresher	<input type="checkbox"/> Powered Industrial Vehicle Operation (PIV)
	<input checked="" type="checkbox"/> HAZWOPER 8 Hour Supervisory Training (Required for Site Safety Officer/Field Lead/Project Manager)	<input type="checkbox"/> Silica Awareness Training
	<input type="checkbox"/> Lock Out / Tag Out	<input checked="" type="checkbox"/> Other: <b>Ameren Contractor EH&amp;S Training must be completed before entering the substation</b>
	<input checked="" type="checkbox"/> OSHA 10 Hour Construction Safety Training	

## Surveillance Components

Refer to the [Medical Surveillance Program](#) of the Corporate H&S Program Manual for guidance on this section.

<input type="checkbox"/> None. No further action needed.	<input checked="" type="checkbox"/> HAZWOPER Medical Surveillance	<input type="checkbox"/> USDOT Screenings
	<input type="checkbox"/> Medical Clearance for Respirator Use	<input type="checkbox"/> Vision Test (required every 3 years to operate a PIV)
	<input type="checkbox"/> Silica Medical Clearance (for employees wearing respirator for silica protection ≥ 30 days per year.)	<input checked="" type="checkbox"/> Client Required Screenings
	<input type="checkbox"/> Other:	

## Decontamination Procedures

<input type="checkbox"/> Not Required	<input checked="" type="checkbox"/> Required (Attach procedures to HASP)
---------------------------------------	--

## Job Hazard Analysis

Please list all JHA's for the project and attach them to this HASP

- |   |   |
|---|---|
| 1. General Site Activities                            | 4. Soil Monitoring and Sampling                                   |
| 2. In Situ Bioremediation / Bioaugmentation Injection | 5. Groundwater Extraction System (GETS) operation and maintenance |
| 3. Groundwater Monitoring                             | 6.  |

## Client Specific Emergency Procedures

Please summarize any additional emergency procedures or reporting protocols below or attach to this HASP

Immediately contact:

Ameren Distribution Dispatch at (573) 681-7567 and Ameren Transmission Dispatch at (314) 554-2262.



## ASSEMBLY AREA



## Decontamination Procedures

The JHAs included in the HASP outline procedures to minimize contamination of on-site personnel. **In most cases, PPE will be removed without need for decontamination procedures and will be deposited in a designated container for disposal.**

There is a potential that certain tasks will require implementation of the personal decontamination procedures outlined below. Such a determination will be made by the site safety lead and will typically be presented during the daily safety meeting. Prior to commencing work, all personnel will be trained in routine decontamination procedures by the site safety lead or appointed designee.

### Procedure:

All employees leaving a contaminated area shall be decontaminated as appropriate. Personal decontamination procedures, if deemed necessary by the site safety lead, will be as follows:

- Rinse and dispose of outer disposable protective clothing and boots.
- If permeable clothing becomes wetted with hazardous materials, the clothing should be removed. Such wetted clothing shall be decontaminated or disposed of before it is removed from the work zone.
- Remove outer non-disposable protective clothing while keeping inner gloves/boots on.
- Wash face, hands, and forearms.

### Location:


Decontamination should occur in a location that will minimize the exposure of uncontaminated employees or equipment to contaminated employees or equipment. A personal decontamination station where workers can drop equipment and remove PPE will be set up inside the boundary of the work zone.

**Good personal hygiene practices will be followed at all times.** Handwashing facilities will be provided, and personnel are required to wash hands prior to entering vehicles, eating, drinking, or when departing the work zone.

### Section 1: Identification

Product Name:	<b>EOS Pro</b>
Chemical Description:	Mixture; vegetable oil emulsion
Manufacturer:	EOS Remediation 1101 Nowell Road Raleigh, NC 27607 (P): 919-873-2204 www.eosremediation.com
Recommended Use:	Groundwater bioremediation (environmental applications)
Restricted Use:	Not for human consumption.
24-Hour Emergency Contact:	ChemTel: United States (P): 800-255-3924 ChemTel: International (P): 813-248-0585

### Section 2: Hazard(s) Identification

Hazard Classification:	Irritant (skin and eye)
Signal Word:	Warning
Hazard Statement(s):	Potential eye and skin irritant.
Pictograms:	
Precautionary Statement(s):	Not for human consumption. Do not store near excessive heat or oxidizers. Avoid contact with eyes and skin. Wear protective gloves and eye protection.

### Section 3: Composition/Information on Ingredients

Common Name(s)	CAS NO.	% by Weight
Soybean Oil	8001-22-7	59.8
Food Grade Emulsifiers Trade Secret <sup>1,2</sup>	Proprietary	10
Soluble Substrates Trade Secret <sup>1,2</sup>	Proprietary	4
Food Additives/Preservatives Trade Secret <sup>1</sup>	Proprietary	0.3
Nutrients/Extracts Trade Secret <sup>1,2</sup>	Proprietary	1
Water	7732-18-5	Balance

1 – The precise composition of this product is proprietary information. A more complete disclosure will be provided to a physician in the event of a medical emergency.

2 – The soluble substrates and emulsifiers are generally recognized as safe for food contact.



**Section 4: First-Aid Measures**

Routes of Exposure	Emergency First-Aid Procedures
Inhalation	Remove to fresh air.
Eye Contact	Flush with water for 15 minutes; if irritation persists see a physician.
Skin Contact	Wash with mild soap and water.
Ingestion	Product is non-toxic. If nausea occurs, induce vomiting and seek medical attention.

**Section 5: Fire-Fighting Measures**

Extinguishing Media:	CO <sub>2</sub> , foam, dry chemical Note: Water, fog and foam may cause frothing and spattering.
Special Fire Fighting Procedures:	Wear self-contained breathing apparatus and chemical resistant clothing. Use water spray to cool fire exposed containers.
Fire Hazard(s):	Burning will cause oxides of carbon.

**Section 6: Accidental Release Measures**

Personal Precautions:	Avoid contact with eyes and skin. Do not consume.
Emergency Procedures:	N/A
Methods & Materials used for Containment:	Compatible granular absorbent
Cleanup Procedures:	Spread compatible granular absorbent over spill area and sweep using broom and pan; dispose in appropriate receptacle. Clean area with water.

**Section 7: Handling and Storage**

Safe Handling & Storage:	Do not store near excessive heat or oxidizers.
Other Precautions:	Consumption of food and beverages should be prevented in work area where product is being used. After handling product, always wash hands and face thoroughly with soap and water before eating, drinking, or smoking.

**Section 8: Exposure Controls/Personal Protection****Exposure Limits**

OSHA PEL:	NE	
ACGIH TLV:	NE	
NIOSH REL:	NE	

**Personal Protective Measures**

Respiratory Protection:	Not normally required. P95 respirator if aerosols might be generated.
Hand Protection:	Protective gloves are recommended
Eye Protection:	Recommended
Engineering Measures:	Local exhaust ventilation if aerosols are generated
Hygiene Measures:	Wash promptly with soap & water if skin becomes irritated from contact.
Other Protection:	Wear appropriate clothing to prevent skin contact.



**Section 9: Physical and Chemical Properties**

Appearance:	White Liquid	Explosive Limits:	NE
Odor:	Vegetable Oil	Vapor Pressure:	NE
Odor Threshold:	NE	Vapor Density:	Heavier than air
pH:	Neutral	Relative Density:	0.96-0.98
Melting Point/Freezing Point:	Liquid at room temperature	Solubility:	Dispersible
Boiling Point:	212°F (100°C)	Partition coefficient:	NE
Flash Point:	>300°F (149°C)	Auto-ignition Temperature:	NE
Evaporation Rate:	NE	Decomposition Temperature:	N/A
Flammability (solid, gas):	NE	Viscosity:	500-1500 cP

NE – Not Established

**Section 10: Stability and Reactivity**

Stability:	Stable
Incompatibility:	Strong acids and oxidizers
Hazardous Decomposition Products:	Thermal decomposition may produce oxides of carbon
Hazardous Reactions/Polymerization:	Will not occur
Conditions to Avoid:	None known

**Section 11: Toxicological Information**

Likely Routes of Exposure:	Ingestion, dermal and eye contact
Signs and Symptoms of Exposure:	None known
Health Hazards	
Acute:	Potential eye and skin irritant
Chronic:	None known
Carcinogenicity	
NTP:	No
IARC:	No
OSHA:	No

**Section 12: Ecological Information (non-mandatory)**

There is no data on the ecotoxicity of this product.

**Section 13: Disposal Considerations (non-mandatory)**

Waste Disposal Methods:	Dispose of according to Federal and local regulations for non-hazardous waste. Recycle, if practical.
-------------------------	---

**Section 14: Transport Information (non-mandatory)**

The product is not covered by international regulation on the transport of dangerous goods.

No transport warning required.

**Section 15: Regulatory Information (non-mandatory)**

N/A

**Section 16: Other Information**

Date of Preparation: 29 May 2014

Last Modified Date: 5 September 2014

The information contained herein is based on available data and is believed to be correct. However, EOS Remediation, LLC makes no warranty, expressed or implied, regarding the accuracy of this data or the results to be obtained thereof. This information and product are furnished on the condition that the person receiving them shall make his/her own determination as to the suitability of the product for his/her particular purpose.



# SAFETY DATA SHEET



## 1. IDENTIFICATION OF MATERIAL AND SUPPLIER

**Product Identifier:** Wilclear Sodium Lactate 60% Solution  
**Other Name(s):** sodium lactate  
**Recommended Use:** In-situ Bioremediation  
**Recommended Restrictions:** none known

**Supplier Name:** JRW Bioremediation, LLC  
**Address:** 14321 W. 96<sup>th</sup> Terrace  
Lenexa, KS 66215  
**Telephone:** 913-438-5544  
**EMERGENCY Telephone:** 800-779-5545 x 116 (Mon-Fri 9am-5pm CST)  
913-961-6644 (afterhours)

## 2. HAZARD IDENTIFICATION

### Health & Physical Hazards:

This product contains no substances in their current physical state that are considered to be hazardous to health and has a low order of toxicity. No acute or delayed symptoms or effects have been observed.

### Flammability Hazards:

This is a Non-Flammable liquid

### Reactivity Hazards:

This product is considered stable. There are no known physical or chemical hazards, incompatibilities, hazardous decomposition or byproducts.

### OSHA Hazards:

L

This material is not considered hazardous by OSHA. No labels or signage are known to be required.

### 3. COMPOSITION / INFORMATION ON INGREDIENTS

Components	CAS #	% by Weight	Hazard Classification
Sodium lactate	72-17-3	60%	none
Water	7732-18-5	40%	none

### 4. FIRST-AID MEASURES

**Inhalation:**

Inhalation of mist may cause mild irritation of respiratory system. Move to fresh air.

**Skin Contact:**

In case of contact with skin, immediately wash with plenty of soap and water while removing contaminated clothing. Seek medical attention if skin Irritation develops or persists.

**Eye Contact:**

In case of contact with eyes, immediately flush eyes with water for at least 15 minutes, lifting eyelids to facilitate irrigation. Get medical attention if necessary.

**Ingestion:**

If swallowed, rinse mouth. Should symptoms occur, get medical attention.

**Signs and symptoms of exposure:**

None determined. Treat symptomatically.

**Medical Conditions aggravated by exposure:**

None determined. Treat symptomatically.

### 5. FIRE-FIGHTING MEASURES

**Suitable Extinguishing Media:**

Water, carbon dioxide, foam, or dry chemical.

**Unsuitable Extinguishing Media:**

Do not use heavy water stream as it may spread or scatter.

**Specific hazards from substance/mixture:**

Thermal decomposition may lead to release of irritating or toxic gases and vapors.

**General fire hazards:**

No unusual fire or explosion hazards noted

**Special protective equipment / precautions for fire-fighters:**

Wear full protective clothing and positive pressure breathing apparatus.

## 6. ACCIDENTAL RELEASE MEASURES

### Methods and Materials for containment and clean up:

Contain spill with absorbent materials such as vermiculite or soil; shovel and place material in drum for disposal. Flush area with water. Surfaces may become slippery after spillage. Dispose of according to all local, state, and federal regulations at an approved waste treatment facility.

### Personal precautions / Protective equipment:

Use personal protective equipment. Prevent spills, contamination, and leakage.

### Environmental precautions:

No special environmental precautions required.

## 7. HANDLING AND STORAGE

### Precautions for safe handling:

Observe good work and industrial hygiene practices. Use personal protective equipment. Avoid contact with skin, eyes, and clothing. Avoid breathing mists and vapors. Wash hands after use of this product. Do not eat, drink, or smoke while using product. Prevent spills, contamination, and leakage.

### Conditions for safe storage, including any incompatibilities:

Keep container tightly closed. Keep in properly labeled containers. Store in a well ventilated, cool, dry area.

## 8. EXPOSURE CONTROLS / PERSONAL PROTECTION

### Control parameters:

No exposure or biological limits noted for ingredients(s).

### Appropriate engineering controls:

Use adequate mechanical ventilation, especially in confined spaces. Local exhaust is recommended.  
Temperatures best kept below 200<sup>0</sup> C or 390<sup>0</sup> F.

### Individual protection measures, such as Personal Protective Equipment (PPE):

Eye/Face protection:	Chemical goggles recommended.
Skin / hand / body protection:	Chemical resistant gloves recommended. Suitable protective clothing as defined by employer.
Respiratory protection:	None required under normal use.
General considerations:	Use good industrial hygiene and best safety practices. When using material, do not eat, drink, or smoke. Remove and wash any contaminated clothing before storage or re-use.

## 9. PHYSICAL AND CHEMICAL PROPERTIES

<b>Appearance:</b>	Clear to light yellow
<b>Physical state:</b>	liquid
<b>Odor:</b>	slight to no odor
<b>Odor threshold:</b>	not applicable
<b>pH:</b>	6.0 - 8.5
<b>Melting point/freezing point:</b>	decomposes
<b>Initial boiling point:</b>	221°F
<b>Closed cup Flash point:</b>	not applicable
<b>Evaporation rate:</b>	not determined
<b>Flammability (solid, gas):</b>	not determined
<b>Upper/lower flammability or explosive limits:</b>	not determined
<b>Vapor pressure (Mg Hg):</b>	not determined
<b>Vapor density (air = 1):</b>	not determined
<b>Density:</b>	1320-1340 kg/m <sup>3</sup>
<b>Viscosity</b>	100cP @ 20 <sup>0</sup>
<b>Molecular Weight:</b>	112.07
<b>Solubility in water:</b>	soluble
<b>Auto-ignition temperature:</b>	not determined
<b>Decomposition temperature:</b>	>200 <sup>0</sup> C / >392 °F
<b>Specific Gravity (H<sub>2</sub>O = 1):</b>	1.32 H <sub>2</sub> O=1 @ 20°C

## 10. STABILITY AND REACTIVITY

<b>Reactivity:</b>	Non-reactive under conditions of normal use, storage & transport.
<b>Chemical stability:</b>	Stable under conditions of normal use, storage and transport.
<b>Possibility of hazardous reactions:</b>	
<b>Conditions to avoid:</b>	Temperatures above >200 <sup>0</sup> C / >392 °F
<b>Incompatible materials:</b>	None in particular.
<b>Hazardous decomposition products:</b>	None known.

## 11. TOXICOLOGICAL INFORMATION

No adverse health effects are expected if the product is used as intended and in accordance with this Safety Data Sheet.

- Inhalation:** No known effects but if symptoms are experienced, remove source of contamination or move to fresh air.
- Ingestion:** If swallowed, get medical attention.
- Skin:** In case of contact with skin, immediately wash with plenty of soap and water while removing contaminated clothing. No known effect but seek medical attention if skin irritation develops or persists.
- Eye contact:** In case of contact with eyes, immediately flush eyes with water for at least 15 minutes, lifting eyelids to facilitate irrigation. Get medical attention if necessary.

### Signs & symptoms of exposure:

- Carcinogenicity:** Contains no known ingredient listed as carcinogen.
- Mutagenicity:** No known effect.
- Reproductive Toxicity:** No known effect.

## 12. ECOLOGICAL INFORMATION

- Ecotoxicity:** Product is not considered environmentally hazardous and is not expected to cause significant harm to aquatic, animal, or plant life.
- Persistence/degradability:** Readily biodegradable.
- Bioaccumulative potential:** Not expected to bioconcentrate or bioaccumulate.
- Mobility in soil:** No specific information available.

## 13. DISPOSAL CONSIDERATIONS

### Disposal Methods:

Contain spill with absorbent materials such as clay or soil and shovel and place material in drum for disposal. Surfaces may become slippery after spillage. Dispose of according to all local, state, and federal regulations at an approved waste treatment facility.

## 14. TRANSPORTATION INFORMATION

<b>DOT hazard class:</b>	Not Applicable, non-regulated
<b>Labeling:</b>	Not Applicable
<b>Proper Shipping Name:</b>	Wilclear® Sodium Lactate 60% Solution
<b>NMFC#:</b>	46400.02
<b>Class</b>	70

## 15. REGULATORY INFORMATION

**Restrictions on use:** None.

**Other regulations:** No information available or not applicable.

## 16. OTHER INFORMATION


The information in this SDS summarizes to the best of our knowledge at the date of issue, the chemical health and safety hazards of this material and general guidance for safe handling, use, processing, storage, transportation, disposal, and release. This information is not intended to be considered a warranty or quality specifications. The information contained relates only to the specific material designated and may not be valid if used in conjunction with other materials or in any other processes other than intended use. If further clarification or information is required, please contact JRW Bioremediation.



### Section 1: Identification

Product Name:	EOS® Vitamin B-12 Supplement
Chemical Description:	Solution
Manufacturer:	EOS Remediation 1101 Nowell Road Raleigh, NC 27607 (P): 919-873-2204
Recommended Use:	Groundwater bioremediation (environmental applications)
Restricted Use:	Not for human consumption.
24-Hour Emergency Contact:	ChemTel: United States (P): 800-255-3924 ChemTel: International (P): 813-248-0585

### Section 2: Hazard(s) Identification

Hazard Classification:	Irritant (skin and eye)
Signal Word:	Warning
Hazard Statement(s):	Potential eye and skin irritant.
Pictograms:	
Precautionary Statement(s):	Not for human consumption. Avoid contact with eyes and skin. Wear protective gloves and eye protection. Ingestion of large quantities may cause gastric disturbances.

### Section 3: Composition/Information on Ingredients

Common Name(s)	CAS NO.	% by Weight
Cyanocobalamin	68-19-9	0.2-0.26
Water	7732-18-5	0.74-0.8

### Section 4: First-Aid Measures

Routes of Exposure	Emergency First-Aid Procedures
Inhalation	Remove to fresh air.
Eye Contact	Flush with water for 15 minutes; if irritation persists see a physician.
Skin Contact	Wash with mild soap and water.
Ingestion	Product is non-toxic. If nausea occurs, induce vomiting and seek medical attention.

**Section 5: Fire-Fighting Measures**

Extinguishing Media:	CO <sub>2</sub> , foam, dry chemical
Special Fire Fighting Procedures:	None
Fire Hazard(s):	None

**Section 6: Accidental Release Measures**

Personal Precautions:	Avoid contact with eyes and skin. Do not consume.
Emergency Procedures:	N/A
Methods & Materials used for Containment:	Compatible granular absorbent
Cleanup Procedures:	Spread compatible granular absorbent over spill area and sweep using broom and pan; dispose in appropriate receptacle. Clean area with water.

**Section 7: Handling and Storage**

Safe Handling & Storage:	Keep container tightly closed in a dry and well-ventilated place. Protect from sunlight. Recommended storage temperature is 2-8 °C.
Other Precautions:	Consumption of food and beverages should be prevented in work area where product is being used. After handling product, always wash hands and face thoroughly with soap and water before eating, drinking, or smoking.

**Section 8: Exposure Controls/Personal Protection****Exposure Limits**

OSHA PEL:	NE	
ACGIH TLV:	NE	
NIOSH REL:	NE	

**Personal Protective Measures**

Respiratory Protection:	Not normally required.
Hand Protection:	Protective gloves are recommended
Eye Protection:	Recommended
Engineering Measures:	Local exhaust ventilation
Hygiene Measures:	Wash promptly with soap & water if skin becomes irritated from contact.
Other Protection:	Wear appropriate clothing to prevent skin contact.

**Section 9: Physical and Chemical Properties**

Appearance:	Red Liquid	Explosive Limits:	N/A
Odor:	None	Vapor Pressure:	24 mm Hg
Odor Threshold:	N/A	Vapor Density:	NE
pH:	Neutral	Relative Density:	NE
Melting Point/Freezing Point:	32°F (0°C)	Solubility:	Soluble
Boiling Point:	212°F (100°C)	Partition coefficient:	NE
Flash Point:	NE	Auto-ignition Temperature:	NE
Evaporation Rate:	NE	Decomposition Temperature:	NE
Flammability (solid, gas):	NE	Viscosity:	NE

**Section 10: Stability and Reactivity**

Stability:	Stable. Decomposes on exposure to light.
Incompatibility:	Water reactive materials
Hazardous Decomposition Products:	None known
Hazardous Reactions/Polymerization:	Will not occur
Conditions to Avoid:	None known

**Section 11: Toxicological Information**

Likely Routes of Exposure:	Ingestion, dermal and eye contact
Signs and Symptoms of Exposure:	None known
Health Hazards	
Acute:	Potential eye and skin irritant. Ingestion in large amounts may cause gastric disturbances.
Chronic:	None known
Carcinogenicity	
NTP:	No
IARC:	No
OSHA:	No

**Section 12: Ecological Information (non-mandatory)**

There is no data on the ecotoxicity of this product.

**Section 13: Disposal Considerations (non-mandatory)**

Waste Disposal Methods:	Dispose of according to Federal and local regulations for non-hazardous waste. Recycle, if practical.
-------------------------	---

**Section 14: Transport Information (non-mandatory)**

The product is not covered by international regulation on the transport of dangerous goods.

No transport warning required.

**Section 15: Regulatory Information (non-mandatory)**

N/A

**Section 16: Other Information**

Date of Preparation:	21 November 2014
Last Modified Date:	21 November 2014
The information contained herein is based on available data and is believed to be correct. However, EOS Remediation, LLC makes no warranty, expressed or implied, regarding the accuracy of this data or the results to be obtained thereof. This information and product are furnished on the condition that the person receiving them shall make his/her own determination as to the suitability of the product for his/her particular purpose.	



# SAFETY DATA SHEET

## 1. Identification

Product identifier	RemOx® L ISCO Reagent
Other means of identification	Not available.
Recommended use	Liquid oxidant recommended for applications that require a concentrated permanganate solution.
Recommended restrictions	Use in accordance with supplier's recommendations.
<b>Manufacturer / Importer / Supplier / Distributor information</b>	
Manufacturer/Supplier	CARUS CORPORATION
Address	315 Fifth Street, Peru, IL 61354, USA
Telephone	815 223-1500 - All other non-emergency inquiries about the product should be directed to the company salesmkt@caruscorporation.com
E-mail	www.caruscorporation.com
Website	Dr. Chithambarathanu Pillai
Contact person	For Hazardous Materials [or Dangerous Goods] Incidents ONLY (spill, leak, fire, exposure or accident), call CHEMTREC at CHEMTREC®, USA: 001 (800) 424-9300 CHEMTREC®, Mexico (Toll-Free - must be dialed from within country): 01-800-681-9531 CHEMTREC®, Other countries: 001 (703) 527-3887
Emergency Telephone	

## 2. Hazard(s) identification

Physical hazards	Oxidizing liquids	Category 2
Health hazards	Acute toxicity, oral	Category 4
	Skin corrosion/irritation	Category 1B
	Serious eye damage/eye irritation	Category 1
	Specific target organ toxicity, single exposure	Category 3 respiratory tract irritation
OSHA defined hazards	Not classified.	

### Label elements



Signal word	Danger
Hazard statement	May intensify fire; oxidizer. Harmful if swallowed. Causes severe skin burns and eye damage. May cause respiratory irritation.
Precautionary statement	
Prevention	Keep away from heat. Take any precaution to avoid mixing with combustibles. Keep/Store away from clothing//combustible materials. Use only outdoors or in a well-ventilated area. Do not breathe mist or vapor. Wear protective gloves/protective clothing/eye protection/face protection. Do not eat, drink or smoke when using this product. Wash thoroughly after handling.
Response	In case of fire: Use water for extinction. If in eyes: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If on skin (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. If swallowed: Rinse mouth. Do NOT induce vomiting. If inhaled: Remove person to fresh air and keep comfortable for breathing.
Storage	Store locked up. Store in a well-ventilated place. Keep container tightly closed.
Disposal	Dispose of contents/container in accordance with local/regional/national/international regulations.
Hazard(s) not otherwise classified (HNOC)	Not classified.
Environmental hazards	Hazardous to the aquatic environment, acute hazard Category 1 Hazardous to the aquatic environment, long-term hazard Category 1

## Hazard symbol



## Hazard statement

Very toxic to aquatic life with long lasting effects.

## Precautionary statement

## Prevention

Avoid release to the environment.

## Response

Collect spillage.

### 3. Composition/information on ingredients

## Mixtures

Chemical name	CAS number	%
Sodium permanganate	10101-50-5	36 - 40

## Composition comments

All concentrations are in percent by weight unless ingredient is a gas. Gas concentrations are in percent by volume.

### 4. First-aid measures

## Inhalation

If breathing is difficult, remove to fresh air and keep at rest in a position comfortable for breathing. Remove victim to fresh air and keep at rest in a position comfortable for breathing. Move to fresh air. For breathing difficulties, oxygen may be necessary. Call a physician or poison control center immediately. Get medical attention immediately. Call a physician if symptoms develop or persist. Get medical attention if symptoms persist.

## Skin contact

Take off immediately all contaminated clothing. (Caution: Solution may ignite certain textiles). Immediately flush skin with plenty of water. Get medical attention immediately. Wash contaminated clothing before reuse.

## Eye contact

Contact with skin may leave a brown stain of insoluble manganese dioxide. This can be easily removed by washing with a mixture of equal volume of household vinegar and 3% hydrogen peroxide, followed by washing with soap and water.

Immediately flush with plenty of water for up to 15 minutes. Remove any contact lenses and open eyelids wide apart. Continue rinsing. Get medical attention immediately.

## Ingestion

Immediately rinse mouth and drink plenty of water. Never give anything by mouth to a victim who is unconscious or is having convulsions. Do not induce vomiting. If vomiting occurs, keep head low so that stomach content doesn't get into the lungs. Get medical attention immediately.

**Most important symptoms/effects, acute and delayed**

Before using, read Material Safety Data Sheet (MSDS) for this product. Rinse container at least three times to an absence of pink color before disposing.

Contact with this material will cause burns to the skin, eyes and mucous membranes. Corrosive effects. Irritation of eyes and mucous membranes. Symptoms may include stinging, tearing, redness, swelling, and blurred vision. May cause temporary blindness and severe eye damage. Permanent eye damage including blindness could result. Show this safety data sheet to the doctor in attendance.

**Indication of immediate medical attention and special treatment needed**

Provide general supportive measures and treat symptomatically. In case of shortness of breath, give oxygen. Decomposition products are alkaline. Brown stain is insoluble manganese dioxide.

## General information

In the case of accident or if you feel unwell, seek medical advice immediately (show the label where possible). If you feel unwell, seek medical advice (show the label where possible). Ensure that medical personnel are aware of the material(s) involved, and take precautions to protect themselves. For personal protection, see Section 8 of the MSDS. Show this safety data sheet to the doctor in attendance. Wash contaminated clothing before reuse.

### 5. Fire-fighting measures

## Suitable extinguishing media

Flood with water from a distance, water spray or fog.

## Unsuitable extinguishing media

The following extinguishing media are ineffective: Dry chemical. Foam. Carbon dioxide (CO<sub>2</sub>). Halogenated materials.

## Specific hazards arising from the chemical

May intensify fire; oxidizer. May ignite combustibles (wood, paper, oil, clothing, etc.). Contact with incompatible materials or heat (135 °C / 275 °F) could result in violent exothermic chemical reaction. Oxidizing agent, may cause spontaneous ignition of combustible materials. By heating and fire, corrosive vapors/gases may be formed.

**Special protective equipment and precautions for firefighters**

Self-contained breathing apparatus and full protective clothing must be worn in case of fire. Selection of respiratory protection for firefighting: follow the general fire precautions indicated in the workplace.

## Fire-fighting equipment/instructions

Move container from fire area if it can be done without risk. Cool containers exposed to flames with water until well after the fire is out. Prevent runoff from fire control or dilution from entering streams, sewers, or drinking water supply. Dike fire control water for later disposal. Water runoff can cause environmental damage.

## 6. Accidental release measures

### Personal precautions, protective equipment and emergency procedures

Keep unnecessary personnel away. Keep upwind. Do not touch damaged containers or spilled material unless wearing appropriate protective clothing. Avoid inhalation of vapors and contact with skin and eyes. Wear protective clothing as described in Section 8 of this safety data sheet. Local authorities should be advised if significant spillages cannot be contained.

### Methods and materials for containment and cleaning up

Keep combustibles (wood, paper, oil, etc.) away from spilled material. Should not be released into the environment. This product is miscible in water.

Large Spills: Stop leak if possible without any risk. Dike the spilled material, where this is possible. Proceed with either of the following two options depending upon the size of the spill and the availability of the neutralizing agents:

Option # 1: Dilute to approximately 6% with water, and then reduce with sodium thiosulfate, a bisulfite or ferrous salt solution. The bisulfite or ferrous salt may require some dilute sulfuric acid (10% w/w) to promote reduction. Neutralize with sodium carbonate to neutral pH, if acid was used. Decant or filter and deposit sludge in approved landfill. Where permitted, the sludge may be drained into sewer with large quantities of water.

Option # 2: Absorb with inert media like diatomaceous earth or inert floor dry, collect into a drum and dispose of properly. Do not use saw dust or other incompatible media. Disposal of all materials shall be in full and strict compliance with all federal, state, and local regulations pertaining to permanganates.

To clean contaminated floors, flush with abundant quantities of water into sewer, if permitted by federal, state, and local regulations. If not, collect water and treat as described above. Cover with reducing agent (e.g. sodium bisulphite/thiosulphate or a ferrous salt plus 2M H<sub>2</sub>SO<sub>4</sub>). Transfer to container with water and neutralize with soda ash. Otherwise, absorb spill with vermiculite or other inert material, then place in a container for chemical waste. Do not use sawdust or other combustible material. Following product recovery, flush area with water. Prevent product from entering drains.

Small Spills: Cover with reducing agent (e.g. sodium bisulphite/thiosulphate or a ferrous salt plus 2M H<sub>2</sub>SO<sub>4</sub>). Transfer to container with water and neutralize with soda ash. Clean surface thoroughly to remove residual contamination.

Never return spills in original containers for re-use. Never return spills in original containers for re-use.

### Environmental precautions

Do not allow to enter drains, sewers or watercourses. Contact local authorities in case of spillage to drain/aquatic environment.

## 7. Handling and storage

### Precautions for safe handling

Take any precaution to avoid mixing with combustibles. Keep away from clothing and other combustible materials. Do not get this material in your eyes, on your skin, or on your clothing. Do not breathe mist or vapor. If clothing becomes contaminated, remove and wash off immediately. Spontaneous ignition may occur in contact with cloth or paper. When using, do not eat, drink or smoke. Good personal hygiene is necessary. Wash hands and contaminated areas with water and soap before leaving the work site. Avoid release to the environment.

### Conditions for safe storage, including any incompatibilities

Store locked up. Keep container tightly closed and in a well-ventilated place. Store in a cool, dry place. Store away from incompatible materials (See Section 10). Follow applicable local/national/international recommendations on storage of oxidizers. Store in accordance with NFPA 430 requirements for Class II oxidizers.

## 8. Exposure controls/personal protection

**Occupational exposure limits** No exposure limits noted for ingredient(s).

### US. OSHA Table Z-1 Limits for Air Contaminants (29 CFR 1910.1000)

Components	Type	Value
Sodium permanganate (CAS 10101-50-5)	Ceiling	5 mg/m <sup>3</sup>

### US. ACGIH Threshold Limit Values

Components	Type	Value	Form
Sodium permanganate (CAS 10101-50-5)	TWA	0.1 mg/m <sup>3</sup>	Inhalable fraction.
		0.02 mg/m <sup>3</sup>	Respirable fraction.

**US NIOSH Pocket Guide to Chemical Hazards: Recommended exposure limit (REL)**

Components	Type	Value	Form
Sodium permanganate (CAS 10101-50-5)	TWA	1 mg/m3	Fume.

**US NIOSH Pocket Guide to Chemical Hazards: Short Term Exposure Limit (STEL)**

Components	Type	Value	Form
Sodium permanganate (CAS 10101-50-5)	STEL	3 mg/m3	Fume.

<b>Biological limit values</b>	No biological exposure limits noted for the ingredient(s).
<b>Exposure guidelines</b>	Follow standard monitoring procedures.
<b>Appropriate engineering controls</b>	Provide adequate general and local exhaust ventilation. An eye wash and safety shower must be available in the immediate work area.
<b>Individual protection measures, such as personal protective equipment</b>	
<b>Eye/face protection</b>	Wear safety glasses with side shields (or goggles). Wear face shield if there is risk of splashes.
<b>Skin protection</b>	
<b>Hand protection</b>	Wear chemical-resistant, impervious gloves. Use protective gloves made of: Rubber or plastic. Suitable gloves can be recommended by the glove supplier.
<b>Other</b>	Wear appropriate chemical resistant clothing. Rubber or plastic apron.
<b>Respiratory protection</b>	In case of inadequate ventilation or risk of inhalation of vapors, use suitable respiratory equipment. In the United States of America, if respirators are used, a program should be instituted to assure compliance with OSHA 29 CFR 1910.134.
<b>Thermal hazards</b>	Wear appropriate thermal protective clothing, when necessary.
<b>General hygiene considerations</b>	When using, do not eat, drink or smoke. Keep from contact with clothing and other combustible materials. Remove and wash contaminated clothing promptly. Wash hands before breaks and immediately after handling the product. Handle in accordance with good industrial hygiene and safety practice.

**9. Physical and chemical properties**

<b>Appearance</b>	Dark purple liquid.
<b>Physical state</b>	Liquid.
<b>Form</b>	Aqueous solution.
<b>Color</b>	Dark purple.
<b>Odor</b>	Odorless.
<b>Odor threshold</b>	Not available.
<b>pH</b>	5 - 8
<b>Melting point/freezing point</b>	< 24.8 °F (< -4 °C)
<b>Initial boiling point and boiling range</b>	> 213.8 °F (> 101 °C)
<b>Flash point</b>	Does not flash.
<b>Evaporation rate</b>	As water.
<b>Flammability (solid, gas)</b>	Not applicable.
<b>Upper/lower flammability or explosive limits</b>	
<b>Flammability limit - lower (%)</b>	Not applicable.
<b>Flammability limit - upper (%)</b>	Not applicable.
<b>Vapor pressure</b>	760 mm Hg (105 °C)
<b>Vapor density</b>	Not available.
<b>Relative density</b>	1.37 - 1.4 (20 °C) ( Water = 1)
<b>Solubility(ies)</b>	Miscible with water.
<b>Partition coefficient (n-octanol/water)</b>	Not available.
<b>Auto-ignition temperature</b>	Not available.
<b>Decomposition temperature</b>	Not available.
<b>Viscosity</b>	Not available.



## Other information

### Explosive properties

Not explosive. Can explode in contact with sulfuric acid, peroxides and metal powders.

### Oxidizing properties

Strong oxidizing agent.

## 10. Stability and reactivity

### Reactivity

The product is non-reactive under normal conditions of use, storage and transport.

### Chemical stability

Stable at normal conditions.

### Possibility of hazardous reactions

Contact with combustible material may cause fire. Can explode in contact with sulfuric acid, peroxides and metal powders.

### Conditions to avoid

Contact with incompatible materials or heat (135 °C / 275 °F) could result in violent exothermic chemical reaction.

### Incompatible materials

Acids. Peroxides. Reducing agents. Combustible material. Metal powders.

### Hazardous decomposition products

By heating and fire, corrosive vapors/gases may be formed. Contact with hydrochloric acid liberates chlorine gas.

## 11. Toxicological information

### Information on likely routes of exposure

#### Ingestion

Causes digestive tract burns. Harmful if swallowed. Ingestion causes burns of the upper digestive and respiratory tracts.

#### Inhalation

May cause irritation to the respiratory system.

#### Skin contact

Causes severe skin burns.

#### Eye contact

Causes serious eye damage.

### Symptoms related to the physical, chemical and toxicological characteristics

Contact with this material will cause burns to the skin, eyes and mucous membranes. Permanent eye damage including blindness could result.

### Information on toxicological effects

#### Acute toxicity

Causes severe skin burns and eye damage. Causes burns. Harmful if swallowed. Health injuries are not known or expected under normal use. Harmful if swallowed.

### Components

### Species

### Test Results

Potassium permanganate (CAS 7722-64-7)

#### Acute

##### Dermal

LD50

Rat

2000 mg/kg

##### Oral

LD50

Rat

2000 mg/kg

Toxicity data are not available for sodium permanganate. Toxicity is expected to be similar to that of potassium permanganate.

#### Skin corrosion/irritation

Causes severe skin burns.

#### Serious eye damage/eye irritation

Causes serious eye damage.

#### Respiratory sensitization

Not classified.

#### Skin sensitization

Not classified.

#### Germ cell mutagenicity

Not classified.

#### Carcinogenicity

Not classified.

#### Reproductive toxicity

Not classified.

#### Specific target organ toxicity - single exposure

May cause irritation of respiratory tract.

#### Specific target organ toxicity - repeated exposure

Not classified.

#### Aspiration hazard

Not classified.

#### Further information

Chronic effects are not expected when this product is used as intended. Prolonged exposure, usually over many years, to manganese oxide fume/dust can lead to chronic manganese poisoning, chiefly affecting the central nervous system.

## 12. Ecological information

### Ecotoxicity

Very toxic to aquatic life with long lasting effects.

Components		Species	Test Results
Potassium permanganate (CAS 7722-64-7)			
Aquatic			
Fish	LC50	Bluegill (Lepomis macrochirus)	2.7 mg/l, 96 hours, static
			2.3 mg/l, 96 hours, flow through
			2.3 mg/l, 96 hours
			1.8 - 5.6 mg/l
		Carp (Cyprinus carpio)	3.16 - 3.77 mg/l, 96 hours
			2.97 - 3.11 mg/l, 96 hours
		Goldfish (Carassius auratus)	3.3 - 3.93 mg/l, 96 hours, static
		Milkfish, salmon-herring (Chanos chanos)	> 1.4 mg/l, 96 hours
		Rainbow trout (Oncorhynchus mykiss)	1.8 mg/l, 96 hours
			1.08 - 1.38 mg/l, 96 hours
			0.77 - 1.27 mg/l, 96 hours
		Rainbow trout,donaldson trout (Oncorhynchus mykiss)	0.275 - 0.339 mg/l, 96 hours

Toxicity data are not available for sodium permanganate. Toxicity is expected to be similar to that of potassium permanganate.

<b>Persistence and degradability</b>	Expected to be readily converted by oxidizable materials to insoluble manganese oxide.
<b>Bioaccumulative potential</b>	Potential to bioaccumulate is low.
<b>Mobility in soil</b>	The product is miscible with water. May spread in water systems.
<b>Mobility in general</b>	The product is miscible with water. May spread in water systems.
<b>Other adverse effects</b>	None known.

### 13. Disposal considerations

<b>Disposal instructions</b>	Dispose of contents/container in accordance with local/regional/national/international regulations.
<b>Local disposal regulations</b>	Rinse container at least three times to an absence of pink color before disposing.
<b>Hazardous waste code</b>	D001: Ignitable waste The Waste code should be assigned in discussion between the user, the producer and the waste disposal company.
<b>Waste from residues / unused products</b>	Do not allow this material to drain into sewers/water supplies. Dispose of in accordance with local regulations.
<b>Contaminated packaging</b>	Since emptied containers may retain product residue, follow label warnings even after container is emptied. Rinse container at least three times to an absence of pink color before disposing. Empty containers should be taken to an approved waste handling site for recycling or disposal.

### 14. Transport information

#### DOT

<b>UN number</b>	UN3214
<b>UN proper shipping name</b>	Permanganates, inorganic, aqueous solution, n.o.s. (Sodium permanganate)
<b>Transport hazard class(es)</b>	5.1
<b>Subsidiary class(es)</b>	-
<b>Packing group</b>	II
<b>Environmental hazards</b>	
<b>Marine pollutant</b>	Yes
<b>Special precautions for user</b>	Read safety instructions, SDS and emergency procedures before handling.
<b>Special provisions</b>	26, 353, IB2, T4, TP1
<b>Packaging exceptions</b>	152
<b>Packaging non bulk</b>	202
<b>Packaging bulk</b>	242

#### IATA

<b>UN number</b>	UN3214
<b>UN proper shipping name</b>	Permanganates, inorganic, aqueous solution, n.o.s. (Sodium permanganate)
<b>Transport hazard class(es)</b>	5.1
<b>Subsidiary class(es)</b>	-
<b>Packaging group</b>	II
<b>Environmental hazards</b>	Yes
<b>Labels required</b>	5.1
<b>ERG Code</b>	5L

**Special precautions for user** Read safety instructions, SDS and emergency procedures before handling.

#### IMDG

**UN number** UN3214  
**UN proper shipping name** PERMANGANATES, INORGANIC, AQUEOUS SOLUTION, N.O.S. (Sodium permanganate)  
**Transport hazard class(es)** 5.1  
**Subsidiary class(es)** -  
**Packaging group** II  
**Environmental hazards**  
**Marine pollutant** Yes  
**Labels required** 5.1  
**EmS** F-H, S-Q  
**Special precautions for user** Read safety instructions, SDS and emergency procedures before handling.

**Transport in bulk according to Annex II of MARPOL 73/78 and the IBC Code** This substance/mixture is not intended to be transported in bulk.

## 15. Regulatory information

**US federal regulations** This product is a "Hazardous Chemical" as defined by the OSHA Hazard Communication Standard, 29 CFR 1910.1200.  
All components are on the U.S. EPA TSCA Inventory List.  
  
CERCLA/SARA Hazardous Substances - Not applicable.  
  
Drug Enforcement Administration (DEA) (21 CFR 1310.02 (b) 8: List II chemical.

#### TSCA Section 12(b) Export Notification (40 CFR 707, Subpt. D)

Not regulated.

#### US. OSHA Specifically Regulated Substances (29 CFR 1910.1001-1050)

Not listed.

#### CERCLA Hazardous Substance List (40 CFR 302.4)

Sodium permanganate (CAS 10101-50-5) LISTED

#### Superfund Amendments and Reauthorization Act of 1986 (SARA)

**Hazard categories** Immediate Hazard - Yes  
Delayed Hazard - No  
Fire Hazard - Yes  
Pressure Hazard - No  
Reactivity Hazard - No

**SARA 302 Extremely hazardous substance** No

**SARA 311/312 Hazardous chemical** Yes

#### SARA 313 (TRI reporting)

Chemical name	CAS number	% by wt.
Sodium permanganate	10101-50-5	36 - 40
Potassium permanganate	7722-64-7	2

#### Other federal regulations

##### Clean Air Act (CAA) Section 112 Hazardous Air Pollutants (HAPs) List

Sodium permanganate (CAS 10101-50-5)

##### Clean Air Act (CAA) Section 112(r) Accidental Release Prevention (40 CFR 68.130)

Not regulated.

**Safe Drinking Water Act (SDWA)** Not regulated.

##### Drug Enforcement Administration (DEA). List 2, Essential Chemicals (21 CFR 1310.02(b) and 1310.04(f)(2) and Chemical Code Number

Sodium permanganate (CAS 10101-50-5) 6588

##### Drug Enforcement Administration (DEA). List 1 & 2 Exempt Chemical Mixtures (21 CFR 1310.12(c))

Sodium permanganate (CAS 10101-50-5) 15 % wt

##### DEA Exempt Chemical Mixtures Code Number

Sodium permanganate (CAS 10101-50-5) 6588

**Food and Drug Administration (FDA)** Not regulated.

**US state regulations**

This product does not contain a chemical known to the State of California to cause cancer, birth defects or other reproductive harm.

**US. Massachusetts RTK - Substance List**

Not regulated.

**US. New Jersey Worker and Community Right-to-Know Act**

Sodium permanganate (CAS 10101-50-5) 500 lbs

**US. Pennsylvania RTK - Hazardous Substances**

Not regulated.

**US. Rhode Island RTK**

Sodium permanganate (CAS 10101-50-5)

**US. California Proposition 65****US - California Proposition 65 - Carcinogens & Reproductive Toxicity (CRT): Listed substance**

Not listed.

**International Inventories**

Country(s) or region	Inventory name	On inventory (yes/no)*
Australia	Australian Inventory of Chemical Substances (AICS)	Yes
Canada	Domestic Substances List (DSL)	No
Canada	Non-Domestic Substances List (NDSL)	Yes
China	Inventory of Existing Chemical Substances in China (IECSC)	Yes
Europe	European Inventory of Existing Commercial Chemical Substances (EINECS)	Yes
Europe	European List of Notified Chemical Substances (ELINCS)	No
Japan	Inventory of Existing and New Chemical Substances (ENCS)	Yes
Korea	Existing Chemicals List (ECL)	Yes
New Zealand	New Zealand Inventory	Yes
Philippines	Philippine Inventory of Chemicals and Chemical Substances (PICCS)	Yes
United States & Puerto Rico	Toxic Substances Control Act (TSCA) Inventory	Yes

\*A "Yes" indicates this product complies with the inventory requirements administered by the governing country(s).

A "No" indicates that one or more components of the product are not listed or exempt from listing on the inventory administered by the governing country(s).


**16. Other information, including date of preparation or last revision**

**Issue date** 27-November-2013

**Revision date** -

**Version #** 01

**NFPA Ratings**

**References**

HSDB® - Hazardous Substances Data Bank  
Registry of Toxic Effects of Chemical Substances (RTECS)  
EPA: AQUIRE database  
NLM: Hazardous Substances Data Base  
US. IARC Monographs on Occupational Exposures to Chemical Agents  
IARC Monographs. Overall Evaluation of Carcinogenicity  
National Toxicology Program (NTP) Report on Carcinogens  
ACGIH Documentation of the Threshold Limit Values and Biological Exposure Indices

## Disclaimer

This safety data sheet was prepared in accordance with the Safety Data Sheet for Chemical Products (JIS Z 7250:2005). The information contained herein is accurate to the best of our knowledge. However, data, safety standards and government regulations are subject to change and, therefore, holders and users should satisfy themselves that they are aware of all current data and regulations relevant to their particular use of product. CARUS CORPORATION DISCLAIMS ALL LIABILITY FOR RELIANCE ON THE COMPLETENESS OR ACCURACY OR THE INFORMATION INCLUDED HEREIN. CARUS CORPORATION MAKES NO WARRANTY, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR PARTICULAR USE OR PURPOSE OF THE PRODUCT DESCRIBED HEREIN. All conditions relating to storage, handling, and use of the product are beyond the control of Carus Corporation, and shall be the sole responsibility of the holder or user of the product.

(Carus and design) is a registered service mark of Carus Corporation. RemOx® is a registered trademark of Carus Corporation. Copyright 1998.

# **Hazard Communication**

CONSTITUENT OF CONCERN	EXPOSURE LIMITS	IDLH (ppm)	SYMPTOMS AND EFFECTS OF EXPOSURE
Tetrachloroethylene (PCE)	PEL = 100 ppm TWA C = 200 ppm (for 5 min. in any 3-hr period) with a max peak of 300 ppm REL = * IP = 9.32 eV <b>Ca</b>	150	Acute health effects: Irritation of the skin and eyes, mucous membranes and upper respiratory tract, drowsiness, central nervous system effects resulting in respiratory failure.
Trichloroethylene (TCE)	PEL = 100 ppm TWA C = 200 ppm 5-min max peak in any 2-hr period = 300 ppm REL = 25 ppm IP = 9.45 eV <b>Ca</b>	1,000	Long term or repeated exposure may cause dermatitis, effects on the central nervous system resulting in loss of memory and may cause liver and kidney injury.
1,1-dichloroethene (1,1-DCE)	PEL = None REL = * IP = 10.00 eV <b>Ca</b>	NL	Acute health effects: Headache, visual disturbance, eye and skin irritation, central nervous system depression, dizziness. Long term effects: Dermatitis, cardiac arrhythmia, liver injury.
trans-1,2-dichloroethene (trans-1,2-DCE)	PEL = 200 ppm TWA REL = 200 ppm TWA IP = 9.65 eV	1,000	Acute health effects: Irritation of the skin, eyes, mucous membranes and upper respiratory tract, dizziness, nausea, vomiting, central nervous system intoxication, drowsiness, weakness, tremor, and cramps. Long term or repeated exposure may affect the liver and kidneys.
cis-1,2-dichloroethene (cis-1,2-DCE)			
Vinyl Chloride	PEL= None REL = * IP = 10.00 eV <b>Ca</b>	NL	Abdominal pain, gastrointestinal bleeding, enlarged liver, paralysis of extremities

IDLH = Immediately dangerous to life and health

ppm = parts per million

PEL = Permissible exposure limit (OSHA) is a time-weighted average (TWA) concentration over an 8-hour workday.

REL = Recommended exposure limit (NIOSH) is a TWA concentration over a 10-hour workday

C = Ceiling concentration, not to be exceeded

**Ca** = Potential occupational carcinogen

IP= Ionization Potential

NL = No limit found in reference materials.

\* = Minimize exposure to the lowest feasible limit at all times

# **Job Hazard Analyses**



JOB HAZARD ANALYSIS		
<b>JHA Rev.#</b> 000	<b>Job or Operation Title:</b> General Site Activities	
<b>Job Location</b> Ameren-Huster Road Substation	<b>Job Address</b> 3800 Huster Road; St. Charles, Missouri	<b>Employees /Subs</b>
<b>Date JHA Performed</b> 01/11/2022	<b>Team Performing JHA</b> Karen O'Shaughnessy	<b>Verified By</b> Derek Ingram
<b>Special or Primary Hazards</b>	Vehicular traffic, lifting heavy items, general electrical hazards associated with substation	
<b>Personal Protective Equipment:</b>	<u>Level D – minimum unless specified otherwise</u> <ul style="list-style-type: none"> <li>• Steel Toed Boots (conforms to ANSI Standard Z41)</li> <li>• Hearing Protection (protection up to 95 dBA, as necessary)</li> <li>• Hard hat (as needed)</li> <li>• Eye protection with side shields (ANSI Z-87.1 approved)</li> <li>• Work gloves (leather/cotton - general work) – when handling non-hazardous/ non-contaminated material</li> <li>• Disposable chemical resistant gloves – when handling treatment reagents, contaminated material, and/or hazardous material</li> </ul>	
<b>BASIC JOB STEPS</b>	<b>EXISTING AND/OR POTENTIAL HAZARDS</b>	<b>CORRECTIVE MEASURES/CONTROLS</b>
All on-site activities	Slips, trips, and falls	<ul style="list-style-type: none"> <li>• Mark, identify, or barricade obstructions, tripping hazards, or precipices.</li> <li>• Continuously evaluate areas for potential causes of slips/trips/falls.</li> <li>• Practice good housekeeping: create walkways, establish proper materials/equipment storage, keep work areas free of debris, materials, tools, etc.</li> <li>• Store/maintain equipment and tools in designated areas.</li> <li>• Wear properly fitted footwear with proper tread for site conditions.</li> <li>• Walk carefully on uneven terrain. Look for changes in grade when walking.</li> <li>• Always watch where you are walking; do not read or text while walking.</li> <li>• Avoid spilling liquids that can create a slip hazard. <ul style="list-style-type: none"> <li>○ If liquids are spilled, clean them up immediately.</li> <li>○ Use signage to identify wet surfaces/areas.</li> </ul> </li> </ul>

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

All on-site activities (continued)	High/Low Ambient Temperature	<ul style="list-style-type: none"> <li>• Use buddy system to monitor coworkers for symptoms of heat/cold stress.</li> <li>• Wear appropriate clothing to prevent heat exhaustion (light, breathable clothing) or hypothermia (layers of insulating clothing, gloves, and hat, waterproof if necessary).</li> <li>• As appropriate, consider the following actions to mitigate environmental factors that can contribute to cold/heat stress: <ul style="list-style-type: none"> <li>○ Create a work schedule that limits exposure to heat or cold.</li> <li>○ Provide an air conditioned or heated space for cooling or warming (as appropriate), such as an office trailer or vehicle.</li> <li>○ In high temperatures, provide shade.</li> </ul> </li> <li>• Set a frequent break schedule in areas where workers can cool down or warm up, as appropriate.</li> </ul>
	Traffic	<ul style="list-style-type: none"> <li>• Maintain situational awareness.</li> <li>• Wear appropriate high visibility clothing.</li> <li>• Stay in proper line of sight of vehicle operators.</li> <li>• Maintain barricades and signage to direct vehicles away from work areas.</li> </ul>
	Insects, snakes, rodents, poisonous plants, and other biological hazards.	<ul style="list-style-type: none"> <li>• Biological hazards will be addressed in the field, as necessary, through proper identification of the potential hazards.</li> <li>• Identify and avoid working near, walking through, or touching poisonous plants and insect nests.</li> <li>• Site personnel should notify the project manager and other on-site personnel of any allergies to insect stings or severe allergies to poisonous plants before site activities are initiated.</li> <li>• Employees with severe allergies who require medication for severe allergic reactions (such as Epi-pens) are responsible for providing their own medications and should keep medications on hand if the potential for exposure is present.</li> </ul>

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

All on-site activities (continued)	<p>Inclement weather such as lightning / thunderstorms, heavy rain, high winds / tornado, hail, and snow can create hazardous conditions.</p> <ul style="list-style-type: none"> <li>Lightning can result in injuries (electrocution / burns from lightning strike or injury from falling debris) or fire.</li> <li>Rain or snow can result in slippery conditions, increasing the risk of falls.</li> <li>High winds can result in flying debris and dust causing injury to personnel and site damage, possibility of personnel being swept off their feet, equipment being blown over.</li> </ul>	<ul style="list-style-type: none"> <li>Wear appropriate clothing and footwear for weather conditions.</li> <li>Personnel should be regularly updated regarding any changes to potential weather conditions.</li> <li>When lightning is seen, count the seconds until thunder is heard and then divide the seconds by <b>FIVE</b> to estimate the distance in miles. Follow the 30-30 rule: <ul style="list-style-type: none"> <li>If you count <b>30 seconds</b> or less between seeing lightning and hearing thunder, the lightning is within 6 miles of your location - <u>you are in potential danger and should stop work and seek shelter.</u></li> <li>Wait <b>30 minutes</b> from the last flash of lightning or sound of thunder to establish an “all clear” to return to work.</li> </ul> </li> <li>In high winds: <ul style="list-style-type: none"> <li>Lower all equipment such as lifts or drill rigs and remove all personnel/ equipment from elevated areas.</li> <li>Tie down and secure all loose equipment</li> <li>Protect your eyes from potential injury from flying debris</li> </ul> </li> <li>If a tornado watch or warning has been issued, take appropriate actions. <ul style="list-style-type: none"> <li><u>Evacuate the area immediately if instructed by a regulatory authority or the site safety supervisor.</u></li> <li>Secure equipment <b>ONLY</b> if there is time that it can be done safely</li> <li>Do not attempt to return to the area until an “all clear” signal has been given by a regulatory authority or the site safety supervisor.</li> </ul> </li> </ul>
	<p>Electrical hazards associated with site being an operational electrical substation. Hazards range from a small shock to significant electrocutions.</p>	<ul style="list-style-type: none"> <li>Stay clear of all electrical lines, panels, and other substation equipment.</li> <li>Maintain situational awareness and always be conscious of surroundings.</li> </ul>

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

Lifting and moving materials and/or equipment during all activities	Physical injuries from lifting and moving heavy/ bulky objects	<ul style="list-style-type: none"> <li>• Evaluate the object/equipment to be moved before attempting to move it. <ul style="list-style-type: none"> <li>○ Know how heavy the object is and the effort required to move it.</li> <li>○ Know if the load can be moved with one person. If not, arrange for assistance.</li> </ul> </li> <li>• Determine if mechanical assistance can be used. Use material handling equipment for heavy loads such as hand-truck, drum dolly, forklift, or pallet jack.</li> <li>• If moving a heavy pallet with a non-motorized pallet jack: <ul style="list-style-type: none"> <li>○ Consider using a second person to help start the load moving.</li> <li>○ Do not jerk or yank the load. Use slow even motions.</li> </ul> </li> <li>• Avoid tasks that will involve awkward motions such as twisting or lifting a load that is far away from your body. Reconfigure the task to bring loads closer to your body and pivot with feet.</li> <li>• Always use proper lifting techniques.</li> <li>• Avoid material handling on slippery surfaces. Attempting to “catch yourself” after slipping is a frequent cause of strains.</li> <li>• If a load slips out of your hands and is falling, do not try to catch it. Rather, step out of the way.</li> </ul>
Equipment receiving and staging	Struck/caught between heavy equipment	<ul style="list-style-type: none"> <li>• Wear appropriate high visibility clothing.</li> <li>• Ensure clearances for personnel, overhead lines, physical obstacles.</li> <li>• Only experienced and trained operators shall operate motorized equipment.</li> <li>• Inspect fork-lift, hand trucks, pallet jacks prior to use.</li> <li>• Use all equipment according to operator’s manual.</li> <li>• Ensure equipment backup warning alarms are functional.</li> <li>• Honk horn when navigating blind corners/intersections.</li> <li>• Personnel will avoid blind side and swing areas.</li> <li>• Make eye contact with operator before approaching equipment.</li> </ul>

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

JOB HAZARD ANALYSIS		
<b>JHA Rev.#</b> 000	<b>Job or Operation Title:</b> Groundwater Sampling	
<b>Job Location</b> Ameren-Huster Road Substation	<b>Job Address</b> 3800 Huster Road; St. Charles, Missouri	<b>Employees /Subs</b>
<b>Date JHA Performed</b> 01/13/2022	<b>Team Performing JHA</b> Karen O'Shaughnessy	<b>Verified By</b> Derek Ingram
<b>Special or Primary Hazards</b>	Exposure to contaminated groundwater, vehicular traffic, lifting heavy items	
<b>Personal Protective Equipment</b>	<b><u>Level D – minimum unless specified otherwise</u></b> <ul style="list-style-type: none"> <li>• Steel Toed Boots (conforms to ANSI Standard Z41)</li> <li>• Hard hat (as needed)</li> <li>• Safety glasses (ANSI Z-87.1 approved)</li> <li>• Work gloves (leather/cotton - general work) – when handling non-hazardous/ non-contaminated material</li> <li>• Chemical-resistant disposable gloves (nitrile)</li> <li>• High visibility safety vests</li> <li>• Tyvek coveralls – as needed when there is a potential for contact with contaminated media</li> </ul>	
<b>BASIC JOB STEPS</b>	<b>EXISTING AND/OR POTENTIAL HAZARDS</b>	<b>CORRECTIVE MEASURES/CONTROLS</b>
All on-site activities	Slips, trips, and falls	See JHA for "General Site Activities"
	Insects, snakes, rodents, poisonous plants, and other biological hazards.	
	Inclement weather (lightning/ thunderstorms, heavy rain, high winds / tornado, hail, snow) can create hazardous conditions.	
	High/Low Ambient Temperature	
	Traffic	

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

All on site activities (continued)	Electrical hazards associated with site being an operational electrical substation. Hazards range from a small shock to significant electrocutions.	<ul style="list-style-type: none"> <li>• See JHA for “General Site Activities”</li> </ul>
Equipment set up / moving equipment around the site.	Lifting heavy objects (e.g. access covers, well lids, pumps, sampling equipment, coolers, buckets filled with purge water from wells etc.) resulting in muscle strains and/or back injuries.	<ul style="list-style-type: none"> <li>• Use hand cart or wagon if available.</li> <li>• Use proper lifting techniques when lifting or moving heavy equipment, coolers, buckets, etc.</li> <li>• Avoid tasks that will involve awkward motions such as twisting or lifting a load that is far away from your body. Reconfigure the task to bring loads closer to your body and pivot with feet.</li> <li>• Get help from a co-worker to lift and carry heavy equipment, coolers, buckets of water, etc.</li> <li>• Avoid spilling water that can create mud/slippery conditions.</li> </ul>
Groundwater sample collection	Chemical exposure to contaminants in groundwater, chemicals / byproducts in groundwater from current or past remedial activities at the site, and/or sample preservatives.	<ul style="list-style-type: none"> <li>• Always wear proper PPE including eye protection and chemical-resistant gloves.</li> <li>• Review and understand the SDS for all chemicals of concern in media being collected.</li> <li>• Set up sampling equipment / position body upwind of monitoring well to minimize downwind exposures.</li> <li>• Keep face away from well when opening to avoid exposure to vapors that have accumulated in the well.</li> <li>• Wear proper PPE and handle sample containers carefully to keep groundwater and preservation chemicals off of hands and clothing.</li> </ul>

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

JOB HAZARD ANALYSIS		
<b>JHA Rev.#</b> 000	<b>Job or Operation Title:</b> Soil Monitoring and Sampling	
<b>Job Location</b> Ameren-Huster Road Substation	<b>Job Address</b> 3800 Huster Road; St. Charles, Missouri	<b>Employees /Subs</b>
<b>Date JHA Performed</b> 01/13/2022	<b>Team Performing JHA</b> Karen O'Shaughnessy	<b>Verified By</b> Derek Ingram
<b>Special or Primary Hazards</b>	Exposure to contaminated soil and vapors, heavy equipment, vehicular traffic	
<b>Personal Protective Equipment</b>	<b><u>Level D – minimum unless specified otherwise</u></b> <ul style="list-style-type: none"> <li>• Steel Toed Boots (conforms to ANSI Standard Z41)</li> <li>• Hard hat (as needed)</li> <li>• Safety glasses (ANSI Z-87.1 approved)</li> <li>• Work gloves (leather/cotton - general work) – when handling non-hazardous/ non-contaminated material</li> <li>• Chemical-resistant disposable gloves (nitrile)</li> <li>• High visibility safety vests</li> <li>• Tyvek coveralls – as needed when there is a potential for contact with contaminated soil</li> </ul>	
<b>BASIC JOB STEPS</b>	<b>EXISTING AND/OR POTENTIAL HAZARDS</b>	<b>CORRECTIVE MEASURES/CONTROLS</b>
All on-site activities	Slips, trips, and falls	See JHA for "General Site Activities"
	Insects, snakes, rodents, poisonous plants, and other biological hazards.	
	Inclement weather (lightning/ thunderstorms, heavy rain, high winds / tornado, hail, snow) can create hazardous conditions.	
	High/Low Ambient Temperature	
	Traffic	

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

All on site activities (continued)	Electrical hazards associated with site being an operational electrical substation. Hazards range from a small shock to significant electrocutions.	See JHA for "General Site Activities"
Equipment set up / moving equipment around the site	Lifting heavy equipment resulting in muscle strains and/or back injuries.	<ul style="list-style-type: none"> <li>• Use mechanical assistance if needed available.</li> <li>• Use proper lifting techniques when lifting or moving heavy equipment.</li> <li>• Avoid tasks that will involve awkward motions such as twisting or lifting a load that is far away from your body. Reconfigure the task to bring loads closer to your body and pivot with feet.</li> <li>• Get help from a co-worker to lift and carry heavy equipment.</li> <li>• Avoid spilling water that can create mud/slippery conditions.</li> </ul>
<p>Soil and air monitoring during site construction activities involving groundbreaking (*).</p> <p>*Construction activities related to substation operations and not related to site remedial actions.</p>	Chemical exposure to contaminants in soils, chemicals / byproducts in subsurface from current or past remedial activities at the site, and/or sample preservatives.	<ul style="list-style-type: none"> <li>• Wear proper PPE including eye protection and chemical-resistant gloves. Wear Tyvek coveralls if there is a potential for contact with contaminated soil.</li> <li>• Review and understand the SDS for all site contaminants and chemicals of concern in media being monitored and sampled.</li> <li>• Monitor air in breathing zone with a photoionization detector (PID) equipped with an 10.6 electron-volt (eV) bulb to determine the adequacy of the current level of protection relative to existing site conditions. <ul style="list-style-type: none"> <li>○ Upgrade PPE, if necessary, as determined by the site safety officer.</li> <li>○ If hazardous conditions are deemed present, shut down operations and re-evaluate the situation.</li> </ul> </li> <li>• Visually monitor soils for evidence of potentially high contaminant concentrations (i.e. NAPL).</li> <li>• Avoid direct contact with soils.</li> <li>• Use engineering controls wherever possible to minimize exposure risk and stand upwind of exposed soils to minimize downwind exposures to soil vapors.</li> <li>• Cordon off work area using traffic cones, caution tape, barricading, and signage/placarding to prevent unauthorized personnel from entering a dangerous work area.</li> </ul>

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.



<p>Soil and air monitoring during site construction activities involving groundbreaking (*).</p> <p>*Construction activities related to substation operations and not related to site remedial actions.</p>	<p>Physical injuries caused by soil collapse during trenching and/or excavation</p>	<ul style="list-style-type: none"> <li>• <u>Loureiro personnel will not enter confined spaces at any time.</u></li> <li>• Do not enter a trench or excavation that is greater than 4 feet below ground surface.</li> <li>• Do not enter a trench or excavation that has standing water.</li> <li>• Do not enter any trench where the spoils are less than 2 feet from the edge of the excavation.</li> </ul>
	<p>Working near heavy equipment</p>	<ul style="list-style-type: none"> <li>• Establish exclusion zone around the work area using traffic cones, caution tape, barricading, and/or signage and placarding to prevent unauthorized personnel from entering a dangerous work area.</li> <li>• Only trained and authorized personnel may operate heavy equipment and/or assist in equipment moving.</li> <li>• Hard hats and high visibility vests must be worn at all times when working near heavy equipment.</li> <li>• Designate a flag person to facilitate movement of equipment, if necessary.</li> <li>• Make eye contact with equipment operators before approaching operating equipment.</li> <li>• Avoid blind side and swing areas.</li> <li>• Understand and review hand signals.</li> </ul>

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

## JOB HAZARD ANALYSIS

<b>JHA Rev.#</b>	0	
<b>Location:</b>	<b>Job or Operation Title:</b> Groundwater Extraction System (GETS) Operation and Maintenance	
Ameren – Huster Road Substation	<b>Job Address</b>	<b>Employees /Subs</b>
	3800 Huter Road; St. Charles, Missouri	
<b>Date JHA Performed/Updated</b>	<b>Team Performing JHA</b>	<b>Verified By</b>
01/13/2022	Karen O’Shaughnessy	Derek Ingram
<b>Special or Primary Hazards</b>	Exposure to contaminated groundwater, vehicular traffic, heavy lifting	
<b>Personal Protective Equipment</b>	<p><b><u>Level D – minimum unless specified otherwise</u></b>  Steel Toe Boots (conforms to ANSI Standard Z41)  Hearing Protection (protection up to 95 dBA, as necessary)  Hard hat (as needed)  Eye protection with side shields (ANSI Z-87.1 approved)  Work gloves (leather/cotton - general work) – when handling non-hazardous material  Disposable chemical resistant gloves (nitrile) – when handling hazardous material</p> <p><b><u>Modified Level D – Includes above Level D plus the following:</u></b>  Tyvek polyethylene-coated coverall or sleeved-apron – as needed when there is a potential for contact with hazardous material  Chemical resistant face shield – when opening drums / handling hazardous material</p>	
<b>BASIC JOB STEPS</b>	<b>EXISTING AND/OR POTENTIAL HAZARDS</b>	<b>CORRECTIVE MEASURES/CONTROLS</b>
All on-site activities	Slips, trips, and falls	See JHA for “General Site Activities”
	Insects, snakes, rodents, poisonous plants, and other biological hazards.	
	Inclement weather (lightning/ thunderstorms, heavy rain, high winds / tornado, hail, snow) can create hazardous conditions.	
	High/Low Ambient Temperature	
	Traffic	

The following are the basic JHA steps:

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property, or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

Daily Operations - Lifting and Moving Materials and/or Equipment	Physical injuries from lifting and moving heavy/ bulky objects	See JHA for “General Site Activities”
LOTO - Lock-Out/Tag-Out	Injury from electrical and pneumatic sources.	Loureiro employee will avoid doing activities that require implementation of LOTO unless absolutely necessary. Employees must be trained and authorized to conduct LOTO, if required.
Daily Operations - General Hand Tool Use	Minor to moderate punctures or laceration caused by damaged or broken hand tools.	See JHA for “General Site Activities”
	Serious injuries caused by using the inappropriate tool for a specific task.	
	Ergonomic related strains caused by swinging hand tools such as hammers / sledgehammers/ mallets.	
	Fatigue and strain caused by using the tool in awkward body positions (reaching, stretching, pushing, pulling).	
	Flying debris (or tool parts) causing foreign body penetration / injury to the body, face, and eyes of the operator and/or other nearby personnel.	
	Serious bodily injury caused by altering or devising a “homemade” tool.	
Daily Operations – Electrical Power Tool Use	Electric shock	See JHA for “General Site Activities”
System Operation, Monitoring, and Equipment Maintenance	Noise levels (> <b>85 dbA</b> ) that can result in hearing damage or inability to communicate safety-critical information	Wear hearing protection (plugs or muffs) with NRR (Noise Reduction Rating) of at least 32dB if noise level is above 85 dBA (decibels-time-weighted average).

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property, or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

System Operation, Monitoring, and Equipment Maintenance (continued)	Injury caused by mechanical equipment/ moving parts	<ul style="list-style-type: none"> <li>• Never remove protective covers/guards while equipment is operational.</li> <li>• De-energize all equipment before removing cover/guards. Replace all covers/guards before restarting equipment.</li> <li>• Body parts, loose clothing, hair, jewelry, and foreign objects should be kept from contacting moving parts.</li> <li>• Operators will use appropriate Level D PPE while operating or maintaining the system.</li> </ul>
	Release of / exposure to treatment chemicals, untreated water, and wastewater	<ul style="list-style-type: none"> <li>• Review SDS for all chemicals on site.</li> <li>• Wear proper Level D PPE with additional splash protection (Tyvek coveralls/ splash apron, safety goggles, and face shield) when handling hazardous materials.</li> <li>• Do not break lines when system is under pressure.</li> <li>• Ensure system back-pressure has dissipated before breaking any connections.</li> <li>• Slowly relieve system pressure before breaking piping connections (if necessary).</li> <li>• Immediately clean up any drips or spills in accordance with SDS.</li> <li>• Disconnect equipment from power source when performing maintenance operations.</li> <li>• Visually confirm that all piping connections are secure before powering up equipment and all personnel are away from potential release points.</li> <li>• Do not break lines when system is under pressure.</li> <li>• Confirm that all valves that should be open are open before powering up equipment to avoid rapid, excessive build-up of system backpressure.</li> <li>• Confirm that all valves that should be closed are closed before powering up equipment to avoid accidental release of chemical/ wastewater.</li> </ul>

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property, or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

System Operation, Monitoring, and Equipment Maintenance (continued)	Release of / exposure to treatment chemicals, untreated water, and wastewater (continued)	<p><b><u>Treatment system will have alarms for any parameter value that is outside of the typical operating range.</u></b> The alarms will link to the system controls to prevent a release of treatment chemicals, untreated water, or wastewater (or other problems) by shutting down the relevant system components or the entire system as appropriate. Typical parameters for which alarms are installed include:</p> <ul style="list-style-type: none"> <li>• High tank levels</li> <li>• High differential pressure across filters</li> <li>• Well vault or building sump water/chemical accumulation</li> <li>• Low water flow in the treatment system</li> <li>• Fire/Smoke Detection</li> <li>• System Shutdown</li> </ul>
Filter Change Out	Exposure to contaminants in groundwater, chemicals / byproducts in groundwater from current or past remedial activities at the site, or wastewater/sludge	<ul style="list-style-type: none"> <li>• Wear proper Level D PPE with additional splash protection (Tyvek coveralls/ splash apron, safety goggles, and face shield) when changing filters.</li> <li>• Do not break lines when system is under pressure.</li> <li>• Ensure system back-pressure has dissipated before breaking any connections.</li> <li>• Slowly relieve system pressure before opening any closed system components/connections (if necessary).</li> <li>• Keep face away when opening filter housing to avoid spray from residual pressure and/or exposure to vapors that have accumulated.</li> </ul>
	Heavy lifting resulting in muscle strains and/or back injuries.	<ul style="list-style-type: none"> <li>• Use proper lifting techniques when lifting spent filters.</li> <li>• Avoid awkward motions such as twisting or lifting a load that is far away from your body. Reconfigure the task to bring loads closer to your body and pivot with feet.</li> <li>• Allow water to drain from filter before pulling filter out of housing to reduce its weight.</li> <li>• Get help from a co-worker to lift spent filters.</li> <li>• Avoid spilling water that can create slippery conditions.</li> <li>• <i>See JHA for "General Site Activities" for additional corrective measures / controls.</i></li> </ul>

**The following are the basic JHA steps:**

1. At earliest possible point (proposal/bidding) list job tasks & steps in the appropriate order.
2. Identify hazards associated with each task/step (possible harm to people, property, or environment).
3. Define practical actions to eliminate/minimize hazards/risks to acceptable levels.
4. Ensure all applicable Standard Operating Procedures (SOP) and Cardinal Rules are applied.
5. Communicate JHA to all employees and Subs – Post on Job-site.
6. Update JHA information when conditions, tasks, equipment, etc., change.

**Loureiro Engineering Associates, Inc.  
Standard Operating Procedure  
For  
Groundwater Sample Collection and Field Analysis**

**SOP ID: 10004  
Date Initiated: 02/20/90  
Revision No. 007: 06/11/20**

**Revised By: /s/ Jo Ann Robertson      09/25/20  
Jo Ann Robertson  
Technical Associate      Date**

**Revised By: /s/ Thomas J. Salimeno      09/25/20  
Thomas J. Salimeno  
Technical Practice Leader      Date**

**Approved By: /s/ Karen Harris      01/21/21  
Karen Harris  
Quality Assurance Manager      Date**

## REVISION RECORD

---

Rev #	Date	Additions/Deletions/Modifications
Initial Issue	02/20/90	
001-004	NR	No record.
005	01/15/99	No record.
006	12/31/01	Updated to conform the new SOP format. Minor revisions throughout.
007	09/25/20	Text and formatting updates.

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**For**  
**Groundwater Sample Collection and Field Analysis**

1. Purpose and Scope

This document describes procedures to be followed for the collection and field measurement of groundwater samples from monitoring wells, Geoprobe® Screen Point Groundwater Sampler or temporary wells. This Standard Operating Procedure (SOP) describes the procedures for the groundwater sample collection using the calculated volume purge method, or non-low flow purge method and the collection of groundwater samples from temporary wells. This SOP does not describe the low-flow sampling method, refer to SOP 10039 – *Low-flow (low-stress) Liquid Sample Collection and Field Analysis* for guidance.

These procedures are not intended to address all potential situations or considerations which may arise in the process of performing this task. Project-specific sampling precautions, conditions, methods, plans, and strategies will be addressed in the project-specific work plan (Work Plan), Field Sampling Plan (FSP) and/or health and safety documentation. Any variations or deviations to procedures in this document should be discussed with project management and fully documented on the appropriate field forms.

2. Related Standard Operating Procedures

- 10005 – Quality Assurance/Quality Control Measures for Field Sampling Activities
- 10011 – Direct Push Probing and Sample Tooling Advancement
- 10024 – Geoprobe® Screen Point Groundwater Sampler or Temporary Well Installation
- 10038 – Documentation and Integrity of Field Sampling Activities
- 10059 – Management of Investigation Derived Waste
- 10065 – Decontamination of Field Sampling Equipment
- 10067 – Handling, Packaging, and Shipping of Analytical Samples
- 10068 – Groundwater and Non-Aqueous Phase Liquids (NAPL) Measurements

In addition to the above-noted SOPs, project and client-specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the Work Plan, FSP, site-specific Health and Safety Plan (HASP), and/or Quality Assurance Project Plan (QAPP) for adherence during the execution of the project.

3. Definitions

**Post Run Tubing (PRT):** A Geoprobe® proprietary system of tubing and fittings that are used both for vapor<sup>1</sup> and groundwater sampling.

---

<sup>1</sup> Vapor sample collection is not covered by this SOP.



**Screen Point Groundwater Sampler:** A stainless steel, completely sealed groundwater sampler installed using the Geoprobe® or other direct push technology to collect representative groundwater samples from unconsolidated formations.

**Temporary well:** A slotted well screen placed in a borehole and used to collect grab groundwater samples for screening proposes.

#### 4. Equipment

The following equipment and supplies shall be used during the collection and field analysis of groundwater samples, as required:

- Health and safety equipment (as required by the site-specific HASP)
- Polyethylene plastic sheeting
- Photoionization detector (PID) and calibration kit
- Water quality meters for measuring pH, temperature, specific conductance, oxidation reduction potential (ORP), and dissolved oxygen (DO), calibration solutions and flow-through cell
- Turbidity meter
- Colorimetric tests for dissolved oxygen (DO)
- Temporary well screen (stainless steel or Polyvinyl chloride [PVC])
- Adjustable-rate centrifugal pump, peristaltic pump, bladder pump (constructed of stainless steel or Teflon®), adjustable-rate submersible pump, or adjustable-rate centrifugal pump. The preferable style of pump to be used is project specific and will be determined in the Work Plan or FSP.
- Appropriate tubing for the pump or check valve. Either Teflon or polyethylene tubing may be used for groundwater sampling. Selection of tubing material should be based on the contaminants of concern and the purpose of the groundwater investigation, refer to Work Plan or FSP.
- Bladder pump control units for Nitrogen and Carbon Dioxide Tanks, and electronic and gas operated air compressors (if needed)
- Interface probe/clear view bailer (to check for non-aqueous phase liquids, as appropriate)
- Electronic water-level indicator (accurate to 0.01 foot)
- 0.45 or 10 -micron filter
- Bailer with disposable nylon or polyethylene rope
- 5-gallon bucket or other containers for purged groundwater
- Graduated measuring cup or bucket
- Table or flat surface
- Decontamination tools and fluids
- Traffic cones, caution tape, or barriers
- Cooler and ice
- Field forms
- Laboratory provided sample containers

#### 5. Procedures

##### 5.1. Utilities Clearance

- 5.1.1. Underground utility clearance will be conducted in accordance with the Loureiro Engineering Associates, Inc. (LEA) ground breaking procedure.

**5.2. Site Preparation**

- 5.2.1. Review and follow the health and safety procedures or requirements specified in the site-specific HASP. All necessary personal protective equipment (PPE) shall be donned as specified in the site-specific HASP.
- 5.2.2. A sufficient area shall be cordoned off using traffic cones, caution tape, or barriers. The area adjacent to the well shall be covered with plastic sheeting to avoid contact with the field equipment and the surface of the ground.

**5.3. Equipment Decontamination and Cleaning**

- 5.3.1. All equipment will be decontaminated prior to starting and in between collection of samples in accordance with SOP 10065 Decontamination of Field Sampling Equipment or as otherwise specified in the Work Plan or FSP. Disposable equipment does not need to be decontaminated and will be handled as waste after use.

**5.4. Opening monitoring wells and collection of liquid measurements**

- 5.4.1. Refer to SOP 10068 *Groundwater and Non-Aqueous Phase Liquids (NAPL) Measurements* for guidance of the procedure for opening a well and collection of liquid thickness data. If NAPL is observed in a well, contact the project lead to determine if sampling should proceed.

**5.5. Analysis of Groundwater Field Parameters using Water Quality Meter**

- 5.5.1. Field parameters including pH, temperature, specific conductance, turbidity, DO, and oxidation reduction potential (ORP). DO may be measured using a water quality meter or colorimetric test kits. The meters shall be calibrated immediately prior to use, if conditions change, and at the end of the day using manufacturer supplied solutions in accordance with the instructions provided by the manufacturer. Calibration information will be recorded on the calibration log.
- 5.5.2. Collect a water sample for field analysis using a pump or bailer.
- 5.5.3. Measure field parameters using a water quality meter immediately after the groundwater sample has been collected from the well. Field parameters can also be measured using downhole water quality meters. If you are unsure if the meter can be used in the well, refer to the instruction manual.
- 5.5.4. The water quality meter shall be placed into a sample and allowed to stabilize for a minimum of twenty seconds. The sample shall be discarded in an appropriate manner (refer to Section 5.11) upon completion of the field analysis. Measurements will be documented in accordance with SOP 10038 *Documentation and Integrity of Field Sampling Activities*.
- 5.5.5. The water quality meters shall be decontaminated using a distilled/deionized water rinse between each sample or be decontaminated

in accordance with the instrument instructions. To the extent possible, the same water quality meter shall be used for all measurements at a given site for the duration of monitoring at the site. Liquid samples have that been in contact with water quality meters shall not be submitted for laboratory analysis.

## 5.6. Well Purging

- 5.6.1. Centrifugal, submersible, Waterra, bladder, inertial, or peristaltic pump, or bailer may be used to purge wells. The selection of the pump will be based well construction, refer to Work Plan for FSP.
- 5.6.2. Sampling and purging equipment, such as pump, tubing, bailers, containers, etc., shall be placed on polyethylene sheet, never placed on the ground.
- 5.6.3. Prior to purging the well, use the water level meter or tape measure to measure the total depth of the well to calculate standing water in the well based on the following schedule and record on the appropriate field form:

Well Diameter (inches)	Conversion Factor (gal/feet)
½	0.01
1	0.041
1 ¼	0.064
1 ½	0.091
2	0.163
4	0.654
6	1.47

- 5.6.4. Prepare pump and tubing for insertion into the well, ensuring that any tubing or pump apparatus is of sufficient length to reach the appropriate depth for pumping. Attached a rope or cord to the top of the pump and use the rope to raise and lower the pump. Do not lower the pump using the tubing.
- 5.6.5. Pumping shall occur within the well screened interval as indicated on the well construction diagram. If the well construction information is not available, the bottom of the tubing or pump shall be placed 1' - 2' above the bottom of the well. Record the intake depth of the tubing in the field notes.
- 5.6.6. Measure field parameters (pH, temperature, specific conductance, turbidity, DO, ORP and other water quality parameters) in the well from the first water extracted during the purging process (refer to Section 5.4 for field parameter analysis) and then measure field parameters after each well volume purged. Refer to the Work Plan or FSP for monitoring frequency and list of parameters to monitor.
- 5.6.7. Purge a volume of water equal to 3 to 5 times the standing water from the well into an appropriate container. Refer to the Work Plan or FSP for purge volume requirements. Measure the pumping rate using a graduated

measure cup or bucket. For slow-yielding wells, decrease the pumping rate to allow for recharge. Refer to the Work Plan or the FSP for purging requirements.

**5.6.8.** If it is not possible to remove three volumes as described above because the well goes dry, allow for the well to recover and collect the groundwater sample. In slow-yielding wells, whenever full recovery exceeds two hours, the sample shall be extracted as soon as a sufficient volume is available to collect a sample for each parameter.

**5.6.9.** Well evacuation is deemed to be complete when the following criteria have been met:

- pH measurements vary no more than  $\pm 0.1$  standard units.
- Specific conductance measurements vary no more than  $\pm 3\%$ .
- Temperature measurements vary no more than  $\pm 3^\circ\text{Celsius}$ .
- Turbidity measurements are below 5 Nephelometric Turbidity Units (NTUs), if practicable.

Alternatively, well purging shall be deemed complete if a maximum of five well volumes have been removed from the well and/or other site-specific or method-specific parameters have stabilized.

## 6. Sample Withdrawal

**6.1.** In order to ensure that the groundwater sample is representative of the formation, it is important to minimize physical alteration (i.e., agitation during purging and/or sample collection) or chemical contamination of the sample during the withdrawal process.

**6.2.** Samples to be analyzed for the following constituents shall be collected using a peristaltic pump, bladder pump or bailer. If bailer is used for sample collection, gently remove the pump and tubing from the well and slowly lower the bailer into the well and gently remove the bailer. Volatiles can be lost from groundwater samples through agitation.

- Volatile organic compounds (VOCs)
- Purgeable organic carbons (POCs)
- Purgeable organic halogens (POX)
- Total organic halogens (TOX)
- Total organic carbon (TOC)

**6.3.** To minimize agitation of the water column, samples shall be collected from the pump tubing in the following order into pre-labeled sample containers:

- Extractable organic compounds (semi-volatile)
- Total petroleum hydrocarbons (TPH)
- Polychlorinated biphenyls (PCBs)
- Metals
- Phenols
- Cyanide
- Chloride and sulfate

- Nitrate and ammonia
- Turbidity
- Radionuclides

- 6.4. Samples shall be obtained from the wells as soon as possible after purging. This may require waiting an extended period for low-yielding wells.
- 6.5. Samples collected for VOC analysis shall be free of any air bubbles and inverted upon filling.
- 6.6. Bacterial samples shall be collected using dedicated gloves; taking care not to allow anything to touch the inside of the sampling container. Biological contaminant bottles are sterile, so be careful not to contaminate the bottle by allowing it to come in contact with anything (e.g., sampler or surroundings). Wear gloves and fill the bottle quickly after opening, holding the cap by the edges only. Do not set the cap down on a table or other surface.
- 6.7. Samples collected for metals analysis (i.e., dissolved metals), which are to be filtered in the field shall be passed through an appropriately sized filter prior to placement in the sample bottle. Pre-rinse the filter with approximately 25 to 50 milliliters of groundwater prior to collecting the samples for filtered metals analyses. Filter sizes will generally be either 10 microns for metals that could be present as colloids, or adsorbed onto colloids that could be mobile in the aquifer, or 0.45 microns for dissolved metals. The appropriate filter size for the individual project must be provided in the Work Plan or FSP. The filter can be used in-line or under negative pressure prior to placement in the sample bottle.
- 6.8. Measure pH, temperature, specific conductance, DO, ORP and turbidity (and other specific parameters) again after sampling to determine the effectiveness of purging and sample stability.
- 6.9. Record sampler's name, weather conditions, sampling time, volume of water purged, pumping rate, parameters measured, sample number, and analyses required and all other pertinent information on appropriate field forms in accordance with SOP 10038 Documentation and Integrity of Field Sampling Activities, and complete the chain of custody form as per SOP 10067 Handling, Packaging, and Shipping of Analytical Samples.
- 6.10. The field paperwork shall also provide an indication of other field conditions that could potentially impact water levels (i.e., major rain storm or snow melt, a pond being drained, or presence of a beaver dam in nearby surface water).
- 6.11. Do not re-use purging equipment (bailers, rope, tubing, sampling vials, etc.). Any non-disposable bailers shall be returned to the office for decontamination.
- 6.12. Pumps shall be decontaminated between monitoring wells, in accordance with procedures in SOP 10065 Decontamination of Field Sampling Equipment or as otherwise specified in the site-specific Work Plan or FSP.
- 6.13. **Screen Point Groundwater Sampler and Temporary Well Sampling**

**6.13.1.** There are three methods for collecting groundwater samples from a Screen Point Groundwater Sampler or temporary wells. Refer to SOP 10024 Geoprobe□ Screen Point Groundwater Sampler or Temporary Well Installation for guidance on installation of the Screen Point Groundwater Sampler or temporary wells. The three methods include the following:

- Bottom Check Valve Sampling
- Sampling Through PRT
- Temporary Well Sampling

**6.13.2. Bottom Check Valve Sampling**

**6.13.2.1.** This method is often referred to as "sampling from the open rods," and it can be deployed to pump directly from the bore of the probe rods immediately above the Screen Point Groundwater Sampler using a tubing bottom check valve. This method will be used if the water table is greater than 21 feet. Note that in order for this method to be employed, the piezometric head in the saturated formation must be above the top of the deployed Screen Point Groundwater Sampler; water from the formation must rise into the probe rods where it can then be pumped to the surface. The following procedures are used to obtain groundwater samples using bottom check valve sampling:

**6.13.2.2.** Place a tubing check valve at the bottom end of a roll of tubing.

**6.13.2.3.** Push the tubing, check valve end first, down the bore of the probe rods until it strikes the top of the Screen Point Groundwater Sampler.

**6.13.2.4.** Lift the tubing approximately 4 inches off the bottom (top of the Screen Point Groundwater Sampler) and oscillate.

**6.13.2.5.** Reduce the pumping rate if air bubbles appearing in the pumped stream indicate that the pumping action is exceeding recharge from the screen point, allowing air to enter at the check valve end.

**6.13.2.6.** If water cannot be pumped to the surface, sufficient sample may be obtained by using the tubing and check valve as a bailer. Gently oscillate the tubing to fill it with several feet of sample and then remove the tubing from the rods.

**6.13.3. Sampling Through PRT**

**6.13.3.1.** Installation of the PRT system will be completed in accordance with SOP 10024 Screen Point Groundwater Sampler or Temporary Well Installation. This tubing is inserted down the rods after the sampler has already been driven to depth and has been deployed for sampling. The top of the Screen Point Groundwater Sampler is equipped with a PRT fitting, which serves as a receptacle for a

corresponding PRT adapter fitted onto the end of the sampling tube. The disadvantage of this method is that it is limited to maximum groundwater depths of 20 to 28 feet below ground surface. The following procedures are used to obtain groundwater samples using PRT fittings and tubing.

- 6.13.3.1.1. Push the adapter end of the tubing down the bore of the probe rods until it comes into contact with the PRT threads at the top of the Screen Point Groundwater Sampler.
- 6.13.3.1.2. Rotate the tubing counter-clockwise at the surface to screw the adapter into the screen point threads. Rotate the tubing several revolutions until the downhole adapter is completely seated and the tubing starts twisting.
- 6.13.3.1.3. The tubing can now be attached to a peristaltic pump or vacuum source at the surface.
- 6.13.3.1.4. After sampling is complete, tubing should be removed by pulling it up at the surface.

#### 6.13.4. Temporary Well Sampling

- 6.13.4.1. This procedure is intended to describe the collection of grab groundwater samples from an open borehole using a temporary well. Such a procedure serves to provide “screening level” groundwater data in instances when such data will enhance our understanding of site conditions, and/or in cases where access to the site is limited and other means of conventional groundwater sample collection are not suitable. The borehole will be advanced in accordance with SOP 10011 *Direct Push Probing and Sample Tooling Advancement*. Well screen material and the method of soil boring advancement will be provided in the site-specific Work Plan or FSP. The procedure consists of the following steps:
  - 6.13.4.1.1. Advance soil boring as deep as possible below the top of the water table to loosen the soil.
  - 6.13.4.1.2. Place appropriately selected screen with enough riser attached to reach ground surface into the open borehole. Advance the temporary monitoring point to get as much of the screen below the top of the water table as possible.
  - 6.13.4.1.3. Thread tubing down through the riser and slotted screen into the water column.
  - 6.13.4.1.4. Using a peristaltic pump, purge at least one volume of water corresponding to the volume of disturbed material

around the temporary point (this includes the volume calculated using the borehole diameter).

**6.13.4.1.5.** Record pH, temperature, specific conductance, and turbidity DO, ORP prior to sampling (Refer to Section 5.4).

**6.14. Sample Custody**

**6.14.1.** Sample custody will be managed in accordance with SOP 10067 *Handling, Packaging, and Shipping of Analytical Samples*.

**6.15. Waste Management**

**6.15.1.** Investigation derived wastes, including purge water, decontamination liquids, disposable equipment and disposable materials (PPE, plastic sheeting, etc.), will be placed in clearly labeled, appropriate containers in accordance with SOP 10059 Management of Investigation Derived Waste, or managed as otherwise specified in the Work Plan or FSP.

**6.16. Documentation**

**6.16.1.** Documentation of field activities will be completed in accordance with SOP 10038 Documentation and Integrity of Field Sampling Activities. In addition, field measurements will be recorded on the Well Sample Record (attached). Any deviations from SOPs will be documented in the field paperwork.

**7. References**

None.

END OF DOCUMENT



**Loureiro Engineering Associates, Inc.  
Standard Operating Procedure  
for  
Quality Assurance/Quality Control Measures  
for  
Field Sampling Activities**

**SOP ID: 10005  
Date Initiated: 02/20/90  
Revision No. 006: 07/28/18**

**Revised By: /s/ Karen A. Goldenberg                      07/19/18**  
**Karen A. Goldenberg                      Date**  
**Senior Technical Associate**

**Reviewed By: /s/ David W. Payne                      09/04/18**  
**David W. Payne                      Date**  
**Project Manager**

**Approved By: /s/ Karen Harris                      09/04/18**  
**Karen Harris                      Date**  
**Quality Assurance Manager**

## REVISION RECORD

---

<u>Rev #</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	02/20/90	
001-003	-	No record.
004	12/31/01	Updated to reflect new SOP format. Added Section 4.3, Results Evaluation. Minor revisions throughout.
005	11/05/09	Added Section 4.4 on sample management procedures. Revised signature page.
006	07/28/18	Revised to: (1) reference related SOPs, (2) remove performance evaluation (PE) samples and sample management procedures, which are addressed in related SOPs, (3) update and clarify field QA/QC sample types, (4) clarify field QA/QC sample collection methods, (5) include other types of cooler temperature indicators, (6) remove spiked samples prepared outside the laboratory, and (7) reflect new SOP format and language.

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Quality Assurance/Quality Control Measures**  
**for**  
**Field Sampling Activities**

**1. Purpose and Scope**

This document describes procedures to be followed for proper Quality Assurance (QA) / Quality Control (QC) practices, which shall incorporate all activities associated with field measurements and sampling, proper documentation of field and post-field activities, QC sample preparation, chain-of-custody protocol, sample management procedures, and laboratory analytical procedures. The purpose of QA/QC practices is to confirm that Data Quality Objectives (DQOs) are met for a project.

Since a field QA/QC sample may be referred to in different ways, or the same term may be used to refer to different types of QA/QC samples, the names and intended meanings of the field QA/QC samples that may be collected for Loureiro Engineering Associates, Inc. (LEA) projects are provided in Section 3. The use of specific QA/QC measures is project-specific as defined in the project work plan. Similarly, the frequency of QA/QC sample collection is project-specific. Although general guidelines are provided in this SOP, refer to the project-specific work plan or Quality Assurance Project Plan (QAPP) for the types and frequencies of QA/QC samples to be used for a specific project.

**2. Related Standard Operating Procedures**

- 10030 – Processing Performance Evaluation Samples
- 10038 – Documentation and Integrity of Field Sampling Activities
- 10067 – Handling, Packaging, and Shipping of Analytical Samples

**3. Definitions**

- **Equipment Blank:** A sample of analyte-free water poured over or through field sampling equipment. It is collected after completion of decontamination and prior to sampling at another location. The sample accompanies the other field samples to the laboratory for analysis. When used with decontaminated field sampling equipment, the purpose is to assess the adequacy of the decontamination process. May also be called a rinse blank or rinsate blank. When used with disposable sampling

equipment, the purpose is to evaluate contamination introduced from the sampling equipment.

- **Field Blank:** A generic term for any sample submitted from the field that is identified as a blank. In the context of this SOP, field blank means a sample of media free of measurable contaminants that is exposed to the same field conditions as the field samples and opened in the field for a predefined period of time. Liquid field blanks may also be collected by pouring water free of measurable contaminants from its original container into sample containers in the field. The sample accompanies the other field samples to the laboratory for analysis. The purpose of a field blank is to measure ambient contamination in the field.
- **Field Duplicate:** A generic term for two (or more) field samples taken at the same time in the same location and are intended to represent the same population. A duplicate may also be referred to as a replicate. In the context of this SOP, “Field Duplicate” means samples that are intended to represent the same population and are taken through all steps of the analytical procedure in an identical manner and provide precision information for the data collection activity. There are two categories of Field Duplicate samples defined by the collection method: co-located Field Duplicates and subsample Field Duplicates.
  - **Subsample Field Duplicate:** A type of Field Duplicate where the sample is homogenized and then divided into two or more portions so that lab variability can be evaluated. The samples are given independent names so they are not associated with one another by the analytical laboratory (e.g., double blind). Note: Homogenization may have an impact on sample integrity for some sample types (e.g., volatile organic compounds [VOCs] in soil); in these cases, co-located samples may be more appropriate.
  - **Co-Located Field Duplicate:** A type of Field Duplicate where independent samples are collected as close as possible to the same point in space and time using the same sampling method. They are two separate samples taken from the same source, stored in separate containers, and analyzed independently by the same method and laboratory. Co-located Field Duplicates generally provide more information about the measurement precision of the sampling process, including the sampling equipment and heterogeneity of the site. The samples are given independent names so they are not associated with one another by the analytical laboratory (e.g., double blind).
- **Matrix Spike (MS):** A type of field duplicate (generic) where the sample is divided into two representative portions taken from one sample in the field. The sample is mixed (except volatiles) prior to division to minimize sample heterogeneity. At the laboratory, known concentrations of certain target analytes are added before sample preparation, cleanup, and determinative procedures have been implemented. The

matrix spike analysis is used to assess the performance of the method by measuring the effects of interferences caused by the sample matrix and reflects the bias of the method for the particular matrix in question.

- **Matrix Spike Duplicate (MSD):** Additional replicates of matrix spike samples that are subjected to the same sample preparation and analytical scheme as the original sample. The matrix spike duplicate is used to document the precision as well as bias of a method in a given sample matrix.
- **Replicate Sample:** A type of field duplicate (generic) where the sample is divided into two or more representative portions. The sample is mixed (except volatiles) prior to division to minimize sample heterogeneity. The replicate sample is archived to provide a back-up sample for analysis if the primary sample is damaged during shipment and handling or if lab blanks associated with the analysis of the primary sample show clear evidence of contamination.
- **Split Field Sample:** A type of field duplicate (generic) where the sample is divided into two or more representative portions taken from one sample in the field and analyzed by at least two different laboratories and/or methods. The sample is mixed (except volatiles) prior to splitting to minimize sample heterogeneity. These samples are used to assess precision variability, and data comparability between laboratories or methods.
- **Temperature Blank:** A vial of water that accompanies the sample(s) that will be tested upon arrival at the laboratory to ensure that the temperature of the contents of the shipping container were within the required temperature range (generally  $4^{\circ}\text{C} \pm 2^{\circ}$ ). Other devices, such as a recording thermometer or temperature strip, may be used in lieu of a temperature blank, providing they monitor the appropriate temperature range.
- **Trip Blank:** A sample of media free of measurable contaminants taken from the laboratory to the sampling site and returned to the laboratory unopened. A trip blank is used to document contamination attributable to shipping and field handling procedures. Most commonly used for VOC samples. When used for other parameters, it gives a measure of the contamination introduced to a sample by the container (also referred to as a bottle blank). For VOC samples, trip blanks should be prepared at a frequency of one per day of sampling during which samples are collected for VOC samples.

#### **4. Equipment**

- Laboratory glassware
- Cooler with identifiable cooler ID
- Chain-of-custody

## 5. Procedures

### 5.1. General

5.1.1. All QA/QC sample preparation procedures shall be properly documented including:

- Name of person(s) involved in sample preparation.
- Sample numbers.
- Analyses required.
- Number, type, size of containers used.
- Preservation method.
- Date and time of sample preparation.

5.1.2. All information shall be included in the field logbook and/or appropriate field forms, but not necessarily in the chain-of-custody record except as needed for proper sample identification and analysis. Blind sample numbers are used in order not to disclose the nature of the sample to the laboratory. No information that would identify the sample as a QA/QC sample shall be included in the chain-of-custody record.

5.1.3. At the conclusion of each sampling day, a quality control review shall be conducted using the Field Quality Review Checklist and the Daily Field Report.

### 5.2. QC Sample Preparation

#### 5.2.1. Trip Blank

5.2.1.1. Trip blanks shall be used when sampling surface water, groundwater, soil, and sediment for VOCs. Trip blank(s) shall be included in each shipping container (cooler) carrying solid and/or liquid matrix samples that are to be analyzed for VOCs.

5.2.1.2. Trip blanks shall be provided by the analytical laboratory, and used only with samples that are to be analyzed for VOCs. **Trip blanks shall not be opened at any time prior to arrival at the laboratory for processing and analysis.**

5.2.1.3. The trip blank samples shall be transported to the field with the sample bottleware. Trip blank samples shall be handled and treated in the same manner as the field samples collected for VOC analysis.

- 5.2.1.4. For solid-matrix samples collected using the water and methanol preservation methods, unopened vials will be submitted to the laboratory as trip blanks. For solid-matrix samples collected using En Core<sup>®</sup> containers, two sealed En Core<sup>®</sup> containers will be submitted to the laboratory as the trip blank sample.

#### 5.2.2. Temperature Blank

- 5.2.2.1. Temperature blanks shall be used when sampling surface water, groundwater, soil, and sediment. One temperature blank should be included per shipping container (cooler) containing environmental samples.
- 5.2.2.2. Temperature blanks may indicate if the required temperature range (generally  $4^{\circ}\text{C} \pm 2^{\circ}$ ) has been exceeded.
- 5.2.2.3. Temperature blanks shall be provided by the laboratory and accompany the bottleware to the field.
- 5.2.2.4. Other devices, such as a recording thermometer or temperature strip, may be used in lieu of a temperature blank, providing the device monitors the appropriate temperature range.
- 5.2.2.5. The temperature blank or other temperature-indicating device shall be placed in the cooler at the same time as the ice, in preparation for sample collection.

#### 5.2.3. Equipment Blank

- 5.2.3.1. Equipment blanks shall be used when sampling surface water, groundwater, soil, and sediment. One equipment blank shall be collected for each sample bottle/preservation technique/analysis procedure per matrix per sampling event, or as otherwise specified in project-specific documents
- 5.2.3.2. The purpose of an equipment/rinsate blank is to determine if decontamination procedures were adequate or if any of the equipment might contribute contaminants to the sample.
- 5.2.3.3. An equipment blank is prepared by running analyte-free deionized water through all sample collection equipment (bailers, pumps, filters, split-spoon) and placing it in the appropriate sample containers for analysis. If equipment has

been decontaminated in the field, the equipment blank shall be collected after decontamination procedures have been performed before sample collection at the next location. The locations of the samples collected before and after the equipment blank should be recorded on the field paperwork.

- 5.2.3.4. For certain constituents (e.g., per- and polyfluorinated alkyl substances [PFAS]), the laboratory may need to provide certified analyte-free water for the equipment blank.

#### 5.2.4. Field Blank

- 5.2.4.1. Field blanks shall be used only when dictated by project-specific DQOs. Refer to project-specific documents for instruction regarding frequency of collection.
- 5.2.4.2. The purpose of a field blank is to evaluate ambient contamination in the field.
- 5.2.4.3. This procedure only covers the collection of liquid matrix field blanks. If a solid matrix field blank is needed, project-specific modifications to this procedure will be required.
- 5.2.4.4. A liquid field blank is prepared by pouring analyte-free deionized water into the appropriate sample containers for analysis at the field sampling location. For certain constituents (e.g., PFAS), the laboratory may need to provide certified analyte-free water for the field blank.

#### 5.2.5. Field Duplicates

- 5.2.5.1. Subsample field duplicate samples shall be used for soil and sediment samples, unless project-specific documents specify the use of co-located samples. One sample shall be obtained for each sample bottle/preservation technique/analysis procedure per sampling event or one out of every 20 samples, unless co-located samples are used (see below), or as otherwise directed in project-specific documents
- 5.2.5.2. No information that would identify the sample as a duplicate sample shall be included in the chain-of-custody record.
- 5.2.5.3. Subsample Field Duplicate Samples



- 5.2.5.3.1. Subsample field duplicate samples provide precision information on handling, shipping, storage, preparation, and laboratory analysis.
- 5.2.5.3.2. These are samples that have been divided into two or more portions in the field after the samples have been homogenized. Due to potential VOC loss during homogenization, non-homogenized VOC sampling methods intended to minimize the variability between samples shall be used, as indicated below.
- 5.2.5.3.3. For soil or sediment VOC samples, collect side-by-side samples from the sampling device (e.g., core, auger). For non-VOC samples, collect twice as much volume as is normally collected. Homogenize the sample well before filling the sample jars.
- 5.2.5.3.4. For aqueous VOCs samples, fill the sample vials from the same bailer or consecutively from the same tubing. For non-VOC samples, alternate filling bottles from the sampling device (e.g., bailer, pump). For example, VOCs for the primary sample, VOCs for the duplicate sample, SVOCs for the primary sample, SVOCs for the duplicate sample, etc.

#### 5.2.5.4. Co-located Field Duplicate Samples

- 5.2.5.4.1. Co-located field duplicate samples provide precision information on the sampling process, including the sampling equipment and heterogeneity of the site.
- 5.2.5.4.2. For soil or sediment, co-located samples shall be collected from adjacent surface locations or at the same depth interval from side-by-side boreholes.
- 5.2.5.4.3. For aqueous samples, co-located samples shall be collected by filling all of the sample bottles for the primary sample, then filling all of the sample bottles for the co-located sample.

## 5.2.6. Split Samples and Replicates

5.2.6.1. These samples shall be used only when dictated by project-specific DQOs. Refer to project-specific documents for instruction regarding frequency of collection. Sample collection follows the same procedures as indicated for subsample field duplicate samples above.

### 5.2.6.2. Split Samples

5.2.6.2.1. Split samples provide information to assess precision variability, and data comparability between laboratories or methods.

5.2.6.2.2. For soil or sediment VOC samples, collect side-by-side samples from the sampling device (e.g., core, auger). For non-VOC samples, collect twice as much volume as is normally collected. Homogenize the sample well before filling the sample jars.

5.2.6.2.3. For aqueous VOCs samples, fill the sample vials from the same bailer or consecutively from the same tubing. For non-VOC samples, alternate filling bottles from the liquid sampling device (e.g., bailer, pump). For example, VOCs for the primary sample, VOCs for the duplicate sample, SVOCs for the primary sample, SVOCs for the duplicate sample, etc.

### 5.2.6.3. Replicate Samples

5.2.6.3.1. Replicate samples provide a back-up sample for analysis, if needed.

5.2.6.3.2. For soil or sediment VOC samples, collect side-by-side samples from the sampling device (e.g., core, auger). For non-VOC samples, collect twice as much volume as is normally collected. Homogenize the sample well before filling the sample jars.

5.2.6.3.3. For aqueous VOCs samples, fill the sample vials from the same bailer or consecutively from the same tubing. For non-VOC samples, alternate filling bottles from the liquid sampling device (e.g., bailer,

pump). For example, VOCs for the primary sample, VOCs for the duplicate sample, SVOCs for the primary sample, SVOCS for the duplicate sample, etc.

#### 5.2.7. Matrix Spike/Matrix Spike Duplicate Samples

- 5.2.7.1. MS/MSD samples shall only be used when dictated by project-specific DQOs. Refer to project-specific documents for sample frequency.
- 5.2.7.2. Aqueous samples are collected from one sampling location at triple the normal sample volume. In the filling sequence for aqueous MS/MSD samples, bottles will alternate (e.g., VOCs for the primary sample, VOCs for the MS, VOCs for the MSD, SVOCs for the primary sample, SVOCS for the MS, SVOCs for the MSD, etc.).
- 5.2.7.3. Solid samples are collected from one sampling interval at double or triple the normal sample volume. For VOCs, triple side-by-side samples should be collected. For non-VOC samples, collect twice as much volume as is normally collected. Homogenize the sample well before filling the sample jars.
- 5.2.7.4. Identify the MS/MSD on the chain-of-custody form by adding “MS/MSD” after the sample number.

#### 5.3. QA/QC Sample Result Evaluation

The analytical results on QA/QC samples should be evaluated along with the remaining analytical data as follows:

- 5.3.1. No constituents should be detected in the trip blank, equipment blank, or field blank.
- 5.3.2. The relative percent differences (RPDs) shall be computed for all constituents detected in subsample and co-located duplicate samples used. If split samples are used to evaluate different laboratories or methods, the RPDs shall be computed for all constituents detected in both the sample and split sample.

The RPD between two measurements (e.g., M1 and M2) is calculated as follows:

$$RPD = \frac{|M1 - M2|}{(M1 + M2)/2} \times 100\%$$

5.3.3. Refer to project-specific documents for evaluation of MS/MSD sample results.

## 6.0 References

EPA, *Test Methods for Evaluating Solid Waste, Physical/Chemical Methods* (SW-846) Chapter 1, Revision 2. July 2014

EPA, *Uniform Federal Policy for Quality Assurance Project Plans, Part 2B, Quality Assurance/Quality Control Compendium: Minimum QA/QC Activities*, EPA Publication: EPA-505-B-04-900B.

ASTM, *Standard Guide for Field Quality Assurance in a Groundwater Sampling Event*, ASTM D7069 (2015), January 2015.

END OF DOCUMENT

**Loureiro Engineering Associates, Inc.  
Standard Operating Procedure  
for  
Soil Sampling**

**SOP ID: 10006  
Date Initiated: 02/20/90  
Revision No. 011: 09/12/18**

<b>Revised By:</b>	<u><i>/s/ Sarah Burkhalter-Sweeney</i></u>	<u><i>07/17/18</i></u>
	<b>Sarah Burkhalter-Sweeney</b>	<b>Date</b>
	<b>Project Geologist</b>	
<b>Reviewed By:</b>	<u><i>/s/ Jo Ann Robertson</i></u>	<u><i>09/12/18</i></u>
	<b>Jo Ann Robertson</b>	<b>Date</b>
	<b>Technical Associate</b>	
<b>Approved By:</b>	<u><i>/s/ Karen Harris</i></u>	<u><i>09/12/18</i></u>
	<b>Karen Harris</b>	<b>Date</b>
	<b>Quality Assurance Manager</b>	

## REVISION RECORD

---

<u>Rev #</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	02/20/90	
001-004	-	No record.
005	07/19/00	Revisions to template, including new logo.
006	05/16/01	Revisions to Sections 4.2.1, 4.2.2; add Section 4.2.3.
007	07/27/01	Updated to conform with new SOP format.
008	12/31/01	Minor revisions throughout.
009	01/18/06	Removed use of wood spatula
010	07/17/18	Revisions throughout. Update to reflect new SOP format and updated sampling methodologies.
011	09/12/18	Added text to Section 5.4 to clarify sample recovery requirements and photographing soil samples

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Soil Sampling**

**1. Purpose and Scope**

This document discusses procedures for collection of soil samples for analysis. Methods for collection and quality assurance/quality control (QA/QC) requirements are covered under separate standard operating procedures (SOPs). The procedures outlined in this document are in accordance with Environmental Protection Agency (EPA) document entitled, *Test Methods for Evaluating Solid Waste, Physical/Chemical Methods* (SW-846). The collection of soil and sediment samples for analysis of Volatile Organic Compounds (VOCs) is not covered in this SOP, refer to SOP 10057 *Collecting and Preserving Soil and Sediment Samples for Laboratory Determination of Volatile Organic Compounds (VOCs)*.

**2. Related Standard Operating Procedures**

- 10005 – QA/QA Measures for Field Sampling Activities
- 10015 – Geologic Logging of Unconsolidated Sedimentary Deposits
- 10038 – Documentation and Integrity of Field Sampling Activities
- 10057 – Collecting and Preserving Soil and Sediment Samples for Laboratory Determination of Volatile Organic Compounds (VOCs)
- 10059 – Management of Investigation Derived Waste
- 10065 – Decontamination of Sampling Equipment
- 10066 – Sediment Sampling Using Vibratory Corer

In addition to the above-noted SOPs, project and client-specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the project-specific work plan (Work Plan) or Field Sampling Plan (FSP) for adherence during the execution of the project.

### 3. Definitions

Scale: A linear scale, also called a bar scale, scale bar, graphic scale, or graphical scale, is a means of visually showing scale in photograph.

### 4. Equipment

The following equipment and supplies shall be used during soil sampling activities, as required:

- Health and safety equipment (as required by the site-specific Health and Safety Plan [HASPP])
- Polyethylene or stainless steel spatula (spoon, scoop, trowel, Terra Core™, EnCore®, etc.) for transfer of soil from sample collection device to sample container
- Soil collection devices will be identified in the site-specific Work Plan, but may include polyethylene or stainless steel hand augers, trowel, trier, soil coring device, direct push, spilt-spoon sampler, bobcat, excavator, etc.
- Latex or nitrile gloves
- Polyethylene plastic sheeting
- Table or flat surface
- Measuring tape and scale
- Paper towels
- Balance for weighing samples
- Utility knife
- Re-sealable plastic bags
- Photoionization Detector (PID) and calibration kit
- Bowl/bucket/container for compositing sample (of appropriate material)
- Traffic cones, caution tape or barriers
- Camera
- Cooler
- Ice
- Laboratory provided containers

### 5. Procedures

#### 5.1. Utilities Clearance

Underground utility clearance shall be conducted in accordance with the LEA ground breaking procedure.

#### 5.2. Site Preparation



- 5.2.1. Review and follow the health and safety procedures or requirements specified in the site-specific HASP. All personal protective equipment (PPE) shall be donned as specified in the site-specific HASP during all sampling procedures.
- 5.2.2 A sufficient area shall be cordoned off using traffic cones, caution tape, or barriers to restrict access to the work area.
- 5.2.3 A level table shall be placed in the vicinity of the sample collection location and covered with polyethylene sheeting.
- 5.2.4 Decontaminated soil sampling devices and spatulas shall be placed on the table or flat surface. Sample bottles shall be placed in a convenient location and in order of sample collection.
- 5.2.5 PID and plastic bags shall be placed on the table for VOC screening, if necessary.

### 5.3. Equipment Decontamination and Cleaning

All equipment will be decontaminated prior to starting and in between collection of samples in accordance with SOP 10065 *Decontamination of Field Sampling Equipment* or as otherwise specified in the project-specific Work Plan or FSP.

### 5.4. Sampling Procedures

Tools and procedures for collecting soil samples depend on the desired depth of sample. The sample will be rejected if recovery is less than 80% or sample recovery requirements specified in the work plan or FSP are not met. If the sample is rejected, an additional attempt will be made. Document the location of soil boring attempts on a map (tape off existing/permanent features or use a GPS).

- 5.4.1. The particular soil collection device (i.e., hand auger, split spoon, etc.) shall be retrieved from the point of collection and placed on a level table covered in polyethylene sheeting.
- 5.4.2 Photograph the sample with a scale (if allowed).
- 5.4.3 Soil samples for analysis of VOCs will be collected immediately and will be collected from an undisturbed area of the soil sample.
- 5.4.2. Based on analytical and project requirements, soil will be transferred directly into a container to be homogenized. Materials placed in the

container (e.g, an aluminum pan [or bowl of alternate material], ziplock bag) will be homogenized by hand (mixed and/or kneaded) until uniform in color and texture. Care should be taken to fill sample containers with the appropriate mass and/or volume for the desired analysis. Large void spaces within the container shall be minimized by packing, not agitation.

5.4.4 Wipe the rim of the sample container with a clean paper towel to remove excess solids, which would prevent adequate sealing of the sample container, and seal the container.

5.4.5 The order of sample collection shall be based on the work plan/FSP.

5.4.6 Place and secure sample within cooler and complete all sample collection documentation including logging of soil utilizing SOP 10015 *Geologic Logging of Unconsolidated Sedimentary Deposits*. The cooler should not be left unattended without a custody seal.

5.4.7 If required by the site-specific Work Plan, place stake or flagging in sampling location.

## 5.5. Post Sampling Procedures

As required, upon completion of all sampling procedures for a particular site, secure the lid of the cooler using packaging tape with the chain of custody inside in accordance with SOP 10067 *Handling, Packing, and Shipping of Analytical Samples*.

## 5.6. Waste Management

Investigation derived wastes (IDW), including soil cuttings, decontamination liquids, and disposable materials (PPE, plastic sheeting, etc.) will be placed in clearly labeled, appropriate containers in accordance with SOP 10059 *Management of Investigation Derived Waste*, or managed as otherwise specified in the work plan/FSP.

## 5.7. Documentation

5.7.1. Documentation of field activities will be completed in accordance with SOP 10038 *Documentation of Field Sampling Activities* and 10015 *Geologic Logging of Unconsolidated Sedimentary Deposits*.

5.7.2. In general, the following field forms are required for collection of soil samples:

- Daily Field Report
- Daily Field Report “Supplemental Sheet”
- Daily Field Report “Calibration Record” (if PID or balance were used)
- Field Sampling Record “Miscellaneous Samples”
- Field Boring Log
- Chain of Custody

5.7.3. The following general information shall be recorded in the field log book and/or on the appropriate field forms:

- Name of recorder
- Identification of borings
- Collection method
- Date and time of collection
- Types of sample containers used, sample identification numbers and QA/QC sample identification
- Preservative(s) used
- Parameters requested for analysis
- Field analysis method(s)
- Field observations on sampling event
- Name of collector
- Climatic conditions, including air temperature
- Investigation derived waste (IDW)
- Field Sketch of sample location and color/type of flagging (as needed)
- Coordinates and elevations of soil sample locations

## 6. References

EPA. *Test Methods for Evaluating Solid Waste, Physical/Chemical Methods (SW-846)*.

Terra Core<sup>TM</sup>. *Terra Core<sup>TM</sup> Sampling Guidance*. ALS Global. Accessed 2/19/2018.

EnCore<sup>®</sup>. *EnCore<sup>®</sup> Sampler Sampling Procedures*. En Novative Technologies, Inc., 2013. Accessed 2/19/2018.

END OF DOCUMENT

**Loureiro Engineering Associates, Inc.  
Standard Operating Procedure  
for  
Installation of Non-Water Supply Wells  
and  
Piezometers in Unconsolidated Deposits**

**SOP ID: 10007A  
Date Initiated: 02/20/90  
Revision No. 009: 09/07/18**

<b>Approved By:</b> <u>/s/ <i>Jeremy Marcantonio</i></u>	<u>02/20/18</u>
<b>Jeremy Marcantonio</b>	<b>Date</b>
<b>Senior Project Scientist</b>	
<b>Reviewed By:</b> <u>/s/ <i>Jo Ann Robertson</i></u>	<u>09/07/18</u>
<b>Jo Ann Robertson</b>	<b>Date</b>
<b>Technical Associate</b>	
<b>Approved By:</b> <u>/s/ <i>Karen Harris</i></u>	<u>09/12/18</u>
<b>Karen Harris</b>	<b>Date</b>
<b>Quality Assurance Manager</b>	

## REVISION RECORD

---

<u>Rev #</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	02/20/90	
001-004	-	No record.
005	12/31/01	Formatting and minor revisions throughout.
006	08/12/02	Added section on utility clearance.
007	11/01/12	Reference was provided to the company's updated Groundbreaking Procedure, (dated December 6, 2011). The requirement for a site-specific HASP and JHA It was also noted that surging and pumping at the same time may not be as effective as surging and then pumping. Table 1 was incorporated describing and assessing well development equipment. Finally, Figures 1 and 2 were revised to reflect current practices for monitoring well installation.
008	07/18/18	Revisions throughout. Update to reflect new SOP format. Checked against up-to-date standards. Divided installation and development into two separate SOPs: SOP 10007A <i>Installation of Non-Water Supply Wells and Piezometers in Unconsolidated Deposits</i> and SOP 10007B <i>Development of Non-Water Supply Wells and Piezometers in Unconsolidated Deposits</i> . Sampling methodologies were updated.
009	09/07/18	Added nomenclature section.

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Installation of Non-Water Supply Wells**  
**and**  
**Piezometers in Unconsolidated Deposits**

## **1. Purpose and Scope**

This standard operating procedure (SOP) is designed to describe the proper methods and procedures to be used to install wells and piezometers in water-table aquifers and unconsolidated deposits. Because each site is unique and the purpose of the monitoring wells may vary from installation to installation, no definitive rules can be established. Throughout this SOP, reference to monitoring wells is also intended to mean piezometers, unless specifically indicated otherwise. This SOP applies to monitoring wells and piezometers installed by both manual and by Geoprobe<sup>®</sup> or similar direct push technologies.

## **2. Related Standard Operating Procedures**

- 10005 – Quality Assurance/Quality Control Measures for Field Sampling Activities
- 10015 – Geologic Logging of Unconsolidated Sedimentary Deposits
- 10038 – Documentation and Integrity of Field Sampling Activities
- 10059 – Management of Investigation Derived Waste
- 10065 – Decontamination of Field Sampling Equipment

In addition to the above-noted SOPs, project and client-specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the project specific work plan (Work Plan) for adherence during the execution of the project.

## **3. Definitions**

- Geoprobe<sup>®1</sup> or similar direct push technologies: A vehicle-mounted, hydraulically-powered, soil probing machine that utilizes static force and percussion to advance small diameter sampling tools into the subsurface for collecting soil cores, soil gas, or

---

1 Geoprobe<sup>®</sup> is a registered trademark of Kejr Engineering, Inc., Salina, Kansas

groundwater samples. Throughout this SOP, reference to Geoprobe® includes similar direct push technologies, unless specifically indicated otherwise.

- **Prepacked Well Screen (0.5 in and 1.5 in):** An assembly consisting of a slotted polyvinyl chloride (PVC) pipe surrounded by environmental grade sand contained within a stainless steel wire mesh cylinder. The inner component of the prepacked screen is a flush-threaded, 0.5 inch Schedule 80 PVC pipe with 0.01 inch slots. (Alternatively, a 1.5 inch Schedule 80 PVC pipe can be used). Stainless steel wire mesh with a pore size of 0.011 inches makes up the outer component of the prepacked screen. The space between the inner slotted pipe and outer wire mesh is filled with 20/40 mesh silica sand. Geoprobe® prepacked screens are available in sections of various lengths (3 feet or 5 feet) and a nominal inside diameter of 0.5 in or 1.5 in.
- **Cement-Bentonite Grout:** mixture of 95 pounds of Type II Portland cement, 4 to 6 pounds of powdered sodium bentonite, and 5 gallons of potable water. The bentonite must be thoroughly mixed with the water *before* the cement is added.
- **Filter Pack Sand:** all filter pack sand shall have an average specific gravity of 2.5 with not more than 1% of the material having a specific gravity less than 2.25. Thin, flat or elongated particles shall not exceed 2% of the material, no more than 5% of the material shall be soluble in hydrochloric acid, and the material shall be washed and free of shale, mica, clay, dirt, loam, and organic impurities.

#### **4. Equipment**

The following equipment and supplies shall be used during monitoring well installation activities, as required:

- Health and safety equipment (as required by the site-specific Health and Safety Plan [HASP])
- All necessary permits and licenses
- Soil Color Chart
- Hand len
- Drilling rig
- Hand Auger
- Monitoring well casing
- Monitoring well slotted screen or Geoprobe® Pre-pack screen
- Bottom caps, plugs, or points
- Centering guides (if they are to be used)
- Bentonite chips
- Cement-bentonite grout

- Grout pump with mechanical mixing ability (if warranted)
- Filter pack sand
- Protective casing or road box
- American lock(s) and keys
- Weighted ape measure
- Electronic water-level indicator (accurate to 0.01 foot)
- Field forms or field book
- Caution tape, traffic cones, or barriers
- Polyethene plastic sheeting
- Table or flat surface
- Soil sampling tools, laboratory containers, cooler, and ice, if needed
- Decontamination fluids
- Camera/tablet

## 5. Procedures

### 5.1. Utilities Clearance

Underground utility clearance will be conducted in accordance with the LEA ground breaking procedure.

### 5.2. Site Preparation

- 5.2.1. Review and follow the health and safety procedures or requirements specified in the site-specific HASP. All personal protective equipment (PPE) shall be donned as specified in the site-specific HASP.
- 5.2.2. A sufficient area shall be cordoned off using caution tape, traffic cones or barriers to restrict access to the work area.
- 5.2.3. The area adjacent to the proposed borehole may be covered with 5-mil plastic sheeting (depending on site-specific needs). If sheeting is used, soil cuttings shall be placed on the plastic sheeting to avoid contact with the ground surface.

### 5.3. Equipment Decontamination and Cleaning

All equipment will be decontaminated prior to starting and in between well installation in accordance with SOP 10065 *Decontamination of Field Sampling Equipment* or as otherwise specified in the site-specific WP/FSP.

### 5.4. Borehole Advancement



- 5.4.1. The borehole will be advanced using the Geoprobe® the steel casing to the specified depth. Hand augers may be used if it is not possible to access the location using the Geoprobe®.
- 5.4.2. Soil samples will be collected during borehole advancement and described in accordance with SOP 10015 *Geologic Logging of Unconsolidated Sedimentary Deposits* and documented in accordance with SOP 10038 *Documentation and Integrity of Field Sampling Activities*.
- 5.4.3. If the borehole has been drilled to a depth greater than that at which the well is to be set, the borehole must be backfilled with bentonite pellets, bentonite chips, or a cement-bentonite grout slurry to a depth of approximately one foot below the intended well depth. A grout pump may be needed to prevent voids in the grout or dilution of the grout. Approximately one foot of clean sand must be placed on top of the backfill to return the borehole to the proper depth for the well installation.

## 5.5. Installation of Well Screen and Casing

The appropriate lengths of well screen (with bottom cap, or plug, or well point) and casing must be joined watertight and carefully lowered inside the drill stem to the bottom of the borehole. If centering guides are used, they must be placed at intervals around the well casing, beginning no lower than 5 feet above the top of the screen.

## 5.6. Design and Installation of the Filter Pack

After the well screen and casing are installed in the borehole, the filter pack shall be installed. For monitoring wells in unconsolidated materials, the selection of the appropriate filter pack material shall be based upon project specific parameters and any state or local guidance, or applicable regulatory requirements.

A filter pack of clean silica sand will be placed around the well screen. Place the filter pack into the borehole at a uniform rate in a manner that will allow even placement of the sand. The drill stem shall be raised slowly while the sand is being placed to avoid caving of the borehole walls; the drill stem shall never be raised above the top of the filter pack during installation. Using a weighted tape (stainless steel weight on the end of a measuring tape), continuously sound the top of the filter pack as it is being installed. The filter pack shall extend from a depth of approximately one foot below the screened interval to a minimum height of one

to two feet above the top of the well screen. However, this length may be adjusted if it would create the potential for cross-contamination or in the case of shallow water tables.

A finer-grained sand cap shall be installed for a minimum of one foot above the filter pack. This height may also be adjusted in the case of shallow water tables.

#### 5.7. Geoprobe® Prepacked Screen Monitoring Well Installation

The installation of prepacked screen monitoring wells in general follows the following four steps (Figure 2):

##### 5.7.1. Anchoring the Well Assembly at Depth

In the first step, an expendable anchor point is driven to the desired depth on the end of a 2.25 inch outside diameter probe rod string. A prepacked screen assembly is inserted into the inside diameter of the rod string with 5-foot sections of PVC riser. The screens and riser pipe are attached to the anchor point via a snap-lock connector. If the monitoring well is to have a flush-mount finish, it is suggested to prepare a large enough hole to accept a standard well protector before driving the probe rods.

##### 5.7.2. Providing a Sand Pack and Grout Barrier

The natural formation will sometimes collapse around the well screens as the probe rod string is withdrawn. This is frequently encountered in sandy formations below the water table. This provides an effective barrier between the screens and grout material used to seal the well annulus. If the formation does not collapse, a sand barrier must be placed from the surface while retracting the well casing. This procedure needs to be followed carefully to prevent the grout from reaching the well screens, potentially giving rise to non-representative samples.

Using a flat tape measure, determine the depth from the top of the PVC riser to the bottom of the annulus between the riser and probe rods. If unstable conditions have resulted in formation collapse (measured depth of 2 to 3 feet), then proceed to 5.7.4. If the borehole has not collapsed, then retract the casing to 1 foot above the screen while adding sand. Take measurements with a weighted tape. Continue until 2 feet of sandpack have been established above the well screen.

#### 5.7.3. Installation of Impermeable Seal

An impermeable seal at least two feet thick must be placed on top of the fine sand cap. The seal may be composed of either bentonite pellets or bentonite slurry. The thickness of the bentonite seal may be adjusted for wells completed in aquifers with shallow water tables. The pellets must be placed into the borehole in a slow and continuous manner that prevents bridging. This is especially important in deeper monitoring wells where the pellets may have to be emplaced through a considerable depth of standing water in the borehole.

The bentonite slurry shall be prepared by mixing approximately 2 pounds of bentonite per one gallon of water. The slurry shall be emplaced in the borehole via a tremie pipe. The tremie pipe must be plugged on the bottom and have openings along the sides of the bottom one foot of pipe. This will allow the slurry to be emplaced into the borehole without disturbing the fine sand cap. This procedure is especially important for the relatively deeper wells.

Verify the position of the top of the bentonite seal using a weighted tape measure. If all or a portion of the bentonite seal must be emplaced above the water table, hydrate the bentonite with clean water. Allow 30 minutes after adding the water for the bentonite to hydrate.

#### 5.7.4. Installation of Grout Backfill

Place an annular seal of cement-bentonite grout above the bentonite seal. Install the cement-bentonite grout continuously from the bottom of the annular space to the ground surface through a tremie pipe. The tremie pipe must be plugged on the bottom and have openings along the sides of the bottom one-foot length of pipe. This will allow the grout to be emplaced into the borehole without disturbing the bentonite seal. Alternatively, a bentonite slurry can be used.

#### 5.8. Surface Completion

All monitoring wells will be finished at the surface with a concrete pad (Figure 1). The concrete pad shall typically be two-feet square and at least four inches thick. The concrete shall fill the borehole to a depth below the frost line. The pad shall be constructed in one continuous pour of concrete. Note that some of the cement-bentonite grout used for the annular seal may have to be removed to install the

concrete pad. A survey pin may be installed in the concrete pad before it dries, if necessary.

For monitoring wells that will be completed above-grade, a locking steel protective casing shall be installed in the concrete. The protective casing shall extend at least three feet into the ground and two feet above ground. For monitoring wells that will be completed flush, a steel roadbox, suitable for traffic loads, with a gasketed cover shall be installed.

All monitoring wells shall be locked upon completion of installation.

#### 5.9. Nomenclature

The well identification guidance will be provided in the Work Plan. The following standard naming guild lines:

- “R” will only be added to the end of a well identification if the well is a replacement for a destroyed or abandoned well. An example, MW-07R is a replacement of destroyed well MW-07.
- “A, B, C” will be added to the end of a well identification if the well is the result of an offset of a pilot borehole or a location that is revisited. The A, B, C notation can only be used for borings or wells that are within 5 feet of the original location. The offset distance and direction must be documented in the field notes. An example, the borehole for MW-07 could not be completed (due to refusal or other issues), MW-07A is the second attempt to complete MW-07.

#### 5.10. Well Protection Bollards (optional)

Guard posts may be installed in high-traffic areas for additional protection. One to four guard posts would be installed around the protective casing, within the edges of the concrete pad. If used, guard posts will consist of concrete-filled steel tubes, at least 3 inches in diameter, painted with multiple coats of epoxy-based paint to prevent rust. The guard posts would extend at least two feet below ground and approximately three feet above ground.

#### 5.11. Waste Management

Investigation derived wastes (IDW), including soil cuttings, decontamination liquids, and disposable materials (PPE, plastic sheeting, etc.) will be placed in

clearly labeled, appropriate containers in accordance with SOP 10059 *Management of Investigation Derived Waste*, or managed as otherwise specified in the site-specific Work Plan or FSP.

#### 5.12. Documentation

Documentation of field activities will be completed in accordance with SOP 10038 *Documentation of Field Sampling Activities*. In addition, record all appropriate information concerning the quantity of materials used, the type and manufacturer of the materials, the mixtures of grouts or slurries, and any pertinent notes regarding the installation of each well on the Supplemental Daily Field Report Form. A complete geologic log shall be kept during advancement of the borehole for the well and the procedures for completing geologic logs are presented in SOP ID 10015 *Standard Operating Procedure for Geologic Logging of Unconsolidated Sedimentary Materials*. Well construction details shall be recorded on the monitoring well completion form is provided in Attachment 1.

## 6. References

EPA. *RCRA Groundwater Monitoring Technical Enforcement Guidance Document, OSWER 9950.1*. September 1986.

EPA. *Handbook of Suggested Practices for the Design and Installation of Groundwater Monitoring Wells, 160014-891034*. March 1991.


Geoprobe®. *Geoprobe® 0.5-in x 1.4 in OD and 0.75 in x 1.4 in OD Prepacked Screen Monitoring Wells, Standard Operating Procedure, Technical Bulletin No. 962000*. September 1996, revised; June 2002.

ASTM. *ASTM standard D5092, Design and Installation of Groundwater Monitoring Wells in Aquifers*. ASTM International, 2017.

END OF DOCUMENT

## FIGURES

**ATTACHMENT 1: Well Construction Details**



FLUSH TO GRADE WELLHEAD  
CONSTRUCTION DETAIL - NOT TO SCALE

REFERENCES:

EPA, "RCRA GROUNDWATER MONITORING TECHNICAL ENFORCEMENT GUIDANCE DOCUMENT", OSWER 9950.1, SEPTEMBER 1986.

EPA, "HANDBOOK OF SUGGESTED PRACTICES FOR THE DESIGN AND INSTALLATION OF GROUNDWATER MONITORING WELLS", EPA/600/4-89/034, 1989.



Loureiro Engineering Associates, Inc.  
100 Northwest Drive • Plainville, Connecticut 06062  
Phone: 860-747-6181 • Fax: 860-747-8822  
An Employee Owned Company • www.Loureiro.com

©Loureiro Engineering Associates, Inc.  
All rights reserved 2018

LEA SOP FOR INSTALLING & DEVELOPING  
MONITORING WELLS & PIEZOMETERS

FLUSH MOUNT WELLHEAD DETAILS

PREPARED FOR:

SCALE

NTS

COMM. NO.


00001.01

DATE

02/22/2018

FIGURE 1





ABOVE GRADE WELLHEAD  
CONSTRUCTION DETAIL - NOT TO SCALE

REFERENCES:

EPA, "RCRA GROUNDWATER MONITORING TECHNICAL ENFORCEMENT GUIDANCE DOCUMENT", OSWER 9950.1, SEPTEMBER 1986.

EPA, "HANDBOOK OF SUGGESTED PRACTICES FOR THE DESIGN AND INSTALLATION OF GROUNDWATER MONITORING WELLS", EPA/600/4-89/034, 1989.



Loureiro Engineering Associates, Inc.  
100 Northwest Drive • Plainville, Connecticut 06062  
Phone: 860-747-6181 • Fax: 860-747-8822  
An Employee Owned Company • www.Loureiro.com

©Loureiro Engineering Associates, Inc.  
All rights reserved 2018

LEA SOP FOR INSTALLING & DEVELOPING  
MONITORING WELLS & PIEZOMETERS

STICK-UP WELLHEAD DETAIL

PREPARED FOR:

SCALE

NTS


COMM. NO.

00001.01

DATE

02/22/2018

FIGURE 2



ADAPTED FROM "GEOPROBE ® SYSTEMS –  
THE COMPLETE PROBING SYSTEM",  
TECHNICAL BULLETIN 99250, AUG. 1999,  
REVISED DEC. 2002.



Loureiro Engineering Associates, Inc.  
100 Northwest Drive • Plainville, Connecticut 06062  
Phone: 860-747-6181 • Fax: 860-747-8822  
An Employee Owned Company • www.Loureiro.com

©Loureiro Engineering Associates, Inc.  
All rights reserved 2017

LEA SOP FOT INSTALLING & DEVELOPING  
MONITORING WELLS & PIEZOMETERS

COMPLETED PRE-PACKED SCREEN WELL

PREPARED FOR:

SCALE

NTS

COMM. NO.

00001.01

DATE

02/22/2018

FIGURE 3

# WELL COMPLETION REPORT

<b>Project:</b> <b>LEA Comm. No.</b> _____ <b>Client</b> _____ <b>Location</b> _____		<b>Start Date</b> _____ <b>End Date</b> _____ <b>Well ID</b> _____	
<b>Drilling Contractor</b> _____ <b>Drilling Method</b> _____ <b>Sampling Method</b> _____ <b>Groundwater Observation</b> _____ <b>Depth</b> _____ <b>at</b> _____ <b>Hours</b> _____		<b>Logged by</b> _____ <b>Drilling Foreman</b> _____ <b>Drill Rig</b> _____ <b>GPS Latitude</b> _____ <b>GPS Longitude</b> _____	

<b>Protector</b> Material _____ Diameter _____ Length _____ <b>Ground</b> _____ Stickup _____ Key # _____ Cover Type _____		Concrete Diameter _____ Concrete Thickness _____  <b>Reference</b> Stickup _____ Description _____  <b>Casing</b> Diameter _____ Material _____ Length _____ Stickup _____  <b>Seal</b> Top _____ Bottom _____ Material _____  <b>Screen</b> Top _____ Bottom _____ Material _____ Diameter _____ Length _____ Slot Size _____  <b>Miscellaneous Materials (Quantity Used/Item)</b> Cement _____ Bentonite Chips _____ Bentonite Pellets _____ Bentonite Powder _____ Grout Weight _____ Filter Pack Sand _____ Capping Sand _____ Well Point _____ Well Plug _____
<b>Top Seal</b> Top _____ Bottom _____ Material _____  <b>Backfill</b> Top _____ Bottom _____ Material _____  <b>Secondary Sand</b> Top _____ Bottom _____ Size _____  <b>Filter Pack</b> Top _____ Bottom _____ Material _____		

Reported depth to bottom of boring _____  Comments _____	
--	--

**Loureiro Engineering Associates, Inc.  
Standard Operating Procedure  
for  
Development of Non-Water Supply Wells  
and  
Piezometers in Unconsolidated Deposits**

**SOP ID: 10007B  
Date Initiated: 02/20/90  
Revision No. 008: 07/18/18**

**Revised By: /s/ *Jeremy Marcantonio* 2/20/18  
Jeremy Marcantonio Date  
Senior Project Scientist**

**Reviewed By: /s/ *Jo Ann Robertson* 7/18/18  
Jo Ann Robertson Date  
Technical Associate**

**Approved By: /s/ *Karen Harris* 7/18/18  
Karen Harris Date  
Quality Assurance Manager**

## REVISION RECORD

---

<u>Rev #</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	02/20/90	
001-004	-	No record.
005	12/31/01	Formatting and minor revisions throughout.
006	08/12/02	Added section on utility clearance.
007	11/01/12	Reference was provided to the company's updated Groundbreaking Procedure, (dated December 6, 2011). The requirement for a site-specific HASP and JHA. It was also noted that surging and pumping at the same time may not be as effective as surging and then pumping. Table 1 was incorporated describing and assessing well development equipment. Finally, Figures 1 and 2 were revised to reflect current practices for monitoring well installation.
008	07/18/18	Revisions throughout. Update to reflect new SOP format. Checked against up-to-date standards. Divided installation and development into two separate SOPs: SOP 10007A <i>Installation of Non-Water Supply Wells and Piezometers in Unconsolidated Deposits</i> and SOP 10007B <i>Development of Non-Water Supply Wells and Piezometers in Unconsolidated Deposits</i> . Sampling methodologies were updated.

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Development of Non-Water Supply Wells**  
**and**  
**Piezometers in Unconsolidated Deposits**

**1. Purpose and Scope**

Monitoring well development may be accomplished by surging and bailing (or pumping), or over pumping. Other methods, such as air jetting, backwashing, or air-lift pumping, shall be avoided because these methods introduce fluids into the formation and may have unexpected influences on groundwater quality, if only for a short period of time. This standard operating procedure (SOP) is designed to describe the proper methods and procedures to be used to develop wells and piezometers using surging and bailing or over pumping. Applicable to wells screened in water-table aquifers and unconsolidated deposits. Throughout this SOP reference to wells is also intended to mean piezometers unless specifically indicated otherwise.

Monitoring wells will not be developed within 24 hours of installation unless specified stated otherwise in the project specific work plan (Work Plan) or Field Sampling Plan.

**2. Related Standard Operating Procedures**

- 10038 – Documentation and Integrity of Field Sampling Activities
- 10059 – Management of Investigation Derived Waste
- 10065 – Decontamination of Field Sampling Equipment

In addition to the above-noted SOPs, project and client-specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the project-specific plan for adherence during the execution of the project.

**3. Definitions**

None.

**4. Equipment**

The following equipment shall be used during development of non-water supply well and piezometer, as required:

- Health and safety equipment (as required by the site-specific Health and Safety Plan [HASP])
- Well Construction record
- Surge block and extensions
- Peristaltic, Whale, or Waterra pumps with matching tubing
- YSI or other meters for monitoring pH, temperature, and specific conductivity
- Turbidity meter
- Photoionizing Detector (PID) and calibration kit
- Electronic water level indicator and interface probe (accurate to 0.01 foot)
- 5-gallon bucket
- Graduated measuring cup
- Bailer
- Polyethylene plastic sheeting
- Traffic cones or barriers
- 55-gallon drum(s) and drum label(s)
- Hand tools or keys to access well
- Field documentation forms or field book
- Indelible pen
- Camera/tablet

## 5. Procedures

### 5.1. Site Preparation

- 5.1.1. Review and follow the health and safety procedures or requirements specified in the site-specific HASP. All personal protective equipment (PPE) shall be donned as specified in the site-specific HASP.
- 5.1.2. A sufficient area shall be cordoned off using traffic cones, caution tape, or barriers to restrict access to the work area.
- 5.1.3. Place plastic sheeting on ground surface around the well.
- 5.1.4. Do a visual inspection around the well and note any subsidence or raised ground around the well. Use keys or hand tools to open well.

### 5.2. Equipment Decontamination and Cleaning

All equipment will be decontaminated prior to starting and in between well development in accordance with SOP 10065 *Decontamination of Field Sampling Equipment* or as otherwise specified in the project-specific plan.

### 5.3. Well Development

Monitoring well development may be accomplished by surging and bailing (or pumping), or over pumping. Other methods, such as air jetting, backwashing, or air-lift pumping, shall be avoided because these methods introduce fluids into the formation and may have unexpected influences on groundwater quality, if only for a short period of time.

- 5.3.1. Immediately upon opening the well, the air in the wellhead will be screened for VOCs using a PID. The well cap shall be opened slightly and the sampling port of the PID shall be inserted into the well. The maximum reading shall be recorded on the appropriate field paperwork. The instrument shall be zeroed with ambient air prior to the measurement, and the initial and final readings shall be recorded for each well.
- 5.3.2. Establish a measuring point on the inner casing of well and mark with an indelible pen.
- 5.3.3. Collect measurements of depth to water surface and depth to bottom of well from the measuring point. Record the height of the stick up outer casing (if applicable). Use an interface probe to screen for non-aqueous phase liquids (NAPL) at the top and bottom of the well. If NAPL is identified, use bailer to collect a sample for visual description. If NAPL is observed, the project team leader shall be notified before proceeding with well development.
- 5.3.4. Calculate the volume of water using the following schedule and record on the appropriate field form:

Well Diameter (inches)	Conversion Factor (gallons/foot)
½	0.01
1	0.041
1 ¼	0.064
1 ½	0.091
2	0.163
4	0.654
6	1.47



#### 5.4. Surging and Purging

In surging and purging, a well is developed by alternately surging a short section of the screen with a tight-fitting surge block and removing water from the well. Begin by lowering the surge block to the top of the screened interval and swab the well with a pumping action with a up and down stroke of 2 to 3 feet. (Begin surging at the top of the well intake to avoid having loosened material from "sand-locking" the surge block.) Do not surge the well too violently to avoid damaging the well screen or the filter pack. Remove the surge block at regular intervals and bail (or pump) the fine material from the well. Proceed with surging throughout the length of the well screen, being careful to avoid hitting the bottom of the well. Check the purge water quality using a water gage at regular intervals, as described in Section 5.6. Containerize the purge water as specified in the Work Plan.

In cases where a considerable volume of sediment may initially be drawn into the well, begin surging the well gently in the casing above the well screen. Proceed with surging and bailing to the bottom of the screened interval.

It is recommended to surge and then pump, and then repeat the cycle. However, in certain circumstances surging and pumping at the same time can be equally effective and is therefore acceptable. For example, use of an inertial pump is suitable for this process. On the other hand, in small diameter wells, a thinner diameter well casing can be used inside the larger diameter well to surge it, while at the same time the pump tubing is inserted through the inner well casing to allow pumping and removal of the grit at the same time. This technique is suitable in surging small diameter monitoring wells, however the effectiveness of surging would need to be verified by purging the well to evaluate the quality of the purged water.

If the well is screened in a low yielding formation, limit purging of the well.

Table 1 summarizes well development equipment and lists the associated advantages and disadvantages of each. The equipment is listed in the table in order of preference. However, the decision for which equipment to use is influenced by the advantages and limitations of each technique and determined by the Project Manager.

#### 5.5. Overpumping

In overpumping, a well is developed by operating a pump in the well at a capacity which exceeds the formation's ability to supply water. The flow velocity into the well during overpumping usually exceeds the flow velocity induced during normal

sampling. This increased velocity causes movement of particles from the formation into the well.

Begin developing the well by installing a suitable pump at the bottom of the well. Alternatively, a surface-mounted pump with a suction hose may be used if the drawdown inside the well will not exceed the pump's available lift. The discharge from the pump shall be directed to approved containers. The pump (or intake hose) must be equipped with a backflow-prevention valve to prevent introducing aerated water into the aquifer.

Start the pump and discharge water at the highest practical rate. If the well runs dry, stop the pump and allow the well to recharge. Check the quality of the discharged water at regular intervals as described in the section "Completing Well Development".

## 5.6. Completing Well Development

During bailing or pumping, measure and record water quality parameters to gauge the degree and effectiveness of development. Field parameters including pH, temperature, specific conductivity, and turbidity shall be checked at periodic intervals (but at least every well-volume) until field parameters are stable and the purge water is clear or as specified in the project plan. The water quality parameters may be considered stable when:

- pH, temperature, and specific conductivity of consecutive measurements have relative percent differences (RPD), as defined below, of less than 10%; and
- The turbidity is 5 NTU or less (applicable only in aquifers with low percentages of fines). This may not be achievable in all situations, but the turbidity shall be less than 50 NTU and shall stabilize with an RPD of less than 10%).

However, in no case shall the development stop before the above criteria are met, and:

- At least 3 well volumes have been removed; or
- The well has been surged and pumped for at least 30 minutes

The RPD between two measurements (e.g., M1 and M2) is calculated as follows:

$$RPD = \frac{|M1 - M2|}{(M1 + M2)/2} \times 100\%$$

If the well goes dry during development, development will resume when the well has recharged to 80% of the pre-development volume.

#### 5.7. Waste Management

Investigation derived wastes (IDW), including pumping discharge decontamination liquids, and disposable materials (PPE, plastic sheeting, etc.) will be placed in clearly labeled, appropriate containers in accordance with SOP 10059 *Management of Investigation Derived Waste*, or managed as otherwise specified in the site-specific project plan.

### 6. Documentation

Documentation of field activities will be completed in accordance with SOP 10038 *Documentation and Integrity of Field Sampling Activities*. In addition, well development activities will be documented on the *Field Data Record Well Development Report* form.

### 7. References

RCRA. *Groundwater Monitoring Technical Enforcement Guidance Document*, OSWER 9950.1, EPA, September 1986.

ASTM. *Standard D5092, Design and Installation of Groundwater Monitoring Wells in Aquifers*, ASTM International, 2017.

END OF DOCUMENT

**Table**

TABLE 1

## WELL DEVELOPMENT EQUIPMENT

Well Development Equipment	Order of Preference	Limitations	Use Scenarios
Waterra <sup>®</sup> Pump	This is the preferred method; but if not practical use methods below in the order listed.	<ul style="list-style-type: none"> <li>Well diameter must be 1” or greater. Check valves or surge blocks may need to be modified to fit into a well smaller than 2” in diameter.</li> <li>High amounts of silt/sand may clog check valve.</li> <li>Weight of equipment (generator, stabilizing weights for flush mount well applications).</li> <li>Runs on 110V, so either a power supply or a generator is required close to the well.</li> </ul>	<p>Shall be used for all well development, since the flow rate and mechanical action stresses the formation and the sand pack.</p> <p>Shall <b>not</b> be used in wells where there is a significant amount of silt/sand which may clog the check valve.</p>
Blue Mamba <sup>®</sup> Submersible Pump	Preferred if Waterra <sup>®</sup> is not used; if well casing is not of sufficient diameter, use method below.	<ul style="list-style-type: none"> <li>Well diameter must be 1.5” or greater</li> <li>Operates off a vehicle battery, which can lose power over the course of the day, so a backup power source must be provided.</li> </ul>	This pump can be used in a highly turbid well and must be used in combination with surge rods and a surge block.
Peristaltic Pump	Preferred if diameter of well is smaller than the outside diameter of a Waterra <sup>®</sup> check valve or a submersible pump.	<ul style="list-style-type: none"> <li>Flow rates sometimes do not stress the formation and the sand pack, even when flow rates used are at the high end of pump capability (which are the recommended rates for well development).</li> <li>Water level must be within 30’ of ground surface.</li> </ul>	<p>Shall be used along with surge rods and surge block to pump and surge at the same time.</p> <p>Shall not be used in wells where a submersible pump will work.</p>
Bailers	Not preferred for development without the use of a pump, but may be used to surge and remove high accumulations of silt from wells, allowing for the use of other development equipment described above.	<ul style="list-style-type: none"> <li>Slow process.</li> <li>Physically demanding.</li> <li>Cannot provide steady flow rates for purging.</li> <li>Need to use stainless steel bailers for weight.</li> <li>Well diameters of 1” in diameter or less.</li> </ul>	Can be used for the surge portion of well development, unless no pump is suitable.



## LEA Comm. No.

Project

Location

Client

Page \_\_\_\_ of \_\_\_\_

Date \_\_\_\_/\_\_\_\_/\_\_\_\_

Time \_\_\_\_:\_\_\_\_

Monitoring Well Number \_\_\_\_\_ Sample Number(s) \_\_\_\_\_

## Depth of Well \_\_\_\_\_

Reference Used \_\_\_\_\_

Depth to Water \_\_\_\_\_

PID/FID Reading \_\_\_\_\_

Height of Column\_\_\_\_\_

Interface      Yes / No      If yes, Depth \_\_\_\_\_ Lighter / Heavier

Well Casing Diameter

Material \_\_\_\_\_

### General Condition

OK      Bad

Protector	Road Box / Stickup
-----------	--------------------

Casing Secure

Ground to Reference \_\_\_\_\_

Collar Intact

Comments \_\_\_\_\_

Cover Locked

Other (describe)

### Purge Volume Factors

$0.5'' - 0.01$

 $1'' - 0.041$ 

*1.5'' - 0.091*

 $2'' - 0.16$ 

4" - 0.65

6'' - 1.5

## Initial Sample Observations

Clear

Colored

## Cloudy

Turbid

Odor

Sheen

[illegible]

Development Method	Peristaltic Pump / Bailer / Inertial Pump / Other

Field Decontamination?	Yes / No	If Yes, with what?
------------------------	----------	--------------------

Waste Container ID

### Additional Comments

Field Personnel		
-----------------	--	--

*Signature*

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Direct Push Probing and**  
**Sample Tooling Advancement**

**SOP ID: 10011**  
**Date Initiated: 11/10/94**  
**Revision No. 009: 09/07/18**

<b>Revised By:</b>	<u><i>/s/ David C. Brisson</i></u>	<u><i>04/04/18</i></u>
	<b>David C. Brisson</b>	<b>Date</b>
	<b>Senior Project Manager</b>	

<b>Reviewed By:</b>	<u><i>/s/ Jo Ann Robertson</i></u>	<u><i>09/07/18</i></u>
	<b>Jo Ann Robertson</b>	<b>Date</b>
	<b>Technical Associate</b>	

<b>Approved By:</b>	<u><i>/s/ Karen Harris</i></u>	<u><i>09/07/18</i></u>
	<b>Karen Harris</b>	<b>Date</b>
	<b>Quality Assurance Manager</b>	

## REVISION RECORD

---

<u>Rev #</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	11/10/94	
001-002	-	No record.
003	06/17/97	No record.
004	07/19/00	Revisions to template, including new logo. Revisions to Sections 3, 4, 5 and 6 in order to generalize sampling procedures and reference Geoprobe® Systems' catalog and specific soil sampling standard operating procedures.
005	12/31/01	Revisions made to reflect new SOP format. Addition of QA/QC section, minor changes throughout.
006	02/11/08	Added Appendix A: Macro-Core Soil Sampling; Revisions to Section 4.13.
007	08/23/10	Added supplemental information regarding grout mixture preparation in the section on "Boring Abandonment."
008	07/13/18	Removed sections of text regarding: tooling, health and safety, decontamination. Added technical bulletin for MC5 sampler.
009	09/07/18	Added nomenclature section.

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Direct Push Probing and Sampling Tooling Advancement**

## **1. Purpose and Scope**

The objective of this standard operating procedure (SOP) is to collect discrete soil samples at depth using Geoprobe<sup>®</sup> or other direct push probing and sampling methodologies and to recover the samples for visual inspection and/or analysis. Procedures for soil sampling for analysis are included in SOP 10006 *Soil Sampling*. Throughout this SOP, references to Geoprobe<sup>®</sup> are also intended to include other direct push technologies unless specifically stated otherwise.

## **2. Related Standard Operating Procedures**

- 10005 – Quality Assurance/Quality Control Measures for Field Sampling Activities
- 10006 – Soil Sampling
- 10015 – Geologic Logging of Unconsolidated Sedimentary Deposits
- 10038 – Documentation and Integrity of Field Sampling Activities
- 10059 – Management of Investigation-Derived Waste
- 10065 – Decontamination of Field Sampling Equipment

In addition to the above-noted SOPs, project and client-specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the project-specific work plan or Field Sampling Plan (WP/FSP) for adherence during the execution of the project.

## **3. Definitions**

Geoprobe<sup>®</sup><sup>1</sup>: or similar direct push technology: A vehicle-mounted, hydraulically-powered, soil probing machine that utilizes static force and percussion to advance small diameter sampling tools into the subsurface for collecting soil core, soil gas, or groundwater samples.

- **Sampler:** A piston type soil sampler capable of recovering a discrete sample in the form of a core contained inside a removable liner.
- **Liner:** A removable/replaceable, thin-walled tube inserted inside the sampler body for the purpose of containing and storing soil samples. Clear plastic (either Polyethylene Terephthalate Glycol [PETG] or cellulose acetate butyrate) are utilized as liner materials.

---

<sup>1</sup> Geoprobe<sup>®</sup> is a registered trademark of Kejr Engineering, Inc., Salina, Kansas.



#### 4. Equipment

The equipment required to recover soil core samples using the Geoprobe® samplers and driving system can be found in the Geoprobe® Systems catalog for tools and equipment, as referenced in Section 6. Some things to note when selecting equipment:

- Health and safety equipment (as required by the site-specific Health and Safety Plan [HASP])
- Geoprobe® or similar direct push technology
- Sample liners for the Geoprobe® samplers are available in four different materials. Liner materials should be selected based on sampling purpose, analytical parameters, and data quality objectives
- Traffic cones, caution tape, or barrier

#### 5. Procedure

##### 5.1. Utilities Clearance

Underground utilities clearance will be conducted in accordance with the LEA ground breaking procedure.

##### 5.2. Site Preparation

5.2.1. Review and follow the health and safety procedures or requirements specified in the site-specific HASP. All necessary personal protective equipment (PPE) shall be donned as specified in the site-specific HASP.

5.2.2. A sufficient area shall be cordoned off using traffic cones, caution tape or barriers to restrict access to the work area.

##### 5.3. Equipment Decontamination and Cleaning

5.3.1. All downhole drilling equipment will be decontaminated in accordance with SOP 10065 *Decontamination of Sampling Equipment*. Prior to conducting a boring, the LEA representative will ensure that all necessary equipment is clean and decontaminated, including the rig, all augers and probing equipment, samplers, brushes, and any other tools or equipment. Decontamination procedures may vary slightly from site to site. Refer to the site-specific WP/FSP for decontamination procedure alterations.

#### 5.4. General Sampler Assembly

- 5.4.1. The sampler is connected to the leading end of a Geoprobe<sup>®</sup> probe rod and driven into the subsurface using a Geoprobe<sup>®</sup> drilling apparatus. Additional probe rods are connected in succession to advance the sampler to depth. The sampler remains sealed (closed) by a piston tip to prevent cross contamination from above as it is being driven. The piston is held in place by internal rods. The first four-foot interval does not require the piston tip assembly. In addition, if the borehole remains open, the piston tip assembly may not be required for deeper intervals. If there is evidence that the borehole is collapsing, the piston tip will be utilized.
- 5.4.2. When the sampler tip has reached the top of the desired sampling interval, the internal rods are removed.
- 5.4.3. After the internal rods have been removed, the tool string is advanced an additional 24 to 48 inches (depending on the soil sampling system in use). The piston is displaced inside the sampler body by the soil as the sample is cut. To recover the sample, the sampler is recovered from the hole and the liner containing the soil sample is removed.
- 5.4.4. Refer to the Geoprobe<sup>®</sup> System standard operating procedures for operation of various soil sampling systems (e.g., MC5 Soil Sampling System, Macro Core Piston Rod Soil Sampling System, DT21 Dual Tube Soil Sampling System, Large Bore Soil Sampling System).

#### 5.5. Concrete Coring

Should the borehole be located on concrete, the Geoprobe<sup>®</sup> can be used to core through the concrete to gain access to the underlying soil. A carbide-tipped drill bit and Geoprobe<sup>®</sup> drill steel will be attached to the drill assembly and utilized to core the concrete. For concrete in excess of 16 inches, other methods (i.e., a core saw) should be utilized to penetrate the concrete.

- 5.5.1. If excessive resistance is encountered while attempting to lift the sampler and probe rod out of the hole using the foot control, unscrew the drive head from the sampler and remove it with the probe rod, the piston rod, and the piston tip. Replace the drive head onto the sampler and attach a pull cap to it. Lower the probe shell and close the hammer latch over the pull cap and pull the sampler the remaining distance out of the hole with the probe machine foot firmly on the ground.

#### 5.6. Sample Recovery

Unscrew the cutting shoe using the cutting shoe wrench, if necessary. Pull the cutting shoe out with the liner attached. If the liner doesn't slide out readily with the cutting shoe, take off the drive head and push down on the sidewall of the liner. The liner and sample should slide out easily.

#### 5.7. Core Liner Capping

The ends of the liners can be capped off using the vinyl end cap for further storage or transportation. A black end cap should be used at the bottom (down end) of the sample core and a red end cap at the top (up end) of the core. The soil boring identifier and depth of sample should be marked at the top of the core (on the red end cap).

#### 5.8. Sample Removal

5.8.1. To facilitate sample removal, each vinyl end cap can be slid off or, if there is resistance, they can be slit using a utility knife with a carpet blade. To cut vinyl end cap, slide blade under edge of cap at shallow angle and rotate the blade until cutting edge begins to cut the vinyl cap, and then draw the knife slowly toward the end of the cap. As the friction is reduced the end cap may move with the knife and become free of the sample liner.

5.8.2. Clear plastic and Teflon<sup>®</sup> liners can be slit open easily with a utility knife for the samples to be analyzed or placed in appropriate containers.

5.8.3. The procedures for collection of soil samples for chemical analysis are described in SOP 10006 *Soil Sampling*.

#### 5.9. Refusal

Refusal is defined as failure to penetrate the subsurface materials to any greater depth using the maximum reasonable pressure limits of the Geoprobe<sup>®</sup> machine. The term "refusal" should be used on the boring log to describe the conditions at the interval in which the tooling would no longer advance.

The term "bedrock" will not be used in a boring log or other description of subsurface materials that have been collected using the Geoprobe<sup>®</sup> machine, since a confirmatory core cannot be collected.

#### 5.10. Boring Abandonment

- 5.10.1. If the boring is not to be used for other purposes (i.e., monitoring well, soil vapor probe, soil vapor extraction well, etc.) it shall be abandoned.
- 5.10.2. Excess cuttings shall be containerized, labeled and the analytical data of the contents reviewed/profiled before disposal.
- 5.10.3. The boring shall be filled and sealed with in accordance with the site-specific WP/FSP.
- 5.10.4. In paved areas, the upper three feet of the borehole shall be filled, from 3 feet below ground surface up to two inches below the existing grade with sand, to allow for repairing of the pavement.
- 5.10.5. The surface shall be repaired to match existing conditions.

#### 5.11. Nomenclature

The boring identification guidance will be provided in the WP/FSP. The following is guidance for identify offsets or step out borings.

- “A, B, C” will be added to the end of a boring identification if the boring is the result of an offset from a pilot borehole or a location that is revisited. The A, B, C notation will only by used for borings that are within 5 ft of the original location. The offset distance and direction must be documented in the field notes. An example, the borehole for SB-07 could not be completed (due to refusal or other issues), SB-07A is the second attempt to complete SB-07. Borings greater than 5 feet from the original location will be assigned a new boring ID.

#### 5.12. Waste Management

Investigation-derived wastes (IDW), including soil cuttings, decontamination liquids, and disposable materials (PPE, plastic sheeting, etc.), will be placed in clearly labeled, appropriate containers in accordance with SOP 10059 *Management of Investigation Derived Waste*, or managed as otherwise specified in the site-specific WP/FSP.

#### 5.13. Documentation

Documentation of field activities will be completed in accordance with SOP 10038 *Documentation of Field Sampling Activities*.

## 6. References

Geoprobe® Systems. *1998-1999, 2017 Tools and Equipment Catalog*. 1997.

Geoprobe® Systems. *Geoprobe® DT22 Dual Tube Soil Sampling System, Continuous Core Soil Sampler Standard Operating Procedure*, Technical Bulletin No. 982100. 9/98 revised 01/2013.

Geoprobe® Systems. *Geoprobe® Large Bore Soil Sampler, Discrete Interval Soil Sampler Standard Operating Procedure*, Technical Bulletin No. 93-660. Prepared 09/96, revised 04/98, 01/2011.

Geoprobe® Systems. *Geoprobe® Macro Core MC5 1.25 inch Light-Weight Center Rod Soil Sampling System, Standard Operating Procedure*, Technical Bulletin No. MK3139. 2011.

END OF DOCUMENT

**Loureiro Engineering Associates, Inc.  
Standard Operating Procedure  
for  
Geologic Logging  
of  
Unconsolidated Sedimentary Materials**

**SOP ID: 10015  
Date Initiated: 12/27/94  
Revision No. 004: 09/12/18**

**Revised By: /s/ Sarah Burkhalter-Sweeney 09/10/18**  
**Sarah Burkhalter-Sweeney** **Date**  
**Senior Project Scientist**

**Reviewed By: /s/ Jo Ann Robertson 09/10/18**  
**Jo Ann Robertson** **Date**  
**Technical Associate**

**Approved By: /s/ Karen Harris 09/12/18**  
**Karen Harris** **Date**  
**Quality Assurance Manager**

## REVISION RECORD

---

<u>Rev #</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	12/27/94	
001	11/20/96	No record.
002	01/15/02	Formatting and minor revisions throughout.
003	07/17/18	Updating, formatting, and minor revisions throughout.
004	09/12/18	Revised Section 5.1 to include photographing soil samples and attached boring log form

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Geologic Logging of Unconsolidated Sedimentary Materials**

**1. Purpose and Scope**

This document presents the methods and procedures used to describe unconsolidated sedimentary materials for geological purposes in a uniform and consistent manner. It includes procedures for properly recording the observations by providing guidelines for completing boring logs and submitting those logs for computer entry. This Standard Operating Procedure (SOP) refers only to geologic logging of soils and sediments (including artificial fill and other man-made deposits) and specifically is not intended to describe logging of soils or sediments for geotechnical or other engineering purposes. Although the SOP presents a system for describing sediments, it is not intended to be a definitive reference for classifying sedimentary materials, nor is it intended to replace experience or training. Individuals using this SOP should be trained and competent in field methodologies and geologic logging prior to commencing field activities.

**2. Related Standard Operating Procedures**

- 10003 – Hand Auger Borings
- 10006 – Soil Sampling
- 10008 – Hollow Stem Auger Soil Borings
- 10011 – Direct Push Probing and Sampling Tool Advancement
- 10038 – Documentation and Integrity of Field Sampling Activities
- 10057 – Collecting and Preserving Soil and Sediment Samples for Laboratory Determination of Volatile Organic Compounds
- 10059 – Management of Investigation Derived Waste
- 10065 – Decontamination of Field Sampling Equipment

In addition to the above-noted SOPs, project and client-specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the project-specific work plan (work plan) for adherence during the execution of the project.



### 3. Definitions

Scale: A linear scale, also called a bar scale, scale bar, graphic scale, or graphical scale, is a means of visually showing scale in photograph.

### 4. Equipment

The following equipment and supplies shall be used during geologic logging of soil/sediment samples, as required:

- Tape measure or scale
- Hand lens
- Color chart
- Grain-size comparator
- Field forms
- Clipboard
- Camera (if dictated by project)
- Scale or measuring tape

### 5. Procedures

#### 5.1. Sample Collection

Sampling should occur prior to description of soils or sediments to preserve VOCs (if applicable), but also to prevent cross contamination. VOCs will be sampled in accordance with SOP 10057 *Collecting and Preserving Soil and Sediment Samples for Laboratory Determination of Volatile Organic Compounds* and other samples in accordance with SOP 10006 *Soil Sampling*. Photograph each soil sample with scale. Photography may be restricted based on site-specific requirements and should be reviewed prior to field activities.

#### 5.2. Descriptions of Unconsolidated Sedimentary Materials

##### 5.2.1. General Sediment Description Guidelines

For the purposes of geologically logging unconsolidated soils and sedimentary materials, a Modified Burmister method of description and classification will be used. The Modified Burmister Sediment Classification System (or simply, Burmister System) is intended as a rapid field method for identifying and classifying sediments. The system is based upon visual identification of the generalized grain-size distribution and description of the physical characteristics of the sample.

A Burmister System description is comprised of three parts: a color descriptor; a grain-size descriptor; and modifier(s). The color descriptor indicates the overall color or colors of the wet sample. The descriptor consists of a color name or names and (if possible) the color code from a standard color reference (for example, a Munsell Color Chart). The grain-size description indicates the predominant grain size in the sample, as well as the relative percentages of other grain sizes present.

Modifiers are used to further describe the geologic character of the sample. Modifiers may include descriptions of moisture content, sorting, sphericity, angularity, sedimentary structures, or other pertinent information.

#### 5.2.2. Color Description

The color of the wet sediment should be determined with reference to a standard color comparator (for example, a Munsell Color Chart) for rocks or sediment. The included color descriptor should contain the color name and, when a color comparator is used, the appropriate hue-chroma value code, for example "Reddish brown (5YR 4/4)". The color of a sample should be gauged when the sample is wet, or it should be noted otherwise.

#### 5.2.3. Predominant Grain-Size Description

The first step in describing a sediment sample is visually estimating the size range and percentage of the various grain sizes in the sample. Reference should be made to standard geologic comparators for assessment of the grain size(s).

The primary grain-size descriptor indicates the predominant grain size, as judged visually, of the sample. The descriptor is always capitalized and underlined. Possible descriptors include: CLAY, SILT, SAND, and GRAVEL (GRANULES, PEBBLES, COBBLES, and BOULDERS). These correspond to the standard Wentworth size-classification scheme used for describing sediments for geologic purposes. Size classifications for CLAY through GRAVEL are presented in Figure 1 (COBBLES and BOULDERS as defined in the Wentworth classification scheme, are not depicted and will be defined as necessary in the Work Plans). The descriptor should also include an indication of the relative size range of the sample within the predominant grain size (for example, "fine-to-medium sand", "coarse sand", etc.). Although the Wentworth size classification scheme includes divisions of the silt category, this is applicable only to sediment samples analyzed by pipette or hydrometer and cannot be

distinguished in the field. The processes to perform pipette or hydrometer analysis are not covered in this SOP and, if required, will be provided in the work plan.

The presence of other grain sizes, in addition to the predominant material is also included in the grain-size descriptor. Appropriate grain sizes are the same as for the predominant grain size of the material (clay, silt, etc.), however only the initial letter of the word is capitalized. The description should also include an indication of the relative amount of the minor components. Appropriate indicators for the relative percentages present are provided in Table 1.

It is generally not considered possible to visually distinguish between clay and silt. Estimation of the silt/clay content of a sample should be based upon the plastic properties of the sample. The plastic properties of the sample may be estimated by taking an approximately 1 cubic centimeter ball of the sediment and attempting to roll a thread of the material between the palms of the hand. The minimum size of the thread which may be rolled may be compared to the values presented in Table 2 and the plasticity estimated. A comparison of the minimum thread diameter which may be formed with the information presented in Table 2 provides an approximate silt/clay content estimate for sand-silt-clay sediments and composite clay sediments.

#### 5.2.4. Modifiers

Various modifiers may be added to the basic sediment description to further describe the geologic character of the sample.

For sand or coarser-sized material, the relative degree of sorting, the sphericity, and angularity should also be recorded. Sorting may be visually estimated. Sphericity and angularity, however, should be made with reference to an accepted comparator. A chart illustrating various degrees of sorting, sphericity, and angularity is attached as Figure 1.

The mineralogy of the sample should also be recorded if possible. Reference should be made to the relative percentages, grain size(s), and sphericity of the mineral particles (especially where it differs significantly from that of the predominant grain-size material).

Other information which should be recorded for each sample includes an estimate of the density and cohesiveness of the sample (made from blow counts where applicable, or other specific instrumentation where

appropriate), the relative moisture content of the sample, visible sedimentary structures, and any odors or staining noticeable during logging. Tables 2 and 3 present appropriate terms for describing the plasticity, density, and cohesiveness of sediment samples.

Especially important is an indication that a specific portion of the material may represent "sluff" or material collapsed from the borehole walls.

### 5.3. Written Sediment Descriptions

The written sediment description may be made as either an unabbreviated or an abbreviated description. Both methods should relate the same information, however the abbreviated description is better suited for field use.

In an unabbreviated description, all of the words of the description should be written out in their entirety. The descriptor should include pertinent information regarding the sample's size gradation (smallest to largest), consistency, color, and relative grain size, as described previously. The color descriptor should precede the primary sediment component name, while additional details such as the plasticity, mineralogy, visible sedimentary structures, etc., should follow the sediment component name.

An example of an unabbreviated description is:

**Red-brown (5YR 4/4), fine to coarse SAND, little fine Gravel, little Silt, moist, moderately well sorted, low sphericity, Gravel waterworn, Sand subangular, micaceous.**

Since the Burmister system is intended to provide a means for describing uniform sediments, three "special" cases should be addressed.

**First**, the Burmister system is intended only to describe the sediment. Where a genetic classification of the material is significant, it should be added as a separate statement at the end of the description. For example:

**Olive gray (5Y 4/2), coarse to fine SAND, some fine Gravel, little Silt, moist, poorly sorted, sub-rounded to angular, dense. TILL.**

A genetic classification should only be used when the origin of the material is very clear and not simply a field interpretation of possible depositional environment.

**Second**, in the case where the sediment sample is heterogeneous (for example, a varved silt and clay), each component should be described individually, and

reference should be made to the relative percentages of each component and to the interlayering. For example:

**Reddish-brown (5YR 3/4), CLAY and SILT, alternately layered, soft, medium to high overall plasticity. Layers: CLAY layers, 3/8" to 5/8" thick, comprise 60% of sample. SILT layers, 1/8" to 3/8" thick, comprise 40% of sample. VARVED CLAY and SILT.**

**Third**, when one material grades uniformly into a distinct sediment type, the individual components should be described separately and the gradation noted. For example:

**Reddish-brown (5YR 3/4), CLAY, medium overall plasticity, grading into soft, reddish-brown (5YR 4/4), SILT, trace Clay, soft, low overall plasticity.**

In the abbreviated sediment descriptions, the sample information is presented in a manner analogous to that for the unabbreviated description substituting standard abbreviations for specific portions of the text. Abbreviations for the identifying terms in the Burmister system are presented in Tables 1, 2, and 3. Mineralogic and geologic abbreviations may be found in standard geologic and mineralogic texts and field manuals. Except for the use of abbreviations, the abbreviated description is completely analogous to the unabbreviated description.

For the sake of consistency in describing unconsolidated sedimentary materials, the description should follow the order and general definitions presented in Table 4.

## 6. Documentation

Documentation of field activities will be completed in accordance with Loureiro SOP 10038 *Documentation and Integrity of Field Sampling Activities*. Additional documentation will include the following:

### 6.1. Recording Descriptions

#### Geologic Boring Logs

Attached to this SOP is a copy of LEA standard geologic boring log form. This log should be completed for each boring that is completed. The heading information is self-explanatory. The body of the log contains space for information for each sampled interval in the boring. The following information should be recorded:

Depth Interval	The upper and lower depths from which the sample was collected.
Sample No.	The sample number, as obtained from LEA Data Management, assigned to this sample.
Recovery	The length of the recovered sample and the length of the sampler (in consistent units). The percent recovery will be calculated by the LEA Data Management program.
Blows/6"	The number of blow counts per 6" interval for the sample. Alternately, the downhole pressure or other pertinent information regarding the required drilling or sampling force.
Sample Description	The sample description using the guidelines and order presented in Section 5.0 and Table 4.
PID/FID	The headspace reading from a photoionization detector (PID) or flame ionization detector (FID) in ppm (if required).

The comments section of the form should be used to record general observations regarding drilling conditions, backfilling of the borehole, or other pertinent information regarding drilling the borehole.

6.2. The following general information shall be recorded in the field log book and/or on the appropriate field forms:

- Name of recorder
- Identification of borings
- Collection method
- Date and time of collection
- Types of sample containers used, sample identification numbers and QA/QC sample identification
- Preservative(s) used
- Parameters requested for analysis
- Field analysis method(s)
- Field observations on sampling event
- Name of collector
- Climatic conditions, including air temperature
- Investigation derived waste (IDW)
- Field Sketch of sample location and color/type of flagging (if used)

## **7. References**

None.

END OF DOCUMENT

Table 1 Modified Burmister System Descriptors				
Fractions		Proportion Descriptors		
(+)	Major Fraction	Quantity	Descriptor	Abbreviation
(-)	Minor Fraction	35% - 50%	and	a
e.g., a medium to coarse SAND which is predominantly medium grained would be written as: m(+) - c <u>SAND</u>		20% - 35%	some	s
		10% - 20%	little	l
		1% - 10%	trace	t
Modifiers: (+) Upper a of the range (-) Lower a of the range				

Table 2 Plasticity of Sediment Samples						
Material	Symbol	Feel	Ease of Rolling Thread	Minimum Thread Diameter	Plasticity Index	Plasticity
Clayey SILT	CyM	Rough	Difficult	1/4"	1 to 5	Slight (SI)
SILT & CLAY	M & C	Rough	Less Difficult	1/8"	5 to 10	Low (L)
CLAY & SILT	C & M	Smooth, dull	Readily	1/16"	10 to 20	Medium (M)
Silty CLAY	MyC	Shiny	Easy	1/32"	20 to 40	High (H)
CLAY	C	Waxy, very shiny	Easy	1/64"	40 +	Very High (VH)


Table 3 Density and Cohesiveness of Sediment Samples			
Density of Cohesionless Soils		Consistency of Cohesive Soils	
Blow Counts	Relative Density	Blow Counts	Consistency
0 to 4	Very Loose	0 to 2	Very Soft
5 to 9	Loose	2 to 4	Soft
10 to 29	Medium Dense	4 to 8	Medium
30 to 49	Dense	8 to 15	Stiff
50 to 79	Very Dense	15 to 30	Very Stiff
80 or more	Extremely Dense	30 or more	Hard



Table 4  
Description of Sediment Properties

Sediment Parameter	Properties
Color	The color of the sample should be described for the wet sediments. If possible the color should be referenced to a standard color chart such as a Munsell7 Color Chart.
Primary Grain Size	Primary grain size refers to the size of the predominant sedimentary size class within the material (as judged visually). The grain size divisions should conform to the standard Wentworth Scale divisions, as shown in Figure 1.
Secondary Grain Size(s)	Secondary grain size(s) refer to material which, as a grain-size group, comprises less than the majority of the sediment. Aside from stating the size classification, the relative percentage of the material must be stated. The grain size divisions should conform to the standard Wentworth Scale divisions as shown in Figure 1. To describe the approximate percentage of the secondary grain size(s) present, qualifiers shown in Table 1 should be used.
Moisture Content	The moisture content of the sample should be described as dry, slightly moist, moist, or wet. Gradation from one state to another should be recorded as, for example, moist to wet, or moisty wet.
Sorting	The relative degree of sorting of the sediment should be indicated as poor, moderate, good, or very good. The degree of sorting is a function of the number of grain size classes present in the sample; the greater the number of classes present the poorer the sorting. In addition, for samples composed only of sand, the relative degree of sorting is a function of the number of sand-size subclasses present.
Sphericity	Sphericity is a measure of how well the individual grains, on average, approximate a sphere. The average sphericity of the sand and larger size fractions should be described as low, moderate or high. A chart illustrating various degrees of sphericity is presented in Figure 1.
Angularity	Angularity, or roundness, refers to the sharpness of the edges and corners of a grain (or the majority of the grains). Five degrees of angularity are shown in Figure 1: Angular (sharp edges and corners, little evidence of wear); Subangular (edges and corners rounded, faces untouched by wear); Subrounded (edges and corners rounded to smooth curves, original faces show some areas of wear); Rounded (edges and corners rounded to broad curves, original faces worn away); and, Well Rounded (no original edges, faces, or curves, no flat surfaces remain on grains).
Sedimentary Structures	Sedimentary structures are such things as varved layers, distinct bedding, or stratification.
Density -or- Cohesiveness	The density of cohesion of a sample (for the purposes of this application) refer to the sample's resistance to penetration by a sampling device. Density is used in reference to sediments primarily silt-size and coarser while cohesiveness is used in reference to primarily clay-sized sediments. Density or cohesiveness can be assessed from the number of blows from "standard" split-spoon sampling (i.e., 140# hammer, 30" fall, 2" X 2" (O.D., 1 3/8" I.D.)) split-spoon samplers according to the scale in Table 2.

Figure 1



**ATTACHMENT 1**  
Field Boring Log



**BORING ID:**

LEA Comm. No. 0000100.001

Elevation Page of

Project \_\_\_\_\_ Datum \_\_\_\_\_ Date \_\_\_\_/\_\_\_\_/\_\_\_\_

Location	LEA	GPS Latitude/Easting	
----------	-----	----------------------	--

Client \_\_\_\_\_ GPS Longitude/Northing \_\_\_\_\_

Drilling Method \_\_\_\_\_ Drilling Contractor \_\_\_\_\_

Sampling Method \_\_\_\_\_ Drill Foreman \_\_\_\_\_

Groundwater Depth \_\_\_\_\_ at \_\_\_\_\_ Drill Rig \_\_\_\_\_

[illegible]

Comments
----------

Survey accuracy

Waste Container	Trip Blank ID(s)	Cooler ID
-----------------	------------------	-----------

Field Personnel	<i><b>Signature</b></i>
-----------------	-------------------------

---

**Loureiro Engineering Associates, Inc.  
Standard Operating Procedure  
for  
Processing Performance Evaluation Samples**

**SOP ID: 10030  
Date Initiated: 04/01/98  
Revision No. 003: 07/27/18**

<b>Revised By:</b> <u>/s/ <i>Dan J. Hagen</i></u>	<u><i>07/19/18</i></u>
<b>Dan J. Hagen</b>	<b>Date</b>
<b>Project Scientist</b>	
<b>Reviewed By:</b> <u>/s/ <i>Karen A. Goldenberg</i></u>	<u><i>07/27/18</i></u>
<b>Karen A. Goldenberg</b>	<b>Date</b>
<b>Senior Technical Associate</b>	
<b>Reviewed By:</b> <u>/s/ <i>Brian A. Cutler</i></u>	<u><i>07/27/18</i></u>
<b>Brian A. Cutler</b>	<b>Date</b>
<b>President</b>	

## REVISION RECORD

---

<u>Rev #</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	07/07/11	
001	07/11/11	Revisions throughout updated to reflect new SPS format
002	07/07/11	Changed SPS title from "Ordering" to "Processing"
003	07/11/11	Revisions throughout revised to: include additional definitions and types of cooler temperature indicators, update and clarify the ordering instructions, allow for sample processing at a location other than the EHS office, and reflect new SPS format and language

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Processing Performance Evaluation Samples**

**1. Purpose and Scope**

This document discusses procedures for obtaining and submitting full volume liquid performance evaluation (PE) samples to analytical laboratories that are used by Loureiro Engineering Associates, Inc. Please note that these samples may also be referred to as proficiency testing (PT) samples. The procedures outlined in this document are for the purpose of establishing systematic procedures for obtaining, storing, handling, and submitting PE samples. This standard operating procedure (SOP) is intended to serve as a reference for any PE employee submitting PE samples to an analytical laboratory. Quality assurance/quality control (QA/QC) procedures as they pertain to PE samples have also been incorporated into this SOP.

Not all projects or media sampled require the use of PE samples. The decision whether to use PE samples is project-specific, dictated by data quality objectives (DQOs) and agency requirements. Refer to project-specific documents, the site-specific work plan, field sampling plan, or quality assurance project plan (QAPP) for details regarding the need for PE samples as well as the media, constituents, concentrations, and frequency at which PE samples are required.

The procedures outlined in this document are standard and typically applicable to operating procedures which may be varied or changed as required, dependent upon site conditions, equipment limitation, or limitations imposed by the procedure. Any variations from this procedure should be documented in the Daily Field Report Supplemental Sheet. The procedures outlined in this document will result in a single or double-blind full volume liquid or solid PE sample. If a site-specific or air media PE sample is required, project-specific modifications to this procedure will be required.

**2. Related Standard Operating Procedures**

- 000000/00 Measures for Field Sampling Activities
- 0000 Documentation and Integrity of Field Sampling Activities
- 0000 Handling, Packaging, and Shipping of Analytical Samples

### 3. Definitions

- **Test sample:** A sample, the composition of which is known to the auditor and unknown to the laboratory or analyst. Test samples are provided to assess the capability of the laboratory or analyst to produce analytical results within acceptable criteria. Test samples can fall into three categories: 1. Pre-qualification conducted prior to a laboratory beginning project work to establish initial proficiency 2. Periodic (e.g., quarterly, monthly, or episodic) to establish ongoing laboratory proficiency and 3. Batch specific, which is conducted simultaneously with analysis of a sample batch. Test samples may also be referred to as QA samples.
- **Blind Sample:** A sample submitted for analysis with a composition and/or identity known to the auditor but unknown to the laboratory or analyst. Samples may be either single-blind (the analytes and concentrations in the sample are unknown) or double-blind (the analytes, concentrations, and identity of the sample are unknown). Pre-qualification samples are typically single-blind.
- **Unaltered Test sample:** A sample that is received from the Test vendor that requires dilution before it can be processed by the laboratory as an analytical sample. These types of Test samples can only be single blind.
- **Full Volume Test sample:** A Test sample that is received by the laboratory ready to be treated as an analytical sample. It does not require dilution and therefore can be single or double blind.
- **Site-Specific Test sample:** A Test sample created using a well-characterized contaminated matrix and treated as an analytical sample by the laboratory to test its capabilities.
- **Cooler temperature indicator:** A device that monitors the temperature inside the sample cooler. A temperature alarm will indicate the temperature of the samples when the cooler is opened. Other devices, such as a recording thermometer or temperature strip, will notify the recipient when the samples have exceeded the maximum temperature.
- **Temperature-controlled container:** A temperature-controlled container may be a refrigerator or iced cooler. The container must be kept at a temperature of 4°C or less.

### 4. Equipment

- Laboratory glassware
- Cooler with identifiable cooler ID
- Chain of custody form





S□□ ID: 000

Date initiated: 00/00/00

Rev No 00: 00/00/00

Page 000

000000 The temperature blank must accompany the bottle/care and the samples. The tri-blank and the temperature blank are of paramount concern if you are also sending sample jars for volatile organic compound (VOC) analysis (e.g., 10 ml vials) to the E manufacturer/carer to S□□ ID 000, *Quality Assurance/Quality Control Measures for Field Sampling Activities*.

000000 The date that the samples will arrive for processing should be correlated with any sampling activities that are to be conducted so the samples can be submitted concurrently with environmental media samples.

000000 Arrangements should be made so that the samples are received on the same day that field activities are conducted. The laboratory should be notified that analyses should be performed on a shorter holding time. This is important since the samples are being prepared a day earlier and the holding time expiration is one day ahead of the field samples.

000000 Avoid requesting receipt of the samples on Monday, as this will shorten the holding time by days.

000000 Advise vendor/specific requirements regarding sample bottle/care. Vendors may have bottle/care similar in size and color to the analytical laboratory analyzing the samples or may require empty laboratory bottle/care in which to place the sample.

000000 Submit a letter/or request to the E project chemist for applicable field letter/or and sample labels for field sampling activities, or list for samples if no concurrent sampling is to be conducted.

#### 0000 Sending Sample Jars to E Vendor if applicable

000000 Place a bottle order with the analytical laboratory, requesting the appropriate bottles for the environmental analyses selected, based on the environmental media and the intended analytes of the sampling program that is to be undertaken.

000000 Once the empty bottles are received from the analytical laboratory select the appropriate glass/care for the sample constituents.

000000 Pack empty bottles in bubble wrap, including a tri-blank if samples will be submitted for analysis of VOCs and a temperature blank.

000000 Fill out a chain of custody form for the bottles you are sending to the E vendor. Send the original chain of custody with the cooler and keep a copy of the chain of custody for your records.



Users are fully to transcribe the E sample number from the label that has been affixed to the jar onto the field "after" or as each vendor label is removed. Write the constituent e.g., 0000s, S0000s next to the sample number on the field "after" or. Also, write the vendor's name and E lot number on the field "after" or.

S□□ ID: 000  
 Date initiated: 00/00/00  
 Ev□ No 00: 00/00/00  
 Age 000

Include the LE samples on the chain-of-custody afteror **This chain-of-custody form is different than the one used to ship and receive the glassware from the PE vendor.** Include a sample matrix code appropriate to the types of field and LE sample, as indicated in the table below:

Sample Matrix	Liquid LE Samples	Solid LE Samples
Liquid Field Samples	Use the same matrix code as the field samples e.g., G Groundwater or S Surface Water	N/A
Solid Field Samples	Use the matrix code for liquid samples that may be collected at the same time as the solid samples e.g., G Groundwater with soil S Solid samples or S Surface Water with sediment SE Sediment	Use the same matrix code as the field samples e.g., S Soil or SE Sediment

Have another LE employee check the cooler chain-of-custody form for accuracy and have that person initial the chain-of-custody form

File copies of all applicable field sampling afteror including the age with the original vendor's tags taped to it

#### Result Interpretation

Once the LE sample results reported by the laboratory are entered into the Project-Specific database, it should be verified for accuracy against the hard copy laboratory reports. Similarly, once the vendor-Specified acceptance limits and true values are entered in the database, they should be verified against the hard copies for accuracy

Once the data in the Project-Specific database have been verified for accuracy, compare the laboratory LE sample results to the vendor-Specified acceptance limits. Submit any NE or SE NE or SE information to the analytical laboratory so they can check for possible errors and report any corrective actions taken. Please note that in some instances, the client may limit the amount of information reported to the laboratory to only the NE and SE NE or SE designation. The information reported back to the laboratory is Project-Specific

Standard: 0000  
Date initiated: 00/00/00  
Revision: 00/00/00  
Page 000

## 6. References

EPA *Guidance on Technical Audits and Related Assessments for Environmental Data Operations*, EPA 823/3-90, Final EPA/600/3-90/000 January 2000

EPA *Uniform Federal Policy for Quality Assurance Project Plans – Evaluating, Assessing, and Documenting Environmental Data Collection and Use Programs*. March 2000

END DOCUMENT

**ATTACHMENT 1**

**PE Sample Ordering Information**

SOIL - BLIND PERFORMANCE SAMPLES					
	VOCs	SVOCs	METALS	TPH	PCBs
LOT #	1	2	3	4	5
A	Stock Lot - 1 of 11 available	Stock Lot - 1 avail = 4/year	Stock Lot - 1 of 2 available	Stock Lot - 1 of 3 available	Stock Lot - 1260 Low 1 avail = 4/year
B	Stock Lot - 2 of 11 available	Stock Lot - 1 avail = 4/year	Stock Lot - 2 of 2 available	Stock Lot - 2 of 3 available	Stock Lot - 1254 Low 1 of 3 available
C	Stock Lot - 3 of 11 available	Stock Lot - 1 avail = 4/year	Stock Lot - 1 of 2 available	Stock Lot - 3 of 3 available	Stock Lot - 1248 Low 1 of 2 available
D	Stock Lot - 4 of 11 available	Stock Lot - 1 avail = 4/year	Stock Lot - 2 of 2 available	Stock Lot - 2 of 3 available	Stock Lot - 1254 Low 2 of 3 available
PRICE	\$295 each	\$261 each	\$215 each	\$107 each	\$215 each

WATER - DOUBLE BLIND SAMPLES					
	VOCs	SVOCs	METALS	TPH	PCBs
LOT #	1	2	3	4	5
A	TCE = 25 ug/l PCE = 50 ug/l VC = 80 ug/l	Bis (2) = 50 ug/l NAP = 75 ug/l PYR = 125 ug/l	Cr = 0.4 mg/l Zn = 0.5 mg/l	1 mg/l	1260 = 1.4 ug/l
B	TCA = 25 ug/l PCE = 100 ug/l MC = 25 ug/l	BAP = 10 ug/l BBF = 10 ug/l PHN = 5 ug/l	As = 0.2 mg/l Pb = 0.5 mg/l	0.7 mg/l	1248 = 0.8 ug/l
C	BZ = 5 ug/l EBZ = 75 ug/l TL = 100 ug/l	ANTH = 150 ug/l Bis (2) = 100 ug/l DBP = 5 ug/l	Cd = 0.1 mg/l Hg = 0.01 mg/l	2 mg/l	1260 = 1 ug/l
D	MC = 50 ug/l ACT = 125 ug/l PCE = 25 ug/l	FA = 35 ug/l FLE = 50 ug/l BA = 5 ug/l	Ba = 1 mg/l Ni = 0.20 mg/l	5 mg/l	1254 = 0.7 ug/l
PRICE	\$216-B,C,D (\$266-A)	\$216 each	\$155 each	\$115 each	\$126 each

## LIST OF ABBREVIATIONS:

TCE = Trichloroethylene  
PCE = Tetrachloroethylene  
VC = Vinyl chloride  
TCA = 1,1,1-Trichloroethane  
MC = Methylene chloride  
BZ = Benzene  
EBZ = Ethylbenzene

TL = Toluene  
ACT = Acetone  
Bis (2) = Bis(2-ethylhexyl) phthalate  
NAP = Naphthalene  
PYR = Pyrene  
BAP = Benzo[a]pyrene  
BBF = Benzo[b]fluoranthene

PHN = Phenanthrene  
ANTH = Anthracene  
DBP = Di-n-butyl phthalate  
FA = Fluoranthene  
FLE = Fluorene  
BA = Benzo[a]anthracene





## FACSIMILE TRANSMITTAL SHEET

Loureiro Engineering Associates, Inc.

---

TO:	<b>Dale Shallenberger</b>	FAX NUMBER:	<b>303-421-0159</b>
			<b>303.421.3062</b>
			<b>(lab)</b>
COMPANY:	<b>ERA</b>	DATE:	<b>12/04/2001</b>
FROM:	<b>Nick Skoularikis</b>	NO. OF PAGES (including cover):	<b>3</b>
RE:	<b>PE sample preparation</b>	LEA REFERENCE NUMBER:	

---

<input type="checkbox"/> URGENT	<input type="checkbox"/> FOR REVIEW	<input type="checkbox"/> FOR YOUR USE	<input type="checkbox"/> PLEASE COMMENT	<input type="checkbox"/> PLEASE REPLY
---------------------------------	-------------------------------------	---------------------------------------	---	---------------------------------------

---

NOTES/COMMENTS:

Dale

I am shipping the cooler with the glassware today. Please call tomorrow if there are any questions.  
I am attaching the PO # 6312 and the solution types to be used.

**Please reference the PO# in the invoice. Also add the Commission Number: 68VD134.001**

Please use Lots A and B.

The lab needs the following jars per sample:

- 3 VOA vials
- Two 1-Liter for TPH
- Two 1-Liter for SVOCs
- Two 1-Liter for PCBs
- One 1-Liter for Cyanide
- Two for metals (one for filtered and one unfiltered)

Please ship overnight on Monday 8/6/01 and on Tuesday 8/7/01 (one each) for receipt the following day.

Thanks  
Nick



**Loureiro Engineering Associates, Inc.**  
100 Northwest Drive  
Plainville, CT 06062  
Phone: (860) 747-6181 Fax: (860) 747-8822

Date: 12/04/01

**Ordered By: Nick Skoularikis**

**Approved By: Nick Skoularikis**

**Commission Number** 68VD135

<b>Task Number</b>	<b>001</b>
--------------------	------------

Company

## Env Resource Associates

Street Address/P.O. Box

5540 Marshall street

City/State/Zip Code

Arvada, CO 80002

Phone 800.446.8736

Fax

**LEA, Plainville CT, Nick Skoularikis**

Company

### Attention

Loureiro Engineering Assoc., Inc.

Street Address/P.O. Box

100 Northwest Drive

City/State/Zip Code

Plainville, CT 06062

Phone 860/747-6181

Fax 860/747-8822

---

**Shipping/Delivery Instructions:**

Overnight ,

U:\ndekoularikis\WORD\PO5 ERA.DOC

**ATTACHMENT 2**

**Field Sampling Record  
Performance Sample**



**FIELD SAMPLING RECORD**  
**PERFORMANCE SAMPLE**

Loureiro Engineering Associates, Inc.

<b>LEA Comm. No.</b>	<b>67PV102.001</b>	<b>Page</b> _____ <b>of</b> _____
<b>Project</b>		<b>Date</b> ____/____/____
<b>Location</b>	Plainville Landfill, Plainville, CT	
<b>Client</b>	Town of Plainville	

LEA Sample ID \_\_\_\_\_

LEA Sample ID \_\_\_\_\_

LEA Sample ID \_\_\_\_\_

LEA Sample ID \_\_\_\_\_

LEA Sample ID \_\_\_\_\_

LEA Sample ID \_\_\_\_\_

<b>Field Personnel</b>	_____	<b>Signature</b>
------------------------	-------	------------------

**Loureiro Engineering Associates, Inc.  
Standard Operating Procedure  
for  
Documentation and Integrity  
of  
Field Sampling Activities**

**SOP ID: 10038  
Date Initiated: 04/30/99  
Revision No. 004: 09/04/18**

<b>Revised By:</b>	<b><u>/s/Jeremy Marcantonio</u></b>	<b><u>02/28/18</u></b>
	<b>Jeremy Marcantonio</b>	<b>Date</b>
	<b>Senior Project Scientist</b>	
<b>Reviewed By:</b>	<b><u>/s/Jo Ann Robertson</u></b>	<b><u>09/04/18</u></b>
	<b>Jo Ann Robertson</b>	<b>Date</b>
	<b>Technical Associate</b>	
<b>Approved By:</b>	<b><u>/s/Karen Harris</u></b>	<b><u>09/04/18</u></b>
	<b>Karen Harris</b>	<b>Date</b>
	<b>Quality Assurance Manager</b>	

## REVISION RECORD

---

<u>Rev #</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	04/30/99	
001	12/31/01	Formatting and minor revisions throughout
002	08/09/02	Added requirement for briefing or written work instructions prior to sampling; Added section on field equipment request and vehicle request; Added section on chain-of-custody form; Added section on cooler integrity and shipment.
003	07/18/18	Revisions throughout. Update to reflect new SOP format and updated sampling methodologies.
004	09/04/18	Updated to include documentation of sample coordinates and photographing samples.

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Documentation**  
**of**  
**Field Sampling Activities**

**1. Purpose and Scope**

This document describes procedures to be followed for proper documentation of all activities associated with sampling of environmental media, including field measurements and sampling, quality assurance/quality control (QA/QC) sample documentation, and chain-of-custody protocols. The use of specific documentation procedures depends on the goals of a particular project and should be dictated by the project-specific documents (e.g. work plan, FSP, QAPP). This Standard Operating Procedure (SOP) is to be used in conjunction with other Loureiro Engineering Associates, Inc. (LEA) SOPs and guidance for the performance of the associated field sampling activities.

**2. Related Standard Operating Procedures**

- 10030 – Processing Performance Evaluation Samples
- This SOP relates to all sampling, descriptive, and operational SOPs.

In addition to the above-noted SOPs, project and client-specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the project specific documents for adherence during the execution of the project.

**3. Definitions**

None.

**4. Equipment**

The following equipment and supplies shall be used during documentation of field sampling activities, as required:

- Pens
- Clipboard
- Field paperwork
- Indelible marker

- Camera

## 5. Procedures

- 5.1. Field procedures for which documentation covered under this SOP is required include sampling of soil, groundwater, air, surface water, sediment, and any other media from which samples are collected, as well as associated activities.

Documentation to be provided will include:

- Summary of daily field activities. (i.e., but not limited to: date, onsite/offsite time, client/office interactions, site visitors, changes in scope, out of the ordinary situations, changes in health and safety situations)
  - Sample descriptions (Location ID, Sample ID, Depths, PID, and other observations)
  - Photographic log
  - Coordinates and elevation of sample locations. Include the datum and accuracy of the method
  - Deviations from project scope and SOPs
  - Equipment used
  - Instrument calibration form
  - Waste disposal form
  - Decontamination procedures
- 5.2. All relevant information shall be included on the appropriate field report forms. However, the chain-of-custody record will include only that information necessary for proper sample identification and analysis.
- 5.3. Field Activities Documentation
- 5.3.1. The purpose of field paperwork is to adequately document all field activities. It is important to document field conditions that may have an impact on the field activities, such as weather conditions, physical constraints, nearby construction or dewatering activities (to the extent known).
- 5.3.2. All field paperwork must be filled out accurately and be completed in the field before the end of the workday. The only exception is the preparation of performance evaluation (PE) samples at the office, which should be completed in the office after the PE samples have been properly labeled in accordance with SOP 10030 *Processing Performance Evaluation Samples*. Information on equipment and expendable item usage shall be completed during the day, but checked for omissions at the end of the day.



5.3.3. At the conclusion of each sampling day, the field personnel shall conduct a quality control review before leaving the field, using the Quality Assurance Checklist section of the Daily Field Report.

#### 5.4. Chain-of-Custody Form

Although the chain-of-custody forms vary between laboratories and the analyses requested vary on a project-specific basis, the following information should be provided on the chain-of-custody forms:

- 5.4.1. Specify the LEA seven-digit sample number, date and time of collection, sample matrix, the type of analyses requested, and the preservatives used. For aqueous samples, the information provided should clearly indicate which preservative is used for which analyses. The analytical method requested should be specified.
- 5.4.2. The cooler containing the samples should be labeled with the appropriate identification information as specified in the project specific documents.
- 5.4.3. Specify whether an electronic data deliverable (EDD) or data validation package is required.
- 5.4.4. Specify the laboratory quote number or any additional project-specific numbers.
- 5.4.5. Unless otherwise specified in the site-specific project documents, use the suffix “uf” after the seven-digit LEA sample number to denote unfiltered metal samples.

#### 5.5. Photograph Log

Photographs will be taken of the following:

- The area the samples will be collected from (before and after sampling)
- Sampling process (periodically)
- Each of the soil and sediment samples
- Site conditions (daily)
- Location of the dust and VOC monitors
- Waste disposal area (periodically)
- Decontamination area and during the decontamination process (periodically)

Photographs will be logged in the field notes. The direction of the photograph and coordinates will be recorded in the photo log or recorded on the photograph using Solocator or similar software. Photographs of samples will include a scale and

sample identification. Photography is restricted at some job sites and the use of photography should be discussed with Project Manager.

#### 5.6. Post Field Activities

- Ensure that the paperwork is complete and that the pages are numbered sequentially, and dates are accurate.
  - Verify that all waste container information has been recorded.
- Appropriate entries should be made for all visitors to the site related to the field activities performed.
- Document in the photograph log the location of each the photograph or what the photograph is of. Photographs and log will be submitted to the data manager.
- Upon completion of the daily field activities and after review of the completed paperwork, a copy of the field paperwork shall be submitted to the database manager. The originals shall be retained for filing in the project notebook.
- All required information from the field is entered into the database by the database manager or a designee. A data review checklist is printed out upon completion. Included with the data review checklist may be a comment sheet indicating inconsistencies in the data entered that were readily apparent based on electronic comparison of the data or noted by personnel entering the data.

## 6. References

ATSM. ASTM 4840-99 *Standard Guide for Sampling Chain of Custody Procedures*. Reapproved in 2010.

END OF DOCUMENT

## **ATTACHMENTS AND FORMS**

**LEA Comm. No.** \_\_\_\_\_

Page \_\_\_\_\_ of \_\_\_\_\_

**Project** \_\_\_\_\_

Date \_\_\_\_/\_\_\_\_/\_\_\_\_

**Location** \_\_\_\_\_

**Client** \_\_\_\_\_

**Arrived at Site** \_\_\_\_\_

**Departed from Site** \_\_\_\_\_

**Vehicle** \_\_\_\_\_

**Site Activities**

Odometer (Start) \_\_\_\_\_

Return \_\_\_\_\_

- ☐ Soil Sampling
- ☐ Groundwater Sampling
- ☐ Surface Water Sampling
- ☐ Vapor/Air Sampling
- ☐ Concrete Sampling
- ☐ Other Sampling
- ☐ Other Sampling
- ☐ Well Development

- ☐ Geoprobe Work
- ☐ Concrete Coring
- ☐ Construction
- ☐ Waste Management
- ☐ Inspection
- ☐ Site Walk Over
- ☐ Surveying
- ☐ Other (Describe) \_\_\_\_\_

**Current Project Information**

Last Sample Number Used \_\_\_\_\_

Last Location ID Used \_\_\_\_\_

Current Location (if not complete) \_\_\_\_\_

Sampling for \_\_\_\_\_

Laboratories used \_\_\_\_\_

Paperwork & Equipment left at/in \_\_\_\_\_

Site Contact \_\_\_\_\_

Contractors on Site \_\_\_\_\_

**Non-productive Time**

- ☐ None
- ☐ Equipment Breakdown
- ☐ Late

- ☐ Weather
- ☐ Missing Equipment
- ☐ Other (Describe) \_\_\_\_\_

Time and place to meet contractors \_\_\_\_\_

**Quality Assurance Checks**

Yes N/A No

<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Sample labels complete
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Sample/cooler seals OK
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	All samples obtained
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Chains of custody
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	All forms/logs complete
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Site condition OK
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Site H&S Plan on site
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Instruments calibrated

**Residuals Disposition**

Item	Approx. Amount	Container ID
Soil/Solid		
Groundwater		
Decon Fluid		
PPE		
Other		

**Weather Conditions**

Temperature \_\_\_\_\_ Precipitation \_\_\_\_\_ Wind \_\_\_\_\_

Comments \_\_\_\_\_

**Checked By** \_\_\_\_\_

**Expendable Items Used**

**Equipment Used**

Qty	Item	LEA Number	Qty	Item	LEA Number
	Bailer, 2 Part Product	197		Bomb Sampler	042
	Bailer, Disposable (specify size)	090		Meter, Conductivity	022
	Bailer, PVC, 1"	187		Meter, pH/Temp	021
	Bailer, PVC, 1-1/2"	026		Miscellaneous Small Tools & Equipment	152
	Bailer, PVC, 2"	018		Pump, Peristaltic (spec. Master or Isco)	040
	Bailer, Stainless, 2"	027		Pump, Watera	038
	Bailer, Teflon	059		Turbidimeter	023
	Decontamination Supplies	081		Water Sampling Kit	152
	Filter, In Line	024			
	Filter, Zap Cap	024			
	Foot Valve and/or Surge Bloc	194			
	Miscellaneous Health & Safety Items	060			
	Tubing, 1/2", NOS	007			
	Tubing, 3/8", NOS	008			
	Water, Distilled	025			

**Field Personnel** \_\_\_\_\_

**Signature** \_\_\_\_\_

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Low-Flow (Low-Stress)**  
**Liquid Sample Collection and Field Analysis**

**SOP ID: 10039**  
**Date Initiated: 06/11/01**  
**Revision No. 006: 07/19/18**

<b>Revised By:</b>	<u>/s/ <i>Daniel J. Hagen</i></u>	<u>02/09/18</u>
	<b>Daniel J. Hagen</b>	<b>Date</b>
	<b>Project Scientist</b>	

<b>Reviewed By:</b>	<u>/s/ <i>Jo Ann Robertson</i></u>	<u>07/18/18</u>
	<b>Jo Ann Robertson</b>	<b>Date</b>
	<b>Technical Associate</b>	

<b>Approved By:</b>	<u>/s/ <i>Karen Harris</i></u>	<u>07/19/18</u>
	<b>Karen Harris</b>	<b>Date</b>
	<b>Quality Assurance Manager</b>	

## REVISION RECORD

---

<u>Rev #</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	06/11/01	
001	04/01/02	Updated to reflect new SOP format.
002	12/02/02	Updated to reflect stabilization procedures.
003	04/01/05	Incorporated modified low-flow sampling procedure to include the use of a peristaltic pump.
004	08/09/11	Allowed use of plastic tub as secondary containment. Provided equation for standing water calculation. Required recording of depth of pump intake. Required direct calculation of flow rate. Minor wording changes to improve precision. Deleted reference since it has been rescinded: [Connecticut Department of Environmental Protection, Bureau of Water Management, Permitting Enforcement and Remediation Division. <i>Site Characterization Guidance Document</i> , Draft, June 12, 2000.]
005	04/01/12	Added unit conversion information from gallons to liters.
006	07/19/18	Removed instructions that are provided in separate SOPs and added references to related SOPs.

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**For**  
**Low-Flow (Low-Stress)**  
**Liquid Sample Collection and Field Analysis**

**1. Purpose and Scope**

This standard operating procedure (SOP) describes the procedures to be followed for measurement of static water-level elevations, detection of immiscible layers, well evacuation, sample withdrawal, and field analyses utilizing low-flow sampling techniques.

**2. Related Standard Operating Procedures**

- 10004 – Liquid Sample Collection and Field Analysis
- 10005 – QA/QA Measures for Field Sampling Activities
- 10038 – Documentation and Integrity of Field Sampling Activities
- 10059 – Management of Investigation Derived Waste
- 10065 – Decontamination of Field Sampling Equipment

In addition to the above-noted SOPs, project and client-specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the project specific work plan (Work Plan) for adherence during the execution of the project.

**3. Definitions**

- Immiscible layers: The term is used to denote separate-phase liquids that may be present in the aquifer as a result of a release. These liquids may have a density lighter than water (light non-aqueous phase liquids [LNAPL], which float) or heavier than water (dense non-aqueous phase liquids [DNAPL], which sink).

**4. Equipment**

The following equipment and supplies shall be used during the collection and field analysis of low-flow liquid samples, as required:

- Health and safety equipment (as required by the site-specific Health and Safety Plan [HASP])
- Electronic water-level indicator (accurate to 0.01 foot)

- Photoionization Detector (PID) and calibration kit
- Interface probe/clear view bailer (to check for non-aqueous phase liquids, as appropriate)
- Water quality meter capable of monitoring (at a minimum) pH, temperature, specific-conductance, oxidation reduction potential (Eh), and dissolved oxygen (DO) and calibration fluids
- Flow-through cell
- Turbidimeter
- Polyethylene plastic sheeting and secondary containment units (plastic tubs)
- Adjustable rate centrifugal pump, peristaltic pump, bladder pump (constructed of stainless steel or Teflon<sup>®</sup>), adjustable rate submersible pump, or adjustable rate centrifugal pump. The preferable style of pump to be used is project specific and will be determined in the site-specific Work Plan
- Bladder pump control units for Nitrogen and Carbon Dioxide Tanks, and electronic and gas operated air compressors (if needed)
- Appropriate tubing for the pump used based on project specific sampling requirements, or polyethylene tubing, silicone tubing for the peristaltic pump. Note: Teflon<sup>®</sup> or Teflon<sup>®</sup>-lined tubing is not to be used when sampling for polyfluorinated alkyl substances (PFAS) compounds
- Hand tools for opening well
- Graduated measuring cup
- Decontamination fluids
- Watch

## 5. Procedure

### 5.1. Site Preparation

Review and follow the health and safety procedures or requirements specified in the site-specific HASP. All necessary personal protective equipment (PPE) shall be donned as specified in the site-specific HASP.

### 5.2. Equipment Decontamination

- 5.2.1. All reusable equipment will be decontaminated prior to starting and in between groundwater low flow sampling in accordance with SOP 10065 *Decontamination of Field Sampling Equipment* or as otherwise specified in the site-specific Work Plan or Field Sampling Plan (FSP).
- 5.2.2. Materials such as the bailer cord should not be decontaminated and should just be disposed of after each test. Note: Bailers should be used **only** to check for LNAPL **before** sample collection using low-flow/low stress procedures. A bailer may be used to check for DNAPL



only **after** all sample collection equipment has been removed from the well.

### 5.3. Approaching the Monitoring Well

- 5.3.1. Make sure the well is properly labeled if there can be any question about the well I.D. based on location (i.e., more than one well in close proximity to each other). If the well cannot be clearly identified, either based on location or by a specific label of some kind on the well itself, clearly indicate that fact on the field sampling record, water-level measurement form, and/or field paperwork. Well IDs may be located on the concrete collar of the monitoring well, on the protective casing of the monitoring well, or on the locking cap of the well. Should an ID not be easily visible, a measurement of depth-to-bottom of the well can be made in an attempt to clarify the well ID, in a manner not to mobilize any settled particulate in the bottom of the well. If the well historically contains a significant amount of settle particulate matter, the depth-to-bottom measurement should be taken after the well is sampled, as indicated in Section 5.4.4.
- 5.3.2. Each well shall have a surveyed reference point located at the top of the well casing with the locking cap removed. The reference point shall be easily recognizable, since the personnel conducting the sampling may differ from one sampling event to the next.
- 5.3.3. Remove the protective cover and locking cap from the well using hand tools.
- 5.3.4. Immediately upon opening the well, the air in the well head will be screened for VOCs using a PID. The instrument shall be zeroed with ambient air prior to the measurement, and the highest reading observed shall be recorded for each well. Measurements should be taken until stabilization of the readings has occurred.

### 5.4. Measurement of Static Water Level

- 5.4.1. The static water-level depths in each well shall be measured prior to each sampling event. This is performed initially to characterize the site, and in subsequent sampling rounds to determine whether horizontal or vertical flow gradients have changed. A change in hydrologic conditions may necessitate modification of the groundwater monitoring program.

- 5.4.2. The following parameters shall be measured with an accuracy of 0.01 foot:
- Depth to standing water.
  - Depth to bottom of well (after all liquid samples have been collected from the well if the depth to bottom cannot be collected during the initial round of waterlevels).
- 5.4.3. A water-level indicator with a fiberglass tape will be used for measurement. As a result of possible pressure differences between the well atmosphere and the ambient atmosphere, the water level will be allowed fifteen minutes to equilibrate upon removal of the well cap. If excess pressure is encountered, the water level will be allowed greater than fifteen minutes to equilibrate upon removal of the well cap. The results shall be recorded on the appropriate field form(s).
- 5.4.4. Total depth measurements will be compared to original depths to determine the degree of siltation that may have occurred. This information shall be noted on the field forms. Should significant siltation occur in any well, the well shall be redeveloped by an approved method.
- 5.4.5. The portion of the tape immersed in the well shall be decontaminated during retrieval using analconox wash, a distilled water rinse followed by drying with a clean wipe, prior to use in another well. This decontamination procedure shall be amended, as needed, to accommodate the specific type of contamination anticipated.
- 5.4.6. The static water level should be monitored and recorded throughout the purging and sampling of each well.

## 5.5. Detection of Immiscible Layers

- 5.5.1. If LNAPL is detected in a well, collection of a groundwater sample from that well is not recommended unless otherwise specified in the site-specific Work Plan. However, if a groundwater sample must be collected from that well, low-flow sampling is the recommended technique, although care must be taken to minimize mobilization of the LNAPL into the zone from which the sample will be collected. This is best accomplished by ensuring that the tubing or pump intake is placed well below the interface between the separate phase liquid and the water in the well.

## 5.6. Field Analysis

- 5.6.1. Parameters that are physically or chemically unstable shall be measured using probes that are inside a flow-through cell. Such parameters as pH, temperature, specific conductance, DO, Eh, and turbidity will be measured in the field at the temperature of the well sample.
- 5.6.2. Parameters such as pH, temperature, specific conductance, DO, and Eh shall be measured using a transparent flow-through-cell. The meter shall be calibrated immediately prior to use, if conditions change, and at the end of the day using supplied solutions in accordance with the instructions provided by the manufacturer. Calibration information will be recorded in the field before and after each calibration.
- 5.6.3. Turbidity will be measured with a separate turbidimeter, although some flow-through cells include a turbidimeter. It is useful to have a separate turbidimeter on hand to check the validity of the turbidity values obtained using the flow-through cell if there is difficulty reaching low turbidity values or if the turbidity readings recorded do not seem to be consistent with visual observation of the water samples. All samples, including turbidity samples and samples to be submitted for analysis, must be collected before the groundwater passes through the flow-through cell to prevent cross-contamination by potentially stagnant fluid within the flow-through cell. This can be accomplished by using a bypass assembly or disconnecting the tubing from the flow-cell inlet prior to sampling.

## 5.7. Well Evacuation

- 5.7.1. Generally, a centrifugal, peristaltic pump, bladder, submersible, or air-lift pump equipped with appropriate tubing of inert materials (such as polyethylene), shall be used to evacuate the monitoring wells.
- 5.7.2. A new piece of polyethylene plastic sheeting shall be placed on the ground adjacent to the well. Sampling and purging equipment such as the pump, tubing, containers, etc., shall be placed on the polyethylene sheet and/or a plastic secondary containment unit, never on the ground.
- 5.7.3. The pumps and tubing shall be prepared for insertion into the well while wearing disposable gloves. Make sure that any tubing or pump apparatus is of sufficient length to reach the appropriate depth for pumping. The water receiving tubing line should be kept out of direct

sunlight, as to avoid heating of the purged groundwater to cause a potential loss of VOCs.

- 5.7.4. Lower the pump and/or tubing gently into the water column to the midpoint of the saturated portion of the screened interval, unless otherwise specified. A site-specific sampling plan may specify a specific sampling depth, or provide specific criteria for the selection of intake depth for each well, but as a default, the tubing/intake should be placed at the midpoint of the saturated portion of the screen. **Record the actual depth at which the tubing/intake is placed.** If the saturated portion of the screen is less than 3 feet, the tubing or pump intake should be placed no closer than 1 foot from the bottom of the well. If the column of water in the well is less than 6 inches, serious consideration must be given to sampling the well, since it is not clear that the water in the well will be representative of water in the aquifer. If samples are collected from a well under these conditions, the limited volume of water should be specifically noted in the field paperwork.
- 5.7.5. Start the pump at the lowest speed setting and slowly increase the speed until discharge occurs. The initial pumping rate shall be approximately 0.1 liters per minute, however, the pumping rate shall not exceed 0.25 liters per minute. Measure the water level to ensure that drawdown in excess of 0.3 feet does not occur in the well. Adjust the pumping rate as necessary until little or no drawdown occurs. At least one actual measurement of the pumping rate should be conducted once drawdown stabilizes. That measurement should be made using a suitable measurement device for the volume anticipated over a measurement period of at least 20 to 30 seconds. Record the actual pumping rate on the field sampling record.
- 5.7.6. If the drawdown exceeds 0.3 feet, reduce pumping rate if possible. If drawdown still does not stabilize at a depth above the pump intake, shut the pump down and allow the well to recharge. It should be noted that a stable drawdown of approximately 0.3 feet is desirable but not mandatory. Stabilization of the drawdown at a depth greater than 0.3 feet is acceptable, as long as the depth at which stabilization occurs is above the pump intake. However, it is important that the stabilization depth is clearly recorded and maintained.
- 5.7.7. Monitor and record the water level and pumping rate at a minimum of every three to five minutes during purging. Calculate the volume of

the discharge tubing, bladder pump (if used), and the flow-through cell. Monitor and record indicator field parameters (turbidity, pH, Eh, DO, temperature and specific conductance) in the well from the first water extracted during the purging process and at least every three to five minutes, or sufficient time to purge at least one flow cell volume thereafter. During monitoring, place the flow-through cell in a position to prevent the possibility of gas bubble entrapment. It may be beneficial to place it at a 45 degree angle while monitoring groundwater parameters. When recording field measurements, follow the SOP 10038 *Documentation and Integrity of Field Sampling Activities*.

5.7.8. Stabilization of field parameters is considered to be achieved when three consecutive readings are within the following limits and no increasing or decreasing trend in the data can be observed:

- Turbidity (10% for values less than 5 and greater than 1 NTU). It should be noted that achievements of turbidity levels less than 5 NTUs are not mandatory but efforts should be made to collect a groundwater samples with the lowest turbidity achievable
- DO (10% for values greater than 0.5 milligrams per liter (mg/L); if three dissolved oxygen values are less than 0.5 mg/L, consider the values as stabilized)
- Specific Conductance and Temperature (3%)
- pH (+/- 0.1 unit)
- ORP/Eh (+/- 10 millivolts)

5.7.9. If after 2 hours of purging the field parameters have not stabilized, purging may be discontinued to allow sample collection. Similarly, if it is not possible to obtain stabilization as described above as a result of slow recovery of the well, the well shall be evacuated and allowed to recover, at which point the samples should be collected immediately. The appropriate sampling forms shall include a notation that sample collection occurred without stabilization. Samples obtained from slow-yielding wells shall be collected as soon as a sufficient volume is available for a sample for each parameter.

5.7.10. Do **not** re-use purging equipment. Pumps shall be decontaminated between monitoring wells, in accordance with SOP 10065 *Decontamination of Field Sampling Equipment* or as otherwise specified in the site-specific Work Plan or Field Sampling Plan (FSP).

- 5.7.11. Any water purged from the monitoring wells shall be stored in appropriate waste containers.

## 5.8. Sample Withdrawal

- 5.8.1. In order to ensure that the groundwater sample is representative of the formation, it is important to minimize physical alteration (i.e. agitation during purging and/or sample collection) or chemical contamination of the sample during the withdrawal process.
- 5.8.2. Use an appropriate pump to purge each well; the same pump used for purging shall be used for sample withdrawal.
- 5.8.3. The samples shall be collected at a location before entering the flow-through cell. To minimize the effects of water column agitation on sample quality, samples shall be collected from the pump tubing in the following order into pre-labeled sample containers:
- VOCs
  - Total petroleum hydrocarbons
  - Extractable organics (semivolatiles)
  - PCBs
  - Metals
  - Phenols
  - Cyanide
  - Chloride and sulfate
  - Nitrate and ammonia
  - Turbidity
  - Radionuclides
  - Purgeable organic carbon (POCs)
  - Purgeable organic halogens (POX)
  - Total organic halogens (TOX)
  - Total organic carbon (TOC)
- 5.8.4. Samples shall be obtained from the monitoring wells as soon as possible after purging. This may require waiting an extended period for low-yielding wells.
- 5.8.5. Samples collected for VOC analysis shall be free of any air bubbles and inverted upon filling. Bacterial samples shall be collected using dedicated gloves; taking care not to allow anything to touch the inside of the sampling container.

5.8.6. Should samples collected for metals analysis need to be filtered, they must be done so in the field. Filter metals samples shall be passed through an appropriately sized filter prior to placement in the sample bottle. Pre-rinse the filter with approximately 25 to 50 milliliters of groundwater prior to collecting the samples for filtered metals analyses. Filter sizes will generally be either 10 microns for metals that could be present as colloids, or adsorbed onto colloids that could be mobile in the aquifer, or 0.45 microns for dissolved metals. The appropriate filter size for the individual project must be provided in site-specific Work Instructions.

5.8.7. After samples have been collected, secure the monitoring well.

## 5.9. “What If” Scenarios

5.9.1. Certain field conditions may be encountered that influence the choice of equipment to be used or altogether limit the feasibility of low-flow sampling techniques. The following is a brief description of select scenarios to provide field personnel with a guideline if similar circumstances are encountered.

### 5.9.2. Turbidity

If samples are being collected for analysis for total (unfiltered) metals and the turbidity has not stabilized below 10 NTU, a sample for additional analysis for metals should also be collected after being filtered in the field through an in-line 10-micron filter, if specified in the work instructions. Discard the first 500 milliliters of filtered groundwater sample to ensure the filter media has equilibrated to the sample.

### 5.9.3. Peristaltic Pump

5.9.3.1. Difficulty may be encountered while advancing the flexible polyethylene peristaltic pump tubing to the desired depth within a deep well or older well. Excessive friction may result from the tubing contacting the sidewall of the well casing or accumulations of material on the well casing (i.e., mineral and bacterial deposits). In these scenarios, the tubing may coil within the well during advancement and prevent the desired depth from being attained. Efforts to weight the tubing using inert materials should be attempted before using alternate pumping techniques.



- 5.9.3.2. If well conditions discussed in Section 5.9.3.1 are expected, a bladder pump or other submersible pump should be used instead of a peristaltic pump. A bladder pump provides sufficient mass on the tubing to allow for advancement in deep or older wells.
- 5.9.3.3. A peristaltic pump cannot be used to sample wells in which the depth to water is greater than approximately 25 to 30 feet.

#### 5.9.4. Sampling Depth

If conditions exist that prevent the appropriate pump or tubing from being advanced to the midpoint of the saturated portion of the screened interval, low-flow sampling techniques shall not be used. Instead, sampling shall be conducted using conventional purging and sampling techniques, as described in SOP 10004 *Liquid Sample Collection and Field Analysis*. Justification for not using low-flow sampling techniques must be provided in the field paperwork.

#### 5.10. Waste Management

Investigation derived wastes (IDW), including purge water, decontamination liquids, and disposable materials (PPE, plastic sheeting, etc.), will be placed in clearly labeled, appropriate containers in accordance with SOP 10059 *Management of Investigation Derived Waste*, or managed as otherwise specified in the site-specific Work Plan or FSP.

#### 5.11. Documentation

Documentation of field activities will be completed in accordance with SOP 10038 *Documentation and Integrity of Field Sampling Activities*. In addition, field measurements will be recorded on the Low Flow Well Sample Record (attached). Any deviations from SOPs will be documented.

## 6. References

EPA. *Region I. Low Stress (Low Flow) Purging and Sampling Procedure for the Collection of Groundwater Samples from Monitoring Wells*, September 19, 2017, Revision 4.

EPA. *Groundwater Sampling Guidelines for Superfund and RCRA Project Managers – Groundwater Forum Issue Paper, Office of Solid Waste and Emergency Response, (EPA 542-S-02-001)*, May 2002.



Robert W. Puls and Michael Barcelona, EPA. *Low-Flow (Minimal Drawdown) Ground-Water Sampling Procedures, in Groundwater Issue, (EPA/540/S-95/504), April 1996.*

END OF DOCUMENT



Field Personnel \_\_\_\_\_ *Signature*



Field Personnel \_\_\_\_\_ *Signature*

**FIELD SAMPLING RECORD**  
**LOW FLOW WELL SAMPLE**

**LEA Comm. No.**      **0000100.001**

Page \_\_\_\_ of \_\_\_\_

**Project**

Date \_\_\_\_/\_\_\_\_/\_\_\_\_

**Location**              LEA, Plainville, CT

Sample Time \_\_\_\_:\_\_\_\_

**Client**

**Field Personnel**      \_\_\_\_\_  
\_\_\_\_\_

*Signature*

**Loureiro Engineering Associates, Inc.  
Standard Operating Procedure  
for  
Monitoring Well and  
Piezometer Abandonment**

**SOP ID: 10041  
Date Initiated: 08/13/02  
Revision No. 001: 07/18/18**

<b>Revised By:</b>	<u><i>/s/ Seth D. Travis</i></u>	<u><i>02/19/18</i></u>
	<b>Seth D. Travis</b>	<b>Date</b>
	<b>Senior Geologist</b>	
<b>Reviewed By:</b>	<u><i>/s/ Jo Ann Robertson</i></u>	<u><i>07/18/18</i></u>
	<b>Jo Ann Robertson</b>	<b>Date</b>
	<b>Technical Associate</b>	
<b>Approved By:</b>	<u><i>/s/ Karen Harris</i></u>	<u><i>07/18/18</i></u>
	<b>Karen Harris</b>	<b>Date</b>
	<b>Quality Assurance Manager</b>	

Additions/Deletions/Modifications

Revisions throughout are dated to reflect new SRS format and incorporation of new SRSs revised to include piezometers.

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Monitoring Well and**  
**Piezometer Abandonment**

## **1. Purpose and Scope**

The purpose of this standard operating procedure (SOP) is to outline the procedures that govern the abandonment of groundwater monitoring wells. All abandoned groundwater monitoring wells shall be properly plugged in order to safeguard public health and help mitigate the potential for surface water infiltration, circulation of water between producing zones, or any other process that could result in the contamination or pollution of groundwater. Throughout this SOP, reference to monitoring wells also includes piezometers unless specifically indicated otherwise. Well abandonment can also be completed in the following methods: perforating the well casing followed by grouting in place, grouting in place followed by casing pulling, and overdrilling and grouting with or without temporary casing. This SOP includes only the procedure for the abandonment of monitoring wells by grouting in place. Note that the abandonment of water supply wells are not covered by this SOP.

## **2. Related Standard Operating Procedures**

- 0000 Documentation and Integrity of Field Sampling Activities
- 0000 Management of Investigation Derivedastes
- 0000 Decontamination of Field Sampling Equipment

In addition to the above noted SOPs, project and client specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the project specific work plan or plan for adherence during the execution of the project.

## **3. Definitions**

- Groundwater monitoring well: A well designed and installed to obtain representative groundwater samples and hydrogeologic data.
- Piezometer: A well designed and installed to obtain representative hydrogeologic data.
- Cement/bentonite grout: A mixture of approximately 10 pounds of type 1 Portland cement, approximately 10 pounds of powdered sodium bentonite, and approximately 10 gallons of potable water or a mixture of the same ratio. The bentonite must be

SD: 00

Date initiated: 07/07/07

Rev No: 07/07/07

Page 00

thoroughly mixed with the water before the cement is added. The cement bentonite grout shall have a density of approximately 11 pounds/gallon.

- Remie pipe: A vertical or near vertical pipe used to gravity feed concrete below a water table.
- Water supply well: A well, constructed for the purpose of obtaining or providing water for drinking or other domestic, industrial, commercial, agricultural, or recreational use. Note that in the case of water supply wells, a permit is required (State Specific), and the abandonment must be approved by the regional director of public health or other designated party (State Specific).

## Equipment

The following equipment and supplies shall be used during well abandonment activities, as required:

- Health and safety equipment as required by the site-specific Health and Safety Plan (SPP)
- Chlorine solution
- Airtight can
- Cement bentonite grout (Type 1 Portland cement, powdered sodium bentonite, water)
- Remie pipe
- Rotor drum with mechanical mixing ability
- Polyethylene plastic sheeting
- Electronic water level indicator (accurate to 0.0 foot)
- Hand tools for accessing well
- Traffic cones, caution tape or barrier
- 55-gallon drum and label

## 5. Procedures

5.1 Abandonment procedures shall be performed on all groundwater monitoring wells that are no longer being utilized to collect analytical or hydrogeological data or have been damaged. When a damaged or unused well is encountered during the course of normal field operations notify the project manager. Upon approval, complete the well abandonment procedure.

### 5.1.1 Site Preparation

5.1.1.1 Review and follow the health and safety procedures or requirements specified in the site-specific SPP. All personal protective equipment (PPE) shall be donned as specified in the site-specific SPP.



age o

SD: 00

Date initiated: 07/07/07

Rev No 00: 07/07/07

Page 00

Wells constructed in a consolidated rock formation may be filled with fine sand in the zone or zones of consolidated rock. The top of the sand fill shall be at least ten (10) feet below the bottom of the casing.

Any test well or boring shall be abandoned in such a manner that it does not become a channel for the vertical movement of water or other substances to potable groundwater resources.

Upon completion of abandonment of the well, the top of the casing or grout material shall be terminated at least 6 feet below the ground surface.

## Waste Management

Investigation derived wastes (DW), including decontamination liquids and disposable materials (DE), plastic sheeting, etc., will be placed in clearly labeled, appropriate containers in accordance with SD 00 Management of Investigation Derived Waste, or managed as otherwise specified in the site-specific plan or SDS. Disposed water will be managed as specified in the site-specific plan or SDS.

## 6. References

Description of Organization, Rules of Practice and Regulations for the Well Drilling Industry (American Petroleum Institute), Connecticut Department of Consumer Protection, March 2000

EPA Handbook of Suggested Practices for the Design and Installation of Groundwater Monitoring Wells, EPA 600/6-90/001, United States Environmental Protection Agency (EPA), March 1990

NDES Groundwater Monitoring Well Decommissioning Policy, New York State Department of Environmental Conservation (NDES), November 1, 2000

DEM Groundwater Quality Rules (Appendix 1 – Construction Standards for Monitoring Wells and Abandonment Procedures for Monitoring Wells, Piezometers, and Other Subsurface Borings), State of Rhode Island and Providence Plantations Department of Environmental Management, March 2000

ASM ASTM D-5299/D-5299M-17: Standard Guide for Decommissioning of Groundwater Wells, Vadose Zone Monitoring Devices, Boreholes, and Other Devices for Environmental Activities, ASM International, 2000

END DDMEN

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Collecting and Preserving Soil and Sediment Samples for**  
**Laboratory Determination of Volatile Organic Compounds**

**SOP ID: 10057**  
**Date Initiated: 03/01/06**  
**Revision No. 002: 07/23/18**

<b>Revised By:</b>	<u><b>/s/Karen Goldenberg</b></u>	<u><b>04/01/18</b></u>
	<b>Karen Goldenberg</b>	<b>Date</b>
	<b>Senior Technical Associate</b>	
<b>Reviewed By:</b>	<u><b>/s/Jo Ann Robertson</b></u>	<u><b>07/19/18</b></u>
	<b>Jo Ann Robertson</b>	<b>Date</b>
	<b>Technical Associate</b>	
<b>Approved By:</b>	<u><b>/s/Karen Harris</b></u>	<u><b>07/23/18</b></u>
	<b>Karen L. Harris</b>	<b>Date</b>
	<b>Quality Assurance Manager</b>	

## REVISION RECORD

---

<u>Rev #</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	03/01/06	
001	04/01/12	Removed 'Draft' designation.
002	07/23/18	Updated format, minor edits throughout.

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Collecting and Preserving Soil and Sediment Samples for**  
**Laboratory Determination of Volatile Organic Compounds**

**1. Purpose and Scope**

Volatile organic compounds (VOCs) are lost from soil and sediment samples (hereinafter referred to as soil samples) due to volatilization and biodegradation during collection, storage, and analysis. This leads to low-biased results. Some commonly used sampling techniques are prone to relatively large losses and results that are potentially biased quite low. Such techniques involve collection of disturbed soil samples and storage in soil jars without air-tight seals. This standard operating procedure (SOP) describes soil sample collection and preservation techniques designed to minimize such losses. The procedure below has been adapted from EPA Method 3035A.

**2. Related Standard Operating Procedures**

- 10005 – Quality Assurance/Quality Control Measures for Field Sampling Activities
- 10006 – Soil Sampling
- 10015 – Geologic Logging of Unconsolidated Sedimentary Deposits
- 10038 – Documentation and Integrity of Field Sampling Activities
- 10059 – Management of Investigation Derived Waste
- 10065 – Decontamination of Field Sampling Equipment
- 10067 – Handling, Packaging, and Shipping of Analytical Samples

**3. Definitions**

- EnCore<sup>®</sup> Sampler: a disposable volumetric sampling device designed to assist field personnel in taking soil samples with minimal handling and maximum accuracy.
- Low Concentration Soil Samples: the specific concentration may vary between laboratories, but generally “low” refers to a concentration below approximately 200 micrograms per kilogram ( $\mu\text{g/kg}$ ).
- High Concentration Soil Samples: the specific concentration may vary between laboratories, but generally “high” refers to any concentration greater than 200  $\mu\text{g/kg}$ .
- Undisturbed samples: those for which the sampling device minimizes break-up of the structure of the soil to the extent practicable. Undisturbed samples can be collected using such techniques as:

- Coring, such as the methods utilizing split-spoon sampling devices, MacroCores™, and large-bore direct-push samplers;
- Bulk sampling, for example, undisturbed soil volumes collected using a backhoe bucket from sidewalls of trenches and excavations where direct access to the sampling location (sidewall or bottom) is not safe; and
- Direct collection of sub-samples from the subsurface.
- Sub-samples: those samples that are submitted to the laboratory for analysis for VOCs.

#### **4. Equipment**

- Health and safety equipment (as required by the site-specific Health and Safety Plan [HASP])
- Photoionization Detector (PID) and calibration kit
- Electronic field balance accurate to 0.1 grams
- Sample labels and custody seals
- Re-sealable plastic bags
- Utility knife
- Stainless steel spatula or trowel
- Decontamination fluids
- Paper towels
- Magnetic stir bar
- Cooler and ice
- Syringe (if needed)
- Water (if needed)
- Methanol (if needed)
- Sodium bisulfate solution (if needed)
- Volatile Organic Analysis (VOA) vials (40 ml) (if needed)
- 20 gram sample container for percent solids (a different size container may also be suitable) (if needed)
- EnCore®-type Sampler (5, 10 and 25 gram samplers) and T-handle (if needed)

##### **4.1. Site Preparation**

- A level table shall be placed within the exclusion zone and covered with polyethylene sheeting.
- Decontaminated spatulas shall be placed on the table. Sample bottles and EnCore®-type sampler with T-handle shall be placed in a convenient location and in order of sample collection.

- PID and plastic bags shall be placed on the table for VOC field screening, if necessary.

#### 4.2. Cleaning and Decontamination

Prior to and following collection of soils sample, ensure that all sampling equipment is cleaned and decontaminated in accordance with SOP 10065 *Decontamination and Integrity of Field Sampling Equipment*.

#### 4.3. Personal Protective Equipment

All personal protective equipment (PPE) should be donned and maintained in accordance with the site-specific work plan or health and safety plan during all sampling procedures.

#### 4.4. Overview of Sampling Approach

The soil sample collection procedure for determination of VOCs is a two-step process:

**Step 1 – Collect an undisturbed soil sample**, as defined below, from the subsurface, or expose the targeted area from where a sub-sample for laboratory analysis will be collected.

**Step 2 – Collect a representative sub-sample** from the undisturbed sample or directly from the exposed subsurface.

#### 4.5. Collection of Undisturbed Samples

When collecting samples for laboratory determination of VOCs, the device used to collect the undisturbed soil sample shall be removed as soon as possible from the subsurface; and most importantly, **the sub-samples that are intended for VOC determination must be collected as soon as possible (ideally within five minutes of collection of the undisturbed sample) to reduce loss of VOCs due to volatilization.** Attempts must be made to further minimize loss of VOCs by managing the sample collection environment (i.e. limiting sun, wind, heat, etc.).

Planning and careful preparation are critical for a successful sampling event. Checklists should be used to ensure that all necessary equipment and supplies are present and in proper working order and that the following conditions are achieved:

- Undisturbed soil to be collected for sub-sampling should be collected in a manner that controls the procurement of the samples such that they do not “stack up” awaiting logging and sub-sampling;
- Cores should not be stored in small- or large-diameter sampling devices or capped liners (brass, acetate, lexan, polycarbonate, etc.);
- Cores should not be exposed to extreme weather conditions, such as direct sunlight, rain and wind, and sub-sample collection should occur in an area that minimizes exposure to the elements (e.g., under cover, shady areas); and
- Undisturbed soil samples cannot be transferred from the core sampler to a secondary container (empty sample bottle, re-sealable bag, aluminum foil, or sampling bowls) for future sample collection.

Leaving samples in core tubes, split-spoons, covered liners, or intermediate containers will lead to VOC losses and will thus yield poor quality data. If a backlog develops, request the sample collection/drilling crew to slow down.

To the extent practicable, undisturbed samples should always be collected. However, under no circumstances should a sub-sample be collected from a disturbed sample that was previously used for field-screening purposes.

#### 4.6. Collection of the Soil Sub-Sample for Determination of VOCs

Sub-samples are those samples that are submitted to the laboratory for analysis for VOCs. Sub-sampling of the undisturbed soil sample must be performed using a dedicated or decontaminated small-diameter sampler. Sub-samples must be collected as soon as possible from the undisturbed sample (ideally within five minutes) after the undisturbed soil sample is collected.

### 5. Overview of Sub-Sampling Devices

Sub-sampling of the large-diameter or bulk sampling device for VOCs must be performed with the use of a dedicated or decontaminated small-diameter core sampler. The small-diameter core sampler should fit inside the mouth of the sample container to avoid loss of sample, prevent damage to the sealing surfaces or container threads, and ease the soil transfer process.

The small-diameter core sampler must be constructed with non-reactive materials that will not sorb VOCs (stainless steel, brass, glass, polytetrafluoroethylene (PTFE), and some rigid plastics).



## 5.1. Procedure for Obtaining Test Samples to Determine Sub-Sample Volume

The purge and trap laboratory procedure used to determine VOCs requires approximately equal amounts of soil and liquid to be used in the analysis. If the ratio of soil to liquid is too high, the soil will not be adequately dispersed in the liquid, leading to poor results. If the amount of soil is too low, the detection limits will be increased, potentially rendering the results to be of limited use. It is better to use a slightly lower weight of soil than a higher weight, as the regulatory limits are, in general, significantly higher than the typical laboratory reporting limit for volatile analytes.

The small-diameter core sampler must be able to deliver a minimum of 5 grams of sample ( $\approx 3 \text{ cm}^3$  of sample, assuming a density of  $1.7 \text{ g/cm}^3$ ) into a 40-ml VOA vial. While most small-diameter core samplers can only be used for sampling and placement into the appropriate sample containers, only the EnCore<sup>®</sup> -type samplers can be used for sampling, storage, and transportation of the sample to the laboratory.

It is important that the small-diameter core sampler provide the required mass of sample material. As such, a test sample (of similar matrix to that being sampled) may be collected and weighed to determine the amount of soil needed to obtain the required mass of sample material for each type of small-diameter core sampler and analytical method.

### 5.1.1. The procedure for obtaining a test sample is as follows:

- 5.1.1.1. Using a small electronic portable scale with an accuracy of 0.1 grams, weigh the empty small-diameter core sampler (e.g., disposable syringe) to the nearest 0.1 grams. The scale must be calibrated before use and intermittently checked during the day to ensure accurate weight measurement. Calibration information must be recorded in the field logbook. A translucent cover can be placed over the scale during the weighing process to negate variations caused by wind.
- 5.1.1.2. Push the small-diameter core sampler test sample into the matrix to collect the required mass of material ( $3 \text{ cm}^3$  should yield approximately 5 grams of sample [wet weight]).
- 5.1.1.3. Wipe clean any soil adhering to the outside of the small-diameter core sampler before weighing.

- 5.1.1.4. If the weight is above the required amount, remove excessive soil by extruding a small portion of the core and cutting it away with a decontaminated trowel or spatula. If the weight is below the weight limit, obtain additional soil by reinserting the small-diameter core sampler into the soil core. Re-weigh after each addition or removal of sample from the small-diameter core sampler until the target weight is attained. Note the sample volume and amount in the small-diameter core sampler.
- 5.1.1.5. Discard the test sample appropriately.
- 5.1.1.6. Use the volume of the test sample as a guide in collecting the appropriately sized sub-sample of a similar matrix. **Additional test samples should be weighed whenever a change in the matrix is observed.**

## 5.2. Overview of Procedure for Collection of Sub-Samples

The goal of soil sampling for the purposes of evaluating concentrations of contaminants in soil is to obtain a representative soil sample in accordance with the data quality objectives for the project. Often, this is accomplished using an appropriate small-diameter core sampler.

Different sample matrices (e.g., sand, gravel, clay, fill) will be encountered and may warrant slightly different sub-sampling field techniques. The goal for all techniques is to collect the sub-sample as quickly as possible while minimizing disruption. Environmental professionals should use good judgment as to how to handle samples that do not fit into the samplers and must describe the rationale for any deviations from this guidance.

The procedure for obtaining soil sub-samples is as follows:

- 5.2.1. Once the sampling interval has been selected, trim off the exposed surface of the matrix to expose a fresh surface. A loss of VOCs from the surface of the matrix will occur even if the matrix has been exposed for a short period of time (during screening, etc.). Removal of the unwanted surficial material can be accomplished by scraping the matrix surface with a decontaminated spatula or trowel. Soil sampling must commence immediately once a fresh surface has been exposed.
- 5.2.2. If hand augering, collect the sub-sample directly from the bottom of the hand auger immediately after pulling it from the ground. Do not attempt to remove the soil from the hand auger first.

- 5.2.3. Using the test sample as a guide, push the small-diameter core sampler into the matrix to collect a volume of material that will yield the required mass of sample (wet weight) as determined by the analytical method.
- 5.2.4. Depending upon the texture, depth or moisture content, insert the small-diameter core sampler straight into the matrix, on an angle. Multiple insertions can be made to obtain the required sample weight.
- 5.2.5. After sample collection, wipe the outside of the small-diameter core sampler to remove any excess material adhering to the barrel.
- 5.2.6. Immediately open the sample container and extrude the soil core into the sample container that will be submitted to the laboratory. Avoid splashing any preservative, if present, out of the sample container by holding the container at an angle while slowly extruding the soil core into the sample container. Do not immerse the small-diameter core sampler into the preservative. If an EnCore<sup>®</sup>-type sampler is to be used for storage and shipment, prepare the sampler for shipment according to manufacturer's instructions.
- 5.2.7. Collect the required number of sample containers or EnCore<sup>®</sup>-type samplers based on the chosen preservation and analytical methods, as discussed in the subsequent section on soil preservation methods.
- 5.2.8. Include an additional sample for determination of soil moisture content and sample screening.
- 5.2.9. Ensure the threads and cap of the sample container or EnCore<sup>®</sup>-type sampler are free of soil particles. Use a clean paper towel to remove soil particles from the threads and sealing surface of the sample container or EnCore<sup>®</sup>-type sampler. The presence of soil particles will compromise the container's seal and may result in loss of preservative or VOCs. This loss ultimately may invalidate the sample analysis. Always make sure the sample lid is firmly secure.
- 5.2.10. Record the laboratory and field identification numbers in the field notes and on the chain of custody in accordance with SOPs 10038 *Documentation of Field Sampling Activities* and 10067 *Handling, Packaging, and Shipping of Analytical Samples*.
- 5.2.11. After sample collection, immediately return the containers to an iced cooler. Sample containers from different locations should be placed in separate re-sealable bags to help avoid cross-contamination. The

laboratory sample number or field sample identification number may be placed on the bag and cross-referenced on the chain of custody. The laboratory performing the analysis will determine the sample weight.

## 6. Preservation of the Soil Sample

### 6.1. Overview of the Soil Preservation Procedure

Samples must be physically preserved (e.g. iced or frozen) in the field immediately upon sample collection. It is important to match up the correct physical preservation method with the appropriate sample container and field chemical preservation method. According to the United States Environmental Protection Agency (EPA) Contract Laboratory Protocol (CLP) Guidance for Field Samplers, the physical preservation methods are described as:

Iced – soil and sample containers are cooled to  $4^{\circ} \pm 2^{\circ}\text{C}$ .

Frozen – soil and sample containers are cooled to between  $-11^{\circ} \pm 4^{\circ}\text{C}$ .

Sample containers that will be frozen should be placed on their side prior to freezing process to prevent breakage. Additional aliquots for screening and moisture determination need only be iced and kept cooled at  $4^{\circ} \pm 2^{\circ}\text{C}$ ; these sample containers should not be frozen. ***Sample containers and EnCore®-type samplers should not be frozen below  $-20^{\circ}\text{C}$ , as the integrity of the container seals, o-rings and septum may be compromised by the freezing, resulting in the loss of VOCs upon thawing of the sample.***

In addition, the use of dry ice to freeze samples immediately upon sample collection or for use during shipment is not recommended. Dry ice, which is at a temperature of  $-78.5^{\circ}\text{C}$ , will lower the temperature of the sample container below the design specifications, causing damage to the glass, septum, seals, o-rings, and cap. In addition, dry ice has specific handling, storage and shipping requirements that outweigh its usefulness to the field sampling team.

### 6.2. Sub-Soil Sample Collection Procedures

When collecting soil sub-samples for determination of volatile organic compounds, up to four types of samples may be required:

- A high-concentration-level sample (two options)
- A low-concentration-level sample (four options)
- An Synthetic Precipitation Leaching Procedure (SPLP)/Toxicity Characteristic Leaching Procedure (TCLP) sample

- A sample for percent solids determination

When the expected VOC concentrations are not known, it is recommended to collect both the high- and low-concentration samples. The analysis procedure should be coordinated with the laboratory. For example, one approach would be to analyze one first (and if needed, the second one).

Additional samples may be necessary for matrix spikes and matrix spike duplicates. Field and trip blanks also may be required.

An overview of the various options for sample collection procedures is attached as Figure 1.

### 6.3. High-Concentration Sub-sample Collection Procedures

There are two options for collection of the high-concentrations sample: collection of the sample in a methanol preserved VOA vial or using EnCore<sup>®</sup>-type samplers.

#### 6.3.1. OPTION 1 – High Concentration Sample, Methanol Preservation

Supplies:

- Electronic field balance accurate to 0.1 grams
- Minimum of one VOA vial (40 ml), pre-weighed and containing 5 or 10 ml of methanol
- Sub-sampling device

- 6.3.1.1. Label the vials as appropriate. Do not add excessive labels (e.g. more weight) to the pre-weighed vials.
- 6.3.1.2. Weigh the vials to confirm the recorded vial weight.
- 6.3.1.3. Select the area to be sampled as soon as possible after the soil is exposed.
- 6.3.1.4. Obtain a test sample, using the coring device and field balance, to determine approximately how much volume of soil will yield equal grams of soil to methanol ( $5$  or  $10 \pm 1$  grams). This step may be skipped when the amount of soil needed for a particular matrix at a site has been determined.
- 6.3.1.5. Scrape away the surface material from the area to be sampled using a clean/decontaminated spatula or trowl to expose fresh soil.

- 6.3.1.6. Rapidly insert the syringe into the soil to obtain the sample. Quickly extrude the sample into the vial containing the methanol. Wipe off the threads and cap using a paper towel; seal the vial.
- 6.3.1.7. Using the field balance, weigh and record the weight of the vial in the field notes.
- 6.3.1.8. Place sample in cooler with ice.
- 6.3.1.9. Collect separate sample for percent solids, if necessary.

#### **6.3.2. OPTION 2 - High-Concentration Sample, Using EnCore®-Type Samplers**

Supplies: One 5 or 10-gram EnCore®-type Sampler

- 6.3.2.1. Label the re-sealable pouch as appropriate.
- 6.3.2.2. Select the area to be sampled as soon as possible after the soil is exposed.
- 6.3.2.3. Scrape away the surface material from the area to be sampled using a clean/decontaminated spatula or trowel to expose fresh soil.
- 6.3.2.4. Rapidly insert the sampler into the soil to obtain the sample. Quickly wipe the contact areas using a paper towel to remove any soil particles, close and seal the device.
- 6.3.2.5. Place devices in re-sealable pouch, place in cooler on ice.
- 6.3.2.6. Collect separate sample for percent solids, if necessary.
- 6.3.2.7. Samples must be frozen, preserved, or analyzed within 48 hours of collection.

#### **6.4. Low-Concentration Sub-Sample Collection Procedures**

There are four options for collecting low-concentration soil samples:

- Collection in VOA vials containing water
- Collection in empty VOA vials

- Collection in VOA vials containing sodium bisulfate
- Collection using EnCore<sup>®</sup>-type devices

All of the procedures using VOA vials are essentially the same, except for the media contained in the vial. It should be noted that sodium bisulfate preservation might lead to formation of acetone in samples containing high amount of humic material. Additionally, certain analytes, such as styrene, vinyl chloride, trichloroethylene (TCE), may be decomposed by the bisulfate, leading to low-biased results. Also carbonate-rich soils may effervesce. The effervescing will result in significant losses of VOCs, and in such cases the sodium bisulfate cannot be used. Environmental professionals should use caution in using this preservation technique. **For these reasons, it is recommended that another one of the other low-level preservation options be used. If the sodium bisulfate preservation option is used, the data should be considered in relation to the conceptual site model.**

#### **6.4.1. OPTION 1 - Low-Concentration Sample, Using VOA Vials Containing Water**

Supplies:

- Electronic field balance accurate to 0.1 grams
  - 2 VOA vials (40 ml), pre-weighed, containing 5 ml of water and a magnetic stir bar
  - Sub-sampling device
- 6.4.1.1. Label the vials as appropriate. Do not add excessive labels or tape over the label (e.g. more weight) to the pre-weighed vials.
- 6.4.1.2. Select the area to be sampled as soon as possible after the soil is exposed.
- 6.4.1.3. Obtain a test sample, using the coring device and field balance, to determine approximately how much volume of soil will yield 5 grams of soil. Note that the sample weight should be within 1 gram of the nominal weight, e.g.  $5 \pm 1$  gram. This step may be skipped when the amount of soil needed for a particular matrix at a site has been determined.
- 6.4.1.4. Scrape away the surface material from the area to be sampled using a trowel or spatula to expose fresh soil.

- 6.4.1.5. Rapidly insert the syringe into the soil to obtain the first 5-gram sample. Quickly extrude the sample into one of the two vials containing the water. Wipe off the threads and cap using paper towels; seal the vial.
- 6.4.1.6. Repeat steps 6.4.1.4 and 6.4.1.5 for the second vial containing water.
- 6.4.1.7. Using the field balance, weigh and record the weight of each vial in the field notes.
- 6.4.1.8. Place all samples in cooler with ice.
- 6.4.1.9. Collect separate sample for percent solids, if necessary.
- 6.4.1.10. Samples must be frozen or analyzed within 48 hours of collection.

**6.4.2. OPTION 2 - Low-Concentration Sample, Collection in Empty VOA Vials**

Supplies:

- Electronic field balance accurate to 0.1 grams
  - 2 VOA vials (40 ml), pre-weighed containing a magnetic stir bar
  - Sub-sampling device
- 6.4.2.1. Label the vials as appropriate. Do not add excessive labels or tape over the label (e.g. more weight) to the pre-weighed vials.
  - 6.4.2.2. Select the area to be sampled as soon as possible after the soil is exposed.
  - 6.4.2.3. Obtain a test sample using the coring device and field balance, to determine approximately how much volume of soil will yield 5 grams of soil. Note that the sample weight should be within 1 gram of the nominal weight, e.g.  $5 \pm 1$  gram. This step may be skipped when the amount of soil needed for a particular matrix at a site has been determined.
  - 6.4.2.4. Scrape away the surface material from the area to be sampled using a spatula or trowel to expose fresh soil.



- 6.4.2.5. Rapidly insert the syringe into the soil to obtain the first 5-gram sample. Quickly extrude the sample into one of the two vials. Wipe off the threads and cap using paper towels; seal the vial.
- 6.4.2.6. Repeat steps 6.4.2.4 and 6.4.2.5 for the second vial.
- 6.4.2.7. Using the field balance, weigh and record the weight of each vial. A record of the weight must be submitted with the samples to the laboratory.
- 6.4.2.8. Place all samples in cooler with ice.
- 6.4.2.9. Collect separate sample for percent solids, if necessary.
- 6.4.2.10. Samples must be frozen or analyzed within 48 hours of collection.

**6.4.3. OPTION 3: Low-Concentration Sample, Collection in VOA Vials Containing Sodium Bisulfate**

Supplies:

- Electronic field balance accurate to 0.1 grams.
  - 2 VOA vials (40 ml), pre-weighed containing 5 ml sodium bisulfate solution and a magnetic stir bar.
  - Sub-sampling device.
- 6.4.3.1. Label the vials as appropriate. Do not add excessive labels or tape over the label (e.g. more weight) to the pre-weighed vials.
  - 6.4.3.2. Select the area to be sampled as soon as possible after the soil is exposed.
  - 6.4.3.3. Obtain a test sample using the coring device and field balance to determine approximately how much volume of soil will yield 5 grams of soil. Note that the sample weight should be within 1 gram of the nominal weight, e.g.  $5 \pm 1$  gram. This step may be skipped when the amount of soil needed for a particular matrix at a site has been determined.
  - 6.4.3.4. Scrape away the surface material from the area to be sampled using a spatula or trowel to expose fresh soil.
  - 6.4.3.5. Rapidly insert the syringe into the soil to obtain the first 5-gram sample. Quickly extrude the sample into one of the two vials

containing the bisulfate solution. Wipe off the threads and cap using a paper towel; seal the vial.

- 6.4.3.6. Repeat steps 6.4.3.4 and 6.4.3.5 for the second vial.
- 6.4.3.7. Using the field balance, weigh and record the weight of each vial and record in the field notes.
- 6.4.3.8. Place all samples in cooler with ice.
- 6.4.3.9. Collect separate sample for percent solids, if necessary.

6.4.4. **OPTION 4 - Low-Concentration Sample, Collection Using EnCore®-Type Devices**

Supplies: Two 5-gram EnCore®-type sampling devices

- 6.4.4.1. Label the re-sealable pouch as appropriate.
- 6.4.4.2. Select the area to be sampled as soon as possible after the soil is exposed.
- 6.4.4.3. Scrape away the surface material from the area to be sampled using a spatula or trowel to expose fresh soil.
- 6.4.4.4. Rapidly insert the sampler into the soil to obtain the first sample. Quickly wipe the contact areas to remove any soil particles using a paper towel, close and seal the device. Place device in re-sealable pouch
- 6.4.4.5. Repeat steps 6.4.4.3 and 6.4.4.4 for the second EnCore®-type device.
- 6.4.4.6. Place both devices in re-sealable pouches, place in cooler on ice.
- 6.4.4.7. Collect separate sample for percent solids, if necessary.
- 6.4.4.8. Samples must be frozen, preserved or analyzed within 48 hours of collection.

6.5. Collection of Soil Samples for TCLP or SPLP Volatile Organic Analysis

The holding time for soil samples to begin the leaching procedure for TCLP or SPLP extraction for VOC analysis is 14 days from collection. If the environmental professional requests the laboratory to hold the samples until the results of the total (e.g., mass) analysis for VOCs is available, the total analysis must be available within a time-frame that will permit the environmental professional to give the laboratory sufficient notice to be able to start the SPLP/TCLP leaching within the 14-day holding time.

Supplies: 25-gram EnCore<sup>®</sup>-Type Sampler

- 6.5.1. Label the re-sealable pouch as appropriate.
  - 6.5.2. Select the area to be sampled as soon as possible after the soil is exposed.
  - 6.5.3. Scrape away the surface material from the area to be sampled using a spatula or trowel to expose fresh soil.
  - 6.5.4. Rapidly insert the sampler into the soil to obtain the sample. Wipe off the threads and cap using paper towels; seal the sampler.
  - 6.5.5. Place sampler in re-sealable pouch and place in cooler with ice.
  - 6.5.6. Samples must be frozen or leached within 48 hours of collection.
- 6.6. Collection of Soil Samples for Percent Solids Determination

A laboratory typically can use any container submitted for analysis to determine the percent solids of a soil, **except a container submitted for VOC analysis**. If the other laboratory analyses, besides VOCs (either total or TCLP/SPLP volatiles), are to be performed on soil for a given sampling interval and location, a separate container(s) will be needed for the other tests. The percent solids determination can then be performed using the soil in the container(s) for the other tests. In the event that only VOCs are to be determined for a given soil sample, the environmental professional must collect additional sample (no more than 20 grams would be needed) in a separate container for submittal to the laboratory. Typically, a small plastic container would suffice, although any container would do.

## 7. Documentation

Documentation of field activities will be completed in accordance with SOP 10038 *Documentation and Integrity of Field Sampling Activities*.

## 8. References

EPA. *EPA Method 5035A Closed-System purge-and-trap and extraction for Volatile Organics in Soil and Waste Samples*. Draft Revision 1, July 2002.

EPA. *Behavior and Determination of Volatile Organic Compounds in Soil*, EPA/600/R-93/140, May 1993.

USACE. *Chemical Preservation of Volatile Organic Compounds in Soil Subsamples*, Hewitt, A.D., USACE Special Report 95-5, February 1995.


Hewitt, A.D. and Lukash, N., USACE. *Obtaining and Transferring Soils for In-Vial Analysis of Volatile Organic Compounds*, USACE Special Report 96-5, February 1996.

USACE. *Sample Collection and Preparation Strategies for Volatile Organic Compounds in Solids* (October 1998). <http://clu-in.org/download/stats/sampling.pdf>.

Hewitt, A.D., USACE. *Preparing Soil Samples for Volatile Organic Compound Analysis*, USACE Special Report 97-11, April 1997.

Hewitt, A.D., USACE. *Storage and Preservation of Soil Samples for Volatile Organic Compound Analysis*, USACE Special Report 99-5, May 1999.

**Figure 1 – Sample Collection Flow Chart**



Note: Not appropriate for all circumstances – see Section 6.4 of this document.

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Management**  
**of**  
**Investigation Derived Waste**

**SOP ID: 10059**  
**Date Initiated: 03/04/09**  
**Revision No. 001: 07/18/18**

**Prepared By: /s/ Seth Travis 02/27/18**  
**Seth Travis** **Date**  
**Senior Geologist**

**Reviewed By: /s/ Jo Ann Robertson 07/18/18**  
**Jo Ann Robertson** **Date**  
**Technical Associate**

**Reviewed By: /s/ Karen Harris 07/18/18**  
**Karen Harris** **Date**  
**Quality Assurance Manager**

## REVISION RECORD

---

<u>Rev#</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	03/04/09	
001	07/18/18	Add types if IDW, modify definitions

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Management**  
**of**  
**Investigation Derived Waste**

**1. Purpose and Scope**

During field investigation activities, there are various investigation derived wastes (IDW) generated by day-to-day operations that may pose a risk to human health and the environment. These materials are typically stored in containers (portable devices including, but not limited to, 55-gallon drums, cubic yard boxes, roll-off containers, etc.) temporarily and managed by the client/property owner prior to off-site disposal. The management of IDW at Loureiro Engineering Associates, Inc. (LEA) client sites must be performed in such a way as to ensure the protection of human health and the environment and must comply with applicable regulatory requirements.

**2. Related Standard Operating Procedures**

- None

While no related SOPs are referenced in this document, project and client-specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the project-specific documents work plan (Work Plan) for adherence during the execution of the project.

**3. Definitions**

- IDW: wastes generated during the normal course of environmental site investigations. Types of IDW include:
  - Personal protective equipment (PPE) - This includes disposable coveralls, gloves, booties, respirator canisters, splash suits, etc.
  - Disposable equipment and items - This includes plastic ground and equipment covers, aluminum foil, conduit pipe, composite liquid waste samplers (COLIWASAs), Teflon® tubing, broken or unused sample containers, sample container boxes, tape, etc.
  - Soil cuttings – soil generated from drilling or hand augering



- Drilling mud - mud and/or water generated during mud or water rotary drilling
  - Groundwater – groundwater purged from well
  - Cleaning fluids – Fluids used in decontamination of equipment, including spent solvents and wash water
  - Packing and shipping materials
- Temporary storage: Temporary storage is defined as the holding of waste materials for a temporary period, at the end of which the waste material is treated, disposed of, or stored elsewhere.
- Container: A container is a portable device in which a material is stored, transported, treated, disposed of, or otherwise handled.
- Containerized Waste: Solids, liquids or sludges that are found in drums, bulk storage tanks, transformer or lab packs
- Un-containerized Waste: Solids, liquids or sludges that are found in indoor or outdoor waste piles and surface impoundments.
- Large Quantity Generators (LQGs): The generation of 1,000 kg or more per month of hazardous waste or more than 1 kg per month of acutely hazardous waste. See 40 CFR part 262 for a complete description of LQG regulations.
- Small Quantity Generators (SQGs): The generation of 100 kg, but less than 1000kg of hazardous waste per month. See 40 CFR part 262 for a complete description of SQG regulations.

#### **4. Equipment**

The following equipment and supplies shall be used while managing Investigation Derived Waste, as required:

- Health and safety equipment (as required by the site-specific Health and Safety Plan [HASP])
- Containers (open-top & closed-top drums, cubic yard boxes, totes, roll-offs, etc.)
- Containment pallets
- Wood pallets
- Polyethylene plastic sheeting
- Adhesive labels
- Clear tape
- Indelible markers
- Paint stick

- Hand tools for opening drums

## 5. Procedure

### 5.1. Pre-job communications

5.1.1. The project manager or designee shall communicate with the assigned field personnel the management methods for IDW generated at the site. Based on the planned scope of work, ensure the appropriate number and types of containers are available for the volume and types of IDW generated.

5.1.2. Clearly identify how the naming convention for IDW containers at the site will be done to facilitate identification at time of disposal. LEA provides containers and assigns a unique container designation that consists of the following information, each separated by a dash:

- A two-letter site identifier (e.g., XY-)
- A two-digit container type identifier (e.g., OT-)
- A three-digit container identifier (e.g., 001)

Using the above information, the resulting container designation is XY-OT-001.

Container type identifiers are as follows:

OT – Open Top Drum  
CT – Closed Top Drum  
RO – Roll-Off  
CY – Cubic Yard Box  
5G – 5 Gallon Pail  
PT – Portable Tank/Tote

Note: some clients/sites issue containers with existing container identifications (IDs) and labels, however, this is not typical.

5.1.3. Based on Resource Conservation and Recovery Act (RCRA) regulations, a site may be limited in the number of hazardous waste containers on a site at any given time (i.e., small quantity generators and conditionally exempt small quantity generators). If it is known or presumed that the IDW generated meets the definition of a hazardous waste, the project manager or designee shall communicate with the assigned field personnel the maximum amount of waste that may be generated at the site prior to IDW characterization.

## 5.2. Safety

Proper safety precautions must be followed during the management and handling of IDW. Review and follow the health and safety procedures or requirements, including movement of containers and chemical safety, specified in the site-specific HASP. All necessary personal protective equipment (PPE) shall be donned as specified in the site-specific HASP.

## 5.3. Temporary storage area location:

- 5.3.1. The location chosen for the temporary storage of IDW must be determined in advance and approved by the project manager or client. At locations where the client may not be the property owner, a location must be approved by the operating facility manager to ensure that they have knowledge of the material in case of an emergency condition (fire, flood, storm, etc.) and that the storage/location of the containers does not interfere with daily operations.
- 5.3.2. The location of the temporary storage area should be level and stable in order to prevent containers from shifting/tipping.
- 5.3.3. The location chosen should be readily accessible for waste vendors and transportation vehicles at the time of off-site disposal. Containers should not be located in areas which are not accessible for their removal.

## 5.4. Container Identification

- 5.4.1. Clearly identify each container with a unique container identification number and record information on daily field sheet. Write generator site name/address and a description of the waste along with the accumulation date on adhesive label and attach to the side of the container. The container markings should also include the words “investigationderived waste pending determination” and the container designation. The markings and labels should be covered with clear tape to prevent wash off and fading. A sample label is provided below. **Note:** once a container is full the word “full” should be marked on the container so that no additional material is added.

XYZ Corporation  
10 Main Street  
Somewhere, CT 00000

Investigation Derived Waste Pending Determination

(Soil Cuttings, Disposable sampling equipment)

XY-OT-001

Accumulation Start Date: 02/27/2018

Due to the time limitations and restrictions posed by RCRA regulations on storage of hazardous waste, accumulation dates should be identified on all containers of IDW so that they can be managed in a timely manner. Note that the RCRA regulations on number of days in storage starts when waste is added to the drum/container for the first time, not when the drum is full.

- 5.4.2. If a label is not available, use a paint marker and paint the following information on the side of the container: "Investigation derived waste pending determination", Container ID, description of the waste and accumulation date.
- 5.4.3. If it is known or presumed that the IDW generated meets the definition of a hazardous waste, the IDW drum shall be labeled as specified by the project manager and/or the site-specific Work Plan, but at a minimum should be marked with the words "hazardous waste" along with the other labeling information listed above.

## 5.5. Container Management

- 5.5.1. Only use containers that are compatible with the IDW generated.
- 5.5.2. Containers must be closed securely except when actively adding or removing waste.
- 5.5.3. Do not handle containers in a manner that could cause them to leak.
- 5.5.4. If a container holding IDW is not in good condition, or it begins to leak, transfer the IDW to another container in good condition.
- 5.5.5. Open-top drums are for the management of solid-phase IDW only (i.e., soil, PPE, disposable sampling equipment, debris). Liquid-phase IDW must not be managed in open-top drums.
- 5.5.6. Do not completely fill liquid containers. Leave at least two to four inches of headspace in all liquid containers to allow for expansion (in the event of heat generation or freezing conditions). To minimize the

potential for container failure, work with the client to arrange for disposal of the IDW as soon as possible following generation.

- 5.5.7. Any IDW that is known to be characteristically hazardous for ignitability (D001) or reactivity (D003) must be stored at least 50 feet from the facility property line.

## 5.6. Temporary storage area management

- 5.6.1. Containers of IDW known to be hazardous should be physically segregated from non-hazardous IDW to minimize the volume of hazardous IDW that must be disposed of.
- 5.6.2. Place containers on surface that will allow monitoring for leakage. Liquid containers must be stored off the ground surface (e.g., be placed on a shipping pallet). If the IDW is known or presumed that the IDW generated meets the definition of a hazardous waste, the IDW must be placed on an impervious surface, such as a coated concrete floor or a containment pallet. Asphalt or uncoated concrete do not constitute an impervious surface.
- 5.6.3. Provide adequate access to each container for the purposes of inspection and emergency response. Containers must be arranged so that each container may be accessed.
- 5.6.4. If the IDW is incompatible with other wastes generated or materials stored in the area, (e.g., acids and bases), segregate the containers by waste type. Do not store incompatible wastes/materials together.
- 5.6.5. Arrange containers on pallet in a manner in which that identification information is visible (facing outward).
- 5.6.6. If temporary storage area is located outside, cover containers with plastic sheeting and secure sheeting to prevent rips, tears, and loss (for non-hazardous drums only).
- 5.6.7. If there are a large number of containers, segregate by waste type (e.g., soil/groundwater/decon fluid, hazardous/non-hazardous/PCBs). It is likely that different handling will be required for the contents.
- 5.6.8. When demobilizing from the site, confirm waste container storage area is free of waste materials and/or debris upon departure. Photograph the storage area to document the condition, if possible.

## 5.7. Post-Job Client Communications

- 5.7.1. When applicable, after completion of sampling activities, provide the client with a copy of the IDW inventory on-site.
- 5.7.2. When applicable, provide receipt of the analytical data, provide the client with a copy of the data to assist with characterization and disposal of the IDW containers on-site.
- 5.7.3. Additional assistance with characterization and/or management of IDW may be provided for certain clients as specified by the project manager and/or the project-specific Work Plan.

## 6. Documentation

Documentation of field activities will be completed in accordance with SOP 10038 *Documentation and Integrity of Field Sample Activities*. In addition, the following documentation is required:

- Summarize waste container inventory on “Waste Container Inventory Sheet” included as Attachment 1, and include with daily field record sheets when no additional waste will be generated.
- Enter waste information into the Sharepoint waste spreadsheet to accurately track waste generation.
- Provide facility representative (where applicable) with waste container inventory to allow them to make arrangements for disposal.

## 7. References

EPA. *Science and Ecosystem Support Division, Operating Procedure SESDPROC-202-R1, July 2, 2014. Management of Investigation Derived Waste*. USEPA, Science and Ecosystem Support Division. 2014.

EPA. *Management of Remediation Waste under RCRA*. Publication EPA/530-F-98-026, October 1998.

EPA. *Superfund Program Representative Sampling Guidance, Volume 4: Waste*. OSWER Directive 9360.4-14, Publication EPA/540/R-95/141. December 1995.

EPA. *Guides to Management of Investigation-Derived Wastes*. OSWER Directive 9345.3-03FS. April 1992.

END OF DOCUMENT

**ATTACHMENT 1: Waste Container Inventory Sheet**



**Loureiro Engineering Associates, Inc.  
Standard Operating Procedure  
for  
Decontamination of Field Sampling Equipment**

**SOP ID: 10065  
Date Initiated: 09/04/18**

<b>Revised By:</b>	<u><i>/s/ David Payne</i></u>	<u><i>04/04/18</i></u>
	<b>David Payne, P.E.</b>	<b>Date</b>
	<b>Project Manager</b>	

<b>Reviewed By:</b>	<u><i>/s/ Jo Ann Robertson</i></u>	<u><i>09/04/18</i></u>
	<b>Jo Ann Robertson</b>	<b>Date</b>
	<b>Technical Associate</b>	

<b>Approved By:</b>	<u><i>/s/ Karen Harris</i></u>	<u><i>09/04/18</i></u>
	<b>Karen Harris</b>	<b>Date</b>
	<b>Quality Assurance Manager</b>	

DESIGN DEED

---

Rev

Date

Additions/Deletions/Modifications

---

Initial Issue

00/00/00

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**For**  
**Decontamination of Field Sampling Equipment**

**1. Purpose and Scope**

This document outlines procedures for decontaminating sampling and processing equipment contaminated by either organic or inorganic materials. To prevent cross contamination of samples, all reusable sampling and processing equipment will be decontaminated before each use. The procedures outlined in this document are site specific regarding sampling methods and constitutes of concern. The procedures outlined in this document are in accordance with the Environmental Protection Agency EPCRA document entitled, SESD00000000 *Field Equipment Cleaning and Decontamination*.

**2. Related Standard Operating Procedures**

- 0000 Management of Investigation Derived Waste

In addition to the above noted SOP, project and client specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the project specific work plan or plan of adherence during the execution of the project.

**3. Definitions**

None

**4. Equipment**

The following equipment and supplies shall be used during equipment decontamination activities, as required:

- Health and safety equipment as required by the site specific Health and Safety Plan or SOP
- Scrub brushes at least 12"
- Polyethylene plastic sheeting 6 millimeter or thicker
- Clean 5 gallon buckets
- Versi-Tek plastic tub secondary containment for drilling tooling
- Distilled/Deionized Water or DI Water

- quino or other phosphate-free detergent
- 00 methanol
- 00 nitric acid
- 000 heane
- 000ml laboratory squirt bottles
- plastic bags size based on equipment
- aluminum foil
- large heavy-duty garbage bags
- 00 ml plastic squirt bottles
- paper towels and/or clean cloths

## 5. Procedures

### Site Preparation

Review and follow the health and safety procedures or requirements specified in the site-specific SDS. All necessary personal protective equipment (PPE) shall be donned as specified in the site-specific SDS.

A section of polyethylene plastic sheeting shall be cut of sufficient size to underlie the decontamination area to contain any discharge of decontamination solutions.

The following solutions as appropriate for the anticipated contaminants shall be prepared and placed in 000ml laboratory squirt bottles: methanol solution less than 00 solution, 000 nitric acid solution, 0000 heane solution, and distilled deionized water. A 10th solution of phosphate-free detergent and tap water approximately 000 gallons shall be prepared in a clean five-gallon bucket.

### Decontamination Procedures

All loose debris shall be removed from sampling equipment into an empty 00 gallon bucket or plastic sheeting, using a stiff-bristled brush.

The order of decontamination solutions is as follows:

00 Detergent Scrub

00 Deionized Water Rinse

00 Heane Rinse to be used only in case of a hydrocarbon petroleum product, other than gasoline, is present.

Standard: 0000

Date initiated: 00/00/00

Page 000

00 Decontaminate

00 00 Nitric acid Decontaminate to be used only when inorganics are suspected as potential contaminants

00 Decontaminate

00 Methanol Decontaminate to be used only when organics are suspected as potential contaminants

00 Air Dry

After decontamination of all sampling equipment, dispose of DDE, loose material and decontamination fluid in accordance with your plan and SOP 0000 *Management of Investigation Derived Waste*

#### 0000 Specific Decontamination Procedures

The specific procedures for decontamination of non-disposable small sampling equipment used during soil, sediment, groundwater and or surface water collection include hand auger bucket, spatulas, scoops, bowls, cutting shoe, etc that comes in contact with organic and/or inorganic contamination

#### 00000 Cleaning of Small Sampling Equipment when Analyzing for Organic Compounds

00 If necessary, remove all loose debris from sampling equipment into an empty clean 5-gallon bucket or plastic sheeting, using a clean dedicated stiff bristled brush

00 Scrub sampling equipment thoroughly using a second clean dedicated brush and non-phosphate detergent to removal all visible particulate matter

00 Thoroughly rinse equipment with Decontaminate into a 5-gallon bucket. Sampling equipment can be rinse off into non-phosphate detergent and water bucket to remove non-phosphate detergent from sampling equipment

00 If separate phase petroleum product, other than gasoline, has encountered, carefully rinse equipment with 0000 heptane from squirt bottle, and let excess solvent drain into a separate waste 5-gallon bucket

After a heptane rinse has been used, rinse sampling equipment with DI water into same waste 5-gallon bucket.

Thoroughly rinse sampling equipment with a 10% methanol from squirt bottle, and let excess solvent drain into a separate waste 5-gallon bucket.

Rinse sampling equipment with DI water in waste 5-gallon bucket and allow sampling equipment to air dry. Equipment does not need to be dried prior to use.

When the sampling equipment is not to be used immediately, store in aluminum foil or place in a clean plastic bag until ready for use.

After decontamination of all sampling equipment, dispose of HDE and decontamination fluid in accordance with Oregon Plan and SD 00 *Management of Investigation Derived Waste*.

#### Cleaning of Small Sampling Equipment when Analyzing Inorganic Compounds

When necessary, remove all loose debris from sampling equipment into an empty clean 5-gallon bucket or plastic sheeting, using a clean dedicated stiff-bristled brush.

Scrub sampling equipment thoroughly using a second clean brush with non-phosphate detergent to remove all visible particulate matter.

Thoroughly rinse equipment with DI water to remove non-phosphate detergent from sampling equipment into a 5-gallon bucket. Sampling equipment can be rinsed into non-phosphate detergent and water bucket.

Thoroughly rinse sampling equipment with a 10% nitric acid from squirt bottle, and let excess acid drain into a separate waste 5-gallon bucket.

Double rinse with DI water into same 5-gallon bucket and allow sampling equipment to air dry. Equipment does not need to be dried prior to use.

When the sampling equipment is not to be used immediately, store in aluminum foil or place in clean plastic bag until ready for use.

After decontamination of all sampling equipment, dispose of HDE and decontamination fluid in accordance with Oregon Plan and SD 00 *Management of Investigation Derived Waste*.

## Specific Field Equipment Procedures

The following procedures are specific decontamination procedures for hand auguring, direct push drilling, sediment sampling, groundwater sampling and surface water sampling.

### Direct Push Drilling Equipment

In preparation of cleaning drilling tooling, a 1 mil thick plastic sheeting will be laid out and a clean over sized plastic tub (secondary containment) will be placed on plastic sheeting. 5-gallon rinse buckets should be placed within the plastic tub. When the drill rig or any heavy equipment comes in contact with contaminated soil, a decontamination pad should be constructed with the specification listed below. Drilling equipment that comes in contact with sample media should be cleaned in the field per the procedures described above. This includes but not limited to piston sampler point, screen point sampler, cutting shoes, and drive rods.

Disposable material such as sample tube liners, and sample tubing is not to be reused and is to be placed in a large heavy duty garbage bag which will be managed in accordance with Section 0000.

### Cleaning of Direct Push Drilling Equipment

1. Remove all loose debris from sampling equipment into an empty 5-gallon bucket or onto plastic sheeting using a stiff bristled brush, paper towel and/or cloth rag.
2. Break down components of the sampling tooling to clean each individual component separately.
3. Scrub sampling equipment thoroughly with non-phosphate detergent to removal all visible particulate matter.
4. Thoroughly rinse equipment with Dewater to remove non-phosphate detergent from sampling equipment into a 5-gallon bucket. Sampling equipment can be rinse off into non-phosphate detergent and water bucket.
5. Follow Steps through as described above for organic and inorganic compounds as specified.

#### Decontamination Pad Specification

The decontamination pad will be constructed only for the purpose for a drill rig and/or heavy equipment to drive into pad to be washed between mobilizations from areas of elevated contamination to relatively low contamination or onsite. The pad should be constructed in an area believed to be free of surface contamination. The pad should be bermed to eliminate potential leaching.

The pad should be constructed on a level surface and should facilitate the removal of wash water. This may be accomplished by either creating a sum or pit in one corner or along one side or constructing the pad with one corner lower than the rest.

Wooden pallets should be used for heavy tooling such as hollow stem augers so that the liner is not compromised from the weight and edges of the tooling.

Wash water should be removed from decontamination pad frequently and stored in appropriate labeled containers and stored with other investigation derived waste containers.

After completion of investigation, the decontamination pad should be deactivated. All waste water will be pumped into appropriately labeled containers and the area where the pad was staged should be returned to its original state.

#### Sediment Sampling

Any non-disposable fibercore sediment equipment (core catcher) that is used to obtain or comes in contact with sample media is to be cleaned in the field in accordance with the procedures described in Section 4.4.

#### Waste Management

Investigation derived wastes (IDW), including decontamination liquids and disposable materials (PPE, plastic sheeting, etc.), will be placed in clearly labeled, containers appropriate to material produced in accordance with SD 00 *Management of Investigation Derived Waste*, or managed as otherwise specified in the site-specific or plan.



## 6. Documentation

Documentation of the decontaminations will be completed in accordance with S□□ 00□□ *Documentation of Field Sample Activities*. The completed decontamination process will be recorded in the field notes.

## 7. References

E□□ SESDPROC – *Field Equipment Cleaning and Decontamination* □□/□□/0□□□

END □□D□□□MEN□

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Handling, Packaging, and Shipping**  
**of**  
**Analytical Samples**

**SOP ID: 10067**

**Date Initiated: 07/23/18**

**Prepared By: /s/ Jo Ann Robertson 07/19/18**

**Jo Ann Robertson                      Date**  
**Technical Associate**

**Reviewed By: /s/ William Morris 07/19/18**

**William C. Morris                      Date**  
**Technical Director, EHS**

**Approved By: /s/ Karen L. Harris 07/23/18**

**Karen Harris                      Date**  
**Quality Assurance Manager**

<u>Rev</u>	<u>Date</u>	<u>Additions/Deletions/Modifications</u>
Initial Issue	00/00/00	

**Loureiro Engineering Associates, Inc.**  
**Standard Operating Procedure**  
**for**  
**Handling, Packaging, and Shipping of Analytical Samples**

## 1. Purpose and Scope

This document describes the procedures to be followed for the protocols pertaining to the handling of samples in the field, chain-of-custody documentation, and the packaging and shipping of analytical samples. This Standard Operating Procedure (SOP) is to be used in conjunction with other Loureiro Engineering Associates, Inc. (LEA) SOPs and guidance for the performance of the associated field sampling activities.

The shipment (including packing, marking and labeling) of analytical samples is regulated by Department of Transportation under 49 CFR, Subchapter C, Hazardous Materials Regulations, and the International Air Transport Authority (IATA), which is equivalent to United Nations International Civil Aviation Organization (UN/ICAO). Anyone handling, packing, submitting a cooler or sample package for shipment must have IATA training every three years. Training records must be kept in the central file.

This SOP does not cover the transport of Materials of Trade in LEA vehicle or shipment of large sample containers.

## 2. Related Procedures

Project and client-specific requirements may be applicable to individual projects and should be discussed with the Project Manager and incorporated into the Project-Specific Work Plan or field sampling plan.

## 3. Definitions

- **Dangerous Goods:** those goods that meet the criteria of one or more of the nine UN hazard classes.
- **Inner Packing:** a package for which an outer package is required for transport (for example, a sample bottle).
- **Outer Packaging:** the outer protection of a composite or combination packaging together with any absorbent materials, cushioning and any other components necessary to contain and protect sample bottles.
- **Carrier:** a commercial company that is responsible for the actual shipment of environmental samples from the point of sample receipt from the shipper to the sample's final destination.

- Custody as defined in Section 000000 of E00, 0000: A sample is under custody if one or more of the following criteria are met:
  - The sample is in the sampler's possession
  - It is in the sampler's view after being in possession
  - It is in the sampler's possession and then is located up to prevent tampering
  - It is in a designated secure area

#### 4. Equipment

The following equipment and supplies shall be used during the handling, packaging, and shipping of analytical samples, as required:

- Cooler
- Sample labels
- Large plastic bag
- Tape
- Lens ballpoint
- Shipping labels
- Field marker or
- Packaging tape
- Protective packaging materials like, foam, bubble wrap
- Custody seals
- Chain of custody forms
- Field bag or equivalent

#### 5. Procedures

##### 0000 Field Procedures

##### Obtaining Sample Labels:

0000 Prior to initial start-up activities, the Project Manager, or Project Designee, shall submit the Project site information to the Database Manager. This information shall include: Project name, client name, commission and task number, site name, site location, field personnel, Project start date, type of field work, number and matrix of samples anticipated, analyses to be performed, any required field forms, and an approximate duration of field activities.

0000 Once the site information is entered in the database, requested field marker or sample identification numbers, sample labels, and custody seals may be obtained directly by field personnel through the database or by requesting verification by the Database Manager. This task should be completed 24 to 48 hours prior to initiation of field activities.

Sample labels Sample labels will have multiple unique seven-digit identification numbers, generated by the Loureiro database, printed on adhesive labels with analysis classes printed on them. The labels will be used to adhere to the appropriate containers attachment

## Shipping Determination

Prior to the mobilization for any sampling activities, the following steps must be completed to determine the hazard classes of the material to be shipped or transported. Environmental sample are not excluded from HCS or DOT regulation.

The Project team shall identify the potential constituents and the approximate concentrations in the sample using historical data or professional judgment based on the historical use of the area. Also, determine what sample preservatives will be used and volume in each bottle and the number of samples that will be in each cooler.

The cooler shipping name will be determined using the list of Dangerous Goods in Section 2 of the Dangerous Goods Manual. Once the cooler shipping name has been determined, use list of Dangerous Goods to determine the following:

- Requirements for both inner and outer packaging
- The quantity of the material that can be shipped as a non-dangerous good. Quality limits will include both the sample size and the number of samples per cooler or package
- Additional shipping instructions

The results of the Dangerous Goods analysis, including the cooler shipping name, packaging requirements and any special instructions will be documented and stored in the Project file **even it not determined to be a dangerous good.**

The shipping determinations are used as a method of hazard communication while the samples are in transit. The shipping determination will help the carrier or authorities determine the best approach for addressing a release.

The shipping determination will be completed even if the samples are being transported by a carrier because EPC cannot control the transportation method once it releases custody of the samples to the carrier.

If the samples are not determined to be a Dangerous Good and do not require specific packaging, they can be transported in a cooler.

## Chain of Custody Form Procedures

Once the samples have been collected, custody of the samples must be traced. The sample chain of custody forms and custody seals are provided in Appendix. The following information shall be provided on the chain of custody forms:

- Prior to collecting samples, fill out the Project information field, Project name, number, sampler names in the headers on the chain of custody form using a ballpoint pen.
- As samples are collected, specify the seven-digit sample number, date and time of collection, sample matrix, the type of analytical parameters and methods requested, and the preservatives used on the chain of custody.
- For aqueous samples, the information provided should clearly indicate which preservative is used for which analyses.
- Use the suffix 'u' after the seven-digit sample number to denote unfiltered metal samples, as applicable.
- Specify whether an electronic data deliverable (EDD) or data validation package is required.
- Specify the laboratory quote number, or any additional Project-specific requirements, such as reporting limits.

## Handling and Custody of Samples

Each sampling team will maintain a cooler containing ice and applicable 00/00 tri-blend samples prior to and during sample collection. The bottom of the cooler will be lined with packaging material, and ice inside of the cooler will be double bagged in sealed plastic bags to prevent samples from directly contacting melted ice and to prevent leakage during shipment and/or transportation. Blue ice shall not be used.

Coolers containing samples will be labeled with a unique, seven-digit, EID number, which will be recorded in the field notebook.

Collection of samples will adhere to applicable EID sample collection SOPs, as identified in the site-specific Work Plan or Field Sampling Plan.

Following collection into labeled, laboratory provided sample bags, samples will be placed in protective packaging foam, bubble wrap, or other protective packaging material, and then directly into the cooler containing ice and 00/00 samples.

EID Personnel will maintain custody of the samples according to the definition of custody as outlined in Section until custody is transferred to

Place the samples and ice into a large clear plastic bag. The ice bags should be placed along all sides of cooler and on the top of the samples. Glass 10 mL vials will be placed in the center of the cooler. The plastic bag will be sealed with tape once the samples and ice are placed in the coolers.



are will be taken when packing coolers for shipment during extreme temperatures hot or cold. Extra ice will be used during periods of elevated temperature. When the temperature is below freezing, place the glass jars or bottles in the center of the cooler and extra bubble wrap will be used to insulate the sample so the glass bottles are not shattered by expanding water. Glass 10mL vials will be placed on their sides so that expanding water pushes against the cap of the sample.

0000 The chain of custody form shall be placed inside of a ziploc bag or equivalent and taped to the inside lid of each cooler. The chain of custody form includes samples in multiple coolers, a copy of the chain of custody form will be placed in each cooler and a note will be added that the cooler is one of a group of coolers.


0000 Two custody seals should be used, one placed over the front opening and the other over the side opening for hinged cooler lids or the back opening for non-hinged cooler lids. Clear packing tape should be placed over the signed and dated custody seal. The tape should be placed so that it covers one half of the custody seal, continues around the cooler, and then covers the entire custody seal. The custody seal number should be recorded on the chain of custody form.

0000 Seal the cooler using sturdy tape.

0000 Place up arrow, the package contains wet ice, and fragile stickers on the outside of the cooler. Examples are provided below. Place any additional stickers onto the cooler as required by 0000.

00000 The shipment tracking number is known before the coolers are sealed, the tracking number should be recorded on the chain of custody form before it is sealed in the cooler so that it is on all copies of the 0000 and in the field notes. The tracking number is not known until shipment, it should be recorded on the retained copy of the chain of custody and in the field notes.

SD: 00  
Date initiated: 00/00/00  
Page 000



## 6. References

SM ASTM D4840 - *Standard Guide for Sampling Chain-of-Custody Procedures.*  
000

SM ASTM D6911-15 *Standard for Packing and Shipping Environmental Laboratory Analysis* 0000

EPA *Compendium of Superfund Field Operations Methods: Volume 1.* SE  
SE Directive 000000000000

IATA *Dangerous Goods Regulations (DGR) Manual*, International Air Transport  
Authority 0000

END DMMEN

## **ATTACHMENT 1**

Example Chain of Custody

Tunxis Laboratories, LLC

**Tel: (860) 793-8866**

Chain of Custody # 8183

Client:					Project Location:					Analysis Required:										Project Number / P.O. Number				
REPORT TO:																				Turnaround: 14 days Rush				
INVOICE TO:																								
Item	Sample Number	Source Code	Date of Collection	Time of Collection	Container Information														Tunxis Lab. No.	Transfer Number				
					Number	Type	Volume	Pres.												1	2	3	4	
1																								
2																								
3																								
4																								
5																								
6																								
7																								
8																								
9																								
10																								
11																								
12																								
13																								
Sampler:					Source Codes: W=Well MW=Monitoring Well RO=Runoff B=Bottom Sediment T=Treatment Facility S=Soil SG=Sludge LF=Landfill L=Lake/Ocean O=Outfall X=Other, Please Specify										Preservation Code: I=Iced S=H2SO4 N=HNO3 H=HCL R=NaOH T=Sodium Thiosulfate F=Filtered									
Transfer Number		Transfers Relinquished By			Accepted By			Date		Time		Comments:												
1																								
2																								
3																								
4																								

## **ATTACHMENT 2**

Example Sample Labels

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
SVOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555uf  
07MD509.001  
Centredale Manor Litigation Support  
Metals (unfiltered)  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
Standard Leachate  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
Miscellaneous Analyses  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
SVOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556uf  
07MD509.001  
Centredale Manor Litigation Support  
Metals (unfiltered)  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
Standard Leachate  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
Miscellaneous Analyses  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
PCB Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
TPH  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
Pesticides/Herbicides  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID  
.  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
PCB Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
TPH  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
Pesticides/Herbicides  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
Metals  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
ETPH  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378555  
07MD509.001  
Centredale Manor Litigation Support  
Physical Analyses  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID  
.  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
Metals  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
ETPH  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378556  
07MD509.001  
Centredale Manor Litigation Support  
Physical Analyses  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_

Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
Metals  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
ETPH  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
Physical Analyses  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
PCB Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
TPH  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
Pesticides/Herbicides  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
SVOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378557uf  
07MD509.001  
Centredale Manor Litigation Support  
Metals (unfiltered)  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
Standard Leachate  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
Miscellaneous Analyses  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
Metals  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
ETPH  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
Physical Analyses  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
PCB Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
TPH  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378557  
07MD509.001  
Centredale Manor Litigation Support  
Pesticides/Herbicides  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
VOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
SVOC Scan  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558uf  
07MD509.001  
Centredale Manor Litigation Support  
Metals (unfiltered)  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
Standard Leachate  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



Sample ID 1378558  
07MD509.001  
Centredale Manor Litigation Support  
Miscellaneous Analyses  
Date: \_\_/\_\_/\_\_ Time:\_\_:\_\_:\_\_



### **ATTACHMENT 3**

Example Custody Seal



CUSTODY SEAL	
[LEA CUSTODY SEAL/COOLER ID NUMBER]	
Date:	Sampler:
Time:	Signature

CUSTODY SEAL	
[LEA CUSTODY SEAL/COOLER ID NUMBER]	
Date:	Sampler:
Time:	Signature

CUSTODY SEAL	
[LEA CUSTODY SEAL/COOLER ID NUMBER]	
Date:	Sampler:
Time:	Signature

CUSTODY SEAL	
[LEA CUSTODY SEAL/COOLER ID NUMBER]	
Date:	Sampler:
Time:	Signature

CUSTODY SEAL	
[LEA CUSTODY SEAL/COOLER ID NUMBER]	
Date:	Sampler:
Time:	Signature

CUSTODY SEAL	
[LEA CUSTODY SEAL/COOLER ID NUMBER]	
Date:	Sampler:
Time:	Signature

CUSTODY SEAL	
[LEA CUSTODY SEAL/COOLER ID NUMBER]	
Date:	Sampler:
Time:	Signature

CUSTODY SEAL	
[LEA CUSTODY SEAL/COOLER ID NUMBER]	
Date:	Sampler:
Time:	Signature

CUSTODY SEAL	
[LEA CUSTODY SEAL/COOLER ID NUMBER]	
Date:	Sampler:
Time:	Signature

CUSTODY SEAL	
[LEA CUSTODY SEAL/COOLER ID NUMBER]	
Date:	Sampler:
Time:	Signature