

### **ANALYTICAL REPORT**

Job Number: 280-70279-3

Job Description: GSI - McConnell AFB - SWMU 207

For:

GSI Environmental, Inc 9600 Great Hills Trail, Ste 350E Austin, TX 78759

Attention: Anna Zabierek

M. Elains Walker


Approved for release Elaine M Walker Project Manager II 6/25/2015 3:14 PM

Elaine M Walker, Project Manager II 4955 Yarrow Street, Arvada, CO, 80002 (303)736-0156 elaine.walker@testamericainc.com 06/25/2015

The test results in this report relate only to the samples in this report and meet all requirements of NELAC, with any exceptions noted. Pursuant to NELAP, this report shall not be reproduced except in full, without the written approval of the laboratory. All questions regarding this report should be directed to the TestAmerica Denver Project Manager.

The Lab Certification ID# is 4025.

Reporting limits are adjusted for sample size used, dilutions and moisture content if applicable.





### **Table of Contents**

Cc	over Title Page	1
Da	ata Summaries	4
	Report Narrative	4
	Sample Summary	5
	Executive Summary	6
	Method Summary	7
	Method / Analyst Summary	8
	Sample Datasheets	9
	QC Data Summary	10
	Data Qualifiers	13
	QC Association Summary	14
	Lab Chronicle	15
	Reagent Traceability	17
	COAs	18
	Certification Summary	21
Ind	organic Sample Data	22
	General Chemistry Data	22
	Gen Chem Cover Page	23
	Gen Chem Sample Data	24
	Gen Chem QC Data	25
	Gen Chem ICV/CCV	25
	Gen Chem Blanks	26
	Gen Chem MS/MSD/PDS	27
	Gen Chem Duplicates	29
	Gen Chem LCS/LCSD	30
	Gen Chem MDL	31

### **Table of Contents**

	Gen Chem Preparation Log	35
	Gen Chem Analysis Run Log	36
	Gen Chem Raw Data	39
	Gen Chem Prep Data	46
Shi	ipping and Receiving Documents	51
	Client Chain of Custody	52
	Sample Receipt Checklist	53

### **CASE NARRATIVE**

Client: GSI Environmental, Inc

Project: GSI - McConnell AFB - SWMU 207

**Report Number: 280-70279-3** 

With the exceptions noted as flags or footnotes, standard analytical protocols were followed in the analysis of the samples and no problems were encountered or anomalies observed. In addition all laboratory quality control samples were within established control limits, with any exceptions noted below. Each sample was analyzed to achieve the lowest possible reporting limit within the constraints of the method. In some cases, due to interference or analytes present at high concentrations, samples were diluted. For diluted samples, the reporting limits are adjusted relative to the dilution required.

Calculations are performed before rounding to avoid round-off errors in calculated results.

All holding times were met and proper preservation noted for the methods performed on these samples, unless otherwise detailed in the individual sections below.

#### RECEIPT

Six samples were received on 06/05/2015; the samples arrived in good condition, properly preserved and on ice. The temperature of the cooler at receipt was 1.9°C.

The Chain of Custody does not list a sample collection time for trip blank sample 54403-TB19-0615 (280-70279-1). The sample was logged with a collection time of 09:00 per instructions received on Friday, June 05, 2015.

The Chain of Custody requests that samples 54400-MW43-0615 (280-70279-3) and 54400-MW55D-0615 (280-70279-6) be analyzed on a rush turnaround time for the VOC analysis. Due to current laboratory capacity, the fastest turnaround time that TA Denver is able to provide for the requested analyses is 10 business days.

The rush VOC analysis for samples 54400-MW43-0615 (280-70279-3) and 54400-MW55D-0615 (280-70279-6) will be reported under SDG 280-70279-2 on a 10 business day turnaround time with a Level II report. The results of these rush samples, along with the other samples/analyses will be reported with a Level IV report and EDD under SDG 280-70279-1 on a standard 15 business day turnaround time.

Please note - this report contains the results of Total Phosphorus and Sulfite, which the TestAmerica Denver laboratory does not hold DoD ELAP certification for. These parameters are being reported under the TestAmerica Standard QC program, and not as a DoD QSM 5.0 report.

### **TOTAL PHOSPHORUS**

Sample 54400-MW55D-0615 (280-70279-6) was analyzed for total phosphorus in accordance with EPA Method 365.1. The sample was prepared and analyzed on 06/19/2015.

No analytical or quality issues were noted, other than those described above or in the Definitions/Glossary page.

#### SULFITE

Sample 54400-MW55D-0615 (280-70279-6) was analyzed for sulfite in accordance with SM20 4500 SO3 B. The sample was analyzed on 06/08/2015.

No analytical or quality issues were noted, other than those described above or in the Definitions/Glossary page.

### **SAMPLE SUMMARY**

Client: GSI Environmental, Inc Job Number: 280-70279-3

Lab Sample ID	Client Sample ID	Client Matrix	Sampled	Received	_
280-70279-6	54400-MW55D-0615	Water	06/04/2015 1510	06/05/2015 0700	

### **EXECUTIVE SUMMARY - Detections**

Client: GSI Environmental, Inc Job Number: 280-70279-3

Lab Sample ID Analyte	Client Sample ID	Result	Qualifier	Reporting Limit	Units	Method
280-70279-6	54400-MW55D-0615					
Total Phosphorus as	s PO4	0.016	J	0.15	mg/L	365.1

### **METHOD SUMMARY**

Client: GSI Environmental, Inc Job Number: 280-70279-3

Description	Lab Location	Method	Preparation Method
Matrix: Water			
Phosphorus, Total	TAL DEN	EPA 365.1	
Phosphorus, Total	TAL DEN		MCAWW 365.2/365.3/365
Sulfite	TAL DEN	SM SM 4500	SO3 B

### Lab References:

TAL DEN = TestAmerica Denver

### **Method References:**

EPA = US Environmental Protection Agency

MCAWW = "Methods For Chemical Analysis Of Water And Wastes", EPA-600/4-79-020, March 1983 And Subsequent Revisions.

SM = "Standard Methods For The Examination Of Water And Wastewater"

### **METHOD / ANALYST SUMMARY**

Client: GSI Environmental, Inc Job Number: 280-70279-3

Method	Analyst	Analyst ID
EPA 365.1	Schwemin, Andrew J	AJS
SM SM 4500 SO3 B	Bland, Morgan R	MRB

### **Analytical Data**

Client: GSI Environmental, Inc Job Number: 280-70279-3

### **General Chemistry**

54400-MW55D-0615 Client Sample ID:

280-70279-6 Date Sampled: 06/04/2015 1510 Lab Sample ID: Date Received: 06/05/2015 0700 Client Matrix:

Water

MDL RLAnalyte Result Qual Units Dil Method Total Phosphorus as PO4 0.016 J mg/L 0.015 0.15 1.0 365.1

Analysis Batch: 280-282883 Analysis Date: 06/19/2015 2230 Prep Batch: 280-282836 Prep Date: 06/19/2015 1544

Sulfite 0.50 U HF mg/L 0.50 2.0 1.0 SM 4500 SO3

Analysis Batch: 280-280818 Analysis Date: 06/08/2015 1208

Client: GSI Environmental, Inc. Job Number: 280-70279-3

Method Blank - Batch: 280-282836 Method: 365.1

Preparation: 365.2/365.3/365

WC\_Konelab MB 280-282836/4-A Analysis Batch: 280-282883 Lab Sample ID: Instrument ID:

Client Matrix: Water Prep Batch: 280-282836 Lab File ID: 061915TPHOS.xls Leach Batch: 50.0 ml 1.0 N/A Dilution: Initial Weight/Volume:

Analysis Date: 06/19/2015 2230 mg/L Final Weight/Volume: 50.0 mL Units:

Prep Date: 06/19/2015 1544

RL MDL Analyte Result Qual

U Total Phosphorus as PO4 0.015 0.015 0.15

Lab Control Sample - Batch: 280-282836 Method: 365.1

Leach Date:

Leach Date:

N/A

N/A

N/A

N/A

Preparation: 365.2/365.3/365

Analysis Batch: LCS 280-282836/3-A 280-282883 WC Konelab Lab Sample ID: Instrument ID:

Prep Batch: 061915TPHOS.xls Client Matrix: Water 280-282836 Lab File ID: Leach Batch: 50.0 mL Dilution: 1.0 N/A Initial Weight/Volume:

Analysis Date: 06/19/2015 2230 Units: mg/L Final Weight/Volume: 50.0 mL

06/19/2015 1544 Prep Date:

Analyte Spike Amount Result % Rec. Limit Qual Total Phosphorus as PO4 90 - 110 1.53 1.65 108

Method: 365.1 Matrix Spike/

Preparation: 365.2/365.3/365 Matrix Spike Duplicate Recovery Report - Batch: 280-282836

MS Lab Sample ID: 280-70279-6 Analysis Batch: 280-282883 WC Konelab Instrument ID:

Prep Batch: 280-282836 061915TPHOS.xls Client Matrix: Water Lab File ID: 1.0 Leach Batch: 50.0 mL Dilution:

N/A Initial Weight/Volume: 06/19/2015 2230 50.0 mL Analysis Date: Final Weight/Volume:

Prep Date: 06/19/2015 1544 Leach Date:

MSD Lab Sample ID: 280-70279-6 Analysis Batch: 280-282883 WC Konelab Instrument ID:

Water Prep Batch: 280-282836 061915TPHOS.xls Client Matrix: Lab File ID:

1.0 Leach Batch: 50.0 mL Dilution: N/A Initial Weight/Volume: 50.0 mL

Analysis Date: 06/19/2015 2230 Final Weight/Volume:

Prep Date: 06/19/2015 1544 Leach Date:

107

105

% Rec. MS **MSD** MS Qual MSD Qual Analyte Limit **RPD RPD Limit** Total Phosphorus as PO4 90 - 110 2

10

Client: GSI Environmental, Inc Job Number: 280-70279-3

Matrix Spike/ Method: 365.1

Matrix Spike Duplicate Recovery Report - Batch: 280-282836 Preparation: 365.2/365.3/365

MS Lab Sample ID: 280-70279-6 Units: mg/L MSD Lab Sample ID: 280-70279-6

Client Matrix: Water Client Matrix: Water

Dilution: 1.0 Dilution: 1.0

Analysis Date: 06/19/2015 2230 Analysis Date: 06/19/2015 2230 Prep Date: 06/19/2015 1544 Prep Date: 06/19/2015 1544

Leach Date: N/A Leach Date: N/A

Analyte	Sample	MS Spike	MSD Spike	MS	MSD
	Result/Qual	Amount	Amount	Result/Qual	Result/Qual
Total Phosphorus as PO4	0.016 J	1.53	1.53	1.63	1.66

2.0

Client: GSI Environmental, Inc Job Number: 280-70279-3

Method Blank - Batch: 280-280818 Method: SM 4500 SO3 B Preparation: N/A

MB 280-280818/1 Analysis Batch: 280-280818 No Equipment Assigned Lab Sample ID: Instrument ID:

Client Matrix: Water Prep Batch: N/A Lab File ID: N/A 1.0 Leach Batch: 50 mL N/A Initial Weight/Volume: Dilution:

06/08/2015 1208 Analysis Date: Units: mg/L Final Weight/Volume: 50 mL Prep Date: N/A

Leach Date:

Leach Date:

Leach Date:

Sulfite

Sulfite

N/A

N/A

N/A

MDL RL Result Analyte Qual 0.50

Lab Control Sample - Batch: 280-280818 Method: SM 4500 SO3 B

Preparation: N/A

LCS 280-280818/2 Analysis Batch: 280-280818 Instrument ID: No Equipment Assigned Lab Sample ID:

U

0.50

Prep Batch: Client Matrix: Water N/A Lab File ID: N/A Leach Batch: 50 mL Dilution: 1.0 N/A Initial Weight/Volume:

06/08/2015 1208 Analysis Date: Units: mg/L Final Weight/Volume: 50 mL Prep Date: N/A

Analyte Spike Amount Result % Rec. Limit

Qual Sulfite 31.0 20.0 65 50 - 150

Duplicate - Batch: 280-280818 Method: SM 4500 SO3 B Preparation: N/A

280-70279-6 Analysis Batch: 280-280818 No Equipment Assigned Lab Sample ID: Instrument ID:

Water Prep Batch: Client Matrix: N/A Lab File ID: N/A 1.0 Leach Batch: 50 mL Dilution: Initial Weight/Volume: N/A

06/08/2015 1208 50 mL Analysis Date: Units: mg/L Final Weight/Volume: Prep Date: N/A

0.50

Analyte Sample Result/Qual Result RPD Limit Qual

IJ

0.50

NC

20

IJ

### **DATA REPORTING QUALIFIERS**

Client: GSI Environmental, Inc Job Number: 280-70279-3

Lab Section	Qualifier	Description
General Chemistry		
	HF	Field parameter with a holding time of 15 minutes. Test performed by laboratory at client's request.
	U	Indicates the analyte was analyzed for but not detected.
	J	Result is less than the RL but greater than or equal to the MDL and the concentration is an approximate value.

Client: GSI Environmental, Inc Job Number: 280-70279-3

### **QC Association Summary**

		Report			
Lab Sample ID	Client Sample ID	Basis	Client Matrix	Method	Prep Batch
General Chemistry					
Analysis Batch:280-28	0818				
LCS 280-280818/2	Lab Control Sample	T	Water	SM 4500 SO3 B	
MB 280-280818/1	Method Blank	T	Water	SM 4500 SO3 B	
280-70279-6	54400-MW55D-0615	T	Water	SM 4500 SO3 B	
280-70279-6DU	Duplicate	Т	Water	SM 4500 SO3 B	
Prep Batch: 280-28283	36				
LCS 280-282836/3-A	Lab Control Sample	Т	Water	365.2/365.3/365	
MB 280-282836/4-A	Method Blank	Т	Water	365.2/365.3/365	
280-70279-6	54400-MW55D-0615	Т	Water	365.2/365.3/365	
280-70279-6MS	Matrix Spike	Т	Water	365.2/365.3/365	
280-70279-6MSD	Matrix Spike Duplicate	Т	Water	365.2/365.3/365	
Analysis Batch:280-28	2883				
LCS 280-282836/3-A	Lab Control Sample	T	Water	365.1	280-282836
MB 280-282836/4-A	Method Blank	T	Water	365.1	280-282836
280-70279-6	54400-MW55D-0615	Т	Water	365.1	280-282836
280-70279-6MS	Matrix Spike	Т	Water	365.1	280-282836
280-70279-6MSD	Matrix Spike Duplicate	T	Water	365.1	280-282836
	• •				

Report Basis T = Total

Client: GSI Environmental, Inc Job Number: 280-70279-3

### **Laboratory Chronicle**

Lab ID: 280-70279-6 Client ID: 54400-MW55D-0615

Sample Date/Time: 06/04/2015 15:10 Received Date/Time: 06/05/2015 07:00

			Analysis		Date Prepared /			
Method	Bottle ID	Run	Batch	Prep Batch	Analyzed	Dil	Lab	Analyst
P:365.2/365.3/36	280-70279-F-6-A		280-282883	280-282836	06/19/2015 15:44	1	TAL DEN	AJS
5 A:365.1	280-70279-F-6-A		280-282883	280-282836	06/19/2015 22:30	1	TAL DEN	AJS
A:SM 4500 SO3 E	280-70279-A-6		280-280818		06/08/2015 12:08	1	TAL DEN	MRB

Lab ID: 280-70279-6 MS Client ID: 54400-MW55D-0615

Sample Date/Time: 06/04/2015 15:10 Received Date/Time: 06/05/2015 07:00

			Analysis		Date Prepared /			
Method	Bottle ID	Run	Batch	Prep Batch	Analyzed	Dil	Lab	Analyst
P:365.2/365.3/36 5	280-70279-F-6-B MS		280-282883	280-282836	06/19/2015 15:44	1	TAL DEN	AJS
A:365.1	280-70279-F-6-B MS		280-282883	280-282836	06/19/2015 22:30	1	TAL DEN	AJS

Lab ID: 280-70279-6 MSD Client ID: 54400-MW55D-0615

Sample Date/Time: 06/04/2015 15:10 Received Date/Time: 06/05/2015 07:00

			Analysis		Date Prepared /			
Method	Bottle ID	Run	Batch	Prep Batch	Analyzed	Dil	Lab	Analyst
P:365.2/365.3/36 5	280-70279-F-6-C MSD		280-282883	280-282836	06/19/2015 15:44	1	TAL DEN	AJS
A:365.1	280-70279-F-6-C MSD		280-282883	280-282836	06/19/2015 22:30	1	TAL DEN	AJS

Lab ID: 280-70279-6 DU Client ID: 54400-MW55D-0615

Sample Date/Time: 06/04/2015 15:10 Received Date/Time: 06/05/2015 07:00

			Analysis		Date Prepared /			
Method	Bottle ID	Run	Batch	Prep Batch	Analyzed	Dil	Lab	Analyst
A:SM 4500 SO3 E	280-70279-A-6 DU		280-280818		06/08/2015 12:08	1	TAL DEN	MRB

Lab ID: MB Client ID: N/A

Sample Date/Time: N/A Received Date/Time: N/A

		Analysis		Date Prepared /			
Bottle ID	Run	Batch	Prep Batch	Analyzed	Dil	Lab	Analyst
MB 280-282836/4-A		280-282883	280-282836	06/19/2015 15:44	1	TAL DEN	AJS
MB 280-282836/4-A		280-282883	280-282836	06/19/2015 22:30	1	TAL DEN	AJS
MB 280-280818/1		280-280818		06/08/2015 12:08	1	TAL DEN	MRB
	MB 280-282836/4-A	MB 280-282836/4-A MB 280-282836/4-A	Bottle ID         Run         Batch           MB 280-282836/4-A         280-282883           MB 280-282836/4-A         280-282883	Bottle ID         Run         Batch         Prep Batch           MB 280-282836/4-A         280-282883         280-282836           MB 280-282836/4-A         280-282883         280-282836	Bottle ID         Run         Batch         Prep Batch         Analyzed           MB 280-282836/4-A         280-282883         280-282836         06/19/2015         15:44           MB 280-282836/4-A         280-282883         280-282836         06/19/2015         22:30	Bottle ID         Run         Batch         Prep Batch         Analyzed         Dil           MB 280-282836/4-A         280-282883         280-282836         06/19/2015         15:44         1           MB 280-282836/4-A         280-282883         280-282836         06/19/2015         22:30         1	Bottle ID         Run         Batch         Prep Batch         Analyzed         Dil         Lab           MB 280-282836/4-A         280-282883         280-282836         06/19/2015         15:44         1         TAL DEN           MB 280-282836/4-A         280-282883         280-282836         06/19/2015         22:30         1         TAL DEN

TestAmerica Denver A = Analytical Method P = Prep Method
Page 15 of 53
06/25/2015

Client: GSI Environmental, Inc Job Number: 280-70279-3

### **Laboratory Chronicle**

Lab ID: LCS Client ID: N/A

> Received Date/Time: N/A Sample Date/Time: N/A

			Analysis		Date Prepared /			
Method	Bottle ID	Run	Batch	Prep Batch	Analyzed	Dil	Lab	Analyst
P:365.2/365.3/36	LCS 280-282836/3-A		280-282883	280-282836	06/19/2015 15:44	1	TAL DEN	AJS
5								
A:365.1	LCS 280-282836/3-A		280-282883	280-282836	06/19/2015 22:30	1	TAL DEN	AJS
A:SM 4500 SO3 B	LCS 280-280818/2		280-280818		06/08/2015 12:08	1	TAL DEN	MRB

### Lab References:

TAL DEN = TestAmerica Denver

TestAmerica Denver A = Analytical Method P = Prep Method 06/25/2015

#### REAGENT TRACEABILITY SUMMARY

Lab	Name:	TestAmerica	Denver	Job No.:	280-70279-3
SDG	No ·				

	Exp	Prep	Dilutant	Reagent Final	Parent Reagent	Volume		
Reagent ID	Date	Date	Used	Volume	Reagent ID	Added	Analyte	Concentration
Phos Cal Int_00301	06/24/15	06/17/15	Di Water, Lot na	100 mL	phos cal std_00019	1 mL	Orthophosphate	10 mg/L
_							P	10 mg/L
							Total Phosphorus as PO4	30.66 mg/L
.phos cal std_00019	08/01/16		Ricca, Lot 4408888		(Purchased Reager	nt)	Orthophosphate	1000 mg/L
							P	1000 mg/L
							Total Phosphorus as PO4	3066 mg/L
phos icv Int_00280	06/23/15	06/16/15	Di Water, Lot na	100 mL	Phos ICV std_00010	1 mL	Orthophosphate	10 mg/L
							P	10 mg/L
							Total Phosphorus as PO4	30.66 mg/L
.Phos ICV std_00010	07/18/16		Lab Chem, Lot D198-09		(Purchased Reager	nt)	Orthophosphate	1000 mg/L
							P	1000 mg/L
							Total Phosphorus as PO4	3066 mg/L
Sulfite LCS_00131	06/09/15	06/08/15	Di Water, Lot na	1000 mL	sodium	0.314 g	Sulfite	309.918 mg/L
					sulfit 00005			
.sodium sulfit_00005	03/31/17		Acros, Lot A0343849		(Purchased Reager	nt)	Sulfite	98.7 %



### RICCA CHEMICAL COMPANY

Arlington, TX 76012
Pocomoke City, MD 21851
Batesville, IN 47006
http://www.riccachemical.com
1-888-GO-RICCA
customerservice@riccachemical.com

### Certificate of Analysis

Phosphorus AA Standard, 1 mL = 1 mg P (1,000 ppm P) NH4H2PO4 in H2O

Lot Number: 4408888

Product Number: AP1KW

Expiration Date: AUG 2016

Manufacture Date:8/26/2014

This is a single element solution that was prepared volumetrically to contain the certified value reported. The uncertainty associated with the certified value is the sum of the estimated errors due to the purity of the raw material, the volumetric preparation of the solution, and transpiration of the solution through the container wall.

The final solution concentration is confirmed by AA, ICP, or ICP-MS, and is traceable to NIST Standard Reference Material 3139.

This product number replaces 5857 as of 2007.

#### Contains:

Name	CAS#	Grade
Ammonium Dihydrogen Phosphate, NH4H2PO4	7722-76-1	High Purity
Water, Deionized, H2O	7732-18-5	ACS, ASTM D 1193 (Type I)

Test Name	Assay Method	Specification	Result
Appearance	Clarity, Color, Odor	Clear, colorless, odorless	Passed Test
Certified Concentration	Based on accurate volumetric	$1000 \pm 5 \text{ ppm P}$	1000 ppm P
	preparation		0.000000000000000 <b>♣</b> Such ted

Volumetric glassware complies with Class A tolerance requirements of ASTM E 288 and NIST Circular 434; it is calibrated before first use and recalibrated regularly in accordance with ASTM E 542 and NIST Procedure NBSIR 74-461. Balances are calibrated regularly with weights certified traceable to the NIST national mass standard. Thermometers and temperature probes are calibrated before first use and recalibrated regularly with a thermometer traceable to NIST standards. All products are prepared according to master documents that assure manufacture according to validated methods. Batch records document raw material traceability and production and testing history for each lot manufactured.

Shelf Life (unopened container):

Part Number	Shelf Life	- 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	
AP1KW-100	24 months		
AP1KW-500	24 months		
	Parties of the Control of the Contro		

Recommended Storage: 15°C - 30°C (59°F - 86°F)

felle Chlhausen

LaNelle Ohlhausen Quality Assurance

This Certificate of Analysis is designed to comply with ISO Guide 31 "Reference Materials -- Contents of Certificates and Labels."

To determine manufacture site using lot number, visit <a href="http://www.riccachemical.com/Documents/lot.pdf">http://www.riccachemical.com/Documents/lot.pdf</a>.



Jackson's Pointe Commerce Park - Building 1000 1010 Jackson's Pointe Court, Zelienople, PA 16063 Ph: 412-826-5230 | Fax: 724-473-0647 | www.labchem.com

### **CERTIFICATE OF ANALYSIS**

Description: PHOSPHATE (AS PHOSPHORUS) STANDARD, 1000ppm (1mL = 1mg P)

Catalog Number: LC18590

Lot Number: D198-09

Mfg Date:

07/18/2014

Expiration Date: 07/18/2016

### **ANALYTICAL SECTION**

Test	Specification	Test Result
Appearance	clear, colorless solution	Pass Test
Concentration ppm P	1000ppm +/- 10ppm	1004ppm
Concentration mg P/mL	1.000 +/- 0.010 mg P/mL	1.004 mg P/mL
Traceable to NIST	Potassium Hydrogen Phthalate	84L


Submitted By: Greg Albright, Chemist Supervisor

An ISO9001:2008 certified company. Registration # 0306-01

09/19/2014 9:50:35 AM

Form #17.12 06/19/2012

Page 1 of 1



# ACRŌS ORGANICS

Version0Molecular weight126.04Molecular formulaNa2 O3 SCAS No7757-83-7Linear formulaNa2SO3

Flash point (°C)

### Certificate of Analysis

Acros Organics quality system has been found to conform to quality management system ISO9001:2008 standard by SAI global Certificate number CERT-0063301.

This is to certify that units of the below mentioned lot number were tested and found to comply with the specifications of the grade listed. Certain data have been supplied by third parties. Acros Organics expressly disclaims all warranties, expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose. Unless otherwise stated, these products are not intended for use in manufacturing, consumption or application of drugs, cosmetics, dialysis, parenteral, injectable products, household chemicals, food additives, agricultural or pesticide products without further processing. The following are the actual analytical results obtained;

Catalog Number	21927	Quality Test / Release Date	24 January 2014		
Lot Number	A0343849 Suggested Retest Date		January 2019		
Description	Sodium sulfite,98.5%,for analysis,anhydrous				
Country of Origin	BELGIUM				
Declaration of Origin	synthetic				

### Origin Comment

Result Name	Specifications	Test Value	
Appearance	White fine crystals or crystalline powder	White fine crystals	
Assay Iodimetry	>=98 %	98.5 %	
Heavy metals (as Pb)	=<10 ppm	=<10 ppm	
Free acid	passes test	passes test	
Free alkali (Na2CO3)	=<0.15 %	=<0.15 %	
Trace analysis	Type: Cl measure =< 100 ppm	Type: CI measure =< 30 ppm	
Trace analysis Type: Fe measure =< 10 ppm		Type: Fe measure =< 10 ppm	
Trace analysis	Type: As measure =< 1 ppm	Type: As measure =< 1 ppm	



L. Van den Broek, QA Manager

On Ola Block

Issued: 21 February 2015

Acros Organics

ENA23, zone 1, nr 1350, Janssen Pharmaceuticalaan 3a, B-2440 Geel, Belgium Tel +32 14/57.52.11 - Fax +32 14/59.34.34 Internet: <a href="http://www.acros.com">http://www.acros.com</a>

1 Reagent Lane, Fair Lawn, NJ 07410,USA Fax 201-796-1329

### **Certification Summary**

Client: GSI Environmental, Inc.

TestAmerica Denver

TestAmerica Denver

TestAmerica Denver

TestAmerica Denver

TestAmerica Denver

TestAmerica Denver

Utah

Virginia

Washington

Wisconsin

West Virginia DEP

Wyoming (UST)

Project/Site: GSI - McConnell AFB - SWMU 207

Laboratory **Authority Program EPA Region Certification ID** TestAmerica Denver A2LA DoD ELAP 2907.01 A2LA ISO/IEC 17025 TestAmerica Denver 2907.01 TestAmerica Denver Alaska (UST) State Program 10 UST-30 9 State Program AZ0713 TestAmerica Denver Arizona 6 TestAmerica Denver Arkansas DEQ State Program 88-0687 9 TestAmerica Denver California State Program 2513 TestAmerica Denver Connecticut 1 PH-0686 State Program TestAmerica Denver Florida 4 E87667 TestAmerica Denver Georgia 4 N/A State Program Illinois 200017 TestAmerica Denver **NELAP** 7 TestAmerica Denver Iowa State Program 370 7 TestAmerica Denver Kansas **NELAP** E-10166 6 TestAmerica Denver **NELAP** 02096 Louisiana TestAmerica Denver Maine State Program 1 CO0002 5 TestAmerica Denver Minnesota **NELAP** 8-999-405 TestAmerica Denver Nevada State Program CO0026 TestAmerica Denver New Hampshire **NELAP** 1 205310 TestAmerica Denver **NELAP** 2 CO004 New Jersey 2 TestAmerica Denver New York NELAP 11964 TestAmerica Denver North Carolina (WW/SW) 4 358 State Program TestAmerica Denver North Dakota State Program 8 R-034 6 8614 TestAmerica Denver Oklahoma State Program 4025 TestAmerica Denver Oregon **NELAP** 10 3 TestAmerica Denver Pennsylvania **NELAP** 68-00664 State Program 4 TestAmerica Denver South Carolina 72002001 TestAmerica Denver Texas **NELAP** 6 T104704183-13-8 TestAmerica Denver **USDA** Federal P330-13-00202 8

Accreditation may not be offered or required for all methods and analytes reported in this package. Please contact your project manager for the laboratory's current list of certified methods and analytes.

NELAP

**NELAP** 

A2LA

State Program

State Program

State Program

3

10

3

5

8

TestAmerica Job ID: 280-70279-3

CO00026

999615430

2907.01

460232

C583

354

# GENERAL CHEMISTRY

### COVER PAGE GENERAL CHEMISTRY

Lab Name	: TestAmerica Denver	Job Number: 280-70279-3
SDG No.:		
Project:	GSI - McConnell AFB - SWMU 207	
	Client Sample ID 54400-MW55D-0615	Lab Sample ID 280-70279-6

Comments:

# 1B-IN INORGANIC ANALYSIS DATA SHEET GENERAL CHEMISTRY

Client Sample ID: 54400-MW55D-0615	Lab Sample ID: 280-70279-6
Lab Name: TestAmerica Denver	Job No.: 280-70279-3
SDG ID.:	
Matrix: Water	Date Sampled: 06/04/2015 15:10
Reporting Basis WET	Date Received: 06/05/2015 07:00

CAS No.	Analyte	Result	RL	MDL	Units	С	Q	DIL	Method
	Total Phosphorus as PO4	0.016	0.15	0.015	mg/L	J		1	365.1
14265-45-3	Sulfite	0.50	2.0	0.50	mg/L	Ū	HF	1	SM 4500 SO3 B

# 2-IN CALIBRATION QUALITY CONTROL GENERAL CHEMISTRY

Lab Name: TestAmerica Denver Job No.: 280-70279-3

SDG No.:

Analyst: AJS Batch Start Date: 06/19/2015

Reporting Units: mg/L Analytical Batch No.: 282883

Sampl	QC Tyne	Time	Analyte	Result	Spike Amoun	(%) Recovery	Limits	Qual	Reagent
-	1 ICV	22:30	Total Phosphorus as PO4	1.29	1.23	105	90-110		phos icv Int 00280
2	2 ICB	22:30	Total Phosphorus as PO4	0.015				U	
3	8 CCV	22:30	Total Phosphorus as PO4	1.65	1.53	108	90-110		Phos Cal Int 00301
9	9 CCB	22:30	Total Phosphorus as PO4	0.015				Ū	-

### 3-IN METHOD BLANK GENERAL CHEMISTRY

Lab Name: TestAmerica Denver Job No.: 280-70279-3

SDG No.:

Method	Lab Sample ID	Analyte	Result Qual Units	RL	Dil
Batch II	282883 Date:	06/19/2015 22:30 Prep Batch: Total Phosphorus as	282836 Date: 06/19/2015 0.015 U mg/L	0.15	1
	280-282836/4-A	PO4			
Batch II	: 280818 Date:	06/08/2015 12:08			
SM 4500	MB 280-280818/1	Sulfite	0.50 U mg/L	2.0	1
SO3 B					

### 5-IN MATRIX SPIKE SAMPLE RECOVERY GENERAL CHEMISTRY

Lab Name:	TestAmerica Denver	Job No.:	280-70279-3
SDG No.:			

Matrix: Water

Method	Lab Sample I	D Analyte	Result C Unit	Spike Pct. RPD Amount Rec. Limits RPD Limi Q	2
Batch 365.1	ID: 282883 280-70279-6	Date: 06/19/2015 22:30 Total Phosphorus as	Prep Batch: 282836 0.016 J mg/L	Date: 06/19/2015 15:44	
365.1	280-70279-6 MS	PO4 Total Phosphorus as PO4	1.63 mg/L	1.53 105 90-110	

# 5-IN MATRIX SPIKE DUPLICATE SAMPLE RECOVERY GENERAL CHEMISTRY

Lab	Name:	TestAmerica Denver	Job No.:	280-70279-3
SDG	No.:			

Matrix: Water

Method Lab Sample ID Analyte	Result C Unit	Spike Pct. RPD RPD Amount Rec. Limits RPD Limi	Q
Batch ID: 282883 Date: 06/19/2015 22:30	Prep Batch: 282836	Date: 06/19/2015 15:44	
365.1 280-70279-6 Total Phosphorus as	1.66 mg/L	1.53 107 90-110 2 10	
MSD PO4			

### 6-IN DUPLICATE GENERAL CHEMISTRY

Lab	Name:	TestAmerica	Denver	Job No.:	280-70279-3
-----	-------	-------------	--------	----------	-------------

SDG No.: \_\_\_\_

Matrix: Water

Method	Client Sample ID	Lab Sample ID	Analyte	Result	Unit	RPD	RPD T.i mi	Qual
Batch ID:	280818 Date: 06/	08/2015 12:08						
SM 4500	54400-MW55D-0615	280-70279-6	Sulfite	0.50	mg/L			U
SO3 B								
SM 4500	54400-MW55D-0615	280-70279-6 DU	Sulfite	0.50	mg/L	NC	20	U
SO3 B								

# 7A-IN LAB CONTROL SAMPLE GENERAL CHEMISTRY

Lab	Name:	TestAmerica Denver	Job No.:	280-70279-3
SDG	No.: _			

Matrix: Water

Method	Lab Sample ID	Analyte	Result C Unit	Spike P Amount R	ct. ec. Limits RPI	RPD T.imi	Q
Batch	ID: 282883	Date: 06/19/2015 22:30	Prep Batch: 282836		/19/2015 15:44		
			LCS S	Source: Pho	s Cal Int_00301		
365.1	LCS 280-282836/3 -A	Total Phosphorus as PO4	1.65 mg/L	1.53	108 90-110		
Batch	ID: 280818	Date: 06/08/2015 12:08					
			LCS S	Source: Sul	fite LCS 00131		
SM 4500 SO3 B	LCS 280-280818/2	Sulfite	20.0 mg/L	31.0	65 50 <b>-</b> 150		

# 9-IN DETECTION LIMITS GENERAL CHEMISTRY

Lab Name: TestAmerica Denver Job Number: 280-70279-3

SDG Number:

Matrix: Water Instrument ID: WC\_Konelab

Method: 365.1 MDL Date: 11/29/2010 00:00

Prep Method: 365.2/365.3/365

Analyte	Wavelength/	RL	MDL
	Mass	(mg/L)	(mg/L)
Total Phosphorus as PO4		0.15	0.01533

# 9-IN CALIBRATION BLANK DETECTION LIMITS GENERAL CHEMISTRY

Lab Name: TestAmerica Denver	Job Number: 280-70279-3
SDG Number:	
Matrix: Water	Instrument ID: WC_Konelab
Method: 365.1	XMDL Date: 11/29/2010 00:00

Analyte	Wavelength/	XRL	XMDL
	Mass	(mg/L)	(mg/L)
Total Phosphorus as PO4		0.15	0.01533

# 9-IN DETECTION LIMITS GENERAL CHEMISTRY

Lab Name: TestAmerica Denver	Job Number: 280-70279-3
SDG Number:	
Matrix: Water	Instrument ID: NOEQUIP
Method: SM 4500 SO3 B	MDL Date: 11/01/2009 00:00

Analyte	Wavelength/	RL	MDL
	Mass	(mg/L)	(mg/L)
Sulfite		2	0.5

# 9-IN CALIBRATION BLANK DETECTION LIMITS GENERAL CHEMISTRY

Lab Name: TestAmerica Denver	Job Number: 280-70279-3
SDG Number:	
Matrix: Water	Instrument ID: NOEQUIP
Method: SM 4500 SO3 B	XMDL Date: 11/01/2009 00:00

Analyte	Wavelength/	XRL	XMDL
	Mass	(mg/L)	(mg/L)
Sulfite		2	0.5

# 12-IN PREPARATION LOG GENERAL CHEMISTRY

Lab	Name:	TestAmerica	Denver	Job No.:	280-70279-3

SDG No.:

Prep Method: 365.2/365.3/365

Lab Sample	Preparation Date	Prep Batch	Initial Weight	Initial Volume (mL)	Final Volume (mL)
LCS 280-282836/3-A	06/19/2015 15:44	282836		50.0	50.0
MB 280-282836/4-A	06/19/2015 15:44	282836		50.0	50.0
280-70279-6	06/19/2015 15:44	282836		50.0	50.0
280-70279-6 MS	06/19/2015 15:44	282836		50.0	50.0
280-70279-6 MSD	06/19/2015 15:44	282836		50.0	50.0

### 13-IN ANALYSIS RUN LOG GENERAL CHEMISTRY

Lab Name: TestAmer		merica Denver	_ Job No.:	280-70279-3				
SDG No.:								
Instrument	ID:	WC_Konelab	Method:	365.1				

Start Date: 06/19/2015 22:30 End Date: 06/19/2015 22:40

				Analytes																
				_								A	11d]	_y t	es 					_
				T _																
Lab	D	Т		P																
Sample	/	У		0																
ID	F	p	Time	4																
		_	Time	1																
ICV 280-282836/1-A	1		22:30	Х																
ICB 280-282836/2-A	1		22:30	Х																
LCS 280-282836/3-A	1	Т	22:30	Х																
MB 280-282836/4-A	1	Т	22:30	Х																
280-70279-6	1	Т	22:30	Х																
280-70279-6 MS	1	Т	22:30	Х																
280-70279-6 MSD	1	Т	22:30	Х																
CCV 280-282836/11-A	1		22:30	Х																
CCB 280-282836/12-A	1		22:30	Х																
ICV 280-282836/1-A			22:33																	
ICB 280-282836/2-A			22:33																	
ZZZZZZ			22:33																	
ZZZZZZ			22:33																	
ZZZZZZ			22:33																	
ZZZZZZ			22:33																	
ZZZZZZ			22:33																	
ZZZZZZ			22:33																	
ZZZZZZ			22:33																	
ZZZZZZ			22:33																	
CCV 280-282836/11-A			22:33																	
CCB 280-282836/12-A			22:33																	
ZZZZZZ			22:37																	
ZZZZZZ			22:37																	
ZZZZZZ			22:37																	
ZZZZZZ			22:37																	
ZZZZZZ			22:37																	
ZZZZZZ			22:37																	
ZZZZZZ			22:37																	
ZZZZZZ			22:37																	
ZZZZZZ			22:37																	
ZZZZZZ			22:37																	
CCV 280-282836/23-A			22:37																	
CCB 280-282836/24-A			22:37																	
ZZZZZZ			22:40																	
ZZZZZZ			22:40																	
ZZZZZZ			22:40																	
ZZZZZZ			22:40																	
ZZZZZZ			22:40																	
			22:40																	
ZZZZZZ			22:40																	
ZZZZZZ	1		22:40																	
CCV 280-282836/33-A	1		22:40																	

### 13-IN ANALYSIS RUN LOG GENERAL CHEMISTRY

Lab Name:	TestAmerica	Denver		Job No.:	280-7027	9-3			
SDG No.:									
Instrument	ID: WC_Kone	elab		Method: 3	365.1				
Start Date	<u>06/19/2015</u>	22:30		End Date:	06/19/2	015 22:4	10		
			T		Ana	alytes			

								А	nal	yt	es				
				Т											
				-											
Lab	D	T		P											
Lab Sample ID	/	У		0											
ID	F	р	Time	4											
CCB 280-282836/34-A			22:40												

### 13-IN ANALYSIS RUN LOG GENERAL CHEMISTRY

Lab Name: TestAmerica Denver	Job No.: 280-70279-3
SDG No.:	
Instrument ID: NOEQUIP	Method: SM 4500 SO3 B
Start Date: 06/08/2015 12:08	End Date: 06/08/2015 12:08

								A	nal	yt.	es				
				0											
Lab	D			3 S											
Sample	/	У		-											
ID	F	р	Time	2											
MB 280-280818/1	1	Т	12:08	Х											Ī
LCS 280-280818/2	1	Т	12:08	Х											
280-70279-6	1	Т	12:08	Х											
280-70279-6 DU	1	Т	12:08	Х											

 $\frac{\texttt{Prep Types}}{\texttt{T = Total/NA}}$ 



	Data Review Checklist – Calibration Methods				
Method(s):	Instrument: Kanglas Run Date 6 19 15 Analyst Initials: A15	SOP	#: W(	001	7
365.		1288			
	strument Run QC	Yes	No	N/A	2nd
	andards in ICAL or as specified in SOP?	V			
Correlation coeffic		\ <u>\</u>			
	V analyzed, and recovery within acceptance limits?	$ V_{j} $			***************************************
	ediately after the ICV & results < the RL er every ten samples & recovery within acceptance limits?	1			
	er every CCV & results < RL?	<del>                                     </del>	<u> </u>		
	the x intercept is < ± ½ the RL?	1			
Elution order verifi		<del>                                     </del>		V	
Were manual inte	grations performed correctly and properly documented? (anions)	<del>                                     </del>		3/	****
B. Sample Resul	ts		<del>                                     </del>		
	er than highest calibration standard diluted and reanalyzed?	V			,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
Do associated RL:	s/MDLs reflect dilutions or limited sample volume?	V			
	s bracketed by in control CCV results?	<b>V</b>			
Sample analyses	done within holding time? If no, create HTV NCM. NCM#	V			
	er calibration range? If reported, are results E flagged?		V		
	esult of over dilution?	ļ,	V		
	is reviewed and met?  Ily transcribed from instrument printouts or benchsheets into TALS verified 100% including	V			V
	in transcribed from instrument printodis of benchsheets into TALS verified 100% including inficially inficially including inficially including inficially including inficially including including inficially including inficially including inficially including inficially inficially including inficially including inficially inficially inficially inficially inficially inficially including inficially inficiall			V	
	nalysis dates in TALS reflect the actual dates?	1			
Were peak assign	ments verified? (anions)		<del></del>	J	
	grations performed correctly and properly documented? (anions)			1	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
C. Preparation/M	atrix QC	<b>—</b>			
Method blank < 1/2	RL or all reported samples > 10x blank have NCM? - (COD, Phenol MB <rl)< td=""><td>TV_</td><td></td><td></td><td>and a</td></rl)<>	TV_			and a
	RL or NCM provided? - (COD, Phenol MB <rl)< td=""><td>V</td><td></td><td></td><td></td></rl)<>	V			
	batch and within QC limits?	V			
MS/MSD run at red	quired frequency? Verify that MS/MSD failures are matrix issues and not analytical issues gor not applying the appropriate dilution.		ļ		
DUP run at require				T	
Menu or Tab	Check	L.		15	<b>2</b> <sup>nd</sup>
Analyst Desktop	Create or open batch		· ·······		
View Batch Info	Confirm all fields are populated			J	
	Edit Analyst ID as is appropriate			V	/
Run log	Verify the correct samples and QC are run at the correct frequency (i.e., 10 samples per Co	CV)		7	1400
Sample List	Confirm all Graphics have been uploaded (IC only)			NA	4
	In edit mode, if prompted to process samples, select "Yes"			/	
	Confirm samples are identified (Blue P Icon)  Confirm correct analysis date and time are listed			\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	r =======
	Confirm samples have the correct dilution factors. TOC – Check for manual dilutions no	tontor	ad into	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	1
	instrument run log, Auto dilutions (Aut. Dil.) and Injections volume (Inj. Vol.)	r <del>e</del> ritere	au IIRO	/	(alexandra
	Confirm samples have the correct method chain assigned			1	Accord To
	Confirm that solid samples have the % moisture listed			NA	
Worksheet	Populate all appropriate fields in the worksheet. Initial Amount, Final Amount, pH, etc.				
Reagents	Confirm reagents are correct and properly associated with QC samples. Confirm that reag-	ent amo	ounts	1	Lip-
Desults	are correct. If reagents are new, verify that the correct COA has been attached to the source	ce stan	dard		and the same of
Results	Check for special instructions (Login, Method and Sample comments) - red notebook icon Check for any QC failures			<b>√</b>	
	Set status for samples based on QC and sample results info (i.e., set to primary analysis w	itis is see	in a OC		A STATE OF THE STA
	or reject samples without passing QC or samples that are over-range).	ıııı pass	ang QC	'   V	at or the same
	Address any results that are reported without passing QC with an NCM			1	
QC Links	Confirm QC links are correct			1	
Hist. Data Check	Check historical data. Print charts for outliners. Take corrective action as is appropriate			1	
Sample List	Re-calculate data and set to appropriate review status (1 <sup>st</sup> or 2 <sup>nd</sup> level review)			<i>J</i>	/
A 1	Scan and attach raw data & save batch			J	
Analyst:	Date: 6 20 5 2nd Level Reviewer:		Da	e: (_	72/1
The state of the s				· · · · · · · · · · · · · · · · · · ·	1/21, 7

Calibration results

Aquakem 7.2AQ1

Page:

Laboratory Analyzer Üser

6/19/2015 22:12


TPHOS Test

Accepted 6/17/2015 16:40

Factor 2.356 Bias 0.001

Coeff. of det. 0.999089

Errors



	Calibrator	Response	Calc. con.	Conc.	Errors
1 2 3 4 5	TPH 0.025 TPH 0.05 TPH 0.10 TPH 0.2 TPH 0.5 TPH 1.0	0.008 0.020 0.040 0.090 0.220 0.421	0.01792 0.04469 0.09325 0.21181 0.51716 0.99018	0.02500 0.05000 0.10000 0.20000 0.50000 1.00000	
Cali	.brator In	formation	. — — — — — — — —		
TPH	0.05 0 0.10 0 0.2 0 0.5 0	0.025 MG/L TPHOS 0.05 MG/L TPHOS 0.10 MG/L TPHOS 0.2 MG/L TPHOS 0.5 MG/L TPHOS 0.0 MG/L TPHOS	A15	<b>(</b> 5	Ascorbic Acid 200174 TPhos Colorl 200037 WC 5ML AA
			Page 40 of 5	3	WE 1000 A A 06/25/2015

Test results

Aquakem 7.2AQ1

Page: 1

Laboratory Analyzer Úser

6/20/2015 8:46

	Test: TPHOS				
	Sample Id	Result	Dil. 1 +	Response	Errors
,	icv 280-282836/1 icb 280-282836/2 lcs 280-282836/4- 280-70279-f-6-a 280-70279-f-6-b 280-70279-f-6-c 280-70625-y-2-b 280-70625-y-2-b 280-70185-q-1-a ccv 280-282836/1 -70283-d-1-a 280-70283-d-2-a 280-70283-f-1-a 280-70283-d-1-a 280-70183-e-3-a 280-70556-d-1-c 580-50649-a-1-a ccv 280-282836/2 ccb 280-282836/2 280-70183-f-1-a 280-70183-f-1-a 280-70183-e-1-a 280-70183-e-1-a 280-70183-e-2-a 280-70183-e-3-a 280-70183-e-4-a 280-69983-a-4-c ccv 280-282836/3 ccb 280-282836/3	0.4185 -0.0011 0.5304 -0.0009 0.0056 0.5326 0.5329 0.0320 0.1022 2.8576 0.5402 -0.0007 0.0009 -0.0020 0.1972 0.0006 0.0227 -0.0029 157.3304 145.8667 146.2325 2.2852 0.5361 -0.0010 0.1161 0.0715 0.0091 1.7603 0.0034 0.0408 0.00408 0.0066 6.7411 0.5322 -0.0009	0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0	0.178 0.000 0.226 0.000 0.003 0.227 0.230 0.014 0.044 0.122 0.230 0.000 0.001 -0.000 0.084 0.001 0.010 -0.001 0.335 0.310 0.311 0.098 0.228 0.000 0.050 0.031 0.004 0.374 0.002 0.018 0.003 0.287 0.226 0.000	
	N Mean SD CV%	34 13.7442 43.01341 312.96			ATS

6/20/15

Calibration results

Aquakem 7.2AQ1

Page:

1

Laboratory Analyzer User

6/19/2015 22:12

\_\_\_\_\_\_\_\_\_\_\_\_


Test T-PO4

Accepted 6/17/2015 18:24

Factor 7.293 Bias 0.001

Coeff. of det. 0.998635

Errors



	Calibrator	Response	Calc. con.	Conc.	Errors
1	TPO4 .0766	0.007	0.04852	0.07665	
2	TPO4 0.153	0.019	0.13340	0.15330	
3	TPO4 0.307	0.040	0.28381	0.30660	
4	TPO4 0.613	0.091	0.65573	0.61320	
5	TPO4 1.533	0.220	1.59863	1.53300	
6	TPO4 3.066	0.416	3.02866	3.06600	

Calibrator Information

TPO4 .0766

TPO4 0.153

TPO4 0.307

TPO4 0.613

TPO4 1.533

TPO4 3.066

Test results

Aquakem 7.2AQ1

Page: 1

Laboratory Analyzer Úser

6/19/2015 22:32

Test: T-PO4

	Sample Id	Result	Dil. 1 +	Response	Errors
MS MS	icv 280-282836/1 icb 280-282836/2 lcs 280-282836/3 mb 280-282836/4- 280-70279-f-6-a 280-70279-f-6-b 280-70279-f-6-c ccv 280-282836/1 ccb 280-282836/1	1.2896 -0.0042 1.6520 -0.0066 0.0162 1.6254 1.6586 1.6537 -0.0061	0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0	0.178 0.000 0.227 -0.000 0.003 0.224 0.228 0.228 -0.000	Blank resp. low

Ν 0.8754 Mean SD 0.83840 CV% 95.77



	Wet Chemistry Data Review Checklist for Titration N	lethods				-C-1742 113311
Method(s): SMU	500803-B Instrument: burette SOP #: WC 0054	Analyst:	ME	3		
Run Date: 6 8		Analytical Bat	ch: 2	808	18	
THE THE PROPERTY OF STREET	strument Run QC	Yes	No	N/A	2nd	Level
	of the titrant verified and found acceptable?				100	
B. Sample Resul				1465		
Are all sample dilu limited sample volu	tions appropriate and do associated RLs/MDLs reflect required dilutions or			/		
	s bracketed by in control CCV/CCB?					
	done within holding time? If no, create HTV NCM. NCM #					_
	cumented for all samples (if required)?					_
	sheet completed and included in package (if applicable)?					_
	irements checked?					
	y transcribed from instrument printouts or benchsheet into TALS verified 100%	,		-		
	actors and significant figures? (If Applicable)	0 /				_
	nalysis dates in TALS reflect the actual dates?					
	formation is updated and included?					_
C. Preparation/M		528 Jan 12 11		neme.		
	RL or all reported samples > 10x blank? – (Alkalinity MB <rl)< td=""><td></td><td></td><td></td><td></td><td>_</td></rl)<>					_
	RL or NCM provided? – (Alkalinity MB <rl)< td=""><td></td><td></td><td></td><td></td><td>_</td></rl)<>					_
	batch and within QC limits?					_
MS/MSD run at red	quired frequency and within limits or NCM written?					A total
	d frequency and RPD within 20% or NCM written?					
Menu or Tab	Check			-	1 <sup>st</sup>	2 <sup>nd</sup>
Analyst Desktop	Create or open batch		-	in miles	Salar de la companya	2
View Batch Info	Confirm all fields are populated			200		
VICW Dater IIIIo	Edit Analyst ID as is appropriate					
Run log	Verify the correct samples and QC are run at the correct frequency (i.e., 10	camples per C	·C\/\			
Sample List	In Edit mode, If prompted to process samples, select "Yes"	samples per C	,CV)			_
odinpio Liet	Confirm samples are identified (Blue P Icon)					
	Confirm correct analysis date and time are listed					
	Confirm samples have the correct dilution factors					_
	Confirm samples have the correct method chain assigned					
	Confirm that solid samples have the % moisture listed					
Worksheet	Populate all appropriate fields in the worksheet. Initial Amount, Final Amount	nt nH etc				
	Confirm that data are entered correctly. Verify pH is recorded when approp	riate for the m	athod			-
Reagents	Confirm reagents are correct and properly associated with QC samples. Co					
3	amounts are correct. If reagents are new verify that the correct COA has be	een attached to	the			
	source standard			-		-
Results	Check for special instructions (Login, Method and Sample comments) - red	notebook icor	1		/	
	Check for any QC failures					
	Check for "E" flagged (over-range) data					
	Set status for samples based on QC and sample results info (i.e., set to prin	nary analysis v	vith		_	
	passing QC or reject samples without passing QC or samples that are over-	range)				_
	Address any results that are reported without passing QC with an NCM	<u> </u>				
QC Links	Confirm QC links are correct					_
Hist. Data Check	Check historical data. Print charts for outliners. Take corrective action as is	appropriate		-		_
Sample List	Re-calculate data and set to appropriate review status (1st or 2nd level review	v)			_	_
	Scan and attach raw data & save batch				/	
Amaluati X	21 000/15			10		
Analyst:	Date: Analyst Comments:					
Reviewer:	Date: 6 2 15 Reviewer Comments:					

# Sulfite by Titration 377.1 and SM 4500 ${\rm SO_3}^{-2}$ B

					ons & Reage	ents			
Analyst:	ME	3	Solution 1:	SO3 titr	ant_00004		Solution 4:	Sulfamic Acid	00010
Date:	6/8/2	015	Normality:	0.0125			Exp Date:	3/31/2016	
Batch No.	2808	318	Exp. Date:	6/30/20	15		Solution 5:	SO3 H2SO4_	_0011
SOP No.:	DV-WC	-0056	Solution 2:	EDTA S	Solution_0003	1	Exp Date:	5/10/2015	
Rev.:	2.3	3	Exp. Date:	6/21/20	15		LCS ID;	Sulfite LCS 00	)131
RL (mg/L):	2		Solution 3:	Starch I	nd 00025		Exp Date:	6/9/2015	
MDL (mg/L):	0.5	5	Exp Date:	6/30/20	15	-	Spike Conc:		mg/L
Sample ID	Sample Volume (mL)	Buret Start (mL)	Buret Stop (mL)	Blank (mL)	Final mL (blank corrected)	Conc (mg/L)	Dilution Factor	Final Conc (mg/L)	% Rec
MB	50	30	30.1	0.1	0.00	0.000	1	ND	***
LCS	50	30.10	32.20	0.1	2.00	20.000	1	20.00	100.00
LCSD				0.1	-0.10	#DIV/0!	#DIV/0!	#D!V/0!	#DIV/0
280-70279-A-6	50	32.20	32.30	0.1	0.00	0.000	1	ND	
du 280-70279-A-6	50	32.30	32.40	0.1	0.00	0.000	1	ND	
580-50426-C-4	50	32.40	32.60	0.1	0.10	1.000	1	1.00	P-74
580-50426-C-5	50	32.60	32.80	0.1	0.10	1.000	1	1.00	
580-50483-C-1	50	32.80	32.90	0.1	0.00	0.000	1	ND	
580-50483-C-2	50	32.90	33.00	0.1	0.00	0.000	1	ND	
144									
								participation of the second	
	-	-					Andrew Contract Contr		
			-						
			-						
							······································		
·				·······					
		AND THE PERSON NAMED IN COLUMN							
		······································		<del></del>					
						····			
				<del></del>					
				WARREST				The state of the s	

06/25/2015

Lab Name: TestAmerica Denver Job No.: 280-70279-3

SDG No.:

Batch Number: 282836 Batch Start Date: 06/19/15 15:44 Batch Analyst: Schwemin, Andrew J

Batch Method: 365.2/365.3/365 Batch End Date:

Lab Sample ID	Client Sample I	Method Chain	Basis	InitialAmount	FinalAmount	Phos Cal Int	phos icv Int	AnalysisCommen	
						00301	00280	t	
ICV		365.2/365.3		50.0 mL	50.0 mL		2 mL	pH 2	
280-282836/1		/365, 365.1							
ICB		365.2/365.3		50.0 mL	50.0 mL			pH 2	
280-282836/2		/365, 365.1							
LCS		365.2/365.3		50.0 mL	50.0 mL	2.5 mL		pH 2	
280-282836/3		/365, 365.1							
MB		365.2/365.3		50.0 mL	50.0 mL			pH 2	
280-282836/4		/365, 365.1							
280-70279-F-6	54400-MW55D-06	365.2/365.3	Т	50.0 mL	50.0 mL			pH 2	
	15	/365, 365.1							
280-70279-F-6	54400-MW55D-06	365.2/365.3	Т	50.0 mL	50.0 mL	2.5 mL		pH 2	
MS	15	/365, 365.1							
280-70279-F-6	54400-MW55D-06	365.2/365.3	Т	50.0 mL	50.0 mL	2.5 mL		pH 2	
MSD	15	/365, 365.1							
CCV		365.2/365.3		50.0 mL	50.0 mL	2.5 mL		pH 2	
280-282836/11		/365, 365.1							
CCB		365.2/365.3		50.0 mL	50.0 mL			pH 2	
280-282836/12		/365, 365.1							

Batch Notes					
Block Digestor Name	A & B				
First End time	1830				
Ammonium Persulfate Lot #	Ammonium SO4_00019				
Oven, Bath or Block Temperature 1	140 Centigrade				
Pipette ID	wc5MLAA				
First Start time	1630				
Sulfuric Acid Reagent ID Number	11N h2s04_00041				
ID number of the thermometer	140				
Digestion Tube/Cup Lot #	1408268				
Uncorrected Temperature	140 Celsius				

The pound sign (#) in the amount added field denotes that the reagent was used undiluted. All calculations are performed using the stated concentration for this reagent.

365.1 Page 1 of 2

Lab Name: Test	America Denver	Job No.: 280-70279-3		
SDG No.:				
Batch Number:	282836	Batch Start Date: 06/19/15 15:44	Batch Analyst:	Schwemin, Andrew J
Batch Method:	365.2/365.3/365	Batch End Date:		

Basis	Basis Description
Т	Total/NA

The pound sign (#) in the amount added field denotes that the reagent was used undiluted. All calculations are performed using the stated concentration for this reagent.

365.1 Page 2 of 2

Lab Name: TestAmerica Denver Job No.: 280-70279-3

SDG No.:

Batch Number: 282883 Batch Start Date: 06/19/15 22:30 Batch Analyst: Schwemin, Andrew J

Batch Method: 365.1 Batch End Date:

Lab Sample ID	Client Sample I	Method Chain	Basis	InitialAmount	FinalAmount	CalcMsg		
ICV		365.1		2.0 mL	2.0 mL	Not		
280-282836/1-						Calculated. No		
A						Phosphorus		
						result		
ICB		365.1		2.0 mL	2.0 mL	Not		
280-282836/2-						Calculated. No		
A						Phosphorus		
						result		
LCS		365.1		2.0 mL	2.0 mL	Not		
280-282836/3-						Calculated. No		
A						Phosphorus		
						result		
MB		365.1		2.0 mL	2.0 mL	Not		
280-282836/4-						Calculated. No		
A						Phosphorus		
						result		
280-70279-F-6	54400-MW55D-06	365.1	Т	2.0 mL	2.0 mL	Not		
-A	15					Calculated. No		
						Phosphorus		
						result		
280-70279-F-6	54400-MW55D-06	365.1	Т	2.0 mL	2.0 mL	Not		
-B MS	15					Calculated. No		
						Phosphorus		
						result		
280-70279-F-6	54400-MW55D-06	365.1	Т	2.0 mL	2.0 mL	Not		
-C MSD	15					Calculated. No		
						Phosphorus		
						result		
CCV		365.1		2.0 mL	2.0 mL	Not		
280-282836/11						Calculated. No		
-A						Phosphorus		
						result		

The pound sign (#) in the amount added field denotes that the reagent was used undiluted. All calculations are performed using the stated concentration for this reagent.

365.1 Page 1 of 2

Lab Name: TestAmerica Denver	Job No.: 280-70279-3
------------------------------	----------------------

SDG No.:

Batch Number: 282883 Batch Start Date: 06/19/15 22:30 Batch Analyst: Schwemin, Andrew J

Batch Method: 365.1 Batch End Date:

Lab Sample ID	Client Sample I	Method Chain	Basis	InitialAmount	FinalAmount	CalcMsg		
ССВ		365.1		2.0 mL	2.0 mL	Not		
280-282836/12						Calculated. No		
-A						Phosphorus		
						result		
LCS 280-282836/3-		365.1		2.0 mL	2.0 mL	OK		
A								
MB		365.1		2.0 mL	2.0 mL	OK		
280-282836/4-								
A								
280-70279-F-6	54400-MW55D-06	365.1	Т	2.0 mL	2.0 mL	OK		
-A	15							
280-70279-F-6	54400-MW55D-06	365.1	Т	2.0 mL	2.0 mL	OK		
-B MS	15							
280-70279-F-6	54400-MW55D-06	365.1	Т	2.0 mL	2.0 mL	OK		
-C MSD	15							

Batch Notes					
Ammonium Molybdate Reagent ID Number	tphos color1_00037				
Ascorbic Acid Reagent ID Number	Ascorbic Acid_0174				
Potassium Antimonyl Tartrate Reagent ID	tphos color1_00037				
Pipette ID	wc5MLAA wc1000AA				
Perform Calculation (0=No, 1=Yes)	1				
Sulfuric Acid Reagent ID Number	tphos color1_00037				

Basis	Basis Description
T	Total/NA

The pound sign (#) in the amount added field denotes that the reagent was used undiluted. All calculations are performed using the stated concentration for this reagent.

365.1 Page 2 of 2

Lab Name: TestAmerica Denver	Job No.: <u>280-70279-3</u>	
SDG No.:		
Batch Number: 280818	Batch Start Date: 06/08/15 12:08	Batch Analyst: Bland, Morgan R
Batch Method: SM 4500 SO3 B	Batch End Date:	

Lab Sample ID	Client Sample I	Method Chain	Basis	InitialAmount	FinalAmount	TitrantBlank	TitrantVolume1	Sulfite LCS	
								00131	
MB		SM 4500 SO3		50 mL	50 mL	0.1 mL	0.00 mL		
280-280818/1		В							
LCS		SM 4500 SO3		50 mL	50 mL	0.1 mL	2.00 mL	5 mL	
280-280818/2		В							
280-70279-A-6	54400-MW55D-06	SM 4500 SO3	Т	50 mL	50 mL	0.1 mL	0.00 mL		
	15	В							
280-70279-A-6	54400-MW55D-06	SM 4500 SO3	Т	50 mL	50 mL	0.1 mL	0.00 mL		
DU	15	В							

Batch Notes						
Batch Comment	pipets: 1000CL ,5000EE, 5000MLBB					
Nominal Amount Used	50 mL					
Normality	0.0125 N					

Basis	Basis Description
Т	Total/NA

The pound sign (#) in the amount added field denotes that the reagent was used undiluted. All calculations are performed using the stated concentration for this reagent.

SM 4500 SO3 B Page 1 of 1

# Shipping and Receiving Documents

Phone (303) 736-0100 Fax (303) 431-7171

Arvada, 130 80002 4955 Yarrow Street

TestAmerica Denver

280-70279 Chain of Custody Chain of Custody F

**TestAmerica** 

THE LEADER IN ENVIRONMENTAL TESTING

COC No:

N - None
O - AsNa02
P - Na204S
Q - Na2838
R - Na282503
S - H2804
T - TSP Dodecahydrate Short Holds: Hex. Chromium (<u>24 hr),</u> Nitrate/Nitrite, Sulfite(48 hr) Special Instructions/Note: U - Acetone V - MCAA W - ph 4-5 Z - other (specify) Company 16-6365 # Opt 6/5/15 Sample Disposal (A fee may be assessed if samples are retained longer than 1 month) of O H - Ascorbic Acid Rush Rish E - NaHSO4 F - MeOH Page: Page Archive For Fed ex 8065 245 7 2298 Total Number of containers ercent Molsture - Soil Cooler Temperature(s) °C and Other Remarks +0. | IR+S Date/Time: llos - nodra Organic Carbon - Soli Method of Shipment: M S260\_AFCEE - VOCs (Terracores) - Soil bisposal By Lab KSK\_175 - Dissolved Gases (Methane/Ethane/Ethene) - W Analysis Requested 1964 - Hexavalent Chromium - Water Special Instructions/QC Requirements: SZUB - AIKBIIDILY - Water elaine.walker@testamericainc.com SM4500503\_B - Suifite - Water Return To Client 9056 28D - Sulfate/Chloride, 9056 48HR - Nitrate/Nitrite - W Received by: 2010C\_DOD5 - Total Fe, Ca, K, Mg, Na - Water Lab PM: Walker, Elaine M E-Mail: Perform MS/MSD (Yes of No) if Time: Matrix (w=water, S=solid, O=waste/oil, Preservation Code: Company Company 18-5968 Radiological  $\mathcal{M}$ D **Labierel**A PO#. Purchase Order Requested wo#. 0935 1405 1510 0915 1155 Sample Date/Time:

6-4-/5/
Date/Time: がなどの Date: Unknown Due Date Requested: Sample Date 5.7.0 Project #: 28013169 4 Date/Time: Poison B 'evel 54466 - MW555-0615 54466-MWSSD - 0615 <del>544</del>Ø3-TB19-Ø615 Skin Irritant 54402-EB18-0615 54400-MW43-0615 54406 - MW56- 0615 Deliverable Requested: I, II, III, IV, Other (specify) Custody Seal No.: Kansas Flammable ossible Hazard Identification 9600 Great Hills Trail, Ste 350E roject Name: 3SI - McConnell Air Force Empty Kit Relinquished by: Custody Seals Intact: Δ Yes Δ No Client Information GSI Environmental, Inc Sample Identification 512-346-4474(Tel) Non-Hazard alw@gsi-net.com Anna Zabierek slinguished by: elinquished by: TX. 78759 State, Zip: City: Austin

## **Login Sample Receipt Checklist**

Client: GSI Environmental, Inc Job Number: 280-70279-3

Login Number: 70279 List Source: TestAmerica Denver

List Number: 1

Creator: White, Denise E

Question	Answer	Comment
Radioactivity wasn't checked or is = background as measured by a survey meter.</td <td>N/A</td> <td></td>	N/A	
The cooler's custody seal, if present, is intact.	True	
Sample custody seals, if present, are intact.	True	
The cooler or samples do not appear to have been compromised or tampered with.	True	
Samples were received on ice.	True	
Cooler Temperature is acceptable.	True	
Cooler Temperature is recorded.	True	
COC is present.	True	
COC is filled out in ink and legible.	True	
COC is filled out with all pertinent information.	True	
Is the Field Sampler's name present on COC?	True	
There are no discrepancies between the containers received and the COC.	True	
Samples are received within Holding Time.	True	
Sample containers have legible labels.	True	
Containers are not broken or leaking.	True	
Sample collection date/times are provided.	True	
Appropriate sample containers are used.	True	
Sample bottles are completely filled.	True	
Sample Preservation Verified.	True	
There is sufficient vol. for all requested analyses, incl. any requested MS/MSDs	True	
Containers requiring zero headspace have no headspace or bubble is <6mm (1/4").	True	
Multiphasic samples are not present.	True	
Samples do not require splitting or compositing.	True	
Residual Chlorine Checked.	N/A	