

THE STANLEY WORKS

Since 1843

NEW BRITAIN, CONNECTICUT 06050

(203) 225-5111

February 29, 1984

Ms. Barbara L. Bush
Office of Solid Waste (WH-562)
U. S. Environmental Protection Agency
Washington, D. C. 20460

Re: Delisting Petition #0533

Dear Ms. Bush:

Enclosed please find the additional information you have requested to complete the review of the Delisting Petition (#0533) submitted by The Stanley Works Corporate Laboratory for the Stanley Tools - Fowlerville facility. I have attached the Material Safety Data Sheets for the chemical compounds used in our finishing process that may enter the waste stream. You will note that I have not included the data sheets on the basic raw materials that make up the primary plating process solutions such as, sodium cyanide, caustic soda, copper metal anodes, nickel sulfate hexahydrate, nickel chloride hexahydrate, boric acid, nickel metal anodes, chromic acid, sulfuric acid, and insoluble lead metal anodes. Much information on the safety and toxicity of these materials can be readily obtained from a variety of reference materials.

The additional information you have asked for, will be answered in Paragraph form.

1. Past Disposal Practices:

The Stanley Works acquired the Stanley Tools - Fowlerville facility in January of 1980. The metal hydroxide sludge was accumulated in the surface impoundments until October 1980, when approximately 97,000 gallons of metal hydroxide sludge was pumped out of the surface impoundments by Chem-Met Services of Wyandotte, Michigan and transported to their facility for disposal. The remaining sludge was left to accumulate in the surface impoundments and became regulated as hazardous waste Code #F006 under RCRA on November 19, 1980.

Ms. Barbara L. Bush
Office of Solid Waste (WH-562)
U. S. Environmental Protection Agency
Washington, D. C. 20460

Re: Delisting Petition #0533

2. Current Disposal Practices:

Chem-Met Services, EPA ID# MID096963194, is still being contracted as the disposal firm for the F006 waste stored in the surface impoundments. Once yearly, the surface impoundments are pumped out. The F006 sludge is transported to Chem-Met's facility where the sludge slurry is dewatered and the resultant solid sludge is combined with other solid metal hydroxide sludge of the same hazardous waste code classification. The solid material is then transported to Wayne County #2 Landfill for disposal.

3. Proposed Disposal Practice:

In the event that the F006 waste is delisted, the sludge would be handled as a solid waste and would be sent to Chem-Met Services for dewatering. The solid sludge that remains after dewatering would be sent to an engineered landfill for proper disposal.

4. Tests for Characteristic Hazardous Waste:

Ignitability Characteristic; The F006 sludge would not exhibit the characteristic of ignitability because the material is an aqueous slurry with approximately 97% water and 3% solid metal hydroxide sludge which does not readily ignite nor support combustion. This material does not exhibit a Flash Point less than 140°F.

Corrosivity Characteristic; The F006 sludge does not exhibit the characteristic of corrosivity. When the pH of the sludge was measured, it was found to fall within the 9.03 to the 10.50 pH range which is within the non-corrosive pH range.

Ms. Barbara L. Bush
Office of Solid Waste (WH-562)
U. S. Environmental Protection Agency
Washington, D. C. 20460

Re: Delisting Petition #0533

Reactivity Characteristic; The F006 sludge does not exhibit the characteristic of reactivity. The sludge does not react violently with water and when exposed to mild acids or alkalies does not generate toxic gases or vapors. Analysis of the sludge indicates that the free cyanide level in the sludge is well below 10 mg/l limit.

5. Total Metal Analysis, Arsenic, Mercury & Selenium:

The total metals analysis for arsenic, mercury, and selenium has been provided in Part I of the Delisting Petition. This information is available on Pages 7 and 55 of Part I of the Petition.

6. Total Organic Carbon Analysis:

Attached, with this letter, are the results of the Total Organic Carbon analysis (TOC) performed upon sludge samples from both the clarifier blowdown and the surface impoundment system. As discussed with Mr. Morse in our phone conversation of January 27, 1984, five representative samples would have to be submitted for TOC analysis. One sample being a composite sample of the clarifier blowdown, and the remaining four being composite samples taken from each of the four surface impoundments. Due to extremely cold weather conditions, two of the surface impoundments have frozen over making composite sampling of those two surface impoundments virtually impossible. I advised Mr. Morse of this situation and he had suggested that we forego the composite sampling of those two impoundments and obtain grab samples from them.

Ms. Barbara L. Bush
Office of Solid Waste (WH-562)
U. S. Environmental Protection Agency
Washington, D. C. 20460

Re: Delisting Petition #0533

The sampling was performed on February 7, 1984. Composite samples were obtained from surface impoundments Numbers 3 and 4 and grab samples were taken from surface impoundments Numbers 1 and 2. A composite of the clarifier blowdown was obtained from grab samples taken during the blowdown periods.


You will also note that along with the TOC analysis, the samples were also tested to determine the presence of the metal Thallium. Though Thallium is not listed as an EP Toxic Metal, a review of the Material Safety Data Sheets has alerted us to the fact that one of the products in use, Isobrite 607 used in our cyanide copper plating solution as an additive, contains small amounts of Thallium Carbonate. Each sample was analyzed for Total Thallium based upon the dosage rate of Isobrite 607, (one-third gallon per day added to a 5000 gallon plating tank with a small dragout rate), we would estimate that the amount of Thallium that may enter the sludge would be extremely small.

I am also including a summary sheet with this letter, detailing the analyses performed and the results of those analyses.

I will once again remind both you and Mr. Morse that the Stanley Tools-Fowlerville facility has received a request from EPA Region V for the submission of their Part B Permit application. The submission date is targeted for July 15, 1984.

I hope this additional information will assist you in completing your review of the petition in a timely manner. Should any additional information regarding this petition be needed, please contact me as soon as possible.

Sincerely,



William J. Guerrero
Environmental Chemist
Stanley Laboratory
1309 Corbin Avenue
New Britain, CT 06053
(203) 225-5111 - Ext.5211

Ms. Barbara Bush
RE: Delisting Petition #0533

Analysis Data:

Sample #	Type	TOC	mg/l	Thallium (Tl)
1000	Blowdown Composite	1,400		2.0*
1001	Lagoon #1, Grab	51		2.0*
1002	Lagoon #2, Grab	3,100		2.0*
1003	Lagoon #3, Composite	1,300		2.0*
1004	Lagoon #4, Composite	100		2.0*

* - Not detected, concentration found to be lower than the detection limit given.

The analytical data presented on this page has been developed by Baron Consulting Company. The Thallium analysis was performed on a Perkin-Elmer 503 Atomic Absorption Spectrophotometer. The Thallium values were quantified by the method of standard additions. The TOC analysis was performed in accordance with Method 415.1 described in EPA-600/4-79-020 STORET No. 00680.

STANLEY

T H E S T A N L E Y W O R K S

Since 1843

P.O. Box 1800

NEW BRITAIN, CONNECTICUT 06050

(203) 225-5111

October 21, 1983

Mr. William D. Ruckelshaus
Administrator
U.S. Environmental Protection Agency
Washington, D. C. 20460

RE: STANLEY TOOLS - FOWLerville
EPA ID #MID099124299

Dear Mr. Ruckelshaus:

The following petition for the delisting of electroplating wastewater treatment sludge, EPA Hazardous Waste Code Number F006, is being submitted to you by The Stanley Works Corporate Laboratory. The Stanley Works is the owner of the Stanley Tools facility located in Fowlerville, Michigan and herein identified as Stanley Tools - Fowlerville.

The facility's electroplating operations are cyanide copper, watts nickel, and hexavalent chromium. The rinse waters from these operations are treated in tanks. Vibratory finishing waste from the deburring of zinc base die-casts is discharged to the surface impoundment system for settling.

The F006 waste is being generated in a clarifier at the Fowlerville facility. The underflow from the clarifier is directed to surface impoundments for both sludge storage and increased solid-liquid separation. The supernatant liquid from the surface impoundments is directed to a receiving stream and discharged under the guidelines of an NPDES Permit.

This petition will be submitted in two parts. The first part will provide the requirements pursuant to Title 40CFR Part 260.22 with the exception of the cyanide analysis, and the determination of the oil and grease content of the sludge.

Mr. William D. Ruckelshaus
U. S. Environmental Protection Agency

RE: STANLEY TOOLS - FOWLERVILLE
EPA ID #MID099124299

The presence of a sulfide compound contaminant in the sludge samples has interfered with the cyanide determination which resulted in non-repeatable results. When a suitable method to determine cyanide in the presence of sulfide was obtained, the sludge samples had aged thus altering the concentration of the cyanide in the sludge.

As discussed in a phone conversation with Mr. Myles Morse on August 31, 1983, fresh samples of the underflow from the clarifier before discharge to the surface impoundments will be taken. These samples would be representative of our sludge generation, at a worst case condition since the sludge would not be allowed to further settle and age in the surface impoundments. The samples will be analyzed for Total, Amenable, and Leachable Cyanide, as well as oil and grease content. The results of these analyses will be submitted in the second part of the delisting petition.

The sludge exhibited some unusual characteristics when subjected to the EP Toxicity Extraction Procedure. In all cases, the maximum amount of acetic acid for the weight taken had to be added to the sample and still the resultant pH never dropped near the pH 5.0 range. A composite sample of all the samples taken was made up and tested. The extract metal analyses from the composite sample are lower than the statistical average that would be expected from the individual sample extract analysis. It appears that compositing causes a reaction to occur which binds the metals therefore making them less mobile.

The delisting petition certification will be signed by a Corporate Vice President. I greatly request that any inquiries regarding this petition be referred to me.

Sincerely,

THE STANLEY WORKS



William J. Guerrero
Environmental Chemist
Stanley Laboratory
1309 Corbin Avenue
New Britain, CT 06053
(203) 225-5111 - Extension 5211

EPA ID #MID099124299

PETITIONER: OWNER: THE STANLEY WORKS
195 LAKE STREET
NEW BRITAIN, CONNECTICUT 06050

OPERATOR: STANLEY TOOLS - FOWLERVILLE
425 FRANK STREET
FOWLERVILLE, MICHIGAN 48836

STATEMENT OF INTEREST AND NEED:

The Stanley Tools facility, in Fowlerville, Michigan, a Division of The Stanley Works, is primarily involved in the manufacture, plating and finishing of zinc base die-castings. The facility treats cyanide, hexavalent chromium and nickel electroplating rinse waters. The underflow from the clarifier is directed to the first of four settling lagoons which are in series. The bulk of the settling occurs in Lagoon #1 while further settling is achieved in the remaining lagoons. The final discharge from Lagoon #4 is directed to a receiving stream under the guidelines of an NPDES Permit. The State of Michigan is one of several areas throughout the United States with the lack of sufficient hazardous waste disposal capacity.

Of particular interest to The Stanley Works is that the electroplating wastewater treatment sludge generated at the clarifier and stored in the surface impoundments be removed from the hazardous waste listing for the following purposes:

1. The result of the EP Toxicity Test indicate that the hazardous waste constituents in the sludge are below the hazardous criteria for a toxic waste.
2. The present method of sludge handling, and transporting for final disposal, is extremely expensive and has overburdened the facility's operating budget.
3. The dewatered sludge is capable of being accepted by an approved solid waste landfill.

EPA ID #MID099124299

PROPOSED ACTION:

That the EPA exclude the Stanley Tools - Fowlerville Division's electroplating wastewater treatment sludge from Sub Part D, 40CFR Part 261.31 which presently lists EPA Hazardous Waste Code Number F006, Wastewater Treatment Sludges from Electroplating Operations.

The following information is supplied pursuant to 40CFR Part 260.22:

1. Name and Address of the Laboratories performing the testing.

- a) The Stanley Works
Corporate Laboratory
1309 Corbin Avenue
New Britain, CT 06053
- b) TRC Environmental Consultants
800 Connecticut Blvd.
East Hartford, CT 06108

2. Name of person sampling and testing the waste.

- a) Sampling - Reza Rejaei, Stanley Tools - Fowlerville

The lagoon sampling and sample compositing was performed by Mr. Rejaei on March 17, 1983. Mr. Rejaei is employed as a chemist by the Stanley Tools facility in Fowlerville, Michigan and holds a Masters degree in Engineering Management. The sampling was conducted in accordance with the lagoon sampling methodology as discussed in a letter to Mr. Morse on March 15, 1983. A copy of the letter is enclosed for reference. A dipper sampler was used to collect the samples from the quadrants. A minimum of four grab samples were taken from each quadrant. Approximately three-quarters of a gallon was collected with each sampling pass. The dipper was pulled through the sludge from top to bottom to obtain a representative cross section sample. The samples were collected in a bucket and composited and one gallon was poured off and placed in a nalgene bottle and labeled with proper identification, the sampler was then cleaned and the procedure was repeated on another quadrant. The samples were sent to the Corporate Laboratory for analysis.

EPA ID #MID099124299

b) Testing - William J. Guerrera, The Stanley Works Laboratory

Mr. Guerrera was responsible for the sample handling, percent solids determination, and performing the EP Toxicity Extractions on the samples. He is an Environmental Chemist in the Environmental Science Section of The Stanley Works Corporate Laboratory and holds a Bachelors Degree in Chemistry and an Associates Degree in Chemical Engineering with over six years environmental control experience.

Philip L. Talarico, The Stanley Works Laboratory

Mr. Talarico was responsible for the metals analysis by Atomic Absorption Spectroscopy, and the wet chemical analysis for the cyanide determinations. He is an Analytical Chemist for The Stanley Works Corporate Laboratory, and holds a Masters Degree in Science with over twenty-eight years analytical chemistry experience.

c) Outside Testing - Margaret Flanagan, Ann Levine,
TRC Environmental Consultants.

TRC Environmental Consultants were contacted to perform metals analysis on metals not routinely analyzed by The Stanley Works Laboratory. A composite sample made up of all the samples taken from the lagoons was sent to TRC for the determination of total arsenic, mercury, and selenium in the sludge. Since these materials are not used in our process, analysis for total metals will be performed. If the analysis indicates that the concentration of the constituents is sufficient enough to yield a leachable metal concentration greater than the allowable EP Toxicity limits, an EP Toxicity Extraction will be performed upon the sludge and the concentration of the suspect metals in the extract will be determined.

The attached resumes are those of the analysts employed by TRC who performed the analysis on the sludge. TRC Laboratory is certified by the Connecticut State Department of Health as an Approved Public Health Laboratory (PH-0426).

MARGARET FLANAGAN

EDUCATION

1972, B.A. Saint Joseph College, West Hartford, Connecticut, Chemistry

Graduate courses at Central Connecticut State College and University of Hartford

Completed the State of Connecticut Director of Laboratory Qualifying Exam

SUMMARY OF EXPERIENCE

Ms. Flanagan is an Senior Chemist - Inorganic Section in TRC's Chemistry Laboratory. She participates in the analysis of environmental samples using instrumental and wet chemical methods. She is specifically working on the development of new analytical procedures using the Perkin-Elmer 560 Atomic Absorption unit which is equipped with auto samplers, data printer, metal hydride generator and HGA furnace. She has performed a variety of chemical analyses on a range of projects. These include the analysis of leachate from flyash for a utility (arsenic, selenium, chromium, nickel, calcium, zinc, antimony, molybdenum, boron, aluminum, and manganese) and effluent from a sewage treatment facility (solids, BOD, COD - by the micro-ampulmatic procedure, nitrogen, nitrate, oil and grease, cyanide, and a variety of heavy metals). She has conducted the analysis of hi-vol filters for vanadium, lead, bromide, iron, TSP, and sulfate using the methyl-thymol blue auto-analyzer method. Sludge samples have been analyzed for heat content, sulfur and metals such as mercury and chromium. She performs the EPA emission analytical methods for particulate, SO₂ and NO_x.

Ms. Flanagan has participated in projects requiring on-site chemical analysis. These include a tracer study involving the dispersion of sulfur dioxide using gas chromatography and colorimetric procedures. She has assisted in the determination of the efficiency of organic vapor emission control in the chemical industry. Another program was conducted for the EPA to determine the emissions from fertilizer plants. For this project, she conducted and compared methods of analysis involving standard colorimetric procedures and instrumental methods. She also modified procedures for the particular interferences encountered.

Prior to working at TRC, Ms. Flanagan was a manager of an electroplating analytical laboratory which performed wastewater analysis and developed new analytical procedures for the plating solutions using atomic absorption methods. She also participated in the development of analytical procedures to determine the quality of photocopier products.

PROFESSIONAL AFFILIATIONS

American Chemical Society

ANNE M. LEVINE

EDUCATION

1981 Kevex Training Course - X-ray Energy Spectrophotometry

1978 Perkin Elmer Training Course - Atomic Absorption Spectrophotometry

1977, B.S. Trinity College, Hartford, Connecticut, Chemistry

SUMMARY OF EXPERIENCE

Ms. Levine is a Chemist in TRC's Chemistry Laboratory. Her responsibilities include the chemical analysis of water, coal, and ash samples. She works with a variety of instrumentation including the atomic absorption spectrophotometer, UV/visible spectrophotometer, infrared analyzer, and others. She is familiar with most standard procedures recommended by EPA, and ASTM for pollutant analysis.

Ms. Levine has also participated as a TRC project team member on various programs. In this role, she provides project managers with chemistry-related knowledge and skills. In a recent project, she performed metal analyses on the atomic absorption spectrophotometer for coal, fly ash and bottom ash samples. She has also participated in a water quality monitoring program for a utility plant project in which she analyzed pollutant metals in coal pile runoff samples. She determined the matrix interferences and utilized methods of chemically treating these samples to eliminate such interferences. In a hazardous waste management program, she researched literature on attenuation of metals in ground water as related to hazardous waste dumping, and provided the chemistry of these metals as explanation of reactions in the soil.

Prior to joining TRC, Ms. Levine was a quality control chemist for Pratt & Whitney Aircraft. Her main responsibilities were the programming, maintenance, and procedural analysis of a computerized Kevex X-ray Energy Spectrophotometer. Prior to that assignment, she placed the computerized Jarrell-Ash Direct Reading Spectrophotometer on line as a simultaneous multi-element analyzing tool for complex metal alloys. She de-bugged many wet chemical procedures, as well as wrote manual sections for their final established procedures. Through this experience Ms. Levine has gained extensive knowledge regarding quality control and quality assurance of laboratory analysis work.

While attending Trinity College, Ms. Levine completed an independent study research project entitled "The Applicability of Polarography and Atomic Absorption Spectrophotometry in Elemental Analysis of Europium and Ytterbium in Binary Hydride Compounds".

PROFESSIONAL AFFILIATIONS

American Chemical Society

EPA ID #MID099124299

3. Testing Dates:

a) EP Toxicity Extraction for Metals and Percent Solids Data:

3/22/83	4/13/83
3/23/83	4/19/83
3/29/83	4/21/83
4/12/83	

b) Total Metals Analysis and Leachate Analysis by Atomic Absorption Spectroscopy:

3/29/83	4/25/83	5/18/83	7/8/83	8/4/83
4/6/83	4/26/83	6/6/83	7/11/83	8/5/83
4/11/83	4/29/83	6/20/83	7/12/83	8/9/83
4/17/83	5/2/83	6/22/83	7/13/83	
4/18/83	5/5/83	7/5/83	7/14/83	
4/19/83	5/10/83	7/7/83	8/3/83	

4. Location of the Generating Facility:

425 Frank Street
Fowlerville, Michigan 48836

5. Description of Manufacturing Processes, Raw Materials Used and Assessment of Operations:

The Stanley Tools - Fowlerville facility is primarily involved in the manufacture, finishing, and plating of zinc base die-castings. The facility operates under the primary Standard Industrial Classification Code Number 3428. Other operations include processes identified under S.I.C. Code Number 3400. The electroplating process discharges are regulated by the NPDES Program.

The raw materials producing the wastewater for treatment are rinse waters following the process solutions, and zinc vibratory finishing waste discharges. The primary process solutions are copper, nickel and chromium. Presently, the chromium plating solution that enters the rinse water as drag-out from the chromium plating process is recovered. Process solutions which are not reclaimed are treated in tanks at the facility. The sludge generated is stored in surface impoundments to achieve settling and further separation of solid and liquid. The top water from the surface impoundments is directed to a receiving stream under the guidelines of an NPDES Permit.

PROCESS DESCRIPTION:

a) Deburring of zinc die-castings:

Zinc die-cast parts are trimmed and then placed in vibratory finishing equipment. Preform cone-shaped media and liquid burnishing compounds are added to achieve deburring. The parts are agitated for 1/2 hour. The parts are then rinsed and dried with the washings directed to a containment sump.

b) Buffing:

Following the deburring process, the parts proceed to a buffing operation where the parts are buffed to yield a highly reflective surface.

c) Plating Operations:

The buffed die-cast parts are then racked and transferred by a conveyor line to the plating area. The plating process involves the following procedures with subsequent rinses:

1) Alkaline Clean -

A mild alkaline soap cleaner SU-486 manufactured by MacDermid, Inc.

2) Alkaline Clean -

A mild alkaline cleaner P-1777 manufactured by MacDermid, Inc.

3) Electro Clean -

A mild alkaline electrocleaner EN-1751 manufactured by MacDermid, Inc.

4) Acid Dip -

5% Sulfuric Acid.

5) Copper Strike -

Contains sodium cyanide, caustic soda, and copper metal.

6) Copper Plate -

Contains sodium cyanide, caustic soda, and copper metal.

7) Electro Clean -

A mild alkaline electrocleaner B-920 manufactured by Benchmark Company.

EPA ID #MID099124299

8) Acid Dip -

2% Sulfuric Acid.

9) Nickel Plate -

Contains nickel sulfate, nickel chloride, boric acid, and sulfuric acid.

10) Chrome Activator -

A 2% Chromic Acid Solution.

11) Chromium Plate -

Contains chromic acid and sulfuric acid.

d) Rack Stripping Operation:

The racks used to hold the parts during the plating operation have to be stripped before they can be reused. The stripping operation produces a better contact between the parts and the rack thus increasing the conductivity when the parts are immersed in the plating solution. The stripping process is as follows:

1) Nitric Acid Stripper -

60% Nitric Acid, and 6% Acid Activator Clepo 569N manufactured by Frederick Gumm Chemical Company.

2) Neutralization Rinse -

A soda ash solution used to neutralize acid drag-in.

6. General Description of Wastewater Treatment Operations:

The rinses following plating processes and any spills of process solutions are collected in separate tanks in the plating area. From these tanks, they are pumped to various treatment areas at the facility, for treatment. Details of the treatment methodology are as follows:

- 1) Nitric acid solution from the rack stripping operation is combined with the first alkaline cleaner in the plating process line. The combined solution is then shipped off-site for treatment and disposal.
- 2) The alkaline cleaner, electrocleaner, and acid dip solution prior to the copper plating process are pumped to the clarifier. Lime and caustic soda are added for pH adjustment and a polyelectrolyte is added to aid precipitation.
- 3) Cyanide rinses and the electrocleaner after the copper plating process, are pumped to the cyanide retention tank for cyanide treatment. Caustic soda is added for pH adjustment; sodium hypochlorite is added to oxidize the cyanide; sodium bisulfite is added for the treatment of residual chlorine; sodium hydrosulfite is added for the reduction of chromium which is slowly leached out of the racks by the copper plating solution; calcium chloride, ferrous sulfate and aluminum sulfate are added for the treatment of copper; and finally, a polyelectrolyte is added to aid precipitation. The treated wastewater is then pumped to the clarifier for pH adjustment and further precipitation.
- 4) The acid dip, prior to the nickel plating bath, is pumped to the clarifier unit for pH adjustment use.
- 5) Nickel plating rinse waters are pumped to the clarifier for pH adjustment and precipitation.
- 6) Chromic acid solutions and rinse waters are pumped to the chrome recovery system. The chrome recovery system is now a closed loop system. We recover and regenerate hexavalent chromium through the use of a ChromeNapper manufactured by Innova, Inc. The use of this recovery equipment has significantly reduced our need to treat chromium in our discharge.

EPA ID #MID099124299


- 7) The zinc vibratory finishing waste is pumped from the containment sump to Lagoon #1 for settling.
- 8) All metal free-rinses are pumped to the neutralization basin for pH adjustment.
- 9) The treated wastewater overflow from the clarifier discharges to the neutralization basin for pH adjustment, then is gravity fed to Lagoon #3. The underflow from the clarifier (metal hydroxide sludge) discharges to a holding tank, then is pumped to Lagoon #1 for settling. There are four lagoons connected in series. The clarifier underflow flows gradually from Lagoon #1 through Lagoons #2 and #3 into #4 and is finally discharged to the receiving stream.
- 10) The metal hydroxide sludge (F006) remains in the lagoons and is allowed to accumulate for a period of one year. At the end of a year's time, the sludge is pumped from the lagoons into tanker trucks and sent for disposal.

THE ESTIMATED SLUDGE GENERATION IS AS FOLLOWS:

AVERAGE MONTHLY	110.2 TONS
AVERAGE YEARLY	1322 TONS
MAXIMUM MONTHLY	119.9 TONS
MAXIMUM YEARLY	1439 TONS

A flow schematic of the treatment process is included with the petition.

TREATMENT SYSTEM FLOW SCHEMATIC



7. Discussion of Factors Delineated in Criteria for Listing Hazardous Waste:

Based on the established drinking water standards and the results of the EP Toxicity Extraction Procedure for Metals, the sludge generated at Stanley Tools - Fowlerville is non-hazardous even though hazardous waste constituents are treated. The metal characteristics of the sludge are far below the allowable concentrations for a toxic waste. The results show that the extract solutions meet the drinking water standards within the sensitivity of the test procedures. As a result of the treatment process, the metals are basically held in an immobile form and are not capable of posing a substantial present or potential hazard to human health or the environment when treated, stored, transported, or disposed of, or otherwise managed.

8. Sampling Methodology:

As discussed earlier under 2a, Sampling, the lagoons were sampled according to the sampling methodology devised by Mr. Morse, a copy of which is included in this petition. The sample dipper was constructed from a one-gallon plastic bottle with the neck cut off. The bottle was attached to a long wooden pole. The dipper was pulled through the sludge from top to bottom to obtain a representative cross section sample.

9. Sample Handling and Testing Methodology:

The samples were kept in sealed nalgene bottles at all times. At the time of testing, each sample was well mixed with a paddle mixer, and a portion of the sample slurry was drawn off using Tygon tubing and a vacuum line. The slurry was collected in pre-weighed 500 ml nalgene bottles which were covered to prevent evaporation losses. In all cases, over 100 grams of slurry was initially taken. A portion of the sample was tested for percent non-filterable solids, gravimetric method as described in, "Test Methods for the Evaluation of Solid Waste, Physical/Chemical Methods", U.S. EPA Publication #SW-846, Second Edition, July 1982, Method 1310, Section 7.0.

The pH of the slurry was also measured at this time.

EPA ID #MID099124299

The remaining sample portions were subjected to the E.P. Toxicity Test Extraction Procedure as outlined in, "Test Methods for the Evaluation of Solid Waste Physical/Chemical Methods", U.S. EPA Publication #SW-846, Second Edition, July 1982, Method 1310. A Millipore Hazardous Waste Filtration Unit using a pre-weighed 142 mm, 0.45 micron filter pad and nitrogen as the pressurizing gas was incorporated to achieve the solid-liquid separation. The liquid portion of the samples were collected in glass 500 ml Erlenmyer flasks and were stoppered immediately after the liquid flow ceased and the pressurizing nitrogen gas evolved from the filter unit. The liquid fractions from the initial separation were stored at 4°C for future usage. The remaining solid portion was evaluated for particle size and then the solid along with the filter pad and the support screen were placed in a covered Petri dish and the solids were immediately weighed to the nearest 0.1 mg. The solid samples were then introduced into a suitable extractor along with sixteen times their weight of deionized water. The agitation was started and the pH of the solution was measured. In all cases, the initial pH measured was greater than $\text{pH } 5.0 \pm .2$, therefore the pH was decreased using 0.5N acetic acid. After each acid addition, a 20 second equalization time was allowed and then the pH was recorded. Once again, in all cases, the maximum amount of 0.5N acetic acid (4 mls/gm of solid charged to the extractor) was added to the samples and the resultant pH never dropped near the $\text{pH } 5.0 \pm .2$ range.

The agitation was continued for a twenty-four hour period during which the pH was measured. At the end of the twenty-four hour period, the pH was again measured and the agitation was stopped. The extracted solution was then introduced into a Hazardous Waste Filtration Unit and the solid and liquid portions were separated using a 142 mm, 0.45 micron filter pad and nitrogen gas for pressurization.

EPA ID #MID099124299

The resultant liquid was collected in a 1000 ml glass Erlenmyer flask and combined with the liquid obtained from the initial separation. The combined solution was preserved for metals analysis to a pH of less than 2 using nitric acid. The sample was analyzed for E.P. Toxic Metals by Atomic Absorption Spectroscopy, as outlined in the, "Test Methods for the Evaluation of Solid Waste, Physical/-Chemical Methods", U.S. EPA Publication #SW-846, Second Edition, July 1982, Section 7.0.

Since the waste is both generated and disposed of in the State of Michigan, the elements copper and zinc were also analyzed since they are considered by the State of Michigan as EP Toxic Metals.

10. Testing Results:

The results of the E.P. Toxic Metals analysis analyzed by Atomic Absorption Spectroscopy using the methods of standard additions for quantification of the species concentration and the results of the percent solids determination are tabulated on the following pages. Each individual quadrant was analyzed separately for both total and leachable metals, also a composite sample was made up from all the samples taken and analyzed for both total and leachable metals. The total metal samples were reported in both percent by weight (on a dry weight basis) and in mg/l. Preliminary scans were run on each sample, the elements which gave absorption readings corresponding to concentrations far below the allowable limits were not quantitated by the method of standard addition techniques. The Atomic Absorption Unit was calibrated using both commercially prepared high purity atomic absorption cation standards and in-house prepared cation standards utilizing a metal or salt of the highest commercially available purity.

EPA ID #MID099124299

The sludge samples were prepared for analysis following the sample digestion methods outlined in, "Test Methods for the Evaluation of Solid Waste, Physical/Chemical Methods", U.S. EPA Publication #SW-846, Second Edition, July 1982, Method 3050. All acid reagents used were of the trace metals analysis grade purity with the exception of the acetic acid which was reagent grade purity. The liquid samples were prepared for analysis following the sample digestion methods outlined in, "Test Methods for the Evaluation of Solid Waste, Physical/Chemical Methods", U.S. EPA Publication #SW-846, Second Edition, July 1982, Method 3010. All glassware used was acid washed and rinsed prior to usage.

Sample preparation and analysis procedures performed by TRC Environmental Consultants (Outside Testing Laboratory) have been documented on their reports, and are in accordance with the testing references incorporated by Title 40 CFR Part 260.11 referenced in Title 40 CFR Part 261 Appendix III.

11. Names and Model Numbers of the Instruments Used:

a) TRC Environmental Consultants

- 1) Perkin Elmer Model 560 Atomic Absorption Spectrophotometer, equipped with background correction, and an electrodeless lamp power supply, and HGA-2200 furnace and a MHS-10 Mercury Hydride System.

b) Stanley Works Corporate Laboratory

- 1) Perkin Elmer Model 2380 Atomic Absorption Spectrophotometer, equipped with a background correction system.
- 2) Mettler H31 Electronic Balance with sensitivity to 0.1 mg.
- 3) Ainsworth Model 10N Electronic Balance with sensitivity to 0.1 mg.

EPA ID #MID099124299

- 4) Orion Model 501 Digital pH Meter.
- 5) Millipore Hazardous Waste Filtration Unit
Catalog No. YT30142HW.
- 6) Millipore 0.45 Micron Membrane Filters, 142 mm Diameter,
Catalog No. HAWP14250.

I certify under penalty of law that I have personally examined and am familiar with the information submitted in this demonstration and, that based on my inquiry of those individuals immediately responsible for obtaining the information, I believe that the submitted information is true, accurate and complete, except for the cyanide analysis and the determination of the oil and grease content of the sludge which will be submitted in the second part of the petition. I am aware that there are significant penalties for submitting false information, including the possibility of fine and imprisonment.

Sincerely,

THE STANLEY WORKS

A handwritten signature in dark ink, appearing to read "Richard H. Ayers", is written over the typed name.

Richard H. Ayers
Group Vice President

T H E S T A N L E Y W O R K S

Since 1843

P.O. Box 1800

NEW BRITAIN, CONNECTICUT 06050

(203) 225-5111

March 15, 1983

Mr. Myles Morse
Office of Solid Waste (WH-565)
U.S. Environmental Protection Agency
Washington, D.C. 20460

Re: Stanley Tools, Fowlerville, MI
EPA I.D.# MID-099124299

Dear Mr. Morse:

As per our phone conversation of March 10, 1983, I am sending you this letter to confirm the lagoon sampling methodology that we discussed. To summarize our conversation, our Michigan Tools facility is involved in the fabrication, plating, and finishing of zinc-die castings. The facility treats cyanide, hexavalent chromium, and nickel electroplating rinse waters in tanks. The blow down and underflow from our clarifier is directed to the first of four settling lagoons which are in series. The bulk of the solids settling occurs in Lagoon #1 while further settling is achieved in the remaining lagoons. The final discharge from Lagoon #4 is directed to a receiving stream under the guidelines of an NPDES Permit. The F006 waste remains in the lagoon for a period of time of about one year, before the lagoons are pumped down and the waste is sent for disposal.

The average dimensions of the lagoons are 60' wide x 80' long x 4' deep. We discussed that in order to obtain a representative sample from the lagoons, lagoons #1 and #2 should be divided into quadrants while lagoons #3 and #4 divided in two sections. From each quadrant or section, at least four grab samples will be collected. The samples will be taken in a manner that will cross-section the area of the quadrant or section being sampled. Each grab sample will be a representative sample of the buildup of sludge in the quadrant or section. The grab samples will then be composited and one composite sample from each quadrant or section will be obtained. Please see attached drawing.

Page 2

Mr. Myles Morse
Re: Stanley Tools, Fowlerville, MI
EPA I.D.# MID-099124299


The composite samples will be analyzed for total metals along with total and amenable cyanide. The extract from the EP Toxicity Test will be analyzed for leachable metals.

If, in your opinion, the sampling methodology discussed above meets the requirements of 260.22H, please sign and date below and return a copy for our records. If the plan does not meet the requirements of 260.22H, please contact me at your earliest convenience.

Thank you for your cooperation with this matter.

Sincerely,

THE STANLEY WORKS



William J. Guerrera
Environmental Chemist
Stanley Laboratory
1309 Corbin Avenue
New Britain, CT 06053

jzz


LAGOON

SAMPLING

METHODOLOGY




4




3

← ARROWS INDICATE DIRECTION IN WHICH SAMPLES WILL BE DRAWN



1



2

The analytical data presented on the following pages has been developed by TRC Environmental Consultants. A total metals analysis for Arsenic, Mercury, and Selenium was performed by TRC on sample #1299 which corresponds to composite sample M. The results of the analyses indicate that the levels of Arsenic, Mercury, and Selenium, on a % dry weight basis are below the detection limits given. Arsenic and Selenium were not analyzed in the leachate since their levels from the total metals analysis were so low that if all the metals were leachable, they would still yield levels less than the E.P. Toxicity limits.

An exception was made for mercury, since signal suppression from matrix interference yielded a level of mercury in the total metals analysis which could be E.P. Toxic, mercury was analyzed in the leachate. The leachate analysis indicated that the mercury content was significantly less than the E.P. Toxic limits.



Environmental
Consultants, Inc.

800 Connecticut Boulevard
East Hartford, Connecticut 06108
(203) 289-8631

April 29, 1983

Mr. William Guerrero
Stanley Laboratory
The Stanley Works
New Britain, CT 06053

Dear Bill:

TRC Project 2150-B51-09
P.O. 27726L

The results of the analysis by Method of Addition of Sludge sample #1299 are as follows:

% solids	3.16%
Arsenic	non-detected <2.72 µg/g (dry weight basis)
Mercury	non-detected <5.89 µg/g (dry weight basis)
Selenium	non-detected <5.44 µg/g (dry weight basis)

The sample was prepared and analyzed using methods given in Standard Methods for the Examination of Water and Wastewater 15th Edition, 1980 APHA-AWWA-WPCF and "Methods for Chemical Analysis of Water and Wastes" (EPA-600/4-79-020, March 1979). Standard Methods Procedure 302H "Digestion of Sludge with High or Refractory Organic Content" was followed for the preparation for Arsenic and Selenium analysis. The sludge was prepared for mercury analysis by an aquaregia-permanganate digestion similar to EPA Method 245.5. Matrix effects caused suppression of the signal for the three metals.

Arsenic was analyzed by the EPA Furnace Method 206.2. First the original digestion solution was used for the Method of Addition procedure but results were inconsistent due to the sample matrix and/or acid concentration. The sample was diluted five-fold and then analyzed without interference or suppression of the signal. The result, calculated by linear regression using three points from the Method of Addition, was below the limit of detection.

Mercury was analyzed by cold vapor generation following the Perkin-Elmer procedure for the MHS-10 Mercury-Hydride System. The sample matrix caused approximately 70-fold suppression of the mercury signal. The result, calculated by linear regression using four points from the Method of Addition, was below the limit of detection.

Selenium was first analyzed by hydride generation. However, severe suppression of the signal occurred and this method was abandoned and EPA Method 270.2 was used instead. A five-fold dilution of the sample was used for Method of Addition which still gave about 20% suppression of the signal. The result, calculated by linear regression using three points of the Method of Addition was below the limit of detection.

Mr. William Guerrero
The Stanley Works

-2-

April 29, 1983
TRC Project 2150-B51-09

I am enclosing copies of the notebook pages and charts for this sample. If you have any questions about this analysis please do not hesitate to call.

Sincerely,

TRC ENVIRONMENTAL CONSULTANTS, INC.

Margaret F. Flanagan

Margaret F. Flanagan
Senior Chemist

MFF/jjs
Enclosures

TRC

4-27-83

ELEMENT Se FLOW TIME 3 Stop
 WAVE LENGTH 196.0 TUBE TYPE non-pyro
 SLIT 0.7 DRY 125 ° 22 sec 10 ramp
 GAS Ar CHAR 1200 ° 25 sec 10 ramp
 DIV. 31 ATOM 2700 ° 7 sec _____ ramp

Standard paper 4-27-83 AAPB 1 p36 in 0.5% HNO₃

To 1.0 ml add 20µl 5% HNO₃ and 20µl 30% H₂O₂

501 0.0 ppb Se

2 100.0

3 50

4 20

5 0.0

6 100.0

Response

-0.008

0.875 → 100.0

54.1

22.8

1.2

102.9 → 100

Limit of det.

$$\frac{100}{0.875} \times 0.02 = 7.27$$

7 EPA-WS-12-Blank 125 → 25

8 1 125 → 25

9 2 125 → 25

10 0.0 ppb Se

9.9 × $\frac{25}{125}$

2.0 ppb

69.4 × $\frac{25}{125}$

$$13.88 - 2.0 = 11.9 \text{ ppb}$$

overall

3.9 → 0.0

11 Stanley Sludge (16-0) m4A Dilution → 5 +0.0 ppb Se

12 +50.0

13 +100.0

14 +200.0



4.7

4th linear reg.

corr 0.9983

(3 pte)

0.9998

20.6

Slope 0.299

0.33

37.7

Y-int 5.72

4.5

64.4

if y=0, x=-19.2

(-13.6)

$$-13.6 \times \frac{10}{1.25} \times \frac{0.1002}{1.25} \times 5 = -5.44 \mu\text{g/l}$$

66.6

-2.0 = 64.6 ppb Se

15 EPA (2) 100 → 100

16 Sludge Blank m4A No dil 0+0

17 Sludge Blank 0+100

18 0+200

19

-4.3

corr 0.9998

21.1

Slope 0.175

44.7

Y-int -4.0

if y=0, x=-14.3

n Page No. _____

% Solids

wt of dish + shaken slurry sample = 81.9349

wt dish = 59.2326

wt sample (wet) = 22.7023

Dried @ 100° C overnight

Take 3 wts to agree w/k 1%

wt of dish + dried sludge = 59.9472

59.9492

59.9508

avg = 59.9491

wt dish = 59.2326

wt dry solids = 0.7165

$$\% \text{ dry solids} = \frac{0.7165}{22.7023} \times 100 = 3.16\%$$

To Page No. _____

Witnessed & Understood by me,

M. Alkawas...

Date

4-25-80

Invented by

A. L. ...

Date

4-10-80

Ascorbic AcidFrom Page No. 1Sample 1 (Dish #8)

Wt of wet sample + dish = 110.7585

Wt of dish = 67.9671

Wt of wet sample = 42.7914 $\times 0.0316 = 1.35$ g wt of dry sampleSample 2 (Dish #16-0)

Wt of wet sample + dish = 108.2967

Wt of dish = 68.6183

Wt of wet sample = 39.6784 $\times 0.0316 = 1.25$ g wt of dry sampleSample 3 (Dish #17) For spike

Wt of wet sample + dish = 110.6937

Wt of dish = 68.57669

Wt of wet sample = 42.11708 $\times 0.0316 = 1.33$ g wt of dry spike sampleAdd 50 μ l of 100 ppm AsAdd 50 μ l of 100 ppm Se} = 50 μ l spike when samples are built up to 100 μ lSample 4 (Dish #91411)

Reagent Blank

Samples evaporated on hot plate to ~20 ml. Add 12 ml HNO_3 (100% H₂O₂) to near dryness, & repeat HNO_3 addition to get rid of organic.

Add 20 ml HClO_4 , fume, build to 100 ml w/ di H₂OTo Page No. 2

Witnessed & Understood by me,

Date

Invented by PL

Date

Recorded by

11/1/83

4-27-83

Limit of detection

$$\frac{100}{1.1845} \times 1.02 = 6.89 \text{ ppb/As}$$

for $1 \rightarrow 5$ dis = 3%
for $5 \rightarrow 1$ com = 1.36

Recorded by

on Page No. 21As - Blank Analysis onlystd 1 0, 100, 50, 20 ppb As in 0.5% HNO_3 (AR 5608 12 31-83 MF)Reagent to 1 ml Sample add 0.02 ml 5% $\text{Ni}(\text{NO}_3)_2$ ~~from Stanley, 1st P. 70~~

Stanley must be done by method of addition

ELEMENT As FLOW TIME 3-5 sec
 TUBE TYPE non-pyro filter in
 DRY 125 ° 46 sec 10 ramp
 CHAR 1000 ° 46 sec 10 ramp
 DIV. 10000 ATOM 2700 ° 7 sec — ramp

Cap H	Sample	dilution	Response	ppb As
101	0.0	1 ppb As		
2	100.0			
3	50.0			
4	20.0			
105	0.5 ml Stanley Blank + 0.5 ml	0 ppb As		
6	+ 0.5 ml 20			
7	+ 0.5 ml 50			
8	+ 0.5 ml 100			
109	0.5 ml sample ① + 0.5 ml	0 ppb As		
10	+ 0.5 ml 20			
11	+ 0.5 ml 50			
12	+ 0.5 ml 100			

Use the note p. 76

To Page No. 22

Witnessed & Understood by me,

Date

Invented by

Date

Recorded by

4/27/82

Page No. _____

Sample	Solution	Response	100 AT
WFOIL CIA T.M. Blank		1.9	26.9 ACP
" (1)			
" (2)			
0.5 ml Sample Blank + 0.5 ml 0.1% AT	1 → 5	3.7	
20		12.5	
50		43.1	
100		55.9	
		corr = 0.9897	
		slope = 0.52	
		y-inter = 2.13	
		y = 0, x = -4.14 (neg)	
		x = 20.7	
		= 34.5 mg/ml	

0.5 ml Sample (1) + 0.5 ml 0.1% AT	1 → 5	4.4	corr = 0.9889
dry wt = 1.35 g	20	36.4	slope = 0.59
	50	50.0	y-inter = 1.00
	100	68.8	y = 0, x = -20.6
			x = 128 mg/ml
		Repeated	948.1 mg/g = 9.48 mg/g

0.5 ml Spike Sample + 0.5 ml 0.1% AT	1 → 5	7.5	corr = 0.9883
dry wt = 1.33 g	20	26.0	slope = 0.52
+ 50.0 μl AT Spike	50	38.0	y-inter = 11.36
Subtract 0.5 ml to get spike	100	61.7	y = 0, x = 22.02
(Diluted 1:5, then read again; final result shows good agreement)			x = 110.1 μg/ml
0.0 1% AT		70	= 8278 mg/g = 8.28 mg/g
100.0 1% AT		448	

dc

+ conc. of added std (i.e. 0, 20, 50, or 100) plus response units LR 0, 2nd "x", via linear

(as 1:5 dilution) gives conc. of AT in sample in mg/ml

x 100 = mg in sample

÷ sample wt (1.74) = mg/g

(avg)

To Page No. _____

ed & Understood by me,

Date

Invented by

Date

From Page No. _____

Mercury Digestion

3607

1) wet weight sample 1 = 11.4149 g wet = 0.3765 g dry

2) wet weight sample 2 = 12.1189 g wet = 0.3924 g dry

3) wet weight spiked sample (1200 ng Hg) = 11.8837 g wet

4) Blank

Standards

WS I = 1 ppm Hg 1000 ng/ml * 0.1 ml → 100.0 ml = 1.111 Hg = 1 ng/ml

WS II = 0.1 ppm Hg 1 ng/ml * 5 ml → 50 ml = 0.1 ppm Hg =

ml WS II in final	total ng	ng/ml
Vol. of 100 ml	Hg	Hg
0.2 ml	0 ng	0.111
0.5	50	0.5
1.0	100	1.0
2.0	200	2.0
5.0	500	5.0
10.0	1000	10.0

Procedure

Add 5 ml aqua regia. Heat 2 minutes @ 95°C in constant temp H₂O bath - cool

Add 15 ml 5% KMnO₄ solution Heat for 30 min @ 95°C in const temp H₂O bath - cool

Add 6 ml sodium chloride hydroxylamine sulfate soln (12 g of each mixed together → 100 ml)

Dilute to 100 ml, Try a 10 ml aliquot by hydride

Mod of addition -- actually, it isn't necessary to run the standards above, since we will be run MOA

To Page No. _____

Witnessed & Understood by me,

Margaret J. J. Loran

Date

4-26-83

Invented by

Ali

Date

4-25-83

Recorded by

No. _____

Mercury Cold Vapor

samples were digested as on p. 78, no acid or KNO₃ treatment required (as on p. 66)

1% NaBH₄

1% NaOH

Condition

Hg EOC 5 ml/min

V₁ = 20 psi

= 253.6

V₂ = 0.7 atm

variation = 5.000

= 0.5 ml

= const

1-60

Recorder = TLM

Qual. Comp.

In. Out

Recorder

~~7.5~~ = 10 mV

Speed = 1 cm/min

Try using a 10 ml aliquot of sample (not taken
add 0 ng, 25 ng, 50 ng, & 75 ng Hg ^{← true digestion procedure}
(0, 25, 50, & 75 ml of 1 ppm std) for

method of addition but first purge system with
blank taken with digestion procedure, then 10 ml
with 10 ml 10 ppm standard taken with digestion
procedure

Sample	Aliquot, ml	col	ng Hg in aliquot	ng/g (dry) Hg
Blank, 1 + 0 ng Hg ①	10.0	10.0	corr = 0.9913	
+ 25 ng Hg ②	↓	22.0	m. 0.71	
+ 50 ng Hg ③	↓	40.5	g. inter = 7.25	
+ 75 ng Hg ④	↓	63.0	0.240 ml = 10.21	
			<u>1.102 ng/ml</u>	
Sample 1 + 0 ng Hg ①	10.0	3.0		
+ 25 ng Hg		2.0		
+ 50 ng Hg		2.0		
Sample 1 + 250 ng Hg		3.5		
+ 2500 ng Hg ②	10.0	27.5		

used - run out
of sample 1, use sample 2

To Page No. _____

d & Understood by me,

Date

4-26-83

Invented by

Date

4-25-83

Project No. 111 01Book No. Amc(1)TITLE Hg, cont - Sample, EPA, LtdPage No.

Sample	Aliquot	Cal
2 + 0 ng Hg (1) (A)	10.0	2.0
+ 2500 ng Hg (2) (B)		31.0
+ 3750 ng Hg (3) (C)		39.5
+ 5000 ng Hg OMIT		36.0 OMIT
+ 8000 ng Hg (4)		48.0
+ 10000 ng Hg (5) (D)		12.0

ng Hg in
aliquot

LA = 5.10.00

WTR = 0.932

r = 0.906

y-inter = 2.40

0.240 x = -16.77

or 167.7 ng/ml

ng/g (avg)

LA-4 p15 11-D

r = 0.9937

m = 0.0103

y = 2.39

0.24 x = -231


427.37 ng/g


Correct

$$4 \text{ p15 } \frac{231 \text{ ng}}{10 \text{ ml}} = \frac{231 \text{ ng}}{\text{ml}} \text{ or } \frac{546 \text{ ng}}{9} \approx \frac{589 \text{ ng}}{9}$$

ng/g

Mercury Chart





August 16, 1983

Mr. William Guerrero
Stanley Laboratories
The Stanley Works
New Britain, Connecticut 06053

Re: TRC Project 2150-B51-15
P.O. C 28684 L

Dear Bill:

The concentration of mercury in EP toxicity Leachate #1299 is 0.0027 µg/ml. The sample and lab blank were analyzed by method of additions on August 9th by Anne Levine. Mercury was analyzed by the Cold Vapor Technique using Perkin-Elmer Method EN-1 for the MHS-10 Mercury Hydride System on the Perkin Elmer 560 Atomic Absorption Unit. Each response was recorded and peak height was used for the calculations. The responses were corrected for the blank and then linear regression was used to calculate the result. X was the nanograms added to the sample and y was the blank corrected peak height. The x-intercept equalled the ng mercury in the aliquot analyzed. I have enclosed copies of the notebook pages and chart.

If you have any questions about the analysis please do not hesitate to call.

Very truly yours,

TRC ENVIRONMENTAL CONSULTANTS, INC.

Margaret F. Flanagan

Margaret F. Flanagan
Senior Chemist

MFF/jjs

Enclosures

PROJECT NO.

Book No. AN-3TITLE Hg - Hydride - Standby

From Page No. _____

3% NaBH₄
10% NaOH15g
5g

> 100

$$1000 \mu\text{g/ml} \times 0.1 \mu\text{l} \times 100 \mu\text{l} = 1 \mu\text{g/ml}$$

$$= 1 \text{ ng/ml}$$

$$\times 1 \mu\text{l} \rightarrow 100 = 10 \mu\text{g/ml} = 10 \text{ ng/l}$$

Hg EDC - 5 watts file

NL: 40 psi

λ: 253.6 g/l: 0.7 alt

Mode: cond

AA-Bu

signal: cone

Expansion: 3.5

E: 0.5

Recorder: TCI

- Take suitable aliquot, suck to 100

- Add 1 ml 30% HNO₃ - 30% H₂O₄- Add 5% KNO₃ dropwise till purple

100 ml

- Run all by MOD

$$\frac{\text{ng in aliquot}}{\text{aliquot}} = \text{ng/ml Hg}$$

From Page No. _____

<u>Run</u>	<u>Sample</u>	<u>cd</u>	<u>cd-blank</u>	
17	0 ng Hg	11.0		
18	25	22.0		
19	50	35.0		
20	75	45.0		
21	100	52.5		
22	same as run #15 (50 ng undigested)	35.0		
23	" " " #16 (50 ng digested)	22.0		
24	5 ml Stanley + 0 ng Hg	21.0	11.0	r = 0.9541
25	+ 100	46.0	36.0	m = 0.382
26	+ 50	29.0	19.0	y = 25.1
27	+ 150	79.0	69.0	x = -13.4
				<u>2.67 ng/ml</u>
28	5 ml Blank + 0 ng Hg	10.0	0.0	r = 0.4992
29	+ 50	33.0	23.0	m = 0.487
30	+ 75	38.0 - omit	28.0	y = -0.583
31	+ 100	59.5	49.5	x = +1.2
				<u>< 1 ng/ml ND</u>
32	1 ml Stanley (A) + 0 ng Hg	11.0		<u>< 500 ng/ml</u> <u>ND</u>
33	+ 100	10.0 - OMIT		
34	0 + 1000 ng	28.5		
35	+ 100	23.0		

To Page h

46

25

2

24

22

20
23

10

20

30

40

50

60

70

35

22
21

0.69

24

52.5

24

45

20

25

20

10

20

30

40

50

60

70

20

20

3

10

32

1

31

59.5

30

38

29

10

20

30

40

50

60

70

Nr. 1069

28

10

27

0

10

20

30

40

50

60

70

26

24

DETERMINATION OF ARSENIC, SELENIUM AND MERCURY IN DRINKING WATER

SCOPE

This method describes the determination of As, Se and Hg in drinking water in concentrations above 1 µg/l. This method is also suitable for determining Bi and Sb.

OPERATING PARAMETERS

Element	As	Se	Hg	
Source	EDL	EDL	EDL	
Wavelength (nm)	193.7	196.0	253.6	
Slit Setting (nm)	0.7	2.0	0.7	
Purge Gas	Ar/N ₂	Ar/N ₂	Ar/N ₂	
Background Correction	No	No	No	
MHS-1 Program	HYD I	HYD IV	Hg III	
Cell Temp.	900 °C	900 °C	200 °C	
Reductant (2.5 ml)	5% NaBH ₄ 2% NaOH	5% NaBH ₄ 2% NaOH	5% NaBH ₄ 2% NaOH	
MHS-10 Cell Heating	Air/C ₂ H ₂	Air/C ₂ H ₂	-	
Reductant	3% NaBH ₄ 1% NaOH	3% NaBH ₄ 1% NaOH	3% NaBH ₄ 1% NaOH	

INTERFERENCES

No interferences have been reported.

REAGENTS

30% hydrochloric acid

5% potassium permanganate solution

1.5% ; 30% nitric acid

1.5% ; 30% sulphuric acid

All reagents of Analytical Reagent (AR) grade.

STANDARD SOLUTIONS

0.002	0.004	0.008 $\mu\text{g As/ml}$
0.002	0.004	0.008 $\mu\text{g Se/ml}$
0.001	0.002	0.004 $\mu\text{g Hg/ml}$ (diluent: 1.5% HNO_3 + 1.5% H_2SO_4 solution)

10-ml aliquots used for calibration.

SAMPLE PREPARATION

For As and Se determinations, 10-ml sample aliquots are dispensed into the reaction flask and acidified with 500 μl 30% HCl .

For Hg determinations, 10-ml sample aliquots are dispensed into the reaction flask and acidified with 500 μl 30% HNO_3 and 500 μl 30% H_2SO_4 . To oxidize any organically-bound Hg, 5% KMnO_4 solution is added dropwise until the violet colour just remains. At least 30 s should elapse before the determination is performed.

ANALYSIS

10-ml sample aliquots are normally used for all determinations.

To determine lower concentrations, sample aliquots of up to 50 ml may be used. To prepare calibration plots, the standard solutions should be correspondingly diluted. The acid content must be increased appropriately.

CALCULATION

The standard solutions have concentrations corresponding to:

2, 4, 8 $\mu\text{g As/l}$

2, 4, 8 $\mu\text{g Se/l}$

1, 2, 4 $\mu\text{g Hg/l}$

The concentration of each metal in the sample can be obtained by direct comparison to the standard calibration plot.

The analytical data presented on the following pages has been developed by the Stanley Works Corporate Laboratory. Included in the data is an E.P. Toxicity summary sheet on all the samples analyzed; individual data sheets detailing both Total and Extractable metal values for each sample; and the analytical data derived by the method of standard additions for both Total and Extractable metals.

As stated earlier in the petition, metals which yielded absorbance values corresponding to concentrations below the allowable limits, were not quantified by the method of standard additions. The metals barium and silver consistently yielded low absorbance values and were not quantified. Cadmium and lead also yielded low absorbance values but due to the low E.P. Toxicity limits placed on these metals and since they could be present in electroplating operations at the facility, the leachate samples were quantified by the method of additions.

ANALYSIS DATA

STANLEY TOOLS - FOWLERVILLE
EPA ID #MID099124299

E. P. TOXICITY EXTRACTION RESULTS SUMMARY mg/l

SAMPLE	ARSENIC	BARIUM	CADMIUM	CHROMIUM TOTAL	COPPER	LEAD	MERCURY	NICKEL	SELENIUM	SILVER	ZINC
A	N.A.	5.0*	0.02*	0.05*	0.38	0.05*	N.A.	1.60	N.A.	0.02*	0.85
B	N.A.	5.0*	0.02*	0.05	0.70	0.05*	N.A.	4.50	N.A.	0.02*	10.5
C	N.A.	5.0*	0.02*	0.05*	0.50	0.05*	N.A.	2.70	N.A.	0.02*	7.10
D	N.A.	5.0*	0.02*	0.05*	0.38	0.05*	N.A.	1.33	N.A.	0.02*	1.05
E	N.A.	5.0*	0.02*	0.05*	0.23	0.05*	N.A.	1.45	N.A.	0.02*	1.71
F	N.A.	5.0*	0.02*	0.05*	1.05	0.05*	N.A.	8.20	N.A.	0.02*	17.6
G	N.A.	5.0*	0.02*	0.05*	0.20	0.05*	N.A.	0.63	N.A.	0.02*	3.25
H	N.A.	5.0*	0.02*	0.05*	0.20	0.05*	N.A.	4.87	N.A.	0.02*	14.5
I	N.A.	5.0*	0.02*	0.32	0.32	0.05*	N.A.	6.25	N.A.	0.02*	0.70
J	N.A.	5.0*	0.02*	0.05*	0.38	0.05*	N.A.	9.50	N.A.	0.02*	5.5
K	N.A.	5.0*	0.02*	0.05*	0.40	0.05*	N.A.	1.95	N.A.	0.02*	0.94
L	N.A.	5.0*	0.02*	0.05*	0.20	0.05*	N.A.	6.20	N.A.	0.02*	2.20
M	N.A.	5.0*	0.02*	0.05*	0.37	0.05*	0.0027	0.95	N.A.	0.02*	2.65

N.A. - Not analyzed for in the extractable metals sample since they are not used in our process and total constituent analysis of composite indicates a level below the given detection limits.

* Not detected, concentration found to be lower than the detection limit given.

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample ALagoon # 1

Parameter	Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic	N.A.	N.A.
Barium	N.D. - < 0.10%	N.D. - < 5.0
Cadmium	N.D. - < 0.0004%	N.D. - < 0.02
Chromium, Total	2.40%	N.D. - < 0.05
Copper	3.86%	0.38
Lead	N.D. - < 0.001%	N.D. - < 0.05
Mercury	N.A.	N.A.
Nickel	2.74%	1.60
Selenium	N.A.	N.A.
Silver	N.D. - < 0.0004%	N.D. - < 0.02
Zinc	2.80%	0.85
pH	9.54	
% Solids -	4.25%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample BLagoon # 1

Parameter	Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic	N.A.	N.A.
Barium	N.D. - < 0.10%	N.D. - < 5.0
Cadmium	N.D. - < 0.0004%	N.D. - < 0.02
Chromium, Total	1.70%	0.05
Copper	3.24%	0.70
Lead	N.D. - < 0.001%	< 0.05
Mercury	N.A.	N.A.
Nickel	1.80%	4.50
Selenium	N.A.	N.A.
Silver	N.D. - < 0.0004%	N.D. - < 0.02
Zinc	4.00%	10.5
pH	9.12	
% Solids -	3.57%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample C Lagoon # 1

Parameter	Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic	N.A.	N.A.
Barium	N.D. - <0.10%	N.D. - <5.0
Cadmium	N.D. - <0.0004%	N.D. - <0.02
Chromium, Total	5.60%	N.D. - <0.05
Copper	2.54%	0.50
Lead	N.D. - <0.001%	N.D. - <0.05
Mercury	N.A.	N.A.
Nickel	1.80%	2.70
Selenium	N.A.	N.A.
Silver	N.D. - <0.0004%	N.D. - <0.02
Zinc	3.74%	7.10
pH	9.20	
% Solids -	10.28%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample DLagoon # 1

Parameter	Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic	N.A.	N.A.
Barium	N.D. - <0.10%	N.D. - <5.0
Cadmium	N.D. - <0.0004%	N.D. - <0.02
Chromium, Total	5.60%	N.D. - <0.05
Copper	1.52%	0.38
Lead	N.D. - <0.001%	N.D. - <0.05
Mercury	N.A.	N.A.
Nickel	2.30%	1.33
Selenium	N.A.	N.A.
Silver	N.D. - <0.0004%	N.D. - <0.02
Zinc	2.80%	1.05
pH	10.50	
% Solids -	2.63%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

jzz

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample ELagoon # 2

Parameter	Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic	N.A.	N.A.
Barium	N.D. - <0.1%	N.D. - <5.0
Cadmium	N.D. - <0.0004%	N.D. - <0.02
Chromium, Total	2.70%	N.D. - <0.05
Copper	4.24%	0.23
Lead	N.D. - <0.001%	N.D. - <0.05
Mercury	N.A.	N.A.
Nickel	1.10%	1.45
Selenium	N.A.	N.A.
Silver	N.D. - <0.0004%	N.D. - <0.02
Zinc	3.78%	1.71
pH	9.30	
% Solids -	1.74%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample FLagoon # 2

Parameter	Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic	N.A.	N.A.
Barium	N.D. <0.1%	N.D. <5.0
Cadmium	N.D. <0.0004%	N.D. <0.02
Chromium, Total	1.86%	N.D. <0.05
Copper	5.04%	1.05
Lead	N.D. <0.001%	N.D. <0.05
Mercury	N.A.	N.A.
Nickel	2.08	8.20
Selenium	N.A.	N.A.
Silver	N.D. <0.0004%	N.D. <0.02
Zinc	6.14	17.6
pH	8.92	
% Solids -	4.15%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

dlw

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample G Lagoon # 2

Parameter		Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic		N.A.	N.A.
Barium	N.D.	<0.10%	N.D. <5.0
Cadmium	N.D.	<0.0004%	N.D. <0.02
Chromium, Total		2.18%	N.D. <0.05
Copper		3.00%	0.20
Lead	N.D.	<0.001%	N.D. <0.05
Mercury		N.A.	N.A.
Nickel		1.10%	0.63
Selenium		N.A.	N.A.
Silver	N.D.	<0.0004%	N.D. <0.02
Zinc		4.00%	3.25
pH		8.53	
% Solids -		3.02%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

dlw

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample HLagoon # 2

Parameter	Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic	N.A.	N.A.
Barium	N.D.<0.10%	N.D. <5.0
Cadmium	N.D.<0.0004%	N.D. <0.02
Chromium, Total	2.44	N.D. <0.05
Copper	3.10	0.20
Lead	N.D.<0.001%	N.D. <0.05
Mercury	N.A.	N.A.
Nickel	1.36%	4.87
Selenium	N.A.	N.A.
Silver	N.D.<0.0004%	N.D. <0.02
Zinc	5.16%	14.5
pH	8.85	
% Solids -	2.73%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

dlw

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample ILagoon # 3

Parameter	Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic	N.A.	N.A.
Barium	N.D. <0.10%	N.D. <5.0
Cadmium	N.D. <0.0004%	N.D. <0.02
Chromium, Total	1.28%	0.32
Copper	1.64%	0.32
Lead	N.D. <0.001%	N.D. <0.05
Mercury	N.A.	N.A.
Nickel	1.88%	6.25
Selenium	N.A.	N.A.
Silver	N.D. <0.0004%	N.D. <0.02
Zinc	1.70%	0.70
pH	9.13	
% Solids -	1.74%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

dlw

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample JLagoon # 3

Parameter		Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic		N.A.	N.A.
Barium	N.D.	<0.10%	N.D. < 5.0
Cadmium	N.D.	<0.0004%	N.D. < 0.02
Chromium, Total		1.34%	N.D. < 0.05
Copper		2.76%	0.38
Lead	N.D.	<0.001%	N.D. < 0.05
Mercury		N.A.	N.A.
Nickel		2.60%	9.50
Selenium		N.A.	N.A.
Silver	N.D.	<0.0004%	N.D. < 0.02
Zinc		2.68%	5.50
pH		9.09	
% Solids -		2.01%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

dlw

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample KLagoon # 4

Parameter	Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic	N.A.	N.A.
Barium	N.D. < 0.10%	N.D. < 0.50
Cadmium	N.D. < 0.0004%	N.D. < 0.02
Chromium, Total	0.96%	N.D. < 0.05
Copper	0.80%	0.40
Lead	N.D. < 0.001%	N.D. < 0.05
Mercury	N.A.	N.A.
Nickel	1.40%	1.95
Selenium	N.A.	N.A.
Silver	N.D. < 0.0004%	N.D. < 0.02
Zinc	1.32%	0.94
pH	9.53	
% Solids -	1.13%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

dlw

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample LLagoon # 4

Parameter		Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic		N.A.	N.A.
Barium	N.D.	<0.10%	N.D. <5.0
Cadmium	N.D.	<0.0004%	N.D. <0.02
Chromium, Total		1.06%	N.D. <0.05
Copper		2.00%	0.20
Lead	N.D.	0.001%	N.D. <0.05
Mercury		N.A.	N.A.
Nickel		1.68%	6.20
Selenium		N.A.	N.A.
Silver	N.D.	<0.0004%	N.D. <0.02
Zinc		2.00%	2.20
pH		9.03	
% Solids -		1.25%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

dlw

Analysis Data

Stanley Tools - Fowlerville

E.P.A. I.D. #MID099124299

Sample M
#1299Lagoon #1,2,3,4 Composite

Parameter	Total Metals % Dry Weight	Extractable Metals mg/l
Arsenic *	N.D. <0.000272%	N.A.
Barium	N.D. <0.01%	N.D. <5.0
Cadmium	N.D. <0.0004%	N.D. <0.02
Chromium, Total	2.14%	N.D. <0.05
Copper	3.36%	0.37
Lead	N.D. <0.001%	N.D. <0.05
Mercury *	N.D. <0.000589%	0.0027
Nickel	1.64%	0.95
Selenium *	N.D. <0.000544%	N.A.
Silver	N.D. <0.0004%	N.D. <0.02
Zinc	4.00%	2.65
pH	9.02	
% Solids -	3.16%	

N.A. - Not analyzed for in the individual samples since they are not used in our process. See Total Constituent Analysis Sample M.

N.D. - Not detected, concentration found to be lower than the detection limit given.

* Analyzed by TRC Environmental Consultants

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ASample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.047</u>	<u>.046</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.060</u>	<u>.060</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.076</u>	<u>.075</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.104</u>	<u>.104</u>

X - Intercept = 1.93

Sample Concentration x Dilution Factor = Actual Concentration
1.93 mg/l 100 193.0 mg/l Cu

% By Weight (dry weight basis) - 3.86

William J. Guerrera
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ASample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Zinc (Zn)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.173</u>	<u>.171</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.227</u>	<u>.226</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.286</u>	<u>.285</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.394</u>	<u>.395</u>

X - Intercept = 1.40

Sample Concentration x Dilution Factor = Actual Concentration

1.40 mg/l 100 140.0 mg/l Zn% By Weight (dry weight basis) - 2.80

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ASample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.020</u>	<u>.020</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.027</u>	<u>.027</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.035</u>	<u>.034</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.047</u>	<u>.049</u>

X - Intercept = 1.37

Sample Concentration x Dilution Factor = Actual Concentration

1.37 mg/l 100 137.0 mg/l Ni

% By Weight (dry weight basis) - 2.74

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ASample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Chromium (Cr)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.032</u>	<u>.032</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.045</u>	<u>.045</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.059</u>	<u>.059</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.086</u>	<u>.085</u>

X - Intercept = 1.20

Sample Concentration x Dilution Factor = Actual Concentration

1.20 mg/l 100 120.0mg/l Cr
% By Weight (dry weight basis) - 2.40

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample BSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions

Absorbance

20 mls Blank and 30 mls Sample	<u>.047</u>	<u>.047</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.061</u>	<u>.061</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.075</u>	<u>.075</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.105</u>	<u>.103</u>

X - Intercept = 1.62

Sample Concentration x Dilution Factor = Actual Concentration
1.62 mg/l 100 162.0 mg/l Cu

% By Weight (dry weight basis) - 3.24

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample BSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Zinc (Zn)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.226</u>	<u>.225</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.282</u>	<u>.282</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.339</u>	<u>.338</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.450</u>	<u>.450</u>

X - Intercept = 2.00

Sample Concentration x Dilution Factor = Actual Concentration

2.00 mg/l 100 200.0 mg/l Zn% By Weight (dry weight basis) - 4.00

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample BSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.013</u>	<u>.013</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.020</u>	<u>.020</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.027</u>	<u>.027</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.041</u>	<u>.041</u>

X - Intercept = .90

Sample Concentration x Dilution Factor = Actual Concentration

0.90 mg/l 100 90.0 mg/l Ni% By Weight (dry weight basis) - 1.80

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample BSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Chromium (Cr)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.023</u>	<u>.023</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.036</u>	<u>.036</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.049</u>	<u>.049</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.074</u>	<u>.074</u>

X - Intercept = .850

Sample Concentration x Dilution Factor = Actual Concentration

0.85 mg/l 100 85.0 mg/l Cr% By Weight (dry weight basis) - 1.70

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample CSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.031</u>	<u>.031</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.044</u>	<u>.044</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.056</u>	<u>.056</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.080</u>	<u>.080</u>

X - Intercept = 1.27

Sample Concentration x Dilution Factor = Actual Concentration

1.27 mg/l 100 127 mg/l Cu

% By Weight (dry weight basis) - 2.54

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample CSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Zinc (Zn)

Standard Additions

Absorbance

20 mls Blank and 30 mls Sample	<u>.195</u>	<u>.194</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.245</u>	<u>.245</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.298</u>	<u>.298</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.390</u>	<u>.400</u>

X - Intercept = 1.87

Sample Concentration x Dilution Factor = Actual Concentration

1.87 mg/l 100 187 mg/l Zn% By Weight (dry weight basis) - 3.74

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample CSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.017</u>	<u>.017</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.026</u>	<u>.026</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.035</u>	<u>.035</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.051</u>	<u>.051</u>

X - Intercept = .90

Sample Concentration x Dilution Factor = Actual Concentration
.90 mg/l 100 90 mg/l Ni

% By Weight (dry weight basis) - 1.80

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample CSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Chromium (Cr)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.056</u>	<u>.056</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.066</u>	<u>.066</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.076</u>	<u>.076</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.096</u>	<u>.097</u>

X - Intercept = 2.80

Sample Concentration x Dilution Factor = Actual Concentration

2.80 mg/l 100 280 mg/l Cr

% By Weight (dry weight basis) - 5.60

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample DSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.021</u>	<u>.021</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.034</u>	<u>.034</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.047</u>	<u>.047</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.074</u>	<u>.076</u>

X - Intercept = .76

Sample Concentration x Dilution Factor = Actual Concentration

.76 mg/l 100 76 mg/l Cu

% By Weight (dry weight basis) - 1.52

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample DSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.017</u>	<u>.017</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.024</u>	<u>.024</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.032</u>	<u>.032</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.047</u>	<u>.048</u>

X - Intercept = 1.15

Sample Concentration x Dilution Factor = Actual Concentration
1.15 mg/l 100 115 mg/l Ni

% By Weight (dry weight basis) - 2.30

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample DSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Zinc (Zn)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.162</u>	<u>.159</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.217</u>	<u>.216</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.276</u>	<u>.274</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.380</u>	<u>.381</u>

X - Intercept = 1.40

Sample Concentration x Dilution Factor = Actual Concentration

1.40 mg/l 100 140 mg/l Zn

% By Weight (dry weight basis) - 2.80

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample DSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Chromium (Cr)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.057</u>	<u>.057</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.066</u>	<u>.064</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.077</u>	<u>.076</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.098</u>	<u>.097</u>

X - Intercept = 2.80

Sample Concentration x Dilution Factor = Actual Concentration
2.80 mg/l 100 280 mg/l Cr

% By Weight (dry weight basis) - 5.60

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ESample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.059</u>	<u>.058</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.073</u>	<u>.072</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.087</u>	<u>.086</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.115</u>	<u>.114</u>

X - Intercept = 2.12

Sample Concentration x Dilution Factor = Actual Concentration

2.12 mg/l 100 212 mg/l Cu% By Weight (dry weight basis) - 4.24

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ESample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.011</u>	<u>.010</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.020</u>	<u>.021</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.029</u>	<u>.032</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.047</u>	<u>.054</u>

X - Intercept = .55

Sample Concentration x Dilution Factor = Actual Concentration

.55 mg/l 100 55 mg/l Ni% By Weight (dry weight basis) - 1.10

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ESample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100
Element Analyzed Zinc (Zn)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.238</u>	<u>.239</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.303</u>	<u>.298</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.364</u>	<u>.363</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.469</u>	<u>.463</u>

X - Intercept = 1.89

Sample Concentration x Dilution Factor = Actual Concentration

1.89 mg/l 100 189 mg/l Zn

% By Weight (dry weight basis) - 3.78

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ESample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Chromium (Cr)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.034</u>	<u>.034</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.046</u>	<u>.046</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.061</u>	<u>.060</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.085</u>	<u>.084</u>

X - Intercept = 1.35

Sample Concentration x Dilution Factor = Actual Concentration

1.35 mg/l 100 135 mg/l Cr

% By Weight (dry weight basis) - 2.70

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample FSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.074</u>	<u>.074</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.088</u>	<u>.088</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.102</u>	<u>.102</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.130</u>	<u>.130</u>

X - Intercept = 2.52

Sample Concentration x Dilution Factor = Actual Concentration

2.52 mg/l 100 252 mg/l Cu

% By Weight (dry weight basis) - 5.04

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample FSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Zinc (Zn)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.345</u>	<u>.345</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.400</u>	<u>.400</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.456</u>	<u>.458</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.556</u>	<u>.556</u>

X - Intercept = 3.07

Sample Concentration x Dilution Factor = Actual Concentration
3.07 mg/l 100 307.0 mg/l Zn

% By Weight (dry weight basis) - 6.14

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample FSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.013</u>	<u>.013</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.019</u>	<u>.019</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.025</u>	<u>.025</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.037</u>	<u>.037</u>

X - Intercept = 1.04

Sample Concentration x Dilution Factor = Actual Concentration
1.04 mg/l 100 104.0 mg/l Ni

% By Weight (dry weight basis) - 2.08

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample FSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Chromium (Cr)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.024</u>	<u>.024</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.037</u>	<u>.037</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.051</u>	<u>.051</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.075</u>	<u>.075</u>

X - Intercept = .93

Sample Concentration x Dilution Factor = Actual Concentration

.93 mg/l 100 93 mg/l Cr

% By Weight (dry weight basis) - 1.86

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample GSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.039</u>	<u>.039</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.053</u>	<u>.052</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.065</u>	<u>.065</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.092</u>	<u>.091</u>

X - Intercept = 1.50

Sample Concentration x Dilution Factor = Actual Concentration

1.50 mg/l 100 150 mg/l Cu

% By Weight (dry weight basis) - 3.00

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample GSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Zinc (Zn)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.241</u>	<u>.238</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.298</u>	<u>.299</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.355</u>	<u>.352</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.452</u>	<u>.451</u>

X - Intercept = 2.00

Sample Concentration x Dilution Factor = Actual Concentration

2.00 mg/l 100 200 mg/l Zn

% By Weight (dry weight basis) - 4.00

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample G Sample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100 Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u> .010 </u>	<u> .010 </u>
20 mls 0.5 mg/l <u> Ni </u> and 30 mls Sample	<u> .019 </u>	<u> .019 </u>
20 mls 1.0 mg/l <u> Ni </u> and 30 mls Sample	<u> .028 </u>	<u> .029 </u>
20 mls 2.0 mg/l <u> Ni </u> and 30 mls Sample	<u> .046 </u>	<u> .047 </u>

X - Intercept = .55

Sample Concentration x Dilution Factor = Actual Concentration

 0.55 mg/l 100 55.0 mg/l Ni % By Weight (dry weight basis) - 1.10

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample G Sample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100 Element Analyzed Chromium Total

Standard Additions

Absorbance

20 mls Blank and 30 mls Sample	<u> .024 </u>	<u> .024 </u>
20 mls 0.5 mg/l <u> Cr </u> and 30 mls Sample	<u> .034 </u>	<u> .034 </u>
20 mls 1.0 mg/l <u> Cr </u> and 30 mls Sample	<u> .047 </u>	<u> .045 </u>
20 mls 2.0 mg/l <u> Cr </u> and 30 mls Sample	<u> .068 </u>	<u> .068 </u>

X - Intercept = 1.09

Sample Concentration x Dilution Factor = Actual Concentration

 1.09 mg/l 100 109 mg/l Cr % By Weight (dry weight basis) - 2.18

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample HSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.046</u>	<u>.046</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.060</u>	<u>.060</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.075</u>	<u>.075</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.106</u>	<u>.106</u>

X - Intercept = 1.55

Sample Concentration x Dilution Factor = Actual Concentration

1.55 mg/l 100 155.0 mg/l Cu
% By Weight (dry weight basis) - 3.10

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample HSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Zinc (Zn)

Standard Additions

Absorbance

20 mls Blank and 30 mls Sample	<u>.279</u>	<u>.279</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.333</u>	<u>.333</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.387</u>	<u>.387</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.485</u>	<u>.485</u>

X - Intercept = 2.58

Sample Concentration x Dilution Factor = Actual Concentration

2.58 mg/l 100 258.0 mg/l Zn% By Weight (dry weight basis) - 5.16

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample HSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.011</u>	<u>.011</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.019</u>	<u>.019</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.027</u>	<u>.027</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.043</u>	<u>.043</u>

X - Intercept = .68

Sample Concentration x Dilution Factor = Actual Concentration

0.68 mg/l 100 68.0 mg/l Ni
% By Weight (dry weight basis) - 1.36

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample HSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Chromium (Cr)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.024</u>	<u>.026</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.035</u>	<u>.035</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.045</u>	<u>.045</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.068</u>	<u>.068</u>

X - Intercept = 1.22

Sample Concentration x Dilution Factor = Actual Concentration

1.22 mg/l 100 122.0 mg/l Cr% By Weight (dry weight basis) - 2.44

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ISample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.029</u>	<u>.029</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.046</u>	<u>.046</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.062</u>	<u>.062</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.096</u>	<u>.098</u>

X - Intercept = .820

Sample Concentration x Dilution Factor = Actual Concentration

0.82 mg/l 100 82.0 mg/l Cu

% By Weight (dry weight basis) - 1.64

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ISample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Zinc (Zn)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.115</u>	<u>.116</u>
20 mls 0.5 mg/l <u>zn</u> and 30 mls Sample	<u>.182</u>	<u>.182</u>
20 mls 1.0 mg/l <u>zn</u> and 30 mls Sample	<u>.248</u>	<u>.251</u>
20 mls 2.0 mg/l <u>zn</u> and 30 mls Sample	<u>.381</u>	<u>.380</u>

X - Intercept = .85

Sample Concentration x Dilution Factor = Actual Concentration

0.85 mg/l 100 85.0 mg/l Zn% By Weight (dry weight basis) - 1.70

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ISample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.018</u>	<u>.017</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.027</u>	<u>.022</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.038</u>	<u>.035</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.054</u>	<u>.052</u>

X - Intercept = .940

Sample Concentration x Dilution Factor = Actual Concentration

0.94 mg/l 100 94.0 mg/l Ni% By Weight (dry weight basis) - 1.88

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample ISample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Chromium (Cr)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.018</u>	<u>.018</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.033</u>	<u>.033</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.047</u>	<u>.046</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.076</u>	<u>.075</u>

X - Intercept = .640

Sample Concentration x Dilution Factor = Actual Concentration

0.64 mg/l 100 64.0 mg/l Cr
% By Weight (dry weight basis) - 1.28

William J. Guerrera
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample JSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.049</u>	<u>.050</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.066</u>	<u>.066</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.082</u>	<u>.083</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.118</u>	<u>.119</u>

X - Intercept = 1.38

Sample Concentration x Dilution Factor = Actual Concentration

1.38 mg/l 100 138.0 mg/l Cu
% By Weight (dry weight basis) - 2.76

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample JSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Zinc (Zn)

Standard Additions

Absorbance

20 mls Blank and 30 mls Sample	<u>.170</u>	<u>.170</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.235</u>	<u>.235</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.299</u>	<u>.299</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.420</u>	<u>.420</u>

X - Intercept = 1.34

Sample Concentration x Dilution Factor = Actual Concentration

1.34 mg/l 100 134 mg/l Zn% By Weight (dry weight basis) - 2.68

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample JSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.026</u>	<u>.026</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.036</u>	<u>.035</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.046</u>	<u>.044</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.075</u>	<u>.076</u>

X - Intercept = 1.30

Sample Concentration x Dilution Factor = Actual Concentration

1.30 mg/l 100 130.0 mg/l Ni

% By Weight (dry weight basis) - 2.60

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample J Sample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100 Element Analyzed Chromium (Cr)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u> .015 </u>	<u> .015 </u>
20 mls 0.5 mg/l <u> Cr </u> and 30 mls Sample	<u> .029 </u>	<u> .029 </u>
20 mls 1.0 mg/l <u> Cr </u> and 30 mls Sample	<u> .044 </u>	<u> .043 </u>
20 mls 2.0 mg/l <u> Cr </u> and 30 mls Sample	<u> .075 </u>	<u> .076 </u>

X - Intercept = .670

Sample Concentration x Dilution Factor = Actual Concentration

 0.67 mg/l 100 67.0 mg/l Cr % By Weight (dry weight basis) - 1.34

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample KSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions

Absorbance

20 mls Blank and 30 mls Sample	<u>.011</u>	<u>.010</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.025</u>	<u>.026</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.039</u>	<u>.040</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.069</u>	<u>.070</u>

X - Intercept = .400

Sample Concentration x Dilution Factor = Actual Concentration

0.40 mg/l 100 40.0 mg/l Cu% By Weight (dry weight basis) - 0.80

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample KSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Zinc (Zn)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.160</u>	<u>.160</u>
20 mls 0.5 mg/l <u>zn</u> and 30 mls Sample	<u>.285</u>	<u>.285</u>
20 mls 1.0 mg/l <u>zn</u> and 30 mls Sample	<u>.410</u>	<u>.411</u>
20 mls 2.0 mg/l <u>zn</u> and 30 mls Sample	<u>.645</u>	<u>.646</u>

X - Intercept = .660

Sample Concentration x Dilution Factor = Actual Concentration

0.66 mg/l 100 66.0 mg/l Zn

% By Weight (dry weight basis) - 1.32

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample K Sample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100 Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u> .013 </u>	<u> .013 </u>
20 mls 0.5 mg/l <u> Ni </u> and 30 mls Sample	<u> .022 </u>	<u> .021 </u>
20 mls 1.0 mg/l <u> Ni </u> and 30 mls Sample	<u> .031 </u>	<u> .032 </u>
20 mls 2.0 mg/l <u> Ni </u> and 30 mls Sample	<u> .049 </u>	<u> .049 </u>

X - Intercept = .200

Sample Concentration x Dilution Factor = Actual Concentration

 0.200 mg/l 100 20.0 mg/l Ni % By Weight (dry weight basis) - 1.40

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample KSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Chromium (Cr)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.011</u>	<u>.011</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.019</u>	<u>.019</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.028</u>	<u>.029</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.046</u>	<u>.047</u>

X - Intercept = .480

Sample Concentration x Dilution Factor = Actual Concentration

0.48 mg/l 100 48.0 mg/l Cr% By Weight (dry weight basis) - 0.96

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample LSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.031</u>	<u>.030</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.046</u>	<u>.046</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.061</u>	<u>.061</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.091</u>	<u>.091</u>

X - Intercept = 1.00

Sample Concentration x Dilution Factor = Actual Concentration

1.00 mg/l 100 100.0 mg/l Cu% By Weight (dry weight basis) - 2.00

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample L Sample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100 Element Analyzed Zinc (Zn)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u> .130 </u>	<u> .130 </u>
20 mls 0.5 mg/l <u> Zn </u> and 30 mls Sample	<u> .198 </u>	<u> .197 </u>
20 mls 1.0 mg/l <u> Zn </u> and 30 mls Sample	<u> .264 </u>	<u> .260 </u>
20 mls 2.0 mg/l <u> Zn </u> and 30 mls Sample	<u> .370 </u>	<u> .368 </u>

X - Intercept = 1.00

Sample Concentration x Dilution Factor = Actual Concentration

 1.00 mg/l 100 100.0 mg/l Zn % By Weight (dry weight basis) - 2.00

William J. Guerrera
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample LSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.017</u>	<u>.018</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.027</u>	<u>.027</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.037</u>	<u>.037</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.055</u>	<u>.056</u>

X - Intercept = .840

Sample Concentration x Dilution Factor = Actual Concentration

0.84 mg/l 100 84.0 mg/l Ni% By Weight (dry weight basis) - 1.68

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample LSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Chromium (Cr)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.016</u>	<u>.018</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.034</u>	<u>.034</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.050</u>	<u>.050</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.082</u>	<u>.083</u>

X - Intercept = .530

Sample Concentration x Dilution Factor = Actual Concentration

0.53 mg/l 100 53.0 mg/l Cr

% By Weight (dry weight basis) - 1.06

William J. Guerrera
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample MSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Copper (Cu)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.043</u>	<u>.043</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.057</u>	<u>.056</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.072</u>	<u>.071</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.101</u>	<u>.100</u>

X - Intercept = 1.68

Sample Concentration x Dilution Factor = Actual Concentration

0.168 mg/l 100 168.0 mg/l Cu% By Weight (dry weight basis) - 3.36

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample MSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Zinc (Zn)

Standard Additions

Absorbance

20 mls Blank and 30 mls Sample	<u>.195</u>	<u>.195</u>
20 mls 0.5 mg/l <u>zn</u> and 30 mls Sample	<u>.252</u>	<u>.252</u>
20 mls 1.0 mg/l <u>zn</u> and 30 mls Sample	<u>.311</u>	<u>.309</u>
20 mls 2.0 mg/l <u>zn</u> and 30 mls Sample	<u>.410</u>	<u>.409</u>

X - Intercept = 2.00

Sample Concentration x Dilution Factor = Actual Concentration

2.00 mg/l 100 200.0 mg/l Zn
% By Weight (dry weight basis) - 4.00

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample MSample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100Element Analyzed Nickel (Ni)

Standard Additions	Absorbance	
20 mls Blank and 30 mls Sample	<u>.015</u>	<u>.016</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.025</u>	<u>.025</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.033</u>	<u>.034</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.049</u>	<u>.053</u>

X - Intercept = .82

Sample Concentration x Dilution Factor = Actual Concentration

0.82 mg/l 100 82.0 mg/l Ni% By Weight (dry weight basis) - 1.64

William J. Guerrera
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

Total Metals Analysis

E.P.A. I.D. #MID099124299

Sample M Sample Size 1.0000 gm

Acid digested and analyzed by the Method of Standard Additions
performed in duplicate.

Dilution Factor 100 Element Analyzed Chromium (Cr)

Standard Additions

Absorbance

20 mls Blank and 30 mls Sample	<u> .033 </u>	<u> .033 </u>
20 mls 0.5 mg/l <u> Cr </u> and 30 mls Sample	<u> .050 </u>	<u> .050 </u>
20 mls 1.0 mg/l <u> Cr </u> and 30 mls Sample	<u> .065 </u>	<u> .065 </u>
20 mls 2.0 mg/l <u> Cr </u> and 30 mls Sample	<u> .092 </u>	<u> .092 </u>

X - Intercept = 1.07

Sample Concentration x Dilution Factor = Actual Concentration

 1.07 mg/l 100 107.0 mg/l Cr % By Weight (dry weight basis) - 2.14

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample A

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None
Element Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.008</u>	<u>.008</u>	<u>.008</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.019</u>	<u>.019</u>	<u>.019</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.029</u>	<u>.029</u>	<u>.029</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.050</u>	<u>.050</u>	<u>.050</u>

X - Intercept = .38

Sample Concentration x Dilution Factor = Actual Concentration
0.38 mg/l - 0.38 mg/l Cu

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample A

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.019</u>	<u>.019</u>	<u>.019</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.025</u>	<u>.025</u>	<u>.025</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.031</u>	<u>.031</u>	<u>.031</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.043</u>	<u>.043</u>	<u>.043</u>

X - Intercept = 1.60

Sample Concentration x Dilution Factor = Actual Concentration

1.60 mg/l - 1.60 mg/l Ni

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample A

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.077</u>	<u>.078</u>	<u>.079</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.120</u>	<u>.120</u>	<u>.120</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.166</u>	<u>.166</u>	<u>.166</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.250</u>	<u>.250</u>	<u>.250</u>

X - Intercept = .85

Sample Concentration x Dilution Factor = Actual Concentration
0.85 mg/l - 0.85 mg/l Zn

William J. Guerrera
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample A

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.005</u>	<u>.005</u>	<u>.005</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.010</u>	<u>.010</u>	<u>.010</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.020</u>	<u>.020</u>	<u>.020</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Pb

N.D. - Not detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample A

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Chromium, Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.006</u>	<u>.006</u>	<u>.006</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.011</u>	<u>.011</u>	<u>.011</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.021</u>	<u>.021</u>	<u>.021</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Cr

N.D. - Not detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample A

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.033</u>	<u>.033</u>	<u>.033</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.060</u>	<u>.060</u>	<u>.060</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.120</u>	<u>.120</u>	<u>.120</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - < 0.02 mg/l Cd

N.D. - Not detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

JWS

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample B

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.015</u>	<u>.015</u>	<u>.015</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.025</u>	<u>.025</u>	<u>.025</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.037</u>	<u>.037</u>	<u>.037</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.058</u>	<u>.058</u>	<u>.058</u>

X - Intercept = .70

Sample Concentration x Dilution Factor = Actual Concentration

0.70 mg/l - 0.70 mg/l Cu

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample B

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.057</u>	<u>.057</u>	<u>.057</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.063</u>	<u>.063</u>	<u>.063</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.069</u>	<u>.069</u>	<u>.069</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.082</u>	<u>.082</u>	<u>.082</u>

X - Intercept = 4.5

Sample Concentration x Dilution Factor = Actual Concentration

4.50 mg/l - 4.50 mg/l Ni

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample B

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor 10
Element Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.080</u>	<u>.082</u>	<u>.085</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.121</u>	<u>.121</u>	<u>.125</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.160</u>	<u>.160</u>	<u>.163</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.230</u>	<u>.233</u>	<u>.236</u>

X - Intercept = .105

Sample Concentration x Dilution Factor = Actual Concentration
0.105 mg/l 10 10.5 mg/l Zn

William J. Guerrera
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample B

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Chromium, Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.006</u>	<u>.005</u>	<u>.005</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.011</u>	<u>.010</u>	<u>.011</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.021</u>	<u>.020</u>	<u>.021</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - < 0.05 mg/l Cr

N.D. - Not detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample B

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.004</u>	<u>.005</u>	<u>.004</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.010</u>	<u>.009</u>	<u>.009</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.018</u>	<u>.019</u>	<u>.019</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Pb

N.D. - Not detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample B

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.031</u>	<u>.032</u>	<u>.030</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.063</u>	<u>.062</u>	<u>.063</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.121</u>	<u>.120</u>	<u>.121</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.02 mg/l Cd

N.D. - Not detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample C

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.011</u>	<u>.011</u>	<u>.011</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.022</u>	<u>.022</u>	<u>.022</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.033</u>	<u>.033</u>	<u>.033</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.053</u>	<u>.054</u>	<u>.054</u>

X - Intercept = .50

Sample Concentration x Dilution Factor = Actual Concentration

0.50 mg/l - 0.50 mg/l Cu

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample C

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.038</u>	<u>.038</u>	<u>.038</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.045</u>	<u>.046</u>	<u>.045</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.052</u>	<u>.052</u>	<u>.052</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.065</u>	<u>.065</u>	<u>.065</u>

X - Intercept = 2.70

Sample Concentration x Dilution Factor = Actual Concentration

2.70 mg/l - 2.70 mg/l Ni

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample C

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.427</u>	<u>.423</u>	<u>.424</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.455</u>	<u>.452</u>	<u>.452</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.485</u>	<u>.485</u>	<u>.485</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.545</u>	<u>.546</u>	<u>.547</u>

X - Intercept = 7.10

Sample Concentration x Dilution Factor = Actual Concentration
7.10 mg/l - 7.10 mg/l Zn

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample C

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Chromium, Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.007</u>	<u>.007</u>	<u>.007</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.014</u>	<u>.014</u>	<u>.014</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.028</u>	<u>.028</u>	<u>.028</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Cr

N.D. - Not Detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample C

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None
Element Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.005</u>	<u>.005</u>	<u>.005</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.009</u>	<u>.009</u>	<u>.009</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.018</u>	<u>.018</u>	<u>.018</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration
N.D. mg/l - <0.05 mg/l Pb

N.D. - Not Detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample C

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None
Element Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.032</u>	<u>.032</u>	<u>.032</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.064</u>	<u>.064</u>	<u>.064</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.123</u>	<u>.123</u>	<u>.123</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration
N.D. mg/l - <0.02 mg/l Cd

N.D. - Not Detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample D

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None Element Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.008</u>	<u>.007</u>	<u>.008</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.018</u>	<u>.018</u>	<u>.018</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.028</u>	<u>.028</u>	<u>.028</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.049</u>	<u>.048</u>	<u>.048</u>

X - Intercept = .38

Sample Concentration x Dilution Factor = Actual Concentration
0.38 mg/l - 0.38 mg/l Cu

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample D

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None
Element Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.016</u>	<u>.016</u>	<u>.016</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.022</u>	<u>.022</u>	<u>.022</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.028</u>	<u>.028</u>	<u>.028</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.040</u>	<u>.040</u>	<u>.040</u>

X - Intercept = 1.33

Sample Concentration x Dilution Factor = Actual Concentration
1.33 mg/l - 1.33 mg/l Ni

William J. Guerrera
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample D

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.045</u>	<u>.095</u>	<u>.095</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.139</u>	<u>.138</u>	<u>.138</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.182</u>	<u>.182</u>	<u>.183</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.271</u>	<u>.269</u>	<u>.269</u>

X - Intercept = 1.05

Sample Concentration x Dilution Factor = Actual Concentration

1.05 mg/l - 1.05 mg/l Zn

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample D

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None Element Analyzed Chromium, Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.007</u>	<u>.007</u>	<u>.007</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.014</u>	<u>.014</u>	<u>.014</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.028</u>	<u>.028</u>	<u>.028</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Cr

N.D. - Not Detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample D

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.006</u>	<u>.006</u>	<u>.006</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.012</u>	<u>.012</u>	<u>.012</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.017</u>	<u>.017</u>	<u>.017</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - < 0.05 mg/l Pb

N.D. - Not Detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample D

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.031</u>	<u>.032</u>	<u>.031</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.064</u>	<u>.063</u>	<u>.063</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.117</u>	<u>.117</u>	<u>.117</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - < 0.02 mg/l Cd

N.D. - Not Detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample E

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.005</u>	<u>.005</u>	<u>.005</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.015</u>	<u>.015</u>	<u>.015</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.025</u>	<u>.025</u>	<u>.025</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.047</u>	<u>.049</u>	<u>.046</u>

X - Intercept = .23

Sample Concentration x Dilution Factor = Actual Concentration

0.23 mg/l - 0.23 mg/l Cu

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample E

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.019</u>	<u>.019</u>	<u>.019</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.025</u>	<u>.025</u>	<u>.025</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.032</u>	<u>.031</u>	<u>.031</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.045</u>	<u>.044</u>	<u>.045</u>

X - Intercept = 1.45

Sample Concentration x Dilution Factor = Actual Concentration

1.45 mg/l - 1.45 mg/l Ni

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample E

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None
Element Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.160</u>	<u>.163</u>	<u>.165</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.211</u>	<u>.213</u>	<u>.212</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.258</u>	<u>.257</u>	<u>.260</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.350</u>	<u>.346</u>	<u>.351</u>

X - Intercept = 1.71

Sample Concentration x Dilution Factor = Actual Concentration
1.71 mg/l - 1.71 mg/l Zn

William J. Guerrera
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample E

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Chromium , Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.007</u>	<u>.007</u>	<u>.007</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.014</u>	<u>.014</u>	<u>.014</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.028</u>	<u>.028</u>	<u>.028</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l <0.05 mg/l Cr

N.D. - Not Detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample E

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.004</u>	<u>.005</u>	<u>.005</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.009</u>	<u>.009</u>	<u>.008</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.018</u>	<u>.018</u>	<u>.018</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l <0.05 mg/l Pb

N.D. - Not Detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample E

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NONEElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.037</u>	<u>.037</u>	<u>.037</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.072</u>	<u>.072</u>	<u>.072</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.134</u>	<u>.134</u>	<u>.134</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration
N.D. mg/l - <0.02 mg/l Cd

N.D. - Not Detected, sample concentration was found to be lower
than the detection limit given.

William J. Guerrero
Stanley Laboratory

jzz

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample F

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.024</u>	<u>.024</u>	<u>.024</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.035</u>	<u>.035</u>	<u>.035</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.048</u>	<u>.046</u>	<u>.046</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.067</u>	<u>.068</u>	<u>.068</u>

X - Intercept = 1.05

Sample Concentration x Dilution Factor = Actual Concentration

1.05 mg/l - 1.05 mg/l Cu

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample F

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.125</u>	<u>.125</u>	<u>.125</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.133</u>	<u>.132</u>	<u>.134</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.140</u>	<u>.140</u>	<u>.140</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.155</u>	<u>.155</u>	<u>.156</u>

X - Intercept = 8.20

Sample Concentration x Dilution Factor = Actual Concentration
8.20 mg/l - 8.20 mg/l Ni

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample F

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor 10Element Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.172</u>	<u>.174</u>	<u>.173</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.222</u>	<u>.221</u>	<u>.223</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.268</u>	<u>.270</u>	<u>.270</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.356</u>	<u>.357</u>	<u>.356</u>

X - Intercept = 1.76

Sample Concentration x Dilution Factor = Actual Concentration

1.76 mg/l 10 17.6 mg/l Zn

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample F

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Chromium, Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.009</u>	<u>.008</u>	<u>.009</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.016</u>	<u>.015</u>	<u>.017</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.031</u>	<u>.030</u>	<u>.031</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Cr

N.D. - Not detected, sample concentration was found to be lower than the
detection limit given.

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample F

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor -Element Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.006</u>	<u>.006</u>	<u>.006</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.011</u>	<u>.012</u>	<u>.011</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.022</u>	<u>.022</u>	<u>.022</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Pb

N.D. - Not detected, sample concentration was found to be lower than the
detection limit given.

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample F

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.001</u>	<u>.00</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.030</u>	<u>.031</u>	<u>.032</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.060</u>	<u>.060</u>	<u>.062</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.112</u>	<u>.113</u>	<u>.114</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.02 mg/l Cd

N.D. - Not detected, sample concentration was found to be lower than the
detection limit given.

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample G

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.004</u>	<u>.004</u>	<u>.005</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.014</u>	<u>.015</u>	<u>.015</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.026</u>	<u>.027</u>	<u>.027</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.049</u>	<u>.049</u>	<u>.050</u>

X - Intercept = .200

Sample Concentration x Dilution Factor = Actual Concentration

0.20 mg/l - 0.20 mg/l Cu

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample G

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.011</u>	<u>.012</u>	<u>.012</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.021</u>	<u>.022</u>	<u>.022</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.031</u>	<u>.032</u>	<u>.031</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.049</u>	<u>.049</u>	<u>.049</u>

X - Intercept = .630

Sample Concentration x Dilution Factor = Actual Concentration

0.63 mg/l - 0.63 mg/l Ni

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample G

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.312</u>	<u>.313</u>	<u>.312</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.360</u>	<u>.360</u>	<u>.360</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.407</u>	<u>.408</u>	<u>.410</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.480</u>	<u>.479</u>	<u>.480</u>

X - Intercept = 3.25

Sample Concentration	x	Dilution Factor	=	Actual Concentration
<u>3.25</u> mg/l		<u>-</u>		<u>3.25</u> mg/l <u>Zn</u>

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample G

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Chromium, Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.008</u>	<u>.009</u>	<u>.008</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.016</u>	<u>.017</u>	<u>.016</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.032</u>	<u>.032</u>	<u>.032</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Cr

N.D. - Not detected, sample concentration was found to be lower than the
the detection limit given.

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample G

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.004</u>	<u>.005</u>	<u>.004</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.009</u>	<u>.009</u>	<u>.009</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.018</u>	<u>.018</u>	<u>.018</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Pb

N.D. - Not detected, sample concentration was found to be lower than
the detection limit given.

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample G

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.035</u>	<u>.034</u>	<u>.036</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.070</u>	<u>.070</u>	<u>.071</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.134</u>	<u>.133</u>	<u>.135</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.02 mg/l Cd

N.D. - Not detected, sample concentration was found to be lower than the
detection limit given.

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample H

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.005</u>	<u>.005</u>	<u>.005</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.017</u>	<u>.016</u>	<u>.017</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.029</u>	<u>.028</u>	<u>.028</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.052</u>	<u>.051</u>	<u>.052</u>

x - Intercept = .200

Sample Concentration x Dilution Factor = Actual Concentration

0.20 mg/l - 0.20 mg/l Cu

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample H

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.069</u>	<u>.068</u>	<u>.069</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.076</u>	<u>.075</u>	<u>.075</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.084</u>	<u>.083</u>	<u>.084</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.097</u>	<u>.096</u>	<u>.096</u>

X - Intercept = 4.87

Sample Concentration x Dilution Factor = Actual Concentration
4.87 mg/l - 4.87 mg/l Ni

William Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample H

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor 10Element Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.141</u>	<u>.142</u>	<u>.138</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.190</u>	<u>.191</u>	<u>.190</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.240</u>	<u>.235</u>	<u>.233</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.328</u>	<u>.322</u>	<u>.324</u>

X - Intercept = 1.45

Sample Concentration x Dilution Factor = Actual Concentration

1.45 mg/l 10 = 14.5 mg/l Zn

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample H

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Chromium Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.007</u>	<u>.007</u>	<u>.006</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.014</u>	<u>.015</u>	<u>.013</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.028</u>	<u>.028</u>	<u>.028</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Cr

N.D. - Not detected, sample concentration was found to be lower than
the detection limit given.

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample H

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.005</u>	<u>.006</u>	<u>.005</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.010</u>	<u>.010</u>	<u>.010</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.021</u>	<u>.020</u>	<u>.020</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Pb

N.D. - Not detected, sample concentration was found to be lower than
the detection limit given.

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample H

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.039</u>	<u>.039</u>	<u>.039</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.078</u>	<u>.077</u>	<u>.078</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.153</u>	<u>.154</u>	<u>.153</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.02 mg/l Cd

N.D. - Not detected, sample concentration was found to be lower than the
detection limit given.

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample I

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.008</u>	<u>.008</u>	<u>.008</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.020</u>	<u>.020</u>	<u>.020</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.032</u>	<u>.032</u>	<u>.032</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.057</u>	<u>.058</u>	<u>.056</u>

X - Intercept = .32

Sample Concentration x Dilution Factor = Actual Concentration
0.32 mg/l - 0.32 mg/l Cu

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample I

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.064</u>	<u>.064</u>	<u>.064</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.070</u>	<u>.069</u>	<u>.070</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.075</u>	<u>.073</u>	<u>.074</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.082</u>	<u>.082</u>	<u>.082</u>

X - Intercept = 6.25

Sample Concentration x Dilution Factor = Actual Concentration

6.25 mg/l - 6.25 mg/l Ni

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample I

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.063</u>	<u>.064</u>	<u>.064</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.108</u>	<u>.108</u>	<u>.108</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.154</u>	<u>.154</u>	<u>.154</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.239</u>	<u>.239</u>	<u>.240</u>

X - Intercept = .70

Sample Concentration x Dilution Factor = Actual Concentration

0.70 mg/l - 0.70 mg/l Zn

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample I

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Chromium, Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.003</u>	<u>.002</u>	<u>.002</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.010</u>	<u>.009</u>	<u>.010</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.017</u>	<u>.018</u>	<u>.017</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.031</u>	<u>.030</u>	<u>.030</u>

X - Intercept = .32

Sample Concentration x Dilution Factor = Actual Concentration

0.32 mg/l - 0.32 mg/l Cr

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample I

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.005</u>	<u>.004</u>	<u>.005</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.011</u>	<u>.009</u>	<u>.010</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.020</u>	<u>.020</u>	<u>.019</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Pb

N.D. - Not detected, sample concentration was found to be lower than
the detection limit given.

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample I

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.033</u>	<u>.033</u>	<u>.035</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.065</u>	<u>.066</u>	<u>.069</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.125</u>	<u>.125</u>	<u>.177</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.02 mg/l Cd

N.D. - Not detected, sample concentration was found to be lower than
the detection limit given.

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample J

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.009</u>	<u>.009</u>	<u>.009</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.021</u>	<u>.021</u>	<u>.021</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.034</u>	<u>.033</u>	<u>.033</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.057</u>	<u>.057</u>	<u>.057</u>

X - Intercept = .38

Sample Concentration x Dilution Factor = Actual Concentration
0.38 mg/l - 0.38 mg/l Cu

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample J

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor 10Element Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.014</u>	<u>.014</u>	<u>.014</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.022</u>	<u>.022</u>	<u>.022</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.029</u>	<u>.029</u>	<u>.029</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.044</u>	<u>.045</u>	<u>.044</u>

X - Intercept = .95

Sample Concentration x Dilution Factor = Actual Concentration
0.95 mg/l 10 9.50 mg/l Ni

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample J

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor 10Element Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.056</u>	<u>.056</u>	<u>.056</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.101</u>	<u>.101</u>	<u>.101</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.153</u>	<u>.155</u>	<u>.153</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.253</u>	<u>.252</u>	<u>.252</u>

X - Intercept = .55

Sample Concentration x Dilution Factor = Actual Concentration

0.55 mg/l 10 5.50 mg/l Zn

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample J

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor noneElement Analyzed Chromium Total, (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.011</u>	<u>.011</u>	<u>.010</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.018</u>	<u>.018</u>	<u>.018</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.032</u>	<u>.031</u>	<u>.032</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration
N.D. mg/l - <0.05 mg/l Cr

N.D. - Not detected, sample concentration was found to be less than
the detection limit given.

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample J

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor noneElement Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.005</u>	<u>.006</u>	<u>.005</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.011</u>	<u>.010</u>	<u>.011</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.021</u>	<u>.020</u>	<u>.020</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Pb

N.D. - Not detected, sample concentration was found to be less than
the detection limit given.

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample J

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor noneElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.031</u>	<u>.029</u>	<u>.030</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.060</u>	<u>.060</u>	<u>.060</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.107</u>	<u>.108</u>	<u>.106</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.02 mg/l Cd

N.D. - Not detected, sample concentration was found to be less than the
detection limit given.

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample K

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.006</u>	<u>.005</u>	<u>.005</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.017</u>	<u>.017</u>	<u>.017</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.030</u>	<u>.030</u>	<u>.030</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.055</u>	<u>.055</u>	<u>.055</u>

X - Intercept = .400

Sample Concentration x Dilution Factor = Actual Concentration
0.40 mg/l - 0.40 mg/l Cu

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample K

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None Element Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.030</u>	<u>.030</u>	<u>.030</u>
20 mls 0.5 mg/l <u> Ni </u> and 30 mls Sample	<u>.037</u>	<u>.038</u>	<u>.038</u>
20 mls 1.0 mg/l <u> Ni </u> and 30 mls Sample	<u>.045</u>	<u>.044</u>	<u>.045</u>
20 mls 2.0 mg/l <u> Ni </u> and 30 mls Sample	<u>.059</u>	<u>.059</u>	<u>.059</u>

X - Intercept = 1.95

Sample Concentration x Dilution Factor = Actual Concentration

 1.95 mg/l - = 1.95 mg/l Ni

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample K

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.093</u>	<u>.093</u>	<u>.093</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.100</u>	<u>.102</u>	<u>.100</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.200</u>	<u>.200</u>	<u>.199</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.397</u>	<u>.398</u>	<u>.398</u>

X - Intercept = .940

Sample Concentration x Dilution Factor = Actual Concentration

0.94 mg/l - 0.94 mg/l Zn

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample K

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None Element Analyzed Chromium, Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.010</u>	<u>.010</u>	<u>.010</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.029</u>	<u>.020</u>	<u>.039</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.040</u>	<u>.039</u>	<u>.039</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Cr

N.D. - Not given, sample concentration was found to be lower than the
detection limit given.

William J. Guerrera
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample K

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None Element Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.004</u>	<u>.005</u>	<u>.004</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.010</u>	<u>.011</u>	<u>.011</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.021</u>	<u>.020</u>	<u>.021</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Pb

N.D. - Not given, sample concentration was found to be lower than the
detection limit given.

William J. Guerrera
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample K

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.038</u>	<u>.036</u>	<u>.037</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.077</u>	<u>.079</u>	<u>.077</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.140</u>	<u>.151</u>	<u>.153</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.02 mg/l Cd

N.D. - Not detected, sample concentration was found to be lower than the
detection limit given.

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample L

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None Element Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.005</u>	<u>.005</u>	<u>.005</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.018</u>	<u>.018</u>	<u>.018</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.031</u>	<u>.030</u>	<u>.030</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.054</u>	<u>.055</u>	<u>.059</u>

X - Intercept = .200

Sample Concentration x Dilution Factor = Actual Concentration

0.20 mg/l 100 = 0.20 mg/l Cu

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample L

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor 10Element Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.011</u>	<u>.010</u>	<u>.011</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.026</u>	<u>.026</u>	<u>.028</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.044</u>	<u>.043</u>	<u>.043</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.075</u>	<u>.077</u>	<u>.074</u>

X - Intercept = .620

Sample Concentration x Dilution Factor = Actual Concentration
0.62 mg/l 10 = 6.20 mg/l Ni

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample L

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.214</u>	<u>.213</u>	<u>.213</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.260</u>	<u>.262</u>	<u>.257</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.305</u>	<u>.306</u>	<u>.308</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.405</u>	<u>.407</u>	<u>.405</u>

X - Intercept = 2.20

Sample Concentration x Dilution Factor = Actual Concentration

2.20 mg/l - 2.20 mg/l Zn

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample L

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Chromium, Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cr</u> and 30 mls Sample	<u>.012</u>	<u>.011</u>	<u>.012</u>
20 mls 1.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.023</u>	<u>.024</u>	<u>.023</u>
20 mls 2.0 mg/l <u>Cr</u> and 30 mls Sample	<u>.047</u>	<u>.048</u>	<u>.047</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Cr

N.D. - Not given, sample concentration was found to be lower than the
detection limit given.

William J. Guerrera
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample L

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.006</u>	<u>.006</u>	<u>.007</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.013</u>	<u>.012</u>	<u>.014</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.025</u>	<u>.025</u>	<u>.025</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Pb

N.D. - Not detected, sample concentration was found to be lower than
the detection limit given.

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample L

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.043</u>	<u>.042</u>	<u>.043</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.082</u>	<u>.083</u>	<u>.084</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.165</u>	<u>.166</u>	<u>.165</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.02 mg/l Cd

N.D. - Not detected, sample concentration was found to be lower than
the detection limit given.

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample M

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Copper (Cu)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.011</u>	<u>.011</u>	<u>.011</u>
20 mls 0.5 mg/l <u>Cu</u> and 30 mls Sample	<u>.025</u>	<u>.025</u>	<u>.025</u>
20 mls 1.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.040</u>	<u>.040</u>	<u>.040</u>
20 mls 2.0 mg/l <u>Cu</u> and 30 mls Sample	<u>.069</u>	<u>.069</u>	<u>.069</u>

X - Intercept = .370

Sample Concentration x Dilution Factor = Actual Concentration

0.37 mg/l - 0.37 mg/l Cu

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample M

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Nickel (Ni)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.019</u>	<u>.020</u>	<u>.020</u>
20 mls 0.5 mg/l <u>Ni</u> and 30 mls Sample	<u>.030</u>	<u>.029</u>	<u>.030</u>
20 mls 1.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.040</u>	<u>.040</u>	<u>.039</u>
20 mls 2.0 mg/l <u>Ni</u> and 30 mls Sample	<u>.057</u>	<u>.057</u>	<u>.055</u>

X - Intercept = 0.95

Sample Concentration x Dilution Factor = Actual Concentration
0.95 mg/l - 0.95 mg/l Ni

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample M

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Zinc (Zn)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.280</u>	<u>.279</u>	<u>.280</u>
20 mls 0.5 mg/l <u>Zn</u> and 30 mls Sample	<u>.335</u>	<u>.334</u>	<u>.333</u>
20 mls 1.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.387</u>	<u>.388</u>	<u>.386</u>
20 mls 2.0 mg/l <u>Zn</u> and 30 mls Sample	<u>.483</u>	<u>.480</u>	<u>.483</u>

X - Intercept = 2.65

Sample Concentration x Dilution Factor = Actual Concentration

2.65 mg/l - 2.65 mg/l Zn

William J. Guerrero
Stanley Laboratory

dlw

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample M

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Chromium, Total (Cr)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/1 <u>Cr</u> and 30 mls Sample	<u>.010</u>	<u>.010</u>	<u>.011</u>
20 mls 1.0 mg/1 <u>Cr</u> and 30 mls Sample	<u>.019</u>	<u>.019</u>	<u>.019</u>
20 mls 2.0 mg/1 <u>Cr</u> and 30 mls Sample	<u>.037</u>	<u>.037</u>	<u>.036</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/1 - <0.05 mg/1 Cr

N.D. - Not detected, sample concentration was found to be lower than
the detection limit given.

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample M

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor None Element Analyzed Lead (Pb)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Pb</u> and 30 mls Sample	<u>.006</u>	<u>.005</u>	<u>.007</u>
20 mls 1.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.013</u>	<u>.013</u>	<u>.012</u>
20 mls 2.0 mg/l <u>Pb</u> and 30 mls Sample	<u>.025</u>	<u>.026</u>	<u>.026</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.05 mg/l Pb

N.D. - Not detected, sample concentration was found to be less than the
detection limit given.

William J. Guerrero
Stanley Laboratory

Atomic Absorption Analysis

Stanley Tools - Fowlerville

E.P. Toxicity Extraction

E.P.A. I.D. #MID099124299

Sample M

Acid digested and analyzed by the Method of Standard Additions
performed in triplicate.

Dilution Factor NoneElement Analyzed Cadmium (Cd)

Standard Additions	Absorbance		
20 mls Blank and 30 mls Sample	<u>.000</u>	<u>.000</u>	<u>.000</u>
20 mls 0.5 mg/l <u>Cd</u> and 30 mls Sample	<u>.041</u>	<u>.041</u>	<u>.042</u>
20 mls 1.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.081</u>	<u>.082</u>	<u>.082</u>
20 mls 2.0 mg/l <u>Cd</u> and 30 mls Sample	<u>.156</u>	<u>.156</u>	<u>.156</u>

X - Intercept = .000

Sample Concentration x Dilution Factor = Actual Concentration

N.D. mg/l - <0.02 mg/l Cd

N.D. - Not detected, sample concentration was found to be lower than the
detection limit given.

William J. Guerrera
Stanley Laboratory

T H E S T A N L E Y W O R K S*Since 1843*

NEW BRITAIN, CONNECTICUT 06050

(203) 225-5111

November 23, 1983

Mr. William D. Ruckelshaus,
Administrator
U.S. Environmental Protection Agency
Washington, D. C. 20460

RE: Stanley Tools - Fowlerville
EPA ID #MID099124299

Dear Mr. Ruckelshaus:

The following petition for the delisting of electroplating wastewater treatment sludge, EPA Hazardous Waste Code Number F006, is being submitted to you by The Stanley Works Corporate Laboratory. The Stanley Works is the owner of the Stanley Tools facility located in Fowlerville, Michigan and herein identified as Stanley Tools-Fowlerville.

This is the second and final part of the petition. This part contains the cyanide analyses, and the determination of the oil and grease content of the sludge. Together both parts fulfill the requirements pursuant to Title 40 CFR Part 260.22.

Samples were taken of the underflow from the clarifier as it is being discharged to the surface impoundments for settling. As discussed with Mr. Myles Morse on August 31, 1983, these samples would be representative of our sludge generation in a worst case condition, since the sludge would not be allowed to further settle and age in the surface impoundments.

The samples collected on November 8, 9, 14 and 16, 1983 did not exhibit any significant levels of sulfide and no interference from sulfide was noted during the cyanide analyses. We can now conclude that the sulfide interference present in the samples taken from the surface impoundments on March 17, 1983 is the result of natural bacteriological attack of organic matter in the surface impoundments.

Page 2

Mr. William D. Ruckelshaus
Washington, D.C.

RE: Stanley Tools - Fowlerville
EPA ID #MID099124299

The Part II delisting petition certification will be signed by a Corporate Vice President. I gratefully request that any inquiries regarding this petition be referred to me.

Sincerely,

THE STANLEY WORKS

A handwritten signature in dark ink, appearing to read "William J. Guerrero". The signature is fluid and cursive, with a large loop at the end of the last name.

William J. Guerrero
Environmental Chemist
Stanley Laboratory
1309 Corbin Avenue
New Britain, CT 06053
(203) 225-5111 - Ext.5211

jzz

EPA ID #MID099124299

The following information listed below has been addressed in Part I of the petition submitted earlier. Part II of the petition will fulfill the requirements pursuant to Title 40 CFR Part 260.22:

Petitioner

Statement of Interest and Need

Proposed Action

Location of the Generating Facility

Description of Manufacturing Processes, Raw Materials Used and Assessment of Operations

General Description of Wastewater Treatment Operations

The Estimated Sludge Generation

Discussion of Factors Delineated in Criteria for Listing Hazardous Waste

1. Name and Address of the Laboratory performing the testing.

The Stanley Works
Corporate Laboratory
1309 Corbin Avenue
New Britain, CT 06053

2. Name of persons sampling and testing the waste.

- a) Sampling - Reza Rejaei, Stanley Tools, Fowlerville

The underflow from the clarifier was sampled every half hour during the time period when treated cyanide wastewater was being pumped to the clarifier from the cyanide treatment tanks. The samples were collected and composited in a plastic bucket and a one gallon sample of the composite was sent to the Corporate Laboratory arriving the day after it was collected for analysis.

- b) Testing - William J. Guerrero, The Stanley Works Laboratory

Mr. Guerrero performed the deionized water extractions and the oil and grease determinations on the samples. The deionized water extractions were started on the same day that the samples arrived at the Laboratory. The procedure used was identical to the procedure outlined in the E.P. Toxicity Extraction Procedure with the exception that no acid was added to the sample and the total volume of deionized water used was equivalent to twenty (20) times the weight of the sludge sample charged to the extractor. The determination of the oil and grease content of the sludge was also performed on the same day that the samples arrived at the Laboratory utilizing a Gravimetric, Separatory Funnel Freon Extraction.

EPA ID #MID099124299

Testing - Philip L. Talarico, The Stanley Works Laboratory

The wet chemical analyses were performed by Mr. Talarico. Total Cyanide, Amenable Cyanide and Leachable Cyanide were analyzed by the acid distillation method. Total and Amenable Cyanide determinations were performed on the same day that the samples arrived at the Laboratory. The Leachable Cyanide determinations were performed at the end of the twenty-four (24) hour extraction.

3. Sampling and Testing Data:

a) Sampling was performed on the following dates:

H-11/8/83,	11 AM- 3 PM	G-11/14/83,	8 AM-12 PM
K-11/9/83,	10 AM- 2 PM	L-11/16/83,	1 PM- 5 PM

b) Total, Amenable and Leachable Cyanide analyses were performed on the following dates:

11/9/83	11/15/83	11/18/83
11/10/83	11/16/83	
11/11/83	11/17/83	

c) Oil and grease determinations were made on the following dates:

11/9/83	11/15/83
11/10/83	11/17/83

EPA ID #MID099124299

4. Sampling Methodology:

As discussed in 2A Sampling, the underflow from the clarifier was sampled each half hour during the time period when treated cyanide wastewater was being pumped to the clarifier for pH adjustment and further precipitation of metals. The sampling was accomplished by opening the blowdown valve and collecting a sample from the underflow. Each sample collected during the discharge cycle was placed in a covered plastic bucket. At the end of the cycle, the samples in the bucket were mixed well and a one (1) gallon composite sample was poured off. The sample was delivered using an overnight delivery service and arrived at the Laboratory for analysis on the following day.

The flow from the rinse waters following process operations that contain cyanide are fairly steady. The cyanide bearing rinse waters are pumped to the cyanide retention tanks for treatment. These tanks, in which treatment is performed, also act as an equalization basin for the cyanide bearing discharges. At the present time, there are three (3) cyanide retention tanks, each tank holds approximately 32,000 gallons. When production is at its peak, approximately 80,000 gallons of cyanide wastewater is generated per week. The cyanide wastewater is pumped to an empty retention tank until the level reaches the full capacity marking. At that point, the cyanide wastewater is directed to another empty retention tank and treatment is started on the full tank. After the completion of the treatment cycle, the treated wastewater is slowly pumped to the clarifier. Approximately one-half the volume of the retention tank is bled into the clarifier over a 4 hour period. The treated wastewater that remains in the retention tank is then slowly bled into the clarifier on the following day. The procedure is then repeated on another retention tank that has reached full capacity.

Based upon the above described operation, the monitoring and sampling of the underflow from the clarifier during the time period when the treated wastewater is being bled into the clarifier would constitute a representative sampling of the cyanide discharges from the clarifier.

EPA ID #MID099124299

5. Sample Handling & Testing Methodology:

The samples were kept in sealed Nalgene bottles at all times. At the time of testing, each sample was well mixed with a paddle mixer, and a portion of the sample slurry was drawn off using Tygon tubing and a vacuum line. For the Cyanide analyses, the slurry was collected in pre-weighed 500 ml Nalgene bottles which were covered to prevent evaporation losses. A minimum of 100 grams of slurry was initially taken for each of the cyanide analyses.

The slurry samples were subjected to a Deionized Water E.P. Toxicity Extraction Procedure to determine the amount of leachable cyanide present. This procedure is similar to the E.P. Toxicity Extraction Procedure outlined in, "Test Methods for the Evaluation of Solid Waste, Physical/Chemical Methods", U.S. EPA Publication #SW-846, Second Edition, July 1982, Method 1310. The exception being that no acid is added to the sample, and twenty (20) times the sample weight of deionized water is added to the extractor at the start of the extraction. A Millipore Hazardous Waste Filtration Unit using a pre-weighed 142 mm, 0.45 micron filter pad and nitrogen as the pressurizing gas was incorporated to achieve the solid-liquid separation. The liquid portion of the samples was collected in glass 500 ml Erlenmyer flasks and were stoppered immediately after the liquid flow ceased and the pressurizing nitrogen gas evolved from the filter unit. Liquid fractions from the initial separation were preserved with sodium hydroxide to a pH of greater than 11.0, and were stored at 4°C for future usage. The remaining solid portion was evaluated for particle size. The solid sample along with the filter pad and the support screen were placed in a covered Petri dish and the solids were immediately weighed to the nearest 0.1 mg. After weighing, the solid samples were introduced into a suitable extractor along with twenty (20) times their weight of deionized water. The agitation was started and the initial pH of the solution was measured. The agitation was continued for a 24-hour period. At the end of the 24-hour period, the pH was measured and the agitation was stopped. The extracted solution was then introduced into the Hazardous Waste Filtration Unit and the solid and liquid portions were separated using a 142 mm, 0.45 micron filter pad and nitrogen gas for pressurization. The resultant filtrate was collected in a 1000 ml glass Erlenmyer flask and combined with the initial filtrate obtained from the initial solid-liquid separation. The combined solution was then analyzed for cyanide content in accordance with the procedures outlined in the, "Test Methods for the Evaluation of Solid Waste, Physical/Chemical Methods", U.S. EPA Publication #SW-846, Second Edition, July 1982, Method 9019.

Samples of the slurry were also collected and analyzed for both total and amenable cyanide in accordance with the test method referenced above.

EPA ID #MID099124299

Samples were also collected and evaluated for oil and grease content in accordance with the procedures outlined in the, "Methods for Chemical Analyses of Water and Waste", U.S. EPA Publication #EPA 600/4-79-020, March 1979, Method 413.1, STORET No. 00556. This method incorporates the use of Freon 113 as the extraction solvent in a separatory funnel extraction. The amount of Freon extractable matter is determined gravimetrically.

Approximately 1 liter from each of the well mixed slurry samples was drawn off for testing. The sample was placed in a beaker and the pH of the slurry was adjusted to pH 2.0 with hydrochloric acid. The pH adjusted sample was then transferred to a 2000 ml separatory funnel. The beaker was then thoroughly rinsed out with 30 mls of Freon 113, then the washings were transferred to the separatory funnel. The sample was extracted by shaking vigorously for 2 minutes. Then the layers were allowed to separate. While the layers were settling, a clean 250 ml boiling flask was weighed up. The settled solvent layer was then passed through a funnel with a solvent moistened Whatman #40 filter paper and collected in the tared 250 ml flask. The aqueous slurry sample in the separatory funnel was extracted twice more with additional portions of fresh solvent. All the Freon 113 extracts were collected in the same boiling flask. The tip of the separatory funnel, the filter paper, and then the funnel, were rinsed with 20 mls more of fresh solvent, the washings were collected in the boiling flask. The flask was gently heated in a water bath at 50°C until all the solvent was evaporated off. The flask was then quickly removed from the water bath and the outside of the flask was wiped to remove any moisture or fingerprints remaining on the flask. The flask was cooled in a desiccator for 1/2 hour and then reweighed. A blank sample utilizing the same volume of Freon 113 as required for the sample extraction was also tested in this manner. The amount of Freon 113 extractable matter was then calculated from the weights obtained and initial volume of slurry sample used.

6. Testing Results:

The results of cyanide analyses and the oil and grease determinations have been tabulated on the pages following. The cyanide and the oil and grease determination have both been reported in mg/l. Blank and standard reference samples were analyzed in both the cyanide analyses and the oil and grease determinations. The reagents used to prepare the reference standards were all of reagent grade purity. The cyanide was analyzed titrimetrically while the oil and grease determinations were made gravimetrically.

EPA ID #MID099124299


7. Names and Model Numbers of the Instruments Used:

- a) Mettler H31 Electronic Balance with Sensitivity to 0.1 mg.
- b) Orion Model 501 Digital pH Meter.
- c) Millipore Hazardous Waste Filtration Unit Catalog #YT30142HW.
- d) Millipore 0.45 Micron Membrane Filters, 142 mm Diameter, Catalog #HAWP14250.
- e) SGA Scientific, Cyanide Distillation Apparatus, Referenced in ASTM Test Method D2036, Catalog #JD-1360.

I certify under penalty of law that I have personally examined and am familiar with the information submitted in this demonstration and, that based on my inquiry of those individuals immediately responsible for obtaining the information, I believe that the submitted information is true, accurate and complete. I am aware that there are significant penalties for submitting false information, including the possibility of fine and imprisonment.

Sincerely,

THE STANLEY WORKS



Richard H. Ayers
Group Vice President

EPA I.D.# MID099124299

The analytical data presented on the following pages has been developed by The Stanley Works Corporate Laboratory. Included in the data is a summary sheet of all the analyses performed on the samples and individual data sheets detailing both sample and standard values obtained for Total Cyanide, Leachable Cyanide, and Cyanide Amenable to Chlorination. The results of the Freon Extractable Oil and Grease determinations are also included in the data.

Cyanide Analysis
Total Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample 1.00 mg/l Cyanide Standard

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO_3) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 500 mls

Distillate Sample Titrated 250 mls

Sample Titration mls AgNO_3 Used - 0.67 = A

Blank Titration mls AgNO_3 Used - 0.17 = B

Calculations:

Cyanide Concentration, mg/l = $\frac{A-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide Concentration, mg/l = $\frac{0.67 - 0.17}{500} \times 1000 \times \frac{250}{250}$

Total Cyanide Concentration = 1.00 mg/l CN

Percent Recovery - 100%

William J. Guerrera
Stanley Laboratory

Cyanide Analysis
Total Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample 273.0 mg/l Cyanide Standard

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO_3) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 25 mls

Distillate Sample Titrated 250 mls

Sample Titration mls AgNO_3 Used - 6.83 = A

Blank Titration mls AgNO_3 Used - 0.17 = B

Calculations:

Cyanide Concentration, mg/l = $\frac{A-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide Concentration, mg/l = $\frac{6.83 - 0.17}{25} \times 1000 \times \frac{250}{250}$

Total Cyanide Concentration = 266.4 mg/l CN

Percent Recovery - 97.6%

William J. Guerrero
Stanley Laboratory

Cyanide Analysis
Total Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample G

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO_3) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 100 mls

Distillate Sample Titrated 250 mls

Sample Titration mls AgNO_3 Used - 0.26 = A

Blank Titration mls AgNO_3 Used - 0.10 = B

Calculations:

Cyanide Concentration, mg/l = $\frac{A-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide Concentration, mg/l = $\frac{0.26 - 0.10}{100} \times 1000 \times \frac{250}{250}$

Total Cyanide Concentration = 1.60 mg/l CN

William J. Guerrero
Stanley Laboratory

Cyanide Analysis
Total Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample H

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO_3) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 100 mls

Distillate Sample Titrated 250 mls

Sample Titration mls AgNO_3 Used - 1.27 = A

Blank Titration mls AgNO_3 Used - 0.14 = B

Calculations:

Cyanide Concentration, mg/l = $\frac{A-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide Concentration, mg/l = $\frac{1.27 - 0.14}{100} \times 1000 \times \frac{250}{250}$

Total Cyanide Concentration = 11.3 mg/l CN

William J. Guerrero
Stanley Laboratory

Cyanide Analysis
Total Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample K

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO_3) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 100 mls

Distillate Sample Titrated 250 mls

Sample Titration mls AgNO_3 Used - 1.69 = A

Blank Titration mls AgNO_3 Used - 0.14 = B

Calculations:

Cyanide Concentration, mg/l = $\frac{A-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide Concentration, mg/l = $\frac{1.69 - 0.14}{100} \times 1000 \times \frac{250}{250}$

Total Cyanide Concentration = 15.5 mg/l CN

William J. Guerrero
Stanley Laboratory

Cyanide Analysis
Total Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample L

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO_3) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 200 mls

Distillate Sample Titrated 250 mls

Sample Titration mls AgNO_3 Used - 1.85 = A

Blank Titration mls AgNO_3 Used - 0.14 = B

Calculations:

Cyanide Concentration, mg/l = $\frac{\text{A-B}}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide Concentration, mg/l = $\frac{1.85 - 0.14}{200} \times 1000 \times \frac{250}{250}$

Total Cyanide Concentration = 8.55 mg/l CN

William J. Guerrero
Stanley Laboratory

Cyanide Analysis
Amenable Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample G

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO₃) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 100 mls

Distillate Sample Titrated 250 mls

Chlorinated Sample Titration mls AgNO₃ Used - 0.26 = C

Blank Titration mls AgNO₃ Used - 0.10 = B

Calculations:

Cyanide in Chlorinated Sample, mg/l = $\frac{C-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide in Chlorinated Sample, mg/l = $\frac{0.26 - 0.10}{100} \times 1000 \times \frac{250}{250}$

Chlorinated Sample = 1.60 mg/l CN

Amenable Cyanide = Total Cyanide - Chlorinated Cyanide

 0 mg/l 1.60 mg/l 1.60 mg/l

William J. Guerrero
Stanley Laboratory

Cyanide Analysis
Amenable Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample H

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO₃) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 100 mls

Distillate Sample Titrated 250 mls

Chlorinated Sample Titration mls AgNO₃ Used - 0.82 = C

Blank Titration mls AgNO₃ Used - 0.14 = B

Calculations:

Cyanide in Chlorinated Sample, mg/l = $\frac{C-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide in Chlorinated Sample, mg/l = $\frac{0.82 - 0.14}{100} \times 1000 \times \frac{250}{250}$

Chlorinated Sample = 6.8 mg/l CN

Amenable Cyanide = Total Cyanide - Chlorinated Cyanide

4.5 mg/l

11.3 mg/l

6.8 mg/l

William J. Guerrero
Stanley Laboratory

Cyanide Analysis
Amenable Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample K

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO₃) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 100 mls

Distillate Sample Titrated 250 mls

Chlorinated Sample Titration mls AgNO₃ Used - 1.32 = C

Blank Titration mls AgNO₃ Used - 0.14 = B

Calculations:

Cyanide in Chlorinated Sample, mg/l = $\frac{C-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide in Chlorinated Sample, mg/l = $\frac{1.32 - 0.14}{100} \times 1000 \times \frac{250}{250}$

Chlorinated Sample = 11.8 mg/l CN

Amenable Cyanide = Total Cyanide = Chlorinated Cyanide

 3.7 mg/l 15.5 mg/l 11.8 mg/l

William J. Guerrero
Stanley Laboratory

Cyanide Analysis
Amenable Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample L

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO₃) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 200 mls

Distillate Sample Titrated 250 mls

Chlorinated Sample Titration mls AgNO₃ Used - 0.50 = C

Blank Titration mls AgNO₃ Used - 0.14 = B

Calculations:

Cyanide in Chlorinated Sample, mg/l = $\frac{C-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide in Chlorinated Sample, mg/l = $\frac{0.50 - 0.14}{200} \times 1000 \times \frac{250}{250}$

Chlorinated Sample = 1.80 mg/l CN

Amenable Cyanide = Total Cyanide - Chlorinated Cyanide

 6.75 mg/l

 8.55 mg/l

 1.80 mg/l

William J. Guerrero
Stanley Laboratory

Cyanide Analysis
Leachable Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample G

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO_3) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 500 mls

Distillate Sample Titrated 250 mls

Sample Titration mls AgNO_3 Used - 0.30 = A

Blank Titration mls AgNO_3 Used - 0.10 = B

Calculations:

Cyanide Concentration, mg/l = $\frac{A-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide Concentration, mg/l = $\frac{0.30 - 0.10}{500} \times 1000 \times \frac{250}{250}$

Leachable Cyanide Concentration = 0.40 mg/l CN

William J. Guerrero
Stanley Laboratory

Cyanide Analysis
Leachable Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample H

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO_3) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 500 mls

Distillate Sample Titrated 250 mls

Sample Titration mls AgNO_3 Used - 0.27 = A

Blank Titration mls AgNO_3 Used - 0.17 = B

Calculations:

Cyanide Concentration, mg/l = $\frac{A-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide Concentration, mg/l = $\frac{0.27 - 0.17}{500} \times 1000 \times \frac{250}{250}$

Leachable Cyanide Concentration = 0.20 mg/l CN

William J. Guerrero
Stanley Laboratory

Cyanide Analysis
Leachable Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample K

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO₃) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 500 mls

Distillate Sample Titrated 250 mls

Sample Titration mls AgNO₃ Used - 0.29 = A

Blank Titration mls AgNO₃ Used - 0.17 = B

Calculations:

Cyanide Concentration, mg/l = $\frac{A-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide Concentration, mg/l = $\frac{0.29 - 0.17}{500} \times 1000 \times \frac{250}{250}$

Leachable Cyanide Concentration = 0.24 mg/l CN

William J. Guerrera
Stanley Laboratory

Cyanide Analysis
Leachable Cyanide

Stanley Tools - Fowlerville
EPA I.D. #MID099124299

Sample L

Acid Distillation Utilizing a Titrimetric End-Point Determination.

Titrant: Silver Nitrate , (AgNO₃) 0.0192N, 1 ml = 1 mg Cyanide (CN)

Original Sample Size 473.5 mls

Distillate Sample Titrated 250 mls

Sample Titration mls AgNO₃ Used - 0.23 = A

Blank Titration mls AgNO₃ Used - 0.16 = B

Calculations:

Cyanide Concentration, mg/l = $\frac{A-B}{\text{mls Original Sample}} \times 1000 \times \frac{250}{\text{mls Distillate Titrated}}$

Cyanide Concentration, mg/l = $\frac{0.23 - 0.16}{473.5} \times 1000 \times \frac{250}{250}$

Leachable Cyanide Concentration = 0.15 mg/l CN

William J. Guerrero
Stanley Laboratory

Oil and Grease Analysis
Freon 113 Solvent Residue

Stanley Tools - Fowlerville
EPA I.D.# MID099124299

Gravimetric, Separatory Funnel Freon 113 Extraction

Sample - Freon 113 Extraction Solvent

Volume of Sample Extracted - 1000 mls

Weight of Flask & Residue - 110.0731 gm

Weight of Flask - 110.0730 gm

Weight of Residue - 0.0001 gm

Weight of Residue For Blank - 0.1 mg

William J. Guerrera
Stanley Laboratory

Oil and Grease Analysis
Freon 113 Extraction

Stanley Tools - Fowlerville
EPA I.D.# MID099124299

Gravimetric, Separatory Funnel Freon 113 Extraction

Sample 410.0 mg/l Freon Extractable Oil Standard

Volume of Sample Used	-	500	mls
Volume of Acid Added	-	1.5	mls
Total Volume Extracted	-	501.5	mls

Weight of Flask and Residue	-	113.1467	gm
Weight of Flask	-	112.9437	gm
Weight of Sample Residue	-	0.2030	gm

Calculations:

Total Oil and Grease, mg/l = $\frac{\text{Weight of Sample Residue} - \text{Weight of Solvent Blank Residue}^*}{\text{Total Volume Extracted}}$

Total Oil and Grease = $\frac{203.0 \text{ mg} - 0.1 \text{ mg}}{0.5015 \text{ l}}$

Total Oil and Grease - 404.6 mg/l

Percent Recovery - 98.7%

* A solvent blank was analyzed to determine the residue from an equivalent volume of extraction solvent. When one liter of triple distilled Freon 113 was extracted, the residue was found to be 0.1 mg.

William J. Guerrero
Stanley Laboratory

Oil and Grease Analysis
Freon 113 Extraction

Stanley Tools - Fowlerville
EPA I.D.# MID099124299

Gravimetric, Separatory Funnel Freon 113 Extraction

Sample G

Volume of Sample Used	-	1000	mls
Volume of Acid Added	-	100	mls
Total Volume Extracted	-	1100	mls

Weight of Flask and Residue	-	110.1248	gm
Weight of Flask	-	110.0680	gm
Weight of Sample Residue	-	0.0568	gm

Calculations:

Total Oil and Grease, mg/l = $\frac{\text{Weight of Sample Residue} - \text{Weight of Solvent Blank Residue}^*}{\text{Total Volume Extracted}}$

Total Oil and Grease = $\frac{56.8 \text{ mg} - 0.1 \text{ mg}}{1.100 \text{ l}}$

Total Oil and Grease - 51.6 mg/l

* A solvent blank was analyzed to determine the residue from an equivalent volume of extraction solvent. When one liter of triple distilled Freon 113 was extracted, the residue was found to be 0.1 mg.

William J. Guerrera
Stanley Laboratory

Oil and Grease Analysis
Freon 113 Extraction

Stanley Tools - Fowlerville
EPA I.D.# MID099124299

Gravimetric, Separatory Funnel Freon 113 Extraction

Sample H

Volume of Sample Used	-	990	mls
Volume of Acid Added	-	68	mls
Total Volume Extracted	-	1058	mls
Weight of Flask and Residue	-	110.1382	gm
Weight of Flask	-	110.0943	gm
Weight of Sample Residue	-	0.0439	gm

Calculations:

Total Oil and Grease, mg/l = $\frac{\text{Weight of Sample Residue} - \text{Weight of Solvent Blank Residue}^*}{\text{Total Volume Extracted}}$

Total Oil and Grease = $\frac{43.9 \text{ mg} - 0.1 \text{ mg}}{1.058 \text{ l}}$

Total Oil and Grease - 41.4 mg/l

* A solvent blank was analyzed to determine the residue from an equivalent volume of extraction solvent. When one liter of triple distilled Freon 113 was extracted, the residue was found to be 0.1 mg.

William J. Guerrero
Stanley Laboratory

Oil and Grease Analysis
Freon 113 Extraction

Stanley Tools - Fowlerville
EPA I.D.# MID099124299

Gravimetric, Separatory Funnel Freon 113 Extraction

Sample K

Volume of Sample Used	-	1010	mls
Volume of Acid Added	-	95	mls
Total Volume Extracted	-	1105	mls
Weight of Flask and Residue	-	110.4540	gm
Weight of Flask	-	110.3946	gm
Weight of Sample Residue	-	0.0594	gm

Calculations:

Total Oil and Grease, mg/l = $\frac{\text{Weight of Sample Residue} - \text{Weight of Solvent Blank Residue}^*}{\text{Total Volume Extracted}}$

Total Oil and Grease = $\frac{59.4 \text{ mg} - 0.1 \text{ mg}}{1.105 \text{ l}}$

Total Oil and Grease - 53.7 mg/l

* A solvent blank was analyzed to determine the residue from an equivalent volume of extraction solvent. When one liter of triple distilled Freon 113 was extracted, the residue was found to be 0.1 mg.

William J. Guerrera
Stanley Laboratory

Oil and Grease Analysis
Freon 113 Extraction

Stanley Tools - Fowlerville
EPA I.D.# MID099124299

Gravimetric, Separatory Funnel Freon 113 Extraction

Sample L

Volume of Sample Used	-	1000	mls
Volume of Acid Added	-	100	mls
Total Volume Extracted	-	1100	mls

Weight of Flask and Residue	-	110.1260	gm
Weight of Flask	-	110.0720	gm
Weight of Sample Residue	-	0.0540	gm

Calculations:

Total Oil and Grease, mg/l = $\frac{\text{Weight of Sample Residue} - \text{Weight of Solvent Blank Residue}^*}{\text{Total Volume Extracted}}$

Total Oil and Grease = $\frac{54.0 \text{ mg} - 0.1 \text{ mg}}{1.100 \text{ l}}$

Total Oil and Grease - 49.0 mg/l

* A solvent blank was analyzed to determine the residue from an equivalent volume of extraction solvent. When one liter of triple distilled Freon 113 was extracted, the residue was found to be 0.1 mg.

William J. Guerrera
Stanley Laboratory

Analysis Data

Stanley Tools - Fowlerville

EPA I.D.# MID099124299

<u>SAMPLE</u>	<u>CYANIDE ANALYSES, mg/l</u>			<u>OIL AND GREASE, mg/l</u>
	<u>TOTAL</u>	<u>AMENABLE*</u>	<u>LEACHABLE</u>	<u>FREON 113 EXTRACTABLE</u>
G	1.60	0.00	0.40	51.6
H	11.3	4.50	0.20	41.4
K	15.5	3.70	0.24	53.7
L	8.55	6.75	0.15	49.0

* AMENABLE TO CHLORINATION

Sample H, 11/8/83, 11 a.m. - 3 p.m.

Sample K, 11/9/83, 10 a.m. - 2 p.m.

Sample G, 11/14/83, 8 a.m. - 12 p.m.

Sample L, 11/16/83, 1 p.m. - 5 p.m.

William J. Guerrera
Stanley Laboratory

T H E S T A N L E Y W O R K S*Since 1843*

NEW BRITAIN, CONNECTICUT 06050

(203) 225-5111

February 29, 1984

Ms. Barbara L. Bush
Office of Solid Waste (WH-562)
U. S. Environmental Protection Agency
Washington, D. C. 20460

Re: Delisting Petition #0533

Dear Ms. Bush:

Enclosed please find the additional information you have requested to complete the review of the Delisting Petition (#0533) submitted by The Stanley Works Corporate Laboratory for the Stanley Tools - Fowlerville facility. I have attached the Material Safety Data Sheets for the chemical compounds used in our finishing process that may enter the waste stream. You will note that I have not included the data sheets on the basic raw materials that make up the primary plating process solutions such as, sodium cyanide, caustic soda, copper metal anodes, nickel sulfate hexahydrate, nickel chloride hexahydrate, boric acid, nickel metal anodes, chromic acid, sulfuric acid, and insoluble lead metal anodes. Much information on the safety and toxicity of these materials can be readily obtained from a variety of reference materials.

The additional information you have asked for, will be answered in Paragraph form.

1. Past Disposal Practices:

The Stanley Works acquired the Stanley Tools - Fowlerville facility in January of 1980. The metal hydroxide sludge was accumulated in the surface impoundments until October 1980, when approximately 97,000 gallons of metal hydroxide sludge was pumped out of the surface impoundments by Chem-Met Services of Wyandotte, Michigan and transported to their facility for disposal. The remaining sludge was left to accumulate in the surface impoundments and became regulated as hazardous waste Code #F006 under RCRA on November 19, 1980.

Ms. Barbara L. Bush
Office of Solid Waste (WH-562)
U. S. Environmental Protection Agency
Washington, D. C. 20460

Re: Delisting Petition #0533

2. Current Disposal Practices:

Chem-Met Services, EPA ID# MID096963194, is still being contracted as the disposal firm for the F006 waste stored in the surface impoundments. Once yearly, the surface impoundments are pumped out. The F006 sludge is transported to Chem-Met's facility where the sludge slurry is dewatered and the resultant solid sludge is combined with other solid metal hydroxide sludge of the same hazardous waste code classification. The solid material is then transported to Wayne County #2 Landfill for disposal.

3. Proposed Disposal Practice:

In the event that the F006 waste is delisted, the sludge would be handled as a solid waste and would be sent to Chem-Met Services for dewatering. The solid sludge that remains after dewatering would be sent to an engineered landfill for proper disposal.

4. Tests for Characteristic Hazardous Waste:

Ignitability Characteristic; The F006 sludge would not exhibit the characteristic of ignitability because the material is an aqueous slurry with approximately 97% water and 3% solid metal hydroxide sludge which does not readily ignite nor support combustion. This material does not exhibit a Flash Point less than 140°F.

Corrosivity Characteristic; The F006 sludge does not exhibit the characteristic of corrosivity. When the pH of the sludge was measured, it was found to fall within the 9.03 to the 10.50 pH range which is within the non-corrosive pH range.

Ms. Barbara L. Bush
Office of Solid Waste (WH-562)
U. S. Environmental Protection Agency
Washington, D. C. 20460

Re: Delisting Petition #0533

Reactivity Characteristic; The F006 sludge does not exhibit the characteristic of reactivity. The sludge does not react violently with water and when exposed to mild acids or alkalies does not generate toxic gases or vapors. Analysis of the sludge indicates that the free cyanide level in the sludge is well below 10 mg/l limit.

5. Total Metal Analysis, Arsenic, Mercury & Selenium:

The total metals analysis for arsenic, mercury, and selenium has been provided in Part I of the Delisting Petition. This information is available on Pages 7 and 55 of Part I of the Petition.

6. Total Organic Carbon Analysis:

Attached, with this letter, are the results of the Total Organic Carbon analysis (TOC) performed upon sludge samples from both the clarifier blowdown and the surface impoundment system. As discussed with Mr. Morse in our phone conversation of January 27, 1984, five representative samples would have to be submitted for TOC analysis. One sample being a composite sample of the clarifier blowdown, and the remaining four being composite samples taken from each of the four surface impoundments. Due to extremely cold weather conditions, two of the surface impoundments have frozen over making composite sampling of those two surface impoundments virtually impossible. I advised Mr. Morse of this situation and he had suggested that we forego the composite sampling of those two impoundments and obtain grab samples from them.

Ms. Barbara L. Bush
Office of Solid Waste (WH-562)
U. S. Environmental Protection Agency
Washington, D. C. 20460

Re: Delisting Petition #0533

The sampling was performed on February 7, 1984. Composite samples were obtained from surface impoundments Numbers 3 and 4 and grab samples were taken from surface impoundments Numbers 1 and 2. A composite of the clarifier blowdown was obtained from grab samples taken during the blowdown periods.


You will also note that along with the TOC analysis, the samples were also tested to determine the presence of the metal Thallium. Though Thallium is not listed as an EP Toxic Metal, a review of the Material Safety Data Sheets has alerted us to the fact that one of the products in use, Isobrite 607 used in our cyanide copper plating solution as an additive, contains small amounts of Thallium Carbonate. Each sample was analyzed for Total Thallium based upon the dosage rate of Isobrite 607, (one-third gallon per day added to a 5000 gallon plating tank with a small dragout rate), we would estimate that the amount of Thallium that may enter the sludge would be extremely small.

I am also including a summary sheet with this letter, detailing the analyses performed and the results of those analyses.

I will once again remind both you and Mr. Morse that the Stanley Tools-Fowlerville facility has received a request from EPA Region V for the submission of their Part B Permit application. The submission date is targeted for July 15, 1984.

I hope this additional information will assist you in completing your review of the petition in a timely manner. Should any additional information regarding this petition be needed, please contact me as soon as possible.

Sincerely,



William J. Guerrero
Environmental Chemist
Stanley Laboratory
1309 Corbin Avenue
New Britain, CT 06053
(203) 225-5111 - Ext. 5211

Ms. Barbara Bush
RE: Delisting Petition #0533

Analysis Data:

Sample #	Type	TOC	mg/l	Thallium (Tl)
1000	Blowdown Composite	1,400		2.0*
1001	Lagoon #1, Grab	51		2.0*
1002	Lagoon #2, Grab	3,100		2.0*
1003	Lagoon #3, Composite	1,300		2.0*
1004	Lagoon #4, Composite	100		2.0*

* - Not detected, concentration found to be lower than the detection limit given.

The analytical data presented on this page has been developed by Baron Consulting Company. The Thallium analysis was performed on a Perkin-Elmer 503 Atomic Absorption Spectrophotometer. The Thallium values were quantified by the method of standard additions. The TOC analysis was performed in accordance with Method 415.1 described in EPA-600/4-79-020 STORET No. 00680.

BARON CONSULTING CO.

HARRY AGAHIGIAN, Ph.D., DIRECTOR

analytical services

P.O. BOX 663, ORANGE CT. 06477

March 12, 1984

To: Mr. W.J. Guerrera
Stanley Works
P.O. Box 1308
New Britain, Conn. 06050

From: Robert O. Blake, Jr.

Re: Elemental Analysis P.O. # C29583
BC# 39387

Sample	TOC	Tl
1000	1,400	ND/2.0
1001	51	"
1002	3,100	"
1003	1,300	"
1004	100	"


These Samples were digested and run by Atomic Absorption using a Perkin-Elmer 503. The values for Tl were based on values obtained using the method of standard addition.

Sample homogeneity maybe a problem.

All values are expressed in mg/l.

Please review the data and contact us if you wish more information.

ROB/dc


Robert O. Blake Jr.
Baron Consulting Co.

This report is submitted with the understanding that it is not to be reproduced for advertising or other purposes over our signature without express written permission from us. We do not accept any liability concerning the use of these results.

NOT RESPONSIBLE FOR SAMPLES LEFT OVER 30 DAYS AFTER RECEIPT OF REPORT.

MATERIAL SAFETY DATA SHEET

SECTION I

PRODUCT NAME OR NUMBER Isobrite 607		EMERGENCY TELEPHONE NO. Day — (313) 437-8161 Nite — (313) 644-5626	
MANUFACTURER'S NAME ALLIED-KELITE Products, Division of the Richardson Co.			
ADDRESS (Number, Street, City, State and Zip Code) 29111 Milford Rd., New Hudson, Michigan 48165			
CHEMICAL FAMILY Copper Cyanide Additive		FORMULA Proprietary	

SECTION II — HAZARDOUS INGREDIENTS

		%	TLV (Units)
Thallium Compounds		0.32	
Water Base			
Poisonous by ingestion			

SECTION III — PHYSICAL DATA

BOILING POINT (°F) (°C)	> 212°	SPECIFIC GRAVITY (H ₂ O=1)	1.01		
VAPOR PRESSURE (mm Hg)	N/A	PERCENT VOLATILE BY VOLUME (%)	N/A		
VAPOR DENSITY (AIR=1)	N/A	EVAPORATION RATE (=1)	N/A		
SOLUBILITY IN WATER Complete		pH=			
APPEARANCE AND ODOR Light yellow liquid - no odor					

SECTION IV — FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (method used) Water solution - None	FLAMMABLE LIMITS	LEL	UEL
EXTINGUISHING MEDIA Water or Foam			
SPECIAL FIRE FIGHTING PROCEDURES None			
UNUSUAL FIRE AND EXPLOSION HAZARDS None			

SECTION V – HEALTH HAZARD DATA

EFFECTS OF OVEREXPOSURE Chronic toxicity - ingestion - weakness	THRESHOLD LIMIT VALUE
and pain in extremities - loss of hair.	
EMERGENCY AND FIRST AID PROCEDURES Eye Contact: Immediately flush with water for 15 minutes – See a physician	
Skin Contact: Thoroughly wash with soap and water	

SECTION VI – REACTIVITY DATA

STABILITY	UNSTABLE STABLE	<input type="checkbox"/> <input checked="" type="checkbox"/>	CONDITIONS TO AVOID
INCOMPATIBILITY (materials to avoid) Acids			
HAZARDOUS DECOMPOSITION PRODUCTS: Catastrophic fire may emit toxic fumes of Thallium			
HAZARDOUS POLYMERIZATION	MAY OCCUR WILL NOT OCCUR	<input type="checkbox"/> <input checked="" type="checkbox"/>	CONDITIONS TO AVOID

SECTION VII – SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED Flush with water
WASTE DISPOSAL METHOD When used in copper cyanide plating baths, #607 will be co-ppt. with conventional treatments. However, if desired #607 by itself can be ppt. by small amounts of Potassium Iodide.

SECTION VIII – SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (specify type) Dust Mask _____			
VENTILATION	LOCAL EXHAUST (Specify Rate) <input checked="" type="checkbox"/> MECHANICAL (general) (Specify Rate) _____	SPECIAL	OTHER
PROTECTIVE GLOVES Rubber <input checked="" type="checkbox"/> Plastic _____	EYE PROTECTION Goggles _____ Face Shield <input checked="" type="checkbox"/>		
OTHER PROTECTIVE EQUIPMENT Rubber Apron <input checked="" type="checkbox"/> Rubber Boots <input checked="" type="checkbox"/>			

SECTION IX – SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING Protect from freezing _____ Isolate from reactive materials <input checked="" type="checkbox"/> Store away from direct heat <input checked="" type="checkbox"/>
Avoid skin or eye contact - wash thoroughly after handling.
OTHER PRECAUTIONS

SECTION X – TRANSPORTATION DATA

PROPER SHIPPING (Article) NAME Potassium Cyanide Solution		DOT CLASSIFICATION Poison
DOT LABEL Poison	DOT MARKING Poison	EMERGENCY ACCIDENT PRECAUTIONS AND PROCEDURES See Above
DOT PLACARD Poison	PRECAUTIONS TO BE TAKEN IN TRANSPORTATION See Above	

We believe the statements, technical information and recommendations contained herein are reliable, but are given without warranty or guarantee of any kind and we assume no responsibility for any loss, damage or expense, direct or consequential, arising out of their use.

ALLIED-KELITE PRODUCTS DIVISION



MATERIAL SAFETY DATA SHEET

PRODUCT Isobrite 607

N F P A	HAZARD RATING	 Fire Reactivity Toxicity Special
	4 - EXTREME	
	3 - HIGH	
	2 - MODERATE	
	1 - SLIGHT	
0 - INSIGNIFICANT		

SECTION I

WITCO MANUFACTURING DIVISION OR SUBSIDIARY

1 ADDRESS (NUMBER, STREET, CITY, STATE, ZIP CODE)

2

CHEMICAL NAME OR FAMILY

3 Cyanide Copper Plating Solution Additive

FORMULA

4 ProprietaryEMERGENCY TELEPHONE
MANUFACTURER

CHEM TREC 1-(800) 424-9300

SECTION II - CHEMICAL AND PHYSICAL PROPERTIES

CHEMICAL

PHYSICAL

HAZARDOUS DECOMPOSITION PRODUCTS

5 None

INCOMPATIBILITY (KEEP AWAY FROM)

6 None

LIST ALL TOXIC AND HAZARDOUS INGREDIENTS

7 Thallium Carbonate - CAS 6533-73-9

FORM

8 Liquid

ODOR

9 None

APPEARANCE

10 Clear

COLOR

11 Light yellow

SPECIFIC GRAVITY

12 (WATER = 1)

1.01

BOILING PT.

> 100 °C> 212 °F

MELTING PT.

°C

°F

14 NA

SOLUBILITY

IN WATER

AT 20 °CComplete

15 % VOLATILE

16 (BY WT %)

NA

EVAP. RATE

17 (= 1)

NA

VAPOR PRESSURE

18 (mm Hg at 20 °C)

NA

VAPOR DENSITY

19 (AIR = 1)

NA

pH AS IS

8.0

20 pH ()

STRONG ACID ☐STRONG BASE ☐STABLE ☒UNSTABLE ☐

VISCOSITY

SUS

AT 100 °F

< 100 ☐100 OR > ☐NDA

SECTION III - FIRE AND EXPLOSION DATA

SPECIAL FIRE FIGHTING PROCEDURES

24 None

FLASH POINT (METHOD USED)

Water Solution

26 °C °F

FLAMMABLE LIMITS %

None

27 LOWER UPPER

☐ DRYCHEMICAL ☒ CO₂☒ WATERSPRAY ☒ FOAM☐ WATERFOG ☐ SAND/EARTH

28 OTHER

UNUSUAL FIRE AND EXPLOSION HAZARDS

25 None

SECTION IV - HEALTH HAZARD DATA

PERMISSIBLE CONCENTRATIONS (AIR)

29 OSHA STANDARD - air: TWA 0.1 mg/m³ (as Thallium)

EFFECTS OF OVEREXPOSURE

30 Thallium Carbonate TXDS: oral-rat LDLO 23 mg/kg

TOXICOLOGICAL PROPERTIES

Acute - nausea, vomiting, diarrhrea, weakness, coma, death.31 Chronic - weakness and pain in extremities, loss of hair.

EMERGENCY FIRST AID PROCEDURES

32 EYES Immediately flush with large amounts of water for 15 minutes. Call a physician.33 SKIN CONTACT Flush with large amounts of water for 15 minutes34 INHALATION Remove to fresh air.35 IF SWALLOWED Call a physician.

NA = NOT APPLICABLE

NDA = NO DATA AVAILABLE

<= LESS THAN

>= MORE THAN

Witco MATERIAL SAFETY DATA SHEET

PRODUCT Isobrite 607

SECTION V — SPECIAL PROTECTION INFORMATION

VENTILATION TYPE REQUIRED (LOCAL, MECHANICAL, SPECIAL)	PROTECTIVE GLOVES
Local to maintain below the OSHA standard for Thallium.	38 Rubber
36	EYE PROTECTION
RESPIRATORY PROTECTION (SPECIFY TYPE)	39 Goggles, face shield
None	OTHER PROTECTIVE EQUIPMENT
37	Rubber apron
	40 Rubber gloves

SECTION VI — HANDLING OF SPILLS OR LEAKS

PROCEDURES FOR CLEAN-UP
Wear protective clothing and equipment during clean-up. Absorb with an inert material such as sand, earth or vermiculite; sweep up and dispose of in accordance with federal, state and local regulations.
41
WASTE DISPOSAL
By methods consistent with federal, state, and local regulations.
42

SECTION VII — SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORAGE
Wear protective clothing and equipment while handling. Wash thoroughly after handling.
43

SECTION VIII — TRANSPORTATION DATA

UNREGULATED BY D.O.T. <input type="checkbox"/>	U.S. D.O.T. PROPER SHIPPING NAME	
44	47 Poison Liquid NOS (Thallium Carbonate)	
REGULATED BY D.O.T. <input checked="" type="checkbox"/>	U.S. D.O.T. HAZARD CLASS	I.D. NUMBER
45	48 Poison B	49 UN-2810
TRANSPORTATION EMERGENCY INFORMATION	RQ	LABEL(S) REQUIRED
	50 NA	51 Poison
	FREIGHT CLASSIFICATION	
	52 70	
CHEM TREC	SPECIAL TRANSPORTATION NOTES	
1-(800) 424-9300	53 NA	
46		

SECTION IX — COMMENTS

Do not swallow. Avoid contact with clothing. Wash thoroughly after handling. Wash clothing before reuse. Keep from feed and food products. Keep out of reach of children. Keep container tightly closed when not in use.
54

SIGNATURE <u>C.V. Wilkie</u>	C.V. Wilkie	TITLE <u>Sr. Dev. Chem.</u>
REVISION DATE <u>11-29-83</u>	SENT TO	ATTN:
SUPERSEDES		DATE

We believe the statements, technical information and recommendations contained herein are reliable, but they are given without warranty or guarantee of any kind, express or implied, and we assume no responsibility for any loss, damage, or expense, direct or consequential, arising out of their use.

MATERIAL SAFETY DATA SHEET

SECTION I

PRODUCT NAME OR NUMBER Isobrite #622		EMERGENCY TELEPHONE NO. Day - (313) 437-8161 Nite - (313) 644-5626	
MANUFACTURER'S NAME ALLIED-KELITE Products, Division of the Richardson Co.			
ADDRESS (Number, Street, City, State and Zip Code) 29111 Milford Rd., New Hudson, Michigan 48165			
CHEMICAL FAMILY Cyanide Copper Brightener		FORMULA Proprietary	

SECTION II - HAZARDOUS INGREDIENTS

		%	TLV (Units)
Selenium Compounds	<	0.1	
Cyanide Compounds	<	0.1	
Water Base			
Selenium and cyanide are both considered highly toxic.			

SECTION III - PHYSICAL DATA

BOILING POINT (°F) (°C)	212°	SPECIFIC GRAVITY (H ₂ O=1)	1.001		
VAPOR PRESSURE (mm Hg)	N/A	PERCENT VOLATILE BY VOLUME (%)	N/A		
VAPOR DENSITY (AIR=1)	N/A	EVAPORATION RATE (=1)	N/A		
SOLUBILITY IN WATER Complete		pH=			
APPEARANCE AND ODOR Clear white - no odor					

SECTION IV - FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (method used) Water solution	FLAMMABLE LIMITS	LEL	UEL
EXTINGUISHING MEDIA Water or Foam			
SPECIAL FIRE FIGHTING PROCEDURES None			
UNUSUAL FIRE AND EXPLOSION HAZARDS None			

SECTION V – HEALTH HAZARD DATA

EFFECTS OF OVEREXPOSURE Swelling of feet, vomiting, nephritis and gastro-intestinal disorders.	THRESHOLD LIMIT VALUE
EMERGENCY AND FIRST AID PROCEDURES Eye Contact: Immediately flush with water for 15 minutes – See a physician Skin Contact: Thoroughly wash with soap and water	

SECTION VI – REACTIVITY DATA

STABILITY	UNSTABLE STABLE	<input type="checkbox"/> <input checked="" type="checkbox"/>	CONDITIONS TO AVOID
INCOMPATIBILITY (materials to avoid) Strong acids or oxidants			
HAZARDOUS DECOMPOSITION PRODUCTS: Hydrogen Cyanide and Selenium in catastrophic fire.			
HAZARDOUS POLYMERIZATION	MAY OCCUR WILL NOT OCCUR	<input type="checkbox"/> <input checked="" type="checkbox"/>	CONDITIONS TO AVOID

SECTION VII – SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED Wash and flush with large quantities of water.
WASTE DISPOSAL METHOD As for sodium cyanide and selenium - if required.

SECTION VIII – SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (specify type) Dust Mask _____ None			
VENTILATION	LOCAL EXHAUST (Specify Rate) <input checked="" type="checkbox"/> MECHANICAL (general) (Specify Rate)	SPECIAL OTHER	
PROTECTIVE GLOVES Rubber <input checked="" type="checkbox"/> Plastic _____	EYE PROTECTION Goggles _____ Face Shield <input checked="" type="checkbox"/>		
OTHER PROTECTIVE EQUIPMENT Rubber Apron <input checked="" type="checkbox"/> Rubber Boots _____ Periodic disposal of gloves if contaminated.			

SECTION IX – SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING Protect from freezing _____ Isolate from reactive materials <input checked="" type="checkbox"/> Store away from direct heat <input checked="" type="checkbox"/>
None, except do not heat to evaporate.
OTHER PRECAUTIONS

SECTION X – TRANSPORTATION DATA

PROPER SHIPPING (Article) NAME Potassium Cyanide Solution		DOT CLASSIFICATION Poison
DOT LABEL Poison	DOT MARKING Poison	EMERGENCY ACCIDENT PRECAUTIONS AND PROCEDURES See Above
DOT PLACARD Poison	PRECAUTIONS TO BE TAKEN IN TRANSPORTATION See Above	

We believe the statements, technical information and recommendations contained herein are reliable, but are given without warranty or guarantee of any kind and we assume no responsibility for any loss, damage or expense, direct or consequential, arising out of their use.

ALLIED-KELITE PRODUCTS DIVISION

MATERIAL SAFETY DATA SHEET

SECTION I

PRODUCT NAME OR NUMBER Isobrite 630		EMERGENCY TELEPHONE NO. Day - (313) 437-8161 Nite - (313) 644-5626	
MANUFACTURER'S NAME ALLIED-KELITE Products, Division of the Richardson Co.			
ADDRESS (Number, Street, City, State and Zip Code) 29111 Milford Rd., New Hudson, Michigan 48165			
CHEMICAL FAMILY Complexing Agents		FORMULA Proprietary	

SECTION II - HAZARDOUS INGREDIENTS

		%	TLV (Units)
Rochelle Salts and Similar Chelants	Approx.	60	
EDTA Tetrasodium Salt	Approx.	2	
Water		Bal.	

SECTION III - PHYSICAL DATA

BOILING POINT (°F) (°C)	> 212°	SPECIFIC GRAVITY (H ₂ O=1)	1.28		
VAPOR PRESSURE (mm Hg)	N/A	PERCENT VOLATILE BY VOLUME (%)	N/A		
VAPOR DENSITY (AIR=1)	N/A	EVAPORATION RATE (=1)	N/A		
SOLUBILITY IN WATER Complete		pH=	12		
APPEARANCE AND ODOR Brown, dark colored solutions - slight ammonical odor					

SECTION IV - FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (method used) Non-flammable	FLAMMABLE LIMITS	LEL	UEL
EXTINGUISHING MEDIA Water or Foam			
SPECIAL FIRE FIGHTING PROCEDURES None			
UNUSUAL FIRE AND EXPLOSION HAZARDS None			

SECTION V – HEALTH HAZARD DATA

EFFECTS OF OVEREXPOSURE Can be irritant to skin or eyes.	THRESHOLD LIMIT VALUE
EMERGENCY AND FIRST AID PROCEDURES Eye Contact: Immediately flush with water for 15 minutes – See a physician	
Skin Contact: Thoroughly wash with soap and water	

SECTION VI – REACTIVITY DATA

STABILITY	UNSTABLE STABLE	<input type="checkbox"/> <input checked="" type="checkbox"/>	CONDITIONS TO AVOID
INCOMPATIBILITY (materials to avoid) Strong oxidizing agents (i.e. chromic acid)			
HAZARDOUS DECOMPOSITION PRODUCTS: None			
HAZARDOUS POLYMERIZATION	MAY OCCUR WILL NOT OCCUR	<input type="checkbox"/> <input checked="" type="checkbox"/>	CONDITIONS TO AVOID

SECTION VII – SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED Flush with water
WASTE DISPOSAL METHOD No special problems

SECTION VIII – SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (specify type) Dust Mask _____ Non-volatile			
VENTILATION	LOCAL EXHAUST (Specify Rate) MECHANICAL (general) (Specify Rate)	SPECIAL	OTHER
PROTECTIVE GLOVES Rubber <input checked="" type="checkbox"/> Plastic _____	EYE PROTECTION Goggles _____ Face Shield <input checked="" type="checkbox"/>		
OTHER PROTECTIVE EQUIPMENT Rubber Apron <input checked="" type="checkbox"/> Rubber Boots <input checked="" type="checkbox"/>			

SECTION IX – SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING Protect from freezing _____ Isolate from reactive materials _____ Store away from direct heat <input checked="" type="checkbox"/>	
Avoid skin or eye contact	
OTHER PRECAUTIONS	

SECTION X – TRANSPORTATION DATA

PROPER SHIPPING (Article) NAME Compound Cleaning Liquid		DOT CLASSIFICATION Non-Hazardous
DOT LABEL N/R	DOT MARKING	EMERGENCY ACCIDENT PRECAUTIONS AND PROCEDURES
DOT PLACARD N/R	PRECAUTIONS TO BE TAKEN IN TRANSPORTATION	

We believe the statements, technical information and recommendations contained herein are reliable, but are given without warranty or guarantee of any kind and we assume no responsibility for any loss, damage or expense, direct or consequential, arising out of their use.

ALLIED-KELITE PRODUCTS DIVISION

MATERIAL SAFETY DATA SHEET

SECTION I

PRODUCT NAME OR NUMBER Isobrite 631		EMERGENCY TELEPHONE NO. Day — (313) 437-8161 Nite — (313) 644-5626	
MANUFACTURER'S NAME ALLIED-KELITE Products, Division of the Richardson Co.			
ADDRESS (Number, Street, City, State and Zip Code) 29111 Milford Rd., New Hudson, Michigan 48165			
CHEMICAL FAMILY Complexing & mild reducing agents		FORMULA Proprietary	

SECTION II — HAZARDOUS INGREDIENTS

		%	TLV (Units)
Aldohexos	Approx.	60	
EDTA Tetrasodium Salt	Approx.	2	
Water		Bal.	

SECTION III — PHYSICAL DATA

BOILING POINT (°F) (°C) > 212°	SPECIFIC GRAVITY (H ₂ O=1) 1.12		
VAPOR PRESSURE (mm Hg) N/A	PERCENT VOLATILE BY VOLUME (%) N/A		
VAPOR DENSITY (AIR=1) N/A	EVAPORATION RATE (=1) N/A		
SOLUBILITY IN WATER Complete	pH= 11		
APPEARANCE AND ODOR Clear Straw color - no odor			

SECTION IV — FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (method used) Water solution	FLAMMABLE LIMITS	LEL	UEL
EXTINGUISHING MEDIA Water or Foam			
SPECIAL FIRE FIGHTING PROCEDURES None			
UNUSUAL FIRE AND EXPLOSION HAZARDS None			

SECTION V – HEALTH HAZARD DATA

EFFECTS OF OVEREXPOSURE Could be a skin and eye irritant.	THRESHOLD LIMIT VALUE Unknown
EMERGENCY AND FIRST AID PROCEDURES Eye Contact: Immediately flush with water for 15 minutes – See a physician Skin Contact: Thoroughly wash with soap and water	

SECTION VI – REACTIVITY DATA

STABILITY	UNSTABLE STABLE	<input type="checkbox"/> <input checked="" type="checkbox"/>	CONDITIONS TO AVOID
INCOMPATIBILITY (materials to avoid) Strong oxidants			
HAZARDOUS DECOMPOSITION PRODUCTS: None			
HAZARDOUS POLYMERIZATION	MAY OCCUR WILL NOT OCCUR	<input type="checkbox"/> <input checked="" type="checkbox"/>	CONDITIONS TO AVOID

SECTION VII – SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED Flush with water
WASTE DISPOSAL METHOD Neutralize and dispose

SECTION VIII – SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (specify type) Dust Mask _____ None			
VENTILATION	LOCAL EXHAUST (Specify Rate) <input checked="" type="checkbox"/> MECHANICAL (general) (Specify Rate)	SPECIAL	OTHER
PROTECTIVE GLOVES Rubber <input checked="" type="checkbox"/> Plastic _____	EYE PROTECTION Goggles _____ Face Shield <input checked="" type="checkbox"/>		
OTHER PROTECTIVE EQUIPMENT Rubber Apron <input checked="" type="checkbox"/> Rubber Boots <input checked="" type="checkbox"/>			

SECTION IX – SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING Protect from freezing _____ Isolate from reactive materials _____ Store away from direct heat <input checked="" type="checkbox"/>
Avoid skin and eye contact
OTHER PRECAUTIONS

SECTION X – TRANSPORTATION DATA

PROPER SHIPPING (Article) NAME Compound Cleaning Liquid		DOT CLASSIFICATION Non-Hazardous
DOT LABEL N/R	DOT MARKING	EMERGENCY ACCIDENT PRECAUTIONS AND PROCEDURES
DOT PLACARD N/R	PRECAUTIONS TO BE TAKEN IN TRANSPORTATION	

We believe the statements, technical information and recommendations contained herein are reliable, but are given without warranty or guarantee of any kind and we assume no responsibility for any loss, damage or expense, direct or consequential, arising out of their use.

ALLIED-KELITE PRODUCTS DIVISION

U.S. DEPARTMENT OF LABOR
Occupational Safety and Health Administration

Form Approved
OMB No. 44-R1387

MATERIAL SAFETY DATA SHEET

Required under USDL Safety and Health Regulations for Ship Repairing,
Shipbuilding, and Shipbreaking (29 CFR 1915, 1916, 1917)

SECTION I

MANUFACTURER'S NAME OMI International Corporation - Udylite		EMERGENCY TELEPHONE NO. (313) 497-9129
ADDRESS (Number, Street, City, State, and ZIP Code) 21441 Hoover Road, Warren, Michigan 48089		
CHEMICAL NAME AND SYNONYMS Udylite Nickel Brightener 3J		TRADE NAME AND SYNONYMS Same
CHEMICAL FAMILY See below	FORMULA Proprietary	

SECTION II - HAZARDOUS INGREDIENTS

PAINTS, PRESERVATIVES, & SOLVENTS	%	TLV (Units)	ALLOYS AND METALLIC COATINGS	%	TLV (Units)
PIGMENTS	No	No	BASE METAL	No	No
CATALYST			ALLOYS		
VEHICLE			METALLIC COATINGS		
SOLVENTS			FILLER METAL PLUS COATING OR CORE FLUX		
ADDITIVES			OTHERS		
OTHERS					

HAZARDOUS MIXTURES OF OTHER LIQUIDS, SOLIDS, OR GASES	%	TLV (Units)
A dry mixture containing Boric Acid and an aromatic	-	NA
sulfo-oxygen compound	-	NA

SECTION III - PHYSICAL DATA

BOILING POINT (°F.)	Unknown	SPECIFIC GRAVITY (H ₂ O=1)	
VAPOR PRESSURE (mm Hg.)	NA	PERCENT VOLATILE BY VOLUME (%)	NA
VAPOR DENSITY (AIR=1)	NA	EVAPORATION RATE (_____ =1)	NA
SOLUBILITY IN WATER	Slight		
APPEARANCE AND ODOR	White Powder		

SECTION IV - FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (Method used)	None	FLAMMABLE LIMITS	<input checked="" type="checkbox"/>	Lel	Uel
EXTINGUISHING MEDIA	No special requirements				
SPECIAL FIRE FIGHTING PROCEDURES	None known				
UNUSUAL FIRE AND EXPLOSION HAZARDS	None known				

SECTION V - HEALTH HAZARD DATA

THRESHOLD LIMIT VALUE

None known or established

EFFECTS OF OVEREXPOSURE

Irritant to skin, eyes, and respiratory system

EMERGENCY AND FIRST AID PROCEDURES

Flush skin and eyes with clean, cool water

SECTION VI - REACTIVITY DATA

STABILITY

UNSTABLE

CONDITIONS TO AVOID

STABLE

X

INCOMPATIBILITY (Materials to avoid)

None known

HAZARDOUS DECOMPOSITION PRODUCTS

At extremely high temperatures oxides of sulfur and boron hydrides can form.

HAZARDOUS POLYMERIZATION

MAY OCCUR

CONDITIONS TO AVOID

WILL NOT OCCUR

X

SECTION VII - SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED

Work up-wind of spill. Sweep up and return to container for re-use or disposal. Flush residue away with water.

WASTE DISPOSAL METHOD

Use licensed waste disposal agent

SECTION VIII - SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (Specify type)

For prolonged exposure, use mechanical dust respirator

VENTILATION

LOCAL EXHAUST

Yes

SPECIAL

No

MECHANICAL (General)

No

OTHER

No

PROTECTIVE GLOVES

Rubber Gloves

EYE PROTECTION

Chemical safety goggles

OTHER PROTECTIVE EQUIPMENT

SECTION IX - SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING

Avoid skin and eye contact. Wash thoroughly after handling

OTHER PRECAUTIONS

U.S. DEPARTMENT OF LABOR
Occupational Safety and Health Administration

Form Approved
OMB No. 44-R1387

MATERIAL SAFETY DATA SHEET

Required under USDL Safety and Health Regulations for Ship Repairing,
Shipbuilding, and Shipbreaking (29 CFR 1915, 1916, 1917)

SECTION I

MANUFACTURER'S NAME OMI International Corporation - Udylite		EMERGENCY TELEPHONE NO. (313) 497-9129
ADDRESS (Number, Street, City, State, and ZIP Code) 21441 Hoover Road Warren, Michigan 48089		
CHEMICAL NAME AND SYNONYMS Udylite Nickel Brightener 61 Adjustor		TRADE NAME AND SYNONYMS Same
CHEMICAL FAMILY (See Below)	FORMULA Proprietary	

SECTION II - HAZARDOUS INGREDIENTS

PAINTS, PRESERVATIVES, & SOLVENTS	%	TLV (Units)	ALLOYS AND METALLIC COATINGS	%	TLV (Units)
PIGMENTS	No	No	BASE METAL	No	No
CATALYST			ALLOYS		
VEHICLE			METALLIC COATINGS		
SOLVENTS			FILLER METAL PLUS COATING OR CORE FLUX		
ADDITIVES			OTHERS		
OTHERS					

HAZARDOUS MIXTURES OF OTHER LIQUIDS, SOLIDS, OR GASES	%	TLV (Units)
An aqueous solution of unsaturated sulfo-oxygen compounds, as with a pH range of 5 to 6	> 10	NA

SECTION III - PHYSICAL DATA

BOILING POINT (°F.)	> 200°F	SPECIFIC GRAVITY (H ₂ O=1)	1.19
VAPOR PRESSURE (mm Hg.)	NA	PERCENT VOLATILE BY VOLUME (%)	None
VAPOR DENSITY (AIR=1)	NA	EVAPORATION RATE (_____ =1)	NA
SOLUBILITY IN WATER	Appreciable		NA
APPEARANCE AND ODOR	Light yellow liquid with an aromatic odor.		

SECTION IV - FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (Method used)	None	FLAMMABLE LIMITS	None	Lel	Uel
				X	X
EXTINGUISHING MEDIA	None. Product does not burn.				
SPECIAL FIRE FIGHTING PROCEDURES	None				
UNUSUAL FIRE AND EXPLOSION HAZARDS	None				

SECTION V - HEALTH HAZARD DATA

THRESHOLD LIMIT VALUE

None known or established.

EFFECTS OF OVEREXPOSURE

May cause irritation.

EMERGENCY AND FIRST AID PROCEDURES

Flush skin and eyes with water. For eyes get medical attention.

SECTION VI - REACTIVITY DATA

STABILITY

UNSTABLE

CONDITIONS TO AVOID

STABLE

X

INCOMPATIBILITY (Materials to avoid)

Strong oxidizers.

HAZARDOUS DECOMPOSITION PRODUCTS

Probable SO₂

HAZARDOUS POLYMERIZATION

MAY OCCUR

CONDITIONS TO AVOID

WILL NOT OCCUR

X

SECTION VII - SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED

Flush with water.

WASTE DISPOSAL METHOD

Bury in impervious soil in accordance with local statutes.

SECTION VIII - SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (Specify type)

None

VENTILATION

LOCAL EXHAUST

Yes

SPECIAL

No

MECHANICAL (General)

No

OTHER

No

PROTECTIVE GLOVES

rubber gloves

EYE PROTECTION

chemical safety goggles

OTHER PROTECTIVE EQUIPMENT

None

SECTION IX - SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING

Do not permit ambient temperature to exceed 110°F or fall below 32°F

OTHER PRECAUTIONS

Avoid excessive skin contact. Wash with soap and water after handling.

U.S. DEPARTMENT OF LABOR
Occupational Safety and Health Administration

OMB No. 44-11337

MATERIAL SAFETY DATA SHEET

Required under USDL Safety and Health Regulations for Ship Repairing,
Shipbuilding, and Shipbreaking (29 CFR 1915, 1916, 1917)

SECTION I

MANUFACTURER'S NAME OMI International Corporation - Udylite		EMERGENCY TELEPHONE NO. (313) 497-9129
ADDRESS (Number, Street, City, State, and ZIP Code) 21441 Hoover Road Warren, Michigan 48089		
CHEMICAL NAME AND SYNONYMS Udylite Nickel Brightener 66 IT		TRADE NAME AND SYNONYMS Same
CHEMICAL FAMILY See Below	FORMULA Proprietary	

SECTION II - HAZARDOUS INGREDIENTS

PAINTS, PRESERVATIVES, & SOLVENTS	%	TLV (Units)	ALLOYS AND METALLIC COATINGS	%	TLV (Units)
PIGMENTS	No	No	BASE METAL	No	No
CATALYST			ALLOYS		
VEHICLE			METALLIC COATINGS		
SOLVENTS			FILLER METAL PLUS COATING OR CORE FLUX		
ADDITIVES			OTHERS		
OTHERS					

HAZARDOUS MIXTURES OF OTHER LIQUIDS, SOLIDS, OR GASES	%	TLV (Units)
Aqueous mixture of aliphatic alcohols	< 3	N.A.
aliphatic sulfonates	< 20	X
salt of a polyhydroxy acid	< 5	N.A.
and other organic additives		

SECTION III - PHYSICAL DATA

BOILING POINT (°F.)	> 212 F	SPECIFIC GRAVITY (H ₂ O=1)	1.15
VAPOR PRESSURE (mm Hg.)	NA	PERCENT. VOLATILE BY VOLUME (%)	NA
VAPOR DENSITY (AIR=1)	NA	EVAPORATION RATE (_____ =1)	NA
SOLUBILITY IN WATER	Appreciable		X
APPEARANCE AND ODOR	Amber Liquid		

SECTION IV - FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (Method used)	None	FLAMMABLE LIMITS	Lel	Uel
EXTINGUISHING MEDIA	N.A.		X	X
SPECIAL FIRE FIGHTING PROCEDURES	None Known			
UNUSUAL FIRE AND EXPLOSION HAZARDS				
Prolong heating at extremely high temperatures could liberate toxic oxides of sulfur.				

SECTION V - HEALTH HAZARD DATA

PERMISSIBLE EXPOSURE LIMIT VALUE
None Known or Established

EFFECTS OF OVER EXPOSURE
Skin Irritation

EMERGENCY AND FIRST AID PROCEDURES

Flush skin and eyes with water. For eyes, get medical attention.

SECTION VI - REACTIVITY DATA

STABILITY	UNSTABLE		CONDITIONS TO AVOID
	STABLE	X	
INCOMPATIBILITY (Materials to avoid) None Known			
HAZARDOUS DECOMPOSITION PRODUCTS None Known			
HAZARDOUS POLYMERIZATION	MAY OCCUR		CONDITIONS TO AVOID
	WILL NOT OCCUR	X	

SECTION VII - SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED
Flush area with water.

WASTE DISPOSAL METHOD

Refer to a licensed disposal agent.

SECTION VIII - SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (Specify type) None			
VENTILATION	LOCAL EXHAUST Yes	SPECIAL	No
	MECHANICAL (General) No	OTHER	No
PROTECTIVE GLOVES Rubber Gloves		EYE PROTECTION Chemical Safety Goggles	
OTHER PROTECTIVE EQUIPMENT			

SECTION IX - SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING
Avoid contact. Wash thoroughly after handling. Store upright at temperature between 32 F to 110 F.

OTHER PRECAUTIONS
For Industrial Use Only.

NOV 22 1977

STANLEY TOOL DIV.
FOWLERVILLE MI 48836

1-25-84

U.S. DEPARTMENT OF LABOR
Occupational Safety and Health Administration

Form Approved
OMB No. 44-R1387

MATERIAL SAFETY DATA SHEET

Required under USDL Safety and Health Regulations for Ship Repairing,
Shipbuilding, and Shipbreaking (29 CFR 1915, 1916, 1917)

SECTION I

MANUFACTURER'S NAME Formax Mfg. Corp.		EMERGENCY TELEPHONE NO. 313-921-7030
ADDRESS (Number, Street, City, State, and ZIP Code) 3178 Bellevue Avenue, Detroit, MI 48207		
CHEMICAL NAME AND SYNONYMS Animal Patty Acid O/W Emulsion with Abrasives		TRADE NAME AND SYNONYMS Polishing Compound
CHEMICAL FAMILY Organic	FORMULA #12382 Liquid Compound	

SECTION II - HAZARDOUS INGREDIENTS

PAINTS, PRESERVATIVES, & SOLVENTS	%	TLV (Units)	ALLOYS AND METALLIC COATINGS	%	TLV (Units)
PIGMENTS			BASE METAL		
CATALYST			ALLOYS		
VEHICLE			METALLIC COATINGS		
SOLVENTS			FILLER METAL PLUS COATING OR CORE FLUX		
ADDITIVES			OTHERS		
OTHERS					
HAZARDOUS MIXTURES OF OTHER LIQUIDS, SOLIDS, OR GASES				%	TLV (Units)

SECTION III - PHYSICAL DATA

BOILING POINT (°F.)	212° F	SPECIFIC GRAVITY (H ₂ O=1)	1.2
VAPOR PRESSURE (mm Hg.)		PERCENT VOLATILE BY VOLUME (%)	0
VAPOR DENSITY (AIR=1)		EVAPORATION RATE (_____ =1)	H20
SOLUBILITY IN WATER	Emulsifies		
APPEARANCE AND ODOR	Beige to tan - bland odor		

SECTION IV - FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (Method used)	265° F	COC	FLAMMABLE LIMITS	LM	UM
EXTINGUISHING MEDIA	Water; dry chemical; CO ₂ ; oil fire foams				
SPECIAL FIRE FIGHTING PROCEDURES	Does not constitute a fire or explosive hazard				
UNUSUAL FIRE AND EXPLOSION HAZARDS	NONE				

SECTION V - HEALTH HAZARD DATA

THRESHOLD LIMIT VALUE UNKNOWN

EFFECTS OF OVEREXPOSURE NONE

EMERGENCY AND FIRST AID PROCEDURES NONE REQUIRED

SECTION VI - REACTIVITY DATA

STABILITY	UNSTABLE		CONDITIONS TO AVOID
	STABLE	X	NONE

INCOMPATIBILITY (Materials to avoid) NONE

HAZARDOUS DECOMPOSITION PRODUCTS NONE

HAZARDOUS POLYMERIZATION	MAY OCCUR		CONDITIONS TO AVOID
	WILL NOT OCCUR	X	NONE

SECTION VII - SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED

Wipe or scoop up. Dispose of as a solid waste or incinerate

WASTE DISPOSAL METHOD

SECTION VIII - SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (Specify type) NONE

VENTILATION	LOCAL EXHAUST	X	SPECIAL	NONE
	MECHANICAL (General)	X	OTHER	

PROTECTIVE GLOVES	Operator preference	EYE PROTECTION	Safety glasses - contains abrasive
-------------------	---------------------	----------------	------------------------------------

OTHER PROTECTIVE EQUIPMENT NONE REQUIRED

SECTION IX - SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING No special precautions required - store

in cool space - keep from freezing to prevent breaking emulsion

OTHER PRECAUTIONS

U.S. DEPARTMENT OF LABOR
Occupational Safety and Health Administration

Form Approved
OMB No. 44-R1387

MATERIAL SAFETY DATA SHEET

Required under USDL Safety and Health Regulations for Ship Repairing,
Shipbuilding, and Shipbreaking (29 CFR 1915, 1916, 1917)

SECTION I

MANUFACTURER'S NAME DELROD SALES CORPORATION		EMERGENCY TELEPHONE NO. 616-327-6722
ADDRESS (Number, Street, City, State, and ZIP Code) 2485 Zylman Road, Kalamazoo, Michigan 49002		
CHEMICAL NAME AND SYNONYMS na		TRADE NAME AND SYNONYMS DSC #3368 Compound
CHEMICAL FAMILY buffing compound	FORMULA proprietary	

SECTION II - HAZARDOUS INGREDIENTS

PAINTS, PRESERVATIVES, & SOLVENTS	%	TLV (Units)	ALLOYS AND METALLIC COATINGS	%	TLV (Units)
PIGMENTS			BASE METAL		
CATALYST			ALLOYS		
VEHICLE			METALLIC COATINGS		
SOLVENTS			FILLER METAL PLUS COATING OR CORE FLUX		
ADDITIVES			OTHERS		
OTHERS					
HAZARDOUS MIXTURES OF OTHER LIQUIDS, SOLIDS, OR GASES				%	TLV (Units)

SECTION III - PHYSICAL DATA

BOILING POINT (°F.) approximately	220	SPECIFIC GRAVITY (H ₂ O=1)	1.02
VAPOR PRESSURE (mm Hg.) less than	15	PERCENT VOLATILE BY VOLUME (%)	0
VAPOR DENSITY (AIR=1)	na	EVAPORATION RATE (ether=1) greater than	1
SOLUBILITY IN WATER	complete	pH	9.5
APPEARANCE AND ODOR clear solution, mild pleasant odor.			

SECTION IV - FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (Method used)	na	FLAMMABLE LIMITS	unknown	unknown
EXTINGUISHING MEDIA	na			
SPECIAL FIRE FIGHTING PROCEDURES should not burn in as it or use condition.				
UNUSUAL FIRE AND EXPLOSION HAZARDS none are known.				

SECTION V - HEALTH HAZARD DATA

THRESHOLD LIMIT VALUE

not determined

EFFECTS OF OVEREXPOSURE

may dry skin upon prolonged or repeated exposure, may irritate especially sensitive skin.

EMERGENCY AND FIRST AID PROCEDURES

flush with water, at least 15 minutes if in eyes, consult physician if swelling, blushing or irritation persists after contact.

SECTION VI - REACTIVITY DATA

STABILITY

UNSTABLE

CONDITIONS TO AVOID

STABLE

XXXX

INCOMPATIBILITY (Materials to avoid)

strong oxidants

HAZARDOUS DECOMPOSITION PRODUCTS

none are known

HAZARDOUS
POLYMERIZATION

MAY OCCUR

CONDITIONS TO AVOID

WILL NOT OCCUR

XXXX

SECTION VII - SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED

flush into chemical sewer or absorb onto solid absorbents.

WASTE DISPOSAL METHOD

landfill or incinerate as permitted by local, state and federal statutes.

SECTION VIII - SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (Specify type)

none under normal use conditions

VENTILATION

LOCAL EXHAUST

normally adequate

SPECIAL

MECHANICAL (General)

OTHER

PROTECTIVE GLOVES

rubber or poly

EYE PROTECTION

standard plant type

OTHER PROTECTIVE EQUIPMENT

none under normal use conditions.

SECTION IX - SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING

product will freeze at about +20°F. If frozen, thaw slowly and stir before using.

OTHER PRECAUTIONS

U.S. DEPARTMENT OF LABOR
Occupational Safety and Health Administration

Form Approved
OMB No. 44-R1387

MATERIAL SAFETY DATA SHEET

Required under USDL Safety and Health Regulations for Ship Repairing,
Shipbuilding, and Shipbreaking (29 CFR 1915, 1916, 1917)

SECTION I

MANUFACTURER'S NAME DELROD SALES CORPORATION		EMERGENCY TELEPHONE NO. 616-327-6722
ADDRESS (Number, Street, City, State, and ZIP Code) 2485 Zylman Road, Kalamazoo, Michigan 49002		
CHEMICAL NAME AND SYNONYMS	TRADE NAME AND SYNONYMS DSC #255	
CHEMICAL FAMILY	FORMULA	

SECTION II - HAZARDOUS INGREDIENTS

PAINTS, PRESERVATIVES, & SOLVENTS	%	TLV (Units)	ALLOYS AND METALLIC COATINGS	%	TLV (Units)
PIGMENTS			BASE METAL		
CATALYST			ALLOYS		
VEHICLE			METALLIC COATINGS		
SOLVENTS			FILLER METAL PLUS COATING OR CORE FLUX		
ADDITIVES			OTHERS		
OTHERS					
HAZARDOUS MIXTURES OF OTHER LIQUIDS, SOLIDS, OR GASES				%	TLV (Units)

SECTION III - PHYSICAL DATA

BOILING POINT (°F.)	NA	SPECIFIC GRAVITY (H ₂ O=1)	
VAPOR PRESSURE (mm Hg.)	NA	PERCENT VOLATILE BY VOLUME (%)	NA
VAPOR DENSITY (AIR=1)	NA	EVAPORATION RATE (_____ =1)	NA
SOLUBILITY IN WATER	MODERATE		
APPEARANCE AND ODOR Cream colored powder, slight pine odor			

SECTION IV - FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (Method used)	NA	FLAMMABLE LIMITS	Lel	Uel
EXTINGUISHING MEDIA	NA			
SPECIAL FIRE FIGHTING PROCEDURES	NA			
UNUSUAL FIRE AND EXPLOSION HAZARDS	NA			

SECTION V - HEALTH HAZARD DATA

THRESHOLD LIMIT VALUE

EFFECTS OF OVEREXPOSURE

May cause eye or nasal irritation

EMERGENCY AND FIRST AID PROCEDURES

Flush eyes or skin with plenty of water.

SECTION VI - REACTIVITY DATA

STABILITY

UNSTABLE

CONDITIONS TO AVOID

STABLE

X

INCOMPATIBILITY (Materials to avoid)

NONE

HAZARDOUS DECOMPOSITION PRODUCTS

NONE

HAZARDOUS
POLYMERIZATION

MAY OCCUR

CONDITIONS TO AVOID

WILL NOT OCCUR

X

SECTION VII - SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED

Sweep up so as to minimum airborne dust.

WASTE DISPOSAL METHOD

Landfill or in accordance with local regulations.

SECTION VIII - SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (Specify type)

non-toxic particle mask

VENTILATION

LOCAL EXHAUST

SPECIAL

MECHANICAL (General)

forced draft ventilation

OTHER

PROTECTIVE GLOVES

YES

EYE PROTECTION

goggles

OTHER PROTECTIVE EQUIPMENT

SECTION IX - SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING

OTHER PRECAUTIONS

U. S. DEPARTMENT OF LABOR
WAGE AND LABOR STANDARDS ADMINISTRATION
Bureau of Labor Standards
MATERIAL SAFETY DATA SHEET

11686

SECTION I	
MANUFACTURER'S NAME MACDERMID, INC.	EMERGENCY TELEPHONE NO. 203-754-6161
ADDRESS (Number, Street, City, State, and ZIP Code) 526 HUNTINGDON AVENUE, WATERBURY, CONNECTICUT 06720	
CHEMICAL NAME AND SYNONYMS	TRADE NAME AND SYNONYMS Metex S-486
CHEMICAL FAMILY Soak Cleaner	FORMULA

SECTION II HAZARDOUS INGREDIENTS					
PAINTS, PRESERVATIVES, & SOLVENTS	%	TLV (Units)	ALLOYS AND METALLIC COATINGS	%	TLV (Units)
PIGMENTS			BASE METAL		
CATALYST			ALLOYS		
VEHICLE			METALLIC COATINGS		
SOLVENTS			FILLER METAL PLUS COATING OR CORE FLUX		
ADDITIVES			OTHERS		
OTHERS					
HAZARDOUS MIXTURES OF OTHER LIQUIDS, SOLIDS, OR GASES				%	TLV (Units)
None					

SECTION III PHYSICAL DATA	
BOILING POINT (°F.)	SPECIFIC GRAVITY (H ₂ O=1)
VAPOR PRESSURE (mm Hg.)	PERCENT VOLATILE BY VOLUME (%)
VAPOR DENSITY (AIR=1)	EVAPORATION RATE (_____=1)
SOLUBILITY IN WATER	Complete
APPEARANCE AND ODOR Light tan powder	

SECTION IV FIRE AND EXPLOSION HAZARD DATA			
FLASH POINT (Method used) None	FLAMMABLE LIMITS	LeI	UeI
EXTINGUISHING MEDIA			
SPECIAL FIRE FIGHTING PROCEDURES			
UNUSUAL FIRE AND EXPLOSION HAZARDS			

SECTION V HEALTH HAZARD DATA

THRESHOLD LIMIT VALUE

EFFECTS OF OVEREXPOSURE

EMERGENCY AND FIRST AID PROCEDURES

Mildly alkaline cleaner- Flush with plenty of water.

SECTION VI REACTIVITY DATA

STABILITY

UNSTABLE

CONDITIONS TO AVOID

STABLE

X

INCOMPATIBILITY (Materials to avoid)

HAZARDOUS DECOMPOSITION PRODUCTS

HAZARDOUS
POLYMERIZATION

MAY OCCUR

CONDITIONS TO AVOID

WILL NOT OCCUR

X

SECTION VII SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED

Flush with water.

WASTE DISPOSAL METHOD

Neutralize with dilute acid

SECTION VIII SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (Specify type)

VENTILATION

LOCAL EXHAUST

Dust mask

SPECIAL

MECHANICAL (General)

OTHER

PROTECTIVE GLOVES

Rubber

EYE PROTECTION

Goggles

OTHER PROTECTIVE EQUIPMENT

SECTION IX SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING

OTHER PRECAUTIONS

U. S. DEPARTMENT OF LABOR
WAGE AND LABOR STANDARDS ADMINISTRATION
Bureau of Labor Standards
MATERIAL SAFETY DATA SHEET

12277

SECTION I	
MANUFACTURER'S NAME MACDERMID, INC.	EMERGENCY TELEPHONE NO. 203-754-6161
ADDRESS (Number, Street, City, State, and ZIP Code) 526 HUNTINGDON AVENUE, WATERBURY, CONNECTICUT 06720	
CHEMICAL NAME AND SYNONYMS	TRADE NAME AND SYNONYMS Metex P - 1777
CHEMICAL FAMILY	FORMULA

SECTION II HAZARDOUS INGREDIENTS					
PAINTS, PRESERVATIVES, & SOLVENTS	%	TLV (Units)	ALLOYS AND METALLIC COATINGS	%	TLV (Units)
PIGMENTS			BASE METAL		
CATALYST			ALLOYS		
VEHICLE			METALLIC COATINGS		
SOLVENTS			FILLER METAL PLUS COATING OR CORE FLUX		
ADDITIVES			OTHERS		
OTHERS					
HAZARDOUS MIXTURES OF OTHER LIQUIDS, SOLIDS, OR GASES				%	TLV (Units)
Carbonates				75	
Silicates				15	

SECTION III PHYSICAL DATA	
BOILING POINT (°F.)	SPECIFIC GRAVITY (H ₂ O=1)
VAPOR PRESSURE (mm Hg.)	PERCENT VOLATILE BY VOLUME (%)
VAPOR DENSITY (AIR=1)	EVAPORATION RATE (_____ =1)
SOLUBILITY IN WATER	
APPEARANCE AND ODOR White powder	

SECTION IV FIRE AND EXPLOSION HAZARD DATA			
FLASH POINT (Method used) N.A.	FLAMMABLE LIMITS	Lel	Uel
EXTINGUISHING MEDIA			
SPECIAL FIRE FIGHTING PROCEDURES N.A.			
UNUSUAL FIRE AND EXPLOSION HAZARDS Carbon Dioxide can be emitted if heated to extreme temperature.			

SECTION V HEALTH HAZARD DATA

THRESHOLD LIMIT VALUE

Not known.

EFFECTS OF OVEREXPOSURE

Cause slight skin irritation.

EMERGENCY AND FIRST AID PROCEDURES

Eyes - Flush with water for 15 minutes. Contact doctor.

Skin - Flush with water. wash with vinegar.

SECTION VI REACTIVITY DATA

STABILITY

UNSTABLE

CONDITIONS TO AVOID

STABLE

X

INCOMPATIBILITY (Materials to avoid)

Acids

HAZARDOUS DECOMPOSITION PRODUCTS

Carbon Dioxide

HAZARDOUS
POLYMERIZATION

MAY OCCUR

CONDITIONS TO AVOID

WILL NOT OCCUR

X

SECTION VII SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED

Flush with water to drain.

WASTE DISPOSAL METHOD

Neutralize to pH 7.0 and discard. Consult local regulations
before discarding.

SECTION VIII SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (Specify type)

Dust mask

VENTILATION

LOCAL EXHAUST

SPECIAL

MECHANICAL (General)

OTHER

PROTECTIVE GLOVES

Rubber

EYE PROTECTION

Face shield

OTHER PROTECTIVE EQUIPMENT

Rubber apron

SECTION IX SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING

Store in dry area.

OTHER PRECAUTIONS

U. S. DEPARTMENT OF LABOR
WAGE AND LABOR STANDARDS ADMINISTRATION
Bureau of Labor Standards
MATERIAL SAFETY DATA SHEET

10351

SECTION I	
MANUFACTURER'S NAME MACDERMID, INC.	EMERGENCY TELEPHONE NO. 203-754-6161
ADDRESS (Number, Street, City, State, and ZIP Code) 526 HUNTINGDON AVENUE, WATERBURY, CONNECTICUT 06720	
CHEMICAL NAME AND SYNONYMS	TRADE NAME AND SYNONYMS EN-1751
CHEMICAL FAMILY Electrocleaner	FORMULA

SECTION II HAZARDOUS INGREDIENTS					
PAINTS, PRESERVATIVES, & SOLVENTS	%	TLV (Units)	ALLOYS AND METALLIC COATINGS	%	TLV (Units)
PIGMENTS			BASE METAL		
CATALYST			ALLOYS		
VEHICLE			METALLIC COATINGS		
SOLVENTS			FILLER METAL PLUS COATING OR CORE FLUX		
ADDITIVES			OTHERS		
OTHERS					
HAZARDOUS MIXTURES OF OTHER LIQUIDS, SOLIDS, OR GASES				%	TLV (Units)
Sodium Hydroxide				19	2mg/M ³

SECTION III PHYSICAL DATA	
BOILING POINT (°F.)	SPECIFIC GRAVITY (H ₂ O=1)
VAPOR PRESSURE (mm Hg.)	PERCENT VOLATILE BY VOLUME (%)
VAPOR DENSITY (AIR=1)	EVAPORATION RATE (_____ =1)
SOLUBILITY IN WATER	Complete
APPEARANCE AND ODOR Off white granular mixture.	

SECTION IV FIRE AND EXPLOSION HAZARD DATA			
FLASH POINT (Method used) None	FLAMMABLE LIMITS	Lel	Uel
EXTINGUISHING MEDIA			
SPECIAL FIRE FIGHTING PROCEDURES			
UNUSUAL FIRE AND EXPLOSION HAZARDS			

SECTION V HEALTH HAZARD DATA

THRESHOLD LIMIT VALUE

As with sodium hydroxide

EFFECTS OF OVEREXPOSURE

As with sodium hydroxide

EMERGENCY AND FIRST AID PROCEDURES

Flush with plenty of water. Neutralize with vinegar in case of skin contact a physician in case of injury.

SECTION VI REACTIVITY DATA

STABILITY

UNSTABLE

CONDITIONS TO AVOID

STABLE

X

Additions of cleaner should be made slowly and

INCOMPATIBILITY (Materials to avoid)

preferably in cold water. The reaction liberates

HAZARDOUS DECOMPOSITION PRODUCTS

heat.

HAZARDOUS
POLYMERIZATION

MAY OCCUR

CONDITIONS TO AVOID

WILL NOT OCCUR

X

SECTION VII SPILL OR LEAK PROCEDURES

STEPS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED

As with sodium hydroxide.

WASTE DISPOSAL METHOD

Neutralize to pH between 6.0 to 8.0 with dilute acid prior to discharging to sewer.

SECTION VIII SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (Specify type)

VENTILATION

LOCAL EXHAUST

SPECIAL

MECHANICAL (General)

OTHER

PROTECTIVE GLOVES

Rubber

EYE PROTECTION

Goggles

OTHER PROTECTIVE EQUIPMENT

SECTION IX SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING

As with sodium hydroxide

OTHER PRECAUTIONS

MATERIAL SAFETY DATA SHEET

Required under USDL Safety and Health Regulations for Ship Repairing,
Shipbuilding, and Shipbreaking (29 CFR 1915, 1916, 1917)

SECTION I

MANUFACTURER'S NAME BENCHMARK, INC.		EMERGENCY TELEPHONE NO. 313-285-0900/313-644-5626
ADDRESS (Number, Street, City, State, and ZIP Code) 4060 - 13th Street, Wyandotte, Michigan 48192		
CHEMICAL NAME AND SYNONYMS		TRADE NAME AND SYNONYMS B-920
CHEMICAL FAMILY	FORMULA	

SECTION II - HAZARDOUS INGREDIENTS

PAINTS, PRESERVATIVES, & SOLVENTS	%	TLV (Units)	ALLOYS AND METALLIC COATINGS	%	TLV (Units)
PIGMENTS			BASE METAL		
CATALYST			ALLOYS		
VEHICLE			METALLIC COATINGS		
SOLVENTS			FILLER METAL PLUS COATING OR CORE FLUX		
ADDITIVES			OTHERS		
OTHERS					
HAZARDOUS MIXTURES OF OTHER LIQUIDS, SOLIDS, OR GASES				%	TLV (Units)
Caustic Soda					

SECTION III - PHYSICAL DATA

BOILING POINT (°F.)		SPECIFIC GRAVITY (H ₂ O=1)	
VAPOR PRESSURE (mm Hg.)		PERCENT VOLATILE BY VOLUME (%)	
VAPOR DENSITY (AIR=1)		EVAPORATION RATE (_____ =1)	
SOLUBILITY IN WATER	Approx: 150 g/l		
APPEARANCE AND ODOR	White powder - alkali odor		

SECTION IV - FIRE AND EXPLOSION HAZARD DATA

FLASH POINT (Method used)	N/A	FLAMMABLE LIMITS	LeI	UeI
EXTINGUISHING MEDIA				
SPECIAL FIRE FIGHTING PROCEDURES				
UNUSUAL FIRE AND EXPLOSION HAZARDS				
None known				

SECTION V - HEALTH HAZARD DATA

THRESHOLD LIMIT VALUE

EFFECTS OF OVEREXPOSURE

As caustic soda

EMERGENCY AND FIRST AID PROCEDURES

Treat as caustic soda

SECTION VI - REACTIVITY DATA

STABILITY

UNSTABLE

CONDITIONS TO AVOID

STABLE

X

INCOMPATIBILITY (Materials to avoid)

Acids

HAZARDOUS DECOMPOSITION PRODUCTS

None known

HAZARDOUS
POLYMERIZATION

MAY OCCUR

CONDITIONS TO AVOID

WILL NOT OCCUR

X

SECTION VII - SPILL OR LEAK PROCEDURES

ACTIONS TO BE TAKEN IN CASE MATERIAL IS RELEASED OR SPILLED

Sweep up - flush small amounts with water.

WASTE DISPOSAL METHOD

Neutralize - separate solids.

SECTION VIII - SPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (Specify type)

VENTILATION

LOCAL EXHAUST

SPECIAL

MECHANICAL (General)

OTHER

PROTECTIVE GLOVES

Rubber

EYE PROTECTION

Safety Goggles

OTHER PROTECTIVE EQUIPMENT

SECTION IX - SPECIAL PRECAUTIONS

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORING

Keep dry.

OTHER PRECAUTIONS

CLEPO 569-N

PAGE 1 OF 2

SECTION 01 IDENTIFICATION

```

INFO FURNISHED BY..... FREDERICK GUMM CHEM CO. INC.
ADDRESS..... 538 FOREST ST KEARNY NJ 07032
CHEMICAL NAME/SYNONYMS... CLEPO 569-N
HAZARD CLASS..... CHEMICAL N.O.S
CHEMICAL FAMILY..... ADDITIVE FOR NITRIC ACID
EMERGENCY PHONE #..... 201-991-4174 OR 313-644-5626
FORMULA..... PROPRIETARY

```

SECTION 02 PHYSICAL DATA

```
BOILING POINT(DEG F)..... >212 DEG F
VAPOR PRESSURE(mmHg)..... NA
VAPOR DENSITY(AIR=1)..... NA
SOLUBILITY IN WATER..... COMPLETE
SPECIFIC GRAVITY(H2O=1).. APPROX. 1.32
% VOLATILE BY VOLUME..... APPROX. 45%
EVAPORATION RATE(H2O=1).. NA
APPEARANCE & ODOR..... DARK BROWN LIQUID
```

SECTION 03 FIRE AND EXPLOSION DATA

```
FLASH POINT..... NONE
EXTINGUISHING MEDIA..... NA
SPECIAL FIRE FIGHTING PROCEDURES
  NONE
UNUSUAL FIRE AND EXPLOSION HAZARDS
  NONE
NFPA HAZARD CLASSIFICATION.....HEALTH HAZARD(BLUE) 1
                                     FLAMMABILITY(RED) 0
                                     REACTIVITY(YELLOW) 0
```

SECTION 04 REACTIVITY DATA

```
STABILITY..... STABLE
CONDITIONS TO AVOID... NA
INCOMPATIBILITY(MATERIALS TO AVOID)
STRONG ALKALI
HAZARDOUS DECOMPOSITION PRODUCTS
NONE EXPECTED
HAZARDOUS POLYMERIZATION. WILL NOT OCCUR
CONDITIONS TO AVOID... NA
```

SECTION 05 HAZARDOUS COMPONENTS

PAINTS, PRESERVATIVES, & SOLVENTS NOT APPLICABLE
ALLOYS AND METALLIC COATINGS NOT APPLICABLE

HAZARDOUS COMPONENT	% BY WEIGHT	TLV(MG/M3)
IRON SALTS AS Fe	3.5	1

06 SPILL LEAK AND DISPOSAL PROCEDURES

STEPS TO BE TAKEN IF MATERIAL IS RELEASED OR SPILLED
SWEEP UP AND/OR FLUSH TO WASTE DISPOSAL AREA. WATCH FOR SLIPPERY CONDITIONS

WASTE DISPOSAL METHOD
NEUTRALIZE TO LOCALLY ACCEPTABLE pH. DEPENDING ON USAGE AND LOCALITY,
MAY ALSO REQUIRE PRECIPITATION OF HEAVY METALS. THEN DUMP TO DRAIN

***** SECTION 07 HEALTH HAZARD DATA *****

THRESHOLD LIMIT VALUE (CALCULATED) 28.57 (Mg/M3)

EFFECTS OF OVEREXPOSURE

CORROSIVE-WILL BURN SKIN AND EYES ... HARMFUL IF SWALLOWED

EMERGENCY AND FIRST AID PROCEDURES

REMOVE CONTAMINATED CLOTHING AND SHOES. FLUSH EFFECTED AREA WITH
PLENTY OF WATER (FOR EYES, HOLD EYELIDS OPEN AND FLUSH WITH WATER
FOR AT LEAST 15 MINUTES). IF SWALLOWED DO NOT INDUCE VOMITING
GET MEDICAL ATTENTION

***** SECTION 08 SPECIAL HANDLING PROCEDURES *****

RESPIRATORY PROTECTION(SPECIFY TYPE)

NOT GENERALLY REQUIRED

VENTILATION..... LOCAL EXHAUST SATISFACTORY

PROTECTIVE GLOVES..... RUBBER OR NEOPRENE

EYE PROTECTION..... CHEMICAL SAFETY GOGGLES AND/OR FACE SHIELD

OTHER PROTECTIVE EQUIPMENT

DEPENDING ON LOCAL CONDITIONS, RUBBER BOOTS AND APRON MAY BE NEEDED

***** SECTION 09 SPECIAL PRECAUTIONS *****

PRECAUTIONS TO BE TAKEN IN HANDLING AND STORAGE

DO NOT STORE WITH STRONG ALKALIES. CONTAINER MUST NOT BE
USED FOR ANY OTHER PURPOSE. KEEP TIGHTLY CLOSED

OTHER PRECAUTIONS

AVOID CONTACT WITH SKIN AND EYES

THE INFORMATION HEREIN IS BASED ON TECHNICAL DATA THAT IS BELIEVED TO
BE RELIABLE. IT IS INTENDED FOR USE BY PERSONS HAVING TECHNICAL SKILL
AND AT THEIR OWN DISCRETION AND RISK. SINCE CONDITIONS OF USE ARE
OUTSIDE OUR CONTROL, WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, AND
ASSUME NO LIABILITY IN CONNECTION WITH THE USE OF THIS INFORMATION.