CETIFICATION

SDG No:

JC20660

Laboratory:

Accutest, New Jersey

Site:

BMS, Building 5 Area, PR

Matrix:

Soil/Groundwater

Humacao, PR

SUMMARY:

Groundwater and soil samples (Table 1) were collected on the BMSMC facility – Building 5 Area. The BMSMC facility is located in Humacao, PR. Samples were taken May 13-19, 2016 and were analyzed in Accutest Laboratory of Dayton, New Jersey for the ABN TCL Special List (1,4-Dioxane and Naphthalene were analyzed following the SIM technique); TCL pesticides list; and for low molecular weight alcohols (LMWA) the results were reported under SDG No.: JC20660. Results were validated using the latest validation guidelines (July, 2015) of the EPA Hazardous Waste Support Section. The analyses performed are shown in Table 1. Individual data review worksheets are enclosed for each target analyte group. The data sample organic data samples summary form shows for analytes results that were qualified.

In summary the results are valid and can be used for decision taking purposes.

Table 1. Samples analyzed and analysis performed

SAMPLE ID	SAMPLE DESCRIPTION	MATRIX	ANALYSIS PERFORMED
JC20660-1	BPEB-20	AQ – Equipment Blank	ABN TCL special list; 1,-4- dioxane and Naphthalene (SIM); TCL pesticides; LMWA
JC20660-2	RA2-GWD	Groundwater	ABN TCL special list; 1,-4- dioxane and Naphthalene (SIM); LMWA
JC20660-3	RA1-GWD	Groundwater	ABN TCL special list; 1,-4- dioxane and Naphthalene (SIM); LMWA
JC20660-4	RA1 (11-12)	Soil	ABN TCL special list; 1,-4- dioxane and Naphthalene (SIM); LMWA
JC20660-5	RA2 (10-11)	Soil	ABN TCL special list; 1,-4- dioxane and Naphthalene (SIM); LMWA
JC20660-6	RA2-GWS	Groundwater	ABN TCL special list; 1,-4- dioxane and Naphthalene (SIM); TCL pesticides; LMWA

Reviewer Name:

Rafael Infante

Chemist License 1888

Signature:

Date:

June 16, 2016

Report of Analysis

Ву

SB

05/20/16

Analyzed

05/21/16

Page 1 of 3

Client Sample ID	BPEB-20
Lab Sample ID:	JC20660-

0 - 1Matrix:

File ID

6P26197.D

Method: Project:

AQ - Equipment Blank SW846 8270D SW846 3510C BMSMC, Building 5 Area, PR

DF

1

Date Sampled: 05/13/16 Date Received: 05/20/16

Percent Solids: n/a

OP94071

Prep Date Prep Batch **Analytical Batch**

E6P1221

Run #1 Run #2

> **Initial Volume** Final Volume 800 ml $1.0 \, \mathrm{ml}$

Run #1 Run #2

ABN TCL Special List

CAS No.	Compound	Result	RL	MDL	Units	Q
95-57-8	2-Chlorophenol	ND	6.3	1.0	ug/l	
59-50-7	4-Chloro-3-methyl phenol	ND	6.3	1.1	ug/l	
120-83-2	2,4-Dichlorophenol	ND	2.5	1.6	ug/l	
105-67-9	2,4-Dimethylphenol	ND	6.3	3.1	ug/l	
51-28-5	2,4-Dinitrophenol	ND	13	1.9	ug/l	
534-52-1	4,6-Dinitro-o-cresol	ND	6.3	1.6	ug/l	
95-48-7	2-Methylphenol	ND	2.5	1.1	ug/l	
	3&4-Methylphenol	ND	2.5	1.1	ug/l	
88-75-5	2-Nitrophenol	ND	6.3	1.2	ug/l	
100-02-7	4-Nitrophenol	ND	13	1.4	ug/l	
87-86-5	Pentachlorophenol	ND	6.3	1.7	ug/l	
108-95-2	Phenol	ND	2.5	0.49	ug/l	
58-90-2	2,3,4,6-Tetrachlorophenol	ND	6.3	1.8	ug/l	
95-95-4	2,4,5-Trichlorophenol	ND	6.3	1.7	ug/l	
88-06-2	2,4,6-Trichlorophenol	ND	6.3	1.2	ug/l	
83-32-9	Acenaphthene	ND	1.3	0.24	ug/l	
208-96-8	Acenaphthylene	ND	1.3	0.17	ug/l	
98-86-2	Acetophenone	ND	2.5	0.26	ug/I	
120-12-7	Anthracene	ND	1.3	0.26	ug/l	
1912-24-9	Atrazine	ND	2.5	0.56	ug/l	
100-52-7	Benzaldehyde	ND	6.3	0.36	ug/l	
56-55-3	Benzo(a)anthracene	ND	1.3	0.25	ug/l	
50-32-8	Benzo(a)pyrene	ND	1.3	0.27	ug/l	+
205-99-2	Benzo(b) fluoranthene	ND	1.3	0.26	ug/l	į
191-24-2	Benzo(g,h,i)perylene	ND	1.3	0.43	ug/l	j
207-08-9	Benzo(k)fluoranthene	ND	1.3	0.26	ug/l	- 9
101-55-3	4-Bromophenyl phenyl ether	ND	2.5	0.51	ug/l	
85-68-7	Butyl benzyl phthalate	ND	2.5	0.57	ug/l	
92-52-4	1,1'-Biphenyl	ND	1.3	0.27	ug/l	
91-58-7	2-Chloronaphthalene	ND	2.5	0.30	ug/l	
106-47-8	4-Chloroaniline	ND	6.3	0.43	ug/l	
86-74-8	Carbazole	ND	1.3	0.29	ug/l	

Rafael Infante Méndez LIC. # 1888

ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank



Report of Analysis

Page 2 of 3

Client Sample ID: Lab Sample ID:

BPEB-20

JC20660-1

Date Sampled: (

05/13/16 05/20/16

Matrix: Method: AQ - Equipment Blank SW846 8270D SW846 3510C

Percent Solids: n/a

Project: BMSMC, Building 5 Area, PR

ABN TCL Special List

11111102	and a UD Spould Dak						
CAS No.	Compound	Result	RL	MDL	Units	Q	
105-60-2	Caprolactam	ND	2.5	0.81	ug/l		
218-01-9	Chrysene	ND	1.3	0.22	ug/l		
111-91-1	bis(2-Chloroethoxy)methane	ND	2.5	0.35	ug/l		
111-44-4	bis(2-Chloroethyl)ether	ND	2.5	0.31	ug/l		
108-60-1	bis(2-Chloroisopropyl)ether	ND	2.5	0.50	ug/l		
7005-72-3	4-Chlorophenyl phenyl ether	ND	2.5	0.46	ug/l		
121-14-2	2,4-Dinitrotoluene	ND	1.3	0.69	ug/l		
606-20-2	2,6-Dinitrotoluene	ND	1.3	0.60	ug/l		
91-94-1	3,3'-Dichlorobenzidine	ND	2.5	0.63	ug/l		
53-70-3	Dibenzo(a,h)anthracene	ND	1.3	0.41	ug/l		
132-64-9	Dibenzofuran	ND	6.3	0.28	ug/l		
84-74-2	Di-n-butyl phthalate	ND	2.5	0.62	ug/l		
117-84-0	Di-n-octyl phthalate	ND	2.5	0.29	ug/l		
84-66-2	Diethyl phthalate	ND	2.5	0.33	ug/l		
131-11-3	Dimethyl phthalate	ND	2.5	0.27	ug/l		
117-81-7	bis(2-Ethylhexyl)phthalate	ND	2.5	2.1	ug/l		
206-44-0	Fluoranthene	ND	1.3	0.21	ug/l		
86-73-7	Fluorene	ND	1.3	0.21	ug/l		
118-74-1	Hexachlorobenzene	ND	1.3	0.41	ug/l		
87-68-3	Hexachlorobutadiene	ND	1.3	0.62	ug/l		
77-47-4	Hexachlorocyclopentadiene	ND	13	3.5	ug/l		
67-72-1	Hexachloroethane	ND	2.5	0.49	ug/l		
193-39-5	Indeno(1,2,3-cd)pyrene	ND	1.3	0.42	ug/l		
78-59-1	Isophorone	ND	2.5	0.35	ug/l		
90-12-0	1-Methylnaphthalene	ND	1.3	0.33	ug/l		
91-57-6	2-Methylnaphthalene	ND	1.3	0.26	ug/l		
88-74-4	2-Nitroaniline	ND	6.3	0.35	ug/l		
99-09-2	3-Nitroaniline	ND	6.3	0.48	ug/l		
100-01-6	4-Nitroaniline	ND	6.3	0.55	ug/l		
98-95-3	Nitrobenzene	ND	2.5	0.80	ug/l		
621-64-7	N-Nitroso-di-n-propylamine	ND	2.5	0.60	ug/l		
86-30-6	N-Nitrosodiphenylamine	ND	6.3	0.28	ug/l		
85-01-8	Phenanthrene	ND	1.3	0.22	ug/l		
129-00-0	Pyrene	ND	1.3	0.27	ug/l		
95-94-3	1,2,4,5-Tetrachlorobenzene	ND	2.5	0.46	ug/l		
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Lim	its		
367-12-4	2-Fluorophenol	41%		14-8	8%		
4165-62-2	Phenol-d5	27%		10-1	10%		

Rafael Infinite
Méndez
LIC # 1888

ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Report of Analysis

Client Sample ID: Lab Sample ID:

BPEB-20 JC20660-1

Matrix:

AQ - Equipment Blank

Method: Project: SW846 8270D SW846 3510C BMSMC, Building 5 Area, PR Date Sampled: 05/13/16 Date Received: 05/20/16

Percent Solids: n/a

ABN TCL Special List

CAS No.	Surrogate Recoveries	Run#1	Run# 2	Limits
118-79-6	2,4,6-Tribromophenol	63%		39-149%
4165-60-0	Nitrobenzene-d5	62%		32-128%
321-60-8	2-Fluorobiphenyl	69%		35-119%
1718-51-0	Terphenyl-d14	79%		10-126%



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Report of Analysis

Page 1 of 1

Client Sample ID:	BPEB-20
Lab Sample ID:	JC20660-1

Matrix: Method:

AQ - Equipment Blank

SW846 8270D BY SIM SW846 3510C BMSMC, Building 5 Area, PR

Date Sampled:

Q

05/13/16 Date Received: 05/20/16

Percent Solids: n/a

File ID DF Analyzed By Prep Date Prep Batch **Analytical Batch** 3M61531.D 1 05/22/16 LK 05/20/16 OP94071A E3M2897

Run #1 Run #2

Project:

Initial Volume Final Volume Run #1 800 ml

Run #2

1.0 ml

CAS No.	Compound	Result	RL	MDL	Units
91-20-3 123-91-1	Naphthalene 1,4-Dioxane	ND ND	0.13 0.13	0.037 0.061	ug/l ug/l
CAS No.	AS No. Surrogate Recoveries		Run# 2	Lim	its
4405.00.0	h.t				

4165-60-0 Nitrobenzene-d5 63% 24-125% 321-60-8 2-Fluorobiphenyl 70% 19-127% 1718-51-0 Terphenyl-d14 82% 10-119%



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

Project:

SGS Accutest

Report of Analysis

Page 1 of 1

Client Sample ID: BPEB-20 Lab Sample ID: JC20660-1

Matrix: Method:

AQ - Equipment Blank SW846-8015C (DAI)

BMSMC, Building 5 Area, PR

Date Sampled: 05/13/16 Date Received: 05/20/16

Percent Solids:

Run #1	File ID	DF	Analyzed	By	Prep Date	Prep Batch	Analytical Batch
Run #2	GH105147.D	1	05/20/16	XPL	n/a	n/a	GGH5294

Low Molecular Alcohol List

CAS No.	Compound	Result	RL	MDL	Units	Q
64-17-5	Ethanol	ND	100	55	ug/l	
78-83-1	Isobutyl Alcohol	ND	100	36	ug/l	
67-63-0	Isopropyl Alcohol	ND	100	68	ug/l	
71-23-8	n-Propyl Alcohol	ND	100	43	ug/l	
71-36-3	n-Butyl Alcohol	ND	100	87	ug/l	
78-92-2	sec-Butyl Alcohol	ND	100	66	ug/l	
67-56-1	Methanol	ND	200	71	ug/l	
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Lim	its	
111-27-3	Hexanol	82%		56-1	45%	
111-27-3	Hexanol	86%		56-1	45%	



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank



Report of Analysis

Page 1 of 1

Client Sample ID: BPEB-20 Lab Sample ID: JC20660-1

Matrix: Method:

Project:

AQ - Equipment Blank

SW846 8081B SW846 3510C BMSMC, Building 5 Area, PR Date Sampled: 05/13/16

Q

Percent Solids:

Date Received: 05/20/16

File ID DF Ву Analyzed Prep Date Prep Batch **Analytical Batch** Run #1 1G123361.D 05/22/16 05/20/16 RK OP94098 G1G3994 Run #2

Initial Volume Final Volume 890 ml

Run #1 Run #2

 $10.0 \, \mathrm{ml}$

Pesticide TCL List

CAS No.	Compound	Result	RL	MDL	Units
309-00-2	Aldrin	ND	0.011	0.0068	ug/l
319-84-6	alpha-BHC	ND	0.011	0.0067	ug/l
319-85-7	beta-BHC	ND	0.011	0.0064	ug/l
319-86-8	delta-BHC	ND	0.011	0.0051	ug/l
58-89-9	gamma-BHC (Lindane)	ND	0.011	0.0031	ug/l
5103-71-9	alpha-Chlordane	ND	0.011	0.0052	ug/l
5103-74-2	gamma-Chlordane	ND	0.011	0.0052	ug/l
60-57-1	Dieldrin	ND	0.011	0.0040	ug/l
72-54-8	4,4'-DDD	ND	0.011	0.0043	ug/l
72-55-9	4,4'-DDE	ND	0.011	0.0069	ug/l
50-29-3	4,4'-DDT	ND	0.011	0.0056	ug/l
72-20-8	Endrin	ND	0.011	0.0057	ug/l
1031-07-8	Endosulfan sulfate	ND	0.011	0.0059	ug/l
7421-93-4	Endrin aldehyde	ND	0.011	0.0058	ug/l
53494-70-5	Endrin ketone	ND	0.011	0.0057	ug/l
959-98-8	Endosulfan-I	ND	0.011	0.0056	ug/l
33213-65-9	Endosulfan-II	ND	0.011	0.0048	ug/l
76-44-8	Heptachlor	ND	0.011	0.0043	ug/l
1024-57-3	Heptachlor epoxide	ND	0.011	0.0073	ug/l
72-43-5	Methoxychlor	ND	0.022	0.0064	ug/l
8001-35-2	Toxaphene	ND	0.28	0.21	ug/l
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Limi	ts
877-09-8	Tetrachloro-m-xylene	73%		26-13	12%
877-09-8	Tetrachloro-m-xylene	71%		26-13	12%
2051-24-3	Decachlorobiphenyl	51%		10-11	8%
2051-24-3	Decachlorobiphenyl	53%		10-11	8%



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank



Report of Analysis

By

SB

Prep Date

05/20/16

Page 1 of 3

	Client Sample ID:
ı	Lab Sample ID:

RA2-GWD JC20660-2

Matrix: Method: AQ - Ground Water

DF

1

SW846 8270D SW846 3510C

Date Sampled: 05/18/16 Date Received: 05/20/16

Project:

BMSMC, Building 5 Area, PR

Percent Solids: n/a

OP94071

Q

Analytical Batch Prep Batch

E6P1221

Run #1 Run #2

Run #1

Run #2

Initial Volume

File ID

6P26198.D

Final Volume

Analyzed

05/21/16

910 ml

 $1.0 \, \mathrm{ml}$

ABN TCL Special List

CAS No.	Compound	Result	RL	MDL	Units
95-57-8	2-Chlorophenol	ND	5.5	0.90	ug/l
59-50-7	4-Chloro-3-methyl phenol	ND	5.5	0.98	ug/l
120-83-2	2,4-Dichlorophenol	ND	2.2	1.4	ug/l
105-67-9	2,4-Dimethylphenol	ND	5.5	2.7	ug/l
51-28-5	2,4-Dinitrophenol	ND	11	1.7	ug/l
534-52-1	4,6-Dinitro-o-cresol	ND	5.5	1.4	ug/l
95-48-7	2-Methylphenol	ND	2.2	0.98	ug/l
	3&4-Methylphenol	ND	2.2	0.97	ug/l
88-75-5	2-Nitrophenol	ND	5.5	1.1	ug/l
100-02-7	4-Nitrophenol	ND	11	1.3	ug/l
87-86-5	Pentachlorophenoi	ND	5.5	1.5	ug/l
108-95-2	Phenol	ND	2.2	0.43	ug/l
58-90-2	2,3,4,6-Tetrachlorophenol	ND	5.5	1.6	ug/l
95-95-4	2,4,5-Trichlorophenol	ND	5.5	1.5	ug/l
88-06-2	2,4,6-Trichlorophenol	ND	5.5	1.0	ug/i
83-32-9	Acenaphthene	ND	1.1	0.21	ug/l
208-96-8	Acenaphthylene	ND	1.1	0.15	ug/l
98-86-2	Acetophenone	ND	2.2	0.23	ug/l
120-12-7	Anthracene	ND	1.1	0.23	ug/l
1912-24-9	Atrazine	ND	2.2	0.49	ug/l
100-52-7	Benzaldehyde	ND	5.5	0.32	ug/l
56-55-3	Benzo(a)anthracene	ND	1.1	0.22	ug/l
50-32-8	Benzo(a)pyrene	ND	1.1	0.23	ug/l
205-99-2	Benzo(b)fluoranthene	ND	1.1	0.23	ug/l
191-24-2	Benzo(g,h,i)perylene	ND	1,4	0.37	ug/l
207-08-9	Benzo(k)fluoranthene	ND	1.1	0.23	ug/l
101-55-3	4-Bromophenyl phenyl ether	ND	2.2	0.44	ug/l
85-68-7	Butyl benzyl phthalate	ND	2.2	0.50	ug/l
92-52-4	I,1-Biphenyl	ND	1.1	0.23	ug/l
91-58-7	2-Chloronaphthalene	ND	2.2	0.26	ug/l
106-47-8	4-Chloroaniline	ND	5.5	0.37	ug/l
86-74-8	Carbazole	ND	1.1	0.25	ug/l



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Method:

Project:

Page 2 of 3

Report of Analysis

Client Sample ID: **RA2-GWD** Lab Sample ID: JC20660-2 Matrix:

AQ - Ground Water

SW846 8270D SW846 3510C BMSMC, Building 5 Area, PR

Date Sampled: 05/18/16 Date Received: 05/20/16 Percent Solids: n/a

ABN TCL Special List

CAS No.	Compound	Result	RL	MDL	Units	Q
105-60-2	Caprolactam	ND	2.2	0.71	ug/l	
218-01-9	Chrysene	ND	1.1	0.19	ug/l	
111-91-1	bis(2-Chloroethoxy)methane	ND	2.2	0.31	ug/l	
111444-4	bis(2-Chloroethyl)ether	ND	2.2	0.27	ug/l	
108-60-1	bis(2-Chloroisopropyl)ether	ND	2.2	0.44	ug/l	
7005-72-3	4-Chlorophenyl phenyl ether	ND	2.2	0.40	ug/l	
121-14-2	2,4-Dinitrotoluene	ND	1.1	0.61	ug/l	
606-20-2	2,6-Dinitrotoluene	ND	1.1	0.52	ug/l	
91-94-1	3,3'-Dichlorobenzidine	ND	2.2	0.56	ug/l	
53-70-3	Dibenzo(a,h)anthracene	ND	1.1	0.36	ug/l	
132-64-9	Dibenzofuran	ND	5.5	0.24	ug/l	
84-74-2	Di-n-butyl phthalate	ND	2.2	0.55	ug/l	
117-84-0	Di-n-octyl phthalate	NĐ	2.2	0.26	ug/l	
84-66-2	Diethyl phthalate	ND	2.2	0.29	ug/l	
131-11-3	Dimethyl phthalate	ND	2.2	0.24	ug/l	
117-81-7	bis(2-Ethylhexyl)phthalate	ND	2.2	1.8	ug/l	
206-44-0	Fluoranthene	ND	1.1	0.19	ug/l	
86-73-7	Fluorene	ND	1,1	0.19	ug/l	
118-74-1	Hexachlorobenzene	ND	1.1	0.36	ug/l	
87-68-3	Hexachlorobutadiene	ND	1.1	0.54	ug/l	
77-47-4	Hexachlorocyclopentadiene	ND	11	3.1	ug/l	
67-72-1	Hexachloroethane	ND	2.2	0.43	ug/l	
193-39-5	Indeno(1,2,3-cd)pyrene	ND	1,1	0.36	ug/l	
78-59-1	Isophorone	ND	2.2	0.30	ug/l	
90-12-0	I-Methylnaphthalene	ND	1.1	0.29	ug/l	
91-57-6	2-Methylnaphthalene	ND	1,1	0.23	ug/l	
88-74-4	2-Nitroaniline	ND	5.5	0.30	ug/l	
99-09-2	3-Nitroaniline	ND	5.5	0.43	ug/l	
100-01-6	4-Nitroaniline	ND	5.5	0.48	ug/l	
98-95-3	Nitrobenzene	ND	2.2	0.71	ug/l	
621-64-7	N-Nitroso-di-n-propylamine	ND	2.2	0.53	ug/l	SOCIADO DE
86-30-6	N-Nitrosodiphenylamine	ND	5.5	0.24	ug/l	300
85-01-8	Phenanthrene	ND	1.1	0.19	ug/l	Brafael Infante
129-00-0	Pyrene	ND	1.1	0.24	ug/l	Méndez Mindez
95-94-3	1,2,4,5-Tetrachlorobenzene	ND	2.2	0.41	ug/l	LIC # 1888
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Lim	its	CHIMICO LICENCIASIS
367-12-4	2-Fluorophenol	40%		14-8	8%	LOLLICEN
4165-62-2	Phenol-d5	27%		10-1	10%	

ND = Not detected RL = Reporting Limit MDL = Method Detection Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Report of Analysis

Page 3 of 3

Client Sample ID: **RA2-GWD** Lab Sample ID:

JC20660-2

Matrix: Method: AQ - Ground Water SW846 8270D SW846 3510C

Date Sampled: 05/18/16 Date Received: Percent Solids:

05/20/16

Project:

BMSMC, Building 5 Area, PR

ABN TCL Special List

CAS No.	Surrogate Recoveries	Run#1	Run# 2	Limits
118-79-6	2,4,6-Tribromophenol	70%		39-149%
4165-60-0	Nitrobenzene-d5	63%		32-128%
321-60-8	2-Fluorobiphenyl	69%		35-119%
1718-51-0	Terphenyl-d14	69%		10-126%



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E - Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Report of Analysis

Page 1 of 1

Client Sample ID:	RA2-GWD
Lab Sample ID:	JC20660-2

Matrix: Method: AQ - Ground Water

Date Sampled: Date Received:

Percent Solids:

Q

05/18/16 05/20/16

Project:

SW846 8270D BY SIM SW846 3510C BMSMC, Building 5 Area, PR

File ID DF Analyzed By Prep Date Prep Batch **Analytical Batch** Run #1 3M61532.D 05/22/16 1 LK 05/20/16 OP94071A E3M2897

Run #2

Initial Volume Final Volume Run #1 910 ml

Run #2

1.0 ml

CAS No.	Compound	Result	RL	MDL	Units
91-20-3 123-91-1	Naphthalene 1,4-Dioxane	ND 3.48	0.11 0.11	0.032 0.054	ug/l ug/l
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Lim	its
4165-60-0 321-60-8	Nitrobenzene-d5 2-Fluorobiphenyl	74% 76%			25% 27%
1718-51-0	Terphenyl-d14	78%			19%



ND = Not detected

MDL = Method Detection Limit

J = Indicates an estimated value

RL = Reporting Limit

B = Indicates analyte found in associated method blank

E = Indicates value exceeds calibration range

N = Indicates presumptive evidence of a compound

Report of Analysis

Ву

XPL

Analyzed

05/20/16

Page 1 of 1

Client Sample ID: **RA2-GWD** Lab Sample ID:

JC20660-2

Date Sampled: Date Received:

Prep Date

n/a

05/18/16 05/20/16

Matrix: Method: AQ - Ground Water SW846-8015C (DAI)

DF

1

Percent Solids:

Q

Project:

BMSMC, Building 5 Area, PR

Prep Batch **Analytical Batch** n/a GGH5294

Run #1 Run #2

Low Molecular Alcohol List

File ID

GH105148.D

CAS No.	Compound	Result	RL	MDL	Units
64-17-5	Ethanol	ND	100	55	ug/l
78-83-1	Isobutyl Alcohol	ND	100	36	ug/l
67-63-0	Isopropyl Alcohol	ND	100	68	ug/l
71-23-8	n-Propyl Alcohol	ND	100	43	ug/l
71-36-3	n-Butyl Alcohol	ND	100	87	ug/l
78-92-2	sec-Butyl Alcohol	ND	100	66	ug/l
67-56-1	Methanol	ND	200	71	ug/l
CAS No.	Surrogate Recoveries	Run# 1	Run# 2	Lim	its
111-27-3	Hexanol	84%		56-1	45%
111-27-3	Hexanol	87%		56-1	45%



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E | Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Report of Analysis

Page 1 of 3

Client Sample ID:	RA1-GWD
Lab Sample ID:	JC20660-3

900 ml

Matrix: Method: AQ - Ground Water

SW846 8270D SW846 3510C BMSMC, Building 5 Area, PR

Date Sampled: Date Received:

Q

05/18/16 05/20/16

Percent Solids: n/a

Ву File ID DF Analyzed Prep Date Prep Batch **Analytical Batch** Run #1 6P26199.D 1 05/21/16 SB 05/20/16 OP94071 E6P1221

Run #2

Project:

Initial Volume **Final Volume**

Run #1 Run #2

1.0 ml

ABN TCL Special List

CAS No.	Compound.	Result	RL	MDL	Unit
95-57-8	2-Chlorophenol	ND	5.6	0.91	ug/l
59-50-7	4-Chloro-3-methyl phenol	ND	5.6	0.99	ug/l
120-83-2	2,4-Dichlorophenol	ND	2.2	1.4	ug/l
105-67-9	2,4-Dimethylphenol	ND	5.6	2.7	ug/l
51-28-5	2,4-Dinitrophenol	ND	11	1.7	ug/l
534-52-1	4,6-Dinitro-o-cresol	ND	5.6	1.4	ug/l
95-48-7	2-Methylphenol	ND	2.2	0.99	ug/l
	3&4-Methylphenol	ND	2.2	0.98	ug/l
88-75-5	2-Nitrophenol	ND	5.6	1.1	ug/l
100-02-7	4-Nitrophenol	ND	11	1.3	ug/l
87-86-5	Pentachlorophenol	ND	5.6	1.5	ug/l
108-95-2	Phenol	ND	2.2	0.44	ug/l
58-90-2	2,3,4,6-Tetrachlorophenol	ND	5.6	1.6	ug/l
95-95-4	2,4,5-Trichlorophenol	ND	5.6	1.5	ug/l
88-06-2	2,4,6-Trichlorophenol	ND	5.6	1.0	ug/l
83-32-9	Acenaphthene	ND	1.1	0.21	ug/l
208-96-8	Acenaphthylene	ND	1.1	0.15	ug/l
98-86-2	Acetophenone	ND	2.2	0.23	ug/l
120-12-7	Anthracene	ND	$1_{2}1$	0.23	ug/l
1912-24-9	Atrazine	ND	2.2	0.50	ug/l
100-52-7	Benzaldehyde	ND	5.6	0.32	ug/l
56-55-3	Benzo(a)anthracene	ND	1.1	0.23	ug/l
50-32-8	Benzo(a)pyrene	ND	1.1	0.24	ug/l
205-99-2	Benzo(b) fluoranthene	ND	1.1	0.23	ug/l
191-24-2	Benzo(g,h,i)perylene	ND	1.1	0.38	ug/l
207-08-9	Benzo(k)fluoranthene	ND	1.1	0.23	ug/l
101-55-3	4-Bromophenyl phenyl ether	ND	2.2	0.45	ug/l
85-68-7	Butyl benzyl phthalate	ND	2.2	0.51	ug/l
92-52-4	1,1'-Biphenyl	ND	1.1	0.24	ug/l
91-58-7	2-Chloronaphthalene	ND	2.2	0.26	ug/l
106-47-8	4-Chloroaniline	ND	5.6	0.38	ug/l
86-74-8	Carbazole	ND	1.1	0.25	ug/l
					_



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Method:

Project:

Page 2 of 3

Report of Analysis

Client Sample ID:	RA1-GWD
Lab Sample ID:	JC20660-3
Matrix:	AQ - Ground

AQ - Ground Water

SW846 8270D SW846 3510C BMSMC, Building 5 Area, PR

Date Sampled: 05/18/16 Date Received: Percent Solids:

05/20/16

ABN TCL Special List

CAS No.	Compound	Result	RL	MDL	Units	Q
105-60-2	Caprolactam	ND	2.2	0.72	ug/l	
218-01-9	Chrysene	ND	1.1	0.20	ug/l	
111-91-1	bis(2-Chloroethoxy)methane	ND	2.2	0.31	ug/l	
111-44-4	bis(2-Chloroethyl)ether	ND	2.2	0.28	ug/l	
108-60-1	bis(2-Chloroisopropyl)ether	ND	2.2	0.45	ug/l	
7005-72-3	4-Chlorophenyl phenyl ether	ND	2.2	0.41	ug/l	
121-14-2	2,4-Dinitrotoluene	ND	1.1	0.61	ug/l	
606-20-2	2,6-Dinitrotoluene	ND	1.1	0.53	ug/I	
91-94-1	3,3'-Dichlorobenzidine	ND	2.2	0.56	ug/l	
123-91-1	1,4-Dioxane	7.9	1.1	0.73	ug/l	
53-70-3	Dibenzo(a,h)anthracene	ND	1.1	0.37	ug/l	
132-64-9	Dibenzofuran	ND	5.6	0.24	ug/l	
84-74-2	Di-n-butyl phthalate	ND	2.2	0.55	ug/l	
117-84-0	Di-n-octyl phthalate	ND	2.2	0.26	ug/l	
84-66-2	Diethyl phthalate	ND	2.2	0.29	ug/l	
131-11-3	Dimethyl phthalate	ND	2.2	0.24	ug/l	
117-81-7	bis(2-Ethylhexyl)phthalate	ND	2.2	1.8	ug/l	
206-44-0	Fluoranthene	ND	1.1	0.19	ug/l	
86-73-7	Fluorene	ND	1.1	0.19	ug/l	
118-74-1	Hexachlorobenzene	ND	1.1	0.36	ug/l	
87-68-3	Hexachlorobutadiene	ND	1.1	0.55	ug/l	
77-47-4	Hexachlorocyclopentadiene	ND	11	3.1	ug/l	
67-72-1	Hexachloroethane	ND	2.2	0.43	ug/l	
193-39-5	Indeno(1,2,3-cd)pyrene	ND	1.1	0.37	ug/l	
78-59-1	Isophorone	ND	2.2	0.31	ug/l	
90-12-0	1-Methylnaphthalene	ND	1.1	0.29	ug/l	
91-57-6	2-Methylnaphthalene	ND	1.1	0.23	ug/l	
88-74-4	2-Nitroaniline	ND	5.6	0.31	սց/1	
99-09-2	3-Nitroaniline	ND	5.6	0.43	ug/l	
100-01-6	4-Nitroaniline	ND	5.6	0.49	ug/l	
98-95-3	Nitrobenzene	ND	2.2	0.71	ug/l	
621-64-7	N-Nitroso-di-n-propylamine	ND	2.2	0.53	ug/l	
86-30-6	N-Nitrosodiphenylamine	ND	5.6	0.25	ug/l	
85-01-8	Phenanthrene	ND	1.1	0.19	ug/l	- /.
129-00-0	Pyrene	ND	1.1	0.24	ug/l	100
95-94-3	1,2,4,5-Tetrachlorobenzene	ND	2.2	0.41	ug/l	15
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Lim	its	\

afael Infante Méndez LIC # 1888

367-12-4

25%

2-Fluorophenol

14-88%

ND = Not detected

 $MDL = Method\ Detection\ Limit$

RL = Reporting Limit

E - Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

Report of Analysis

Client Sample ID: RA1-GWD Lab Sample ID: JC20660-3

AQ - Ground Water

SW846 8270D SW846 3510C

Date Sampled: 05/18/16
Date Received: 05/20/16
Percent Solids: n/a

Method: Project:

Matrix:

BMSMC, Building 5 Area, PR

ABN TCL Special List

CAS No.	Surrogate Recoveries	Run#1	Run# 2	Limits
4165-62-2	Phenol-d5	18%		10-110%
118-79-6	2,4,6-Tribromophenol	50%		39-149%
4165-60-0	Nitrobenzene-d5	42%		32-128%
321-60-8	2-Fluorobiphenyl	50%		35-119%
1718-51-0	Terphenyl-d14	44%		10-126%



E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

Report of Analysis

Page 1 of 1

Client Sample ID: **RA1-GWD** Lab Sample ID: JC20660-3

Matrix:

Method: Project:

AQ - Ground Water

SW846 8270D BY SIM SW846 3510C BMSMC, Building 5 Area, PR

Date Sampled: 05/18/16 Date Received: 05/20/16

Q

Percent Solida:

File ID DF Analyzed By Prep Date Prep Batch **Analytical Batch** Run #1 3M61533.D 1 05/22/16 05/20/16 LK OP94071A E3M2897 Run #2

Initial Volume Final Volume Run #1 900 ml 1.0 ml

Run #2

CAS No. Compound Result RL MDL Units 91-20-3 Naphthalene ND 0.11 0.033ug/l CAS No. Surrogate Recoveries Run#1 Run# 2 Limits 4165-60-0 Nitrobenzene-d5 50% 24-125% 321-60-8 2-Fluorobiphenyl 58% 19-127% 1718-51-0 Terphenyl-d14 55% 10-119%



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Report of Analysis

Ву

XPL

n/a

Page 1 of 1

Client Sample ID: RA1-GWD Lab Sample ID:

JC20660-3

Date Sampled: Date Received:

05/18/16 05/20/16

Matrix: Method: AQ - Ground Water SW846-8015C (DAI)

Percent Solids: n/a

Project:

BMSMC, Building 5 Area, PR

Prep Batch **Analytical Batch**

File ID DF Analyzed Run #1 GH105149.D 05/20/16

Prep Date GGH5294 n/a

Run #2

Low Molecular Alcohol List

CAS No.	Compound	Result	RL	MDI	Units	Q
64-17-5	Ethanol	ND	100	55	ug/l	
78-83 -1	Isobutyl Alcohol	ND	100	36	ug/l	
67-63-0	Isopropyl Alcohol	ND	100	68	ug/l	
71-23-8	n-Propyl Alcohol	ND	100	43	ug/l	
71-36-3	n-Butyl Alcohol	ND	100	87	ug/l	
78-92-2	sec-Butyl Alcohol	ND	100	66	ug/l	
67-56-1	Methanol	ND	200	71	սց/1	
CAS No.	Surrogate Recoveries	Run#1	Run# 2	L	imits	
111-27-3	Hexanol	94%		56	6-145%	
111-27-3	Hexanol	99%		56	6-145%	



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Report of Analysis

Ву

SB

05/27/16

Prep Date

05/24/16

Page 1 of 3

Client Sample ID:	RA1 (11-12)
Lab Sample ID:	JC20660-4

2M84213.D

Matrix: Method: SO - Soil

SW846 8270D SW846 3546

Date Sampled: Date Received:

Q

05/19/16 05/20/16

Percent Solids: 78.8

Project: BMSMC, Building 5 Area, PR

File ID DF Analyzed

Prep Batch **Analytical Batch** OP94191 E2M3705

Run #1 Run #2

> Initial Weight Final Volume 30.5 g

Run #1 Run #2

1.0 ml

ABN TCL Special List

CAS No.	Compound	Result	RL	MDL	Units	
95-57-8	2-Chlorophenol	ND	83	21	ug/kg	
59-50-7	4-Chloro-3-methyl phenol	ND	210	26	ug/kg	
120-83-2	2,4-Dichlorophenol	ND	210	35	ug/kg	
105-67-9	2,4-Dimethylphenol	ND	210	74	ug/kg	
51-28-5	2,4-Dinitrophenol	ND	210	160	ug/kg	
534-52-1	4,6-Dinitro-o-cresol	ND	210	45	ug/kg	
95-48-7	2-Methylphenol	ND	83	27	ug/kg	
	3&4-Methylphenol	ND	83	34	ug/kg	
88-75-5	2-Nitrophenol	ND	210	28	ug/kg	
100-02-7	4-Nitrophenol	ND	420	110	ug/kg	
87-86-5	Pentachlorophenol	ND	210	39	ug/kg	
108-95-2	Phenol	ND	83	22	ug/kg	
58-90-2	2,3,4,6-Tetrachlorophenol	ND	210	28	ug/kg	
95-95-4	2,4,5-Trichlorophenol	ND	210	31	ug/kg	
88-06-2	2,4,6-Trichlorophenol	ND	210	25	ug/kg	
83-32-9	Acenaphthene	ND	42	14	ug/kg	
208-96-8	Acenaphthylene	ND	42	21	ug/kg	
98-86-2	Acetophenone	ND	210	8.9	ug/kg	
120-12-7	Anthracene	ND	42	26	ug/kg	
1912-24-9	Atrazine	ND	83	18	ug/kg	
56-55-3	Benzo(a) anthracene	ND	42	12	ug/kg	
50-32-8	Benzo(a)pyrene	ND	42	19	ug/kg	
205-99-2	Benzo(b) fluoranthene	ND	42	18	ug/kg	
191-24-2	Benzo(g,h,i)perylene	ND	42	21	ug/kg	
207-08-9	Benzo(k)fluoranthene	ND	42	19	ug/kg	
101-55-3	4-Bromophenyl phenyl ether	ND	83	16	ug/kg	
85-68-7	Butyl benzyl phthalate	ND	83	10	ug/kg	
92-52-4	1,1'-Biphenyl	ND	83	5.7	ug/kg	
100-52-7	Benzaldehyde	ND	210	10	ug/kg	
91-58-7	2-Chloronaphthalene	ND	83	9,9	ug/kg	
106-47-8	4-Chloroaniline	ND	210	15	ug/kg	
86-74-8	Carbazole	ND	83	6.0	ug/kg	



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Report of Analysis

Client Sample ID: RAI (11-12) Lab Sample ID: JC20660-4

Matrix: SO - Soil

Method: SW846 8270D SW846 3546 Project: BMSMC, Building 5 Area, PR

05/19/16 Date Sampled: Date Received: 05/20/16

Percent Solids: 78.8

Q

ABN TCL Special List

CAS No.	Compound	Result	RL	MDL	Units	
105-60-2	Caprolactam	ND	83	16	ug/kg	
218-01-9	Chrysene	ND	42	13	ug/kg	
111-91-1	bis(2-Chloroethoxy)methane	ND	83	8.9	ug/kg	
111-44-4	bis(2-Chloroethyl)ether	ND	83	18	ug/kg	
108-60-1	his(2-Chloroisopropyl)ether	ND	83	15	ug/kg	
7005-72-3	4-Chlorophenyl phenyl ether	ND	83	13	ug/kg	
121-14-2	2,4-Dinitrotoluene	ND	42	13	ug/kg	
606-20-2	2,6-Dinitrotoluene	ND	42	21	ug/kg	
91-94-1	3,3'-Dichlorobenzidine	ND	83	35	ug/kg	
53-70-3	Dibenzo(a,h)anthracene	ND	42	18	ug/kg	
132-64-9	Dibenzofuran	ND	83	17	ug/kg	
84-74-2	Di-n-butyl phthalate	ND	83	6.8	ug/kg	
117-84-0	Di-n-octyl phthalate	ND	83	10	ug/kg	
84-66-2	Diethyl phthalate	ND	83	8.9	ug/kg	
131-11-3	Dimethyl phthalate	ND	83	7.4	ug/kg	
117-81-7	bis(2-Ethylhexyl)phthalate	ND	83	9.7	ug/kg	
206-44-0	Fluoranthene	ND	42	19	ug/kg	
86-73-7	Fluorene	ND	42	19	ug/kg	
118-74-1	Hexachlorobenzene	ND	83	11	ug/kg	
87-68-3	Hexachlorobutadiene	ND	42	17	ug/kg	
77-47-4	Hexachlorocyclopentadiene	ND	420	17	ug/kg	
67-72-1	Hexachloroethane	ND	210	21	ug/kg	
193-39-5	Indeno(1,2,3-cd)pyrene	ND	42	20	ug/kg	
78-59-1	Isophorone	ND	83	8.9	ug/kg	
90-12-0	1-Methylnaphthalene	ND	83	8.2	ug/kg	
91-57-6	2-Methylnaphthalene	ND	83	9.4	ug/kg	
88-74-4	2-Nitroaniline	ND	210	9.8	ug/kg	
99-09-2	3-Nitroaniline	ND	210	10	ug/kg	
100-01-6	4-Nitroaniline	ND	210	11	ug/kg	
98-95-3	Nitrobenzene	ND	83	16	ug/kg	
621-64-7	N-Nitroso-di-n-propylamine	ND	83	12	ug/kg	
86-30-6	N-Nitrosodiphenylamine	ND	210	15	ug/kg	
85-01-8	Phenanthrene	ND	42	14	ug/kg	
129-00-0	Pyrene	ND	42	13	ug/kg	
95-94-3	1,2,4,5-Tetrachlorobenzene	ND	210	11	ug/kg	
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Lim	its	
367-12-4	2-Fluorophenol	73%		30-1	06%	
4165-62-2	Phenol-d5	73%		30-106%		



ND = Not detected MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Method:

Project:

Report of Analysis

Client Sample ID: RA1 (11-12) Lab Sample ID: JC20660-4 Matrix:

SO - Soil

SW846 8270D SW846 3546 BMSMC, Building 5 Area, PR

05/19/16 Date Sampled: Date Received: 05/20/16

Percent Solids: 78.8

ABN TCL Special List

CAS No.	Surrogate Recoveries	Run# 1	Run# 2	Limits
118-79-6	2,4,6-Tribromophenol	70%		24-140%
4165-60-D	Nitrobenzene-d5	73%		26-122%
321-60-8	2-Fluorobiphenyl	76%		36-112%
1718-51-0	Terphenyl-d14	83%		36-132%



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

1718-51-0

Terphenyl-d14

Report of Analysis

Page 1 of 1

						_				
Client Sample ID: RA1 (11-12) Lab Sample ID: JC20660-4 Matrix: SO - Soil Method: SW846 8270D BY Project: BMSMC, Building							Date Sampled: 05/19/16 Date Received: 05/20/16 Date Received: 78.8			
Run #1 ² Run #2	File ID 4M65742.D	DF 1	Analyzed 06/04/16	By LK	Prep D 05/24/1		Prep Batch OP94191A	Analytical Batch E4M2949		
Run #1 Run #2	Initial Weight 30.5 g	Final Vo	olume							
CAS No.	Compound		Result	RL	MDL	Units	Q	-		
123-91-1 91-20-3	1,4-Dioxane ^h Naphthalene		ND 12.6	4.2 4.2	0.84 0.51	ug/kg ug/kg	В			
CAS No.	Surrogate Rec	coveries	Run#1	Run# 2	Lim	its				
4165-60-0 321-60-8	Nitrobenzene-c 2-Fluorobipher		77% 100%			38% 48%				

(a) Method Blank had been contaminated. There is no sample left to reextract for confirmation.

86%

(b) Not accredited for this compound at the time of analysis, but all method requirements were followed.



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

10-157%

B = Indicates analyte found in associated method blank



Report of Analysis

By

XPL

Prep Date

n/a

Page 1 of 1

Client Sample ID: Lab Sample ID: Matrix:

RA1 (11-12) JC20660-4

SO - Soil

Date Sampled: 05/19/16 Date Received: 05/20/16

Method:

SW846-8015C (DAI)

DF

Percent Solids:

Project:

BMSMC, Building 5 Area, PR

Analyzed

05/23/16

Prep Batch **Analytical Batch** n/a GGH5295

Run #1 Run #2

Initial Weight

File ID

Run #1 Run #2

5.1 g

GH105162.D

Low Molecular Alcohol List

CAS No.	Compound	Result	RL	MDL	Units	Q
64-17-5	Ethanol	ND	120	86	ug/kg	
78-83-1	Isobutyl Alcohol	ND	120	73	ug/kg	
67-63-0	Isopropyl Alcohol	ND	120	71	ug/kg	
71-23-8	n-Propyl Alcohol	ND	120	50	ug/kg	
71-36-3	n-Butyl Alcohol	ND	120	68	ug/kg	
78-92-2	sec-Butyl Alcohol	ND	120	66	ug/kg	
67-56-1	Methanol	ND	250	60	ug/kg	
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Limits		
111-27-3	Hexanol	77%		52-1	41%	
111-27-3	Hexanol	85%		52-1	41%	



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

Report of Analysis

Page 1 of 3

Client Sample ID:	RA2 (10-11)
Lab Sample ID:	JC20660-5

Matrix: Method: SO - Soil

SW846 8270D SW846 3546

Date Sampled:

05/19/16 Date Received: 05/20/16

Project:

BMSMC, Building 5 Area, PR

Percent Solids: 80.0

	File ID	DF	Analyzed	Ву	Prep Date	Prep Batch	Analytical Batch
Run #1	2M84214.D	1	05/27/16	SB	05/24/16	OP94191	E2M3705

Run #2

Initial Weight Final Volume 30.1 g

Run #1

1.0 ml

Run #2

ABN TCL Special List

CAS No.	Compound	Compound Result RL		MDL	Units	Q
95-57-8	2-Chlorophenol	ND	83	21	ug/kg	
59-5 0- 7	4-Chloro-3-methyl phenol	ND	210	25	ug/kg	
120-83-2	2,4-Dichlorophenol	ND	210	35	ug/kg	
105-67-9	2,4-Dimethylphenol	ND	210	74	ug/kg	
51-28-5	2,4-Dinitrophenol	ND	210	160	ug/kg	
534-52-1	4,6-Dinitro-o-cresol	ND	210	44	ug/kg	
95-48-7	2-Methylphenol	ND	83	27	ug/kg	
	3&4-Methylphenol	ND	83	34	ug/kg	
88-75-5	2-Nitrophenol	ND	210	27	ug/kg	
100-02-7	4-Nitrophenol	ND	420	110	ug/kg	
87-86-5	Pentachlorophenol	ND	210	39	ug/kg	
108-95-2	Phenol	ND	83	22	ug/kg	
58-90-2	2,3,4,6-Tetrachlorophenol	ND	210	27	ug/kg	
95-95-4	2,4,5-Trichlorophenol	ND	210	31	ug/kg	
88-06-2	2,4,6-Trichlorophenol	ND	210	25	ug/kg	
83-32-9	Acenaphthene	ND	42	14	ug/kg	
208-96-8	Acenaphthylene	ND	42	21	ug/kg	
98-86-2	Acetophenone	ND	210	8.9	ug/kg	
120-12-7	Anthracene	ND	42	25	ug/kg	
1912-24-9	Atrazine	ND	83	18	ug/kg	
56-55-3	Benzo(a)anthracene	ND	42	12	ug/kg	
50-32-8	Benzo(a)pyrene	ND	42	19	ug/kg	
205-99-2	Benzo(b)fluoranthene	ND	42	18	ug/kg	
191-24-2	Benzo(g,h,i)perylene	ND	42	21	ug/kg	
207-08-9	Benzo(k)fluoranthene	ND	42	19	ug/kg	1
101-55-3	4-Bromophenyl phenyl ether	ND	83	16	ug/kg	
85-68-7	Butyl benzyl phthalate	ND	83	10	ug/kg	
92-52-4	1,1*-Biphenyl	ND	83	5.7	ug/kg	1
100-52-7	Benzaldehyde	ND	210	10	ug/kg	
91-58-7	2-Chloronaphthalene	ND	83	9,9	ug/kg	
106-47-8	4-Chloroaniline	ND	210	15	ug/kg	
86-74-8	Carbazole	ND	83	6.0	ug/kg	



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Method:

Project:

Report of Analysis

Client Sample ID: RA2 (10-11) Lab Sample ID: JC20660-5 Matrix:

SO - Soil SW846 8270D SW846 3546

BMSMC, Building 5 Area, PR

Date Sampled: 05/19/16 Date Received: 05/20/16 Percent Solids: 80.0

ABN TCL Special List

CAS No.	Compound	Result	RL	MDL	Units	Q
105-60-2	Caprolactam ND 83 1			16	ug/kg	
218-01-9	Chrysene	ND	42	13	ug/kg	
111-91-1	bis(2-Chloroethoxy)methane	ND	83	8.9	ug/kg	
111-44-4	bis (2-Chloroethyl) ether	ND	83	18	ug/kg	
108-60-1	bis(2-Chloroisopropyl)ether	ND	83	15	ug/kg	
7005-72-3	4-Chlorophenyl phenyl ether	ND	83	13	ug/kg	
121-14-2	2,4-Dinitrotoluene	ND	42	13	ug/kg	
606-20-2	2,6-Dinitrotoluene	ND	42	21	ug/kg	
91-94-1	3,3'-Dichlorobenzidine	ND	83	35	ug/kg	
53-70-3	Dibenzo (a,h) anthracene	ND	42	18	ug/kg	
132-64-9	Dibenzofuran	ND	83	17	ug/kg	
84-74-2	Di-n-butyl phthalate	ND	83	6.8	ug/kg	
117-84-0	Di-n-octyl phthalate	ND	83	10	ug/kg	
84-66-2	Diethyl phthalate	ND	83	8.8	ug/kg	
131-11-3	Dimethyl phthalate	ND	83	7.4	ug/kg	
117-81-7	bis(2-Ethylhexyl)phthalate	ND	83	9.7	ug/kg	
206-44-0	Fluoranthene	ND	42	19	ug/kg	
86-73-7	Fluorene	ND	42	19	ug/kg	
118-74-1	Hexachlorobenzene	ND	83	11	ug/kg	
87-68-3	Hexachlorobutadiene	ND	42	17	ug/kg	
77-47-4	Hexachlorocyclopentadiene	ND	420	17	ug/kg	
67-72-1	Hexachloroethane	ND	210	21	ug/kg	
193-39-5	Indeno(1,2,3-cd)pyrene	ND	42	19	ug/kg	
78-59-1	Isophorone	ND	83	8.9	ug/kg	
90-12-0	1-Methylnaphthalene	ND	83	8.1	ug/kg	
91-57-6	2-Methylnaphthalene	ND	83	9.4	ug/kg	
88-74-4	2-Nitroaniline	ND	210	9.8	ug/kg	
99-09-2	3-Nitroaniline	ND	210	10	ug/kg	
100-01-6	4-Nitroaniline	ND	210	11	ug/kg	
98-95-3	Nitrobenzene	ND	83	16	ug/kg	
621-64-7	N-Nitroso-di-n-propylamine	NĐ	83	12	ug/kg	
86-30-6	N-Nitrosodiphenylamine	ND	210	15	ug/kg	
85-01-8	Phenanthrene	ND	42	14	ug/kg	
129-00-0	Pyrene	ND	42	13	ug/kg	
95-94-3	1,2,4,5-Tetrachlorobenzene	ND	210	11	ug/kg	
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Limi	is	
367-12-4	2-Fluorophenol	77%		30-11	06%	
4165-62-2	Phenol-d5	80%		30-11	06%	



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank





Method:

Project:

Report of Analysis

Page 3 of 3

Client Sample ID: RA2 (10-11) Lab Sample ID: JC20660-5

Matrix: SO -

SO - Soil SW846 8270D SW846 3546 BMSMC, Building 5 Area, PR Date Sampled: 05/19/16 Date Received: 05/20/16

Percent Solids: 80.0

ABN TCL Special List

CAS No.	Surrogate Recoveries	Run#1	Run# 2	Limits
118-79-6	2,4,6-Tribromophenol	92%		24-140%
4165-60-0	Nitrobenzene-d5	74%		26-122%
321-60-8	2-Fluorobiphenyl	79%		36-112%
1718-51-0	Terphenyl-d14	88%		36-132%



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Report of Analysis

Page 1 of 1

Client Sample I	D: RA2 (10-11)
Lab Sample ID:	JC20660-5
Matrix:	SO - Soil
Method:	SW846 8270D

File ID

4M65743.D

SW846 8270D BY SIM SW846 3546

Date Sampled: 05/19/16 Date Received: 05/20/16 Percent Solids: 80.0

Project: BMSMC, Building 5 Area, PR

DF

					}
Analyzed	Ву	Prep Date	Prep Batch	Analytical Batch	
06/04/16	LK	05/24/16	OP94191A	E4M2949	

Run #1 Run #2

Run #1 Run #2	Initial Weight 30.1 g	Final Volume 1.0 ml	c		-				
CAS No.	Compound		Result	RL	MDL	Units	0		

CAB INU.	Combound	Kesmr	KL	MUL	Units	Ų
123-91-1	1,4-Dioxane a	ND	4.2	0.83	ug/kg	
91-20-3	Naphthalene	ND	4.2	0.51	ug/kg	
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Lim	its	
4165-60-0	Nitrobenzene-d5	77%		15-1	38%	
321-60-8	2-Fluorobiphenyl	104%		12-1	48%	
1718-51-0	Terphenyl-d14	96%		10-1	57%	

(a) Not accredited for this compound at the time of analysis, but all method requirements were followed.



ND = Not detected

MDL = Method Detection Limit

J = Indicates an estimated value

RL = Reporting Limit

B = Indicates analyte found in associated method blank

E = Indicates value exceeds calibration range

N = Indicates presumptive evidence of a compound

Report of Analysis

Page 1 of 1

Client Sample ID: RA2 (10-11) Lab Sample ID: JC20660-5

Matrix: Method:

Project:

SO - Soil

SW846-8015C (DAI)

Date Sampled: Date Received:

05/19/16 05/20/16 Percent Solids: 80.0

BMSMC, Building 5 Area, PR

File ID DF Analyzed By Prep Date Prep Batch **Analytical Batch** Run #1 GH105163.D 1 05/23/16 XPL **GGH5295** n/a n/a Run #2

Initial Weight

Run #1 Run #2 5.1 g

Low Molecular Alcohol List

CAS No.	Compound	Result	RL	MDL	Units	Q
64-17-5	Ethanol	ND	120	85	ug/kg	
78-83-1	Isobutyl Alcohol	ND	120	72	ug/kg	
67-63-0	Isopropyl Alcohol	ND	120	70	ug/kg	
71-23-8	n-Propyl Alcohol	ND	120	49	ug/kg	
71-36-3	n-Butyl Alcohol	ND	120	67	ug/kg	
78-92-2	sec-Butyl Alcohol	ND	120	65	ug/kg	
67-56-1	Methanol	ND	250	59	ug/kg	
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Limi	its	
111-27-3	Hexanol	96%		52-1	41%	
111-27-3	Hexanol	96%		52-1	41%	
						_



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

Report of Analysis

Page 1 of 3

Client Sample ID:	RA2-GWS
Lab Sample ID:	JC20660-6

Matrix: Method:

Project:

AQ - Ground Water

SW846 8270D SW846 3510C

Date Sampled: 05/19/16 Date Received: 05/20/16

Percent Solids: n/a

Q

BMSMC, Building 5 Area, PR

File ID DF Analyzed By Prep Date Prep Batch **Analytical Batch** Run #1 6P26200.D SB 1 05/21/16 05/20/16 OP94071 E6P1221

Run #2

Initial Volume **Final Volume**

Run #1 Run #2

1.0 ml

ABN TCL Special List

900 ml

CAS No.	Compound	Result	RL,	MDL	Unit
95-57-8	2-Chlorophenol	ND	5.6	0.91	ug/l
59-5 0- 7	4-Chloro-3-methyl phenol	ND	5.6	0.99	ug/l
120-83-2	2,4-Dichlorophenol	ND	2.2	1.4	ug/l
105-67-9	2,4-Dimethylphenol	ND	5.6	2.7	ug/l
51-28-5	2,4-Dinitrophenol	ND	11	1.7	ug/l
534-52-1	4,6-Dinitro-o-cresol	ND	5.6	1.4	ug/l
95-48-7	2-Methylphenol	ND	2.2	0.99	ug/l
	3&4-Methylphenol	ND	2.2	0.98	ug/l
88-75-5	2-Nitrophenol	ND	5.6	1:1	ug/l
100-02-7	4-Nitrophenol	ND	11	1,3	ug/l
87-86-5	Pentachlorophenol	ND	5.6	1.5	ug/l
108-95-2	Phenol	ND	2.2	0.44	ug/l
58-90-2	2,3,4,6-Tetrachlorophenol	ND	5.6	1.6	ug/l
95-95-4	2,4,5-Trichlorophenol	ND	5.6	1,5	ug/l
88-06-2	2,4,6-Trichlorophenol	ND	5.6	1,0	ug/l
83-32-9	Acenaphthene	ND	1.1	0.21	ug/l
208-96-8	Acenaphthylene	ND	1.1	0.15	ug/l
98-86-2	Acetophenone	ND	2.2	0.23	ug/l
120-12-7	Anthracene	ND	1.1	0.23	ug/l
1912-24-9	Atrazine	ND	2.2	0.50	ug/l
100-52-7	Benzaldehyde	ND	5.6	0.32	ug/l
56-55-3	Benzo(a)anthracene	ND	1.1	0.23	ug/l
50-32-8	Benzo(a)pyrene	ND	1.1	0.24	ug/l
205-99-2	Benzo(b)fluoranthene	ND	1.1	0.23	ug/l
191-24-2	Benzo(g,h,i)perylene	ND	1.1	0.38	ug/l
207-08-9	Benzo(k)fluoranthene	ND	1.1	0.23	ug/l
101-55-3	4-Bromophenyl phenyl ether	ND	2.2	0.45	ug/l
85-68-7	Butyl benzyl phthalate	ND	2.2	0.51	ug/l
92-52-4	1,1'-Biphenyl	ND	1.1	0.24	ug/l
91-58-7	2-Chloronaphthalene	ND	2.2	0.26	ug/l
106-47-8	4-Chloroaniline	ND	5.6	0.38	ug/l
86-74-8	Carbazole	ND	T.T	0.25	ug/l
					-



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

Page 2 of 3

Report of Analysis

Client Sample ID: **RA2-GWS** Lab Sample ID: JC20660-6

Matrix: Method:

Project:

AQ - Ground Water

SW846 8270D SW846 3510C BMSMC, Building 5 Area, PR

Date Sampled: 05/19/16 Date Received: 05/20/16

Percent Solids: n/a

ABN TCL Special List

	•					
CAS No.	Compound	Result	RL	MDL	Units	Q
105-60-2	Caprolactam	ND	2.2	0.72	ug/l	
218-01-9	Chrysene	ND	1.1	0.20	ug/l	
111-91-1	bis(2-Chloroethoxy)methane	ND	2.2	0.31	ug/l	
111-44-4	bis(2-Chloroethyl)ether	ND	2.2	0.28	ug/l	
108-60-1	bis(2-Chloroisopropyl)ether	ND	2.2	0.45	ug/l	
7005-72-3	4-Chlorophenyl phenyl ether	ND	2.2	0.41	ug/l	
121-14-2	2,4-Dinitrotoluene	ND	1.1	0.61	ug/l	
606-20-2	2,6-Dinitrotoluene	ND	1.1	0.53	ug/l	
91-94-1	3,3'-Dichlorobenzidine	ND	2.2	0.56	ug/l	
53-70-3	Dibenzo(a,h)anthracene	ND	1.1	0.37	ug/l	
132-64-9	Dibenzofuran	ND	5.6	0.24	ug/l	
84-74-2	Di-n-butyl phthalate	ND	2.2	0.55	ug/l	
117-84-0	Di-n-octyl phthalate	ND	2.2	0.26	ug/l	
84-66-2	Diethyl phthalate	ND	2.2	0.29	ug/l	
131-11-3	Dimethyl phthalate	ND	2.2	0.24	ug/l	
117-81-7	bis(2-Ethylhexyl)phthalate	ND	2.2	1.8	ug/l	
206-44-0	Fluoranthene	ND	1.1	0.19	ug/l	
86-73-7	Fluorene	ND	1:1	0.19	ug/l	
118-74-1	Hexachlorobenzene	ND	1.1	0.36	ug/l	
87-68-3	Hexachlorobutadiene	ND	1.1	0.55	ug/l	
77-47-4	Hexachlorocyclopentadiene	ND	11	3.1	ug/l	
67-72-1	Hexachloroethane	ND	2.2	0.43	ug/l	
193-39-5	Indeno(1,2,3-cd)pyrene	ND	1.1	0.37	ug/l	
78-59-1	Isophorone	ND	2.2	0.31	ug/l	
90-12-0	1-Methylnaphthalene	ND	1.1	0.29	ug/l	
91-57-6	2-Methylnaphthalene	ND	1.1	0.23	ug/l	
88-74-4	2-Nitroaniline	ND	5.6	0.31	ug/l	
99-09-2	3-Nitroaniline	ND	5.6	0.43	ug/l	
100-01-6	4-Nitroaniline	ND	5.6	0.49	ug/l	
98-95-3	Nitrobenzene	ND	2.2	0.71	ug/l	
621-64-7	N-Nitroso-di-n-propylamine	ND	2.2	0.53	ug/l	
86-30-6	N-Nitrosodiphenylamine	ND	5.6	0.25	ug/l	
85-01-8	Phenanthrene	ND	1.1	0.19	ug/l	
129-00-0	Pyrene	ND	1.1	0.24	ug/l	
95-94-3	1,2,4,5-Tetrachlorobenzene	ND	2.2	0.41	ug/l	
CAS No.	Surrogate Recoveries	Run# 1	Run# 2	Limit	8	
367-12-4	2-Fluorophenol	30%		14-88	%	
4165-62-2	Phenol-d5	22%		10-11	0%	





ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

Client Sample ID: **RA2-GWS** Lab Sample ID: JC20660-6 Matrix:

AQ - Ground Water

Date Sampled: Date Received:

05/19/16 05/20/16

Method: Project:

SW846 8270D SW846 3510C BMSMC, Building 5 Area, PR

Percent Solids: n/a

ABN TCL Special List

CAS No.	Surrogate Recoveries	Run# 1	Run# 2	Limits
118-79-6	2,4,6-Tribromophenol	54%		39-149%
4165-60-0	Nitrobenzene-d5	50%		32-128%
321-60-8	2-Fluorobiphenyl	56%		35-119%
1718-51-0	Terphenyl-d14	46%		10-126%



ND = Not detected

 $MDL = Method \ Detection \ Limit$

RL = Reporting Limit

E = Indicates value exceeds calibration range

] = Indicates an estimated value

B = Indicates analyte found in associated method blank

Report of Analysis

Page 1 of 1

Client Sample ID:	RA2-GWS
Lab Sample ID:	JC20660-6

Matrix: Method: AQ - Ground Water

Date Sampled: 05/19/16 Date Received: 05/20/16

Percent Solids: n/a

Q

Project:

SW846 8270D BY SIM SW846 3510C BMSMC, Building 5 Area, PR

File ID DF Analyzed Ву Prep Date Prep Batch **Analytical Batch** 3M61534.D 05/22/16 LK 05/20/16 1 OP94071A E3M2897

Run #1 Run #2

Initial Volume **Final Volume** Run #1 900 ml

Run #2

1.0 ml

CAS No.	Compound	Result	RL	MDL	Units
91-20-3 123-91-1	Naphthalene I,4-Dioxane	ND 2.43	0.11 0.11	0.033 0.054	ug/l ug/l
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Lim	its
4165-60-0 321-60-8 1718-51-0	Nitrobenzene-d5 2-Fluorobiphenyl Terphenyl-d14	57% 63% 56%		19-1	25% 27% 19%



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

Report of Analysis

Page 1 of 1

Client Sample ID: **RA2-GWS** Lab Sample ID: JC20660-6

Matrix: Method:

Project:

AQ - Ground Water SW846-8015C (DAI)

BMSMC, Building 5 Area, PR

Date Sampled: 05/19/16 Date Received: 05/20/16

Percent Solids: n/a

	File ID	DF	Analyzed	By	Prep Date	Prep Batch	Analytical Batch
Run #1	GH105150.D	1	05/20/16	XPL	n/a	n/a	GGH5294
Run #2							

Low Molecular Alcohol List

CAS No.	Compound	Result	RL	MDL	Units	Q
64-17-5	Ethanol	ND	100	55	ug/l	
78-83-1	Isobutyl Alcohol	ND	100	36	ug/l	
67-63-0	Isopropyl Alcohol	ND	100	68	ug/l	
71-23-8	n-Propyl Alcohol	NĐ	100	43	ug/l	
71-36-3	n-Butyl Alcohol	ND	100	87	ug/l	
78-92-2	sec-Butyl Alcohol	ND	100	66	ug/l	
67-56-1	Methanol	ND	200	71	ug/l	
CAS No.	Surrogate Recoveries	Run#1	Run# 2	Lim	its	
111-27-3	Hexanol	92%		56-1	45%	
111-27-3	Hexanol	97%		56-1	45%	



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

N = Indicates presumptive evidence of a compound

Report of Analysis

Page 1 of 1

Client Sample ID: Lab Sample ID:

RA2-GWS JC20660-6

Matrix:

AQ - Ground Water

Method:

SW846 8081B SW846 3510C

Project:

BMSMC, Building 5 Area, PR

Date Sampled: Date Received:

Q

05/19/16 05/20/16

Percent Solids: n/a

tel cells Dollars, 1911

Run #1 Run #2

Run #1

File ID 6G35344.D DF 1 Analyzed 05/22/16
 By
 Prep Date

 RK
 05/21/16

Prep Batch OP94129 Analytical Batch G6G1016

FZ_____

Initial Volume 990 ml

Final Volume

Run #2

10.0 ml

Pesticide TCL List

CAS No.	Compound	Result	RL	MDL	Units
309-00-2	Aldrin	ND	0.010	0.0061	ug/l
319-84-6	alpha-BHC	ND	0.010	0.0061	ug/l
319-85-7	beta-BHC	ND	0.010	0.0057	ug/l
319-86-8	delta-BHC	ND	0.010	0.0046	ug/l
58-89-9	gamma-BHC (Lindane)	ND	0.010	0.0028	ug/l
5103-71-9	alpha-Chlordane	ND	0.010	0.0047	ug/l
5103-74-2	gamma-Chlordane	ND	0.010	0.0046	ug/l
60-57-1	Dieldrin	ND	0.010	0.0036	ug/l
72-54-8	4,4*-DDD	ND	0.010	0.0038	ug/l
72-55-9	4,4'-DDE	ND	0.010	0.0062	ug/l
50-29-3	4,4'-DDT	ND	0.010	0.0050	ug/l
72-20-8	Endrin	ND	0.010	0.0051	ug/l
1031-07-8	Endosulfan sulfate	ND	0.010	0.0053	ug/l
7421-93-4	Endrin aldehyde	ND	0.010	0.0052	ug/l
53494-70-5	Endrin ketone	ND	0.010	0.0051	ug/l
959-98-8	Endosulfan-I	ND	0.010	0.0050	ug/l
33213-65-9	Endosulfan-II	ND	0.010	0.0043	ug/l
76-44-8	Heptachlor	ND	0.010	0.0038	ug/l
1024-57-3	Heptachlor epoxide	ND	0.010	0.0066	ug/l
72-43-5	Methoxychlor	ND	0.020	0.0057	ug/l
8001-35-2	Toxaphene	ND	0.25	0.19	ug/l
CAS No.	Surrogate Recoveries	Run# 1	Run# 2	Limit	s
877-09-8	Tetrachloro-m-xylene	70%		26-13	2%
877-09-8	Tetrachloro-m-xylene	70%		26-13	2%
2051-24-3	Decachlorobiphenyl	37%		10-11	8%
2051-24-3	Decachlorobiphenyl	38%		10-11	8%



ND = Not detected

MDL = Method Detection Limit

RL = Reporting Limit

E = Indicates value exceeds calibration range

J = Indicates an estimated value

B = Indicates analyte found in associated method blank

	SGS	C	HAIN OF CUST			PAGE OF	
The second	2-5-20-20-20-20-20-20-20-20-20-20-20-20-20-	ACCUTEST - NJ	SUS Accident - Doyson 2235 Raute 130, Doyson, NJ 1088 737-329-0200 FAX: 732-329-34	F(# B)		The Critical Country II	
						3020660	
	Anderson Mulholland	Asicinc BMS Relea	ise Assessman	L	0	Matrix Crates	
	2700 Westchest	'er	OC PIBLES MO	THE RESERVE OF THE PARTY OF THE	E 25 2	DW - Drinking Water OW - Oround Water	
	Purchase NY		R Company Hame	net from Regard tas)	100 mm	WW-Water SW-Batton Water SO-Soil	
	TETTY TOYLOT	HUMACAO P	Street Address	90	P 2 3 0	SL- Slutge SED Sethment	
	94-25 -040	Came Purchase Order I	Cay	ද	3 5 63	DI - Ca LIQ - Other Liquid AIR - Air	
	TRIVERY Toylor, D.	Piprod Polyect Marragan	American	70 20	2 500	SCL - Other Solid WP - Wipe FIL-Flore Blank	
	1 1 1	-MNSKAW)		원	1 2 2 2	EB-Coupmon Stare RSI-Rosse Stare	
	rote Field ID / Point of Collection				है दिखें	TB-Trip Blance	
E	/ BPER- 76	τ,	100 rs ER 6 3	\$ \(\varepsilon \)	1923	LAB USE ONLY	
-	RAZ-GWD	1 - 1 - 1 - 1	00 TT EB 6 3		XXX	F53	
	KAI - GWL	05/18/16 16	30 TT GW 5				
-	RA2 (10-11) 05/19/16 110 05/19/16 114	10 TT 50 3	2 1 2 3	रे हि	++++ = = 7/	
-	6 RAZ-GWS	05/9/L 10	5 TT 6W 6 3	2 X	K X	140	
-	+		3				
-	 				 		
							
-	-			╏╏╏╏	+++-		
345	Tenturciand Time (Business mays)	To The State of th		 	╫╌╂╌╂╌╂╌╏		
	Marie 14 Business Days Foll Sai	CONTRACTOR STREET AND ADDRESS OF THE PARTY O	Communicial "A" (Layed		A A A A A A	Commence of the page of the page.	
	S Day RUSH 1 Day RUSH	INSTIAL ASSESSMENT 28/0	Communicative (Lovel)	MYASP Calegory 8	Add to Report: 1	-methyl paphthalene	
ĺ	Bion Rush For a great		Commence C	EDO Format	with svac N	lethed 8270D	
	methor		Continuous "A" - Plenuts Only, Co	ly Protect Reporting Workin' IS' > Results + DC Suremay			
216	1-1-2-1	Sample Custody must be do	AU Reduced a Reside - OC Sure commented below each little sample	stry + Parini Row date s change pogeomics, including couries	Sample inventory is varified o	pon receipt in the Laboratory	
1 Ps	merson	05719/161500 Fed 1	EX ,	Keles	57010	CAP V STEP WORK	
3 4	Anaphred by:	Onto Tiping: Passah and Shyl Dates Timer: Restation 6 for	4	Annual By:	2 (D) (O) 2	7/1/	
15		<u> </u>	33	7/352 8 =_	Property where opposite the		

JC20660: Chain of Custody Page 1 of 2

EXECUTIVE NARRATIVE

SDG No:

JC20660

Laboratory:

Accutest, New Jersey

Analysis:

SW846-8270D

Number of Samples:

6

Location:

BMSMC, Building 5 Area

Humacao, PR

SUMMARY:

Six (6) samples were analyzed for the ABN TCL list following method SW846-8270D; Naphthalene and 1,4-Dioxane were also analyzed by SW846-8270D using the selective ion monitoring (SIM) technique. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: EPA Hazardous Waste Support Section, SOP HW-35A, July 2015 –Revision 0. Semivolatile Data Validation. The QC criteria and data validation actions listed on the data review worksheets are from the primary guidance document, unless otherwise noted.

Results are valid and can be used for decision making purposes.

Critical issues:

None

Major:

None

Minor:

None

Critical findings:

None

Major findings:

None

Minor findings:

1. Initial and continuing calibration verifications meet the required criteria. Analytes not meeting the method % difference criteria meet the guidance document performance criteria for continuing calibration verification of \pm 25 or 40 %, no action taken. No closing calibration verification included in data package. No action taken, professional judgment.

GCMS5P used to analyze QC samples for this batch on 06/02/16 and GCMS3E used to analyze QC samples for this batch on 06/02-03/16. No qualification was performed on QC samples.

- 2. Naphthalene detected in the 06/03/16 method blank. The laboratory qualified naphthalene result in sample JC20660-4 as (B). Results further qualified as estimated (J) by the validator. Naphthalene was not detected in sample JC20660-5, no action taken.
- **3.** MSMSD % recovery outside control limits for several analytes in JC20784-1MS/MSD. No action taken, MS/MSD results apply to the unspiked sample. Unspiked sample was from another project.

MS/MSD % recoveries outside the lower control limits in sample JC20660-4MS/MSD. 1,4-dioxane not detected in sample JC20660-4. Non-detects are rejected (R).

No MS/MSD performed for aqueous samples analyzed by the SIM technique. No action taken, blank spike/blank spike duplicate used to assess accuracy. % recoveries within laboratory control limits. RPD was outside laboratory control limit. No qualifications made based on RPD, professional judgment.

COMMENTS:

Results are valid and can be used for decision making purposes.

Reviewers Name:

Rafael Infante

Chemist License 1888

Signature:

Date:

June 16, 2016

SAMPLE ORGANIC DATA SAMPLE SUMMARY

Sample ID: JC20660-1

Sample location: BMSMC Building 5 Area

Sampling date: 5/13/2016

Matrix: AQ - Equipment Blank

METHOD: 8270D

Analyte Name	Result	Units I	Dilution Factor	Lab Flag	Validation	Reportable
2-Chlorophenol	6.3	ug/l	1		U	Yes
4-Chloro-3-methyl phenol	6.3	ug/l	1	_	U	Yes
2,4-Dichlorophenol	2.5	ug/l	1	-	U	Yes
2,4-Dimethylphenol	6.3	ug/l	1	-	U	Yes
2,4-Dinitrophenol	13	ug/l	1	-	U	Yes
4,6-Dinitro-o-cresol	6.3	ug/l	1	-	U	Yes
2-Methylphenol	2.5	ug/l	1	-	U	Yes
3&4-Methylphenol	2.5	ug/i	1	-	U	Yes
2-Nitrophenol	6.3	ug/l	1	-	U	Yes
4-Nitrophenol	13	ug/l	1	-	U	Yes
Pentachlorophenol	6.3	ug/l	1	-	U	Yes
Phenol	2.5	ug/l	1	-	U	Yes
2,3,4,6-Tetrachlorophenol	6.3	ug/l	1	-	U	Yes
2,4,5-Trichlorophenol	6.3	ug/l	1	-	U	Yes
2,4,6-Trichlorophenol	6.3	ug/l	1	-	U	Yes
Acenaphthene	1.3	ug/l	1	-	U	Yes
Acenaphthylene	1.3	ug/l	1	-	U	Yes
Acetophenone	2.5	ug/l	1	-	U	Yes
Anthracene	1.3	ug/l	1	-	U	Yes
Atrazine	2.5	ug/l	1	-	U	Yes
Benzaldehyde	6.3	ug/l	1	-	U	Yes
Benzo(a)anthracene	1.3	ug/l	1	-	U	Yes
Benzo(a)pyrene	1.3	ug/l	1	-	U	Yes
Benzo(b)fluoranthene	1.3	ug/i	1	-	U	Yes
Benzo(g,h,i)perylene	1.3	ug/l	1	-	U	Yes
Benzo(k)fluoranthene	1.3	ug/l	1	-	U	Yes
4-Bromophenyl phenyl ether	1.3	ug/l	1	-	U	Yes
Butyl benzyl phthalate	2.5	ug/i	1	-	U	Yes
1,1'-Biphenyl	1.3	ug/l	1	-	U	Yes
2-Chloronaphthalene	2.5	ug/l	1	-	U	Yes
4-Chloroaniline	6.3	ug/l	1	-	U	Yes
Carbazole	1.3	ug/l	1	-	U	Yes
Caprolactam	2.5	ug/l	1	-	U	Yes
Chrysene	1.3	ug/l	1	-	U	Yes
bis(2-Chloroethoxy)methane	2.5	ug/l	1	-	U	Yes
bis(2-Chloroethyl)ether	2.5	ug/l	1	-	U	Yes

bis(2-Chloroisopropyl)ether	2.5	ug/l	1		U	Yes
4-Chlorophenyl phenyl ether	2.5	ug/l	1	-	U	Yes
2,4-Dinitrotoluene	1.3	ug/l	1	0_0	U	Yes
2,6-Dinitrotoluene	1.3	ug/l	1	-	U	Yes
3,3'-Dichlorobenzidine	2.5	ug/l	1	-	U	Yes
Dibenzo(a,h)anthracene	1.3	ug/l	1	-	U	Yes
Dibenzofuran	6.3	ug/l	1	1.00 C	U	Yes
Di-n-butyl phthalate	2.5	ug/l	1	-	U	Yes
Di-n-octyl phthalate	2.5	ug/l	1		U	Yes
Diethyl phthalate	2.5	ug/l	1	-	U	Yes
Dimethyl phthalate	2.5	ug/l	1	-	U	Yes
bis(2-Ethylhexyl)phthalate	2.5	ug/l	1	(*)	U	Yes
Fluoranthene	1.3	ug/l	1	-	U	Yes
Fluorene	1.3	ug/l	1	5 - 5	U	Yes
Hexachlorobenzene	1.3	ug/l	1	-	U	Yes
Hexachlorobutadiene	1.3	ug/l	1	-	U	Yes
Hexachlorocyclopentadiene	13	ug/l	1	-	U	Yes
Hexachloroethane	2.5	ug/l	1	77.0	U	Yes
Indeno(1,2,3-cd)pyrene	1.3	ug/l	1	-	U	Yes
Isophorone	2.5	ug/i	1	-	U	Yes
1-Methylnaphthalene	1.3	ug/l	1	-	U	Yes
2-Methylnaphthalene	1.3	ug/l	1	120	U	Yes
2-Nitroaniline	6.3	ug/l	1		U	Yes
3-Nitroaniline	6.3	ug/l	1	_	U	Yes
4-Nitroaniline	6.3	ug/i	1	-	U	Yes
Nitrobenzene	2.5	ug/l	1	17.4	U	Yes
N-Nitroso-di-n-propylamine	2.5	ug/l	1	-	U	Yes
Nitrosodiphenylamine	6.3	ug/l	1	-	U	Yes
Phenanthrene	1.3	ug/l	1	-	U	Yes
Pyrene	1.3	ug/l	1	-	U	Yes
1,2,4,5-Tetrachlorobenzene	2.5	ug/l	1		U	Yes
METHOD: 8	270D (SI	M)				
Naphthalene	0.13	ug/l	1		U	Yes
1,4-Dioxane	0.13	ug/l	1	127	U	Yes

ŷ.

. .

Sample location: BMSMC Building 5 Area

Sampling date: 5/18/2016 Matrix: Groundwater

WILTIOD.	32700					
Analyte Name	Result	Units	Dilution Factor	Lab Flag	Validation	Reportable
2-Chlorophenol	5.5	ug/l	1	-	U	Yes
4-Chloro-3-methyl phenol	5.5	ug/l	1	-	U	Yes
2,4-Dichlorophenol	2.2	ug/l	1	-	U	Yes
2,4-Dimethylphenol	5.5	ug/l	1	-	U	Yes
2,4-Dinitrophenol	11	ug/l	1	-	U	Yes
4,6-Dinitro-o-cresol	5.5	ug/l	1	-	U	Yes
2-Methylphenol	2.2	ug/l	1	-	U	Yes
3&4-Methylphenol	2.2	ug/l	1	-	U	Yes
2-Nitrophenol	5.5	ug/l	1	-	U	Yes
4-Nitrophenol	11	ug/l	1	-	U	Yes
Pentachlorophenol	5.5	ug/l	1	-	U	Yes
Phenol	2.2	ug/l	1	-	U	Yes
2,3,4,6-Tetrachlorophenol	5.5	ug/l	1	-	U	Yes
2,4,5-Trichlorophenol	5.5	ug/l	1	-	U	Yes
2,4,6-Trichlorophenol	5.5	ug/l	1	-	U	Yes
Acenaphthene	1.1	ug/l	1	-	U	Yes
Acenaphthylene	1.1	ug/l	1	-	U	Yes
Acetophenone	2.2	ug/l	1	-	Ų	Yes
Anthracene	1.1	ug/l	1	-	U	Yes
Atrazine	2.2	ug/l	1	-	U	Yes
Benzo(a)anthracene	1.1	ug/l	1	-	Ų	Yes
Benzo(a)pyrene	1.1	ug/l	1	-	U	Yes
Benzo(b)fluoranthene	1.1	ug/l	1	-	U	Yes
Benzo(g,h,i)perylene	1.1	ug/l	1	-	U	Yes
Benzo(k)fluoranthene	1.1	ug/l	1	-	U	Yes
4-Bromophenyl phenyl ether	2.2	ug/l	1	-	U	Yes
Butyl benzyl phthalate	2.2	ug/l	1	-	U	Yes
1,1'-Biphenyl	1.1	ug/l	1	-	U	Yes
Benzaldehyde	2.2	ug/l	1	-	U	Yes
2-Chloronaphthalene	5.5	ug/l	1	-	U	Yes
4-Chloroaniline	1.1	ug/l	1	-	U	Yes
Carbazole	5.5	ug/l	1	-	U	Yes
Caprolactam	2.2	ug/l	1	-	U	Yes
Chrysene	1.1	ug/l	1	-	U	Yes
bis(2-Chloroethoxy)methane	2.2	ug/l	1	-	U	Yes
bis(2-Chloroethyl)ether	2.2	ug/l	1	•	U	Yes
bis(2-Chloroisopropyl)ether	2.2	ug/l	1	-	U	Yes
4-Chlorophenyl phenyl ether	2.2	ug/l	1	-	U	Yes

2,4-Dinitrotoluene	1.1	ug/l	1		U	Yes
2,6-Dinitrotoluene	1.1	ug/l	1	75.1	U	Yes
3,3'-Dichlorobenzidine	2.2	ug/l	= 1	-	U	Yes
Dibenzo(a,h)anthracene	1.1	ug/l	1	-	U	Yes
Dibenzofuran	5.5	ug/l	1	_	U	Yes
Di-n-butyl phthalate	2.2	ug/l	1	-	U	Yes
Di-n-octyl phthalate	2.2	ug/l	1	-	U	Yes
Diethyl phthalate	2.2	ug/l	1	2	U	Yes
Dimethyl phthalate	2.2	ug/l	1	- 1	U	Yes
bis(2-Ethylhexyl)phthalate	2.2	ug/l	1	177	U	Yes
Fluoranthene	1.1	ug/l	1	-	U	Yes
Fluorene	1.1	ug/l	1	(*)	U	Yes
Hexachlorobenzene	1.1	ug/l	1	-	U	Yes
Hexachlorobutadiene	1.1	ug/l	1	12-	U	Yes
Hexachlorocyclopentadiene	11	ug/l	1	1.00	U	Yes
Hexachloroethane	2.2	ug/l	1	~	U	Yes
Indeno(1,2,3-cd)pyrene	1.1	ug/l	1	-	U	Yes
Isophorone	2.2	ug/l	1	15	U	Yes
1-Methylnaphthalene	1.1	ug/l	1	-	U	Yes
2-Methylnaphthalene	1.1	ug/l	1	9-00	U	Yes
2-Nitroaniline	5.5	ug/l	1	-	U	Yes
3-Nitroaniline	5.5	ug/l	1	54	U	Yes
4-Nitroaniline	5.5	ug/l	1	17	U	Yes
Nitrobenzene	2.2	ug/l	1	12	U	Yes
N-Nitroso-di-n-propylamine	2.2	ug/l	1	-	U	Yes
Nitrosodiphenylamine	5.5	ug/l	1	17	U	Yes
Phenanthrene	1.1	ug/l	1	-	U	Yes
Pyrene	1.1	ug/l	1	-	U	Yes
1,2,4,5-Tetrachlorobenzene	2.2	ug/l	1	-	U	Yes
METHOD:	9270D /SI	NA)				
WEITIOD:	627UD (31	ivi <i>j</i>				
Naphthalene	0.11	ug/l	1		U	Yes
1,4-Dioxane	3.48	ug/l	1	-	-	Yes

Sample location: BMSMC Building 5 Area

Sampling date: 5/18/2016 Matrix: Groundwater

IVIETHOD:						
Analyte Name	Result		Dilution Factor	Lab Flag		•
2-Chlorophenol	5.6	ug/l	1	-	U	Yes
4-Chloro-3-methyl phenol	5.6	ug/l	1	-	U	Yes
2,4-Dichlorophenol	2.2	ug/l	1	-	U	Yes
2,4-Dimethylphenol	5.6	ug/l	1	-	U	Yes
2,4-Dinitrophenol	11	ug/l	at 1	-	U	Yes
4,6-Dinitro-o-cresol	5.6	ug/l	1	-	U	Yes
2-Methylphenol	2.2	ug/l	1	-	U	Yes
3&4-Methylphenol	2.2	ug/l	1	-	U	Yes
2-Nitrophenol	5.6	ug/l	1	-	U	Yes
4-Nitrophenol	11	ug/l	1	-	U	Yes
Pentachlorophenol	5.6	ug/l	1	-	U	Yes
Phenol	2.2	ug/l	1	-	U	Yes
2,3,4,6-Tetrachlorophenol	5.6	ug/l	1	-	U	Yes
2,4,5-Trichlorophenol	5.6	ug/l	1	-	U	Yes
2,4,6-Trichlorophenol	5.6	ug/l	1	-	U	Yes
Acenaphthene	1.1	ug/l	1	- x	U	Yes
Acenaphthylene	1.1	ug/l	1	-	U	Yes
Acetophenone	2.2	ug/l	1	-	U	Yes
Anthracene	1.1	ug/l	1	-	U	Yes
Atrazine	2.2	ug/l	1	-	U	Yes
Benzaldehyde	1.1	ug/l	1	-	:: U	Yes
Benzo(a)anthracene	1.1	ug/l	1	-	U	Yes
Benzo(a)pyrene	1.1	ug/l	1	-	U	Yes
Benzo(b)fluoranthene	1.1	ug/l	1	-	U	Yes
Benzo(g,h,i)perylene	1.1	ug/l	1	-	U	Yes
Benzo(k)fluoranthene	2.2	ug/l	1	-	U	Yes
4-Bromophenyl phenyl ether	2.2	ug/l	1	-	U	Yes
Butyl benzyl phthalate	1.1	ug/l	1	-	IJ	Yes
1,1'-Biphenyl	2.2	ug/l	1	-	U	Yes
2-Chloronaphthalene	5.6	ug/l	1	-	U	Yes
4-Chloroaniline	1.1	ug/l	1	-	U	Yes
Carbazole	5.6	ug/l	1	-	U	Yes
Caprolactam	2.2	ug/l	1	-	U	Yes
Chrysene	1.1	ug/l	1	-	U	Yes
bis(2-Chloroethoxy)methane	2.2	ug/l	1	-	U	Yes
bis(2-Chloroethyl)ether	2.2	ug/l	1	-	U	Yes
bis(2-Chloroisopropyl)ether	2.2	ug/l	1	-	U	Yes
4-Chlorophenyl phenyl ether	2.2	ug/l	1	-	U	Yes

2,4-Dinitrotoluene	1.1	ug/l	1	-	U	Yes
2,6-Dinitrotoluene	1.1	ug/l	1		U	Yes
3,3'-Dichlorobenzidine	2.2	-	1	-5.	U	Yes
·		ug/l		-	U	
1,4-Dioxane	7.9	ug/l	1	100	-	Yes
Dibenzo(a,h)anthracene	1.1	ug/l	1	-	U	Yes
Dibenzofuran	5.6	ug/l	1	-	U	Yes
Di-n-butyl phthalate	2.2	ug/l	1	5.5	U	Yes
Di-n-octyl phthalate	2.2	ug/l	1	_	U	Yes
Diethyl phthalate	2.2	ug/l	1	-	U	Yes
Dimethyl phthalate	2.2	ug/l	1	(7.5)	U	Yes
bis(2-Ethylhexyl)phthalate	2.2	ug/l	1	-	U	Yes
Fluoranthene	1.1	ug/l	1	35.5	U	Yes
Fluorene	1.1	ug/l	1		U	Yes
Hexachlorobenzene	1.1	ug/l	1	-	U	Yes
Hexachlorobutadiene	1.1	ug/i	1	-	U	Yes
Hexachlorocyclopentadiene	11	ug/l	1	-	U	Yes
Hexachloroethane	2.2	ug/l	1	-	U	Yes
Indeno(1,2,3-cd)pyrene	1.1	ug/l	1		U	Yes
Isophorone	2.2	ug/l	1	-	U	Yes
1-Methylnaphthalene	1.1	ug/l	1	-	U	Yes
2-Methylnaphthalene	1.1	ug/l	1	-	U	Yes
2-Nitroaniline	5.6	ug/l	1	-	U	Yes
3-Nitroaniline	5.6	ug/l	1	-	U	Yes
4-Nitroaniline	5.6	ug/l	1	-	U	Yes
Nitrobenzene	2.2	ug/l	1	-	U	Yes
N-Nitroso-di-n-propylamine	2.2	ug/l	1	-	U	Yes
Nitrosodiphenylamine	5.6	ug/l	1	2	U	Yes
Phenanthrene	1.1	ug/l	1		Ū	Yes
Pyrene	1.1	ug/l	1		Ü	Yes
1,2,4,5-Tetrachlorobenzene	2.2	ug/l	1		U	Yes
-,-, -,		~6/ ·	-		_	>

METHOD: 8270D (SIM)

Naphthalene 0.11 ug/l 1 - U Yes

Sample location: BMSMC Building 5 Area

Sampling date: 5/19/2016

Matrix: Soil

Analyte Name	Result	Units	Dilution Factor	Lah Flag	Validation	Reportable
2-Chlorophenol	83	ug/kg	1	- -	ป	Yes
4-Chloro-3-methyl phenol	210	ug/kg	1	-	Ü	Yes
2,4-Dichlorophenol	210	ug/kg	1	_	U	Yes
2,4-Dimethylphenol	210	ug/kg	1	_	Ü	Yes
2,4-Dinitrophenol	210	ug/kg	1	**	Ü	Yes
4,6-Dinitro-o-cresol	210	ug/kg	1	-	U	Yes
2-Methylphenol	83	ug/kg	1	_	U	Yes
3&4-Methylphenol	83	ug/kg	1	_	Ü	Yes
2-Nitrophenol	210	ug/kg	1	_	U	Yes
4-Nitrophenol	420	ug/kg	1	_	U	Yes
Pentachlorophenol	210	ug/kg	1	_	Ü	Yes
Phenol	83	ug/kg	1	_	Ü	Yes
2,3,4,6-Tetrachlorophenol	210	ug/kg	1	_	Ū	Yes
2,4,5-Trichlorophenol	210	ug/kg	1	-	U	Yes
2,4,6-Trichlorophenol	210	ug/kg	1	_	U	Yes
Acenaphthene	42	ug/kg	1		U	Yes
Acenaphthylene	42	ug/kg	1	_	U	Yes
Acetophenone	210	ug/kg	1	-	U	Yes
Anthracene	42	ug/kg	1	-	U	Yes
Atrazine	83	ug/kg	1	-	U	Yes
Benzo(a)anthracene	42	ug/kg	1	-	U	Yes
Benzo(a)pyrene	42	ug/kg	1	-	U	Yes
Benzo(b)fluoranthene	42	ug/kg	1	-	U	Yes
Benzo(g,h,i)perylene	42	ug/kg	1	-	U	Yes
Benzo(k)fluoranthene	42	ug/kg	1	-	U	Yes
4-Bromophenyl phenyl ether	83	ug/kg	1	-	U	Yes
Butyl benzyl phthalate	83	ug/kg	1	-	U	Yes
1,1'-Biphenyl	83	ug/kg	1	-	U	Yes
Benzaldehyde	210	ug/kg	1	-	U	Yes
2-Chloronaphthalene	83	ug/kg	1	-	U	Yes
4-Chloroaniline	210	ug/kg	1	-	U	Yes
Carbazole	83	ug/kg	1	-	U	Yes
Caprolactam	83	ug/kg	1	-	U	Yes
Chrysene	42	ug/kg	1	-	U	Yes
bis(2-Chloroethoxy)methane	83	ug/kg	1	-	U	Yes
bis(2-Chloroethyl)ether	83	ug/kg	1	-	U	Yes
bis(2-Chloroisopropyl)ether	83	ug/kg	1	-	U	Yes

4-Chlorophenyl phenyl ether	83	ug/kg	1	-	U	Yes
2,4-Dinitrotoluene	42	ug/kg	1	-	U	Yes
2,6-Dinitrotoluene	42	ug/kg	1	-	U	Yes
3,3'-Dichlorobenzidine	83	ug/kg	1		U	Yes
Dibenzo(a,h)anthracene	42	ug/kg	1	-	U	Yes
Dibenzofuran	83	ug/kg	1		U	Yes
Di-n-butyl phthalate	83	ug/kg	1	77	U	Yes
Di-n-octyl phthalate	83	ug/kg	1	~	U	Yes
Diethyl phthalate	83	ug/kg	1	*	U	Yes
Dimethyl phthalate	83	ug/kg	1	-	U	Yes
bis(2-Ethylhexyl)phthalate	83	ug/kg	1	-	U	Yes
Fluoranthene	42	ug/kg	1		U	Yes
Fluorene	42	ug/kg	1	_	U	Yes
Hexachlorobenzene	83	ug/kg	1	-	U	Yes
Hexachlorobutadiene	42	ug/kg	1	-2	U	Yes
Hexachlorocyclopentadiene	420	ug/kg	1	· <u>· · · · · · · · · · · · · · · · · · </u>	U	Yes
Hexachloroethane	210	ug/kg	1	74	U	Yes
Indeno(1,2,3-cd)pyrene	42	ug/kg	1		U	Yes
Isophorone	83	ug/kg	1	12	U	Yes
1-Methylnaphthalene	83	ug/kg	1	15	U	Yes
2-Methylnaphthalene	83	ug/kg	1	-	U	Yes
2-Nitroaniline	210	ug/kg	1	-	U	Yes
3-Nitroaniline	210	ug/kg	1		U	Yes
4-Nitroaniline	210	ug/kg	1	2	U	Yes
Nitrobenzene	83	ug/kg	1	*	U	Yes
N-Nitroso-di-n-propylamine	83	ug/kg	1	5	U	Yes
Nitrosodiphenylamine	210	ug/kg	1	2	U	Yes
Phenanthrene	42	ug/kg	1		U	Yes
Pyrene	42	ug/kg	1	-	U	Yes
1,2,4,5-Tetrachlorobenzene	210	ug/kg	1	2	U	Yes
METHOD:	8270D (S	IM)				
Naphthalene	12.6	ug/kg	1	В	JB	Yes
1,4-Dioxane	4.2	ug/kg	1	-	R	Yes

Sample location: BMSMC Building 5 Area

Sampling date: 5/19/2016

Matrix: Soil

METHOD.	02700					
Analyte Name	Result		Dilution Factor	Lab Flag		•
2-Chlorophenol	83	ug/kg	1	-	U	Yes
4-Chloro-3-methyl phenol	210	ug/kg	1	-	U	Yes
2,4-Dichlorophenol	210	ug/kg	1	-	U	Yes
2,4-Dimethylphenol	210	ug/kg	1	-	U	Yes
2,4-Dinitrophenol	210	ug/kg	1	-	U	Yes
4,6-Dinitro-o-cresol	210	ug/kg	1	-	U	Yes
2-Methylphenol	83	ug/kg	1	-	U	Yes
3&4-Methylphenol	83	ug/kg	1	-	U	Yes
2-Nitrophenol	210	ug/kg	1	-	U	Yes
4-Nitrophenol	420	ug/kg	1	-	U	Yes
Pentachlorophenol	210	ug/kg	1	-	U	Yes
Phenol	83	ug/kg	1	-	U	Yes
2,3,4,6-Tetrachlorophenol	210	ug/kg	1	-	U	Yes
2,4,5-Trichlorophenol	210	ug/kg	1	-	U	Yes
2,4,6-Trichlorophenol	210	ug/kg	1	-	U	Yes
Acenaphthene	42	ug/kg	1	-	U	Yes
Acenaphthylene	42	ug/kg	1	-	υ	Yes
Acetophenone	210	ug/kg	1	-	U	Yes
Anthracene	42	ug/kg	1	-	U	Yes
Atrazine	83	ug/kg	1	-	U	Yes
Benzaldehyde	42	ug/kg	1	-	U	Yes
Benzo(a)anthracene	42	ug/kg	1	-	U	Yes
Benzo(a)pyrene	42	ug/kg	1	-	U	Yes
Benzo(b)fluoranthene	42	ug/kg	1	-	U	Yes
Benzo(g,h,i)perylene	42	ug/kg	1	-	U	Yes
Benzo(k)fluoranthene	83	ug/kg	1	-	U	Yes
4-Bromophenyl phenyl ether	83	ug/kg	1	-	U	Yes
Butyl benzyl phthalate	83	ug/kg	1	-	U	Yes
1,1'-Biphenyl	210	ug/kg	1	-	U	Yes
2-Chloronaphthalene	83	ug/kg	1	-	U	Yes
4-Chloroaniline	210	ug/kg	1	-	U	Yes
Carbazole	83	ug/kg	m 1	-	U	Yes
Caprolactam	83	ug/kg	1	-	U	Yes
Chrysene	42	ug/kg	1	-	U	Yes
bis(2-Chloroethoxy)methane	83	ug/kg	1	-	U	Yes
bis (2-Chloroethyl) ether	83	ug/kg	1	-	U	Yes
bis(2-Chloroisopropyl)ether	83	ug/kg	1	-	U	Yes
4-Chlorophenyl phenyl ether	83	ug/kg	1	-	U	Yes

2,4-Dinitrotoluene	42	ug/kg	1		U	Yes
2,6-Dinitrotoluene	42	ug/kg	1		U	Yes
3,3'-Dichlorobenzidine	83	ug/kg	1	4	U	Yes
Dibenzo(a,h)anthracene	42	ug/kg	1		U	Yes
Dibenzofuran	83	ug/kg	1	-	U	Yes
Di-n-butyl phthalate	83	ug/kg	1	-	U	Yes
Di-n-octyl phthalate	83	ug/kg	1	7.5	Ų	Yes
Diethyl phthalate	83	ug/kg	1	-	U	Yes
Dimethyl phthalate	83	ug/kg	1	-	U	Yes
bis(2-Ethylhexyl)phthalate	83	ug/kg	1	-	U	Yes
Fluoranthene	42	ug/kg	1	12	U	Yes
Fluorene	42	ug/kg	1	-	U	Yes
Hexachlorobenzene	83	ug/kg	1	17	U	Yes
Hexachlorobutadiene	42	ug/kg	1	12	U	Yes
Hexachlorocyclopentadiene	420	ug/kg	1	-	U	Yes
Hexachloroethane	210	ug/kg	1	-	U	Yes
Indeno(1,2,3-cd)pyrene	42	ug/kg	1	~	U	Yes
Isophorone	83	ug/kg	1	-	U	Yes
1-Methylnaphthalene	83	ug/kg	1	1/2	U	Yes
2-Methylnaphthalene	83	ug/kg	1	-	U	Yes
2-Nitroaniline	210	ug/kg	1	-	U	Yes
3-Nitroaniline	210	ug/kg	1	12	U	Yes
4-Nitroaniline	210	ug/kg	1	75	U	Yes
Nitrobenzene	83	ug/kg	1	-	U	Yes
N-Nitroso-di-n-propylamine	83	ug/kg	1	12	U	Yes
Nitrosodiphenylamine	210	ug/kg	1	2	U	Yes
Phenanthrene	42	ug/kg	1	2	U	Yes
Pyrene	42	ug/kg	1	~	U	Yes
1,2,4,5-Tetrachlorobenzene	210	ug/kg	1	170	U	Yes
METHOD:	927ND /S	1BA)				
Naphthalene	4.2	ug/kg	1	~	U	Yes
1,4-Dioxane	4.2	ug/kg ug/kg	1		U	Yes
1,7-DIOXATIC	4.2	nR\ vR	1	-	U	162

Sample location: BMSMC Building 5 Area

Sampling date: 5/18/2016 Matrix: Groundwater

Analyte Name	Result	Units	Dilution Factor	Lab Flag	Validation	Reportable
2-Chlorophenol	5.6	ug/l	1	-	U	Yes
4-Chloro-3-methyl phenol	5.6	ug/l	1	-	U	Yes
2,4-Dichlorophenol	2.2	ug/l	1	-	U	Yes
2,4-Dimethylphenol	5.6	ug/l	1	-	U	Yes
2,4-Dinitrophenol	11	ug/l	1	-	U	Yes
4,6-Dinitro-o-cresol	5.6	ug/l	1	-	υ	Yes
2-Methylphenol	2.2	ug/l	1	-	Ų	Yes
3&4-Methylphenol	2.2	ug/l	1	73	U	Yes
2-Nitrophenol	5.6	ug/l	1	-	U	Yes
4-Nitrophenol	11	ug/l	1	-	U	Yes
Pentachlorophenol	5.6	ug/l	1	-	Ų	Yes
Phenol	2.2	ug/l	1	-	U	Yes
2,3,4,6-Tetrachlorophenol	5.6	ug/l	1	-	U	Yes
2,4,5-Trichlorophenol	5.6	ug/l	1	-	U	Yes
2,4,6-Trichlorophenol	5.6	ug/l	1	-	U	Yes
Acenaphthene	1.1	ug/l	1	-	U	Yes
Acenaphthylene	1.1	ug/l	1	-	U	Yes
Acetophenone	2.2	ug/l	1	-	U	Yes
Anthracene	1.1	ug/l	1	-	U	Yes
Atrazine	2.2	ug/l	1	-	U	Yes
Benzaldehyde	1.1	ug/l	1	-	U	Yes
Benzo(a)anthracene	1.1	ug/l	1	-	U	Yes
Benzo(a)pyrene	1.1	ug/l	1	-	U	Yes
Benzo(b)fluoranthene	1.1	ug/l	1	-	U	Yes
Benzo(g,h,i)perylene	1.1	ug/l	1	-	U	Yes
Benzo(k)fluoranthene	2.2	ug/l	1	-	U	Yes
4-Bromophenyl phenyl ether	2.2	ug/l	1	-	U	Yes
Butyl benzyl phthalate	1.1	ug/l	1	-	U	Yes
1,1'-Bipheny!	2.2	ug/l	1	-	U	Yes
2-Chloronaphthalene	5.6	ug/l	1	-	U	Yes
4-Chloroaniline	1.1	ug/l	1	-	U	Yes
Carbazole	5.6	ug/l	1	-	U	Yes
Caprolactam	2.2	ug/l	1	-	U	Yes
Chrysene	1.1	ug/l	1	-	U	Yes
bis(2-Chloroethoxy)methane	2.2	ug/l	1	-	U	Yes
bis(2-Chloroethyl)ether	2.2	ug/l	1	-	U	Yes
bis(2-Chloroisopropyl)ether	2.2	ug/l	1	-	U	Yes
4-Chlorophenyl phenyl ether	2.2	ug/l	1	-	U	Yes

2,4-Dinitrotoluene	1.1	ug/l	1	-	บ	Yes
2,6-Dinitrotoluene	1.1	ug/l	1	177	U	Yes
3,3'-Dichlorobenzidine	2.2	ug/l	1	12	U	Yes
Dibenzo(a,h)anthracene	1.1	ug/l	1	-	U	Yes
Dibenzofuran	5.6	ug/l	1	-	U	Yes
Di-n-butyl phthalate	2.2	ug/l	1	-	U	Yes
Di-n-octyl phthalate	2.2	ug/l	1	-	U	Yes
Diethyl phthalate	2.2	ug/l	1	12	U	Yes
Dimethyl phthalate	2.2	ug/l	1	-	U	Yes
bis(2-Ethylhexyl)phthalate	2.2	ug/l	1	- 2	U	Yes
Fluoranthene	1.1	ug/l	1	-	U	Yes
Fluorene	1.1	ug/l	1	1.5	U	Yes
Hexachlorobenzene	1.1	ug/l	1	-	U	Yes
Hexachlorobutadiene	1.1	ug/l	1	12	U	Yes
Hexachlorocyclopentadiene	11	ug/l	1	-	U	Yes
Hexachloroethane	2.2	ug/l	1	1	⊺ U	Yes
Indeno(1,2,3-cd)pyrene	1.1	ug/l	1		U	Yes
Isophorone	2.2	ug/l	1		U	Yes
1-Methylnaphthalene	1.1	ug/l	1	- 2	U	Yes
2-Methylnaphthalene	1.1	ug/l	1	-	U	Yes
2-Nitroaniline	5.6	ug/l	1	-	U	Yes
3-Nitroaniline	5.6	ug/l	1	-	U	Yes
4-Nitroaniline	5.6	ug/l	1	-	U	Yes
Nitrobenzene	2.2	ug/l	1	-	U	Yes
N-Nitroso-di-n-propylamine	2.2	ug/l	1	-	U	Yes
Nitrosodiphenylamine	5.6	ug/l	1	-	U	Yes
Phenanthrene	1.1	ug/l	1	-	U	Yes
Pyrene	1.1	ug/l	1	-	U	Yes
1,2,4,5-Tetrachlorobenzene	2.2	ug/l	1	-	U	Yes

METHOD: 8270D (SIM)

Naphthalen	0.11	ug/l	1	2	U	Yes
1,4-Dioxane	2.43	ug/l	1	-	-	Yes

	Project Number:_JC20660 Date:May_13-19,_2016
	Shipping Date:May_19,_2016 EPA Region:2
REVIEW OF SEMIVOLATILE O	DRGANIC PACKAGE
The following guidelines for evaluating volatile orgulation actions. This document will assist the remake more informed decision and in better serving results were assessed according to USEPA data following order of precedence: EPA Hazardous V 2015 –Revision 0. Semivolatile Data Validation. The Quon the data review worksheets are from the prima noted.	eviewer in using professional judgment to the needs of the data users. The sample a validation guidance documents in the Vaste Support Section, SOP HW-35A, July C criteria and data validation actions listed
The hardcopied (laboratory name) _Accutest reviewed and the quality control and performance daincluded:	
Lab. Project/SDG No.:JC20660 No. of Samples:6_Full_scan/6_SIM	Sample matrix: _Groundwater
Trip blank No.:	
X Data CompletenessX Holding TimesX GC/MS TuningX Internal Standard PerformanceX BlanksX Surrogate RecoveriesX Matrix Spike/Matrix Spike Duplicate	X Laboratory Control SpikesX Field DuplicatesX CalibrationsX Compound IdentificationsX Compound QuantitationX Quantitation Limits
Overall Comments:_ABN_TCL_list_by_method_SW846-8 _analyzed_by_method_SW846-8270D_(SIM)	3270D;_Naphthalene_and_1,4-Dioxane_
Definition of Qualifiers:	
J- Estimated results U- Compound not detected R- Rejected data UJ- Estimated nondetect Reviewer: A refaul Date:June_15,_2016	

DATA COMPLETENESS

MISSING INFORMATION	DATE LAB. CONTACTED	DATE RECEIVED
4		
		4
	<u> </u>	
		<u> </u>
	<u> </u>	
		
		

All criteria were met _	Х_
Criteria were not met	
and/or see below	

HOLDING TIMES

The objective of this parameter is to ascertain the validity of the results based on the holding time of the sample from time of collection to the time of analysis.

Complete table for all samples and note the analysis and/or preservation not within criteria

DATE SAMPLED	DATE EXTRACTED/ANALYZED	рН	ACTION	
All samples extracted and analyzed within method recommended holding time. Sample preservation was acceptable.				
	SAMPLED	SAMPLED EXTRACTED/ANALYZED	SAMPLED EXTRACTED/ANALYZED	

	Cooler temperature	(Criteria: 4 + 2 °C'	:5.3°C) !
--	--------------------	----------------------	--------	--------

Actions

Results will be qualified based on the criteria of the following Table:

Table 1. Holding Time Actions for Semivolatile Analyses

			Action		
Matrix	Preserved	Criteria	Detected Associated Compounds	Non-Detected Associated Compounds	
	No ≤7 days (for extraction) ≤40 days (for analysis)		Use professi	onal judgment	
No		> 7 days (for entraction) > 40 days (for analysis)	Ţ	Use professional judgment	
Aqueous	Aqueous Yes ≤7 days (for extra ≤ 40 days (for ana		No qualification		
Yes		> 7 days (for extraction) > 40 days (for analysis)	J CJ		
	Yes/No	Grossly Exceeded	J	ÜJ or R	
	No	≤ 14 days (for extraction) ≤ 40 days (for analysis)	Use professional judgme		
N'an Agusaus	No	> 14 days (for extraction) > 40 days (for analysis)	J	Use professional judgment	
Non-Aqueous	Yes	≤ 14 days (for extraction) ≤ 40 days (for analysis)	No qualification		
	Yes	> 14 days (for extraction) > 40 days (for analysis)	J	UJ	
	Yes/No	Grossly Exceeded	J UJ		

All criteria were metX_	_
Criteria were not met see below	

GC/MS TUNING

The assessment of the tuning results is to determine if the sample instrumentation is within the standard tuning QC limits

- _X__ The DFTPP performance results were reviewed and found to be within the specified criteria.
- _X__ DFTPP tuning was performed for every 12 hours of sample analysis.

If no, use professional judgment to determine whether the associated data should be accepted, qualified or rejected.

Notes: These requirements do not apply when samples are analyzed by the Selected Ion Monitoring (SIM) technique.

All mass spectrometer conditions must be identical to those used during the sample analysis. Background subtraction actions resulting in spectral distortion are unacceptable

Notes: No data should be qualified based of DFTPP failure.

The requirement to analyze the instrument performance check solution is optional when analysis of PAHs/pentachlorophenol is to be performed by the SIM technique.

List	the	samples	affected:

Actions:

- If sample are analyzed without a preceding valid instrument performance check or are analyzed 12 hours after the Instrument Performance Check, qualify all data in those samples as unusable (R).
- 2. If ion abundance criteria are not met, use professional judgment to determine to what extent the data may be utilized.
- 3. State in the Data Review Narrative, decisions to use analytical data associated with DFTPP instrument performance checks not meeting the contract requirements.
- 4. Use professional judgment to determine if associated data should be qualified based on the spectrum of the mass calibration compounds.

All criteria were met	_X_	_
Criteria were not met		
and/or see below		

INITIAL CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

Date of initial calibration: Instrument ID numbers:	_05/31/16_(SIM) GCMS4M	05/17/2016_(SIM) GCMS3M
Matrix/Level:	Aqueous/low	Aqueous/low
Date of initial calibration:_05/1 Instrument ID numbers: Matrix/Level:	GCMS6P	05/16/16;_(Scan) GCMS2M Aqueous/low

DATE	LAB ID#	FILE	CRITERIA OUT RFs, %RSD, %D, r	COMPOUND	SAMPLES AFFECTED
Initial and initial calibration verification meets the method and guidance validation document performance criteria.					

Actions:

Qualify the initial calibration analytes listed in Table 2 using the following criteria:

Table 3. Initial Calibration Actions for Semivolatile Analysis

Civitania	Action		
Criteria	Detect	Non-detect	
Initial Calibration not performed at specified frequency and sequence	Use professional judgment R	Use professional judgment R	
Initial Calibration not performed at the specified concentrations	J	UJ	
RRF < Minimum RRF in Table 2 for target analyte	Use professional judgment J± or R	R	
RRF > Minimum RRF in Table 2 for target analyte	No qualification	No qualification	
%RSD > Maximum %RSD in Table 2 for target analyte	Ţ	Use professional judgment	
%RSD ≤ Maximum %RSD in Table 2 for target analyte	No qualification	No qualification	

Initial Calibration

Table 2. RRF, %RSD, and %D Acceptance Criteria in Initial Calibration and CCV for Semivolatile Analysis

Analyte	Minimum RRF	Maximum %RSD	Opening Maximum %D ¹	Opening Maximum %D ¹	
1,4-Dioxane	0.010	40.0	-40.0	-50.0	
Benzaldehyde	0,100	40,0	= 40.0	=50.0	
Phenol	0.080	20.0	= 20.0	- 25.0	
Bis(2-chloroethyl)ether	0.100	20.0	-20.0	-25.0	
2-Chlorophenol	0,200	20.0	= 20,0	= 25.0	
2-Methylphenol	0.010	20,0	=20.0	= 25.0	
3-Methylphenol	0,010	20.0	= 20.0	= 25.0	
2,2'-Oxybis-(1-chloropropane)	0,010	20.0	= 25.0	= 50.0	
Acetophenone	0,060	20.0	= 20.0	= 25.0	
4-Methylphenol	0,010	20.0	- 20.0	- 25.0	
N-Nitroso-di-n-propylamine	0.080	20.0	±25.0	= 25.0	
Hexachloroethane	0.100	20.0	- 20.0	-25.0	
Nitrobenzene	0,090	20,0	= 20.0	- 25.0	
Isophorone	0.100	20.0	-20.0	-25.0	
2-Nitrophenol	0,060	20.0	-20.0	-25.0	
2,4-Dimethylphenol	0.050	20,0	-25.0	-50.0	
Bis(2-chloroethoxy)methane	0.080	20.0	-20.0	-25.0	
2,4-Dichlorophenol	0.060	20.0	= 20.0	= 25.0	
Naphthalene	0.200	20,0	± 20.0	-25.0	
4-Chloroaniline	0.010	40.0	-40.0	-50.0	
Hexachlorobutadiene	0.040	20.0	- 20.0	- 25.0	
Caprolactam	0.010	40.0	= 30.0	= 50.0	
4-Chloro-3-methylphenol	0.040	20.0	- 20.0	=25.0	
2-Methylnaphthalene	0.100	20,0	- 20.0	-25.0	
Hexachlorocyclopentadiene	0.010	40.0	= 40.0	- 50.0	
2,4,6-Trichlorophenol	0.090	20.0	-20.0	-25.0	
2,4,5-Trichlorophenol	0,100	20,0	- 20.0	- 25.0	
1,1'-Biphenyl	0,200	20.0	= 20.0	- 25.0	

Analyte	Minimum RRF	Maximum %RSD	Opening Maximum %D ¹	Opening Maximum %D
2-Chloronaphthalene	0.300	20.0	-20.0	-25.0
2-Nitroaniline	0.060	20.0	= 25.0	- 25.0
Dimethylphthalate	0.300	20.0	-25.0	-25.0
2.6-Dinitrotoluene 0.080		20.0	-20.0	- 25.0
Acenaphthylene	0,400	20.0	-20.0	-25.0
3-Nitroaniline	0.010	20.0	-25.0	- 50.0
Acenaphthene	0.200	20.0	±20.0	-25.0
2,4-Dinitrophenol	0.010	40.0	-50.0	-50.0
4-Nitrophenol	0.010	40.0	- 40.0	- 50.0
Dibenzofuran	0.300	20.0	-20.0	= 25.0
2,4-Dinitrotoluene	0.070	20.0	- 20.0	-25.0
Diethylphthalate 0.300		20.0	- 20.0	= 25.0
1,2,4,5-Tetrachlorobenzene	0,100	20.0	-20.0	-25.0
4-Chlorophenyl-phenylether	0.100	20.0	-20.0	= 25.0
Fluorene	0.200	-20.0	=20.0	= 25.0
4-Nitroaniline	0.010	40.0	-40.0	- 50.0
4,6-Dinitro-2-methylphenol	0.010	40.0	-30.0	-50.0
4-Bromophenyl-phenyl ether	0.070	20.0	-20.0	-25.0
N-Nitrosodiphenylamine	0.100	20.0	- 20.0	-25.0
Hexachlorobenzene	0.050	20.0	-20.0	-25.0
Atrazine	0.010	40.0	- 25.0	- 50.0
Pentachlorophenol	0.010	40.0	-40.0	-50.0
Phenanthrene	0.200	20.0	- 20.0	-25.0
Anthracene	0.200	20.0	-20.0	-25,0
Carbazole	0.050	20.0	- 20.0	- 25.0
Di-n-butylphthalate	0.500	20.0	-20.0	-25.0
Fluoranthene	0,100	20,0	- 20.0	-25.0
Pyrene	0.400	20.0	-25.0	-50.0
Buty/benzy/phthalate	0.100	20,0	-25.0	-50.0

Analyte	Minimum RRF	Maximum %RSD	Opening Maximum %D ^t	Opening Maximum %D ¹
3,3'-Dichlorobenzidine	0.010	40,0	-40.0	-50.0
Benzo(a)anthracene	0,300	20,0	-20.0	-25.0
Chrysene	0.200	20.0	- 20.0	-50.0
Bis(2-ethylhexyl) phthalate	0,200	20,0	-25.0	-50.0
Di-n-octylphthalate	0.010	40.0	-40.0	- 50.0
Benzo(b)fluoranthene	0.010	20,0	-25.0	- 50.0
Benzo(k)fluoranthene	0.010	20,0	-25.0	- 50.0
Benzo(a)pyrene	0.010	20.0	-20.0	- 50.0
Indeno(1,2,3-cd)pyrene	0.010	20.0	-25.0	- 50.0
Dibenzo(a,h)anthracene	0.010	20.0	-25.0	= 50.0
Benzo(g,h,i)perylene	0.010	20.0	-30.0	- 50.0
2,3,4,6-l'etrachlorophenol	0,040	20.0	- 20.0	= 50.0
Naphthalene	0.600	20.0	-25.0	- 25.0
2-Methylnaphthalene	0,300	20.0	-20.0	- 25.0
Acenaphthylene	0.900	20.0	- 20.0	= 25.0
Acenaphthene	0.500	20,0	- 20.0	-25.0
Fluorene	0.700	20.0	-25.0	- 50.0
Phenanthrene	0.300	20,0	= 25.0	= 50.0
Anthracene	0,400	20.0	- 25.0	= 50.0
Fluoranthene	0,400	20.0	- 25.0	- 50.0
Pyrene	0.500	20.0	-30.0	+ 50.0
Benzo(a)anthracene	0.400	20.0	- 25.0	- 50.0
Chyrsene	0,400	20,0	= 25.0	- 50.0
Benzo(b)fluoranthene	0,100	20,0	-30.0	- 50.0
Benzo(k)fluoranthene	0.100	20.0	-30.0	- 50.0
Benzo(a)pyrene	0.100	20.0	- 25.0	- 50.0
Indeno(1,2,3-cd)pyrene	0.100	20.0	-40.0	- 50.0
Dibenzo(a,h)anthracene	0.010	25.0	-40.0	- 50.0
Benzo(g,h,i)perylene	0.020	25.0	-40.0	- 50.0

Pentachlorophenol	0.010	40.0	- 50.0	- 50.0
Deuterated Monitoring Comp	ounds			

Analyte	Minimum RRF	Maximum %RSD	Opening Maximum %D ¹	Closing Maximum %D
1,4-Dioxane-d ₈	0,010	20.0	-25.0	-50.0
Phenol-d ₅	0.010	20.0	-25.0	=25.0
Bis-(2-chloroethyl)ether-dx	0.100	20.0	- 20.0	- 25.0
2-Chlorophenol-d ₁	0.200	20.0	-20.0	= 25.0
4-Methylphenol-ds	0.010	20.0	-20.0	-25.0
4-Chloroaniline-d ₄	0.010	40.0	-40.0	- 50.0
Nitrobenzene-ds	0.050	20.0	- 20.0	-25.0
2-Nitrophenol-di	0.050	20,0	-20.0	-25.0
2,4-Dichlorophenol-d;	0.060	20,0	-20.0	-25.0
Dimethy lphthalate-d ₆	0.300	20.0	-20.0	-25.0
Acenaphthy lene-d _x	0.400	20.0	- 20.0	- 25.0
4-Nitrophenol-d ₁	0.010	40.0	-40.0	- 50.0
Fluorene-d ₁₀	0.100	20.0	- 20:0	- 25.0
4,6-Dinitro-2-methylphenol-d-	0.010	40,0	-30,0	-50.0
Anthracene-d _{fit}	0.300	20.0	- 20.0	- 25.0
Pyrene-d ₁₀	0,300	20.0	-25.0	- 50.0
Benzo(a)pyrene-d ₁₂	0.010	20.0	-20.0	-50.0
Fluoranthene-d ₁₀ (SIM)	0,400	20,0	-25.0	- 50.0
2-Methylnaphthalene-d ₁₀ (SIM)	0.300	20,0	- 20.0	-25.0

If a closing CCV is acting as an opening CCV, all target analytes must meet the requirements for an opening CCV.

Note: If analysis by SIM technique is requested for PAH/pentachlorophenols, calibration standards analyzed at 0.10, 0.20, 0.40, 0.80, and 1.0 ng/uL for each target compound of interest and the associated DMCs. Pentachlorophenol will require only a four point initial calibration at 0.20, 0.40, 0.80, and 1.0 ng/uL.

All criteria were met
Criteria were not met
and/or see belowX

CONTINUING CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

Date of initial calibration:	_05/17/16_(SIM)
Date of initial calibration verification (IC)	v):05/17-18/16
	n (CCV):_05/22/16
Date of closing CCV:	-
Instrument ID numbers:	GCMS3M
Matrix/Level:	Aqueous/low
Date of initial calibration:05/13/16_	(Scan)
	v):05/13/16;_05/16/16
Date of continuing calibration verificatio	n (CCV): 05/20/16
Date of closing CCV:	GCMS6P
Instrument ID numbers:	GCMS6P
Matrix/Level:	Aqueous/low
Date of initial calibration:	05/16/16_(Scan)
Date of initial calibration:	05/16/16_(Scan)
Date of initial calibration verification (IC) Date of continuing calibration verificatio	V):05/16-17/16 n (CCV):05/26/16;_05/27/16
Date of initial calibration verification (IC) Date of continuing calibration verificatio Date of closing CCV:	V):05/16-17/16 n (CCV):05/26/16;_05/27/16
Date of initial calibration verification (IC) Date of continuing calibration verificatio Date of closing CCV:	V):05/16-17/16 n (CCV):05/26/16;_05/27/16
Date of initial calibration verification (IC' Date of continuing calibration verificatio Date of closing CCV: Instrument ID numbers:	V):05/16-17/16 n (CCV):05/26/16;_05/27/16
Date of initial calibration verification (IC' Date of continuing calibration verificatio Date of closing CCV: Instrument ID numbers: Matrix/Level: Date of initial calibration:05/31/	/):05/16-17/16_ n (CCV):05/26/16;_05/27/16 GCMS2M Aqueous/low
Date of initial calibration verification (IC' Date of continuing calibration verificatio Date of closing CCV: Instrument ID numbers: Matrix/Level: Date of initial calibration:05/31/	/):05/16-17/16_ n (CCV):05/26/16;_05/27/16 GCMS2M Aqueous/low
Date of initial calibration verification (IC' Date of continuing calibration verificatio Date of closing CCV: Instrument ID numbers: Matrix/Level: Date of initial calibration: Date of initial calibration verification (IC' Date of continuing calibration verification	/):05/16-17/16
Date of initial calibration verification (IC' Date of continuing calibration verificatio Date of closing CCV: Instrument ID numbers: Matrix/Level: Date of initial calibration: Date of initial calibration verification (IC' Date of continuing calibration verification	/):05/16-17/16
Date of initial calibration verification (IC' Date of continuing calibration verificatio Date of closing CCV: Instrument ID numbers: Matrix/Level: Date of initial calibration: Date of initial calibration verification (IC' Date of continuing calibration verification	/):05/16-17/16 n (CCV):05/26/16;_05/27/16 GCMS2M Aqueous/low 16_(SIM) /):05/31/16

DATE	LAB FILE ID#	CRITERIA OUT RFs, %RSD, <u>%D</u> , r	COMPOUND	SAMPLES AFFECTED
GCMS3P				_
05/20/16	cc1209-25	-24.5	2,4-dinitrophenol*	JC20660-1; -2; -3; -
		-25.8	4,6-Dinitro-2-methylphenol*	6
GCMS2M				
05/26/16	cc3688-50	-23.4	Caprolactam*	QC samples
		-20.6	4-nitroaniline*	
05/26/16	cc3688-25	20.3	Hexachlorocyclopentadiene*	

Note: Initial and continuing calibration verifications meet the method and guidance document required performance criteria except the cases describe in this document. Results qualified as estimated (J), (UJ) for non-detects.

No closing calibration verification included in data package. No action taken, professional judgment.

* Analytes with % difference in the continue calibration verification outside the method performance criteria but within the validation guidelines criteria, +40 %. No action taken.

GCMS5P used to analyze QC samples for this batch on 06/02/16 and GCMS3E used to analyze QC samples for this batch on 06/02-03/16. No qualification was performed on QC samples.

Actions:

Notes: Verify that the CCV is run at the required frequency (an opening and closing CCV must be run within 12-hour period).

All DMCs must meet the RRF values given in Table 2. No qualification of the data is necessary on DMCs RRF and %RSD/%D alone. Use professional judgment to evaluate DMCs and %RSD/%D data in conjunction with DMCs recoveries to determine the need for qualification of the data.

Qualify the initial calibration analytes listed in Table 2 using the following criteria in the CCVs:

Table 4. CCV Actions for Semivolatile Analysis

Criteria for Opening CCV	Criteria for Closing CCV -	Action	
Criteria for Opening CC. V.	Chemis C. V. Chemis Of Closing C. V.		Non-detect
CCV not performed at required frequency and sequence	CCV not performed at required frequency	Use professional judgment R	Use professional judgment R
CCV not performed at specified concentration	CCV not performed at specified concentration	Use professional judgment	Use professional judgment
RRF Minimum RRF in Table 2 for target analyte	RRF < Minimum RRF in Table 2 for target analyte	Use professional judgment J or R	R
RRF ≥ Minimum RRF in Table 2 for target analyte	RRF > Minimum RRF in Table 2 for target analyte	No qualification	No qualification
%D outside the Opening Maximum %D limits in Table 2 for target analyte	%D outside the Closing Maximum %D limits in Table 2 for target analyte	J	1.1
%D within the inclusive Opening Maximum %D limits in Table 2 for target analyte	Maximum %D limits in Table 2		No qualification

All criteria were mel	
Criteria were not met	
and/or see belowX	

BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including trip, equipment, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamination in the blanks below. High and low levels blanks must be treated separately.

Notes: The concentration of non-target compounds in all blanks must be less than or equal to 10 ug/L.

The concentration of target compounds in all blanks must be less than its CRQL listed in the method.

Samples taken from a drinking water tap do not have and associated field blank.

Laboratory blanks

DATE ANALYZED	LAB ID	LEVEL/ MATRIX	COMPOUND	CONCENTRATION UNITS
			nks_except_in_the_ca	ses_described_in_this
06/03/16	OP94191A-MB1	Soil/low	Naphthalene	8.68_ug/kg
Note:		ated (J) by th		20660-4 as (B). Results further ne was not detected in sample
Field/ <u>Equipmen</u>	<u>t</u> /Trip blank			31
DATE ANALYZED	LAB ID	LEVEL/ MATRIX	COMPOUND	CONCENTRATION UNITS
70 (70) - 1000		75. 970,700	nent_blankNo_field/tri	p_blanks_analyzed_with_this
-07715			in the second se	
1,000				
	V-90			N.W. 10 85 82

All criteria were met
Criteria were not met
and/or see belowX

BLANK ANALYSIS RESULTS (Section 3)

Blank Actions

Qualify samples based on the criteria summarized in Table 5:

Table 5. Blank and TCLP/SPLP LEB Actions for Semivolatile Analysis

Blank Type	Blank Result	Sample Result	Action
	Detect	Non-detect	No qualification
8	< CRQL	< CRQL	Report at CRQL and qualify as non-detect (U)
	2.5	≥ CRQL	Use professional judgment
		< CRQL	Report at CRQL and qualify as non-detect (U)
≥ CRQL.	≥ CRQL	≥ CRQL but < Blank Result	Report at sample results and qualify as non-detect (U) or as unusable (R)
TCLP/SPLP LEB, Field		≥ CRQL and ≥ Blank Result	Use professional judgment
8005	Grossly high	Detect	Report at sample results and qualify as unusable (R)
	TIC > 5.0 ug/L (water) or 0.0050 mg/L (TCLP leachate) or TIC > 170 ug/Kg (soil)	Detect	Use professional judgment

List samples qualified

CONTAMINATION SOURCE/LEVEL	COMPOUND	CONC/UNITS	AL/UNITS	SQL	AFFECTED SAMPLES
					
		1			
		L			

%R > Upper Acceptance Limit

All criteria were met _	_X	_
Criteria were not mel		
and/or see below		

SURROGATE SPIKE RECOVERIES - DEUTERATED MONITORING COMPOUNDS (DMCs)

Laboratory performance of individual samples is established by evaluation of surrogate spike recoveries – deuterated monitoring compounds. All samples are spiked with surrogate compounds prior to sample analysis. The accuracy of the analysis is measured by the surrogate percent recovery. Since the effects of the sample matrix are frequently outside the control of the laboratory and may present relatively unique problems, the validation of data is frequently subjective and demands analytical experience and professional judgment.

Notes: Recoveries for DMCs in samples and blanks must be within the limits specified in Table 6.

The recovery limits for any of the compounds listed in Table 6 may be expanded at any time during the period of performance if USEPA determines that the limits are too restrictive.

If a DMC is not added in the samples and blanks or the concentrations of DMCs in the samples and blank not the specified, use professional judgment in qualifying the data.

J+

No qualification

 Action

 Criteria
 Detect
 Non-detect

 %R < 10% (excluding DMCs with 10% as a lower acceptance limit)</th>
 J R

 $10\% \le \%$ R (excluding DMCs with 10% as a lower acceptance limit) < Lower Acceptance Limit</td>
 J UJ

 Lower Acceptance limit $\le \%$ R \le Upper Acceptance Limit
 No qualification
 No qualification

Table 7. DMC Actions for Semivolatile Analysis

List the percent recoveries (%Rs) which do not meet the criteria for DMCs (surrogate) recovery.

	SAMPLE ID	SURROGATE COMPOUND	ACTION
_DMCs_meet_the_required_criteriaNon-deuterated_surrogates_added_to_the_samples_were_within_laboratory_recovery_limits			

Table 8. Semivolatile DMCs and the Associated Target Analytes

1,4-Dioxane-ds (DMC-1)	Phenol-d ₅ (DMC-2)	Bis(2-Chloroethyl) ether-d ₃ (DMC-3)
1,4-Dioxane	Benzaldehyde	Bis(2-chloroethyl)ether
	Phenol	2,2'-Oxybis(1-chloropropane)
		Bis(2-chloroethoxy)methane
2-Chlorophenol-d ₄ (DMC-4)	4-Methylphenol-da (DMC-5)	4-Chloroaniline-d ₄ (DMC-6)
2-Chlorophenol	2-Methylphenol	4-Chloroaniline
	3-Methylphenol	Hexachlorocyclopentadiene
	4-Methylphenol	Dichlorobenzidine
	2,4-Dimethylphenol	
Nitrobenzene-d ₅ (DMC-7)	2-Nitrophenol-d ₄ (DMC-8)	2,4-Dichlorophenol-d3(DMC-9)
Acetophenone	Isophorone	2,4-Dichlorophenol
N-Nitroso-di-n-propylamine	2-Nitrophenol	Hexachlorobutadiene
Hexachloroethane		Hexachlorocyclopentadiene
Nitrobenzene		4-Chloro-3-methylphenol
2,6-Dinitrotoluene	Į.	2,4,6-Trichlorophenol
2,4-Dinitrotoluene		2,4,5-Trichlorophenol
N-Nitrosodiphenylamine		1,2,4,5-Tetrachtorobenzene
		*Pentachlorophenol
		2,3,4,6-Tetrachlorophenol
Dimethylphthalate-d ₆ (DMC-10)	Acenaphthylene-da (DMC-11)	4-Nitrophenol-d ₄ (DMC-12)
Caprolactam	*Naphthalene	2-Nitroaniline
1,1'-Biphenyl	*2-Methylnaphthalene	3-Nitroaniline
Dimethylphthalate	2-Chloronaphthalene	2,4-Dinitrophenol
Diethylphthalate	*Acenaphthylene	4-Nitrophenol
Di-n-butylphthalate	*Acenaphthene	4-Nitroaniline
Butylbenzylphthalate		
Bis(2-ethylhexyl) phthalate		
Di-n-octylphthalate		1

Fluorene-d _{in} (DMC-13)	4,6-Dinitro-2-methylphenol-d ₂ (DMC-14)	Anthracene-d ₁₀ (DMC-15)
Dibenzofuran *Fluorene 4-Chlorophenyl-phenylether 4-Bromophenyl-phenylether Carbazole	4,6-Dinitro-2-methylphenol	Hexachlorobenzene Atrazine *Phenanthrene *Anthracene
Pyrene-d ₁₀ (DMC-16)	Benzo(a)pyrene-d ₁₂ (DMC-17)	
*Fluoranthene	3,3'-Dichlorobenzidine	
*Pyrene	*Benzo(b)fluoranthene	
*Benzo(a)anthracene	*Benzo(k)fluoranthene	
*Chrysene	*Benzo(a)pyrene	
	*Indeno(1,2,3-cd)pyrene	
	*Dibenzo(a,h)anthracene	
	*Benzo(g,h,i)perylene	

^{*}Included in optional Target Analyte List (TAL) of PAHs and PCP only.

Table 9. Semivolatile SIM DMCs and the Associated Target Analytes

Fluoranthene-d10 (DMC-1)	2-Methylnaphthalene-d10 (DMC-2)
Fluoranthene	Naphthalene
Pyrene	2-Methylnaphthalene
Benzo(a)anthracene	Acenaphthylene
Chrysene	Acenaphthene
Benzo(b)fluoranthene	Fluorene
Benzo(k)fluoranthene	Pentachlorophenol
Benzo(a)pyrene	Phenanthrene
Indeno(1,2,3-ed)pyrene =	Anthracene
Dibenzo(a,h)anthracene	
Benzo(g,h,i)perylene	

All criteria were met _X
Criteria were not met
and/or see below

VII. A MATRIX SPIKE/MATRIX SPIKE DUPLICATE (MS/MSD)

This data is generated to determine long term precision and accuracy in the analytical method for various matrices. This data alone cannot be used to evaluate the precision and accuracy of individual samples. If any % R in the MS or MSD falls outside the designated range, the reviewer should determine if there are matrix effects, i.e. LCS data are within the QC limits but MS/MSD data are outside QC limit.

MS/MSD Recoveries and Precision Criteria

The laboratory should use one MS and a duplicate analysis of an unspiked field sample if target analytes are expected in the sample. If target analytes are not expected, MS/MSD should be analyzed.

NOTES:

Data for MS and MSDs will not be present unless requested by the Region. Notify the Contract Laboratory COR if a field or trip blank was used for the MS and MSD.

For a Matrix Spike that does not meet criteria, apply the action to only the field sample used to prepare the Matrix Spike sample. If it is clearly stated in the data validation materials that the samples were taken through incremental sampling or some other method guaranteeing the homogeneity of the sample group, then the entire sample group may be qualified.

List the %Rs, RPD of the compounds which do not meet the criteria.

Sample ID:J(Sample ID:J(Sample ID:J(C20784-	1			-		Matrix/l	_evel: _evel: _evel:	Soil	
The QC reporte JC20660-4, JC2		pplies to	the follo	wing sa	mples:			Method	: SW846	8270D
Compound	JC2078 ug/kg	84-1 Q	Spike ug/kg	MS ug/kg	MS %	Spike ug/kg	MSD ug/kg	MSD %	RPD	Limits Rec/RPD
Acenaphthene Acenaphthylene Anthracene Benzo(a)-	2750 96.6 5100	E	1920 1920 1920	2160 820 3300	-31* a 38 -94* c	1940 1940 1940	3740 1420 5590	51 68 25* c	54* b 54* b 52* b	34-125/36 28-113/34 31-131/41
anthracene Benzo(a)pyrene Benzo(b)-	8200 d 7830 d		1920 1920	4270 3380	-205* c -232* c		8320 7800	6* c -2* c	64* b 79* b	23-136/43 22-144/42
fluoranthene Benzo(g,h,i)-	9070 d		1920	4240	-251* c	1940	9700	32	78 * b	18-145/43
perylene Benzo(k)-	3840		1920	2050	-93* a	1940	5490	85	91* b	20-138/43
fluoranthene 4-Bromophenyl	3040		1920	1760	-67* a	1940	3850	42	75* b	27-129/43
phenyl ether	ND		1920	727	38* a	1940	1620	84	76* b	39-124/33

The QC reported here applies to the following samples: JC20660-4, JC20660-5

Method: SW846 8270D

Compound	JC2078 ug/kg	84-1 Q	Spike ug/kg	MS ug/kg	MS ,	Spike ug/kg	MSD ug/kg	MSD %	RPD	Limits Rec/RPD
Butyl benzyl-										
phthalate	ND		1920	769	40	1940	1460	75	62* b	27-143/35
1,1'-Biphenyl	ND		1920	959	50	1940	1630	84	52* b	33-116/32
2-Chloro-	MD		4000	707	00	40.40	4.400	7.4	0.54	00.440400
naphthalene Carbazole	ND ND		1920 1920	727 2790	38 145* a	1940 1940	1430	74 179* a	65* b	38-110/32
Chrysene	7090	E	1920	3740	-174* c		3470 7400	1/9 a 16* c	22 66* b	27-129/38 21-142/43
bis(2-Chloro-	7000	_	1020	3740	-114 0	1370	7400	10 0	00 D	21-172/73
isopropyl)ether	ND		1920	806	42	1940	1140	59	34* b	28-110/33
4-Chlorophenyl										
phenyl ether	ND		1920	745	39	1940	1410	73	62* b	38-119/33
2,4-Dinitrotoluene	ND		1920	924	48	1940	1410	73	42* b	28-126/36
Dibenzo(a,h)-	075		4000	005	0+ -	4040	0.400	70	00+1	05 405:44
anthracene Dibenzofuran	975 ND		1920 1920	935 2040	-2* a 106	1940 1940	2480 3150	78 162* a	90* b 43* b	25-135/41 30-125/35
Di-n-butyl	ND		1920	2040	100	1940	3130	102 a	43 U	30-120/30
phthalate	ND		1920	649	34	1940	1150	59	56* b	32-131/34
Di-n-octyl					•					02 10 170 1
phthalate	ND		1920	624	32	1940	1500	77	82* b	28-144/35
bis(2-Ethylhexyl)-										
phthalate	ND	_	1920	674	35	1940	1680	87	85* b	25-146/35
Fluoranthene	16300	E	1920	8760	-392* c	1940	14200	-108* c	47* b	15-143/46
Fluorene Hexachloro-	3050		1920	2390	-34* a	1940	3940	46	49* b	30-129/37
benzene	ND		1920	434	23* a	1940	1640	85	116* b	34-125/34
Hexachloro-	110		1020	707	25 0	1370	10-10	03	110 0	J-125/54
butadiene	ND		1920	482	25* a	1940	1250	64	89* b	29-120/34
Hexachlorocyclo-										
pentadiene	ND		3840	293	8* a	3880	936	24	105* b	10-127/46
Hexachloroethane	ND		1920	557	29	1940	1330	69	82* b	21-109/38
Indeno(1,2,3-cd)-	4470	_	4000	0.400	400+ -	4040	0400	404	00+1	00 44444
pyrene 2-Methyl-	4470	E	1920	2490	-103* c	1940	6490	104	89* b	23-141/44
naphthalene	675		1920	1280	31	1940	1920	64	40* b	21-125/33
N-Nitrosodiphenyl			1020	1200	01	1040	1020	04	40 D	21-120/00
amine	ND		1920	938	49	1940	1590	82	52* b	24-142/35
Phenanthrene	14800	Е	1920	10100	-245* c	1940	15700	46	43	14-144/44
Pyrene	13000	E	1920	9120	-202* c	1940	17100	211* c	61* b	16-147/46
1,2,4,5-Tetrachlor			4000	E00	20+	4040	4556	00	0441	07 //
benzene	ND		1920	583	30* a	1940	1550	80	91* b	37-115/32

- (a) Outside control limits due to matrix interference.
- (b) Analytical precision exceeds in-house control limits.
- (c) Outside control limits due to high level in sample relative to spike amount.
- (d) Result is from Run #2.

Note: No action taken, MS/MSD results apply to unspiked sample. Unspiked sample was from another project.

The QC reported here applies to the following samples:

Method: SW846 8270D BY SIM

JC20660-4, JC20660-5

Compound	JC2066 ug/kg		Spike ug/kg	MS ug/kg	MS %	Spike ug/kg	MSD ug/kg	MSD %	RPD	Limits Rec/RPD
1,4-Dioxane	ND	В	209	13.7	7* b	209	16.4	8* b	18	50-150/30
Naphthalene	12.6		41.9	36.3	57	41.7	36.6	57	1	10-190/36

⁽a) Method Blank had been contaminated. There is no sample left to re-extract for confirmation.

Note: 1,4-dioxane not detected in sample JC20660-4. Non-detects are rejected (R).

No MS/MSD performed for aqueous samples analyzed by the SIM technique. No action taken, blank spike/blank spike duplicate used to assess accuracy. % recoveries within laboratory control limits. RPD was outside laboratory control limit. No qualifications made based on RPD, professional judgment.

- * QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- * If QC limits are not available, use limits of 70 130 %.

Actions:

QUALITY	%R < LL	%R > UL
Positive results	J	J
Nondetects results	R	Accept

MS/MSD criteria apply only to the unspiked sample, its dilutions, and the associated MS/MSD samples:

If the % R for the affected compounds were < LL (or 70 %), qualify positive results (J) and nondetects (UJ).

If the % R for the affected compounds were > UL (or 130 %), only qualify positive results (J).

If 25 % or more of all MS/MSD %R were < LL (or 70 %) or if two or more MS/MSD %Rs were < 10%, qualify all positive results (J) and reject nondetects (R).

A separate worksheet should be used for each MS/MSD pair.

^{*} Outside control limit.

⁽b) Outside control limits due to matrix interference.

^{*} Outside control limit.

All criteria were met _X	
Criteria were not met	
and/or see below	

INTERNAL STANDARD PERFORMANCE

The assessment of the internal standard (IS) parameter is used to assist the data reviewer in determining the condition of the analytical instrumentation.

List the internal standard area of samples which do not meet the criteria.

DATE SAMPLE ID IS OUT IS AREA ACCEPTABLE ACTION RANGE

Internal area meets the required criteria of batch samples corresponding to this data package.

Action:

- If an internal standard area count for a sample or blank is greater than 200.0% of the area for the associated standard (opening CCV or mid-point standard from initial calibration) (see Table 10 below):
 - a. Qualify detects for compounds quantitated using that internal standard as estimated low (J-).
 - Do not qualify non-detected associated compounds.
- 2. If an internal standard area count for a sample or blank is less than 20.0% of the area for the associated standard (opening CCV or mid-point standard from initial calibration):
 - a. Qualify detects for compounds quantitated using that internal standard as estimated high (J+).
 - b. Qualify non-detected associated compounds as unusable (R).
- If an internal standard area count for a sample or blank is greater than or equal to 50.0%, and less than or equal to 200% of the area for the associated standard opening CCV or mid-point standard from initial calibration, no qualification of the data is necessary.
- 4. If an internal standard RT varies by more than 10.0 seconds: Examine the chromatographic profile for that sample to determine if any false positives or negatives exist. For shifts of a large magnitude, the reviewer may consider partial or total rejection of the data for that sample fraction. Detects should not need to be qualified as unusable (R) if the mass spectral criteria are met.
- 5. If an internal standard RT varies by less than or equal to 10.0 seconds, no qualification of the data is necessary.

Note: Inform the Contract Laboratory Program Project Officer (CLP PO) if the internal standard performance criteria are grossly exceeded. Note in the Data Review Narrative potential effects on the data resulting from unacceptable internal standard performance.

State in the Data Review Narrative if the required internal standard compounds are not added to a sample or blank or if the required internal standard compound is not analyzed at the specified concentration.

Actions:

Table 10. Internal Standard Actions for Semivolatile Analysis

Criteria	Action	
Criteria	Detect	Non-detect
Area response < 20% of the opening CCV or mid-point standard CS3 from ICAL	J+	R
20% ≤ Area response ≤ 50% of the opening CCV or mid-point standard CS3 from ICAL	3+	Ü
50% ≤ Area response ≤ 200% of the opening CCV or mid-point standard CS3 from ICAL	No qualification	No qualification
Area response > 200% of the opening CCV or mid-point standard CS3 from ICAL	J-	No qualification
RT shift between sample/blank and opening CCV or mid-point standard CS3 from ICAL > 10.0 seconds	R	R
RT shift between sample/blank and opening CCV or mid-point standard CS3 from ICAL < 10.0 seconds	No qualification	No qualification

		All criteria were metX Criteria were not met and/or see below
TARGET COI	MPOUND IDENTIFICATION	
Criteria:		
		ounds within ±0.06 RRT units of the standard CV) or mid-point standard from the initia Yes? or No?
List compoun	ds not meeting the criteria described above:	
Sample ID	Compounds	Actions
spectrum from	m the associated calibration standard (openust match according to the following criteria. All ions present in the standard mass sp must be present in the sample spectrum. The relative intensities of these ions mus sample spectra (e.g., for an ion with an the corresponding sample ion abundance lons present at greater than 10% in the	ectrum at a relative intensity greater than 10% tagree within ±20% between the standard and abundance of 50% in the standard spectrum.
List compoun	ds not meeting the criteria described above:	
Sample ID	Compounds	Actions
_ldentified_co	pmpounds_meet_the_required_criteria	

Action:

- 1. The application of qualitative criteria for GC/MS analysis of target compounds requires professional judgment. It is up to the reviewer's discretion to obtain additional information from the laboratory. If it is determined that incorrect identifications were made, qualify all such data as unusable (R).
- 2. Use professional judgment to qualify the data if it is determined that cross-contamination has occurred.
- Note in the Data Review Narrative any changes made to the reported compounds or concerns regarding target compound identifications. Note, for Contract Laboratory COR action, the necessity for numerous or significant changes.

TENTATIVELY IDENTIFIED COMPOUNDS (TICS)

NOTE: Tentatively identified compounds should only be evaluated when requested by a party from outside of the Hazardous Waste Support Section (HWSS).

List	T	ICs
------	---	-----

Sample ID	Compound	Sample ID	Compound

Action:

- 1. Qualify all TIC results for which there is presumptive evidence of a match (e.g. greater than or equal to 85% match) as tentatively identified (NJ), with approximated concentrations. TICs labeled "unknown" are qualified as estimated (J).
- 2. General actions related to the review of TIC results are as follows:
 - a. If it is determined that a tentative identification of a non-target compound is unacceptable, change the tentative identification to "unknown" or another appropriate identification, and qualify the result as estimated (J).
 - b. If all contractually-required peaks were not library searched and quantitated, the Region's designated representative may request these data from the laboratory.
- 3. In deciding whether a library search result for a TIC represents a reasonable identification, use professional judgment. If there is more than one possible match, report the result as "either compound X or compound Y". If there is a lack of isomer specificity, change the TIC result to a nonspecific isomer result (e.g., 1,3,5-trimethyl benzene to trimethyl benzene isomer) or to a compound class (e.g., 2-methyl, 3-ethyl benzene to a substituted aromatic compound).
- 4. The reviewer may elect to report all similar compounds as a total (e.g., all alkanes may be summarized and reported as total hydrocarbons).

- 5. Target compounds from other fractions and suspected laboratory contaminants should be marked as "non-reportable".
- 6. Other Case factors may influence TIC judgments. If a sample TIC match is poor, but other samples have a TIC with a valid library match, similar RRT, and the same ions, infer identification information from the other sample TIC results.
- 7. Note in the Data Review Narrative any changes made to the reported data or any concerns regarding TIC identifications.
- 8. Note, for Contract Laboratory COR action, failure to properly evaluate and report TICs

All criteria were metX
Criteria were not met
and/or see below

SAMPLE QUANTITATION AND REPORTED CONTRACT REQUIRED QUANTITATION LIMITS (CRQLS)

Action:

- 1. When a sample is analyzed at more than one dilution, the lower CRQL are used unless a QC exceedance dictates the use of higher CRQLs from the diluted sample. Samples reported with an "E" qualifier should be reported from the diluted sample.
- 2. If any discrepancies are found, the Region's designated representative may contact the laboratory to obtain additional information that could resolve any differences. If a discrepancy remains unresolved, the reviewer must use professional judgment to decide which value is the most accurate. Under these circumstances, the reviewer may determine that qualification of data is warranted. Note in the Data Review Narrative a description of the reasons for data qualification and the qualification that is applied to the data.
- 3. For non-aqueous samples, if the solids is less than 10.0%, use professional judgment for both detects and non-detects. If the percent solid for a soil sample is greater than or equal to 10.0% and less than 30.0%, use professional judgment to qualify detects and non-detects. If the percent solid for a soil sample is greater than or equal to 30.0%, detects and non-detects should not be qualified (see Table 11).
- 4. Note, for Contract Laboratory COR action, numerous or significant failures to accurately quantify the target compounds or to properly evaluate and adjust CRQLs.
- 5. Results between MDL and CRQL should be qualified as estimated "J".
- 6. Results < MDL should be reported at the CRQL and qualified "U". MDLs themselves should not be reported.

Table 11. Percent Solids Actions for Semivolatile Analysis for Non-Aqueous Samples

Criteria -	Ac	Action		
	Detects	Non-detects		
%Solids < 10.0%	Use professional judgment	Use professional judgment		
10.0% ≤ %Solids ≤ 30.0%	Use professional judgment	Use professional judgment		
%Solids > 30.0%	No qualification	No qualification		

SAMPLE QUANTITATION

The sample quantitation evaluation is to verify laboratory quantitation results. In the space below, please show a minimum of one sample calculation:

QUANTITATION LIMITS

A. Dilution performed

SAMPLE ID	DILUTION FACTOR	REASON FOR DILUTION
· · · · · · · · · · · · · · · · · · ·		

All criteria were metN/A	
Criteria were not met	
and/or see below	

FIELD DUPLICATE PRECISION

Sample IDs: _	JC20660-1/JC20660-2	Matrix:	_Groundwater	
---------------	---------------------	---------	--------------	--

Field duplicates samples may be taken and analyzed as an indication of overall precision. These analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples.

The project QAPP should be reviewed for project-specific information.

Suggested criteria: if large RPD (> 50 %) is observed, confirm identification of the samples and note differences. If both samples and duplicate are <5 SQL, the RPD criteria is doubled.

COMPOUND	SQL ug/L	SAMPLE CONC.	DUPLICATE CONC.	RPD	ACTION				
	Field duplicate analyzed as part of this data package. RPD within the required criteria < 50 % for detected target analytes.								

All criteria were met _X
Criteria were not met
and/or see below

OTHER ISSUES

Sample ID	Comments	Actions
Action:		
Use professional jud during sample anal		nined that system performance has degrad y Program COR any action as a result cted the data.
Use professional jud during sample anal degradation of syste	yses. Inform the Contract Laborato m performance which significantly afformation in the contract of the contr	y Program COR any action as a result
during sample anal degradation of system B. Overall Asse	yses. Inform the Contract Laborato m performance which significantly afformation in the contract of the contr	y Program COR any action as a result

Action:

- 1. Use professional judgment to determine if there is any need to qualify data which were not qualified based on the Quality Control (QC) criteria previously discussed.
- 2. Write a brief narrative to give the user an indication of the analytical limitations of the data. Inform the Contract Laboratory COR the action, any inconsistency of the data with the Sample Delivery Group (SDG) Narrative. If sufficient information on the intended use and required quality of the data is available, the reviewer should include their assessment of the usability of the data within the given context. This may be used as part of a formal Data Quality Assessment (DQA).
- 3. Sometimes, due to dilutions, re-analysis or SIM/Scan runs are being performed, there will be multiple results for a single analyte from a single sample. The following criteria and professional judgment are used to determine which result should be reported:
 - The analysis with the lower CRQL
 - The analysis with the better QC results
 - The analysis with the higher results

EXECUTIVE NARRATIVE

SDG No:

JC20660

Laboratory:

Accutest, Florida

Analysis:

SW846-8015C

Number of Samples:

Location:

BMSMC, Building 5 Area

Humacao, PR

SUMMARY:

Six (6) samples were analyzed for the low molecular weight alcohols (LMWAs) list following method SW846-8015C. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence: "Test Methods for Evaluating Solid Waste, Physical/Chemical Methods SW-846 (Final Update III, December 1996)," specifically for Methods 8000/8015C are utilized. The QC criteria and data validation actions listed on the data review worksheets are from the primary

guidance document, unless otherwise noted.

Results are valid and can be used for decision making purposes.

Critical issues:

None

Major:

None

Minor:

None

Critical findings:

None

Major findings:

None

Minor findings:

None

COMMENTS:

Results are valid and can be used for decision making purposes.

Reviewers Name:

Rafael Infante

Chemist License 1888

Signature:

Date:

June 16, 2016

SAMPLE ORGANIC DATA SAMPLE SUMMARY

Sample ID: JC20660-1

Sample location: BMSMC Building 5 Area

Sampling date: 5/13/2016

Matrix: AQ - Equipment Blank

METHOD: 8015C

Analyte Name	Result	Units	Dilution Factor	Lab Flag	Validation	Reportable
Ethanol	100	ug/l	1.0	-	U	Yes
Isobutyl Alcohol	100	ug/l	1.0	-	U	Yes
Isopropyl Alcohol	100	ug/l	1.0	-	U	Yes
n-Propyl Alcohol	100	ug/l	1.0	-	U	Yes
n-Butyl Alcohol	100	ug/l	1.0	-	U	Yes
sec-Butyl Alcohol	100	ug/l	1.0	-	U	Yes
Methanol	200	ug/l	1.0	-	U	Yes

Sample ID: JC20660-2

Sample location: BMSMC Building 5 Area

Sampling date: 5/18/2016

Matrix: Groundwater

METHOD: 8015C

Analyte Name	Result	Units	Dilution Factor	Lab Flag	Validation	Reportable
Ethanol	100	ug/l	1.0	-	U	Yes
Isobutyi Alcohol	100	ug/l	1.0	-	U	Yes
Isopropyl Alcohol	100	ug/l	1.0	-	U	Yes
n-Propyl Alcohol	100	ug/l	1.0	-	U	Yes
n-Butyl Alcohol	100	ug/l	1.0	-	U	Yes
sec-Butyl Alcohol	100	ug/l	1.0	-	U	Yes
Methanol	200	ug/l	1.0	-	U	Yes

Sample ID: JC20660-3

Sample location: BMSMC Building 5 Area

Sampling date: 5/18/2016 Matrix: Groundwater

METHOD: 8015C

Analyte Name	Result	Units	Dilution Factor	Lab Flag	Validation	Reportable
Ethanol	100	ug/l	1.0	-	U	Yes
Isobutyl Alcohol	100	ug/l	1.0	-	U	Yes
Isopropyl Alcohol	100	ug/l	1.0	-	U	Yes
n-Propyl Alcohol	100	ug/l	1.0	-	U	Yes
n-Butyl Alcohol	100	ug/l	1.0	-	U	Yes
sec-Butyl Alcohol	100	ug/l	1.0	-	U	Yes
Methanol	200	ug/l	1.0	-	U	Yes

Sample ID: JC20660-4

Sample location: BMSMC Building 5 Area

Sampling date: 5/19/2016

Matrix: Soil

METHOD: 8015C

Analyte Name	Result	Units	Dilution Factor	Lab Flag	Validation	Reportable
Ethanol	120	ug/kg	1.0	-	U	Yes
isobutyl Alcohoi	120	ug/kg	1.0	-	U	Yes
Isopropyl Alcohol	120	ug/kg	1.0	-	U	Yes
n-Propyl Alcohol	120	ug/kg	1.0	-	U	Yes
n-Butyl Alcohol	120	ug/kg	1.0	-	U	Yes
sec-Butyl Alcohol	120	ug/kg	1.0	-	υ	Yes
Methanol	250	ug/kg	1.0	-	U	Yes

Sample ID: JC20660-5

Sample location: BMSMC Building 5 Area

Sampling date: 5/19/2016

Matrix: Soil

METHOD: 8015C

Analyte Name	Result	Units	Dilution Factor	Lab Flag	Validation	Reportable
Ethanol	120	ug/kg	1.0	-	U	Yes
Isobutyl Alcohol	120	ug/kg	1.0	-	U	Yes
Isopropyl Alcohol	120	ug/kg	1.0	-	U	Yes
n-Propyl Alcohol	120	ug/kg	1.0	-	U	Yes
n-Butyl Alcohol	120	ug/kg	1.0	-	U	Yes
sec-Butyl Alcohol	120	ug/kg	1.0	-	U	Yes
Methanol	250	ug/kg	1.0	-	U	Yes

Sample ID: JC20660-6

Sample location: BMSMC Building 5 Area

Sampling date: 5/19/2016 Matrix: Groundwater

METHOD: 8015C

Analyte Name	Result	Units	Dilution Factor	Lab Flag	Validation	Reportable	
Ethanol	100	ug/l	1.0	-	U	Yes	
Isobutyl Alcohol	100	ug/l	1.0	-	U	Yes	
Isopropyl Alcohol	100	ug/l	1.0	-	U	Yes	
n-Propyl Alcohol	100	ug/l	1.0	-	U	Yes	
n-Butyl Alcohol	100	ug/l	1.0	-	U	Yes	
sec-Butyl Alcohol	100	ug/l	1.0	-	U	Yes	
Methanol	200	ug/l	1.0	-	U	Yes	

	Project Number:JC20660
	Date:05/13-19/2016
	Shipping Date:05/19/2016
	EPA Region:2
REVIEW OF VOLATILE Of the following guidelines for evaluating volatile organics were document will assist the reviewer in using professional judicerving the needs of the data users. The sample results guidance documents in the following order of precedents and Judicell'Chemical Methods SW-846 (Final Update III, Decentialized. The QC criteria and data validation actions listed guidance document, unless otherwise noted. The hardcopied (laboratory name) _Accutest	PRGANIC PACKAGE e created to delineate required validation actions. This igner to make more informed decision and in better were assessed according to USEPA data validation ence: "Test Methods for Evaluating Solid Waste, ember 1996)," specifically for Methods 8000/8015C are on the data review worksheets are from the primary data package received has been reviewed
The same state of the same sta	
_ab. Project/SDG No.:JC20660	_ Sample matrix:SoilGroundwater
No. of Samples:6	_
Trip blank No.:	
Field blank No.:	
Equipment blank No.:JC20660-1	
Field duplicate No.:	
X Data CompletenessX Holding TimesN/A_ GC/MS TuningN/A_ Internal Standard PerformanceX BlanksX Surrogate RecoveriesX Matrix Spike/Matrix Spike Duplicate	X Laboratory Control SpikesX Field DuplicatesX CalibrationsX Compound IdentificationsX Compound QuantitationX Quantitation Limits
Overall Comments:_Low_molecular_weight_alc	ohols_by_SW-846_8015C
Definition of Qualifiers: J- Estimated results U- Compound not detected R- Rejected data UJ- Estimated nondetect Reviewer: Date:June_16, 2016	

DATA COMPLETENESS

MISSING INFORMATION	DATE LAB. CONTACTED	DATE RECEIVED
		· · · · · · · · · · · · · · · · · · ·
	0 0 0 0 0	
200 200		
	1	·-

All criteria were met _	X_	_
Criteria were not met		
and/or see below		

HOLDING TIMES

The objective of this parameter is to ascertain the validity of the results based on the holding time of the sample from time of collection to the time of analysis.

Complete table for all samples and note the analysis and/or preservation not within criteria

SAMPLE ID	DATE SAMPLED	DATE ANALYZED	pН	ACTION	
All samples analy preserved.	zed within the re	commended method	holding ti	me. All samples pr	operly
	s				
				-	
	1	 	+		

Criteria

Aqueous samples – 14 days from sample collection for preserved samples (pH \leq 2, 4°C), no air bubbles.

Aqueous samples – 7 days from sample collection for unpreserved samples, 4°C, no air bubbles.

Soil samples- 7 days from sample collection.

Cooler temperature (Criteria: 4 + 2 °C): 5.3°C

Actions

If the VOCs vial(s) have air bubbles, estimate positive results (J) and reject nondetects (R).

If the % solids of soil samples is 10-50%, estimates positive results (J) and nondetects (UJ)

If the % solid of soil samples is < 10%, estimate positive results (J) and reject nondetects (R).

If holding times are exceeded but < 14 days beyond criteria, estimate positive results (J) and nondetects (UJ).

If holding times are exceeded but < 28 days beyond criteria, estimate positive results (J) and reject nondetects (R).

If holding times are grossly exceeded (> 28 days beyond criteria), reject all results (R).

If samples were not iced or if the ice were melted (> 10°C), estimate positive results (J) and nondetects (UJ).

All criteria were metN/A Criteria were not met see below
mentation is within the standard
hin the specified criteria.
•
ta chould be accopted gualified

GC/MS TUNING

GC/MS TUNING
The assessment of the tuning results is to determine if the sample instrumentation is within the standard tuning QC limits
N/A_ The BFB performance results were reviewed and found to be within the specified criteria.
N/A_ BFB tuning was performed for every 12 hours of sample analysis.
If no, use professional judgment to determine whether the associated data should be accepted, qualified or rejected.
List the samples affected:
If mass calibration is in error, all associated data are rejected

All criteria were metX
Criteria were not met
and/or see below

CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

		Dates of continuing Dates of final calib Instrument ID num	g calibration:_05/17/16 ration verification:05	/17/16 (initial);_05/20/16;_05/23/16_ /20/16;_05/23/16 GCGH DW
DATE	LAB FILE ID#	CRITERIA OUT RFs, %RSD, %D, r	COMPOUND	SAMPLES AFFECTED
		775		

Note: Initial, continuing, and final calibration verifications meets method specific criteria in at least one of the column, second column used for confirmation only.

Criteria

All RFs must be > 0.05 regardless of method requirements for SPCC.

All %RSD must be \leq 15 % regardless of method requirements for CCC.

All %Ds must be < 20% regardless of method requirements for CCC.

It should be noted that Region 2 SOP HW-24 does not specify criterion for the curve correlation coefficient (r). A limit for r of \geq 0.995 has therefore been utilized as professional judgment.

Actions

If any compound has an initial RF or a continuing RF of < 0.05, estimate positive results (J) and reject nondetects (R), regardless of method requirements.

If any compound has a %RSD > 15%, estimate positive results (J) and use professional judgment to qualify nondetects.

If any compound has a %RSD > 90%, estimate positive results (J) and reject nondetects (R).

If any compound has a % D > 20%, estimate positive results (J) and reject nondetects (R).

If any compound has a % D > 20%, estimate positive results (J) and nondetects (UJ).

If any compound has a % D > 90%, estimate positive results (J) and reject nondetects (R).

If any compound has r < 0.995, estimate positive results and nondetects.

A separate worksheet should be filled for each initial curve

All criteria were met _X
Criteria were not met
and/or see below

V A. BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including trip, equipment, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamination in the blanks below. High and low levels blanks must be treated separately.

Laboratory blanks

DATE ANALYZED	LAB ID	LEVEL/ MATRIX	COMPOUND	CONCENTRATION UNITS
Field/ <u>Equipmen</u>				
DATE ANALYZED	LAB ID	LEVEL/ MATRIX	COMPOUND	CONCENTRATION UNITS
_package				_blanks_included_in_this_data
		<u> </u>	72200 to	

All criteria were met _X
Criteria were not met
and/or see below

VB. BLANK ANALYSIS RESULTS (Section 3)

Blank Actions

Action Levels (ALs) should be based upon the highest concentration of contaminant determined in any blank. Do not qualify any blank with another blank. The ALs for samples which have been diluted should be corrected for the sample dilution factor and/or % moisture, where applicable. No positive sample results should be reported unless the concentration of the compound in the samples exceeds the ALs:

ALs = 10x the amount of common contaminants (methylene chloride, acetone, 2-butanone, and toluene) ALs = 5x for any other compounds

Specific actions are as follows:

If the concentration is < sample quantitation limit (SQL) and \le AL, report the compound as not detected (U) at the SQL.

If the concentration is \geq SQL but \leq AL, report the compound as not detected (U) at the reported concentration.

If the concentration is \geq SQL and > AL, report the concentration unqualified.

Notes:

High and low level blanks must be treated separately

Compounds qualified "U" for blank contamination are still considered "hits" when qualifying for calibration criteria.

CONTAMINATION SOURCE/LEVEL	COMPOUND	CONC/UNITS	AL/UNITS	SQL	AFFECTED SAMPLES
				edi .	
-					

All criteria were metX
Criteria were not met
and/or see below

SURROGATE SPIKE RECOVERIES

Laboratory performance of individual samples is established by evaluation of surrogate spike recoveries. All samples are spiked with surrogate compounds prior to sample analysis. The accuracy of the analysis is measured by the surrogate percent recovery. Since the effects of the sample matrix are frequently outside the control of the laboratory and may present relatively unique problems, the validation of data is frequently subjective and demands analytical experience and professional judgment.

List the percent recoveries (%Rs) which do not meet the criteria for surrogate recovery. Matrix: solid/aqueous

SAMPLE ID		SURROG	ATE COMPOUND)	ACTION
	Hexanol	DBFM	TOL-d8	BFB	
_All_surrogate_	recoveries_withir	n_laboratory_co	ontrol_limits		5
	3 325				
				21 (3)	
QC Limits* (Aqu	Jeous)				
	JL73_to_ ⁻	123to_	to	to	-
LL_to_L	JL69_to_	121to_	to_	to	_
QC Limits* (Soli	la-mea) JL to_	to	to	to	_
	Dichloromethane- nofluoromethane	d4		s = Toluene-d8 Bromofluorobenze	ene
			mance criteria, LL of 80 – 120 % for		
samples.				•	
Actions:					
QUALI	TY	%R < 10%	%R = 1	0% - LL	> UL
Positiv	e results	J	J	J	
Nonde	tects results	R	UJ	Acce	ept

Surrogate action should be applied:

If one or more surrogate in the VOC fraction is out of specification, but has a recovery of > 10%. If any one surrogate in a fraction shows < 10 % recovery.

All criteria were met _X
Criteria were not met
and/or see below

VII. A MATRIX SPIKE/MATRIX SPIKE DUPLICATE (MS/MSD)

This data is generated to determine long term precision and accuracy in the analytical method for various matrices. This data alone cannot be used to evaluate the precision and accuracy of individual samples. If any % R in the MS or MSD falls outside the designated range, the reviewer should determine if there are matrix effects, i.e. LCS data are within the QC limits but MS/MSD data are outside QC limit.

1. MS/MSD Recoveries and Precision Criteria

The laboratory should use one MS and a duplicate analysis of an unspiked field sample if target analytes are expected in the sample. If target analytes are not expected, MS/MSD should be analyzed.

List the %Rs, RPD of the compounds which do not meet the criteria.

Sample ID:JC20202-1MS/-MSD Sample ID:JC20660-5MS/-MSD					Groundwater/owSoil/ow	
MS OR MSD	COMPOUND	% R		QC LIMITS	ACTION	
MS/MSD%_red	overies_and_RPD_	within_lab	oratory_	control_limits		
	- V					

- * QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit.
- * If QC limits are not available, use limits of 70 130 %.

Actions:

QUALITY	%R < LL	%R > UL
Positive results	J	J
Nondetects results	R	Accept

All criteria were metX
Criteria were not met
and/or see below

MS/MSD criteria apply only to the unspiked sample, its dilutions, and the associated MS/MSD samples:

If the % R for the affected compounds were < LL (or 70 %), qualify positive results (J) and nondetects (UJ).

If the % R for the affected compounds were > UL (or 130 %), only qualify positive results (J). If 25 % or more of all MS/MSD %R were < LL (or 70 %) or if two or more MS/MSD %Rs were < 10%, qualify all positive results (J) and reject nondetects (R).

Note: No action taken, MS/MSD applies only the unspiked sample. Unspiked sample from another data package, used for QC purposes only

VII. B MATRIX SPIKE/MATRIX SPIKE DUPLICATE

MS/MSD - Unspiked Compounds

It should be noted that Region 2 SOP HW-24 does not specify a MS/MSD criteria for the unspiked compounds in the sample. A %RSD of < 50% has therefore been utilized as professional judgment.

If all target analytes were spiked in the MS/MSD, this review element is not applicable.

List the %RSD of the compounds which do not meet the criteria.

Sample ID:	- _		Matrix/Le	vei/Unit:		
COMPOUND	SAMPLE CONC.	MS CONC.	MSD CONC.	% RSD	ACTION	
						_
			<u> </u>			
- 400						
		100000		2020		

Actions:

A separate worksheet should be used for each MS/MSD pair.

^{*} If the % RSD > 50, qualify the positive result in the unspiked samples as estimated (J).

^{*} If the % RSD is not calculated (NC) due to nondetected value, use professional judgment to qualify the data.

All criteria were met _X
Criteria were not met
and/or see below

VIII. LABORATORY CONTROL SAMPLE (LCS) ANALYSIS

This data is generated to determine accuracy of the analytical method for various matrices.

1. LCS Recoveries Criteria

Where LCS spiked with the same analyte at the same concentrations as the MS/MSD? Yes or No. If no make note in data review memo.

List the %R of compounds which do not meet the criteria

	LCS ID	COMPOUND	% R	QC LIMIT	
Recoveri	es_within_labor	ratory_control_limits			
	- 1000 p				
				-Wall 1992 100 100	

- * QC limits are laboratory in-house performance criteria, LL = lower limit, UL = upper limit
- * If QC limits are not available, use limits of 70 130 %.

Actions:

QUALITY	%R < LL	%R > UL
Positive results	J	J
Nondetects results	R	Accept

All analytes in the associated sample results are qualified for the following criteria.

If 25 % of the LCS recoveries were < LL (or 70 %), qualify all positive results (j) and reject nondetects (R).

If two or more LCS were below 10 %, qualify all positive results as (J) and reject nondetects (R).

2. Frequency Criteria:

Where LCS analyzed at the required frequency and for each matrix? <u>Yes</u> or No. If no, the data may be affected. Use professional judgment to determine the severity of the effect and qualify data accordingly. Discuss any actions below and list the samples affected.

		All critena were metN/A Criteria were not met and/or see below
IX.	FIELD/LABORATORY DUPLICATE PRECISION	
	Sample IDs:	Matrix:

Field/laboratory duplicates samples may be taken and analyzed as an indication of overall precision. These analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples.

The project QAPP should be reviewed for project-specific information.

Suggested criteria: RPD + 30% for aqueous samples. RPD + 50 % for solid samples.

Suggested criteria: RPD \pm 30% for aqueous samples, RPD \pm 50 % for solid samples. If both samples and duplicate are <5 SQL, the RPD criteria is doubled.

COMPOUND	SQL	SAMPLE CONC.	DUPLICATE CONC.	RPD	ACTION
No field/laboratory duplicate analyzed with this data package. MS/MSD % recoveries RPD used to assess precision. RPD within laboratory and generally acceptable control limits.					
				1	_
		141		<u> </u>	

Actions:

Qualify as estimated positive results (J) and nondetects (UJ) for the compound that exceeded the above criteria. For organics, only the sample and duplicate will be qualified.

If an RPD cannot be calculated because one or both of the sample results is not detected, the following actions apply:

If one sample result is not detected and the other is greater than 5x the SQL qualify (J/UJ).

If one sample value is not detected and the other is greater than 5x the SQL and the SQLs for the sample and duplicate are significantly different, use professional judgment to determine if qualification is appropriate.

If one sample value is not detected and the other is less than 5x, use professional judgment to determine if qualification is appropriate.

If both sample and duplicate results are not detected, no action is needed.

All criteria were met _	_N/A
Criteria were not met	
and/or see below	

X. INTERNAL STANDARD PERFORMANCE

The assessment of the internal standard (IS) parameter is used to assist the data reviewer in determining the condition of the analytical instrumentation.

List the internal standard area of samples which do not meet the criteria.

- * Area of +100% or -50% of the IS area in the associated calibration standard.
- * Retention time (RT) within 30 seconds of the IS area in the associated calibration standard.

DATE	SAMPLE ID	IS OUT	IS AREA	ACCEPTABLE RANGE	ACTION
			1		
					-

Actions:

1. IS actions should be applied to the compound quantitated with the out-of-control ISs

QUALITY	IS AREA < -25%	IS AREA = -25 % TO - 50%	IS AREA > + 100%
Positive results	J	J	J
Nondetected results	R	UJ	ACCEPT

2. If a IS retention time varies more than 30 seconds, the chromatographic profile for that sample must be examined to determine if any false positive or negative exists. For shifts of a large magnitude, the reviewer may consider partial or total rejection of the data for the sample fraction.

All criteria were metX
Criteria were not met
and/or see below

XII. SAMPLE QUANTITATION

The sample quantitation evaluation is to verify laboratory quantitation results. In the space below, please show a minimum of one sample calculation:

JC20660-5MS

isopropyl alcohol

[] = (102697)/(19.93)

= 5,153 ppm OK

All criteria were met _X
Criteria were not met
and/or see below

XII. QUANTITATION LIMITS

A. Dilution performed

SAMPLE ID	DILUTION FACTOR	REASON FOR DILUTION
100		

6 11
-

Actions:

If the % solids of a soil sample is 10-50%, estimate positive results (J) and nondetects (UJ)

If the % solids of a soil sample is < 10%, estimate positive results (J) and reject nondetects (R)

EXECUTIVE NARRATIVE

SDG No:

JC20660

Laboratory:

Accutest, New Jersey

Analysis:

SW846-8081B

Number of Samples:

: 2

Location:

BMSMC, Building 5 Area

Humacao, PR

SUMMARY:

Two (2) samples were analyzed for selected pesticides following method SW846-8081B. The sample results were assessed according to USEPA data validation guidance documents in the following order of precedence *Hazardous Waste Support Section SOP No. HW-36A, Revision 0, June, 2015. SOM02.2. Pesticide Data Validation.* The QC criteria and data validation actions listed on the data review worksheets are from the primary

guidance document, unless otherwise noted.

Results are valid and can be used for decision making purposes.

Critical issues:

None

Major:

None

Minor:

None

Critical findings:

None

Major findings:

None

Minor findings:

None

COMMENTS:

Results are valid and can be used for decision making purposes.

Reviewers Name:

Rafael Infante

Chemist License 1888

Signature:

June 16, 2016

Date:

SAMPLE ORGANIC DATA SAMPLE SUMMARY

Sample ID: JC20660-1

Sample location: BMSMC Building 5 Area

Sampling date: 13-May-16

Matrix: AQ - Equipment Blank

METHOD: 8081B

Analyte Name		Result	Units	Dilution Factor	Lab Flag	Validation	Reportable
Aldrin		0.011	ug/L	1	-	U	Yes
alpha-BHC		0.011	ug/L	1	-	U	Yes
beta-BHC		0.011	ug/L	1	-	U	Yes
delta-BHC		0.011	ug/L	1	-	U	Yes
gamma-BHC (Lindane)		0.011	ug/L	1	-	U	Yes
alpha-Chlordane		0.011	ug/L	1	-	U	Yes
gamma-Chlordane		0.011	ug/L	1	-	U	Yes
Dieldrin		0.011	ug/L	1	-	U	Yes
4,4'-DDD		0.011	ug/L	1	-	U	Yes
4,4'-DDE		0.011	ug/L	1	-	U	Yes
4,4'-DDT		0.011	ug/L	1 %	-	U	Yes
Endrin		0.011	ug/L	1	-	U	Yes
Endosulfan sulfate		0.011	ug/L	1	-	U	Yes
Endrin aldehyde		0.011	ug/L	1	-	U	Yes
Endrin ketone		0.011	ug/L	1	-	U	Yes
Endosulfan-I		0.011	ug/L	1	-	U	Yes
Endosulfan-II		0.011	ug/L	1	-	U	Yes
Heptachlor		0.011	ug/L	1	-	U	Yes
Heptachlor epoxide		0.011	ug/L	1	-	U	Yes
Methoxychlor		0.022	ug/L	1	-	UJ	Yes
Toxaphene	66	0.28	ug/L	1	-	U	Yes

Sample ID: JC20660-6

Sample location: BMSMC Building 5 Area

Sampling date: 19-May-16 Matrix: Groundwater

METHOD: 8081B

Analyte Name	Result	Units	Dilution Factor	Lab Flag	Validation	Reportable
Aldrin	0.010	ug/l	1	•	U	Yes
alpha-BHC	0.010	ug/l	1	-	U	Yes
beta-BHC	0.010	ug/l	1	-	U	Yes
delta-BHC	0.010	ug/l	1	-	U	Yes
gamma-BHC (Lindane)	0.010	ug/l	1	-	U	Yes
alpha-Chlordane	0.010	ug/l	1	-	U	Yes
gamma-Chlordane	0.010	ug/l	1	-	U	Yes
Dieldrin	0.010	ug/l	1	-	U	Yes
4,4'-DDD	0.010	ug/l	ı	-	Ų	Yes
4,4'-DDE	0.010	ug/l	1	-	U	Yes
4,4'-DDT	0.010	ug/l	1	-	U	Yes
Endrin	0.010	ug/l	1	-	U	Yes
Endosulfan sulfate	0.010	ug/l	1	-	U	Yes
Endrin aldehyde	0.010	ug/l	1	-	U	Yes
Endrin ketone	0.010	ug/l	1	-	U	Yes
Endosulfan-I	0.010	ug/l	1	-	U	Yes
Endosulfan-II	0.010	ug/l	1	-	U	Yes
Heptachlor	0.010	ug/l	1	-	U	Yes
Heptachlor epoxide	0.010	ug/l	1	-	U	Yes
Methoxychlor	0.020	ug/l	1	-	U	Yes
Toxaphene	0.25	ug/l	1	-	U	Yes

	Project/Case Number:JC20660
	Sampling Date:May_13-19,_2016
	Shipping Date:May_19,_2016
	EPA Region No.:2
REVIEW OF PESTICIDE ORG	GANIC PACKAGE
The following guidelines for evaluating volatile required validation actions. This document will as judgment to make more informed decision and i users. The sample results were assessed accord documents in the following order of precedence HW-36A, Revision 0, June, 2015. SOM02.2. Pesticidata validation actions listed on the data reviguidance document, unless otherwise noted.	ssist the reviewer in using professional in better serving the needs of the data ing to USEPA data validation guidance dazardous Waste Support Section SOP No. de Data Validation. The QC criteria and
The hardcopied (laboratory name) _Accutest reviewed and the quality control and performance data sumn	data package received has been narized. The data review for VOCs included:
Lab. Project/SDG No.:JC20660 No. of Samples:2	Sample matrix:Aqueous
Trip blank No.:	
X Data CompletenessX Holding TimesN/A GC/MS TuningX_ Internal Standard PerformanceX BlanksX Surrogate RecoveriesX Matrix Spike/Matrix Spike Duplicate	X Laboratory Control SpikesX Field DuplicatesX CalibrationsX Compound IdentificationsX Compound QuantitationX Quantitation Limits
Overall Comments:TCL_pesticides_list_by_SW846-8	081B
Definition of Qualifiers: J- Estimated results U- Compound not detected R- Rejected data UJ- Estimated nondetect Reviewer: Date:June_16,_2016	

DATA COMPLETENESS

MISSING INFORMATION	DATE LAB. CONTACTED	DATE RECEIVED
		- E
<u> </u>		
A. A	100 T II. 2019 1073	
		<u> </u>
<u> </u>		
-		
	2.00	
5	5187 - 485.	

All criteria were met _X
Criteria were not met
and/or see below

HOLDING TIMES

The objective of this parameter is to ascertain the validity of the results based on the holding time of the sample from time of collection to the time of analysis.

Complete table for all samples and note the analysis and/or preservation not within criteria

SAMPLE ID	DATE SAMPLED	DATE EXTRACTED/ANALYZED	ACTION
Samples properly pr	eserved.		

Preservatives:	All_samples_extracted_and_analyzed_within_the_required_criteria

Criteria

Aqueous samples - seven (7) days from sample collection for extraction; 40 days from sample collection for analysis.

Non-aqueous samples – fourteen (14) days from sample collection for extraction; 40 days from sample collection for analysis.

Cooler temperature (Criteria: 4 + 2 °C): 5.3°C - OK

Actions

Qualify aqueous sample results using preservation and technical holding time information as follows:

- a. If there is no evidence that the samples were properly preserved ($T = 4^{\circ}C \pm 2^{\circ}C$), and the samples were extracted or analyzed within the technical holding times, qualify detects as estimated (J) and non-detects as estimated (UJ).
- b. If there is no evidence that the samples were properly preserved ($T = 4^{\circ}C \pm 2^{\circ}C$), and the samples were extracted or analyzed outside the technical holding times, qualify detects as estimated (J) and non-detects as estimated (UJ).
- c. If the samples were properly preserved, and were extracted and analyzed within the technical holding times, no qualification of the data is necessary.
- d. If the samples were properly preserved, and were extracted or analyzed outside the technical holding times, qualify detects as estimated (J) and non-detects as estimated (UJ). Note in the Data Review Narrative that holding times were exceeded and the effect of exceeding the holding time on the resulting data.

- e. Use professional judgment to qualify samples whose temperature upon receipt at the laboratory is either below 2 degrees centigrade or above 6 degrees centigrade.
- f. If technical holding times are grossly exceeded, use professional judgment to qualify the data.

Qualify non-aqueous sample results using preservation and technical holding time information as follows:

- a. If there is no evidence that the samples were properly preserved (T = 4° C \pm 2° C), and the samples were extracted or analyzed within the technical holding time, qualify detects as estimated (J) and non-detects as estimated (UJ).
- b. If there is no evidence that the samples were properly preserved ($T = 4^{\circ}C \pm 2^{\circ}C$), and the samples were extracted or analyzed outside the technical holding time, qualify detects as estimated (UJ) and non-detects as estimated (UJ).
- c. If the samples were properly preserved, and were extracted and analyzed within the technical holding time, no qualification of the data is necessary.
- d. If the samples were properly preserved, and were extracted or analyzed outside the technical holding time, qualify detects as estimated (J) and non-detects as estimated (UJ). Note in the Data Review Narrative that holding times were exceeded and the effect of exceeding the holding time on the resulting data.
- e. Use professional judgment to qualify samples whose temperature upon receipt at the laboratory is either below 2 degrees centigrade or above 6 degrees centigrade.
- f. If technical holding times are grossly exceeded, use professional judgment to qualify the data.

	All criteria were melX
Criteria	were not met see below

GAS CHROMATOGRAPH WITH ELECTRON CAPTURE DETECTOR (GC/ECD) INSTRUMENT PERFORMANCE CHECK (SECTIONS 1 TO 5)

1. Resolution Check Mixture

Criteria

is the resolution between two adjacent peaks in the Resolution Check Mixture C greater than or equal to 80.0% for all analytes for the primary column and greater than or equal to 50.0% for the confirmation column?

Yes? or No?

Is the resolution between two adjacent peaks in the Resolution Check Mixture (A and B) greater than or equal to 60.0%?

Yes? or No?

Note:

If resolution criteria are not met, the quantitative results may not be accurate due to inadequate resolution. Qualitative identifications may also be questionable if coelution exists.

Action

- a. Qualify detects for target compounds that were not adequately resolved as tentatively identified (NJ).
- b. Qualify non-detected compounds as unusable (R).

2. Performance Evaluation Mixture (PEM) Resolution Criteria

Criteria

Is PEM analysis performed at the required frequency (at the end of each pesticide initial calibration sequence and every 12 hours)?

Yes? or No?

Action

a. If PEM is not performed at the required frequency, qualify all associated sample and blank results as unusable (R).

Criteria

Is PEM % Resolution < 90%?

Yes? or No?

Action

- a. a. Qualify detects for target compounds that were not adequately resolved as tentatively identified (NJ).
- b. Qualify non-detected compounds as unusable (R).

	All criteria were metX_	
Criteria	were not met see below	

3. PEM 4,4'-DDT Breakdown

Criteria

Is the PEM 4,4'-DDT % Breakdown >20.0% and 4,4'-DDT is detected?

Yes? or No?

Action

a. Qualify detects for 4,4'-DDT; detects for 4,4'-DDD; and detects for 4,4'-DDE as estimated (J)

Criteria

Is the PEM 4,4'-DDT % Breakdown >20.0% and 4,4'-DDT is not detected

Yes? or No?

Action

- a. Qualify non-detects for 4,4'- DDT as unusable (R)
- b. Qualify detects for 4,4'-DDD as tentatively identified (NJ)
- c. Qualify detects for 4,4'-DDE as tentatively identified (NJ)

4. PEM Endrin Breakdown

Criteria

Is the PEM Endrin % Breakdown >20.0% and Endrin is detected?

Yes? or No?

Action

a. Qualify detects for Endrin; detects for Endrin aldehyde; and detects for Endrin ketone as estimated (J)

Criteria

Is the PEM Endrin % Breakdown >20.0% and Endrin is not detected

Yes? or No?

Action

- a. Qualify non-detects for Endrin as unusable (R)
- b. Qualify detects for Endrin aldehyde as tentatively identified (NJ)
- c. Qualify detects for Endrin ketone as tentatively identified (NJ)

	All criteria were met	X
Criteria	were not met see below	

5. Mid-point Individual Standard Mixture Resolution -

Criteria

Is the resolution between two adjacent peaks in the Resolution Check Mixture C greater than or equal to 80.0% for all analytes for the primary column and greater than or equal to 50.0% for the confirmation column?

Yes? or No?

Is the resolution between two adjacent peaks in the Resolution Check Mixture (A and B) greater than or equal to 90.0%?

Yes? or No?

Note: If resolution criteria are not met, the quantitative results may not be accurate due to inadequate resolution. Qualitative identifications may also be questionable if coelution exists.

Action

- a. Qualify detects for target compounds that were not adequately resolved as tentatively identified (NJ).
- b. Qualify non-detected compounds as unusable (R).

Criteria

Is mid-point individual standard mixture analysis performed at the required frequency (every 12 hours)?

Yes? or No?

Action

a. If the mid-point individual standard mixture analysis is not performed at the required frequency, qualify all associated sample and blank results as unusable (R).

All criteria were met _X			
Criteria were not met			
and/or see below			

CALIBRATION VERIFICATION

Compliance requirements for satisfactory instrument calibration are established to ensure that the instrument is capable of producing and maintaining acceptable quantitative data.

Date of initial calibration:05/16/16 Dates of initial calibration verification:05/16/16 Dates of continuing calibration:05/22/16;_05/23/16 Dates of final calibration05/22/16 Instrument ID numbers:GC1G Matrix/Level:Aqueous/low				6/16 :3/16	04/14/16 04/14/16 05/22/16 05/22/16 HP_G1530A Aqueous/low	
DATE	LAB ID#	FILE	CRITERIA OUT RFs, %RSD, %D, r	COMPOUND	SAMPLES AFFECTED	
Initial and initial calibration verification within the guidance document performance criteria. Continuing calibration % differences meet the performance criteria in at least one of the two columns. Final calibration verification included in data package.						

Criteria

Are a five point calibration curve delivered with concentration levels as shown in Table 3 of SOP HW-36A, Revision 0, June, 2015?

Yes? or No?

Actions

If the standard concentrations listed in Table 3 are not used, use professional judgment to evaluate the effect on the data

Criteria

Are RT Windows calculated correctly?

Yes? or No?

Action

Recalculate the windows and use the corrected values for all evaluations.

Criteria

Are the Percent Relative Standard Deviation (%RSD) of the CFs for each of the single component target compounds less than or equal to 20.0%, except for alpha-BHC and delta-BHC?

Yes? or No?

Are the %RSD of the CFs for alpha-BHC and delta-BHC less than or equal to 25.0%. Yes? or No?

Is the %RSD of the CFs for each of the Toxaphene peaks must be < 30% when 5-point ICAL is performed?

Yes? or No?

Is the %RSD of the CFs for the two surrogates (tetrachloro-m-xylene and decachlorobiphenyl) less than or equal to 30.0%.

Yes? or No?

Action

- a. If the %RSD criteria are not met, qualify detects as estimated (J) and use professional judgment to qualify non-detected target compounds.
- b. If the %RSD criteria are within allowable limits, no qualification of the data is necessary

Continuing Calibration Checks

Criteria

Is the continuing calibration standard analyzed at the acceptable time intervals? Yes? or No?

Action

- a. If more than 14 hours has elapsed from the injection of the instrument blank that begins an analytical sequence (opening CCV) and the injection of either a PEM or mid-point concentration of the individual Standard Mixtures (A and B) or (C), qualify all data as unusable (R).
- b. If more than 12 hours has elapsed from the injection of the instrument blank that begins an analytical sequence (opening CCV) and the injection of the last sample or blank that is part of the same analytical sequence, qualify all data as unusable (R).
- c. If more than 72 hours has elapsed from the injection of the sample with a Toxaphene detection and the Toxaphene Calibration Verification Standard (CS3), qualify all data as unusable (R).

Criteria

Is the Percent Difference (%D) within ±25.0% for the PEM sample?

Yes? or No?

Action

a. Qualify associated detects as estimated (J) and non-detects as estimated (UJ).

Criteria

For the Calibration Verification Standard (CS3); is the Percent Difference (%D) within ±25.0%?
Yes? or No?

Action

Qualify associated detects as estimated (J) and non-detects as estimated (UJ).

All criteria were met __X__ Criteria were not met and/or see below

Criteria

Is the PEM 4,4'-DDT % Breakdown >20.0% and 4,4'-DDT is detected?

Yes? or No?

Action

- a. Qualify detects for 4,4'-DDT; detects for 4,4'-DDD; and detects for 4,4'-DDE as estimated (J)
- b. Non-detected associated compounds are not qualified

Criteria

Is the PEM 4,4'-DDT % Breakdown >20.0% and 4,4'-DDT is not detected

Yes? or No?

Action

- a. Qualify non-detects for 4,4'- DDT as unusable (R)
- b. Qualify detects for 4,4'-DDD as tentatively identified (NJ)
- c. Qualify detects for 4,4'-DDE as tentatively identified (NJ)

Criteria

Is the PEM Endrin % Breakdown >20.0% and Endrin is detected?

Yes? or No?

Action

- a. Qualify detects for Endrin; detects for Endrin aldehyde; and detects for Endrin ketone as estimated (J)
- b. Non-detected associated compounds are not qualified

Criteria

Is the PEM Endrin % Breakdown >20.0% and Endrin is not detected

Yes? or No?

Action

- a. Qualify non-detects for Endrin as unusable (R)
- b. Qualify detects for Endrin aldehyde as tentatively identified (NJ)
- c. Qualify detects for Endrin ketone as tentatively identified (NJ)

A separate worksheet should be filled for each initial curve

All criteria were met _	Х_
Criteria were not met	
and/or see below	

BLANK ANALYSIS RESULTS (Sections 1 & 2)

The assessment of the blank analysis results is to determine the existence and magnitude of contamination problems. The criteria for evaluation of blanks apply only to blanks associated with the samples, including trip, equipment, and laboratory blanks. If problems with any blanks exist, all data associated with the case must be carefully evaluated to determine whether or not there is an inherent variability in the data for the case, or if the problem is an isolated occurrence not affecting other data.

List the contamir	nation in the bla	nks below. Hig	jh and low levels blanks	must be treated separately.
CRQL concentra	ationN	/A	2	
Laboratory blank	KS .			
DATE ANALYZED	LAB ID	LEVEL/ MATRIX	COMPOUND	CONCENTRATION UNITS
SCAL PARKS -	- 0.000		assa una Fina	nit_of_0.01_and_0.001_ug/L
Field/ <u>Equipment</u>	/Trip blank			
DATE ANALYZED	LAB ID	LEVEL! MATRIX	COMPOUND	CONCENTRATION UNITS
_data_package.			17	p_blanks_analyzed_with_this
2 2 20 2022				
			144	141 - 150 - 150 - 150

All criteria were met __X__ Criteria were not met and/or see below ____

BLANK ANALYSIS RESULTS (Section 3)

Blank Actions

Action Levels (ALs) should be based upon the highest concentration of contaminant determined in any blank. Do not qualify any blank with another blank. The ALs for samples which have been diluted should be corrected for the sample dilution factor and/or % moisture, where applicable. No positive sample results should be reported unless the concentration of the compound in the samples exceeds the ALs:

The concentration of non-target compounds in all blanks must be less than or equal to 10 μ g/L. The concentration of each target compound found in the method or field blanks must be less than its CRQL listed in the method.

Data concerning the field blanks are not evaluated as part of the CCS process. If field blanks are present, the data reviewer should evaluate this data in a similar fashion as the method blanks.

Specific actions are as follows:

Blank Actions for Pesticide Analyses

Blank Type Blank Result		Sample Result	Action for Samples	
	Detects	Not detected	No qualification required	
	< CRQL	< CRQL	Report CRQL value with a U	
		≥CRQL	No qualification required	
Method, Sulfur		< CRQL	Report CRQL value with a U	
Cleanup, Instrument, Field, TCLP/SPLP	> CRQL	≥ CRQL and ≤ blank concentration	Report blank value for sample concentration with a	
		≥ CRQL and > blank concentration	No qualification required	
	= CRQL	≤CRQL	Report CRQL value with a U	
		> CRQL	No qualification required	
	Gross contamination	Detects	Report blank value for sample concentration with a U	

All criteria were met _	_X	_
Criteria were not met		
and/or see below	_	

CONTAMINATION SOURCE/LEVEL	COMPOUND	CONC/UNITS	AL/UNITS	SQL	AFFECTED SAMPLES
		 			

All criteria were met __X__ Criteria were not met and/or see below ____

SURROGATE SPIKE RECOVERIES

Laboratory performance of individual samples is established by evaluation of surrogate spike recoveries. All samples are spiked with surrogate compounds prior to sample analysis. The accuracy of the analysis is measured by the surrogate percent recovery. Since the effects of the sample matrix are frequently outside the control of the laboratory and may present relatively unique problems, the validation of data is frequently subjective and demands analytical experience and professional judgment.

List the percent recoveries (%Rs) which do not meet the criteria for surrogate recovery.

Matrix:_Aqueou	s				
Lab Sample ID	Lab File ID	S1 a	S1 b	S2 a	S2 b
JC20660-1 JC20660-6 OP94098-BS1 OP94098-MB1 OP94098-MSD OP94129-BS1 OP94129-BSD OP94129-MB1	1G123361.D 6G35344.D 1G123359.D 1G123358.D 1G123378.D 1G123379.D 6G35342.D 6G35343.D 6G35341.D	73 70 101 87 86 82 82 73 79	71 70 95 83 83 82 80 72 78	51 37 110 92 67 64 87 80 88	53 38 110 92 75 74 89 81 92
Surrogate Compounds		Recov Limits	ery		
S1 = Tetrachloro-m-xylene S2 = Decachlorobiphenyl		26-132 10-118			
(a) Recovery from	om GC signal #1 om GC signal #2				

Note: Surrogate recoveries within laboratory control limits.

Actions:

- a. For any surrogate recovery greater than 150%, qualify detected target compounds as biased high (J+).
- b. Do not qualify non-detected target compounds for surrogate recovery > 150 %.
- c. If both surrogate recoveries are greater than or equal to 30% and less than or equal to 150%, no qualification of the data is necessary.
- d. For any surrogate recovery greater than or equal to 10% and less than 30%, qualify detected target compounds as biased low (J-).
- e. For any surrogate recovery greater than or equal to 10% and less than 30%, qualify non-detected target compounds as approximated (UJ).

- f. If low surrogate recoveries are from sample dilution, professional judgment should be used to determine if the resulting data should be qualified. If sample dilution is not a factor:
 - i. Qualify detected target compounds as biased low (J-).
 - ii. Qualify non-detected target compounds as unusable (R).
- g. If surrogate RTs in PEMs, Individual Standard Mixtures, samples, and blanks are outside of the RT Windows, the reviewer must use professional judgment to qualify data.
- h. If surrogate RTs are within RT windows, no qualification of the data is necessary.
- i. If the two surrogates were not added to all samples, MS/MSDs, standards, LCSs, and blanks, use professional judgment in qualifying data as missing surrogate analyte may not directly apply to target analytes.

Summary Surrogate Actions for Pesticide Analyses

	Action*		
Criteria	Detected Target Compounds	Non-detected Target Compounds	
%R > 150%	J+	No qualification	
30% < %R < 150%	No qualification		
10% < %R < 30%	J-	UJ	
%R < 10% (sample dilution not a factor)	J-	R	
%R < 10% (sample dilution is a factor)	Use professional judgment		
RT out of RT window	Use professional judgment		
RT within RT window	No qualification		

Use professional judgment in qualifying data, as surrogate recovery problems may not directly apply to target analytes.

All criteria were metX
Criteria were not met
and/or see below

MATRIX SPIKE/MATRIX SPIKE DUPLICATE (MS/MSD)

This data is generated to determine long term precision and accuracy in the analytical method for various matrices. This data alone cannot be used to evaluate the precision and accuracy of individual samples. If any % R in the MS or MSD falls outside the designated range, the reviewer should determine if there are matrix effects, i.e. LCS data are within the QC limits but MS/MSD data are outside QC limit.

1. MS/MSD Recoveries and Precision Criteria

Data for MS and MSDs will not be present unless requested by the Region.

Notify the Contract Laboratory Program Project Officer (CLP PO) if a field blank was used for the MS and MSD, unless designated as such by the Region.

NOTE: For a Matrix Spike that does not meet criteria, apply the action to only the field sample used to prepare the Matrix Spike sample. If it is clearly stated in the data validation materials that the samples were taken through incremental sampling or some other method guaranteeing the homogeneity of the sample group, then the entire sample group may be qualified.

List the %Rs, RPD of the compounds which do not meet the criteria.

Sample ID:___JC20377-2_____ Matrix/Level:___Aqueous____

MS OR MSD COMPOUND % R RPD QC LIMITS ACTION

Action

No qualification of the data is necessary on MS and MSD data alone. However, using professional judgment, the validator may use the MS and MSD results in conjunction with other QC criteria and determine the need for some qualification of the data.

Note: MS/MSD % recoveries and RPD within laboratory control limits.

A separate worksheet should be used for each MS/MSD pair.

All criteria were metX
Criteria were not met
and/or see below

LABORATORY CONTROL SAMPLE (LCS) ANALYSIS

This data is generated to determine accuracy of the analytical method for various matrices.

1. LCS Recoveries Criteria

LCS Spike Compound	Recovery Limits (%)
gamma-BHC	50 – 120
Heptachlor epoxide	50 – 150
Dieldrin	30 – 130
4,4'-DDE	50 – 150
Endrin	50 – 120
Endosulfan sulfate	50 – 120
trans-Chlordane	30 – 130
Tetrachloro-m-xylene (surrogate)	30 – 150
Decachlorobiphenyl (surrogate)	30 – 150

	:0.25_ug/L which do not meet the criteria	a	
LCS ID	COMPOUND	% R	QC LIMIT

Action

The following guidance is suggested for qualifying sample data for which the associated LCS does not meet the required criteria.

- a. If the LCS recovery exceeds the upper acceptance limit, qualify detected target compounds as estimated (J). Do not qualify non-detected target compounds.
- b. If the LCS recovery is less than the lower acceptance limit, qualify detected target compounds as estimated (J) and non-detects as unusable (R).
- c. Use professional judgment to qualify data for compounds other than those compounds that are included in the LCS.
- d. Use professional judgment to qualify non-LCS compounds. Take into account the compound class, compound recovery efficiency, analytical problems associated with each compound, and comparability in the performance of the LCS compound to the non-LCS compound.
- e. If the LCS recovery is within allowable limits, no qualification of the data is necessary.

2. Frequency Criteria:

Where LCS analyzed at the required frequency and for each matrix? <u>Yes</u> or No. If no, the data may be affected. Use professional judgment to determine the severity of the effect and qualify data accordingly. Discuss any actions below and list the samples affected.

Note: Blank spike/blank spike duplicate analyzed for aqueous matrices. % recoveries and RPD within laboratory control limits.

All criteria were met
Criteria were not met
and/or see belowN/A

FLORISIL CARTRIDGE PERFORMANCE CHECK

NOTE: Florisil cartridge cleanup is mandatory for all extracts.

Criteria

Is the Florisil cartridge performance check conducted at least once on each lot of cartridges used for sample cleanup or every 6 months, whichever is most frequent?

Yes? or No?

Criteria

Are the results for the Florisil Cartridge Performance Check solution included with the data package?

Yes? or No?

Note: If % criteria are not met, examine the raw data for the presence of polar interferences and use professional judgment in qualifying the data as follows:

Action:

- a. If the Percent Recovery is greater than 120% for any of the pesticide target compounds in the Florisil Cartridge Performance Check, qualify detected compounds as estimated (J). Do not qualify non-detected target compounds.
- b. If the Percent Recovery is greater than or equal to 80% and less than or equal to 120% for all the pesticide target compounds, no qualification of the data is necessary.
- c. If the Percent Recovery is greater than or equal to 10% and less than 80% for any of the pesticide target compounds in the Florisil Cartridge Performance Check, qualify detected target compounds as estimated (J) and non-detected target compounds as approximated (UJ).
- d. If the Percent Recovery is less than 10% for any of the pesticide target compounds in the Florisil Cartridge Performance Check, qualify detected compounds as estimated (J) and qualify non-detected target compounds as unusable (R).
- e. If the Percent Recovery of 2,4,5-trichlorophenol in the Florisil Cartridge Performance Check is greater than or equal to 5%, use professional judgment to qualify detected and non-detected target compounds, considering interference on the sample chromatogram.

Note: State in the Data Review Narrative potential effects on the sample data resulting from the Florisil Cartridge Performance Check analysis not yielding acceptable results.

Note: No information for florisil cartridge performance check included in data package. Florisil cartridge not used for sample extraction/clean-up. No qualification of the data performed, professional judgment.

All criteria were metN/A
Criteria were not met
and/or see below

GEL PERMEATION CHROMATOGRAPHY (GPC) PERFORMANCE CHECK

NOTE: GPC cleanup is mandatory for all soil samples.

If GPC criteria are not met, examine the raw data for the presence of high molecular weight contaminants; examine subsequent sample data for unusual peaks; and use professional judgment in qualifying the data. Notify the Contract Laboratory Program Project Officer (CLP PO) if the laboratory chooses to analyze samples under unacceptable GPC criteria.

Action:

- a. If the Percent Recovery is less than 10% for the pesticide compounds and surrogates during the GPC calibration check, the non-detected target compounds may be suspect, qualify detected compounds as estimated (J).
- b. If the Percent Recovery is less than 10% for the pesticide compounds and surrogates during the GPC calibration check, qualify all non-detected target compounds as unusable (R).
- c. If the Percent Recovery is greater than or equal to 10% and is less than 80% for any of the pesticide target compounds in the GPC calibration, qualify detected target compounds as estimated (J) and non-detected target compounds as approximated (UJ).
- d. If the Percent Recovery is greater than or equal to 80% and less than or equal to 120% for all the pesticide target compounds, no qualification of the data is necessary.
- e. If high recoveries (i.e., greater than 120%) were obtained for the pesticides and surrogates during the GPC calibration check, qualify detected compounds as estimated (J). Do not qualify non-detected target compounds.

Note: State in the Data Review Narrative potential effects on the sample data resulting from the GPC cleanup analyses not yielding acceptable results.

Note: No information for performance of GPC cleanup included in data package. No qualification of the data performed, professional judgment.

All criteria were met	_X
Criteria were not met	
and/or see below	

TARGET COMPOUND IDENTIFICATION

Criteria:

- 1. Is Retention Times (RTs) of both of the surrogates and reported target compounds in each sample within the calculated RT Windows on both columns? Yes? or No?
- 2. Is the Tetrachloro-m-xylene (TCX) RT ±0.05 minutes of the Mean RT (RT) determined from the initial calibration and Decachlorobiphenyl (DCB) within ±0.10 minutes of the RT determined from the initial calibration?

 Yes? or No?
- 3. Is the Percent Difference (%D) for the detected mean concentrations of a pesticide target compound between the two Gas Chromatograph (GC) columns within the inclusive range of \pm 25.0 %?

 Yes? or No?
- 4. When no analytes are identified in a sample; are the chromatograms from the analyses of the sample extract and the low-point standard of the initial calibration associated with those analyses on the same scaling factor?

 Yes? or No?
- 5. Does the chromatograms display the Single Component Pesticides (SCPs) detected in the sample and the largest peak of any multi-component analyte detected in the sample at less than full scale.

 Yes? or No?
- 6. If an extract is diluted; does the chromatogram display SCPs peaks between 10-100% of full scale, and multi-component analytes between 25-100% of full scale? Yes? or No?
- 7. For any sample; does the baseline of the chromatogram return to below 50% of full scale before the elution time of alpha-BHC, and also return to below 25% of full scale after the elution time of alpha-BHC and before the elution time of DCB?

 Yes? or No?
- 8. If a chromatogram is replotted electronically to meet these requirements; is the scaling factor used displayed on the chromatogram, and both the initial chromatogram and the replotted chromatogram submitted in the data package.

 Yes? or No?

Action:

- a. If the qualitative criteria for both columns were not met, all target compounds that are reported as detected should be considered non-detected.
- b. Use professional judgment to assign an appropriate quantitation limit using the following guidance:
 - If the detected target compound peak was sufficiently outside the pesticide RT Window, the reported values may be a false positive and should be replaced with the sample Contract Required Quantitation Limits (CRQL) value.

- ii. If the detected target compound peak poses an interference with potential detection of another target peak, the reported value should be considered and qualified as unusable (R).
- c. If the data reviewer identifies a peak in both GC column analyses that falls within the appropriate RT Windows, but was reported as a non-detect, the compound may be a false negative. Use professional judgment to decide if the compound should be included.

Note: State in the Data Review Narrative all conclusions made regarding target compound identification.

- d. If the Toxaphene peak RT windows determined from the calibration overlap with SCPs or chromatographic interferences, use professional judgment to qualify the data.
- e. If target compounds were detected on both GC columns, and the Percent Difference between the two results is greater than 25.0%, consider the potential for coelution and use professional judgment to decide whether a much larger concentration obtained on one column versus the other indicates the presence of an interfering compound. If an interfering compound is indicated, use professional judgment to determine how best to report, and if necessary, qualify the data according to these guidelines.
- f. If Toxaphene exhibits a marginal pattern-matching quality, use professional judgment to establish whether the differences are due to environmental "weathering" (i.e., degradation of the earlier eluting peaks relative to the later eluting peaks). If the presence of Toxaphene is strongly suggested, report results as presumptively present (N).

GAS CHROMATOGRAPH/MASS SPECTROMETER (GC/MS) CONFIRMATION

NOTE: This confirmation is not usually provided by the laboratory. In cases where it is provided, use professional judgment to determine if data qualified with "C" can be salvaged if it was previously qualified as unusable (R).

Action:

- a. If the quantitative criteria for both columns were met (≥ 5.0 ng/µL for SCPs and ≥ 125 ng/µL for Toxaphene), determine whether GC/MS confirmation was performed. If it was performed, qualify the data using the following guidance:
 - i. If GC/MS confirmation was not required because the quantitative criteria for both columns was not met, but it was still performed, use professional judgment when evaluating the data to decide whether the detect should be qualified with "C".
 - ii. If GC/MS confirmation was performed, but unsuccessful for a target compound detected by GC/ECD analysis, qualify those detects as "X".

All criteria were metX_	_
Criteria were not met	
and/or see below	

COMPOUND QUANTITATION AND REPORTED CONTRACT REQUIRED QUANTITATION LIMITS (CRQLS)

The sample quantitation evaluation is to verify laboratory quantitation results. In the space below, please show a minimum of one sample calculation:

Action:

- a. If sample quantitation is different from the reported value, qualify result as unusable (R).
- b. When a sample is analyzed at more than one dilution, the lowest CRQLs are used unless a QC exceedance dictates the use of the higher CRQLs from the diluted sample.
- c. Replace concentrations that exceed the calibration range in the original analysis by crossing out the "E" and its corresponding value on the original reporting form and substituting the data from the diluted sample.
- d. Results between the MDL and CRQL should be qualified as estimated (J).
- e. Results less than the MDL should be reported at the CRQL and qualified (U). MDLs themselves are not reported.
- f. For non-aqueous samples, if the percent moisture is less than 70.0%, no qualification of the data is necessary. If the percent moisture is greater than or equal to 70.0% and less than 90.0%, qualify detects as estimated (J) and non-detects as approximated (UJ). If the percent moisture is greater than or equal to 90.0%, qualify detects as estimated (J) and non-detects as unusable (R) (see Table).

Percent Moisture Actions for Pesticide Analysis for Non-Aqueous Samples

Criteria	Action			
	Detected Associated Compounds	Non-detected Associated Compounds		
% Moisture < 70.0	No qualification			
70.0 < % Moisture < 90.0	J	UJ		
% Moisture > 90.0	J	R		

List sam	nples wh	ich have	≤ 50 %	solids				
					<u>.</u>		- 50	
							_	
						_		
	_							

Note: If any discrepancies are found, the Region's designated representative may contact the laboratory to obtain additional information that could resolve any differences. If a discrepancy remains unresolved, the reviewer must use professional judgment to decide which value is the most accurate. Under these circumstances, the reviewer may determine that qualification of data is warranted. Note in the Data Review Narrative a description of the reasons for data qualification and the qualification that is applied to the data.

Dilution performed

SAMPLE ID	DILUTION FACTOR	REASON FOR DILUTION	
		1	
			_
	1.6		m

All criteria were metN/A_	
Criteria were not met	
and/or see below	

FIELD DUPLICATE PRECISION

NOTE: In the absence of QAPP guidance for validating data from field duplicates, the following action will be taken.

Field duplicates samples may be taken and analyzed as an indication of overall precision. These analyses measure both field and lab precision; therefore, the results may have more variability than laboratory duplicates which only laboratory performance. It is also expected that soil duplicate results will have a greater variance than water matrices due to difficulties associated with collecting identical field duplicate samples. Identify which samples within the data package are field duplicates. Estimate the relative percent difference (RPD) between the values for each compound. If large RPDs (> 50%) is observed, confirm identification of samples and note difference in the executive summary.

Sample IDs	š:		Matrix:				
COMPOUND	SQL ug/L	SAMPLE CONC.	DUPLICATE CONC.	RPD	ACTION		
					_		
			s data package. LCS/L thin the required criter				
				1			

Actions:

- a. Qualify as estimated positive results (J) and nondetects (UJ) for the compound that exceeded the above criteria. For organics, only the sample and duplicate will be qualified.
- b. If an RPD cannot be calculated because one or both of the sample results is not detected, the following actions apply:
 - i. If one sample result is not detected and the other is greater than 5x the SQL qualify (J/UJ).
 - ii. If one sample value is not detected and the other is greater than 5x the SQL and the SQLs for the sample and duplicate are significantly different, use professional judgment to determine if qualification is appropriate.
 - iii. If one sample value is not detected and the other is less than 5x, use professional judgment to determine if qualification is appropriate.
 - iv. If both sample and duplicate results are not detected, no action is needed.

OVERALL ASSESSMENT OF DATA

Action:

- 1. Use professional judgment to determine if there is any need to qualify data which were not qualified based on the Quality Control (QC) criteria previously discussed.
- 2. Write a brief narrative to give the user an indication of the analytical limitations of the data.

Note: The Contract Laboratory Program Project Officer (CLP PO) must be informed if any inconsistency of the data with the Sample Delivery Group (SDG) Narrative. If sufficient information on the intended use and required quality of the data is available, the reviewer should include their assessment of the usability of the data within the given context. This may be used as part of a formal Data Quality Assessment (DQA).

Overall assessment of the data: Results are valid; the data can be used for decision making purposes.