Messrs. Ministry of Land, Infrastructure, Transport and Tourism, Maritime Bureau, Inspection and Measurement Division

Ballast Water Management System Report of Onboard Test Results

January 22, 2010



JFE Engineering Corporation

Contents

Introduction

- 1. Experimental Equipment
 - (1) Outline of Experimental Ship
 - (2) Ballast Water Management System
 - (2-1) Pump and Piping System
 - (2-2) Sampling Devices
- 2. Content of Onboard Test
 - 2.1 Continuous Test Cycle in Port of Kobe
 - (1) Test Cycle
 - (2) Measurements and Records
 - (3) Sampling Methods and Amount of Water
 - (4) Analysis of Samples
 - (5) Results
 - 2.2 System Operation Period
 - 2.3 Overall Test Schedule
 - 2.4 Results of Preliminary Inspections before Onboard Test
 - · 2.5 Results of Biological and Other Measurements
- Annex−1 Piping System Diagram
- Annex −2 Sampling Timing Chart
- Annex 3 Record of Uptake and Discharge
- Annex 4 Data Logger Record of BWMS Onboard Test
- Annex 5 Overall Schedule of Onboard Test
- Annex 6 Results of Preliminary Inspections before Onboard Test
- Annex 7 Results of Biological and Other Measurements
- Note) In the text, the following expressions are used:
 - NaOCl (sodium hypochlorite) means TG Ballastcleaner[®]. Na₂SO₃ (sodium sulfite) means TG Environmentalguard[®].

Introduction

An "onboard test" of the JFE Ballast Water Management System, as provided in the "Ballast Water Management Systems Model Examination Test Standard," was completed. The results of the onboard test are reported herein.

- (1) Test period January 21-July 25, 2009
- (2) The following are the dates of test cycles in which treated ballast water satisfied Regulation D-2, Ballast Water Performance Standard, of the International Convention for the Control and Management of Ships' Ballast Water and Sediments in 3 continuous valid test cycles.

No. 1 cycle Uptake: July 18, 2009, discharge, July 20, 2009 No. 2 cycle Uptake: July 19, 2009, discharge: July 21, 2009 No. 3 cycle Uptake: July 20, 2009, discharge: July 22, 2009

(3) Treatment rate capacity, TRC, of object equipment of application before test The rated treatment capacity of the equipment in this application is 1,050 m³/h.

Outline of Ballast Water Management System




Fig. 1 Ballast Water Uptake System Configuration Diagram




Fig. 2 Ballast Water Uptake System Configuration Diagram

The details of this onboard test are described in the following.

1. Experimental Equipment

(1) Outline of Experimental Ship

This experiment was performed using a JFE-BWMS ballast water management system for onboard test use (hereinafter, abbreviated BWMS) installed on the SAGA PIONEER, a ship registered in Hong Kong. An outline of the experimental ship is presented below.

Ship name: M.V. SAGA PIONEER

Ship type: Box Shape Bulker

Ship owner: SAGA Shipholding (Norway) AS Shipbuilder: Ohshima Shipbuilding Co., Ltd.

Date delivered: August 4, 2008

Main specifications

LPP 190.00 m Breadth 30.50 m Depth 16.40 m Draft (summer) 11.80 m Service speed 14.9 knot Deadweight (summer) 46,822 MT	LOA	199.20 m
Depth 16.40 m Draft (summer) 11.80 m Service speed 14.9 knot	LPP	190.00 m
Draft (summer) 11.80 m Service speed 14.9 knot	Breadth	30.50 m
Service speed 14.9 knot	Depth	16.40 m
	Draft (summer)	11.80 m
Deadweight (summer) 46,822 MT	Service speed	14.9 knot
	Deadweight (summer)	46,822 MT



General view of SAGA PIONEER

The ballast tanks of the experimental ship are F.P.T., A.P.T, and No. 1, 12 B.W.T.(C), and No. 2-11(P)/(S) B.W.T. The capacities of the ballast tanks are shown in Table 1.

Table 1 Ballast tank capacity

Tank Name	Side	Volume	Tank Name	Side	Volume	Tank Name	Side	Volume
		(m ³)			(m^3)			(m^3)
F.P.T.	C	1385.9	No.5W.B.T.	P	746.2	No.9W.B.T.	P	684.9
No.1 W.B.T	C	1640.3	No.5 W.B.T.	S	746.2	No.9W.B.T.	S	684.9
No.2 W.B.T.	P	343.4	No.6 W.B.T.	P	746.6	No.10W.B.T.	P	410.9
No.2 W.B.T.	S	343.4	No.6 W.B.T.	S	746.6	No.10W.B.T.	S	410.9
No.3 W.B.T.	P	595.8	No.7 W.B.T.	P	746.2	No.11W.B.T.	P	597.0
No.3 W.B.T.	S	595.8	No.7 W.B.T.	S	746.2	No.11W.B.T.	S	597.0
No.4 W.B.T.	P	742.0	No.8 W.B.T.	P	746.2	No.12W.B.T.	С	443.7
No.4 W.B.T.	S	742.0	No.8 W.B.T.	S	746.2	A.P.T	C	428.4

In the onboard test which began in January 2009, No. 12 WBT was used as a treated water tank. In the continuous onboard test cycles at the Port of Kobe in July 2009, the test cycles were performed using No. 6, 8, and 11 W.B.T. as one group (2089.8 m³/side) and No. 5, 7, and 10 W.B.T. as another group (1903.3 m³/side).

(2) Ballast Water Management System

(2-1) Pump and Piping System

A diagram of the piping system for installation of the BWMS used in the test on the SAGA PIONEER is shown in Annex—1.


In normal ballast operation of this ship, F.P.T. and No. 2-11(S) B.W.T. are operated using No. 1 ballast pump, and No. 1.2-11(P).12 B.W.T. and A.P.T are operated using No. 2 ballast pump. The BWMS was installed in the system of No. 2 ballast pump.

In the onboard test, the ballast tanks in the system of No. 1 ballast pump were used as control water (untreated water used for comparison purposes), and the ballast tanks in the system of No. 2 ballast pump were used as treated water (ballast water treated by BWMS). For the capacities of these tanks, see Table 1.

It should also be noted that a ballast booster pump was installed to compensate for head loss due to installation of the BWMS.

(2-2) Sampling Devices

Sampling was performed at locations S1 and S2 in the piping system diagram (Annex – 1). Drawings of the sampling devices are shown below.



Direction of
Sampling pipe
Valve
Cover

Flow direction

S1: For control water (Lower Deck)

S2: For treated water (3rd Deck)

Fig-1 Sampling devices

As isokinetic sampling was assumed, the sampling rate was $1,050 \text{ m}^3/\text{h} \times 10/920 = 11.4 \text{ m}^3/\text{h} = 190 \text{ L/min}$ as calculated from the cross-sectional area ratio of the main ballast pipe, 922 cm^2 and the sampling pipe, 10 cm^2 . The flow rate was adjusted to take a sample of 1 m^3 of ballast water in approximately 5.8 minutes.

In the continuous onboard test cycles at the Port of Kobe in July 2009, water samples could not be taken during discharge when operating at 1,050 m³/h, as negative pressure was generated at the sampling position. Therefore, confirmation operation was performed at 1,050 m³/h for 10min, and operation was performed at 700 m³/h during sampling at other times. In this case, the sampling time was approximately 8.6 min.



Sampling time control

2. Content of Onboard Test

2.1 Continuous Test Cycles in Port of Kobe

(1) Test Cycle

One test cycle was performed as follows. See also the piping system diagram in Annex – 1.

1) Uptake of ballast treatment water (solid red line)

No. 2 ballast pump was started. The ballast booster pump was also started. Treatment was performed during ballast water uptake by passing the ballast water through the respective processes of the BWMS filter, injection of sodium hypochlorite from the nozzle, and the Venturi tube. The treated ballast water was then pumped to the ballast treated water tank.

2) Uptake of control water (dotted red line)

No. 1 ballast pump was started, and ballast water was pumped to the ballast control water tank while taking samples from the sampling line.

3) Discharge of ballast treated water (solid blue line)

In order to discharge the treated water held in the ballast treated water tank, the treated water was pumped from the treated water tank using No. 2 ballast pump. In this process, the remaining chlorine in the treated water was neutralized by injecting sodium sulfite from the nozzle on the upstream side (suction side) of the ballast pump. After neutralization, the treated water was discharged overboard while taking samples from the sampling line.

4) Discharge of control water (dotted blue line)

In parallel with discharge of the ballast treated water, the control water was pumped from the ballast control water tank by No. 1 ballast pump, and was discharged overboard while taking samples from the sampling line.





The test cycles were performed with the test ship in a moored condition at Rokko Island Public Wharf C-1 at the Port of Kobe. The test cycles were performed with No. 6, 8, and 11 WBT as one group, and No. 5, 7, and 10 WBT as another group.

(2) Measurements and Records

The following records were taken in connection with the ballast water.

- · Amount and location of uptake and discharge
- Time of sampling (start and finish times)

For details, see the following:

Annex-2 Sampling Timing Chart

Annex — 3 Record of Uptake and Discharge



Record-keeping in control room

The following records were also taken using the BWMS data logger.

 ${}^{\raisebox{3.5pt}{\text{\circle*{1.5}}}}$ Various parameters, including control, monitoring, flow rate, etc.

For details, see Annex -4:

Annex-4 Data Logger Record of BWMS Onboard Test

(3) Sampling Methods and Amount of Water

All sampling was performed in parallel during ballast uptake and discharge.

The contents of the samples were as follows.

S1: Ballast control water 3 samples of control water during ballast uptake and discharge

(1 time each during 1st half, middle part, and 2nd half of uptake and discharge)

S2: Ballast treated water 9 samples of neutralized treated water during ballast water discharge

(3 times each during 1st half, middle part, and 2nd half of discharge)

· Samples were taken using the sampling device for control water on the lower deck and sample device for

treated water on the 3rd deck. The samples were transferred by hose and temporarily stored as-sampled in buffer tanks on the 2nd deck. In order to take plankton counts and water quality data, 1.1 m³ of sample water was collected in the buffer tanks in 1 sampling operation. An image of the sampling and concentration procedures is



Control water sampling on lower deck



Treated water sampling on 3rd

shown in the following figure.




Fig-2 Image of sampling and concentration

• In order to count viable organisms with a minimum size of 50 μm or larger, samples were transferred by hose

to the quay via the upper deck by way of an underwater pump, and were then concentrated on the quay by passing through a net with a 35 µm mesh. The concentrated water captured by the net was observed with a microscope and organisms were counted.





Pumping from 2nd deck (attachment room)

Concentration on quay

Water which passed through the net was stored in a 1 m³ tank. This completed one sampling operation. To avoid contamination, the pumps, hoses, and tanks used in the sampling operation were clearly identified as for use with treated water or use with control water, and were used appropriately.

• In order to detect viable organisms with sizes from ≥ 10 to < 50 μm , water samples were collected in 1 L plastic bottles. Sampling was performed at the outlet of the hose leading to the quay. For organism counts, the samples were






concentrated using a net with a 7 µm mesh.

• For evaluation of bacteria, water samples were collected in 500 mL sterilized bottles. The water samples were

taken from a branch pipe on the sampling device attached to the ballast pipe.







Counting S size plankton

(4) Analysis of Samples

Chlorine concentration, temperature, particulate organic carbon concentration, and total suspended solids were recorded for all samples.

Bioassays were performed by the following procedures:

- During ballast uptake, the concentration of living organisms in the control water was checked to determine whether the concentration was 10 times or more than the standard value for ballast water discharge (S1).
- During ballast discharge, the concentration of living organisms in the control water checked to determine whether the concentration was equal to or larger than the standard value for ballast water discharge (S1).



Bacteria culture



Formed colonies (control water)



Counting colonies

3) During ballast discharge, the concentration of living organisms in the treated water was checked to determine whether the concentration satisfied the standard value for ballast water discharge (S2).

(5) Results

· Judgment standard

"It shall be confirmed that the test cycle from ballast water uptake through discharge satisfies the standard values for ballast water discharge in 3 consecutive valid test cycles. Invalid test cycles are not considered to affect continuity."

• Results of this test

In this test, a total of 6 test cycles were performed. All 6 cycles were valid cycles, and it was confirmed that the cycles satisfied the standard values for ballast water discharge.

Summary of Test Results

		No. I	No. 2	No. 3	No. 4	No. 5	No. 6
	Test cycle	cycle	cycle	cycle	cycle	cycle	cycle
Test date	Uptake	7/18	7/19	7/20	7/21	7/22	7/23
Test date	Discharge	7/20	7/21	7/22	7/23	7/24	7/25
	Uptake control water (≧100)	126,200	213,033	97,220	19,740	64,807	27,283
L size plankton (individuals/m³)	Discharge control water (≥10)	313,933	89,580	34,310	. 177,267	65,710	50,987
	Discharge treated water (<10)	2	0	0	0	0	0
	Uptake control water (≥100)	1,022	1,413	1,330	760	1,140	807
S size plankton (individuals/ml)	Discharge control water (≥10)	1,043	1,063	733	630	747	117
	Discharge treated water (<10)	0	0	0	0	0	0
	Uptake control water	7	21	31	5	20	30
E. coli (cfu/100 ml)	Discharge control water	6	6	6	3	4	12
	Discharge treated water (<250cfu)	0	0	0	0	0	0
Intestinal	Uptake control water	25	44	37	47	62	9
Enterococci	Discharge control water	2	4	2	1	1	. 2
(cfu/100 ml)	Discharge treated water (<100cfu)	0	0	0	0	0	0
Toxicogenic	Uptake control water	0	0	0	0	0	0
Vibrio cholerae (cfu/100 ml)	Discharge control water	0	0	0	0	0	0
(CIW 100 MII)	Discharge treated water (<1cfu)	0	0	0	0	0	0
Pass or fail	(Valid cycle standard) (Treatment standard)	Pass	Pass	Pass	Pass	Pass	Pass

2.2 System Operation Period

Monitoring by data logger was performed for a period of 6 months. The starting date of this period was the first ballast treatment (January 21, 2009) after the chemicals were loaded. The ending date was the final day (July 25, 2009) of the test cycles in the Port of Kobe.

2.3 Overall Test Schedule

The overall test schedule is shown in Annex — 5 Overall Schedule of Onboard test.2.4 Results of Preliminary Inspections before Onboard Test


Before the start of the onboard test, various "preliminary inspections before onboard test," beginning with an inspection of the external appearance of the equipment, were performed by Ohshima Shipbuilding Co., Ltd., which installed the equipment of the BWMS.

For details, see Annex — 6, Results of Preliminary Inspections before Onboard Test.

2.5 Results of Biological and Other Measurements

Measurements of organisms, bacteria, and water quality were performed in the continuous cycle test. For details, see Annex – 7 Results of Biological and Other Measurements.

Annex – 1 Piping system diagram (ballast uptake)



(Operated at 1,050m3/h)

Uptake of Ballast Wate

Annex - 2 Sampling timing chrart of sample correction

A. Mechanical

1. External Appearance

The external appearance and structure of the equipment shall be confirmed, referred to the relevant specifications and drawings.

2. Dimensional Inspection

The dimensions of the equipment shall be confirmed, referred to the relevant specifications and drawings.

3. Confirmation of Markings

Proper marking of all necessary items shall be confirmed.

Examples of markings



NaOCI injector



Venturi Tubes



TRO Meter

Test Results

No.	Equipment name	Date	Appearance	Dimensions	Marking
1.	BALLAST FILTER	08/06/30	OK	OK	OK
2.	VENTURI	08/06/30	OK	OK	OK
3.	NaClO PUMP	08/06/30	OK	OK	OK
4.	NaClO INJECTOR	08/06/30	OK	OK	OK
5.	Na ₂ SO ₃ PUMP	08/06/30	OK	OK	OK
6.	Na ₂ SO ₃ INJECTOR	08/06/30	OK	OK	OK
7.	BALLAST WATER FLOW MTR.	08/06/30	OK	OK	OK
8.	NaClO FLOW MTR.	08/06/30	OK	OK	OK
9.	Na ₂ SO ₃ FLOW MTR.	08/06/30	OK	OK	OK
10.	TRO METER 1 (0-30ppm)	08/06/30	OK	OK	OK
11.	TRO METER 2 (0-30ppm)	08/06/30	OK	OK	OK
12.	TRO METER 3 (0-3ppm)	08/06/30	OK	OK	OK

Annex-3 Records of Uptake and Discharge

	14:45:55	Sampling end time	<u> </u>
	14:40:20	Sampling start time	П
	14:18:55	Sampling end time	
	14:13:15	Sampling start time	P!M
	13:49:20	Sampling end time	DCS.
	13:42:30	Sampling start time	٥٠٥
13:24:55	13:22:00	Ballashing start time	Balla
Treated(P)	Control(S)		
	18th July 2009 (Sat.)		Date
³/h)	(Operation at 1,050m ³ /h)	Record of uptake	Reco
	1.1 m³	Sampled Volume	Sam
	2089.8m ³ ×P/S	Ballast Volume	Balla
	No.6,8,11	Tank Group	Tank
	Test cycle-1	Cycle No.	Syci

Record of de-ballasthing

Date

20th July 2009 (Mon.)

		Control (S)	11	Treated(P)	((
De−b	De-ballashing start time	8:48:24		w	8:49:30
			1st	2nd	3rd
, ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	Sampling start time	9:14:40	9:05:03	9:24:30	9:39:00
g.	Sampling end time	9:22:34	9:13:00	9:32:50	9:47:45
P;W	Sampling start time	10:04:40		9:55:00 10:14:50 10:30:40	10:30:40
WII.	Sampling end time	10:13:05 10:03:22 10:23:40	10:03:22	10:23:40	10:39:10
7 9	Sampling start time	11:00:10 10:49:50 11:10:40 11:26:50	10:49:50	11:10:40	11:26:50
ם ב	Sampling end time	11:09:20 10:58:15 11:19:00 11:35:00	10:58:15	11:19:00	11:35:00
De-b	De-ballasting end time	11:50:05		11	1:59:00

15:16:53	15:10:00	Ballasting end time	Balla
	14:35:25	Sampling end time	<u>.</u>
	14:30:00	Sampling start time	ц ц
	13:56:40	Sampling end time	j
	13:50:30	Sampling start time	7.74
	13:26:50	Sampling end time	ָ מ ט
	13:22:10	Sampling start time	ū
13:08:03	13:04:21	Ballashing start time	Balla
Treated(P)	Control(S)		
	19th July 2009 (Sun.)	į	Date
1 ³ /h)	(Operation at $1,050 \text{ m}^3/\text{h}$)	Record of uptake	Reco
	1.1 m³	Sampled Volume	Samp
	$1903.3 \text{m}^3 \times \text{P/S}$	Ballast Volume	Balla
	No.5,7,10	Tank Group	Tank
	Test cycle-2	No.	Cycle No.

Record of de-ballasthing

15:55:30

15:49:50

Ballasting end time

Date		21st July 2009 (Tue.)	_		
		Control (S)	ĭ	Treated(P)	<u></u>
De-b	De-ballashing start time	00:00:6			9:02:00
			1st	2nd	3rd
ď	Sampling start time	9:26:40	9:16:30	9:37:10	9:53:10
B	Sampling end time	9:35:15	9:24:30	9:45:50	10:02:05
Min	Sampling start time	10:20:25 10:09:35 10:29:40 10:44:10	10:09:35	10:29:40	10:44:10
WIIG.	Sampling end time	10:28:25 10:18:15 10:37:40	10:18:15	10:37:40	10:52:20
L D	Sampling start time	11:08:40 10:59:00 11:18:50	10:59:00	11:18:50	11:34:25
<u> </u>	Sampling end time	11:16:45 11:07:30 11:27:05	11:07:30	11:27:05	11:42:40
De-b	De-ballasting end time	11.57.00		-	12.07.00

Test Cycle-3	40.6,8,11	2089.8m³×P/S	اء،	(Operation at $1,050$ m $^3/h$)	20th Jul 2009 (Mon.)	
Cycle No. Test	Tank Group No.6	Ballast Volume 2089	Sampled Volume 1.1m ³	Record of uptake (Ope	Date 20th	

		Control (S)	Treated(P)
Ballas	Ballashing start time	13:37:00	13:40:30
0 %	Sampling start time	13:52:30	
i i	Sampling end time	13:58:20	
P:W	Sampling start time	14:23:00	
MIG.	Sampling end time	14:29:05	
P 4 3	Sampling start time	15:09:30	
	Sampling end time	15:15:25	
Ballas	Ballasting end time	16:05:20	15:55:00

Record of de-ballasthing	Record of de-ballasthing (9:44:50 \sim 9:54:50 Operation at 1,050m ³ /h
Date	22nd July 2009 (Wed.)

		Control (S)	Tr	Treated(P)	(c
De-ba	De-ballashing start time	8:45:00		~	8:48:00
,	o		1st	2nd	3rd
0	Sampling start time	9:10:20 9:01:00	9:01:00	9:20:30	9:34:30
	Sampling end time	9:19:05	9:09:00	9:28:40	9:42:36
P : P 4	Sampling start time	10:10:00		9:59:00 10:22:00	10:37:20
ž Ž	Sampling end time	10:18:43 10:07:50 10:30:36 10:46:04	10:07:50	10:30:36	10:46:04
P	Sampling start time	11,03,00 10.53.20 11:12:20 11:28:20	10:53:20	11:12:20	11:28:20
בנם	Sampling end time	11:11:08 11:01:30 11:20:25 11:36:24	11:01:30	11:20:25	11:36:24
De-ba	De-ballasting end time	11:44:20		1	11:53:00

Treated(P) 13:29:23	ation at 1,050m July 2009 (Tue.) Control (S) 13:27:18 13:40:35 13:46:36 14:15:00 14:55:00 15:27:00	21st, (Uper (Coper (Cop	shing start time Sampling start time Sampling end time Sampling start time Sampling start time Sampling end time Sampling start time
	14:15:00	Sampling start time Sampling end time	Mid.
	13:46:36	Sampling end time	ock.
	13:40:35	Sampling start time	ţ
13:29:23	13:27:18	shing start time	llas
Treated(P)	Control (S)		
(21st July 2009 (Tue.)		Date
³ /h)	(Operation at $1,050 \text{m}^3/\text{h}$)	Record of uptake	00
	1.1m³	Sampled Volume	ш
	$1903.3 \text{m}^3 \times \text{P/S}$	Ballast Volume	<u> </u>
	No.5,7,10	Tank Group	논
	Test cycle-4	Cycle No.	See

$(9.57.40 \sim 10.07.40 \text{ Operation at } 1,050 \text{m}^3/\text{h})$	23rd July 2009 (Thu.)
Record of de-ballasthing	Date

		Control (S)	Tr	Treated(P)	(د
Derb	De∽ballashing start time	8:47:00	,		8:50:00
			1st	2nd	3rd
, , , , , , , , , , , , , , , , , , ,	Sampling start time	9:18:43	9:07:15	9:30:02	9:46:02
0 0 0	Sampling end time	9:27:02	9:16:12	9:39:12	9:54:35
P.4:~	Sampling start time	10:22:03 10:11:04 10:33:00 10:49:04	10:11:04	10:33:00	10:49:04
MICI.	Sampling end time	10:30:49 10:19:57 10:41:34 10:58:10	10:19:57	10:41:34	10:58:10
ا 1	Sampling start time	11:48:14 11:06:02 11:21:43 11:37:18	11:06:02	11:21:43	11:37:18
<u>ם</u>	Sampling end time	11:56:44 11:14:50 11:30:38 11:45:50	11:14:50	11:30:38	11:45:50
De-b	De-ballasting end time	12:20:00		15	12:11:00

Cycle No.	Test cycle-5	
Tank Group	No.6,8,11	
Ballast Volume	2089.8m ³ ×P/S	
Sampled Volume	1.1m³	
Record of uptake	(Operation at 1,050m ³ /h)	
Date	22nd July 2009 (Wed.)	
		,

		Control(S)	Treated(P)
Ballas	Ballashing start time	13:16:20	13:19:00
۵۵۳	Sampling start time	13:30:00	
G K	Sampling end time	13:36:10	
P:M	Sampling start time	14:05:00	
MIG.	Sampling end time	14:11:30	
P = _	Sampling start time	14:40:00	
Erlu	Sampling end time	14:46:05	
Ballas	Ballasting end time	15:20:00	15:35:20

Record of de-ballasthing $(9.38:00 \sim 9.48:00 \text{ Operation at } 1,050\text{m}^3/\text{h})$ Date

		Control (S)	Tr	Treated(P)	(د
De-ba	De-ballashing start time	8:37:00		w	8:40:00
	0		İst	2nd	3rd
1	Sampling start time	9:04:20	8:54:50	9:13:30	9:28:30
Deg.	Sampling end time	9:12:22	9:03:08	9:21:35	9:36:42
7:5	Sampling start time	10:01:40		9:52:00 10:11:40 10:27:00	10:27:00
MIG.	Sampling end time	10:10:11 10:00:06 10:20:05	10:00:06	10:20:05	10:35:12
7	Sampling start time	10.53;15 10.42.00 11.03:15 11:18:20	10:42:00	11:03:15	11:18:20
	Sampling end time	11:01:24 10:51:08 11:11:25 11:26:26	10:51:08	11:11:25	11:26:26
De-ba	De-ballasting end time	11:47:18		1	11:50:20

15:29:15	15:33:30	Ballasting end time	Balla
	15:05:51	Sampling end time	<u> </u>
	15:00:00	Sampling start time	т 11 11
	14:31:05	Sampling end time	į
	14:25:00	Sampling start time	: 2
	13:57:55	Sampling end time	i g
	13:52:04	Sampling start time	D
13:39:00	13:36:30	Ballashing start time	Balla
Treated(P)	Control(S)		
	23rd July 2009 (Thr.)		Date
1 ³ /h)	(Operation at $1,050m^3/h$)	Record of uptake	Reco
	1.1m³	Sampled Volume	Samp
	$1903.3 \text{m}^3 \times \text{P/S}$	Ballast Volume	Balla
	No.5,7,10	Tank Group	Tank
	Test cycle-6	Cycle No.	O Şc

Record of de-ballasthing $(9.40:30 \sim 9.50:30$ Operation at $1,050 \text{m}^3/\text{h})$	25th July 2009 (Sat.)	
Record of de-ballas	Date	

		Control (S)	Tr	Treated(P)	(د
De-b	De-ballashing start time	8:38:30		ω	8:39:30
•			1st	2nd	3rd
٥٠٠	Sampling start time	9:03:30	8:54:00	9:13:00	9:28:15
0 0	Sampling end time	9:11:50	9:02:18	9:21:18	9:36:24
7:M	Sampling start time	10:04:25		9:54:40 10:14:30 10:30:10	10:30:10
MIG.	Sampling end time	10:13:05 10:03:05 10:23:18 10:38:15	10:03:05	10:23:18	10:38:15
2	Sampling start time	10:55:00 10:45:00 11:05:00 11:20:00	10:45:00	11:05:00	11:20:00
2	Sampling end time	11:03:13 10:53:05 11:13:06 11:28:08	10:53:05	11:13:06	11:28:08
De-ba	De-ballasting end time	11:49:30		11	11:46:00

Process Chart of Onboard Test Cycles

July 10th	Equipmenta	for by dapail Lent All Co.															
(Thu)	00:6	of Equipments from YOKOHAMA	OHAMA	ž	NaOCL 2,000 L		Na2SO3 4,000 L		Underwater Pump, Hose serimental Equipments (Incubator etc).	serimental	Equipments	(Incubator	etc).				
July 17th	Arrival in Port 10:00	Loading of Equipments and Unloading of	nd Unloadir	lm3	anks		Installation of 1m3 Capacity Tanks	n of / Tanks	Hose Sets	Elements	Elements by Fresh Water	ater	,				
(Fri.)		Take out of NaOCI in Tank		Load	Loading of New NaOCI	Addition of Na2SO3										*1: Uptake *2: Dischrge	96
		Tank No. (group A)		9	, 8, 11 (To	6, 8, 11 (Total 2142.1m3)	3)		Tank No. (group B)		5	, 7, 10 (To	5, 7, 10 (Total 1951.0m3)	3)		No. of Samples	mples
		Work Item	Begi	Beginning trol Treated	Control	Middle ol Treated	Control	Treated	Work Item	Begi	Beginning trol Treated	Control	Middle Treated	Control	End	• ‡	0
July 18th	9:00-13:30	Stripping Discharge									-		-11				
(Sat.)	14:00-17:00	Uptake (Cycle 1)	•		•		•									က	
18th (Sun.)	9:00-13:30								Stripping Discharge	•		•				c	
	9:00-10:00	Discharge	C	000					Uptake (Uycle 2)	•		•		•		2	4
	10:30-11:30	Discharge			0	000											4
20th (Mon.)	12:00-13:00	Discharge (Complete Cycle 1)					0	000									4
	14:00-17:00	Uptake (Cycle 3)	•		•		•		→							က	
	9:00-10:00								Discharge	0	000						4
	10:30-11:30								Discharge			0	000				4
21st (Tue.)	12:00-13:00								Discharge (Complete Cycle 2)					0	000		4
	14:00-17:00	•							Uptake (Cycle 4)	•		•		•		က	
	9:00-10:00	Discharge	0	000													4
	10:30-11:30	Discharge			0	000											4
22nd (Wed.)	12:00-13:00	Discharge (Complete Cycle 3)					0	000									4
	14:00-17:00	Uptake (Cycle 3)	•		•		•		-							ဗ	
	9:00-10:00								Discharge	0	000		7				4
E	10:30-11:30								Discharge			0	000				4
Z3rd (Thu.)	12:00-13:00								Discharge (Complete Cycle 4)					0	000		4
	14:00-17:00	→							Uptake for Departure								
	9:00-10:00	排水	0	000													4
	10:30-11:30	排水			0	0000											4
24th (Fri.)	12:00-13:00	Discharge (Complete Cycle 5)					0	000									4
	14:00-17:00	Uptake for Departure															
25th (Sat.)	Leave Port	Loading of the things to be returned to the ship	be returne	d to the sh.	<u>Q</u>									Total No.	Total No. of Samples	15	09
26th (Sun.)		Pull out tents															
27th (Mon.)																	
28th (Tue)	End of Cultivation	0															
		Send Equipments to															

Annex-4 Data Logger Records of JFE-BWMS Onboard Tests

1. Onboard Test Duration

Start: 21st January 2009

JFE-BWMS Operation Start

End: 25th July 2009

Test Time: 6 month and 4 days

2. Onboard test Imprementation Date and Place


Start	End	Country	Place
21st January ~	22nd January	U.S.A.	Mobile
23rd January ~	24th January	U.S.A.	Darrow
16th March ~	18th March	India	Mundra
21st June ~	23rd June	India	Daheji
7th July ~	7th July	Chine	Hong Kong
18th July ~	25th July	Japan	Kobe

3. Test Records at Kobe

 After supplying TG Ballastcleaner and TG Environmentalguard in the chemical tanks at Kobe, the uptaking and discharge tests of the onboard tests were implemented from 18th July 2009 to 25th July 2009 (In Japanese time).

All of the trend data of onboard tests are shown below.


JFE-BWMS SHIP'S TEST in KOBE UPTAKING & DISCHARGE (090718-090725)



4. Records of the tests at Kobe

Among the records of onboard tests in Kobe, the trend data of uptakingly (21st July) and discharge (23rd July) are shown below.

21th July 2009 UPTAKING




(Supplemental remarks: A: Coondition only ballast pump was operating

B: Condition only ballast pump and booster pump were operating

C: #5, 7 Valve closed at ballast tank entry and booster pump shutdown condi-

23rd July 2009 DISCHARGE



Supplemental remarks. X: By attenuating the opening of outlet valve, discharging ballast flow rate was adjusted from 600 to 700m3/h


Y: By attenuating the outlet valve, ballast discharging flow rate was increase more than 1,000m³/h

5. Imprementation condition of whole onboard tests

1) Chemical supply to JFE-BWMS

Chemicals were supplied on 3: 38, 21(Japan local time) st, Jan. 2009 at Mobile, USA. About 1.8 L of TG ballastcleanner (TGBC) was transferred to TGBC tank. About 2.3 L of TG Environmental Guard (TGEG) was transferred to TGEG tank.


JFE-BWMS Chemical Tank Level (090121:JAPAN TIME)




2) 22nd Jan. 2009, 14:00 ~ (Japan Time) Uptaking & Discharge tests.

at Mobile

JFE-BWMS Ship's TEST in MOBILE(090122)




JFE-BWMS Ship's TEST in DARROW (090124)




4) 16th March 2009~18th March 16, 16:00~18:00 (Japan Time) Uptaking & Discharge at MUNDRA

JFE-BWMS Ship's TEST in MUNDRA INDIA (090316_18)




JFE-BWMS Ship's TEST in DAHEJI INDIA (00623)



6) 7th Jul. 2009 11 Uptaking &Discharge tests


at HONGKONG

JFE-BWMS Ship's TEST in HONGKONG CHINA (090707)




7) 17th Jul. 2009 13:40 Chemical supply at Kobe.
1.2m3 of TG Ballastcleaner (TGBC) was supplied into TGBC tank with 1.2m3 capacity.
1.8m3 of TG Environmentalguard (TGEG) was supplied into TGEG tank

JFE-BWMS Chemical Tank Level (090717 in KOBE)




8) 18th Jul. 2009, 13:00 ~ 25th (Japan time) Uptaking &Discharge test at KOBE

JFE-BWMS SHIP'S TEST in KOBE UPTAKING & DISCHARGE (090718-090725)



9) 24th Jul. 2009 13:00 chemicals were additionally supplied at Kobe 0.7m3 of TG Ballastcleaner (TGBC) was supplied into TGBC Tank 2.2m3 of TG Environmentalguard (TGEG) was supplied into TGBC tank


JFE-BWMS SHIP'S TEST CHEMICAL TANK LEVEL (IN KOBE 090724)





Master schedule (Plan)

JFE Engineering Corporation Ship Machinery Div. BWMS Dept.



Annex—6 Results of Preliminary Inspections before Onboard Test

B. Electrical

Ballast Water Management System

Onboard Test Procedure

- 1. Wiring Check
- 2. Insulation Resistance Measurement Test
- 3. Grounding Check
- 4. Auxiliary Equipment Operation Confirmation Test
- Instrumentation Calibration Test: Seawater Flow Meters, Chemical Injection Flow Meters, and Residual Chlorine Meters
- Sequence Test (Operation Monitoring Operation, Alarm Tests, Protective Interlock Test)
- 7. Interlock Test (Water Test)
- 8. Interlock Test (Chemical Agent Test): Marine Test

1. Wiring Check

(1) Purpose

To confirm that electrical and instrumentation equipment in the Ballast Water Management System (BWMS) which is the object of inspection is correctly wired.

(2) Inspection Method

Confirm that the wiring of the BWMS which is the object of inspection is as shown in the connection diagrams (schematics) prepared by Ohshima Shipbuilding Co., Ltd. and JFE Engineering Corporation.

(3) Judgment criteria

Shall be wired as shown in the connection diagrams.

2. Insulation Resistance Measurement Test

(1) Purpose

To confirm whether the insulation conditions of the electrical equipments and electrical circuits of the BWMS, which is the object of inspection, are acceptable or not.

(2) Inspection Method

Measure the insulation resistance between conducting parts and ground using a DC 500 V insulation resistance tester.

The objects of measurement are power supply cables of boards and equipment, and power supply cables of electric motors and motor-driven valves.

(3) Judgment criteria

Shall be $\geq 100 \text{ M}\Omega$.

3. Grounding Check

(1) Purpose

To confirm that the grounds of electrical and instrumentation equipment of the BWMS which is the object of inspection are connected to the ship's hull (common steel plate).

(2) Inspection Method

Measure the tester resistance ranges of the ground terminals of boards and equipment and part of the steel plates of the ship's hull.

(3) Judgment criteria

Confirm that the terminals of panels and equipment and the steel plates of the ship's hull are completely connected.

4. Auxiliary Equipment Operation Confirmation Test

(1) Purpose

To confirm that the direction of rotation and current values of electric motors of the BWMS, which is the object of inspection, are normal.

(2) Inspection Method

Measure the direction of rotation and the current value of the electric motors concerned. Current values shall be measured under load operation. Voltage shall also be measured at the same time.

(3) Judgment Criteria

The direction of rotation shall agree with the rotation marking, and the current value shall be the rated current or less.

5. Instrumentation Calibration Test

(1) Purpose

To confirm that the seawater flow meters, chemical injection flow meters, and residual chlorine meters of the BWMS which is the object of inspection give correct readings.

(2) Inspection Method

① Seawater Flow Meters

In a condition in which chemical agents are not injected, start the ballast pump and perform either injection of water into the ballast tank or discharge from the ballast tank, measure the amount of increase (or decrease) in the tank and the time. Using these measurement results, calculate the seawater flow rate, and compare the result with the reading of the seawater flow meter.

② Chemical Injection Flow Meters

Fill the chemical tank with tap water, start the chemical injection pump, and measure the amount of decrease in the tank and time. Using the measurement results, calculate the chemical injection rate, and compare the result with the reading of the chemical injection flow meter.

③ Residual Chlorine Meters

- Connect the electrode of the residual chlorine meter to the electrode tank of the simple tank unit.
- Inject the equivalent of 10 ppm of sodium hypochlorite into the pump unit for 0-30 mg/L residual chlorine meter.

Measure the water in the simple pump unit by the DPD method.

Compare the result with the reading of the residual chlorine meter.

 Inject the equivalent of 2 mg/L of sodium hypochlorite into the pump unit for 0.2-3 mg/L residual chlorine meter.

Measure the water in the simple pump unit by the DPD method.

Compare the result with the reading of the residual chlorine meter.

Also confirm 0 mg/L using water without injection of sodium hypochlorite.

(3) Judgment Criteria

The results shall be within the range of allowable error for each instrument:

- ① Seawater flow meter: ±5% (value of rated value)
- ② Chemical injection flow meter: ±5% (value of rated value)
- ③ Residual chlorine meter: ±5% (value of rated value)

6. Sequence Test (Operation Monitoring Operation, Alarm Tests, Protective Interlock Test)

(1) Purpose

To confirm that the BWMS which is the object of inspection operates normally, and display devices, alarm devices, and protective devices operate normally.

(2) Inspection Method

① With the ballast pump in a stopped condition, input a simulation signal that the ballast pump is in operation.

Short-circuit the signal wire using the control panel outside wire terminal.

- ② Fill the chemical tank with tap water.
- Start the sodium hypochlorite pump by operating the ballast water injection switch, and confirm by the electromagnetic flow meter that water is being injected.
- 4 Confirm that the BWMS stops normally by operating the ballast water stop switch.
- Start the sodium hypochlorite pump by operating the ballast water discharge switch, and confirm by the electromagnetic flow meter that water is being discharged.
- 6 Confirm that the BWMS stops normally by operating the ballast water stop switch.
- Confirm alarm displays, valve closing operation, and pump stop on the ballast water control panel and the ballast water operation panel using simulated signals.
- Perform ballast booster pump stop operation, and confirm operation stop and abnormal signals. However, this operation is performed in an MCCB cut condition so that the pump is not started.

(3) Judgment Criteria

- ① Confirm operation/stop of ballast water injection/discharge operate normally in accordance with the operation stop interlock diagram.
- ② Confirm proper display of alarms in accordance with the protective interlock diagram.

7. Interlock Test (Water Test)

(1) Purpose

To confirm normal operation of the BWMS which is the object of inspection under a condition without injection of chemical agents.

(2) Inspection Method

- ① Fill the chemical agent tanks with tap water.
- ② Start the ballast pump.
- ③ Confirm that sodium hypochlorite (water) is injected and ballast water of the target residual chlorine concentration (simulated input) is injected by operating the ballast water injection switch.
- 4 Collect the ballast water in the ballast tank.
- ⑤ Start the ballast booster pump.
- 6 Stop the ballast booster pump.
- ① Confirm that the BWMS stops normally by operating the ballast water stop switch.
- While discharging the ballast water from the tank by operating the ballast water discharge switch, measure the residual chlorine content, inject sodium sulfite corresponding to that residual chlorine concentration (simulated value), and discharge the ballast water overboard.
- (9) Confirm that the BWMS stops normally by operating the ballast water stop switch.

(3) Judgment Criteria

Confirm that operation/stop of ballast water injection/discharge operate normally in accordance with the operation stop interlock diagram.

8. Interlock Test (Chemical Agent Test)

(1) Purpose

To confirm that the BWMS which is the object of inspection operates normally.

(2) Inspection Method

- (9) Fill the chemical agent tanks with sodium hypochlorite and sodium sulfite.
- 10 Start the ballast pump.
- (i) Confirm that sodium hypochlorite is injected and the target residual chlorine is injected into ballast water by operating the injection switch.
- Collect the ballast water in the ballast tank.
- Start the ballast booster pump.
- Stop the ballast booster pump.
- © Confirm that the BWMS stops normally by operating the ballast water stop switch. While injecting ballast water from the tank by operating the ballast water discharge switch, measure the residual chlorine concentration. Inject sodium sulfite corresponding to that residual chlorine concentration, and discharge the ballast water overboard.
- (b) Confirm that the BWMS stops normally by operation of the ballast water stop switch.

(3) Judgment criteria

Confirm that operation/stop of ballast water injection/discharge operate normally in accordance with the operation stop interlock diagram.

Test Results

- 1. Wiring Check
- 2. Insulation Resistance Measurement Test
- 3. Grounding Check
- 4. Auxiliary Equipment Operation Confirmation Test
- Instrumentation Calibration Test: Seawater Flow Meters, Chemical Injection Flow Meters, Residual Chlorine Meters
- 6. Sequence Test (Operation Monitoring Operation, Alarm Tests, Protective Interlock Test)
- 7. Interlock Test (Water Test)
- 8. Interlock Test (Chemical Agent Test): Marine Test

1. Wiring Check

Checked by: Aoki

	T			- Auki	Ι
No.	Equipment name	_	Equipment name	Date	Result
1	BWMS MOTOR		Filter Motor	6/30	OK
	PANEL				
2	BWMS MOTOR		NaClO injection pump	6/30	OK
	PANEL				
3	BWMS MOTOR		Na ₂ SO ₃ injection pump	6/30	OK
	PANEL				
4	BWMS MOTOR	:	Sampling pump for treated	6/30	OK
	PANEL		water		
5	BWMS MOTOR		Sampling pump for Ball. Pump	6/30 ·	OK
	PANEL		Suc.		
6	BWMS MOTOR		Ballast Booster Pump inlet	6/30	OK
	PANEL		valve		
7	BWMS MOTOR		Filter outlet valve	6/30	OK
	PANEL				
8	BWMS MOTOR		Filter Normal Backwash valve	6/30	OK
	PANEL				
9	BWMS MOTOR		Filter Highflow Backwash	6/30	OK
	PANEL		valve		
10	BWMS MOTOR		Filter Bypass valve	6/30	OK
	PANEL				
- 11	BWMS Chemical		NaClO injection Pump	6/30	OK
٠	Injection Pump Starting		ζ.		
	Panel				
12	BWMS Chemical		Na ₂ SO ₃ injection Pump	6/30	OK
	Injection Pump Starting			•	
	Panel				_
13	BWMS Control Panel		Sea Water Flow	6/30	OK
14	BWMS Control Panel		NaClO injection Flow	6/30	OK
15	BWMS Control Panel		Na ₂ SO ₃ injection Flow	6/30	OK
16	BWMS Control Panel		Residual Chlorine Meter (For	6/30	OK
			NaClO control) 0-30 ppm		
17	BWMS Control Panel	-	Residual Chlorine Meter (For	6/30	OK
	,		Na ₂ SO ₃ control) 0-30 ppm		
			<u> </u>		

18	BWMS Control Panel	Residual Chlorine Meter (For	6/30	OK
		Supervision of discharge) 0-3		
		ppm		
19	BWMS Control Panel	ORP meter	6/30	OK
20	BWMS Control Panel	Press. Transmitter for Ballast	6/30	OK
		Booster Pump Suc.		
21	BWMS Control Panel	Press. Transmitter for Ballast	6/30	OK
		Booster Pump del.		
22	BWMS Control Panel	Press. Transmitter for Venturi	6/30	OK
		inlet .		
23	BWMS Control Panel	Press. Transmitter for Venturi	6/30	OK
		outlet		
24	BWMS Control Panel	Press. Transmitter for Filter	6/30	OK
		inlet		
25	BWMS Control Panel	Press. Transmitter for Filter	6/30	OK
		outlet		_
26	BWMS Control Panel	Diff. Press. Transmitter for	6/30	OK
		Filter		
27	BWMS Control Panel	Diff. Press. Switch for Filter	6/30	OK
28	Chemical Tank Level	NaClO storage Tank Level	6/30	OK
20	meter Box	Transmitter	610.0	077
29	Chemical Tank Level	Na ₂ SO ₃ storage Tank Level	6/30	OK
20	meter Box	Transmitter	(12.0	OIZ
30	BWMS Control Panel	Chemical Tank Level meter	6/30	OK
31	BWMS Control Panel	Box Chemical Tank Level Alarm	6/30	OV
31	b wivis Control Panel	Box	0/30	OK
32	BWMS Control Panel	BWMS Motor Panel	6/30	OK
33	BWMS Control Panel	BWMS Operation Panel	6/30	OK
34	BWMS Control Panel	Ballast Pump Starting Panel	6/30	OK
35	BWMS Control Panel	Ballast Booster Pump Starting	6/30	OK
	2 John of I uno	Panel	0,00	
}	,	,		
			·	
l				į .

2. Insulation Resistance Measurement Test

Measured by: Aoki

		, 	TVICasuic	u by. Abki	
No.	Equipment name	Measurement	Insulation	Date	Result
		point	resistance		
			(ΜΩ)		
1	BWMS Control Panel	Primary power	$100~\mathrm{M}\Omega$ or	6/30	OK
		supply - E	more		
2	BWMS Motor Panel	Primary power	100 MΩ or	6/30	OK
		supply - E	more		
3	BWMS Operation Panel	Primary power	$100~\mathrm{M}\Omega$ or	6/30	OK
		supply - E	more	<u> </u>	
4	BWMS Chemical Injection	Primary power	$100~\mathrm{M}\Omega$ or	6/30	OK
	Pump Starting Panel	supply - E	more		
5	Chemical Tank Level meter	Primary power	$100~\mathrm{M}\Omega$ or	6/30	OK
	Box	supply - E	more		·
6	Chemical Tank Level Alarm	Primary power	$100~\mathrm{M}\Omega$ or	6/30	OK
	Box	supply - E	more		
7	Filter Motor	Coil – E	$100~\mathrm{M}\Omega$ or	6/30	OK
			more		
8	NaClO injection pump	Coil – E	100 MΩ or	6/30	OK
	,		more		
9	Na ₂ SO ₃ injection pump	Coil – E	100 MΩ or	6/30	OK
			more		
10	Sampling pump for treated	Coil – E	. 100 MΩ or	6/30	OK ·
	water		more		
11	Sampling pump for Ball.	Coil – E	100 MΩ or	6/30	OK
	Pump Suc.		more		
		·			
					-
			_		
	•				-

Judgment criteria: 100 $M\Omega$ or more

3. Grounding Check

Measured by: Aoki

- NT -) (L by. Aoki	D 1/
No.	Equipment name	Measurement	Connection	Date	Result
		point			
1	BWMS Control Panel	E – Hull plate	Common	6/30	OK
2	BWMS Motor Panel	E – Hull plate	Common	6/30	OK
3	BWMS Operation Panel	E – Hull plate	Common	6/30	OK
4	BWMS Chemical Injection	E − Hull plate	Common	6/30	OK
	Pump Starting Panel				
5	Chemical Tank Level meter Box	E - Hull plate	Common	6/30	OK
6	Chemical Tank Level Alarm	E – Hull plate	Common	6/30	OK
	Box		·		
7	Filter Motor	E - Hull plate	Common	6/30	OK
8	NaClO injection pump	E - Hull plate	Common	6/30	OK
9	Na ₂ SO ₃ injection pump	E - Hull plate	Common	6/30	OK
10	Sampling pump for freated	E – Hull plate	Common	6/30	OK
	water	_		•	
11	Sampling pump for Ball. Pump	E - Hull plate	Common	6/30	OK
	Suc.				
12	Ballast Booster Pump inlet valve	E - Hull plate	Common	6/30	OK
13	Filter outlet valve	E – Hull plate	Common	6/30	OK
14	Filter Normal Backwash valve	E – Hull plate	Common	. 6/30	OK
15	Filter Highflow Backwash valve	E - Hull plate	Common	6/30	OK
16	Filter Bypass valve	E – Hull plate	Common	6/30	OK
17	NaClO injection Pump	E - Hull plate	Common	6/30	OK
18	Na ₂ SO ₃ injection Pump	E – Hull plate	Common	6/30	OK
19	Sea Water Flow	E – Hull plate	Common	6/30	OK
20	NaClO injection Flow	E – Hull plate	Common	6/30	OK
21	Na ₂ SO ₃ injection Flow	E – Hull plate	Common	6/30	OK
22	Residual Chlorine Meter (For	E - Hull plate	Common	6/30	OK
	NaClO control) 0-30 ppm	I			
23	Residual Chlorine Meter (For	E – Hull plate	Common	6/30	OK
_=	Na ₂ SO ₃ control) 0-30 ppm			2.20	
24	Residual Chlorine Meter (For	E – Hull plate	Common	6/30	OK
4 7	Supervision of discharge) 0-3	- Hum prace		0/30	
	Supervision of discharge) 0-3				

	ppm				L
25	ORP meter	E - Hull plate	Common	6/30	OK
26	Press. Transmitter for Ballast	E – Hull plate	Common	6/30	OK
	Booster Pump suc.				
27	Press. Transmitter for Ballast	E - Hull plate	Common	6/30	OK
	Booster Pump del.				
28	Press. Transmitter for Venturi	E – Hull plate	Common	6/30	OK
	inlet				
29	Press. Transmitter for Venturi	E − Hull plate	Common	6/30	OK
	outlet				
30	Press. Transmitter for Filter inlet	E – Hull plate	Common	6/30	OK
31	Press. Transmitter for Filter	E - Hull plate	Common	6/30	OK
	outlet				
32	Diff. Press. Transmitter for	E - Hull plate	Common	6/30	OK
	Filter				
33	Diff. Press. Switch for Filter	E - Hull plate	Common	6/30	OK
34	NaClO storage Tank Level	E - Hull plate	Common	6/30	OK
	Transmitter	,			
35	Na ₂ SO ₃ storage Tank Level	E - Hull plate	Common	6/30	ОК
	Transmitter				
					-
				. 1	

4. Auxiliary Equipment Operation Confirmation Test

Measured by: Aoki

					•
No.	Equipment name	Rotation	Current value	Date	Result
		direction	(A)		
-1	Filter Motor	Clockwise	0.2	7/1, 31	OK
2	NaClO injection pump	Clockwise	0.64/100%	7/1, 31	OK
3	Na ₂ SO ₃ injection pump	Clockwise	0.64/100%	7/1, 31	OK
4	Sampling pump for treated water	Clockwise	0.7	7/1, 31	OK
5	Sampling pump for Ball. Pump Suc.	Clockwise	0.7	7/1, 31	OK
6	Ballast Booster Pump inlet valve	Both directions	2.6	7/1, 31	OK
7	Filter outlet valve	Both directions	2.2	7/1, 31	OK
8	Filter Normal Backwash valve	Both directions	0.7	7/1, 31	OK
9	Filter Highflow Backwash valve	Both directions	0.7	7/1, 31	OK
10	Filter Bypass valve	Both directions	2.1	7/1, 31	OK
				,	

5. Instrumentation Calibration Test: Seawater Flow Meters, Chemical Flow Meters, and Residual Chlorine Meters

Measured by: Kataoka, Aoki, Maeda

(1) Seawater Flow Meters

No.	Flow meter	Ballast tank	Time	Value of flow	Date	Result
	reading	level (m³)	(sec)	rate converted		
	(m ³ /h)	-	- ,	from tank level		
				(m ³ /h)		
1	ì	_	17:19:57	_	7/16	OK
2	· . —	<u> </u>	17:24:57	385.1		
3	1	1	17:29:57	367.2		
4	_	-	17:34:57	379.2		
			·			
Average	395.4			377.2		i

(2) NaClO Flow Meters

No.	Flow meter	NaClO tank	Time	Value of flow	Date	Result
	reading	level(L)	(sec)	rate converted		
	(L/min)			from tank level		
				(L/min)		
	-			_	7/18	OK
1			9:10:00			
2	_		9:40:00			
	1					
Average	2.097	119.8	30	1.997		

(3) Na₂SO₃ Flow Meters

No.	Flow meter	Na₂SO₃ tank	Time	Value of flow	Date	Result
	reading	level (L)	(sec)	rate converted	,	
	(L/min)			from tank level		
	,		.,	(L/min)		
	_		_	_	7/31	OK
1	_	2,179.4(1.0897	16:18:25			
		m)				

2	<u> </u>	2,159(1.0795 m)	16:28:25		
	_		·		
Average	1.995	20.4	10	2.04	

(4) Residual Chlorine Meters

	Application	Standard Cl	Reading of	DPD	Date	Result
		residual	residual	(ppm)		
		chlorine	chlorine			
		concentration	meter			
		for calibration	(ppm)			
	,	(ppm)				
1	For NaClO control	10	10.2	9.6	7/15	OK
	0-30 ppm					
2	For Na ₂ SO ₃ control	10	11	10.2	7/15	OK
	0-30 ppm		-			
3	For Supervision of	0	0	0	7/15	OK
	discharge-0.2-3 ppm		2.44	2.3		

6. Sequence Test

(1) Operation Monitoring

Test date: July 1, 2008

Test performed by: Aoki, Aiba

No.	Equipment name	Start	Stop	Control	Operation	Result
,		operation	operation	panel	panel	
				display	display	
1	Filter Motor	0	0	0	0	OK
2	NaCIO injection pump	0	0	0	0	OK
3	Na ₂ SO ₃ injection pump	0	, O	0	0	OK
4	Sampling pump for treated	0	0	0	0	OK
	water					
5	Sampling pump for Ball.	0	0	0		OK
	Pump Suc					
No.	Equipment name	Opening	Closing	Control	Operation	Result
		operation	operation	panel	panel	
				display	display	
6	Ballast Booster Pump inlet	0	0	display	display	OK
6	Ballast Booster Pump inlet valve	0	0			OK
6	•	0	0			OK OK
	valve	_		0	0	
7	valve Filter outlet valve	0	0	0	0	OK
7	valve Filter outlet valve Filter Normal Backwash	0	0	0	0	OK
7 8	valve Filter outlet valve Filter Normal Backwash valve	0	0	0 0	0 0	OK OK
7 8	valve Filter outlet valve Filter Normal Backwash valve Filter Highflow Backwash	0	0	0 0	0 0	OK OK
7 8	valve Filter outlet valve Filter Normal Backwash valve Filter Highflow Backwash valve	0 0	0 0	0 0	0 0	OK OK

(2) Alarm Test/Protective Interlock Test

Test date: July 2, 2008

Test performed by: Aoki, Aiba

No.	Alarm name	Control	Operation	BWMS	Result
		panel/Display	panel/Display	Stop	
1	BALLAST BOOSTER PUMP FAULT	0	0	4	OK
2	FILTER BYPASS VALVE FAULT	0	0	3,4	OK
3	NaClO PUMP FAULT	0	0	①,②,④	OK
4	NaCIO STORAGE TANK LEVEL LOW	0	0	1,2,4	OK
5	Na ₂ SO ₃ PUMP FAULT	0	0	3,4	OK
6	BOOSTER PUMP INLET VALVE FAULT	0	0	1,2,4	OK
7	FILTER OUTLET VALVE FALUT	0	0	①,②,④	OK
8	NORMAL BACKWASH VALVE FAULT	0	0	1,2,4	OK
9	HIGHFLOW BACKWASH VALVE FAULT	0	0	①,②,④	OK
10	BALLAST PUMP FAULT	0	0	①,②,③ ④	OK
11	FLOW METER FAULT	0	0	①,②,③ ④	OK
12	NaCIO INJECTION CONTROL ABNORMAL	0	0	①,②,④	OK
13	Na ₂ SO ₃ INJECTION CONTROL ABNORMAL	0	Ο.	3,4	OK
14	Na ₂ SO ₃ STORAGE TANK LEVEL LOW	0	0	3,4	OK
15	DELIVERY PRESS. OF BBP LOW	0	0	①,②,③ ④	OK
16	UPTAKE.WATER R.CL.	0	0	1,2	OK

	ABNORMAL				
17	NaCIO INJECTION FLOW	0	0	1),2	OK
	ABNORMAL				
18	PLC ABNORMAL .	0	0	None	OK
19	BALLAST WATER FLOW	0	0	1),2,3	OK
	LOW			4	
20	SEA WATER FLOW FAULT	0	0	1,2,3	OK
				4	
21	ORP FAULT	0	0	None	OK
22	NaClO INJECTION FLOW	0	0	1,2,4	OK
	HIGH LIMIT				
23	R.CL. FAULT(DISCHARGE)	0	0	3.4	OK
24	R.CL. FAULT(UPTAKING)	0	0	1,2,4	OK
25	DISCH. WATER R.CL.	0	0	3,4	OK
	ABNORMAL		· · · · · · · · · · · · · · · · · · ·		
26	FILTER FAULT	0	0	1,2,4	OK
27	EMERGENCY STOP	0		1,2,3	OK
				4	
28	INLET PRESS. OF FILTER	0	0	None	OK
	LOW		_		
29	BALLAST WATER FLOW	0	0	None	OK
	LOW				
30	Na ₂ SO ₃ INJECTION FLOW	0	0	3,4	OK
	ABNORMAL				
31	NaCIO STORAGE TANK	O	O .	None	OK
	LEVEL H				
32	Na ₂ SO ₃ STORAGE TANK	0		None	OK
22	LEVEL H		,	X T -	
33	CONTROL FAILURE	0	0	No	OK
21	CAMDI D EOD DALI DIDAD			starting	Ov.
34	SAMPL.P. FOR BALL.PUMP SUC. FAULT	0	0	3,4	OK
35	NETWORK ABNORMAL		0	None	
36	DATA LOGGER ABNORMAL		0	None	OK OK
37		······································			OK
١٤.	FILTER DIFFERENTIAL	0	0	None	OK

	PRESS. HIGH				
38	SAMPL.P. FOR TREATED	0	0	1,2,3	OK
	WATER FAULT			4	
39	DISCH. WATER R.CL	0	. 0	None	OK
	WARNING			ź	1

<Notes>

Stopped or fully-closed equipment

① Group:FILTER

BALLAST BOOSTER PUMP INLET VALVE FILTER OUTLET VALVE FILTER NORMAL BACKWASH VALVE FILTER HIGH FLOW BACKWASH VALVE

- ② Group: SAMPLING PUMP FOR TREATED WATER NaCIO INJECTION PUMP
- ③ Group: SAMPLING PUMP FOR TREATED WATER SAMPLING PUMP FOR BALL. PUMP SUC. Na₂SO₃ INJECTION PUMP FILTER BYPASŚ VALVE
- 4 Group: BALLAST BOOSTER PUMP

7. Interlock Test (Water Test)

Test date: July 18, 2008

Test performed by: Kataoka, Aoki,

Maeda, Aiba

1) Interlock Tests

July 18, 2008, 9:00-12:15 Sodium hypochlorite control (simulated)

July 31, 2008, 12:15 - 16:12 Sodium sulfite control (simulated)

2) Trend Record

See Annex -1.

ANNEX-7 Bioanalytical Results of Onboard Tests using JFE-BWMS

Contents

- 1. Abstract
- 2. Test Items and Requirements
- 3. Test Methods
- 4. Results of the Measurements
- 5. Conclusions

1. Abstract

Onboard tests using SAGA PIONEER equipped with JFE-BWMS were conducted for continuous 6 test cycles at a quay of Rokko Island in Port of Kobe from July 18th to July 25th, 2009. All test cycles fulfilled the requirements specified in G8 guideline and were "Effective Test Cycle". As all measurement results for each test cycle met the regulation D-2, it was evaluated that JFE-BWMS met regulation D-2 of BWM Convension with 6 continuous test cycles of onboard tests.

JFE-BWMS was installed in the 47,000 DWT Type Bulk Carrier "SAGA Pioneer" and the test water sampling, concentration and bioanalytical measurements were performed using test water taken from the sampling water outlet of two systems, which consist of pre-treatment water, treated water and control water, and lead to 1 m³ capacity tanks prepared on the mooring quay. But the sample water for bacteria analysis was collected in the engine room to prevent contamination. Except for the water quality terms measured directly at site, conservations and measurements were performed in the onsite labolatory which was set up at 50m distance from mooring quay.

These onboard tests were performed based on the standard methods specified in "Bioanalytical Methods for the Approval of Ballast Water Management Systems (Revised Edition)" proposed by the Ship Equipment Inspection Society of Japan.

- 2. Test items and Requirements
- 2.1 Requirements
- 2.1.1 Regulation D-2

Regulation D-2 Ballast Water Performance Standard consisted of D-2.1 and D-2.2 as follows.

- D-2.1 Ships conducting Ballast Water Management in accordance with this regulation shall discharge less than 10 viable organisms per cubic metre greater than or equal to 50 micrometres in minimum dimension and less than 10 viable organisms per millilitre less than 50 micrometres in minimum dimension and greater than or equal to 10 micrometres in minimum dimension; and discharge of the indicator microbes shall not exceed the specified concentrations described in paragraph 2.
- D-2.2 Indicator microbes, as a human health standard, shall include:
 - .1 Toxicogenic *Vibrio cholerae* (O1 and O139) with less than 1 colony forming unit (cfu) per 100 millilitres or less than 1 cfu per 1 gram (wet weight) zooplankton samples;
 - .2 Escherichia Coli. less than 250 cfu per 100 millilitres;
 - .3 Intestinal Enterococci less than 100 cfu per 100 milliliters.
- 2.1.2 Requirements for onboard tests

As following requirements were shown for onboard tests, all measurements were performed to meet these requirements during each test cycle.

(1) Test Cycle

Tests shall be performed at normal flow rate and normal ballast capacity of the test ship. Each test cycle should consist of the consecutive works of ballast water uptake, storage and discharge.

(2) Effectiveness standards of the test

Tests of each test cycle are judged as "Effective" only in the case where the density of aquatic organisms during uptake exceed more than 10 times of regulation D-2.1 and the density of aquatic organisms in non-treated ballast tank (called as control tank hereinafter) exceed more than regulation D-2.1.

(3) Standards for approval

BWMS shall be approved only in the case where the density of aquatic organisms in treated ballast water at discharge meets regulation D-2 in three consecutive effective test cycles.

(4) Number of samples

Number of the samples required for the performance evaluation is 3 (beginning, middle and end) for control tank during uptake and discharge, 9 (beginning 3 samples, middle 3 samples and end 3 samples) for treated ballast water during discharge.

(5) Sample volume etc.

Sample volume is at least $1m^3$ for large size group aquatic organisms, at least 1L for small size group aquatic organisms and at least 500mL for bacteria. In concentrating L size group and S size group organisms, net with mesh size of less than $50\mu m$ and $10\mu m$ in diagonal line should be used respectively.

(6) Measuring items for water quality

In respect of measuring items for water quality, measurements of salinity, particulate organic carbon (POC hereinafter), total suspended solids (TSS hereinafter) are required.

2.2 Test items

Measured items during onboard tests are shown in Table-1 including above stated regulation D-2 requirements.

Table-1 Measured items during onboard tests

Classification	Measured Items	Point of measurement and sampling	Measuring Method
Aquatic	L size group	Sampled and concentrated at quay	Speculum by microscope
organisms	S size group	Sampled at quay	Speculum by microscope
Bacteria	Toxicogenic <i>Vibrio Cholerae</i> (O1 and O139)	Sampled in engine room	Spread plate method
	Escherichia Coli.	ditto	ditto
	Enterococci	ditto	ditto

	Heterotorophic bacteria	ditto	ditto		
Water Quality	Tamparatura	Massured at quay	Direct measurement		
Water Quality	Temperature	Measured at quay ditto Sampled at quay ditto Water sampling ar analysis Water sampling ar analysis Water sampling ar analysis Direct measureme by water quality measurement by water qu			
	Salinity	ditto	ditto		
	TSS	Completed at avery	Water sampling and		
	155	Sampled at quay	analysis		
	POC	ditto	Water sampling and		
	POC	ditto	analysis		
	Trucki dike	Management at a service	Direct measurement		
	Turbidity	ivieasured at quay	by water quality meter		
	рН	ditto	ditto		
	Dissolved Oxgen (DO)	ditto	ditto		

Test water was sampled, measured and treated with concentration, microscopic observation during these onboard tests.

In these onboard tests, it became possible to sample and concentrate the control and treated ballast water at the quay, because test ship, "Bulk carrier, SAGA Pioneer", equipped with JFE-BWMS was layed up at the quay. Therefore, works for obtaining test water and sampling for bacteria analysis were performed on board and other works for obtaining test water, measurements, concentration and counting were performed at the facilities which were set-up on the quay (i.e., $1m^3$ capacity tanks and onsite laboratory).

Hence, the works relating bioanalytical evaluation of organisms and measurements of water quality became as follows.

a. Engine Room Valve operations for control and treated ballast water intake Sampling of test water for bacteria analysis

b. Attachment Room Filling test water into 1m³ tank and re-transfer work using

underwater pump (Pump was stopped after siphonic condition)

c. Quay (Tank side) Filling test water into 1m³ tank and concentration of L size sample

Sampling of test water for S size organisms and water quality

measurements, cleaning of tanks

d. Quay (Onsite Laboratory)

Re-concetration and speculum by microscope for L size organisms Concetration and speculum by microscope for S size organisms

Spread, incubation and measurement of bacteria Filtration and desiccation for TSS measurement

Sampling valves, hoses and tanks relating to uptake water, control water and treated water were set up as separated system in order to prevent cross contamination, and operated carefully not to contact each other.

< Photographs >



Photo 1: Test Ship and water collecting tanks and measuring facility

Test Ship "SAGA PIONEER" and test water collecting tanks and measuring facility (Front side tents)



Photo 2: Outside view of onsite laboratory
50m distance from the test ship



Photo 3: Facility for water sampling and measurements

Tanks with 1m3 capacity for concentration of L size rganisms



Photo 4: Water sampling for bacteria analysis

Water sampling for bacteria analysis (in Engine Room)




Photo 5: 1m3 capacity tank in attachment room

1m3 capacity tank in attachment room (Temporary storage of test water from engine room. This water is lead to 1m3 tank on the quay.)



Photo 6: Set up of the net for concentration of L size organisms

Net with 30cm diameter, $35\mu m$ mesh was set on the top of $1m^3$ tank.



Photo 7: Water quality meter (direct reading type)

Water quality measuring sensor (temperature, salinity, DO etc.)



Photo 8: Speculum by microscope L size organisms

Concentrated test water sample was transfered to petri dish and visualized by stereomicroscope

3. Test Methods

- 3.1 Aquatic organisms
- 3.1.1 L size group organisms

(1) Summary

Countings for L size group were performed on the samples defined in G8 guideline. Concentration was performed using $35\mu m$ mesh size hand net and filter with the same mesh size. Measurement was done confirming the minimum dimension using stereomicroscope. In these onboard tests, 1 m³ test water was concentrated and L size organisms were enumerated in accordance with G8 guideline.

(2) Concentration

1m³ test water samples were collected and concentrated simultaneously for uptake water during uptake, treated water and control water during discharge. 1m³ test water capacity was measured based on the scale indicated on the tank wall. However, 1,10 m³ sampling was performed in the attachment room considering to avoid residual water in the hoses to tanks on the quay and just about 1,05 m³ was collected in the tank on the quay subtracting test water for analysis (less than 10L in total) and water quality measurement. Therefore counted results for L size organisms were for 1.05m³ sample water volume, but this results were regarded as for that of 1.0 m³.

Primary Concentration was conducted at the tank side on quay. Test water led from engine room into the 1m^3 tank in attachment room through hose was led using underwater pump. Cocentration work was done at the exit of hose using hand net with $35\mu\text{m}$ mesh size and the concentrated sample water to several hundreds mL was preserved in the plastic bottle.

Secondary concentration was applied to this concentrated sample water preserved in plastic bottle into several tens mL level using filtration equipment made of PVC pipe and 35µm mesh size net. In the case of treated ballast water where high concentration rate is possible, concentration rate becomes several ten thousands. However, in the case for uptake water and control water where the density of organisms are very high, high rate concentration was not necessary and concentration rate was determined depending on the situation.

(3) Measurement

Stereomicroscope was used for the counting of L size organisms. Test water was transferred to the ruled petri dish (5mm x 5mm) using pipetter and counted for every 5mm x 5mm area. Minimum dimension was measured using the micro scale on eyepiece lens.

Number of individual was counted using couter with distinguishing species.

Judgement of life and death were done according to appearance and mobility of the individual.

Used stereomicroscopes were SZ-H type manufactured by Olympus and WILD type manufactured by Leica.

(4) Records of the measurement results

After recording the sample name, date and time of measurement, name of the person who measured, concentration condition and volume of speculum, measurement result for each sample were recorded with principal species name (or genus name), number of the organism, minimum dimension and characteristics of the sample etc.

3.1.2 S size group organisms

(1) Summary

Measurements for S size group were performed on the samples defined in G8 guideline. Concentration works were conducted in the onsite laboratory as appropriate, and if necessary, conducted to the necessary concentration level using the filter with 7μm mesh size. Measurement work were done using biological microscope. Samle water volume should be more than 1 litter according to G8 guideline, however considering the necessity of concentration, 2 litters sample volume was adopted for these measurement.

(2) Concentration

As necessity for concentration depends on the sample condition, the filter made of $7\mu m$ mesh size was used for concentration if necessary. As in the case where the test water is 2 litters, concentration into 50ml means 40th concentration, counting of 1ml of this concentrated test water means 40 ml counting.

(3) Determination

Biological microscope was used for counting. Appropriate quantities of test water was transferred onto glass slide with ruled lines using pipetter and counted. Minimum dimension was confirmed using the micro scale on the eyepiece lens.

Number of individuals was divided broadly into species and counted using counter. Judgement of dead or alive was done essentially by the mobility for the species with motion capability and by the distributions of pigment under the microscopic observation for the species with no mobility like Diatom.

Confirmation of the viability by re-cultivation was not done because this process was not practically necessary. When organisms greater than $50\mu m$ mixed in, these were not included in the measurement.

Used microscope was BX-51 type and BX-60 type of the Olympas product.

(4) Records of the measurement results

After recording the sample name, date and time of measurement, name of the person who measured, concentration condition and volume of speculum, measurement result for each sample were recorded with principal species name (or genus name), number of the organism, minimum dimension and characteristics of the sample etc.

3.2 Measurement of bacteria

For the samples specified in G8 guideline, measurements of the toxicogenic *Vibrio Cholerae*, *Escherichia Coli*, Intestinal Enterococci and Heterotropic bacteria were performed.

In order to avoid contaminations, samples were collected at the nearest sampling water valve to the BWMS in engine room. Nevertheless minimum sampling volume for bacteria analysis is specified 500ml by G8 guideline, 2 litters sample for each test was collected in these onboard tests because it might be necessary to concentrate the sample.

The spread plate method and membrane filter method were used depend on the number of

colonies to be expected. Cultivation was performed using the incubator installed in the onsite laboratory and counting of colonies was done after specified cultivation time. Dilution and concentration were done in specified method and the results were indicated as converted values in specified unit.

3.2.1 Toxicogenic Vibrio Cholerae

As toxicogenic *Vibrio Chlerae* (serotype O1 and O139) specified in regulation D-2 can not measured at once, number of *Vibrio* genus including *Vibrio Cholera* was counted first using TCBS culture media. After that the appeared colonies is re-cultivated using alkaline peptone water and then toxicogenic *Vibrio Cholerae* is confirmed by separating into toxinogenicity using antiserum. In these onboard tests, the first and second steps were conducted within these separated three steps operations. That is, the colonies of *Vibrio* genus appeared even in the treated water but *Vibrio cholerae* became negative in next step cultivation, therefore it was not necessary to proceed in the third step.

As to the concentration and dilution of test water samples, the spread plate method was used for the uptaken water and control water samples and the membrane filter method was used for 100ml of treated water using more than three culture medias for each sample water.

Cultivation temperature was kept at 35°C of and duration was 24 hours. Measured results were recorded in the field note and averaged values were adopted omitting the abnormal values.

3.2.2 Escherichia Coli.

As explained in "BIOANALYTICAL METHODS FOR THE APPROVAL OF BALLAST WATER MANAGEMENT SYSTEMS", *Escherichia Coli* is the objective of the regulation D-2, however it is allowed to measure the number of Coliform bacteria as the alternative bacteria.

In these onboard tests, Chromocult Coliform enzyme culture media, which can be used for measure both *Escherichia coli* and Coliform were used and countings were done after the 24 hours cultivation at 35°C. More than three culture medias were used under each condition.

As to the concentration and dilution of test water samples, 100 ml of both uptake, control and treated test water was filtered, spread onto the culture media and incubated.

Measured results were recorded in the field note and averaged values were adopted omitting the abnormal values.

3.2.3 Intestinal Enterococci

As to Intestinal Enterococci, *Enterococus* group can be used in place of Intestinal Enterococci, which include Intestinal Enterococci, as explained in the "Bioanalytical method" manual. However in the case when colonies of *Enterococcus* group are found in the treated water samples, it becomes necessary to cultivate these colonies and enumerate Intestinal Enterococci. As no *Enterococcus* group colony was found, i.e. 0 cfu/100ml in these onboard tests, no secondary cultivation was performed. All works were conducted in the onsite laboratory.

The spread plate method was adoptd for the measurement of *Enterococcus* group using commercially available *Enterococus* agar media and 100ml concentrated test water using membrane filter for uptake, control and treated water was measured with more than three agar medias for each sample.

Cultivation was conducted at 36°C for 48 hours and the colonies with the color from faint pink to red were confirmed as *Enterococcus* group. Results of determination were recorded on the field note for analysis for each test water sample. After eliminating abnormal value, averaged value was

adopted.

3.2.4 Heterotropic bacteria

The spread plate method was adoptd for the measurement of Heterotropic bacteria. MB2216 agar culture media was used and cultivated at 25°C for 5 days.

For uptake water and control water, 0.1 ml of dilutioned test water into 1, 10, 100, and 1,000 times were spread on the 5 culture medias, and 100 ml of treated test water was spread onto more than 3 culture media after being filtered by the membrane filter and the number of colonies were enumerated after 5 days culturing duration.

Results of determination were recorded on the field note for analysis for each test water sample. After eliminating abnormal value, averaged value was adopted.

3.3 Water quality

It is required to measure water temperature, salinity, POC and TSS in G8 guideline, but turbidity, pH, DO (Dissolved Oxygen) and in addition to these items ORP (Oxidation Reduction Potential) were performed. Measurements were done during uptake, discharge of treated water, and control water, and the direct measurement by the measuring equipment were done at the quay where the test water samples for L size and S size group were collected.

Measurering method for each item is explained below.

3.3.1 Water temperature

Water temperature was measured by direct-reading multiple water quality equipment, AAQ1183 type made by JFE-Advantech Co., Ltd (former ALEC Electronics Co., Ltd). The sensor for water temperature is thermistor and measurering range is from −5°C to 40°C, resolution is 0.001°C and accuracy is ±0.02°C.

3.3.2 Salinity

Salinity was also measured by the direct-reading multiple water quality equipment type AAQ1183, same as water temperature.

Salinity is calculated using electric conductivity and water temperature measured by electromagnetic induction cell. Measureing range is from 0 to 40PSU, resolution is 0.001PSU and accuracy is ± 0.03 PSU, as practical salinity.

3.3.3 Total suspended solid (TSS)

TSS was measured by sampled water analysis. Sampled test water was filterated using filter (Wattman GF-F type, pore size $0.7\mu m$) weighed and dryed using drying oven in the onsite laboratory after removing salt by washing with purified water. Filters were put in the hermetically sealed enclosures and weighed at the main laboratory after transportation.

Used balance was Shimazu LIBROR AEU-210.

3.3.4 Particulate organic carbon (POC)

The sampled test water was transported to the environmental laboratory and POC was measured there. TOC and DOC was measured using TOC meter and POC was calculated by subtracting DOC from TOC as the analysis method of POC.

Shimazu TOC-5000A type was used as the analytical equipment and Advantec QR100 type

was used as the filter.

3.3.5 pH

pH was measured by the direct-reading multiple water quality equipment AAQ1183 type made by JFE-Advantech Co., Ltd which was used in measurements of water temperature and salinity.

pH sensor is made of glass electrode and measuring range is from 0 to 14pH, resolution is 0.01pH and accuracy is ± 0.2 .

3.3.6 Dissolved oxygen (DO)

DO was also measured by the same direct-reading multiple water quality equipment AAQ1183 type made by JFE-Advantech Co., Ltd.

DO sensor is made of galvanic electrode and measuring range is from 0 to 20 mg/L (0-200%), resolution is 0.01 mg/L (0.01%) and accuracy is $\pm 0.2 \text{mg/L}$ ($\pm 1\%$).

3.3.7 Turbidity

Turbidity was also measured by the same direct-reading multiple water quality equipment AAQ1183 type made by JFE-Advantech Co., Ltd.

Turbidity sensor is the infrared ray backward scattering type, and measuring range is from 0 to 1000 FTU in FTU^{*1} , resolution is 0.03 FTU and accuracy is $\pm 0.2\%$.

*1: FTU (Forumajin Turbidity Unit)

3.3.8 Oxidation-reduction potential (ORP)

ORP was measured by small measuring instrument HM-21P type product of DKK -TOA Corporation. Measuring range is from 0 to 1.999mV and accuracy is ± 2 mV.

Table-2 Specification of the direct-reading multiple water quality equipment (AAQ1183 type made by JFE-Advantech Co., Ltd.)

Item	Туре	Meas. Range	Resolution	Accuracy	Time Constant (sec.)
Deapth	Semi-conductor type pressure gauge	0~100m	0.002m	0.3% FS	0.2
Water Temp.	Thermistor	-5 ~ 40°C	0.001°C	±0.02 °C	0.28
Conductivity	Electromagnetic induction cell	0∼60ms/cm	0.001ms/cm	±0.02 ms/cm	0.28
Salinity	Practical salinity type	0~40	0.001	±0.03	1
Turbidity	Infrared ray backward scattering type	0~1000FTU	0.03FTU	±2% of m.v.*1	0.2
DO	Galvanic electrode type	0~20mg/L	0.01mg/L	±0.2 mg/L	3.5
pН	Glass	0 ~ 14 pH	0.01pH	± 0.2	10

*1; measured value

4. Results of Measurements

Measurement results are shown as three parts consist of the measurement results relating to the effectiveness of onboard tests, the decision to pass or fail to regulation D-2 and other measurements.

4.1 Measurement results relating to the effectiveness of onboard tests

It is required by G8 guideline that the concentration of organisms in ballast water during uptake should be more than 10 times of D-2.1 specified value of regulation D-2 and the concentration of organisms in ballast tank storing non-treated ballast watert (control ballast tank) should be more than D-2.1 specified value during discharge.

That is, it is necessary that the concentration of L size group organisms in ballast water should be more than 100 ind./m³, the concentration of S size group should be more than 100 ind./m¹ during uptake and the concentration of organisms should be more than 10 ind./m³ for L size and more than 10 ind./m¹ for S size during discharge.

Mesurement results of this onboard tests indicated that concentration of L size group organisms was 11,551-240,642 ind./m³, 680-2,210 ind./ml for S size group organisms during uptake and 28,982-336,713 ind./m³ for L size group, 103-1,280 ind./ml for S size group during discharge. As these results shown that the concentration of organisms all cleared the above stated specified value of regulation D-2, all six test cycles are judged as "Effective Test Cycle".

Measurement results are shown in Table 3.

Table 3 Measurement results relating to the effectiveness of onboard tests

		t water during before treatmen	-	Control	water during d	ischarge
	Size group	L	S	Size group	L	S
Toot Cyala	Unit	Ind./m³	Ind./ml	Unit	Ind./m ³	Ind./ml
Test Cycle	Required value	100	100	Required value	10	10
	Beginning	84,000	1,587	Beginning	273,100	870
,	Middle	148,300	680	Middle	336,700	1,190
1	End .	146,300			332,000	1,070
	Average	126,200	1,022	Average	313,933	1,043
	Beginning	169,900	2,210	Beginning	115,800	1,280
2	Middle	228,500	1,140	Middle	51,940	880
2	End	240,700	890	End	101,000	1,030
	Average	213,033	1,413	Average	89,580	1,063
	Beginning	74,200	1,680	Beginning	33,750	570
3	Middle	157,600	1,310	Middle	28,980	820
3	End	59,860	1,000	End	40,200	810
	Average	97,220	1,330	Average	34,310	733
4	Beginning	20,150	880	Beginning	154,400	720
	Middle	20,450	710	Middle	174,400	560

	End	18,620	690	End	203,000	630
	Average	19,740	760	Average	177,267	637
	Beginning	64,260	1,040	Beginning	66,800	610
_	Middle	76,020	1,180	Middle	59,800	900
5	End	54,140	1,200	End	70,530	730
	Average	64,807	1,140	Average	65,710	747
	Beginning	53,130	800	Beginning	49,280	132
	Middle	17,170	860	Middle	43,400	103
6	End	11,550	760	End	60,280	118
	Average	27,283	807	Average	50,987	117

4.2 Measurement results relating to the decision to pass or fail to regulation D-2 As stated above, the regulation D-2 specified the pass or fail decision for L size and S size group

organisms in D-2.1 and foe bacteria in D-2.2 as in the table below.

Item	Standard value
L size group organisms	less than 10 viable organisms per cubic metre
S size group organisms	less than 10 viable organisms per millilitre
Toxicogenic Vibrio Cholerae	1 cfu/100ml
Escherichia Coli.	250 cfu/100ml
Intestinal Enterococci	100 cfu/100ml

Measurement results relating to the decision to pass or fail to regulation D-2 for each test cycle are shown below.

(1) Test cycle 1

As test cycle 1, uptake and discharge works were performed on July 18th and July 20th respectively. Test results for test cycle 1 are shown in Table 4-1.

Number of L size group organisms in treated ballast water was 2, 4 and 1 ind./m³ for three measurements (beginning, middle, end) respectively, 2 in average. Number of S size group organisms was 1, 0 and 0 ind./ml respectively. In regard to bacteria, Toxicogenic *Viblio Cholerae* was 0 cfu/100ml, *Escherichia Coli* was 0 cfu/100ml and Intestinal Enterococci was 0 cfu/100ml. Therefore, the results of test cycle 1 meet regulation D2.

(2) Test cycle 2

As test cycle 2, uptake and discharge works were performed on July 19th and July 21th respectively. Test results for test cycle 2 are shown in Table 4-2.

Number of L size group organisms in treated ballast water was 0.3, 0.3 and 0 ind./m³ for three measurements (beginning, middle, end) respectively. Number of S size group organisms was 0, 0 and 0 ind./ml respectively. In regard to bacteria, Toxicogenic *Viblio Cholerae* was 0 cfu/100ml, *Escherichia Coli* was 0 cfu/100ml and Intestinal Enterococci was 0 cfu/100ml. Therefore, the results of test cycle 2 meet regulation D2.

(3) Test cycle 3

As test cycle 3, uptake and discharge works were performed on July 20th and July 22th

respectively. Test results for test cycle 3 are shown in Table 4-3.

Number of L size group organisms in treated ballast water was 0, 0.3 and 0 ind./m³ for three measurements (beginning, middle, end) respectively. Number of S size group organisms was all 0 ind./ml for three measurements. In regard to bacteria, Toxicogenic *Viblio Cholerae* was 0 cfu/100ml, *Escherichia Coli* was 0 cfu/100ml and Intestinal Enterococci was 0 cfu/100ml. Therefore, the results of test cycle 3 meet regulation D2.

(4) Test cycle 4

As test cycle 4, uptake and discharge works were performed on July 21th and July 23th respectively. Test results for test cycle 4 are shown in Table 4-4.

Number of L size group organisms in treated ballast water was 0, 0 and 0 ind./m³ for three measurements (beginning, middle, end) respectively. Number of S size group organisms was all 0 ind./ml for three measurements. In regard to bacteria, Toxicogenic *Viblio Cholerae* was 0 cfu/100ml, *Escherichia Coli* was 0 cfu/100ml and Intestinal Enterococci was 0 cfu/100ml. Therefore, the results of test cycle 4 meet regulation D2.

(5) Test cycle 5

As test cycle 5, uptake and discharge works were performed on July 22th and July 24th respectively. Test results for test cycle 5 are shown in Table 4-5.

Number of L size group organisms in treated ballast water was 0, 0 and 0 ind./m³ for three measurements (beginning, middle, end) respectively. Number of S size group organisms was all 0 ind./ml for three measurements. In regard to bacteria, Toxicogenic *Viblio Cholerae* was 0 cfu/100ml, *Escherichia Coli* was 0 cfu/100ml and Intestinal Enterococci was 0 cfu/100ml. Therefore, the results of test cycle 5 meet regulation D2.

(6) Test cycle 6

As test cycle 6, uptake and discharge works were performed on July 23th and July 25th respectively. Test results for test cycle 5 are shown in Table 4-6.

Number of L size group organisms in treated ballast water was 0, 0 and 0 ind./m³ for three measurements (beginning, middle, end) respectively. Number of S size group organisms was all 0 ind./ml for three measurements. In regard to bacteria, Toxicogenic *Viblio Cholerae* was 0 cfu/100ml, *Escherichia Coli* was 0 cfu/100ml and Intestinal Enterococci was 0 cfu/100ml. Therefore, the results of test cycle 6 meet regulation D2.

Table 4-1 Results of biological efficacy measurements in test cycle 1

Upatake		18-Jul-09				Discharge		20-Jul-09	
	U	ptaken wate	r			Treated Water		C	ontrol Water
	Required condition	≧100			Required condition	<10	Measured value for 3 samples	Required condition	≧10
		ind./m3				ind./m3	Samples	Retail to the second	ind./m3
L size group	Uptake B	84,000	De la constitución de la constit	→	Discharge B	2	1,2,3	Disschrge B	273,100
(≥50µm)	M	148,300		→	M	4	6,2,4	М	336,700
(= John)	E	146,300		_	E	1	0,2,1	E	332,000
	Average	126,200			Average	2	0,2,1	Average	313,933
	Strd. Dev.	36,560			Strd. Dev.	2		Strd. Dev.	35,441
	Stru. Dev.	30,300	<note></note>			r: Propagation	of rotifer wa		00,111
			(Note)			ated water is no			
		lptaken wate			Species in tre	Treated Water	or observed		ontrol Water
		ptaken wate	il.			Treated Water	Measured		Onci of Water
S size group	Required condition	≧100			Required condition	<10	value for 3 samples	Required condition	≧10
	100 100 100	ind./ml	Server.			ind./ml			ind./ml
(10−50µm)	Uptake B	1,587		\rightarrow	Discharge B	1.0		Discharge B	870
	M	680		\rightarrow	M	0	0,0,0	M	1,190
	E	800		\rightarrow	E	0	0,0,0	E	1,070
	Average	1,022	0 10 10 10 E		Average	0		Average	1,043
	Strd. Dev.	493			Strd. Dev.	1		Strd. Dev.	162
Bacteria	. 1	lptaken wate	er			Treated Water		C	ontrol Water
	Required		Harry Harry		Required		Treated water		
Vibrio sp.	condition	none			condition	none	/Uptake		none
		cfu/100ml			Condition	cfu/100ml			cfu/100ml
Including Chalana	Uptake B	3.3E+04		_	Discharge B	70	2 1E-02	Discharge B	2.8E+04
Including Cholerae	The second secon			-	Discharge B	55	1.0E-03	Discharge B	
(A part of Vibrio)	M	5.4E+04		→				E	THE RESERVE AND ADDRESS OF THE PARTY OF THE
	E	5.3E+04		\rightarrow	E	45	8.5E-04		3.4E+04
	Average	47,052			Average	57	1.2E-03	Average	72,222
	Strd. Dev.	11,783			Strd. Dev.	13	ENTER SERVICE	Strd. Dev.	71,477
		Jptaken wate	r			Treated Water		C	Control Water
Vibrio cholerae	Required	none	100		Required	<1(Toxicogenic	:)		none
TIDITO UTIDICIAE	condition		Merce by		condition				
		cfu/100ml	K. W. Le			cfu/100ml			cfu/100ml
(Incl. Toxicogenic	Uptake B	0		-	Discharge B	0		Discharge B	0
Viblio Cholerae)	M	0		\rightarrow	M	0		M	0
Annual Control of Cont	E	0	(A. 15 P. 15)	\rightarrow	E	0		E	0
	Average	_			Average		151112	Average	V - 100
	Strd. Dev.				Strd. Dev.			Strd. Dev.	_
		Jptaken wate	ar		oura, pov.	Treated Water			Control Water
Coliform	Required				Required			Since Services	
	condition				condition				none
bacteria	condition				Condition	cfu/100ml			cfu/100ml
		cfu/100ml			D: 1 D			Disabarga P	
	Uptake B	14		\rightarrow	Discharge B	0		Discharge B	48
	M	21		\rightarrow	M	0		M	72
	E	23	W 24 2 2	\rightarrow	E	0		E	
	Average	19			Average	Market State		Average	45
	10: 10	5	END STORE				Charles of the latest of the l	Strd. Dev.	
	Strd. Dev.				Strd. Dev.		N. Handard Street, St. of St. of Street, St. of St.		29
	l	Jptaken wate	er			Treated Water			29 Control Water
Escherichia			er		Strd. Dev. Required	DEVISION SERVICE			Control Water
Escherichia coli	l	none	er			<250			none
	Required	none	er		Required	<250			Control Water
	Required condition	none		\rightarrow	Required	<250			none cfu/100ml
	Required condition Uptake B	none		1 1	Required condition	<250 cfu/100ml		C	none cfu/100ml
	Required condition Uptake B	none cfu/100ml 8		1 1 1	Required condition Discharge B	<250 cfu/100ml		Discharge B	none cfu/100ml
	Required condition Uptake B M	none cfu/100ml 8 7			Required condition Discharge B M E	<250 cfu/100ml 0		Discharge B	none cfu/100ml 4
	Required condition Uptake B M E Average	none cfu/100ml 8 7 7 7			Required condition Discharge B M E Average	<250 cfu/100ml 0		Discharge B M E Average	none cfu/100ml 4 7
	Required condition Uptake B M E Average Strd. Dev.	none cfu/100ml 8 7 7 7 1			Required condition Discharge B M E	<250 cfu/100ml 0 0		Discharge B M E Average Strd. Dev.	none cfu/100ml 4 7 7 6 6 2
	Required condition Uptake B M E Average Strd. Dev.	none cfu/100ml 8 7 7 7 1 Jptaken wate			Required condition Discharge B M E Average Strd. Dev.	<250 cfu/100ml 0 0 0 Treated Water Intestinal		Discharge B M E Average Strd. Dev.	none cfu/100ml 4 7 7 6
	Required condition Uptake B M E Average Strd. Dev.	none cfu/100ml 8 7 7 7 1 Jptaken wate			Required condition Discharge B M E Average Strd. Dev.	cfu/100ml 0 0 0 - Treated Water Intestinal		Discharge B M E Average Strd. Dev.	none cfu/100ml 4 7 7 6 2 Control Water
coli	Required condition Uptake B M E Average Strd. Dev.	none cfu/100ml 8 7 7 1 Jptaken water			Required condition Discharge B M E Average Strd. Dev.	cfu/100ml 0 0 0 - Treated Water Intestinal Enterococci		Discharge B M E Average Strd. Dev.	none cfu/100ml 4 7 7 6 6 2
coli Enterococcus	Required condition Uptake B M E Average Strd. Dev. Required	none cfu/100ml 8 7 7 7 1 Jptaken wate			Required condition Discharge B M E Average Strd. Dev.	cfu/100ml 0 0 0 0 Treated Water Intestinal Enterococi <100)		Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 Control Water none
coli Enterococcus	Required condition Uptake B M E Average Strd. Dev. Required condition	none cfu/100ml 8 7 7 1 Jptaken wate none cfu/100ml	er		Required condition Discharge B M E Average Strd. Dev. Required condition	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 control Water none cfu/100ml
coli Enterococcus	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B	none cfu/100ml 8 7 7 7 1 Jptaken wate none cfu/100ml 38	er		Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B	C250 cfu/100ml 0 0 0 0 Treated Water Intestinal Enterococi C100) cfu/100ml 0		Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 Control Water none cfu/100ml 2
coli Enterococcus	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M M M M M M M M M M M M M M M M M M	none cfu/100ml 8 7 7 7 1 Jptaken wate none cfu/100ml 38 34	er		Required condition Discharge B M E E Average Strd. Dev. Required condition Discharge B M			Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 Control Water none cfu/100ml 2 1
coli Enterococcus	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E	none cfu/100ml 8 7 7 7 1 Jptaken wate none cfu/100ml 38 34 3	er		Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E E E E E E E E E E E E E E E E E			Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 Control Water none cfu/100ml 2 1 2
coli Enterococcus	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average	none cfu/100ml 8 7 7 7 1 Jptaken water none cfu/100ml 38 34 32 25	er		Required condition Discharge B M E E Average Strd. Dev. Required condition Discharge B M E E E E E E E E E E E E E E E E E E			Discharge B Average Strd. Dev. Discharge B M Average Average	control Water none cfu/100ml 4 7 7 6 2 Control Water none cfu/100ml 2 1
coli Enterococcus	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev.	none cfu/100ml 8 7 7 7 1 Jptaken wate none cfu/100ml 38 34 3 25 19	er		Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E E E E E E E E E E E E E E E E E	<pre> <250 cfu/100ml 0 0 0</pre>		Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 7 6 2 Control Water none cfu/100ml 2 1 2 2 2 1
coli Enterococcus	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev.	none cfu/100ml 8 7 7 7 1 Jptaken water none cfu/100ml 38 34 32 25	er		Required condition Discharge B M E Average Strd. Dev. Discharge B M M E E Average Strd. Dev.	C250 cfu/100ml 0 0 0 0		Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 Control Water none cfu/100ml 2 1 2
coli Enterococcus	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev.	none cfu/100ml 8 7 7 7 1 Jptaken wate none cfu/100ml 38 34 3 25 19 Jptaken wate	er		Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E Average STRD M M E E E E E E E E E E E E E E E E E	C250 cfu/100ml 0 0 0 0	Treated water	Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 Control Water none cfu/100ml 2 1 2 2 1 Control Water
Enterococcus Group	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev.	none cfu/100ml 8 7 7 7 1 Jptaken wate none cfu/100ml 38 34 3 25 19 Jptaken wate	er		Required condition Discharge B M E Average Strd. Dev. Discharge B M M E E Average Strd. Dev.	C250 cfu/100ml 0 0 0 0		Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	Control Water
Enterococcus Group	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E E Average Strd. Dev.	none cfu/100ml 8 7 7 7 1 Jptaken wate none cfu/100ml 38 34 3 25 19 Jptaken wate	er		Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E Average STRD M M E E E E E E E E E E E E E E E E E	C250 cfu/100ml 0 0 0 0	Treated water	Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 Control Water none cfu/100ml 2 1 2 2 1 Control Water
Enterococcus Group	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition	none cfu/100ml 8 7 7 7 1 Jptaken wate none cfu/100ml 38 34 32 5 19 Jptaken wate none cfu/100ml	er		Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev. Required condition	C250 cfu/100ml 0 0 0 Treated Water Intestinal Enterococi C100) cfu/100ml 0 Treated Water none cfu/100ml	Treated water	Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 Control Water none cfu/100ml 2 1 2 2 1 Control Water none cfu/100ml cfu/100ml
Enterococcus Group	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E E Average Strd. Dev.	none cfu/100ml 8 7 7 7 1 Jptaken wate none cfu/100ml 38 34 32 5 19 Jptaken wate none cfu/100ml	er		Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E Average STRD M M E E E E E E E E E E E E E E E E E	C250 cfu/100ml 0 0 0 Treated Water Intestinal Enterococi C100) cfu/100ml 0 Treated Water none cfu/100ml	Treated water	Discharge B M E Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 Control Water none cfu/100ml 2 1 2 2 1 Control Water none cfu/100ml cfu/100ml
Enterococcus Group	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition	none cfu/100ml 8 7 7 7 1 Jptaken wate none cfu/100ml 38 34 3 25 19 Jptaken wate none cfu/100ml 9.1E+05	er		Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev. Required condition	C250 cfu/100ml 0 0 0 0	Treated water/Uptake	Discharge B Average Strd. Dev. Discharge B Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 control Water none cfu/100ml 2 1 2 2 1 Control Water none cfu/100ml 6 0 Control Water none cfu/100ml 6 Control Water none cfu/100ml
Enterococcus Group	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E E Average Strd. Dev. Uptake B M E E Average Strd. Dev. Required condition Uptake B M M E E Average Strd. Dev.	none cfu/100ml 8 7 7 7 7 1 Jptaken wate none cfu/100ml 38 34 3 25 19 Jptaken wate none cfu/100ml 9.1E+05	er		Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E E E E E E E E E E E E E E E E E	C250 cfu/100ml 0 0 0 0 Treated Water Intestinal Enterococi C100) cfu/100ml 0 Treated Water none cfu/100ml 1.0E+03	Treated water/Uptake 1.1E-03	Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev. O Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 Control Water none cfu/100ml 2 1 2 2 1 Control Water 1 6.0E+05
Enterococcus Group	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition	none cfu/100ml 8 7 7 7 1 Jptaken wate none cfu/100ml 38 34 3 25 19 Jptaken wate none cfu/100ml 9.1E+05	er		Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E Average Strd. Dev. Required condition Discharge B M E E E E E E E E E E E E E E E E E E	C250 cfu/100ml 0 0 0 0 Treated Water Intestinal Enterococi C100) cfu/100ml 0 Treated Water none cfu/100ml 1.0E+03	Treated water /Uptake	Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev. O Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 4 7 7 6 2 Control Water none cfu/100ml 2 1 2 2 1 Control Water 1 6.0E+05

Table 4-2 Results of biological efficacy measurements in test cycle 2

Upatake		19-Jul-09		→		Discharge		21-Jul-09		
		Jptake wate	r	Mile I		Treated Water		C	ontrol Wat	er
	Required condition	≧100			Required condition	<10	Measured value for 3 samples	Required condition	≧10	
	Version 150	ind./m3				ind./m3	Campioo	Test de la Confession d	ind./m3	
L size group	Uptake B	169,900	ind./m3	\rightarrow	Dischrge B	0.3	1,0,0	Discharge B	115,800	ind./m3
(≧50μm)	M	228,500			M	0.3	1,0,0	M	51,940	
	Е	240,700			E	0	0,0,0	E	101,000	Bank
	Average	213,033			Average	0		Average	89,580	
	Strd. Dev.	37,849			Strd. Dev.	0		Strd. Dev.	33,427	
	THE RESERVE OF THE PARTY OF THE	Jptake wate	r			Treated Water	Measured	The second secon	ontrol Wat	er
S size group	Required condition	≧100			Required condition	<10	value for 3 samples	Required condition	≧10	
		ind./ml		line.		ind./ml			ind./ml	
(10-50µm)	Uptake B	2,210		\rightarrow	Dischrge B	0	0,0,0	Dischrge B	1,280	
	M	1,140			M	0	0,0,0	М	880	
	E	890			E	0	0,0,0	E	1,030	
	Average	1,413			Average	0		Average	1,063	
	Strd. Dev.	701			Strd. Dev.	-		Strd. Dev.	202	BURNO
D		lataka wata				Treated Water			ontrol Wat	0.5
Bacteria	Required	Jptake wate		a land	Required		Treated water			
Vibrio sp.	condition	none			condition	none cfu/100ml	/Uptake		none cfu/100ml	
Including Cholerae	Uptake B	4.4E+04	2	-	Discharge B	107	2 4F-03	Discharge B	8.7E+04	Benjaman.
(A part of Vibrio)	Оргаке В	3.5E+04	2	→	M	70		Discharge B	6.9E+04	
(A part of Vibrio)	E	3.2E+04		→	E	34		E	4.9E+04	
	Average	3.7E+04	NAME OF TAXABLE PARTY.		Average	70		Average	6.9E+04	107618220
	Strd. Dev.	6.3E+03			Strd. Dev.	37	1.02 00	Strd. Dev.	1.9E+04	
		Jptake wate	r	1	otra. Dev.	Treated Water			ontrol Wat	
Vibrio cholerae	Required				Required	and the second section of the section of the second section of the section of the second section of the section of th	ALEXANDER OF THE PARTY OF THE P		DESIGNATION OF THE PROPERTY OF	
Vibrio choierae	condition	none		1	condition	(I oxicogeni	C)		none	
		cfu/100ml	mi. 158	Toys		cfu/100ml			cfu/100ml	
(Incl. Toxicogenic	Uptake B	0		\rightarrow	Discharge B	0		Discharge B	0	
Viblio Cholerae)	M	0		\rightarrow	M	0		М	0	
	. E	0		→	E	0		E	0	
	Average				Average			Average		
	Strd. Dev.				Strd. Dev.	Treated Water		Strd. Dev.	ontrol Wat	0.5
Coliform	Required	Jptake wate			Required			in the second se	ontroi wat	er
bacteria	condition	none		1 3	condition	none			none	100
Dacteria	Condition	cfu/100ml			Condition	cfu/100ml			cfu/100ml	
	Uptake B	268		→	Discharge B	1	E 15 1 15 1 15	Discharge B	22	-
	M	47		→	M	0		M	11	The state of the s
	E	59		→	E	0		Е	5	
	Average	125			Average	0		Average	13	
	Strd. Dev.	124		1	Strd. Dev.	1		Strd. Dev.	9	
		Jptaken wate	r			Treated Water		C	ontrol Wat	er
Escherichia	Required	none			Required	<250			none	
coli	condition		186		condition		The state of the s			
		cfu/100ml	SENEAR.			cfu/100ml			cfu/100ml	
	Uptake B		cfu/100ml	\rightarrow	Discharge B	0		Discharge B	8	
	M	15		→	M	0		M	8	
	E	17	ALCOHOL: N	_	Ε	0		E A.v.e.ve	2	
	Average	21			Average Strd Dov	_		Average Strd Day	6 3	
	Strd. Dev.	Jptaken wate	r		Strd. Dev.	Treated Water		Strd. Dev.	ontrol Wat	er
		ptaken wate				Intestinal			CALL OF TRAL	
Enterococcus	Required	none			Required	Enterococci			none	STEET TO
Group	condition	Home			condition	<100)				
	AUTOWY SIZE	cfu/100ml	ME MAN			cfu/100ml			cfu/100ml	
Control of the second	Uptake B		cfu/100ml	\rightarrow	Discharge B	0		Discharge B	3	
	M	22		-	M	0	and the second second second	М	3	
	E	53	STEED VE	→	E	0		E	5	
	Average	44			Average			Average	4	
	Strd. Dev.	19			Strd. Dev.			Strd. Dev.	1	
		Jptaken wate	r	1		Treated Wate	Ilreated	C	ontrol Wat	er
Heterotrophic	Required	none			Required	none	Treated water		none	
bacteria	condition		THE STAN		condition		/Untake			
		cfu/100ml				cfu/100ml	A STATE OF		cfu/100ml	
	Uptake B		cfu/100ml	\rightarrow	Discharge B	4.1E+02		Discharge B	7.0E+05	
	M	1.2E+05		→	M	4.5E+02			6.5E+05	
	E	2.1E+06		-	E	4.9E+02				
	Average	1.0E+06			Average	4.5E+02	4.3E-04	Average	4.7E+05	
	Strd. Dev.	1.0E+06			Strd. Dev.	4.0E+01		Strd. Dev.	3.6E+05	

Table 4-3 Results of biological efficacy measurements in test cycle 3

Upatake		20-Jul-09		\rightarrow		Discharge		22-Jul-09		
	l	Jptaken wate	er		100100000000000000000000000000000000000	Treated Water	Q/445.50	C	ontrol Wate	er
	Required condition	≧100			Required condition	<10	Measured value for 3 samples	Required condition	≧10	
		ind./m3			VALUE OF THE SAME	ind./m3			ind./m3	Bed State
L size group	Uptake B	74,200		-	Discharge B	0	0,0,0	Disschrge B	33,750	ind./m3
(≧50µm)	M	157,600			M	0.3	0,1,0	M	28,980	u= STSIC
	E	59,860			E	0	0,0,0	Ε	40,200	
	Average	97,220	Section 1988		Average	0		Average	34,310	
	Strd. Dev.	52,780			Strd. Dev.	0		Strd. Dev.	5,631	
		Jptaken wate	er			Treated Water		C	ontrol Wate	er
	Required	>	Name and	1100	Required	440	Measured	Required	~10	
S size group	condition	≧100 ind./ml			condition	<10 ind./ml	value for 3 samples	condition	≧10	
(10-50µm)	Uptake B	1,680	ind./ml	→	Discharge B	0	0,0,0	Discharge B	570	ind./ml
(10-30μπ)	M	1,310	IIIu./ IIII		M M	0	0,0,0	M M	820	1110./ 1111
	E	1,000			E	0	0,0,0	E	810	
	-	1,330		188		0	0,0,0	Average	733	BUANCO BOOK
	Average	340			Average	0		Strd. Dev.	142	
	Strd. Dev.	340			Strd. Dev.	U		Stra. Dev.	142	British Co.
D. stavia	I and the second	Intolen wate		1		Treated Water			ontrol Wat	05
Bacteria		Jptaken wate	er I		D	and the second s			ontroi wat	er
Vibrio sp.	Required condition	none			Required condition	none	Treated water /Uptake		none	
	Unit				D: 1	cfu/100ml	F F F 00	D:1	cfu/100ml	
Including Cholerae	Uptake B	3.0E+04		-	Discharge B	165		Discharge B	4.0E+03	
(A part of Vibrio)	M	1.3E+03		\rightarrow	M	48	3.6E-02	M	3.4E+04	
	E	6.0E+03		\rightarrow	Е	55	9.2E-03	E	3.0E+04	
	Average	1.2E+04			Average	89	7.2E-03	Average	22,778	
	Strd. Dev.	1.5E+04			Strd. Dev.	66		Strd. Dev.	16,406	
	L	Jptaken wate	er			Treated Water		C	ontrol Wat	er
Vibrio cholerae	Required				Required	<1(Toxicogeni	-)		none	
VIDIO choierae	condition	none			condition	(1(1 oxicogeni	C)		none	
		cfu/100ml	ALC: NO			cfu/100ml			cfu/100ml	
(Incl. Toxicogenic	Uptake B	0	cfu/100ml	-	Discharge B	0	DESCRIPTION.	Discharge B	0	
Viblio Cholerae)	M	0		-	M	0		M	0	Difference N
	E	0	Manual Add	-	E	0	TOTAL CALL	E	0	
	Average	0			Average	0		Average	0	
	Strd. Dev.	0			Strd. Dev.	0		Strd. Dev.	0	
		Jptaken wate	er			Treated Water	THE SHOW	C	ontrol Wat	er
Coliform	Required				Required				PERSONAL SE	
bacteria	condition	none			condition	none			none	
		cfu/100ml				cfu/100ml			cfu/100ml	
	Uptake B	61	HONE YES	-	Discharge B	- 0		Discharge B	14	cfu/100ml
	M	60		-	M	0		М	16	
	E	43		-	E	0		E	15	
	Average	55			Average	0		Average	15	
	Strd. Dev.	10			Strd. Dev.	0		Strd. Dev.	1	
		Jptaken wate	-		Stru. Dev.	Treated Water	ALEXANDER DE LA COMPANION DE L La companion de la companion de		ontrol Wat	or
Escherichia	Required				Required		REVIEWS (INC.)		Vontion wat	
coli	condition	none			condition				none	
COII	Condition	cfu/100ml			Condition	cfu/100ml			cfu/100ml	200
	Hatalia D		In the Carlo		Discharge B			Discharge B		
	Uptake B M	27		[Discharge B	0		Discharge B	7	
	E E	25		\rightarrow	E	0		E	3	
			reint avenue			0			6	No. of Concession, Name of Street, or other party of the Concession, Name of Street, or other pa
	Average	31			Average	0		Average	3	
	Strd. Dev.	Intokon wate			Strd. Dev.			Strd. Dev.		or .
	U	Jptaken wate	er I			Treated Water	Carried Services	C	ontrol Wat	er
Enterococcus	Required				Required	Intestinal				
Group	condition	none			condition	Enterococci			none	
				DAY.		(100)			-F. /100 I	
	11 . 1	cfu/100ml	f /200 ·		D: 1 D	cfu/100ml		Dil- D	cfu/100ml	
	Uptake B		cfu/100ml	→	Discharge B	0		Discharge B		
	M	33	-	-	M			M	2	Contract Contract
	E	39		→	E			E	3	
	Average	37			Average	0		Average	2	
	Strd. Dev.	3			Strd. Dev.	0		Strd. Dev.	1	AND CONTROL
		Jptaken wate	er			Treated Water		C	ontrol Wat	er
Heterotrophic	Required				Required	none	Treated water		none	
bacteria	condition				condition		/Uptake			
		cfu/100ml				cfu/100ml			cfu/100ml	
	Uptake B	1.8E+06	cfu/100ml	-	Discharge B	2.1E+02	1.2E-04	Discharge B	1.9E+06	
	M	3.2E+06		-	M				4.9E+05	
	E			-	E					
	Average	3.0E+06	531600		Average	1.8E+02	6.0E-05	Average	1.0E+06	
	Strd. Dev.	1.2E+06			Strd. Dev.	6.4E+01		Strd. Dev.	7.8E+05	
THE RESERVE OF THE PARTY OF THE										

Table 4-4 Results of biological efficacy measurements in test cycle 4

Uptake		21-Jul-09	Total Control		Discharge		23-Jul-09	
	L	Jptaken water			Treated Water		C	ontrol Water
	Required condition	≧100		Required condition	<10	Measured value for 3 samples	Required condition	≧10
		ind./m3			ind./m3			ind./m3
_ size group	Uptake B	20,150	→	Discharge B	0	0,0,0	Description of	154,400
≧50μm)	М	20,450	A STATE OF THE STA	M	0			174,400
	E	18,620		E	0			203,000
	Average	19,740		Average	0		Average	177,267
	Strd. Dev.	981		Strd. Dev.	0		Strd. Dev.	24,426
		Jptaken water			Treated Water			Control Water
		The second secon	1		Treated Water	Measured		I I
S size group	Required condition	≧100		Required condition	<10	value for 3 samples	Required condition	≧10
		ind./ml	SELECTION OF		ind./ml			ind./ml
(10∼50 μ m)	Uptake B	880	-	Discharge B	0	0,0,0	Discharge B	720
	M	710		M	0	0,0,0	M	560
	E	690	RESCHOOL STATE	E	0	0,0,0	E	610
	Average	760		Average	0		Average	630
	Strd. Dev.	104		Strd. Dev.	0		Strd. Dev.	82
	ou a. Dov.							
Bacteria		Jptaken water	SCHOOL STATE		Treated Water		C	Control Water
	Required			Required		Treated water		
Vibrio sp.	condition	none		condition	none	/Uptake		none
	Unit	cfu/100ml	100	Solidicion	cfu/100ml			cfu/100ml
Including Cholerae	Uptake B	3.7E+03	_	Discharge B	102	2 8E-02	Discharge B	
			\rightarrow	Discharge B	The second second		Discharge B	
(A part of Vibrio)	M	8.0E+03			14	1.8E-03		
	. E	2.4E+04	→	. E	65	2.7E-03	. E	
	Average	1.2E+04		Average	60	5.1E-03		2.1E+04
	Strd. Dev.	1.1E+04		Strd. Dev.	44		Strd. Dev.	4.5E+03
		Jptaken water			Treated Water		C	Control Water
Vibrio cholerae	Required	none		Required	<1(Toxicogeni	(c)		none
Vibrio choierae	condition	none		condition	(1(10xicogeni	C)		none
	TWILE THE	cfu/100ml	N 100 - 100 100		cfu/100ml			cfu/100ml
(Incl. Toxicogenic	Uptake B	0	→	Discharge B	0		Discharge B	0
Viblio Cholerae)	М	0	→	М	0	C. Vicelling Ed	М	
Vibilo Cholerae)	E	0	→	E	0		E	AND DESCRIPTION OF THE PERSON NAMED IN COLUMN 1
	Average	0		Average	0		Average	0
	Strd. Dev.	0		Strd. Dev.	0		Strd. Dev.	0
					Treated Water			Control Water
0 116		Jptaken water	Selection (I Water
Coliform	Required	none		Required	none			none
bacteria	condition	. //		condition	5 (400 1			5 (400 1
		cfu/100ml		18.11. 46.	cfu/100ml			cfu/100ml
	注入 前	34	-	排出前	0		cfu/100ml	12
	中	40	→	中	0			10
	後	33	\rightarrow	後	0			12
	平均	36		平均	0		平均	11
	標準偏差	4		標準偏差	0		標準偏差	1
	ĺ	Jptaken water				The state of the s		
Escherichia	D				Treated Water	Company of the second	C	Control Water
	Required			Required				
coli	Required condition	none		Required condition			· ·	none
coli	condition	none			<250		•	none
coli	condition	cfu/100ml	1	condition	<250 cfu/100ml			none cfu/100ml
coli	condition Uptake B	cfu/100ml	→	condition Discharge B	<250 cfu/100ml		Discharge B	none cfu/100ml
coli	condition	cfu/100ml	→ → 1	condition Discharge B	<250 cfu/100ml 0		Discharge B	none cfu/100ml 4 3
coli	Uptake B M E	cfu/100ml 9 5	→ → →	condition Discharge B M E	<250 cfu/100ml 0 0		Discharge B M E	none cfu/100ml 4 3 2
coli	Uptake B M E Average	cfu/100ml 9 5 2 5	→ →	Discharge B M E Average	<250 cfu/100ml 0 0 0 0		Discharge B M E Average	none cfu/100ml 4 3
coli	Uptake B M E Average Strd. Dev.	cfu/100ml 9 5 2 5	†	condition Discharge B M E	<250 cfu/100ml 0 0 0 0 0 0		Discharge B M E Average Strd. Dev.	none cfu/100ml 4 3 2 2 3
Enterococcus Group	Uptake B M E Average Strd. Dev. Required	rone cfu/100ml 9 5 2 5 4 Jptaken water	→ → →	Discharge B M E Average	cfu/100ml 0 0 0 0 Treated Water Intestinal Enterococci		Discharge B M E Average Strd. Dev.	none cfu/100ml 4 3 2
	Uptake B M E Average Strd. Dev.	rone cfu/100ml 9 5 2 5 4 Jptaken water none		condition Discharge B M E Average Strd. Dev.	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev.	none cfu/100ml 4 3 2 3 1 Control Water none
Enterococcus	Condition Uptake B M E Average Strd. Dev. U Required condition	100ml 9 5 5 2 5 4	→	condition Discharge B M E Average Strd. Dev. Required condition	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev.	none cfu/100ml 4 3 2 3 1 Control Water none cfu/100ml
Enterococcus	Condition Uptake B M E Average Strd. Dev. Required condition Uptake B	rone cfu/100ml 9 5 2 5 4 Uptaken water none cfu/100ml 80	→	condition Discharge B M E Average Strd. Dev. Required condition Discharge B	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev. C	none cfu/100ml 4 3 2 3 1 Control Water none cfu/100ml 0
Enterococcus	Condition Uptake B M E Average Strd. Dev. U Required condition	100ml 9 5 5 2 5 4	→	condition Discharge B M E E E E E E E E E E E E E E E E E E	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev.	none cfu/100ml 4 3 2 3 1 1 Control Water none cfu/100ml 6 0 1
Enterococcus	Condition Uptake B M E Average Strd. Dev. Required condition Uptake B	rone cfu/100ml 9 5 2 5 4 Uptaken water none cfu/100ml 80	→	condition Discharge B M E Average Strd. Dev. Required condition Discharge B	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev. C	none cfu/100ml 4 3 2 3 1 1 Control Water none cfu/100ml 6 0 1
Enterococcus	Condition Uptake B M E Average Strd. Dev. Required condition Uptake B M	rone cfu/100ml 9 5 2 5 4 Jptaken water none cfu/100ml 80 44	→	condition Discharge B M E E E E E E E E E E E E E E E E E E	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev.	none cfu/100ml 4 3 2 3 1 1 Control Water none cfu/100ml 6 0 1
Enterococcus	condition Uptake B M E Average Strd. Dev. U Required condition Uptake B E Average	rone cfu/100ml 9 5 2 5 4 Jptaken water none cfu/100ml 80 44 16	→	Condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev. C	none cfu/100ml 4 3 2 3 1 Control Water none cfu/100ml 1 0 1 1 1 1 1 1 1 1
Enterococcus	condition Uptake B Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev.	rone cfu/100ml 9 5 2 5 4 Jptaken water none cfu/100ml 80 44 16 47 32	→	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E Average	<pre><250 cfu/100ml</pre>		Discharge B Average Strd. Dev. Discharge B M Average Strd. Dev.	none cfu/100ml 4 3 2 3 1 Control Water none cfu/100ml 1 1 1 1 1 1 1 1 1
Enterococcus Group	condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. L	rone cfu/100ml 9 5 2 5 4 Jptaken water none cfu/100ml 80 44 16 47 32 Jptaken water	→	Condition Discharge B M E Average Strd. Dev. Discharge B M E M E M E M E M E M E M E M E E M E E M E	<pre><250 cfu/100ml</pre>		Discharge B Average Strd. Dev. Discharge B M Average Strd. Dev.	none cfu/100ml 4 3 2 3 1 Control Water none cfu/100ml 1 1 1 1 1 1 1 1 1
Enterococcus Group	Condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Uptake B M E Required	rone cfu/100ml 9 5 2 5 4 Jptaken water none cfu/100ml 80 44 16 47 32 Jptaken water	→	Condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E Average Strd. Dev.	<pre><250 cfu/100ml</pre>	Treated water	Discharge B Average Strd. Dev. Discharge B M Average Strd. Dev.	none cfu/100ml 4 3 2 3 1 Control Water none cfu/100ml 1 1 1 1 1 1 1 1 1
Enterococcus Group	condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. L	rone cfu/100ml 9 5 2 5 4 Jptaken water none cfu/100ml 80 44 16 47 32 Jptaken water	→	Condition Discharge B M E Average Strd. Dev. Discharge B M E M E M E M E M E M E M E M E E M E E M E	<pre><250 cfu/100ml</pre>		Discharge B Average Strd. Dev. Discharge B M Average Strd. Dev.	none cfu/100ml 4 3 2 3 1 Control Water none cfu/100ml 1 0 1 1 1 1 1 Control Water none cfu/100ml 1 1 1 1 1 1 1 1 1
Enterococcus Group	Condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Uptake B Required condition	rone cfu/100ml 9 5 2 5 4 Jptaken water none cfu/100ml 80 44 16 47 32 Jptaken water none cfu/100ml	1 1 1	condition Discharge B Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev. Required condition	<pre><250 cfu/100ml</pre>	Treated water /Uptake	Discharge B M E Average Strd. Dev. C Discharge B M E Average Strd. Dev. C	none cfu/100ml 4 3 3 2 3 1 2 2 3 1 2 2 3 1 2 3 1 1 1 1 1 1 1 1 1
Enterococcus Group	Condition Uptake B Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Uptake B Average Strd. Dev. Required condition Uptake B	rone cfu/100ml 9 5 2 5 4 Jptaken water none cfu/100ml 80 44 16 47 32 Jptaken water none cfu/100ml 7.8E+05	1 1 1	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E Average Strd. Dev. Required condition Discharge B Overage Strd. Dev.	<pre><250 cfu/100ml</pre>	Treated water/Uptake	Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev. C Discharge B M E Average Strd. Dev. C	none cfu/100ml 4 3 2 3 1 1 Control Water none cfu/100ml 1 1 1 1 1 1 1 1 1
Enterococcus	Condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Uptake B Required condition	rone cfu/100ml 9 5 2 5 4 Jptaken water none cfu/100ml 80 44 16 47 32 Jptaken water none cfu/100ml	1 1 1	Condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E Average Strd. Dev. Required condition Discharge B M M E E Average Strd. Dev.	<pre><250 cfu/100ml</pre>	Treated water/Uptake 2.9E-04 4.3E-04	Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev. C Discharge B M E Average Strd. Dev. C	none cfu/100ml 4 3 2 3 1 1 Control Water none cfu/100ml 1 1 1 1 1 1 Control Water none cfu/100ml 3 2.4E+05 1.0E+06 cfu/10ml 3 2.4E+05 1.0E+06 cfu/100ml 3 2.4E+05 0.0E+06 cfu/100ml 0.0E+06
Enterococcus Group	Condition Uptake B Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Uptake B Average Strd. Dev. Required condition Uptake B	rone cfu/100ml 9 5 2 5 4 Jptaken water none cfu/100ml 80 44 16 47 32 Jptaken water none cfu/100ml 7.8E+05	1 1 1	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E Average Strd. Dev. Required condition Discharge B Overage Strd. Dev.	<pre><250 cfu/100ml</pre>	Treated water/Uptake 2.9E-04 4.3E-04	Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev. C Discharge B M E Average Strd. Dev. C	none cfu/100ml 4 3 2 3 1 1 Control Water none cfu/100ml 1 1 1 1 1 1 Control Water none cfu/100ml 3 2.4E+05 1.0E+06 cfu/10ml 3 2.4E+05 1.0E+06 cfu/100ml 3 2.4E+05 0.0E+06 cfu/100ml 0.0E+06
Enterococcus Group	Condition Uptake B Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Uptake B M E Condition Uptake B M Uptake B M Average Strd. Dev. Uptake B M Required condition Uptake B	rone cfu/100ml 9 5 2 5 4 Jptaken water none cfu/100ml 80 44 16 47 32 Jptaken water none cfu/100ml 7.8E+05 6.9E+05	1 1 1	Condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E Average Strd. Dev. Required condition Discharge B M M E E Average Strd. Dev.	<pre><250 cfu/100ml</pre>	Treated water/Uptake 2.9E-04 4.3E-04 7.0E-04	Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev. C Discharge B M E Average Strd. Dev. C	none cfu/100ml 4 3 2 3 1 1 Control Water none cfu/100ml 1 1 1 1 1 1 Control Water none cfu/100ml 3 2.4E+05 1.0E+06 cfu/10ml 3 2.4E+05 1.0E+06 cfu/100ml 3 2.4E+05 0.0E+06 cfu/100ml 0.0E+06

Table 4-5 Results of biological efficacy measurements in test cycle 5

Uptake	22-Jul-09 -				Discharge		24-Jul-09		
		Uptaken water			Treated Water		C	ontrol Wate	er
	Required condition	≧100		Required condition	<10	Measured value for 3 samples	Required condition	≧10	
	1947	ind./m3			ind./m3			ind./m3	
L size group	Uptake B	64,260	\rightarrow	Discharge B	- 0	0,0,0	Disschrge B	66,800	7.76
(≧50µm)	M	76,020		- M	0		M	59,800	
	E	54,140		E	0	0,0,0	E	70,530	
	Average	64,807		Average	0		Average	65,710	
	Strd. Dev.	10,950		Strd. Dev.	0		Strd. Dev.	5,447	
		Uptaken water			Treated Water		C	ontrol Wate	er
S size group	Required condition			Required condition	<10	Measured value for 3 samples	Required condition	≧10	
		ind./ml			ind./ml			ind./ml	
(10~50 µ m)	Uptake B	1,040	\rightarrow	Discharge B	0	0,0,0	Discharge B	610	
	M	1,180		M	0	0,0,0	M	900	
	E	1,200		E	0	0,0,0	E	730	
	Average	1,140		Average	0		Average	747	
	Strd. Dev.	87		Strd. Dev.	0		Strd. Dev.	146	
							DUBLISHED TO		
Bacteria		Uptaken water			Treated Water	Contract to the Contract of th	C	ontrol Wate	er
Vibrio sp.	Required condition			Required condition		Treated water /Uptake		none	
	The state of the s			condition	cfu/100ml	, Speare		cfu/100ml	
Including Of I	Unit		AN GOVERN	Disabassa D		105.00	Disabarra D		
Including Cholerae	Uptake B			Discharge B	16		Discharge B		EL COLOR DE SE
(A part of Vibrio)	M	9.3E+03		M		1.1E-04	M E		
	E	5.0E+03	<u> </u>	E		5.8E-03			
	Average	9.1E+03		Average	15	1./E-03	Average	1.1E+04	
	Strd. Dev.	4.0E+03 Uptaken water	Account to	Strd. Dev.	14 Treated Water		Strd. Dev.	5.9E+03	ar.
	Required			Required		CONTRACTOR AND CONTRACTOR			er e
Vibrio cholerae	condition			condition	<1(Toxicogeni	c)		none	
	Condition	cfu/100ml		22.00	cfu/100ml	Carrie Same	242012000	cfu/100ml	
Including Cholerae	Uptake B	0	\rightarrow	Discharge B	0		Discharge B		cfu/100ml
(A part of Vibrio)	M	0	\rightarrow	М	0		M	0	
	E		→	E	0		E	0	asia jedi
	Average	0		Average	0		Average	0	
	Strd. Dev.	0		Strd. Dev.	0		Strd. Dev.	0	
		Uptaken water	No.		Treated Water			ontrol Wate	er
Coliform	Required			Required		REPRESENTED FOR			STERRING OF
bacteria	condition	none		condition	none			none	
ANCINE NEW AND AND		cfu/100ml		Alexander and the second	cfu/100ml		Manager St.	cfu/100ml	
	Uptake B	54	\rightarrow	Discharge B	0	Kun Kushusha	Discharge B	27	
	M	49	\rightarrow	M	0		M	8	
	E	61	\rightarrow	E	0		E	10	
	Average	55		Average	0		Average	15	
	Strd. Dev.	6		Strd. Dev.	0		Strd. Dev.	10	
		Uptaken water			Treated Water			ontrol Wat	er
Escherichia	Required			Required				none	
coli	condition			condition				No.	
		cfu/100ml		D:	cfu/100ml		D'	cfu/100ml	
	Uptake B	18	\rightarrow	I Disabayes D		The second secon	Discharge B		
	Charles and the second			Discharge B	0				
	М	19	→	M	0		M	2	
	E	19 22	→	M E	0		M E	2 3	
	E Average	19 22 20	→	M E Average	0 0 0		M E Average	2 3 4	
	Average Strd. Dev.	19 22 20 20	$\overrightarrow{\rightarrow}$	M E	0 0 0		M E Average Strd. Dev.	2 3 4 2	
	Average Strd. Dev.	19 22 20	$\overrightarrow{\rightarrow}$	M E Average	0 0 0 0 Treated Water		M E Average Strd. Dev.	2 3 4	
Enterococcus Group	Average Strd. Dev.	19 22 20 2 Uptaken water	→	M E Average	0 0 0 Treated Water Intestinal		M E Average Strd. Dev.	2 3 4 2	
	Average Strd. Dev.	19 22 20 2 Uptaken water	=	M E Average Strd. Dev.	0 0 0 0 Treated Water Intestinal Enterococci		M E Average Strd. Dev.	2 3 4 2 Control Wat	
	Average Strd. Dev. Required condition	19 22 20 2 Uptaken water none	→ → → →	M E Average Strd. Dev. Required condition	0 0 0 0 Treated Water Intestinal Enterococci <100) cfu/100ml		M E Average Strd. Dev.	2 3 4 2 Control Wat none	
	Average Strd. Dev. Required condition Uptake B	19 22 20 2 Uptaken water none cfu/100ml	→ →	Average Strd. Dev. Required condition Discharge B	0 0 0 0 Treated Water Intestinal Enterococci <100) cfu/100ml 0		Average Strd. Dev.	2 3 4 2 control Wat none cfu/100ml	
	Average Strd. Dev. Required condition Uptake B	19 22 20 2 Uptaken water none cfu/100ml 173 8	→	M E Average Strd. Dev. Required condition Discharge B M	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		M E Average Strd. Dev. C	2 3 4 2 Control Wate none cfu/100ml 0	
	Average Strd. Dev. Required condition Uptake B M E	19 22 20 2 Uptaken water none cfu/100ml 173 8	→ → → → → →	M E Average Strd. Dev. Required condition Discharge B M E	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		Average Strd. Dev.	2 3 4 2 Control Wate none cfu/100ml 0 0	
	Average Strd. Dev. Required condition Uptake B M E Average	19 22 20 2 Uptaken water none cfu/100ml 173 8 4	→	Average Brown Brow	0 0 0 0 Treated Water Intestinal Enterococi <100) cfu/100ml 0 0		Average Strd. Dev. Discharge B M M E Average	2 3 4 2 Control Wate none cfu/100ml 0	
	Required condition Uptake B Average Average Strd. Dev.	19 22 20 2 Uptaken water none cfu/100ml 173 8 4 62 96	→	M E Average Strd. Dev. Required condition Discharge B M E	0 0 0 0 Treated Water Intestinal Enterococi <100) cfu/100ml 0 0 0 0 0		Average Strd. Dev. Discharge B M E Average Strd. Dev.	2 3 4 2 2 Control Water none cfu/100ml 0 0 2 1	er
Group	Required condition Uptake B Average Strd. Dev.	19 22 20 2 2 Uptaken water none cfu/100ml 173 8 4 62 96 Uptaken water	→	M E Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev.	0 0 0 1 Treated Water Intestinal Enterococi <100) cfu/100ml 0 0 0 Treated Water		Average Strd. Dev. Discharge B M E Average Strd. Dev.	2 3 4 2 2 2 2 2 2 2 2 2 2 2 0 0 1 0 0 0 0 0 0	er
Group Heterotrophic	Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required	19 22 20 2 2 Uptaken water none cfu/100ml 173 8 4 62 96 Uptaken water	→	M E Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev.	O 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		Average Strd. Dev. Discharge B M E Average Strd. Dev.	2 3 4 2 2 Control Water none cfu/100ml 0 0 2 1	er
Group	Required condition Uptake B Average Strd. Dev.	19 22 20 2 Uptaken water none cfu/100ml 173 8 4 62 96 Uptaken water	→	M E Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev.	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Treated water	Average Strd. Dev. Discharge B M E Average Strd. Dev.	2 3 4 2 2 control Wat none cfu/100ml 0 0 2 1 1 control Wat none	er
Group Heterotrophic	Required condition Uptake B M E Average Strd. Dev. Required condition	19 22 20 2 Uptaken water none cfu/100ml 173 8 4 62 96 Uptaken water none cfu/100ml	→	Average B M E Average Strd. Dev. Discharge B M E Average Strd. Dev. Required condition	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Treated water /Uptake	Average Strd. Dev. Discharge B M E Average Strd. Dev.	2 3 4 2 control Wat none cfu/100ml 0 2 1 1 control Wat none cfu/100ml	er
Group Heterotrophic	Required condition Uptake B E Average Strd. Dev. Required condition Uptake B G E Average Strd. Dev. Required condition Uptake B	19 22 20 2 Uptaken water none cfu/100ml 173 8 4 62 96 Uptaken water none cfu/100ml 9.6E+05	→ → →	Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev. Required condition	0 0 0 0 0 Treated Water Intestinal Enterococi <100) cfu/100ml 0 0 0 Treated Water none cfu/100ml 1.3E+03	Treated water //Uptake 1.4E-03	Average Strd. Dev. Discharge B M E Average Strd. Dev. C Discharge B Strd. Dev. C Discharge B	2 3 4 2 2 Control Wat none cfu/100ml 0 2 1 1 control Wat none cfu/100ml	er
Group Heterotrophic	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M	19 22 20 2 2 Uptaken water none cfu/100ml 173 8 4 62 96 Uptaken water none cfu/100ml 9.6E+05 6.0E+05	→ → →	Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev.	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Treated water/Uptake 1.4E-03 2.5E-03	Average Strd. Dev. Discharge B M E Average Strd. Dev. C Discharge B M E Average Strd. Dev. C Discharge B M	2 3 4 2 control Wat- none cfu/100ml 0 2 1 1 control Wat none cfu/100ml 1.5E+05 1.7E+05	er
Group Heterotrophic	Required condition Uptake B E Average Strd. Dev. Required condition Uptake B G E Average Strd. Dev. Required condition Uptake B	19 22 20 2 2 Uptaken water none cfu/100ml 173 8 4 62 96 Uptaken water none cfu/100ml 9.6E+05 6.0E+05	→ → →	Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev. Required condition	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Treated water/Uptake 1.4E-03 2.5E-03	Average Strd. Dev. Discharge B M E Average Strd. Dev. C Discharge B Strd. Dev. C Discharge B	2 3 4 2 control Wat- none cfu/100ml 0 2 1 1 control Wat none cfu/100ml 1.5E+05 1.7E+05	er
Group Heterotrophic	Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M	19 22 20 2 2 Uptaken water none cfu/100ml 173 8 4 62 96 Uptaken water none cfu/100ml 9.6E+05 6.0E+05	→ → →	Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev.	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Treated water /Uptake 1.4E-03 2.5E-03 3.5E-03	Average Strd. Dev. Discharge B M E Average Strd. Dev. C Discharge B M E Average Strd. Dev. C Discharge B M	2 3 4 2 control Wat- none cfu/100ml 0 2 1 1 control Wat none cfu/100ml 1.5E+05 1.7E+05	er

Table 4-6 Results of biological efficacy measurements in test cycle 6

Uptake		23-Jul-09		\rightarrow		Discharge		25-Jul-09	
		Jptaken water				Treated Water		C	ontrol Water
	Required	≧100			Required condition	<10	Measured value for 3 samples	Required condition	≧10
	condition	ind./m3			Condition	ind./m3	Tor o sumples	Condition	ind./m3
L size group	Uptake B	53,130		-	Discharge B	0	0,0,0	Disschrge B	49,280
(≧50μm)	М	17,170	THE PARTY		M	0		M	43,400
	E	11,550			E	0	0,0,0	E	60,280
	Average	27,283			Average	0		Average	50,987
	Strd. Dev.	22,560			Strd. Dev.	0		Strd. Dev.	8,568
		Jptaken water	2/2/12/2			Treated Water			ontrol Water
	Required		4 7 19 34		Required	Managar Plance	Measured value	Required	
S size group	condition	≧100			condition	<10	for 3 samples	condition	≧10 ind./ml
(40 50)		ind./ml			D' 1 D	ind./ml	0,0,0	Discharge B	132
(10∼50 µ m)	Uptake B	800		-	Discharge B M	0		Discharge B	103
	M	860				0	the same of the sa	E	118
	E	760			E		0,0,0		The second secon
	Average	807			Average	0		Average	117
	Strd. Dev.	50			Strd. Dev.	0		Strd. Dev.	14
		l-4-l				Treated Water		0	ontrol Water
Bacteria	Required	Jptaken water			Required	rieated water	Treated water	C	
Vibrio sp.		none	Mr.		condition	none	Treated water /Uptake		none
	condition	-f./100!			Condition	cfu/100ml			cfu/100ml
L. I. J C'. /	Unit	cfu/100ml			Disabarra	15	215_02	Discharge B	9.7E+03
Including Cholerae	Uptake B	7.3E+03			Discharge B				1.6E+04
(A part of Vibrio)	M	8.3E+03		→	M	13	1.6E-03	M	
	. E	3.0E+04		→	E	33	1.1E-03	E	3.1E+04
	Average	1.5E+04			Average	20	1.3E-03	Average	1.9E+04
	Strd. Dev.	1.3E+04	100000000000000000000000000000000000000		Strd. Dev.	11		Strd. Dev.	1.1E+04
		Jptaken water				Treated Water		C	ontrol Water
Vibrio cholerae	Required	none	No feet		Required	<1(Toxicogeni	c)		none
VIDITO CHOIEFAE	condition	none			condition	(1(10xicogeni	,		THE PERSON NAMED IN
		cfu/100ml	3 2 3 3			cfu/100ml	OF STREET		cfu/100ml
Including Cholerae	Uptake B	0	cfu/100m	\rightarrow	Discharge B	0		Discharge B	0
(A part of Vibrio)	М	0	De Principal	\rightarrow	М	0		М	0
	E	0	Table 1	\rightarrow	E	0		E	0
	Average	0	1200000		Average	0		Average	0
	Strd. Dev.	0	V-3255		Strd. Dev.	0		Strd. Dev.	0
		Uptaken water	-			Treated Water			ontrol Water
Coliform	Required		MA GILLO		Required	DOS STORES		No.	
bacteria	condition	none			condition	none			none
bactoria	CONTRICTON	cfu/100ml				cfu/100ml	No. of the last	NEW YORK	cfu/100ml
	Uptake B		cfu/100m	→	Discharge B	0		Discharge B	143
	М	277	014, 100	_	M	0		М	201
	E	339	le dias	→	E	1		E	121
	Average	269	NO STREET		Average	0	1.2F-03	Average	155
		74			Strd. Dev.	1	1.22 00	Strd. Dev.	41
	Strd. Dev.	Uptaken water			Stru. Dev.	Treated Water			
Ezabariabia									
Escherichia	Required condition	none	B. JEKI		Required	A STATE OF THE STA			Control Water
coli	condition	AND RESIDENCE OF THE PARTY OF T			Required				
The state of the s		of. /100 1			condition	<250			none
	Hatalia D	cfu/100ml	af./100		condition	<250 cfu/100ml			none cfu/100ml
	Uptake B	24	cfu/100m	→	condition Discharge B	<250 cfu/100ml		Discharge B	none cfu/100ml
	M	24 32	cfu/100m	\rightarrow	condition Discharge B	<250 cfu/100ml 0		Discharge B	none cfu/100ml
	M E	24 32 33	cfu/100m		Discharge B	<250 cfu/100ml 0 0		Discharge B M E	none cfu/100ml 11 15 11
	M E Average	24 32 33 30	cfu/100m	\rightarrow	Discharge B M E Average	<250 cfu/100ml 0 0 0 0		Discharge B M E Average	none cfu/100ml 11 15 11 12
	M E Average Strd. Dev.	24 32 33 30 5		\rightarrow	Discharge B	<250 cfu/100ml 0 0 0 0 0 0 0		Discharge B M E Average Strd. Dev.	none cfu/100ml 11 15 11 12 2
	M E Average Strd. Dev.	24 32 33 30		\rightarrow	Discharge B M E Average	<250 cfu/100ml 0 0 0 0 Treated Water		Discharge B M E Average Strd. Dev.	none cfu/100ml 11 15 11 12
Enterococcus	M E Average Strd. Dev.	24 32 33 30 5 Uptaken wate		\rightarrow	Discharge B M E Average	<250 cfu/100ml 0 0 0 0 Treated Water Intestinal		Discharge B M E Average Strd. Dev.	none cfu/100ml 11 15 11 2 2 control Water
	M E Average Strd. Dev.	24 32 33 30 5 Uptaken water		\rightarrow	condition Discharge B M E Average Strd. Dev.	<250 cfu/100ml 0 0 0 0 Treated Watel Intestinal Enterococi		Discharge B M E Average Strd. Dev.	none cfu/100ml 11 15 11 12 2
Enterococcus Group	M E Average Strd. Dev.	24 32 33 30 5 Uptaken water		\rightarrow	condition Discharge B M E Average Strd. Dev.	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev.	none cfu/100ml 11 15 11 12 2 control Water none
	M E Average Strd. Dev. Required condition	24 32 33 30 5 Uptaken water none	r	\rightarrow	condition Discharge B M E E Average Strd. Dev. Required condition	<pre><250 cfu/100ml 0 0 0 0 0 Treated Water Intestinal Enterococci <100) cfu/100ml</pre>		Discharge B M E Average Strd. Dev.	none cfu/100ml 11 15 11 2 2 control Water
	M E Average Strd. Dev. Required condition Uptake B	24 32 33 30 5 Uptaken wate none		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	condition Discharge B M E Average Strd. Dev. Required condition Discharge B	<pre><250 cfu/100ml</pre>		Discharge B M M E Average Strd. Dev.	none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml
	M E Average Strd. Dev. I Required condition Uptake B	24 32 33 30 5 Uptaken water none cfu/100ml	r	\rightarrow	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev.	ontrol Water none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml 1 2
	M E Average Strd. Dev. Required condition Uptake B	24 32 33 30 5 Uptaken water none cfu/100ml 5 11	r	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	condition Discharge B M E Average Strd. Dev. Required condition Discharge B	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev. C Discharge B M E	control Water none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml 1 2 2 2
	M E Average Strd. Dev. I Required condition Uptake B	24 32 33 30 5 Uptaken water none cfu/100ml	r	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M	<pre><250 cfu/100ml</pre>		Discharge B M E Average Strd. Dev. C Discharge B M E Average	ontrol Water none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml 1 2
	M E Average Strd. Dev. Required condition Uptake B M E	24 32 33 30 5 Uptaken water none cfu/100ml 5 11	r	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E	<pre><250 cfu/100ml</pre>		Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml 1 2 2 2 2 1
	M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev.	24 32 33 30 5 Uptaken water none cfu/100ml 5 11 10 9	cfu/100m	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E Average	<pre><250 cfu/100ml</pre>		Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml 1 2 2 2
Group	M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev.	24 32 33 30 5 Uptaken water none cfu/100ml 5 11 10 9 3 Uptaken water	cfu/100m	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev.	<pre><250 cfu/100ml</pre>		Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 11 15 11 12 2 Control Water none cfu/100ml 1 2 2 2 1 Control Water
Group Heterotrophic	M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required	24 32 33 30 5 Uptaken water none cfu/100ml 5 11 10 9 3 Uptaken water	cfu/100m	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E Average Strd. Dev.	<pre><250 cfu/100ml</pre>		Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml 1 2 2 2 2 1
Group	M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev.	24 32 33 30 5 Uptaken water none cfu/100ml 5 11 10 9 3 Uptaken water	cfu/100m	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev.	<pre><250 cfu/100ml</pre>	Treated water	Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 11 15 11 12 2 Control Water none cfu/100ml 1 2 2 2 1 Control Water
Group Heterotrophic	M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition	24 32 33 30 5 Uptaken water none cfu/100ml 5 11 10 9 3 Uptaken water none cfu/100ml	r cfu/100m	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev. Required condition	<pre> <250 cfu/100ml 0 0 0 0 0 0 0 Treated Watel Intestinal Enterococi <100) cfu/100ml 0 0 0 Treated Watel none cfu/100ml 0 </pre>	Treated water //Uptake	Discharge B Average Strd. Dev. Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml 1 2 2 2 1 control Water none cfu/100ml cfu/100ml cfu/100ml
Group Heterotrophic	M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B	24 32 33 30 5 Uptaken water none cfu/100ml 5 11 10 9 3 Uptaken water none cfu/100ml 5.1E+05	r cfu/100m	1 1 1 T	condition Discharge B Average Strd. Dev. Required condition Discharge B M E Average Strd. Dev. Required condition Discharge B Output Discharge B Average Strd. Dev.	<pre><250 cfu/100ml</pre>	Treated water //Uptake 2.5E-03	Discharge B M E Average Strd. Dev. Discharge B M E Average Strd. Dev. C	control Water none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml 1 2 2 2 1 Control Water none cfu/100ml 1.5E+05
Group Heterotrophic	M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Uptake B M E Average Strd. Dev.	24 32 33 30 5 Uptaken water none cfu/100ml 5 11 10 9 3 Uptaken water none cfu/100ml 5.1E+05 6.3E+05	r cfu/100m	111	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E Average Strd. Dev. Required condition Required condition	<pre><250 cfu/100ml</pre>	Treated water /Uptake 2.5E-03 2.4E-03	Discharge B M E Average Strd. Dev. C Discharge B M E Average Strd. Dev. C Discharge B M E E Average Strd. Dev. C Discharge B M M E E E E E E E E E E E E E E E E E	control Water none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml 1 2 2 2 1 Control Water none cfu/100ml 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Heterotrophic	M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B	24 32 33 30 5 Uptaken water none cfu/100ml 5 11 10 9 3 Uptaken water none cfu/100ml 5.1E+05 6.3E+05 1.6E+06	r cfu/100m	1 1 1 T	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E Average Strd. Dev. Required condition Discharge B M M E E Average Strd. Dev.	<pre></pre>	Treated water //Uptake 2.5E-03 2.4E-03 2.4E-03	Discharge B M E Average Strd. Dev. Discharge B M E Average Strd. Dev. C Discharge B M E Average Strd. Dev.	control Water none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml 1 2 2 2 1 Control Water 1 5 11 10 11 12 12 10 11 10 11 11 11 12 12 11 11 12 12 11 12 11 12 11 12 11 12 11 12 11 12 11 12 11 12 11 12 11 12 11 12 11 12 11 12 11 12 11 12 12
Group Heterotrophic	M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Required condition Uptake B M E Average Strd. Dev. Uptake B M E Average Strd. Dev.	24 32 33 30 5 Uptaken water none cfu/100ml 5 11 10 9 3 Uptaken water none cfu/100ml 5.1E+05 6.3E+05	r cfu/100m	111	condition Discharge B M E Average Strd. Dev. Required condition Discharge B M E E Average Strd. Dev. Required condition Required condition	<pre><250 cfu/100ml</pre>	Treated water //Uptake 2.5E-03 2.4E-03 2.4E-03	Discharge B M E Average Strd. Dev. C Discharge B M E Average Strd. Dev. C Discharge B M E E Average Strd. Dev. C Discharge B M M E E E E E E E E E E E E E E E E E	control Water none cfu/100ml 11 15 11 12 2 control Water none cfu/100ml 1 2 2 2 1 Control Water none cfu/100ml 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

4.3 Water quality measurements based on the requirements of onboard tests

According to the requirements on onboard tests, the measurement on water temperature, salinity, POC and TSS are required. Along with these items, DO, turbidity, pH and ORP were measured in these onboard tests at the same time.

(1) Test cycle 1

Measurement results are shown in Table 5-1 Measurement results of water quality in test cycle 1. As test cycle 1, uptake and discharge works were performed on July 18th and July 20th respectively.

Water temperature was between 27.48-28.13°C during uptake and 27.31-28.07°C during discharge. Salinity was between 28.21-28.62 PSU during uptake and 28.45-28.60 PSU during discharge. POC was 0.3-1.0 mg/L during uptake and 0.1-0.6 mg/L during discharge. TSS was between 3.1-4.3 mg/L during uptake and 1.7-2.7 mg/L during discharge.

Table 5-1 Measured results of water quality of test cycle-1

Test o	ycle 1
--------	--------

Uptake

18th July, 2009

Discharge

20th July, 2009

		Uptake				
		Uptake	Uptake	Uptake		
	Unit	(B)	(M)	(E)		
Water Temp.	ů	28.13	27.48	27.84		
Salinity	PSU	28.21	28.62	28.34		
pН		8.54	8.48	8.57		
Turbidity	NTU	11.69	6.39	7.16		
DO	mg/l	7.51	6.94	7.36		
ORP	mV	211	218	213		
TSS	mg/L	3.4	3.9	4.3		
POC	mg/L	1	0.5	0.3		

		Treated			Control
		Discharge	Discharge	Discharge	Uptake
	Unit	(B)	(B)	(B)	(B)
Water Temp	_ °C	27.31	27.46	27.46	27.51
Salinity	PSU	28.52	28.53	28.53	28.6
pΗ		8.48	8.5	8.5	8.41
Turbidity	NTU	7.64	8.02	7.8	16.53
DO	mg/l	6.68	6.68	6.82	6.7
ORP	mV	216	185	196	200
TSS	mg/L	2.2	1.9	2.1	2.3
POC	mg/L	0.4	0.6	0.1	0.2

			Control		
		Discharge	Discharge	Discharge	Uptake
	Unit	(M)	(M)	(M)	(M)
Water Temp	'C	27.5	27.5	27.77	27.71
Salinity	PSU	28.52	28.5	28.48	28.56
pН		8.5	8.5	8.5	8.42
Turbidity	NTU	4.31	3.02	6.19	5.41
DO	mg/l	6.68	6.69	6.86	6.65
ORP	mV	196	204	196	200
TSS	mg/L	1.7	2	2.2	2.6
POC	mg/L	0.5	0.1	0.3	0.3

			Control		
		Discharge	Discharge	Discharge	Uptake
	Unit	(E)	(E)	(E)	(E)
Water Temp	°C	27.87	27.95	27.99	28.07
Salinity	PSU	28.47	28.46	28.45	28.48
Нq		8.5	8.5	8.49	8.41
Turbidity	NTU	4.5	3.97	4.18	9.33
DO	mg/	6.76	6.77	6.79	6.61
ORP	mV	207	190	179	181
TSS	mg/L	1.9	1.7	2.7	2.3
POC	mg/L	0.1	0.4	0.2	0.5

(2) Test cycle 2

Test cycle 2

POC

Measurement results are shown in Table 5-2 Measurement results of water quality in test cycle 2. As test cycle 1, uptake and discharge works were performed on July 19th and July 21st respectively.

Water temperature was between 27.13-27.53°C during uptake and 26.98-27.26°C during discharge. Salinity was between 29.75-29.85 PSU during uptake and 29.84-29.90 PSU during discharge. POC was 0.3-0.9 mg/L during uptake and 0.1-0.7 mg/L during discharge. TSS was between 4.3-4.5 mg/L during uptake and 1.9-4.6 mg/L during discharge.

Table 5-2 Measured results of water quality of test cycle-2

19th July, 2009

4.4

4.5

		Uptake					
		Uptake	Uptake	Uptake			
	Unit	(B)	(M)	(E)			
Water Temp.	°C	27.2	27.58	27.13			
Salinity	PSU	29.78	29.75	29.85			
pΗ		8.29	8.42	8.38			
Turbidity	NTU	8.1	8.84	5.75			
DO	mg/l	7.1	6.78	6.85			
ORP	mV	240	218	212			

4.3

mg/L

Uptake

			Treated				
		Discharge	Discharge	Discharge	Uptake		
	Unit	(B)	(B)	(B)	(B)		
Water Temp	,C	26.98	27.05	27.07	27.02		
Salinity	PSU	29.88	29.85	29.87	29.89		
pН		8.33	8.33	8.31	8.25		
Turbidity	NTU	5.66	7	7.78	7.33		
DO	mg/l	6.76	6.75	6.73	6.7		
ORP	mV	178	180	174	178		
TSS	mg/L	1.9	2.4	2.3	4.5		
POC	mg/L	0.2	0.2	0.1	0.5		

21th July, 2009

Discharge

			Control		
		Discharge	Discharge	Discharge	Uptake
	Unit	(M)	(M)	(M)	(M)
Water Temp	°C	27.15	27.16	27.23	27.21
Salinity	PSU	29.86	29.86	29.84	29.9
pН		8.32	8.33	8.33	8.28
Turbidity	NTU	5.68	5.77	5.78	1.3
DO	mg/l	6.88	6.8	6.78	6.64
ORP	mV	182	177	196	185
TSS	mg/L	2.2	2.9	2.7	4.6
POC	mg/L	0.3	0.1	0.4	0.7

		Treated			Control
		Discharge	Discharge	Discharge	Uptake
	Unit	(E)	(E)	(E)	(E)
Water Temp	°C	27.26	27.26	27.24	27.26
Salinity	PSU	29.86	29.88	29.87	29.85
pΗ		8.34	8.33	8.33	8.25
Turbidity	NTU	5.52	5.37	6.44	13.45
DO	mg/l	6.81	6.81	6.81	6.67
ORP	mV	181	178	197	181
		,			
TSS	mg/L	3.3	3.1	3.5	4.1
POC	mg/L	0.3	0.5	0.5	0.6

(3) Test cycle 3

Measurement results are shown in Table 5-3 Measurement results of water quality in test cycle 3. As test cycle 3, uptake and discharge works were performed on July 20th and July 22nd respectively.

Water temperature was between 27.06-27.16°C during uptake and 26.97-27.18°C during discharge. Salinity was between 26.75-26.98 PSU during uptake and 26.78-27.16 PSU during discharge. POC was 0.4-0.6 mg/L during uptake and 0.1-0.3 mg/L during discharge. TSS was between 3.8-4.7 mg/L during uptake and 2.0-3.8 mg/L during discharge.

Table 5-3 Measured results of water quality of test cycle-3

Test cycle 3

Uptake

20th July, 2009

Discharge

22th July, 2009

		Uptake				
		Uptake	Uptake	Uptake		
	Unit	(B)	(M)	(E)		
Water Temp.	'C	27.09	27.06	27.16		
Salinity	PSU	26.75	26.98	27.06		
pН		8.55	8.53	8.53		
Turbidity	NTU	4.25	1.4	4.95		
DO ORP	mg/l	7.3	7.36	7.19		
ORP	m۷	165	197	177		
TSS	mg/L	4.1	4.7	3.8		
POC	mg/L	0.4	0.6	0.5		

			Treated		
		Discharge	Discharge	Discharge	Uptake
	Unit	(B)	(B)	(B)	(B)
Water Temp	°C	26.97	27	26.99	26.97
Salinity	PSU	26.96	26.96	26.97	27.14
рH		8.5	8.49	8.48	8.4
Turbidity	NTU	2.54	3.6	4.8	5.62
DO	mg/l	6.27	6.62	6.48	6.73
ORP	mV	176	178	180	178
TSS	mg/L	2.1	2	2	3.8
POC	mg/L	0.1	0.2	0.3	0.1

			Control		
			Treated		
		Discharge	Discharge	Discharge	Uptake
	Unit	(M)	(M)	(M)	(M)
Water Temp	ů	27.11	27.16	27.15	27.14
Salinity	PSU	26.88	27.16	26.81	27.06
pΗ		8.5	8.51	8.52	8.41
Turbidity	NTU	4.38	3.38	5.5	4.18
DO	mg/i	6.61	6.49	6.69	6.82
ORP	mV	182	180	177	191
TSS	mg/L	2.4	2.2	2.3	4.4
POC	mg/L	0.2	0.3	0.1	0.1

			Treated		Control
		Discharge	Discharge	Discharge	Uptake
	Unit	(E)	(E)	(E)	(E)
Water Temp	°C	27.15	27.16	27.14	27.18
Salinity	PSU	26.78	26.83	26.83	27.02
pН		8.51	8.52	8.52	8.41
Turbidity	NTU	4.75	11.07	5.31	19.78
DO	mg/l	6.61	6.59	6.48	6.78
ORP	mV	177	178	175	181
			"-		
TSS	mg/L	2.3	2.9	2.8	3.8
POC	mg/L	0.1	0.1	0.1	0.1

(4) Test cycle 4

Measurement results are shown in Table 5-4 Measurement results of water quality in test cycle 4. As test cycle 4, uptake and discharge works were performed on July 21st and July 23rd respectively.

Water temperature was between 26.96-27.43°C during uptake and 27.14-27.55°C during discharge. Salinity was between 27.67-28.98PSU during uptake and 26.78-28.52PSU during discharge. POC was 0.4-0.5 mg/L during uptake and 0.1-0.4 mg/L during discharge. TSS was between 3.7-4.9 mg/L during uptake and 2.4-4.5 mg/L during discharge.

Table 5-4 Measured results of water quality of test cycle-4

Test cycle 4

Uptake

21th July, 2009

Discharge

23th July, 2009

		Uptake				
	Unit	Uptake (B)	Uptake (M)	Uptake (E)		
Water Temp.	°C	27.27	27.43	26.96		
Salinity	PSU	27.67	28.59	28.98		
pН		8.33	8.26	8.23		
Turbidity	NTU	5.8	9.42	7.68		
ĎΟ	mg/l	6.67	6.42	6.01		
ORP	mV	189	187	176		
TSS	mg/L	4.9	3.9	3.7		
POC	mg/L	0.5	0.4	0.5		

			Control		
		Discharge	Discharge	Discharge	Uptake
	Unit	(B)	(B)	(B)	(B)
Water Temp	°C	27.23	27.27	27.36	27.34
Salinity	PSU	28.52	28.52	28.5	28.48
Hq		8.14	8.19	8.05	8.03
Turbidity	NTU	4.34	6.67	6.23	6.47
DO	mg/l	5.69	5.92	5.4	5.78
ORP	mV	186	183	182	195
TSS	mg/L	2.4	2.6	3.1	4.5
POC	mg/L	0.1	0.3	0.1	0.2

			Treated		Control
		Discharge	Discharge	Discharge	Uptake
	Unit	(M)	(M)	(M)	(M)
Water Temp	,C	27.45	27.54	27.45	27.55
Salinity	PSU	28.48	28.52	28.52	28.45
pН		8.05	8.21	8.22	8.05
Turbidity	NTU	5.78	7.21	6.78	3.09
DO	mg/l	5.58	5.83	5.95	5.78
ORP	mV	189	191	194	186
TSS	mg/L	2.8	2.6	2.5	4.5
POC	mg/L	0.1	0.2	0.3	0.2

			Treated		Control
		Discharge	Discharge	Discharge	Uptake
	Unit	(E)	(E)	(E)	(E)
Water Temp	°C	27.15	27.16	27.14	27.74
Salinity	PSU	26.78	26.83	26.83	28.49
pН		8.51	8.52	8.52	8.16
Turbidity	NTU	4.75	11.07	5.31	4.68
DO	mg/l	6.61	6.59	6.48	6.12
ORP	mV	170	177	178	181
TSS	mg/L	3	2.8	3.5	4.2
POC	mg/L	0.3	0.1	0.4	0.1

(5) Test cycle 5

Measurement results are shown in Table 5-5 Measurement results of water quality in test cycle 5. As test cycle 5, uptake and discharge works were performed on July 22nd and July 24th respectively.

Water temperature was between 26.83-26.96°C during uptake and 27.07-27.82°C during discharge. Salinity was between 25.89-26.18PSU during uptake and 26.03-26.302PSU during discharge. POC was 0.1-0.2 mg/L during uptake and 0.1-0.3 mg/L during discharge. TSS was between 3.6-4.7 mg/L during uptake and 1.3-2.5 mg/L during discharge.

Table 5-5 Measured results of water quality of test cycle-5

Test cycle 5

Uptake

22th July, 2009

Discharge

24th July, 2009

		Uptake				
	Uptake	Uptake	Uptake			
Unit	(B)	(M)	(E)			
°C	26.83	26.96	26.91			
P\$U	26.18	25.89	26.02			
	8.48	8.51	8.5			
NTU	7.02	5.42	4.02			
mg/l	7.24	7.16	7.27			
mV	198	186	192			
mg/L	4.7	4.5	3.6			
mg/L	0.1	0.2	0.2			
	°C PSU NTU mg/l mV	°C 26.83 PSU 26.18 8.48 NTU 7.02 mg/l 7.24 mV 198 mg/L 4.7	Unit (B) (M) °C 26.83 26.96 PSU 26.18 25.89 8.48 8.51 NTU 7.02 5.42 mg/l 7.24 7.16 mV 198 186 mg/L 4.7 4.5			

			Treated		Control
		Discharge	Discharge	Discharge	Uptake
	Unit	(B)	(B) .	(B)	(B)
Water Temp	°C	27.07	27.07	27.36_	27.11
Salinity	PSU	26.3	26.25	26.25	26.14
рH		8.39	8.49	8.5	8.39
Turbidity	NTU	5.09	6.69	13.62	6.47
DO	mg/l	5.69	6.44	6.58	6.79
ORP	mV	169	179	162	181
TSS	mg/L	1.3	1.3	1.3	2.4
POC	mg/L	0.1	0.1	0.2	0.3

			Treated		
		Discharge	Discharge	Discharge	Uptake
	Unit	(M)	(M)	(M)	(M)
Water Temp	°C	27.39	27.63	27.52	27.41
Salinity	PSU	26.21	26.19	26.19	26.23
pΗ		8.51	8.51	8.52	8.42
Turbidity	NTU -	4.41	2.72	5.8	2.26
DO	mg/1	6.26	6.17	6.5	6.73
ORP	mV	160	169	157	169
TSS	mg/L	1.5	1.8	1.6	2
POC	mg/L	0.1	0.2	0.2	0.2

			Control		
		L	Treated	6.	
		Discharge	Discharge	Discharge	Uptake
	Unit	(E)	(E)	(E)	(E)
Water Temp	°C	27.67	27.71	27.8	27.82
Salinity	PSU	26.15	26.03	26.15	26.21
Нq		8.52	8.51	8.52	8.39
Turbidity	NTU	4.07	4.04	4.07	13.2
DO	mg/l	6.54	6.51	6.41	6.65
ORP	mV	175	171	170	178
TSS	mg/L	1.9	2.4	2.5	2.5
POC	mg/L	0.1	0.1	0.1	0.2

(6) Test cycle 6

Measurement results are shown in Table 5-6 Measurement results of water quality in test cycle 6. As test cycle 6, uptake and discharge works were performed on July 23rd and July 25th respectively.

Water temperature was between 26.83-26.96°C during uptake and 27.07-27.82°C during discharge. Salinity was between 25.89-26.18PSU during uptake and 26.03-26.302PSU during discharge. POC was 0.1-0.2 mg/L during uptake and 0.1-0.3 mg/L during discharge. TSS was between 3.6-4.7 mg/L during uptake and 1.3-2.5 mg/L during discharge.

Table 5-6 Measured results of water quality of test cycle-6

Test cycle 6

Uptake

23th July, 2009

Discharge

25th July, 2009

		Uptake			
		Uptake	Uptake	Uptake	
	Unit	(B)	(M)	(E)	
Water Temp.	°C	27.2	27.15	26.89	
Salinity	PSU	26.16	27.37	28.86	
рН		8.24	8.19	8.11	
Turbidity	NTU	7.19	6.89	7.82	
DO	mg/l	6.64	6.54	6.25	
ORP	mV	194	176	217	
TSS	mg/L	5.7	4.7	4	
POC	mg/L	0.4	0.3	0.2	

		Treated			Control
		Discharge	Discharge	Discharge	Uptake
	Unit	(B)	(B)	(B)	(B)
Water Temp	°C	26.98	27.08	27.13	27.02
Salinity	PSU	28.06	27.97	27.87	27.9
рH		8.11	8.13	8.14	8.09
Turbidity	NTU	8.51	6.66	3.18	9.19
DO	mg/l	5.69	6.08	5.69	6.02
ORP	mV	136	184	188	184
TSS	mg/L	3.6	5.1	5	2.8
POC	mg/L	0.3	0.1	0.1	0.5

		Treated			Control
ή		Discharge Discharge Discharge		Uptake	
	Unit	(M)	(M)	(M)	(M)
Water Temp	°C_	27.37	27.39	27.44	27.57
Salinity	PSU	27.68	27.61	27.56	27.53
pН		8.15	8.16	8.16	8.1
Turbidity	NTU	7.61	4.14	4.66	3.08_
DO	mg/l	6.17	5.95	5.51	5.88
ORP	mV	194	194	180	182
TSS	mg/L	4.7	4.7	4.9	3.4
POC	mg/L	0.2	0.3	0.1	0.1

		Treated			Control
:		Discharge	Discharge	Discharge	Uptake
	Unit	(E) _	(E)	(E)	(E)
Water Temp	°C	27.48	27.56	27.47	27.64
Salinity	PSU	27.5	27.43	27.22	27.36
pН		8.16	8.17	8.17	8.11
Turbidity	NTU	9.33	7.78	3.5	2.7
DO	mg/l	6.18	6.48	6.37	5.93
ORP	mV	191	191	189	184
TSS	mg/L	5	6.5	5.4	2.6
POC	mg/L	0.3	0.5	0.6	0.5

Rokko-island is located the northern part of Osaka bay and the surround water has hard bay-characteristic. Measured temperature value was higher than the existent one in the center of the bay. And salinity value showed lower than usual because of the effect of river water.

POC values showed lower generally and the value of discharge is lower than the intake.

TSS values showed regular as the average coast data and the value of discharge is lower than intake. It suggests that the suspended matter became lower by the ballast water treatment.

4.4 Other measurement results

(1) Variation of DO by ballast water treatment

Effect of the addition of sodium sulfite used as neutralizating agent on DO discharged coastal water body was pointed out by GESAMP-BWWG at the reviewing process of G9 basic approval application. DO concentration in discharged treated ballast water was measured using water quality meter during these onboard tests and was confirmed using saturation calculated by Weiss's equation.

Measured DO saturation values in discharged ballast water are shown in Table 6. Although slight decrease can be seen compared to uptaking state, the saturation of discharge water shows more than 80%. Considering the dilution by environmental water after discharge into water, it can be judged that there is no apparent effect to aquatic organisms.

Table 6 Measured DO saturation values in discharged ballast water

	Disc	Uptake	
Test Cycle	Minimum Value	Maximum Value	
	(%)	(%)	(%)
1	99	103	109
2	99	103	103
3	92	100	107
4	80	92	94
5	83	99	105
6	82	91	95

(2) Information on meteorological and hydrographic phenomenon during onboard test period Outline of the information on meteorological and hydrographic phenomenon during onboard test period, from July 18th to July 25th, are shown in Table 7.

Table 7 Meteorological phenomenon during onboard test period

Month/Day	Atospheric	Most frequent	Mean wind	Precipitation
	Temperature	wind direction	velocity	amount
	(°C)		(m/s)	(mm)
July 18th	26.4	SW	5.4	0.0
July 19th	26.1	SW	5.8	62.0
July 20th	25.7	W	2.9	18.0
July 21st	25.3	SW	3.8	16.0
July 22nd	25.6	wsw	3.5	5.5
July 23rd	27.1	ENE	4.1	0.0
July 24th	26.8	W	2.7	0.0
July 25th	26.0	SE	4.4	30.5

Tidal level fluctuation during test period were middle tide from 18th to 20th, spring tide from 21st to 23rd, and middle tide from 24th and 25th. The lowest tide during spring tide was early in the afternoon and corresponded to uptaking perid.

According to the red tide occurrence status in Hyogo Prefecture on July 29th, Red tide composed of diatom complex occurred along the coast of Kobe city to Nishinomiya city but the density of organisms did not reach the red tide condition during test period.

5. Conclusions

In these onboard tests, requirements for (1) Test cycle, (2) Effective standard of the test, (3) Standards for approval, (4) Sample number, (5) Sample volume and (6) Measuring items for water quality were all fulfilled.

It is required that one test cycle should consist of consecutive works of water uptake, storage and discharge. These onboard tests which started from July 18th were performed with water uptaking on 1st day and discharging on 3rd day after 2day storage period.

Effective standaeds of the test is that density of aquatic organisms should be more than 10 times of regulation D2 during uptake and more than regulation D2 for control water during discharge. In uptaken water, density of L size group organisms were 28,982-336,713,ind./m³ and S size group were 680-2,210 ind./ml in these onboard tests. As these results of all test cycles fulfilled the above standard, all six test cycles were evaluated as "Effective test cycles".

In regard to regulation D2, bio-efficacy test results of L size group organisms for all test cycles fulfilled regulation D-2. Even though survived organisms in treated ballast water during discharge were found from the 1st to 3rd test cycle, no survived organisms found after 4th test cycle. *Halpacticoida* (Copepod), found in treated ballast water at the initial tests, are the species living in bottom sediment and did not appeare in uptake water. Hence, it can be considered that these were living in the bottom sediment in ballast water tanks, mixed in during discharge and survived because of quick neutralization at discharge.

Bio-efficacy test results of S size group organisms for all test cycles also fulfilled regulation D-2. Survived organism was only genus *Scrippsiella* (Dinoflagellate) appeared in 1st test cycle.

In regard to bacteria, results of all test cycles fulfilled regulation D-2. Results of *Esherichia Coli* were all 0 cfu/100ml for D-2.2 standard limit 250 cfu/100ml. In regard to Intestinal Enterococci, measurement results of *Enterococcus* group for all test cycles were all 0 cfu/100ml for D-2.2 standard limit 100 cfu/100ml. In regard to Toxicogenic *Vibrio Cholerae*, measurement results of genus *Vibrio* showed some colonies in treated water, however the existance of *Vibrio cholerae* was denied in 2nd screening process and then the existance of Toxicogenic *Vibrio cholerae* was all denied before 3rd screening process.

Sample number and sample volume were fulfilled more than required.

As to water quality items, more items and numbers than the IMO guidelines were measured. Water temperature was between 16 and 28°C, salinity between 25 and 29 PSU, TSS between 3.4 and 5.7 mg/L and POC between 0.1 and 0.9 mg/L. Moreover, pH, turbidity DO and ORP were also measured and these values for discharge water did not show any abnomal differences to uptake water.

As stated above, all results of the onboard test measurement for six test cycles fulfill the standards defined in IMO guideline G8 and also fulfill the approval standards for "three consecutive effective

test cycles".