

PCB REMEDIATION PLAN

Yale University
Kline Chemistry
Laboratory

New Haven, Connecticut

225540 **Yale - KCL**August 2012





TABLE OF CONTENTS

SE	SECTION			
1.	INTROD	UCTION	1-1	
	1.1	Conceptual Site Model	1-1	
	1.2	Plan Organization		
	1.3	Certification		
2.	SAMPLE	COLLECTION, ANALYSES, AND USABILITY	2-1	
	2.1	Characterization Sample Collection		
	2.1.1	Sample Collection Methods		
	2.1.2	Laboratory Analysis		
	2.2	Characterization Sample Result Summary		
	2.2.1	≥ 50 ppm Caulking/Sealants		
	2.2.2	< 50 ppm Caulking		
	2.2.3	Adjacent Building Materials		
	2.3	Data Usability Assessment		
3.	REMEDI	ATION PLAN OVERVIEW	3-1	
4.	PREPAR	ATION, COMMUNICATIONS, AND CONTROLS	4-1	
	4.1	Preparation and Communications		
	4.1	Controls		
5.	NORTH	NORTH SIDE MAIN ENTRY AND SECOND FLOOR CURTAIN WALL WINDOW SYSTEMS5-		
	5.1	Characterization	5-1	
	5.2	Remediation	5-2	
	5.3	Building Material Verification Sampling		
6.	BUILDING WINDOWS ON EXTERIOR FAÇADES		6-1	
	6.1	Window Frames and Components	6-1	
	6.1.1	Characterization		
	6.1.2	Remediation	6-1	
	6.2	Interior Building Materials Adjacent to Windows	6-2	
	6.2.1	Characterization	6-2	
	6.2.2	Remediation		
	6.2.3	Interior Building Material Verification Sampling	6-4	
	6.3	Exterior Building Materials Adjacent to Windows – Scheduled for Removal		
	6.3.1	Characterization		
	6.3.2	Remediation	6-5	
	6.3.3	Exterior Building Material Verification Sampling		
	6.4	Exterior Building Materials Adjacent to Windows – To Remain In Place		
	6.4.1	Characterization		
	6.4.1.1	Brick		
	6.4.1.2	Brownstone Sills		
	6.4.2	Remediation		
	6.4.2.1	Additional Delineation Sampling	6-8	



	6.4.2.2	Encapsulant Application	6-9
	6.4.3	Verification Wipe Sampling	
	6.4.3.1	Former Direct Contact Areas	
	6.4.3.2	Materials Away from the Joint	6-10
7.	ROOFTO	OP PENTHOUSE EXTERIOR BUILDING MATERIALS	7-1
	7.1	Characterization	7-1
	7.2	Remediation	
	7.3	Building Material Verification Sampling	
8.	VENTILA	ATION SYSTEM COMPONENTS AND DUCTWORK	8-1
	8.1	Characterization	8-1
	8.2	Pilot Test Activities	
	8.3	Remediation	
	8.4	Building Material Verification Sampling	
	8.4.1	Concrete	
	8.4.2 8.4.3	CMU Block Ductwork	
9.	-	STORAGE AND DISPOSAL	
10.	CONCE	PTUAL MONITORING AND MAINTENANCE PLAN	10-1
11.	SITE RE	STORATION AND PROJECT SCHEDULE	11-1
	12. COMMUNICATION AND DOCUMENTATION		

LIST OF TABLES

TABLE

Table 2-1:	Summary of Sealant Characterization Sampling Results
Table 2-2:	Summary of Building Material Characterization Sampling Results
Table 3-1:	Summary of Proposed Remedial Approach
Table 3-2:	Verification Sampling Summary
Table 8-1:	Summary of Pilot Test Wipe Sample Results



LIST OF FIGURES

FIGURE

Figure 1-1:	Site Location Map (embedded in text)
Figure 2-1:	Basement Floor Sample Locations
Figure 2-2:	First Floor Sample Locations
Figure 2-3:	Second Floor Sample Locations
Figure 2-4:	Roof Top Sample Locations
Figure 6-1:	CMU Block Waste Segregation Approach – First Floor
Figure 6-2:	CMU Block Waste Segregation Approach – Second Floor
Figure 8-1:	Typical Ventilation Ductwork Configuration

LIST OF APPENDICES

APPENDIX

Appendix A:	Written Certification
Appendix B:	Analytical Laboratory Reports and Data Validation Summary
Appendix C:	Perimeter Dust Monitoring Plan
Appendix D:	Manufacturer's Product Information



1. INTRODUCTION

This remediation plan has been prepared by Woodard & Curran on behalf of Yale University (Yale) to comply with U.S. Environmental Protection Agency (EPA) requirements for a polychlorinated biphenyl (PCB) cleanup and disposal under 40 CFR Part 761.61. This plan describes the data collected and details the proposed remedial approach for PCB-containing caulking and PCB-impacted building materials to be encountered during planned renovations at the Kline Chemistry Laboratory building located at 225 Prospect Street on the Yale University's New Haven, Connecticut Campus (Figure 1-1).




Figure 1-1

The Kline Chemistry Laboratory is an academic building located in the Science Hill area of the Yale Campus. The building was constructed in 1964 and has a footprint of approximately 21,000 square feet with a full basement and two floors with laboratory, classroom, and office spaces. Landscaped and paved areas surround the building; there are courtyards to the north and south of the building. Prospect Street runs to the west of the building, and there are additional academic buildings and a parking area to the east of the building.

1.1 CONCEPTUAL SITE MODEL

In preparation for a building renovation and window/door replacement project, a materials survey was conducted to assess for the presence of various hazardous materials that may be encountered during the project. This included inspection and sampling of caulking and sealants for PCBs.

Certain joint caulking used as part of standard construction practices for masonry buildings and concrete structures erected between the 1950's and late 1970's is known to have been manufactured with PCBs. As indicated above, the Kline Chemistry Laboratory was constructed during this timeframe. PCBs were added to caulking for durability, resistance to degradation, and as a softener/plasticizer for application. Due to the porous nature of concrete and



other masonry surfaces, PCBs in caulking may penetrate into adjacent materials during application or over time, may leach or weather, and/or may be disturbed during renovations or other work. Production and approved usage of PCBs was halted in the United States in the late 1970s.

The scope of the planned renovation project includes the following:

- All non-structural interior materials (including ductwork and air handling equipment) are scheduled to be removed:
- The roof top mechanical room penthouses are scheduled for removal;
- Exterior windows and doors are scheduled for replacement including: 84 windows; one curtain wall window; and one main entry way curtain wall door/window system; and
- The removal of a portion of the southern building façade for the installation of a new curtain wall window system that will span from ground level to the roofline.

Interior and exterior window caulking and glazing sealants, door caulking, masonry joint caulking, and ductwork sealant (caulking) were observed during the survey and samples were collected for PCB analysis. Results from the sealant sampling indicated that PCBs were present in some of the caulking/sealant samples at concentrations ≥ 50 parts per million (ppm).

Characterization samples of building materials adjacent to the caulking were also collected to assess potential PCB impacts to these materials. Characterization sample results have been used, in conjunction with the overall renovation plan, to develop a two-part remediation plan, which includes: 1) removal and off-site disposal of ≥ 50 ppm PCB-containing caulking/sealants, associated window/door frames, ductwork, and other adjacent materials; and 2) in-place management via encapsulating containment barriers of PCB-containing building materials adjacent to the caulking based on the scope of the renovation project (i.e., materials not planned for removal).

Currently the majority of the building is vacant with the remaining staff and students to be relocated prior to work initiation. The overall project schedule calls for the hazardous materials abatement task to be completed as a first component of the project. In order to meet the overall project schedule, this abatement task, including PCB remediation, is scheduled to initiate in October 2012.

Following completion of the renovations, the building will contain classrooms, laboratories, and office spaces.

1.2 PLAN ORGANIZATION

This Remediation Plan is organized into the following sections:

Section 2: Sample Collection, Analyses, and Usability

This section provides a description of the sample collection methods, laboratory testing, and data usability evaluation performed for the samples collected in support of this plan development. Specific details on the results, including data tables, figures, and photographs are not presented in this section, but rather in the individual sections that follow (Sections 5 through 8).



Section 3: Remediation Plan Overview

This section presents an overview of the remedial plans and approaches for the different PCB containing or affected materials to be managed during the project.

Section 4: Preparation, Communications, and Controls

This section presents the site preparation and practices to be implemented prior to and during work activities for the protection of workers and surrounding receptors.

Sections 5 through 8: Remediation Plans

These sections present the characterization data associated with each major material type followed by the proposed remediation and verification processes.

Section 9: Waste Storage and Disposal

This section describes the on-site management of PCB wastes, and lists proposed disposal facilities for off-site transport and disposal of the wastes.

Section 10: Conceptual Monitoring and Maintenance Plan

Given that this plan includes proposed approaches for the in-place management of PCBs, a conceptual monitoring and maintenance plan is provided in this section.

Section 11: Site Restoration and Project Schedule

This section includes a brief summary of the work area restoration as part of the overall renovation project and the anticipated schedule.

Section 12: Communication and Documentation

This section describes the communications between Yale and building occupants and project team members, as well as the project documentation that will be developed as part of the project.

1.3 CERTIFICATION

The following is information regarding the entity submitting this plan:

Yale University
Environmental Health and Safety
135 College Street, Suite 100
New Haven, CT 06510

John Bollier

Yale University Associate Vice President for Facilities

A copy of the written certification signed by the owner of the property and required as part of this plan submittal is provided in Appendix A.



2. SAMPLE COLLECTION, ANALYSES, AND USABILITY

This section provides a description of the sample collection methods, laboratory testing, and data usability evaluation performed for the samples collected in support of this plan development. Specific details on the results, including data tables, figures, and photographs are not presented in this section, but rather in the individual sections that follow (Sections 5 through 8).

During characterization activities, samples were collected from the following media: caulking, glazing sealants, ductwork sealants, concrete masonry unit (CMU) block, brick, and brownstone in observance of proper sample collection techniques, analytical methods, and reporting procedures.

2.1 CHARACTERIZATION SAMPLE COLLECTION

A total of 86 samples were collected and submitted for PCBs during multiple field events. A breakdown of the samples by media is provided as follows:

- Caulking/Sealant Samples 31 samples of caulking and sealants were collected and submitted for PCB analysis from windows, doors, the penthouse, and ventilation systems; and
- Adjacent Materials 55 samples of CMU block, brick, and brownstone were collected from interior and exterior locations and submitted for PCB analysis.

Summaries of the characterization samples collected and analytical results are presented on Tables 2-1 (sealants) and 2-2 (building materials). The locations of the characterization samples are presented on Figures 2-1 through 2-4.

2.1.1 Sample Collection Methods

Caulking samples were collected by cutting and scraping the material from the joint with hand tools. If adjacent media (e.g., concrete or a foam backer rod) was inadvertently removed in the process of sample collection, this media was physically removed from the caulking before the sample was placed in its sample container.

Building material sampling was conducted in accordance with the USEPA Region I Standard Operating Procedure for Sampling Porous Surfaces for PCBs (May 2011); concrete was ground into dust using a hammer drill to a depth of 0.5 inches into the masonry.

All reusable sampling equipment was decontaminated between each sampling location by scrubbing with a biodegradable soap and water solution (Alconox) followed by a water rinse and a final methanol rinse and allowed to air dry.

2.1.2 Laboratory Analysis

All samples were logged on standard Chain-of-Custody (COC) forms and stored on ice for delivery to Con-Test Analytical Laboratory of East Longmeadow, Massachusetts or Analytics Environmental Laboratory of Portsmouth, New Hampshire. All samples were extracted using USEPA Method 3540C (Soxhlet Extraction) and analyzed for PCBs using USEPA Method 8082.

The complete laboratory analytical reports for the samples are provided in Appendix B.



2.2 CHARACTERIZATION SAMPLE RESULT SUMMARY

A summary of the characterization sample results by media and reported concentrations is presented in the following sections.

2.2.1 ≥ 50 ppm Caulking/Sealants

A summary of materials reported to contain ≥ 50 ppm PCBs, based on the major material types and work areas in which they were identified, is presented on Table 2-1 and as follows:

- North Side Main Entry caulking and glazing sealants were identified as follows:
 - Exterior Frame to Masonry and Masonry to Masonry Joints (120 linear feet [l.f.]) One sample of caulking was collected from the frame to masonry exterior joint. Analytical results indicated that PCBs were present at a concentration of 70,500 ppm; and
 - Glazing Sealants One sample of glazing sealants was collected from the frame to glass joints on the interior side of the main entry. Analytical results indicated that PCBs were present at a concentration of 6,500 ppm.
- Second Floor Curtain Wall Area Joints (160 l.f.) Samples of caulking and glazing sealants were not
 collected from this area due to access restrictions. Based on the similar construction of the curtain wall
 window and the north side main entry, analytical results from caulking and sealants collected from the north
 side main entry are to be applied to the second floor curtain wall window sealants;
- Windows (84 windows) caulking and glazing sealants were identified as follows:
 - Interior Frame to Masonry Joints (vertical joints only; 1,512 l.f.) Analytical results indicated that PCBs were present at concentrations ranging from 209,000 to 400,000 ppm in the four samples collected;
 - Interior Glazing Sealants Analytical results indicated that PCBs were present at a concentration of 1,900 ppm in the one sample collected;
 - Exterior Frame to Masonry Joints (horizontal and vertical joints; 2,100 l.f.) Analytical results indicated that PCBs were present at concentrations ranging from 71,300 to 390,000 ppm in the four samples collected; and
 - Exterior Glazing Sealants Analytical results indicated that PCBs were present at concentrations of 2,680, 3,060, and 213,000 ppm in the three samples collected.
- Roof Top Penthouses caulking was identified as follows:
 - o Penthouse Doors (3 doors; approximately 50 l.f.) Analytical results indicated that PCBs were present at a concentration of 490,000 ppm in the sample collected;
 - Penthouse Ventilation Louvers (16 louvers; approximately 144 l.f.) Analytical results indicated that PCBs were present at a concentration of 730 ppm in the sample collected; and



- Penthouse Parapet Cap (265 I.f.) Analytical results indicated that PCBs were present at a concentration of 67 ppm.
- Ductwork A red sealant/coating was identified along metal to concrete joints at wall penetrations points and in metal to metal ductwork joints within the rooftop penthouses, the interior building spaces overhead areas, and the basement mechanical spaces. Analytical results indicated that PCBs were present at concentrations ranging from 31 to 3,000 ppm in the nine samples collected.

2.2.2 < 50 ppm Caulking

As indicated on Table 2-1, caulking identified as containing PCBs < 50 ppm has been identified in three locations:

- Building Parapet Cap Joints (175 I.f.) Two samples of caulking were collected from the south building elevation parapet wall scheduled for removal as part of the renovation project. Caulking was observed along the brownstone cap to flashing joint (150 I.f.) and along the brownstone to brownstone cap joints (25 one-foot long joints). Analytical results indicated that PCBs were present at concentrations of 2.0 and 33 ppm. During sample collection no other caulking or caulk residue were observed in the joint. The initial sampling frequency was based on the initial project scope which included the removal of the building parapet cap along the southern building elevation only. A revised project scope includes the replacement of all portions of the building parapet cap (approximately 800 I.f. parapet cap). Based on the recent change in project scope, two additional samples of the caulking will be collected prior to project implementation to confirm total PCBs < 50 ppm in this sealant type;</p>
- Roof Top Penetrations Two samples of caulking surrounding rooftop penetrations associated with the building ventilation support structures were collected. Analytical results indicated that PCBs were nondetect (< 0.95 ppm) in one sample and present at a concentration of 1.4 ppm in the second sample collected; and
- Interior CMU Control Joints (1 joint; 9 l.f.) One sample of caulking collected from the single observed interior CMU control joint was collected and reported PCBs as non-detect (< 0.87 ppm).

Based on this information, Yale has determined that these caulking materials meet the definition of an Excluded PCB Product per 40 CFR 761.3. The project specifications prepared for the renovation project will identify these specific materials as having detectable concentrations of PCBs at these levels for management and disposal purposes. If analytical results from the additional building parapet wall caulking samples indicated that PCBs are present at concentrations \geq 50 ppm, the building parapet wall will be remediated as described for the penthouse parapet wall included in Section 7 of this plan.

2.2.3 Adjacent Building Materials

A total of 55 samples of building materials were collected to determine the extent of PCBs from caulking/sealants identified as containing \geq 50 ppm PCBs. Additional details of the building material sampling, including analytical results and locations of samples, are presented in subsequent sections of this plan. Summaries of the samples collected and the analytical results are presented on Table 2-2. Locations of the adjacent building material samples are presented on Figures 2-1 through 2-4.



2.3 DATA USABILITY ASSESSMENT

This data quality and data usability assessment has been conducted to review the caulking/sealant and building material samples collected to date in support of the characterization activities.

Data validation and review of samples was conducted by both Woodard & Curran and a third-party validator, Data Check, Inc. of New Durham, New Hampshire. This review included a check of field documentation including sample collection and preservation methods, a check of the laboratory data and documentation, a review of the internal laboratory QA/QC procedures and results including surrogate recoveries, blank results, laboratory control standard (LCS) and laboratory control standard duplicate (LCSD) results, and an evaluation of sample holding times and field duplicate results. Data validation summary is provided in Appendix B.

A summary of the data usability assessment is presented below:

- All samples analyzed for PCBs were extracted and analyzed within technical holding times. No qualifications were applied to the data;
- Some samples were analyzed at dilutions due to the high concentrations of PCBs present in the samples and/or due to the sample matrix. Elevated quantitation limits (laboratory reporting limits) are reported in these samples as a result of the dilutions performed;
- The PCB method blanks were non-detect (ND) for all target analytes with the exception of the Aroclor 1254 method blank result for laboratory report 68098. No qualifications were applied to the data because the concentration of Aroclor 1254 in all associated samples was greater than the blank action concentration;
- One field equipment blank sample was collected for equipment used for the collection of masonry samples
 and submitted to the laboratory as part of the field QA/QC procedures. The blank sample was ND for the
 target analytes. No qualifications were applied to the data;
- Results of the matrix spike/matrix spike duplicate (MS/MSD) samples met acceptance criteria with the
 exception of percent recoveries for Aroclor 1260 in sample KCL-CBC-015. Aroclor 1260 results for sample
 KCL-CBC-015 were not qualified based on Aroclor interferences in the primary sample;
- Accuracy of the analytical data was assessed by reviewing LCS/LCSD and surrogate recoveries. The
 recoveries for both surrogates and LCS/LCSD sample results met acceptance criteria. No qualifications
 were applied to the data;
- Two field duplicate samples were collected and submitted to the laboratory as part of the field QA/QC procedures. RPD between the primary and duplicate samples met the acceptance criteria and no qualifications were applied to the data;
- Due to continuing calibration non-conformance, the lower of the two column results was reported for Aroclor 1254 in samples KCL-CBR-039 and field duplicate KCL-CBRD-041. The data is still usable for the intended purposes given that total PCBs were reported at concentrations > 25 ppm and final extent of encapsulation will be based on the limits of PCBs > 1 or 25 ppm as demonstrated through verification sample collection;
- The Relative Percent Difference (RPD) between the column results met the acceptance criteria (≤ 25%) with the exception of the Aroclor 1248 (KCL-CBK-017), Aroclor 1254 (KCL-CBK-003, KCL-CBB-021, KCL-CBR-023, KCL-CBC-212, KCL-CBC-213, and KCL-CBC-214 [duplicate sample]), and Aroclor 1260 (KCL-VBC-205). Aroclor 1248, Aroclor 1254, and Aroclor 1260 results for these samples have been qualified as



estimated (J), as applicable. RPD results for detected PCBs in laboratory reports 12F0342, 09800337, and 09800339 were not available; no qualifications were applied;

- Representativeness of the data was evaluated qualitatively utilizing site information and sampling data. Samples were extracted and analyzed within the allowable holding times. Consistent procedures and laboratory analysis of the data were achieved. Samples were accompanied by complete chain of custody forms from the time of sample collection until laboratory delivery. PCBs were not detected in the method blank analysis, indicated that there were no interferences introduced at the laboratory or during sample analysis;
- Samples associated with laboratory reports 12F0342, 09800337, 09800339, 68098, 68444, and 68983 were
 received at temperatures above six degrees Celsius. All associated sample results were qualified J/UJ; and
- The data packages were reviewed to ensure that all sample and associated quality assurance results were available. The completeness review indicated that all samples were analyzed and all quality control results were available to complete the data validation process.

Based on a review of the collective data set, the data adequately represents the materials tested. The characterization data is of sufficient quality for the purposes of characterizing PCB-affected media in accordance with 40 CFR 761 and for use in developing the remediation plan presented herein.



3. REMEDIATION PLAN OVERVIEW

This plan has been developed for the remediation of the PCB-containing sealants and PCB-impacted building materials that will be disturbed during the Kline Chemistry Laboratory renovation project. A general overview of the proposed remedial activities is presented below with detailed descriptions of the plan for each of the affected media presented in the following sections.

The remediation plan proposed herein is a combination of a removal and off-site disposal of PCB bulk product waste under 40 CFR 761.62 with a risk-based cleanup and disposal request prepared in accordance with 40 CFR Part 761.61(c) for PCB remediation wastes (CMU block, brick, concrete, etc.).

In summary, all caulking and sealants containing \geq 50 ppm PCBs encountered/disturbed within the work area will be removed and disposed off-site as a \geq 50 ppm PCB waste. Window frames and components (including glass) coated with \geq 50 ppm PCB sealants will also be removed for off-site disposal as \geq 50 ppm PCB waste.

Building materials scheduled for removal (interior CMU block walls, penthouse building materials, ventilation ductwork, etc.) will be removed and segregated for disposal as either ≥ 50 ppm PCB wastes, < 50 ppm PCB Remediation waste, or general demolition debris following a cut-line approach. The location of the cut-line will be based on results of verification sampling. To the extent practical, verification samples will be collected prior to implementation of the project to confirm the location of the cut-line as described in the following sections.

Residual concentrations of PCBs in building materials not scheduled for removal (i.e., the majority of exterior brick and brownstone) are proposed to be contained through the application of a liquid coating and managed in-place to prevent direct contact with PCBs and/or potential migration effects to other media. The rationale for this decision is that the removal or scarification of these materials could result in structural damage to the building and result in significant aesthetic changes to the architectural appearance of the building (for example, brownstone construction). Building material removals would also result in the need for extensive re-configurations not planned for this renovation project that would change the historic appearance of the building.

The applicable cleanup criteria for materials remaining on the building will be assigned as follows:

- Interior Locations and Exterior First Floor Locations High occupancy cleanup criteria of 1 ppm; and
- Exterior Second Floor Locations Low occupancy cleanup criteria of 25 ppm.

The use of the low occupancy cleanup criteria at exterior second floor locations is based on the 40 CFR 761.3 definition of this type of occupancy and the low potential for direct contact with these materials given that there is no access to exterior portions of the second floor via balconies, doors, or other access points.

The in-place management of PCB remediation waste is an interim solution designed to shield impacted materials from the effects of weathering and leaching mechanisms, thereby eliminating potential exposure pathways and mitigating the potential for PCB transfer via direct contact and/or leaching to other media/materials. Accordingly, there will be no resultant exposure to PCBs and the remnant PCBs will not present a risk to human health or to the environment. Proper disposal of any remaining PCBs in building materials will be required upon removal of the material or at the time of structure demolition.

A summary of the remedial approach for the caulking and building materials is presented on Table 3-1. An overall summary of the verification samples and frequency is presented as Table 3-2. Detailed discussions on the proposed remediation and verification are presented in the following sections.



4. PREPARATION, COMMUNICATIONS, AND CONTROLS

Prior to initiating any of the remediation activities, the following activities will be implemented.

4.1 PREPARATION AND COMMUNICATIONS

- A Health & Safety Plan will be developed for the specific work activities to be conducted. Workers will follow
 applicable Federal and State regulations regarding the work activities, including but not limited to OSHA
 regulations, fall protection standards, respiratory protection, ladder/scaffolding safety, personal protective
 equipment (PPE), etc.
- Additional notifications and plans required for the work activities, including the preparation and submittal of a Contractor Workplan following Contractor selection, will also be prepared and submitted for approval, as needed.
- The work is scheduled to be conducted when the entire building is vacant; however, prior to initiation and periodically during the work activities, project-related communications with University staff and contractors will be undertaken on an as needed basis.

4.2 CONTROLS

- Access to the active work areas will be restricted by fencing and signage with controlled access points.
- To reduce particulate levels and exposures to airborne particulates, a combination of engineering controls (e.g., work zone enclosures, polyethylene sheeting, HEPA filtration, wetting, etc.) and PPE will be implemented as part of the work activities.
- Polyethylene sheeting will be placed within the work areas including on scaffolding and lifts used to access
 the work areas. Wet wiping and water misting will be used as a dust suppressant as appropriate. No
 grinding or saw cutting will be used for caulking removal.
- Dust monitoring will be conducted in accordance with Appendix C during active dust generating removal
 activities. Based on the engineering controls to be implemented and the minimal amount of disturbance to
 the caulking required for caulking removal, dust monitoring will not be conducted when only caulking and
 window/doors are being removed.
- Ground cover (polyethylene sheeting or equivalent) will be placed along the building walls to serve as containment for any debris or building materials that may fall during removal activities. Any debris collected on the polyethylene sheeting will be gathered and placed in the appropriate containers at the end of each work day. After use, disposable PPE and poly sheeting used to collect debris will placed in the appropriate containers for disposal as PCB remediation waste as described in Section 9.
- Wet wiping, spraying, and/or vacuuming of tools and equipment in the work area will be performed at the
 completion of the work activity. At the completion of the project, any non-disposable equipment and tools
 that handled PCB material will be decontaminated following the procedures described in 40 CFR 761.79.



5. NORTH SIDE MAIN ENTRY AND SECOND FLOOR CURTAIN WALL WINDOW SYSTEMS

This section presents the characterization data and proposed remediation plans associated with north side main entry and second floor curtain wall window systems.

The north side main entry and second floor curtain wall window systems are scheduled for removal as part of the renovation project. Following removal, the openings for each will be filled in with brick and smaller individual windows to match the rest of the elevation.

5.1 CHARACTERIZATION

Characterization samples of caulking, glazing sealants, and adjacent building materials were



collected from the main entry doorway. Approximately 40 l.f. of caulking was identified along the exterior frame to brick vertical joints (20 l.f.) and the upper horizontal frame to brownstone ceiling joint (20 l.f.). Caulking was also observed along brownstone to brownstone masonry joints on the overhang ceiling in front of the door (80 l.f.). No caulking was observed along the lower horizontal joint between the frames and the bluestone decking. Caulking was not observed along interior joints. Analytical results indicated that PCBs were present at a concentration of 70,500 ppm in the exterior caulking and at a concentration of 6,500 ppm in the window glazing sealants.

Access to the exterior side of the second floor curtain wall window system was not available at the time of characterization. No caulking or glazing sealants were observed on the interior side of the window. Based on similar physical construction, it is assumed that caulking along the exterior frame to masonry joints of the second floor curtain wall window (including the lower horizontal frame to terrazzo floor joint) contains PCBs \geq 50 ppm. This includes a total of approximately 40 l.f. of caulking along brick joints (includes frame to brick vertical joints [20 l.f.] and horizontal brick wall to terrazzo floor joints [20 l.f.]), 100 l.f. of caulking along brownstone joints (includes the upper horizontal frame to brownstone ceiling joint [20 l.f.]) and the brownstone to brownstone ceiling joints [80 l.f.]), and 20 l.f. of caulking along the exterior frame to terrazzo floor joint.

Characterization samples of building materials were collected to determine the extent of PCBs > 1 ppm for waste segregation purposes. A summary of the samples collected and the analytical results is as follows:

- Two samples of exterior brick were collected at a distance of four inches from the vertical caulked joints. Analytical results indicated that PCBs were non-detect in both samples (< 0.43 and < 0.48 ppm); and
- One sample of brownstone ceiling was collected at a distance of six inches from the upper horizontal caulked joint. Analytical results indicated that PCBs were non-detect (< 0.48 ppm).

Summaries of the caulking and building material characterization sampling results are presented on Table 2-1. The locations of the samples are depicted on Figure 2-2.



5.2 REMEDIATION

The remedial approach for the north side main entry and the second floor curtain wall window systems is described below. The approach is a material removal and segregation approach through the establishment of a cut-line for segregation of materials as either \geq 50 ppm PCB wastes or general demolition debris (i.e., PCBs \leq 1 ppm).

≥ 50 ppm PCB Containing Caulking and Sealants and Coated Door/Window Components – Caulking, glazing sealants, backer materials, and coated door/window components (including glass) associated with the north side main entry and second floor curtain wall window system will be removed for disposal as ≥ 50 ppm PCB waste to a hazardous waste disposal facility.

Refer to Section 6 for additional details on the removal procedures.

<u>Adjacent Building Materials</u> – Building materials within the project work area will be removed as follows (pre-removal verification samples to be collected as described on Section 5.3 to confirm extent):

Brick Walls –

- The first half-row of bricks along vertical caulked joints (i.e., materials formerly in direct contact with and to a distance of approximately four inches from the joint) will be removed for disposal as ≥ 50 ppm PCB wastes;
- The first row of bricks along horizontal floor to wall caulked joints (i.e., materials formerly in direct contact with and to a distance of approximately 3 inches above the joint) will be removed for disposal as ≥ 50 ppm PCB wastes;
- Remaining brick materials will be removed and segregated for disposal as general demolition debris based on results of verification sampling (see below); and
- All ≥ 50 ppm PCB wastes will be disposed of at a hazardous waste disposal facility.
- Brownstone Ceiling Based on the limited volume of materials associated with the brownstone ceiling, the
 overhang ceiling will be removed in its entirety for disposal as ≥ 50 ppm PCB waste to a hazardous waste
 disposal facility; and
- Terrazzo Floor Floor materials formerly in direct contact with and to a distance of eight inches from the caulked joints to be removed for disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility. This distance was selected based on discussions with the project team regarding anticipated methods of removal and based on results from terrazzo floor sampling conducted at the Kline Geology Laboratory in 2011 which indicated that PCBs > 1 ppm were present at distances of up to 1.25 inches from the caulked joint. Samples for delineation of PCBs were not collected as part of this plan preparation because there is not currently access to the exterior portion of the building at this location. As indicated below, verification samples will be collected prior to removal. Remaining floor materials (beyond the cut-line) will be removed and segregated for disposal as general demolition debris in accordance with the project specifications.

5.3 BUILDING MATERIAL VERIFICATION SAMPLING

Prior to removal of any ≥ 50 ppm PCB wastes from the building, verification samples will be collected from brick and terrazzo floor materials to verify the extent of PCBs > 1 ppm as follows:



- Brick Verification samples will be collected as follows:
 - O Vertical Frame to Brick Joints Samples to be collected from the first full row of bricks away from the caulked joint (i.e., immediately past the first half-row of brick or approximately four inches from the joint) at a frequency of 1 sample per 20 l.f. of caulked joint. Based on a total of 40 l.f. between the first and second floors, a total of two samples will be required; as indicated previously, the samples from the north side main entryway have already been collected; and
 - Horizontal Floor to Brick Joints Samples to be collected from the second row of brick above the joint (approximately four inches from the joint) at a frequency of 1 sample per 20 l.f. of caulked joint for a total of one sample.
- Terrazzo Floor Verification samples will be collected at a distance of eight inches from the caulked joint along the frame to floor joint and the frame to brick joints at a frequency of 1 sample per 20 l.f. for a total of 2 samples.

Analytical results will be compared to the unrestricted use criteria of 1 ppm for waste segregation purposes. If results indicated that PCBs are present at concentrations > 1 ppm, additional verification samples will be collected at distances further from the respective joints to delineate the extent of PCBs > 1 ppm and the cut-line will be adjusted based on results of the testing. A summary of the verification sampling plan is provided on Table 3-2.

Refer to Section 9 for the waste storage and disposal procedures for the materials.



6. BUILDING WINDOWS ON EXTERIOR FAÇADES

This section presents the characterization data and remediation plans associated with the windows scheduled to be removed and interior and exterior building materials in direct contact with and away from the caulked frame to masonry joints.

6.1 WINDOW FRAMES AND COMPONENTS

As part of the initial inspection, an inventory of windows was conducted. As shown on Figures 2-2 and 2-3, there are a total of 84 windows with dimensions of approximately 2.5 ft. by 9 ft. located on the first and second floor of the building.

6.1.1 Characterization

Caulking is present on interior and exterior metal frame to masonry vertical joints and exterior horizontal joints. Glazing sealants are present along interior and exterior frame to glass joints.

Caulking and glazing sealant samples were collected from various locations throughout the building to determine the concentrations of PCBs in the caulking and sealants. The sample locations were spatially distributed throughout the work area and collected from interior and exterior locations. A total of eight caulking samples and four glazing sealant samples were collected as presented on Table 2-1.

As indicated on Table 2-1, all samples detected PCBs at concentrations > 50 ppm ranging from 1,900 ppm in the interior window glazing sealant sample to 400,000 ppm in one of the interior window caulking samples. Based on these results, window caulking and glazing sealants encountered will be managed as ≥ 50 ppm PCB wastes.

6.1.2 Remediation

The caulking and window removal task described below involves the removal and off-site disposal of the caulking and window glazing sealant encountered as well as the associated window frames and components (including glass) during the performance of the window replacement project.

- Removal of the majority of the caulking will be done during window removal. Windows will be removed as single units with minimal size reduction performed as required for safe management and handling and/or waste disposal facility requirements;
- For building materials scheduled to remain in place, residual caulking will be removed using hand tools or
 electric caulking removal tools to achieve caulking removal to the maximum extent practicable while
 minimizing dust or other airborne particulates generated from caulking or adjacent materials. There will be
 no grinding or saw cutting of caulking. Upon the completion of caulking removal activities, the joints will be
 visually inspected for the presence of any residual caulking. If residual caulking is observed, it will be
 removed from the adjacent material to the maximum extent practicable;
- For building materials scheduled to be removed, no additional caulking removal will be conducted following window removal. Residual caulking will be removed with the adjacent building materials (brick, brownstone, etc.) for off-site disposal as ≥ 50 ppm PCB waste (see subsequent sections);
- Wet wiping and/or vacuuming of all tools and equipment in the work area will be performed at the completion of the work activity;



- During the project, equipment and tools used in the removal process will be decontaminated through spraying and wet wiping. At the completion of the project, any non-disposable equipment and tools that handled PCB material will be decontaminated following the procedures described in 40 CFR 761.79;
- Any debris collected on the polyethylene sheeting will be gathered and placed in the ≥ 50 ppm PCB waste containers at the end of each work day. After use, disposable PPE and poly sheeting used to collect debris will placed in the appropriate containers for disposal as PCB waste;
- All removed caulking, window frames and components (including glass), and associated debris will be transported for off-site disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility; and
- Following completion of removal activities, the work area will be cleaned through HEPA vacuuming and wet wiping in preparation for the application of the liquid sealant, where needed.

Refer to Section 9 for the waste storage and disposal procedures for the materials.

6.2 INTERIOR BUILDING MATERIALS ADJACENT TO WINDOWS

This section presents the characterization data and remediation plans associated with interior CMU walls adjacent to interior window caulking.

6.2.1 Characterization

The interior building walls adjacent to the windows consist of CMU block. The windows are installed in a recess ranging from 15 to 18 inches from the face of the interior building wall. Caulking containing PCBs \geq 50 ppm is present along both vertical metal window frame to CMU joints. Caulking is not present along the horizontal joints.

Characterization samples of CMU block within the window recess were collected from distances of one, seven, and ten inches away from the caulked joints at four window locations. Results of the sampling are summarized below and indicated decreasing levels with distance from the caulked joint:

- 1 inch from the caulked joint Analytical results indicated that PCBs were present at concentrations of 10.5 and 13.5 ppm;
- 7 inches from the caulked joint Analytical results indicated that PCBs were present at concentrations of 1.34 and 1.56 ppm; and
- 10 inches from the caulked joint Analytical results indicated that PCBs were present at concentrations of 0.893, 0.777, 2.2, and 3.8 ppm.



Characterization samples of CMU block were also collected immediately after the window recess (i.e., at distances of either 15 or 18 inches from the caulked joints) at four locations. Analytical results indicated that PCBs were present at concentrations of 1.46, 1.50, 4.12, and 4.42 ppm.

To confirm that other sources of PCBs were not contributing to PCBs at concentrations > 1 ppm, additional characterization samples of CMU block (0 to 0.5 inch depth) were collected from locations with no physical relationship to interior caulking (i.e., from areas without windows or caulking such as hallways and in the basement).



The location of the samples and the analytical results were as follows:

- Basement Level –Analytical results indicated that PCBs were < 1 ppm in four samples collected from CMU within hallways and rooms with total PCBs reported at concentrations of 0.15, 0.36, 0.84, and 0.95 ppm;
- First Level Analytical results indicated that PCBs were present at concentrations of 0.71 and 0.89 ppm in samples collected from first floor hallways; and
- Second Level Analytical results indicated that PCBs were present at a concentration of 0.70 ppm in a sample collected from the second floor hallway.

Based on these results, PCBs reported in characterization samples at concentrations above the unrestricted use clean up level are considered attributable to the caulking located on the interior window frame to masonry joints.

Characterization samples of CMU block were also collected to confirm the surficial nature of the PCB impacts and to provide analytical data of the waste stream for waste disposal purposes. A summary of the samples and the analytical results is as follows:

- Four samples of CMU block were collected at a depth of 0.5 to 1.0" from the surface of the block at first and second floor locations. Analytical results indicated that PCBs were < 1 ppm in all four samples with total PCB concentrations of 0.34, 0.38, 0.54, and 0.68 ppm; and
- Two core samples of the entire width of the CMU block were collected. Analytical results indicated that PCBs were present at concentrations of 0.74 and 1.3 ppm.

A summary of the characterization sample results is included on Table 2-2. The locations of the samples are depicted on Figures 2-1, 2-2, and 2-3.

6.2.2 Remediation

All interior non-structural materials are scheduled for removal as part of the overall building renovation project. To support this project scope, a materials segregation/materials management strategy was developed for CMU materials. Under this approach, CMU materials will be removed and segregated for disposal as ≥ 50 ppm PCB wastes, < 50 ppm PCB wastes, and general demolition debris following a cut-line approach as follows:

- ≥ 50 ppm PCB Wastes The first row of CMU block materials (i.e., the row of block in direct contact with caulked joints; approximately 20 cubic yards (yd³) of materials) are to be removed for disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility;
- < 50 ppm PCB Wastes CMU block materials located beyond the first row of block (approximately 115 yd³ of materials) are to be removed through a cut-line approach for disposal as < 50 ppm PCB wastes to a non-hazardous waste disposal facility. Based on the limited distance between windows (typically eight feet), the extent of removal as < 50 ppm PCB wastes will include all CMU between windows and will extend to a defined boundary or "break point" such as door openings, or interior 90-degree angles where there is no additional caulking (see Figures 6-1 and 6-2). This "point" will be confirmed through verification sampling (see Section 6.2.3); and</p>
- Pending verification results, the remaining CMU block materials will be removed for disposal as general demolition debris.

The extent of CMU block materials to be removed as PCB wastes are depicted on Figure 6-1 and 6-2.



6.2.3 Interior Building Material Verification Sampling

CMU block materials are to be removed for off-site disposal as either \geq 50 ppm PCB wastes, as < 50 ppm PCB wastes, or as general demolition debris. No additional samples are proposed to be collected to confirm the location of the cut-line between \geq 50 ppm PCB wastes and < 50 ppm PCB wastes. This approach is supported by the existing data set and the planned disposal of CMU block beyond this point as < 50 ppm PCB waste. The existing data set includes 12 characterization samples collected from six locations at varying distances from the caulked joint, which indicated that PCBs were present at concentrations up to 13.5 ppm. Of the 12 samples, ten were collected beyond the first row of CMU block with analytical results indicating that PCBs ranged from 0.777 to 4.42 ppm, well below 50 ppm. This corresponds to an overall sample frequency of one sample per 14 windows.

Verification samples are to be collected to confirm the cut-line between < 50 ppm PCB wastes and general demolition debris. Verification samples will be collected from CMU block materials immediately past proposed cut-lines at a frequency of 1 sample per 50 l.f. of cut-line. Analytical results will be compared to the unrestricted use criteria of 1 ppm for waste segregation purposes. If results indicated that PCBs are present at concentrations > 1 ppm, additional verification samples will be collected at further distances to delineate the extent of PCBs > 1 ppm and the cut-line will be adjusted based on results of the testing.

In total, 9 verification samples are proposed to be collected. The location of each verification sample will be selected by randomly selecting a number from zero to nine (based on the length of the caulked joint and typical CMU wall height) with the zero point assigned to the bottom of the wall.

A summary of the proposed verification sampling plan is provided on Table 3-2.

6.3 EXTERIOR BUILDING MATERIALS ADJACENT TO WINDOWS - SCHEDULED FOR REMOVAL

This section presents the characterization data, remediation plans, and verification process associated with exterior brick materials surrounding windows in the southern courtyard area scheduled to be removed for the installation of a curtain wall window system.

6.3.1 Characterization

Brick surrounding the 36 south courtyard windows is scheduled for removal to allow for the installation of the courtyard curtain wall window system. The windows are recessed approximately three to four inches from the face of the building. Caulking containing PCBs \geq 50 ppm is present along all vertical and horizontal metal window frame to brick joints.

Characterization samples of brick were collected from four locations as summarized below:

• Two samples were collected at a distance of ½-inch from the edge of the window recess along the vertical joint (approximately 4 inches from the joint). Analytical results indicated that PCBs were non-detect (< 0.48 and < 0.091 ppm);



and



• Two samples were collected at a distance of 3" below the edge of the lower horizontal window recess (approximately 6" from the caulked joint). Analytical results indicated that PCBs were non-detect (< 0.091 ppm) and present at a concentration of 0.64 ppm.

A summary of the characterization sample results is included on Table 2-1. The locations of the samples are depicted on Figures 2-2. Based on these results, a remedial plan for the removal and segregation of exterior brick materials through a cut-line approach was developed.

6.3.2 Remediation

Brick materials in the southern courtyard will be removed and segregated for disposal as either ≥ 50 ppm PCB wastes or general demolition debris following a cut-line approach as follows:

- Vertical Joints The first half-row of brick away from the recess (i.e., formerly in direct contact with the caulking and to a distance of approximately 4 inches from the caulked joint) will be removed for disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility;
- Horizontal Joints The first full row of brick above and below the window recess (i.e., formerly in direct
 contact with the caulking and to a distance of approximately 6 inches from the caulked joint) will be removed
 for disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility; and
- All remaining brick materials will be removed for disposal as general demolition debris provided verification samples are ≤ 1 ppm.

The location of the cut-line will be verified through the collection of verification brick samples prior to implementation as described in the following section.

6.3.3 Exterior Building Material Verification Sampling

Verification samples will be collected from brick materials to verify the extent of PCBs > 1 ppm. Verification samples will be collected from bricks as follows:

- Vertical Joints Samples will be collected immediately past the first half-row of brick away from the edge of the recess; and
- Horizontal Joints Samples will be collected from the second row of brick below the edge of the recess (all samples associated with horizontal joints are to be collected below the lower horizontal joint based on an assumed "worse-case" migration down the face of the building).

Verification samples will be collected at a sample frequency of approximately 1 sample per 50 l.f. of caulked joint. There is approximately 25 l.f. of exterior caulked joints per window; therefore, a total of 18 samples will be collected.

The location of each verification sample will be selected as follows:

- The individual joint will be randomly selected; and
- The location on the selected joint will be selected by randomly selecting a number between zero and nine (vertical joints) or zero and three (lower horizontal joints) with the zero point assigned to the bottom of vertical joints and the left end of the lower horizontal joint.



Analytical results will be compared to the unrestricted use criteria of 1 ppm for waste segregation purposes. If results indicated that PCBs are present at concentrations > 1 ppm, additional verification samples will be collected at distances further from the respective joints to delineate the extent of PCBs > 1 ppm and the cut-line will be adjusted based on results of the testing.

6.4 EXTERIOR BUILDING MATERIALS ADJACENT TO WINDOWS – TO REMAIN IN PLACE

This section presents the characterization data, remediation plans, and verification process associated with exterior building materials that are scheduled to remain in place following the removal of the 48 windows on the north, east, and west elevations.

6.4.1 Characterization


Exterior building materials adjacent to windows consist of brick and brownstone. A summary of each of the materials and the characterization data collected from each follows.

6.4.1.1 Brick

Brick materials are located along vertical joints of each window. Samples of brick were collected from the face of brick materials perpendicular to the building face within the window recess at distances of one and three inches from the caulked joints. A total of six brick samples were collected for characterization purposes. A summary of the analytical results is as follows:

- 1 inch from the caulked joint Three samples were collected and analytical results indicated that PCBs were present at concentrations of 0.615, 2.9, and 4.1 ppm; and
- 3 inches from the caulked joint Three samples were collected and analytical results indicated that the concentration of PCBs were
 1 ppm (0.045, 0.11, and 0.22 ppm).

The locations of the samples are depicted on Figure 2-2.



6.4.1.2 Brownstone Sills

Brownstone sills are located above and below each of the windows and extend approximately 24 inches from the window frames. Up to three samples of brownstone were collected from four locations at distances of one, three, and ten inches from the lower horizontal caulked joint. A summary of the analytical results is as follows:

- 1 inch from the caulked joint Four samples were collected and analytical results indicated that PCBs were present at concentrations of 2.6, 7.9, 8.2, and 10 ppm;
- 3 inches from the caulked joint One sample was collected and analytical results indicated that PCBs were present at a concentration of 0.855 ppm; and



• 10 inches from the caulked joint – Three samples were collected and analytical results indicated that PCBs were present at concentrations < 1 ppm (0.23, 0.29, and 0.63 ppm).

The locations of the samples are depicted on Figure 2-2.

6.4.2 Remediation

As discussed previously, bricks and brownstone at these windows are not scheduled to be removed during the renovation project. To address residual levels of PCBs in these materials following caulking and window removal, an in-place management program will be applied to these materials to prevent direct contact exposure and migration of PCBs outside the existing PCB limits. The in-place management of building materials will be conducted through the application of liquid coatings to materials formerly in direct contact with ≥ 50 ppm caulking and to materials away from the joint containing PCBs greater than the applicable occupancy criteria.

Materials formerly in direct contact with the caulking and those to be covered by the replacement window frames and caulking will be coated with two coats of a liquid epoxy coating (i.e., Sikagard 62 liquid epoxy coating [see Appendix D for manufacturer's product information], or equivalent product).


Materials away from the joints containing PCB greater than the applicable use criteria will be coated with two coats of a clear coating, penetrating sealer, or equivalent product compatible for exterior brick/brownstone coating (i.e., Sikagard 670W clear [see Appendix D for manufacturer's product information], or equivalent product). As with the Kline Geology Project in 2011, preservation of the architectural nature and aesthetics of the building is critically important and a driving factor for product selection. For this project, the specific product to be selected for this application will also be determined based on mock-ups to be performed by the project team during the initial phases of the project. Regardless of the product selected, verification of the effectiveness of the product to contain PCBs will be evaluated through the verification wipe sampling program detailed below.

Based on the differing potential for direct contact exposures, both a high occupancy and low occupancy cleanup criteria will be applied to the bulk delineation samples collected as follows:

- High Occupancy Cleanup Criteria: The high occupancy cleanup criteria of ≤ 1 ppm total PCBs will be
 applied to all first floor building materials. The cleanup criteria is applicable due to the location of the
 windows within ten feet of the ground surface; and
- Low Occupancy Cleanup Criteria: The low occupancy cleanup criteria of ≤ 25 ppm total PCBs will be applied to building materials adjacent to windows on the second floor locations. The application of the low occupancy criteria to these locations is based on their location and use which limits direct contact exposure to these materials given the limited to no access and that the selected replacement windows are inoperable.

The photograph below provides examples of where the applicable criteria are to be applied:





North Building Elevation

6.4.2.1 Additional Delineation Sampling

The extent of sealant application will be subject to modification based on the results of additional delineation sampling to be conducted prior to application. Samples will be collected as follows:

Brick:

High Occupancy Areas (First Floor Locations – 24 window locations): Verification brick samples will be collected at the end of the window recess away from the caulked joint and proposed encapsulation area (see Section 6.4.2.2) to verify the extent of PCBs > 1 ppm. Verification samples are to be collected at a sample frequency of 1 sample per 100 l.f. of caulking. There is approximately 19 l.f. of caulking next to brick per window; therefore, five samples will be collected. At each selected window, the sample location along the joint will be randomly selected using a random number generator based on the total linear footage of the caulked joints; and

Low Occupancy Areas (Second Floor Locations – 24 locations): Verification brick samples will be collected at a distance of one inch from the caulked joint from an area beyond the proposed encapsulation area (see Section 6.4.2.2) to verify that PCBs > 25 ppm are not present beyond the extent of the replacement windows and caulking. Verification samples are to be collected at a sample frequency of 1 sample per 100 l.f. of caulking (5 samples). At each selected window, the sample location along the joint will be randomly selected using a random number generator based on the total linear footage of the caulked joints.



• Brownstone Sills:

- O High Occupancy Areas (First Floor Locations 24 locations): Verification brownstone samples will be collected at a distance of 10 inches from the caulked joint from an area beyond the proposed encapsulation area to verify the extent of PCBs > 1 ppm. Verification samples are to be collected at a sample frequency of 1 sample per 50 l.f. of caulking. There is approximately 6 l.f. of caulking next to brownstone on each window; therefore, three samples will be collected. At each selected window, the sample location along the joint will be randomly selected using a random number generator based on the total linear footage of the caulked joints; and
- O Low Occupancy Areas (Second Floor Locations 24 locations): Verification samples will be collected at a distance of one inch from the caulked joint from an area beyond the proposed encapsulation area to verify that PCBs > 25 ppm are not present beyond the extent of the replacement windows and caulking. Verification samples are to be collected at a sample frequency of 1 sample per 50 l.f. of caulking (3 samples). At each selected window, the sample location along the joint will be randomly selected using a random number generator based on the total linear footage of the caulked joints.

If results of the sampling indicate that PCBs are present at concentrations above the applicable cleanup levels, additional samples will be collected at the frequencies detailed above to delineate the extent of PCB impacts above the cleanup level and to establish the required extent of the barrier coating / sealant.

6.4.2.2 Encapsulant Application

The application of the liquid coating/sealant will be performed following removal of the PCB-containing caulking and windows and under the same containments and controls used for the window removals. Access to the work areas will remain restricted through the use of barrier markers and signage. Access to the work areas will be through aerial lift, staging, or from the interior of the building.

Twenty four windows are located within the high occupancy area and 24 windows are located in the low occupancy designated areas. Around all 48 windows, brick materials formerly in direct contact with the ≥ 50 ppm PCB caulking and to be covered by the replacement windows and new caulking will be coated with two coats of epoxy (approximately ½" beyond current exterior caulking).

Surrounding the 24 windows in the high occupancy areas, brick materials beyond the extent of epoxy application to the end of the window recess (i.e., a distance of approximately three or four inches depending on the size of the recess) will be coated with two coats of a clear coating or penetrating sealant.

For those windows identified within the low occupancy area, if the verification sample results are ≤ 25 ppm, then no additional sealant will be applied to the brick surfaces away from the joint. If results of the verification samples indicate that PCBs > 25 ppm are present, additional verification samples will be collected and the liquid coating/sealant will be applied to materials identified as containing PCBs above the low occupancy criteria.

Brownstone sills and headers are present along 24 windows within the high occupancy areas and 24 windows within the low occupancy areas. Around all 48 windows, brownstone materials formerly in direct contact with the \geq 50 ppm PCB caulking and to be covered by the replacement windows and new caulking will be coated with two coats of epoxy (approximately $\frac{1}{4}$ " beyond current exterior caulking).

Surrounding the 24 windows in the high occupancy areas, all materials beyond the extent of epoxy application to the end of the sill/header (approximately 24 inches) will be coated with two coats of a clear acrylic or penetrating sealant.



For those windows identified within the low occupancy area, if the verification sample results are ≤ 25 ppm, then no additional sealant will be applied to the brownstone surfaces away from the joint. If results of the verification samples indicate that PCBs > 25 ppm are present, additional verification samples will be collected and the liquid coating/sealant will be applied to materials identified as containing PCBs above the low occupancy criteria.

6.4.3 Verification Wipe Sampling

Following application of the sealant, verification baseline wipe samples will be collected from materials formerly in direct contact with the exterior caulked joint and from materials away from the caulked joint. Wipe samples will be collected following the standard wipe test procedures described in 40 CFR 761.123. Details of the sampling program are presented in the following sections.

6.4.3.1 Former Direct Contact Areas

Verification wipe samples of sealed building materials formerly in direct contact with the caulked joints will be collected to evaluate the effectiveness of the sealant. A summary of the verification sample frequency for each building material is provided below:

- Brick (48 windows) Verification wipe samples collected from sealed brick materials formerly in direct
 contact with the exterior caulking will be collected at a sample frequency of 1 sample per 100 l.f. of
 caulking next to brick for a total of 10 samples (48 x 19 l.f. = 912 l.f.); and
- Brownstone (48 windows) Verification wipe samples collected from sealed brownstone materials formerly in direct contact with the exterior caulking will be collected at a sample frequency of 1 sample per 50 l.f. of caulking next to brownstone for a total of 6 samples (48 x 6 l.f. = 288 l.f.).

6.4.3.2 Materials Away from the Joint

Verification wipe samples of sealed building materials adjacent to the former caulked joint will be collected to evaluate the effectiveness of the sealant. A summary of the verification sample frequency for each of the building materials is provided below:

- Brick (24 High Occupancy Windows) Brick materials adjacent to caulked joints are to be sealed on a total
 of 24 first floor windows. Verification wipe samples will be collected at a sample frequency of 1 sample per
 100 l.f. of caulking next to brick for a total of 5 samples (24 x 19 l.f. = 456 l.f.); and
- Brownstone (24 High Occupancy Windows) Brownstone materials adjacent to caulked joints are to be sealed on a total of 24 first floor windows. Verification wipe samples will be collected at a sample frequency of 1 sample per 50 l.f. of caulking next to brownstone for a total of 3 samples (24 x 6 l.f. = 144 l.f.).

At this time, liquid sealant application is not anticipated at low occupancy areas. However, if applied then verification wipe samples will be collected at the same frequency as the high occupancy areas.

Results from wipe samples collected from sealed surfaces adjacent to the windows (i.e., areas of clear coat application) will be compared to the standard as follows:

- ≥ 1 μg/100cm² Additional coat of liquid sealant may be applied and verification sample re-collected at an off-set location depending on product specifications for coating/sealant layers; and
- < 1 μg/100cm² No further action.



7. ROOFTOP PENTHOUSE EXTERIOR BUILDING MATERIALS

This section presents the characterization data, remediation plans, and verification process associated with sealants identified on exterior locations of the rooftop penthouse. The entire rooftop penthouse is scheduled for removal as part of the overall building renovation project.

7.1 CHARACTERIZATION

Characterization samples of caulking were collected from the penthouse doors, the penthouse ventilation louvers, and the penthouse parapet cap. Analytical results indicated that PCBs were present at concentrations \geq 50 ppm. A summary of the caulking identified on the penthouse is as follows:

- Approximately 50 l.f. of caulking was observed along the vertical and upper horizontal penthouse door frame to brick joints (3 doors);
- Approximately 144 l.f. of caulking was observed along the vertical and upper horizontal penthouse ventilation louver frame to brick joints (16 locations); and
- Approximately 265 l.f. of caulking was observed along the stone to flashing joints and stone to stone joints of the penthouse parapet cap.



Penthouse Door (typical)



(Mortar Joint)

Penthouse Parapet Cap

One characterization sample of brick was collected at a distance of four inches from the penthouse door caulked joint. Analytical results indicated that PCBs were non-detect (< 0.091 ppm). One sample of brick was collected at a distance of four inches from the vertical louver caulked joint. Analytical results indicated that PCBs were non-detect (< 0.095 ppm).

Summaries of the caulking and building material characterization sampling results are presented on Table 2-1. The locations of the samples are depicted on Figure 2-4.



7.2 REMEDIATION

The remedial approach for the penthouse doors, louvers, and parapet cap is described below. The approach is a material removal and waste material segregation approach through the establishment of a cut-line for segregation of materials as either ≥ 50 ppm PCB wastes or general demolition debris (i.e., PCBs ≤ 1 ppm).

≥ 50 ppm PCB Containing Caulking and Sealants, Door/Louver Components, and Parapet Cap Components – Caulking, backer materials, door/louver components associated with penthouse doors, louvers, and parapet cap brownstone and flashing materials will be removed for disposal as ≥ 50 ppm PCB waste to a hazardous waste disposal facility. Refer to Section 6 for additional details on the removal procedures.

<u>Adjacent Building Materials</u> – Building materials within the project work area will be removed as follows (pre-removal verification samples to be collected as described in Section 7.3 to confirm extent):

- Brick Walls Associated with Doors and Louvers
 - o The first half-row of bricks along vertical caulked joints (i.e., materials formerly in direct contact with and to a distance of approximately four inches from the joint) and the first row of brick along horizontal joints will be removed for disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility; and
 - Remaining brick materials will be removed and segregated for disposal as general demolition debris pending results of verification sampling (see below).
- Parapet Cap Materials Based on the limited volume of materials associated with the parapet cap, parapet cap materials including brownstone cap, metal flashing, and bricks directly below the lateral caulked joints will be removed for disposal as ≥ 50 ppm PCB waste to a hazardous waste disposal facility.
- Metal Flashing below Louvers Metal flashing directly below each louver and to a distance of six inches
 from the louvers will be removed for disposal as ≥ 50 ppm PCB waste to a hazardous waste disposal
 facility. All remaining metal flashing will be removed for disposal as general demolition debris pending
 results of verification sampling (see below).

7.3 BUILDING MATERIAL VERIFICATION SAMPLING

Prior to removal of any \geq 50 ppm PCB wastes from the roof penthouse, verification samples will be collected from brick and materials to verify the extent of PCBs > 1 ppm as follows:

- Penthouse Doors Verification samples to be collected at a frequency of 1 sample per door (3 samples) to
 be collected immediately past the first half-row of brick away from the vertical joints (approximately 4 inches
 from the joint). No samples are proposed to be collected above the doors based on potential worse-case
 migration of PCBs laterally away from vertical joints.
- Penthouse Louvers (16 locations) Verification samples to be collected immediately past the first half-row of brick away from the vertical joints (approximately 4 inches from the joint) at a frequency of 1 sample per 50 l.f. of caulking. There is approximately 9 l.f. of caulking next to brick per louver; therefore, three samples will be collected. At each selected louver, the sample location along the joint will be randomly selected using a random number generator based on the total linear footage of the vertical caulked joints (no samples are proposed to be collected above the louvers based on potential worse-case migration of PCBs laterally away from the vertical joints).
- Parapet Cap Joints Verification samples to be collected at a frequency of 1 sample per 10 joints at the beginning of the second row of brick below the lateral stone to stone cap joint (total of 6 samples).



• Penthouse Louver Metal Flashing (16 locations) – Verification wipe samples to be collected at a distance of six inches from the base of the vertical caulked joints at a frequency of 1 sample per 50 l.f. of caulking. There is approximately 9 l.f. of caulking per louver; therefore, three samples will be collected.

Analytical results will be compared to the unrestricted use criteria of 1 ppm (brick samples) or $10 \,\mu\text{g}/100\text{cm}^2$ (metal flashing) for waste segregation purposes. If results indicated that PCBs are present at concentrations above these levels, additional samples will be collected at distances further from the respective joints to delineate the extent of PCBs > 1 ppm or $10 \,\mu\text{g}/100\text{cm}^2$, as applicable, and the cut-line will be adjusted based on results of the testing.

Refer to Section 9 for the waste storage and disposal procedures for the materials.



8. VENTILATION SYSTEM COMPONENTS AND DUCTWORK

This section presents the characterization data, remediation plans, and verification process associated with sealant/coating identified on metal to metal and metal to concrete joints of the ventilation ductwork at the rooftop penthouses, basement mechanical spaces, and in overhead areas within the building and on metal to metal joints within the ventilation system components in the basement mechanical spaces.



All ventilation system components and ductwork is scheduled for removal as part of the overall building renovation project.

8.1 CHARACTERIZATION

During the site inspection and inventory, a red sealant was observed on ductwork along metal to concrete and metal to metal joints in the penthouses, interior building spaces, and the basement mechanical spaces:

- Roof Top Mechanical Penthouses Sealant was observed along metal to metal joints of the ductwork and along the metal to CMU block joints at approximately 36 wall penetration points.
- Interior Building Spaces Overhead Areas Interior spaces have two main ventilation trunks located in the
 overhead areas (approximately 10 to 12 feet above the floor). The two trunks come together into a single
 ventilation system at mixing junction boxes approximately six to eight feet from wall penetrations. The



typical configuration is presented on Figure 8-1. Where flexible ductwork was observed, sealant was present along metal to concrete joints at wall penetration points in the basement floor, first floor, and second floor spaces and along metal to metal joints of the ductwork between the wall penetration and the junction boxes. A total of 92 wall penetrations (joining into 46 junction boxes) were observed to have the red sealant on the joints. In areas without flexible ductwork and in ventilation components beyond the junction boxes, metal to metal joints were observed to be gasket materials.

• Basement Mechanical Spaces – Sealant was observed along metal to metal joints of the ductwork and ventilation system components in the east and west mechanical spaces. Due to accessibility issues within the basement mechanical spaces, the number and location of joints containing the sealant is not known at this time. However, the project scope includes the removal of all ductwork and ventilation system components and the remediation strategy presented below has been developed to be scalable to the amount of sealants or number of joints to be encountered.

Characterization samples of sealants and building materials were collected as follows:

- Six characterization samples of the red sealant/coating were collected. Analytical results indicated that PCBs were present at concentrations ranging from 58.9 to 3,000 ppm.
- One characterization sample was collected from interior CMU block materials within the roof top penthouse at a distance of six inches below the sealant at a wall penetration point. Analytical results indicated that PCBs were non-detect (< 0.087 ppm).

8.2 PILOT TEST ACTIVITIES

In order to evaluate whether or not PCB impacts were present in underlying concrete materials at wall penetration points, a pilot test was conducted at three interior locations. At each location, all visible sealant was removed from the concrete under negative pressure controls and HEPA filtrations. Sealant was removed using an electric oscillating removal tool (Fein SuperCut). Once all visible sealant was removed, one sample of concrete was collected from each pilot test area. Analytical results indicated that PCBs were present at concentrations of 0.75, 1.1, and 6.5 ppm.

In addition, to support an overall waste material segregation approach, an evaluation of whether or not PCBs had migrated within the ductwork sealant beyond the location of the red sealants was conducted. Wipe samples of the ductwork were collected within the mixing junction boxes immediately beyond the last observed location of red sealant. Three wipe samples were collected on the interior vertical side wall of the box. Analytical results indicated that PCBs were reported as non-detect (2 samples at < 0.20 μ g/100cm²) and at a concentration of 0.34 μ g/100cm². Wipe sample results are presented on Table 8-1.

8.3 REMEDIATION

For the metal ductwork and adjacent CMU block, the remedial approach is a material removal and waste material segregation approach through the establishment of a cut-line for segregation of materials as either \geq 50 ppm PCB wastes or general demolition debris (i.e., PCBs \leq 1 ppm for CMU block or \leq 10 µg/100cm² for metal ductwork). For concrete wall materials scheduled to remain in place surrounding the wall penetration points, the remedial approach is to remove all materials impacted by PCBs > 1 ppm through physical removal method (i.e., grinding, chipping, etc.) with a contingency for in place management via encapsulation if this level cannot be achieved (given that additional concrete removal beyond the initial depth cannot be conducted due to structural concerns). A summary of the approach is as follows:



 \geq 50 ppm PCB Containing Sealants – PCB containing ductwork sealants will be removed for disposal as \geq 50 ppm PCB waste to a hazardous waste disposal facility. For the rooftop penthouse metal to CMU joints and metal to metal joints building wide, removal of the sealant will be conducted as part of the CMU block and metal ductwork removal. For sealant on the concrete scheduled to remain in place surrounding wall penetration points, the sealant will be removed through grinding or chipping of the sealant and coated concrete to a depth of $\frac{1}{4}$.

<u>Concrete Materials</u> – Concrete materials in direct contact with the sealant and to a depth of $\frac{1}{4}$ " will be removed for disposal as ≥ 50 ppm PCB wastes through physical methods (e.g., grinding or chipping). All other concrete materials will remain in place based on the project scope (potentially under an encapsulant coating – see below).

Roof Top Penthouse CMU Block – Interior CMU block at wall penetrations within the rooftop penthouses formerly in direct contact with the sealant and to a distance of six inches from the sealant will be removed for disposal as ≥ 50 ppm PCB waste to a hazardous waste disposal facility. Remaining CMU block materials will be removed for disposal as general demolition debris pending results of verification sampling described below.

<u>Metal Ductwork</u> – Ductwork in direct contact with the sealant and to the distances described below will be removed with the sealants for off-site disposal as ≥ 50 ppm PCB waste to a hazardous waste disposal facility. Remaining ductwork materials will be segregated for disposal as general demolition debris. The segregation approach is as follows:

- Roof Top Penthouse Ductwork Due to the number and location of joints, all ductwork will be removed for disposal as ≥ 50 ppm PCB wastes (i.e., no waste segregation) to a hazardous waste disposal facility;
- Interior Overhead Spaces Ductwork materials from the wall penetrations to the mixing junction boxes will be removed for disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility. Pending verification sample results (see below), all remaining ductwork will be removed for disposal as general demolition debris; and
- Basement Mechanical Spaces The ventilation system component and ductwork cut-line will be established at a distance of six inches from the joints based on the anticipated methods for waste segregation and verified through wipe sampling of materials beyond the cut-line. In support of this cut-line location, verification wipe samples will be collected prior to project implementation as described below. Portions of the materials may be removed for disposal in their entirety as ≥ 50 ppm PCB wastes (i.e., no waste segregation) if the number and location of joints do not support waste segregation.

8.4 BUILDING MATERIAL VERIFICATION SAMPLING

To the extent practical, verification samples will be collected prior to removal. A summary of the verification sampling programs for concrete materials and ductwork is described in the sections below.

8.4.1 Concrete

Following removal of the ductwork and concrete materials in direct contact with the sealants to a depth of $\frac{1}{4}$ ", verification samples of underlying concrete will be collected at a frequency of 1 sample per every 10 penetrations for a total of 10 samples. Verification sample locations will be randomly selected based on the total length of application at the selected penetration point with the lower left hand corner assigned zero and proceeding clockwise around the removal area. Results of the verification samples will be compared to the high occupancy cleanup standard of \leq 1 ppm as follows:

 Total PCBs > 1 ppm - Concrete materials formerly in direct contact with sealant to be encapsulated using two coats of a liquid epoxy coating (Sikagard 62, or equivalent product) following the procedures described



in Section 6 of the plan. Verification wipe samples to be collected of encapsulated surfaces at the same frequency as the bulk samples; and

• Total PCBs ≤ 1 ppm – No additional action, removal complete.

8.4.2 CMU Block

Verification samples of CMU block in the penthouses will be collected at a distance of six inches from the caulked joint. Samples are to be collected at a frequency of 1 sample per 10 penetrations for a total of four samples including the sample already collected. Results of the verification sampling will be compared to the high occupancy clean up standard as follows:

- Total PCBs > 1 ppm Additional verification sample collected at a greater distance from the sealant and the segregation location adjusted accordingly; and
- Total PCBs ≤ 1 ppm Waste segregation conducted as described above.

8.4.3 Ductwork

Verification wipe samples of metal ductwork will be collected as follows:

- Rooftop Penthouse Area No verification samples to be collected, all ductwork to be removed for disposal as ≥ 50 ppm waste due to the number and location of joints;
- Interior Spaces Overhead Areas Verification wipe samples will be collected from inside the mixing junction boxes at a frequency of 1 sample per 5 junction boxes (total of 10 wipe samples); and
- Basement Mechanical Spaces Verification wipe samples will be collected from ventilation system
 components and ductwork materials at a distance of six inches from the sealant at a frequency of
 approximately 1 sample per 100 l.f. of joints. This proposed sample frequency is based on the amount of
 sealant observed in currently accessible areas and may be modified based on amount of sealant identified
 when the full inventory is completed. Samples will be collected immediately past the cut line as follows:
 - The side of the joint will be alternated between the left and right;
 - The center point of the wipe will be randomly selected along the selected seam; and
 - At the selected location, the wipe will be collected in a 10 cm by 10 cm area immediately outside the cut line.

Results from the verification wipe samples will be compared to the high occupancy cleanup standard for non-porous materials as follows:

- ≥ 10 µg/100cm² Additional verification wipe sample to be collected further from the joint and the cut line extended to the next sample point in either direction that meets the level; and
- < 10 μg/100cm² No additional action.



9. WASTE STORAGE AND DISPOSAL

Caulking containing \geq 50 ppm PCBs, backing materials, window frames and components (including glass), and backing materials and other materials (brick, brownstone, ductwork, etc.) in direct contact with the caulking and removed to the specified cut-lines described in this plan will be managed as a single waste stream and designated as \geq 50 ppm PCB wastes. Building materials scheduled for removal and impacted by PCBs at a concentration > 1 ppm will be removed for disposal as either \geq 50 ppm PCB wastes or < 50 ppm PCB wastes as described in the previous sections. Polyethylene sheeting, PPE, and other disposable equipment and tools will be managed for disposal as < 50 ppm PCB wastes.

The following activities will be completed with regard to the proper storage and disposal of PCB wastes:

- Secure, lined, and covered waste containers (roll-off containers or equivalent), 55-gallon DOT-approved steel containers, or cubic yard boxes/totes will be staged for the collection of PCB wastes generated during the work activities in accordance with 40 CFR 761.65;
- Containers will be properly labeled and marked in accordance with 40 CFR 761.40;
- Upon completion of the work or when a container is considered full, PCB waste ≥ 50 ppm will be transported off-site under manifest, for disposal at a hazardous waste disposal facility (EQ Wayne Disposal Facility located in Belleville, Michigan, or equivalent);
- Upon completion of the work or when a container is considered full, PCB waste < 50 ppm will be transported
 off-site for disposal at a non-hazardous waste landfill permitted to accept such wastes (Waste
 Management's Turnkey Landfill located in Rochester, New Hampshire, or equivalent); and
- At the end of their use on the project, non-disposable tools and equipment will be decontaminated in accordance with 40 CFR 761.79. Decontamination fluids generated during the work will be collected/contained and managed/disposed in accordance with 40 CFR 761.79.

Copies of the waste shipment records, including manifests and certificates of disposal, will be collected and provided as part of the final report to EPA.



10. CONCEPTUAL MONITORING AND MAINTENANCE PLAN

As described in this plan, remediation activities to be completed will require implementation of a remedial approach under 40 CFR 761.61(c). This approach removes source materials and utilizes a physical barrier approach (liquid coating or sealant followed by new window frames in some locations) to eliminate the direct contact exposure pathway and migration pathways of PCBs remaining on the building. Upon completion of the remedial actions, the impacted building materials would not be accessible to direct exposure or migration to surrounding building materials.

Following implementation of this approach, a monitoring and maintenance plan (MMP) will be developed and implemented. The main components of the plan are as follows:

- Visual inspections Visual inspections of the coated/sealed surfaces will be conducted. The inspections will consist of an assessment of the following:
 - Signs of the underlying coating, or excessive pitting, peeling, or breakages in the coating;
 - Signs of weathering or disturbance of the replacement caulking (where applied); and
 - A general inspection of the joints.
 - Surface Wipe Sampling Surface wipe samples will be collected from the sealed surfaces at a frequency developed based on the final areas to be encapsulated. Wipe samples will be collected following the standard wipe test procedures described in 40 CFR 761.123 and/or an alternate proposed method;
 - Corrective Actions If results of the inspections indicate that damage has occurred to a component of the barrier system or if monitoring results exceed project-specific action levels (to be developed in the MMP), the needed repairs or corrective actions will be conducted;
 - Maintenance Guidelines and Procedures To prevent potential exposure to maintenance and facility
 personnel that may perform activities in the sealed areas, guidelines and procedures will be developed
 and implemented for any work being conducted in the respective areas. These guidelines and procedures
 will detail communications procedures, worker protection requirements, and worker training requirements
 to be conducted for maintenance or other activities in these areas; and
 - Reporting A report documenting the findings of the visual inspections and monitoring results will be prepared and submitted to EPA.

The details of the MMP will be developed following completion of the remedial activities described above. The results of the verification testing, baseline sampling, and inspections will be used to develop the details of the plan. The MMP will be provided to EPA under a separate submittal following the completion of the remedial activities.



11. SITE RESTORATION AND PROJECT SCHEDULE

Currently the majority of the building is vacant with the remaining staff and students to be relocated prior to work initiation. The overall project schedule calls for the hazardous materials abatement task to be completed as a first component of the project. In order to meet the overall project schedule, this abatement task, including PCB remediation, is scheduled to initiate in October 2012.

Following completion of the removal activities and verification that the cleanup levels have been met or the risk-based approach applied, the overall building renovation project will continue in accordance with the overall project specifications. The site controls will be dismantled and all wastes will be transported off-site for proper disposal.



12. COMMUNICATION AND DOCUMENTATION

Prior to initiation and periodically during the work activities, project-related communications with Yale University staff and contractors will be undertaken on an as needed basis. These communications may include schedule and access updates regarding disruption to particular areas or significant project updates. As indicated previously, the building will be vacant during the remediation work.

Following completion of the work activities, records and documents per 40 CFR Part 761 will be generated and maintained in the Yale University Environmental Health and Safety Department files. A final report documenting the completion of the work activities, verification analytical results, volumes of disposed materials, and waste disposal records will be prepared and submitted to EPA.

Table 2-1 Summary of Sealant Characterization Sampling Results

Material Type	Material Application	Material Description	Number of Samples	Sample Location	Sample ID	Sample Date	Total PCBs (ppm)		
North Side Main En	tryway				<u> </u>	<u> </u>			
Caulking	Exterior Door Frame to Masonry	1/2" light brown, soft, flexible.	1	Main entryway frame to brick joint	KCL3	1/7/2009	70,500 J		
Glazing	Interior Door Frame to Glass	1/8" light gray, soft, not flexible, brittle 1 Main entryway frame to glass joint		Main entryway frame to glass joint	KCL-CBK-032	3/29/2012	6,500		
Windows									
	Interior Window Frame to Glass	1/8" gray, medium soft, very flexible	1	Interior window, second floor, Room 233	KCL-CBK-014	3/29/2012	1,900		
Glazing				Exterior window, first floor, Room 114	10187 KCL ext	10/18/2010	2,680 J		
Glazing	Exterior Window Frame to Glass		Exterior Window Frame	1/8" white, soft, not flexible, brittle	3	Exterior window, first floor, Room 110	10186 KCL ext	10/18/2010	213,000 J
				Exterior window, first floor, Room 146	KCL-CBK-025	3/29/2012	3,060		
					Interior window, second floor, Room 256	KCL-CBK-001	3/29/2012	400,000	
	Interior Window Frame to	1/2" light brown, soft,	4	Interior window, first floor, Room 114	10181 KCL 114 int	10/18/2010	209,000 J		
	Masonry	flexible	4	Interior window, first floor, Room 110	10182 KCL 110 int	10/18/2010	274,000 J		
Caulking				Interior window, first floor, Room 110	10183 KCL 110 int	10/18/2010	227,000 J		
Cauking	Exterior Window Frame to	1/2" light brown, soft,	4	Exterior window, first floor, Room 133	KCL-CBK-018	3/29/2012	390,000		
	Masonry	flexible	7	Exterior window, first floor, Room 110	KCL1	1/7/2009	71,300 J		
	Exterior Window Frame to	tterior Window Frame to 1/2" light brown, soft,		Exterior window, first floor, Room 114	10184 KCL 114 ext	10/18/2010	294,000 J		
	Masonry		4	Exterior window, first floor, Room 110	10185 KCL 110 ext	10/18/2010	310,000 J		

Table 2-1 Summary of Sealant Characterization Sampling Results

Material Type	Material Application	Material Description	Number of Samples	Sample Location	Sample ID	Sample Date	Total PCBs (ppm)
Ventilation and Heat	ing Systems						
	Interior Metal Duct to Masonry		2	Ductwork in interior of rooftop penthouse	KCL-CBK-012	3/29/2012	67
			2	Ductwork in interior of roontop pentinouse	KCL-CBK-013	3/29/2012	75
		Red, medium hard,		Ductwork in interior of Room 254	KCL-CBK-017	3/29/2012	58.9 J
		slightly flexible	4	Ductwork in interior of Room 254	254-6-12	6/12/2012	203 J
				Ductwork in interior of Room 256	256-6-12	6/12/2012	560 J
Caulking/Sealant				Ductwork in interior of Room 137	137-6-12	6/12/2012	3,000 J
				Duetwork in cost side machanical room	KCL-CBK-036	6/26/2012	60
	Interior Metal to Metal Duct	Red, medium hard, slightly flexible	3	Ductwork in east side mechanical room	KCL-CBK-037	6/26/2012	61
				Ductwork in west side mechanical room	KCL-CBK-038	6/26/2012	31
	Exterior Rooftop Vent	1" gray, soft flexible,		Metal to roofing material, roof area near northwest corner of courtyard area elevation	KCL-CBK-007	3/29/2012	< 0.95
	Penetration	1/4" thick	2	Metal to roofing material, roof area near northeast corner of courtyard area elevation	KCL-CBK-008	3/29/2012	1.4

Table 2-1 Summary of Sealant Characterization Sampling Results

Kline Chemistry Laboratory Yale University

Material Type	Material Application	Material Description	Number of Samples	Sample Location	Sample ID	Sample Date	Total PCBs (ppm)			
Interior Control Join	nterior Control Joints									
Caulking	Basement CMU to CMU Control Joint	1/2" black, soft, flexible	1	CMU to CMU control joint in west side basement hall	KCL-CBK-039	6/26/2012	< 0.87			
Rooftop Penthouse										
	Exterior Door Frame to Masonry	1/2" gray, soft, flexible	1	Door to interior stairwell	KCL-CBK-004	3/29/2012	490,000			
Caulking	Exterior Masonry to Masonry	1/4" light brown, soft, flexible	1	Brownstone cap on edge of penthouse roof, near northeast corner of northern elevation	KCL-CBK-005	3/29/2012	67			
	Exterior Louver Frame to Masonry	1/2" light brown, soft, flexible	1	Louver on northwest corner of penthouse	KCL-CBK-006	3/29/2012	730			
Building Cap Joint										
Caulking	Exterior Masonry to	1/2" reddish brown,	2	Brownstone cap on roof's edge, northeast corner of courtyard area	KCL-CBK-003	3/29/2012	2 J			
Cauking	Caulking Masonry Soft, flexible		2	Brownstone cap on roof's edge, northwest corner of courtyard area	KCL-CBK-002	3/29/2012	33			

Notes:

All samples extracted by Soxhlet Method 3540C and analyzed for PCBs by USEPA Method 8082.

All PCBs reported as Aroclor 1248, 1254, and 1260. No other Aroclor reported above the minimum laboratory reporting limit.

J/UJ = Analytical results qualified based on results of external data validation. Additional information included in Appendix B.

Material Type	Sample Rationale	Number of Samples	Sample Location	Sample ID	Sample Date	Total PCBs (ppm)	
North Side Main Entryw	ay						
Exterior Brick Wall	Delineation of PCB extent	2	4" from east side of main entryway frame to brick joint	KCL-CBB-030	3/29/2012	< 0.43	
Exterior Blick Wall	Delineation of PGB extent	2	4" from west side of main entryway frame to brick joint	KCL-CBB-031	3/29/2012	< 0.48	
Exterior Brownstone Ceiling	Delineation of PCB extent	1	6" from main entryway frame to brownstone joint	KCL-CBR-033	3/29/2012	< 0.48	
Windows							
		2	CMU block 1" from frame to CMU joint	1116-1 KCL (Room 110)	10/16/2010	10.5 J	
			2	CIVIO BIOCK I HOITH Harife to CIVIO Joint	1116-2 KCL (Room 114)	10/16/2010	13.5 J
					KCL 2-1-1 (Room 110	2/1/2011	1.34 J
		2	CMU block 7" from frame to CMU joint -	KCL 2-1-3 (Room 114)	2/1/2011	1.56 J	
				KCL 2-1-2 (Room 110)	2/1/2011	0.893 J	
Interior CMLL Block Wall	Delineation of PCB extent			KCL 2-1-4 (Room 114)	2/1/2011	0.777 J	
Interior Civio Block Wall	Delineation of PCB extent		CMU block 10" from frame to CMU joint	KCL-CBC-015 (Room 233)	3/29/2012	3.8	
		4		KCL-CBC-016 (Room 156)	3/29/2012	2.2	
		4		KCL-VBC-048 (Room 156)	6/26/2012	1.46	
			CMU block immediately past window recess	KCL-VBC-049 (Room 233)	6/26/2012	4.12	
			(15 or 18" from frame to CMU joint)	KCL-VBC-050 (Room 133)	6/26/2012	1.50	
				KCL-VBC-051 (Room 243)	6/26/2012	4.42	

Material Type	Sample Rationale	Number of Samples	Sample Location	Sample ID	Sample Date	Total PCBs (ppm)
			CMU block past the window recess	KCL-VBC-202 (Room 243)	7/31/2012	0.38
	Evaluation of PCBs with Depth	4		KCL-VBC-203 (Room 233)	7/31/2012	0.54
	(0.5 to 1.0")	4	approximately 20 to 27" from frame to CMU joint)	KCL-VBC-204 (Room 156)	7/31/2012	0.34
				KCL-VBC-207 (Room 133)	7/31/2012	0.68
	Core Characterization Sample	n 2	Waste Characterization sample of concrete block	KCL-VBC-201	7/31/2012	1.3
				KCL-VBC-205	7/31/2012	0.74 J
Interior CMU Block Wall				KCL-CBC-200 (2nd floor hallway)	7/31/2012	0.7
				KCL-CBC-206 (1st floor hallway)	7/31/2012	0.89
				KCL-CBC-208 (1st floor hallway)	7/31/2012	0.71
	Confirmation of Source Material	8	CMU block in locations without existing known source mateirals (i.e., no caulking in vicinity of sample)	KCL-CBC-209 (Basement Hallway)	7/31/2012	0.15
			vicinity of sample)	KCL-CBC-210 (Basement Hallway)	7/31/2012	0.84
				KCL-CBC-211 (Room 19)	7/31/2012	0.36
				KCL-CBC-213 (Basement Hallway)	7/31/2012	0.95 J

Material Type	Sample Rationale	Number of Samples	Sample Location	Sample ID	Sample Date	Total PCBs (ppm)
				KCL-CBB-022 (Room 154)	3/29/2012	4.1
		3	1" from exterior frame to brick window joint	KCL-CBB-027 (Room 146)	3/29/2012	2.9
				1117-3 (Room 110)	10/17/2011	0.615 J
				KCL-CBB-021 (Room 154)	3/29/2012	0.11 J
Exterior Brick Wall	Delineation of PCB extent	3	3" from exterior frame to brick window joint	KCL-CBB-026 (Room 146)	3/29/2012	0.22
Exterior blick wall	Delineation of PCB extent			1117-4 KCL (Room 110)	10/17/2010	0.045 J
		2	3" from bottom horizontal edge of recessed window on face of the building, courtyard	KCL-CBB-020 (Room 125)	3/29/2012	0.64
		۷	area	KCL-VBB-053 (Room 133)	6/26/2012	< 0.091
		2	1/2" from vertical edge of recessed window	KCL-CBB-019 (Room 133)	3/29/2012	< 0.48
		2	on face of the building, courtyard area	KCL-VBB-052 (Room 129)	6/26/2012	< 0.091
				1117-2 KCL (Room 110)	10/17/2010	2.6 J
			1" from exterior frame to brownstone	KCL-CBR-024 (Room 160)	3/29/2012	8.2
		4	window joint	KCL-CBR-029 (Room 146)	3/29/2012	10
Exterior Brownstone Sill	Delineation of PCB extent			KCL-CBR-035 (Room 120)	3/29/2012	7.9
EXICITOR DIOWNSTONIC CITE	Connection of FOD GARCIII	1	3" from exterior frame to brownstone window joint	1117-1 KCL (Room 110)	10/17/2010	0.855 J
				KCL-CBR-023 (Room 160)	3/29/2012	0.63 J
		3	10" from exterior frame to brownstone window joint	KCL-CBR-028 (Room 146)	3/29/2012	0.23
				KCL-CBR-034 (Room 120)	3/29/2012	0.29

Kline Chemistry Laboratory **Yale University**

Material Type	Sample Rationale	Number of Samples	Sample Location	Sample ID	Sample Date	Total PCBs (ppm)			
Ventilation and Heating Systems									
			Concrete Following Removal of Sealant in Room 256	KCL-VBC-042	6/26/2012	4.5			
Concrete Wall	Pilot Test Removal Areas	3	Concrete Following Removal of Sealant in Room 254	KCL-VBC-043	6/26/2012	1.1			
			Concrete Following Removal of Sealant in Room 135	KCL-VBC-047	6/26/2012	0.75			
Rooftop Penthouse									
	Fortonian VA/all	1	4" from exterior door frame to brick joint, door to interior stairwell	KCL-CBB-011	3/29/2012	< 0.091			
Masonry	Exterior Wall	1	4" from louver frame to brick joint	KCL-VBB-040	6/26/2012	< 0.095			
	Interior Wall	1	6" below sealant to CMU joint (beginning of second row of block)	KCL-VBB-041	6/26/2012	< 0.087			
Penthouse Parapet Cap)								
Caulking	Exterior Masonry to	2	Brownstone cap on roof's edge, northeast corner of courtyard area	KCL-CBK-003	3/29/2012	2 J			
Cauking	Masonry	2	Brownstone cap on roof's edge, northwest corner of courtyard area	KCL-CBK-002	3/29/2012	33			

All samples extracted by Soxhlet Method 3540C and analyzed for PCBs by USEPA Method 8082.

All PCBs reported as Aroclor 1248, 1254, and 1260. No other Aroclor reported above the minimum laboratory reporting limit.

J/UJ = Analytical results qualified based on results of external data validation. Additional information included in Appendix B.

Kline Chemistry Laboratory Yale University

Planned Project Work Area	Renovation Project Scope	Materials	Characterization Results Summary	Remedial Approach	
WORK Area		Caulking (120 l.f.)	Caulking (70,500 ppm PCBs) present on exterior frame to masonry joints and brownstone to brownstone overhang ceiling masonry joints. No interior caulking present.	Caulking, backing material, glazing, frames and components (including glass) removed for disposal as ≥ 50 ppm PCB Wastes.	
	Scope of Work: Entire North Side Main	Glazing Sealants	Glazing sealants (6,500 ppm PCBs) present on interior frame to glass joints. No interior glazing sealant observed.		
North Side Main Entry	Entryway curtain wall windows and doors to be	Exterior Brick	Two samples of exterior brick collected at a distance of 4" from vertical caulked joint (1 sample per joint). Analytical results reported PCBs as non-detect in both	First half-row of brick (i.e., brick materials in direct contact with caulked joints and to a distance of 4") along vertical joints and the first row of brick above horizontal floor joints to be removed through a cut-line approach for disposal as ≥ 50 ppm PCB wastes. Verification samples to be collected at a frequency of 1 sample per 20 l.f. of caulked joint at a distance of 4" from the joint to verify total	
Litay		(20 l.f.)	samples (< 0.43 and < 0.48 ppm).	PCBs ≤ 1 ppm (No additional samples to be collected). Brick materials > 4" from the cut-line to be removed as required by the project specifications for off-site disposal as general demolition debris.	
		Exterior Brownstone Ceiling (100 l.f.)	One sample of exterior brownstone collected at a distance of 6" from the upper horizontal caulked joint. Analytical results reported PCBs as non-detect (< 0.48 ppm).	Based on number and configuration of caulked joints and total volume of brownstone materials (approximately 1.5 cubic yards), all brownstone materials to be removed for disposal as ≥ 50 ppm PCB wastes.	
		Caulking (160 l.f.)¹	Caulking present on exterior frame to masonry joints and brownstone to brownstone overhang ceiling masonry joints. Exterior caulking assumed to contain ≥ 50 ppm PCBs based on results from North Side Main Entry caulking. No interior caulking observed.	Caulking, backing material, glazing, window frames and components (including glass) removed for disposal as ≥ 50 ppm PCB Wastes.	
		Glazing Sealants	Glazing sealants (if present) assumed to contain ≥ 50 ppm PCBs based on results from North Side Main Entry glazing samples. No interior glazing observed.		
		Results of brick samples collected adjacent to North Side Main Entry door used		First half-row of brick (i.e., brick materials in direct contact with caulked joints and to a distance of 4") along vertical joints and the first row of brick above horizontal floor joints to be removed through a cut-line approach for disposal as ≥ 50 ppm PCB wastes.	
	Scope of Work:		Results of brick samples collected adjacent to North Side Main Entry door used to characterize extent of PCB impacts > 1 ppm for remediation planning (area not currently accessible).	Verification samples to be collected at a frequency of 1 sample per 20 l.f. of caulked joint at a distance of 4" from the joint along vijoints (1 sample) and from the second row of brick above floor joints (1 sample) to verify total PCBs ≤ 1 ppm.	
Second Floor Curtain Wall	Entire curtain wall windows to be removed. Opening to be filled in with brick and			Brick materials beyond the cut-line to be removed as required by the project specifications for off-site disposal as general demolition debris.	
Window	windows to match surrounding building.	Exterior Brownstone Ceiling (100 l.f.)	Results of brownstone samples collected adjacent to North Side Main Entry door used to characterize extent of PCB impacts > 1 ppm for remediation planning (area not currently accessible).	Based on number and configuration of caulked joints and total volume of brownstone materials (approximately 1.5 cubic yards), all brownstone materials to be removed for disposal as ≥ 50 ppm PCB wastes.	
				Terrazzo flooring in direct contact with caulked joint and to a distance of 8" from the caulked joint to be removed through a cut-line approach for disposal as ≥ 50 ppm PCB wastes.	
		Exterior Terrazzo Flooring (40 l.f.)	Caulking assumed to contain ≥ 50 ppm PCBs based on caulking surrounding North Side Main Entry door. No characterization data available due to area not currently accessible.	Verification samples to be collected at a frequency of 1 sample per 20 l.f. of caulked joint at a distance of 8" from the caulked joints to verify total PCBs ≤ 1 ppm (2 samples).	
				Terrazzo flooring beyond the cut-line to be removed as required by the project specification for off-site disposal as general demolition debris.	

Note (1) Linear footage of caulking does not include 20 l.f. of a common joint between the brick walls and terrazzo flooring included in the linear footages below.

Planned Project Work Area	Renovation Project Scope	Materials	Characterization Results Summary	Conceptual Remedial Approach
		Caulking (1,512 l.f.)	Caulking present on interior vertical window frame to masonry joints (approximately 18 l.f. per window) with reported PCB concentrations ranging from 209,000 to 400,000 ppm.	Caulking, backing material, glazing sealant, window frames and components (including glass) removed for disposal as ≥ 50 ppm PCB Waste to a hazardous waste disposal facility.
Interior Portions of Windows (84 windows)	Scope of Work: Windows to be removed and replaced. Interior building materials adjacent to the windows to be completely removed as part of interior.	Glazing Sealants	Glazing sealants present on interior frame to glass joints with a reported PCB concentration of 1,900 ppm.	
	renovations.	Samples of CMU block were collected at distances up to 18 inches from caulked joints. Analytical results indicated that PCBs were reported in samples at concentrations ranging from 0.777 to 14 ppm. Block Walls (1,512 l.f.) Based on analytical results, additional samples of CMU block were collected at areas away from identified source materials (i.e., caulking). Analytical results indicated that PCBs were < 1 ppm.		 CMU block materials to be segregated for disposal as follows: First row of CMU block materials (i.e., the row in direct contact with caulked joints) to be removed and segregated for disposal as ≥ 50 ppm PCB wastes at a hazardous waste disposal facility; CMU block materials beyond the first row and to a point beyond the presence of additional source materials (see Section 6 for discussion) to be removed through cut-line approach for disposal as < 50 ppm PCB wastes to a non-hazardous waste disposal landfill. Verification samples collected immediately beyond the extent of proposed removal to confirm total PCBs ≤ 1 ppm. CMU block materials beyond the cut-line to be removed for off-site disposal as general demolition debris.
Exterior Portions of Windows	Scope of Work: Windows to be removed and replaced. Exterior brick and brownstone to remain in place except in south	Caulking (2,100 l.f.)	Caulking present on all exterior frame to masonry joints (approximately 25 l.f. per window) with reported PCB concentrations ranging from 71,300 to 390,000 ppm.	
(84 windows)	courtyard within limits of proposed curtain wall window system, where the entire façade is to be removed in this area.	brownstone to remain in place except in south courtyard within limits of proposed curtain wall window system, where the entire façade is to be removed in		Caulking, backing material, glazing sealants, window frames and components (including glass) removed for disposal as ≥ 50 ppm PCB Waste to a hazardous waste disposal facility.

Planned Project Work Area	Renovation Project Scope	Materials	Characterization Results Summary	Conceptual Remedial Approach
Exterior Portions of Windows (con't)	Scope of Work (con't): Windows to be removed and replaced. Exterior brick and brownstone to remain in place except in south courtyard within limits of	Brick – To be Removed (36 windows)	Brick materials are present along the vertical and horizontal frame to masonry joints of 36 of the courtyard area windows to be removed (approximately 25 l.f. per window) Samples of brick collected at a distance of 1/2" from the vertical edge of the window recess and at a distance of 3" below the lower horizontal edge of the window recess (i.e., all samples collected outside the window recess on the face of the building). Analytical results indicated that PCBs were non-detect (< 0.48 and < 0.091 ppm) along the vertical joints and non-detect (< 0.091 ppm) and present at a concentration of 0.64 ppm along the horizontal joints.	Brick materials surrounding windows in the southern courtyard area (36 windows) to be removed for off-site disposal for installation of new curtain wall system. Brick materials in direct contact with caulked joints, within the window recess, and to a distance of 6" from the caulked joints (first row of horizontal bricks above and below the windows) and a distance of 4" away from vertical joints (i.e., first half-row of brick away from the recess) to be removed through a cut-line approach for disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility. Verification samples to be collected at a sample frequency of 1 sample per 50 l.f. to verify total PCBs < 1 ppm (18 samples). Verification samples will be evenly divided between materials below the recess and materials adjacent to the vertical joints. Along each joint, the specific location of each sample will be selected using a random number generator based on the total length of the caulked joint. Samples to be collected as follows: • Away from Vertical Joints – samples to be collected immediately past the first half-row of brick outside the window recess; and • Below Lower Horizontal Joints – samples to be collected from the beginning of the second row of brick below the window recess (no samples proposed to be collected above the windows based on assumed worse-case migration of PCBs to materials below the windows). Brick materials beyond the cut-line (i.e., ≤ 1 ppm) to be removed for off-site disposal as general demolition debris.
	proposed curtain wall window system, where the entire façade is to be removed in this area.	Brick – To remain in Place (48 windows)	Brick materials are present along the vertical frame to masonry joints of the windows (approximately 19 l.f. per window). Samples of brick collected at distances of 1" and 3" from the caulked joint. Reported PCB concentrations of 0.615, 2.9, and 4.1 ppm at a distance of 1" from the caulked joint and < 1 ppm (0.045, 0.11, and 0.22 ppm) at a distance of 3" from the caulked joint.	High Occupancy Clean Up Standard of 1 ppm to be applied to first floor locations (24 windows). Low Occupancy Clean Up Standard of 25 ppm to be applied to all second floor locations (24 windows). Pre-application delineation bulk sampling to be conducted at a sample frequency of 1 sample per 100 l.f. of caulking next to brick to determine the extent of the coating/sealant application (10 samples). Following caulking and window removal, liquid coating/sealant to be applied to materials as follows (based on pre-application sampling): • All Locations – Brick materials formerly in direct contact with PCB-containing caulking and away from the caulking that will be covered by the replacement window frames to be encapsulated with two coats of Sikagard 62 epoxy; • High Occupancy Locations – Brick materials away from the caulked joint beyond the extent of the replacement window frames and to the end of the window recess (approximately 4") to be encapsulated with two coats of a liquid coating/sealant (to be selected by the project team). • Low Occupancy Locations – None assumed at this time; to be confirmed by additional samples. Following application of liquid coating/sealant, verification wipe samples to be collected from encapsulated brick materials both formerly in direct contact with and away from the caulked joints at a sample frequency of 1 sample per 100 l.f. Wipe samples to be collected from epoxy coated materials (10 samples) and from clear coated materials (5 samples). Results of verification sampling to be compared to encapsulation standard as follows: • ≥ 1 μg/100cm² – Additional liquid coating/sealant may be applied, verification samples recollected; • < 1 μg/100cm² – No Further Action
		Brownstone Sills (48 windows)	Brownstone materials are present along upper and lower horizontal frame to masonry joints (approximately 5.5 l.f. per window). Samples of brownstone collected at distances of 1", 3", and 10" from the caulked joint. Reported PCB concentrations as follows: 1" (4 samples) – total PCB concentrations of 2.6, 7.9, 8.2, and 10 ppm; 3" (1 sample) – total PCB concentration of 0.855 ppm; and 10" (3 samples) – total PCB concentrations of 0.23, 0.29, and 0.63 ppm.	High Occupancy Clean Up Standard of 1 ppm to be applied to first floor locations (24 windows). Low Occupancy Clean Up Standard of 25 ppm to be applied to all other locations (24 windows). Pre-application delineation bulk sampling to be conducted at a sample frequency of 1 sample per 50 l.f. of caulking next to brownstone to determine the extent of coating/sealant application (6 samples). Following caulking and window removal, liquid coating/sealant to be applied to materials as follows: All Locations - Brownstone materials formerly in direct contact with PCB-containing caulking and materials away from the caulking that will be covered by the replacement window frames to be encapsulated with two coats of Sikagard 62 epoxy; High Occupancy Areas - Brownstone materials across the entire upper horizontal face of the window sill and lower horizontal face

Planned Project Work Area	Renovation Project Scope	Materials	Characterization Results Summary	Conceptual Remedial Approach
Exterior Portions of Windows (con't)	Scope of Work (con't): Windows to be removed and replaced. Exterior brick and brownstone to remain in place except in south courtyard within limits of proposed curtain wall window system, where the entire façade is to be removed in this area.	Brownstone Sills (48 windows) (cont'd)		 of the window header beyond the extent of the replacement window frames to be encapsulated with two coats of a liquid coating/sealant (to be selected by the project team). Low Occupancy Locations – None assumed at this time; to be confirmed by additional samples. Following application of liquid coating/sealant, verification wipe samples to be collected from encapsulated brownstone materials both formerly in direct contact with and away from the caulked joints at a sample frequency of 1 sample per 50 l.f. Wipe samples to be collected from epoxy coated materials (6 samples) and from clear coated materials (3 samples). Results of verification sampling to be compared to encapsulation standard as follows: ≥ 1 µg/100cm² - Additional liquid coating/sealant may be applied, verification samples recollected; < 1 µg/100cm² - No Further Action.
		Caulking (50 l.f doors) (144 l.f. – louvers)	Caulking present on exterior frame to brick joints on all three doors and 16 louvers (approximately 9 l.f. per louver). Door caulking with a reported PCB concentration of 490,000 ppm and ventilation louver caulking with a reported PCB concentration of 730 ppm.	Caulking, backing material, and door and louver frames and components removed for disposal as ≥ 50 ppm PCB Wastes to a hazardous waste disposal facility.
Roof Top Doors (3 doors) and Ventilation Louvers (16 Louvers)	Scope of Work: Penthouse doors and ventilation louvers to be removed as part of roof top penthouse demolition and removal.	Brick	Two samples of brick collected at a distance of 4" from the caulked joint (beginning of second full row of brick, immediately past first half-row of brick). PCBs reported as non-detect (≤ 0.091 and < 0.095 ppm).	Brick materials in direct contact with caulked joints and to a distance of 4" from the vertical caulked joints and the first row of bricks above and below the horizontal joints to be removed through a cut-line approach for disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility. Verification samples to be collected at a frequency of 1 sample per door (3 samples) and 1 sample per 4 louvers (4 samples) to be collected 4" from the joint to verify total PCBs ≤ 1 ppm. Brick materials beyond the cut-line to be removed as required by the project specifications for off-site disposal as general demolition debris.
		Metal Flashing	No samples collected to date.	Metal flashing in direct contact (i.e., at the base of each vertical frame to brick joint) and to a minimum distance of 6" from the caulked joint to be removed for disposal as ≥ 50 ppm PCB Wastes to a hazardous waste disposal facility. Wipe samples to be collected at a distance of 6" from the base of the vertical joint for every 4 th louver (total of 4 samples) to verify PCBs ≤ 10 μg/100cm². Results of verification sampling to be compared to non-porous decontamination standard as follows: > 10 μg/100cm² – Additional flashing to be removed, verification samples recollected at a further distance from the joint. ≤ 10 μg/100cm² – No Further Action
Penthouse Parapet Cap	Scope of Work: Penthouse parapet cap to be removed as part of roof top penthouse demolition and removal.	Caulking (265 l.f.)	Caulking present on brownstone cap to metal flashing joints along the top of penthouse cap (220 l.f.) and on brownstone to brownstone cap joints oriented laterally across the penthouse cap (55, 10-inch joints located every 4 feet along the cap). One sample of penthouse cap joint caulking collected with a reported PCB concentration of 67 ppm.	Caulking, backing material, and metal flashing removed for disposal as ≥ 50 ppm PCB Wastes to a hazardous waste disposal facility.

Planned Project Work Area	Renovation Project Scope	Materials	Characterization Results Summary	Conceptual Remedial Approach
Penthouse	apet Cap removed as part of roof top	Brownstone Cap	Samples of cap materials not collected. Assume impacts to brownstone cap based on results of brownstone sill samples.	All brownstone cap materials removed for off-site disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility.
Parapet Cap (con't)		Brick	Samples of brick not collected.	Brick in direct contact with lateral joints (immediately below the joint) to be removed for off-site disposal as ≥ 50 ppm PCB waste to a hazardous waste disposal facility. Verification samples to be collected at a frequency of 1 sample per 10 joints at the beginning of the second row of brick below the joint to verify total PCBs ≤ 1 ppm (total of 6 samples). Remaining brick materials to be removed as required by the project specifications for off-site disposal as general demolition debris.
		Ductwork Sealant	Ductwork sealant identified on metal to metal and metal to masonry joints in the penthouse mechanical rooms and on metal to masonry joints in select areas of the building, reported PCB concentrations ranging from of 58.9 to 3,000 ppm.	Ductwork sealant removed for off-site disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility.
		Metal Ductwork	Three wipe samples collected from metal ductwork within the variable flow control boxes immediately past the sealant. PCBs reported as non-detect (2 samples at < 0.20 µg/100cm²) and at a concentration of 0.34 µg/100cm².	Ductwork to be removed through waste segregation approach as described in Section 8.3 for disposal as either ≥ 50 ppm PCB wastes or general demolition debris. Verification wipe samples to be collected to confirm waste segregation approach per specific location. Results of verification wipe samples to be compared to the high occupancy non-porous clean up standard as follows: • > 10 μg/100cm² – Additional samples collected to determine extent of PCBs > 10 μg/100cm². Cut-line modified based on results; and • ≤ 10 μg/100cm² –No further action. Remaining ductwork materials to be removed for disposal as required by the project specifications as general demolition debris.
Ductwork	Ductwork Scope of Work: Ductwork to be removed as part of roof top penthouse demolition.	Concrete	No samples collected.	Removal of concrete materials in direct contact with sealant to a depth of ¼ through physical methods (e.g. chipping). Removed concrete materials to be disposed of as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility. Following removal, verification samples of underlying concrete to be collected at a frequency of 1 sample per 10 penetrations. Results of verification sampling to be compared to the high occupancy use clean up criteria as follows: > 1 ppm – Concrete formerly in direct contact with sealant to be encapsulated with two coats of liquid epoxy coating, follow-up verification wipe samples to be collected at the same sample frequency; and ≤ 1 ppm – No further action.
		CMU Block Walls	One sample collected at a distance of 6" from the sealant. Total PCBs reported as non-detect (< 0.087 ppm).	CMU block materials formerly in direct contact with and to a distance of 6" from the sealant to be removed for disposal as ≥ 50 ppm PCB wastes to a hazardous waste disposal facility. Verification samples to be collected at a frequency of 1 sample per 10 penetrations to verify waste segregation. Sample location selected using a random number generator based on the total perimeter of the ductwork at the selected penetration with the lower left hand comer representing zero and progressing clockwise around the ductwork. CMU block materials beyond the cut-line to be removed for disposal as general demolition debris.

Table 3-2 Verification Sampling Summary

Materials	Associated Joint	Verification Sampling Plan	Verification Sample Frequency	Number of Samples	Notes					
	North Side Main Entryway									
Brick	Vertical Frame to Brick Joints (20 l.f.)	Samples collected at a distance of 4" from the joint (i.e., immediately past the first half-row of brick).	1 sample per 20 l.f.	2	Samples collected previously. No additional samples to be collected					
		North Side Second Floor Curtain V	Vall Window							
Brick	Vertical Frame to Brick Joints (20 l.f.)	Samples collected at a distance of 4" from the joint (i.e., immediately past the first half-row of brick).	1 sample per 20 l.f.	1						
DIICK	Horizontal Brick to Terrazzo Floor Joints (20 I.f.)	Samples collected from the beginning of the second row of horizontal brick above the caulked joints.	1 sample per 20 l.f.	1						
Terrazzo Floor	Horizontal Frame to Terrazzo Flooring (20 l.f.)	Samples to be collected at a distance of 8" from the caulked joint.	1 sample per 20 l.f.	1						
Horizontal Brick to Terrazzo Floor Joints (20 l.f.)		Samples to be collected a at a distance of 8" from the caulked joints.	1 sample per 20 l.f.	1						
		Windows								
Interior CMU Block	Interior Vertical Frame to CMU Block	Samples to be collected from materials beyond the extent of additional source materials, typically at a clean "break point" such as 90-degree wall angle or door opening.	1 sample per 50 l.f.	9	Approximate wall height of 9 ft. at each of the 46 identified "breakpoints"					
Exterior Brick To Be Removed	Frame to Brick Joints (36 windows)	Samples to be collected immediately past the first half- row of brick along vertical joints and from the second row of brick below the lower horizontal joints.	1 sample per 50 l.f.	18	Approximately 25 l.f. of caulking per window; 4 of the 18 samples collected previously					
Exterior Brick To	High Occupancy Area Frame to Brick Joints (24 windows)	Samples to be collected at end of window recess.	1 sample per 100 l.f.	5	Approximately 19 l.f. of caulking next to brick per window; 3 of the 5 samples collected previously					
Remain In Place	Low Occupancy Area Frame to Brick Joints (24 Windows)	Samples to be collected at a distance of 1" from the former caulked joint.	1 sample per 100 l.f.	5	Approximately 19 l.f. of caulking next to brick per window					
Brownstone	High Occupancy Area Frame to Brownstone Joints (24 windows)	Samples to be collected at a distance of 10" from the caulked joints.	1 sample per 50 l.f.	3	Approximately 6 l.f. of caulking next to brownstone per window; Samples collected previously					
DIOWIISIONE	Low Occupancy Area Frame to Brownstone Joints (24 windows)	Samples to be collected at a distance of 1" from the caulked joints.	1 sample per 50 l.f.	3	Approximately 6 l.f. of caulking next to brownstone per window					

Table 3-2 Verification Sampling Summary

Kline Chemistry Laboratory Yale University

Materials	Associated Joint	Verification Sampling Plan	Verification Sample Frequency	Number of Samples	Notes
	Exterior Brick Formerly in Direct Contact Verification wipe samples to be collected from epoxy coated brick.		1 sample per 100 l.f.	10	
Verification Wipe	Exterior Brick Away from the Joint (High Occupancy Areas)	Verification wipe samples to be collected from clear- coated brick materials.	1 sample per 100 l.f.	5	
Samples	Exterior Brownstone Formerly in Direct Contact	Verification wipe samples to be collected from epoxy coated brownstone.	1 sample per 50 l.f.	6	
	Exterior Brownstone Away from the Joint (High Occupancy Areas)	Verification wipe samples to be collected from clear- coated brownstone materials.	1 sample per 50 l.f.	3	
		Rooftop Penthouse			
	Door Frame to Brick Joints (3 doors; 50 l.f.)	Samples to be collected immediately past the first half- row of bricks away from vertical caulked joint (i.e., approximately 4" from the caulked joint).	1 sample per door.	3	1 of the 3 samples collected previously
Brick	Louver Frame to Brick Joints (16 louvers; 144 l.f.)	Samples to be collected immediately past the first half- row of brick along vertical joints (i.e., approximately 4" from the caulked joint).	1 sample per 50 l.f.	3	1 of the 3 samples collected previously
	Parapet Brownstone to Brownstone Lateral Joints	Samples to be collected at the beginning of the second row of brick immediately below the joint.	1 sample per 10 joints	6	
Metal Flashing	Louver Frame to Metal Flashing (16 louvers)	Wipe samples to be collected at a distance of 6" from the base of the vertical joint.	1 sample per 50 l.f.	3	
		Ventilation System Components a	nd Ductwork		
Concrete	Metal to Concrete Joints	Verification samples to be collected from materials formerly in direct contact with the sealant following sealant and concrete removal to a depth of 1/4".	1 sample per 10 wall penetrations.	10	92 wall penetrations
CMU Block	Metal to CMU Joints in Penthouses	Verification samples to be collected at a distance of 6" from the red sealant.	1 sample per 10 wall penetrations.	4	36 wall penetrations; 1 of the 4 samples collected previously.
Metal Ductwork	Metal to Metal and Metal to Concrete Joints - Interior Overhead Spaces	Verification wipe sample to be collected from junction boxes.	1 sample to be collected per 5 junction boxes.	10	46 mixing junction boxes; 3 of the 10 samples collected previously.
Wetai Ductwork	Metal to Metal Joints - Basement Mechanical Spaces	Verification wipe samples to be collected at a distance of 6" from the joints (i.e., immediately past the selected cut-line).	1 sample per 100 l.f. of joint.	T.B.D.	

Notes:

L.F. = Linear Feet

T.B.D. = To Be Determined All samples extracted by Soxhlet Method 3540C and analyzed for PCBs by USEPA Method 8082.

Table 8-1 Summary of Pilot Test Wipe Sample Results

Kline Chemistry Laboratory Yale University


Pilot Test Area	Verification Concrete Sample ID		Verification Wipe Sample ID	Total PCBs (μg/100cm²)
Room 135	KCL-VBC-047	0.75	KCL-VWP-046	< 0.20
Room 254	KCL-VBC-043	1.1	KCL-VWP-044	0.34
Room 256	KCL-VBC-042	6.5	KCL-VWP-045	< 0.20


Notes:


Verification concrete samples collected following removal of all visible sealant from structural concrete materials. Samples collected from 0 to 0.5 inches.


Veriification wipe samples collected from metal materials within the duct immediately past the last location where sealant was observed.


All samples extracted by Soxhlet Method 3540C and analyzed for PCBs by USEPA Method 8082.



















APPENDIX A: WRITTEN CERTIFICATION



Certification

<u>Project</u> – Kline Chemistry Laboratory Renovations 255 Prospect Street – New Haven, CT Yale University

The undersigned owner of the property where the cleanup site is located and the party conducting the cleanup certify that all sampling plans, sampling collection procedures, sample preparation procedures, extraction procedures and instrumental/chemical analysis procedures used to assess or characterize the PCB contamination at the cleanup site, are on file at the location indicated below and are available for EPA inspection, as set forth below.

Document Location

Title

Yale EHS Office 135 College Street, Suite 100 New Haven, CT 06510

Property Owner and Party Conducting the Cleanup

Date <u>August 22, 2012</u>
<u> </u>



APPENDIX B: ANALYTICAL LABORATORY REPORTS AND DATA VALIDATION SUMMARY

YALE KLINE KCL - PROJECT SUMMARY

Con-Test Analytical Laboratory Job Numbers: 12C0993 & 12C0994

A modified Tier II validation was performed on the data. The criteria detailed below were used to qualify the data. Raw data were not used to verify the results reported by the laboratory.

Samples were received at 4.2 degrees Celsius. No qualifications will be applied.

PCBs:

All polychlorinated biphenyl compound (PCB) samples were extracted and analyzed within technical holding times. No qualifications will be applied.

All PCB surrogates met acceptance criteria or were diluted out. No qualifications will be applied.

The PCB method blanks were non-detect (ND) for all target analytes. No qualifications will be applied.

PCB field blank sample KCL-CBBQ-042 (12C0993-32) was ND for all target analytes. No qualifications will be applied.

The PCB matrix spike/matrix spike duplicate (MS/MSD) performed on samples KCL-CBC-015 (12C0993-12) and KCL-CBB-036 (12C0994-01) met recovery (40%-140%) and relative percent difference (RPD) (≤50%) acceptance criteria with the following exceptions:

LAB ID	SAMPLE ID	PCB-1016 (%) MS/MS/MSD/MSD	PCB-1260 (%) MS/MS/MSD/MSD	QUALIFIER
12C0993-12	KCL-CBC-015	260/602/324/569	620/611/577/567	None, Aroclor-1254
			•	interference

*RPD on column 1 was 55.6%

The PCB laboratory control samples (LCS)/laboratory control sample duplicate (LCSD) met acceptance criteria. No qualifications will be applied.

PCB field duplicate samples KCL-CBK-001 (12C0993-01)/KCL-CBKD-040 (12C0993-30) and KCL-CBB-022 (12C0993-18)/KCL-CBBD-041 (12C0993-31) met acceptance criteria. No qualifications will be applied.

The RPD between the column results for all detected PCBs met acceptance criteria (\(\leq 25\% \right) with the following exceptions:

- LAB ID	SAMPLE ID	PCB	RPD	QUALIFIER
12C0993-03	KCL-CBK-003	1254	27.9	J
12C0993-14	KCL-CBK-017	1248	29.5	J
12C0994-03	KCL-CBB-021	1254	27.6	J
12C0994-05	KCL-CBR-023	1254	25.9	J

Due to continuing calibration non-conformance on the confirmatory detector, the lower of two results was reported for PCB-1254 in samples and KCL-CBBD-041 (12C0993-31).

Many samples were analyzed at a dilution due to the high concentration of PCB-1254. Reporting limits are elevated in these samples as a result of the dilutions performed.

Data Check, Inc. P.O. Box 29 81 Meaderboro Road New Durham, NH 03855

Gloria J. Switalski:

President

Date: 6/2/2012

Page 1 of 1

YALE KLINE CHEMISTRY - PROJECT SUMMARY

Con-Test Analytical Laboratory Job Numbers: 12F0342, 09800337, & 09800339 Analytics Environmental Laboratory Job Numbers: 68098, 68444, & 68983

A modified Tier II validation was performed on the data. The criteria detailed below were used to qualify the data. Raw data were not used to verify the results reported by the laboratory.

Samples were received at 8.2, 9.9, 11.1, and 19.3 degrees Celsius and at "ambient" temperature. All results in all samples will be qualified as estimated (J/UJ) since they were received at the laboratory above 6 degrees Celsius.

PCBs:

All polychlorinated biphenyl compound (PCB) samples were extracted and analyzed within technical holding times. No qualifications will be applied.

All PCB surrogates met acceptance criteria or were diluted out. No qualifications will be applied.

The PCB method blanks were non-detect (ND) for all target analytes with one exception. PCB-1254 (197 μ g/kg) was detected above the reporting limit in the method blank associated with analytical package 68098. Since the sample concentrations in all associated samples were greater than the blank action concentration, no qualifications will be applied to the data.

No PCB field blank samples were submitted with these analytical packages. No qualifications will be applied.

No PCB matrix spike/matrix spike duplicate (MS/MSD) was performed on a sample from these analytical packages. No qualifications will be applied.

The PCB laboratory control samples (LCS)/laboratory control sample duplicate (LCSD) met acceptance criteria. No qualifications will be applied.

No PCB field duplicate samples were submitted with these analytical packages. No qualifications will be applied.

The relative percent difference (RPD) between the column results for all detected PCBs in all Analytics Environmental Laboratory analytical packages met acceptance criteria. No qualifications will be applied. The RPD between the column results for detected PCBs in all ConTest Analytical Laboratory analytical packages were not available. No qualifications will be applied.

Many samples were analyzed at a dilution due to the sample matrix and/or due to the high concentration of PCBs present. Elevated quantitation limits are reported in these samples as a result of the dilutions performed.

Data Check, Inc. P.O. Box 29 81 Meaderboro Road New Durham, NH 03855

Gloria J. Switalski: President

6

Date: 6/20/2012

Page 1 of 1

YALE KLINE CHEMISTRY - PROJECT SUMMARY

Con-Test Analytical Laboratory Job Number: 12F0964

A modified Tier II validation was performed on the data. The criteria detailed below were used to qualify the data. Raw data were not used to verify the results reported by the laboratory.

Samples were received at 3.3 degrees Celsius. No qualifications will be applied.

PCBs:

All polychlorinated biphenyl compound (PCB) samples were extracted and analyzed within technical holding times. No qualifications will be applied.

All PCB surrogates met acceptance criteria or were diluted out. No qualifications will be applied.

The PCB method blanks were non-detect (ND) for all target analytes with one exception. PCB-1254 (0.87 mg/kg) was detected above the reporting limit in the method blank associated with samples KCL-CBK-036 (12F0964-01), KCL-CBK-037 (12F0964-02), and CKL-CBK-038 (12F0964-03). Since the sample concentrations in the associated samples were greater than the blank action concentration, no qualifications will be applied to the data.

The PCB field blank sample, KCL-VBBQ-055 (12F0964-20), was ND for all target analytes. No qualifications will be applied.

No PCB matrix spike/matrix spike duplicate (MS/MSD) was performed on a sample from this analytical package. No qualifications will be applied.

The PCB laboratory control samples (LCS)/laboratory control sample duplicates (LCSD) met acceptance criteria. No qualifications will be applied.

PCB field duplicate samples KCL-VBB-053 (12F0964-18)/KCL-VBBD-054 (12F0964-19) met acceptance criteria. No qualifications will be applied.

The relative percent difference (RPD) between the column results for all detected PCBs met acceptance criteria ($\leq 25\%$) with the following exceptions:

LAB ID	SAMPLE ID	PCB_	RPD	QUALIFIER
12F0964-12	KCL-VBC-047	1254	38.5	J
12F0964-15	KCL-VBC-050	1254	34.6	J

According to the case narrative, for Aroclor 1254 in sample KCL-VBC-043 (12F0964-08); "Sample contains two incompletely resolved Aroclors. Aroclor with the closet matching pattern is reported." No qualifications will be applied.

Many samples were analyzed at a dilution due to the sample matrix and/or due to the high concentration of PCBs present. Elevated reporting limits are reported in these samples as a result of the dilutions performed.

Data Check, Inc. P.O. Box 29 81 Meaderboro Road New Durham, NH 03855

Gloria J. Switalski: President

Date:

7/10/2012

Page 1 of 1

YALE KLINE CHEMISTRY - PROJECT SUMMARY

Con-Test Analytical Laboratory Job Number: 12H0008

A modified Tier II validation was performed on the data. The criteria detailed below were used to qualify the data. Raw data were not used to verify the results reported by the laboratory.

Samples were received at 5.5 degrees Celsius. No qualifications will be applied.

PCBs:

All polychlorinated biphenyl compound (PCB) samples were extracted and analyzed within technical holding times. No qualifications will be applied.

All PCB surrogates met acceptance criteria. No qualifications will be applied.

The PCB method blanks were non-detect (ND) for all target analytes. No qualifications will be applied to the data.

The PCB field blank sample, KCL-FB-7.31.12 (12H0008-16), was ND for all target analytes. No qualifications will be applied.

No PCB matrix spike/matrix spike duplicate (MS/MSD) was performed on a sample from this analytical package. No qualifications will be applied.

The PCB laboratory control samples (LCS)/laboratory control sample duplicates (LCSD) met acceptance criteria. No qualifications will be applied.

PCB field duplicate samples KCL-CBC-213 (12H0008-14)/KCL-CBC-214 (12H0008-15) met acceptance criteria. No qualifications will be applied.

The relative percent difference (RPD) between the column results for all detected PCBs met acceptance criteria ($\leq 25\%$) with the following exceptions:

LAB ID	SAMPLE ID	РСВ	RPD	QUALIFIER
12H0008-06	KCL-VBC-205	1260	25.3	J
12H0008-14	KCL-CBC-213	1254	59.6	J
12H0008-15	KCL-CBC-214	1254	36.1	J

According to the case narrative, for Aroclor 1260 in sample KCL-CBC-210 (12H0008-11); "Sample contains two incompletely resolved Aroclors. Aroclor with the closet matching pattern is reported." No qualifications will be applied.

One sample was analyzed at a 2-fold dilution due to the sample matrix and/or due to the high concentration of PCBs present. Elevated reporting limits are reported in this sample as a result of the dilution performed.

Data Check, Inc. P.O. Box 29 81 Meaderboro Road New Durham, NH 03855

Gloria J. Switalski: President Date: 08/14/2012

Page 1 of 1



39 Spruce Street " East Longmeadow, MA 01028 " FAX 413/525-6405 " TEL. 413/525-2332

REPORT DATE 1/13/2009

YALE UNIVERSITY 135 COLLEGE STREET NEW HAVEN, CT 06510 ATTN: STEVEN MURDZIA

CONTRACT NUMBER: PURCHASE ORDER NUMBER:

PROJECT NUMBER:

ANALYTICAL SUMMARY

LIMS BAT #:

LIMT-22476

JOB NUMBER: -

PROJECT LOCATION: KCL

FIELD SAMPLE #	LAB ID	MATRIX	SAMPLE DESCRIPTION	TEST	Subcontract Lab (if any) Cert. Nos.
KCL1	09800337	SOLID	Ext. Window Caulk	8082 solid	
KCL3	09800339	SOLID	Ext. Entry Caulk	8082 solid	18
	100	-		The same of	

The results of analyses performed are based on samples as submitted to the laboratory and relate only to the items collected and tested. The CON-TEST Environmental Laboratory operates under the following certifications and accreditations. AIHA accreditations only apply to NIOSH methods and Environmental Lead Analyses.

AIHA 100033

MASSACHUSETTS MA0100

CONNECTICUT PH-0567 NEW YORK ELAP/NELAP 10899 AIHA ELLAP (LEAD) 100033

NEW HAMPSHIRE NELAP 2516 VERMONT DOH (LEAD) No. LL015036

RHODE ISLAND (LIC, No. 112)

NORTH CAROLINA CERT. #652

NEW JERSEY NELAP NJ MA007 (AIR)

FLORIDA DOH E871027 (AIR)

I certify that the analyses listed above, unless specifically listed as subcontracted, if any, were performed under my direction according to the approved methodologies listed in this document, and that based upon my inquiry of those individuals immediately responsible for obtaining the information, the material contained in this report is, to the best of my knowledge and belief, accurate and complete.

DATE

SIGNATURE

Tod Kopyscinski

Air Laboratory Manager

Michael Erickson

Assistant Laboratory Director

Edward Denson Technical Director

Daren Damboragian

Organics Department Supervisor



39 Spruce Street $^{\circ}$ East Łongmeadow, MA $\,$ 01028 $^{\circ}$ FAX 413/525-6405 $^{\circ}$ TEL. 413/525-2332 $\,$

STEVEN MURDZIA

YALE UNIVERSITY

135 COLLEGE STREET

NEW HAVEN, CT 06510

Purchase Order No.:

1/13/2009

Page 1 of 4

LIMS-BAT #: LIMT-22476

Job Number: -

Project Location: KCL Date Received:

1/7/2009

Field Sample #: KCL1

09B00337

\$Sampled: 1/6/2009 Ext. Window Caulk

Sample Matrix:

Sample ID:

SOLID

	Units	Results	Date	Analyst	RL	SPEC	Limit	P/F
			Analyzed			Lo	Hi	
PCB 1016	mg/kg	ND	01/12/09	JMR	7580			
PCB-1221	mg/kg	ND	01/12/09	JMR	7580			
PCB-1232	mg/kg	ND	01/12/09	JMR	7580			
⊶PCB-1242	mg/kg*	· NDZ:	01/12/09	JMR-	7580			
PCB-1248	mg/kg	ND	01/12/09	JMR	7580			
PCB-1254	mg/kg	71300	01/12/09	JMR	7580			
PCB-1260	mg/kg	ND	01/12/09	JMR	7580			
PCB 1262	mg/kg	ND	01/12/09	JMR	7580			
PCB 1268	mg/kg	ИD	01/12/09	JMR	7580			
Extraction Date PCB	S	1/8/2009	01/12/09	JMR				

Field Sample #: KCL2

Sample ID:

09B00338

‡Sampled: 1/6/2009

Ext. Bldg. Expansion Caulk

Sample Matrix:

SOLID

	Units	Results	Date	Analyst	RL	SPEC	Limit	P/F
			Analyzed			Lo	Hì	
PCB 1016	mg/kg	ND	01/12/09	JMR	9180			
PCB-1221	mg/kg	ND	01/12/09	JMR	9180			
PCB-1232	mg/kg	ND	01/12/09	JMR	9180			
PCB-1242	mg/kg	ND	01/12/09	JMR	9180			
PCB-1248	mg/kg	ND	01/12/09	JMR	9180			
PCB-1254	mg/kg	98900	01/12/09	JMR	9180			
PCB-1260	mg/kg	ND	01/12/09	JMR	9180			
PCB 1262	mg/kg	ND	01/12/09	JMR	9180			
PCB 1268	mg/kg	ND	01/12/09	JMR 1	9180			
Extraction Date PCBs		1/8/2009	01/12/09	JMR				

RL = Reporting Limit

ND = Not Detected at or above the Reporting Limit

SPEC LIMIT = a client specified recommended or regulatory level for comparison with data to determine PASS (P) or FAIL (F) condition of results.

NM = Not Measured

^{* =} See end of report for comments and notes applying to this sample

^{# =} See attached chain-of-custody record for time sampled



39 Spruce Street * East Longmeadow, MA 01028 * FAX 413/525-6405 * TEL. 413/525-2332

STEVEN MURDZIA

YALE UNIVERSITY

135 COLLEGE STREET

NEW HAVEN, CT 06510

Purchase Order No.:

1/13/2009

Page 2 of 4

Project Location: KCL

1/7/2009

LIMS-BAT #: LIMT-22476 Job Number;

Date Received:

Field Sample #: KCL3

09B00339

\$Sampled: 1/6/2009

Sample ID:

Ext. Entry Caulk

Sample Matrix:

SOLID

	Units	Results	Dale	Analyst	RL	SPEC	Limit	P/ F
			Analyzed			Lo	Hì	
PCB 1016	mg/kg	ND	01/12/09	JMR	.9390			
PCB-1221	mg/kg	ND	01/12/09	JMR	9390			
PCB-1232	mg/kg	МD	01/12/09	JMR	9390			
PCB-1242	mg/kg	NĐ	01/12/09	JMR	9390			
PCB-1248	mg/kg	ND	01/12/09	JMR	9390			
PCB-1254	mg/kg	70500	01/12/09	JMR	9390			
PCB-1260	mg/kg	NĎ	01/12/09	JMR	9390			
PCB 1262	mg/kg	ND	01/12/09	JMR	9390			
PCB 1268	mg/kg	ND	01/12/09	JMR	9390			
Extraction Date PCBs		1/8/2009	01/12/09	JMR				

Field Sample #: KCL4

Sample ID:

09B00340

‡Sampled: 1/6/2009

Wall Caulk

Sample Matrix:

SOLID

MORK	
------	--

	Units	Results	Date Analyzed	Analyst	RL	SPEC Lo	Limit HI	P/F
PCB 1016	mg/kg	ND	01/12/09	JMR	9.48			
PCB-1221	mg/kg	ND	01/12/09	JMR	9.48			
PCB-1232	mg/kg	ND	01/12/09	JMR	9.48			
PCB-1242	mg/kg	ND	01/12/09	JMR	9.48			
PCB-1248	mg/kg	ND	01/12/09	JMR	9.48			
PCB-1254	mg/kg	31.2	01/12/09	JMR	9.48			
PCB-1260	mg/kg	ND:	01/12/09	JMR	9.48			
PCB 1262	mg/kg	ND	01/12/09	JMR	9.48			
PCB 1268	mg/kg	ND	01/12/09	JMR	9.48			
Extraction Date PCBs		1/8/2009	01/12/09	JMR				

RL = Reporting Limit

ND = Not Detected at or above the Reporting Limit

SPEC LIMIT = a client specified recommended or regulatory level for comparison with data to determine PASS (P) or FAIL (F) condition of results.

NM = Not Measured

^{* =} See end of report for comments and notes applying to this sample

^{# =} See attached chain-of-custody record for time sampled



39 Spruce Street ° East Longmeadow, MA 01028 ° FAX 413/525-6405 ° TEL, 413/525-2332

STEVEN MURDZIA

YALE UNIVERSITY

1/13/2009

135 COLLEGE STREET

Page 3 of 4

NEW HAVEN, CT 06510

Purchase Order No.:

Project Location: KCL

LIMS-BAT #: LIMT-22476

Date Received: 1/7/2009

Job Number: -

Analytical Method;

SW846 8081/8082

SAMPLES ARE EXTRACTED BY PRESSURIZED FLUID EXTRACTION (SW846 3545) OR MICROWAVE (SW846 3546), CONCENTRATED, AND ANALYZED BY GAS CHROMATOGRAPHY WITH ELECTRON CAPTURE DETECTION.

RL = Reporting Limit

NO = Not Detected at or above the Reporting Limit

SPEC LIMIT = a client specified recommended or regulatory level for comparison with data to determine PASS (P) or FAIL (F) condition of results,

NM = Not Measured

^{* =} See end of report for comments and notes applying to this sample

^{# =} See attached chain-of-custody record for time sampled



39 Spruce Street * East Longmeadow, MA 01028 * FAX 413/525-6405 * TEL. 413/525-2332

STEVEN MURDZIA YALE UNIVERSITY 135 COLLEGE STREET NEW HAVEN, CT 06510

Purchase Order No.:

1/13/2009

Page 4 of 4

Project Location: KCL Date Received: 1/7/2009 LIMS-BAT #: LIMT-22476

Job Number:

** END OF REPORT **

RL = Reporting Limit

ND = Not Detected at or above the Reporting Limit

NM = Not Measured

SPEC LIMIT = a client specified recommended or regulatory level for comparison with data to determine PASS (P) or FAIL (F) condition of results,

^{* =} See end of report for comments and notes applying to this sample

^{# =} See attached chain-of-custody record for time sampled



39 Spruce Street * East Longmeadow, MA 01028 * FAX 413/525-6405 * TEL. 413/525-2332

QC SUMMARY REPORT

SAMPLE QC: Sample Results with Duplicates

Sample Matrix Spikes and Matrix Spike Duplicates

BATCH QC: Lab fortified Blanks and Duplicates

Standard Reference Materials and Duplicates

Method Blanks

Report Date:	1/13/2009	Lims Bat #: L/MT-22476		Page 1	fof 3
QC Batch Numb	er: GC/ECD-12063				
Sample Id	Analysis	QC Analysis	Values	Units	Limits
09B00337					
	Decachlorobiphenyl	Surrogate Recovery	N.M.	%	30-150
	Tetrachloro-m-Xylene	Surrogate Recovery	N.M.	%	30-150
09B00338					
	Decachlorobiphenyl	Surrogate Recovery	N.M.	%	30-150
	Tetrachloro-m-Xylene	Surrogate Recovery	N.M.	%	30-150
09800339					
	Decachlorobiphenyl	Surrogate Recovery	N.M.	%	30-150
	Tetrachioro-m-Xylene	Surrogate Recovery	N.M.	%	30-150
09B00340	•				
	Decachforobiphenyl	Surrogate Recovery	148.5	%	30-150
	Tetrachioro-m-Xylene	Surrogate Recovery	130.5	%	30-150
BLANK-128419					
	PCB-1232	Blank	<1.00	mg/kg	
	PCB-1242	Blank	<1.00	mg/kg	
	PCB-1254	Blank	<1.00	mg/kg	
	PCB-1260	Blank	<1.00	mg/kg	
	PCB-1248	Blank	<1.00	mg/kg	
	PCB-1221	Blank	<1.00	mg/kg	
	PCB 1016	Blank	<1.00	mg/kg	
	PCB 1262	Blank	<1.00	mg/kg	
	PCB 1268	Blank	<1.00	mg/kg	
FBLANK-90456	3 ,			- •	
	PCB-1260	Lab Fort Blank Amt.	10.000	mg/kg	
		Lab Fort Blk. Found	10.545	mg/kg	
		Lab Fort Blk. % Rec.	105.450	%	40-140
		Dup Lab Fort Bl Amt.	10.000	mg/kg	
		Dup Lab Fort Bl. Fnd	10.845	mg/kg	
		Dup Lab Fort BI %Rec	108.450	%	
		Lab Fort Blank Range	3.000	units	
		Lab Fort Bi. Av. Rec	106.950	%	
		LFB Duplicate RPD	2.805	%	0-30
	PCB 1016	Lab Fort Blank Amt.	10.000	mg/kg	
		Lab Fort Blk. Found	10.245	mg/kg	
		Lab Fort Blk, % Rec.	102,450	%	40-140
		Dup Lab Fort Bl Amt.	10.000	mg/kg	
		Dup Lab Fort Bl. Fnd	11,855	mg/kg	
		Dup Lab Fort Bl %Rec	118.550	%	
		Lab Fort Blank Range	16,100	units	
		Lab Fort Bl. Av. Rec	110.500	%	
		LF8 Duplicate RPD	14.570	%	0-30



39 Spruce Street * East Longmeadow, MA 01028 * FAX 413/525-6405 * TEL. 413/525-2332

QC SUMMARY REPORT

SAMPLE QC: Sample Results with Duplicates

BATCH QC: Lab fortified Blanks and Duplicates

Sample Matrix Spikes and Matrix Spike Duplicates

Standard Reference Materials and Duplicates

Method Blanks

Report Date:

1/13/2009

Lims Bat #: LIMT-22476 Page 2 of 3

NOTES:

QC Batch No. :

GC/ECD-12063

Sample ID

09B00337

Analysis

Decachlorobiphenyl

SURROGATE CONCENTRATION BELOW DETECTION LIMIT DUE TO DILUTION REQUIRED

FOR SAMPLE ANALYSIS.

QC Batch No.:

GC/ECD-12063

Sample ID :

09B00337

Analysis

Tetrachloro-m-Xylene

SURROGATE CONCENTRATION BELOW DETECTION LIMIT DUE TO DILUTION REQUIRED

FOR SAMPLE ANALYSIS.

QC Batch No. :

GC/ECD-12063

Sample ID :

09B00338

Analysis

Decachlorobiphenyl

SURROGATE CONCENTRATION BELOW DETECTION LIMIT DUE TO DILUTION REQUIRED

FOR SAMPLE ANALYSIS.

QC Batch No.:

GC/ECD-12063

Sample ID :

09B00338

Analysis

Tetrachioro-m-Xylene

SURROGATE CONCENTRATION BELOW DETECTION LIMIT DUE TO DILUTION REQUIRED

FOR SAMPLE ANALYSIS.

QC Batch No. :

GC/ECD-12063

Sample ID :

09B00339

Decachlorobiphenyl

SURROGATE CONCENTRATION BELOW DETECTION LIMIT DUE TO DILUTION REQUIRED

FOR SAMPLE ANALYSIS.

QC Batch No.;

GC/ECD-12063

Sample ID :

09B00339

Analysis

Tetrachloro-m-Xylene

SURROGATE CONCENTRATION BELOW DETECTION LIMIT DUE TO DILUTION REQUIRED

FOR SAMPLE ANALYSIS.



39 Spruce Street " East Longmeadow, MA | 01028 " FAX 413/525-6405 " TEL | 413/525-2332

QC SUMMARY REPORT

SAMPLE QC: Sample Results with Duplicates

Sample Matrix Spikes and Matrix Spike Duplicates

BATCH QC; Lab fortified Blanks and Duplicates

Standard Reference Materials and Duplicates

Method Blanks

Report Date:

1/13/2009

Lims Bat #: LIMT-22476

Page 3 of 3

QUALITY CONTROL DEFINITIONS AND ABBREVIATIONS

QC BATCH NUMBER

This is the number assigned to all samples analyzed together that would be subject to comparison with a particular set of Quality

Control Data.

LIMITS

Upper and Lower Control Limits for the QC ANALYSIS Reported. All values normally would fall within these statistically determined limits, unless there is an unusual circumstance that would be documented in a NOTE appearing on the last page of the QC SUMMARY REPORT. Not all QC results will have Limits defined.

Sample Amount

Amount of analyte found in a sample.

Blank

Method Blank that has been taken though all the steps of the

analysis.

LEBLANK

Laboratory Fortified Blank (a control sample)

STDADD

Standard Added (a laboratory control sample)

Matrix Spk Amt Added MS Amt Measured Matrix Spike % Rec.

Amount of analyte spiked into a sample Amount of analyte found including amount that was spiked

% Recovery of spiked amount in sample.

Duplicate Value 'Duplicate RPD

The result from the Duplicate analysis of the sample.

The Relative Percent Difference between two Duplicate Analyses.

Surrogate Recovery

The % Recovery for non-environmental compounds (surrogates) spiked into samples to determine the performance of the

analytical methods.

Sur. Recovery (ELCD) Sur. Recovery (PlD) Surrogate Recovery on the Electrolytic Conductivity Detector.

Surrogate Recovery on the Photoionization Detector.

Standard Measured Standard Amt Added Standard % Recovery

Amount measured for a laboratory control sample Known value for a laboratory control sample

% recovered for a laboratory control sample with a known value.

Lab Fort Blank Amt
Lab Fort Blk. Found
Lab Fort Blk % Rec
Dup Lab Fort Bl Amt
Dup Lab Fort Bl Fnd
Dup Lab Fort Bl % Rec
Lab Fort Blank Range

Laboratory Fortified Blank Amount Added Laboratory Fortified Blank Amount Found Laboratory Fortified Blank % Recovered

Duplicate Laboratory Fortified Blank Amount Added Duplicate Laboratory Fortified Blank Amount Found Duplicate Laboratory Fortified Blank % Recovery

Duplicate Laboratory Fortified Blank % Recovery Laboratory Fortified Blank Range (Absolute value of difference between recoveries for Lab Fortified Blank and Lab Fortified Blank Duplicate).

Lab Fort Bl. Av. Rec.

Laboratory Fortified Blank Average Recovery

Duplicate Sample Amt MSD Amount Added MSD Amt Measured MSD % Recovery MSD Range Sample Value for Duplicate used with Matrix Spike Duplicate Matrix Spike Duplicate Amount Added (Spiked)

Matrix Spike Duplicate Amount Added (Spiked) Matrix Spike Duplicate Amount Measured

Matrix Spike Duplicate % Recovery
Absolute difference between Matrix Spike and Matrix Spike
Duplicate Recoveries

Company Name:	
	CON-LEST
′	SEATORY ®

CHAIN OF CUSTODY RECORD

	0 = Other	O = other			Require lab approval.		
ulfate	B = Sodjum bisutfate	SL = slower			Date needed -	Date/∏me:	Received by: (signature)
G.	S = Sulfuric Acid	Solid	5;	Special Requirements or DL's:	Other* Spe		
	N = Nitric Acid		[(MA MCP sites only)		Date/Time:	Relinquished by: (signature)
- Na Utiosunate	M = Methanol	DW= drinking water	Y	Data Enhancement Project? Y N		17/10/1500	J. C. T.
A - Na hydroxide	1 200	Gee - Groomstander		4		The state of the s	eceived within a ring
Codes:	**Preservation Codes:		<u>irements</u>	Regulations?	i urnaround	できた。いまで	Service Control
					1		
							0
		-					
					:		and the second s
	-						
			-				
			5	8	1/6/09	00339	KCL3 Ext entry caulk
							Application of the state of the
Comments:			9	ς σ	60/9/1	00337	KCL1 ext window caulk
				Comp- oslie Grab *Matrix Code	Start Stop Co Date/Time Date/Time os	Lab # OSS	Field ID Sample Description
900					te S		yes proposal date
Techar bag				3.3			Proposel Pravided? (For Silling purposes)
Ka Wai			···,	Zia@yaie.edu	Email: Steven.murdzia@yale.edu		Sampled By: S. Murdzia
017567#					Fax#:		Project Location; KCL
P≕plastic			. 00	PEMAIL WEBSITE CLIENT	∏FAX VEMAIL UN		
			- l	k onel:	DATA DELIVERY (check one):	 - -	Attention: Steven Murdzia
Com, Code	ESTED	ANALYSIS REQUESTED			Client PO #		New Haven, CT 06510
~Conf.Code					Project #		Address: 135 College St, Ste 100
**Preservation				-2236	Telephone:(203) 785-2236		Company Name: Yale OEHS
# of containers						www.contestlabs.com	
مد	V, MA 01028	EASTLONGMEADOW, MA 01028	367	1, mt # 22476		Fax: 413-525-6405 Email: info@contestlabs.com	ANALYTICAL LABORATORY
Page of	FLOOR	39 SPRUCE ST, 2ND FLOOR	CORD	CUSTODY REC	CHAIN OF	Phone: 413-525-2332	ううういかで

www.contestlabs.com

Do all samples have the proper pH: Yes No N/A



Sample Receipt Checklist

39 Spruce St.
East Longmeadow, MA.
01028
P: 413-525-2332
F: 413-525-6405

CLIENT NAME: Vale		_ RECEIVE	D BY: OE	DA	TE: 117/08
1) Was the chain(s) of custody 2) Does the chain agree with the if not, explain:		ned?	Yes (Fes	No \ No	
3) Are all the samples in good of lift not, explain:	condition?		(Yes)	No	
4) How were the samples received	ved:				
On Ice Direct from	Sampling 🔲	Ambient	In Coo	oler(s)	
Were the samples received in T	emperature Complia	nce of (2-6°	C)? Yes	Νo	
Temperature °C by Temp blank _		Temperat	ure °C by Temp	gun	
5) Are there Dissolved samples			Yes	(No	
Who was notified	Date	Time		20	
6) Are there any samples "On H		Yes	(No Stor	ed where:	
7) Are there any RUSH or SHORT HOLDING TIME samples? Yes					
Who was notified	Date	Time			
8) Location where samples are	stored:		1		t samples? Yes No it already approved
			Client Signatu		
			TOICH CIGHER	ne. Majoriya jiba d	
•	Containers se	ent in to	Con-Tes	st	
	# of containers				# of containers
1 Liter Amber	<u> </u>		8 oz clear	jar	
500 mL Amber	•		4 oz clear	jar	
250 mL Amber (8oz amber)			2 oz clear	jar	
1 Liter Plastic			Other glass	s jar	
500 mL Plastic			Plastic Bag /	Ziploc	4
250 mL plastic	<u> </u>		Air Casse	tte	,
40 mL Vial type listed below			Brass Slee	ves	
Colisure / bacteria bottle			Tubes		
Dissolved Oxygen bottle			Summa Ca	ans	
Flashpoint bottle			Regulator	rs	
Encore			Other		
Laboratory Comments:					
40 mŁ vials: # HCI	# Methanol			- ,	
	# DI Water		Time and Dat	e Frozen:	
	Unpreserved			_	



195 Commerce Way Suite E Portsmouth, New Hampshire 03801 603-436-5111 Fax 603-430-2151 800-929-9906 www.analyticslab.com

November 1, 2010

Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

RE: Analytical Results Case Narrative

Analytics # 68098 KCL Mock Up

Dear Mr. Klein;

Enclosed please find the analytical results for samples submitted for the above-mentioned project. The attached Cover Page lists the sample IDs, Lab tracking numbers and collection dates for the samples included in this deliverable.

Samples were analyzed Polychlorinated Biphenyls (PCBs) by EPA Method 8082.

Unless otherwise noted in the Non-conformance Summary listed below, all of the quality control (QC) criteria including initial calibration, calibration verification, surrogate recovery, holding time and method accuracy/precision for these analyses were within acceptable limits.

This Level II data package has been assembled in the following order:

Case Narrative/Non-Conformance Summary
Sample Log Sheet - Cover Page
PCB Form 1 Data Sheet for Samples and Blanks
Chromatograms
PCB Form 10 Confirmation Results
PCB Form 3 MS/MSD (LCS) Recoveries
Chain of Custody (COC) Forms

QC NON-CONFORMANCE SUMMARY

Sample Receipt:

The cooler temperature upon receipt was 19.3^o C upon receipt at the laboratory. The client was contacted an instructed the laboratory to proceed with analysis.

One sample 68098-7 (10186 KCL 110 ext) was supplied in the cooler and was not listed on the Chain of Custody (COC). In addition one sample 68098-6 had the station ID incorrectly written on the COC. The client was contacted and sample 68098-7 was added to the COC and the station ID was corrected for 68098-6.

PCBs by EPA Method 8082:

All samples in this SDG required dilution due to the high concentrations of PCBs detected in the samples.

The laboratory blank B102510PSOX had PCB 1254 detected. PCB 1254 was detected in all samples at levels greater than 10X the level detected in the blank. Results were reported without qualification.

The closing continuing calibration standards (M32521Sc &M32522SC) had recoveries greater than 115% but less than 120% on column#2. Column#1 was in control for all analytes. Results were reported without qualification.

Sincerely,

ANALYTICS Environmental Laboratory, LLC

Stephen Knollmeyer Laboratory Director

Mallelli for



195 Commerce Way Suite E Portsmouth, New Hampshire 03801 603-436-5111 Fax 603-430-2151 800-929-9906 www.analyticslab.com

Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510 Report Number: 68098

Revision: Rev. 0

Re: KCL Mock Up (Project No: 102010)

Enclosed are the results of the analyses on your sample(s). Samples were received on 21 October 2010 and analyzed for the tests listed. Samples were received in acceptable condition, with the exceptions noted below or on the chain of custody. These results pertain to samples as received by the laboratory and for the analytical tests requested on the chain of custody. The results reported herein conform to the most current NELAC standards, where applicable, unless otherwise narrated in the body of the report. Please see individual reports for specific methodologies and references.

Lab Number	Sample Date	Station Location	<u>Analysis</u>	Comments
68098-1	10/18/10	10181 KCL 114 int	EPA 8082 (PCBs only)	
68098-2	10/18/10	10182 KCL 110 int	EPA 8082 (PCBs only)	
68098-3	10/18/10	10183 KCL 110 int	EPA 8082 (PCBs only)	
68098-4	10/18/10	10184 KCL 114 ext	EPA 8082 (PCBs only)	
68098-5	10/18/10	10185 KCL 110 ext	EPA 8082 (PCBs only)	
68098-6	10/18/10	10187 KCLext glaz	EPA 8082 (PCBs only)	
68098-7	10/18/10	10186 KCL 110 ext	EPA 8082 (PCBs only)	

Sample Receipt Exceptions: None

Analytics Environmental Laboratory is certified by the states of New Hampshire, Maine, Massachusetts, Connecticut, Rhode Island, Virginia, Maryland, and is accredited by the Department of Defense (DOD) ELAP program. A list of actual certified parameters is available upon request.

If you have any questions on these results, please do not hesitate to contact us.

Authorized signature _

Stephen L. Knollmeyer Lab. Director

Date

This report shall not be reproduced, except in full, without the written consent of Analytics Environmental Laboratory, LLC.



Surrogate Compound Limits

	Matrix: Units:	Aqueous % Recovery	Solid % Recovery	Method
Volatile Organic Compounds - Dr	inking Wa	ter		
1,4-Difluorobenzene		70-130		EPA 524.2
Bromofluorobenzene		70-130		
1,2-Dichlorobenzene-d4		70-130		
Volatile Organic Compounds				
1,2-Dichloroethane-d4		70-120	70-120	EPA 624/8260B
Toluene-d8		85-120	85-120	
Bromofluorobenzene		75-120	75-120	
Semi-Volatile Organic Compound	s			
2-Fluorophenol		20-110	35-105	EPA 625/8270C
d5-Phenol		15-110	40-100	
d5-nitrobenzene		40-110	35-100	
2-Fluorobiphenyl		50-110	45-105	
2,4,6-Tribromophenol		40-110	40-125	
d14-p-terphenyl		50-130	30-125	
PAH's by SIM				
d5-nitrobenzene		21-110	35-110	EPA 8270C
2-Fluorobiphenyl		36-121	45-105	21.102700
d14-p-terphenyl		33-141	30-125	
Pesticides and PCBs				
2,4,5,6-Tetrachloro-m-xylene (TCX)		46-122	40-130	EPA 608/8082
Decachlorobiphenyl (DCB)		40-135	40-130	
Herbicides				
Dichloroacetic acid (DCAA)		30-150	30-150	
Gasoline Range Organics/TPH Ga	soline			
Trifluorotoluene TFT (FID)	3011110	60-140	60-140	MEDEP 4217/EPA 8015
Bromofluorobenzene (BFB) (FID)		60-140	60-140	THE SALE THE PROPERTY OF THE SALE THE S
Trifluorotoluene TFT (PID)		60-140	60-140	
Bromofluorobenzene (BFB) (PID)		60-140	60-140	
Diesel Range Organics/TPH Diesel				
m-terphenyl		60-140	60-140	MEDEP 4125/EPA 8015/CT ETPH
Valatila Datuslaum Hudusaankana				
Volatile Petroleum Hydrocarbons 2,5-Dibromotoluene (PID)		70 120	70 120	MADED VIDLI May 2004 Parel 1
2,5-Dibromotoluene (FID)		70-130 70-130	70-130 70-130	MADEP VPH May 2004 Rev1.1
2,5 Diolomolotuche (11D)		/0-130	70-130	
Extracatable Petroleum Hydrocarb	ons	40.140	40.140	MADED POHAL GOOD
1-chloro-octadecane (aliphatic)		40-140	40-140	MADEP EPH May 2004 Rev1.1
o-Terphenyl (aromatic)		40-140	40-140	
2-Fluorobiphenyl (Fractionation)		40-140	40-140	
2-Bromonaphthalene (fractionation)		40-140	40-140	



PCB DATA SUMMARIES



Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

KCL Mock Up

Project Number:

102010

Field Sample ID:

Lab OC

November 1, 2010

SAMPLE DATA

Lab Sample ID:

B102510PSOX RR

Matrix:

Soil

Percent Solid:

N/A

Dilution Factor:

1.0

Collection Date:

Lab Receipt Date:

Extraction Date:

10/25/10

Analysis Date:

10/29/10

	PCB ANALYTICAL RES	SULTS
COMPOUND	Quantitation Limit μg/kg	Results $\mu g/kg$
PCB-1016	33	U
PCB-1221	33	U
PCB-1232	33	U
PCB-1242	33	· U
PCB-1248	33	U
PCB-1254	33	197
PCB-1260	33	U
	Surrogate Standard Recovery	<u>.</u>
	•	96 % 68 %
U=Undetected	J=Estimated E=Exceeds Calibration Ra	ange B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

PCB Report

Authorized signature Mullull

Data Path : C:\msdchem\1\DATA\102910-M\

Data File : M32503B.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 29 Oct 2010 2:30 pm

Operator : JK

Sample : B102510PSOX,RR,,A/C

Misc : SOIL

ALS Vial : 6 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e

Quant Time: Nov 01 09:59:57 2010

Quant Method: C:\msdchem\1\METHODS\PCB100910.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update: Tue Oct 12 11:29:57 2010


Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um




File :C:\msdchem\1\DATA\102910-M\M32503B.D

Operator : JK

Acquired : 29 Oct 2010 2:30 pm using AcqMethod PEST.M

Instrument : Instrument M
Sample Name: B102510PSOX,RR,,A/C

Misc Info : SOIL Vial Number: 6





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

KCL Mock Up

Project Number:

102010

Field Sample ID:

10181 KCL 114 int

November 1, 2010

SAMPLE DATA

Lab Sample ID:

68098-1

Matrix:

Solid

Percent Solid:

99

Dilution Factor:

450000

Collection Date:

10/18/10

Lab Receipt Date:

10/21/10 10/25/10

Extraction Date: Analysis Date:

10/29/10

PCB ANALYTICAL RESULTS

COMPOUND	Quantitation Limit µg/kg	Results μg/kg
PCB-1016	14850000	U
PCB-1221	14850000	U
PCB-1232	14850000	U
PCB-1242	14850000	U
PCB-1248	14850000	\mathbf{U}^{c}
PCB-1254	14850000	209000000
PCB-1260	14850000	U
1		

Surrogate Standard Recovery

2,4,5,6-Tetrachloro-m-xylene

%

Decachlorobiphenyl

%

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS:

Results are expressed on a dry weight basis.

* The surrogates were diluted out.

PCB Report

Authorized signature Mullell

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68098

GC Column #1: STX-CLPesticides I

Sample: 68098-1,1:50000,,A/C

Column ID: 0.25 mm

Data File: M32513.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 450119.6

Column ID: 0.25 mm

C - 1		11.1
10	umn	##

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	183219633	209172131	13.2	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:	

^{*} Values outside QC limits

Data Path : C:\msdchem\1\DATA\102910-M\

Data File: M32513.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 29 Oct 2010 4:25 pm

Operator : JK

Sample : 68098-1,1:50000,,A/C

Misc : SOIL

ALS Vial : 16 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Nov 01 10:17:05 2010

Quant Method: C:\msdchem\1\METHODS\PCB100910.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update: Tue Oct 12 11:50:46 2010


Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase : STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

November 1, 2010

SAMPLE DATA

Lab Sample ID:68098-2Matrix:SolidPercent Solid:99Dilution Factor:831000

Collection Date: 10/18/10
Lab Receipt Date: 10/21/10
Extraction Date: 10/25/10

Analysis Date: 10/29/10

CLIENT SAMPLE ID

Project Name: KCL Mock Up

Project Number: 102010

Field Sample ID: 10182 KCL 110 int

PCB ANALYTICAL RESULTS

COMPOUND	Quantitation Limit µg/kg	Results μg/kg
PCB-1016	27423000	U
PCB-1221	27423000	U
PCB-1232	27423000	U
PCB-1242	27423000	U
PCB-1248	27423000	U
PCB-1254	27423000	27400000
PCB-1260	27423000	U
·		

Surrogate Standard Recovery

2,4,5,6-Tetrachloro-m-xylene * %
Decachlorobiphenyl * %

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

* The surrogates were diluted out.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68098

GC Column #1: STX-CLPesticides I

Sample: 68098-2,1:100000,,A/C

Column ID: 0.25 mm

Data File: M32514.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 831351.3

Column ID: 0.25 mm

Column #1

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	272704411	273680500	0.4	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:	

^{*} Values outside QC limits

Data Path : C:\msdchem\1\DATA\102910-M\

Data File: M32514.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 29 Oct 2010 4:35 pm

Operator : JK

Sample : 68098-2,1:100000,,A/C

Misc : SOIL

ALS Vial: 17 Sample Multiplier: 1

Integration File signal 1: events.e
Integration File signal 2: events2.e
Quant Time: Nov 01 10:17:07 2010

Quant Method : C:\msdchem\1\METHODS\PCB100910.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update : Tue Oct 12 11:50:46 2010


Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name: KCL Mock Up

Project Number: 102010

Field Sample ID: 10183 KCL 110 int

November 1, 2010

SAMPLE DATA

Lab Sample ID: 68098-3 Matrix: Solid Percent Solid: 100 **Dilution Factor:** 465000 **Collection Date:** 10/18/10 Lab Receipt Date: 10/21/10 **Extraction Date:** 10/25/10 **Analysis Date:** 10/29/10

PCB ANALYTICAL RESULTS

COMPOUND	Quantitation Limit μg/kg	Results μg/kg
PCB-1016	15345000	U
PCB-1221	15345000	U
PCB-1232	15345000	U
PCB-1242	15345000	U
PCB-1248	15345000	U
PCB-1254	15345000	227000000
PCB-1260	15345000	U

Surrogate Standard Recovery

2,4,5,6-Tetrachloro-m-xylene * %
Decachlorobiphenyl * %

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

* The surrogates were diluted out.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68098

GC Column #1: STX-CLPesticides I

Sample: 68098-3,1:50000,,A/C

Column ID: 0.25 mm

Data File: M32515.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 464495.8

Column ID: 0.25 mm

Column #1

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	200723034	227037464	12.3	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:	

^{*} Values outside QC limits

Data Path : C:\msdchem\1\DATA\102910-M\

Data File: M32515.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

: 29 Oct 2010 Acq On 4:45 pm

: JK Operator

: 68098-3,1:50000,,A/C Sample

Misc : SOIL

ALS Vial : 18 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Nov 01 10:17:09 2010

Quant Method: C:\msdchem\1\METHODS\PCB100910.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254


QLast Update : Tue Oct 12 11:50:46 2010 Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um





Mr. Rob Klein Yale University Environmental Health & 135 Čollege Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

KCL Mock Up

Project Number:

102010

Field Sample ID:

10184 KCL 114 ext

November 1, 2010

SAMPLE DATA

Lab Sample ID:

68098-4

Matrix:

Solid

Percent Solid:

98

Dilution Factor:

758000

Collection Date: Lab Receipt Date: 10/18/10

Extraction Date:

10/21/10 10/25/10

Analysis Date:

10/29/10

COMPOUND	Quantitation Limit μ g/kg	Results μg/kg	
PCB-1016	25014000	U	
PCB-1221	25014000	U	
PCB-1232	25014000	uustaan missa, uurun saan eedhanii isaan oo ee riitaa Ha hiid aan oo ee aasta oo oo dhoo oo oo oo oo oo oo oo oo	et e construit de la construit
PCB-1242	25014000	U	
PCB-1248	25014000	U	
PCB-1254	25014000	294000000	
PCB-1260	25014000	U	

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

2,4,5,6-Tetrachloro-m-xylene

Decachlorobiphenyl

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS:

Results are expressed on a dry weight basis.

PCB Report

%

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68098

GC Column #1: STX-CLPesticides I

Sample: 68098-4,1:100000,,A/C

Column ID: 0.25 mm

Data File: M32516.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 758403.1

Column ID: 0.25 mm

Column #1

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	256954329	293743174	13.4	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:		

^{*} Values outside QC limits

Data Path : C:\msdchem\1\DATA\102910-M\

Data File: M32516.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 29 Oct 2010 4:55 pm

Operator : JK

Sample : 68098-4,1:100000,,A/C

: SOIL Misc

ALS Vial : 19 Sample Multiplier: 1

Integration File signal 1: events.e
Integration File signal 2: events2.e Quant Time: Nov 01 10:17:11 2010

Quant Method: C:\msdchem\1\METHODS\PCB100910.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update : Tue Oct 12 11:50:46 2010


Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase : STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

KCL Mock Up

Project Number:

102010

Field Sample ID:

10185 KCL 110 ext

November 1, 2010

SAMPLE DATA

Lab Sample ID:

68098-5

Matrix:

Solid

Percent Solid:

100

Dilution Factor:

1.01e+6

Collection Date:

10/18/10

Lab Receipt Date:

10/21/10

Extraction Date:

10/25/10

Analysis Date:

10/29/10

PCB ANALYTICAL RESULTS						
COMPOUND	Quantitation Limit μg/kg	Results μg/kg				
PCB-1016	33330000	\mathbf{U}				
PCB-1221	33330000	U				
PCB-1232	33330000					
PCB-1242	33330000	U				
PCB-1248	33330000	U				
PCB-1254	33330000	310000000				
PCB-1260	33330000	U				
	Surrogate Standard Recovery					
	2,4,5,6-Tetrachloro-m-xylene *	%				
	Decachlorobiphenyl *	%				
U=Undetected J=	Estimated E=Exceeds Calibration Range	B=Detected in				

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS:

Results are expressed on a dry weight basis.

* The surrogates were diluted out.

PCB Report

Authorized signature Wallell

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68098

GC Column #1: STX-CLPesticides I

Sample: 68098-5,1:100000,,A/C

Column ID: 0.25 mm

Data File: M32517.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 1010101.0

Column ID: 0.25 mm

Column #1

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	271147980	310016768	13.4	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:				

^{*} Values outside QC limits

Data Path : C:\msdchem\1\DATA\102910-M\

Data File: M32517.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 29 Oct 2010 5:06 pm

Operator : JK

Sample : 68098-5,1:100000,,A/C

Misc : SOIL

ALS Vial : 20 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Nov 01 10:17:13 2010

Quant Method: C:\msdchem\1\METHODS\PCB100910.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update: Tue Oct 12 11:50:46 2010


Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info $: 30 \text{ m} \times 0.25 \text{mm} \times 0$ Signal #2 Info $: 30 \text{ m} \times 0.25 \text{mm} \times 0.25$ um



Analytics Report 68098 page 23 of 37



10187 KCLext glaz

Mr. Rob Klein Yale University Environmental Health & Safety 135 Čollege Street New Haven CT 06510

Field Sample ID:

November 1, 2010

SAMPLE DATA

68098-6

Lab Sample ID: Matrix:

Solid CLIENT SAMPLE ID Percent Solid: 100 **Project Name:** KCL Mock Up **Dilution Factor:** 3330

Project Number: 102010 **Collection Date:** 10/18/10 Lab Receipt Date: 10/21/10

Extraction Date: 10/25/10 **Analysis Date:** 10/29/10

PCB ANALYTICAL RESULTS Quantitation Results Limit μ g/kg $\mu g/kg$ **COMPOUND** PCB-1016 110000 U PCB-1221 110000 U 110000 PCB-1232 U 110000 PCB-1242 U 110000 PCB-1248 U 110000 2680000 PCB-1254 110000 U PCB-1260 **Surrogate Standard Recovery** 2,4,5,6-Tetrachloro-m-xylene % Decachlorobiphenyl %

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

* The surrogates were diluted out.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68098

GC Column #1: STX-CLPesticides I

Sample: 68098-6,1:500,,A/C

Column ID: 0.25 mm

Data File: M32511.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 3333.3

Column ID: 0.25 mm

Co	lumn	#1

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	2395113	2678407	11.2	

Column to be used to flag RPD values greater than QC limit of 40%

* Values outside QC limits

Comments:		

Data Path: C:\msdchem\1\DATA\102910-M\

Data File: M32511.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 29 Oct 2010 3:53 pm

Operator : JK

Sample : 68098-6,1:500,,A/C

Misc : SOIL

ALS Vial: 14 Sample Multiplier: 1

Integration File signal 1: events.e
Integration File signal 2: events2.e
Quant Time: Nov 01 10:17:01 2010

Quant Method: C:\msdchem\1\METHODS\PCB100910.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254


QLast Update : Tue Oct 12 11:50:46 2010 Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : $30 \text{ m} \times 0.25 \text{mm} \times 0$ Signal #2 Info : $30 \text{ m} \times 0.25 \text{mm} \times 0.25$ um



Analytics Report 68098 page 26 of 37



Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

KCL Mock Up

Project Number:

102010

Field Sample ID:

10186 KCL 110 ext

November 1, 2010

SAMPLE DATA

Lab Sample ID:

68098-7

Matrix:

Solid

Percent Solid:

100

Dilution Factor:

424000

Collection Date:

10/18/10

Lab Receipt Date:

10/21/10

Extraction Date:

10/25/10

Analysis Date:

10/29/10

PCB ANALYTICAL RESULTS

	COMPOUND	Quantitation Limit μ g/kg	Results μg/kg
	PCB-1016	13992000	Ü
	PCB-1221	13992000	U .
alam eero o or o eero o sasiissii	PCB-1232	13992000	oo
	PCB-1242	13992000	\mathbf{U}
	PCB-1248	13992000	U
	PCB-1254	13992000	213000000
	PCB-1260	13992000	U

Surrogate	Standard	Recovery

2,4,5,6-Tetrachloro-m-xylene

%

Decachlorobiphenyl

: %

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS:

Results are expressed on a dry weight basis.

* The surrogates were diluted out.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68098

GC Column #1: STX-CLPesticides I

Sample: 68098-7,1:50000,,A/C

Column ID: 0.25 mm

Data File: M32518.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 423728.8

Column ID: 0.25 mm

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	187119788	213298602	13.1	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:	

^{*} Values outside QC limits

Data Path : C:\msdchem\1\DATA\102910-M\

Data File: M32518.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 29 Oct 2010 5:16 pm

Operator : JK

Sample : 68098-7,1:50000,,A/C

Misc : SOIL

ALS Vial : 21 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Nov 01 10:17:15 2010

Quant Method: C:\msdchem\1\METHODS\PCB100910.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update: Tue Oct 12 11:50:46 2010


Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um





PCB QC FORMS

AnalyticsLLC:AEL Documents LLC:Pkg Dividers:PCBQC.doc

PCB SOIL SYSTEM MONITORING COMPOUNDS SUMMARY

SDG: 68098

Instrument ID: M

GC Column #1: STX-CLPesticides I

Column ID: 0.25 mm

GC Column #2: STX-CLPesticides II

Column ID: 0.25 mm

B102510PSOX,RR,,A/C 96 68 100 83 L102510PSOX,RR,,A/C 94 67 99 79 LD102510PSOX,RR,,A/C 95 68 100 73 68098-6,1:500,,A/C D D D D D 68098-1,1:50000,,A/C D D D D D 68098-2,1:100000,,A/C D D D D D 68098-3,1:50000,,A/C D D D D D 68098-4,1:100000,,A/C D D D D 68098-5,1:100000,,A/C D D D D			Column	#1			Column	ı #2	
L102510PSOX,RR,,A/C 94 67 99 79 LD102510PSOX,RR,,A/C 95 68 100 73 68098-6,1:500,,A/C D D D D 68098-1,1:50000,,A/C D D D D 68098-2,1:100000,,A/C D D D D 68098-3,1:50000,,A/C D D D D 68098-4,1:100000,,A/C D D D D 68098-5,1:100000,,A/C D D D D	SAMPLE ID	SMC 1 (%)	#	SMC 2 (%)	#	SMC 1 (%)	#	SMC 2 (%)	#
L102510PSOX,RR,,A/C 94 67 99 79 LD102510PSOX,RR,,A/C 95 68 100 73 68098-6,1:500,,A/C D D D D 68098-1,1:50000,,A/C D D D D 68098-2,1:100000,,A/C D D D D 68098-3,1:50000,,A/C D D D D 68098-4,1:100000,,A/C D D D D 68098-5,1:100000,,A/C D D D D	B102510PSOX,RR,,A/C	96		68		100		83	
LD102510PSOX,RR,,A/c 95 68 100 73 68098-6,1:500,,A/C D D D D 68098-1,1:50000,,A/C D D D D 68098-2,1:100000,,A/C D D D D 68098-3,1:50000,,A/C D D D D 68098-4,1:100000,,A/C D D D D 68098-5,1:100000,,A/C D D D D	L102510PSOX,RR,,A/C	94		67		99		79	
68098-1,1:50000,,A/C D D D D 68098-2,1:100000,,A/C D D D D 68098-3,1:50000,,A/C D D D D 68098-4,1:100000,,A/C D D D D 68098-4,1:100000,,A/C D D D D 68098-5,1:100000,,A/C D D D D	LD102510PSOX,RR,,A/0	95		68		100		73	
68098-2,1:100000,,A/C D D D D 68098-3,1:50000,,A/C D D D D 68098-4,1:100000,,A/C D D D D 68098-5,1:100000,,A/C D D D D	68098-6,1:500,,A/C	D		D		D		D	
68098-3,1:50000,,A/C D D D D 68098-4,1:100000,,A/C D D D D 68098-5,1:100000,,A/C D D D D	68098-1,1:50000,,A/C	D		D					
68098-4,1:100000,,A/C D D D D D D D D D D D D D D D D D D D	68098-2,1:100000,,A/C	D							
68098-5,1:100000,,A/C D D D	68098-3,1:50000,,A/C	D							
	68098-4,1:100000,,A/C	D		D		D		D	
68098-7,1:50000A/C D D D D D	68098-5,1:100000,,A/C	D		D					
	68098-7,1:50000,,A/C	D		D		D		D	

	Lower	Upper
	Limit	Limit
SMC #1 = TCX	40	130
SMC #2 = DCB	40	130

- # Column to be used to flag recovery values outside of QC limits
- * Values outside QC limits
- D System Monitoring Compound diluted out

PCB SOIL LABORATORY CONTROL SAMPLE/DUPLICATE PERCENT RECOVERY

Instrument ID: M

GC Column #1: STX-CLPesticides I

SDG: 68098

Column ID: 0.25 mm

Non-spiked sample: B102510PSOX,RR,,A/C

GC Column #2: STX-CLPesticides II

Spike: L102510PSOX,RR,,A/C

Column ID: 0.25 mm

Spike duplicate: LD102510PSOX,RR,,A/C

	LCS SPIKE	LCSD SPIKE	LOWER	UPPER	RPD	NON-SPIKE	SPIKE	SPIKE		SPIKE DUP	SPIKE DUP			
COMPOUND	ADDED (ug/kg)	ADDED (ug/kg)	LIMIT	LIMIT	LIMIT	RESULT (ug/kg)	RESULT (ug/kg)	% REC	#	RESULT (ug/kg)	% REC	#	RPD	#
PCB 1016	200	200	65	140	30	0	237	118		245	122		3.2	
PCB 1260	200	200	60	130	30	0	240	120		259	130		7.5	
PCB 1016 #2	200	200	65	140	30	0	259	130		265	132		2,0	
PCB 1260 #2	200	200	60	130	30	0	256	128		259	130		1.1	

Column to be used to flag recovery and RPD values outside of QC limits

LCS/LCSD spike added values have been weight adjusted.

Non-spike result of "0" used in place of "U" to allow calculation of spike recovery.

Comments	

^{*} Values outside QC limits



CHAIN OF CUSTODIES

Chain Of Custody Form

				1000U FILE DOOD	-				-
) 	<u> </u>	laboratory		Portsmouth, NH 03801 Phone (603) 436-5111 Fax (603) 430-2151	Sample 1) Shipp	Samples were:	Samples were: 1) Shipped or hand-delivered		
102010	102010 Proj. Name:	ne:	KCL Mock up	Matrix Key:	2) Temp	2) Temp blank °C	S. 5.	\prec	刘
Company:	Yale EHS	S		C = Concrete WP = Wipe	3) Recei	- ved in god	3) Received in good condition Y or N	5	5
	Steve Mo	Steve Murdzia/Rob Klein	Klein	WW = Wastewater SW = Surface Water		4) pH checked by:	S	P	2
	135 Colle	135 College St, Ste 100	100	GW = Groundwater DW = Drinking Water		5) Labels checked by:	by: 1805 10/21/10	<u>5</u>	8₹.
	New Hav	New Haven, CT 06510	510	S = Soil/Sludge O = Oil					O
203-737-4453	PO#	Quote #	e#	E = Extract X = Other	Container Key	r Key		bəviə bəviə) bəviə
Sampler (Signature):				Preservation	P=plastic	G=glass			
Station Identification	Sample Date	Sample Time	Analysis	Methanol H ^S 2O [†] HNO ³ † _o C Nubres	Other Matrix	Container number/type	pH Analytics Sample #		00
10181 KCL 114 int	18-Oct NA	NA	PCB in caulk		solid	a	1-86089	A A/	2
10182 KCL 110 int	AN ####	NA A	EPA method 8082		solid	a	B	miT SmiT	, miT
10183 KCL 110 int	18-Oct NA	NA	3540C Soxhlet extract		solid	d	3		<
10184KCL 114 ext	18-Oct NA	NA			solid	d	<u> </u>	9/) /
10185 KCL 110 ext	18-Oct NA	NA			solid	۵	S	04	0/0
10186 KCLext glaz	18-Oct NA	NA					0	Date Date)/ eteO
* 1018/2 KCL 110 ext	7	NA					registross. state		
	Commer	Comments / Instructions:			Pre	Project Requirements:	rements:		
Email Results to: rob.klein@yale.edu	Somp	Sample "10186 Kc listed on COC but 18	LIIO EXT meterat	shipment 10/21/10	Report Type	State: NH	State Standard:	bies	XTX
Standard Priority Due Date Due Date	W St	Sample mane of steve M. @ You	45 par Ste 0/ -cp/ Shanged as) 2	Star	≥ <u></u>	EDD Type:	mes va padainpula	Relinquished By:

ANALYTICS SAMPLE RECEIPT CHECKLIST



AEL LAB#: 68098	COOLER NUMBER:	<u> </u>	
client: <u>Vale</u>	NUMBER OF COOLERS:	N/A	
PROJECT: KCL Mock UP	DATE RECEIVED:	10/21/10	
A: PRELIMINARY EXAMINATION:	DATE COOLER OPENED:	10/21/10	
1. Cooler received by(initials):	Date Received:	10/21/10	
2. Circle one: Hand delivered	Shipped	,	
(If so, skip 3) 3. Did cooler come with a shipping slip?	\bigcirc	N	
3a. Enter carrier name and airbill number here:	1 Ex 7963 629	88 9443	
4. Were custody seals on the outside of cooler? How many & where: Seal Date:	Y Seal Name:	N	
5. Did the custody seals arrive unbroken and intact upon arrival?	Y	NA	
6. COC#: N/A			sompler
7. Were Custody papers filled out properly (ink,signed, etc)?	Y	N	sampler signature
8. Were custody papers sealed in a plastic bag?	Y	N	J
9. Did you sign the COC in the appropriate place?	Y	N	
10. Was the project identifiable from the COC papers?	Y	N	
11. Was enough ice used to chill the cooler? Y N	Temp. of cooler:	19.3°	
B. Log-In: Date samples were logged in:	<u>ву:</u> СР	<u>.</u>	
12. Type of packing in cooler(bubble wrap, popcorn)	Y	N	
13. Were all bottles sealed in separate plastic bags?	(Y)	N	
14. Did all bottles arrive unbroken and were labels in good condition?	Y	N	
15. Were all bottle labels complete(ID,Date,time,etc.)	Y	N- No	s time listed
16. Did all bottle labels agree with custody papers?	Y	N	n cac/ labels
17. Were the correct containers used for the tests indicated:	Y	N-PU	8 needs to
18. Were samples received at the correct pH?	Y		rin Glass long
19. Was sufficient amount of sample sent for the tests indicated?	Ŷ	N	of plastic bag
20. Were bubbles absent in VOA samples?	Y	(N/A)	
If NO, List Sample ID's and Lab #s:			
21. Laboratory labeling verified by (initials):	Date:	10/21/10	

10-21-2010

T-481 P.001/004 F-880



SAMPLE RECEIPT NON-COMPLIANCE NOTIFICATION (SENT VIA FACSIMILE)

DATE_ 10/64/10 F	ROM_ (asey
FAX CONTACT Steve Murdizia Rob F.	AX NUMBER <u>203-785-7</u> 568
CLIENT YOR EHS L	AB NUMBER 68098
The exceptions noted below were found on the sample(s) re Custody (COC) form. These exceptions may render the dat will continue to proceed with the analysis of the sample(s) t analysis. This document may become part of the final repor	a results as non-defensible. Analytics unless notified in writing to stop the
Please check the appropriate box and sign below an at 603-430-2151.	nd fax back to "Sample Receipt"
Exceptions: Sample(s) not on ice or not at 4°C ± 2°C - So	amples @ 19.3°
Sample(s) received unpreserved or not at the property (pH was adjusted at the laboratory)	oper pH.
Sample(s) received in incorrect containers -	Blass and be in Yoz'jou
Insufficient sample volume received (Detection limits may be elevated due to this ex	2
Trip Blank provided in cooler, but not recorded	on the chain of custody
Other: Sample "10186 KCL 110 Ext"	is not listed on cac but
Acknowledgment:	
Please do not analyze/report Trip Blank, pro	ceed with other analyses
Proceed with the analysis.	
Please stop the analysis and wait for further i	
Date: 1024/U	e: GRANN MURDZIA

AnalyticsLLC:ABL Documents LLC:* B_FORMS:sample receipt noncompliance

Rev. 0, 3/10/03

FedEx First Overnight*

147918 REV 8/08 RRD

- Frank Evaroce® Shipping Label here.

Ship Date: 20OCT 10 Activit. 0.5 LB CAD: 6271659/WBUS0200

From: Origin ID: EFBA (203) 785-3550 Maritim Meaner Yale University 135 College St

Delivery Address Bar Cod

Ref# KCL Invoice# PO# Dept#

BALL SENDER

FIRST OVERNIGHT THU - 21 OCT DSR

03801

NH-US MHT



Analytics Environmental Laboratory 195 Commerce Way Suite E Portsmouth, NH 03801 SHIP TO: (603) 436-5111 Now Haven, CT 86518

Express

Analytics Report 68098 page

of 37 37



195 Commerce Way Suite E Portsmouth, New Hampshire 03801 603-436-5111 Fax 603-430-2151 800-929-9906 www.analyticslab.com

December 2, 2010

Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

RE: Analytical Results Case Narrative

Analytics # 68444

Dear Mr. Klein;

Enclosed please find the analytical results for samples submitted for the above-mentioned project. The attached Cover Page lists the sample IDs, Lab tracking numbers and collection dates for the samples included in this deliverable.

Samples were analyzed Polychlorinated Biphenyls (PCBs) by EPA Method 8082.

Unless otherwise noted in the Non-conformance Summary listed below, all of the quality control (QC) criteria including initial calibration, calibration verification, surrogate recovery, holding time and method accuracy/precision for these analyses were within acceptable limits.

This Level II data package has been assembled in the following order:

Case Narrative/Non-Conformance Summary
Sample Log Sheet - Cover Page
PCB Form 1 Data Sheet for Samples and Blanks
Chromatograms
PCB Form 10 Confirmation Results
PCB Form 3 MS/MSD (LCS) Recoveries
Chain of Custody (COC) Forms

QC NON-CONFORMANCE SUMMARY

Sample Receipt:

The cooler temperature upon receipt was 8.2° C upon receipt at the laboratory. The client was contacted an instructed the laboratory to proceed with analysis.

PCBs by EPA Method 8082:

Samples 68444-1, 68444-2, 68444-4, 68444-7 and 68444-8 required dilution due to concentrations of PCBs that exceeded the calibration range of the instrument.

Sincerely,

ANALYTICS Environmental Laboratory, LLC

Mullilli W Stephen Knollmeyer Laboratory Director



195 Commerce Way Suite E Portsmouth, New Hampshire 03801 603-436-5111 Fax 603-430-2151 800-929-9906 www.analyticslab.com

Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510 Report Number: 68444

Revision: Rev. 0

Re:

Enclosed are the results of the analyses on your sample(s). Samples were received on 23 November 2010 and analyzed for the tests listed. Samples were received in acceptable condition, with the exceptions noted below or on the chain of custody. These results pertain to samples as received by the laboratory and for the analytical tests requested on the chain of custody. The results reported herein conform to the most current NELAC standards, where applicable, unless otherwise narrated in the body of the report. Please see individual reports for specific methodologies and references.

Lab Number	Sample Date	Station Location	<u>Analysis</u>	Comments
68444-1	10/16/10	1116-1 KCL	EPA 8082 (PCBs only)	
68444-2	10/16/10	1116-2 KCL	EPA 8082 (PCBs only)	
68444-3	10/17/10	1117-1 KCL	EPA 8082 (PCBs only)	
68444-4	10/17/10	1117-2 KCL	EPA 8082 (PCBs only)	
68444-5	10/17/10	1117-3 KCL	EPA 8082 (PCBs only)	
68444-6	10/17/10	1117-4 KCL	EPA 8082 (PCBs only)	
68444-7	10/17/10	1117-5 KCL	EPA 8082 (PCBs only)	
68444-8	10/17/10	1117-6 KCL	EPA 8082 (PCBs only)	

Sample Receipt Exceptions: None

Analytics Environmental Laboratory is certified by the states of New Hampshire, Maine, Massachusetts, Connecticut, Rhode Island, Virginia, Maryland, and is accredited by the Department of Defense (DOD) ELAP program. A list of actual certified parameters is available upon request.

If you have any questions on these results, please do not hesitate to contact us

Authorized signature

tephen L. Knollmeyer Lab. Director

Date

This report shall not be reproduced, except in full, without the written consent of Analytics Environmental Laboratory, LLC.



Surrogate Compound Limits

	Matrix:	Aqueous	Solid	
	Units:	% Recovery	% Recovery	Method
Volatile Organic Compounds - D	rinking Wa	ter		
I,4-Difluorobenzene		70-130		EPA 524.2
Bromofluorobenzene		70-130		LIA 324.2
1,2-Dichlorobenzene-d4		70-130		
,		10 100		
Volatile Organic Compounds				
1,2-Dichloroethane-d4		70-120	70-120	EPA 624/8260B
Toluene-d8		85-120	85-120	
Bromofluorobenzene		75-120	75-120	
Semi-Volatile Organic Compound	de			•
2-Fluorophenol	43	20-110	35-105	EPA 625/8270C
d5-Phenol		15-110	40-100	EFA 023/82/0C
d5-nitrobenzene		40-110	35-100	
2-Fluorobiphenyl		50-110	45-105	
2,4,6-Tribromophenol		40-110	40-125	
d14-p-terphenyl		50-130	30-125	
or prosphery:		30-130	30-1.23	
PAH's by SIM				
d5-nitrobenzene		21-110	35-110	EPA 8270C
2-Fluorobiphenyl		36-121	45-105	
d14-p-terphenyl		33-141	30-125	
Pesticides and PCBs				
2,4,5,6-Tetrachloro-m-xylene (TCX))	46-122	40-130	EPA 608/8082
Decachlorobiphenyl (DCB)	,	40-135	40-130	LIA 000/8082
Herbicides				
Dichloroacetic acid (DCAA)		30-150	30-150	
Gasoline Range Organics/TPH Ga	soline			
Trifluorotoluene TFT (FID)		60-140	60-140	MEDEP 4217/EPA 8015
Bromofluorobenzene (BFB) (FID)		60-140	60-140	MDDEI 421//EIA 0015
Trifluorotoluene TFT (PID)		60-140	60-140	
Bromofluorobenzene (BFB) (PID)		60-140	60-140	
Diesel Range Organics/TPH Diesel				
m-terphenyl		60-140	60-140	MEDEP 4125/EPA 8015/CT ETPH
Volatile Petroleum Hydrocarbons				
2,5-Dibromotoluene (PID)		70-130	70-130	MADEP VPH May 2004 Rev1.1
2,5-Dibromotoluene (FID)		70-130	70-130	MADER VPH May 2004 Rev1.1
, ,		-	. •	
Extracatable Petroleum Hydrocarb	ons			
1-chloro-octadecane (aliphatic)		40-140	40-140	MADEP EPH May 2004 Rev1.1
o-Terphenyl (aromatic)		40-140	40-140	
2-Fluorobiphenyl (Fractionation)		40-140	40-140	
2-Bromonaphthalene (fractionation)		40-140	40-140	



PCB DATA SUMMARIES



Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

Project Number:

Field Sample ID: Lab QC

December 2, 2010

SAMPLE DATA

Lab Sample ID: B112310PSOX

Matrix: Soil
Percent Solid: N/A
Dilution Factor: 1.0

Collection Date: Lab Receipt Date:

Extraction Date: 11/23/10 **Analysis Date:** 11/24/10

PCB ANALYTICAL RESULTS						
COMPOUND	Quantitation Limit μg/kg	Results μg/kg				
PCB-1016	33	U				
PCB-1221	33	U				
PCB-1232	33	U				
PCB-1242	33	U				
PCB-1248	33	U				
PCB-1254	33	U				
PCB-1260	33	U				
	Surrogate Standard Recovery					
	2,4,5,6-Tetrachloro-m-xylene 88 Decachlorobiphenyl 64	% %				
U=Undetected J	=Estimated E=Exceeds Calibration Range	B=Detected in				

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

PCB Report

Authorized signature



Data Path : C:\msdchem\1\DATA\112410-M\

Data File: M33431B.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 24 Nov 2010 11:50 am

Operator : JK

Sample : B112310PSOX,,A/C

Misc : SOIL

ALS Vial : 6 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e

Quant Time: Nov 29 08:50:29 2010

Quant Method: C:\msdchem\1\METHODS\PCB110310.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254


QLast Update: Wed Nov 03 16:48:45 2010 Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

Project Number:

Field Sample ID: 1116-1 KCL

December 2, 2010

SAMPLE DATA

11/24/10

Lab Sample ID:68444-1Matrix:SolidPercent Solid:100Dilution Factor:20Collection Date:10/16/10Lab Receipt Date:11/23/10Extraction Date:11/23/10

Analysis Date:

	PCB ANALYTICAL RESULTS						
COMPOUND	Quantitation Limit μg/kg	Results μg/kg					
PCB-1016	660	U					
PCB-1221	660	U					
PCB-1232	660	U					
PCB-1242	660	U					
PCB-1248	660	U					
PCB-1254	660	10500					
PCB-1260	660	U					
S	urrogate Standard Recovery						
2,4,	5,6-Tetrachloro-m-xylene * Decachlorobiphenyl *	%					
U=Undetected J=Estimat	ed E=Exceeds Calibration Range	B=Detected in					

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

* The surrogates were diluted out.

PCB Report

Authorized signature Mullull

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68444

GC Column #1: STX-CLPesticides I

Sample: 68444-1,1:20,,A/C

Column ID: 0.25 mm

Data File: M33442.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 20.0

Column ID: 0.25 mm

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	10533	10485	0.5	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:

^{*} Values outside QC limits

Data Path : C:\msdchem\1\DATA\112410-M\

Data File: M33442.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 24 Nov 2010 1:43 pm

Operator : JK

Sample : 68444-1,1:20,,A/C

Misc : SOIL

ALS Vial : 17 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Nov 29 08:50:52 2010

Quant Method : C:\msdchem\1\METHODS\PCB110310.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update : Wed Nov 03 16:48:45 2010


Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um




File :C:\msdchem\1\DATA\112410-M\M33442.D

Operator : JK

Acquired : 24 Nov 2010 1:43 pm using AcqMethod PEST.M

Instrument : Instrument M
Sample Name: 68444-1,1:20,,A/C

Misc Info : SOIL Vial Number: 17





Mr. Rob Klein Yale University Environmental Health & 135 Čollege Street New Haven CT 06510

December 2, 2010 SAMPLE DATA

Lab Sample ID:

68444-2

CLIENT SAMPLE ID

Matrix:

Solid

99

Percent Solid:

50

Dilution Factor:

10/16/10

Collection Date: Lab Receipt Date:

11/23/10

Extraction Date:

11/23/10

Analysis Date:

11/24/10

Field Sample ID: 1116-2 KCL

Project Name:

Project Number:

PCB ANALYTICAL RESULTS

COMPOUND	Quantitation Limit µg/kg	Results μg/kg
PCB-1016	1650	U
PCB-1221	1650	U
PCB-1232	1650	U
PCB-1242	1650	U
PCB-1248	1650	U
PCB-1254	1650	13500
PCB-1260	1650	U

Surrogate Standard Recovery

2,4,5,6-Tetrachloro-m-xylene

Decachlorobiphenyl

%

%

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS:

Results are expressed on a dry weight basis.

* The surrogates were diluted out.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68444

GC Column #1: STX-CLPesticides I

Sample: 68444-2,1:50,,A/C

Column ID: 0.25 mm

Data File: M33443.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 50.3

Column ID: 0.25 mm

C 1		11
1 0	umn	.11
	umm	$\tau \tau$

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	13515	13545	0.2	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:	

^{*} Values outside QC limits

Data File: M33443.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 24 Nov 2010 1:53 pm

Operator : JK

Sample : 68444-2,1:50,A/C

Misc : SOIL

ALS Vial : 18 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Nov 29 08:50:54 2010

Quant Method: C:\msdchem\1\METHODS\PCB110310.M


Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update : Wed Nov 03 16:48:45 2010 Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um



Analytics Report 68444 page 14 of 40



Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

Project Number:

Field Sample ID: 1117-1 KCL

December 2, 2010

SAMPLE DATA

Lab Sample ID:68444-3Matrix:SolidPercent Solid:100Dilution Factor:1.0Collection Date:10/17/10Lab Receipt Date:11/23/10Extraction Date:11/23/10

Analysis Date: 11/24/10

PCB ANALYTICAL RESULTS			
COMPOUND	Quantitation Limit μg/kg	Results $\mu g/kg$	
PCB-1016	33	U	
PCB-1221	33	U	
PCB-1232	33	U	
PCB-1242	33	U	
PCB-1248	33	U	
PCB-1254	33	855	
PCB-1260	33	U	
	Surrogate Standard Recovery		
	2,4,5,6-Tetrachloro-m-xylene 101 Decachlorobiphenyl 63	% %	
U=Undetected	J=Estimated E=Exceeds Calibration Rang	ge B=Detected in	

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68444

GC Column #1: STX-CLPesticides I

Sample: 68444-3,,A/C

Column ID: 0.25 mm

Data File: M33436.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 1.0

Column ID: 0.25 mm

Co	lumn	#

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	855	836	2.2	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:	

^{*} Values outside QC limits

Data Path : C:\msdchem\1\DATA\112410-M\

Data File: M33436.D

Signal(s) : Signal #1: ECD1A.ch Signal #2: ECD2B.ch Acq On : 24 Nov 2010 12:41 pm

: JK Operator

: 68444-3,,A/C Sample

Misc : SOIL

ALS Vial : 11 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Nov 29 08:50:40 2010

Quant Method : C:\msdchem\1\METHODS\PCB110310.M


Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254 QLast Update : Wed Nov 03 16:48:45 2010 Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um




File :C:\msdchem\1\DATA\112410-M\M33436.D

Operator : JK

Acquired : 24 Nov 2010 12:41 pm using AcqMethod PEST.M

Instrument : Instrument M
Sample Name: 68444-3,,A/C

Misc Info : SOIL Vial Number: 11





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

Project Number:

Field Sample ID:

1117-2 KCL

December 2, 2010

SAMPLE DATA

68444-4 Lab Sample ID:

Matrix:

Solid

Percent Solid:

100

Dilution Factor:

5.0

Collection Date: Lab Receipt Date: 10/17/10

Extraction Date:

11/23/10 11/23/10

Analysis Date:

11/24/10

PCB ANALYTICAL RESULTS

COMPOUND	Quantitation Limit μg/kg	Results μg/kg
PCB-1016	170	U
PCB-1221	170	U
PCB-1232	170	<u>U</u>
PCB-1242	170	U
PCB-1248	170	U
PCB-1254	170	2600
PCB-1260	170	U

Surrogate Standard	đ	Recovery
--------------------	---	----------

2,4,5,6-Tetrachloro-m-xylene

94 %

Decachlorobiphenyl

73 %

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M SDG: 68444

GC Column #1: STX-CLPesticides I Sample: 68444-4,1:5,,A/C

Column ID: 0.25 mm Data File: M33444.D

GC Column #2: STX-CLPesticides II Dilution Factor: 5.0

Column ID: 0.25 mm

	Column #1	Column #2		
COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	2502	2598	3.8	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:	

^{*} Values outside QC limits

Data Path : C:\msdchem\1\DATA\112410-M\

Data File : M33444.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch Acq On : 24 Nov 2010 2:03 pm

: JK Operator

: 68444-4,1:5,,A/C Sample

Misc : SOIL

Sample Multiplier: 1 ALS Vial : 19

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Nov 29 08:50:56 2010


Quant Method: C:\msdchem\1\METHODS\PCB110310.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254 QLast Update : Wed Nov 03 16:48:45 2010 Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

Project Number:

Field Sample ID:

1117-3 KCL

December 2, 2010

SAMPLE DATA

Lab Sample ID:

68444-5

Matrix:

Solid

Percent Solid:

100

Dilution Factor:

1.0

Collection Date:

10/17/10

Lab Receipt Date:

11/23/10 11/23/10

Extraction Date: Analysis Date:

11/24/10

	PCB ANALYTICAL RESULTS		
COMPOUND	Quantitation Limit μ g/kg	Results $\mu \mathrm{g/kg}$	
PCB-1016	33	U	
PCB-1221	33	U	
PCB-1232	33	<u>U</u>	
PCB-1242	33	U	
PCB-1248	33	U	
PCB-1254	33	615	
PCB-1260	33	U	
	Surrogate Standard Recovery		
	2,4,5,6-Tetrachloro-m-xylene 87 Decachlorobiphenyl 63	% %	
U=Undetected	J=Estimated E=Exceeds Calibration Range	e B=Detected in	

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68444

GC Column #1: STX-CLPesticides I

Sample: 68444-5,,A/C

Column ID: 0.25 mm

Data File: M33438.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 1.0

Column ID: 0.25 mm

Cal	lumn	44.1
-00	шшш	#1

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	615	581	5.6	

Column to be used to flag RPD values greater than QC limit of 40%

* Values outside QC limits

Comments:

Data Path : C:\msdchem\1\DATA\112410-M\

Data File : M33438.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 24 Nov 2010 1:02 pm

Operator : JK

Sample : 68444-5,,A/C

Misc : SOIL

ALS Vial : 13 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Nov 29 08:50:44 2010

Quant Method : C:\msdchem\1\METHODS\PCB110310.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254


QLast Update: Wed Nov 03 16:48:45 2010 Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase : STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m \times 0.25mm \times 0 Signal #2 Info : 30 m \times 0.25mm \times 0.25 um





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

Project Number:

Field Sample ID: 1117-4 KCL

December 2, 2010

SAMPLE DATA

Lab Sample ID: 68444-6 Matrix: Solid 100 **Percent Solid: Dilution Factor:** 1.0 **Collection Date:** 10/17/10 Lab Receipt Date: 11/23/10 **Extraction Date:** 11/23/10 **Analysis Date:** 11/24/10

	PCB ANALYTICAL RESUL	TS
COMPOUND	Quantitation Limit μg/kg	Results μg/kg
PCB-1016	33	U
PCB-1221	33	U
PCB-1232	33	U
PCB-1242	33	U
PCB-1248	33	U
PCB-1254	33	45
PCB-1260	33	U
	Surrogate Standard Recovery	
	2,4,5,6-Tetrachloro-m-xylene 83 Decachlorobiphenyl 63	% %
U=Undetected J=	Estimated E=Exceeds Calibration Range	B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

PCB Report

Authorized signature

Mullell

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68444

GC Column #1: STX-CLPesticides I

Sample: 68444-6,,A/C

Column ID: 0.25 mm

Data File: M33439.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 1.0

Column ID: 0.25 mm

	Column #1	Column #2		
COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	33	45	31.1	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:	

^{*} Values outside QC limits

Data Path : C:\msdchem\1\DATA\112410-M\

Data File: M33439.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

: 24 Nov 2010 Acq On 1:12 pm

: JK Operator

Sample : 68444-6,,A/C

: SOIL Misc

ALS Vial : 14 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Nov 29 08:50:46 2010

Quant Method : C:\msdchem\1\METHODS\PCB110310.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254 QLast Update : Wed Nov 03 16:48:45 2010


Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info $: 30 \text{ m} \times 0.25 \text{mm} \times 0$ Signal #2 Info $: 30 \text{ m} \times 0.25 \text{mm} \times 0.25$ um





1117-5 KCL

Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

Project Number:

Field Sample ID:

December 2, 2010 SAMPLE DATA

Lab Sample ID: 68444-7 Matrix: Solid

Percent Solid:

99

Dilution Factor:

2980 **Collection Date:** 10/17/10

Lab Receipt Date:

11/23/10

Extraction Date:

11/23/10

Analysis Date:

11/24/10

PCB ANALYTICAL RESULTS

COMPOUND	Quantitation Limit μg/kg	Results μg/kg
PCB-1016	98300	U
PCB-1221	98300	U
PCB-1232	98300	U
PCB-1242	98300	U
PCB-1248	98300	U
PCB-1254	98300	1660000
PCB-1260	98300	U

Surrogate Standard Recovery

2,4,5,6-Tetrachloro-m-xylene

Decachlorobiphenyl %

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

PCB Report

%

Authorized signature Mullill

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68444

GC Column #1: STX-CLPesticides I

Sample: 68444-7,1:1000,,A/C

Column ID: 0.25 mm

Data File: M33445.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 2976.4

Column ID: 0.25 mm

Column #1

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	1659715	1534667	7.8	

Column to be used to flag RPD values greater than QC limit of 40%

* Values outside QC limits

Comments:	

Data Path : C:\msdchem\1\DATA\112410-M\

Data File : M33445.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 24 Nov 2010 2:13 pm

Operator : JK

Sample : 68444-7,1:1000,,A/C

Misc : SOIL

ALS Vial : 20 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Ouant Time: Nov 29 08:50:58 2010

Quant Method : C:\msdchem\1\METHODS\PCB110310.M


Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update: Wed Nov 03 16:48:45 2010 Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

December 2, 2010 **SAMPLE DATA**

Lab Sample ID: 68444-8
Matrix: Solid
Percent Solid: 98
Dilution Factor: 55

 Collection Date:
 10/17/10

 Lab Receipt Date:
 11/23/10

 Extraction Date:
 11/23/10

 Analysis Date:
 11/24/10

CLIENT SAMPLE ID

Project Name:

Project Number:

Field Sample ID: 1117-6 KCL

PCB ANALYTICAL RESULTS

COMPOUND	Quantitation Limit μ g/kg	Results $\mu g/kg$
PCB-1016	1820	U
PCB-1221	1820	U
PCB-1232	1820	U
PCB-1242	1820	U
PCB-1248	1820	U
PCB-1254	1820	31700
PCB-1260	1820	U

Surrogate Standard Recovery

2,4,5,6-Tetrachloro-m-xylene * %

Decachlorobiphenyl * %

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

* The surrogates were diluted out.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M SDG: 68444

GC Column #1: STX-CLPesticides I Sample: 68444-8,1:20,,A/C

Column ID: 0.25 mm Data File: M33447.D

GC Column #2: STX-CLPesticides II Dilution Factor: 55.0

Column ID: 0.25 mm

	Column #1	Column #2		
COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	31664	29655	6.6	

Column to be used to flag RPD values greater than QC limit of 40%

* Values outside QC limits

-			
Comments:			

Data Path : C:\msdchem\1\DATA\112410-M\

Data File : M33447.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 24 Nov 2010 2:34 pm

Operator : JK

Sample : 68444-8,1:20,,A/C

Misc : SOIL

ALS Vial : 22 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Ouant Time: Nov 29 08:51:02 2010

Quant Method : C:\msdchem\1\METHODS\PCB110310.M


Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update: Wed Nov 03 16:48:45 2010 Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase : STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um





PCB QC FORMS

PCB SOIL SYSTEM MONITORING COMPOUNDS SUMMARY

Instrument ID: M

GC Column #1: STX-CLPesticides I

SDG: 68444

Column ID: 0.25 mm

GC Column #2: STX-CLPesticides II

Column ID: 0.25 mm

		Column	#1		Column	n #2		
SAMPLE ID	SMC 1 (%)	#	SMC 2 (%)	#	SMC 1 (%)	#	SMC 2 (%)	#
B112310PSOX,,A/C	88		64		84		61	
L112310PSOX,,A/C	89		64		86		61	
LD112310PSOX,,A/C	88		65		85		61	······································
68444-3,,A/C	113		64		101		63	
68444-5,,A/C	87		63		83		59	
68444-6,,A/C	83		63		80		59	
68444-1,1:20,,A/C	D		D		D		D	
68444-2,1:50,,A/C	D		D		D		D	
68444-4,1:5,,A/C	94		73		84		64	
68444-7,1:1000,,A/C	D		D		D		D	
68444-8,1:20,,A/C	D		D		D		D	
		_						
							,	
ł								
	·							

	Lower	Upper
	Limit	Limit
SMC #1 = TCX	40	130
SMC #2 = DCB	40	130

- # Column to be used to flag recovery values outside of QC limits
- * Values outside QC limits
- D System Monitoring Compound diluted out

PCB SOIL LABORATORY CONTROL SAMPLE/DUPLICATE PERCENT RECOVERY

Instrument ID: M

GC Column #1: STX-CLPesticides I

SDG: 68444

Column ID: 0.25 mm

Non-spiked sample: B112310PSOX,,A/C

GC Column #2: STX-CLPesticides II

Spike: L112310PSOX,,A/C

Column ID: 0.25 mm

Spike duplicate: LD112310PSOX,,A/C

	LCS SPIKE	LCSD SPIKE	LOWER	UPPER	RPD	NON-SPIKE	SPIKE	SPIKE		SPIKE DUP	SPIKE DUP			
COMPOUND	ADDED (ug/kg)	ADDED (ug/kg)	LIMIT	LIMIT	LIMIT	RESULT (ug/kg)	RESULT (ug/kg)	% REC	#	RESULT (ug/kg)	% REC	#	RPD	#
PCB 1016	200	200	65	140	30	0	185	92		185	92		0.2	
PCB 1260	200	200	60	130	30	0	188	94		192	96		2.4	
PCB 1016 #2	200	200	65	140	30	0	216	108		237	118		8.9	
PCB 1260 #2	200	200	60	130	30	0	177	89		182	91		2.5	

Column to be used to flag recovery and RPD values outside of QC limits

LCS/LCSD spike added values have been weight adjusted.

Non-spike result of "0" used in place of "U" to allow calculation of spike recovery.

Comments:	

^{*} Values outside QC limits




CHAIN OF CUSTODIES

•1)!		/					bəvi	933¥	and the second s		:ewij			o constitutive	:ətsO							and the second s		***************************************	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	1
	~	m	A	W	E	Z	····	Rece	020		:emiT	01)	£2		:ete0	<u> </u>			X3	(X	24		1	Λ	/.	
	~	X)	· K	Ē	•	By:	bəvi	езеЯ	M	兄	:əmiT	0/	r	411	Date			1				tr	4M	(H	1	
For Analytics Use Only Rev. 4 03/28/08	d-delivered	Ø.2°C	od condition of N) .	by: (P 11 33 10				pH Analytics Sample #	1-12220	2	r	7	v	9	_	8	d		uirements:	State Standard:	A (eg. S-1 or GW-1)		Type: —	Page — of	
o Sandinas de la company de la	Samples were: Shipped or hand-delivered	2) Temp blank °C	3) Received in good condition		***************************************		Container Kev	Т	Containr Containr number/typ	Sur										Project Requirements:	Report Type	MCP Kevel II MA	Level III	DOD	*Fee may apply	DOB
Portsmouth, NH 03801	Phone (603) 436-5111 Fax (603) 430-2151	Matrix Key: C = Concrete	WP = Wipe	SW = Surface Water	DW = Groundwater	S = Soll/Sludge O = Oil	E = Extract X = Other	Preservation	Methanol HCF HMO ³ t _o C nubles												Re				* #	(-1
	Fax (60)	Proj. Name:	OHS .	NOTOR /ROB KLAN	86E 9T. STE100	BUSO B CA	Quote #	N N	note Sample Analysis	OC REP ADTHUM	OCT BRICK/COMMITE	DOCT EPP WETHER	oct 6082	100 3540 C	NOT SOXHLET	EXPLACION	70C			Comments / Instructions:	edu	70	LOSS OF COC as per Steve M	- OF 11/a3/10		SKNAN Gre Durge
		Project#: Proj.	Company: VHLE	Contact: Ottober Mun	Address: 185 Now	1000 HO	Phone 213-75744520#	ature):	Station Identification Date	1116-1 KCL160	116-2 Kal 1600	1.67 1. KGC		1117-3 KCL 170	117.4 KG100	2012					Email Results to:	*	around Request	Standard Priority Due Date Due Date	Lab Approval Required	finalytics/AEL Documents/AEL COC My LMB AM D)
																	* 0) i	Š							

ANALYTICS SAMPLE RECEIPT CHECKLIST



AELLAB#: 68444 CLIENT: 61e EHS PROJECT: NA	COOLER NUMBER: NUMBER OF COOLERS: DATE RECEIVED:	Client cooler 1 11/23/10
A: PRELIMINARY EXAMINATION: 1. Cooler received by(initials): March Marc	Date Received:	11/23/10
2. Circle one: Hand delivered (If so, skip 3) 3. Did cooler come with a shipping slip?	Shipped	N
3a. Enter carrier name and airbill number here:	FedEx	7964 7672 5714
4. Were custody seals on the outside of cooler? How many & where: Seal Date:	Y Seal Name:	S/A
5. Did the custody seals arrive unbroken and intact upon arrival?	Y	N
6. COC#: N/A		
7. Were Custody papers filled out properly (ink,signed, etc)?	Y	N
8. Were custody papers sealed in a plastic bag?	(Y)	N
9. Did you sign the COC in the appropriate place?	Y	N
10. Was the project identifiable from the COC papers?	Y	N
11. Was enough ice used to chill the cooler? Y N	Temp. of cooler:	3.2°C_
B. Log-In: Date samples were logged in:	Ву: 1111	-
12. Type of packing in cooler(bubble wrap, popcorn)	Y	N
13. Were all bottles sealed in separate plastic bags?	Y	N
14. Did all bottles arrive unbroken and were labels in good condition?	\bigcirc	N
15. Were all bottle labels complete(ID,Date,time.etc.)		N
16. Did all bottle labels agree with custody papers?	(Y)	N
17. Were the correct containers used for the tests indicated:	Y	N
18. Were samples received at the correct pH?	Y	N
19. Was sufficient amount of sample sent for the tests indicated?	(Y)	N
20. Were bubbles absent in VOA samples?	Y	N
If NO, List Sample ID's and Lab #s:		
21. Laboratory labeling verified by (initials):	Date:	11/23/10





195 Commerce Way Suite E Portsmouth, New Hampshire 03801 603-436-5111 Fax 603-430-2151 800-929-9906 www.analyticslab.com

February 9, 2011

Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

RE:

Analytical Results Case Narrative Analytics # 68983 KCL MOCK UP

Dear Mr. Klein;

Enclosed please find the analytical results for samples submitted for the above-mentioned project. The attached Cover Page lists the sample IDs, Lab tracking numbers and collection dates for the samples included in this deliverable.

Samples were analyzed Polychlorinated Biphenyls (PCBs) by EPA Method 8082.

Unless otherwise noted in the Non-conformance Summary listed below, all of the quality control (QC) criteria including initial calibration, calibration verification, surrogate recovery, holding time and method accuracy/precision for these analyses were within acceptable limits.

This Level II data package has been assembled in the following order:

Case Narrative/Non-Conformance Summary
Sample Log Sheet - Cover Page
PCB Form 1 Data Sheet for Samples and Blanks
Chromatograms
PCB Form 10 Confirmation Results
PCB Form 3 MS/MSD (LCS) Recoveries
Chain of Custody (COC) Forms

QC NON-CONFORMANCE SUMMARY

Sample Receipt:

The cooler temperature upon receipt was 9.9° C upon receipt at the laboratory. In addition the sample names on the container labels did not match the Chain of Custody (COC). The client was notified and instructed the lab to proceed with analysis and to report the sample names off of the container labels, not the COC.

PCBs by EPA Method 8082:

Muhlulho

The closing continuing calibration standard (M32522SC) had low Decachlorobiphenyl surrogate recovery on column#2. Column #1 was in control for all analytes. Surrogate recoveries were reported from column #1.

Sincerely,

ANALYTICS Environmental Laboratory, LLC

Stephen Knollmeyer Laboratory Director



195 Commerce Way Suite E Portsmouth, New Hampshire 03801 603-436-5111 Fax 603-430-2151 800-929-9906 www.analyticslab.com

Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510 Report Number: 68983

Revision: Rev. 0

Re: KCL MOCK UP (Project No: 102010)

Enclosed are the results of the analyses on your sample(s). Samples were received on 04 February 2011 and analyzed for the tests listed. Samples were received in acceptable condition, with the exceptions noted below or on the chain of custody. These results pertain to samples as received by the laboratory and for the analytical tests requested on the chain of custody. The results reported herein conform to the most current NELAC standards, where applicable, unless otherwise narrated in the body of the report. Please see individual reports for specific methodologies and references.

Lab Number	Sample Date	Station Location	<u>Analysis</u>	<u>Comments</u>
68983-1	02/01/11	KCL 2-1-1	EPA 8082 (PCBs only)	
68983-2	02/01/11	KCL 2-1-2	EPA 8082 (PCBs only)	
68983-3	02/01/11	KCL 2-1-3	EPA 8082 (PCBs only)	
68983-4	02/01/11	KCL 2-1-4	EPA 8082 (PCBs only)	

Sample Receipt Exceptions: Samples received at 9.9 °C which was outside laboratory acceptance criteria. The client was notified and analysis continued.

Analytics Environmental Laboratory is certified by the states of New Hampshire, Maine, Massachusetts, Connecticut, Rhode Island, Virginia, Maryland, and is accredited by the Department of Defense (DOD) ELAP program. A list of actual certified parameters is available upon request.

If you have any questions on these results, please do not hesitate to contact us.

Authorized signature

Stephen L. Knollmeyer Lab. Director

04

This report shall not be reproduced, except in full, without the written consent of Analytics Environmental Laboratory, LLC.

Date



Surrogate Compound Limits

				*
	Matrix:	Aqueous	Solid	
	Units:	% Recovery	% Recovery	Method
Volatile Organic Compounds - D	rinking Wa	ter		
1,4-Difluorobenzene		70-130		EPA 524.2
Bromofluorobenzene		70-130		13111 327.2
1,2-Dichlorobenzene-d4		70-130		
Volatile Organic Compounds				
1,2-Dichloroethane-d4		70-120	70-120	EPA 624/8260B
Toluene-d8		85-120	85-120	E171 024/0200D
Bromofluorobenzene		75-120	75-120	
Semi-Volatile Organic Compound	is			
2-Fluorophenol		20-110	35-105	EPA 625/8270C
d5-Phenol		15-110	40-100	E171 025/0270C
d5-nitrobenzene		40-110	35-100	
2-Fluorobiphenyl		50-110	45-105	
2,4,6-Tribromophenol		40-110	40-125	
d14-p-terphenyl		50-130	30-125	
PAH's by SIM				
d5-nitrobenzene		21-110	35-110	EPA 8270C
2-Fluorobiphenyl		36-121	45-105	E1A 62/0C
d14-p-terphenyl		33-141	30-125	
Pesticides and PCBs				
2,4,5,6-Tetrachloro-m-xylene (TCX))	46-122	40-130	EPA 608/8082
Decachlorobiphenyl (DCB)		40-135	40-130	111110001000
Herbicides				
Dichloroacetic acid (DCAA)		30-150	30-150	
Gasoline Range Organics/TPH Ga	soline			
Trifluorotoluene TFT (FID)		60-140	60-140	MEDEP 4217/EPA 8015
Bromofluorobenzene (BFB) (FID)		60-140	60-140	
Trifluorotoluene TFT (PID)		60-140	60-140	
Bromofluorobenzene (BFB) (PID)		60-140	60-140	
Diesel Range Organics/TPH Diesel				
m-terphenyl		60-140	60-140	MEDEP 4125/EPA 8015/CT ETPH
Volatile Petroleum Hydrocarbons				
2,5-Dibromotoluene (PID)		70-130	70-130	MADEP VPH May 2004 Rev1.1
2,5-Dibromotoluene (FID)		70-130	70-130	
Extracatable Petroleum Hydrocarb	ons			
1-chloro-octadecane (aliphatic)		40-140	40-140	MADEP EPH May 2004 Rev1.1
o-Terphenyl (aromatic)		40-140	40-140	
2-Fluorobiphenyl (Fractionation)		40-140	40-140	
2-Bromonaphthalene (fractionation)		40-140	40-140	
· ·				



PCB DATA SUMMARIES



Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

KCL MOCK UP

Project Number:

102010

Field Sample ID:

Lab QC

February 9, 2011

SAMPLE DATA

Lab Sample ID:

B020411PSOX

Matrix:

Soil

Percent Solid:

N/A 1.0

Dilution Factor:

Collection Date:

Lab Receipt Date:

Extraction Date: Analysis Date:

02/04/11

02/07/11

	PCB ANALYTICAL RESULTS							
COMPOUND	Quantitation Limit μg/kg	Results μg/kg						
PCB-1016	33	U						
PCB-1221	33	U						
PCB-1232	33	U						
PCB-1242	33	U						
PCB-1248	33	U						
PCB-1254	33	U						
PCB-1260	33	U						
	Surrogate Standard Recovery							
	2,4,5,6-Tetrachloro-m-xylene 98 Decachlorobiphenyl 78	% %						
U=Undetected	J=Estimated E=Exceeds Calibration Range	B=Detected in						

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Resul

Results are expressed on a dry weight basis.

PCB Report

Authorized signature __Mullull'

Secretary property sentence free a secretary

Data Path : C:\msdchem\1\DATA\020711-M\

Data File : M35659B.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 7 Feb 2011 4:44 pm

Operator : JK

Sample : B020411PSOX,,A/C

Misc : SOIL

ALS Vial : 6 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Feb 08 07:59:51 2011

Quant Method: C:\msdchem\1\METHODS\PCB020711.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update: Mon Feb 07 15:27:39 2011


Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m \times 0.25mm \times 0 Signal #2 Info : 30 m \times 0.25mm \times 0.25 um





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

KCL MOCK UP

Project Number:

102010

Field Sample ID:

Lab QC

February 9, 2011

SAMPLE DATA

Lab Sample ID:

B020411PSOX RR

Matrix:

Soil

Percent Solid:

N/A

Dilution Factor:

1.0

Collection Date:

Lab Receipt Date:

Extraction Date:

Analysis Date:

02/04/11 02/08/11

PCB.	A	M	A	T	V	7	~	A T	D	TC	T	TT	T	C
rud.	м	1.4	ь	L	/ I	11	·		ıΝ	LL.	"	21		O

COMPOUND	Quantitation Limit µg/kg	Results μg/kg
PCB-1016	33	U
PCB-1221	33	U
PCB-1232	33	U
PCB-1242	33	U
PCB-1248	33	U
PCB-1254	33	U
PCB-1260	33	U

Surrogate Standard Recovery

2,4,5,6-Tetrachloro-m-xylene

100 %

Decachlorobiphenyl

74 %

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS:

Results are expressed on a dry weight basis.

PCB Report

Authorized signature Wullull

Data Path : C:\msdchem\1\DATA\020811-M\

Data File: M35697B.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 8 Feb 2011 9:32 am

Operator : JK

Sample : B020411PSOX, RR2, , A/C

Misc : SOIL

ALS Vial Sample Multiplier: 1 : 6

Integration File signal 1: events.e Integration File signal 2: events2.e

Quant Time: Feb 08 10:25:53 2011

Quant Method: C:\msdchem\1\METHODS\PCB020711.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254


QLast Update : Mon Feb 07 15:22:15 2011 Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase : STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m \times 0.25mm \times 0 Signal #2 Info : 30 m \times 0.25mm \times 0.25 um





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

KCL MOCK UP

Project Number:

102010

Field Sample ID:

KCL 2-1-1

February 9, 2011 **SAMPLE DATA**

Lab Sample ID: Matrix:

68983-1 Solid

Percent Solid:

99

Dilution Factor:

1.9

Collection Date:

02/01/11

Lab Receipt Date: Extraction Date:

02/04/11

Analysis Date:

02/04/11

•

02/08/11

	PCB ANALYTICAL RES	SULT	rs	
COMPOUND	Quantitation Limit μg/kg		Results μg/kg	
PCB-1016	63		U	
PCB-1221	63		U	
PCB-1232	63		U	
PCB-1242	63		U	
PCB-1248	63		U	
PCB-1254	63		1340	
PCB-1260	63		U	
	Surrogate Standard Recovery			
	•		% %	
U=Undetected	J=Estimated E=Exceeds Calibration Ra	ange	B=Detected in	······································

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS:

Results are expressed on a dry weight basis.

PCB Report

Authorized signature ______Muhlull

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68983

GC Column #1: STX-CLPesticides I

Sample: 68983-1,1:2,,A/C

Column ID: 0.25 mm

Data File: M35698.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 1.9

Column ID: 0.25 mm

Column #1	Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	1256	1339	6.4	

Column to be used to flag RPD values greater than QC limit of 40%

Comments:	

^{*} Values outside QC limits

Data Path : C:\msdchem\1\DATA\020811-M\

Data File: M35698.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 8 Feb 2011 9:42 am

Operator : JK

Sample : 68983-1,1:2,,A/C

Misc

: SOIL

ALS Vial : 7 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e

Quant Time: Feb 08 10:27:12 2011

Quant Method : C:\msdchem\1\METHODS\PCB020711.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update : Mon Feb 07 15:22:15 2011


Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase : STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m \times 0.25mm \times 0 Signal #2 Info : 30 m \times 0.25mm \times 0.25 um




File :C:\msdchem\1\DATA\020811-M\M35698.D

Operator : JK

Acquired: 8 Feb 2011 9:42 am using AcqMethod PEST.M

Instrument : Instrument M
Sample Name: 68983-1,1:2,,A/C

Misc Info : SOIL Vial Number: 7





Mr. Rob Klein Yale University Environmental Health & Safety 135 Čollege Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

KCL MOCK UP

Project Number:

102010

Field Sample ID:

KCL 2-1-2

February 9, 2011

SAMPLE DATA

Lab Sample ID:

68983-2

Matrix:

Solid

Percent Solid:

99

Dilution Factor:

1.0

Collection Date:

02/01/11

Lab Receipt Date:

02/04/11

Extraction Date:

02/04/11

Analysis Date:

02/07/11

PCB ANALYTICAL RESULTS

COMPOUND	Quantitation Limit µg/kg	Results μg/kg
PCB-1016	33	U
PCB-1221	33	U
PCB-1232	33	U
PCB-1242	33	U
PCB-1248	33	U
PCB-1254	33	893
PCB-1260	33	U

Surrogate Standard Recovery

2,4,5,6-Tetrachloro-m-xylene

89 %

Decachlorobiphenyl

71 %

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are expressed on a dry weight basis.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68983

GC Column #1: STX-CLPesticides I

Sample: 68983-2,,A/C

Column ID: 0.25 mm

Data File: M35663.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 1.0

Column ID: 0.25 mm

Column #1

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	893	842	5.9	

Column to be used to flag RPD values greater than QC limit of 40%

* Values outside QC limits

Data Path: C:\msdchem\1\DATA\020711-M\

Data File: M35663.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On 7 Feb 2011 5:25 pm

Operator : JK

: 68983-2,,A/C Sample

Misc : SOIL

ALS Vial : 10 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e

Quant Time: Feb 08 09:05:00 2011

Quant Method: C:\msdchem\1\METHODS\PCB020711.M

Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254


QLast Update : Mon Feb 07 15:27:39 2011 Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides

Signal #1 Info : 30 m x 0.25mm x 0 Signal #2 Info : 30 m x 0.25mm x 0.25 um




File :C:\msdchem\1\DATA\020711-M\M35663.D

Operator : JK

Acquired : 7 Feb 2011 5:25 pm using AcqMethod PEST.M

Instrument : Instrument M
Sample Name: 68983-2,,A/C

Misc Info : SOIL Vial Number: 10





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

KCL MOCK UP

Project Number:

102010

Field Sample ID:

KCL 2-1-3

February 9, 2011

SAMPLE DATA

Lab Sample ID:

68983-3

Matrix:

Solid

Percent Solid:

99

Dilution Factor:

2.0

Collection Date: Lab Receipt Date: 02/01/11

Extraction Date:

02/04/11 02/04/11

Analysis Date:

02/08/11

PCR	ANAI	VTICAL	L RESUI	TS
$\mathbf{L} \cup \mathbf{D}$				

COMPOUND	Quantitation Limit μg/kg	Results μg/kg
PCB-1016	66	U
PCB-1221	66	U
PCB-1232	66	U
PCB-1242	66	U
PCB-1248	66	U
PCB-1254	66	1560
PCB-1260	66	U

Surrogate Standard Recovery

2,4,5,6-Tetrachloro-m-xylene

94 %

Decachlorobiphenyl

73 %

U=Undetected J=Estimated E=Exceeds Calibration Range B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS:

Results are expressed on a dry weight basis.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68983

GC Column #1: STX-CLPesticides I

Sample: 68983-3,1:2,,A/C

Column ID: 0.25 mm

Data File: M35699.D

GC Column #2: STX-CLPesticides II

Dilution Factor: 2.0

Column ID: 0.25 mm

Col	lumn	#1

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	1446	1560	7.6	

Column to be used to flag RPD values greater than QC limit of 40%

* Values outside QC limits

Data Path : C:\msdchem\1\DATA\020811-M\

Data File: M35699.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

8 Feb 2011 Acq On 9:52 am

Operator : JK

Sample : 68983-3,1:2,,A/C

: SOIL Misc

ALS Vial : 8 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Quant Time: Feb 08 10:28:21 2011

Quant Method: C:\msdchem\1\METHODS\PCB020711.M


Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254 QLast Update : Mon Feb 07 15:22:15 2011

Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase: STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides Signal #1 Info : $30 \text{ m} \times 0.25 \text{mm} \times 0$ Signal #2 Info : $30 \text{ m} \times 0.25 \text{mm} \times 0.25$ um




File :C:\msdchem\1\DATA\020811-M\M35699.D

Operator : JK

Acquired: 8 Feb 2011 9:52 am using AcqMethod PEST.M

Instrument : Instrument M
Sample Name: 68983-3,1:2,,A/C

Misc Info : SOIL Vial Number: 8





Mr. Rob Klein Yale University Environmental Health & Safety 135 College Street New Haven CT 06510

CLIENT SAMPLE ID

Project Name:

KCL MOCK UP

Project Number:

102010

Field Sample ID:

KCL 2-1-4

February 9, 2011

99

SAMPLE DATA

Lab Sample ID: 68983-4 **Matrix:** Solid

Percent Solid:

Dilution Factor: 1.0

Collection Date: 02/01/11

Lab Receipt Date:

02/04/11

Extraction Date:

02/04/11

Analysis Date: 02/07/11

	PCB ANALYTICAL RESUI	LTS
COMPOUND	Quantitation Limit μg/kg	Results $\mu \mathrm{g/kg}$
PCB-1016	33	U
PCB-1221	33	U
PCB-1232	33	U
PCB-1242	33	U
PCB-1248	33	U
PCB-1254	33	777
PCB-1260	33	U
	Surrogate Standard Recovery	
	2,4,5,6-Tetrachloro-m-xylene 93	%
	Decachlorobiphenyl 73	%
U=Undetected	J=Estimated E=Exceeds Calibration Range	B=Detected in

METHODOLOGY: Sample analysis conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 8082.

Sample preparation conducted according to Test Methods for Evaluating Solid Waste, SW-846 Method 3540C.

COMMENTS: Results are e

Results are expressed on a dry weight basis.

PCB Report

PCB COLUMN RELATIVE PERCENT DIFFERENCE

Instrument ID: M

SDG: 68983

GC Column #1: STX-CLPesticides I

GC Column #2: STX-CLPesticides II

Sample: 68983-4,,A/C

Column ID: 0.25 mm

Data File: M35665.D

Dilution Factor: 1.0

Column ID: 0.25 mm

Col	umn	#	ĺ
	HILLIA	17	3

Column #2

COMPOUND	SAMPLE RESULT (ug/kg)	SAMPLE RESULT (ug/kg)	RPD	#
PCB 1254	777	770	1.0	

Column to be used to flag RPD values greater than QC limit of 40%

* Values outside QC limits

Data Path : C:\msdchem\1\DATA\020711-M\

Data File: M35665.D

Signal(s): Signal #1: ECD1A.ch Signal #2: ECD2B.ch

Acq On : 7 Feb 2011 5:45 pm

Operator : JK

Sample : 68983-4,,A/C

Misc : SOIL

ALS Vial : 12 Sample Multiplier: 1

Integration File signal 1: events.e Integration File signal 2: events2.e Ouant Time: Feb 08 09:06:25 2011

Quant Time: Feb 08 09:06:25 2011
Quant Method : C:\msdchem\1\METHODS\PCB020711.M


Quant Title : SW-846 METHOD 8082 Aroclor 1016/1260/1254

QLast Update : Mon Feb 07 15:27:39 2011 Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : 2 uL

Signal #1 Phase : STX-CLPPesticides Signal #2 Phase: STX-CLPPesticides Signal #1 Info : $30 \text{ m} \times 0.25 \text{mm} \times 0$ Signal #2 Info : $30 \text{ m} \times 0.25 \text{mm} \times 0.25$ um




File :C:\msdchem\1\DATA\020711-M\M35665.D

Operator : JK

Acquired : 7 Feb 2011 5:45 pm using AcqMethod PEST.M

Instrument : Instrument M
Sample Name: 68983-4,,A/C

Misc Info : SOIL Vial Number: 12





PCB QC FORMS

PCB SOIL SYSTEM MONITORING COMPOUNDS SUMMARY

SDG: 68983

Instrument ID: M

GC Column #1: STX-CLPesticides I

Column ID: 0.25 mm

GC Column #2: STX-CLPesticides II

Column ID: 0.25 mm

		Column	n #1			Colum	n #2	
SAMPLE ID	SMC 1 (%)	#	SMC 2 (%)	#	SMC 1 (%)	#	SMC 2 (%)	#
B020411PSOX,,A/C	98		78		86		77	
L020411PSOX,,A/C	94		76		88		76	
LD020411PSOX,,A/C	91		75		87		74	
68983-2,,A/C	89		71		79		66	***************************************
68983-4,,A/C	93		73		82		69	
					, , , , , , , , , , , , , , , , , , , ,			

								*

	1							

	Lower Limit	Upper Limit
SMC #1 = TCX	40	130
SMC #2 = DCB	40	130

- # Column to be used to flag recovery values outside of QC limits
- * Values outside QC limits
- D System Monitoring Compound diluted out

PCB SOIL SYSTEM MONITORING COMPOUNDS SUMMARY

SDG: 68983

Instrument ID: M

GC Column #1: STX-CLPesticides I

Column ID: 0.25 mm

GC Column #2: STX-CLPesticides II

Column ID: 0.25 mm

		Colum	n #1	Column #2				
SAMPLE ID	SMC 1 (%)	#	SMC 2 (%)	#	SMC 1 (%)	#	SMC 2 (%)	#
B020411PSOX,RR2,,A/C	100		74		86		72	
68983-1,1:2,,A/C	91		70		93		68	
68983-3,1:2,,A/C	94		73		97		71	
						1		
				1	1			
			 					
								
				 		<u> </u>		
				 		 		
				 		 		
				 				
			 	 				
				 				
			 		<u> </u>			
				<u> </u>				

					<u> </u>			
	<u> </u>							
	L							

	Lower	Upper
	Limit	Limit
SMC #1 = TCX	40	130
SMC #2 = DCB	40	130

- # Column to be used to flag recovery values outside of QC limits
- * Values outside QC limits
- D System Monitoring Compound diluted out

PCB SOIL LABORATORY CONTROL SAMPLE/DUPLICATE PERCENT RECOVERY

Instrument ID: M

GC Column #1: STX-CLPesticides I

SDG: 68983

Column ID: 0.25 mm

Non-spiked sample: B020411PSOX,,A/C

GC Column #2: STX-CLPesticides II

Spike: L020411PSOX,,A/C

Column ID: 0.25 mm

Spike duplicate: LD020411PSOX,,A/C

COMPOUND	LCS SPIKE ADDED (ug/kg)	LCSD SPIKE ADDED (ug/kg)	LOWER	UPPER LIMIT	RPD LIMIT	NON-SPIKE	SPIKE	SPIKE % REC		SPIKE DUP	SPIKE DUP		mpr	
COMPOUND	ADDED (ug/kg)	ADDED (ug/kg)	LIVIII	Liviii	LIMIT	RESULT (ug/kg)	RESULT (ug/kg)	% KEC	#	RESULT (ug/kg)	% REC	#	RPD	#
PCB 1016	200	200	65	140	30	0	191	95		199	100		4.3	
PCB 1260	200	200	60	130	30	0	181	90		182	91		1.0	
PCB 1016 #2	200	200	65	140	30	0	169	85		172	86		1.5	П
PCB 1260 #2	200	200	60	130	30	0	183	91		185	93		1.5	

- # Column to be used to flag recovery and RPD values outside of QC limits
- * Values outside QC limits

LCS/LCSD spike added values have been weight adjusted.

Non-spike result of "0" used in place of "U" to allow calculation of spike recovery.

Comments:	



CHAIN OF CUSTODIES

11/h/e do	Booolvod By: 0	Date: Time:	Jan Sa
- Co	Received By:	SIC/ :=wil II/ H/ Gied X	FP-1 3
X2 (1)	Received By:	MM .:miT CetsG	TYMEN 3
For Analytics Use Only Rev. 4 03/28/08 Saraptes were: (Shipped or hand-delivered) 2) Temp blank °C	4) pH checked by: NA 5) Labels checked by: Ju. 2.4.1\ Container Key P=plastic G=glass	Contain: Matrix Matrix Mumber/typ Matrix Matrix	Project Requirements: Report Type
		Office Methanol	Report Type MCP Le CTRC Le DOD Le Stands Fee may ap
195 Commerce Way Suite E Portsmouth, NH 03801 Phone (603) 436-5111 Fax (603) 430-2151 C = Concrete WP = Wipe WW = Wastewater	SW = Surface Water GW = Groundwater DW = Drinking Water S = Soil/Sludge O = Oil E = Extract X = Other Preservation	HCF H ² SO ⁴ HNO ² HNO ² t ₀ C Nubles	miess front - CP
In the State of th	Contact: '57216 MWD2.14 (Lob K1911) Address: 135 COULGE ST, STE 100 ADD HAY M, CT OLOT 10 Phone 20373747390# Quote # Sampler (Signature):	Station Identification Date Time RCB Analysis CU. 7-1-7 MKSMM ZIJII RCB CU. 2-1-2 MKSMM ZIJII CVA 8082 KU. 2-1-4 MYSMM COAMM COAMM COAMM	Email Results to: Comments / Instructions: Comments / Instructions: Comments / Instructions: Comments / Instructions: Report Tyre MCP [R] Due Date Standard Priority Companies Companies

ANALYTICS SAMPLE RECEIPT CHECKLIST



AEL LAB#: 68983 CLIENT: VOLE PROJECT: KCL Mock UP	COOLER NUMBER: NUMBER OF COOLERS: DATE RECEIVED:	<u>Client a</u> 1 2/4/11	oder
A: PRELIMINARY EXAMINATION: 1. Cooler received by(initials): 2. Circle one: Hand delivered	DATE COOLER OPENED: Date Received: Shipped	2/4/11	
(If so, skip 3) 3. Did cooler come with a shipping slip?	Y	N	
3a. Enter carrier name and airbill number here: 4. Were custody seals on the outside of cooler? How many & where: Seal Date:	Y Seal Name:	N	
5. Did the custody seals arrive unbroken and intact upon arrival? 6. COC#:	Y		r samples No
7. Were Custody papers filled out properly (ink,signed, etc)?8. Were custody papers sealed in a plastic bag?9. Did you sign the COC in the appropriate place?	Y (Y)	N N N	sampler was sample times listed on coc
10. Was the project identifiable from the COC papers? 11. Was enough ice used to chill the cooler? Y N	Temp. of cooler:	9,9°	
B. Log-In: Date samples were logged in: 12. Type of packing in cooler(bubble wrap popcorn)	Ву:	N	
13. Were all bottles sealed in separate plastic bags?		N N	
14. Did all bottles arrive unbroken and were labels in good condition?15. Were all bottle labels complete(ID,Date,time,etc.)	Y	(N - N)	a times or un labells.
16. Did all bottle labels agree with custody papers?17. Were the correct containers used for the tests indicated:	Ý	$N \rightarrow 3$	Sample labels all State "KCL a-1" Saping by COC
18. Were samples received at the correct pH?19. Was sufficient amount of sample sent for the tests indicated?	Y Y	N/A	unless otherwis specified by
20. Were all samples submitted within holding time?21. Were bubbles absent in VOA samples?	Y	N N/A	Gas by contain
If NO, List Sample ID's and Lab #s:			as per steve Nurdzia over phone
22. Laboratory labeling verified by (initials):	Date: _	2.4.11	



SAMPLE RECEIPT NON-COMPLIANCE NOTIFICATION (SENT VIA FACSIMILE)

DATEFROM	
FAX CONTACT Rob Klein/Steve FAX NUMBER 403-785-158	38
CLIENT YALE LAB NUMBER 68983	
The exceptions noted below were found on the sample(s) received on the attached Chain of Custody (COC) form. These exceptions may render the data results as non-defensible. Analytics will continue to proceed with the analysis of the sample(s) unless notified in writing to stop the analysis. This document may become part of the final report.	
Please check the appropriate box and sign below and fax back to "Sample Receipt" at 603-430-2151.	\supset
Exceptions: Sample(s) not on ice or not at $4^{\circ}C \pm 2^{\circ}C$ Samples @ 9.9°C	
Sample(s) received unpreserved or not at the proper pH. (pH was adjusted at the laboratory)	
Sample(s) received in incorrect containers	
Insufficient sample volume received (Detection limits may be elevated due to this exception)	
Other: Sample names on containers all state "KCL 2-1" which not match COC, AEL to go by COC for sample unless otherwise stated by cheent	, does name
Acknowledgment:	
Please do not analyze/report Trip Blank, proceed with other analyses	
Proceed with the analysis use container labels as sample names, as per silluration over phane	not coc
Please stop the analysis and wait for further instructions.	
Signed: Aly Pary for Struc Print Name: Stave Murdzia Date: 2411	

From: (203) 737-2122 Stephanie Perry Yala University 135 College St

Fed Express

J11101012220225

New Haven, CT 06510

SHIP TO: (603) 436-5111

.Origin ID: EFBA

BILL SENDER

Analytics Environmental Laboratory 195 Commerce Way Suite E Portsmouth, NH 03801



Ship Date: 02FEB11 ActWgt: 7.5 LB CAD: 6271659/WBUS0200

Dims: 13 X 13 X 13 IN

Delivery Address Bar Code



Ref# Invoice# PO# Dept#

THU - 03 FEB A2

FRI - 04 FEB A2 STANDARD OVERNIGHT

03801 NH-US

03 IGGA

Fed 522. 1RK# 7967 2022 4135

T-04 313921 #3FEB11 HVNA 58AC1/82C2/1831



April 6, 2012

George Franklin Woodard & Curran - Andover, MA 35 New England Business Center Andover, MA 01810

Project Location: Yale KCL Client Job Number:

Project Number: 225540

Laboratory Work Order Number: 12C0993

Meghan S. Kelley

Enclosed are results of analyses for samples received by the laboratory on March 30, 2012. If you have any questions concerning this report, please feel free to contact me.

Sincerely,

Meghan E. Kelley Project Manager



Woodard & Curran - Andover, MA 35 New England Business Center Andover, MA 01810 ATTN: George Franklin REPORT DATE: 4/6/2012

PURCHASE ORDER NUMBER:

PROJECT NUMBER: 225540

ANALYTICAL SUMMARY

WORK ORDER NUMBER: 12C0993

The results of analyses performed on the following samples submitted to the CON-TEST Analytical Laboratory are found in this report.

PROJECT LOCATION: Yale KCL

EIELD CANDLE //	LABIB	MATRIX	a . 1 (b) E b Ea ab iberio) :	TERRET	grap r a p
FIELD SAMPLE #	LAB ID:	MATRIX	SAMPLE DESCRIPTION	TEST	SUB LAB
KCL-CBK-001	12C0993-01	Caulk		SW-846 8082A	
KCL-CBK-002	12C0993-02	Caulk		SW-846 8082A	
KCL-CBK-003	12C0993-03	Caulk		SW-846 8082A	
KCL-CBK-004	12C0993-04	Caulk		SW-846 8082A	
KCL-CBK-005	12C0993-05	Caulk		SW-846 8082A	
KCL-CBK-006	12C0993-06	Caulk		SW-846 8082A	
KCL-CBK-007	12C0993-07	Caulk		SW-846 8082A	
KCL-CBK-008	12C0993-08	Caulk		SW-846 8082A	
KCL-CBK-012	12C0993-09	Caulk		SW-846 8082A	
KCL-CBK-013	12C0993-10	Caulk		SW-846 8082A	
KCL-CBK-014	12C0993-11	Caulk		SW-846 8082A	
KCL-CBC-015	12C0993-12	Concrete		SW-846 8082A	
KCL-CBC-016	12C0993-13	Concrete		SW-846 8082A	
KCL-CBK-017	12C0993-14	Caulk		SW-846 8082A	
KCL-CBK-018	12C0993-15	Caulk		SW-846 8082A	
KCL-CBB-019	12C0993-16	Concrete		SW-846 8082A	
KCL-CBB-020	12C0993-17	Concrete		SW-846 8082A	
KCL-CBB-022	12C0993-18	Concrete		SW-846 8082A	
KCL-CBR-024	12C0993-19	Concrete		SW-846 8082A	
KCL-CBK-025	12C0993-20	Caulk		SW-846 8082A	
KCL-CBB-027	12C0993-21	Concrete		SW-846 8082A	
KCL-CBR-029	12C0993-22	Concrete		SW-846 8082A	
KCL-CBB-030	12C0993-23	Concrete		SW-846 8082A	
KCL-CBB-031	12C0993-24	Concrete		SW-846 8082A	
KCL-CBK-032	12C0993-25	Caulk		SW-846 8082A	
KCL-CBR-033	12C0993-26	Concrete		SW-846 8082A	
KCL-CBR-035	12C0993-27	Concrete		SW-846 8082A	
KCL-CBKD-040	12C0993-30	Concrete		SW-846 8082A	
KCL-CBBD-041	12C0993-31	Concrete		SW-846 8082A	
KCL-CBBQ-042	12C0993-32	Equipment Blank Water		SW-846 8082A	



CASE NARRATIVE SUMMARY

All reported results are within defined laboratory quality control objectives unless listed below or otherwise qualified in this report.

SW-846 8082A

Qualifications:

Matrix spike and/or spike duplicate recovery bias high due to contribution of other Aroclors present in the source sample.

Analyte & Samples(s) Qualified:

Aroclor-1016, Aroclor-1016 [2C], Aroclor-1260, Aroclor-1260 [2C]

B048908-MS1, B048908-MSD1

Due to continuing calibration non-conformance on the confirmatory detector, the lower of two results was reported.

Analyte & Samples(s) Qualified:

Aroclor-1254 [2C]

12C0993-29[KCL-CBR-039], 12C0993-31[KCL-CBBD-041]

The surrogate recovery for this sample is not available due to sample dilution below the surrogate reporting limit required from high analyte concentration and/or matrix interferences.

Analyte & Samples(s) Qualified:

$Decach loro bip henyl, Decach loro bip henyl \ [2C], Tetrach loro-m-xylene, Tetrach loro-m-xylene \ [2C]$

12C0993-01[KCL-CBK-001], 12C0993-02[KCL-CBK-002], 12C0993-04[KCL-CBK-004], 12C0993-05[KCL-CBK-005], 12C0993-06[KCL-CBK-006], 12C0993-09[KCL-CBK-012], 12C0993-10[KCL-CBK-013], 12C0993-11[KCL-CBK-014], 12C0993-14[KCL-CBK-017], 12C0993-15[KCL-CBK-018], 12C0993-20[KCL-CBK-025], 12C0993-25[KCL-CBK-032], 12C0993-30[KCL-CBK-040]

Continuing calibration did not meet method specifications and was biased on the high side for this compound. Increased uncertainty is associated with the reported value which is likely to be biased on the high side.

Analyte & Samples(s) Qualified:

Aroclor-1016


B048990-BS1, B048990-BSD1

Continuing calibration did not meet method specifications and was biased on the high side. Data validation is not affected since sample result was "not detected" for this compound.

Analyte & Samples(s) Qualified:

Aroclor-1016

B048990-BS1, B048990-BSD1



 $The \ results \ of \ analyses \ reported \ only \ relate \ to \ samples \ submitted \ to \ the \ Con-Test \ Analytical \ Laboratory \ for \ testing.$

I certify that the analyses listed above, unless specifically listed as subcontracted, if any, were performed under my direction according to the approved methodologies listed in this document, and that based upon my inquiry of those individuuals immediately responsible for obtaining the information, the material contained in this report is, to the best of my knowledge and belief, accurate and complete.

Daren J. Damboragian Laboratory Manager



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-001 Sampled: 3/29/2012 09:50

Sample ID: 12C0993-01
Sample Matrix: Caulk

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	47000	mg/Kg	250000		SW-846 8082A	4/2/12	4/5/12 10:19	PJG
Aroclor-1221 [1]	ND	47000	mg/Kg	250000		SW-846 8082A	4/2/12	4/5/12 10:19	PJG
Aroclor-1232 [1]	ND	47000	mg/Kg	250000		SW-846 8082A	4/2/12	4/5/12 10:19	PJG
Aroclor-1242 [1]	ND	47000	mg/Kg	250000		SW-846 8082A	4/2/12	4/5/12 10:19	PJG
Aroclor-1248 [1]	ND	47000	mg/Kg	250000		SW-846 8082A	4/2/12	4/5/12 10:19	PJG
Aroclor-1254 [1]	400000	47000	mg/Kg	250000		SW-846 8082A	4/2/12	4/5/12 10:19	PJG
Aroclor-1260 [1]	ND	47000	mg/Kg	250000		SW-846 8082A	4/2/12	4/5/12 10:19	PJG
Aroclor-1262 [1]	ND	47000	mg/Kg	250000		SW-846 8082A	4/2/12	4/5/12 10:19	PJG
Aroclor-1268 [1]	ND	47000	mg/Kg	250000		SW-846 8082A	4/2/12	4/5/12 10:19	PJG
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/5/12 10:19	
Decachlorobiphenyl [2]		*	30-150		S-01			4/5/12 10:19	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/5/12 10:19	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/5/12 10:19	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-002 Sampled: 3/29/2012 10:10

Sample ID: 12C0993-02
Sample Matrix: Caulk

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:15	PJG
Aroclor-1221 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:15	PJG
Aroclor-1232 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:15	PJG
Aroclor-1242 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:15	PJG
Aroclor-1248 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:15	PJG
Aroclor-1254 [1]	33	9.1	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:15	PJG
Aroclor-1260 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:15	PJG
Aroclor-1262 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:15	PJG
Aroclor-1268 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:15	PJG
Surrogates		% Recovery	Recovery Limits	1	Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/5/12 9:15	
Decachlorobiphenyl [2]		*	30-150		S-01			4/5/12 9:15	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/5/12 9:15	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/5/12 9:15	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Sample Matrix: Caulk

Field Sample #: KCL-CBK-003

Sample ID: 12C0993-03

Sampled: 3/29/2012 10:12

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.89	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:27	PJG
Aroclor-1221 [1]	ND	0.89	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:27	PJG
Aroclor-1232 [1]	ND	0.89	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:27	PJG
Aroclor-1242 [1]	ND	0.89	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:27	PJG
Aroclor-1248 [1]	ND	0.89	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:27	PJG
Aroclor-1254 [1]	2.0	0.89	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:27	PJG
Aroclor-1260 [1]	ND	0.89	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:27	PJG
Aroclor-1262 [1]	ND	0.89	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:27	PJG
Aroclor-1268 [1]	ND	0.89	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:27	PJG
Surrogates		% Recovery	Recovery Limits	1	Flag				
Decachlorobiphenyl [1]		82.1	30-150					4/5/12 9:27	
Decachlorobiphenyl [2]		78.7	30-150					4/5/12 9:27	
Tetrachloro-m-xylene [1]		113	30-150					4/5/12 9:27	
Tetrachloro-m-xylene [2]		112	30-150					4/5/12 9:27	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-004

Sampled: 3/29/2012 10:15

Sample ID: 12C0993-04
Sample Matrix: Caulk

Dolyahlarinatad	Dinhanyla with	2540 Carblet	Extuastion

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	35000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 13:33	PJG
Aroclor-1221 [1]	ND	35000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 13:33	PJG
Aroclor-1232 [1]	ND	35000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 13:33	PJG
Aroclor-1242 [1]	ND	35000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 13:33	PJG
Aroclor-1248 [1]	ND	35000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 13:33	PJG
Aroclor-1254 [1]	490000	35000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 13:33	PJG
Aroclor-1260 [1]	ND	35000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 13:33	PJG
Aroclor-1262 [1]	ND	35000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 13:33	PJG
Aroclor-1268 [1]	ND	35000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 13:33	PJG
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/5/12 13:33	
Decachlorobiphenyl [2]		*	30-150		S-01			4/5/12 13:33	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/5/12 13:33	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/5/12 13:33	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-005 Sampled: 3/29/2012 10:18

Sample ID: 12C0993-05
Sample Matrix: Caulk

		·							
Analyta	Results	RL	Units	Dilution	Elag	Method	Date	Date/Time	Analyzet
Analyte	Resuits	KL	UIIIS	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	10	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:40	PJG
Aroclor-1221 [1]	ND	10	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:40	PJG
Aroclor-1232 [1]	ND	10	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:40	PJG
Aroclor-1242 [1]	ND	10	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:40	PJG
Aroclor-1248 [1]	ND	10	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:40	PJG
Aroclor-1254 [1]	67	10	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:40	PJG
Aroclor-1260 [1]	ND	10	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:40	PJG
Aroclor-1262 [1]	ND	10	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:40	PJG
Aroclor-1268 [1]	ND	10	mg/Kg	50		SW-846 8082A	4/2/12	4/5/12 9:40	PJG
Surrogates		% Recovery	Recovery Limits	S	Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/5/12 9:40	
Decachlorobiphenyl [2]		*	30-150		S-01			4/5/12 9:40	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/5/12 9:40	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/5/12 9:40	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-006

Sampled: 3/29/2012 10:20

Sample ID: 12C0993-06
Sample Matrix: Caulk

Polychlorinated	Rinhanyle with	3540 Sovblet	Extraction
Polychiorinated	Bidnenvis with	3540 SOXIIIEL	Extraction

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	90	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 21:49	PJG
Aroclor-1221 [1]	ND	90	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 21:49	PJG
Aroclor-1232 [1]	ND	90	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 21:49	PJG
Aroclor-1242 [1]	ND	90	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 21:49	PJG
Aroclor-1248 [1]	ND	90	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 21:49	PJG
Aroclor-1254 [1]	360	90	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 21:49	PJG
Aroclor-1260 [2]	370	90	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 21:49	PJG
Aroclor-1262 [1]	ND	90	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 21:49	PJG
Aroclor-1268 [1]	ND	90	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 21:49	PJG
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/4/12 21:49	
Decachlorobiphenyl [2]		*	30-150		S-01			4/4/12 21:49	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/4/12 21:49	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/4/12 21:49	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-007

Sampled: 3/29/2012 10:45

Sample ID: 12C0993-07
Sample Matrix: Caulk

		Polychlori	nated Biphenyls wi	th 3540 Soxhle	t Extraction		·	·	
Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.95	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:53	PJG
Aroclor-1221 [1]	ND	0.95	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:53	PJG
Aroclor-1232 [1]	ND	0.95	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:53	PJG
Aroclor-1242 [1]	ND	0.95	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:53	PJG
Aroclor-1248 [1]	ND	0.95	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:53	PJG
Aroclor-1254 [1]	ND	0.95	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:53	PJG
Aroclor-1260 [1]	ND	0.95	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:53	PJG
Aroclor-1262 [1]	ND	0.95	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:53	PJG
Aroclor-1268 [1]	ND	0.95	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 9:53	PJG
Surrogates		% Recovery	Recovery Limits	s	Flag				
Decachlorobiphenyl [1]		85.5	30-150					4/5/12 9:53	
Decachlorobiphenyl [2]		85.6	30-150					4/5/12 9:53	
Tetrachloro-m-xylene [1]		108	30-150					4/5/12 9:53	
Tetrachloro-m-xylene [2]		109	30-150					4/5/12 9:53	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-008

Sample ID: 12C0993-08
Sample Matrix: Caulk

Sampled: 3/29/2012 10:48

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.94	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 10:06	PJG
Aroclor-1221 [1]	ND	0.94	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 10:06	PJG
Aroclor-1232 [1]	ND	0.94	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 10:06	PJG
Aroclor-1242 [1]	ND	0.94	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 10:06	PJG
Aroclor-1248 [1]	ND	0.94	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 10:06	PJG
Aroclor-1254 [1]	1.4	0.94	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 10:06	PJG
Aroclor-1260 [1]	ND	0.94	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 10:06	PJG
Aroclor-1262 [1]	ND	0.94	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 10:06	PJG
Aroclor-1268 [1]	ND	0.94	mg/Kg	5		SW-846 8082A	4/2/12	4/5/12 10:06	PJG
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		90.4	30-150					4/5/12 10:06	
Decachlorobiphenyl [2]		90.6	30-150					4/5/12 10:06	
Tetrachloro-m-xylene [1]		115	30-150					4/5/12 10:06	
Tetrachloro-m-xylene [2]		114	30-150					4/5/12 10:06	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Sample Matrix: Caulk

Field Sample #: KCL-CBK-012

Sample ID: 12C0993-09

Sampled: 3/29/2012 11:35

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	9.8	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:28	PJG
Aroclor-1221 [1]	ND	9.8	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:28	PJG
Aroclor-1232 [1]	ND	9.8	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:28	PJG
Aroclor-1242 [1]	ND	9.8	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:28	PJG
Aroclor-1248 [1]	ND	9.8	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:28	PJG
Aroclor-1254 [1]	49	9.8	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:28	PJG
Aroclor-1260 [2]	18	9.8	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:28	PJG
Aroclor-1262 [1]	ND	9.8	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:28	PJG
Aroclor-1268 [1]	ND	9.8	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:28	PJG
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/4/12 22:28	
Decachlorobiphenyl [2]		*	30-150		S-01			4/4/12 22:28	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/4/12 22:28	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/4/12 22:28	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Sample Matrix: Caulk

Field Sample #: KCL-CBK-013

Sample ID: 12C0993-10

Sampled: 3/29/2012 11:38

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	9.6	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:41	PJG
Aroclor-1221 [1]	ND	9.6	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:41	PJG
Aroclor-1232 [1]	ND	9.6	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:41	PJG
Aroclor-1242 [1]	ND	9.6	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:41	PJG
Aroclor-1248 [1]	ND	9.6	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:41	PJG
Aroclor-1254 [1]	55	9.6	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:41	PJG
Aroclor-1260 [2]	20	9.6	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:41	PJG
Aroclor-1262 [1]	ND	9.6	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:41	PJG
Aroclor-1268 [1]	ND	9.6	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 22:41	PJG
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/4/12 22:41	
Decachlorobiphenyl [2]		*	30-150		S-01			4/4/12 22:41	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/4/12 22:41	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/4/12 22:41	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-014

Sampled: 3/29/2012 11:58

Sample ID: 12C0993-11
Sample Matrix: Caulk

Polychlorinated Bin	henvis with 3540	Soxblet Extraction

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	96	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 22:54	PJG
Aroclor-1221 [1]	ND	96	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 22:54	PJG
Aroclor-1232 [1]	ND	96	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 22:54	PJG
Aroclor-1242 [1]	ND	96	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 22:54	PJG
Aroclor-1248 [1]	ND	96	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 22:54	PJG
Aroclor-1254 [1]	1900	96	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 22:54	PJG
Aroclor-1260 [1]	ND	96	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 22:54	PJG
Aroclor-1262 [1]	ND	96	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 22:54	PJG
Aroclor-1268 [1]	ND	96	mg/Kg	500		SW-846 8082A	4/2/12	4/4/12 22:54	PJG
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/4/12 22:54	
Decachlorobiphenyl [2]		*	30-150		S-01			4/4/12 22:54	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/4/12 22:54	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/4/12 22:54	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBC-015

Sampled: 3/29/2012 12:10

Sample ID: 12C0993-12
Sample Matrix: Concrete

		Poly chlo ri	nated Biphenyls wi	ith 3540 Soxhle	t Extraction				
Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:13	JMB
Aroclor-1221 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:13	JMB
Aroclor-1232 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:13	JMB
Aroclor-1242 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:13	JMB
Aroclor-1248 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:13	JMB
Aroclor-1254 [1]	3.8	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:13	JMB
Aroclor-1260 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:13	JMB
Aroclor-1262 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:13	JMB
Aroclor-1268 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:13	JMB
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		85.3	30-150					4/2/12 16:13	
Decachlorobiphenyl [2]		89.4	30-150					4/2/12 16:13	
Tetrachloro-m-xylene [1]		92.9	30-150					4/2/12 16:13	
Tetrachloro-m-xylene [2]		84.1	30-150					4/2/12 16:13	



Analyte

39 Spruce Street * East Longmeadow, MA 01028 * FAX 413/525-6405 * TEL. 413/525-2332

Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBC-016

Sampled: 3/29/2012 12:20

Results

ND

ND

ND

ND

ND

2.2

ND

ND

ND

Sample ID: 12C0993-13
Sample Matrix: Concrete

Aroclor-1016 [1]

Aroclor-1221 [1]

Aroclor-1232 [1]

Aroclor-1242 [1]

Aroclor-1248 [1]

Aroclor-1254 [1]

Aroclor-1260 [1]

Aroclor-1262 [1]

Aroclor-1268 [1]

Polychlor	inated Biphenyls w	ith 3540 Soxhle	t Extraction				
					Date	Date/Time	
RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:25	JMB
0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:25	JMB
0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:25	JMB
0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:25	JMB
0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:25	JMB
0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:25	JMB
0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:25	JMB
0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:25	JMB
0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:25	JMB

Surrogates	% Recovery	Recovery Limits	Flag	
Decachlorobiphenyl [1]	96.1	30-150		4/2/12 16:25
Decachlorobiphenyl [2]	100	30-150		4/2/12 16:25
Tetrachloro-m-xylene [1]	101	30-150		4/2/12 16:25
Tetrachloro-m-xylene [2]	95.1	30-150		4/2/12 16:25



Analyte

39 Spruce Street * East Longmeadow, MA 01028 * FAX 413/525-6405 * TEL. 413/525-2332

Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-017

Sampled: 3/29/2012 12:50

Results

ND

ND

ND

ND

8.9

27

23

ND

ND

Sample ID: 12C0993-14
Sample Matrix: Caulk

Aroclor-1016 [1]

Aroclor-1221 [1]

Aroclor-1232 [1]

Aroclor-1242 [1]

Aroclor-1248 [2]

Aroclor-1254 [1]

Aroclor-1260 [2]

Aroclor-1262 [1]

Aroclor-1268 [1]

Polychlori	nated Biphenyls w	ith 3540 Soxhle	t Extraction				
					Date	Date/Time	
RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
8.7	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 23:06	PJG
8.7	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 23:06	PJG
8.7	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 23:06	PJG
8.7	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 23:06	PJG
8.7	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 23:06	PJG
8.7	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 23:06	PJG
8.7	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 23:06	PJG
8.7	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 23:06	PJG
8.7	mg/Kg	50		SW-846 8082A	4/2/12	4/4/12 23:06	PJG

Surrogates	% Recovery	Recovery Limits	Flag	
Decachlorobiphenyl [1]	*	30-150	S-01	4/4/12 23:06
Decachlorobiphenyl [2]	*	30-150	S-01	4/4/12 23:06
Tetrachloro-m-xylene [1]	*	30-150	S-01	4/4/12 23:06
Tetrachloro-m-xylene [2]	*	30-150	S-01	4/4/12 23:06



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-018

Sampled: 3/29/2012 13:05

Sample ID: 12C0993-15
Sample Matrix: Caulk

Polychlorinated	Dinhanula :	-i+b 2540	Carblet Extuncti	

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:45	PJG
Aroclor-1221 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:45	PJG
Aroclor-1232 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:45	PJG
Aroclor-1242 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:45	PJG
Aroclor-1248 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:45	PJG
Aroclor-1254 [1]	390000	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:45	PJG
Aroclor-1260 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:45	PJG
Aroclor-1262 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:45	PJG
Aroclor-1268 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:45	PJG
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/5/12 10:45	
Decachlorobiphenyl [2]		*	30-150		S-01			4/5/12 10:45	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/5/12 10:45	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/5/12 10:45	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBB-019

Sampled: 3/29/2012 13:15

Sample ID: 12C0993-16
Sample Matrix: Concrete

Polychlorinated	Rinhenvls	with 3540	Soxhlet Extraction
ronychiormateu	Diphenyis	WILL 3340	SOMHET EXTRACTION

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:37	JMB
Aroclor-1221 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:37	JMB
Aroclor-1232 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:37	JMB
Aroclor-1242 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:37	JMB
Aroclor-1248 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:37	JMB
Aroclor-1254 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:37	JMB
Aroclor-1260 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:37	JMB
Aroclor-1262 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:37	JMB
Aroclor-1268 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:37	JMB
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		90.9	30-150					4/2/12 16:37	
Decachlorobiphenyl [2]		95.0	30-150					4/2/12 16:37	
Tetrachloro-m-xylene [1]		92.3	30-150					4/2/12 16:37	
Tetrachloro-m-xylene [2]		86.2	30-150					4/2/12 16:37	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBB-020

Sampled: 3/29/2012 13:25

Sample ID: 12C0993-17
Sample Matrix: Concrete

Polychlorinated	Biphenyls	with 3540	Soxhlet Extraction

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:50	JMB
Aroclor-1221 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:50	JMB
Aroclor-1232 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:50	JMB
Aroclor-1242 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:50	JMB
Aroclor-1248 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:50	JMB
Aroclor-1254 [1]	0.64	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:50	JMB
Aroclor-1260 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:50	JMB
Aroclor-1262 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:50	JMB
Aroclor-1268 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 16:50	JMB
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		93.9	30-150					4/2/12 16:50	
Decachlorobiphenyl [2]		98.3	30-150					4/2/12 16:50	
Tetrachloro-m-xylene [1]		98.8	30-150					4/2/12 16:50	
Tetrachloro-m-xylene [2]		92.5	30-150					4/2/12 16:50	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBB-022 Sampled: 3/29/2012 14:10

Sample ID: 12C0993-18
Sample Matrix: Concrete

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:02	JMB
Aroclor-1221 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:02	JMB
Aroclor-1232 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:02	JMB
Aroclor-1242 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:02	JMB
Aroclor-1248 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:02	JMB
Aroclor-1254 [1]	4.1	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:02	JMB
Aroclor-1260 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:02	JMB
Aroclor-1262 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:02	JMB
Aroclor-1268 [1]	ND	0.50	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:02	JMB
Surrogates		% Recovery	Recovery Limits	s	Flag				
Decachlorobiphenyl [1]		95.4	30-150					4/2/12 17:02	
Decachlorobiphenyl [2]		99.8	30-150					4/2/12 17:02	
Tetrachloro-m-xylene [1]		102	30-150					4/2/12 17:02	
Tetrachloro-m-xylene [2]		95.7	30-150					4/2/12 17:02	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBR-024

Sampled: 3/29/2012 14:30

Sample ID: 12C0993-19
Sample Matrix: Concrete

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.95	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:41	JMB
Aroclor-1221 [1]	ND	0.95	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:41	JMB
Aroclor-1232 [1]	ND	0.95	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:41	JMB
Aroclor-1242 [1]	ND	0.95	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:41	JMB
Aroclor-1248 [1]	ND	0.95	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:41	JMB
Aroclor-1254 [1]	8.2	0.95	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:41	JMB
Aroclor-1260 [1]	ND	0.95	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:41	JMB
Aroclor-1262 [1]	ND	0.95	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:41	JMB
Aroclor-1268 [1]	ND	0.95	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:41	JMB
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		95.7	30-150					4/3/12 7:41	
Decachlorobiphenyl [2]		93.0	30-150					4/3/12 7:41	
Tetrachloro-m-xylene [1]		106	30-150					4/3/12 7:41	
Tetrachloro-m-xylene [2]		95.1	30-150					4/3/12 7:41	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-025

Sampled: 3/29/2012 14:40

Sample ID: 12C0993-20
Sample Matrix: Caulk

Polychlorinated B	Rinhenvls with	3540 Sovhlet l	Extraction

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	170	mg/Kg	1000		SW-846 8082A	4/2/12	4/5/12 0:50	PJG
Aroclor-1221 [1]	ND	170	mg/Kg	1000		SW-846 8082A	4/2/12	4/5/12 0:50	PJG
Aroclor-1232 [1]	ND	170	mg/Kg	1000		SW-846 8082A	4/2/12	4/5/12 0:50	PJG
Aroclor-1242 [1]	ND	170	mg/Kg	1000		SW-846 8082A	4/2/12	4/5/12 0:50	PJG
Aroclor-1248 [1]	ND	170	mg/Kg	1000		SW-846 8082A	4/2/12	4/5/12 0:50	PJG
Aroclor-1254 [1]	2300	170	mg/Kg	1000		SW-846 8082A	4/2/12	4/5/12 0:50	PJG
Aroclor-1260 [2]	760	170	mg/Kg	1000		SW-846 8082A	4/2/12	4/5/12 0:50	PJG
Aroclor-1262 [1]	ND	170	mg/Kg	1000		SW-846 8082A	4/2/12	4/5/12 0:50	PJG
Aroclor-1268 [1]	ND	170	mg/Kg	1000		SW-846 8082A	4/2/12	4/5/12 0:50	PJG
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/5/12 0:50	
Decachlorobiphenyl [2]		*	30-150		S-01			4/5/12 0:50	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/5/12 0:50	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/5/12 0:50	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBB-027

Sampled: 3/29/2012 14:55

Sample ID: 12C0993-21
Sample Matrix: Concrete

Polychloringted	Rinhenvls	with ?	3 <i>54</i> 0 Sax	hlet F	vtraction

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:27	JMB
Aroclor-1221 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:27	JMB
Aroclor-1232 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:27	JMB
Aroclor-1242 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:27	JMB
Aroclor-1248 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:27	JMB
Aroclor-1254 [1]	2.9	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:27	JMB
Aroclor-1260 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:27	JMB
Aroclor-1262 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:27	JMB
Aroclor-1268 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:27	JMB
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		90.9	30-150					4/2/12 17:27	
Decachlorobiphenyl [2]		94.9	30-150					4/2/12 17:27	
Tetrachloro-m-xylene [1]		97.4	30-150					4/2/12 17:27	
Tetrachloro-m-xylene [2]		90.8	30-150					4/2/12 17:27	



Analyte

39 Spruce Street * East Longmeadow, MA 01028 * FAX 413/525-6405 * TEL. 413/525-2332

Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBR-029

Sampled: 3/29/2012 15:10

Results

ND

ND

ND

ND

ND

10

ND

ND

1.0

1.0

Sample ID: 12C0993-22
Sample Matrix: Concrete

Aroclor-1016 [1]

Aroclor-1221 [1]

Aroclor-1232 [1]

Aroclor-1242 [1]

Aroclor-1248 [1]

Aroclor-1254 [1]

Aroclor-1260 [1]

Aroclor-1262 [1]

Polychlorina	ted Biphenyls w	vith 3540 Soxhle	t Extraction				
					Date	Date/Time	
RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:53	JMB
1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:53	JMB
1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:53	JMB
1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:53	JMB
1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:53	JMB
1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:53	JMB

SW-846 8082A

SW-846 8082A

3/30/12

3/30/12

Aroclor-1268 [1]	ND	1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 7:53	JMB
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		93.9	30-150					4/3/12 7:53	_
Decachlorobiphenyl [2]		92.1	30-150					4/3/12 7:53	
Tetrachloro-m-xylene [1]		105	30-150					4/3/12 7:53	
Tetrachloro-m-xylene [2]		94.1	30-150					4/3/12 7:53	

10

10

mg/Kg

mg/Kg

JMB

JMB

4/3/12 7:53

4/3/12 7:53



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBB-030

Sampled: 3/29/2012 15:20

Sample ID: 12C0993-23
Sample Matrix: Concrete

Polychlorinated Bipher	nyls with 3540 Soxhlet E	extraction
Polychlorinated Bipher	nyls with 3540 Soxhlet E	xtraction

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:52	JMB
Aroclor-1221 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:52	JMB
Aroclor-1232 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:52	JMB
Aroclor-1242 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:52	JMB
Aroclor-1248 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:52	JMB
Aroclor-1254 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:52	JMB
Aroclor-1260 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:52	JMB
Aroclor-1262 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:52	JMB
Aroclor-1268 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 17:52	JMB
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		96.5	30-150					4/2/12 17:52	
Decachlorobiphenyl [2]		101	30-150					4/2/12 17:52	
Tetrachloro-m-xylene [1]		101	30-150					4/2/12 17:52	
Tetrachloro-m-xylene [2]		94.4	30-150					4/2/12 17:52	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Sample Matrix: Concrete

Field Sample #: KCL-CBB-031

Sample ID: 12C0993-24

Sampled: 3/29/2012 15:25

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:04	JMB
Aroclor-1221 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:04	JMB
Aroclor-1232 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:04	JMB
Aroclor-1242 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:04	JMB
Aroclor-1248 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:04	JMB
Aroclor-1254 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:04	JMB
Aroclor-1260 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:04	JMB
Aroclor-1262 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:04	JMB
Aroclor-1268 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:04	JMB
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		94.2	30-150					4/2/12 18:04	
Decachlorobiphenyl [2]		98.5	30-150					4/2/12 18:04	
Tetrachloro-m-xylene [1]		98.7	30-150					4/2/12 18:04	
Tetrachloro-m-xylene [2]		91.7	30-150					4/2/12 18:04	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBK-032

Sample ID: 12C0993-25
Sample Matrix: Caulk

Sampled: 3/29/2012 15:26

Polychlorinated Biphenyls with 3540 Soxhlet Extraction

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	440	mg/Kg	2500		SW-846 8082A	4/2/12	4/5/12 1:03	PJG
Aroclor-1221 [1]	ND	440	mg/Kg	2500		SW-846 8082A	4/2/12	4/5/12 1:03	PJG
Aroclor-1232 [1]	ND	440	mg/Kg	2500		SW-846 8082A	4/2/12	4/5/12 1:03	PJG
Aroclor-1242 [1]	ND	440	mg/Kg	2500		SW-846 8082A	4/2/12	4/5/12 1:03	PJG
Aroclor-1248 [1]	ND	440	mg/Kg	2500		SW-846 8082A	4/2/12	4/5/12 1:03	PJG
Aroclor-1254 [1]	6500	440	mg/Kg	2500		SW-846 8082A	4/2/12	4/5/12 1:03	PJG
Aroclor-1260 [1]	ND	440	mg/Kg	2500		SW-846 8082A	4/2/12	4/5/12 1:03	PJG
Aroclor-1262 [1]	ND	440	mg/Kg	2500		SW-846 8082A	4/2/12	4/5/12 1:03	PJG
Aroclor-1268 [1]	ND	440	mg/Kg	2500		SW-846 8082A	4/2/12	4/5/12 1:03	PJG
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/5/12 1:03	
Decachlorobiphenyl [2]		*	30-150		S-01			4/5/12 1:03	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/5/12 1:03	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/5/12 1:03	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBR-033

Sampled: 3/29/2012 15:35

Sample ID: 12C0993-26
Sample Matrix: Concrete

Polychlorinated Biphenyls with 3540 Soxhlet Extraction	

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:16	JMB
Aroclor-1221 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:16	JMB
Aroclor-1232 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:16	JMB
Aroclor-1242 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:16	JMB
Aroclor-1248 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:16	JMB
Aroclor-1254 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:16	JMB
Aroclor-1260 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:16	JMB
Aroclor-1262 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:16	JMB
Aroclor-1268 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	3/30/12	4/2/12 18:16	JMB
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		93.1	30-150					4/2/12 18:16	
Decachlorobiphenyl [2]		97.3	30-150					4/2/12 18:16	
Tetrachloro-m-xylene [1]		97.3	30-150					4/2/12 18:16	
Tetrachloro-m-xylene [2]		90.1	30-150					4/2/12 18:16	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBR-035

Sampled: 3/29/2012 16:05

Sample ID: 12C0993-27
Sample Matrix: Concrete

Polychlorinated	Biphenyls	with 3540	Soxhlet Extraction

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 8:06	JMB
Aroclor-1221 [1]	ND	1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 8:06	JMB
Aroclor-1232 [1]	ND	1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 8:06	JMB
Aroclor-1242 [1]	ND	1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 8:06	JMB
Aroclor-1248 [1]	ND	1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 8:06	JMB
Aroclor-1254 [1]	7.9	1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 8:06	JMB
Aroclor-1260 [1]	ND	1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 8:06	JMB
Aroclor-1262 [1]	ND	1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 8:06	JMB
Aroclor-1268 [1]	ND	1.0	mg/Kg	10		SW-846 8082A	3/30/12	4/3/12 8:06	JMB
Surrogates		% Recovery	Recovery Limits	ı	Flag				
Decachlorobiphenyl [1]		94.7	30-150					4/3/12 8:06	
Decachlorobiphenyl [2]		93.1	30-150					4/3/12 8:06	
Tetrachloro-m-xylene [1]		105	30-150					4/3/12 8:06	
Tetrachloro-m-xylene [2]		93.4	30-150					4/3/12 8:06	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBKD-040

Sample ID: 12C0993-30
Sample Matrix: Concrete

Sampled: 3/29/2012 09:50

Polychlorinated Biphenyls with 3540 Soxhlet Extraction

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:58	PJG
Aroclor-1221 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:58	PJG
Aroclor-1232 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:58	PJG
Aroclor-1242 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:58	PJG
Aroclor-1248 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:58	PJG
Aroclor-1254 [1]	440000	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:58	PJG
Aroclor-1260 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:58	PJG
Aroclor-1262 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:58	PJG
Aroclor-1268 [1]	ND	36000	mg/Kg	200000		SW-846 8082A	4/2/12	4/5/12 10:58	PJG
Surrogates		% Recovery	Recovery Limit	ts	Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			4/5/12 10:58	
Decachlorobiphenyl [2]		*	30-150		S-01			4/5/12 10:58	
Tetrachloro-m-xylene [1]		*	30-150		S-01			4/5/12 10:58	
Tetrachloro-m-xylene [2]		*	30-150		S-01			4/5/12 10:58	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBBD-041 Sampled: 3/29/2012 14:10

Sample ID: 12C0993-31
Sample Matrix: Concrete

Polychlorinated Biphenyls with 3540 Soxhlet Extraction

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	4/2/12	4/4/12 2:20	MJC
Aroclor-1221 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	4/2/12	4/4/12 2:20	MJC
Aroclor-1232 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	4/2/12	4/4/12 2:20	MJC
Aroclor-1242 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	4/2/12	4/4/12 2:20	MJC
Aroclor-1248 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	4/2/12	4/4/12 2:20	MJC
Aroclor-1254 [2]	3.2	0.48	mg/Kg	5	P-04	SW-846 8082A	4/2/12	4/4/12 2:20	MJC
Aroclor-1260 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	4/2/12	4/4/12 2:20	MJC
Aroclor-1262 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	4/2/12	4/4/12 2:20	MJC
Aroclor-1268 [1]	ND	0.48	mg/Kg	5		SW-846 8082A	4/2/12	4/4/12 2:20	MJC
Surrogates		% Recovery	Recovery Limits	S	Flag				
Decachlorobiphenyl [1]		104	30-150					4/4/12 2:20	
Decachlorobiphenyl [2]		104	30-150					4/4/12 2:20	
Tetrachloro-m-xylene [1]		106	30-150					4/4/12 2:20	
Tetrachloro-m-xylene [2]		106	30-150					4/4/12 2:20	



Project Location: Yale KCL Sample Description: Work Order: 12C0993

Date Received: 3/30/2012

Field Sample #: KCL-CBBQ-042

Sampled: 3/29/2012 17:10

Sample ID: 12C0993-32

Sample Matrix: Equipment Blank Water

Polychlorinated	Biphenyls	By GC/ECD
1 ory contornation	Diplicityis	Dy GC/LCD

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.20	μg/L	1		SW-846 8082A	3/31/12	4/2/12 14:50	PJG
Aroclor-1221 [1]	ND	0.20	μg/L	1		SW-846 8082A	3/31/12	4/2/12 14:50	PJG
Aroclor-1232 [1]	ND	0.20	μg/L	1		SW-846 8082A	3/31/12	4/2/12 14:50	PJG
Aroclor-1242 [1]	ND	0.20	μg/L	1		SW-846 8082A	3/31/12	4/2/12 14:50	PJG
Aroclor-1248 [1]	ND	0.20	μg/L	1		SW-846 8082A	3/31/12	4/2/12 14:50	PJG
Aroclor-1254 [1]	ND	0.20	μg/L	1		SW-846 8082A	3/31/12	4/2/12 14:50	PJG
Aroclor-1260 [1]	ND	0.20	μg/L	1		SW-846 8082A	3/31/12	4/2/12 14:50	PJG
Aroclor-1262 [1]	ND	0.20	μg/L	1		SW-846 8082A	3/31/12	4/2/12 14:50	PJG
Aroclor-1268 [1]	ND	0.20	μg/L	1		SW-846 8082A	3/31/12	4/2/12 14:50	PJG
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		54.2	30-150					4/2/12 14:50	
Decachlorobiphenyl [2]		53.4	30-150					4/2/12 14:50	
Tetrachloro-m-xylene [1]		90.3	30-150					4/2/12 14:50	
Tetrachloro-m-xylene [2]		91.9	30-150					4/2/12 14:50	



Sample Extraction Data

Prep Method: SW-846 3546-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [g]	Final [mL]	Date	
12C0993-01 [KCL-CBK-001]	B048989	0.532	10.0	04/02/12	
12C0993-02 [KCL-CBK-002]	B048989	0.552	10.0	04/02/12	
12C0993-03 [KCL-CBK-003]	B048989	0.560	10.0	04/02/12	
12C0993-04 [KCL-CBK-004]	B048989	0.579	10.0	04/02/12	
12C0993-05 [KCL-CBK-005]	B048989	0.502	10.0	04/02/12	
12C0993-06 [KCL-CBK-006]	B048989	0.558	10.0	04/02/12	
12C0993-07 [KCL-CBK-007]	B048989	0.528	10.0	04/02/12	
12C0993-08 [KCL-CBK-008]	B048989	0.531	10.0	04/02/12	
12C0993-09 [KCL-CBK-012]	B048989	0.512	10.0	04/02/12	
12C0993-10 [KCL-CBK-013]	B048989	0.523	10.0	04/02/12	
12C0993-11 [KCL-CBK-014]	B048989	0.523	10.0	04/02/12	
12C0993-14 [KCL-CBK-017]	B048989	0.578	10.0	04/02/12	
12C0993-15 [KCL-CBK-018]	B048989	0.557	10.0	04/02/12	
12C0993-20 [KCL-CBK-025]	B048989	0.579	10.0	04/02/12	
12C0993-25 [KCL-CBK-032]	B048989	0.562	10.0	04/02/12	
12C0993-30 [KCL-CBKD-040]	B048989	0.558	10.0	04/02/12	

Prep Method: SW-846 3540C-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [g]	Final [mL]	Date
12C0993-12 [KCL-CBC-015]	B048908	2.10	10.0	03/30/12
12C0993-13 [KCL-CBC-016]	B048908	2.10	10.0	03/30/12
12C0993-16 [KCL-CBB-019]	B048908	2.10	10.0	03/30/12
12C0993-17 [KCL-CBB-020]	B048908	2.00	10.0	03/30/12
12C0993-18 [KCL-CBB-022]	B048908	2.00	10.0	03/30/12
12C0993-19 [KCL-CBR-024]	B048908	2.10	10.0	03/30/12
12C0993-21 [KCL-CBB-027]	B048908	2.30	10.0	03/30/12
12C0993-22 [KCL-CBR-029]	B048908	2.00	10.0	03/30/12
12C0993-23 [KCL-CBB-030]	B048908	2.30	10.0	03/30/12
12C0993-24 [KCL-CBB-031]	B048908	2.10	10.0	03/30/12
12C0993-26 [KCL-CBR-033]	B048908	2.10	10.0	03/30/12
12C0993-27 [KCL-CBR-035]	B048908	2.00	10.0	03/30/12

Prep Method: SW-846 3546-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [g]	Final [mL]	Date
12C0993-31 [KCL-CBBD-041]	B048990	2.06	10.0	04/02/12

Prep Method: SW-846 3510C-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [mL]	Final [mL]	Date
12C0993-32 [KCL-CBBQ-042]	B048921	1000	10.0	03/31/12



QUALITY CONTROL

Polychlorinated Biphenyls By GC/ECD - Quality Control

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B048921 - SW-846 3510C										
Blank (B048921-BLK1)				Prepared: 03	3/31/12 Anal	yzed: 04/02/	12			
Aroclor-1016	ND	0.20	μg/L							
Aroclor-1016 [2C]	ND	0.20	μg/L							
Aroclor-1221	ND	0.20	μg/L							
aroclor-1221 [2C]	ND	0.20	μg/L							
aroclor-1232	ND	0.20	μg/L							
Aroclor-1232 [2C]	ND	0.20	μg/L							
Aroclor-1242	ND	0.20	μg/L							
aroclor-1242 [2C]	ND	0.20	μg/L							
Aroclor-1248	ND	0.20	μg/L							
Aroclor-1248 [2C]	ND	0.20	μg/L							
Aroclor-1254	ND	0.20	μg/L							
Aroclor-1254 [2C]	ND	0.20	μg/L							
Aroclor-1260	ND	0.20	μg/L							
Aroclor-1260 [2C]	ND	0.20	μg/L							
Aroclor-1262	ND	0.20	μg/L							
aroclor-1262 [2C]	ND	0.20	μg/L							
aroclor-1268	ND	0.20	μg/L							
aroclor-1268 [2C]	ND	0.20	μg/L							
urrogate: Decachlorobiphenyl	1.24		μg/L	2.00		61.9	30-150			
urrogate: Decachlorobiphenyl [2C]	1.21		$\mu g/L$	2.00		60.6	30-150			
urrogate: Tetrachloro-m-xylene	1.41		μg/L	2.00		70.4	30-150			
urrogate: Tetrachloro-m-xylene [2C]	1.43		$\mu g/L$	2.00		71.6	30-150			
CS (B048921-BS1)				Prepared: 03	3/31/12 Anal	yzed: 04/02/	12			
roclor-1016	0.42	0.20	μg/L	0.500		83.7	40-140			
aroclor-1016 [2C]	0.42	0.20	μg/L	0.500		83.2	40-140			
Aroclor-1260	0.39	0.20	μg/L	0.500		77.2	40-140			
Aroclor-1260 [2C]	0.38	0.20	μg/L	0.500		75.2	40-140			
urrogate: Decachlorobiphenyl	1.25		μg/L	2.00		62.4	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.22		μg/L	2.00		61.2	30-150			
Surrogate: Tetrachloro-m-xylene	1.49		μg/L	2.00		74.5	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	1.53		$\mu g/L$	2.00		76.6	30-150			
.CS Dup (B048921-BSD1)				Prepared: 03	3/31/12 Anal	yzed: 04/02/	12			
Aroclor-1016	0.47	0.20	μg/L	0.500		94.9	40-140	12.6	20	
aroclor-1016 [2C]	0.47	0.20	μg/L	0.500		94.6	40-140	12.8	20	
Aroclor-1260	0.44	0.20	μg/L	0.500		87.3	40-140	12.4	20	
Aroclor-1260 [2C]	0.43	0.20	μg/L	0.500		85.7	40-140	13.1	20	
Surrogate: Decachlorobiphenyl	1.36		μg/L	2.00		68.1	30-150		-	
surrogate: Decachlorobiphenyl [2C]	1.36 1.34			2.00		67.2	30-150			
Surrogate: Decacniorooipnenyi [2C]	1.34 1.71		μg/L ug/I			85.5	30-150			
Surrogate: Tetrachloro-m-xylene Surrogate: Tetrachloro-m-xylene [2C]	1.71 1.76		μg/L	2.00 2.00		85.5 87.9	30-150			
ourrogate. retractitoro-in-xytette [2C]	1./0		μg/L	∠.00		01.9	30-130			



QUALITY CONTROL

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B048908 - SW-846 3540C										
Blank (B048908-BLK1)				Prepared: 03	3/30/12 Anal	yzed: 04/02/1	12			
Aroclor-1016	ND	0.10	mg/Kg							
Aroclor-1016 [2C]	ND	0.10	mg/Kg							
Aroclor-1221	ND	0.10	mg/Kg							
Aroclor-1221 [2C]	ND	0.10	mg/Kg							
Aroclor-1232	ND	0.10	mg/Kg							
Aroclor-1232 [2C]	ND	0.10	mg/Kg							
Aroclor-1242	ND	0.10	mg/Kg							
Aroclor-1242 [2C]	ND	0.10	mg/Kg							
Aroclor-1248	ND	0.10	mg/Kg							
Aroclor-1248 [2C]	ND	0.10	mg/Kg							
Aroclor-1254	ND	0.10	mg/Kg							
Aroclor-1254 [2C]	ND	0.10	mg/Kg							
Aroclor-1260	ND	0.10	mg/Kg							
Aroclor-1260 [2C]	ND	0.10	mg/Kg							
Aroclor-1262	ND	0.10	mg/Kg							
Aroclor-1262 [2C]	ND	0.10	mg/Kg							
Aroclor-1268	ND	0.10	mg/Kg							
Aroclor-1268 [2C]	ND	0.10	mg/Kg							
Surrogate: Decachlorobiphenyl	0.966		mg/Kg	1.00		96.6	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.01		mg/Kg	1.00		101	30-150			
Surrogate: Tetrachloro-m-xylene	1.03		mg/Kg	1.00		103	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	0.967		mg/Kg	1.00		96.7	30-150			
.CS (B048908-BS1)				Prepared: 03	3/30/12 Anal	yzed: 04/02/1	2			
Aroclor-1016	0.28	0.10	mg/Kg	0.250		111	40-140			
Aroclor-1016 [2C]	0.26	0.10	mg/Kg	0.250		105	40-140			
Aroclor-1260	0.26	0.10	mg/Kg	0.250		105	40-140			
Aroclor-1260 [2C]	0.25	0.10	mg/Kg	0.250		99.1	40-140			
Surrogate: Decachlorobiphenyl	0.975		mg/Kg	1.00		97.5	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.02		mg/Kg	1.00		102	30-150			
Surrogate: Tetrachloro-m-xylene	0.987		mg/Kg	1.00		98.7	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	0.965		mg/Kg	1.00		96.5	30-150			
.CS Dup (B048908-BSD1)				Prepared: 03	3/30/12 Anal	yzed: 04/02/1	2			
Aroclor-1016	0.28	0.10	mg/Kg	0.250		113	40-140	1.32	30	
Aroclor-1016 [2C]	0.26	0.10	mg/Kg	0.250		104	40-140	1.12	30	
Aroclor-1260	0.26	0.10	mg/Kg	0.250		104	40-140	1.34	30	
Aroclor-1260 [2C]	0.24	0.10	mg/Kg	0.250		97.8	40-140	1.29	30	
Surrogate: Decachlorobiphenyl	0.947	·	mg/Kg	1.00		94.7	30-150		·	
Surrogate: Decachlorobiphenyl [2C]	0.995		mg/Kg	1.00		99.5	30-150			
Surrogate: Tetrachloro-m-xylene	0.972		mg/Kg	1.00		97.2	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	0.947		mg/Kg	1.00		94.7	30-150			



QUALITY CONTROL

		Reporting		Spike	Source			%REC		RPD	
Analyte	Result	Limit	Units	Level	Result	%RE	C	Limits	RPD	Limit	Notes
Satch B048908 - SW-846 3540C											
Matrix Spike (B048908-MS1)	Source	e: 12C0993-	-12	Prepared: 03	/30/12 Analyz	zed: 04/	03/12	2			
aroclor-1016	0.65	0.10	mg/Kg	0.250	0.0	260	*	40-140			MS-21
roclor-1016 [2C]	1.5	0.10	mg/Kg	0.250	0.0	602	*	40-140			MS-21
roclor-1260	1.6	0.10	mg/Kg	0.250	0.0	620	*	40-140			MS-21
aroclor-1260 [2C]	1.5	0.10	mg/Kg	0.250	0.0	611	*	40-140			MS-21
urrogate: Decachlorobiphenyl	0.877		mg/Kg	1.00		87.7		30-150			
urrogate: Decachlorobiphenyl [2C]	0.881		mg/Kg	1.00		88.1		30-150			
urrogate: Tetrachloro-m-xylene	0.933		mg/Kg	1.00		93.3		30-150			
urrogate: Tetrachloro-m-xylene [2C]	0.899		mg/Kg	1.00		89.9		30-150			
latrix Spike Dup (B048908-MSD1)	Source	e: 12C0993-	-12	Prepared: 03	/30/12 Analyz	zed: 04/	03/12	2			
roclor-1016	0.81	0.10	mg/Kg	0.250	0.0	324	*	40-140	21.8	50	MS-21
roclor-1016 [2C]	1.4	0.10	mg/Kg	0.250	0.0	569	*	40-140	5.63	50	MS-21
croclor-1260	1.4	0.10	mg/Kg	0.250	0.0	577	*	40-140	7.20	50	MS-21
roclor-1260 [2C]	1.4	0.10	mg/Kg	0.250	0.0	567	*	40-140	7.42	50	MS-21
urrogate: Decachlorobiphenyl	0.928		mg/Kg	1.00		92.8		30-150			
urrogate: Decachlorobiphenyl [2C]	0.937		mg/Kg	1.00		93.7		30-150			
urrogate: Tetrachloro-m-xylene	0.963		mg/Kg	1.00		96.3		30-150			
urrogate: Tetrachloro-m-xylene [2C]	0.926		mg/Kg	1.00		92.6		30-150			
Batch B048989 - SW-846 3546											
satch B048989 - SW-846 3546				Prepared: 04	/02/12 Analyz	red: 04/	04/12	2			
	ND	0.20	mg/Kg	Prepared: 04	/02/12 Analyz	red: 04/	04/12	2			
Blank (B048989-BLK1)	ND ND	0.20 0.20	mg/Kg mg/Kg	Prepared: 04	/02/12 Analyz	zed: 04/	04/12	2			
Blank (B048989-BLK1) Aroclor-1016				Prepared: 04	/02/12 Analy2	zed: 04/	04/12	2			
slank (B048989-BLK1) troclor-1016 troclor-1016 [2C]	ND	0.20	mg/Kg	Prepared: 04	/02/12 Analy <i>a</i>	zed: 04/	04/12	2			
ilank (B048989-BLK1) troclor-1016 troclor-1016 [2C] troclor-1221	ND ND	0.20 0.20	mg/Kg mg/Kg	Prepared: 04	/02/12 Analy <i>a</i>	zed: 04/	04/12	2			
Slank (B048989-BLK1) troclor-1016 troclor-1016 [2C] troclor-1221 troclor-1221 [2C]	ND ND ND	0.20 0.20 0.20	mg/Kg mg/Kg mg/Kg	Prepared: 04	/02/12 Analyz	zed: 04/	04/12	2			
Slank (B048989-BLK1) proclor-1016 proclor-1221 proclor-1221 [2C] proclor-1232	ND ND ND ND	0.20 0.20 0.20 0.20	mg/Kg mg/Kg mg/Kg mg/Kg	Prepared: 04	/02/12 Analy <i>z</i>	zed: 04/	04/12	2			
Slank (B048989-BLK1) Arcolor-1016 Arcolor-1221 Arcolor-1221 [2C] Arcolor-1232 Arcolor-1232 [2C]	ND ND ND ND	0.20 0.20 0.20 0.20 0.20	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg	Prepared: 04	/02/12 Analy <i>z</i>	zed: 04/	04/12	2			
Slank (B048989-BLK1) Arcolor-1016 Arcolor-1221 Arcolor-1221 [2C] Arcolor-1232 Arcolor-1232 [2C] Arcolor-1242	ND ND ND ND ND ND ND ND	0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg	Prepared: 04	/02/12 Analy <i>z</i>	zed: 04/	04/12	2			
Slank (B048989-BLK1) Arcolor-1016 Arcolor-1221 Arcolor-1221 [2C] Arcolor-1232 [2C] Arcolor-1242 Arcolor-1242 Arcolor-1242 [2C]	ND	0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg	Prepared: 04	/02/12 Analy:	zed: 04/	04/12	2			
Slank (B048989-BLK1) Arcolor-1016 Arcolor-1221 Arcolor-1221 [2C] Arcolor-1232 Arcolor-1232 [2C] Arcolor-1242 Arcolor-1242 [2C] Arcolor-1248	ND N	0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg	Prepared: 04	/02/12 Analy:	zed: 04/	04/12	2			
slank (B048989-BLK1) croclor-1016 croclor-1221 croclor-1221 [2C] croclor-1232 croclor-1232 [2C] croclor-1242 croclor-1242 [2C] croclor-1248 croclor-1248 [2C]	ND N	0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg	Prepared: 04	/02/12 Analy:	zed: 04/	04/12	2			
clank (B048989-BLK1) croclor-1016 croclor-1221 croclor-1221 [2C] croclor-1232 croclor-1232 [2C] croclor-1242 croclor-1242 [2C] croclor-1248 croclor-1248 croclor-1254 croclor-1254 croclor-1254 croclor-1254 croclor-1254	ND N	0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg	Prepared: 04	/02/12 Analy:	zed: 04/	04/12	2			
Blank (B048989-BLK1) proclor-1016 proclor-1221 proclor-1221 [2C] proclor-1232 proclor-1232 [2C] proclor-1242 proclor-1242 [2C] proclor-1248 proclor-1248 [2C] proclor-1254 proclor-1254 [2C] proclor-1254 proclor-1254 [2C] proclor-1254 [2C] proclor-1254 [2C] proclor-1254 [2C] proclor-1254 [2C]	ND N	0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg	Prepared: 04	/02/12 Analy:	zed: 04/	04/12	2			
Blank (B048989-BLK1) proclor-1016 proclor-1221 proclor-1221 [2C] proclor-1232 proclor-1232 [2C] proclor-1242 proclor-1242 [2C] proclor-1248 proclor-1248 [2C] proclor-1254 proclor-1254 [2C] proclor-1254 proclor-1254 [2C] proclor-1260 proclor-1260 [2C]	ND N	0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg	Prepared: 04	/02/12 Analyz	zed: 04/	04/12	2			
clank (B048989-BLK1) croclor-1016 croclor-1221 croclor-1221 [2C] croclor-1232 croclor-1232 [2C] croclor-1242 croclor-1242 croclor-1248 croclor-1248 [2C] croclor-1254 croclor-1254 croclor-1254 croclor-1260 croclor-1260 croclor-1260 croclor-1262	ND N	0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg	Prepared: 04	/02/12 Analyz	zed: 04/	04/12	2			
Slank (B048989-BLK1) Arcolor-1016 Arcolor-1221 Arcolor-1222 Arcolor-1232 Arcolor-1232 [2C] Arcolor-1242 Arcolor-1242 [2C] Arcolor-1248 Arcolor-1248 [2C] Arcolor-1254	ND N	0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg	Prepared: 04	/02/12 Analyz	zed: 04/	04/12	2			
Blank (B048989-BLK1) Arcolor-1016 Arcolor-1221 Arcolor-1221 [2C] Arcolor-1232 Arcolor-1232 [2C] Arcolor-1242 Arcolor-1242 [2C] Arcolor-1248 Arcolor-1248 [2C] Arcolor-1254 Arcolor-1254 Arcolor-1260 Arcolor-1260 Arcolor-1260 [2C] Arcolor-1262 Arcolor-1262 [2C]	ND N	0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg	Prepared: 04	/02/12 Analy <i>z</i>	zed: 04/	04/12	2			
Blank (B048989-BLK1) Arcolor-1016 Arcolor-1221 Arcolor-1221 [2C] Arcolor-1232 Arcolor-1232 [2C] Arcolor-1242 Arcolor-1242 Arcolor-1248 Arcolor-1248 Arcolor-1254 Arcolor-1254 Arcolor-1260 Arcolor-1260 Arcolor-1260 Arcolor-1262 Arcolor-1262 Arcolor-1262 Arcolor-1268	ND N	0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg	Prepared: 04	/02/12 Analy:	red: 04/	04/12				
Slank (B048989-BLK1) Arcolor-1016 Arcolor-1211 Arcolor-1221 Arcolor-1232 Arcolor-1232 [2C] Arcolor-1242 Arcolor-1242 [2C] Arcolor-1248 Arcolor-1248 [2C] Arcolor-1254 Arcolor-1254 [2C] Arcolor-1260 Arcolor-1260 Arcolor-1262 Arcolor-1262 Arcolor-1262 Arcolor-1268 Arcolor-1268 Arcolor-1268 Arcolor-1268 Arcolor-1268 Arcolor-1268	ND N	0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg	4.00	/02/12 Analy:		04/12	30-150			
Slank (B048989-BLK1) Arcolor-1016 Arcolor-1211 Arcolor-1221 Arcolor-1232 Arcolor-1232 [2C] Arcolor-1242 Arcolor-1242 [2C] Arcolor-1248 Arcolor-1248 [2C] Arcolor-1254 Arcolor-1254 Arcolor-1260 Arcolor-1260 Arcolor-1262 Arcolor-1262 Arcolor-1268 Arcolor-1268 Arcolor-1268 Arcolor-1268 [2C] Arcolor-1268 Arcolor-1268 [2C] Arcolor-1268 Arcolor-1268 [2C] Arcolor-1268 [2C]	ND N	0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20 0.20	mg/Kg		/02/12 Analy:	89.0	04/12				



QUALITY CONTROL

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B048989 - SW-846 3546										
CS (B048989-BS1)				Prepared: 04	1/02/12 Anal	yzed: 04/04/	12			
Aroclor-1016	4.2	0.20	mg/Kg	4.00		106	40-140		•	
Aroclor-1016 [2C]	4.3	0.20	mg/Kg	4.00		108	40-140			
Aroclor-1260	3.6	0.20	mg/Kg	4.00		91.1	40-140			
Aroclor-1260 [2C]	3.7	0.20	mg/Kg	4.00		93.2	40-140			
urrogate: Decachlorobiphenyl	3.28		mg/Kg	4.00		82.1	30-150			
Surrogate: Decachlorobiphenyl [2C]	3.32		mg/Kg	4.00		83.0	30-150			
Surrogate: Tetrachloro-m-xylene	4.73		mg/Kg	4.00		118	30-150			
urrogate: Tetrachloro-m-xylene [2C]	4.69		mg/Kg	4.00		117	30-150			
CS Dup (B048989-BSD1)				Prepared: 04	1/02/12 Anal	yzed: 04/04/	12			
roclor-1016	4.0	0.20	mg/Kg	4.00		98.9	40-140	7.14	30	
aroclor-1016 [2C]	4.1	0.20	mg/Kg	4.00		104	40-140	4.43	30	
Aroclor-1260	3.4	0.20	mg/Kg	4.00		84.5	40-140	7.45	30	
Aroclor-1260 [2C]	3.4	0.20	mg/Kg	4.00		86.2	40-140	7.79	30	
urrogate: Decachlorobiphenyl	2.97	·	mg/Kg	4.00	·	74.2	30-150			
urrogate: Decachlorobiphenyl [2C]	3.02		mg/Kg	4.00		75.6	30-150			
urrogate: Tetrachloro-m-xylene	4.51		mg/Kg	4.00		113	30-150			
urrogate: Tetrachloro-m-xylene [2C]	4.48		mg/Kg	4.00		112	30-150			
Batch B048990 - SW-846 3546										
Blank (B048990-BLK1)				Prepared: 04	1/02/12 Anal	yzed: 04/04/	12			
Aroclor-1016	ND	0.10	mg/Kg							
aroclor-1016 [2C]	ND	0.10	mg/Kg							
Aroclor-1221	ND	0.10	mg/Kg							
		0.10	mg/Kg							
Aroclor-1221 [2C]	ND	0.10								
	ND ND	0.10	mg/Kg							
Aroclor-1232										
Aroclor-1221 [2C] Aroclor-1232 Aroclor-1232 [2C] Aroclor-1242	ND	0.10	mg/Kg							
Aroclor-1232 Aroclor-1232 [2C] Aroclor-1242	ND ND	0.10 0.10	mg/Kg mg/Kg							
troclor-1232 troclor-1232 [2C] troclor-1242 troclor-1242 [2C]	ND ND ND	0.10 0.10 0.10	mg/Kg mg/Kg mg/Kg							
roclor-1232 roclor-1232 [2C] roclor-1242 roclor-1242 [2C] roclor-1248	ND ND ND ND	0.10 0.10 0.10 0.10	mg/Kg mg/Kg mg/Kg mg/Kg							
troclor-1232 troclor-1232 [2C] troclor-1242 troclor-1242 [2C] troclor-1248 troclor-1248 [2C]	ND ND ND ND	0.10 0.10 0.10 0.10 0.10	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg							
Aroclor-1232 Aroclor-1232 [2C] Aroclor-1242 Aroclor-1242 [2C] Aroclor-1248 Aroclor-1248 [2C] Aroclor-1254	ND ND ND ND ND	0.10 0.10 0.10 0.10 0.10 0.10	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg							
troclor-1232 troclor-1232 [2C] troclor-1242 troclor-1242 [2C] troclor-1248 troclor-1254 troclor-1254 troclor-1254 [2C]	ND ND ND ND ND ND	0.10 0.10 0.10 0.10 0.10 0.10 0.10	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg							
roclor-1232 roclor-1232 [2C] roclor-1242 roclor-1242 [2C] roclor-1248 roclor-1248 [2C] roclor-1254 roclor-1254 [2C] roclor-1254 [2C]	ND	0.10 0.10 0.10 0.10 0.10 0.10 0.10	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg							
roclor-1232 roclor-1232 [2C] roclor-1242 roclor-1242 [2C] roclor-1248 roclor-1248 [2C] roclor-1254 roclor-1254 [2C] roclor-1260 roclor-1260 [2C]	ND	0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg							
roclor-1232 roclor-1232 [2C] roclor-1242 roclor-1248 roclor-1248 [2C] roclor-1254 roclor-1254 roclor-1260 roclor-1260 [2C] roclor-1262	ND N	0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10	mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg mg/Kg							
roclor-1232 roclor-1232 [2C] roclor-1242 roclor-1242 [2C] roclor-1248 roclor-1248 [2C] roclor-1254 roclor-1254 [2C] roclor-1260 roclor-1260 [2C] roclor-1262 roclor-1262 [2C]	ND N	0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10	mg/Kg							
roclor-1232 roclor-1232 [2C] roclor-1242 roclor-1242 [2C] roclor-1248 roclor-1248 [2C] roclor-1254 roclor-1254 [2C] roclor-1260 roclor-1260 roclor-1262 roclor-1262 [2C] roclor-1262 [2C]	ND N	0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10	mg/Kg							
Aroclor-1232 Aroclor-1232 Aroclor-1242 Aroclor-1242 [2C] Aroclor-1248 Aroclor-1248 [2C] Aroclor-1254 Aroclor-1254 Aroclor-1260 Aroclor-1260 Aroclor-1262 Aroclor-1262 Aroclor-1268 Aroclor-1268	ND N	0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10	mg/Kg	1.00		96.1	30-150			
Aroclor-1232 Aroclor-1232 [2C]	ND N	0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10	mg/Kg	1.00 1.00		96.1 97.2	30-150 30-150			
Aroclor-1232 Aroclor-1242 Aroclor-1242 [2C] Aroclor-1248 Aroclor-1248 [2C] Aroclor-1254 Aroclor-1254 Aroclor-1260 Aroclor-1260 [2C] Aroclor-1262 Aroclor-1268 Aroclor-1268 Aroclor-1268 [2C] Surrogate: Decachlorobiphenyl	ND N	0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10 0.10	mg/Kg							



QUALITY CONTROL

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B048990 - SW-846 3546										
LCS (B048990-BS1)				Prepared: 04	1/02/12 Anal	yzed: 04/04/1	12			
Aroclor-1016	0.25	0.10	mg/Kg	0.250		101	40-140			V-06, V-20
Aroclor-1016 [2C]	0.26	0.10	mg/Kg	0.250		102	40-140			
Aroclor-1260	0.25	0.10	mg/Kg	0.250		100	40-140			
Aroclor-1260 [2C]	0.27	0.10	mg/Kg	0.250		106	40-140			
Surrogate: Decachlorobiphenyl	0.951		mg/Kg	1.00		95.1	30-150			
Surrogate: Decachlorobiphenyl [2C]	0.962		mg/Kg	1.00		96.2	30-150			
Surrogate: Tetrachloro-m-xylene	0.938		mg/Kg	1.00		93.8	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	0.924		mg/Kg	1.00		92.4	30-150			
LCS Dup (B048990-BSD1)				Prepared: 04	1/02/12 Anal	yzed: 04/04/1	12			
Aroclor-1016	0.27	0.10	mg/Kg	0.250		109	40-140	7.82	30	V-06, V-20
Aroclor-1016 [2C]	0.28	0.10	mg/Kg	0.250		111	40-140	8.23	30	
Aroclor-1260	0.27	0.10	mg/Kg	0.250		108	40-140	7.18	30	
Aroclor-1260 [2C]	0.28	0.10	mg/Kg	0.250		113	40-140	5.94	30	
Surrogate: Decachlorobiphenyl	1.02		mg/Kg	1.00		102	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.04		mg/Kg	1.00		104	30-150			
Surrogate: Tetrachloro-m-xylene	0.998		mg/Kg	1.00		99.8	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	0.990		mg/Kg	1.00		99.0	30-150			



FLAG/QUALIFIER SUMMARY

·	QC result is outside of established limits.
†	Wide recovery limits established for difficult compound.
‡	Wide RPD limits established for difficult compound.
#	Data exceeded client recommended or regulatory level
	Percent recoveries and relative percent differences (RPDs) are determined by the software using values in the calculation which have not been rounded.
MS-21	Matrix spike and/or spike duplicate recovery bias high due to contribution of other Aroclors present in the source sample.
P-04	Due to continuing calibration non-conformance on the confirmatory detector, the lower of two results was reported.
S-01	The surrogate recovery for this sample is not available due to sample dilution below the surrogate reporting limit required from high analyte concentration and/or matrix interferences.
V-06	Continuing calibration did not meet method specifications and was biased on the high side for this compound. Increased uncertainty is associated with the reported value which is likely to be biased on the high side.
V-20	Continuing calibration did not meet method specifications and was biased on the high side. Data validation is not affected since sample result was "not detected" for this compound.



CERTIFICATIONS

Certified Analyses included in this Report

Analyte	Certifications	
SW-846 8082A in Product/Solid		
Aroclor-1016	CT,NH,NY,ME,NC	
Aroclor-1016 [2C]	CT,NH,NY,ME,NC	
Aroclor-1221	CT,NH,NY,ME,NC	
Aroclor-1221 [2C]	CT,NH,NY,ME,NC	
Aroclor-1232	CT,NH,NY,ME,NC	
Aroclor-1232 [2C]	CT,NH,NY,ME,NC	
Aroclor-1242	CT,NH,NY,ME,NC	
Aroclor-1242 [2C]	CT,NH,NY,ME,NC	
Aroclor-1248	CT,NH,NY,ME,NC	
Aroclor-1248 [2C]	CT,NH,NY,ME,NC	
Aroclor-1254	CT,NH,NY,ME,NC	
Aroclor-1254 [2C]	CT,NH,NY,ME,NC	
Aroclor-1260	CT,NH,NY,ME,NC	
Aroclor-1260 [2C]	CT,NH,NY,ME,NC	
SW-846 8082A in Water		
Aroclor-1016	CT,NH,NY,RI,NC,ME	
Aroclor-1016 [2C]	CT,NH,NY,RI,NC,ME	
Aroclor-1221	CT,NH,NY,RI,NC,ME	
Aroclor-1221 [2C]	CT,NH,NY,RI,NC,ME	
Aroclor-1232	CT,NH,NY,RI,NC,ME	
Aroclor-1232 [2C]	CT,NH,NY,RI,NC,ME	
Aroclor-1242	CT,NH,NY,RI,NC,ME	
Aroclor-1242 [2C]	CT,NH,NY,RI,NC,ME	
Aroclor-1248	CT,NH,NY,RI,NC,ME	
Aroclor-1248 [2C]	CT,NH,NY,RI,NC,ME	
Aroclor-1254	CT,NH,NY,RI,NC,ME	
Aroclor-1254 [2C]	CT,NH,NY,RI,NC,ME	
Aroclor-1260	CT,NH,NY,RI,NC,ME	
Aroclor-1260 [2C]	CT,NH,NY,RI,NC,ME	
Aroclor-1262	NC	
Aroclor-1262 [2C]	NC	
Aroclor-1268	NC	
Aroclor-1268 [2C]	NC	



 $The \ CON-TEST \ Environmental \ Laboratory \ operates \ under \ the \ following \ certifications \ and \ accreditations:$

Code	Description	Number	Expires
AIHA	AIHA-LAP, LLC	100033	02/1/2014
MA	Massachusetts DEP	M-MA100	06/30/2012
CT	Connecticut Department of Publilc Health	PH-0567	09/30/2013
NY	New York State Department of Health	10899 NELAP	04/1/2013
NH	New Hampshire Environmental Lab	2516 NELAP	02/5/2013
RI	Rhode Island Department of Health	LAO00112	12/30/2012
NC	North Carolina Div. of Water Quality	652	12/31/2012
NJ	New Jersey DEP	MA007 NELAP	06/30/2012
FL	Florida Department of Health	E871027 NELAP	06/30/2012
VT	Vermont Department of Health Lead Laboratory	LL015036	07/30/2012
WA	State of Washington Department of Ecology	C2065	02/23/2013
ME	State of Maine	2011028	06/9/2013
VA	Commonwealth of Virginia	1381	12/14/2012

	N ACCORD			+	
SID#	MA State DW Form Required PWSID #		Connecticut:	RUSH †	Date/Time: /
)quired	 RCP Analysis Certification Form Required 			Other 50%	The South
Required	 MCP Analytical Certification Form Required 			10-Day	(signature)
	Ann broker were as were		Massachusetts:		
O = Other Crish		ments	Detection Limit Require	Turnaround **	Relinguished by (entitle) Date/Time:
SL = sludge	High; M - Medium; L - Low; C - Clean; U - Unknown	H - High; M - Medium			POTESTIAN SOURCE MATERIAN
A = air S = soil/solid	may be high in concentration in Matrix/Conc. Code Box:	may	-	HIGH THE	THE WARRANT BUT HA
	he following codes to let Con-Test know if a specific sample	use	(35%) Please	CATACAWA	KEM 558
ww= wastewater		¢ *	*	\$ 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	KC1 - C20 - C3
GW= groundwater		\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	7 0	72911120	Ke Cox oct "
*Matrix Code:	ξ ο Ε.	,	< 1	Н	
0 1 0 1 1 1		X	× ·	3/24/12 1048	ଜତତ
T = Na thiosulfate		υ* ×	イク	3/26/12 1045	KCL- C3K- 007
X = Na hydroxide		υ* ×	×	3/29/12 1020	06 KCL-CBK-006 3
S = Sulturic Acid		+	×	3/24/12 1018	05 KCL - CBK - CO'S 3
N = Nitric Acid		+	+	_	
M = Methanol		*	×	3/29/12 1015	NU KCL-CBY-OCH 3
H=HCL		C₁ ×	×	419/12 1012	03 KCL-COK-03 4
**Preservation		C ★	\ ≺	3/27/12 1010	02. KCL-CBK-002 3
1		ر _* *	×	3/29/12 0950	B/ KCL-CBK-CDI 3/
T=tedlar bag O=Other		_	Composite Grab Code	beginning Ending Date/Time Date/Time	Con-Test Lab ID Client Sample ID / Description Client Sample I
S=summa can			O "Enhanced Data Package"	llection	
V= yial			_		O yes proposal date
P=plastic		(&	OF CEXCEL COIS	Format:	Project Proposal Provided? (for billing purposes)
G=glass		32/	greener	Email:	Sampled By: Ozoroć Frankum
***Cont. Code:		254		Fax#	Project Location: YALE KCL
		<i>و</i> د)	O FAX O EMAIL OWEBSITE	O FAX O EMAIL	Attention: GEORGE FRANKLIN
O Field Filtered				Client PO#	AMOSVER MA CIBIO
Dissolved Metals	ANALYSIS REQUESTED		225540	Project #	Address: 35 NE Bus. CTR SUITE 180
***Container Code		\range \r	978 651 8150	Telephone:	Company Name: الما ١٥٥٥٨٦٥ أو المادية
		⊢ j		com	₹
# of Containers		- -	いしのしょ	stlabs.com	CCITCUL Email: info@contestlabs.com
Page of 7	East longmeadow, MA 01028	DY RECORD	CHAIN OF CUSTOUT		
۔ د			: >1 >15)	

COMPLETELY OR IS INCORRECT, TURNAROUND TIME WILL NOT START UNTIL ALL QUESTIONS ARE ANSWERED.

7.45 Require lab approval ☐ [†]72-Hr ☐ [†]4-Day □ [†]24-Hr □ [†]48-Hr

Other:

TURNAROUND TIME (business days) STARTS AT 9:00 A.M. THE DAY AFTER SAMPLE RECEIPT UNLESS THERE ARE QUESTIONS ON YOUR CHAIN. IF THIS FORM IS NOT FILLED OUT PLEASE BE CAREFUL NOT TO CONTAMINATE THIS DOCUMENT

NELAC & AIHA Certified WBE/DBE Certified

Phone: 413-525-2332 _®

CHAIN OF CUSTODY RECORD

39 Spruce Street

East longmeadow, MA 01028	The section of the
meadow,	
MA 01	
028	

4,38 Date/Time: 7,45 1-0 14-Day 1-0 15-Day 1-0 15-Day 1-0 15-Day 15-Day	Date/Time:/ 7 YS RUSH † Connecticut:	Received by Signature Date/Time: 6 15 D 10-Day ORCP Analytical Certification Form Required ORCP Analysis Certification Form Required	3/3/1 1932 O 7-Day Massachusetts:	signature)	Matorial	strutes vokum but may be high, This is potent	Please 1 VIA USEPA 8082 W/ SIXHLET Extraction (3540C) Please	KCL-CRB-020 427/12 1325 4	16 KCL-C63-019 3/27/12 1315 XSVX	18 KCL-CBK-018 3/29/12 1305 X C U X		() () () () () () () () () ()	8	21/12 1158 X C U	138 X O X	, 0	***************************************	Date/Time Date/Time Colliposite Glab Lotte	Ending	"Enhanced Data Package"	oject Proposal Provided? (for billing purposes) Format:	Sampled By: Crackled Email: Sharel			ERY (check all that apply)	Client PO#	<u>.</u>	Telephone: 978 557 8150 A	ANALYTICAL LABORATORY www.contestlabs.com	COLCUL Fax. 1 10 COLO COCO TO	1
NELAC & AIHA Certified WBE/DBE Certified	m Required PWSID#	etification Form Required			Unknown SL = Sludge O = other Caulk			DW= drinking water	GW= groundwater	*Matrix Code:	o = Other	X = Na hydroxide	S = Sulturic Acid B = Sodium bisulfate	N = Nitric Acid	H HC	**Preservation		O =Other	∓tedlar bäg	S=summa can	ST=sterile	G=glass P=plastic	A=amber glass	4	O Lab to Filter	O Field Filtered	Dissolved Metals	***Container Code	** Preservation 47	# of Containers	

COMPLETELY OR IS INCORRECT, TURNAROUND TIME WILL NOT START UNTIL ALL QUESTIONS ARE ANSWERED. TURNAROUND TIME (business days) STARTS AT 9:00 A.M. THE DAY AFTER SAMPLE RECEIPT UNLESS THERE ARE QUESTIONS ON YOUR CHAIN. IF THIS FORM IS NOT FILLED OUT

[†] Require lab approval

PLEASE BE CAREFUL NOT TO CONTAMINATE THIS DOCUMENT

	a ACCO		154 Hr 1 148 Hr	1 1.30MY "
#	O MA State DW Form Required PWSID#	Connecticut:	꼰	Relinquished by (signatyse) Date/Time: 1745
red	RCP Analysis Certification Form Required		Other S OAT	1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
uired	MCP Analytical Certification Form Required		☐ 10-Day	Received by: (signature) Date/Time: 12 35
	is your project with or net "	Massachusetts:	, 🗖 7-Day	l
O = other Chour		Detection Limit Requirements	Turnaround #	Relingdished by Isignature Date/Time:
SL = sludge	High; M - Medium; L - Low; C - Clean; U - Unknown	H - High; M - Me		
S = soil/solid		Assir	By Saver MA	+ Comment HIGH Concession THY
A ≈ air	use the following codes to let Con-Test know if a specific sample may be high in concentration in Matrix/Conc. Code Box:	Please use the following may be high in a	EXTRACTOR	Comments: PCB, wa USEPA BUBE - SURHET
WW = wastewater		У () () X	3/27/15 1520	23 KIL. CBB - 030
*Matrix Code: GW= groundwater		× 5 C X	Stes/12 1510	KCL-(BK-029
		1 0 C N	2112	VCC-C2/C-028
0 = Other				k
T = Na thìosulfate		× 00 C	3),,1,2 1455	21 12-08-027 3
X = Na hydroxide		X O X	10/12 1-150	*CE-C88-0CE
S = Suffuric Acid		× × ×	24/12	140 20.088.00
N = Nitric Acid		\$ (*	+	77 ((()
M = Methanol			3) ₂₉₁₁₇ 14750	h20 -627-174 DI
Y = ICEO		* S C * -	1425	
**Preservation		C	3/24/12 1410	-CBB-022
-			+	
Culet		K N V	17 17 17 18 18 18 18 18 18 18 18 18 18 18 18 18	KCI COB TO
T=tediar bag		Composite Grab Lade Lone Lade	Beginning Ending Date/Time Date/Time	Con-Test Lab ID Client Sample ID / Description
S=summa can		O "Enhanced Data Package"	ğ	
ST=sterife		HER_		O yesproposal date
P =plastic		PDF OEXCEL OGIS	Format:	÷
A=amber glass G=glass		STATE OF THE STATE	الے Email:	Sampled By: (DECREE Transcore
***Cont. Code:				Project Location: YALE KCL
O Lab to Fixer		O FAX DEMAIL OWEBSITE	OFAX OF	Attention: (Feozoe Transcon
O Field Filtered		275.849	Client PO#	Anorac M
Dissolved Metal	ANALYSIS REQUESTED	225540	Project #	Address: 35 NE Bus CTL Sitte 180
***Container Cod P		778 557 8150 A	Telephone:	Company Name: Woodan ? Curkan
				ORY
# of Containers &		15 NOOO	itestlabs.com 17	, –
of 51		_	200	Fax: 413-525-6405
	JDD 39 Shriice Street	CHAIN OF CHATODY BECORD		7

COMPLETELY OR IS INCORRECT, TURNAROUND TIME WILL NOT START UNTIL ALL QUESTIONS ARE ANSWERED. TURNAROUND TIME (business days) STARTS AT 9:00 A.M. THE DAY AFTER SAMPLE RECEIPT UNLESS THERE ARE QUESTIONS ON YOUR CHAIN. IF THIS FORM IS NOT FILLED OUT PLEASE BE CAREFUL NOT TO CONTAMINATE THIS DOCUMENT

Received by: (signature

30/12

[745]* Require lab approval ☐ [†]72-Hr ☐ [†]4-Day □ [†]24-Hr □ [†]48-Hr

Other:

NELAC & AIHA Certified WBE/DBE Certified

Company Name: 1200 Aco : Cuccacon-test Fax: 413-525-6405 www.contestlabs.com Email: info@contestlabs.com 12C6993 Phone: 413-525-2332

Sampled By: OF water

MANGEL.

Email:

12 - K

Fax#

Format:

XXPDF OEXCEL

 $\frac{8}{2}$

O OTHER

Con-Test Lab ID

KCL- CB3-031

Client Sample ID / Description

Date/Time Beginning

Composite Grab

Code Matrix

Cons Code

T=tedlar bag

S=summa can V= vial ST=sterile P=plastic G=glass A=amber glass ***Cont. Code:

0=Other

**Preservation

FCB5

Collection

O "Enhanced Data Package"

29/12

KCL- CBK-032

13/29/12

3/29/12

1635 1526 1525 Date/Time Ending

M

0

C*

K1-CBR-033 K(t- (BZ-03)

26

77.

(32-

035

3/27/12

1005

T T

CBB - 036

3/27/12

165

>

U

d

O = Other

DW= drinking water WW= wastewater **GW**= groundwater *Matrix Code: T = Na thiosulfate X = Na hydroxide **B** = Sodium bisulfate S = Sulfuric Acid N = Nitric Acid M = Methanol H=HCL I = lced

0

O yes.

Project Proposal Provided? (for billing purposes)

proposal date

Project Location:

Y4-E

100

Attention: Geoce

استريطمسانات الرمسا

Address: 35 NE Bus.

3

かられ

Project #

225540

Telephone:

05/x LSS 266

⇉ 1-1

Client PO#

DATA DELIVERY (check all that apply) O FAX OF EMAIL OWEBSITE

Answer

CHAIN OF CUSTODY RECORD

39 Spruce Street

East longmeadow,	on about ou ear
ĭ.	
MA 01028	

of Containers ** Preservation

Page 49 of 51

***Container Coc

O Field Filtered O Lab to Filter

Dissolved Meta.

Please use the following codes to let Con-Test know if a specific sample may be high in concentration in Matrix/Conc. Code Box: ANALYSIS REQUESTED Š T

Supl Violiz	b 4.2% Date/Time:		//sigpature/	Worker John	Received by (signature) Date/Time: / 6 3 5 - 0	1 (well - 3 po 1/2 1005 0	roushed by/(signapore) Date/Time:		Comments: PCBy via USEIA SOOL of Southlast CATACIAN (354X)
Other	Hr 🗖 [†] 4-Day	Hr □ [†] 48-Hr	RUSH † Connecticut:	Other 3	10-Day	7-Day Massachusetts:	Irnaround T Detection Limit Requirements		
WBE/DBE Certified	AHA I	TO IN ACCOUNTS	O MA State DW Form Required PWSID#	 RCP Analysis Certification Form Required 	 MCP Analytical Certification Form Required 	is your project when or ner :			Please use the following codes to let Con- Lest know it a specific sample may be high in concentration in Matrix/Conc. Code Box: A = air S = soil/soild
	TRequire lab approval Other:	b 4.2° Date/Time: 0 172-Hr 0 14-Day 1 Other: 2 1 Require lab approval Other: 2 1 Require lab a	1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Date/Time: 67 4 > RUSH † Connecticut: O MA State DW Form Require lab approval Other:	Other 5 Cate/Time: £7 4 > RUSH † Connecticut: Oma State DW Form Require Interest 1/2 Date/Time: 1/2	Date/Time: /d 3 7	Date/Time: /d J 7	Date/Time: / / / > Rush Connecticut: Co	Shed by (signature) Date/Time: Date/Time

KCL-CBKD-040

2/2/12

0850

×

S

Ċ *

KCL - CBR - 058

विव

COMPLETELY OR IS INCORRECT, TURNAROUND TIME WILL NOT START UNTIL ALL QUESTIONS ARE ANSWERED. PLEASE BE CAREFUL NOT TO CONTAMINATE THIS DOCUMENT

***Cont. Code: A=amber glass G=glass P=plastic ST=sterile V= vial S=summa can T=tediar bag 0=Other ***Preservation f= lced H= HCL M= Methanol N= Nitric Acid S= Sulfuric Acid S	CGIS CHARTING CONT. CHARTING. CHARTING CONT. CHARTING. CHARTING.	know if a sp. Conc. Code Conc. Code t MCP t MCP THIS FOR	to let Con-Test kr ration in Matrix/Coration in Mat	Ledde P B Code P Code P Code P Code State Device to let Con-Test know if a specific may be high in concentration in Matrix/Conc. Code Box HHigh; MMedium; LLow; CClean; UUnknown irements Is your project MCP or R O MCP Analysis Certification F O MA State DW Form Require O MA State DW Form Require		RE QUEST	Please us m H Requir	TO FAX VEMAIL OWEBSITE Fax # Email: Section O "Enhanced Data Package" Ending Composite Grab Code Oute Package Composite Grab Code Pate/Time Code Pate/Tim	ELIVERY (check all that Overall Overall Overall Overall Overall) Option Other Oexo Other Oexo Other Other Other Other Other: Aple Receipt Unli	DATA DELIVERY (checky	Cription Beginning Date/Time Collection Ending Date/Time Date/Time Date/Time Date/Time Collection Format: For		Inmpled By: (Jewelle Transconding purposes) O yes Proposal Provided? (for billing purposes) O yes Proposal Provided? (for billing purposes) O yes Proposal date On-Test Lab ID Client Sample ID / Descrip Proposal date NECL - CRBO - C41 KCL - CRBO - C41 KCL - CRBO - C41 KCL - CRBO - C41 Boliz College Colle	Client Sal	Attention: Coulded Project Location: Atta Sampled By:	Attention Project L Sampled Project O ves_ Con-Te Con-Te Claborate Comments: Comments: Comments: Completed by Received by Received by Received by
Dissolved Metals O Field Filtered		AWARIOS NECCESTED				<u> </u>		212540		Project # Client PO#		arco B	61.	ra K	Address: 35 Nic	Address
# of Containers ** Preservation ***Container Code Page 5 of 51	39 Spruce Street East longmeadow, MA 01028	Street meadow,	39 Spruce Street East longmeadov		RECORD		7 \$150	CHAIN OF CUSTOD	NO 2 C O	<u> </u>	-2332 05 ntestlabs.co	113- 1000 1188	ORY	MICAL LA	ANALYTICAL LABORA	Compa

39 Spruce St.
East Longmeadow, MA. 01028
P: 413-525-2332
F: 413-525-6405
www.contestlabs.com





Sample Receipt Checklist

CLIENT NAME: WOOD AND	+ Carran	RECEIVED BY:	C-C-S, DAT	E: 3/30/12
1) Was the chain(s) of custody reli	inquished and sign	ied?	Yes No No	CoC Included
2) Does the chain agree with the s If not, explain:			Yes No	
3) Are all the samples in good con If not, explain:	dition?		Yes No	
4) How were the samples received				
On Ice Direct from Sai	mpling 🔲	Ambient	In Cooler(s)	<u></u>
Were the samples received in Ten	perature Compliar	nce of (2-6°C)?	Yes No N/	Α _
Femperature °C by Temp blank		_Temperature °C	by Temp gun	4.2°
5) Are there Dissolved samples fo			Yes No	
Who was notified	Date	Time		
6) Are there any RUSH or SHORT	HOLDING TIME sa	mples?	Yes No	
Who was notified	Date	Time		· 10-200-
7) Location where samples are stored	. [0) (wa	mission to subcontract lk-in clients only) if no int Signature:	·
B) Do all samples have the proper	Acid pH: Yes N			<u> </u>
9) Do all samples have the proper	•	lo N/A		
				en e
Co	ntainers re	ceived at C	on-Test	
	# of containers			# of containers
1 Liter Amber	2	8 0	zamber/clear jar	31
500 mL Amber		4 0	z amber/clear jar	
250 mL Amber (8oz amber)		2 0	z amber/clear jar	
1 Liter Plastic			Air Cassette	
500 mL Plastic		_	/Hopcalite Tube	
250 mL plastic		_ Pla	istic Bag / Ziploc	
40 mL Vial - type listed below		<u> </u>	PM 2.5 / PM 10	
Colisure / bacteria bottle		- A	PUF Cartridge	_
Dissolved Oxygen bottle			SOC Kit	
Encore			TO-17 Tubes	
Flashpoint bottle		Non-	ConTest Container	
Perchlorate Kit	 	<u>-</u>	Other glass jar	
Other		1	Other	
Laboratory Comments:				
40 mL vials: # HCI	# Met	hanol	Tim	e and Date Frozen:
Doc# 277 # Bisulfate	# DI \	Water		
Rev. 2 Sept 2011 # Thiosulfate	Unpre	eserve <u>d</u>		Page 51



April 16, 2012

George Franklin Woodard & Curran - Andover, MA 35 New England Business Center Andover, MA 01810

Project Location: Yale KCL

Client Job Number: Project Number: 225540

Laboratory Work Order Number: 12C0994

Meghan S. Kelley

Enclosed are results of analyses for samples received by the laboratory on March 30, 2012. If you have any questions concerning this report, please feel free to contact me.

Sincerely,

Meghan E. Kelley Project Manager



Woodard & Curran - Andover, MA 35 New England Business Center Andover, MA 01810

ATTN: George Franklin

PURCHASE ORDER NUMBER:

PROJECT NUMBER: 225540

ANALYTICAL SUMMARY

WORK ORDER NUMBER: 12C0994

REPORT DATE: 4/16/2012

The results of analyses performed on the following samples submitted to the CON-TEST Analytical Laboratory are found in this report.

PROJECT LOCATION: Yale KCL

FIELD SAMPLE #	LAB ID:	MATRIX	SAMPLE DESCRIPTION	TEST	SUB LAB	
VICE CREATE	40.50004.00	D 1 (0 1)1		SW-846 8082A		
KCL-CBB-021 KCL-CBB-026	12C0994-03 12C0994-04	Product/Solid Product/Solid		SW-846 8082A SW-846 8082A		
KCL-CBB-026 KCL-CBR-023	12C0994-04 12C0994-05	Product/Solid		SW-846 8082A		
KCL-CBR-028	12C0994-06	Product/Solid		SW-846 8082A		
KCL-CBR-034	12C0994-07	Product/Solid		SW-846 8082A		
KCL-CBB-011	12C0994-10	Product/Solid		SW-846 8082A		



CASE NARRATIVE SUMMARY

All reported results are within defined laboratory quality control objectives unless listed below or otherwise qualified in this report.

SW-846 8082A

Qualifications:

Matrix spike and/or spike duplicate recovery bias high due to contribution of other Aroclors present in the source sample.

Analyte & Samples(s) Qualified:

Aroclor-1260, Aroclor-1260 [2C]

B049481-MS1

Matrix spike duplicate RPD is outside of control limits. Reduced precision is anticipated for reported result for this compound in this sample.

Analyte & Samples(s) Qualified:

Aroclor-1260

B049481-MS1, B049481-MSD1

 $The \ results \ of \ analyses \ reported \ only \ relate \ to \ samples \ submitted \ to \ the \ Con-Test \ Analytical \ Laboratory \ for \ testing.$

I certify that the analyses listed above, unless specifically listed as subcontracted, if any, were performed under my direction according to the approved methodologies listed in this document, and that based upon my inquiry of those individuuals immediately responsible for obtaining the information, the material contained in this report is, to the best of my knowledge and belief, accurate and complete.

Daren J. Damboragian Laboratory Manager



Project Location: Yale KCL Sample Description: Work Order: 12C0994

Date Received: 3/30/2012

Field Sample #: KCL-CBB-021

Sampled: 3/29/2012 14:05

Sample ID: 12C0994-03
Sample Matrix: Product/Solid

Polychlorinated	Biphenvls	with 3540	Soxhlet Extraction

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:10	MJC
Aroclor-1221 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:10	MJC
Aroclor-1232 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:10	MJC
Aroclor-1242 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:10	MJC
Aroclor-1248 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:10	MJC
Aroclor-1254 [2]	0.11	0.095	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:10	MJC
Aroclor-1260 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:10	MJC
Aroclor-1262 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:10	MJC
Aroclor-1268 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:10	MJC
Surrogates		% Recovery	Recovery Limits	s	Flag				-
Decachlorobiphenyl [1]		121	30-150					4/11/12 23:10	
Decachlorobiphenyl [2]		110	30-150					4/11/12 23:10	
Tetrachloro-m-xylene [1]		114	30-150					4/11/12 23:10	
Tetrachloro-m-xylene [2]		126	30-150					4/11/12 23:10	



Project Location: Yale KCL Sample Description: Work Order: 12C0994

Date Received: 3/30/2012

Field Sample #: KCL-CBB-026

Sampled: 3/29/2012 14:50

Sample ID: 12C0994-04
Sample Matrix: Product/Solid

Polychlorinated Biphenyls with 3540 Soxhlet Extrac	ction	Extra	et E	xhle	Sox	540	13	with	henvls	Bir	ated	lorin	vch	Po
--	-------	-------	------	------	-----	-----	----	------	--------	-----	------	-------	-----	----

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:23	MJC
Aroclor-1221 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:23	MJC
Aroclor-1232 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:23	MJC
Aroclor-1242 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:23	MJC
Aroclor-1248 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:23	MJC
Aroclor-1254 [2]	0.22	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:23	MJC
Aroclor-1260 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:23	MJC
Aroclor-1262 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:23	MJC
Aroclor-1268 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:23	MJC
Surrogates		% Recovery	Recovery Limits	S	Flag				
Decachlorobiphenyl [1]		119	30-150					4/11/12 23:23	
Decachlorobiphenyl [2]		108	30-150					4/11/12 23:23	
Tetrachloro-m-xylene [1]		104	30-150					4/11/12 23:23	
Tetrachloro-m-xylene [2]		114	30-150					4/11/12 23:23	



Project Location: Yale KCL Sample Description: Work Order: 12C0994

Date Received: 3/30/2012

Field Sample #: KCL-CBR-023

Sampled: 3/29/2012 15:05

Sample ID: 12C0994-05
Sample Matrix: Product/Solid

Polychlorinated	Binhenvls	with 3540	Soxhlet Extraction
1 ory contormated	Diphenyis	WILL 22-10	SOAIIICE LAGRETION

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:38	PJG
Aroclor-1221 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:38	PJG
Aroclor-1232 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:38	PJG
Aroclor-1242 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:38	PJG
Aroclor-1248 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:38	PJG
Aroclor-1254 [1]	0.63	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:38	PJG
Aroclor-1260 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:38	PJG
Aroclor-1262 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:38	PJG
Aroclor-1268 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:38	PJG
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		119	30-150					4/12/12 9:38	
Decachlorobiphenyl [2]		108	30-150					4/12/12 9:38	
Tetrachloro-m-xylene [1]		97.7	30-150					4/12/12 9:38	
Tetrachloro-m-xylene [2]		105	30-150					4/12/12 9:38	



Project Location: Yale KCL Sample Description: Work Order: 12C0994

Date Received: 3/30/2012

Field Sample #: KCL-CBR-028

Sampled: 3/29/2012 15:05

Sample ID: 12C0994-06
Sample Matrix: Product/Solid

Dalvahlarinatad	Dinhanula	ith 2540	Carblet Extraction	
Polychlorinated	Binhenvis	with 3540	Soxhlet Extraction	

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:36	MJC
Aroclor-1221 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:36	MJC
Aroclor-1232 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:36	MJC
Aroclor-1242 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:36	MJC
Aroclor-1248 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:36	MJC
Aroclor-1254 [2]	0.23	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:36	MJC
Aroclor-1260 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:36	MJC
Aroclor-1262 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:36	MJC
Aroclor-1268 [1]	ND	0.10	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:36	MJC
Surrogates		% Recovery	Recovery Limits	S	Flag				
Decachlorobiphenyl [1]		117	30-150					4/11/12 23:36	
Decachlorobiphenyl [2]		106	30-150					4/11/12 23:36	
Tetrachloro-m-xylene [1]		97.9	30-150					4/11/12 23:36	
Tetrachloro-m-xylene [2]		107	30-150					4/11/12 23:36	



Project Location: Yale KCL Sample Description: Work Order: 12C0994

Date Received: 3/30/2012

Field Sample #: KCL-CBR-034

Sampled: 3/29/2012 15:55

Sample ID: 12C0994-07
Sample Matrix: Product/Solid

Dolyahlarinatad	Dinhanda wi	th 2510 Carbi	ot Extuaction

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:51	PJG
Aroclor-1221 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:51	PJG
Aroclor-1232 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:51	PJG
Aroclor-1242 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:51	PJG
Aroclor-1248 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:51	PJG
Aroclor-1254 [2]	0.29	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:51	PJG
Aroclor-1260 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:51	PJG
Aroclor-1262 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:51	PJG
Aroclor-1268 [1]	ND	0.10	mg/Kg	5		SW-846 8082A	4/10/12	4/12/12 9:51	PJG
Surrogates		% Recovery	Recovery Limits	s	Flag				
Decachlorobiphenyl [1]		130	30-150					4/12/12 9:51	
Decachlorobiphenyl [2]		118	30-150					4/12/12 9:51	
Tetrachloro-m-xylene [1]		107	30-150					4/12/12 9:51	
Tetrachloro-m-xylene [2]		114	30-150					4/12/12 9:51	



Project Location: Yale KCL Sample Description: Work Order: 12C0994

Date Received: 3/30/2012

Field Sample #: KCL-CBB-011

Sampled: 3/29/2012 11:15

Sample ID: 12C0994-10
Sample Matrix: Product/Solid

Polychlorinated Biphenyls with 3540 Soxhlet Extrac	ction	Extra	et E	xhle	Sox	540	13	with	henvls	Bir	ated	lorin	vch	Po
--	-------	-------	------	------	-----	-----	----	------	--------	-----	------	-------	-----	----

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:49	MJC
Aroclor-1221 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:49	MJC
Aroclor-1232 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:49	MJC
Aroclor-1242 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:49	MJC
Aroclor-1248 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:49	MJC
Aroclor-1254 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:49	MJC
Aroclor-1260 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:49	MJC
Aroclor-1262 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:49	MJC
Aroclor-1268 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	4/10/12	4/11/12 23:49	MJC
Surrogates		% Recovery	Recovery Limits	s	Flag				
Decachlorobiphenyl [1]		113	30-150					4/11/12 23:49	
Decachlorobiphenyl [2]		103	30-150					4/11/12 23:49	
Tetrachloro-m-xylene [1]		97.3	30-150					4/11/12 23:49	
Tetrachloro-m-xylene [2]		107	30-150					4/11/12 23:49	



Sample Extraction Data

Prep Method: SW-846 3540C-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [g]	Final [mL]	Date
	D0 10 10 1	2.10	10.0	24/42/42
12C0994-03 [KCL-CBB-021]	B049481	2.10	10.0	04/10/12
12C0994-04 [KCL-CBB-026]	B049481	2.00	10.0	04/10/12
12C0994-05 [KCL-CBR-023]	B049481	10.0	10.0	04/10/12
12C0994-06 [KCL-CBR-028]	B049481	2.00	10.0	04/10/12
12C0994-07 [KCL-CBR-034]	B049481	10.0	10.0	04/10/12
12C0994-10 [KCL-CBB-011]	B049481	2.20	10.0	04/10/12



QUALITY CONTROL

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B049481 - SW-846 3540C										
Blank (B049481-BLK1)				Prepared: 04	/10/12 Anal	yzed: 04/11/	12			
Aroclor-1016	ND	0.10	mg/Kg							
Aroclor-1016 [2C]	ND	0.10	mg/Kg							
Aroclor-1221	ND	0.10	mg/Kg							
Aroclor-1221 [2C]	ND	0.10	mg/Kg							
Aroclor-1232	ND	0.10	mg/Kg							
Aroclor-1232 [2C]	ND	0.10	mg/Kg							
Aroclor-1242	ND	0.10	mg/Kg							
Aroclor-1242 [2C]	ND	0.10	mg/Kg							
Aroclor-1248	ND	0.10	mg/Kg							
Aroclor-1248 [2C]	ND	0.10	mg/Kg							
Aroclor-1254	ND	0.10	mg/Kg							
Aroclor-1254 [2C]	ND	0.10	mg/Kg							
Aroclor-1260	ND	0.10	mg/Kg							
Aroclor-1260 [2C]	ND	0.10	mg/Kg							
Aroclor-1262	ND	0.10	mg/Kg							
aroclor-1262 [2C]	ND	0.10	mg/Kg							
Aroclor-1268	ND	0.10	mg/Kg							
aroclor-1268 [2C]	ND	0.10	mg/Kg							
urrogate: Decachlorobiphenyl	1.07		mg/Kg	1.00		107	30-150			
urrogate: Decachlorobiphenyl [2C]	0.970		mg/Kg	1.00		97.0	30-150			
Surrogate: Tetrachloro-m-xylene	0.936		mg/Kg	1.00		93.6	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	1.03		mg/Kg	1.00		103	30-150			
LCS (B049481-BS1)				Prepared: 04	/10/12 Anal	yzed: 04/11/	12			
Aroclor-1016	0.29	0.10	mg/Kg	0.250		117	40-140			
Aroclor-1016 [2C]	0.30	0.10	mg/Kg	0.250		120	40-140			
Aroclor-1260	0.27	0.10	mg/Kg	0.250		110	40-140			
Aroclor-1260 [2C]	0.30	0.10	mg/Kg	0.250		120	40-140			
urrogate: Decachlorobiphenyl	1.31		mg/Kg	1.00		131	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.17		mg/Kg	1.00		117	30-150			
Surrogate: Tetrachloro-m-xylene	1.10		mg/Kg	1.00		110	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	1.20		mg/Kg	1.00		120	30-150			
.CS Dup (B049481-BSD1)				Prepared: 04	/10/12 Anal	yzed: 04/11/	12			
Aroclor-1016	0.27	0.10	mg/Kg	0.250		106	40-140	9.91	30	
Aroclor-1016 [2C]	0.27	0.10	mg/Kg	0.250		110	40-140	8.94	30	
Aroclor-1260	0.24	0.10	mg/Kg	0.250		96.8	40-140	12.3	30	
Aroclor-1260 [2C]	0.27	0.10	mg/Kg	0.250		107	40-140	11.2	30	
Surrogate: Decachlorobiphenyl	1.11		mg/Kg	1.00		111	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.01		mg/Kg	1.00		101	30-150			
Surrogate: Tetrachloro-m-xylene	0.974		mg/Kg	1.00		97.4	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	1.07		mg/Kg	1.00		107	30-150			



QUALITY CONTROL

		Reporting		Spike	Source			%REC			RPD	
Analyte	Result	Limit	Units	Level	Result	%RE0	2	Limits	RPD		Limit	Notes
Batch B049481 - SW-846 3540C												
Matrix Spike (B049481-MS1)	Sour	ce: 12C0994-	-01	Prepared: 04	1/10/12 Analy	zed: 04/	12/12					
Aroclor-1016	0.28	0.10	mg/Kg	0.250	0.0	110		40-140				
Aroclor-1016 [2C]	0.32	0.10	mg/Kg	0.250	0.0	127		40-140				
Aroclor-1260	0.59	0.10	mg/Kg	0.250	0.0	237	*	40-140				MS-21, R-06
Aroclor-1260 [2C]	0.47	0.10	mg/Kg	0.250	0.0	187	*	40-140				MS-21
Surrogate: Decachlorobiphenyl	1.13		mg/Kg	1.00		113		30-150				
Surrogate: Decachlorobiphenyl [2C]	1.07		mg/Kg	1.00		107		30-150				
Surrogate: Tetrachloro-m-xylene	1.02		mg/Kg	1.00		102		30-150				
Surrogate: Tetrachloro-m-xylene [2C]	1.12		mg/Kg	1.00		112		30-150				
Matrix Spike Dup (B049481-MSD1)	Sour	ce: 12C0994-	-01	Prepared: 04	1/10/12 Analy:	zed: 04/	12/12					
Aroclor-1016	0.27	0.10	mg/Kg	0.250	0.0	107		40-140	2.65		50	
Aroclor-1016 [2C]	0.29	0.10	mg/Kg	0.250	0.0	118		40-140	7.53		50	
Aroclor-1260	0.33	0.10	mg/Kg	0.250	0.0	134		40-140	55.6	*	50	R-06
Aroclor-1260 [2C]	0.34	0.10	mg/Kg	0.250	0.0	137		40-140	30.7		50	
Surrogate: Decachlorobiphenyl	1.09		mg/Kg	1.00		109		30-150				
Surrogate: Decachlorobiphenyl [2C]	1.02		mg/Kg	1.00		102		30-150				
Surrogate: Tetrachloro-m-xylene	0.981		mg/Kg	1.00		98.1		30-150				
Surrogate: Tetrachloro-m-xylene [2C]	1.07		mg/Kg	1.00		107		30-150				



FLAG/QUALIFIER SUMMARY

T	QC result is outside of established limits.
†	Wide recovery limits established for difficult compound.
‡	Wide RPD limits established for difficult compound.
#	Data exceeded client recommended or regulatory level
	Percent recoveries and relative percent differences (RPDs) are determined by the software using values in the calculation which have not been rounded.
MS-21	Matrix spike and/or spike duplicate recovery bias high due to contribution of other Aroclors present in the source sample.
R-06	Matrix spike duplicate RPD is outside of control limits. Reduced precision is anticipated for reported result for this compound in this sample.



CERTIFICATIONS

Certified Analyses included in this Report

Analyte	Certifications	
SW-846 8082A in Product/Solid		
Aroclor-1016	CT,NH,NY,ME,NC	
Aroclor-1016 [2C]	CT,NH,NY,ME,NC	
Aroclor-1221	CT,NH,NY,ME,NC	
Aroclor-1221 [2C]	CT,NH,NY,ME,NC	
Aroclor-1232	CT,NH,NY,ME,NC	
Aroclor-1232 [2C]	CT,NH,NY,ME,NC	
Aroclor-1242	CT,NH,NY,ME,NC	
Aroclor-1242 [2C]	CT,NH,NY,ME,NC	
Aroclor-1248	CT,NH,NY,ME,NC	
Aroclor-1248 [2C]	CT,NH,NY,ME,NC	
Aroclor-1254	CT,NH,NY,ME,NC	
Aroclor-1254 [2C]	CT,NH,NY,ME,NC	
Aroclor-1260	CT,NH,NY,ME,NC	
Aroclor-1260 [2C]	CT,NH,NY,ME,NC	

The CON-TEST Environmental Laboratory operates under the following certifications and accreditations:

Code	Description	Number	Expires
AIHA	AIHA-LAP, LLC	100033	02/1/2014
MA	Massachusetts DEP	M-MA100	06/30/2012
CT	Connecticut Department of Publilc Health	PH-0567	09/30/2013
NY	New York State Department of Health	10899 NELAP	04/1/2013
NH	New Hampshire Environmental Lab	2516 NELAP	02/5/2013
RI	Rhode Island Department of Health	LAO00112	12/30/2012
NC	North Carolina Div. of Water Quality	652	12/31/2012
NJ	New Jersey DEP	MA007 NELAP	06/30/2012
FL	Florida Department of Health	E871027 NELAP	06/30/2012
VT	Vermont Department of Health Lead Laboratory	LL015036	07/30/2012
WA	State of Washington Department of Ecology	C2065	02/23/2013
ME	State of Maine	2011028	06/9/2013
VA	Commonwealth of Virginia	1381	12/14/2012

The sale Sampled By Created Project Location: Received by (signatying) Received by: (signature) Relingueshed by (Signatury) Attention: Address 35 N.E. Company Name: Libertages 5 Current Relindulyhed by Asignatury TURNAROUND TIME (business 62/ys) STARTS AT 9:00 A.M. THE DAY AFTER SAMPLE RECEIPT UNLESS THERE ARE QUESTIONS ON YOUR CHAIN. IF THIS FORM IS NOT FILLED OUT Joniments: PC 35 ANTHOUSE CO Con-Test Lab ID Project Proposal Provided? (for billing purposes) O Yes ANALYTICAL CAROUNTORY TO THE AMERICA AS BEEN CHAN TOWNER CHARLES YAL. KCL COX OCA KCL-038-024 1-CL-CS12-010 Client Sample ID / Description | KCL- C32 - 023 TC - 00% - 01 X01-087-084 KO1-038-020 たしてのなしのだめ Sand Brown of the Street proposal date 13.4-13C-13 Date/Time: Dafe/Time: 1745 Date/Time: イグップ等 The fort Fax: 413-525-6405 Email: Info@contestlabs.com www.contestlabs.com Phone: 413-525-2332 KIN INC Require lab approval 200 (1) (1) (2) (2) (2) (3) 28 32 K では、これ 100 1 - Co ☐ *72-14 ☐ *4-Day □ 124-Hr □ 148-Hr Date/Time **Beginning** Other * urnaround Ti Collection 思いて o O 7-Day Email: January DATA DELIVERY (check all that apply) Project # in U Telephone: TOUS S Format OFAX GEMAIL OWEBSITE Client PO# I. Fa×# Date/Time 5 9 Buipa CHAIN OF CUSTODY RECORD アクロウマエ SOPP CEXCEL Other Composite Grab O "Enhanced Data Package" (Johan) O OTHER Connecticut Massachusatts: Detection Limit Requirements C18 C17 812 12 N × 12 76 £cei X LIBY Please use the following codes to let Con Test know if a specific sample H - High; M - Medium; L - Low; C - Clean; U - Unknown may be high in concentration in Matrix/Conc. Code Box: Is your project MCP or NCP? ANALYSIS REQUESTED O RCP Analysis Certification Form Required MCP Analytical Certification Form Required MA State DW Form Required PWSID# 39 Spruce Street East longmeadow, MA 01028 180° NELAC & AIHA Certified WBE/DBE Certified # of Containers " Preservation ****Container Code T = Na thiosulfate X = No hydroxide B = Sodium bisuffate S = Sulfucio Acia N = Nitric Acid W - Methanol H F HQ **Preservation O#Other \$T≂sterile O = Other 1 1 Cat Terrediar bag \$#Summa can V. Via P-plastic OH81355 Asamher giass ***Cont. Code: St = sludge \$ = soil/solld DW= drinking water **WW**= wastewater GW- groundwater C Field Filtered Clab to Filter *Matrix Code Dissolved Metals Page 17 of 21

COMPLETELY OR IS INCORRECT, TURNAROUND TIME WILL NOT START UNTIL ALL QUESTIONS ARE ANSWERED.

Please be careful hot to contaminate this document

39 Spruce St.
East Longmeadow, MA. 01028
P: 413-525-2332
F: 413-525-6405
www.contestlabs.com





Sample Receipt Checklist

CLIENT NAME. W/ 03/01/07/07	- GARRAN ME	CEIVED BA: 7-0	DATE	: 3/55/2
1) Was the chain(s) of custody re	linquished and signed?	· Yes.	⇒No NoC	oC Included
2) Does the chain agree with the state of th	samples?	Tes) No	
3) Are all the samples in good coulf not, explain:		Ves	⊃ No	
4) How were the samples receive				april 1818
On Ice Direct from Sa	ımpling 📙 Arr	ibient 🔲 In Cod	oler(s)	
Were the samples received in Ter	nperature Compliance	of (2-6°C)? (Yes		
Temperature °C by Temp blank	Te	mperature °C by Temp	gun	1.2 2
5) Are there Dissolved samples fo		Yes	(গ্ৰহ	
Who was notified				
6) Are there any RUSH or SHORT	HOLDING TIME sample	es? Yes,		
Who was notified	Date	_ Time		
	10.	Permission to	subcontract s	amples? Yes No
7) Location where samples are stored	# <i>[9</i>	(Walk-in clien Client Signatu		lready approved
8) Do all samples have the proper	Acid pH: Yes No	N/A		NAME OF THE PROPERTY OF THE PR
9) Do all samples have the proper	•	N/A	***************************************	
C	ontainers recei	ved at Con-To	est	
	# of containers			<i>tt</i> - f
1 Liter Amber	# Of Containers	8 oz ámbei/c	logrior	# of containers
500 mL Amber		4 oz amber/o		e no.
250 mL Amber (8oz amber)		2 oz amber/c	······································	
1 Lifer Plastic		Air Casse	· · · · · · · · · · · · · · · · · · ·	
500 mL Plastic		Hg/Hopcalite		
250 mL plastic		Plastic Bag /		
40 mt. Vial - type listed below		PM 2.5 / P		
Colisure / bacteria bottle		PUF Cartr		
Dissolved Oxygen bottle		SOC K	315	
Encore		TO-17 T u	***************************************	
Flashpoint bottle		Non-ConTest C		
Perchlorate Kit		Other glas	s jar	
Other		Other		
Laboratory Comments:				
40 mL vials: # HCI	# Methano	ol	Типе а	nd Date Frozen:
Doc# 277 # Bisulfate	# DI Wate			T
Rev. 2 Sept 2011 # Thiosulfate	Unpreserv	red]	

Meghan Kelley

From:

George Franklin [GFranklin@woodardcurran.com]

Sent:

Monday, April 09, 2012 6:47 AM

To:

mkelley@contestlabs.com

Subject:

Yale KCL Samples

Meghan,

Please have the following samples removed from HOLD and analyzed for the Yale KCL project:



I am in the field all day today so call my cell if there are any questions. Standard 5 day turn around on these.


Thank you,

George

George Franklin, CHMM **Project Scientist** Woodard and Curran Office: (978) 557-8150

Cell: (978) 317-8200

gfranklin@woodardcurran.com



1.07

0.936

Decachlorobiphenyl Tetrachloro-m-xylene 0.969545

1.02624

9.85

9.2

B049481-BS1	LCS		
Analyte	Re	sults	%RPD
Aroclor-1016	0.29	0.300265	3.48
Aroclor-1260	0.27	0.299345	10.3
Surrogates			
Decachloro biphenyl	1.31	1.168935	11.4
Letrachloro-m-xylene	1.10	1.203475	8.98
B049481-BSD1	LCS Dup		
Analyte	Re	sults	%RPD
Aroclor-1016	0.27	0.27458	1.68
Aroclor-1260	0.24	0.26771	10.9
Surrogates			
Tetrachloro-m-xylene	0.974	1.06851	9.25
Decachloro biphenyl	1.11	1.013925	9.05
B049481-MS1	Matrix Spike		
Analyte	Re	sults	%RPD
Aroclor-1016	0.28	0.31801	12.7
Aroclor-1260	0.59	0.468235	23
Surrogates			
Decachlorobiphenyl	1.13	1.066795	5.75
Letrachloro-m-xylene	1.02	1.11854	9.22
B049481-MSD1	Matrix Spike	Dup	
Analyte	Re	sults	%RPD
Aroclor-1016	0.27	0.294935	8.83
Aroclor-1260	0.33	0.34346	4
Surrogates			
Tetrachioro-m-xylene	0.981	1.073935	9.05
Decachlorobiphenyl	1.09	1.023285	6.31



June 15, 2012

Steven Murdzia Yale University 135 College Street, Suite 100 New Haven, CT 06510

Project Location: KCL Client Job Number: Project Number: [none]

Laboratory Work Order Number: 12F0342

Lua Watthington

Enclosed are results of analyses for samples received by the laboratory on June 11, 2012. If you have any questions concerning this report, please feel free to contact me.

Sincerely,

Lisa A. Worthington Project Manager



Yale University REPORT DATE: 6/15/2012

135 College Street, Suite 100 New Haven, CT 06510 ATTN: Steven Murdzia

PURCHASE ORDER NUMBER:

PROJECT NUMBER: [none]

ANALYTICAL SUMMARY

WORK ORDER NUMBER: 12F0342

The results of analyses performed on the following samples submitted to the CON-TEST Analytical Laboratory are found in this report.

PROJECT LOCATION: KCL

FIELD SAMPLE #	LAB ID:	MATRIX	SAMPLE DESCRIPTION	TEST	SUB LAB
254-6-12	12F0342-01	Caulk	Red Duct Caulk	SW-846 8082A	
256-6-12	12F0342-02	Caulk	Red Duct Caulk	SW-846 8082A	
137-6-12	12F0342-03	Caulk	Red Duct Caulk	SW-846 8082A	



CASE NARRATIVE SUMMARY

All reported results are within defined laboratory quality control objectives unless listed below or otherwise qualified in this report.

SW-846 8082A

Qualifications:

The surrogate recovery for this sample is not available due to sample dilution below the surrogate reporting limit required from high analyte concentration and/or matrix interferences.

Analyte & Samples(s) Qualified:

Decachlorobiphenyl, Decachlorobiphenyl [2C], Tetrachloro-m-xylene, Tetrachloro-m-xylene [2C] 12F0342-01[254-6-12], 12F0342-02[256-6-12], 12F0342-03[137-6-12]

The results of analyses reported only relate to samples submitted to the Con-Test Analytical Laboratory for testing.

I certify that the analyses listed above, unless specifically listed as subcontracted, if any, were performed under my direction according to the approved methodologies listed

in this document, and that based upon my inquiry of those individuals immediately responsible for obtaining the information, the material contained in this report is, to the best of my knowledge and belief, accurate and complete.

Daren J. Damboragian Laboratory Manager



Project Location: KCL Sample Description: Red Duct Caulk Work Order: 12F0342

Date Received: 6/11/2012

Field Sample #: 254-6-12

Sampled: 6/11/2012 00:00

Sample ID: 12F0342-01
Sample Matrix: Caulk

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	6/11/12	6/13/12 21:42	JMB
Aroclor-1221 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	6/11/12	6/13/12 21:42	JMB
Aroclor-1232 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	6/11/12	6/13/12 21:42	JMB
Aroclor-1242 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	6/11/12	6/13/12 21:42	JMB
Aroclor-1248 [2]	37	9.1	mg/Kg	50		SW-846 8082A	6/11/12	6/13/12 21:42	JMB
Aroclor-1254 [2]	100	9.1	mg/Kg	50		SW-846 8082A	6/11/12	6/13/12 21:42	JMB
Aroclor-1260 [2]	66	9.1	mg/Kg	50		SW-846 8082A	6/11/12	6/13/12 21:42	JMB
Aroclor-1262 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	6/11/12	6/13/12 21:42	JMB
Aroclor-1268 [1]	ND	9.1	mg/Kg	50		SW-846 8082A	6/11/12	6/13/12 21:42	JMB
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			6/13/12 21:42	
Decachlorobiphenyl [2]		*	30-150		S-01			6/13/12 21:42	
Tetrachloro-m-xylene [1]		*	30-150		S-01			6/13/12 21:42	
Tetrachloro-m-xylene [2]		*	30-150		S-01			6/13/12 21:42	



Project Location: KCL Sample Description: Red Duct Caulk Work Order: 12F0342

Date Received: 6/11/2012

Field Sample #: 256-6-12

Sampled: 6/11/2012 00:00

Sample ID: 12F0342-02 Sample Matrix: Caulk

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	35	mg/Kg	200		SW-846 8082A	6/11/12	6/13/12 21:55	JMB
Aroclor-1221 [1]	ND	35	mg/Kg	200		SW-846 8082A	6/11/12	6/13/12 21:55	JMB
Aroclor-1232 [1]	ND	35	mg/Kg	200		SW-846 8082A	6/11/12	6/13/12 21:55	JMB
Aroclor-1242 [1]	ND	35	mg/Kg	200		SW-846 8082A	6/11/12	6/13/12 21:55	JMB
Aroclor-1248 [1]	ND	35	mg/Kg	200		SW-846 8082A	6/11/12	6/13/12 21:55	JMB
Aroclor-1254 [1]	ND	35	mg/Kg	200		SW-846 8082A	6/11/12	6/13/12 21:55	JMB
Aroclor-1260 [2]	560	35	mg/Kg	200		SW-846 8082A	6/11/12	6/13/12 21:55	JMB
Aroclor-1262 [1]	ND	35	mg/Kg	200		SW-846 8082A	6/11/12	6/13/12 21:55	JMB
Aroclor-1268 [1]	ND	35	mg/Kg	200		SW-846 8082A	6/11/12	6/13/12 21:55	JMB
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			6/13/12 21:55	
Decachlorobiphenyl [2]		*	30-150		S-01			6/13/12 21:55	
Tetrachloro-m-xylene [1]		*	30-150		S-01			6/13/12 21:55	
Tetrachloro-m-xylene [2]		*	30-150		S-01			6/13/12 21:55	



Project Location: KCL Sample Description: Red Duct Caulk Work Order: 12F0342

Date Received: 6/11/2012

Field Sample #: 137-6-12

Sampled: 6/11/2012 00:00

Sample ID: 12F0342-03
Sample Matrix: Caulk

Polychlorinated Rinhenyls with 3540 Soxhlet Extraction	

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	190	mg/Kg	1000		SW-846 8082A	6/11/12	6/14/12 7:41	JMB
Aroclor-1221 [1]	ND	190	mg/Kg	1000		SW-846 8082A	6/11/12	6/14/12 7:41	JMB
Aroclor-1232 [1]	ND	190	mg/Kg	1000		SW-846 8082A	6/11/12	6/14/12 7:41	JMB
Aroclor-1242 [1]	ND	190	mg/Kg	1000		SW-846 8082A	6/11/12	6/14/12 7:41	JMB
Aroclor-1248 [1]	ND	190	mg/Kg	1000		SW-846 8082A	6/11/12	6/14/12 7:41	JMB
Aroclor-1254 [1]	ND	190	mg/Kg	1000		SW-846 8082A	6/11/12	6/14/12 7:41	JMB
Aroclor-1260 [2]	3000	190	mg/Kg	1000		SW-846 8082A	6/11/12	6/14/12 7:41	JMB
Aroclor-1262 [1]	ND	190	mg/Kg	1000		SW-846 8082A	6/11/12	6/14/12 7:41	JMB
Aroclor-1268 [1]	ND	190	mg/Kg	1000		SW-846 8082A	6/11/12	6/14/12 7:41	JMB
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			6/14/12 7:41	
Decachlorobiphenyl [2]		*	30-150		S-01			6/14/12 7:41	
Tetrachloro-m-xylene [1]		*	30-150		S-01			6/14/12 7:41	
Tetrachloro-m-xylene [2]		*	30-150		S-01			6/14/12 7:41	



Sample Extraction Data

Prep Method: SW-846 3540C-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [g]	Final [mL]	Date
12F0342-01 [254-6-12]	B053151	0.548	10.0	06/11/12
12F0342-02 [256-6-12]	B053151	0.565	10.0	06/11/12
12F0342-03 [137-6-12]	B053151	0.531	10.0	06/11/12



QUALITY CONTROL

Polychlorinated Biphenyls with 3540 Soxhlet Extraction - Quality Control

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B053151 - SW-846 3540C										
Blank (B053151-BLK1)				Prepared: 06	5/11/12 Analy	yzed: 06/13/1	2			
Aroclor-1016	ND	0.20	mg/Kg							
Aroclor-1016 [2C]	ND	0.20	mg/Kg							
Aroclor-1221	ND	0.20	mg/Kg							
Aroclor-1221 [2C]	ND	0.20	mg/Kg							
Aroclor-1232	ND	0.20	mg/Kg							
Aroclor-1232 [2C]	ND	0.20	mg/Kg							
Aroclor-1242	ND	0.20	mg/Kg							
Aroclor-1242 [2C]	ND	0.20	mg/Kg							
Aroclor-1248	ND	0.20	mg/Kg							
Aroclor-1248 [2C]	ND	0.20	mg/Kg							
Aroclor-1254	ND	0.20	mg/Kg							
Aroclor-1254 [2C]	ND	0.20	mg/Kg							
Aroclor-1260	ND	0.20	mg/Kg							
Aroclor-1260 [2C]	ND	0.20	mg/Kg							
Aroclor-1262	ND	0.20	mg/Kg							
Aroclor-1262 [2C]	ND	0.20	mg/Kg							
Aroclor-1268	ND	0.20	mg/Kg							
Aroclor-1268 [2C]	ND	0.20	mg/Kg							
Surrogate: Decachlorobiphenyl	3.92		mg/Kg	4.00		97.9	30-150			
Surrogate: Decachlorobiphenyl [2C]	4.01		mg/Kg	4.00		100	30-150			
Surrogate: Tetrachloro-m-xylene	4.17		mg/Kg	4.00		104	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	5.13		mg/Kg	4.00		128	30-150			
LCS (B053151-BS1)				Prepared: 06	6/11/12 Analy	yzed: 06/13/1	2			
Aroclor-1016	3.7	0.20	mg/Kg	4.00		91.7	40-140			
Aroclor-1016 [2C]	4.5	0.20	mg/Kg	4.00		112	40-140			
Aroclor-1260	3.6	0.20	mg/Kg	4.00		89.9	40-140			
Aroclor-1260 [2C]	4.3	0.20	mg/Kg	4.00		107	40-140			
Surrogate: Decachlorobiphenyl	3.68		mg/Kg	4.00		92.0	30-150			
Surrogate: Decachlorobiphenyl [2C]	3.61		mg/Kg	4.00		90.1	30-150			
Surrogate: Tetrachloro-m-xylene	4.34		mg/Kg	4.00		108	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	5.30		mg/Kg	4.00		133	30-150			
LCS Dup (B053151-BSD1)				Prepared: 06	5/11/12 Analy	yzed: 06/13/1	2			
Aroclor-1016	3.6	0.20	mg/Kg	4.00		89.3	40-140	2.62	30	
Aroclor-1016 [2C]	4.3	0.20	mg/Kg	4.00		108	40-140	3.37	30	
Aroclor-1260	3.8	0.20	mg/Kg	4.00		94.3	40-140	4.80	30	
Aroclor-1260 [2C]	4.5	0.20	mg/Kg	4.00		112	40-140	4.76	30	
Surrogate: Decachlorobiphenyl	3.95		mg/Kg	4.00		98.7	30-150			
Surrogate: Decachlorobiphenyl [2C]	3.98		mg/Kg	4.00		99.4	30-150			
Surrogate: Tetrachloro-m-xylene	3.90		mg/Kg	4.00		97.4	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	4.72		mg/Kg	4.00		118	30-150			



FLAG/QUALIFIER SUMMARY

*	QC result is outside of established limits.
†	Wide recovery limits established for difficult compound.

‡ Wide RPD limits established for difficult compound.

Data exceeded client recommended or regulatory level

Percent recoveries and relative percent differences (RPDs) are determined by the software using values in the

calculation which have not been rounded.

S-01 The surrogate recovery for this sample is not available due to sample dilution below the surrogate reporting limit

required from high analyte concentration and/or matrix interferences.



CERTIFICATIONS

Certified Analyses included in this Report

Analyte Certifications

No certified Analyses included in this Report

 $The \ CON\text{-}TEST \ Environmental \ Laboratory \ operates \ under \ the \ following \ certifications \ and \ accreditations:$

Code	Description	Number	Expires
AIHA	AIHA-LAP, LLC	100033	02/1/2014
MA	Massachusetts DEP	M-MA100	06/30/2012
CT	Connecticut Department of Publilc Health	PH-0567	09/30/2013
NY	New York State Department of Health	10899 NELAP	04/1/2013
NH	New Hampshire Environmental Lab	2516 NELAP	02/5/2013
RI	Rhode Island Department of Health	LAO00112	12/30/2012
NC	North Carolina Div. of Water Quality	652	12/31/2012
NJ	New Jersey DEP	MA007 NELAP	06/30/2012
FL	Florida Department of Health	E871027 NELAP	06/30/2012
VT	Vermont Department of Health Lead Laboratory	LL015036	07/30/2012
WA	State of Washington Department of Ecology	C2065	02/23/2013
ME	State of Maine	2011028	06/9/2013
VA	Commonwealth of Virginia	1381	12/14/2012

O = Onei	0=0		O = otner_						-	*Require lab approval.	*Require la				
D - Souldin pisunate	ا ا	ī	SL = Sludge						1	Date needed**		Date/Time:	Date	Received by: (signature)	٦
diam bigglesto	1 6	•				, .	Special Requirements of	iai Nequi		Cities			-		
S = Sulfuric Acid	s = Su	ਰ <u>ੰ</u>	S = soil/solid	10		٠ او:	ements o			2	ל נ י-	Date/1111e.	Date	Relinquished by: (signature)	Re
N = Nitric Acid	N = Nit		A = air	_			s only)	(MA MCP sites only)						STORY OF STATES	k
M = Methanol	M = M6	ing water	DW= drinking water		N	ect?	Data Enhancement Project? Y	Enhance		72 Hour*		721 172	2- -	Salar	
CL T = Na thiosultate	H = HCL	ewater	WW= wastewater						<u> </u>	48 Hour*		Time:	Date/		Ū.Ţ
	= iced	ndwater	GW= groundwater	<u> </u>				Regulations?	Regu	24 Hour*		11/200	<u> </u>		
rvation (**Pres	de:	Matrix Code:	•	nents	equirements	Detection Limit Ru	ection	Det	Turnaround	Turna	Time: 120	Date/	Red pouished by (signature)	7
	+	F		ļ	-	-									
-					_				\dashv				\dagger		1
	_														
	+	1		#	+	\downarrow			\dagger						[
									ι.						\exists
	-	-			+										
					\dashv				-				1		T^{\prime}
															<u></u>
	+			†	+	1			\dagger				\vdash		
									1				+		T
	+			+	+						-	03	+	37-6-12 RGO DUCK CARK	(N
					~		_		1		+		╣		1
						7						22 —		79-6-12 RAD DUTICALL	2
Comments:					 	<u> </u>	2000	60	-		dille	0		2546-12 RGD DUCT CAUX	Ñ
	+	1		1	+	ă	Miduly Code	Glab	OSITE	Date/ Line	pate/ ime		Lab #	Field ID Sample Description	Fie
					<u> 1 C</u>		*Matrix Ox	}	_	Stop			-		\neg
O =Other					<u> </u>	B				Date Sampled	Date S		į	ves proposal date	-
T≃tedlar bag									l			. !		Proposal Provided? (For Billing purposes)	ק כ
S=summa can					u		D GIS KEY) ¥	ם PDF	☐ EXCEL	Format:			allibled by 1, 11, 00 % CV	ğ
V= vial					1		reco	work.	war.	ven. m.	Email Steven. Mordina abythe edo			Sampled By: 2: MAN A	ה ה ה
ST=sterile					33		<u> </u>	,			Fax#:	77		スパ	7
P=plastic					40	_	IENT	ISITE CI	TWEB	MEMAIL TWEBSITE CLIENT	DEAX XEMAIL DWEBSITE	IF		Attention: 1606 1100 611	Atte
G=glass					ے(וצה		no).	thock o	WEDY (A TA DE	7		COL M M MON	
A=amber glass	ANALYSIS REQUESTED	S REQ	NALYSI		roi	 Deti				+	Client PO#	<i>y</i>		→ [
		-			\dagger	 				75	Project # 75	1 00/als	5	\sim	Add
-Cont Code		$\frac{1}{1}$		1	\dagger	 			101	16	erepriore			Company Name: 1/HCE EII >	Con
**Preservation	+	+		+	+	-	N	イン	んな	200	وموطووان	www.contestlabs.com	WWW.	^	4
# of containers		\dashv			-	7)	770		3	.com	_	Email:	ANALYTICAL LABORATORY	₫
1028	EAST LONGMEADOW, MA 01028	SMEADO	AST LONG	Ę.			7	7 70)	こりついろ		Fax: 413-525-6405	Fax: 4	CON-LEST	
			S OF NOOL	۽	ָל		7	Ò		CHAIN OF COSTOR		Phone: 413-525-2332	Phone		<u> </u>

Con-Test Laboratory is the ONLY independent laboratory in all of New England with both prestigious AIHA and NELAC Certifications! $4~{\rm DPM} = {\rm ReSun} > {\rm FONDPM}$

Page 11 of 12

Phone: 413-525-2332

CHAIN OF CUSTODY RECORD

39 SPRUCE ST, 2ND FLOOR

Page _____ of _

39 Spruce St.
East Longmeadow, MA. 01028
P: 413-525-2332
F: 413-525-6405
www.contestlabs.com





Sample Receipt Checklist

CLIENT NAME: Yale EH	SRECEIV	ED BY:	>	DATE: 0/11/12
1) Was the chain(s) of custody reli2) Does the chain agree with the salf not, explain:	•	Ye Ve	No No	No CoC Included
3) Are all the samples in good con- lf not, explain:	dition?	Ye	No No	
4) How were the samples received On Ice Direct from San Were the samples received in Tem Temperature °C by Temp blank	mpling Ambien perature Compliance of (2-	·6°C)? Ye		N/A
	Temper	ature 'C by Ten	ip gun	11.1
5) Are there Dissolved samples for		Ye	s (160)	
Who was notified		ne		
6) Are there any RUSH or SHORT I		Ye	S) No	
7) Location where samples are stored	3	Permission (Walk-in cli	ents only)	ntract samples? Yes No if not already approved
8) Do all samples have the proper	Acid pH: Yes No N/A	-		
9) Do all samples have the proper	Base pH: Yes No (N/A)			
	ntainers received	at Con-1	est	
	# of containers	<u> </u>		# of containers
1 Liter Amber		8 oz amber	/clear iar	" of containers
500 mL Amber		4 oz amber		
250 mL Amber (8oz amber)		2 oz amber		3
1 Liter Plastic		Air Cas	sette	
500 mL Plastic		Hg/Hopcal	ite Tube	
250 mL plastic		Plastic Bag	/ Ziploc	
40 mL Vial - type listed below		PM 2.5 /	PM 10	
Colisure / bacteria bottle		PUF Cai	tridge	
Dissolved Oxygen bottle		SOC	Kit	
Encore		TO-17 T	ubes	
Flashpoint bottle		Non-ConTest		er
Perchlorate Kit		Other gla		<u> </u>
Other Laboratory Comments:		Othe	<u>er</u>	
40 mL vials: # HCI	# Methanol			Time and Date Frozen:
Doc# 277 # Bisulfate	# DI Water			
Rev. 2 Sept 2011 # Thiosulfate	Unpreserved		7	Page 12 of



July 6, 2012

George Franklin Woodard & Curran - Andover, MA 35 New England Business Center Andover, MA 01810

Project Location: Yale-KCL

Client Job Number: Project Number: 225540

Laboratory Work Order Number: 12F0964

Meghan S. Kelley

Enclosed are results of analyses for samples received by the laboratory on June 27, 2012. If you have any questions concerning this report, please feel free to contact me.

Sincerely,

Meghan E. Kelley Project Manager



Woodard & Curran - Andover, MA 35 New England Business Center Andover, MA 01810

ATTN: George Franklin

39 Spruce Street * East Longmeadow, MA 01028 * FAX 413/525-6405 * TEL. 413/525-2332

REPORT DATE: 7/6/2012

PURCHASE ORDER NUMBER:

PROJECT NUMBER: 225540

ANALYTICAL SUMMARY

12F0964 WORK ORDER NUMBER:

The results of analyses performed on the following samples submitted to the CON-TEST Analytical Laboratory are found in this report.

PROJECT LOCATION: Yale-KCL

FIELD SAMPLE #	LAB ID:	MATRIX	SAMPLE DESCRIPTION	TEST	SUB LAB
KCL-CBK-036	12F0964-01	Caulk		SW-846 8082A	
KCL-CBK-037	12F0964-02	Caulk		SW-846 8082A	
KCL-CBK-038	12F0964-03	Caulk		SW-846 8082A	
KCL-CBK-039	12F0964-04	Caulk		SW-846 8082A	
KCL-CBB-040	12F0964-05	Brick		SW-846 8082A	
KCL-CBC-041	12F0964-06	Concrete		SW-846 8082A	
KCL-VBC-042	12F0964-07	Concrete		SW-846 8082A	
KCL-VBC-043	12F0964-08	Concrete		SW-846 8082A	
KCL-VWP-044	12F0964-09	Wipe		SW-846 8082A	
KCL-VWP-045	12F0964-10	Wipe		SW-846 8082A	
KCL-VWP-046	12F0964-11	Wipe		SW-846 8082A	
KCL-VBC-047	12F0964-12	Concrete		SW-846 8082A	
KCL-VBC-048	12F0964-13	Concrete		SW-846 8082A	
KCL-VBC-049	12F0964-14	Concrete		SW-846 8082A	
KCL-VBC-050	12F0964-15	Concrete		SW-846 8082A	
KCL-VBC-051	12F0964-16	Concrete		SW-846 8082A	
KCL-VBB-052	12F0964-17	Brick		SW-846 8082A	
KCL-VBB-053	12F0964-18	Brick		SW-846 8082A	
KCL-VBBD-054	12F0964-19	Brick		SW-846 8082A	
KCL-VBBQ-055	12F0964-20	Equipment Blank Water		SW-846 8082A	



CASE NARRATIVE SUMMARY

All reported results are within defined laboratory quality control objectives unless listed below or otherwise qualified in this report.

SW-846 8082A

Qualifications:

Analyte is found in the associated blank as well as in the sample.

Analyte & Samples(s) Qualified:

Aroclor-1254, Aroclor-1254 [2C]

12F0964-01[KCL-CBK-036], 12F0964-02[KCL-CBK-037], 12F0964-03[KCL-CBK-038]

Data is not affected by elevated level in blank since sample result is >10x level found in the blank.

Analyte & Samples(s) Qualified:

Aroclor-1254, Aroclor-1254 [2C]

12F0964-01[KCL-CBK-036], 12F0964-02[KCL-CBK-037], 12F0964-03[KCL-CBK-038]

Sample contains two incompletely resolved aroclors. Aroclor with the closest matching pattern is reported.

Analyte & Samples(s) Qualified:

Aroclor-1260, Aroclor-1260 [2C]

12F0964-08[KCL-VBC-043]

The surrogate recovery for this sample is not available due to sample dilution below the surrogate reporting limit required from high analyte concentration and/or matrix interferences.

Analyte & Samples(s) Qualified:

Decachlorobiphenyl, Decachlorobiphenyl [2C], Tetrachloro-m-xylene, Tetrachloro-m-xylene [2C]

12F0964-01[KCL-CBK-036], 12F0964-02[KCL-CBK-037]

Continuing calibration verification was outside of control limits on the confirmation column, but within control limits on the primary column. All sample results are reported from the column within control criteria.

Analyte & Samples(s) Qualified:

Aroclor-1016 [2C], Aroclor-1260 [2C]

12F0964-01[KCL-CBK-036], 12F0964-02[KCL-CBK-037], 12F0964-03[KCL-CBK-038], B054247-BS1, B054247-BSD1, B054542-BSD1, B054542-BS

The results of analyses reported only relate to samples submitted to the Con-Test Analytical Laboratory for testing.

I certify that the analyses listed above, unless specifically listed as subcontracted, if any, were performed under my direction according to the approved methodologies listed in this document, and that based upon my inquiry of those individuals immediately responsible for obtaining the information, the material contained in this report is, to the best of my knowledge and belief, accurate and complete.

Michael A. Erickson Laboratory Director

Culu



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-CBK-036

Sample ID: 12F0964-01
Sample Matrix: Caulk

Sampled: 6/26/2012 12:35

Polychlorinated	Rinhenvls with	ı 3540 Soxhlet F	extraction

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	9.0	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:34	MJC
Aroclor-1221 [1]	ND	9.0	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:34	MJC
Aroclor-1232 [1]	ND	9.0	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:34	MJC
Aroclor-1242 [1]	ND	9.0	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:34	MJC
Aroclor-1248 [1]	ND	9.0	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:34	MJC
Aroclor-1254 [2]	60	9.0	mg/Kg	50	B-07, B	SW-846 8082A	6/28/12	7/3/12 15:34	MJC
Aroclor-1260 [1]	ND	9.0	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:34	MJC
Aroclor-1262 [1]	ND	9.0	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:34	MJC
Aroclor-1268 [1]	ND	9.0	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:34	MJC
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			7/3/12 15:34	
Decachlorobiphenyl [2]		*	30-150		S-01			7/3/12 15:34	
Tetrachloro-m-xylene [1]		*	30-150		S-01			7/3/12 15:34	
Tetrachloro-m-xylene [2]		*	30-150		S-01			7/3/12 15:34	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-CBK-037

Sampled: 6/26/2012 12:40

Sample ID: 12F0964-02
Sample Matrix: Caulk

Polychlorinated	Rinhenvls with	3540 Soxble	et Extraction
1 diyembi mateu	Diplicity is with	I JJ4U BUAIII	L L'AU ACUON

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	8.6	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:47	MJC
Aroclor-1221 [1]	ND	8.6	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:47	MJC
Aroclor-1232 [1]	ND	8.6	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:47	MJC
Aroclor-1242 [1]	ND	8.6	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:47	MJC
Aroclor-1248 [1]	ND	8.6	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:47	MJC
Aroclor-1254 [2]	61	8.6	mg/Kg	50	B-07, B	SW-846 8082A	6/28/12	7/3/12 15:47	MJC
Aroclor-1260 [1]	ND	8.6	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:47	MJC
Aroclor-1262 [1]	ND	8.6	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:47	MJC
Aroclor-1268 [1]	ND	8.6	mg/Kg	50		SW-846 8082A	6/28/12	7/3/12 15:47	MJC
Surrogates		% Recovery	Recovery Limits		Flag				
Decachlorobiphenyl [1]		*	30-150		S-01			7/3/12 15:47	
Decachlorobiphenyl [2]		*	30-150		S-01			7/3/12 15:47	
Tetrachloro-m-xylene [1]		*	30-150		S-01			7/3/12 15:47	
Tetrachloro-m-xylene [2]		*	30-150		S-01			7/3/12 15:47	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-CBK-038

Sampled: 6/26/2012 12:50

Sample ID: 12F0964-03

Sample Matrix: Caulk

Polychloringtod	Rinhanyle with	3540 Savhlat l	Extraction

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
					Tiag		•		
Aroclor-1016 [1]	ND	3.6	mg/Kg	20		SW-846 8082A	6/28/12	7/3/12 16:00	MJC
Aroclor-1221 [1]	ND	3.6	mg/Kg	20		SW-846 8082A	6/28/12	7/3/12 16:00	MJC
Aroclor-1232 [1]	ND	3.6	mg/Kg	20		SW-846 8082A	6/28/12	7/3/12 16:00	MJC
Aroclor-1242 [1]	ND	3.6	mg/Kg	20		SW-846 8082A	6/28/12	7/3/12 16:00	MJC
Aroclor-1248 [1]	ND	3.6	mg/Kg	20		SW-846 8082A	6/28/12	7/3/12 16:00	MJC
Aroclor-1254 [2]	31	3.6	mg/Kg	20	B-07, B	SW-846 8082A	6/28/12	7/3/12 16:00	MJC
Aroclor-1260 [1]	ND	3.6	mg/Kg	20		SW-846 8082A	6/28/12	7/3/12 16:00	MJC
Aroclor-1262 [1]	ND	3.6	mg/Kg	20		SW-846 8082A	6/28/12	7/3/12 16:00	MJC
Aroclor-1268 [1]	ND	3.6	mg/Kg	20		SW-846 8082A	6/28/12	7/3/12 16:00	MJC
Surrogates		% Recovery	Recovery Limits	1	Flag				
Decachlorobiphenyl [1]		75.1	30-150					7/3/12 16:00	
Decachlorobiphenyl [2]		96.7	30-150					7/3/12 16:00	
Tetrachloro-m-xylene [1]		99.9	30-150					7/3/12 16:00	
Tetrachloro-m-xylene [2]		126	30-150					7/3/12 16:00	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-CBK-039

Sampled: 6/26/2012 12:55

Sample ID: 12F0964-04

Sample Matrix: Caulk

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.87	mg/Kg	5		SW-846 8082A	7/5/12	7/6/12 10:53	MJC
Aroclor-1221 [1]	ND	0.87	mg/Kg	5		SW-846 8082A	7/5/12	7/6/12 10:53	MJC
Aroclor-1232 [1]	ND	0.87	mg/Kg	5		SW-846 8082A	7/5/12	7/6/12 10:53	MJC
Aroclor-1242 [1]	ND	0.87	mg/Kg	5		SW-846 8082A	7/5/12	7/6/12 10:53	MJC
Aroclor-1248 [1]	ND	0.87	mg/Kg	5		SW-846 8082A	7/5/12	7/6/12 10:53	MJC
Aroclor-1254 [1]	ND	0.87	mg/Kg	5		SW-846 8082A	7/5/12	7/6/12 10:53	MJC
Aroclor-1260 [1]	ND	0.87	mg/Kg	5		SW-846 8082A	7/5/12	7/6/12 10:53	MJC
Aroclor-1262 [1]	ND	0.87	mg/Kg	5		SW-846 8082A	7/5/12	7/6/12 10:53	MJC
Aroclor-1268 [1]	ND	0.87	mg/Kg	5		SW-846 8082A	7/5/12	7/6/12 10:53	MJC
Surrogates		% Recovery	Recovery Limits	i	Flag				
Decachlorobiphenyl [1]		121	30-150					7/6/12 10:53	
Decachlorobiphenyl [2]		107	30-150					7/6/12 10:53	
Tetrachloro-m-xylene [1]		118	30-150					7/6/12 10:53	
Tetrachloro-m-xylene [2]		116	30-150					7/6/12 10:53	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-CBB-040 Sampled: 6/26/2012 13:10

Sample ID: 12F0964-05
Sample Matrix: Brick

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:34	MJC
Aroclor-1221 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:34	MJC
Aroclor-1232 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:34	MJC
Aroclor-1242 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:34	MJC
Aroclor-1248 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:34	MJC
Aroclor-1254 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:34	MJC
Aroclor-1260 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:34	MJC
Aroclor-1262 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:34	MJC
Aroclor-1268 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:34	MJC
Surrogates		% Recovery	Recovery Limits	s	Flag				
Decachlorobiphenyl [1]		104	30-150					6/30/12 13:34	
Decachlorobiphenyl [2]		93.6	30-150					6/30/12 13:34	
Tetrachloro-m-xylene [1]		90.7	30-150					6/30/12 13:34	
Tetrachloro-m-xylene [2]		94.2	30-150					6/30/12 13:34	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-CBC-041

Sample ID: 12F0964-06
Sample Matrix: Concrete

Sampled: 6/26/2012 13:50

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:47	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:47	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:47	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:47	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:47	MJC
Aroclor-1254 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:47	MJC
Aroclor-1260 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:47	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:47	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 13:47	MJC
Surrogates		% Recovery	Recovery Limits	1	Flag				
Decachlorobiphenyl [1]		105	30-150					6/30/12 13:47	
Decachlorobiphenyl [2]		94.4	30-150					6/30/12 13:47	
Tetrachloro-m-xylene [1]		88.5	30-150					6/30/12 13:47	
Tetrachloro-m-xylene [2]		92.5	30-150					6/30/12 13:47	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VBC-042 Sampled: 6/26/2012 14:38

Sample ID: 12F0964-07
Sample Matrix: Concrete

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:15	MJC
Aroclor-1221 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:15	MJC
Aroclor-1232 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:15	MJC
Aroclor-1242 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:15	MJC
Aroclor-1248 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:15	MJC
Aroclor-1254 [2]	2.8	0.43	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:15	MJC
Aroclor-1260 [2]	1.7	0.43	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:15	MJC
Aroclor-1262 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:15	MJC
Aroclor-1268 [1]	ND	0.43	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:15	MJC
Surrogates		% Recovery	Recovery Limits	1	Flag				
Decachlorobiphenyl [1]		129	30-150					7/1/12 6:15	
Decachlorobiphenyl [2]		113	30-150					7/1/12 6:15	
Tetrachloro-m-xylene [1]		94.4	30-150					7/1/12 6:15	
Tetrachloro-m-xylene [2]		96.2	30-150					7/1/12 6:15	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VBC-043 Sampled: 6/26/2012 14:45

Sample ID: 12F0964-08
Sample Matrix: Concrete

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 14:52	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 14:52	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 14:52	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 14:52	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 14:52	MJC
Aroclor-1254 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 14:52	MJC
Aroclor-1260 [1]	1.1	0.087	mg/Kg	1	O-03	SW-846 8082A	6/28/12	6/30/12 14:52	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 14:52	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 14:52	MJC
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		82.0	30-150					6/30/12 14:52	
Decachlorobiphenyl [2]		72.8	30-150					6/30/12 14:52	
Tetrachloro-m-xylene [1]		68.0	30-150					6/30/12 14:52	
Tetrachloro-m-xylene [2]		71.6	30-150					6/30/12 14:52	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VWP-044 Sampled: 6/26/2012 15:00

Sample ID: 12F0964-09
Sample Matrix: Wipe

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 20:53	MJC
Aroclor-1221 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 20:53	MJC
Aroclor-1232 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 20:53	MJC
Aroclor-1242 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 20:53	MJC
Aroclor-1248 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 20:53	MJC
Aroclor-1254 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 20:53	MJC
Aroclor-1260 [1]	0.34	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 20:53	MJC
Aroclor-1262 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 20:53	MJC
Aroclor-1268 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 20:53	MJC
Surrogates		% Recovery	Recovery Limits	s	Flag				
Decachlorobiphenyl [1]		118	30-150					6/29/12 20:53	
Decachlorobiphenyl [2]		109	30-150					6/29/12 20:53	
Tetrachloro-m-xylene [1]		103	30-150					6/29/12 20:53	
Tetrachloro-m-xylene [2]		107	30-150					6/29/12 20:53	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VWP-045

Sampled: 6/26/2012 15:05

Sample ID: 12F0964-10
Sample Matrix: Wipe

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:05	MJC
Aroclor-1221 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:05	MJC
Aroclor-1232 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:05	MJC
Aroclor-1242 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:05	MJC
Aroclor-1248 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:05	MJC
Aroclor-1254 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:05	MJC
Aroclor-1260 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:05	MJC
Aroclor-1262 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:05	MJC
Aroclor-1268 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:05	MJC
Surrogates		% Recovery	Recovery Limits	s	Flag				
Decachlorobiphenyl [1]		117	30-150					6/29/12 21:05	
Decachlorobiphenyl [2]		107	30-150					6/29/12 21:05	
Tetrachloro-m-xylene [1]		102	30-150					6/29/12 21:05	
Tetrachloro-m-xylene [2]		106	30-150					6/29/12 21:05	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VWP-046

Sampled: 6/26/2012 15:15

Sample ID: 12F0964-11
Sample Matrix: Wipe

Dalwahlarinatad	Dinhonylo with	2540 Carrblat	Extraction

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:18	MJC
Aroclor-1221 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:18	MJC
Aroclor-1232 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:18	MJC
Aroclor-1242 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:18	MJC
Aroclor-1248 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:18	MJC
Aroclor-1254 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:18	MJC
Aroclor-1260 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:18	MJC
Aroclor-1262 [1]	ND	0.20	μg/Wipe	1		SW-846 8082A	6/28/12	6/29/12 21:18	MJC
Aroclor-1268 [1]	ND	0.20	$\mu g/Wipe$	1		SW-846 8082A	6/28/12	6/29/12 21:18	MJC
Surrogates		% Recovery	Recovery Limits	i	Flag				
Decachlorobiphenyl [1]		113	30-150					6/29/12 21:18	
Decachlorobiphenyl [2]		102	30-150					6/29/12 21:18	
Tetrachloro-m-xylene [1]		102	30-150					6/29/12 21:18	
Tetrachloro-m-xylene [2]		106	30-150					6/29/12 21:18	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VBC-047

Sample ID: 12F0964-12
Sample Matrix: Concrete

Sampled: 6/26/2012 15:30

Polychlorinated Biphenyls with 3540 Soxhlet Extraction												
Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst			
Aroclor-1016 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:05	MJC			
Aroclor-1221 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:05	MJC			
Aroclor-1232 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:05	MJC			
Aroclor-1242 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:05	MJC			
Aroclor-1248 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:05	MJC			
Aroclor-1254 [2]	0.29	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:05	MJC			
Aroclor-1260 [1]	0.46	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:05	MJC			
Aroclor-1262 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:05	MJC			
Aroclor-1268 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:05	MJC			
Surrogates		% Recovery	Recovery Limits	i	Flag							
Decachlorobiphenyl [1]		126	30-150					6/30/12 15:05				
Decachlorobiphenyl [2]		112	30-150					6/30/12 15:05				
Tetrachloro-m-xylene [1]		96.0	30-150					6/30/12 15:05				
Tetrachloro-m-xylene [2]		99.8	30-150					6/30/12 15:05				



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VBC-048

Sample ID: 12F0964-13
Sample Matrix: Concrete

Sampled: 6/26/2012 15:50

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:18	MJC
Aroclor-1221 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:18	MJC
Aroclor-1232 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:18	MJC
Aroclor-1242 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:18	MJC
Aroclor-1248 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:18	MJC
Aroclor-1254 [2]	1.1	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:18	MJC
Aroclor-1260 [1]	0.36	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:18	MJC
Aroclor-1262 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:18	MJC
Aroclor-1268 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 15:18	MJC
Surrogates		% Recovery	Recovery Limits	i	Flag				
Decachlorobiphenyl [1]		126	30-150					6/30/12 15:18	
Decachlorobiphenyl [2]		113	30-150					6/30/12 15:18	
Tetrachloro-m-xylene [1]		99.4	30-150					6/30/12 15:18	
Tetrachloro-m-xylene [2]		104	30-150					6/30/12 15:18	



Analyte

39 Spruce Street * East Longmeadow, MA 01028 * FAX 413/525-6405 * TEL. 413/525-2332

Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VBC-049

Sampled: 6/26/2012 16:00

Results

ND

ND

ND

ND

ND

3.3

0.82

ND

ND

Sample ID: 12F0964-14
Sample Matrix: Concrete

Aroclor-1016 [1]

Aroclor-1221 [1]

Aroclor-1232 [1]

Aroclor-1242 [1]

Aroclor-1248 [1]

Aroclor-1254 [2]

Aroclor-1260 [1]

Aroclor-1262 [1]

Aroclor-1268 [1]

	Polychlorinated	l Biphenyls w						
	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
_	KL	Units	Dilution	Flag	Methou	rrepareu	Allalyzeu	Analyst
	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:28	MJC
	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:28	MJC
	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:28	MJC
	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:28	MJC
	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:28	MJC
	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:28	MJC
	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:28	MJC
	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:28	MJC
	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:28	MJC

Surrogates	% Recovery	Recovery Limits	Flag	
Decachlorobiphenyl [1]	125	30-150		7/1/12 6:28
Decachlorobiphenyl [2]	110	30-150		7/1/12 6:28
Tetrachloro-m-xylene [1]	92.6	30-150		7/1/12 6:28
Tetrachloro-m-xylene [2]	94.6	30-150		7/1/12 6:28



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VBC-050

Sampled: 6/26/2012 16:20

Sample ID: 12F0964-15
Sample Matrix: Concrete

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	6/28/12	7/1/12 6:41	MJC
Aroclor-1221 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	6/28/12	7/1/12 6:41	MJC
Aroclor-1232 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	6/28/12	7/1/12 6:41	MJC
Aroclor-1242 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	6/28/12	7/1/12 6:41	MJC
Aroclor-1248 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	6/28/12	7/1/12 6:41	MJC
Aroclor-1254 [2]	1.1	0.18	mg/Kg	2		SW-846 8082A	6/28/12	7/1/12 6:41	MJC
Aroclor-1260 [2]	0.40	0.18	mg/Kg	2		SW-846 8082A	6/28/12	7/1/12 6:41	MJC
Aroclor-1262 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	6/28/12	7/1/12 6:41	MJC
Aroclor-1268 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	6/28/12	7/1/12 6:41	MJC
Surrogates		% Recovery	Recovery Limits	1	Flag				
Decachlorobiphenyl [1]		126	30-150					7/1/12 6:41	
Decachlorobiphenyl [2]		110	30-150					7/1/12 6:41	
Tetrachloro-m-xylene [1]		96.2	30-150					7/1/12 6:41	
Tetrachloro-m-xylene [2]		99.3	30-150					7/1/12 6:41	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VBC-051

Sampled: 6/26/2012 16:30

Sample ID: 12F0964-16
Sample Matrix: Concrete

Polychloringted	Dinhonylo with	2540 Carrbla	t Extuastion

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:54	MJC
Aroclor-1221 [1]	ND	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:54	MJC
Aroclor-1232 [1]	ND	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:54	MJC
Aroclor-1242 [1]	ND	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:54	MJC
Aroclor-1248 [1]	ND	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:54	MJC
Aroclor-1254 [2]	3.6	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:54	MJC
Aroclor-1260 [2]	0.82	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:54	MJC
Aroclor-1262 [1]	ND	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:54	MJC
Aroclor-1268 [1]	ND	0.45	mg/Kg	5		SW-846 8082A	6/28/12	7/1/12 6:54	MJC
Surrogates		% Recovery	Recovery Limits	1	Flag				
Decachlorobiphenyl [1]		132	30-150					7/1/12 6:54	
Decachlorobiphenyl [2]		117	30-150					7/1/12 6:54	
Tetrachloro-m-xylene [1]		99.4	30-150					7/1/12 6:54	
Tetrachloro-m-xylene [2]		100	30-150					7/1/12 6:54	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VBB-052 Sampled: 6/26/2012 16:40

Sample ID: 12F0964-17
Sample Matrix: Brick

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
-				Dilution	Tiag		•	•	
Aroclor-1016 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:10	MJC
Aroclor-1221 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:10	MJC
Aroclor-1232 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:10	MJC
Aroclor-1242 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:10	MJC
Aroclor-1248 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:10	MJC
Aroclor-1254 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:10	MJC
Aroclor-1260 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:10	MJC
Aroclor-1262 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:10	MJC
Aroclor-1268 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:10	MJC
Surrogates		% Recovery	Recovery Limits	s	Flag				
Decachlorobiphenyl [1]		130	30-150					6/30/12 16:10	
Decachlorobiphenyl [2]		116	30-150					6/30/12 16:10	
Tetrachloro-m-xylene [1]		108	30-150					6/30/12 16:10	
Tetrachloro-m-xylene [2]		111	30-150					6/30/12 16:10	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VBB-053

Sampled: 6/26/2012 16:50

Sample ID: 12F0964-18
Sample Matrix: Brick

1	Polychlorinated	Dinhanyle wit	h 25/0 Covh	lot Extraction
ı	Polychiorinated	Binnenvis wit	n 3540 Soxn	iet Extraction

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:23	MJC
Aroclor-1221 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:23	MJC
Aroclor-1232 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:23	MJC
Aroclor-1242 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:23	MJC
Aroclor-1248 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:23	MJC
Aroclor-1254 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:23	MJC
Aroclor-1260 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:23	MJC
Aroclor-1262 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:23	MJC
Aroclor-1268 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:23	MJC
Surrogates		% Recovery	Recovery Limits	s	Flag				
Decachlorobiphenyl [1]		107	30-150					6/30/12 16:23	
Decachlorobiphenyl [2]		95.2	30-150					6/30/12 16:23	
Tetrachloro-m-xylene [1]		93.3	30-150					6/30/12 16:23	
Tetrachloro-m-xylene [2]		96.3	30-150					6/30/12 16:23	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VBBD-054

12F0964_19

Sampled: 6/26/2012 16:50

Sample ID: 12F0964-19
Sample Matrix: Brick

Polychloringted	Rinhanyle	with 35/0	Soublet F	vtraction

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:35	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:35	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:35	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:35	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:35	MJC
Aroclor-1254 [2]	0.10	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:35	MJC
Aroclor-1260 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:35	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:35	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	6/28/12	6/30/12 16:35	MJC
Surrogates		% Recovery	Recovery Limits	6	Flag				
Decachlorobiphenyl [1]		110	30-150					6/30/12 16:35	
Decachlorobiphenyl [2]		98.0	30-150					6/30/12 16:35	
Tetrachloro-m-xylene [1]		95.5	30-150					6/30/12 16:35	
Tetrachloro-m-xylene [2]		98.2	30-150					6/30/12 16:35	



Project Location: Yale-KCL Sample Description: Work Order: 12F0964

Date Received: 6/27/2012

Field Sample #: KCL-VBBQ-055

Sampled: 6/26/2012 17:00

Sample ID: 12F0964-20

Sample Matrix: Equipment Blank Water

Polychlorinated	Biphenvls	By GC/ECD

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.20	μg/L	1		SW-846 8082A	6/29/12	6/29/12 16:20	MJC
Aroclor-1221 [1]	ND	0.20	μg/L	1		SW-846 8082A	6/29/12	6/29/12 16:20	MJC
Aroclor-1232 [1]	ND	0.20	$\mu g/L$	1		SW-846 8082A	6/29/12	6/29/12 16:20	MJC
Aroclor-1242 [1]	ND	0.20	$\mu g/L$	1		SW-846 8082A	6/29/12	6/29/12 16:20	MJC
Aroclor-1248 [1]	ND	0.20	$\mu g/L$	1		SW-846 8082A	6/29/12	6/29/12 16:20	MJC
Aroclor-1254 [1]	ND	0.20	$\mu g/L$	1		SW-846 8082A	6/29/12	6/29/12 16:20	MJC
Aroclor-1260 [1]	ND	0.20	$\mu g/L$	1		SW-846 8082A	6/29/12	6/29/12 16:20	MJC
Aroclor-1262 [1]	ND	0.20	$\mu g/L$	1		SW-846 8082A	6/29/12	6/29/12 16:20	MJC
Aroclor-1268 [1]	ND	0.20	$\mu g/L$	1		SW-846 8082A	6/29/12	6/29/12 16:20	MJC
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		71.4	30-150					6/29/12 16:20	
Decachlorobiphenyl [2]		63.7	30-150					6/29/12 16:20	
Tetrachloro-m-xylene [1]		78.1	30-150					6/29/12 16:20	
Tetrachloro-m-xylene [2]		81.6	30-150					6/29/12 16:20	



Sample Extraction Data

Prep Method: SW-846 3540C-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [g]	Final [mL]	Date
12F0964-01 [KCL-CBK-036]	B054247	0.557	10.0	06/28/12
12F0964-02 [KCL-CBK-037]	B054247	0.579	10.0	06/28/12
12F0964-03 [KCL-CBK-038]	B054247	0.562	10.0	06/28/12

Prep Method: SW-846 3540C-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [g]	Final [mL]	Date
12F0964-04RE1 [KCL-CBK-039]	B054542	0.572	10.0	07/05/12

Prep Method: SW-846 3540C-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [g]	Final [mL]	Date	
12F0964-05 [KCL-CBB-040]	B054248	2.10	10.0	06/28/12	
12F0964-06 [KCL-CBC-041]	B054248	2.30	10.0	06/28/12	
12F0964-07 [KCL-VBC-042]	B054248	2.30	10.0	06/28/12	
12F0964-08 [KCL-VBC-043]	B054248	2.30	10.0	06/28/12	
12F0964-12 [KCL-VBC-047]	B054248	2.10	10.0	06/28/12	
12F0964-13 [KCL-VBC-048]	B054248	2.10	10.0	06/28/12	
12F0964-14 [KCL-VBC-049]	B054248	2.20	10.0	06/28/12	
12F0964-15 [KCL-VBC-050]	B054248	2.20	10.0	06/28/12	
12F0964-16 [KCL-VBC-051]	B054248	2.20	10.0	06/28/12	
12F0964-17 [KCL-VBB-052]	B054248	2.20	10.0	06/28/12	
12F0964-18 [KCL-VBB-053]	B054248	2.20	10.0	06/28/12	
12F0964-19 [KCL-VBBD-054]	B054248	2.30	10.0	06/28/12	

Prep Method: SW-846 3510C-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [mL]	Final [mL]	Date	
12F0964-20 [KCL-VBBQ-055]	B054269	1000	10.0	06/29/12	

Prep Method: SW-846 3540C-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [Wipe]	Final [mL]	Date
12F0964-09 [KCL-VWP-044]	B054234	1.00	10.0	06/28/12
12F0964-10 [KCL-VWP-045]	B054234	1.00	10.0	06/28/12
12F0964-11 [KCL-VWP-046]	B054234	1.00	10.0	06/28/12



QUALITY CONTROL

Polychlorinated Biphenyls By GC/ECD - Quality Control

Blank (Bio\$4269-BLK1) Prepared & Analyzed: 06/29/12			
Arcolor-1016 ND 0.20 μg/L Arcolor-1016 [2C] ND 0.20 μg/L Arcolor-1221 ND 0.20 μg/L Arcolor-1221 [2C] ND 0.20 μg/L Arcolor-1221 [2C] ND 0.20 μg/L Arcolor-1232 ND 0.20 μg/L Arcolor-1232 [2C] ND 0.20 μg/L Arcolor-1242 ND 0.20 μg/L Arcolor-1242 ND 0.20 μg/L Arcolor-1242 ND 0.20 μg/L Arcolor-1248 ND 0.20 μg/L Arcolor-1248 ND 0.20 μg/L Arcolor-1248 [2C] ND 0.20 μg/L Arcolor-1248 [2C] ND 0.20 μg/L Arcolor-1248 [2C] ND 0.20 μg/L Arcolor-1254 ND 0.20 μg/L Arcolor-1254 ND 0.20 μg/L Arcolor-1254 [2C] ND 0.20 μg/L Arcolor-1260 [2C] ND 0.20 μg/L Arcolor-1260 [2C] ND 0.20 μg/L Arcolor-1260 [2C] ND 0.20 μg/L Arcolor-1262 ND 0.20 μg/L Arcolor-1262 [2C] ND 0.20 μg/L Arcolor-1262 [2C] ND 0.20 μg/L Arcolor-1268 ND 0.20 μg/L 0.00 73.6 30-150 Arcolor-1260 ND 0.44 0.20 μg/L 0.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Arcolor-1016 (0.44 0.20 μg/L 0.500 84.8 40-140 Arcolor-1016 (CC) 0.38 0.20 μg/L 0.500 75.0 40-140 Arcolor-1260 (CC) 0.38 0.20 μg/L 0.500 75.0 40-140 Arcolor-1260 (CC) 0.38 0.20 μg/L 0.500 75.0 40-140 Arcolor-1260 (CC) 0.38 0.20 μg/L 0.500 75.0 40-140			
Arcolor-1016 [2C] ND 0.20 μg/L Arcolor-1221 [2C] ND 0.20 μg/L Arcolor-1221 [2C] ND 0.20 μg/L Arcolor-1232 [2C] ND 0.20 μg/L Arcolor-1242 [2C] ND 0.20 μg/L Arcolor-1242 [2C] ND 0.20 μg/L Arcolor-1248 [2C] ND 0.20 μg/L Arcolor-1254 [2C] ND 0.20 μg/L Arcolor-1260 [2C] ND 0.20 μg/L Arcolor-1260 [2C] ND 0.20 μg/L Arcolor-1262 [2C] ND 0.20 μg/L Arcolor-1262 [2C] ND 0.20 μg/L Arcolor-1268 [2C] ND 0.20 μg/L Arcolor-1268 [2C] ND 0.20 μg/L Surrogate: Decac			
Arcolor-1221 [2C] ND 0.20 μg/L Arcolor-1221 [2C] ND 0.20 μg/L Arcolor-1232 (2C) ND 0.20 μg/L Arcolor-1242 (2C) ND 0.20 μg/L Arcolor-1242 [2C] ND 0.20 μg/L Arcolor-1248 (2C) ND 0.20 μg/L Arcolor-1248 [2C] ND 0.20 μg/L Arcolor-1254 (2C) ND 0.20 μg/L Arcolor-1260 (2C) ND 0.20 μg/L Arcolor-1260 (2C) ND 0.20 μg/L Arcolor-1262 (2C) ND 0.20 μg/L Arcolor-1268 (2C) ND 0.20 μg/L Arcolor-1268 (2C) ND 0.20 μg/L Surrogate: Decachlorobiphenyl (2C) 1.28 μg/L 2.00 73.6			
Arcolor-1221 [2C] ND 0.20 µg/L Arcolor-1232 [2C] ND 0.20 µg/L Arcolor-1232 [2C] ND 0.20 µg/L Arcolor-1242 [2C] ND 0.20 µg/L Arcolor-1242 [2C] ND 0.20 µg/L Arcolor-1248 ND 0.20 µg/L Arcolor-1248 ND 0.20 µg/L Arcolor-1248 ND 0.20 µg/L Arcolor-1254 [2C] ND 0.20 µg/L Arcolor-1260 ND 0.20 µg/L Arcolor-1260 [2C] ND 0.20 µg/L Arcolor-1262 [2C] ND 0.20 µg/L Arcolor-1262 [2C] ND 0.20 µg/L Arcolor-1262 [2C] ND 0.20 µg/L Arcolor-1268 ND 0.20 µg/L Arcolor-1268 [2C] ND 0.20 µg/L 0.500 88.7 30-150 Burrogate: Tetrachloro-m-xylene [2C] 1.48 Prepared & Analyzed: 06/29/12 Arcolor-1016 [2C] 0.42 0.20 µg/L 0.500 88.7 40-140 Arcolor-1016 [2C] 0.42 0.20 µg/L 0.500 88.8 40-140 Arcolor-1260 0.35 0.20 µg/L 0.500 71.0 40-140 Arcolor-1260 [2C] 0.38 0.20 µg/L 0.500 75.0 40-140 Arcolor-1260 [2C] 0.38 0.20 µg/L 0.500 75.0 40-140 Arcolor-1260 [2C] 0.38 0.20 µg/L 0.500 75.0 40-140			
Aroclor-1232 [2C] ND 0.20 μg/L Aroclor-1242 [2C] ND 0.20 μg/L Aroclor-1242 [2C] ND 0.20 μg/L Aroclor-1242 [2C] ND 0.20 μg/L Aroclor-1248 ND 0.20 μg/L Aroclor-1248 [2C] ND 0.20 μg/L Aroclor-1248 [2C] ND 0.20 μg/L Aroclor-1248 [2C] ND 0.20 μg/L Aroclor-1254 [2C] ND 0.20 μg/L Aroclor-1260 [2C] ND 0.20 μg/L Aroclor-1260 [2C] ND 0.20 μg/L Aroclor-1260 [2C] ND 0.20 μg/L Aroclor-1262 [2C] ND 0.20 μg/L Aroclor-1268 ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Aroclor-1260 [2C] 1.48 μg/L 0.00 64.0 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 84.8 40-140 Aroclor-1260 [2C] 0.35 0.20 μg/L 0.500 75.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140			
Aroclor-1232 [2C] ND 0.20 µg/L Aroclor-1242 (1C) ND 0.20 µg/L Aroclor-1242 [2C] ND 0.20 µg/L Aroclor-1248 (1C) ND 0.20 µg/L Aroclor-1248 (1C) ND 0.20 µg/L Aroclor-1248 (1C) ND 0.20 µg/L Aroclor-1254 [2C] ND 0.20 µg/L Aroclor-1254 [2C] ND 0.20 µg/L Aroclor-1254 [2C] ND 0.20 µg/L Aroclor-1256 [2C] ND 0.20 µg/L Aroclor-1260 (1C) ND 0.20 µg/L Aroclor-1260 [2C] ND 0.20 µg/L Aroclor-1262 (1C) ND 0.20 µg/L Aroclor-1268 (1C) ND 0.20 µg/L 0.00 73.6 30-150 Surrogate: Tetrachloro-m-xylene (1C) 1.28 µg/L 0.00 73.9 30-150 LCS (8054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 (1C) 0.44 0.20 µg/L 0.500 88.7 40-140 Aroclor-1260 (1C) 0.35 0.20 µg/L 0.500 71.0 40-140 Aroclor-1260 (1C) 0.38 0.20 µg/L 0.500 75.0 40-140 Aroclor-1260 (1C) 0.38 0.20 µg/L 0.500 75.0 40-140 Aroclor-1260 (1C) 0.38 0.20 µg/L 0.500 75.0 40-140			
Arcolor-1242 ND 0.20			
Aroclor-1242 [2C] ND 0.20 µg/L Aroclor-1248 ND 0.20 µg/L Aroclor-1248 [2C] ND 0.20 µg/L Aroclor-1254 ND 0.20 µg/L Aroclor-1254 [2C] ND 0.20 µg/L Aroclor-1260 [2C] ND 0.20 µg/L Aroclor-1260 [2C] ND 0.20 µg/L Aroclor-1262 [2C] ND 0.20 µg/L Aroclor-1262 [2C] ND 0.20 µg/L Aroclor-1268 ND 0.20 µg/L Aroclor-1268 [2C] ND 0.20 µg/L Aroclor-1268 [2C] ND 0.20 µg/L Aroclor-1268 [2C] ND 0.20 µg/L Aroclor-1268 ND 0.20 µg/L Aroclor-1268 [2C] ND 0.20 µg/L Surrogate: Decachlorobiphenyl [2C] 1.28 µg/L 2.00 73.6 30-150 Surrogate: Decachlorobiphenyl [2C] 1.28 µg/L 2.00 73.9 30-150 Surrogate: Tetrachloro-m-xylene 1.42 µg/L 2.00 73.9 30-150 LCS (B054269-BSI) Prepared & Analyzed: 06/29/12 Aroclor-1016 [2C] 0.42 0.20 µg/L 0.500 88.7 40-140 Aroclor-1260 [2C] 0.38 0.20 µg/L 0.500 75.0 40-140			
Aroclor-1248 ND 0.20 μg/L Aroclor-1248 [2C] ND 0.20 μg/L Aroclor-1254 ND 0.20 μg/L Aroclor-1254 [2C] ND 0.20 μg/L Aroclor-1260 [2C] ND 0.20 μg/L Aroclor-1260 [2C] ND 0.20 μg/L Aroclor-1262 [2C] ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Surrogate: Decachlorobiphenyl 1.47 μg/L 2.00 73.6 30-150 Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 71.1 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 88.7 40-140 Aroc			
Aroclor-1248 [2C] ND 0.20 μg/L Aroclor-1254 ND 0.20 μg/L Aroclor-1254 [2C] ND 0.20 μg/L Aroclor-1260 ND 0.20 μg/L Aroclor-1260 [2C] ND 0.20 μg/L Aroclor-1260 [2C] ND 0.20 μg/L Aroclor-1262 ND 0.20 μg/L Aroclor-1262 [2C] ND 0.20 μg/L Aroclor-1262 [2C] ND 0.20 μg/L Aroclor-1268 ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 73.6 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 71.1 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1260 [2C] 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl			
Aroclor-1254 ND 0.20 μg/L Aroclor-1254 [2C] ND 0.20 μg/L Aroclor-1260 ND 0.20 μg/L Aroclor-1260 [2C] ND 0.20 μg/L Aroclor-1262 ND 0.20 μg/L Aroclor-1262 [2C] ND 0.20 μg/L Aroclor-1262 [2C] ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 73.6 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 64.0 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 88.7 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140			
Aroclor-1254 [2C] ND 0.20 μg/L Aroclor-1260 ND 0.20 μg/L Aroclor-1260 [2C] ND 0.20 μg/L Aroclor-1262 [2C] ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Surrogate: Decachlorobiphenyl 1.47 μg/L 2.00 73.6 30-150 Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 64.0 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 73.6 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140			
Aroclor-1260 ND 0.20 μg/L Aroclor-1260 [2C] ND 0.20 μg/L Aroclor-1262 ND 0.20 μg/L Aroclor-1262 [2C] ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Surrogate: Decachlorobiphenyl 1.47 μg/L 2.00 73.6 30-150 Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 64.0 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 71.1 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 75.0 40-140 Arroglare: Decachlorobiphenyl 1.59 μg/L 2.00 79.5<			
Aroclor-1260 [2C] ND 0.20 μg/L Aroclor-1262 ND 0.20 μg/L Aroclor-1262 [2C] ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Surrogate: Decachlorobiphenyl 1.47 μg/L 2.00 73.6 30-150 Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 64.0 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 73.9 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500			
Aroclor-1262 ND 0.20 μg/L Aroclor-1262 [2C] ND 0.20 μg/L Aroclor-1268 ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Surrogate: Decachlorobiphenyl 1.47 μg/L 2.00 73.6 30-150 Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 64.0 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 71.1 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150 <td></td> <td></td> <td></td>			
Aroclor-1262 [2C] ND 0.20 μg/L Aroclor-1268 ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Surrogate: Decachlorobiphenyl 1.47 μg/L 2.00 73.6 30-150 Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 64.0 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 71.1 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
Aroclor-1268 ND 0.20 μg/L Aroclor-1268 [2C] ND 0.20 μg/L Surrogate: Decachlorobiphenyl 1.47 μg/L 2.00 73.6 30-150 Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 64.0 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 71.1 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 84.8 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 75.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
Aroclor-1268 [2C] ND 0.20 μg/L 2.00 73.6 30-150 Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 64.0 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 71.1 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 84.8 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
Surrogate: Decachlorobiphenyl 1.47 μg/L 2.00 73.6 30-150 Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 64.0 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 71.1 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 84.8 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
Surrogate: Decachlorobiphenyl [2C] 1.28 μg/L 2.00 64.0 30-150 Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 71.1 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 84.8 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
Surrogate: Tetrachloro-m-xylene 1.42 μg/L 2.00 71.1 30-150 Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 84.8 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
Surrogate: Tetrachloro-m-xylene [2C] 1.48 μg/L 2.00 73.9 30-150 LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 84.8 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
LCS (B054269-BS1) Prepared & Analyzed: 06/29/12 Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 84.8 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
Aroclor-1016 0.44 0.20 μg/L 0.500 88.7 40-140 Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 84.8 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
Aroclor-1016 [2C] 0.42 0.20 μg/L 0.500 84.8 40-140 Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
Aroclor-1260 0.35 0.20 μg/L 0.500 71.0 40-140 Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
Aroclor-1260 [2C] 0.38 0.20 μg/L 0.500 75.0 40-140 Surrogate: Decachlorobiphenyl 1.59 μg/L 2.00 79.5 30-150			
Surrogate: Decachlorobiphenyl 1.59 µg/L 2.00 79.5 30-150			
Surrogate: Descablershiphanyl [20] 1.41 ug/L 2.00 70.2 20.150			
Surrogate. Decacinototophenyi [2C] 1.41 µg/L 2.00 /0.5 50-150			
Surrogate: Tetrachloro-m-xylene 1.42 µg/L 2.00 71.0 $30-150$			
Surrogate: Tetrachloro-m-xylene [2C] 1.47 µg/L 2.00 73.4 $30-150$			
LCS Dup (B054269-BSD1) Prepared & Analyzed: 06/29/12			
Aroclor-1016 0.49 0.20 μg/L 0.500 97.6 40-140	9.62	20	
	10.2	20	
Aroclor-1260 0.41 0.20 μg/L 0.500 82.7 40-140	15.3	20	
	13.6	20	
Surrogate: Decachlorobiphenyl 1.65 μg/L 2.00 82.4 30-150			
Surrogate: Decachlorobiphenyl [2C] 1.46 μg/L 2.00 73.0 30-150			
Surrogate: Tetrachloro-m-xylene $I.52$ µg/L 2.00 76.0 $30-150$			
Surrogate: Tetrachloro-m-xylene [2C] 1.58 μg/L 2.00 79.0 30-150			



QUALITY CONTROL

Polychlorinated Biphenyls with 3540 Soxhlet Extraction - Quality Control

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B054234 - SW-846 3540C										
Blank (B054234-BLK1)				Prepared: 06	5/28/12 Anal	yzed: 06/29/	12			
Aroclor-1016	ND	0.20	μg/Wipe							
Aroclor-1016 [2C]	ND	0.20	μg/Wipe							
Aroclor-1221	ND	0.20	μg/Wipe							
Aroclor-1221 [2C]	ND	0.20	μg/Wipe							
Aroclor-1232	ND	0.20	μg/Wipe							
Aroclor-1232 [2C]	ND	0.20	μg/Wipe							
Aroclor-1242	ND	0.20	μg/Wipe							
Aroclor-1242 [2C]	ND	0.20	μg/Wipe							
Aroclor-1248	ND	0.20	μg/Wipe							
Aroclor-1248 [2C]	ND	0.20	μg/Wipe							
Aroclor-1254	ND	0.20	μg/Wipe							
Aroclor-1254 [2C]	ND	0.20	μg/Wipe							
Aroclor-1260	ND	0.20	μg/Wipe							
Aroclor-1260 [2C]	ND	0.20	μg/Wipe							
Aroclor-1262	ND	0.20	μg/Wipe							
Aroclor-1262 [2C]	ND	0.20	μg/Wipe							
Aroclor-1268	ND	0.20	μg/Wipe							
Aroclor-1268 [2C]	ND	0.20	μg/Wipe							
Surrogate: Decachlorobiphenyl	2.71		μg/Wipe	2.00		136	30-150			
Surrogate: Decachlorobiphenyl [2C]	2.45		μg/Wipe	2.00		122	30-150			
Surrogate: Tetrachloro-m-xylene	2.37		μg/Wipe	2.00		119	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	2.47		$\mu g/Wipe$	2.00		124	30-150			
LCS (B054234-BS1)				Prepared: 06	5/28/12 Anal	yzed: 06/29/	12			
Aroclor-1016	0.42	0.20	μg/Wipe	0.500		84.6	40-140			
Aroclor-1016 [2C]	0.42	0.20	μg/Wipe	0.500		84.7	40-140			
Aroclor-1260	0.41	0.20	μg/Wipe	0.500		81.8	40-140			
Aroclor-1260 [2C]	0.43	0.20	$\mu g/Wipe$	0.500		85.1	40-140			
Surrogate: Decachlorobiphenyl	1.80		μg/Wipe	2.00		90.1	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.61		μg/Wipe	2.00		80.6	30-150			
Surrogate: Tetrachloro-m-xylene	1.44		μg/Wipe	2.00		72.1	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	1.50		$\mu g/Wipe$	2.00		75.1	30-150			
LCS Dup (B054234-BSD1)				Prepared: 06	5/28/12 Anal	yzed: 06/29/	12			
Aroclor-1016	0.53	0.20	μg/Wipe	0.500		106	40-140	22.3	30	
Aroclor-1016 [2C]	0.52	0.20	μg/Wipe	0.500		105	40-140	21.0	30	
Aroclor-1260	0.51	0.20	μg/Wipe	0.500		101	40-140	21.4	30	
Aroclor-1260 [2C]	0.53	0.20	μg/Wipe	0.500		107	40-140	22.7	30	
Surrogate: Decachlorobiphenyl	2.23		μg/Wipe	2.00		112	30-150			
Surrogate: Decachlorobiphenyl [2C]	2.00		μg/Wipe	2.00		100	30-150			
Surrogate: Tetrachloro-m-xylene	1.85		μg/Wipe	2.00		92.5	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	1.93		μg/Wipe	2.00		96.5	30-150			



QUALITY CONTROL

Polychlorinated Biphenyls with 3540 Soxhlet Extraction - Quality Control

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B054247 - SW-846 3540C										
Blank (B054247-BLK1)				Prepared: 06	/28/12 Anal	yzed: 07/03/	12			
Aroclor-1016	ND	0.20	mg/Kg							
Aroclor-1016 [2C]	ND	0.20	mg/Kg							
Aroclor-1221	ND	0.20	mg/Kg							
Aroclor-1221 [2C]	ND	0.20	mg/Kg							
Aroclor-1232	ND	0.20	mg/Kg							
Aroclor-1232 [2C]	ND	0.20	mg/Kg							
Aroclor-1242	ND	0.20	mg/Kg							
Aroclor-1242 [2C]	ND	0.20	mg/Kg							
Aroclor-1248	ND	0.20	mg/Kg							
Aroclor-1248 [2C]	ND	0.20	mg/Kg							
Aroclor-1254	0.77	0.20	mg/Kg							
Aroclor-1254 [2C]	0.87	0.20	mg/Kg							
Aroclor-1260	ND	0.20	mg/Kg							
Aroclor-1260 [2C]	ND	0.20	mg/Kg							
Aroclor-1262	ND	0.20	mg/Kg							
Aroclor-1262 [2C]	ND	0.20	mg/Kg							
Aroclor-1268	ND	0.20	mg/Kg							
Aroclor-1268 [2C]	ND	0.20	mg/Kg							
Surrogate: Decachlorobiphenyl	3.24		mg/Kg	4.00		81.0	30-150			
Surrogate: Decachlorobiphenyl [2C]	3.81		mg/Kg	4.00		95.2	30-150			
Surrogate: Tetrachloro-m-xylene	3.83		mg/Kg	4.00		95.7	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	4.24		mg/Kg	4.00		106	30-150			
LCS (B054247-BS1)				Prepared: 06	/28/12 Anal	yzed: 07/03/	12			
Aroclor-1016	3.4	0.20	mg/Kg	4.00		84.8	40-140			
Aroclor-1016 [2C]	4.5	0.20	mg/Kg	4.00		113	40-140			V-24
Aroclor-1260	2.9	0.20	mg/Kg	4.00		73.4	40-140			
Aroclor-1260 [2C]	3.4	0.20	mg/Kg	4.00		84.5	40-140			
Surrogate: Decachlorobiphenyl	2.57		mg/Kg	4.00		64.4	30-150			
Surrogate: Decachlorobiphenyl [2C]	3.15		mg/Kg	4.00		78.7	30-150			
Surrogate: Tetrachloro-m-xylene	3.71		mg/Kg	4.00		92.7	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	3.99		mg/Kg	4.00		99.7	30-150			
LCS Dup (B054247-BSD1)				Prepared: 06	/28/12 Anal	yzed: 07/03/	12			
Aroclor-1016	3.4	0.20	mg/Kg	4.00		85.2	40-140	0.498	30	
Aroclor-1016 [2C]	4.3	0.20	mg/Kg	4.00		107	40-140	4.99	30	V-24
Aroclor-1260	2.7	0.20	mg/Kg	4.00		66.9	40-140	9.15	30	
Aroclor-1260 [2C]	3.0	0.20	mg/Kg	4.00		75.6	40-140	11.1	30	
Surrogate: Decachlorobiphenyl	1.98		mg/Kg	4.00		49.4	30-150			
Surrogate: Decachlorobiphenyl [2C]	2.40		mg/Kg	4.00		60.0	30-150			
Surrogate: Tetrachloro-m-xylene	2 67		mg/Kg	4.00		91.9	30-150			
bullogate. Tetraemolo-m-xylene	3.67		1116/112	4.00		71.7	30-130			



QUALITY CONTROL

Polychlorinated Biphenyls with 3540 Soxhlet Extraction - Quality Control

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B054248 - SW-846 3540C										
Blank (B054248-BLK1)				Prepared: 06	6/28/12 Anal	yzed: 06/30/1	2			
Aroclor-1016	ND	0.10	mg/Kg							
Aroclor-1016 [2C]	ND	0.10	mg/Kg							
Aroclor-1221	ND	0.10	mg/Kg							
Aroclor-1221 [2C]	ND	0.10	mg/Kg							
aroclor-1232	ND	0.10	mg/Kg							
aroclor-1232 [2C]	ND	0.10	mg/Kg							
aroclor-1242	ND	0.10	mg/Kg							
roclor-1242 [2C]	ND	0.10	mg/Kg							
roclor-1248	ND	0.10	mg/Kg							
aroclor-1248 [2C]	ND	0.10	mg/Kg							
aroclor-1254	ND	0.10	mg/Kg							
aroclor-1254 [2C]	ND	0.10	mg/Kg							
aroclor-1260	ND	0.10	mg/Kg							
roclor-1260 [2C]	ND	0.10	mg/Kg							
roclor-1262	ND	0.10	mg/Kg							
roclor-1262 [2C]	ND	0.10	mg/Kg							
roclor-1268	ND	0.10	mg/Kg							
roclor-1268 [2C]	ND	0.10	mg/Kg							
urrogate: Decachlorobiphenyl	1.21		mg/Kg	1.00		121	30-150			
urrogate: Decachlorobiphenyl [2C]	1.05		mg/Kg	1.00		105	30-150			
urrogate: Tetrachloro-m-xylene	0.909		mg/Kg	1.00		90.9	30-150			
urrogate: Tetrachloro-m-xylene [2C]	0.936		mg/Kg	1.00		93.6	30-150			
CS (B054248-BS1)				Prepared: 06	6/28/12 Anal	yzed: 06/30/1	2			
croclor-1016	0.26	0.10	mg/Kg	0.250		104	40-140			
roclor-1016 [2C]	0.27	0.10	mg/Kg	0.250		107	40-140			
aroclor-1260	0.28	0.10	mg/Kg	0.250		110	40-140			
roclor-1260 [2C]	0.28	0.10	mg/Kg	0.250		111	40-140			
urrogate: Decachlorobiphenyl	1.16		mg/Kg	1.00		116	30-150			
urrogate: Decachlorobiphenyl [2C]	1.02		mg/Kg	1.00		102	30-150			
urrogate: Tetrachloro-m-xylene	0.918		mg/Kg	1.00		91.8	30-150			
urrogate: Tetrachloro-m-xylene [2C]	0.949		mg/Kg	1.00		94.9	30-150			
CS Dup (B054248-BSD1)				Prepared: 06	5/28/12 Anal	yzed: 06/30/1	2			
roclor-1016	0.26	0.10	mg/Kg	0.250		103	40-140	1.21	30	
roclor-1016 [2C]	0.28	0.10	mg/Kg	0.250		111	40-140	2.83	30	
croclor-1260	0.27	0.10	mg/Kg	0.250		107	40-140	2.63	30	
aroclor-1260 [2C]	0.28	0.10	mg/Kg	0.250		111	40-140	0.305	30	
urrogate: Decachlorobiphenyl	1.11		mg/Kg	1.00		111	30-150			
urrogate: Decachlorobiphenyl [2C]	0.983		mg/Kg	1.00		98.3	30-150			
urrogate: Tetrachloro-m-xylene	0.944		mg/Kg	1.00		94.4	30-150			
urrogate: Tetrachloro-m-xylene [2C]	0.978		mg/Kg	1.00		97.8	30-150			



QUALITY CONTROL

Polychlorinated Biphenyls with 3540 Soxhlet Extraction - Quality Control

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B054542 - SW-846 3540C										
Blank (B054542-BLK1)				Prepared: 07	7/05/12 Anal	yzed: 07/06/	12			
Aroclor-1016	ND	0.20	mg/Kg							
Aroclor-1016 [2C]	ND	0.20	mg/Kg							
Aroclor-1221	ND	0.20	mg/Kg							
Aroclor-1221 [2C]	ND	0.20	mg/Kg							
Aroclor-1232	ND	0.20	mg/Kg							
Aroclor-1232 [2C]	ND	0.20	mg/Kg							
Aroclor-1242	ND	0.20	mg/Kg							
Aroclor-1242 [2C]	ND	0.20	mg/Kg							
Aroclor-1248	ND	0.20	mg/Kg							
Aroclor-1248 [2C]	ND	0.20	mg/Kg							
Aroclor-1254	ND	0.20	mg/Kg							
Aroclor-1254 [2C]	ND	0.20	mg/Kg							
Aroclor-1260	ND	0.20	mg/Kg							
Aroclor-1260 [2C]	ND	0.20	mg/Kg							
Aroclor-1262	ND	0.20	mg/Kg							
Aroclor-1262 [2C]	ND	0.20	mg/Kg							
Aroclor-1268	ND	0.20	mg/Kg							
Aroclor-1268 [2C]	ND	0.20	mg/Kg							
Surrogate: Decachlorobiphenyl	4.33		mg/Kg	4.00		108	30-150			
Surrogate: Decachlorobiphenyl [2C]	4.47		mg/Kg	4.00		112	30-150			
Surrogate: Tetrachloro-m-xylene	4.25		mg/Kg	4.00		106	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	3.98		mg/Kg	4.00		99.6	30-150			
LCS (B054542-BS1)				Prepared: 07	7/05/12 Anal	yzed: 07/06/	12			
Aroclor-1016	4.0	0.20	mg/Kg	4.00		99.4	40-140			
Aroclor-1016 [2C]	3.9	0.20	mg/Kg	4.00		98.0	40-140			V-24
Aroclor-1260	4.0	0.20	mg/Kg	4.00		100	40-140			
Aroclor-1260 [2C]	3.8	0.20	mg/Kg	4.00		94.9	40-140			V-24
Surrogate: Decachlorobiphenyl	4.40		mg/Kg	4.00		110	30-150			
Surrogate: Decachlorobiphenyl [2C]	3.83		mg/Kg	4.00		95.9	30-150			
Surrogate: Tetrachloro-m-xylene	4.28		mg/Kg	4.00		107	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	3.97		mg/Kg	4.00		99.4	30-150			
.CS Dup (B054542-BSD1)				Prepared: 07	7/05/12 Anal	yzed: 07/06/	12			
Aroclor-1016	4.4	0.20	mg/Kg	4.00		110	40-140	9.96	30	
Aroclor-1016 [2C]	4.2	0.20	mg/Kg	4.00		106	40-140	7.92	30	V-24
Aroclor-1260	4.1	0.20	mg/Kg	4.00		103	40-140	2.93	30	
Aroclor-1260 [2C]	3.9	0.20	mg/Kg	4.00		98.3	40-140	3.45	30	V-24
Surrogate: Decachlorobiphenyl	4.25		mg/Kg	4.00		106	30-150			
Surrogate: Decachlorobiphenyl [2C]	4.44		mg/Kg	4.00		111	30-150			
Surrogate: Tetrachloro-m-xylene	4.44		mg/Kg	4.00		111	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	4.18		mg/Kg	4.00		104	30-150			



FLAG/QUALIFIER SUMMARY

•	QC result is outside of established filmits.
†	Wide recovery limits established for difficult compound.
‡	Wide RPD limits established for difficult compound.
#	Data exceeded client recommended or regulatory level
	Percent recoveries and relative percent differences (RPDs) are determined by the software using values in the calculation which have not been rounded.
В	Analyte is found in the associated blank as well as in the sample.
B-07	Data is not affected by elevated level in blank since sample result is >10x level found in the blank.
O-03	Sample contains two incompletely resolved aroclors. Aroclor with the closest matching pattern is reported.
S-01	The surrogate recovery for this sample is not available due to sample dilution below the surrogate reporting limit required from high analyte concentration and/or matrix interferences.
V-24	Continuing calibration verification was outside of control limits on the confirmation column, but within control limits on the primary column. All sample results are reported from the column within control criteria.



CERTIFICATIONS

Certified Analyses included in this Report

Aroclor-1016 CT,NH,NY,ME,NC Aroclor-1221 CT,NH,NY,ME,NC Aroclor-1221 [2C] CT,NH,NY,ME,NC Aroclor-1232 CT,NH,NY,ME,NC Aroclor-1232 [2C] CT,NH,NY,ME,NC Aroclor-1242 (2C] CT,NH,NY,ME,NC Aroclor-1242 [2C] CT,NH,NY,ME,NC Aroclor-1248 (2C] CT,NH,NY,ME,NC Aroclor-1254 (2C] CT,NH,NY,ME,NC Aroclor-1254 (2C] CT,NH,NY,ME,NC Aroclor-1260 (2C] CT,NH,NY,ME,NC	Analyte	Certifications
Arcolor-1016 [ZC] CT,NE,NY,ME,NC Arcolor-1221 CC] CT,NE,NY,ME,NC Arcolor-1222 CC] CT,NE,NY,ME,NC Arcolor-1232 CT,NE,NY,ME,NC Arcolor-1232 CT,NE,NY,ME,NC Arcolor-1242 CC] CT,NE,NY,ME,NC Arcolor-1242 CC] CT,NE,NY,ME,NC Arcolor-1248 CT,NE,NY,ME,NC Arcolor-1248 CT,NE,NY,ME,NC Arcolor-1248 CT,NE,NY,ME,NC Arcolor-1249 [ZC] CT,NE,NY,ME,NC Arcolor-1240 CT,NE,NY,ME,NC Arcolor-1254 CC] CT,NE,NY,ME,NC Arcolor-1254 CC] CT,NE,NY,ME,NC Arcolor-1260 CT,NE,NY,ME,NC Arcolor-1260 CT,NE,NY,ME,NC XV-446 80824 in Water Arcolor-1260 CT,NE,NY,ME,NC,ME Arcolor-1212 CC] CT,NE,NY,ME,NC,ME Arcolor-1221 CC] CT,NE,NY,ME,NC,ME Arcolor-1221 CC] CT,NE,NY,ME,NC,ME Arcolor-1222 CC,NE,NY,ME,NC,ME Arcolor-1232 CT,NE,NY,ME,NC,ME Arcolor-1232 CT,NE,NY,ME,NC,ME Arcolor-1242 CC,NE,NY,ME,NC,ME Arcolor-1248 CC,NE,NY,ME,NC,ME Arcolor-1240 CC,NE,NY,ME,NC,ME Arcolor-1	SW-846 8082A in Product/Solid	
Arcolor-1221 CT,NH,NY,ME,NC Arcolor-1232 CT,NH,NY,ME,NC Arcolor-1232 CT,NH,NY,ME,NC Arcolor-1232 CT,NH,NY,ME,NC Arcolor-1242 CT,NH,NY,ME,NC Arcolor-1242 CT,NH,NY,ME,NC Arcolor-1248 CT,NH,NY,ME,NC Arcolor-1248 CT,NH,NY,ME,NC Arcolor-1248 CT,NH,NY,ME,NC Arcolor-1249 CT,NH,NY,ME,NC Arcolor-1240 CT,NH,NY,ME,NC Arcolor-1241 CT,NH,NY,ME,NC Arcolor-1241 CT,NH,NY,ME,NC Arcolor-1240 CT,NH,NY,ME,NC Arcolor-1240 CT,NH,NY,ME,NC Arcolor-1240 CT,NH,NY,ME,NC Arcolor-1260 CT,NH,NY,ME,NC Arcolor-1260 CT,NH,NY,ME,NC Arcolor-1260 CT,NH,NY,ME,NC Arcolor-1210 CT,NH,NY,ME,NC Arcolor-1221 CT,NH,NY,ME,NC Arcolor-1221 CT,NH,NY,ME,NC Arcolor-1232 CT,NH,NY,ME,NC Arcolor-1232 CT,NH,NY,ME,NC Arcolor-1232 CT,NH,NY,ME,NC Arcolor-1242 CT,NH,NY,ME,NC Arcolor-1242 CT,NH,NY,ME,NC Arcolor-1248 CT,NH,NY,ME,NC Arcolor-1246 CT,NH,NY,ME,NC Arcolor-1260 CT,NH,NY,ME,NC Arcolo	Aroclor-1016	CT,NH,NY,ME,NC
Aroclor-1221 [2C] CT.NH.NY.ME.NC Aroclor-1232 CC T.NH.NY.ME.NC Aroclor-1242 CC T.NH.NY.ME.NC Aroclor-1242 CC T.NH.NY.ME.NC Aroclor-1248 CC T.NH.NY.ME.NC Aroclor-1248 CC T.NH.NY.ME.NC Aroclor-1248 CC T.NH.NY.ME.NC Aroclor-1248 CC T.NH.NY.ME.NC Aroclor-1246 CC T.NH.NY.ME.NC Aroclor-1254 CC T.NH.NY.ME.NC Aroclor-1254 CC T.NH.NY.ME.NC Aroclor-1260 CT.NH.NY.ME.NC Aroclor-1260 CT.NH.NY.ME.NC Aroclor-1260 CT.NH.NY.ME.NC Aroclor-1260 CC T.NH.NY.ME.NC Aroclor-1260 CC T.NH.NY.ME.NC SW-846 80824 in Water Aroclor-1261 CC T.NH.NY.RI.NC.ME Aroclor-1221 CC T.NH.NY.RI.NC.ME Aroclor-1222 CT.NH.NY.RI.NC.ME Aroclor-1232 CC T.NH.NY.RI.NC.ME Aroclor-1232 CC T.NH.NY.RI.NC.ME Aroclor-1232 CC T.NH.NY.RI.NC.ME Aroclor-1242 CC T.NH.NY.RI.NC.ME Aroclor-1242 CC T.NH.NY.RI.NC.ME Aroclor-1245 CC T.NH.NY.RI.NC.ME Aroclor-1246 CC T.NH.NY.RI.NC.ME Aroclor-1248 CC T.NH.NY.RI.NC.ME Aroclor-1240 CC T.NH.NY.RI.NC.ME Aroclor-1250 CC T.NH.NY.RI.NC.ME Aroclor-1260 CC T.NH.NY.RI.NC.ME	Aroclor-1016 [2C]	CT,NH,NY,ME,NC
Arcolor-1232 (CT,NH,NY,ME,NC Arcolor-1232 (2C) (CT,NH,NY,ME,NC Arcolor-1242 (2C) (CT,NH,NY,ME,NC Arcolor-1242 (2C) (CT,NH,NY,ME,NC Arcolor-1248 (CT,NH,NY,ME,NC Arcolor-1248 (CT,NH,NY,ME,NC Arcolor-1248 (CT,NH,NY,ME,NC Arcolor-1254 (2C) (CT,NH,NY,ME,NC Arcolor-1254 (2C) (CT,NH,NY,ME,NC Arcolor-1254 (2C) (CT,NH,NY,ME,NC Arcolor-1260 (CT,NH,NY,ME,NC Arcolor-1260 (CT,NH,NY,ME,NC Arcolor-1260 (CT,NH,NY,ME,NC Arcolor-1260 (CT,NH,NY,ME,NC Arcolor-1260 (CT,NH,NY,ME,NC Arcolor-1210 (CT,NH,NY,ME,NC Arcolor-1211 (CT,NH,NY,RI,NC,ME Arcolor-1221 (CT,NH,NY,RI,NC,ME Arcolor-1221 (CT,NH,NY,RI,NC,ME Arcolor-1232 (CT,NH,NY,RI,NC,ME Arcolor-1232 (CT,NH,NY,RI,NC,ME Arcolor-1242 (CT,NH,NY,RI,NC,ME Arcolor-1242 (CT,NH,NY,RI,NC,ME Arcolor-1242 (CT,NH,NY,RI,NC,ME Arcolor-1248 (CT,NH,NY,RI,NC,ME Arcolor-1248 (CT,NH,NY,RI,NC,ME Arcolor-1254 (CT,NH,NY,RI,NC,ME Arcolor-1254 (CT,NH,NY,RI,NC,ME Arcolor-1254 (CT,NH,NY,RI,NC,ME Arcolor-1260 (CT	Aroclor-1221	CT,NH,NY,ME,NC
Aroclor-1232 [2C] CT,NH,NY,ME,NC Aroclor-1242 CT,NH,NY,ME,NC Aroclor-1248 CT,NH,NY,ME,NC Aroclor-1248 CT,NH,NY,ME,NC Aroclor-1248 [2C] CT,NH,NY,ME,NC Aroclor-1254 CT,NH,NY,ME,NC Aroclor-1254 CT,NH,NY,ME,NC Aroclor-1254 CT,NH,NY,ME,NC Aroclor-1260 CT,NH,NY,ME,NC Aroclor-1260 CT,NH,NY,ME,NC Aroclor-1260 CT,NH,NY,ME,NC XV-846 80824 in Water Aroclor-1016 CT,NH,NY,RI,NC,ME Aroclor-1211 CT,NH,NY,RI,NC,ME Aroclor-1221 CT,NH,NY,RI,NC,ME Aroclor-1231 CT,NH,NY,RI,NC,ME Aroclor-1232 CT,NH,NY,RI,NC,ME Aroclor-1232 CT,NH,NY,RI,NC,ME Aroclor-1232 CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME	Aroclor-1221 [2C]	CT,NH,NY,ME,NC
Arcolor-1242 CT.NH,NY,ME,NC Arcolor-1248 CT.NH,NY,ME,NC Arcolor-1248 (2C) CT.NH,NY,ME,NC Arcolor-1254 (2C) CT.NH,NY,ME,NC Arcolor-1254 (2C) CT.NH,NY,ME,NC Arcolor-1260 (2C) CT.NH,NY,ME,NC SW-846 80024 in Water SW-846 80024 in Water Arcolor-1016 [2C] CT.NH,NY,RI,NC,ME Arcolor-1221 (2C) CT.NH,NY,RI,NC,ME Arcolor-1221 (2C) CT.NH,NY,RI,NC,ME Arcolor-1232 (2C) CT.NH,NY,RI,NC,ME Arcolor-1232 (2C) CT.NH,NY,RI,NC,ME Arcolor-1242 (2C) CT.NH,NY,RI,NC,ME Arcolor-1242 (2C) CT.NH,NY,RI,NC,ME Arcolor-1248 (2C) CT.NH,NY,RI,NC,ME Arcolor-1248 (2C) CT.NH,NY,RI,NC,ME Arcolor-1254 (2C) CT.NH,NY,RI,NC,ME Arcolor-1264 (2C) CT.NH,NY,RI,NC,ME Arcolor-1260 (2C) NC Arcolor-126	Aroclor-1232	CT,NH,NY,ME,NC
Arcelor-1242 [2C] CT,NH,NY,ME,NC Arcelor-1248 CT,NH,NY,ME,NC Arcelor-1254 CT,NH,NY,ME,NC Arcelor-1254 [2C] CT,NH,NY,ME,NC Arcelor-1260 CT,NH,NY,ME,NC Arcelor-1260 [2C] CT,NH,NY,ME,NC BY 456 8082.4 in Water CT,NH,NY,RLNC,ME Arcelor-1016 CT CT,NH,NY,RLNC,ME Arcelor-1221 [2C] CT,NH,NY,RLNC,ME Arcelor-1222 CT,NH,NY,RLNC,ME CT,NH,NY,RLNC,ME Arcelor-1232 CT CT,NH,NY,RLNC,ME Arcelor-1232 (2C] CT,NH,NY,RLNC,ME Arcelor-1242 CT CT,NH,NY,RLNC,ME Arcelor-1242 (2C] CT,NH,NY,RLNC,ME Arcelor-1242 (2C] CT,NH,NY,RLNC,ME Arcelor-1248 (2C] CT,NH,NY,RLNC,ME Arcelor-1248 (2C] CT,NH,NY,RLNC,ME Arcelor-1254 (2C] CT,NH,NY,RLNC,ME Arcelor-1264 (2C] CT,NH,NY,RLNC,ME Arcelor-1262 (2C] CT,NH,NY,RLNC,ME Arcelor-1262 (2C] CT,NH,NY,RLNC,ME Arcelor-1262 (2C] NC Arcelor-1268 (2C] NC Arcelor-1268 (2C] NC	Aroclor-1232 [2C]	CT,NH,NY,ME,NC
Arcolor-1248 CT,NH,NY,ME,NC Arcolor-1254 (2C) CT,NH,NY,ME,NC Arcolor-1254 (2C) CT,NH,NY,ME,NC Arcolor-1260 (2C) CT,NH,NY,ME,NC Arcolor-1260 (2C) CT,NH,NY,ME,NC SW-846 89824 in Water CT,NH,NY,RI,NC,ME Arcolor-1016 (2C) CT,NH,NY,RI,NC,ME Arcolor-1221 (2C) CT,NH,NY,RI,NC,ME Arcolor-1232 (2C) CT,NH,NY,RI,NC,ME Arcolor-1232 (2C) CT,NH,NY,RI,NC,ME Arcolor-1232 (2C) CT,NH,NY,RI,NC,ME Arcolor-1242 (2C) CT,NH,NY,RI,NC,ME Arcolor-1242 (2C) CT,NH,NY,RI,NC,ME Arcolor-1242 (2C) CT,NH,NY,RI,NC,ME Arcolor-1248 (2C) CT,NH,NY,RI,NC,ME Arcolor-1248 (2C) CT,NH,NY,RI,NC,ME Arcolor-1248 (2C) CT,NH,NY,RI,NC,ME Arcolor-1249 (2C) CT,NH,NY,RI,NC,ME Arcolor-1260 (2C) CT,NH,NY,RI,NC,ME Arcolor-1260 (2C) CT,NH,NY,RI,NC,ME Arcolor-1262 (2C) NC Arcolor-1268 (2C) NC Arcolor-1268 (2C) NC	Aroclor-1242	CT,NH,NY,ME,NC
Arcolor-1248 [2C] CT,NH,NY,ME,NC Arcolor-1254 (2C] CT,NH,NY,ME,NC Arcolor-1260 (2C] CT,NH,NY,ME,NC Arcolor-1260 [2C] CT,NH,NY,ME,NC SW-946 80824 in Water Water Arcolor-1016 (2C] CT,NH,NY,RL,NC,ME Arcolor-1016 [2C] CT,NH,NY,RL,NC,ME Arcolor-1221 (2C] CT,NH,NY,RL,NC,ME Arcolor-1232 (2C] CT,NH,NY,RL,NC,ME Arcolor-1232 [2C] CT,NH,NY,RL,NC,ME Arcolor-1242 [2C] CT,NH,NY,RL,NC,ME Arcolor-1242 [2C] CT,NH,NY,RL,NC,ME Arcolor-1242 [2C] CT,NH,NY,RL,NC,ME Arcolor-1248 (2C] CT,NH,NY,RL,NC,ME Arcolor-1248 (2C] CT,NH,NY,RL,NC,ME Arcolor-1249 [2C] CT,NH,NY,RL,NC,ME Arcolor-1244 [2C] CT,NH,NY,RL,NC,ME Arcolor-1254 (2C] CT,NH,NY,RL,NC,ME Arcolor-1260 (2C] CT,NH,NY,RL,NC,ME Arcolor-1261 [2C] CT,NH,NY,RL,NC,ME Arcolor-1262 (2C] NC Arcolor-1262 (2C] NC Arcolor-1262 (2C] NC Arcolor-1268 (2C) NC <td>Aroclor-1242 [2C]</td> <td>CT,NH,NY,ME,NC</td>	Aroclor-1242 [2C]	CT,NH,NY,ME,NC
Arcelor-1254 (2C) CT,NH,NY,ME,NC Arcelor-1260 CT,NH,NY,ME,NC Arcelor-1260 (2C) CT,NH,NY,ME,NC SW-846 8082A in Water Arcelor-1016 CT,NH,NY,RI,NC,ME Arcelor-1210 (2C) CT,NH,NY,RI,NC,ME Arcelor-1221 (2C) CT,NH,NY,RI,NC,ME Arcelor-1221 (2C) CT,NH,NY,RI,NC,ME Arcelor-1222 (2C) CT,NH,NY,RI,NC,ME Arcelor-1232 CT,NH,NY,RI,NC,ME Arcelor-1242 CT,NH,NY,RI,NC,ME Arcelor-1242 CT,NH,NY,RI,NC,ME Arcelor-1248 CT,NH,NY,RI,NC,ME Arcelor-1248 CT,NH,NY,RI,NC,ME Arcelor-1248 (2C) CT,NH,NY,RI,NC,ME Arcelor-1248 (2C) CT,NH,NY,RI,NC,ME Arcelor-1248 (2C) CT,NH,NY,RI,NC,ME Arcelor-1248 (2C) CT,NH,NY,RI,NC,ME Arcelor-1240 (2C) CT,NH,NY,RI,NC,ME Arcelor-1250 (2C) CT,NH,NY,RI,NC,ME Arcelor-1260 CT,NH,NY,RI,NC,ME Arcelor-1262 NC Arcelor-1262 NC Arcelor-1262 NC Arcelor-1268 NC	Aroclor-1248	CT,NH,NY,ME,NC
Arcelor-1254 [2C] CT,NH,NY,ME,NC Arcelor-1260 [2C] CT,NH,NY,ME,NC SW-846 8082A in Water SW-846 8082A in Water Arcelor-1016 CT,NH,NY,RI,NC,ME Arcelor-1016 [2C] CT,NH,NY,RI,NC,ME Arcelor-1221 [2C] CT,NH,NY,RI,NC,ME Arcelor-1232 [2C] CT,NH,NY,RI,NC,ME Arcelor-1232 [2C] CT,NH,NY,RI,NC,ME Arcelor-1242 [2C] CT,NH,NY,RI,NC,ME Arcelor-1242 [2C] CT,NH,NY,RI,NC,ME Arcelor-1248 [2C] CT,NH,NY,RI,NC,ME Arcelor-1248 [2C] CT,NH,NY,RI,NC,ME Arcelor-1254 [2C] CT,NH,NY,RI,NC,ME Arcelor-1254 [2C] CT,NH,NY,RI,NC,ME Arcelor-1264 [2C] CT,NH,NY,RI,NC,ME Arcelor-1260 [2C] CT,NH,NY,RI,NC,ME Arcelor-1260 [2C] CT,NH,NY,RI,NC,ME Arcelor-1262 [2C] NC Arcelor-1268 [2C] NC Arcelor-1268 [2C] NC Arcelor-1268 [2C] NC	Aroclor-1248 [2C]	CT,NH,NY,ME,NC
Aroclor-1260 CT,NH,NY,ME,NC SW-846 8082A in Water Aroclor-1016 CT,NH,NY,RI,NC,ME Aroclor-1016 CT,NH,NY,RI,NC,ME Aroclor-1221 CT,NH,NY,RI,NC,ME Aroclor-1221 CT,NH,NY,RI,NC,ME Aroclor-1232 CT,NH,NY,RI,NC,ME Aroclor-1232 CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1262 NC Aroclor-1262 NC Aroclor-1268 NC	Aroclor-1254	CT,NH,NY,ME,NC
Arcolor-1260 [2C] CT,NH,NY,ME,NC 5W-846 8082A in Water Arcolor-1016 CT,NH,NY,RI,NC,ME Arcolor-1016 [2C] CT,NH,NY,RI,NC,ME Arcolor-1221 CT,NH,NY,RI,NC,ME Arcolor-1232 CT,NH,NY,RI,NC,ME Arcolor-1232 CT,NH,NY,RI,NC,ME Arcolor-1232 [2C] CT,NH,NY,RI,NC,ME Arcolor-1242 CT,NH,NY,RI,NC,ME Arcolor-1242 CT,NH,NY,RI,NC,ME Arcolor-1248 CT,NH,NY,RI,NC,ME Arcolor-1248 CT,NH,NY,RI,NC,ME Arcolor-1254 [2C] CT,NH,NY,RI,NC,ME Arcolor-1254 CT,NH,NY,RI,NC,ME Arcolor-1254 CT,NH,NY,RI,NC,ME Arcolor-1260 CT,NH,NY,RI,NC,ME Arcolor-1260 CT,NH,NY,RI,NC,ME Arcolor-1260 CT,NH,NY,RI,NC,ME Arcolor-1262 NC Arcolor-1262 [2C] NC Arcolor-1268 NC	Aroclor-1254 [2C]	CT,NH,NY,ME,NC
Aroclor-1016 CT,NH,NY,RI,NC,ME Aroclor-1016 [2C] CT,NH,NY,RI,NC,ME Aroclor-1221 CT,NH,NY,RI,NC,ME Aroclor-1221 CT,NH,NY,RI,NC,ME Aroclor-1232 CT,NH,NY,RI,NC,ME Aroclor-1232 CT,NH,NY,RI,NC,ME Aroclor-1232 (CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1254 (CT,NH,NY,RI,NC,ME Aroclor-1254 (CT,NH,NY,RI,NC,ME Aroclor-1254 (CT,NH,NY,RI,NC,ME Aroclor-1256 (CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1260 (CT,NH,NY,RI,NC,ME Aroclor-1262 (CT,NH,NY,RI,NC,ME Aroclor-1262 (CT,NH,NY,RI,NC,ME Aroclor-1262 (CT,NH,NY,RI,NC,ME Aroclor-1263 (CT,NH,NY,RI,NC,ME Aroclor-1264 (CT,NH,NY,RI,NC,ME Aroclor-1265 (CT,NH,NY,RI,NC,ME Aroclor-1266 (CT,NH,NY,RI,NC,ME Aroclor-1268 (CT,NH,NY,RI,NC,ME	Aroclor-1260	CT,NH,NY,ME,NC
Aroclor-1016 CT,NH,NY,RI,NC,ME Aroclor-1221 CT,NH,NY,RI,NC,ME Aroclor-1221 [2C] CT,NH,NY,RI,NC,ME Aroclor-1232 CT,NH,NY,RI,NC,ME Aroclor-1232 [2C] CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1242 [2C] CT,NH,NY,RI,NC,ME Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 [2C] NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1260 [2C]	CT,NH,NY,ME,NC
Aroclor-1016 [2C] CT,NH,NY,RI,NC,ME Aroclor-1221 CT,NH,NY,RI,NC,ME Aroclor-1221 [2C] CT,NH,NY,RI,NC,ME Aroclor-1232 [2C] CT,NH,NY,RI,NC,ME Aroclor-1242 [2C] CT,NH,NY,RI,NC,ME Aroclor-1242 [2C] CT,NH,NY,RI,NC,ME Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 [2C] NC Aroclor-1262 [2C] NC Aroclor-1262 [2C] NC Aroclor-1268 NC	SW-846 8082A in Water	
Aroclor-1221 CT,NH,NY,RI,NC,ME Aroclor-1221 [2C] CT,NH,NY,RI,NC,ME Aroclor-1232 [2C] CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1242 [2C] CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1016	CT,NH,NY,RI,NC,ME
Aroclor-1221 [2C] CT,NH,NY,RI,NC,ME Aroclor-1232 CT,NH,NY,RI,NC,ME Aroclor-1232 [2C] CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1016 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1232 CT,NH,NY,RI,NC,ME Aroclor-1232 [2C] CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1242 [2C] CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 [2C] NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1221	CT,NH,NY,RI,NC,ME
Aroclor-1232 [2C] CT,NH,NY,RI,NC,ME Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1242 [2C] CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 NC Aroclor-1262 NC Aroclor-1268 NC	Aroclor-1221 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1242 CT,NH,NY,RI,NC,ME Aroclor-1242 [2C] CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1232	CT,NH,NY,RI,NC,ME
Aroclor-1242 [2C] CT,NH,NY,RI,NC,ME Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1232 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1248 CT,NH,NY,RI,NC,ME Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1242	CT,NH,NY,RI,NC,ME
Aroclor-1248 [2C] CT,NH,NY,RI,NC,ME Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1242 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1254 CT,NH,NY,RI,NC,ME Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1248	CT,NH,NY,RI,NC,ME
Aroclor-1254 [2C] CT,NH,NY,RI,NC,ME Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1248 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1260 CT,NH,NY,RI,NC,ME Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1254	CT,NH,NY,RI,NC,ME
Aroclor-1260 [2C] CT,NH,NY,RI,NC,ME Aroclor-1262 NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1254 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1262 NC Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1260	CT,NH,NY,RI,NC,ME
Aroclor-1262 [2C] NC Aroclor-1268 NC	Aroclor-1260 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1268 NC	Aroclor-1262	NC
	Aroclor-1262 [2C]	NC
Aroclor-1268 [2C] NC	Aroclor-1268	NC
	Aroclor-1268 [2C]	NC



The CON-TEST Environmental Laboratory operates under the following certifications and accreditations:

Code	Description	Number	Expires
AIHA	AIHA-LAP, LLC	100033	02/1/2014
MA	Massachusetts DEP	M-MA100	06/30/2013
CT	Connecticut Department of Publilc Health	PH-0567	09/30/2013
NY	New York State Department of Health	10899 NELAP	04/1/2013
NH	New Hampshire Environmental Lab	2516 NELAP	02/5/2013
RI	Rhode Island Department of Health	LAO00112	12/30/2012
NC	North Carolina Div. of Water Quality	652	12/31/2012
NJ	New Jersey DEP	MA007 NELAP	06/30/2013
FL	Florida Department of Health	E871027 NELAP	06/30/2013
VT	Vermont Department of Health Lead Laboratory	LL015036	07/30/2012
WA	State of Washington Department of Ecology	C2065	02/23/2013
ME	State of Maine	2011028	06/9/2013
VA	Commonwealth of Virginia	1381	12/14/2012

-	
-	
-	
***************************************	CONTRACTOR CONTRACTOR AND AND
	<u> </u>
amintanana a	A STATE OF THE PARTY OF THE PAR
-	
	_

-	
2	
~=1	-
- 4	
2	
_3	
(2)	
-	
-	
TICAL I	
E	
æ	-
-	

	Accredited			Manager of the second							Day	□ [†] 72-Hr □ [†] 4-Day	Date/Time:		` در	de Carled by Table 1	Hecailed by
5	NELAC & AIHA-LAP, LLC	NELAC &	00000 m 6	Companie to							¥	0 *24-Hr O *48-Hr	'	d		7/02/	Trail.
	#	Required PWSID	MA State DW Form Required PWSID #	OMA					ut.	Connecticut:	<u>-</u>	RUSH	Date/Time;		rre)	(Signature)	aysinbuiyas
			RCP Form Required	() R _C							Other 5041	17	6-27-12	8			25
	1		MCP Form Required	O ₹							_		Date/Time/			(Mahaan)	Adlparlagas
	MY-WIPE	OF RCP :	is your project MCP or RCP?	s your p					isetts:	Massachusetts:	- 1	O 7-Day	6/27/12 143	\			1 had
LKIZ	0 = other CANLKIN			rs)	y''	ments	guire	mit Re	ion Li	Detection Limit Require	#	Turnaround	Date/Time:		ure)	The same	Relingdshed
	SL = sludge	iknown	C - Clean; U - Unknown	High; M - Medium; L - Low;	1- Medi	High; N	Ŧ							S			
	A = air S = soil/solid	le Box:	y be high in concentration in Matrix/Conc. Code Box:	ncentration in	gh in co	y be hic	130	i !	Ċ	,	,						
vater	DW= drinking water	pecific sample	the following codes to let Con-Test know if a specific sample	odes to let Co	owing o	the follo	8	Please	1	37747	닛	Ė	W) SWALET	೭೪೭	VIA VISEPA	7773 V	Comments:
ter	ww=wastewater					×	C	کر	~		57 58	1 21 (gg/9)	540	しくしゃし	たい	5	. и ж
Ter .	GW= groundwater					X	C	3	1		1200	2(12)	044	- VWP- 0	KCL-	40	
				F		×	(7		(hh)	+		- VISC - 043	701	000	
sharresteckersone	o = Other			1	1	1	, -	+	۷		7	<u>.</u>		200	5	0	Control of the contro
ite	T = Na thiosulfate					×	C	S	×		438	1 <u>(対</u> (数)の	240	-BVBC-	KCL	9	
ultate Je	X = Sodium bisulfate					メ	2	S	\prec		1350	6)26/12 1	047	J-CBC-	KCL	90	
	S = Sulfuric Acid					×	C	1	2		1310	। २(६८)	OYV	CBO-	KCL-	BA	
	N = Nitric Acid			$\frac{1}{1}$	Ī	; >	7	c	{ { }		6621	+	087	1007	700	P	
	No Hotel				<u>/</u>	<		-	7		, 50	_	77 0	COV -	77	3	
	1 = lœd				4	×	C	0	×		1250	1/20/2	250	CBK -	SET.	8	
ime.	**Preservation				×	<u>ر</u>	C	0	<u> </u>		1240	1 20 (SQ	037	KC1-C8K- C	KCL	32	
	7				4	×	C	٥	7		1235	6/26/12	036	COK -	メント	(3)	
	T=tedlar bag					4/2	Dans Co			Composite	e	+	—	Client Sample ID / Description	Client	may use only)	(laborato
	S=summa can) C.		ata Packa	"Enhanced Data Package"	C "Enha	2	Collection Beginning End) - j	2	Con-Test I ah ID	Con-Te
	V= vial					<u>'</u> 3১				-			-	proposal date			O yes_
	P=plastic ST=sterile				Muz	(S	L OGIS	OEXCEL		Format	TI		Project Proposal Provided? (for billing purposes)	vided? (for	Proposal Prov	Project I
	G=glass					<u>}</u>				3 Panklin	Email: عرب		<u> </u>	TRANKLIN		Sampled By: (5E024)	Sampled
• *	***Cont. Code:) (2)						TI O		- KCL	ALE	Project Location: YALE	Project Lo
1	200)		₩ 150%)	OWEBSITE	ME G	OFAX DEMAIL	0 \$		TRANKLIN		GEORGE	Attention:
* 25		-	-		16	1			all that a	Vichork	DATA DELIVERY (check all that apply)	200				7,20010	
1					н						ant DO#	2			, ∠,	ST FINA	
	Dissolved Meta		ANALYSIS REQUESTED	ANALYS				Syo	S	22	Project#	Pr	Switte 1800	מ	. در کی	35 NE	Address: 35
ზ Pag	****Container Co					A	8150	٠.	55	978	Telephone:	7	URRAL	8	ردهه	Company Name: പ്രാസ്കര	Company
	** Preservation					Н	TO THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER	4	9	409	7	tlabs.com	www.contestlabs.com	ANALI II CAL LABORATORI	ין וועאר נ	ANAL	
4 of	# of Containers					_	N	Rey 04.05.12	Rey O		OM .	Email: info@contestlabs.com	Email: info@				ŧ
	Page of C	MA 01028	39 Spruce Street East longmeadow, MA 01028		ストのつれし	Z	GE 1	מטוטט	_	C	CHAIN	-525-2332 \-£405	^(a) Phone: 413-525-2332 Fax: 413-525-6405		Š	6	
			2 A				1						•	ì			*

INCORRECT, TURNAROUND TIME WILL NOT START UNTIL ALL QUESTIONS ARE ANSWERED BY OUR CLIENT. WHANDUND TIME STARTS AT 9:00 A.M. THE DAY AFTER SAMPLE RECEIPT UNLESS THERE ARE QUESTIONS ON YOUR CHAIN. IF THIS FORM IS NOT FILLED OUT COMPLETELY OR PLEASE BE CAREFUL NOT TO CONTAMINATE THIS DOCUMENT WBE/DBE Certified

Accredited		Anthony Company					O †72-Hr O †4-Day	, G			Racdined by/sinhatura-
NELAC & AIHA-LAP, LLC	99033V III 6	Community Community					0 [†] 24-Hr 0 [†] 48-Hr	7.	9		
WSID#	○ MA State DW Form Required PWSID#	0				Connecticut:	2	36.		rė)	Resinquished by (segnature)
	MCP Form Required RCP Form Required					4	Other SOA	Date Trape 7	K		Received by Majore)
		1				Mos samuesto.		9 14 2 6 3 9 7			
) - omer	Is your project MCP or RCP?	ls your pr	rements		imitR	Detection Limit Requ	Turnaround T	Date/Time:	e	Vē.	Relinguished by: Asignature
SL= sludge	H - High; M - Medium; L - Low; C - Clean; U - Unknown	Medium; L - Low;	ligh; M - N	I							
A = air S = soil/solid	may be high in concentration in Matrix/Conc. Code Box:	n concentration in	be high ii	may	i	(XTX+CX+	Jux Hor (X)				(3540)
nple DW= drinking wate	Please use the following codes to let Con-Test know if a specific sample	ng codes to let Co	ne followi	ase use t	Pie		- 1	 	- 1	, I	Comments: D-2
WW = wastewater			×		<u>×</u> ン)66/12/1700	-055	1884-	LC1-	20
*Matrix Code:			×	6	5	~	16/12 1650	-054 b	VBBD-054	ないし	19
			X	C	S	×	16/12/1650	153 6	- VB13-US3	Ker-	81
T = Na thiosulfate			×	2	\(\frac{\sqrt{1}}{\sqrt{2}}\)	ر	10 18 18 10	52 6	V08-052	なレーノ	[7]
8 = Sodium bisulfate X = Na hydroxide			<	C	S	2	ug) /2 \630	051	18C-	KCL	16
S = Sulfuric Acid			X	(S	~	1620 1620	050	VBC-0	KCL	18
M = Methanol			×	6	X	~	26)12 1600	9 540	VBC-C	KCL-	u
H= HC			×	C	× 5		1550	σ	ARC-OHR	KCL	ā
**preservation			Y	(1	~	26/12 1530	مل	18C-C	KCL-	7
			X	c	Ly W	×	- 1215 REP	046	VWP - 0	KCL-	
T=tedlar bag				Cons Cade	ab aban de water	Composite Grab	Beginning Ending Date/Time Date/Time	ID / Description B	mple ID / D	Client Sample	Con-Test Lab ID
S=summa can			> _C	-00 -00 -00	Data Pad	O "Enhanced Data Package"	lec				
ST=sterile			Bs	SIS	ET OGIS	O OTHER OEXCEL	Format		billing purposes) proposal date	ided? (for billi	Project Proposal Provided? (for billing purposes) O yes proposal date
G=glass			(8			ghrenin	Email: 3f	•	FRANKLIE	SEUZUE F	Sampled By: (36)
***Cont. Code:			७८-२			*			KCL	ALE !	Project Location: \(\mathcal{Y} \)
C Lab to Finer			.)		.m€	OFAX DEMAIL OWEBSITE	OFAX OF		TRANKU!		Attention: GE0126E
							Client PO#		MA		Anorra
Dissolved Meta	ANALYSIS REQUESTED	ANALYSI	<u> </u>		25540	225	Project#	DRIVE SUITE		BV5.	Address: 35 NE
****Container Cod			Z	S	5181	3 26	Telephone:	1 PLAN	5	Woodars	Company Name: \
			H	dica en conde di calendari de cole en de cole	Ų	4960J	bs.com 12	www.contestlabs.com	OKAIOKY	ANALY HOAL LABORATORY	2
# of Containers			_	7	Rev 04.05.12	Rev	Email: info@contestlabs.com	Email: info@conto			
Page of	East longmeadow, MA 01028	NECOND 59		1001000	Col		5-2332 CTAIN	Phone: 413-525-2332	<u> </u>		
	Arrive Arrive	-) 	?		_		•		

INCORRECT, TURNAROUND TIME WILL NOT START UNTIL ALL QUESTIONS ARE ANSWERED BY OUR CLIENT. Accredited

| Control of the control PLEASE BE CAREFUL NOT TO CONTAMINATE THIS DOCUMENT

39 Spruce St.
East Longmeadow, MA. 01028
P: 413-525-2332
F: 413-525-6405
www.contestlabs.com





Sample Receipt Checklist

	10 - 1 W W	B (UMOUN RE	ECEIVED BY:	<u> 10</u>	DATE: <u>_</u>	· ·
•	•	linquished and signed	l?	Yes No	No CoC	Included
Does the chain	agree with the	samples?		Yes No		
If not,	, explain:			B		
Are all the samp	<mark>ples in good co</mark> , explain:	ndition?		(Yes No		
How were the s	amples receive	d:				
n Ice 🗹	Direct from Sa	mpling 🔲 An	nbient \square	In Cooler(s)	Image: section of the	
ere the samples		nperature Compliance	of (2-6°C)?	Yes No		
-				\mathcal{O}	7 3	
emperature °C by	Temp blank	I e	emperature °C b	y Temp gun	<u>、</u> フ・, フ	
Are there Disso	lved samples fo	or the lab to filter?		Yes (No)	
	-	Date	Time			
		HOLDING TIME samp		Yes (No)	
-		Date			j	
			1	ission to subc	ontract same	oles? Yes No
		. 19	1		•	
Location where s	amples are store	a: []	11	c-in clients on		lay approved
			Clien	t Signature: _		
Do all samples	have the prope	r Acid pH: Yes No) /NXA			
			· /			
Do all samples	have the prope	r Base pH: Yes Ne	o(N/A		^	
-		•		ples: Yes	No N/A	
-	tified of any dis	r Base pH: Yes No screpancies with the Containers rece	CoC vs the sam		No N/A	outer and the second
_	tified of any dis	screpancies with the C	CoC vs the sam			# of containers
-	otified of any dis	ontainers rece	ived at Co			
) Was the PC no	otified of any dis	ontainers rece	ived at Co	on-Test amber/clear ja	ar	# of containers
1 Liter Ar 500 mL A 250 mL Amber (mber (8oz amber)	ontainers rece	8 oz 4 oz 2 oz	amber/clear jamber/clear jamber/clear ja	ar	
1 Liter Ar 500 mL A 250 mL Amber (1 Liter Pl	mber (8oz amber)	ontainers rece	8 oz 4 oz 2 oz	amber/clear jamber/clear jamber	ar ar	
1 Liter Ar 500 mL A 250 mL Amber (1 Liter Pl 500 mL P	mber (8oz amber) lastic	pntainers rece # of containers	8 oz 4 oz 2 oz Hg/h	amber/clear jamber/clear jamber	ar ar ar	
1 Liter Ar 500 mL A 250 mL Amber (1 Liter Pl 500 mL P 250 mL p	mber (8oz amber) lastic	pntainers rece # of containers	8 oz 4 oz 2 oz Hg/h	amber/clear jamber/clear jamber	ar ar ar	
1 Liter And 500 mL And 250 mL Amber (1 Liter Plus 500 mL Pus 250 mL pus 40 mL Vial - type	mber (8oz amber) lastic Plastic olastic e listed below	pntainers rece # of containers	8 oz 4 oz 2 oz Hg/h	amber/clear jamber/clear jamber	ar ar ar	
1 Liter Ar 500 mL A 250 mL Amber (1 Liter Pl 500 mL P 250 mL p 40 mL Vial - type Colisure / bact	mber (8oz amber) lastic clastic elisted below teria bottle	pntainers rece # of containers	8 oz 4 oz 2 oz Hg/h	amber/clear jamber/clear jamber	ar ar ar	
1 Liter Ar 500 mL A 250 mL Amber (1 Liter Pl 500 mL P 250 mL p 40 mL Vial - type Colisure / back	mber (8oz amber) lastic plastic e listed below teria bottle ygen bottle	pntainers rece # of containers	8 oz 4 oz 2 oz Hg/h Plas	amber/clear jamber/clear jamber	ar ar ar	
1 Liter And 500 mL And 250 mL Amber (1 Liter Plants 500 mL Plants 250 mL plants 40 mL Vial - type Colisure / back Dissolved Oxy Encore	mber (8oz amber) lastic plastic e listed below teria bottle ygen bottle	pntainers rece # of containers	8 oz 4 oz 2 oz Hg/h Plas	amber/clear jamber/clear jamber	ar ar e	
1 Liter Ar 500 mL A 250 mL Amber of 1 Liter Pl 500 mL P 250 mL p 40 mL Vial - type Colisure / back Dissolved Oxy Encor	mber (8oz amber) lastic clastic clasti	pntainers rece # of containers	8 oz 4 oz 2 oz Hg/h Plas PN Non-C	amber/clear jamber/clear jamber	ar ar e	
1 Liter Ar 500 mL A 250 mL Amber (1 Liter Pl 500 mL P 250 mL p 40 mL Vial - type Colisure / bact Dissolved Oxy Encor Flashpoint	mber Amber (8oz amber) lastic clastic clastic elisted below teria bottle ygen bottle re t bottle ate Kit	pntainers rece # of containers	8 oz 4 oz 2 oz Hg/h Plas PN Non-C	amber/clear jamber/clear jamber	ar ar e	
1 Liter Ar 500 mL A 250 mL Amber (1 Liter Pl 500 mL P 250 mL p 40 mL Vial - type Colisure / bact Dissolved Oxy Encor Flashpoint Perchlora	mber (8oz amber) lastic clastic clastic elisted below teria bottle ygen bottle re t bottle ate Kit	pntainers rece # of containers	8 oz 4 oz 2 oz Hg/h Plas PN Non-C	amber/clear jamber/clear jamber	ar ar e	
1 Liter Ar 500 mL A 250 mL Amber (1 Liter Pl 500 mL P 250 mL p 40 mL Vial - type Colisure / bact Dissolved Oxy Encor Flashpoint Perchlora Othe	mber Amber (8oz amber) lastic clastic	# of containers	8 oz 4 oz 2 oz Hg/h Plas PN Non-C	amber/clear jamber/clear jamber	ar ar e e oc	
1 Liter Ar 500 mL A 250 mL Amber of 1 Liter Pl 500 mL P 250 mL p 40 mL Vial - type Colisure / bact Dissolved Oxy Encor Flashpoint Perchlora Othe aboratory Comme	mber More (80z amber) lastic Plastic plastic plastic e listed below teria bottle re t bottle ate Kit er ents:	# Methar	8 oz 4 oz 2 oz Hg/h Plas PN Non-C	amber/clear jamber/clear jamber	ar ar e e oc	19
1 Liter Ar 500 mL A 250 mL Amber (1 Liter Pl 500 mL P 250 mL p 40 mL Vial - type Colisure / bact Dissolved Oxy Encor Flashpoint Perchlora Othe	mber Amber (8oz amber) lastic clastic	# of containers	BoC vs the same ived at Co 8 oz 4 oz 2 oz Hg/h Plas Ph Non-C	amber/clear jamber/clear jamber	ar ar e e oc	19

			RPD FOR D
12F0948-01	C-01		
Analyte	Re	esults	%RPD
Surrogates			
Tetrachloro-m-xylene	0.807	0.8367318	3.62
Decachlorobiphenyl	0.962	0.8525318	12.1
12F0964-01	KCL-CBK-03	6	
Analyte	Re	esults	%RPD
Aroclor-1254 [2C]	60	52.41921	13.5
12F0964-02	KCL-CBK-03	7	
Analyte	Re	esults	%RPD
Aroclor-1254 [2C]	61	53.42055	13.2
12F0964-03	KCL-CBK-03	8	
Analyte	Re	esults	%RPD
Aroclor-1254 [2C] Surrogates	31	27.5726	11.7
Decachlorobiphenyl	2.67	3.439858	25.2
Tetrachloro-m-xylene	3.56	4.468684	22.6
12F0964-04RE1	KCL-CBK-03	9	
Analyte	Re	esults	%RPD
Surrogates			
Decachlorobiphenyl	4.23	3.730419	12.6
Tetrachloro-m-xylene	4.13	4.073164	1.39
12F0964-05	KCL-CBB-04	0	
Analyte	Re	esults	%RPD
Surrogates			
Decachlorobiphenyl	0.994	0.8916905	10.9
Tetrachloro-m-xylene	0.863	0.8969524	3.86
12F0964-06	KCL-CBC-04	1	
Analyte	Re	esults	%RPD
Surrogates			
Decachlorobiphenyl	0.915	0.8208391	10.8
Tetrachloro-m-xylene	0.769	0.8042392	4.48
12F0964-07	KCL-VBC-04	2	
Analyte	Re	esults	%RPD
Aroclor-1254 [2C]	2.8	2.465913	12.7
Aroclor-1260 [2C]	1.7	1.744065	2.56
Surrogates	0.004	0.0000004	4.04
Tetrachloro-m-xylene Decachlorobiphenyl	0.821 1.12	0.8362391 0.9826956	1.84 13.1
12F0964-08	KCL-VBC-04	3	
Analyte	Re	esults	%RPD
Aroclor-1260	1.1	1.004904	9.04
Surrogates			
Decachlorobiphenyl	0.713	0.6333087	11.8
Tetrachloro-m-xylene	0.591	0.622987	5.27
12F0964-09	KCL-VWP-04	14	
Analyte	Re	esults	%RPD
Aroclor-1260 Surrogates	0.34	0.34198	0.581

2.35

2.05

2.17491

2.13538

7.74

4.08

Decachlorobiphenyl

Tetrachloro-m-xylene

12F0964-10	KCL-VWP-04		
Analyte	Re	sults	%RPD
Surrogates			
Decachlorobiphenyl	2.34	8.82	
Tetrachloro-m-xylene	2.04	2.11684	3.7
4250064.44	KCL VAAD 04	6	
12F0964-11			0/ DDD
Analyte	<u> </u>	Suits	%RPD
Surrogates	2.25	2.0402	9.34
Decachlorobiphenyl Tetrachloro-m-xylene	2.04	2.11835	3.77
12F0964-12	KCL-VBC-04	7	
Analyte	Re	sults	%RPD
Aroclor-1254 [2C]	0.29	0.1963238	38.5
Aroclor-1260	0.46	0.4439286	3.56
Surrogates	0.044	0.0507400	0.04
Tetrachloro-m-xylene Decachlorobiphenyl	0.914 1.20	0.9507429 1.064833	3.94 11.9
12F0964-13	KCL-VBC-04	8	
Analyte	Re	sults	%RPD
Aroclor-1254 [2C]	1.1	0.8964667	20.4
Aroclor-1260	0.36	0.3543524	1.58
Surrogates			
Decachlorobiphenyl	1.20	1.076305	10.9
Tetrachloro-m-xylene	0.946	0.9860286	4.14
12F0964-14	KCL-VBC-049	9	
Analyte	Re	sults	%RPD
Aroclor-1260	0.82	0.8094318	1.3
Aroclor-1254 [2C]	3.3	3.008954	9.23
Surrogates			
Decachlorobiphenyl	1.13	1.001455	12.1
Tetrachloro-m-xylene	0.842	0.8596818	2.08
12F0964-15	KCL-VBC-05	0	
Analyte	Re	sults	%RPD
Aroclor-1254 [2C]	1.1	0.7753909	34.6
Aroclor-1260 [2C]	0.40	0.3878727	3.08
Surrogates			
Tetrachloro-m-xylene	0.874	0.9031182	3.28
Decachlorobiphenyl	1.14	1.001764	12.9
12F0964-16	KCL-VBC-05	1	
Analyte	Re	sults	%RPD
Aroclor-1254 [2C]	3.6	3.285341	9.14
Aroclor-1260 [2C]	0.82	0.8076136	1.52
Surrogates			
Tetrachloro-m-xylene		0.9125227	0.938
Decachlorobiphenyl	1.20	1.059636	12.4
12F0964-17	KCL-VBB-052	2	
Analyte	Re	sults	%RPD
Surrogates			
Decachlorobiphenyl	1.18	1.054682	11.2
Tetrachloro-m-xylene	0.978	1.005305	2.75
12F0964-18	KCL-VBB-05	3	
Analyte	2.04 KCL-VWP-046 Results 2.25 2.04 2.11835 KCL-VBC-047 Results 0.29 0.1963238 0.46 0.4439286 0.914 0.9507429 1.20 1.064833 KCL-VBC-048 Results 1.1 0.8964667 0.36 0.3543524 1.20 1.076305 0.946 0.9860286 KCL-VBC-049 Results 0.82 0.8094318 3.3 3.008954 1.13 1.001455 0.842 0.8596818 KCL-VBC-050 Results 1.11 0.7753909 0.40 0.3878727 0.874 0.9031182 1.14 1.001764 KCL-VBC-051 Results 3.6 0.874 1.10 0.7753909 0.40 0.3878727 0.874 0.874 1.10 0.7753909 0.40 0.3878727 0.874 0.803182 1.11 0.904 0.9125227 1.20 1.059636 KCL-VBB-052 Results		%RPD
Surrogates			
Decachlorobiphenyl	0.969	0.8657727	11.3
Tetrachloro-m-xylene	0.848	0.8750454	3.14

12F0964-19	KCL-VBBI		
Analyte		Results	%RPD
Aroclor-1254 [2C] Surrogates	0.10	8.700869E-02	13.9
Decachlorobiphenyl	0.955	0.8519261	11.4
Tetrachloro-m-xylene	0.830	0.8541	2.86
12F0964-20	KCL-VBB		
Analyte		Results	%RPD
Surrogates			
Decachlorobiphenyl	1.43	1.27314	11.6
Tetrachloro-m-xylene	1.56	1.63209	4.52
B054234-BLK1	Blank		
Analyte		Results	%RPD
Surrogates			
Tetrachloro-m-xylene	2.37	2.47306	4.26
Decachlorobiphenyl	2.71	2.44668	10.2
B054234-BS1	LCS		
Analyte		Results	%RPD
Aroclor-1016	0.42	0.4236	0.853
Aroclor-1260	0.41	0.42543	3.69
Surrogates			
Decachlorobiphenyl	1.80	1.61139	11.1
Tetrachloro-m-xylene	1.44	1.50234	4.24
B054234-BSD1	LCS Dup		
Analyte		Results	%RPD
Aroclor-1016	0.53	0.52275	1.38
Aroclor-1260	0.51	0.53417	4.63
Surrogates			
Decachlorobiphenyl	2.23	2.00036	10.9
Tetrachloro-m-xylene	1.85	1.93018	4.24
B054247-BLK1	Blank		
Analyte		Results	%RPD
Aroclor-1254 Surrogates	0.77	0.86654	11.8
Decachlorobiphenyl	3.24	3.80626	16.1
Tetrachloro-m-xylene	3.83	4.2387	10.1
B054247-BS1	LCS		
Analyte		Results	%RPD
Aroclor-1260	2.9	3.37962	15.3
Aroclor-1016	3.4	4.5048	28
Surrogates	5.7	1.5040	
Decachlorobiphenyl	2.57	3.14768	20.2
Tetrachloro-m-xylene	3.71	3.98808	7.22
B054247-BSD1	LCS Dup		
Analyte		Results	%RPD
Aroclor-1016	3.4	4.28534	23
Aroclor-1260	2.7	3.02488	11.3
Surrogates			
Decachlorobiphenyl	1.98	2.39962	19.2
Tetrachloro-m-xylene	3.67	3.97394	7.95
B054248-BLK1	Blank		
Analyte		Results	%RPD
Surrogates			· -
Decachlorobiphenyl	1.21	1.04831	14.3
Tetrachloro-m-xylene	0.909	0.936275	2.96
	0.000	0.000210	00

B054248-BS1	LCS		
Analyte	Re	sults	%RPD
Aroclor-1016	0.26	0.268615	3.26
Aroclor-1260	0.28	0.27641	1.29
Surrogates			
Decachlorobiphenyl	1.16	1.0186	13
Tetrachloro-m-xylene	0.918	0.949115	3.33
B054248-BSD1	LCS Dup		
Analyte	•	sults	%RPD
Aroclor-1016	0.26	0.27632	6.09
Aroclor-1260	0.27	0.277255	2.65
Surrogates			
Decachlorobiphenyl	1.11	0.98339	12.1
Tetrachloro-m-xylene	0.944	0.977535	3.49
B054248-MS1	Matrix Spike		
Analyte	•	sults	%RPD
Aroclor-1016	0.22	0.23565	6.87
Aroclor-1260	0.24	0.2375045	1.05
Surrogates			
Decachlorobiphenyl	0.995	0.8899591	11.1
Tetrachloro-m-xylene	0.793	0.8233682	3.76
D054040 1107 :	Material Control	D	
B054248-MSD1	Matrix Spike	•	
Analyte		sults	%RPD
Aroclor-1016	0.20 0.22	0.2307636 0.2342636	14.3 6.28
Aroclor-1260 Surrogates	0.22	0.2342030	0.28
Decachlorobiphenyl	0.947	0.8438318	11.5
Tetrachloro-m-xylene	0.740	0.7761864	4.77
·			
B054269-BLK1	Blank		
Analyte	Re	sults	%RPD
Surrogates			
Decachlorobiphenyl	1.47 1.42	1.27995 1.47809	13.8
Tetrachloro-m-xylene	1.42	1.47609	4.01
B054269-BS1	LCS		
Analyte		sults	%RPD
Aroclor-1016	0.44	0.42396	3.71
Aroclor-1260	0.35	0.37505	6.91
Surrogates			
Decachlorobiphenyl	1.59	1.40537	12.3
Tetrachloro-m-xylene	1.42	1.46755	3.29
D0E4260 DCD4	LCS Dun		
B054269-BSD1	LCS Dup	aulta	%RPD
Analyte		sults	
Aroclor-1260 Aroclor-1016	0.41 0.49	0.42977 0.46976	4.71 4.22
Surrogates	0.49	0.40370	7.22
Decachlorobiphenyl	1.65	1.46002	12.2
Tetrachloro-m-xylene	1.52	1.57997	3.87
B054542-BLK1	Blank		
Analyte	Re	sults	%RPD
Surrogates		0.0000	0.5
Tetrachloro-m-xylene	4.25	3.98238	6.5 3.22
Decachlorobiphenyl	4.33	4.47154	3.22
B054542-BS1	LCS		
Analyte	Re	sults	%RPD
Aroclor-1016	4.0	3.92016	2.02
Aroclor-1260	4.0	3.79796	5.18

Surrogates			
Tetrachloro-m-xylene	4.28	3.97408	7.41
Decachlorobiphenyl	4.40	3.83456	13.7
B054542-BSD1	LCS Dup		
Analyte		Results	%RPD
Aroclor-1016	4.4	4.24342	3.62
Aroclor-1260	4.1	3.93122	4.2
Surrogates			
Tetrachloro-m-xylene	4.44	4.17568	6.14
Decachlorobiphenyl	4.25	4.43544	4.27



August 8, 2012

George Franklin Woodard & Curran - Andover, MA 35 New England Business Center Andover, MA 01810

Project Location: Yale - KCL, New Haven, CT

Client Job Number: Project Number: 225540

Laboratory Work Order Number: 12H0008

Meghan S. Kelley

Enclosed are results of analyses for samples received by the laboratory on August 1, 2012. If you have any questions concerning this report, please feel free to contact me.

Sincerely,

Meghan E. Kelley Project Manager



Woodard & Curran - Andover, MA 35 New England Business Center Andover, MA 01810

ATTN: George Franklin

REPORT DATE: 8/8/2012

PURCHASE ORDER NUMBER:

PROJECT NUMBER: 225540

ANALYTICAL SUMMARY

WORK ORDER NUMBER: 12H0008

The results of analyses performed on the following samples submitted to the CON-TEST Analytical Laboratory are found in this report.

PROJECT LOCATION: Yale - KCL, New Haven, CT

FIELD SAMPLE #	LAB ID:	MATRIX	SAMPLE DESCRIPTION	TEST	SUB LAB
KCL-CBC-200	12H0008-01	Product/Solid		SW-846 8082A	
KCL-VBC-201	12H0008-02	Product/Solid		SW-846 8082A	
KCL-VBC-202	12H0008-03	Product/Solid		SW-846 8082A	
KCL-VBC-203	12H0008-04	Product/Solid		SW-846 8082A	
KCL-VBC-204	12H0008-05	Product/Solid		SW-846 8082A	
KCL-VBC-205	12H0008-06	Product/Solid		SW-846 8082A	
KCL-CBC-206	12H0008-07	Product/Solid		SW-846 8082A	
KCL-VBC-207	12H0008-08	Product/Solid		SW-846 8082A	
KCL-CBC-208	12H0008-09	Product/Solid		SW-846 8082A	
KCL-CBC-209	12H0008-10	Product/Solid		SW-846 8082A	
KCL-CBC-210	12H0008-11	Product/Solid		SW-846 8082A	
KCL-CBC-211	12H0008-12	Product/Solid		SW-846 8082A	
KCL-CBC-213	12H0008-14	Product/Solid		SW-846 8082A	
KCL-CBC-214	12H0008-15	Product/Solid		SW-846 8082A	
KCL-FB-7.31.12	12H0008-16	Equipment Blank Water		SW-846 8082A	



CASE NARRATIVE SUMMARY

All reported results are within defined laboratory quality control objectives unless listed below or otherwise qualified in this report.

SW-846 8082A

Qualifications:

Sample contains two incompletely resolved aroclors. Aroclor with the closest matching pattern is reported.

Analyte & Samples(s) Qualified:

Aroclor-1260 [2C]

12H0008-11[KCL-CBC-210]

Result was confirmed using a dissimilar column. Relative percent difference between the two results was >40%. The higher result was reported.

Analyte & Samples(s) Qualified:

Aroclor-1254 [2C]

12H0008-14[KCL-CBC-213]

The results of analyses reported only relate to samples submitted to the Con-Test Analytical Laboratory for testing.

I certify that the analyses listed above, unless specifically listed as subcontracted, if any, were performed under my direction according to the approved methodologies listed in this document, and that based upon my inquiry of those individuals immediately responsible for obtaining the information, the material contained in this report is, to the best of my knowledge and belief, accurate and complete.

Michael A. Erickson Laboratory Director

Culu



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-CBC-200 Sampled: 7/31/2012 09:55

Sample ID: 12H0008-01
Sample Matrix: Product/Solid

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:25	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:25	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:25	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:25	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:25	MJC
Aroclor-1254 [1]	0.37	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:25	MJC
Aroclor-1260 [2]	0.33	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:25	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:25	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:25	MJC
Surrogates		% Recovery	Recovery Limits	S	Flag				
Decachlorobiphenyl [1]		104	30-150					8/2/12 21:25	
Decachlorobiphenyl [2]		104	30-150					8/2/12 21:25	
Tetrachloro-m-xylene [1]		97.7	30-150					8/2/12 21:25	
Tetrachloro-m-xylene [2]		95.7	30-150					8/2/12 21:25	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-VBC-201 Sampled: 7/31/2012 10:22

Sample ID: 12H0008-02
Sample Matrix: Product/Solid

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	8/1/12	8/3/12 13:40	MJC
Aroclor-1221 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	8/1/12	8/3/12 13:40	MJC
Aroclor-1232 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	8/1/12	8/3/12 13:40	MJC
Aroclor-1242 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	8/1/12	8/3/12 13:40	MJC
Aroclor-1248 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	8/1/12	8/3/12 13:40	MJC
Aroclor-1254 [1]	1.3	0.18	mg/Kg	2		SW-846 8082A	8/1/12	8/3/12 13:40	MJC
Aroclor-1260 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	8/1/12	8/3/12 13:40	MJC
Aroclor-1262 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	8/1/12	8/3/12 13:40	MJC
Aroclor-1268 [1]	ND	0.18	mg/Kg	2		SW-846 8082A	8/1/12	8/3/12 13:40	MJC
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		84.0	30-150					8/3/12 13:40	
Decachlorobiphenyl [2]		80.4	30-150					8/3/12 13:40	
Tetrachloro-m-xylene [1]		94.1	30-150					8/3/12 13:40	
Tetrachloro-m-xylene [2]		96.9	30-150					8/3/12 13:40	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-VBC-202 Sampled: 7/31/2012 11:11

Sample ID: 12H0008-03
Sample Matrix: Product/Solid

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:51	MJC
Aroclor-1221 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:51	MJC
Aroclor-1232 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:51	MJC
Aroclor-1242 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:51	MJC
Aroclor-1248 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:51	MJC
Aroclor-1254 [2]	0.38	0.095	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:51	MJC
Aroclor-1260 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:51	MJC
Aroclor-1262 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:51	MJC
Aroclor-1268 [1]	ND	0.095	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 21:51	MJC
Surrogates		% Recovery	Recovery Limits	1	Flag				
Decachlorobiphenyl [1]		57.6	30-150					8/2/12 21:51	
Decachlorobiphenyl [2]		57.0	30-150					8/2/12 21:51	
Tetrachloro-m-xylene [1]		53.9	30-150					8/2/12 21:51	
Tetrachloro-m-xylene [2]		54.0	30-150					8/2/12 21:51	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-VBC-203 Sampled: 7/31/2012 11:47

Sample ID: 12H0008-04
Sample Matrix: Product/Solid

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 22:04	MJC
Aroclor-1221 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 22:04	MJC
Aroclor-1232 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 22:04	MJC
Aroclor-1242 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 22:04	MJC
Aroclor-1248 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 22:04	MJC
Aroclor-1254 [1]	0.54	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 22:04	MJC
Aroclor-1260 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 22:04	MJC
Aroclor-1262 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 22:04	MJC
Aroclor-1268 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 22:04	MJC
Surrogates		% Recovery	Recovery Limits	1	Flag				
Decachlorobiphenyl [1]		101	30-150					8/2/12 22:04	
Decachlorobiphenyl [2]		100	30-150					8/2/12 22:04	
Tetrachloro-m-xylene [1]		94.1	30-150					8/2/12 22:04	
Tetrachloro-m-xylene [2]		92.1	30-150					8/2/12 22:04	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-VBC-204 Sampled: 7/31/2012 12:28

Sample ID: 12H0008-05

Sample Matrix: Product/Solid

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:21	MJC
Aroclor-1221 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:21	MJC
Aroclor-1232 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:21	MJC
Aroclor-1242 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:21	MJC
Aroclor-1248 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:21	MJC
Aroclor-1254 [2]	0.34	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:21	MJC
Aroclor-1260 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:21	MJC
Aroclor-1262 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:21	MJC
Aroclor-1268 [1]	ND	0.091	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:21	MJC
Surrogates		% Recovery	Recovery Limit	ts	Flag				
Decachlorobiphenyl [1]		105	30-150					8/2/12 23:21	
Decachlorobiphenyl [2]		104	30-150					8/2/12 23:21	
Tetrachloro-m-xylene [1]		101	30-150					8/2/12 23:21	
Tetrachloro-m-xylene [2]		99.6	30-150					8/2/12 23:21	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-VBC-205 Sampled: 7/31/2012 12:51

Sample ID: 12H0008-06
Sample Matrix: Product/Solid

Polychlorinated	Biphenvls	with 3540	Soxhlet Extraction

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:34	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:34	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:34	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:34	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:34	MJC
Aroclor-1254 [2]	0.47	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:34	MJC
Aroclor-1260 [2]	0.27	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:34	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:34	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:34	MJC
Surrogates		% Recovery	Recovery Limits	S	Flag				
Decachlorobiphenyl [1]		105	30-150					8/2/12 23:34	
Decachlorobiphenyl [2]		104	30-150					8/2/12 23:34	
Tetrachloro-m-xylene [1]		99.2	30-150					8/2/12 23:34	
Tetrachloro-m-xylene [2]		97.2	30-150					8/2/12 23:34	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-CBC-206 Sampled: 7/31/2012 13:21

Sample ID: 12H0008-07
Sample Matrix: Product/Solid

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:47	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:47	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:47	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:47	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:47	MJC
Aroclor-1254 [2]	0.53	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:47	MJC
Aroclor-1260 [2]	0.36	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:47	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:47	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/2/12 23:47	MJC
Surrogates		% Recovery	Recovery Limit	ts	Flag				
Decachlorobiphenyl [1]		94.8	30-150					8/2/12 23:47	
Decachlorobiphenyl [2]		93.8	30-150					8/2/12 23:47	
Tetrachloro-m-xylene [1]		100	30-150					8/2/12 23:47	
Tetrachloro-m-xylene [2]		98.1	30-150					8/2/12 23:47	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-VBC-207 Sampled: 7/31/2012 13:50

Sample ID: 12H0008-08
Sample Matrix: Product/Solid

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:00	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:00	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:00	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:00	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:00	MJC
Aroclor-1254 [1]	0.68	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:00	MJC
Aroclor-1260 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:00	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:00	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:00	MJC
Surrogates		% Recovery	Recovery Limits	1	Flag				
Decachlorobiphenyl [1]		96.3	30-150					8/3/12 0:00	
Decachlorobiphenyl [2]		95.7	30-150					8/3/12 0:00	
Tetrachloro-m-xylene [1]		98.3	30-150					8/3/12 0:00	
Tetrachloro-m-xylene [2]		97.1	30-150					8/3/12 0:00	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-CBC-208 Sampled: 7/31/2012 14:11

Sample ID: 12H0008-09
Sample Matrix: Product/Solid

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:13	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:13	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:13	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:13	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:13	MJC
Aroclor-1254 [2]	0.31	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:13	MJC
Aroclor-1260 [2]	0.40	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:13	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:13	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:13	MJC
Surrogates		% Recovery	Recovery Limits	1	Flag				
Decachlorobiphenyl [1]		88.5	30-150					8/3/12 0:13	
Decachlorobiphenyl [2]		88.4	30-150					8/3/12 0:13	
Tetrachloro-m-xylene [1]		87.7	30-150					8/3/12 0:13	
Tetrachloro-m-xylene [2]		87.1	30-150					8/3/12 0:13	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-CBC-209 Sampled: 7/31/2012 14:33

Sample ID: 12H0008-10
Sample Matrix: Product/Solid

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:26	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:26	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:26	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:26	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:26	MJC
Aroclor-1254 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:26	MJC
Aroclor-1260 [1]	0.15	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:26	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:26	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:26	MJC
Surrogates		% Recovery	Recovery Limits	ı	Flag				
Decachlorobiphenyl [1]		99.6	30-150					8/3/12 0:26	
Decachlorobiphenyl [2]		98.9	30-150					8/3/12 0:26	
Tetrachloro-m-xylene [1]		89.9	30-150					8/3/12 0:26	
Tetrachloro-m-xylene [2]		89.8	30-150					8/3/12 0:26	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-CBC-210 Sampled: 7/31/2012 15:00

Sample ID: 12H0008-11
Sample Matrix: Product/Solid

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:39	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:39	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:39	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:39	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:39	MJC
Aroclor-1254 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:39	MJC
Aroclor-1260 [2]	0.84	0.087	mg/Kg	1	O-03	SW-846 8082A	8/1/12	8/3/12 0:39	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:39	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:39	MJC
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		119	30-150					8/3/12 0:39	
Decachlorobiphenyl [2]		119	30-150					8/3/12 0:39	
Tetrachloro-m-xylene [1]		104	30-150					8/3/12 0:39	
Tetrachloro-m-xylene [2]		101	30-150					8/3/12 0:39	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-CBC-211 Sampled: 7/31/2012 15:20

Sample ID: 12H0008-12
Sample Matrix: Product/Solid

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:51	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:51	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:51	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:51	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:51	MJC
Aroclor-1254 [2]	0.16	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:51	MJC
Aroclor-1260 [2]	0.20	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:51	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:51	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 0:51	MJC
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		104	30-150					8/3/12 0:51	
Decachlorobiphenyl [2]		104	30-150					8/3/12 0:51	
Tetrachloro-m-xylene [1]		101	30-150					8/3/12 0:51	
Tetrachloro-m-xylene [2]		98.7	30-150					8/3/12 0:51	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-CBC-213 Sampled: 7/31/2012 15:50

Sample ID: 12H0008-14
Sample Matrix: Product/Solid

Polychlorinated Biphenyls with 3540 Soxhlet Extraction

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:17	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:17	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:17	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:17	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:17	MJC
Aroclor-1254 [2]	0.41	0.087	mg/Kg	1	P-01	SW-846 8082A	8/1/12	8/3/12 1:17	MJC
Aroclor-1260 [2]	0.54	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:17	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:17	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:17	MJC
Surrogates		% Recovery	Recovery Limits	S	Flag				
Decachlorobiphenyl [1]		119	30-150					8/3/12 1:17	
Decachlorobiphenyl [2]		119	30-150					8/3/12 1:17	
Tetrachloro-m-xylene [1]		107	30-150					8/3/12 1:17	
Tetrachloro-m-xylene [2]		103	30-150					8/3/12 1:17	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-CBC-214 Sampled: 7/31/2012 15:50

Sample ID: 12H0008-15
Sample Matrix: Product/Solid

Polychlorinated Biphenyls with 3540 Soxhlet Extraction

Analyte	Results	RL	Units	Dilution	Flag	Method	Date Prepared	Date/Time Analyzed	Analyst
·				Dilution	riag			-	
Aroclor-1016 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:30	MJC
Aroclor-1221 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:30	MJC
Aroclor-1232 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:30	MJC
Aroclor-1242 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:30	MJC
Aroclor-1248 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:30	MJC
Aroclor-1254 [2]	0.30	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:30	MJC
Aroclor-1260 [2]	0.39	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:30	MJC
Aroclor-1262 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:30	MJC
Aroclor-1268 [1]	ND	0.087	mg/Kg	1		SW-846 8082A	8/1/12	8/3/12 1:30	MJC
Surrogates		% Recovery	Recovery Limits	S	Flag				
Decachlorobiphenyl [1]		112	30-150					8/3/12 1:30	
Decachlorobiphenyl [2]		111	30-150					8/3/12 1:30	
Tetrachloro-m-xylene [1]		106	30-150					8/3/12 1:30	
Tetrachloro-m-xylene [2]		103	30-150					8/3/12 1:30	



Project Location: Yale - KCL, New Haven, CT Sample Description: Work Order: 12H0008

Date Received: 8/1/2012

Field Sample #: KCL-FB-7.31.12 Sampled: 7/31/2012 17:00

Sample ID: 12H0008-16

Sample Matrix: Equipment Blank Water

Polychlorinated	Biphenyls	By GC/ECD
1 orycmormateu	Diplicityis	by GC/LCD

							Date	Date/Time	
Analyte	Results	RL	Units	Dilution	Flag	Method	Prepared	Analyzed	Analyst
Aroclor-1016 [1]	ND	0.20	$\mu g/L$	1		SW-846 8082A	8/4/12	8/6/12 16:01	JMB
Aroclor-1221 [1]	ND	0.20	μg/L	1		SW-846 8082A	8/4/12	8/6/12 16:01	JMB
Aroclor-1232 [1]	ND	0.20	μg/L	1		SW-846 8082A	8/4/12	8/6/12 16:01	JMB
Aroclor-1242 [1]	ND	0.20	μg/L	1		SW-846 8082A	8/4/12	8/6/12 16:01	JMB
Aroclor-1248 [1]	ND	0.20	μg/L	1		SW-846 8082A	8/4/12	8/6/12 16:01	JMB
Aroclor-1254 [1]	ND	0.20	μg/L	1		SW-846 8082A	8/4/12	8/6/12 16:01	JMB
Aroclor-1260 [1]	ND	0.20	μg/L	1		SW-846 8082A	8/4/12	8/6/12 16:01	JMB
Aroclor-1262 [1]	ND	0.20	μg/L	1		SW-846 8082A	8/4/12	8/6/12 16:01	JMB
Aroclor-1268 [1]	ND	0.20	$\mu g/L$	1		SW-846 8082A	8/4/12	8/6/12 16:01	JMB
Surrogates		% Recovery	Recovery Limit	s	Flag				
Decachlorobiphenyl [1]		92.9	30-150					8/6/12 16:01	
Decachlorobiphenyl [2]		91.7	30-150					8/6/12 16:01	
Tetrachloro-m-xylene [1]		64.9	30-150					8/6/12 16:01	
Tetrachloro-m-xylene [2]		66.3	30-150					8/6/12 16:01	



Sample Extraction Data

Prep Method: SW-846 3540C-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [g]	Final [mL]	Date	
12H0008-01 [KCL-CBC-200]	B056240	2.30	10.0	08/01/12	
12H0008-02 [KCL-VBC-201]	B056240	2.20	10.0	08/01/12	
12H0008-03 [KCL-VBC-202]	B056240	2.10	10.0	08/01/12	
12H0008-04 [KCL-VBC-203]	B056240	2.20	10.0	08/01/12	
12H0008-05 [KCL-VBC-204]	B056240	2.20	10.0	08/01/12	
12H0008-06 [KCL-VBC-205]	B056240	2.30	10.0	08/01/12	
12H0008-07 [KCL-CBC-206]	B056240	2.30	10.0	08/01/12	
12H0008-08 [KCL-VBC-207]	B056240	2.30	10.0	08/01/12	
12H0008-09 [KCL-CBC-208]	B056240	2.30	10.0	08/01/12	
12H0008-10 [KCL-CBC-209]	B056240	2.30	10.0	08/01/12	
12H0008-11 [KCL-CBC-210]	B056240	2.30	10.0	08/01/12	
12H0008-12 [KCL-CBC-211]	B056240	2.30	10.0	08/01/12	
12H0008-14 [KCL-CBC-213]	B056240	2.30	10.0	08/01/12	
12H0008-15 [KCL-CBC-214]	B056240	2.30	10.0	08/01/12	

Prep Method: SW-846 3510C-SW-846 8082A

Lab Number [Field ID]	Batch	Initial [mL]	Final [mL]	Date
12H0008-16 [KCL-FB-7.31.12]	B056412	1000	10.0	08/04/12



QUALITY CONTROL

Polychlorinated Biphenyls By GC/ECD - Quality Control

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B056412 - SW-846 3510C										
Blank (B056412-BLK1)				Prepared: 08	3/04/12 Anal	yzed: 08/07/	12			
Aroclor-1016	ND	0.20	μg/L							
Aroclor-1016 [2C]	ND	0.20	μg/L							
Aroclor-1221	ND	0.20	μg/L							
Aroclor-1221 [2C]	ND	0.20	μg/L							
Aroclor-1232	ND	0.20	μg/L							
Aroclor-1232 [2C]	ND	0.20	μg/L							
Aroclor-1242	ND	0.20	μg/L							
Aroclor-1242 [2C]	ND	0.20	μg/L							
Aroclor-1248	ND	0.20	μg/L							
Aroclor-1248 [2C]	ND	0.20	μg/L							
Aroclor-1254	ND	0.20	μg/L							
Aroclor-1254 [2C]	ND	0.20	μg/L							
Aroclor-1260	ND	0.20	μg/L							
Aroclor-1260 [2C]	ND	0.20	μg/L							
Aroclor-1262	ND	0.20	μg/L							
Aroclor-1262 [2C]	ND	0.20	μg/L							
Aroclor-1268	ND	0.20	μg/L							
Aroclor-1268 [2C]	ND	0.20	μg/L							
Surrogate: Decachlorobiphenyl	1.76		μg/L	2.00		88.1	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.70		μg/L	2.00		85.0	30-150			
Surrogate: Tetrachloro-m-xylene	1.08		μg/L	2.00		53.8	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	1.12		μg/L	2.00		55.8	30-150			
LCS (B056412-BS1)				Prepared: 08	3/04/12 Anal	yzed: 08/07/	12			
Aroclor-1016	0.46	0.20	μg/L	0.500		92.5	40-140			
Aroclor-1016 [2C]	0.55	0.20	μg/L	0.500		110	40-140			
Aroclor-1260	0.44	0.20	μg/L	0.500		87.7	40-140			
Aroclor-1260 [2C]	0.45	0.20	μg/L	0.500		90.4	40-140			
Surrogate: Decachlorobiphenyl	1.86		μg/L	2.00		93.2	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.83		$\mu g/L$	2.00		91.3	30-150			
Surrogate: Tetrachloro-m-xylene	1.15		μg/L	2.00		57.4	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	1.19		μg/L	2.00		59.7	30-150			
LCS Dup (B056412-BSD1)				Prepared: 08	3/04/12 Anal	yzed: 08/07/	12			
Aroclor-1016	0.44	0.20	μg/L	0.500		87.6	40-140	5.51	20	
Aroclor-1016 [2C]	0.46	0.20	μg/L	0.500		91.3	40-140	18.8	20	
Aroclor-1260	0.47	0.20	μg/L	0.500		94.5	40-140	7.44	20	
Aroclor-1260 [2C]	0.48	0.20	μg/L	0.500		95.5	40-140	5.56	20	
Surrogate: Decachlorobiphenyl	1.75		μg/L	2.00		87.5	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.72		μg/L	2.00		86.0	30-150			
Surrogate: Tetrachloro-m-xylene	1.22		μg/L	2.00		60.9	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	1.26		μg/L	2.00		63.2	30-150			



QUALITY CONTROL

Polychlorinated Biphenyls with 3540 Soxhlet Extraction - Quality Control

Analyte	Result	Reporting Limit	Units	Spike Level	Source Result	%REC	%REC Limits	RPD	RPD Limit	Notes
Batch B056240 - SW-846 3540C										
Blank (B056240-BLK1)				Prepared: 08	3/01/12 Anal	yzed: 08/02/1	2			
Aroclor-1016	ND	0.10	mg/Kg							
Aroclor-1016 [2C]	ND	0.10	mg/Kg							
Aroclor-1221	ND	0.10	mg/Kg							
Aroclor-1221 [2C]	ND	0.10	mg/Kg							
Aroclor-1232	ND	0.10	mg/Kg							
Aroclor-1232 [2C]	ND	0.10	mg/Kg							
Aroclor-1242	ND	0.10	mg/Kg							
Aroclor-1242 [2C]	ND	0.10	mg/Kg							
aroclor-1248	ND	0.10	mg/Kg							
Aroclor-1248 [2C]	ND	0.10	mg/Kg							
Aroclor-1254	ND	0.10	mg/Kg							
Aroclor-1254 [2C]	ND	0.10	mg/Kg							
Aroclor-1260	ND	0.10	mg/Kg							
Aroclor-1260 [2C]	ND	0.10	mg/Kg							
Aroclor-1262	ND	0.10	mg/Kg							
aroclor-1262 [2C]	ND	0.10	mg/Kg							
Aroclor-1268	ND	0.10	mg/Kg							
Aroclor-1268 [2C]	ND	0.10	mg/Kg							
urrogate: Decachlorobiphenyl	0.971		mg/Kg	1.00		97.1	30-150			
Surrogate: Decachlorobiphenyl [2C]	0.968		mg/Kg	1.00		96.8	30-150			
Surrogate: Tetrachloro-m-xylene	0.995		mg/Kg	1.00		99.5	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	0.973		mg/Kg	1.00		97.3	30-150			
CS (B056240-BS1)				Prepared: 08	3/01/12 Anal	yzed: 08/02/1	2			
Aroclor-1016	0.26	0.10	mg/Kg	0.250		103	40-140			
Aroclor-1016 [2C]	0.27	0.10	mg/Kg	0.250		109	40-140			
Aroclor-1260	0.26	0.10	mg/Kg	0.250		104	40-140			
Aroclor-1260 [2C]	0.30	0.10	mg/Kg	0.250		121	40-140			
urrogate: Decachlorobiphenyl	1.07		mg/Kg	1.00		107	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.07		mg/Kg	1.00		107	30-150			
Surrogate: Tetrachloro-m-xylene	0.979		mg/Kg	1.00		97.9	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	0.957		mg/Kg	1.00		95.7	30-150			
.CS Dup (B056240-BSD1)				Prepared: 08	3/01/12 Anal	yzed: 08/02/1	2			
Aroclor-1016	0.27	0.10	mg/Kg	0.250		109	40-140	5.04	30	
Aroclor-1016 [2C]	0.28	0.10	mg/Kg	0.250		111	40-140	1.77	30	
Aroclor-1260	0.25	0.10	mg/Kg	0.250		101	40-140	2.56	30	
Aroclor-1260 [2C]	0.29	0.10	mg/Kg	0.250		117	40-140	3.45	30	
Surrogate: Decachlorobiphenyl	1.00		mg/Kg	1.00		100	30-150			
Surrogate: Decachlorobiphenyl [2C]	1.00		mg/Kg	1.00		100	30-150			
Surrogate: Tetrachloro-m-xylene	1.02		mg/Kg	1.00		102	30-150			
Surrogate: Tetrachloro-m-xylene [2C]	0.999		mg/Kg	1.00		99.9	30-150			



FLAG/QUALIFIER SUMMARY

*	QC result is outside of established limits.
†	Wide recovery limits established for difficult compound.
‡	Wide RPD limits established for difficult compound.
#	Data exceeded client recommended or regulatory level
	Percent recoveries and relative percent differences (RPDs) are determined by the software using values in the calculation which have not been rounded.
)- 03	Sample contains two incompletely resolved aroclors. Aroclor with the closest matching pattern is reported.
2-01	Result was confirmed using a dissimilar column. Relative percent difference between the two results was $>40\%$ The higher result was reported.



CERTIFICATIONS

Certified Analyses included in this Report

Analyte	Certifications
SW-846 8082A in Product/Solid	
Aroclor-1016	CT,NH,NY,ME,NC
Aroclor-1016 [2C]	CT,NH,NY,ME,NC
Aroclor-1221	CT,NH,NY,ME,NC
Aroclor-1221 [2C]	CT,NH,NY,ME,NC
Aroclor-1232	CT,NH,NY,ME,NC
Aroclor-1232 [2C]	CT,NH,NY,ME,NC
Aroclor-1242	CT,NH,NY,ME,NC
Aroclor-1242 [2C]	CT,NH,NY,ME,NC
Aroclor-1248	CT,NH,NY,ME,NC
Aroclor-1248 [2C]	CT,NH,NY,ME,NC
Aroclor-1254	CT,NH,NY,ME,NC
Aroclor-1254 [2C]	CT,NH,NY,ME,NC
Aroclor-1260	CT,NH,NY,ME,NC
Aroclor-1260 [2C]	CT,NH,NY,ME,NC
SW-846 8082A in Water	
Aroclor-1016	CT,NH,NY,RI,NC,ME
Aroclor-1016 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1221	CT,NH,NY,RI,NC,ME
Aroclor-1221 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1232	CT,NH,NY,RI,NC,ME
Aroclor-1232 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1242	CT,NH,NY,RI,NC,ME
Aroclor-1242 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1248	CT,NH,NY,RI,NC,ME
Aroclor-1248 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1254	CT,NH,NY,RI,NC,ME
Aroclor-1254 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1260	CT,NH,NY,RI,NC,ME
Aroclor-1260 [2C]	CT,NH,NY,RI,NC,ME
Aroclor-1262	NC
Aroclor-1262 [2C]	NC
Aroclor-1268	NC
Aroclor-1268 [2C]	NC



 $The \ CON-TEST\ Environmental\ Laboratory\ operates\ under\ the\ following\ certifications\ and\ accreditations:$

Code	Description	Number	Expires
AIHA	AIHA-LAP, LLC	100033	02/1/2014
MA	Massachusetts DEP	M-MA100	06/30/2013
CT	Connecticut Department of Publilc Health	PH-0567	09/30/2013
NY	New York State Department of Health	10899 NELAP	04/1/2013
NH	New Hampshire Environmental Lab	2516 NELAP	02/5/2013
RI	Rhode Island Department of Health	LAO00112	12/30/2012
NC	North Carolina Div. of Water Quality	652	12/31/2012
NJ	New Jersey DEP	MA007 NELAP	06/30/2013
FL	Florida Department of Health	E871027 NELAP	06/30/2013
VT	Vermont Department of Health Lead Laboratory	LL015036	07/30/2013
WA	State of Washington Department of Ecology	C2065	02/23/2013
ME	State of Maine	2011028	06/9/2013
VA	Commonwealth of Virginia	1381	12/14/2012

1	
\exists	
ANALYTICAL LABORATOR	con-test

	O RCP Form Required					Other sa. s day		ind 0 - 511/2	A TA
	O MCP Form Required					10-Day	<u> </u>	10	Redelyled by Jeignature
					Massachusetts	7-Day	0	'	Round
C = other	is voter project MCD or RCD 3	ments	guirem	imit Re	Detection Limit Require	Turnaround ††	<u>Turr</u>	Date/Tyme:	Relinquisked by. (signature)
SL = sludge	; L - Low; C - (л; М - Medi	H-Hig					/ IAI	Sid. Siday IAI
A = air S = soil/sofid	y be high in concentration in Matrix/Conc. Code Box:	/ be high in conce		; ;				, T	0+2 H 20
DW= drinking water	the following codes to let Con-Test know if a specific sample	following c	Please use the	Plea					Comments:
WW= wastewater		<u> </u>	C	to:	×	7.31.12/1433		KCL-CBC-209	0
*Matrix Code: GW= groundwater			c	ហ	×	7.31.12/1411		KCL-CBC-208	09
ļ			c	ß	×	7.31.12/1350		KCL-VBC-207	20
T = Na thiosulfate O = Other			c	ω	X	7.31.12/1321		KCL-CBC-206	07
X = Na hydroxide			_	ဟ	X	7.31.12/1251		KCL-VBC-205	୦ ଜ
S = Sulfuric Acid		È	c	cO	×	7.31.12/1228		KCL-VBC-204	05
M = Methanol		È	c	is .	×	7.31.12/1147		KCL-VBC-203	40
I = Iced H = HCL			c	S	×	7.31.12/1111		KCL-VBC-202	63
**Preservation			c	w	×	7.31.12/1022		KCL-VBC-201	20
			c	£S	×	7.31.12/0955		KCL-CBC-200	GI
T=tediar bag O=Other		PC.	Canc Code	ab Code	Composite Grab	g Ending e Date/Time	Beginning Date/Time	Client Sample ID / Description	Con-Test Lab ID C
S=summa can			ge")ata Packa	O "Enhanced Data Package"	Collection	δ		
P=plastic ST=sterile V= vial		808	S	ET OGIS	_ —	Format:		위? (for billing purposes) proposal date	Project Proposal Provided? (for billing purposes) O yes
G=glass			an.com	dardcurr	gfranklin@woodardcurran.com	Email:		Soulet	Sampled By: Craig Goulet
A=amber glass		h, 3			1			Yale-KCL, New Haven, CT	Project Location: Yale
o riligi		540C		appiy)	DATA DELIVERY (check all that apply) OFAX	DATA DELIVE		George Franklin	Attention: Geor
		Soxi				Client PO#		Andover, Mass. 01810	Ando
Dissolved Meta 3	ANALYSIS REQUESTED	let)			225540	_Project#	nter	35 New England Business Center	Address: 35 N
***Container Cor C		<u>ြ</u>		50	Telephone: 978-557-8150	_Telephone:		dard & Curran	Company Name: Woodard & Curran
** Preservation			_ 	D	1240002		stlabs.cor	ANALYTICAL LABORATORY www.contestlabs.com	VIII ANALYTIC
# of Containers				04.05.1	Rev		ാംപാ @contesti	Email: info@contestlabs.com	
Page 1 of 2	RD 39 Spruce Street East longmeadow, MA 01028	RECORD	•	USTO	CHAIN OF CUSTODY	CHAI	-525-2332 - 540-5	7001101 ® Phone: 413-525-2332	3

IS INCORRECT, TURNAROUND TIME WILL NOT START UNTIL ALL QUESTIONS ARE ANSWERED BY OUR CLIENT. TURNAROUND TIME STARTS AT 9:00 A.M. THE DAY AFTER SAMPLE RECEIPT UNLESS THERE ARE QUESTIONS ON YOUR CHAIN. IF THIS FORM IS NOT FILLED OUT COMPLETELY OR PLEASE BE CAREFUL NOT TO CONTAMINATE THIS DOCUMENT

S-24 Require lab approval 0 †72-Hr 🗇 †4-Day ☐ [†]24-Hr ☐ [†]48-Hr

Other

RUSH

Connecticut:

O MCP Form Required
O RCP Form Required
O MA State DW Form Required PWSID #

NELAC & AIHA-LAP, LLC

Accredited

WBE/DBE Certified

Other sa s day 10-Day

	ANALYTICAL LABORATORY			
www.contestlabs.con	Email: info@contestl	Fax: 413-525-6405	® Phone: 413-525-2332	

Email: info@contestlabs.com www.contestlabs.com

Sampled By:

Craig Goulet

Project Proposal Provided? (for billing purposes)

proposal date

S S

Con-Test Lab ID

Client Sample ID / Description

Beginning Date/Time

Date/Time

Composite

Grab

Matrix

Cone Lode

0=Other

S=summa can V= vial

T=tedlar bag

ST=sterile

P=plastic G=glass A=amber glass ***Cont. Code

PCB

Ending

Collection

O "Enhanced Data Package"

O OTHER

KCL-CBC-210 KCL-CBC-211

7

2

KCL-FB-7.31.12

KCL-CBC-214 KCL-CBC-213

7.31.12/1550

Ş

7.31.12/1550 7.31.12/1700

> × ×

o Ø

C \subseteq \subset 7.31.12/1520 7.31.12/1500

×

 \subseteq ⊆ Project Location: Yale-KCL, New Haven, CT

Fax#

OFAX ⊕EMAIL

OWEBSITE

Email:

gfranklin@woodardcurran.com

(Extraction by Meth. 3540C Soxhlet)

Format:

Sigo

8082

George Franklin

Address

Attention:

Company Name: Woodard & Curran

35 New England Business Center

Project #

<u>225540</u>

Telephone: 978-557-8150

G

Client PO#

DATA DELIVERY (check all that apply

Andover, Mass. 01810

CHAIN OF CUSTODY RECORD

Rev 04.05.12

39 Spruce Street

Page_

N 으 N

East longmeadow, MA 01028

of Containers ** Preservation ***Container Co

CRWPDF87

O Field Filtered

Dissolved Meta

C Lab to Filter

Page 27 of 31

Please use the following codes to let Con-Test know if a specific sample may be high in concentration in Matrix/Conc. Code Box: H - High; M - Medium; L - Low; C - Clean; U - Unknown Is your project MCP or RCP? ANALYSIS REQUESTED

H=HCL

1 = lced

**Preservation

S = Sulfuric Acid

N = Nitric Acid M = Methanol

T = Na thiosulfate X = Na hydroxide B = Sodium bisulfate

O = Other

GW= groundwater

*Matrix Code:

DW= drinking water WW= wastewater

S = soil/solid

A = air

O = other LAB PROVIDED DI St = sludge

NEL NA ACCORD	O MA State DW Form Required P	RCP Form Required	O MCP Form Required	

Relinquished by

(Signature)

Turnaround

7-Day

Massachusetts:

Detection Limit Requirements

10-Day

by: (signatura)

Comments

Std. 5 day TAT

VSID#

AC & AIHA-LAP, LLC Accredited

WBE/DBE Certified

TURNAROUND TIME STARTS AT 9:00 A.M. THE DAY AFTER SAMPLE RECEIPT UNLESS THERE ARE QUESTIONS ON YOUR CHAIN. IF THIS FORM IS NOT FILLED OUT COMPLETELY OR Se Réquire lab approval Other: PLEASE BE CAREFUL NOT TO CONTAMINATE THIS DOCUMENT

IS INCORRECT, TURNAROUND TIME WILL NOT START UNTIL ALL QUESTIONS ARE ANSWERED BY OUR CLIENT.

Date/Time:

Ime:

RUSH T

Connecticut:

Other Sid. Sidey

☐ [†]24-Hr ☐ [†]48-Hr

39 Spruce St.
East Longmeadow, MA. 01028
P: 413-525-2332
F: 413-525-6405
www.contestlabs.com





CLIENT NAME: 10000000 Sample Receipt Checklist

 Was the chain(s) of custody r 	relinquished and signed?	Yes No No	CoC Included
P) Does the chain agree with the If not, explain:	e samples?	Yes No	
B) Are all the samples in good c If not, explain:	ondition?	Yes No	
) How were the samples receiv	red:		
On Ice Direct from S		oient 🔲 🛮 In Cooler(s) 🖶	
Were the samples received in Te			۸
emperature °C by Temp blank			.5C
5) Are there Dissolved samples		Yes (No)	
Who was notified		Time	
6) Are there any RUSH or SHOR			
Who was notified	=	Time	
7) Location where samples are stor	red: [9	Permission to subcontract (Walk-in clients only) if no	•
3) Do all samples have the prop	er Acid pH: Yes No	CNA	
) Do all samples have the prop	er Base pH: Yes No	(N/A)	
	-		
10) Was the PC notified of any d	iscrenancies with the Col	C ve the samples: Ves No./	N/A
10) Was the PC notified of any d			N/A
	ontainers receiv		N/A)
			N/A # of containers
	# of containers		
C	ontainers receiv	red at Con-Test	
1 Liter Amber	# of containers	/ed at Con-Test 8 oz amber/clear jar	
1 Liter Amber 500 mL Amber	# of containers	/ed at Con-Test 8 oz amber/clear jar 4 oz amber/clear jar	
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic	# of containers	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar	
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic 250 mL plastic	# of containers	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar Air Cassette	
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic 250 mL plastic 40 mL Vial - type listed below	# of containers	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar Air Cassette Hg/Hopcalite Tube Plastic Bag / Ziploc PM 2.5 / PM 10	
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic 250 mL plastic 40 mL Vial - type listed below Colisure / bacteria bottle	# of containers	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar Air Cassette Hg/Hopcalite Tube Plastic Bag / Ziploc PM 2.5 / PM 10 PUF Cartridge	
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic 250 mL plastic 40 mL Vial - type listed below Colisure / bacteria bottle Dissolved Oxygen bottle	# of containers	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar 2 oz amber/clear jar Air Cassette Hg/Hopcalite Tube Plastic Bag / Ziploc PM 2.5 / PM 10 PUF Cartridge SOC Kit	
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic 250 mL plastic 40 mL Vial - type listed below Colisure / bacteria bottle Dissolved Oxygen bottle Encore	# of containers	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar Air Cassette Hg/Hopcalite Tube Plastic Bag / Ziploc PM 2.5 / PM 10 PUF Cartridge SOC Kit TO-17 Tubes	
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic 250 mL plastic 40 mL Vial - type listed below Colisure / bacteria bottle Dissolved Oxygen bottle Encore Flashpoint bottle	# of containers	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar 2 oz amber/clear jar Air Cassette Hg/Hopcalite Tube Plastic Bag / Ziploc PM 2.5 / PM 10 PUF Cartridge SOC Kit TO-17 Tubes Non-ConTest Container	
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic 250 mL plastic 40 mL Vial - type listed below Colisure / bacteria bottle Dissolved Oxygen bottle Encore Flashpoint bottle Perchlorate Kit	# of containers	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar Air Cassette Hg/Hopcalite Tube Plastic Bag / Ziploc PM 2.5 / PM 10 PUF Cartridge SOC Kit TO-17 Tubes Non-ConTest Container Other glass jar	
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic 250 mL plastic 40 mL Vial - type listed below Colisure / bacteria bottle Dissolved Oxygen bottle Encore Flashpoint bottle Perchlorate Kit Other	# of containers	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar 2 oz amber/clear jar Air Cassette Hg/Hopcalite Tube Plastic Bag / Ziploc PM 2.5 / PM 10 PUF Cartridge SOC Kit TO-17 Tubes Non-ConTest Container	
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic 250 mL plastic 40 mL Vial - type listed below Colisure / bacteria bottle Dissolved Oxygen bottle Encore Flashpoint bottle Perchlorate Kit Other aboratory Comments:	# of containers	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar 2 oz amber/clear jar Air Cassette Hg/Hopcalite Tube Plastic Bag / Ziploc PM 2.5 / PM 10 PUF Cartridge SOC Kit TO-17 Tubes Non-ConTest Container Other glass jar Other	
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic 250 mL plastic 40 mL Vial - type listed below Colisure / bacteria bottle Dissolved Oxygen bottle Encore Flashpoint bottle Perchlorate Kit Other aboratory Comments: 40 mL vials: # HCI	# of containers # Methanol	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar Air Cassette Hg/Hopcalite Tube Plastic Bag / Ziploc PM 2.5 / PM 10 PUF Cartridge SOC Kit TO-17 Tubes Non-ConTest Container Other glass jar Other	# of containers
1 Liter Amber 500 mL Amber 250 mL Amber (8oz amber) 1 Liter Plastic 500 mL Plastic 250 mL plastic 40 mL Vial - type listed below Colisure / bacteria bottle Dissolved Oxygen bottle Encore Flashpoint bottle Perchlorate Kit Other aboratory Comments:	# of containers # Methanol # Di Water	8 oz amber/clear jar 4 oz amber/clear jar 2 oz amber/clear jar Air Cassette Hg/Hopcalite Tube Plastic Bag / Ziploc PM 2.5 / PM 10 PUF Cartridge SOC Kit TO-17 Tubes Non-ConTest Container Other glass jar Other	# of containers

12G1033-02RE1	GH-VBC-154		
Analyte	Re	sults	%RPD
Aroclor-1254	1.8	1.3643	27.5
Surrogates			
Decachlorobiphenyl	1.01	0.9844454	2.56
Tetrachloro-m-xylene	0.766	0.7791273	1.7
12H0008-01	KCL-CBC-20	0	
Analyte	Re	sults	%RPD
Aroclor-1254	0.37	0.4531478	20.2
Aroclor-1260 [2C]	0.33	0.2785609	16.9
Surrogates			
Decachlorobiphenyl	0.907	0.9045479	0.271
Tetrachloro-m-xylene	0.850	0.8323783	2.09
12H0008-02	KCL-VBC-20	1	
Analyte	Re	sults	%RPD
Aroclor-1254	1.3	1.226236	5.84
Surrogates			
Tetrachloro-m-xylene	0.856	0.8807363	2.85
Decachlorobiphenyl	0.764	0.7313545	4.37
12H0008-03	KCL-VBC-20	2	
		z sults	%RPD
Analyte			
Aroclor-1254 [2C] Surrogates	0.38	0.3510905	7.91
Tetrachloro-m-xylene	0.514	0.5144667	0.0908
Decachlorobiphenyl	0.548	0.5429572	0.924
BoodemoreDiphenyi	0.010	0.0120012	0.02 1
12H0008-04	KCL-VBC-20	3	
Analyte	Re	sults	%RPD
Aroclor-1254	0.54	0.5010863	7.48
Surrogates			
Decachlorobiphenyl	0.921	0.9109273	1.1
Tetrachloro-m-xylene	0.856	0.8370727	2.24
12H0008-05	KCL-VBC-20	4	
Analyte	Re	sults	%RPD
Aroclor-1254 [2C]	0.34	0.3009909	12.2
Surrogates	0.0.	0.000000	
Decachlorobiphenyl	0.954	0.9469454	0.742
Tetrachloro-m-xylene	0.919	0.9051545	1.52
1240000 06	KCL-VBC-20	F	
12H0008-06			0.55
Analyte		sults	%RPD
Aroclor-1260 [2C]	0.27	0.2094652	25.3
Aroclor-1254 [2C]	0.47	0.4551565	3.21
Surrogates	0.010	0.0000011	
Decachlorobiphenyl	0.910	0.9030218	0.77
Tetrachloro-m-xylene	0.862	0.8454609	1.94
12H0008-07	KCL-CBC-20	6	
Analyte	Re	sults	%RPD
Aroclor-1254 [2C]	0.53	0.483487	9.18
Aroclor-1260 [2C]	0.36	0.3086826	15.3
Surrogates			
Decachlorobiphenyl	0.825	0.8156826	1.14
Tetrachloro-m-xylene	0.869	0.8530043	1.86
1240000 00	KCL VBC 20	7	
12H0008-08	KCL-VBC-20		
Analyte	Re	sults	%RPD
Aroclor-1254	0.68	0.6195305	9.31

Decachlorobiphenyl	0.838	0.8320218	0.716
Tetrachloro-m-xylene	0.855	0.8445913	1.22
12H0008-09	KCL-CBC-20	Ω	
			0/ DDD
Analyte		sults	%RPD
Aroclor-1260 [2C] Aroclor-1254 [2C]	0.40 0.31	0.3513 0.2679957	13 14.5
Surrogates	0.51	0.2019931	14.5
Decachlorobiphenyl	0.770	0.7688348	0.151
Tetrachloro-m-xylene	0.763	0.7574609	0.729
12H0008-10	KCL-CBC-20		
Analyte		sults	%RPD
Aroclor-1260	0.15	0.1778044	17
Surrogates	0.000	0.0500057	0.000
Decachlorobiphenyl	0.866 0.782	0.8599957 0.7806957	0.696 0.167
Tetrachloro-m-xylene	0.702	0.7000907	0.107
2H0008-11	KCL-CBC-21	0	
Analyte	Re	sults	%RPD
Aroclor-1260 [2C]	0.84	0.7572869	10.4
Surrogates			
Decachlorobiphenyl	1.03	1.033191	0.309
Tetrachloro-m-xylene	0.902	0.8813479	2.32
12110000 42	KCI CBC 24	1	
2H0008-12	KCL-CBC-21		0/ DDD
Analyte		sults	%RPD
Aroclor-1254 [2C] Aroclor-1260 [2C]	0.16 0.20	0.1271435 0.1750348	22.9 13.3
Surrogates	0.20	0.1730340	15.5
Tetrachloro-m-xylene	0.880	0.8581391	2.52
Decachlorobiphenyl	0.908	0.907213	0.0867
12H0008-14	KCL-CBC-21	3	
Analyte		3 sults	%RPD
Analyte Aroclor-1254 [2C]	0.41	sults 0.2216217	%RPD 59.6
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C]	Re	sults	
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates	0.41 0.54	0.2216217 0.4794435	59.6 11.9
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates Decachlorobiphenyl	0.41 0.54 1.04	0.2216217 0.4794435 1.031491	59.6 11.9 0.822
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates Decachlorobiphenyl	0.41 0.54	0.2216217 0.4794435	59.6 11.9
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates Decachlorobiphenyl Tetrachloro-m-xylene	0.41 0.54 1.04	0.2216217 0.4794435 1.031491 0.8994131	59.6 11.9 0.822
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates Decachlorobiphenyl Tetrachloro-m-xylene	0.41 0.54 1.04 0.927 KCL-CBC-21	0.2216217 0.4794435 1.031491 0.8994131	59.6 11.9 0.822
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates Decachlorobiphenyl Tetrachloro-m-xylene 2H0008-15 Analyte	0.41 0.54 1.04 0.927 KCL-CBC-21	0.2216217 0.4794435 1.031491 0.8994131	59.6 11.9 0.822 3.02
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates Decachlorobiphenyl Tetrachloro-m-xylene 2H0008-15 Analyte Aroclor-1260 [2C]	0.41 0.54 1.04 0.927 KCL-CBC-21	0.2216217 0.4794435 1.031491 0.8994131 4 sults	59.6 11.9 0.822 3.02
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates Decachlorobiphenyl Fetrachloro-m-xylene 2H0008-15 Analyte Aroclor-1260 [2C] Aroclor-1254 [2C] Surrogates	0.41 0.54 1.04 0.927 KCL-CBC-21 Re 0.39 0.30	0.2216217 0.4794435 1.031491 0.8994131 4 sults 0.3325652 0.2082087	59.6 11.9 0.822 3.02 %RPD 15.9 36.1
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates Decachlorobiphenyl Tetrachloro-m-xylene 12H0008-15 Analyte Aroclor-1260 [2C] Aroclor-1254 [2C] Surrogates Decachlorobiphenyl	0.41 0.54 1.04 0.927 KCL-CBC-21 Re 0.39 0.30	0.2216217 0.4794435 1.031491 0.8994131 4 sults 0.3325652 0.2082087	59.6 11.9 0.822 3.02 %RPD 15.9 36.1
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates Decachlorobiphenyl Tetrachloro-m-xylene 12H0008-15 Analyte Aroclor-1260 [2C] Aroclor-1254 [2C] Surrogates Decachlorobiphenyl	0.41 0.54 1.04 0.927 KCL-CBC-21 Re 0.39 0.30	0.2216217 0.4794435 1.031491 0.8994131 4 sults 0.3325652 0.2082087	59.6 11.9 0.822 3.02 %RPD 15.9 36.1
	0.41 0.54 1.04 0.927 KCL-CBC-21 Re 0.39 0.30	0.2216217 0.4794435 1.031491 0.8994131 4 sults 0.3325652 0.2082087 0.9613826 0.8970913	59.6 11.9 0.822 3.02 %RPD 15.9 36.1
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates Decachlorobiphenyl Tetrachloro-m-xylene 2H0008-15 Analyte Aroclor-1260 [2C] Aroclor-1254 [2C] Surrogates Decachlorobiphenyl Tetrachloro-m-xylene	0.41 0.54 1.04 0.927 KCL-CBC-21 Re 0.39 0.30 0.974 0.921 KCL-FB-7.31	0.2216217 0.4794435 1.031491 0.8994131 4 sults 0.3325652 0.2082087 0.9613826 0.8970913	59.6 11.9 0.822 3.02 %RPD 15.9 36.1
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Surrogates Decachlorobiphenyl Tetrachloro-m-xylene 12H0008-15 Analyte Aroclor-1260 [2C] Aroclor-1254 [2C] Surrogates Decachlorobiphenyl Tetrachloro-m-xylene	0.41 0.54 1.04 0.927 KCL-CBC-21 Re 0.39 0.30 0.974 0.921 KCL-FB-7.31	0.2216217 0.4794435 1.031491 0.8994131 4 sults 0.3325652 0.2082087 0.9613826 0.8970913	59.6 11.9 0.822 3.02 %RPD 15.9 36.1 1.3 2.63
Analyte Aroclor-1254 [2C] Aroclor-1260 [2C] Burrogates Decachlorobiphenyl Tetrachloro-m-xylene 2H0008-15 Analyte Aroclor-1260 [2C] Aroclor-1254 [2C] Burrogates Decachlorobiphenyl Tetrachloro-m-xylene 2H0008-16 Analyte	0.41 0.54 1.04 0.927 KCL-CBC-21 Re 0.39 0.30 0.974 0.921 KCL-FB-7.31	0.2216217 0.4794435 1.031491 0.8994131 4 sults 0.3325652 0.2082087 0.9613826 0.8970913	59.6 11.9 0.822 3.02 %RPD 15.9 36.1 1.3 2.63

B056240-BLK1	Blank		
Analyte		Results	%RPD
Surrogates			
Decachlorobiphenyl	0.971	0.96821	0.288
Tetrachloro-m-xylene	0.995	0.973475	2.19
B056240-BS1	LCS		
Analyte		Results	%RPD
Aroclor-1016	0.26	0.27143	4.3
Aroclor-1260	0.26	0.303235	15.4
Surrogates	0.070	0.057275	2.23
Tetrachloro-m-xylene Decachlorobiphenyl	0.979 1.07	0.957375 1.06503	2.23 0.466
Decacilloropiphenyi	1.07	1.00303	0.400
B056240-BSD1	LCS Dup		
Analyte		Results	%RPD
Aroclor-1260	0.25	0.292945	15.8
Aroclor-1016	0.27	0.27627	2.3
Surrogates			
Tetrachloro-m-xylene	1.02	0.999185	2.06
Decachlorobiphenyl	1.00	0.99977	0.023
B056240-MS1	Matrix Spik	7 0	
	Matrix Opir		0/ DDD
Analyte	0.00	Results	%RPD
Aroclor-1016 Aroclor-1260	0.28 0.94	0.42326 1.034485	40.7 9.57
Surrogates	0.54	1.004400	5.57
Decachlorobiphenyl	1.07	1.05718	1.21
Tetrachloro-m-xylene	0.992	0.962785	2.99
DOEGOAD MCDA	Matrix Snik	co Dun	
B056240-MSD1	Matrix Spik	•	0/000
Analyte		Results	%RPD
Analyte Aroclor-1016	0.26	Results 0.371965	35.4
Analyte Aroclor-1016 Aroclor-1260		Results	
Analyte Aroclor-1016 Aroclor-1260 Surrogates	0.26 0.79	Results 0.371965 0.8712	35.4 9.78
Analyte Aroclor-1016 Aroclor-1260	0.26	Results 0.371965	35.4
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene	0.26 0.79	0.371965 0.8712 0.896805	35.4 9.78 2.66
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene	0.26 0.79	0.371965 0.8712 0.896805	35.4 9.78 2.66
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl	0.26 0.79 0.921 1.02	0.371965 0.8712 0.896805	35.4 9.78 2.66
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1	0.26 0.79 0.921 1.02	0.371965 0.8712 0.896805 1.012275	35.4 9.78 2.66 0.76
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte	0.26 0.79 0.921 1.02	0.371965 0.8712 0.896805 1.012275 Results	35.4 9.78 2.66 0.76 %RPD
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates	0.26 0.79 0.921 1.02 Blank	0.371965 0.8712 0.896805 1.012275	35.4 9.78 2.66 0.76 %RPD
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene	0.26 0.79 0.921 1.02 Blank	0.371965 0.8712 0.896805 1.012275 Results	35.4 9.78 2.66 0.76 %RPD
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene	0.26 0.79 0.921 1.02 Blank	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619	35.4 9.78 2.66 0.76 %RPD 3.48 3.3
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte	0.26 0.79 0.921 1.02 Blank 1.76 1.08	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results	35.4 9.78 2.66 0.76 %RPD 3.48 3.3
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte Aroclor-1016	0.26 0.79 0.921 1.02 Blank 1.76 1.08 LCS	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results 0.5513	35.4 9.78 2.66 0.76 %RPD 3.48 3.3 %RPD 18.1
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte Aroclor-1016 Aroclor-1260	0.26 0.79 0.921 1.02 Blank 1.76 1.08	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results	35.4 9.78 2.66 0.76 %RPD 3.48 3.3
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte Aroclor-1016 Aroclor-1260 Surrogates	0.26 0.79 0.921 1.02 Blank 1.76 1.08 LCS	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results 0.5513 0.45178	35.4 9.78 2.66 0.76 %RPD 3.48 3.3 %RPD 18.1
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte Aroclor-1016 Aroclor-1260	0.26 0.79 0.921 1.02 Blank 1.76 1.08 LCS	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results 0.5513	35.4 9.78 2.66 0.76 %RPD 3.48 3.3 %RPD 18.1 2.64
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte Aroclor-1016 Aroclor-1260 Surrogates Decachlorobiphenyl	0.26 0.79 0.921 1.02 Blank 1.76 1.08 LCS 0.46 0.44	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results 0.5513 0.45178 1.82638	35.4 9.78 2.66 0.76 %RPD 3.48 3.3 %RPD 18.1 2.64
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte Aroclor-1016 Aroclor-1260 Surrogates Decachlorobiphenyl	0.26 0.79 0.921 1.02 Blank 1.76 1.08 LCS	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results 0.5513 0.45178 1.82638	35.4 9.78 2.66 0.76 %RPD 3.48 3.3 %RPD 18.1 2.64
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte Aroclor-1016 Aroclor-1260 Surrogates Decachlorobiphenyl Tetrachloro-m-xylene	0.26 0.79 0.921 1.02 Blank 1.76 1.08 LCS 0.46 0.44	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results 0.5513 0.45178 1.82638	35.4 9.78 2.66 0.76 %RPD 3.48 3.3 %RPD 18.1 2.64
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte Aroclor-1016 Aroclor-1260 Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BSD1	0.26 0.79 0.921 1.02 Blank 1.76 1.08 LCS 0.46 0.44	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results 0.5513 0.45178 1.82638 1.19338	35.4 9.78 2.66 0.76 %RPD 3.48 3.3 %RPD 18.1 2.64 1.82 3.7
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte Aroclor-1016 Aroclor-1260 Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BSD1 Analyte Aroclor-1260 Aroclor-1260 Aroclor-1260 Aroclor-1016 Aroclor-1016 Aroclor-1016 Aroclor-1016 Aroclor-1016 Aroclor-1016 Aroclor-1260	0.26 0.79 0.921 1.02 Blank 1.76 1.08 LCS 0.46 0.44 1.86 1.15 LCS Dup	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results 0.5513 0.45178 1.82638 1.19338 Results	35.4 9.78 2.66 0.76 %RPD 3.48 3.3 %RPD 18.1 2.64 1.82 3.7
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte Aroclor-1016 Aroclor-1260 Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BSD1 Analyte Aroclor-1260 Surrogates Decachlorobiphenyl Tetrachloro-m-xylene	0.26 0.79 0.921 1.02 Blank 1.76 1.08 LCS 0.46 0.44 1.86 1.15 LCS Dup	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results 0.5513 0.45178 1.82638 1.19338 Results 0.45664 0.47763	35.4 9.78 2.66 0.76 %RPD 3.48 3.3 %RPD 18.1 2.64 1.82 3.7
Analyte Aroclor-1016 Aroclor-1260 Surrogates Tetrachloro-m-xylene Decachlorobiphenyl B056412-BLK1 Analyte Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BS1 Analyte Aroclor-1016 Aroclor-1260 Surrogates Decachlorobiphenyl Tetrachloro-m-xylene B056412-BSD1 Analyte Aroclor-1260 Aroclor-1260 Aroclor-1260 Aroclor-1016 Aroclor-1016 Aroclor-1016 Aroclor-1016 Aroclor-1016 Aroclor-1016 Aroclor-1260	0.26 0.79 0.921 1.02 Blank 1.76 1.08 LCS 0.46 0.44 1.86 1.15 LCS Dup	Results 0.371965 0.8712 0.896805 1.012275 Results 1.69976 1.11619 Results 0.5513 0.45178 1.82638 1.19338 Results 0.45664	35.4 9.78 2.66 0.76 %RPD 3.48 3.3 %RPD 18.1 2.64 1.82 3.7



APPENDIX C: PERIMETER DUST MONITORING PLAN

APPENDIX C -PERIMETER DUST MONITORING PLAN

Airborne particulate matter (PM) consists of many different substances suspended in air in the form of particles (solids or liquid droplets) that vary widely in size. Inhalation hazards may be presented if the intake of these particles includes intake of vapors and/or contaminated dust. Particles less than 10 micrometers in diameter (PM-10), which include both respirable fine (less than 2.5 micrometers) and coarse (less than 10 micrometers) dust particles, pose the greatest potential health concern because they can pass through the nose and throat and get into the lungs.

During the performance of the planned remediation activities, particulate matter in the form of potentially PCB-affected dust may be generated. The greatest potential for the generation of affected dust is during saw cutting for waste segregation and removal of concrete coated with ductwork sealant.

As indicated in the remediation plan, the main dust control mechanism to be employed on the project will be the use of engineering controls (e.g. wet techniques and misting), polyethylene containment structures, and personal protective equipment (PPE). In addition, particulate air monitoring will be conducted during intrusive or dust-generating activities in the Support Work Zone (SWZ) and perimeter to the SWZ. The SWZ is the area just outside of the active work areas, in designated safe work zones or support zones. Particulate air monitoring will determine if fugitive dust particles are present in the ambient air within the designated SWZ and/or perimeter during active removal activities. A direct-reading particulate meter will be used to monitor airborne particulate concentrations during site activities. Particulate concentrations shall be utilized as an indirect indicator of exposures to on-site receptors.

Dust concentrations in the SWZ will be measured using a suitable real time aerosol particulate monitor capable of determining ambient air fugitive dust concentrations to 0.001 milligrams per cubic meter (mg/m³). Air monitoring shall be conducted while active removal activities are occurring and at a frequency of one reading every two hours during active dust generating activities. Prior to the active removal actions and at periodic points during the project, air monitoring readings will be recorded to document background particulate matter concentrations.

If total particulate concentrations in the SWZ exceed the action limits (as specified below and incorporating background readings) and are sustained (i.e. greater than 5 minutes), then the following actions will be taken:

- Engineering controls (HEPA filtration, containment, etc.) will be inspected to insure proper operation;
- Work practices will be evaluated:
- Additional dust suppression techniques to mitigate fugitive dust shall be initiated.

Any additional dust suppression techniques shall involve the application of a fine mist of water over the area creating the fugitive dust condition. The water shall be applied either by hand held sprayers, sprinklers, or water hoses/misters. In the event that the total airborne particulate cannot be maintained below the action limit in the SWZ, then work activities shall be ceased until sustained readings are below the action limit or the SWZ designation is reevaluated.

OSHA has published the following permissible exposure limits (8 hour time weighted average) for air contaminants (29 CFR 1910.1000):

Air Contaminant	PEL (8-hour TWA)
Total Dust	15 mg/m ³
Respirable Dust Fraction	5 mg/m³
PCBs (42% Chlorine)	1 mg/m³
PCBs (54% Chlorine)	0.5 mg/m ³

In addition, EPA has established a National Ambient Air Quality Standard for PM-10 of 0.150 mg/m³ (24-hr average).

APPENDIX C -PERIMETER DUST MONITORING PLAN

A total airborne particulate action limit has been established for the building material removal work to be conducted at the Kline Chemistry Laboratory with consideration of the specific receptors, PCB concentrations, work activities, and OSHA permissible exposure limits. The action limit applies only to dust monitoring within the SWZ and perimeter to the SWZ; an action limit has not been set for the active work zones (exclusion zones) as engineering controls and PPE will be used within these zones.

Given the occupancy and use of surrounding buildings (classroom and office buildings) and the anticipated PCB concentration in dust that may be generated during abatement activities, a conservative action limit of 0.1 mg/m³ above background will be maintained during site work. Dust monitoring at a location representative of background air conditions (i.e. a location upwind without active remedial activities in progress) will be conducted at the same frequency as SWZ monitoring to obtain data representative of real-time background conditions. The action limit will be used to determine if and when additional engineered controls and/or work stoppages would be necessary.



APPENDIX D: MANUFACTURER'S PRODUCT INFORMATION

Product Data Sheet

Edition 7.2003 Identification no. 601 Sikagard 62

Sikagard® 62

High-build, protective, solvent-free, colored epoxy coating

Description	Sikagard 62 is a 2-component, 100% solids, moisture-tolerant epoxy resin. It produces a high-build, protective, dampproofing and waterproofing vapor-barrier system.
Where to Use	Use as a high build, corrosion-resistant, protective coating, as a protective lining for secondary containment structures or as a seamless flooring system.
Advantages	 Exceptional tensile strength. Good chemical resistance for long-term protection. Convenient A:B = 1:1 mixing ratio.
	 Easy, paint-like viscosity. Available in 3 standard colors: gray, red, and tan. Special color matches available upon request. Excellent bonding to all common structural substrates.
	 Super abrasion resistance for long-term wear. Sikagard 62 gray, after cure, is approved for contact with potable water. Material is USDA certifiable.
Coverage	Approximately 150-250 sq. ft./gal. depending on condition of substrate.
Packaging	4 gal. units; 1 qt. units, 12/case.
How to Use	
Surface Preparation	Surface must be clean and sound. It may be dry or damp, but free of standing water. Remove dust, laitance, grease, curing compounds, impregnations, waxes and any other contaminants.
	Preparation Work: Concrete - Should be cleaned and prepared to achieve a laitance and contaminant free, open textured surface by blastcleaning or equivalent mechanical means.
	Steel - Should be cleaned and prepared thoroughly by blastcleaning.
Mixing	Pre-mix each component. Proportion equal parts by volume of Components 'A' and 'B' into a clean mixing container. Mix with a low-speed (400-600 rpm) drill using a Sika paddle for 3 minutes, until uniform in color.
Application	Apply coating using high-quality roller, brush or spray. Two coats are recommended. Apply second coat as soon as the first coat is tack-free and the traffic of application will not damage the first coat. The



Shelf Life 2 years in original, unopened containers.

Storage Conditions Store dry at 40°-95°F (4°-35°C). Condition material to 65°-75°F

(18°-24°C) before using.

Color Gray, red, tan.

Mixing Ratio Component 'A': Component 'B'=1:1 by volume.

Viscosity (Mixed) Approximately 3,500 cps.

Pot Life Approximately 35 to 40 minutes. (60 gram mass).

Tack-Free Time Approximately 4 hours.

Open Time Light foot traffic: 5-7 hours. Rubber-wheel traffic: 8-10 hours.

Immersion and Chemical Exposure Minimum cure: 3 days

Tensile Properties (ASTM D-638)

14 day Tensile Strength 5,400 psi (37.3 MPa)

Elongation at Break 2.7 %

Abrasion (ASTM D-1044) (Taber Abrader)

7 day Weight loss, 1,000 cycles (H-22 wheel, 1,000 gm weight) 0.61 gm

Abrasion Resistance (ASTM D-968)

14 day Abrasion Coefficient 51 liters/mil.

Adhesion (ASTM D-3359)

1 day Adhesion Classification 4A

Water Absorption (ASTM D-570)

7 day (24 hour immersion) 0.1%



second coat, however, must be applied within 48 hours since a longer delay will require additional surface preparation.

Do not spray with slip resistant granules mixed into the coating. For use as a seamless flooring system, consult Technical Service.

Limitations

- Minimum substrate and ambient temperature for application 50°F (10°C).
- Do not apply over wet, glistening surface.
- Material is a vapor barrier after cure.
- Do not apply to porous surfaces exhibiting moisture-vapor transmission during the application. Consult Technical Service
- Minimum age of concrete prior to application is 21-28 days, depending on curing and drying conditions.
- Do not apply to exterior, on-grade substrates.
- Use oven-dried aggregate only.
- Do not thin with solvents.
- Color may alter due to variations in lighting and/or UV exposure.
- On 'green or 'damp' concrete, EpoCem can be used as a pore filler to reduce vapor drive and potential osmotic

Caution

Component 'A' - Irritant; Sensitizer - Contains epoxy resin. Can cause sensitization after prolonged or repeated contact. Skin and eye irritant. Vapors may cause respiratory irritation. Use only with adequate ventilation. Use of safety goggles and chemical resistant gloves is recommended. In case of high vapor concentrations, use an appropriate NIOSH approved respirator. Remove contaminated clothing.

Component 'B' - Sensitizer - Contains amines. Contact with eyes or skin may cause severe burns. Can cause sensitization after prolonged or repeated contact. Skin and eye irritant. Vapors may cause respiratory irritation. Use only with adequate ventilation. Use of safety goggles and chemical resistant gloves is recommended. In case of high vapor concentrations, use an appropriate NIOSH approved respirator. Remove contaminated clothing.

First Aid

Eyes: Hold eyelids apart and flush thoroughly with water for 15 minutes. Skin: Remove contaminated clothing. Wash skin thoroughly for 15 minutes with soap and water. Inhalation: Remove person to fresh air. Ingestion: Do not induce vomiting. In all cases, contact a physician immediately if symptoms persist.

Clean Up

Ventilate area. Confine spill. Collect with absorbent material. Dispose of in accordance with current, applicable local, state and federal regulations. Uncured material can be removed with approved solvent. Cured material can only be removed mechanically.

Chemical Resistance

Specimen: Two Coats - 10 mils Total

Cured 10 days

Substrate: asbestos cement

		Storage Time and Evaluation					
Chemical	Test Temp.	1 Day	1 Month	2 Months	6 Months	12 Months	
Water	75°F (24°C) 100°F (38°C) 140°F (60°C)	A A A	A A A	A A A	A A A, D	A A A, D	
Sodium Chloride Solution (Saturated)	75°F (24°F) 100°F (38°C)	A A	A A	A A	A A	A A	
Sodium Hydroxide 30%	75°F (24°C)	Α	Α	Α	А	А	
Cement Water (Saturated)	75°F (24°C)	Α	Α	Α	Α	А	
Detergent Solution (5% Ajax)	75°F (24°C) 140°F (60°C)	A A	A A	A A	A A, D	A A, D	
Hydrochloric Acid 10%	75°F (24°C)	А	Α	А	А	А	
Sulfuric Acid 10%	75°F (24°C)	Α	Α	Α	В	В	
Oxalic Acid 10%	75°F (24°C)	Α	A, D	A, D	A, D	A, D	
Citric Acid 10%	75°F (24°C)	Α	A, D	A, D	A, D	A, D	
Fuel Oil (Home Heating)	75°F (24°C)	Α	А	А	А	A, D	
Gasoline (Unleaded)	75°F (24°C)	Α	Α	А	А	A, D	
Iso-Octane	75°F (24°C)	Α	Α	Α	А	A, D	
Toluol	75°F (24°C)	Α	Α	Α	А	A, D	
Silage	75°F (24°C)	А	А	A, D	A, D	B, D	
Synthetic Silage	75°F (24°C)	Α	Α	B, D	B, D	B, D	
Ethyl Alcohol	75°F (24°C)	Α	С	-	-	-	

- A: Resistant in permanent contact
- B: Temporary resistance
- C: Destroyed
- D: Discolored

KEEP CONTAINER TIGHTLY CLOSED NOT FOR INTERNAL CONSUMPTION KEEP OUT OF REACH OF CHILDREN FOR INDUSTRIAL USE ONLY

CONSULT MATERIAL SAFETY DATA SHEET FOR MORE INFORMATION

Sika warrants this product for one year from date of installation to be free from manufacturing defects and to meet the technical properties on the current Technical Data Sheet if used as directed within shelf life. User determines suitability of product for intended use and assumes all risks. Buyer's sole remedy shall be limited to the purchase price or replacement of product exclusive of labor or cost of labor

NO OTHER WARRANTIES EXPRESS OR IMPLIED SHALL APPLY INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SIKA SHALL NOT BE LIABLE UNDER ANY LEGAL THEORY FOR SPECIAL OR CONSEQUENTIAL DAMAGES. SIKA SHALL NOT BE RESPONSIBLE FOR THE USE OF THIS PRODUCT IN A MANNER TO INFRINGE ON ANY PATENT OR ANY OTHER INTELLECTUAL PROPERTY RIGHTS HELD BY OTHERS

Visit our website at www.sikaconstruction.com

1-800-933-SIKA NATIONWIDE

marks. Made in USA. Printed in USA.


Regional Information and Sales Centers. For the location of your nearest Sika sales office, contact your regional center.


Sika Corporation 201 Polito Avenue Lyndhurst, NJ 07071 Phone: 800-933-7452 Fax: 201-933-6225

Sika Canada Inc. 601 Delmar Avenue Pointe Claire Quebec H9R 4A9 Phone: 514-697-2610 Fax: 514-694-2792

Sika Mexicana S.A. de C.V. Carretera Libre Celaya Km. 8.5 Corregidora, Queretaro C.P. 76920 A.P. 136 Phone: 52 42 25 0122 Fax: 52 42 25 0537









DIVISION 9 - FINISHES

Section 09900 Coatings

Part 1 - General

1.01 Summary

A. This specification describes the coating of substrates with a vapor-barrier, solvent-free, protective, dampproofing, waterproofing, moisture-insensitive, epoxy resin coating.

1.02 Quality Assurance

- A. Manufacturing qualifications: The manufacturer of the specified product shall be ISO 9001 certified and have in existence a recognized ongoing quality assurance program independently audited on a regular basis.
- B. Contractor qualifications: Contractor shall be qualified in the field of concrete repair and protection with a successful track record of 5 years or more. Contractor shall maintain qualified personnel who have received product training by a manufacturer's representative.
- C. Install materials in accordance with all safety and weather conditions required by manufacturer or as modified by applicable rules and regulations of local, state and federal authorities having jurisdiction. Consult Material Safety Data Sheets for complete handling recommendations.

1.03 Delivery, Storage, and Handling

- A. All materials must be delivered in original, unopened containers with the manufacturer's name, labels, product identification, and batch numbers. Damaged material must be removed from the site immediately.
- B. Store all materials off the ground and protect from rain, freezing or excessive heat until ready for use.
- C. Condition the specified product as recommended by the manufacturer.

1.04 Job Conditions

- A. Environmental Conditions: Do not apply material if it is raining or snowing or if such conditions appear to be imminent. Minimum application temperature 40°F (5°C) and rising.
- B. Protection: Precautions should be taken to avoid damage to any surface near the work zone due to mixing and handling of the specified material.

1.05 Submittals

A. Submit two copies of manufacturer's literature, to include: Product Data Sheets and appropriate Material Safety Data Sheets (MSDS).

1.06 Warranty

A. Provide a written warranty from the manufacturer against defects of materials for a period of five (5) years, beginning with date of substantial completion of the project.

Part 2 - Products

2.01 Manufacturer

A. **Sikagard 62**, as manufactured by Sika Corporation, 1682 Marion Williamsport Road, Marion, Ohio, 43302 is considered to conform to the requirements of this specification.

2.02 Materials

- A. Epoxy resin coating:
 - 1. Component A shall be a epoxy resin of diglycidilether of bisphenol A containing suitable viscosity control agents. It shall not contain butyl glycidyl ether.
 - 1. Component B shall be primarily a reaction product of a selected amine blend with an epoxy resin of the epichlorohydrin bisphenol A type containing suitable viscosity control agents, pigments, and accelerators.
 - 2. The ratio of Component A: Component B shall be 1:1 by volume
- B. Granules for slip-resistance shall be supplied by the manufacturer of the specified product and shall be able to be mixed into the coating and shall not settle during application.

2.03 Performance Criteria

- A. Typical Properties of the mixed epoxy resin coating:
 - 1. Application Life: Approximately 20 25 minutes
 - 2. Tack FreeTime: Approximately 4 hours
 - 3. Color: red, grey, tan
 - 4. Solids: 100% VOC g/l: 0.00 Max.
 - 5. Immersion & Chemical Exposure: min. Cure 3 Days
- B. Typical Properties of the cured epoxy resin coating:
 - 1. Water Absorption (ASTM D-570) at 7days: 1.0% max. (2 hour boil)
 - 2. Elongation (ASTM D-522) at 14 days: 5% min.
 - 3. Abrasion Resistance (ASTM D-968) at 14 days: 51 liters/mil
 - 4. Adhesion classification (ASTM 3359) at 14 days: 4A min.
 - 5. Abrasion (Taber Abrader) at 7 days: Weight loss: 0.65 gm. max. (H-22 wheel; 1000 gm weight; 1000 cycles)
 - 6. Tensile Properties (ASTM D-638) at 14 days: Tensile Strength 6400 psi (44.1 Mpa) / Elongation at Break 2.7%
 - 7. Bond Strength (ASTM C-882) Hardened Concrete to Hardened Concrete
 - a. 2 Day (dry cure): 2000 psi min.
 - b. 14 Day (moist cure): 1500 psi min.
 - 8. The coating shall have United States Department of Agriculture approval.

Note: Tests above were performed with the material and curing conditions @ $71^{\circ}F - 75^{\circ}F$ and 45-55% relative humidity.

Part 3 – Execution

3.01 Surface Preparation

A. Substrate must be clean, sound, and free of surface contaminants. Remove dust, laitance, grease, oils, curing compounds, form release agents and all foreign particles by mechanical means. Substrate shall be in accordance with ICRI Guideline No. 03732 for coatings.


3.02 Mixing and Application

- A. Mixing: Premix each component. Proportion equal parts by volume of Component A and Component B into a clean, dry mixing pail. Mix throughly for 3 minutes min. with a jiffy paddle on a low-speed (400-600 rpm) drill. Mix only that quantity of material that can be used within its pot life (35 minutes at 73F). To minimize color difference, blend two complete Components B's together. Use only one of the blended Component B's to mix with a Component A. After the first Component B has been used, blend the second Component B with a new Component B and repeat the above procedeure for the entire application.
- B. Placement Procedure: The epoxy resin coating shall be applied only to approved, prepared surfaces with high-quality brushes, rollers, or spray equipment. Coating shall be applied at ambient and substrate temperatures between 50 and 90F. Application thickness shall be between 4-7 mils per coat. Subsequent coats shall be applied within 48 hours of the previous coat. Care is to be taken on vertical and overhead surfaces to avoid sags or runs. If this occurs, it must be sanded out and the area re-coated. If coating of horizontal surfaces that will receive traffic is specified, a slip-resistant aggregate, Sikagard 62 Granules, shall be incorporated into the mixed epoxy resin coating at 1/2 lb./gallon or as directed by the engineer.
- C. When applying the coating, if possible never stop the application until the entire surface has been coated. If possible always discontinue at an edge, corner, or joint. Never let a previously coated film dry. Always coat into wet film. Always apply the coating at a 45° angle to an edge, corner, or joint.
- E. Adhere to all limitations and cautions for the epoxy resin as stated in the manufacturers printed literature.

3.03 Cleaning

- A. The uncured epoxy resin coating can be cleaned from tools with an approved solvent. The cured epoxy resin coating can only be removed mechanically.
- B. Leave finished work and work area in a neat, clean condition without evidence of spillovers onto adjacent areas.

SC-054 Sikagard 62 Coating



- 1. Apply Sikagard 62 with high quality brushes or rollers. Care should be taken to avoid sags or runs.
- 2. When applying the coating, never stop the application until the entire surface has been coated.
- 3. Subsequent coats shall be applied within 48 hours of the previous coat.
- 4. For a slip-resistant surface, aggregate shall be incorporated into the mixed epoxy resin coating at a ½ lb./gal.

Note: When applying Sikagard 62 always end at an edge, corner or joint. Do not apply 62 directly over joint filler.

Concrete Restoration Systems by Sika Corporation, 201 Polito Avenue, Lyndhurst, NJ 07071



Sikagard 62 - Part A (ALL COLORS)

HMIS

HEALTH	2
FLAMMABILITY	1
REACTIVITY	0
PERSONAL PROTECTION	С

1. Product And Company Identification

Supplier
Sika Corporation
201 Polito Ave
Lyndhurst, NJ 07071

Company Contact: EHS Department Telephone Number: 201-933-8800 FAX Number: 201-933-9379 Web Site: www.sikausa.com

Supplier Emergency Contacts & Phone Number

CHEMTREC: 800-424-9300 INTERNATIONAL: 703-527-3887 Manufacturer
Sika Corporation
201 Polito Ave
Lyndhurst, NJ 07071

Company Contact: EHS Department Telephone Number: 201-933-8800 FAX Number: 201-933-9379 Web Site: www.sikausa.com

Manufacturer Emergency Contacts & Phone Number

CHEMTREC: 800-424-9300 INTERNATIONAL: 703-527-3887

Issue Date: 11/27/2007

Product Name: Sikagard 62 - Part A (ALL COLORS)

CAS Number: Not Established
Chemical Family: Epoxy Compound

MSDS Number: 4220 Product Code: 0601130

2. Composition/Information On Ingredients

Ingredient Name	CAS Number	Percent Of Total Weight
AROMATIC HYDROCARBON BLEND	68477-31-6	
EPOXY RESIN	25085-99-8	

3. Hazards Identification

Eye Hazards

EYE IRRITANT.

Skin Hazards

MAY CAUSE SKIN IRRITATION. PROLONGED AND/OR REPEATED CONTACT WITH SKIN MAY CAUSE AN ALLERGIC REACTION/SENSITIZATION.

Ingestion Hazards

ACUTELY TOXIC. HARMFUL IF ASPIRATED INTO LUNGS.

Sikagard 62 - Part A (ALL COLORS)

3. Hazards Identification - Continued

Inhalation Hazards

MAY CAUSE RESPIRATORY TRACT IRRITATION.

4. First Aid Measures

Eve

RINSE EYES THOROUGHLY WITH WATER FOR AT LEAST 15 MINUTES. CONSULT PHYSICIAN.

Skin

WASH SKIN THOROUGHLY WITH SOAP AND WATER. REMOVE CONTAMINATED CLOTHING. IF SYMPTOMS PERSIST CONSULT PHYSICIAN.

Ingestion

DILUTE WITH WATER. DO NOT INDUCE VOMITING. CONTACT PHYSICIAN.

Inhalation

REMOVE TO FRESH AIR. IF BREATHING HAS STOPPED, INSTITUTE ARTIFICIAL RESPIRATION. CONSULT WITH PHYSICIAN.

5. Fire Fighting Measures

Flash Point: 355 °F

Autoignition Point: N/AV °F

Fire And Explosion Hazards

NONE KNOWN

Extinguishing Media

In case of fire, use water spray (fog) foam, dry chemical, or CO2.

Fire Fighting Instructions

In the event of a fire, firefighters should wear full protective clothing and NIOSH-approved self-contained breathing apparatus with a full facepiece operated in the pressure demand or other positive pressure mode.

6. Accidental Release Measures

WEARING PROPER PROTECTIVE CLOTHING, CONTAIN SPILL AND COLLECT WITH ABSORBENT MATERIAL. SHOVEL INTO CLOSABLE CONTAINERS. AVOID CONTACT.

7. Handling And Storage

Handling And Storage Precautions

STORE IN A COOL AREA. KEEP CONTAINERS TIGHTLY CLOSED.

Work/Hygienic Practices

Wash thoroughly with soap and water after handling.

8. Exposure Controls/Personal Protection

Engineering Controls

Use with adequate general and local exhaust ventilation. Refer to the current edition of "Industrial Ventilation: A Manual of Recommended Practice" published by the American Conference of Governmental Industrial Hygienists for information on the design, installation, use, and maintenance of exhaust systems.

Eye/Face Protection

Safety glasses with side shields or goggles.

Skin Protection

AVOID SKIN CONTACT. WEAR LONG SLEEVE SHIRT AND LONG PANTS. WEAR CHEMICAL RESISTANT GLOVES.

Sikagard 62 - Part A (ALL COLORS)

8. Exposure Controls/Personal Protection - Continued

Respiratory Protection

A respirator protection program that meets 29 CFR 1910.134 requirement must be followed whenever workplace conditions warrant a respirator's use.

Other/General Protection

WASH THOROUGHLY AFTER HANDLING.

Ingredient(s) - Exposure Limits

AROMATIC HYDROCARBON BLEND ACGIH TLV: NOT ESTABLISHED OSHA PEL: NOT ESTABLISHED

NTP: NO IARC: NO EPOXY RESIN

ACGIH TLV: NOT ESTABLISHED OSHA PEL: NOT ESTABLISHED

NTP: NO IARC: NO

9. Physical And Chemical Properties

Appearance

LIGHT YELLOW LIQUID

Odor

MILD AROMATIC ODOR

Chemical Type: Mixture Physical State: Liquid Melting Point: N/AV °F Boiling Point: N/AV °F Specific Gravity: 1.14 Percent Volatiles: 0% Vapor Pressure: N/AV Vapor Density: > AIR Solubility: N/AV

Evaporation Rate: SLOWER THAN ETHER VOC Content (A+B): < 100 grams / liter

10. Stability And Reactivity

Stability: STABLE

Hazardous Polymerization: WILL NOT OCCUR

Conditions To Avoid (Stability)

NONE KNOWN

Incompatible Materials

STRONG OXIDIZING MATERIALS, ACIDS AND BASES.

Hazardous Decomposition Products

CO, CO2, ALDEHYDES AND OTHER ORGANICS

Conditions To Avoid (Polymerization)

FIRES/EXOTHERM WHEN CURING IN MASS.

Sikagard 62 - Part A (ALL COLORS)

11. Toxicological Information

Conditions Aggravated By Exposure

EYE DISEASE, SKIN DISORDERS AND ALLERGIES, CHRONIC RESPIRATORY DISEASE

12. Ecological Information

No Data Available...

13. Disposal Considerations

Dispose in accordance with applicable federal, state and local government regulations.

14. Transport Information

Proper Shipping Name

NOT REGULATED UNDER D.O.T.

15. Regulatory Information

U.S. Regulatory Information

All ingredients of this product are listed or are excluded from listing under the U.S. Toxic Substances Control Act (TSCA) Chemical Substance Inventory.

SARA Hazard Classes

Acute Health Hazard Chronic Health Hazard

SARA Section 313 Notification

This product does not contain any ingredients regulated under Section 313 of the Emergency Planning and Community Right-To-Know Act of 1986 or 40 CFR 372.

16. Other Information

HMIS Rating Health: 2 Fire: 1 Reactivity: 0 PPE: C

Revision/Preparer Information MSDS Preparer: EHS Department

MSDS Preparer Phone Number: 201-933-8800

This MSDS Supercedes A Previous MSDS Dated: 02/20/2007

Disclaimer

The information contained in this Material Safety Data Sheet applies only to the actual Sika Corporation ("Sika") product identified and described herein. This information is not intended to address, nor does it address the use or application of the identified Sika product in combination with any other material, product or process. All of the information set forth herein is based on technical data regarding the identified product that Sika believes to be reliable as of the date hereof. Prior to each use of any Sika product, the user must always read and follow the warnings and instructions on the product's current Technical Data Sheet, product label and Material Safety Data Sheet for each Sika product, which are available at web site and/or telephone number listed in Section 1 of this MSDS.

SIKA MAKES NO WARRANTIES EXPRESS OR IMPLIED AND ASSUMES NO LIABILITY ARISING FROM THIS INFORMATION OR ITS USE. SIKA SHALL NOT BE LIABLE UNDER ANY LEGAL THEORY FOR SPECIAL OR CONSEQUENTIAL DAMAGES AND SHALL NOT BE RESPONSIBLE FOR THE USE OF THIS PRODUCT IN A

Sikagard 62 - Part A (ALL COLORS)

Disclaimer - Continued

MANNER TO INFRINGE ON ANY PATENT OR ANY OTHER INTELLECTUAL PROPERTY RIGHTS HELD BY OTHERS.

All sales of Sika products are subject to its current terms and conditions of sale available at www.sikacorp.com or 201-933-8800.

SIKA CORPORATION

Printed Using MSDS Generator™ 2000



Sikagard 62 - Part B (ALL COLORS)

HMIS

HEALTH	3
FLAMMABILITY	1
REACTIVITY	0
PERSONAL PROTECTION	С

1. Product And Company Identification

Sika Corporation 201 Polito Ave Lyndhurst, NJ 07071

Company Contact: EHS Department **Telephone Number: 201-933-8800** FAX Number: 201-933-9379

Web Site: www.sikausa.com

CHEMTREC: 800-424-9300

INTERNATIONAL: 703-527-3887

Supplier Emergency Contacts & Phone Number

DOT NON CORROSIVE AS PER 11/3/97 TESTING

Issue Date: 11/27/2007

Product Name: Sikagard 62 - Part B (ALL COLORS)

CAS Number: Not Established Chemical Family: Amine MSDS Number: 4221 Product Code: 0601792

Manufacturer

Sika Corporation 201 Polito Ave Lyndhurst, NJ 07071

Company Contact: EHS Department **Telephone Number: 201-933-8800**

FAX Number: 201-933-9379 Web Site: www.sikausa.com

Manufacturer Emergency Contacts & Phone Number

CHEMTREC: 800-424-9300 INTERNATIONAL: 703-527-3887

2. Composition/Information On Ingredients

Ingredient	CAS	Percent Of
Name	Number	Total Weight
AROMATIC HYDROCARBON BLEND	68477-31-6	
BENZYL ALCOHOL	100-51-6	
PROPRIETARY BLEND OF ALIPHATIC & CYCLIC AMINES	Not Establis	
SILICA, QUARTZ	14808-60-7	

*EXPOSURE TO SILICA, QUARTZ IS APPLICABLE ONLY IF CURED WITH PART "A" AND SANDED.

3. Hazards Identification

Eye Hazards

CONTACT MAY CAUSE SEVERE IRRITATION AND PAIN AND MAY CAUSE BURNS, NECROSIS AND PERMANENT INJURY. MAY CAUSE VISUAL DISTURBANCES, CORNEA DAMAGE, DAMAGE TO THE OPTIC NERVE OR BLINDNESS.

Sikagard 62 - Part B (ALL COLORS)

3. Hazards Identification - Continued

Skin Hazards

CONTACT MAY CAUSE SEVERE IRRITATION AND PAIN AND MAY CAUSE BURNS, NECROSIS AND PERMANENT INJURY. PROLONGED AND/OR REPEATED CONTACT WITH SKIN MAY CAUSE ANALLERGIC REACTION/SENSITIZATION.

Ingestion Hazards

ACUTELY TOXIC. HARMFUL IF ASPIRATED INTO LUNGS.

Inhalation Hazards

MAY CAUSE RESPIRATORY TRACT IRRITATION. OVEREXPOSURE MAY CAUSE CENTRAL NERVOUS SYSTEM EFFECTS.

4. First Aid Measures

Eve

RINSE EYES THOROUGHLY WITH WATER FOR AT LEAST 15 MINUTES. CONSULT PHYSICIAN.

Skin

WASH SKIN THOROUGHLY WITH SOAP AND WATER. REMOVE CONTAMINATED CLOTHING. IF SYMPTOMS PERSIST CONSULT PHYSICIAN.

Ingestion

DILUTE WITH WATER. DO NOT INDUCE VOMITING. CONTACT PHYSICIAN.

Inhalation

REMOVE TO FRESH AIR. IF BREATHING HAS STOPPED, INSTITUTE ARTIFICIAL RESPIRATION. CONSULT WITH PHYSICIAN.

5. Fire Fighting Measures

Flash Point: >220 °F

Autoignition Point: N/AV °F

Fire And Explosion Hazards

EXPOSURE TO HEAT BUILDS UP PRESSURE IN CLOSED CONTAINERS.

Extinguishing Media

In case of fire, use water spray (fog) foam, dry chemical, or CO2.

Fire Fighting Instructions

In the event of a fire, firefighters should wear full protective clothing and NIOSH-approved self-contained breathing apparatus with a full facepiece operated in the pressure demand or other positive pressure mode.

6. Accidental Release Measures

WEAR SUITABLE PROTECTIVE EQUIPMENT. VENTILATE AREA. CONTAIN SPILL AND COLLECT WITH ABSORBENT MATERIAL AND TRANSFER INTO SUITABLE CONTAINERS. AVOID CONTACT.

7. Handling And Storage

Handling And Storage Precautions

STORE IN A COOL, DRY, WELL VENTILATED AREA. KEEP CONTAINERS TIGHTLY CLOSED.

Work/Hygienic Practices

Wash thoroughly with soap and water after handling.

Sikagard 62 - Part B (ALL COLORS)

8. Exposure Controls/Personal Protection

Engineering Controls

Use with adequate general and local exhaust ventilation.

Eye/Face Protection

Safety glasses with side shields or goggles.

Skin Protection

AVOID SKIN CONTACT. WEAR LONG SLEEVE SHIRT AND LONG PANTS. CHEMICAL RESISTANT GLOVES.

Respiratory Protection

A respirator protection program that meets 29 CFR 1910.134 requirement must be followed whenever workplace conditions warrant a respirator's use. In areas where the Permissible Exposure Limits are exceeded, use a properly fitted NIOSH-approved respirator.

Other/General Protection

WASH THOROUGHLY AFTER HANDLING.

Ingredient(s) - Exposure Limits

AROMATIC HYDROCARBON BLEND ACGIH TLV: NOT ESTABLISHED OSHA PEL: NOT ESTABLISHED

IARC: NO NTP: NO

PROPRIETARY BLEND OF ALIPHATIC & CYCLIC AMINES

ACGIH TLV: NOT ESTABLISHED OSHA PEL: NOT ESTABLISHED

IARC: NO NTP: NO SILICA, QUARTZ

ACGIH TLV-TWA 0.1 mg/m3 (Notice of Intended Change)

ACGIH TLV-TWA 0.05 mg/m3 (Proposed) OSHA PEL-TWA 30/%SiO2+2 mg/m3 OSHA PEL-TWA 10/%SiO2+2 mg/m3 OSHA PEL-TWA 250/%SiO+5 mppcf

9. Physical And Chemical Properties

Appearance

VISCOUS LIQUID (VARIOUS COLORS)

Odor

AMINE ODOR

Chemical Type: Mixture Physical State: Liquid Melting Point: N/AV °F Boiling Point: N/AV °F Specific Gravity: 1.70 Vapor Pressure: N/AV Vapor Density: >AIR Solubility: N/AV

Evaporation Rate: SLOWER THAN ETHER VOC Content (A+B): < 100 grams / liter

Sikagard 62 - Part B (ALL COLORS)

10. Stability And Reactivity

Stability: STABLE

Hazardous Polymerization: WILL NOT OCCUR

Conditions To Avoid (Stability)

NONE KNOWN

Incompatible Materials

STRONG OXIDIZING AGENTS, ACID AND EPOXY RESINS UNDER

UNCONTROLLED CONDITIONS

Hazardous Decomposition Products

CO, CO2, OXIDES OF NITROGEN

11. Toxicological Information

Miscellaneous Toxicological Information

Conditions Aggravated By Exposure

EYE DISEASE, SKIN DISORDERS AND ALLERGIES, CHRONIC RESPIRATORY CONDITIONS

Ingredient(s) - Carginogenicity

SILICA, QUARTZ

NTP - Listed On The National Toxicology Program

Listed In The IARC Monographs

12. Ecological Information

No Data Available...

13. Disposal Considerations

Dispose in accordance with applicable federal, state and local government regulations.

14. Transport Information

Proper Shipping Name

NOT REGULATED BY D.O.T.

15. Regulatory Information

U.S. Regulatory Information

All ingredients of this product are listed or are excluded from listing under the U.S. Toxic Substances Control Act (TSCA) Chemical Substance Inventory.

SARA Hazard Classes

Acute Health Hazard

Chronic Health Hazard

SARA Section 313 Notification

This product does not contain any ingredients regulated under Section 313 of the Emergency Planning and Community Right-To-Know Act of 1986 or 40 CFR 372.

State Regulations

WARNING: This product contains a chemical known to the State of California to cause cancer, birth defects, or other reproductive harm.

Sikagard 62 - Part B (ALL COLORS)

15. Regulatory Information - Continued

Ingredient(s) - State Regulations

BENZYL ALCOHOL

New Jersey - Workplace Hazard Pennsylvania - Workplace Hazard Massachusetts - Hazardous Substance

SILICA, QUARTZ

New Jersey - Workplace Hazard Pennsylvania - Workplace Hazard

California - Proposition 65

Massachusetts - Hazardous Substance

16. Other Information

HMIS Rating Health: 3

Fire: 1

Reactivity: 0 PPE: C

Revision/Preparer Information

MSDS Preparer: EHS Department

MSDS Preparer Phone Number: 201-933-8800

This MSDS Supercedes A Previous MSDS Dated: 02/20/2007

Disclaimer

The information contained in this Material Safety Data Sheet applies only to the actual Sika Corporation ("Sika") product identified and described herein. This information is not intended to address, nor does it address the use or application of the identified Sika product in combination with any other material, product or process. All of the information set forth herein is based on technical data regarding the identified product that Sika believes to be reliable as of the date hereof. Prior to each use of any Sika product, the user must always read and follow the warnings and instructions on the product's current Technical Data Sheet, product label and Material Safety Data Sheet for each Sika product, which are available at web site and/or telephone number listed in Section 1 of this MSDS.

SIKA MAKES NO WARRANTIES EXPRESS OR IMPLIED AND ASSUMES NO LIABILITY ARISING FROM THIS INFORMATION OR ITS USE. SIKA SHALL NOT BE LIABLE UNDER ANY LEGAL THEORY FOR SPECIAL OR CONSEQUENTIAL DAMAGES AND SHALL NOT BE RESPONSIBLE FOR THE USE OF THIS PRODUCT IN A MANNER TO INFRINGE ON ANY PATENT OR ANY OTHER INTELLECTUAL PROPERTY RIGHTS HELD BY OTHERS.

All sales of Sika products are subject to its current terms and conditions of sale available at www.sikacorp.com or 201-933-8800.

SIKA CORPORATION

Printed Using MSDS Generator™ 2000

Sikagard® 670W

Water dispersed, acrylic, protective, anti-carbonation coating

Description	Sikagard 670W is a water dispersed colored, acrylic, protective coating. Sikagard 670W prevents moisture ingress, is water vapor permeable and provides an excellent carbonation barrier. Above grade, exterior application on buildings or civil engineering structures. It is designed to aesthetically enhance and protect concrete and other masonry substrates subject to normal hydrothermal movement. Protective, decorative seal coat for SikaColor and Sikadur Balcony Systems.		
Where to Use			
Advantages	 Easy to apply. Extremely resistant to dirt pick-up and mildew. Excellent resistance to carbon dioxide and other aggressive gas diffusion. Excellent UV resistance. Excellent weathering resistance. Prevents ingress of chlorides. Cost effective protection. Vapor permeable; allows each way water vapor diffusion (breathable). 		
Coverage	Theoretical per coat: 300 sq. ft./gal. Wet film thickness: 5 mils. Dry film thickness: 2.5 mils. Normal coating system is two coats minimum at a total nominal dry film thickness of 5 mils. Consumption is obviously dependent on substrate. In addition, allowance must be made for surface profile, variations in applied film thickness, loss and waste. A third coat may be necessary where opacity is reduced through thinning of the first coat, on dense substrates or with very bright color shades.		
Packaging	5 gallon, re-closable plastic pails.		
How to Use Surface preparation	All surfaces to be coated must be clean, dry, laitance free, sound and frost-free with curing compound residues and any other contaminants removed. An open textured sandpaper-like surface is ideal (CSP-3). Where necessary, surfaces should be prepared mechanically by blast cleaning or high pressure waterjetting. Allow acquate time for drying. Bugholes, cracks or irregularities of substrate should be filled and		

leveled with SikaTop, Sika MonoTop leveling mortar or Sikagard Surface Fillers as appropriate.

Shelf Life 1 year in original, unopened container.

Storage Conditions Store dry at 40°-95°F (4°-35°C). Condition material to 60°-75°F

 $\begin{picture}(20,20) \put(0,0){\line(1,0){100}} \put(0,0){\line(1,0){10$

Colors 463 standard colors. Custom color-matching available.

Pot Life Indefinite, provided proper care is taken in protecting the system from moisture,

freezing, contamination, or evaporation.

Solids Content by weight: 60% by volume: 46%

Waiting and Drying Times

Between Coats:Rain Resistant AfterFinal Drying45°F (7°C) approx. 90 min.approx. 5 hoursapprox. 24 hours68°F (20°C) approx. 30 min.approx. 1 hourapprox. 4 hours85°F (30°C) approx. 20 min.approx. 40 min.approx. 3 hours

Water Vapor Diffusion (at 5 mils. = 120 microns dry film thickness)

 μ - value H₂O (diffusion coefficient) = 3,140 SdH₂O (equivalent air thickness) = 1.3 ft. (0.4 m)

Carbon Dioxide Diffusion (at 5 mils. = 120 microns dry film thickness)

μ- value CO₂ (diffusion coefficient) = 1,100,000 SdCO₂ (equivalent air thickness) = 433 ft. (132 m.)

Equivalent concrete thickness (Sc) = approximately 13 inches (33 cm.)

Moisture Vapor Permeability (ASTM E-96) 17.9 Perms

Flame Spread and Smoke Development (ASTM E-84-94)

Flame Spread: 0 Smoke Development: 5 Class Rating: A

Weathering (ASTM G-26) 2000 hours Excellent, no chalking or cracking.



Priming	All porous areas or concrete with excessive porosity should be primed using Sikagard 552W Primer or SikaLatex R to allow easy application of Sikagard 670W.
Mixing	Stir thoroughly to ensure uniformity using a low speed (400-600 rpm) drill and Sika paddle. To minimize color variation when using multiple batches, blend two batches of Sikagard 670W. Use one pail and maintain the second pail to repeat this procedure (boxing) for the entire application.
Application	Any areas of glass or other surfaces should be masked. Recommended application temperatures (ambient and substrate) 45°-95°F (5°-35°C). Sikagard 670W can be applied by brush, roller, or spray over entire area moving in one direction. Allow a minimum of 20-90 minutes prior to re-coating. At lower temperatures and high humidity, waiting time will be prolonged. At higher temperatures, work carefully to maintain a 'wet' edge. Sikagard 670W is usually applied using a short nap lambs wool roller. Sikagard 670W is particularly suitable for application by spray using the most standard spray painting equipment. As with all coatings, jobsite mock-ups should always be completed to confirm acceptability of workmanship and material.
	Note: To achieve a dry film thickness of 4-6 mils., two uniform coats should be anticipated. On porous substrates, a third coat may be necessary and on particularly dense substrates, the first coat should be thinned 10% by volume with water. A third coat may then be needed for opacity.
Limitations	 Do not use over moving cracks. Substrate must be dry prior to the application. Minimum age of concrete prior to the application is 14 days, depending on curing and drying conditions (moisture content must be below 5%). Minimum age of SikaTop or Sika MonoTop thin layer renderings is 3 days prior to the application of 670W (moisture content must be below 5%). Sikagard 670W should not be applied at relative humidities greater than 90%, or if rain is forecast within the specified rain resistance period. Allow sufficient time for the substrate to dry after rain or other inclement conditions. Product must be protected from freezing. If frozen, discard. Not designed for use as a vehicular traffic bearing surface. During application, regular monitoring of wet film thickness and material consumption is advised to ensure that the correct layer thickness is achieved. When overcoating existing coatings, compatibility and adhesion testing is recommended. Do not store Sikagard 670W in direct sunlight for prolonged periods.
Caution Warning	Avoid breathing vapors. Use only with adequate ventilation. May cause respiratory irritation and headaches.
Irritant	Skin, eye, and respiratory irritant; avoid contact. Use of safety goggles and chemical resistant gloves is recommended. Remove contaminated clothing.
First Aid	In case of eye contact, flush with water for 15 minutes, contact physician immediately. For skin contact, wash skin with soap water. For respiratory problems, remove person to fresh air. Wash clothing before re-use.
Spill Clean Up	Confine spill, ventilate closed areas, and collect with absorbent material. Dispose of in accordance

Warning	Avoid breathing vapors. Use only with adequate ventilation. May cause respiratory irritation and headaches.	
Irritant	Skin, eye, and respiratory irritant; avoid contact. Use of safety goggles and chemical resistant gloves is recommended. Remove contaminated clothing.	
First Aid	In case of eye contact, flush with water for 15 minutes, contact physician immediately. For skin contact, wash skin with soap water. For respiratory problems, remove person to fresh air. Wash clothing before re-use.	
Spill Clean Up	Confine spill, ventilate closed areas, and collect with absorbent material. Dispose of in accordance with current, applicable, local, state, and federal regulations. Uncured material can be removed water. Cured material can only be removed mechanically.	

KEEP CONTAINER TIGHTLY CLOSED • KEEP OUT OF REACH OF CHILDREN • NOT FOR INTERNAL CONSUMPTION • FOR INDUSTRIAL USE ONLY

KEEP CONTAINER TIGHTLY CLOSED • KEEP OUT OF REACH OF CHILDREN • NOT FOR INTERNAL CONSUMPTION • FOR INDUSTRIAL USE ONLY
All information provided by Sika Corporation ("Sika") concerning Sika products, including but not limited to, any recommendations and advice relating to the
application and use of Sika products, is given in good faith based on Sika's current experience and knowledge of its products when properly stored, handled
and applied under normal conditions in accordance with Sika's instructions. In practice, the differences in materials, substrates, storage and handling conditions, actual site conditions and other factors outside of Sika's control are such that Sika assumes no liability for the provision of such information, advice,
recommendations or instructions related to its products, nor shall any legal relationship be created by or arise from the provision of such information, advice,
recommendations or instructions related to its products. The user of the Sika product(s) must test the product(s) for suitability for the intended application
and purpose before proceeding with the full application of the product(s). Sika reserves the right to change the properties of its products without notice.

**Notice of the product of the produc All sales of Sika product(s) are subject to its current terms and conditions of sale which are available at www.sikausa.com or by calling 800-933-7452.

Prior to each use of any Sika product, the user must always read and follow the warnings and instructions on the product's most current Technical Data Sheet, product label and Material Safety Data Sheet which are available online at www.sikausa.com or by calling Sika's Technical Service Department at 800-933-7452. Nothing contained in any Sika materials relieves the user of the obligation to read and follow the warnings and instruction for each Sika product as set forth in the current Technical Data Sheet, product label and Material Safety Data Sheet prior to product use.

LIMITED WARRANTY: Sika warrants this product for one year from date of installation to be free from manufacturing defects and to meet the technical properties on the current Technical Data Sheet if used as directed within shelf life. User determines suitability of product for intended use and assumes all risks. Buyer's sole remedy shall be limited to the purchase price or replacement of product exclusive of labor or cost of labor. NO OTHER WARRANTIES EXPRESS OR IMPLIED SHALL APPLYINCLUDING ANYMARRANTY OF MERCHANTABILITY OR FITNESS FOR APARTICULAR PURPOSE. SIKASHALL NOTBELIABLE UNDERANYLEGAL THEORY FOR SPECIAL OR CONSEQUENTIAL DAMAGES. SIKASHALL NOTBERESPONSIBLE FOR THE USE OF THIS PRODUCT IN A MANNER TO INFRINGE ON ANY PATENT OR ANY OTHER INTELLECTUAL PROPERTY RIGHTS HELD BY OTHERS.

Visit our website at www.sikausa.com

1-800-933-SIKA NATIONWIDE Regional Information and Sales Centers. For the location of your nearest Sika sales office, contact your regional center.

Sika Corporation 201 Polito Avenue Lyndhurst, NJ 07071 Phone: 800-933-7452 Fax: 201-933-6225

Sika Canada Inc. 601 Delmar Avenue Pointe Claire Quebec H9R 4A9 Phone: 514-697-2610 Fax: 514-694-2792

Sika Mexicana S.A. de C.V. Carretera Libre Celaya Km. 8.5 Fracc. Industrial Balvanera Corregidora, Queretaro C.P. 76920

Phone: 52 442 2385800 Fax: 52 442 2250537



Spec Component: SC-060-03/10

Sikagard 670W

DIVISION 9 - FINISHES Section 09880 Protective Coatings

Part 1 - General

1.01 Summary

A. This specification describes the coating of substrates with an anti-carbonation, protective coating.

1.02 Quality Assurance

- A. Manufacturing qualifications: The manufacturer of the specified product shall be ISO 9001:2008 certified and have in existence a recognized ongoing quality assurance program independently audited on a regular basis.
- B. Contractor qualifications: Contractor shall be qualified in the field of concrete repair and protection with a successful track record of 5 years or more. Contractor shall maintain qualified personnel who have receiveed product training by manufacturer's representative
- C. Install materials in accordance with all safety and weather conditions required by manufacturer or as modified by applicable rules and regulations of local, state and federal authorities having jurisdiction. Consult Material Safety Data Sheets for complete handling recommendations.

1.03 Delivery, Storage, and Handling

- A. All materials must be delivered in original, unopened containers with the manufacturer's name, labels, product identification, and batch numbers. Damaged material must be removed from the site immediately.
- B. Store all materials off the ground and protect from rain, freezing or excessive heat until ready for use.
- C. Condition the specified product as recommended by the manufacturer.

1.04 Job Conditions

- A. Environmental Conditions: Do not apply material if it is raining or snowing or if such conditions appear to be imminent. Minimum application temperature 45°F (7°C) and rising.
- B. Protection: Precautions should be taken to avoid damage to any surface near the work zone due to mixing and handling of the specified material.

1.05 Submittals

- A. Submit two copies of manufacturer's literature, to include: Product Data Sheets, and appropriate Material Safety Data Sheets (MSDS).
- B. Submit copy of Certificate of Approved Contractor status by manufacturer.

1.06 Warranty

A. Provide a written warranty from the manufacturer against defects of materials for a period of one (1) year, beginning with date of substantial completion of the project.

Part 2 - Products

2.01 Manufacturer

- A. **Sikagard 670W**, as manufactured by Sika Corporation, 1682 Marion Williamsport Road, Marion, Ohio, 43302 is considered to conform to the requirements of this specification.
- B. **Sikagard Elastic Textured Base Coat**, manufactured by SikaCorporation 1682 Marion Williamsport Road, Ohio 43302 is considered to conform to requirements of this specification
- **C. Sikagard 552W Primer or SikaLatex R,** as manufactured by Sika Corporation, 1682 Marion Williamsport Road, Marion, Ohio, 43302 is considered to conform to the requirements of this specification.

2.02 Materials

- A. Protective Acrylic Coating:
 - 1. Product shall be 100% Acrylic Emulsion with the following properties:
 - a. Non-vapor barrier
 - b. Must resist ingress of chlorides
 - c. Must resist ingress of carbon dioxide
 - d. The material shall be non-combustible, both before and after cure.
 - B. Elastomeric Acrylic Textured Base Coating:
 - 1. Product shall be 100% Acrylic Emulsion with the following properties:
 - a. Water vapor permeable
 - b. Can bridge dynamically moving cracks
 - c. Crack bridging properties maintained at low temperatures
- B. Surface Conditioner / Adhesion Promoter:
 - 1. Product shall be a water-based acrylic surface conditioner/ primer and promote adhesion of acrylic coatings.
 - a. Solids content 12.5% 20% by volume
 - b. Recoat time 4-24 hours

2.03 Performance Criteria

- A. Properties of the protective acrylic coating:
 - 1. Pot Life: indefinite
 - 2. Tack Free Time 1 Hour @ 73°F, 50% Relative Humidity. Final Cure < 24 Hours
 - 3. Carbon Dioxide Diffusion: μ CO₂ 1,100,000 Carbon Dioxide Diffusion Resistance at 5 mils (120 microns) SdCO₂ = 433 ft (132 m) equivalent air thickness. i.e. Approx. 13-in. of standard concrete cover.
 - 4. Water Vapor Diffusion: μH_2O 13,140. Water Vapor Diffusion Resistance at 5 mils (120 microns) SdH₂O = 1.3 ft (0.4 m) equivalent air thickness.
 - 5. Moisture Vapor permeability (ASTM E96) 17.9 perms
 - 6. Solids content: By weight: 60% By Volume: 46%
 - 7. Flame spread and smoke development (ASTM E-84-94)
 - a. Flame Spread 0
 - b. Smoke Development 5
 - c. Class Rating A
 - 8. Resistance to wind driven rain (TT-C-555B): No passage of water through coating.

Note: Tests above were performed with the material and curing conditions @ $71^{\circ}F - 75^{\circ}F$ and 45-55% relative humidity.

Part 3 – Execution

3.01 Surface Preparation

A. Substrate must be clean, sound, and free of surface contaminants. Remove dust, laitance, grease, oils, curing compounds, form release agents and all foreign particles by mechanical means. Substrate shall be in accordance with ICRI Guideline No. 03732 for coatings and fall within CSP1 to CSP3.

3.02 Mixing and Application


- A. Mixing: Stir materials to ensure uniformity using a low speed (400-600 rpm) drill and paddle. To minimize color variation, blend two batches of material.(boxing)
- B. Coating Application: Apply by brush, roller, or spray over entire area moving in one direction. A minimum of two coats are required. Each coat should be applied at a rate not to exceed 250-sq. ft. per gallon. Total dry film thickness shall be a minimum 2.5 3 dry mils per coat. Allow a minimum of 1 hour prior to re-coating.
- C. When applying the coating, never stop the application until the entire surface has been coated. Always stop application at an edge, corner, or joint. Never let a previously coated film dry; always coat into a wet film. Always apply the coating at a 45° angle to an edge, corner, or joint.
- D. If substrate has been previously coated and presents a "chalky" condition, apply 1 coat of Sikagard 552W or Sika Latex R, primer/surface conditioner by brush, roller, or spray at a rate not to exceed 300 sq. ft. per gallon.
- E. Adhere to all limitations and cautions for the acrylic coating in the manufacturer's printed literature.

3.03 Cleaning

- A. The uncured acrylic coating can be cleaned from tools with water. The cured acrylic coating can only be removed mechanically.
- B. Leave finished work and work area in a neat, clean condition without evidence of spillovers onto adjacent areas.

SC-060 Sikagard 670W_®, Anti-Carbonation, Protective Coating

- 1. Substrate must be dry, clean and sound.
- 2. Condition surface with Sikagard 552W or SikaLatex R(as needed)
- 3. Apply Sikagard 670W by brush, roller or spray over entire area moving in one direction.



Concrete Restoration Systems by Sika Corporation, 201 Polito Avenue, Lyndhurst, NJ 07071

The preceding specifications are provided by Sika Corporation as a guide for informational purposes only and are not intended to replace sound engineering practice and judgment and should not be relied upon for that purpose. SIKA CORPORATION MAKES NO WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, AS TO THE ACCURACY, COMPLETENESS OR THE CONTENTS OF THESE GUIDE SPECIFICATIONS. Sika Corporation assumes no liability with respect to the provision or use of these guide specifications, nor shall any legal relationship be created by, or arise from, the provision of such specifications SIKA SHALL NOT BE RESPONSIBLE UNDER

ANY LEGAL THEORY TO ANY THIRD PARTY FOR ANY DIRECT OR CONSEQUENTIAL DAMAGES OF ANY KIND ARISING FROM THE USE OF THESE GUIDE SPECIFICATIONS. The specifier, architect, engineer or design professional or contractor for a particular project bears the sole responsibility for the preparation and approval of the specifications and determining their suitability for a particular project or application.

Prior to each use of any Sika product, the user must always read and follow the warnings and instructions on the product's most current Technical Data Sheet, product label and Material Safety Data Sheet which are available at www.sikaconstruction.com or by calling (201) 933-7452. Nothing contained in any Sika materials relieves the user of the obligation to read and follow the warnings and instructions for each Sika product as set forth in the current Technical Data Sheet, product label and Material Safety Data Sheet prior to product use.



Sikagard 670W - All Colors

HMIS

HEALTH	1
FLAMMABILITY	1
REACTIVITY	0
PERSONAL PROTECTION	С

1. Product And Company Identification

Supplier Sika Corporation 201 Polito Ave Lyndhurst, NJ 07071

Company Contact: EHS Department **Telephone Number: 201-933-8800** FAX Number: 201-933-9379 Web Site: www.sikausa.com

Supplier Emergency Contacts & Phone Number

CHEMTREC: 800-424-9300 INTERNATIONAL: 703-527-3887

Manufacturer Sika Corporation 201 Polito Ave

Lyndhurst, NJ 07071

Company Contact: EHS Department **Telephone Number:** 201-933-8800 **FAX Number:** 201-933-9379 Web Site: www.sikausa.com

Manufacturer Emergency Contacts & Phone Number

CHEMTREC: 800-424-9300 INTERNATIONAL: 703-527-3887

Issue Date: 08/14/2007

Product Name: Sikagard 670W - All Colors

CAS Number: Not Established

MSDS Number: 4154 Product Code: 0690543

2. Composition/Information On Ingredients

•				
Ingredient Name	CAS Number	Percent Of Total Weight		
CALCIUM CARBONATE	471-34-1			
TALC	14807-96-6			
TITANIUM DIOXIDE	13463-67-7			

3. Hazards Identification

Eye Hazards

EYE IRRITANT.

Skin Hazards

MAY CAUSE A REVERSIBLE INFLAMMATORY EFFECT ON SKIN OR TISSUE AT THE SITE OF CONTACT.

Ingestion Hazards

NOT NORMALLY INGESTED.

Inhalation Hazards

MAY CAUSE A REVERSIBLE INFLAMMATORY EFFECT ON THE UPPER RESPIRATORY SYSTEM.

Sikagard 670W - All Colors

4. First Aid Measures

Eye

RINSE EYES THOROUGHLY WITH WATER FOR AT LEAST 15 MINUTES. CONSULT PHYSICIAN.

Skin

WASH SKIN THOROUGHLY WITH SOAP AND WATER. REMOVE CONTAMINATED CLOTHING.IF SYMPTOMS PERSIST CONSULT PHYSICIAN.

<u>Ingestion</u>

CONSULT PHYSICIAN.

Inhalation

REMOVE TO FRESH AIR. IF BREATHING HAS STOPPED, INSTITUTE ARTIFICIAL RESPIRATION. CONSULT WITH PHYSICIAN.

5. Fire Fighting Measures

Flash Point: >200 °F

Fire And Explosion Hazards

NONE KNOWN

Extinguishing Media

In case of fire, use water spray (fog) foam, dry chemical, or CO2.

Fire Fighting Instructions

Firefighters should wear self-contained breathing apparatus and full protective gear.

6. Accidental Release Measures

WEAR SUITABLE PROTECTIVE EQUIPMENT. ELIMINATE SOURCES OF IGNITION. VENTILATE AREA. CONTAIN SPILL AND COLLECT WITH ABSORBENT MATERIAL. TRANSFER INTO A SUITABLE CONTAINER.

7. Handling And Storage

Handling And Storage Precautions

VENTILATION SHOULD BE SUFFICIENT TO REDUCE AIR CONTAMINANTS TO BELOW PELS. IFPELS ARE EXCEEDED WEAR APPROPRIATE, PROPERLY FITTED NIOSH/MSHA APPROVED RESPIRATOR.

Work/Hygienic Practices

Wash thoroughly with soap and water after handling.

8. Exposure Controls/Personal Protection

Engineering Controls

Use with adequate general and local exhaust ventilation.

Eye/Face Protection

Safety glasses with side shields or goggles.

Skin Protection

AVOID SKIN CONTACT. WEAR LONG SLEEVE SHIRT AND LONG PANTS. CHEMICAL RESISTANT RUBBER OR PLASTIC GLOVES.

Respiratory Protection

In areas where the P.E.L.s are exceeded, use a properly fitted NIOSH-approved respirator.

Ingredient(s) - Exposure Limits

CALCIUM CARBONATE

ACGIH TLV-TWA 10 mg/m3

Sikagard 670W - All Colors

8. Exposure Controls/Personal Protection - Continued

Ingredient(s) - Exposure Limits - Continued

OSHA PEL-TWA 15 mg/m3 OSHA PEL-TWA 5 mg/m3

TALC

ACGIH TLV-TWA 2 mg/m3 OSHA PEL-TWA 20 mppcf

TITANIUM DIOXIDE

ACGIH TLV-TWA 10 mg/m3 OSHA PEL-TWA 15 mg/m3

9. Physical And Chemical Properties

<u>Appearance</u>

THICK EMULSION IN COLORS

<u>Odor</u>

LATEX

Chemical Type: Mixture Physical State: Liquid Melting Point: N/A °F Boiling Point: N/AV °F Specific Gravity: 1.35 Percent Volatiles: N/AV Percent VOCs: 4.1%

Packing Density: 11.24 lb/gallon

Vapor Density: N/AV pH Factor: N/AV Solubility: MISCIBLE

VOC Content: 47.8 grams/ liter (USEPA Method 24)

10. Stability And Reactivity

Stability: STABLE

Hazardous Polymerization: WILL NOT OCCUR

Conditions To Avoid (Stability)

NONE KNOWN

Incompatible Materials

NONE KNOWN

11. Toxicological Information

Miscellaneous Toxicological Information

This product contains chemical(s) known to the state of California to cause cancer, birth defects or other reproductive harms.

Ingredient(s) - Carginogenicity

TALC

Listed In The IARC Monographs

12. Ecological Information

No Data Available...

Sikagard 670W - All Colors

13. Disposal Considerations

Dispose in accordance with applicable federal, state and local government regulations.

14. Transport Information

Proper Shipping Name

NOT REGULATED BY D.O.T.

15. Regulatory Information

U.S. Regulatory Information

All ingredients of this product are listed or are excluded from listing under the U.S. Toxic Substances Control Act (TSCA) Chemical Substance Inventory.

SARA Hazard Classes

Acute Health Hazard

SARA Section 313 Notification

This product does not contain any ingredients regulated under Section 313 of the Emergency Planning and Community Right-To-Know Act of 1986 or 40 CFR 372.

Ingredient(s) - State Regulations

CALCIUM CARBONATE

Pennsylvania - Workplace Hazard

TALC

New Jersey - Workplace Hazard Pennsylvania - Workplace Hazard Massachusetts - Hazardous Substance

TITANIUM DIOXIDE

New Jersey - Workplace Hazard Pennsylvania - Workplace Hazard New York City - Hazardous Substance

16. Other Information

HMIS Rating

Health: 1 Fire: 1 Reactivity: 0 PPE: C

Revision/Preparer Information MSDS Preparer: EHS Department

MSDS Preparer Phone Number: 201-933-8800

This MSDS Supercedes A Previous MSDS Dated: 08/13/2007

Disclaimer

The information contained in this Material Safety Data Sheet applies only to the actual Sika Corporation ("Sika") product identified and described herein. This information is not intended to address, nor does it address the use or application of the identified Sika product in combination with any other material, product or process. All of the information set forth herein is based on technical data regarding the identified product that Sika believes to be reliable as of the date hereof. Prior to each use of any Sika product, the user must always read and follow the warnings and instructions on the product's current Technical Data Sheet, product label and Material Safety Data Sheet for each Sika product, which are available at web site and/or telephone number listed in Section 1 of this MSDS.

Sikagard 670W - All Colors

Disclaimer - Continued

SIKA MAKES NO WARRANTIES EXPRESS OR IMPLIED AND ASSUMES NO LIABILITY ARISING FROM THIS INFORMATION OR ITS USE. SIKA SHALL NOT BE LIABLE UNDER ANY LEGAL THEORY FOR SPECIAL OR CONSEQUENTIAL DAMAGES AND SHALL NOT BE RESPONSIBLE FOR THE USE OF THIS PRODUCT IN A MANNER TO INFRINGE ON ANY PATENT OR ANY OTHER INTELLECTUAL PROPERTY RIGHTS HELD BY OTHERS.

All sales of Sika products are subject to its current terms and conditions of sale available at www.sikacorp.com or 201-933-8800.

SIKA CORPORATION

Printed Using MSDS Generator™ 2000