## CAD 064-573-108

Consulting Scientists, Engineers, and Geologists

June 19, 1994

Ms. Carla Slepak
California Environmental Protection Agency
Department of Toxic Substances Control
1011 North Grandview Avenue
Glendale, California 91201

21001.48/7

Subject:

Area 317 RCRA Quarterly Ground Water Monitoring Report No. 23

April through June 1994--Whittaker Corporation, Bermite Division 22116 West Soledad Canyon Road, Santa Clarita, California 91350

Dear Ms. Slepak:

Enclosed is the Area 317 RCRA Quarterly Ground Water Monitoring Report for the twenty-third quarter, April through June 1994. The monitoring was completed according to the requirements of the Water Quality Monitoring and Response Plan for the Interim Status Area 317 Surface Impoundment.

The statistical analyses for this sampling event showed that the established tolerance limits for pH, specific conductance, chloride, sulfate, TCE, TOC, or TOX were not exceeded. The tolerance limit for sodium was exceeded for the sample from monitoring well MW-10.

Please call me at (916) 939-7550 if there are any questions regarding the enclosed report.

Sincerely,

ACTON • MICKELSON • van DAM, INC.

barbara J. Mickelsony P.

BJM:mjd Enclosure

cc/enc:

Mr. Gordon Louttit, Esq., Whittaker Corporation

Mr. Glen AbdunNur, Bermite Division

Ms. Lily Herskovits, U.S. Environmental Protection Agency, Region IX Mr. Jim Ross, Los Angeles Regional Water Quality Control Board

Mckelson

# AREA 317 RCRA QUARTERLY GROUND WATER MONITORING REPORT NO. 23 APRIL THROUGH JUNE 1994

WHITTAKER CORPORATION, BERMITE DIVISION FACILITY 22116 WEST SOLEDAD CANYON ROAD SANTA CLARITA, CALIFORNIA 91350 AMV PROJECT NO. 21001.48

August 19, 1994

Prepared By

ACTON • MICKELSON • van DAM, INC.

4511 Golden Foothill Parkway, #1 El Dorado Hills, California 95762 (916) 939-7550

PREPARED BY:

REVIEWED BY:

Barbara J. Mickelson, P.E./
California Registered Professional
Engineer #43417

Date 8/19/94

Date 8/19/94

PROFESSION
REVIEWED BY:

## TABLE OF CONTENTS

			<u>Page</u>
LIST OF	TABLI	ES	ii
LIST OF	FIGUE	RES	ii
1.0 II	NTROD	UCTION	1
2.0 G	ROUNI	O WATER LEVEL MEASUREMENTS	2
3.	.1 Re	COLLECTION AND ANALYSIS	3 3 4
4.	.1 Gr	O WATER SAMPLE ANALYTICAL RESULTS	4 4 6
5. 5.	.1 As	SICAL ANALYSIS OF RESULTS TO DATE	6 7 7 8
6.2 6.3	Ground Ground Backgro	Water Level Measurements Water Monitoring Parameters ound Water Quality Parameters cal Analysis	8 8 8 9
7.0 REC	COMME	ENDATIONS	9
8.0 REM	MARKS		9
APPEND APPEND	DIX B. DIX C. DIX D. DIX E.	DOCUMENT SUBMITTAL CHRONOLOGY GROUND WATER SAMPLING PROCEDURES CHAIN-OF-CUSTODY FORMS SAMPLE ANALYSES REQUEST FORMS FGL QUALITY ASSURANCE/QUALITY CONTROL PROGRAM BLANK, DUPLICATE, AND SPIKE SAMPLE ANALYTICAL REPORTS	
APPEND		ANALYTICAL REPORTS FOR BACKGROUND WATER QUALITY PARAMETERS AND GROUND WATER MONITORING PARAMET	
APPEND	OIX H.	STATISTICAL ANALYSES	

## LIST OF TABLES

TABLE 1.	POTENTIOMETRIC SURFACE ELEVATIONS
TABLE 2.	GROUND WATER MONITORING PARAMETER ANALYSES FOR SAMPLES COLLECTED JUNE 22, 1994
TABLE 3.	BACKGROUND WATER QUALITY PARAMETERS

# LIST OF FIGURES

FIGURE 1.	SITE LOCATION
FIGURE 2.	AREA 317 GROUND WATER MONITORING WELL LOCATIONS AND ESTIMATED GROUND WATER FLOW DIRECTION (6/21/94)
FIGURE 3.	POTENTIOMETRIC SURFACE ELEVATIONS (THROUGH JUNE 1994)

# AREA 317 RCRA QUARTERLY GROUND WATER MONITORING REPORT NO. 23 APRIL THROUGH JUNE 1994

### WHITTAKER CORPORATION, BERMITE DIVISION FACILITY 22116 WEST SOLEDAD CANYON ROAD SANTA CLARITA, CALIFORNIA 91350

#### 1.0 INTRODUCTION

The Whittaker Corporation, Bermite Division (Whittaker) facility (site) is located at 22116 West Soledad Canyon Road in Santa Clarita, California (Figure 1). At the time operations were terminated in April 1987, Whittaker had interim status permits for 14 Resource Conservation and Recovery Act (RCRA) Hazardous Waste Management Units (HWMUs) at the site. A document entitled "Whittaker Corporation, Bermite Division, Santa Clarita, California, CAD064573108, Facility Closure Plan Modifications" (Closure Plan), was prepared by Whittaker and approved by the California Environmental Protection Agency, Department of Toxic Substances Control (Cal-EPA) and U.S. Environmental Protection Agency (U.S. EPA) on December 28, 1987. Outlined in the Closure Plan are procedures for obtaining approval by Cal-EPA and U.S. EPA of clean closure certification for the different HWMUs, including the 317 Surface Impoundment (Area 317).

Required in the Closure Plan is the implementation of a ground water monitoring system at Area 317 capable of detecting and assessing the impact of the HWMU on the uppermost aquifer at the site. Implementation of a ground water monitoring system is described in the document entitled "Water Quality Monitoring and Response Plan for the Interim Status Area 317 Surface Impoundment," dated October 9, 1992 (Area 317 Plan). This is a revised response plan approved by Cal-EPA which meets the requirements of the revisions to Title 22 and expands the constituents sampled and reported. The revised Area 317 Plan has been utilized for the nineteenth and subsequent sampling events.

A total of six ground water monitoring wells (MW-1, MW-3, MW-4, MW-5, MW-6, and MW-10) have been installed around Area 317 (Figure 2). Reports detailing the location and construction of monitoring wells, sampling and analysis plans for collecting and analyzing ground water samples from the ground water monitoring wells, abandonment of monitoring well MW-4, and quarterly sampling results which have been submitted to Cal-EPA and U.S. EPA are listed in Appendix A of this report.

Quarterly ground water sampling activities were initiated on October 3, 1988, for monitoring wells MW-1, MW-3, and MW-4. The ground water monitoring program includes analyses of water samples for volatile organic compounds (VOCs). Laboratory analytical results from the third quarterly sampling event reported trichloroethene (TCE) at 4,800 micrograms per liter

( $\mu$ g/l) in the ground water sample collected from monitoring well MW-4. As a result of this detection of TCE in the sample from monitoring well MW-4, two additional monitoring wells were installed in Area 317 (MW-5 and MW-6).

The fourth quarterly monitoring event included sampling of the ground water from monitoring wells MW-1, MW-3, and MW-4. Monitoring wells MW-5 and MW-6 were not equipped for sampling during the fourth quarterly sampling event. Analytical results from the fourth quarter were similar to those reported in the third quarterly sampling event. The concentrations of VOCs reported in samples collected from monitoring wells MW-1 and MW-3 were below laboratory reporting limits; however, analysis of the ground water sample collected from monitoring well MW-4 reported TCE at  $7,200 \,\mu\text{g/l}$ . Analysis of ground water samples collected from monitoring well MW-4 during the fifth through twelfth quarterly sampling events reported a steady decline in TCE concentration. Based on the results of the initial four sampling events, a reduced list of chemical parameters, approved by Cal-EPA, was utilized for the fifth through eighteenth quarterly sampling events.

Statistical analysis of indicator parameters (currently referred to as ground water monitoring parameters) was also initiated during the fifth quarterly sampling event. The ground water samples collected and analyzed for indicator parameters (ground water monitoring parameters) from monitoring wells MW-1, MW-3, and MW-4 for the initial year of monitoring were evaluated to assess whether statistically significant changes to the ground water had occurred as a result of site activities.

A Comprehensive Ground Water Monitoring Evaluation (CME) was conducted by Cal-EPA on January 24 and 25, 1990, during the sixth quarterly monitoring event. Personnel from Cal-EPA were present during all phases of the sixth quarterly monitoring event, from the taking of initial potentiometric surface elevation measurements to the sealing of the coolers containing the quarterly ground water samples.

Ground water samples from monitoring wells MW-1, MW-3, MW-5, MW-6, and MW-10 were collected on June 22, 1994. The results of the twenty-third quarterly ground water sampling event are presented in this report, along with recommendations for future quarterly ground water sampling events.

#### 2.0 GROUND WATER LEVEL MEASUREMENTS

Water level measurements were collected on June 21, 1994, prior to well evacuation and sampling activities. Monitoring well locations with respect to Area 317 are shown on Figure 2. Water levels were measured to the nearest 0.01 foot.

Water level elevations have decreased 51.59, 51.13, 37.61, and 38.22 feet in monitoring wells MW-1, MW-3, MW-5, and MW-6, respectively, since the initiation of RCRA ground water monitoring activities at Area 317. The water level elevation has increased 5.29 feet in monitoring well MW-10 since installation. Water level elevations decreased 1.36, 1.25, 2.28, 1.99, and 1.91 feet in monitoring wells MW-1, MW-3, MW-5, MW-6, and MW-10, respectively, between the twenty-second and twenty-third quarters. Table 1 summarizes potentiometric surface elevation data for monitoring wells in Area 317. Figure 3 graphically illustrates the changes in potentiometric surface elevations in monitoring wells MW-1, MW-3, MW-5, MW-6, and MW-10 over time.

A local ground water flow direction for June 21, 1994, has been estimated utilizing the potentiometric surface elevation data collected that day. Figure 2 illustrates the estimated potentiometric surface contours and the resultant estimated flow direction for June 21, 1994, which is toward the north-northeast. Based upon this data, monitoring well MW-6 is estimated to be located hydraulically downgradient from Area 317, monitoring wells MW-1, MW-5, and MW-10 are estimated to be located hydraulically crossgradient from Area 317, and monitoring well MW-3 is estimated to be located hydraulically upgradient from Area 317. The ground water flow direction estimated for June 21, 1994, is generally similar to the flow direction estimated for the previous sampling event. The estimated ground water flow direction has varied from north-northwest to north-northeast since quarterly ground water monitoring was initiated, which may represent a contributing factor to the reported variability in ground water chemistry.

#### 3.0 SAMPLE COLLECTION AND ANALYSES

Ground water evacuation, stabilization, and sampling procedures are outlined in Appendix B.

#### 3.1 Required Ground Water Analyses

A reduced analytical parameter testing list was approved by Cal-EPA after submittal of "Quarterly Sampling Report No. 4." As of the fifth quarter, ground water samples from monitoring wells MW-1 and MW-3 were analyzed for the following: sulfates, chlorides, total phosphate, pH, specific conductance, total organic carbon (TOC), total organic halogens (TOX), and dissolved metals (antimony, arsenic, barium, cadmium, chromium, copper, lead, mercury, selenium, and thallium) by EPA-approved methods. Ground water samples collected from monitoring wells MW-5, MW-6, and MW-10 were analyzed for pH, specific conductance, TOC, TOX, and VOCs by EPA-approved methods. With approval of the new Area 317 Plan, iron, manganese, and sodium were added to the analytical parameter testing list. Additionally, fluoride, gross alpha, gross beta, lead, nitrate, and turbidity were added temporarily to the analytical parameter testing list as background water quality parameters while total phosphates and other metals were removed from the list.

For the April through June 1994 sampling event, the following analytical parameters were tested:

- Ground Water Monitoring Parameters: pH, specific conductance, TOC, TOX, TCE, sulfate, sodium, manganese, iron, and chloride.
- Background Water Quality Parameters: fluoride, nitrate, lead, gross alpha, gross beta, and turbidity.

All ground water samples collected during the twenty-third sampling event were submitted to FGL Environmental (FGL) in Santa Paula, California. FGL is certified by Cal-EPA to perform the ground water analyses outlined in the Closure Plan. Chain-of-custody and sample analyses request forms are included in Appendices C and D, respectively.

A description of FGL's Quality Assurance/Quality Control (QA/QC) program is provided in Appendix E. Copies of the laboratory analytical reports for all trip, field, and method blanks, and duplicate and spiked samples analyzed by FGL are provided in Appendix F.

### 3.2 Approved Analytical Methods

Ground water monitoring parameters were analyzed by EPA or other approved methodologies. Analytical methodologies were presented in the "Ground Water Sampling and Analysis Plan," dated August 1988. Modifications to this plan were approved by Cal-EPA prior to the fifth quarterly sampling event. Copies of the laboratory test method protocol were included in Appendix B of "Quarterly Sampling Report No. 1," dated December 1988.

A summary of sample volumes, sample containers, and laboratory analytical methods utilized during the twenty-third sampling event is presented in Table B-3, Appendix B. Procedures regarding sample containers, sample labeling, sample collection, and field QA/QC are outlined in Appendix B.

#### 4.0 GROUND WATER SAMPLE ANALYTICAL RESULTS

#### 4.1 Ground Water Monitoring Parameters

Ground water samples from each monitoring well were analyzed for pH, specific conductance, chloride, iron, manganese, sodium, sulfate, TCE, TOC, and TOX to serve as ground water monitoring parameters. Table 2 summarizes the results of the ground water monitoring parameter analyses. Copies of the original laboratory data sheets are presented in Appendix G.

# AREA 317 RCRA QUARTERLY GROUND WATER MONITORING REPORT NO. 23-APRIL THROUGH JUNE 1994 AMV Project No. 21001.48

Laboratory pH measurements of 7.5, 7.6, 7.7, 7.7, and 7.8 were recorded for samples collected from monitoring wells MW-1, MW-3, MW-5, MW-6, and MW-10, respectively, for the twenty-third sampling event. The laboratory pH measurements recorded for samples collected from the monitoring wells during the twenty-third sampling event were generally consistent with the measurements recorded during previous sampling events.

Specific conductance measurements of 740, 630, 540, 550, and 610 micromhos per centimeter squared ( $\mu$ mhos/cm²) were recorded for samples collected from monitoring wells MW-1, MW-3, MW-5, MW-6, and MW-10, respectively, for the twenty-third sampling event. The specific conductance measurements recorded during the twenty-third sampling event are generally consistent with measurements recorded during previous sampling events.

The results for chloride, sodium, and sulfate were 150, 54, and 15 milligrams per liter (mg/l) for the sample from monitoring well MW-1; 29, 53, and 71 mg/l for the sample from monitoring well MW-3; 40, 54, and 35 mg/l for the sample from monitoring well MW-5; 65, 58, and 30 mg/l for the sample from monitoring well MW-6; and 64, 86, and 39 mg/l for the sample from monitoring well MW-10. Laboratory results for iron were 150, <50, 70, 70, and <50  $\mu$ g/l for the ground water samples collected from monitoring wells MW-1, MW-3, MW-5, MW-6, and MW-10, respectively, for the twenty-third sampling event. Manganese was reported at less than the detection limit in samples collected from all five monitoring wells. The results for manganese, iron, sodium, chloride, and sulfate are generally consistent with results from previous sampling events.

TCE was reported at less than the detection limit  $(0.5 \mu g/l)$  in samples from all five monitoring wells. These results for TCE from ground water samples from Area 317 monitoring wells are consistent with the previous sampling event.

TOC was reported at less than 0.5 mg/l in all samples collected from Area 317 monitoring wells during the twenty-third sampling event. The TOC measurements recorded during the twenty-third sampling event are generally consistent with measurements recorded during previous sampling events.

TOX were reported at less than  $5\mu g/l$  in samples collected from Area 317 monitoring wells MW-1, MW-5, and MW-6. The TOX measurements reported for samples collected from monitoring wells MW-3 and MW-10 on June 22, 1994, were 8 and 20  $\mu g/l$ , respectively. Detectable concentrations of TOX have not been reported in MW-3 since the March 1992 sampling event or in MW-10 since the October 1992 sampling event. Since TOX has been infrequently detected in Area 317 wells during previous monitoring events, the present detections reported are not inconsistent with previous results. The statistical inference, based on the methodology described below, is that the present TOX detections are not outside the established tolerance limit for this parameter and do not appear to be problematic at this time.

Copies of the laboratory analytical reports for the ground water monitoring parameters are included in Appendix G.

#### 4.2 Background Water Quality Parameters

Background water quality parameters were established with four sets of analytical data. The analytical results for samples from monitoring wells MW-1 and MW-3 were utilized to establish the background water quality parameters. The background water quality parameters will not be tested again unless there is evidence of a release at any ground water monitoring point (i.e., monitoring well sample analytical data reported outside the established tolerance limits). Table 3 summarizes the results of the background water quality parameter analyses.

#### 5.0 STATISTICAL ANALYSIS OF RESULTS TO DATE

As was indicated in the document entitled "Ground Water Sampling and Analysis Plan," dated August 1988, and required in 40 CFR Part 265.92, statistical analysis of the indicator parameters (currently referred to as ground water monitoring parameters) was previously performed to determine whether a statistically significant difference in the water quality existed between the individual downgradient monitoring wells and the upgradient or background monitoring wells. At that time, monitoring wells MW-1 and MW-3 were considered upgradient or crossgradient relative to Area 317, and monitoring wells MW-5, MW-6, and MW-10 were considered downgradient or crossgradient relative to Area 317.

After four quarters of sampling and analysis of the monitoring system, the mean, standard deviation, variance, and coefficient of variance of the four indicator (ground water monitoring) parameters were calculated. These values were reported to Cal-EPA in correspondence to Mr. Alan Sorsher, P.E., Cal-EPA, from Wenck Associates Inc. (Wenck), dated October 25, 1989. The statistical analysis, presented in the fifth through tenth quarterly sampling reports, indicated only one statistically significant difference in water quality as determined by the indicator (ground water monitoring) parameters. This was interpreted by Wenck to be caused by erroneous TOC results from the sixth quarter.

Since the approval of the Area 317 Plan by Cal-EPA, the statistical comparison of analytical results for each downgradient monitoring well is made against the tolerance limits for the ten established ground water monitoring parameters (chloride, sulfate, iron, manganese, sodium, TCE, TOC, TOX, specific conductance, and pH). The tolerance limits for the ground water monitoring parameters will be updated at a minimum annually to include the latest analytical data.

Concentrations of the ground water monitoring parameters in the ground water samples collected from Area 317 monitoring wells for the twenty-third quarter are included in Table H-1, presented in Appendix H. A summary of the quarterly statistics for each background monitoring well and the tolerance limit calculations for the ground water monitoring parameters are presented in Appendix H, Tables H-2, H-3, and H-4. Graphical presentation of the statistical information is also included in Appendix H.

#### 5.1 Assumptions Used in the Statistical Analysis

As recommended in the document entitled "RCRA Ground Water Monitoring Technical Enforcement Guidance Document," the data points that are less than the detection limit have been given a value equal to one-half the detection limit of the analyte. As recommended in the document entitled "Statistical Analysis of Ground Water Monitoring Data at RCRA Facilities, Interim Final Guidance" (Guidance Document), the statistical analysis assumes a value for the confidence coefficient (1-a) of 0.95 and a value for the proportion (y) of 0.95. This translates to a 95 percent confidence that 95 percent of future background monitoring well results will fall within the tolerance interval predicted. The tolerance limits for pH were calculated using a two-tailed distribution, and the tolerance limits for the other parameters were calculated using a one-tailed distribution. It was assumed that the data are distributed normally.

#### 5.2 Data Preparation

The ground water sample analytical results from the two background or upgradient monitoring wells (MW-1 and MW-3) for all 23 quarters of ground water sampling to date and the three downgradient monitoring wells (MW-5, MW-6, and MW-10) for the twenty-third quarter of ground water sampling have been tabulated and prepared for statistical analysis. In accordance with the tolerance limit methodology used for this statistical analysis, the analytical results for the ten ground water monitoring parameters are summarized by quarter and by monitoring well. Arithmetic mean and standard deviation summary statistics have been calculated and are utilized in calculating the tolerance limits for each of the ground water monitoring parameters.

The statistical analysis for the ground water monitoring parameters involves testing the ground water quality downgradient of Area 317 against the set of tolerance limits, i.e., that there are no excursions of the tolerance limits, which are based on the average of all the quarterly statistics for each of the ten ground water monitoring parameters for background monitoring wells MW-1 and MW-3, compared to the twenty-third quarter results for each of the downgradient monitoring wells MW-5, MW-6, and MW-10 (Table H-1).

The calculations of the quarterly statistics were performed in the same manner as was outlined in the Area 317 Plan. The values of K were taken from the statistical tables based on the number of samples and a one-sided tolerance limit. (An example calculation is included in Appendix H.) Note that pH values have not been reported as hydrogen ion concentrations as was done previously and that the value of K for the analysis of pH is derived from the tables

for two-sided tolerance limits. Manganese and TCE have never been reported above the detection limit in samples from monitoring wells MW-1 and MW-3; therefore, the tolerance limit for these parameters is set at the detection limit.

#### 5.3 Results

The twenty-third quarter results for each ground water monitoring parameter at each downgradient monitoring well were compared to the tolerance limits based on the first through twenty-third quarter results for background monitoring wells MW-1 and MW-3. The statistical analysis indicates that there is no excursion of tolerance limits of pH, specific conductance, chloride, sulfate, iron, manganese, sodium, TCE, TOC, or TOX in downgradient ground water quality, except for sodium in the sample from monitoring well MW-10. Because the concentration of sodium in monitoring well MW-10 had exceeded the defined tolerance limit during three previous sampling events, samples from each of the three downgradient or crossgradient wells, MW-5, MW-6, and MW-10, were analyzed for all six background parameters during the twenty-third monitoring event. Analysis of the data indicates that the concentrations of background water quality parameters in wells MW-5, MW-6, and MW-10 are consistent with the historical data for these parameters in upgradient wells MW-1 and MW-3. The elevated sodium concentration in monitoring well MW-10 relative to sodium concentrations in the other four Area 317 wells has not indicated a statistical impact with respect to the concentration of any other water quality parameters.

#### 6.0 SUMMARY

#### **6.1** Ground Water Level Measurements

Based upon the June 21, 1994 data, the estimated direction of ground water flow is toward the north-northeast, which is generally consistent with the ground water flow direction estimated during the previous sampling event. Utilizing this data, monitoring well MW-6 is estimated to be located hydraulically downgradient from Area 317; monitoring wells MW-1, MW-5, and MW-10 are estimated to be located hydraulically crossgradient from Area 317; and monitoring well MW-3 is estimated to be located hydraulically upgradient from Area 317.

#### **6.2** Ground Water Monitoring Parameters

The pH reported in samples from the five monitoring wells ranged from 7.5 (monitoring well MW-1) to 7.8 (monitoring well MW-10). The specific conductance in samples from the five monitoring wells ranged from 520  $\mu$ mhos/cm² (monitoring wells MW-5 and MW-6) to 730  $\mu$ mhos/cm² (monitoring well MW-1). TOC was reported at less than 0.5 mg/l in samples from all five monitoring wells. TOX detection occurred in monitoring wells MW-3 (8  $\mu$ g/l) and MW-10 (20  $\mu$ g/l). The reported TOX concentrations in MW-3 and MW-10 are not outside the

established tolerance limit for this parameter. The pH, specific conductance, TOC, and TOX results reported for the twenty-third sampling event are generally consistent with the results reported for the previous sampling events.

The constituent of concern for Area 317 is TCE, which was reported as less than the detection limit in samples from all five monitoring wells. This result is consistent with the previous sampling event.

The ground water sample analytical results for chloride, iron, manganese, sodium, and sulfates from the five monitoring wells are generally consistent with the existing data. All are under the tolerance limits, except for sodium in the sample from monitoring well MW-10.

#### 6.3 Background Water Quality Parameters

Monitoring wells MW-1 and MW-3 were sampled for each of the six background water quality parameters during the twenty-third quarter to complete the parameter set. Other background water quality parameters were not tested in this quarter.

#### 6.4 Statistical Analysis

The statistical analyses indicate that the tolerance limits set by the analysis of background water quality are not exceeded for pH, specific conductance, chloride, sulfate, iron, manganese, TCE, TOC, or TOX in the downgradient monitoring wells. The tolerance limit for sodium was exceeded for the sample from monitoring well MW-10.

#### 7.0 RECOMMENDATIONS

Based upon the data collected, current regulatory guidelines, and the professional judgment of AMV, the following recommendations are presented:

- Conduct future sampling events in accordance with the procedures set forth in the document entitled "Water Quality Monitoring and Response Plan for the Interim Status Area 317 Surface Impoundment," dated October 9, 1992.
- Update the tolerance limits for the ground water monitoring parameters following the twenty-fourth quarterly sampling event.

AREA 317 RCRA QUARTERLY GROUND WATER MONITORING REPORT NO. 23-APRIL THROUGH JUNE 1994 AMV Project No. 21001.48

#### 8.0 REMARKS

The recommendations contained in this report represent our professional opinions. These opinions are based on currently available information and were developed in accordance with currently accepted hydrogeologic and engineering practices at this time and location. Other than this, no warranty is implied or intended.

#### TABLE 1

### POTENTIOMETRIC SURFACE ELEVATIONS RCRA GROUND WATER MONITORING WELLS WHITTAKER CORPORATION, BERMITE DIVISION

Well No.	MW-1	MW-3	MW-4	MW-5	MW-6	MW-10
Top of Casing Elevation	1,561.32	1,538.51	1,538.43	1,493.37	1,521.09	1,537.49
Date			Potentiometric S	urface Elevation	Sª	
12/23/87	1,107.81	<sup>b</sup>				
01/27/88	1,108.03	1,109.51				
02/03/88	1,108.32	1,109.88				
02/04/88	1,108.36	1,109.14				
02/05/88	1,108.36	1,109.17				
02/09/88	1,108.24	1,109.13				
02/10/88	1,108.28	1,109.27				
02/12/88	1,108.28	1,109.27				
02/19/88	1,108.11	1,108.86				
03/28/88	1,107.69	1,108.23				
04/05/88	1,107.76	1,108.23				
04/12/88	1,107.66	1,108.23				
04/19/88	1,107.56	1,108.23				
04/26/88	1,107.61	1,108.23				
05/02/88	1,107.86	1,108.23				
07/27/88	1,103.58	1,104.19	1,102.61		]	
10/03/88	1,101.75	1,102.11	1,100.77			
01/23/89	1,099.82	1,100.25	1,098.92			
04/17/89	1,097.37	1,097.62	1,096.05			
07/27/89	1,094.67	1,094.85	1,093.53	1,093.02	1,093.15	
08/10/89	1,093.93	1,094.09	1,092.89	1,092.32	1,092.49	
08/18/89	1,093.62	1,093.76	1,092.64	1,092.03	1,092.19	
10/30/89	1,092.07	1,092.16	1,091.08	1,090.62	1,090.64	
01/24/90	1,090.56	1,090.54	1,089.68	1,089.17	1,089.50	
04/16/90	1,088.66	1,088.78	1,087.83	1,087.23	1,087.32	
07/16/90	1,083.56	1,083.53	1,082.29	1,081.41	1,081.85	
10/17/90	1,079.91	1,079.78	1,078.86	1,078.25	1,078.56	
01/28/91	1,076.52	1,076.54	1,075.46	1,074.64	1,074.91	
04/22/91	1,071.22	1,071.29	1,069.75	1,068.90	1,069.25	
07/17/91	1,063.63	1,063.79	1,061.66	1,060.53	1,061.14	
10/08/91	1,055.22	1,055.41	1,053.28	1,052.12	1,052.69	
01/29/92	1,051.88	1,052.29	1,050.63	1,049.76	1,050.06	1,050.5
04/20/92	1,050.47	1,050.88	1,049.33	1,048.78	1,048.92	1,049.3
07/28/92	1,046.84	1,047.40	<sup>c</sup>	1,045.14	1,045.20	1,045.7
10/19/92	1,043.87	1,044.58	¢	1,042.05	1,042.13	1,042.7
01/25/93	1,044.79	1,045.61	<sup>c</sup>	1,044.22	1,043.64	1,044.2
06/07/93	1,049.24	1,050.36	<sup>c</sup>	1,049.19	1,048.70	1,049.2
09/20/93	1,052.40	1,054.11	c	1,052.47	1,051.79	1,052.5
12/06/93	1,054.26	1,056.27	¢	1,054.29	1,053.58	1,054.5
03/07/94	1,057.58	1,059.63	c	1,057.69	1,056.92	1,057.7
06/21/94	1,056.22	1,058.38	c	1,055.41	1,054.93	1,055.8

<sup>&</sup>lt;sup>a</sup>NGVD = National Geodetic Vertical Datum.

<sup>&</sup>lt;sup>b</sup>Measurement not recorded.

<sup>&</sup>lt;sup>c</sup>Monitoring well abandoned 05/28/92.

TABLE 2 GROUND WATER MONITORING PARAMETER ANALYSES FOR SAMPLES COLLECTED JUNE 22, 1994

		Detection Limit	Monitoring Well No.				
Parameter	Units		MW-1	MW-3	MW-5	MW-6	MW-10
pН			7.5	7.6	7.7	7.7	7.8
Specific Conductance	μmhos/cm <sup>2</sup>	1	740	630	540	550	610
Chloride	mg/l	1	150	29	40	65	64
Iron	μg/l	50	150	< 50	70	70	< 50
Manganese	μg/l	30	< 30	< 30	< 30	< 30	< 30
Sodium	mg/l	1	54	53	54	58	86
Sulfate	mg/l	1	15	71	35	30	39
TCE <sup>a</sup>	μg/l	0.5	< 0.5	< 0.5	< 0.5	< 0.5	<0.5
TOCb	mg/l	0.5	< 0.5	<0.5	< 0.5	< 0.5	< 0.5
TOX°	μg/l	5	<5	8	< 5	< 5	20

<sup>a</sup>TCE = Trichloroethene.


<sup>b</sup>TOC = Total Organic Carbon. <sup>c</sup>TOX = Total Organic Halogens.

TABLE 3
BACKGROUND WATER QUALITY PARAMETERS

Well No.	Date Sampled	Gross Alpha (pCi/l)	Gross Beta (pCi/l)	Lead (mg/l)	Fluoride (mg/l)	Nitrate (mg/l)	Turbidity (NTUs)
Detection	Limits			0.0002	0.1	0.4	0.2
MW-1	10/04/88	0.4 ± 2	0.7 ± 2	ND <sup>a</sup>	b		
	01/27/93	0 ± 1	4 ± 2	ND	0.2		
	06/09/93	0.4 ± 1	0.7 ± 2	ND	0.2	3.9	0.4
	07/14/93	2 ± 2	0 ± 2	ND	0.4	4.8	0.9
	08/11/93	1 ± 1	4 ± 4	ND	0.3	4.8	0.9
	09/22/93						0.5
	03/10/94					ND	
	06/22/94	2 ± 2	4 ± 2	< 0.0002	0.2	3.6	1.0
MW-3	10/04/88	0.7 ± 1	2 ± 3	< 0.01			
	01/27/93	0.8 ± 1	2 ± 2	ND	0.3		
	06/09/93	2 ± 1	1 ± 2	ND	0.2	1.6	ND
	07/14/93	2 ± 2	1 ± 2	ND	0.3	2.1	ND
	08/11/93	4 ± 2	3 ± 4	ND	0.2	2.2	0.3
	09/22/93						ND
	03/10/94					1.4	
	06/22/94	1.0 ± 1	2 ± 2	4.9	0.2	3.6	0.3
MW-5 <sup>b</sup>	06/22/94	1.0 ± 1	3 ± 2	< 0.0002	0.2	3.6	0.9
MW-6 <sup>b</sup>	06/22/94	0.1 ± 1	2 ± 2	< 0.0002	0.2	3.8	0.8
MW-10 <sup>b</sup>	06/22/94	0.4 ± 1	4 ± 2	< 0.0002	0.2	3.7	0.8

<sup>&</sup>lt;sup>a</sup>Sample was not taken.

<sup>&</sup>lt;sup>b</sup>Samples collected from monitoring wells MW-5, MW-6, and MW-7 during the twenty-third sampling event were analyzed for the background water quality parameters because of a repeated tolerance interval exceedence for sodium during previous sampling events.








FIGURE 3
RCRA GROUND WATER MONITORING WELLS
POTENTIOMETRIC SURFACE ELEVATIONS





# APPENDIX A DOCUMENT SUBMITTAL CHRONOLOGY

#### APPENDIX A

#### DOCUMENT SUBMITTAL CHRONOLOGY

The following documents have been submitted to Cal-EPA and U.S. EPA, Region IX, in fulfillment of the Closure Plan regarding ground water monitoring at Areas 317 and 342:

- Whittaker Corporation, Bermite Division, Santa Clarita, CA CAD064573108, Facility Closure Plan Modifications, April 1987.
- Revised Ground Water Monitoring Plan for the 317/342 Area, October 8, 1987.
- Proposed Interim Status Ground Water Monitoring Sampling and Analysis Program, December 1987.
- Documentation Report--Construction and Development of Wells for Ground Water Monitoring of the 342 and 317 Areas, February 1988.
- Verification Sampling Results at Selected RCRA Units, March 1988.
- RCRA Ground Water Monitoring System--Proposed Final Configuration, May 1988.
- Ground Water Sampling and Analysis Plan, August 1988.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 1, December 1988.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 2, March 1989.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 3, July 1989.
- Specific Plan for a Ground Water Quality Assessment Program, June 1989.
- Interim Response Action Plan, 317 Area Soil and Ground Water Remediation, June 1989.
- Site Ground Water Sampling and Analysis Plan, Appendix IV of 40 CFR 264.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 4, September 1989.

- Statistical Analysis--Well MW-2 Versus MW-1 and MW-3, October 1989.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 5, March 1990.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 6, May 1990.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 7, June 1990.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 8, October 1990.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 9, January 1991.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 10, April 1991.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 11, July 1991.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 12, October 1991.
- Specific Plan for a Ground Water Quality Assessment Program for the 317 Surface Impoundment Area.
- RCRA Ground Water Sampling, Quarterly Sampling Report No. 13, January 1992.
- Area 317 RCRA Quarterly Ground Water Quality Monitoring Report No. 14 and Report of Monitoring Well MW-10 Installation, January through March 1992.
- Area 317 RCRA Quarterly Ground Water Quality Monitoring Report No. 15, April through June 1992.
- Area 317 RCRA Quarterly Ground Water Quality Monitoring Report No. 16, July through September 1992.
- Water Quality Monitoring and Response Plan for the Interim Status Area 317 Surface Impoundment, October 1992.
- Area 317 RCRA Quarterly Ground Water Quality Monitoring Report No. 17, October through December 1992.
- Area 317 RCRA Quarterly Ground Water Monitoring Report No. 18, January through March 1993.
- Area 317 RCRA Quarterly Ground Water Monitoring Report No. 19, April through June 1993.

- Area 317 RCRA Quarterly Ground Water Monitoring Report No. 20, July through September 1993.
- Area 317 RCRA Quarterly Ground Water Monitoring Report No. 21, October through December 1993.
- Area 317 RCRA Quarterly Ground Water Monitoring Report No. 22, January through March 1994.

# APPENDIX B GROUND WATER SAMPLING PROCEDURES

#### APPENDIX B

#### GROUND WATER SAMPLING PROCEDURES

On June 21, 1994, initial depth to water measurements were collected prior to the onset of monitoring well evacuation activities. Operation of the pumps in monitoring wells MW-1, MW-3, MW-5, MW-6, and MW-10 was then initiated to evacuate stagnant water. Pumping durations to evacuate these five monitoring wells are summarized in Table B-1. Prior to sample collection, the pumping rate for each monitoring well was reduced to approximately 100 milliliters per minute (ml/min) in a 1/4-inch-diameter tube.

In accordance with the "Ground Water Sampling and Analysis Plan," dated August 1988, evacuated ground water from monitoring wells MW-1, MW-3, MW-5, MW-6, and MW-10 was discharged to the ground surface, downgradient from each monitoring well.

#### Well Stabilization

Well stabilization measurements were periodically collected after well evacuation activities were initiated. Stabilization measurements for pH, temperature, turbidity, and specific conductance were taken three times prior to sampling of each well to increase the likelihood that representative ground water samples were collected. Table B-2 summarizes the results of the stabilization tests. As shown in Table B-2, the reported measurements in each monitoring well indicated a relatively stable condition prior to sampling.

#### Sample Containers

Sample containers used for the collection of ground water samples were supplied by Eagle Picher Environmental Services and I-Chem, Inc. The sample containers used were precleaned and sealed at these facilities and are statistically certified as clean and free of volatile organic and metal compounds. (Certificates of Analysis for the sample containers used during the quarterly ground water sampling event are provided in this appendix.) Table B-3 lists the laboratory analytical methods, sample volume, and containers used for this quarterly ground water sampling event.

#### Sample Labeling

Sample identification labels were filled out in the field at the time of sample collection in accordance with the "Ground Water Sampling and Analysis Plan," dated August 1988. A sample identification system was established to clearly and properly label samples. Each label identifies the monitoring well number, analytical parameter required, quarterly sampling event number, and replicate number (if required). A legend is provided in Table B-4 outlining the labeling system.

#### Sample Collection

#### Sampling Volumetric Flow Rate

A Teflon sampling valve and stem were installed into the invert of the well discharge pipe of each monitoring well to minimize aeration and agitation of the collected ground water sample. The flow rates in the monitoring wells were reduced to approximately 100 milliliters/minute (ml/min) in a 1/4-inch-diameter tube prior to sampling.

#### Order of Sample Collection

The ground water at each monitoring well was sampled for selected analytical parameters in the same order. This order is presented in Table B-5.

#### Field Sample Preservation

Ground water samples collected for TOC and TOX were preserved by adjusting the pH. A 50 percent sulfuric acid solution was added to the sample containers after filtration of the ground water sample to lower the pH. The pH of the water sample was monitored with an electric pH meter as the acid was added with a small pipette. Acid was added until a pH of less than 2 was achieved.

Following collection, labeling, and sealing, each individual ground water sample was placed in a refrigerator and locked. Samples were placed on ice in a cooler following collection and delivered to the laboratory on June 22, 1994.

#### Field and Trip Sample Blanks

During each quarterly sampling event, field and trip blanks were analyzed for TCEs, TOCs, and TOXs in accordance with the "Ground Water Sampling and Analysis Plan," dated August 1988.

The trip blanks were prepared in the laboratory, transferred to the site in coolers, stored in the refrigerator overnight, transferred to each sampling location during sampling activities, and stored with collected ground water samples throughout the sampling event and delivered to the laboratory.

The field blanks are prepared in the field using water provided by the analytical laboratory. These field blanks, once prepared, were stored with the ground water samples throughout the sampling event and delivered to the laboratory.

#### FIELD QA/QC

#### Washing of Field Test Equipment

To minimize the potential for cross-contamination between well samples, field equipment used during sampling activities was decontaminated between each well. Decontamination procedures involved cleaning and rinsing with deionized water before and after each sample was collected at each well. The mercury thermometer, pH probe, sulfuric acid eye droppers, turbidity meter, specific conductance probe, and the water level meter probe were all decontaminated between samples.

Unused sampling gloves were worn by sampling personnel prior to sealing the sample containers with the chain-of-custody seals.

#### Sample Container Labeling and Seals

As previously stated, the sample containers were labeled in the field as each sample was collected. A unique sample identification number was assigned to each ground water sample. Chain-of-custody seals were then placed on the sample containers after sampling and labeling. The ground water samples were placed on ice in a cooler, and the cooler was sealed with chain-of-custody seals prior to shipment to the laboratory.

#### Chain-of-Custody and Sample Analysis Request Forms

Chain-of-custody forms were filled out at the time of sample collection and were kept with the samples until they were delivered to the laboratory. Copies of the signed chain-of-custody forms are provided in Appendix C.

Sample analysis request forms were also filled out at the time of sample collection and were kept with the samples until they were delivered to the laboratory. Sample analysis request forms are used to inform the laboratory of the analysis to run on each ground water sample. Copies of the sample analysis request forms are provided in Appendix D.

#### **Delivery of Samples to Laboratory**

Ground water samples were delivered to FGL in Santa Paula, California, by personnel of Whittaker after sampling activities were completed. FGL is approximately 45 minutes by car from the site. Maximum and minimum thermometers were placed in each cooler for temperature verification. Upon arrival at the laboratory, the temperature was recorded on the sample analysis request form. The temperature of the samples was kept below 4° C.

#### **Security**

Security measures were implemented to minimize the likelihood that unauthorized personnel had access to the wells or ground water samples before, during, or after sampling activities. The site is fenced-in with locking gates and has 24-hour security personnel present. Each monitoring well has a locking cap to deter unauthorized access to the well. The ground water samples were handled by Whittaker personnel only during sampling activities and delivery to FGL.

TABLE B-1

AREA 317 WELL EVACUATION
BERMITE DIVISION, WHITTAKER CORPORATION

		Evacuation	Sampling <sup>a</sup>		
Well Number	Date Pump Started	Approximate Duration of Pumping (hours)	Duration of Pumping (minutes)	Time and Date of Sample Collection	
MW-1	6/21/94	26	15	1000 (6/22/94)	
MW-3	6/21/94	26	20	1020 (6/22/94)	
MW-5	6/21/94	27	19	1045 (6/22/94)	
MW-6	6/21/94	27	20	1110 (6/22/94)	
MW-10	6/21/94	28	21	1135 (6/22/94)	

<sup>&</sup>lt;sup>a</sup>Flow rate from wells was reduced prior to sampling. Actual sample extraction flow rate for all wells approximately 100 milliliter/minute in a 1/4-inch pipe.

TABLE B-2 WELL STABILIZATION TESTS BERMITE DIVISION, WHITTAKER CORPORATION

Well	Turbidity (NTUs)*	Temperature (°C.)	pН	Specific Conductance (μmhos) <sup>b</sup> /cm <sup>2</sup>	Time and Date
MW-1	4.38	22.4	7.09	736	1235 (6/21/94)
	3.92	23.6	7.88	730	1605 (6/21/94)
	2.62	23.1	7.57	728_	0735 (6/22/94)
MW-3	1.32	24.2	7.41	629	1240 (6/21/94)
	1.35	23.9	7.83	628	1610 (6/21/94)
	1.20	23.7	7.76	632	0740 (6/22/94)
MW-5	2.60	23.4	7.71	531	1245 (6/21/94)
	2.58	24.2	7.92	544	1615 (6/21/94)
	2.16	24.3	7.81	540	0745 (6/22/94)
MW-6	3.20	23.6	7.70	554	1250 (6/21/94)
	2.44	24.2	7.90	547	1620 (6/21/94)
	1.90	24.2	7.88	552	0750 (6/22/94)
MW-10	2.62	23.5	7.66	616	1255 (6/21/94)
	2.24	23.8	7.85	607	1625 (6/21/94)
	1.89	23.9	7.97	602	0755 (6/22/94)

<sup>&</sup>lt;sup>a</sup>NTUs - nephelometric turbidity units. <sup>b</sup>µmhos - micromhos.

TABLE B-3

LABORATORY ANALYTICAL METHODS AND SAMPLE VOLUME AND CONTAINER REQUIREMENTS

AREA 317 GROUND WATER MONITORING WELLS WHITTAKER CORPORATION, BERMITE DIVISION

Constituent	Analytical Method	Sample Volume (milliliters)	Container Type
Ground Water Monitoring Parameters	1		
рН	EPA 150.1	50	Plastic/glass
Specific Conductance	EPA 120.1	100	Plastic
Total Organic Carbon	EPA 415.1	250	Amber glass-TFE cap
Total Organic Halogen	EPA 9020	250	Amber glass-TFE cap
Trichloroethylene	EPA 601	3 x 40	Amber glass-TFE cap
Sulfate	EPA 300.0	200	Plastic/glass
Sodium	EPA 200.7	200	Plastic
Iron	EPA 200.7	200	Plastic
Manganese	EPA 200.7	200	Plastic
Chloride	EPA 300.0	100	Plastic/glass
Background Water Quality Parameters			
Fluoride	EPA 340.2	100	Plastic/glass
Lead	EPA 200.8	100	Plastic
Gross Alpha	EPA 900.0	200	Plastic
Gross Beta	EPA 900.0	200	Plastic
Nitrate	EPA 353.2	200	Plastic
Turbidity	EPA 180.1	250	Amber glass

#### TABLE B-4

# AREA 317 KEY TO ANALYSIS DESIGNATION LABELS ON SAMPLE CONTAINERS BERMITE DIVISION, WHITTAKER CORPORATION

Analysis Designation	Parameter(s) to be Analyzed
A	pH Specific Conductance (temperature corrected)
В	Total Organic Carbon (TOC)
С	Total Organic Halogen (TOX)
E	Gross alpha, Gross Beta
Н	Sulfate, Chloride
N	Fluoride
О	Trichloroethene (TCE)
R	Sodium, Iron, Manganese
S	Nitrate
T <sub>.</sub>	Turbidity
v	Lead

Each sample container was labeled with a unique sample number. The form of each label was as follows:

Well I.D./Analysis Designation/Sample Event No.

#### Where:

Well I.D. = MW-1, MW-3, MW-4, MW-5, MW-6, or MW-10. Analysis Designation = A through V according to above table. Sample Event No. = 1 through present event number.

#### TABLE B-5 ORDER OF SAMPLE COLLECTION BERMITE DIVISION, WHITTAKER CORPORATION pH, Specific Conductance Total Organic Carbon (TOC) 1 2 Total Organic Halogen (TOX) 3 Gross Alpha, Gross Beta 4 5 Sulfate, Chloride 6 Trichloroethene (TCE) 7 Sodium, Iron, Manganese 8 Nitrate 9 Turbidity 10 Lead Fluoride 11



36 B. J.: Tunnell Blvd. East Miami, Oktahoma 74354-3300 888-331-7425 A Member of the Specially Materials Division, Eagle-Picher Industries, Inc.

# EAGLE PHCHER

36 B. J. Tunnell Blvd. East Miami, Oktahoma 74354-3300 888-331-7425 A Member of the Specially Materials Division, Eagle-Picher Industries, Inc.

#### Level II Certification

Eagle-Picher level II bottles have been washed in conjunction with the procedures set by the EPA for quality-controlled sample containers.

#### Wash Procedure A

- Bottles, liners, and caps washed in laboratory-grade, non-phosphate detergent.
- Rinsed three times with distilled water.
- 3. Rinsed with 1:1 nitric acid.
- Rinsed three times with ASTM-Type 1 organic-free water.
- 5. Oven-dried for one hour.
- 6. Rinsed with hexane.
- 7. Oven-dried for one hour.

Verified by: ( Like Steephile

## Level II Certification

Eagle-Picher level II bottles have been washed in conjunction with the procedures set by the EPA for quality-controlled sample containers.

#### Wash Procedure A

- Bottles, liners, and caps washed in laboratory-grade, non-phosphate detergent.
- 2. Rinsed three times with distilled water.
- 3. Rinsed with 1:1 nitric acid.
- Rinsed three times with ASTM-Type 1 organic-free water.
- 5. Oven-dried for one hour.
- 6. Rinsed with hexane.
- 7. Oven-dried for one hour.

Verified by:



EAGLE PICHER ENVIRONMENTAL SERVICES

36 B. J. Tunnell Blvd. East Miami, Oklahoma 74354-3300 800-331-7425 A Member of the Specially Materials Division, Eagle-Picher Industries, inc.

#### Level II Certification

Eagle-Picher level II bottles have been washed in conjunction with the procedures set by the EPA for quality-controlled sample containers.

#### Wash Procedure A

- Bottles, liners, and caps washed in laboratory-grade, non-phosphate detergent.
- 2. Rinsed three times with distilled water.
- 3. Rinsed with 1:1 nitric acid.
- Rinsed three times with ASTM-Type 1 organic-free water.
- 5. Oven-dried for one hour.
- 6. Rinsed with hexane.
- 7. Oven-dried for one hour.

Verified by: July Shaphaid



36 B. J. Tunnell Blvd. East Miami, Oklahoma 74354-3300 800-331-7425 A Member of the Specially Materials Division Eagle-Picher Industries, Inc.

#### Level II Certification

Eagle-Picher level II bottles have been washed in conjunction with the procedures set by the EPA for quality-controlled sample containers.

#### Wash Procedure A

- Bottles, liners, and caps washed in laboratory-grade, non-phosphate detergent.
- 2. Rinsed three times with distilled water.
- 3. Rinsed with 1:1 nitric acid.
- Rinsed three times with ASTM-Type 1 organic-free water.
- 5. Oven-dried for one hour.
- 6. Rinsed with hexane.
- Oven-dried for one hour.

Verified by: Let Shaphan

This is your Certificate of Analysis for I-CHEM SUPERFUND-ANALYZED™ product which has been prepared in accordance with I-CHEM Performance-Based Specifications. This product meets or exceeds analyte specifications established in the U.S. EPA "Specifications and Guidance for Contaminant-Free Sample Containers" for use in Superfund and other hazardous waste programs.

Group 1. Glass and HDPE Sample Containers for use in the analysis of Metals

<u>Analyte</u>	Detection Limit (ug/L)	<u>Analyte</u>	Detection Limit (ug/L)	Analyte	Detection Limit (ug/L)
Aluminum	< 80	Cobalt	< 10	Selenium	< 2
Antimony	< 5	Copper	< 10	Silver	< 5
Arsenic	< 2	lron	< 50	Sodium	< 5000
Barium	< 20	Lead	< 2	Sodium (HDPE)	< 100
Barium (Amber HDPE)	< 50	Magnesium	< 100	Thallium	< 5
Beryllium	< 0.5	Manganese	< 10	Vanadium	< 10
Cadmium	< 1	Mercury	< 0.2	Zinc	< 10
Calcium	< 500	Nickel	< 20	Zinc (Amber HDPE)	< 500
Calcium (HDPE)	< 100	Potassium	< 750		
Chromium	< 10	Potassium (HDPE)	< 100		

Group 2. Glass Sample Containers for use in the analysis of Semivolatiles, Pesticides, and PCBs

	Group 2. Glass Sample Containers for use in the analysis of Semivolatiles, resticities, and PCDs							
Compound	Ouantitation Limit(ug/L)	Compound Quant	itation Limit(ug/L)	Compound	Quantitation Limit(ug/L)			
Acenaphthene	< 5	Acenaphthylene	< 5	Anthracene	< 5			
Benzo(a)anthracene	< 5	Benzo(a)pyrene	< 5	Benzo(b)fluoranthene	< 5			
Benzo(k)fluoranthene	< 5	Benzo(g,h,i)perylene	< 5	Benzoic Acid	< 20			
Benzyl Alcohol	< 5	4-Bromophenyl-phenylether	< 5	Butylbenzylphthalate	< 5			
4-Chloroaniline	< 5	4-Chloro-3-methylphenol	< 5	bis-(2-Chloroethoxy)n	nethane < 5			
bis-(2-Chloroethyl)ether	< 5	bis-(2-Chloroisopropyl)ether	< 5	2-Chloronaphthalene	< 5			
2-Chlorophenol	< 5	4-Chlorophenyl-phenylether	< 5	Chrysene	< 5			
Di-n-butylphthalate	< 5	Di-n-octylphthalate	< 5	Dibenzo(a,h)anthracei	ne < 5			
Dibenzofuran	< 5	1,2-Dichlorobenzene	< 5	1.4-Dichlorobenzene	< 5			
1,3-Dichlorobenzene	< 5	3,3'-Dichlorobenzidine	< 5	2,4-Dichlorophenol	< 5			
Diethylphthalate	< 5	Dimethylphthalate	< 5	2.4-Dimethylphenol	< 5			
4,6-Dinitro-2-methylphen	ol < 20	2,4-Dinitrophenol	< 20	2,4-Dinitrotoluene	< 5			
2.6-Dinitrotoluene	< 5	bis-(2-Ethylhexyl)phthalate	< 5	Fluoranthene	< 5			
Fluorene	< 5	Hexachlorobenzene	< 5	Hexachlorobutadiene	< 5			
Hexachlorocyclopentadier	ne < 5	Hexachloroethane	< 5	Indeno(1,2,3-cd)pyrer	ne < 5			
Isophorone	< 5	2-Methylnaphthalene	< 5	2-Methylphenol	< 5			
4-Methylphenol	< 5	2-Nitroaniline	< 20	3-Nitroaniline	< 20			
4-Nitroaniline	< 20	N-Nitroso-di-n-propylamine	< 5	N-Nitrosodimethylam	ine < 5			
N-Nitrosodiphenylamine	< 5	Naphthalene	< 5	Nitrobenzene	< 5			
2-Nitrophenol	< 5	4-Nitrophenol	< 20	Pentachlorophenoi	< 20			
Phenanthrene	< 5	Phenol	< 5	Pyrene	< 5			
1.2.4-Trichlorobenzene	< 5	2,4,5-Trichlorophenol	< 20	2,4,6-Trichlorophenol	< 5			
Azobenzene	< 5	Carbazole	< 5	Aldrin	< 0.01			
4,4'-DDD	< 0.02	Endosulfan II	< 0.02	Alpha-BHC	< 0.01			
4,4'-DDE	< 0.02	Endosulfan Sulfate	< 0.02	Beta-BHC	< 0.01			
4,4'-DDT	< 0.02	Endrin	< 0.02	Delta-BHC	< 0.01			
Dieldrin	< 0.02	Endrin Aldehyde	< 0.02	Gamma-BHC	< 0.01			
Endosulfan I	< 0.01	Heptachlor	< 0.01	Heptachlor Epoxide	< 0.01			
Methoxychior	< 0.10	Endrin Ketone	< 0.02	Alpha-Chlordane	< 0.01			
Gamma-Chlordane	< 0.01	Toxaphene	< 0.30	Aroclor-1016	< 0.20			
Aroclor-1221	< 0.20	Aroclor-1232	< 0.20	Aroclor-1242	< 0.20			
Aroclor-1248	< 0.20	Arocior-1254	< 0.20	Aroclor-1260	< 0.20			
Aroclor-1262	< 0.20	Aroclor-1268	< 0.20					
	6 -161 -6							

Group 3. Glass Sample Containers for use in the analysis of Volatile Organics

or our or other containers for use in the analysis of volume organics					
Compound	Quantitation Limit(ug/L)	Compound O	uantitation Limit(ug/L)	Compound C	Quantitation Limit(ug/L)
Acetone	< 5	1,3-Dichloropropane	< 1	Benzene	< 1
2.2-Dichloropropane	<	Bromobenzene	< 1	1,2-Dichloropropane	< 1
Bromodichloromethane	< 1	trans-1,3-Dichloropropen	e < I	Bromoform	<1
cis-1,3-Dichloropropen	e <1	Bromomethane	< 1	I, I-Dichloropropene	< 1
2-Butanone	< 5	Ethylbenzene	<	tert-Butylbenzene	< 1
Hexachlorobutadiene	< 1	sec-Butylbenzene	<	2-Hexanone	< 5
n-Butylbenzene	< 1	Isopropylbenzene	< 1	Carbon Disulfide	< 1
p-Isopropyltoluene	< 1	Carbon Tetrachloride	< 1	4-Methyl-2-pentanone	< 5
Chlorobenzene	<	Methylene Chloride	< 2	Chloroethane	< 1
Naphthalene	<1	Chloroform	< 1	n-Propylbenzene	< 1
Chloromethane	<1	Styrene	< 1	2 & 4 Chlorotoluene	< 1
1.1,2,2-Tetrachloroetha	ane < i	1,2-Dibromo-3-chloropro	opane < l	Tetrachloroethene	< 1
Dibromochloromethan	< 1	Toluene	< 1	1,2-Dibromoethane (E	DB) < 1
1.2.3-Trichlorobenzene	< 1	Dibromomethane	< 1	1,2,4-Trichlorobenzen	e < i
1.4-Dichlorobenzene	<	1.1.2-Trichloroethane	< 1	1,3-Dichlorobenzene	< 1
1.1,1-Trichloroethane	<1	1.2-Dichlorobenzene	< 1	Trichloroethene	< 1
Dichlorodifluorometha	-	Trichlorofluoromethane	< 1	1.2-Dichloroethane	<1
1.2.3-Trichloropropane		1.1-Dichloroethane	< 1		
trans-1,2-Dichloroethe		1,3,5-Trimethylbenzene	< 1		
Vinyl Acetate	< 5	1,1-Dichloroethene	< 1		
Xylenes (total)	< 1	1.2.4-Trimethylbenzene	< 1		
Vinyl Chloride	< 1	cis-1,2-Dichloroethene	< 1		

Please keep this certificate for your records and to facilitate any necessary correspondence. If additional information is required, contact our Technical Service Department at (800) 443-1689 or (800) 262-5006 inside California.

Randy E. Benson
Corporate Quality Assurance Manager



# APPENDIX C CHAIN-OF-CUSTODY FORMS

N:

										FIELD COORDINATOR
				CHAIN (	OF CUSTODY REC	ORD				GLEN ABOUN-NUR
	PROJEC	TNAM	IE						$\top$	
. भ IS (Sign	BE F	2 HIT	E à	317 AREA 13RD GTR	4. WATER SAMPING	NUMBER	نع رمي جم تير			9544.076
							h VI			REMARKS
DATE	TIME		GRAB	STATI	ION LOCATION	CONTAINERS	PRESERV H2501			
			×	MONITO	RWG UEII	1				ANALYSIS TYPE A
1(	1002		×		M	l	×			11 B
		1	X		11	1	×			u c
11			X		` \( ` ` ` ` ` `	ì				N E
	1007		γ		\\	١				'I H
H	1008		X		l\	3				11 0
			x		16	1				11 R
11	10/0		X		\1	1				11 5
			X		11	)				II T
<u> </u>			X		11	1				II U
ic	1015		8		И	1				11 N
hed by		_		Date Tim			Relinquish	ed by: (Sig	neture)	6-22 Time Received by: (Signature) 1326 SBurungan
hed by	: (Signatu	re)			ne Received by: (Signetu	re)	Relinquish	ed by: (Sig	meture)	Date Time Received by: (Signature)
hed by	: (Signetu	re)		Date Tin	ne Received for Leborato (Signature)	ну бу:	Dete	Time	Remarks	
	DATE  9/27/9/1  11  11  11  11  11  11  11  11  11	DATE TIME  427 1000  11 1001  11 1006  11 1009  11 1010  11 1010  11 1010  11 1010  11 1010  11 1010  11 1010  11 1015	DATE TIME COMP  1002  11 1002  11 1003  11 1009  11 1010  11 1010  11 1010  11 1010  11 1010  11 1010  11 1015	DATE TIME COMP GRAB  427, 1000 X  11 1001 X  11 1006 X  11 1009 X  11 1010 X	PROJECT NAME  3 (7 A REA  3 (7 A REA  3 (8 A REA  3 (7 A REA  3 (7 A REA  3 (8 A REA  4 A REA  4 A REA  4 A REA  4 A REA  5 TAT  6 A REA  6 A REA	PROJECT NAME  3 (7 AREA  BERMITE 23RD, GTR, WATER SAMPLINE  IS (Signature)  DATE TIME COMP GRAB STATION LOCATION  402, 1000 X MONITORING UEII    11 1001 X 11  11 1000 X 11  11 1010 X 11  11 1010 X 11  11 1010 X 11  11 1015 X 1	3 (7 AREA 3 (7 A	PROJECT NAME  3 (7 A REA  1.4 (BERMITE 23 RD, GTR, WATER SANGUY)  OF  2 3  OF  2 4  OF  2 5  CONTAINERS  CONTAINER	PROJECT NAME  3 (7 A REA  3 (7 A REA  SSIGNALURA)  DATE TIME COMP GRAB STATION LOCATION  OF  CONTAINERS  STATION LOCATION  I   0   0   X	PROJECT NAME  3 (7 A REA  BERNITE 23RD, GTR. WATER SANDIUM  OF  OF  OT  OT  IIIME COMP GRAB  STATION LOCATION  CONTAINERS  STATION LOCATION  IIIME COMP GRAB  STATION LOCATION  IIIME CONTAINERS  STATION LOCATION  IIIME COMP GRAB  III

							<del></del>			<del></del>			FIELD COORDINATOR
					CHAI	N OF	CUSTODY REC	מפטי					C = 0
PROJ. NO.		PROJEC	T NAM	E			CUSTODI REC	JUKD				T T	GLEN ABOUN-NUR
SAMPLER	DATE	TIME	COMP	E 2	(Ca)	WATE	CR SAMPLING	NUMBER  OF  CONTAINERS	PRESERVED WITH HOSELAS				REMARKS
MW3/A/23				λ	MONIT	ORIN	GWEIL3	١					ANALYSIS TYPE A
~~316/23		1022		x		7(		(	*				In B
mw3/c/23		1024		×		11		\	X				" C
M3E/13		1026		X	,	,		ľ					II E
MW3/H/23	9	1028		Х		ν(		)					\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
mu3/0/23	11	io 30		λ		l,		3					١ 0
mu3/R/23	11	103,3		×		Υ		1					I R
M47/5/27	11	1036		X		1		١					١
MU3/1/23	"	1037		X		11		١					т у
m3/U/23	И	1038		X		11		l					11 U
m3/N/23	"	1040		X		t)							11 ~
Relinquish					Date Date	Time	Received by: (Signature) Received by: (Signature)	in	Relinqui		Du	i.	Dete Time Received by: (Signature)  SBOWN  Time Received by: (Signature)  Dete Time Received by: (Signature)
Relinquish	ned by:	(Signetui	re)		Date	Time	Received for Laborato (Signature)	ну бу:	Date	r	ime	Remarks	•

														FIELD COORDINATOR	
					CHAI	N OF	CUSTODY REC	CORD						GLEN ABOUN-NUR	
PROJ. NO	. 4   S (Sigi	PROJEC BE	RMII	3 E 2	17 AREA 3 FO. GTR	L- YATE	er samplwe	NUMBER OF	RNED WITH 3x & A					REMARKS	
STA NO.	DATE		сомр	GRAB	s	STATION L	OCATION	CONTAINERS	MRESERY H2SU1						
MW5/A/23	427	1045		x	Manita	3R1N1	SWEIL 5	1						ANALYSIS TYPE	A
1-15/13/23	u	1047		X		11		ı	×					1(	B
w51e123	11	1049		X		11		١	×					Ч	C
405/E/23	lı.	10.50		X		. (		1		٠.				11	E
eu 5/H/23		1052		አ		((								11	#
1W5/0/13	ll.	1054		*		(	(	3						11	G
-w5/R/23		1058		x		1		١						11	R
245/5/23	Ħ	1059		X	7.1.	11		1						)(	S
4W5/T/23		1100		Х		l								11	T
10/23		1102		λ			<b>,</b>	١						Ч	U
-w5/4/23	11	1104		×		//		١						11	7
						T									
Relinquisi	ned by		(0)		Date 22	Time (2:32)	Received by: (Signety	[9] 	Relin	quiahe 	id by: (\$	ignet	uro)	- 6/23/94 1326 SBerry	100
Relinquisi	ned by:				Date	Time	Received by: (Signatu	re)	Relin	quishe	xd by: (S	Signat	ure)	Date Time Received by: (Signature)	
Relinquis	hed by:	: (Signetu	re)		Date	Time	Received for Leborato (Signature)	эгү бу:	Di	rte	Tim	R	emarks		
									1		<u> </u>				

DISTRIBUTION O ..... LA.....

1° 1 C

				·											FIELD COOF	RDINATOF	
		Y			CHAI	IN OF	CUSTODY REC	CORD			· · · · · ·				GLE,	NAB	DUN-NUR
PROJ. NO		PROJEC			317 A	RFA											
85-01	4	BER	MIT	E	23 ro a	TR. WA	ER SAMPING		#								
SAMPLER	S (Sigi	nature)		_				NUMBER	402								REMARKS
						7		OF	I								·
STA NO.	DATE	TIME	СОМР	GRAB		STATION L	OCATION	CONTAINERS	PRESERVED H 7504; C								
w6/A/23	4279			χ	MGNI	TORIN	GWEll 6	1							APA	1/51:	STYPE A
w6/6/23		11,2	1	L		U		1	Х							1	
w6/c/27	)(	11/4		χ		η		١	X							Ų	C
W6/E123	ι(	1116		χ.		11		١				•	•	٠		i i	E
~~(_/k/23	11	1118		K		lı		l								10	Н
16/0/23	1	1120		X		11		3								10	0
·U(/R/23	11	1124		Х		11		1								1	r
w(d5)23	11	1125		Χ		1(		1									11 5
14/7/23	4	1126		X		11		1									lı T
nu6/0/27	1(	1128		Y		lı		١									u U
בלע/טיים	Ιί	1130		X		U		\									11 1
Relinquiel	ned by:	(Signatur	(0)		Date 2-Sep	Time /21,32	Received by: (Signatu	(°)	Relin	quish:	ed by: (S	1910	(ure)		6/23/9×	132C	Received by: (Signature)
Relinquis	ned by:	(Signetul			Dete	Time	Received by: (Signetu	re)	Relin	quish	d by: (S	igna	ture)		Date	Time	Received by: (Signature)
Relinquis	hed by	: (Signatu	re)		Date	Time	Received for Leborato (Signature)	жу бу:	Di	ete	Time	•	Remarks	<del></del>		<u> </u>	
						1			1		1	l_					

															11.	
													FIELD COOF	DINATOR		
					CHA]	N OF	CUSTODY REC	CORD					GLEN	ABO	UN-NUR	
PROJ. NO		PROJEC	T NAM	IE	3/7	AREA										
85-01- SAMPLER	니 S (Sign	BER	MIT		73RD. Q7	R. WA	ER SAMPING	NUMBER	15 D WITH						REMARKS	
STA NO.	DATE			GRAB	lan	STATION L	OCATION	OF	PRESERVED H35046							
wi94/23	423/94	1135		×	Mani	TORI	NG WEII 10	1					ANAL	7515	TYPE	A
ود اوانه، ن	11	1137		×		( )		١	X	<u> </u>				<u> </u>	, <b>,</b>	В
10.0/¢/23		1139		X		(	1	١	×					1 (		С
1W12/E/13	įί	1141	·	X	, ,	. (	1	(	. ,		• ,	·		<u> </u>		E
wal#/23	1(	143		λ		(	1	١						1 (		Н
nusaj9/13	11	1175		χ	<u>-</u>		11	3						11		G
weir123	Ŋ	1150		X			11							11		R
15/23 د ناه		1152		X			11	1						(	(	S
₩û/r/13	Ŋ	1153		λ			11	l							(1	1
10,0/0/23	11	1154		×			\( \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	1							1)	U
460 /123	11	1156		×			11	(							······································	$\sim$
Relinquist	ed by	(Signatur	(0)	•	Date 22-97	Time 2:30	Received by: (Signatu		Relinquie	hed by: (Si	gobi	rure)	922/g4	7326	Received by: (Sign	mure)
Relinquish	ned by:	(Signatu	(0)		Date	Time	Received by: (Signetu	re)	Relinquis	hed by: (Si	gne	lure)	Date	Time	Received by: (Sign	orviet)
Relinquish	ned by:	: (Signatu	re)		Date	Time	Received for Laborato (Signature)	ory by:	Date	Time	F	lemarks	1			

N

															<del></del>		11.		
															FIELD COOR	DINATOR			
					СНАІ	N OF	CUSTODY REC	CORD							GLEI	V AC	50UN-	NUR	
PROJ. NO		PROJEC	TNAM	IE	317 A	RFA													
85-01	.4	BER	2 MY	TE	2380 a	re / 14	TER SAMPLING		ITH										
SAMPLER	S (Sigi	natura)			_		TER STITLES V	NUMBER	3 CR						1		REMARKS		
							',	OF	225								,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		
STA NO.	DATE			GRAB		STATION L	OCATION	CONTAINERS	PRESENSED H+5042		<u> </u>								
15/6/23 1A	427	1105		X	MONIT	-ORW	GWEll 5	1	×						ANA	76451	5 T Y F	E	В
inskþ3 ia	4	1105		X		10		ţ	×							,	\\		C
10 10	Ц	1105		+		10		3									<i>k</i> ı		0.
WEJBP3	łţ	11.31		X	MONIT	or w	GUEII 6	1	×								<u>``</u>		В
NA NA	y	1131		K		Ŋ		1	×								11		С
106/0/27 1A	11	132		x		l(		3											ß
		····							ļ										
					10				ļ										
						<del></del>							-						
									<u> </u>				<b></b>						
													-						
Relinquis	ned by:	(Signatu	re)		Date	Time	Received by: (Signety	nr•)	Relin	quishe	d by: (S	igna	(yeze)	<u></u>	Date	,Tim <b>e</b>	Received b	y: (Signatur	•)
					225	12:30	15	<u> </u>	-			H)	5	<u> </u>	422/94	1326	SRO	າດຄູ້ແ	nello
Relinquis	hed by				Date	Time	Received by (Signatu	ure)	Relin	quishe	d by: (S	igna	iture)		Date	Time	Received t	y: (Signatur	•//
Relinquis	hed by	: (Signetu	ır e)		Date	Time	Received for Laborate (Signatura)	ory by:	ט	ete	Time	•	Remarks	)	1	L			

# APPENDIX D SAMPLE ANALYSES REQUEST FORMS

Sampling Inform	ation			2	SIT AR	<i>L 4</i>		
Project No. 85	5-0/.4 Pro	oject	Name:	BER	MITE	23RO 6	LTP WATER SA	4fi
Sampler Name: 🤄	LEDABOUN-NUR/TIM BRICK	ER	Tele	. но.	(805	259	2241	
Name of Person	Receiving Samples:	SB	errin	a tor	)			
	ceived:0/22/0			<i>U</i>				
Internal Temper	ature of Sample Con	tainer	. <u>e</u>	<del>} </del>		,		
Notes on Sample								
			Analy	sis F	Requir	ed		
		PHIEC	706	TOX	GROSSARHHA GROSSBLTA	SSLFATE, CHLORIOE	TCE	
Sample I.D.	Laboratory I.D.	·						
MW1/A/23	403651-1	×				·		
Mu1/8/23			×					
mw1/c/23				X.				
MUI/E/23					×			
MU1/H/23						X		
MW1/0/23	V						$ \gamma $	
		-						
		-			ļ			

Sampling Informa	ation			2 (~	) ARSA			
Project No. 85	-01.4 Pr	oject	Name:	BERM	TE 23	RD CTR	·WATER	SAMPIN
Sampler Name: 🖭	EN ABOUN-NUR/TIMBA	ICKER	Tele	. No.	(805	259-3	2341	
Name of Person F	Receiving Samples:	SBe	errin	gtcl	)			,
Date Samples Red	celved: 6/22/	94		0				,
Internal Tempera	ature of Sample Con	tainer	·	<u> </u>				•
Notes on Sample:	s;				<del></del>			,
				sis F	Requir	ed		
		TRON, MANCANESE, SODUM	NTRATE	TURBIDITY	LEAD	FLOURIDE		
Sample I.D.	Laboratory I.D.							
MWI/R/23	403651-1	×				· _		
MW1/s/23			×					
MWI/T/23				$\chi$				
MW1/U/23					X			
MW1/N/23	V					×		
								1

Sampling Inform	nation			2	IT ARG	c <u>a</u>		
Project No. 8	5-0/.4 Pr	oject	Hame:	BER	MITE	23RO a	TR WATE	FR SAMPIN
Sampler Name: G	HERABOUN-NUR/TIM BRIEF	ER.	Tele	. но.	(805)	259.	2241	
	Receiving Samples:		rring	gton	···			
Date Samples Re	ecelved: 6122	194		J	<del></del>			
Internal Tempe	rature of Sample Cor	ntainer	· ·	<del>)</del>	<del></del>			
Notes on Sample	es:				<del></del>			,
			Analy	sis F	Requir	ed		
		PH, EC	706	Tox	GROSSARPHA GROSSBETA	SSLFATE, CHLORNOE	TCE	
Sample I.D.	Laboratory I.D.							
MW3/A/23	40365,7-1	×				÷		
MW3/B/23			*					
MW3/C/23				$\sim$				
MW3/E/23					\ \ \			
MW3/H/23						×		
MW3/R/23	V						X	
			-					
					-			1
			1		<del> </del>	-		1
			1			-		-
				1				-
ļ								

Sampling Inform	ation			2.5	AREA			
Project No. 85	-01.4 Pr	oject 1	Name:	BERM	TE 231	RD OTR	·WATER	SAMPIN
Sampler Name: G	IEN ABOUN-NUR/TURBI	RICKER	Tele	. но.	(805)	259.	2341	
Name of Person	Receiving Samples:	SB	errir	ator				
	celved: 0/22/9			0				
	ature of Sample Cor		:	<del>-</del>				
Notes on Sample								
•		,	Analy	sis F	equir	ed		
		TRON! MANGANESE SODUM	NTRATE	TURBOITY	LEAD	FLOURIDE		
Sample I.D.	Laboratory I.D.	•						
MW3/R/23	403657-1	X				·		
MW3/5/23			×					
MW3/T/23				7				
MW3/U/23					×			
MW3/N/03						×		
·								
	<del>                                     </del>							

Sampling Informa	tion			7	BIT ARC	c <u>a</u>		
Project No. <u>85</u>	-0/.4 Pr	oject	Name:	BER	MITE	23RO 0	TRWAR	FR SAHPIN
Sampler Name: Gi	ED+BOUN-NUR/TIMBRIER	ER	Tele	. но.	(805	259.	2241	
	Receiving Samples:							
	celved: <u>6 [22]</u>			J	***************************************			
	ature of Sample Con		., -	<del></del>				
		10011181	•					
Notes on Sample:	s:	<del></del>	Analy	sis )	Requir	ed		
		<u> </u>	711123					
		PH, EC	706	TOX	GROS5A18	SSIFATE, CHLORIDE	TCE	
Sample I.D.	Laboratory I.D.							
MW5/A/23	403653-1	×						
M45/B/73	\		×					
MU5/e/23				X				
MW5/E/23					X			
MUS/H/23						X		
MW5/0/23	1						×	

Project No. 85-0/.4 Project Name: 6ERMITE 23RD QTR. WAR  Sampler Name: GIEW ABDUN-NUR/TM BRICKER Tele. No. (805) 259-2341  Name of Person Receiving Samples: Serring ton  Date Samples Received: 6/22/94  Internal Temperature of Sample Container: Analysis Required	
Tame of Person Receiving Samples: SBerrington  Nate Samples Received: 6/22/94  Internal Temperature of Sample Container: 6  Notes on Samples:	
Tame of Person Receiving Samples: SBerrington  Date Samples Received: 6/22/94  Enternal Temperature of Sample Container: 6  Hotes on Samples:	_
Nate Samples Received: 6/22/94  Internal Temperature of Sample Container: 6  Notes on Samples:	
Internal Temperature of Sample Container:	
Notes on Samples:	
ANAIVSIS REGULTED	-
	7
TURBIDITY TOURIDE	
THEON, MANNER SOCIUM SOCIUM LEAD LEAD FLOURIDE	
	4
Sample I.D. Laboratory I.D.	_
MW5/R/23 403653-1 X	_
MW5/5/23 Y	
MU5/T/23	
mw5/v/23 x	
mws/n/23 V	

Sampling Inform	ation			-	217 40	<i>.</i>		
Project No. 85	5-0/.4 Pr	oject	Name:	BER	BIT ARO CMITE!	23RO, <del>a</del>	TR WHER	SAMPI.
Sampler Name: G	IED+BOUN-NUR/TIM BRIEF	SER.	Tele	. но.	(805	259.	2241	
	Receiving Samples:				_			
	celved: 612210			Ü				
	rature of Sample Cor		<u> </u>	<del>-</del>				
Notes on Sample								
•			Analy	sis	Requir	ed		
		PH, EC	706	TOX	GROSS ALTA	SOLFATE, CHERNOE	TCE	
Sample I.D.	Laboratory I.D.							
MW6/A/23	403654-1	×				,		
MW6/B/23	i		X					
Mub/c/33				7		1		
MW6/E/23					A			
mu 6/11/23						x		
MU6/0/23	V						X	
		·						

Sampling Inform	ation			2 ( >				
Project No. 85	-0).4 Pr	oject	Name:	BERM	TE 23	RD OTR	. WATER	SAMPIN
Sampler Name: G	IEN ABOUN-NUR/TURB	RICKER	Tele	. но.	(805	259-	2341	
Name of Person	Receiving Samples:	SB	erri	nato	3h			
	celved: 612219			<u> </u>				
	ature of Sample Cor		:	0				
Notes on Sample								
		,	Analy	sis F	lequir	ed		
		TRON, MANCANEZ, SOMUM	NTRATE	TURBIDITY	LEAD	FLOURIDE		
Sample I.D.	Laboratory I.D.							
MW6/R/23	403654-1	X						
mu6/5/23	1		×					
MU6/T/23				X				
mu6/0/23					X			
MU6/N/23	$\bigvee$					X		

Sampling Inform	ation			2				
Project No. 85	-0/.4 Pr	oject	Name:	BER	MITE !	<del>SH</del> 23RO G	TRWAR	FR SAHAPI
	LEDABOUN-NUR/TIM BRIEF							
	Receiving Samples:							
Date Samples Re	ceived: 6/22/9L	.)		3				
	ature of Sample Cor			<del>}</del>				
Notes on Sample	·		. —					
			Analy	sis I	Requir	ed		
		PHIEC	706	TOX	GROSSANGHA GROSSBETA	SCIFATE, CHLORIDE	TCE	
Sample I.D.	Laboratory I.D.	•						
MW18/A/23	403655-1	×						
MW10/B/23			X					
MU10/0/23				×				
MW18/E/23					K			
MW18/H/23						X		
Mu10/0/23	V						X	
		_						
			-					

Sampling Information				2.5				
Project No. 85-01.4	Pro	oject	Name:	BERMI	ARSA TE 231	RD OTR	·WATER	SAMPIN
Sampler Name: GIEN ABOU	N-NUR/TMBR	ICKER	Tele	. но.	(305)	259-3	2341	
Name of Person Receivin	g Samples:	SBe	rrir	ato	n			
Date Samples Received:	6/22/94			0				
Internal Temperature of	Sample Con	tainer	:	<u> </u>				
Notes on Samples:								
			Analy	sis R	equir	ed		
		TRON, MARCANEZ, SODIUM	NTRATE	TURBIDITY	LEAD	FLOURIDE		
Sample I.D. Laborat	ory I.D.							
mwje/R/23 403	655-1	*				·		
MW10/5/23			×					
MU10/T/23				<b>X</b> .				
MW10/U/23					K			
MW10/N/23						X		

Sampling Inform	ation				317 <i>M</i>	2 E A	
	5-01.4 Pr			BERM	ITE 2	3 R.D. a	
Sampler Name: 🤇	ILENABOUN-NUR/TIMBR	lier er	Tele	. No.	(80	5)25	9-2241
	Receiving Samples:		errir	gto	ካ		
Date Samples Re	ceived: 6/22/9	<u> </u>					<del></del>
Internal Temper	rature of Sample Con	tainer	:	<u> </u>			
Notes on Sample	(S:	<del></del>					
			Analy	ysis F	Requi	red	
		ÌOC	Tox	TCE BY 601			
Sample I.D.	Laboratory I.D.						
MU5/B/23/1A	403653-2	×					
MU5/0/23/14			X				
MU5/0/23/1A	V			X		ļ	
Muil B/23/1A	403654-2	7					
MULL 12/73/1A		-	X			ļ	
MW6/0/23/19	V	<u> </u>		X		ļ	
		·				-	
			1	-	-	-	

# APPENDIX E FGL QUALITY ASSURANCE/QUALITY CONTROL (QA/QC) PROGRAM



July 12, 1994

INORGANIC QA/QC Report for samples: 403651-403655

Bermite Division of Whittaker 22116 W. Soledad Canyon Road Saugus , CA 91350

	BATCH	EPA		BL	ANK QA/QC			CAL I B	RATION	QA/QC					METHOD	QA/QC			
Constituent	ID	Method	Units	DLR	Result	NOTE	Туре	Conc.	% REC	AR	NOTE	Туре	Conc.	% REC	% REC	AR	% DIF	MAV	NOTE
Iron	128	200.7	ug/L-mg/L	50	ND		LCS	1000	96.8	86-113		MS	556	103	81.9	75 - 125	2.0	20.	
Lead	52A	200.8	ug/L-mg/L	0.50	ND		LCS	50.0	102	75-125		MS	20.8	105	106	75-125	1.0	20.0	
Manganese	128	200.7	ug/L-mg/L	30	ND		LCS	1000	98.0	90-109		MS	556	100	99.9	75-125	0.2	20.	
Sodium	12A1	200.7	mg/L	1.0	ND ·	`	LCS	100	101	75-125	:	MS	22:2	103	87.9	75-125	5.2	20.0	
Chloride	62A	300.0	mg/L	1.0	ND		CCV	101	99.2	93-110		MS	200	92.4	95.7	85-111	2.4	4.1	
	62B	300.0	mg/L	1.0	ND		ccv	101	101	93-110		MS	200	96.2	98.5	85-111	2.0	4.1	
Conductivity	52C	120.1	umhos/cm2	· · · · · · · · · · · · · · · · · · ·	N/A		LCS	1410	100	99-100		Dup	1010	N/A	N/A	N/A	0.0	3.0	
Fluoride	12B	340.2	mg/L	0.10	ND		LCS	12.6	100	75-125		MS	2.00	100	101	75-125	0.2	20.0	
Nitrate	720	353.2	mg/L	0.10	ND		LCS	9.58	102	75-125		MS	2.48	101	106	87-114	3.5	7.3	
pН	02A	150.1	units		N/A		LCS	8.00	99.1	97-101		Dup	7.66	N/A	N/A	N/A	0.1	1.4	
Sulfate	62A	300.0	mg/L	1.00	ND		ccv	107	91.3	89-109		MS	200	90.3	92.8	75-123	1.8	2.8	
	62B	300.0	mg/L	1.00	ND		ccv	107	88.8	89-109		MS	200	97.8	98.3	75-123	0.4	2.8	

FGL ID = 19940622 ND => Not Detected at an above DLR. DLR => Detection Limit for Reporting purposes. N/A => Not Applicable NOTE => See note indicated below.

FGL ENVIRONMENTAL, INC.

Kurt Wilkinson, QA/QC Director

KW/DHN:cl



July 12, 1994

INORGANIC QA/QC Report for samples: 403651-403655

Bermite Division of Whittaker 22116 W. Soledad Canyon Road Saugus , CA 91350

	ВАТСН	EPA		Ві	LANK QA/QC			CALIB	RATION O	A/QC					METHOD	QA/QC			
Constituent	ID	Method	Units	DLR	Result	NOTE	Туре	Conc.	% REC	AR	NOTE	Туре	Conc.	% REC	% REC	AR	% DIF	MAV	NOTE
Turbidity	02A	180.1	טזא		N/A				N/A			Dup	0.0800	N/A	N/A	N/A	0.0	27.2	

FGL ID = 19940623 ND => Not Detected at ar above DLR. DLR => Detection Limit for Reporting purposes. N/A => Not Applicable NOTE => See note indicated below.

FGL ENVIRONMENTAL, INC.

KW/DHN:cl



July 11, 1994

RADIOCHEMISTRY QA/QC Report for samples: 403651-403655

Bermite Division of Whittaker 22116 W. Soledad Canyon Road Saugus , CA 91350

	ВАТСН	EPA		BL.	ANK QA/QC			CALIB	RATION Q	A/QC					METHOD	QA/QC			
Constituent	ID	Method	Units	DLR	Result	NOTE	Туре	Conc.	% REC	AR	NOTE	Туре	Conc.	% REC	% REC	AR	% DIF	MAV	NOTE
Gross Alpha	02A	900.0	pCi/L	1.0	ND				N/A			MS	50.1	93.9	110	60-140	13.1	30.0	
Gross Beta	02A	900.0	pCi/L	1.0	ND				N/A			MS	42.5	112	109	80-130	2.9	30.0	

FGL ID = 19940624 ND => Not Detected at an above DLR. DLR => Detection Limit for Reporting purposes. N/A => Not Applicable NOTE => See note indicated below.

FGL ENVIRONMENTAL, INC.

MMF/DHN:cl



July 8, 1994

ORGANIC QA/QC Report for sample: 403651

Bermite Division of Whittaker 22116 W. Soledad Canyon Road Saugus , CA 91350

	ВАТСН	EPA			CALIB	RATION	QA/QC					METHOD	QA/QC			
Constituent	ID	Method	Units	Туре	Conc.	% REC	AR	NOTE	Туре	Conc.	% REC	% REC	AR	% DIF	MAV	NOTE
тос	02A	TOC	mg/L	LCS	71.4	121	75-125		MS	50.0	117	118	75 - 125	0.5	20.0	
TOX	02A	TOX	ug/L	CCV	10.0	84.7	74-116		MS	100	87.6	99.3	75 - 125	12.5	20.0	

FGL ID = 19940630 N/A => Not Applicable NOTE => See note indicated below.

FGL ENVIRONMENTAL, INC.

HNH/DHN:cl



July 8, 1994

ORGANIC QA/QC Report for sample: 403652

Bermite Division of Whittaker 22116 W. Soledad Canyon Road Saugus , CA 91350

	BATCH	EPA			CALIE	BRATION	QA/QC					METHOD	QA/QC			
Constituent	10	Method	Units	Туре	Conc.	% REC	AR	NOTE	Туре	Conc.	% REC	% REC	AR	% DIF	MAV	NOTE
TOC	02A	TOC	mg/L	LCS	71.4	121	75-125		MS	50.0	117	118	75-125	0.5	20.0	
TOX	02A	TOX	ug/L	ccv	10.0	84.7	74-116		MS	100	87.6	99.3	75-125	12.5	20.0	

FGL ID = 19940630 N/A => Not Applicable NOTE => See note indicated below.

FGL ENVIRONMENTAL, INC.

HNH/DHN:cl



July 8, 1994

ORGANIC QA/QC Report for sample: 403653

Bermite Division of Whittaker 22116 W. Soledad Canyon Road Saugus , CA 91350

	ВАТСН	EPA			CALIB	RATION	QA/QC					METHOD	QA/QC			
Constituent	ID	Method	Units	Туре	Conc.	% REC	AR	NOTE	Туре	Conc.	% REC	% REC	AR	% DIF	MAV	NOTE
TOC	02A	TOC	mg/L	LCS	71.4	121	75-125		MS	50.0	117	118	75 - 125	0.5	20.0	
TOX	02 <b>A</b>	TOX	ug/L	ccv	10.0	84.7	74-116		MS	100	87.6	99.3	75-125	12.5	20.0	

FGL ID = 19940630 N/A => Not Applicable NOTE => See note indicated below.

FGL ENVIRONMENTAL, INC.

HNH/DHN:cl



July 8, 1994

ORGANIC QA/QC Report for sample: 403654

Bermite Division of Whittaker 22116 W. Soledad Canyon Road Saugus , CA 91350

	ВАТСН	EPA			CAL 18	RATION	QA/QC					METHOD	QA/QC			
Constituent	1D	Method	Units	Type	Conc.	% REC	AR	NOTE	Type	Conc.	% REC	% REC	AR	% DIF	MAV	NOTE
TOC	02A	TOC	mg/L	LCS	71.4	121	75-125		MS	50.0	117	118	75 - 125	0.5	20.0	
TOX	02A	TOX	ug/L	CCV	10.0	84.7	74-116		MS	100	87.6	99.3	75-125	12.5	20.0	

FGL ID = 19940630 N/A => Not Applicable NOTE => See note indicated below.

FGL ENVIRONMENTAL, INC.

HNH/DHN:cl



July 8, 1994

ORGANIC QA/QC Report for sample: 403655

Bermite Division of Whittaker 22116 W. Soledad Canyon Road Saugus , CA 91350

	ВАТСН	EPA		CALIBRATION QA/QC			METHOD QA/QC									
Constituent	ID	Method	Units	Туре	Conc.	% REC	AR	NOTE	Type	Conc.	% REC	% REC	AR	% DIF	MAV	NOTE
тос	02A	TOC	mg/L	LCS	71.4	121	75-125		MS	50.0	117	118	75 - 125	0.5	20.0	
TOX	02A	TOX	ug/L	CCV	10.0	84.7	74-116		MS	100	87.6	99.3	75-125	12.5	20.0	

FGL ID = 19940630 N/A => Not Applicable NOTE => See note indicated below.

FGL ENVIRONMENTAL, INC.

HNH/DHN:cl



## ANALYTICAL CHEMISTS

# Quality Assurance Manual



Corporate Offices & Laboratory
P.O. Box 272/853 Corporation Street
Santa Paula, CA 93061-0272
TEL: (805) 659-0910
FAX: (805) 525-4172

Office & Laboratory 2500 Stagecoach Road Stockton, CA 95215 TEL: (209) 942-0181 FAX: (209) 942-0423 Field Office Visalia, California TEL: (209) 734-9473 Mobile: (209) 738-6273

## QUALITY ASSURANCE MANUAL

FGL ENVIRONMENTAL 853 Corporation Street Santa Paula, CA 93060

Reviewed by:	
Dudley S. Jayasinghe, Ph.D. Technical Director	Date
Concurred by:	
Kurt Wilkinson, B.S.  Quality Assurance Director	Date
Approved by:	
Darrell H. Nelson, B.S.	Date

Section No: 2 Page: 1 of 2 Revision No: 2.0 Date: January 15, 1994

#### TABLE OF CONTENTS

<u>Se</u>	ction	Revision	<u>Date</u>	<u>Pages</u>
1	Title Page	2.0	1-15-94	1
2	Table of Contents	2.0	1-15-94	2
3	QA Plan Description	2.0	1-15-94	1
4	Laboratory Organization and Responsibilities	2.0	1-15-94	16
5	Quality Assurance Objectives for Measurement Data in Terms of Precision, Accuracy, Completeness, and Detection Limits for Reporting	2.0	1-15-94	30
6	Sampling Procedures	2.0	1-15-94	16
7	Sample Custody	2.0	1-15-94	6
8	Calibration Procedures and Frequency	2.0	1-15-94	5
9	Analytical Procedures	2.0	1-15-94	12
10	Data Reduction, Validation, and Reporting	2.0	1-15-94	2
11	Internal Quality Control Checks	2.0	1-15-94	19
12	Performance and System Audits	2.0	1-15-94	21
13	Preventative Maintenance	2.0	1-15-94	1
14	Specific Routine Procedures Used to Assess Data Precsion, Accuracy & Completeness	2.0	1-15-94	2
15	Corrective Actions	2.0	1-15-94	3
16	Quality Assurance Reports to Management	2.0	1-15-94	3
A	ppendix A - Equipment List	2.0	1-15-94	2

Section No: 2 Page: 2 of 2

Revision No: 2.0

Date: January 15, 1994

#### LIST OF TABLES

- Table 5-1 Quality Assurance Objectives for Drinking Water Methods
- Table 5-2 Quality Assurance Objectives for Wastewater / Hazardous Waste Liquid Methods
- Table 5-3 Quality Assurance Objectives for Solid Waste / Hazardous Waste Methods
- Table 6-1 Recommended Sample Containers, Preservation and Holding Times
- Table 8-1 GC/MS Volatile Organic Key Ion Abundance Tuning Criteria using BFB
- Table 8-2 GC/MS Semivolatile Organic Key Ion Abundance Tuning Criteria using DFTPP
- Table 9-1 Specific Analytical Drinking Water Methods
- Table 9-2 Specific Analytical Wastewater / Hazardous Waste Liquid Methods
- Table 9-3 Specific Analytical Solid Waste / Hazardous Waste Methods
- Table 11-1 Quality Controls for Drinking Water Methods
- Table 11-2 Quality Controls for Wastewater / Hazardous Waste Liquid Methods
- Table 11-3 Quality Controls for Solid Waste / Hazardous Waste Methods

#### LIST OF FIGURES

- Figure 4-1 Organization Chart Santa Paula Laboratory
- Figure 4-2 Organization Chart Stockton Laboratory
- Figure 7-1 Chain of Custody
- Figure 11-1 FGL Control Chart for LCS
- Figure 11-2 FGL Control Chart for MS/MSD and RPD
- Figure 12-1 FGL QC Inspection Form
- Figure 12-2 FGL Santa Paula CA DHS ELAP Certification
- Figure 12-3 FGL Stockton CA DHS ELAP Certification
- Figure 12-4 FGL Santa Paula NV DHR Certification
- Figure 15-1 Corrective Action Report Form
- Figure 16-1 FGL QC Inspection Summary Report Form

Section No.: 3
Page: 1 of 1
Revision No: 2.0
Date: January 15, 1994

#### **QA Plan Description**

The primary objective of FGL Environmental's quality assurance (QA) program is to ensure that all data is scientifically valid, defensible and of known precision and accuracy. Relative to the use for which the data are obtained, the data must be of sufficient known quality to withstand scientific and legal challenge

This manual describes the overall approach used by FGL Environmental to ensure that the primary objective of the QA/QC program is met. It outlines quality control procedures to be used with field and analytical methods. It also outlines the individual analysis data quality objectives which will accomplish the primary objective. Detailed project-specific FGL standard operating procedures to supplement this manual are provided whenever requested.

FGL's QA manual is based on the 16 essential elements contained in the U.S. Environmental Protection Agency manual "Interim Guidelines and Specifications for Preparing Quality Assurance Project Plans", QAMS-005/80.

As of the date of revision, this manual reflects the current quality assurance program in effect and items in progress of being implemented.

References for this manual include field and laboratory methods published by the U.S. Environmental Protection Agency and other agencies mainly through the following sources:

- (1) "Standard Methods for the Analysis of Water and Wastewater", 17th Edition, 1990.
- (2) "Methods for Chemical Analysis in Waters and Waste" (MCAWW) EPA-600/4-79-020
- (3) "Methods for the Determination of Organic Compounds in Drinking Water", EPA Method Book, EPA-600/4-88-039, December 1988.
- (4) "Methods for the Determination of Organic Compounds in Drinking Water-Supplement I", EPA Method Book, EPA-600/4-90- 020, July 1990.
- (5) "Methods for the Determination of Organic Compounds in Drinking Water-Supplement II", EPA Method Book, EPA-600/4- 90-020, July 1990.
- (6) "Methods for Organic Chemical Analysis of Municipal and Industrial Wastewater", EPA Method Book, EPA 600/4-82-057, July 1982.
- (7) "Methods for Evaluating Solid Waste", EPA Method Book, SW- 846, rev. 3, and Proposed Revisions.
- (8) "Prescribed Procedures for Measurement of Radioactivity in Drinking Water", EPA Method Book, EPA-600/4-80-032, August 1980.
- (9) "Handbook for Sampling and Sample Preservation of Water and Wastewater", EPA Method Book, EPA-600/4-82-029, September 1982.
- (10) "Eastern Environmental Radiation Facility Radiochemistry Procedures Manual", EPA Method Book, EPA 520/5-84-006, August 1984.
- (11) "Environmental Measurements Laboratory Procedures", HASL-300, 27th Edition, February 1992.

÷	
	į
	e de la companya de l
	3
	63 - <b>4</b> - 17 dg
	_
	- # 0:
-	
	:
	Va.
	<b>1</b>
	驗
	Apple :
	:
	•
	e de la companya de l
	• !
	:

Section No: 4 Page: 1 of 16 Revision No: 2.0 Date: January 15, 1994

#### Laboratory Organization and Responsibilities

#### Personnel of FGL Incorporated

Our commitment to providing a superior service requires the high caliber staff employed by FGL. These professionals have considerable experience to meet the technical demand of environmental analysis.

Santa Paula

Darrell H. Nelson, B.S. Denis Barry, B.Comm.

Cheryl Long

Dudley S. Jayasinghe, Ph.D.

Kurt Wilkinson, B.S. Roger Perry, B.A. Eric Cotting, M.S.

Kurt Wilkinson, B.S. Randy Johnson Mike Schraml, B.S. Darrell Shon, B.S. Shelli Perry, B.S. Christine Sullivan, B.S. Christy Masyr, B.S. Katy Prusso, B.S.

Neal Hutchison, B.S. Mark Bolyanatz, B.S. Rick Dotts, B.S. Sarah Edmundson Dudley S. Jayasinghe, Ph.D. Pam Lascoe, B.S. Juan M. Magana, B.S. Roger Perry, B.S.

Michel Franco, B.A. Laura Reed

Ricardo Sandoval, B.S. Joan McKinney

Raquel Harvey Janelle Nelson

George Trouw Scott Bucy, B.S. Carl Tashima Jamie Johnson Pete Munoz Vickie Hengehold

Eric Cotting, M.S. Gary Hornbeck Eva Anda, Ph.D.

President & Lab Director
Marketing Director
Administrative Services Director
Technical Director
Quality Assurance Director
Health & Safety Officer
Radiation Safety Officer

Inorganic Lab Manager
Trace Metals Supervisor
Environmental Chemist
Environmental Chemist
Environmental Chemist
Wet Chemistry Supervisor
Environmental Chemist
Environmental Chemist
Environmental Chemist

Organic Lab Manager Environmental Chemist Environmental Chemist Environmental Chemist Environmental Chemist Environmental Chemist Environmental Chemist Environmental Chemist

Radioactivity Lab Manager Lab Technician

Agricultural Lab Manager Lab Technician

Bacteriologist Bacteriologist

Field Services Director Field Services/Agronomist Field Services

Field Services Field Services Field Services Field Services

Computer Programmer Computer Programmer Computer Programmer

Section No: 4
Page: 2 of 16
Revision No: 2.0
Date: January 15, 1994

#### Laboratory Organization and Responsibilities

#### Personnel continued

Santa Paula continued

Beverly Baca Cindy Aguirre

Kristie Marlow Tiffany Douglas Martha Hamblin

Erin Hart Tonya Lawson Cathy Metelak Shawn Parham Vickie Taylor

Stacey Berrington Gina Kolakowski, B.A.

Stockton

John Quinn, Ph.D. Thomas M. Bartanen, M.S.

John Gregory B.S. Alisha Tran B.S. Hao Van Le, B.S.

Thomas M. Bartanen, M.S. Cynthia Phipps B.S. Madelyn Taasin Brian Sims

Mark D. Brock Patrick Wheeler

Joanna Culham Amelia de la Cruz Narine Sylvia

San Joaquin Neil Jessup, B.S. Accounting Accounting

**Customer Services Manager** 

Customer Services Customer Services Customer Services Customer Services Customer Services Customer Services Customer Services

Sample Receiving Sample Receiving

Vice President & Lab Director Quality Assurance Officer

Environmental Chemist Environmental Chemist Environmental Chemist

Environmental Chemist Environmental Chemist

Technician Technician

Field Services Field Services

Office Manager Customer Services Customer Services

Agronomist/Field Service

Section No: 4 Page: 3 of 16 Revision No: 2.0 Date: January 15, 1994

# Laboratory Organization and Responsibilities

Key Personnel Qualification Summary - Santa Paula

## Darrell H. Nelson

#### **Current Responsibilities:**

President and Lab Director

- To oversee all operational aspects of the Santa Paula and Stockton laboratories
- To guide and direct managers towards the corporation's goals
- To report to the Board of Directors and the stockholders

#### Work Experience:

Assistant Manager, FGL

- Chemical analysis of drinking and waste waters, soils and plant materials
- Supervision of a number of lab operations including work scheduling and field
- Customer Interface

#### Formal Education:

- B.S. (1970) in Soil and Water Science, University of California, Davis.

#### **Continuing Education:**

- University of Southern California (USC) School of Business Administration, "Customer Service Management," April 1990.
- Hazardous Waste Operations and Emergency Response Training, OSHA 29 CFR 1910.120, 40 hr plus annual refresher.
- American Chemical Society (ACS), "Quality Assurance for Analytical Chemistry," Nov.

- University of California Davis (UCD), "Marketing Professional Services," Feb. 1988.
  University of California Davis (UCD), "Guerrilla Marketing," Feb. 1988.
  University of California Davis (UCD), "Enhancing Sales Skills," Feb. 1988.
  American Water Works Association, "Approved Water Sampling Procedures," March
- California Agricultural Leadership Program, 1976 1978.
- NPDES Requirements for Industrial and Construction Site Storm Water Discharges, ASCE, Feb. 1992.
- Senate bill #198, compliance training (State Fund Insurance)
- Nevada Nuclear Associates, "Fundamentals of Radiochemistry", February 1994.

#### Memberships:

#### **Professional:**

- American Chemical Society
- American Water Works Association
- Association of California Testing Laboratories

Section No: 4 Page: 4 of 16 Revision No: 2.0

Date: January 15, 1994

# Laboratory Organization and Responsibilities

Key Personnel Qualification Summary - Santa Paula

# **Denis Barry**

### **Current Responsibilities:**

Marketing Director

- Responsible for marketing of FGL's services to city, county and state agencies in addition to private companies
- Compilation and implementation of FGL's marketing plans
- Responsible for FGL's informational and promotional materials

## Work Experience:

- 3 years experience in marketing analytical services
- Marketing consultancy experience focused on small to medium sized companies
- International programs targeted mainly at the European Economic Community for small U.S. companies

### Formal Education:

- B.Comm (Batchelor of Commerce), University College, Dublin, Ireland

# **Continuing Education:**

- Computer Appreciation - Moorpark College, 1989

### Memberships:

- Vice President - Irish American Club of Ventura County

Section No: 4
Page: 5 of 16
Revision No: 2.0
Date: January 15, 1994

# Laboratory Organization and Responsibilities

Key Personnel Qualification Summary - Santa Paula

Dudley S. Jayasinghe

#### **Current Responsibilities:**

Technical Director - Santa Paula

- Develop new methods and monitor and improve existing methods
- Provide guidance and technical expertise to analysts, review of data and client reports
- Consult with clients on specific needs

### Work Experience:

- 6 years on gas chromatograph/mass spectrometer
- 1 year GC/MS
- 3 years as research officer
- 2 years teaching at undergraduate level

#### Formal Education:

- B.S. (1980) in Organic Chemistry with minor in Physics, University of Peradeniya, Sri Lanka.
- Ph.D. (1989) in Analytical Chemistry with minor in Physical and Organic Chemistry, Oregon State University.

## Continuing Education:

- Post-Doctoral Research in soil chemistry August 1989 - Sept. 1990, Oregon State University.

### Memberships:

#### Professional:

- American Chemical Society
- Phi Lamda Upsilon Academic Honorarium

Section No: 4 Page: 6 of 16 Revision No: 2.0

Date: January 15, 1994

# Laboratory Organization and Responsibilities

Key Personnel Qualification Summary - Santa Paula

#### Kurt Wilkinson

## **Current Responsibilities:**

Quality Assurance Director - Santa Paula

- Primarily responsible for FGL's Quality Assurance Program

# Inorganic Lab Manager - Santa Paula

- Work scheduling and planning for Inorganic Lab
- Staff training and general management
- Client consultation on analysis needs
- Data interpretation

#### Work Experience:

- 8 years experience in environmental testing of drinking water, wastewater, hazardous waste and air analysis
- Additional experience in agricultural testing of soils, plant tissue and food products

#### Formal Education:

- B.S. (1987) in Biochemistry, California Polytechnic State University, San Luis Obispo

#### **Continuing Education:**

- American Chemical Society (ACS), "Environmental Analytical Chemistry, Water and Waste", Nov. 1991.
- American Chemical Society (ACS), "Gas Chromatography/Mass Spectrometry", April 1992.
- Halliburton NUS, "Solving the Mysteries, Collecting Environmental Samples", April 1992.

#### **Memberships:**

#### **Professional:**

- Association of California Testing Laboratories quality assurance/quality control committe member.
- American Chemical Society (ACS)

Section No: 4 Page: 7 of 16 Revision No: 2.0 Date: January 15, 1994

# Laboratory Organization and Responsibilities

Key Personnel Qualification Summary - Santa Paula

### Roger Perry

# **Current Responsibilities:**

Health and Safety Officer

- Responsible for design and implementation of FGL's Health and Safety programs
- Orgaanic Department Chemist

### **Experience:**

- 11 years experience as an environmental analytical chemist Health and Safety regulations and compliance
- Handling accumulation and disposal of Hazardous Wastes and Radioactive Materials

### Formal Education:

- B.A. (1982) in Chemistry, Sonoma State University, Sonoma, California

# Continuing Education:

- Hazardous Waste Operations and Emergency Response Training, OSHA 29 CFR 1910.120, 40 hr plus annual refresher.

Section No: 4 Page: 8 of 16 Revision No: 2.0 Date: January 15, 1994

# Laboratory Organization and Responsibilities

Key Personnel Qualification Summary - Santa Paula

## **Eric Cotting**

## **Current Responsibilities:**

- Development and maintenance of FGL's Laboratory Information Management System (LIMS)
- Training of personnel in the effective use of LIMS

### Work Experience:

- Developed customized LIMS system for FGL
- As research assistant with the University of Wisconsin, was involved in the modification of an existing theoretical computational program designed to model quantum mechanical properties of the Helium Atom

#### Formal Education:

- B.S. (1981) Chemistry, University of Alaska, Fairbanks, Alaska
- B.S. (1981) Math, University of Alaska, Fairbanks, Alaska
- B.S. (1981) Physics, University of Alaska, Fairbanks, Alaska
- M.S. (1987) Physical Chemistry, University of Wisconsin, Madison, Wisconsin

#### **Continuing Education:**

- Computer Networking Seminar: Santa Barbara, CA. January 1991
- Nevada Nuclear Associates, "Fundamentals of Radiochemistry", February 1994.

Section No: 4
Page: 9 of 16
Revision No: 2.0
Date: January 15, 1994

# Laboratory Organization and Responsibilities

Key Personnel Qualification Summary - Santa Paula

#### H. Neal Hutchison

### **Current Responsibilities:**

Organic Lab Manager

- Organization of work flow in Organic Laboratory
- Personnel training, methods development, instrument troubleshooting
- Response to specific customer enquiries

#### Work Experience:

- 8 years experience in environmental organic analysis
- 5 years of supervisory and management roles in organic laboratory operations

#### Formal Education:

- B.S. (1984) in Chemical Engineering, University of Nevada, Reno.

## Continuing Education:

- Extrel training course, "Operation of Extrel ELQ 400 GC/MS", 1986.
- HP short course, "Practical Capillary Chromatography", 1988.
- UCSB Extension, "Introduction to Hazardous Waste Management", 1990.
- Hazardous Waste Operations and Emergency Response Training, OSHA 29 CFR 1910.120, 40 hr plus annual refresher.

#### Memberships:

### **Professional:**

- Bay Area Mass Spectrometrists (BAMS)
- American Society of Mass Spectrometrists (ASMS)

Section No: 4 Page: 10 of 16 Revision No: 2.0

Date: January 15, 1994

# Laboratory Organization and Responsibilities

Key Personnel Qualification Summary - Santa Paula

Michel M. Franco

### **Current Responsibilities:**

Radiochemistry Lab Manager

- Work scheduling, staff supervision for Radiochemistry Laboratory
- Personnel training, methods development, instrument troubleshooting
- Client interface and project management

## Work Experience:

- 6 years experiencein radiochemical analysis, inorganic analysis and organic analysis for TOX and TOC.
- Developed instrument analysis experiment for CSUN (1988)
- Sample trouble shooting, processing and department liason at Reference Laboratory (1986)

#### Formal Education:

- B.A. (1990) Chemistry, California State University, Northridge

# Continuing Education:

- Nevada Nuclear Associates, "Fundamentals of Radiochemistry", February 1994.
  Canberraa Industries Inc., "Environmental Radioactivity Quantification Workshop", March 1994.

Section No: 4 Page: 11 of 16 Revision No: 2.0 Date: January 15, 1994

# Laboratory Organization and Responsibilities

Key Personnel Qualification Summary - Santa Paula

#### Ricardo Sandoval

## Current Responsibilities:

Agriculture Lab Manager - Santa Paula

- Management of Agricultural Department
- Supevision and training of staff

### Work Experience:

- 10 years experience in agricultural testing of soils and plant tissue
  Ranch and Nursery experience dealing with irrigation, pollution, and transplantation

#### Formal Education:

- B.S. (1985) in Crop Science and Technical Degree in Fruit Science, California Polytechnic State University, San Luis Obispo.

Section No: 4 Page: 12 of 16 Revision No: 2.0

Date: January 15, 1994

# Laboratory Organization and Responsibilities

Kev Personnel Qualification Summary - Stockton

John Quinn

# **Current Responsibilities:**

Vice President and Lab Director - Stockton

- Management of the Stockton Laboratory
- Liason with Santa Paula (Corporate) on Stockton lab's performance, budgets and financial results

## Work Experience:

- 11 years experience in environmental analysis for drinking water, wastewater, hazardous waste and air samples
- Consultation with clients on analytical needs

#### Formal Education:

- B.A. (1965) in Chemistry, St. Peter's College
- C.Phil. (1972) in Organic Chemistry, U.C.L.A.
- Ph.D. (1973) in Organic Chemistry, U.C.L.A.

# **Continuing Education:**

- CDFA, "Pesticide Residue Workshop." Feb. 1989, 1990, 1991, 1992.
- The Training Source, "Total Quality Management," Nov. 1991. Coakley Analytical Associates, "Quality Assurance Programs for Environmental Data," Aug. 1988.
- University of California Davis (UCD), "Marketing Professional Services," Feb. 1988.
  University of California Davis (UCD), "Guerrilla Marketing," Feb. 1988.
  University of California Davis (UCD), "Enhancing Sales Skills," Feb. 1988.

- Finnigan Institute "Principles of GC/MS," 1983.
  Halliburton NUS, "Solving the Mysteries, Collecting Environmental samples", April 1992.

### Memberships:

#### **Professional:**

- Sigma Xi, Chemical Honors Fraternity
- American Chemical Society
- American Water Works Association
- Association of California Testing Laboratories

Section No: 4
Page: 13 of 16
Revision No: 2.0
Date: January 15, 1994

# Laboratory Organization and Responsibilities

Key Personnel Qualification Summary - Stockton

#### Thomas Bartanen

#### **Current Responsibilities:**

**Quality Assurance Officer - Stockton** 

- Oversees Stockton laboratory's Quality Assurance Program
- Responsible for organic analysis on drinking water, wastewater, and hazardous waste samples

# Work Experience:

- Experience includes work in soil microbiology, toxicity and reservoir limnology
- Direct customer consultation on needs, concerns and complaints

#### Formal Education:

- B.S. (1980) in Environmental Science, Bradley University, Peoria, IL
- M.S. (1987) in Aquatic Ecology, University of Nevada, Las Vegas

## **Continuing Education:**

- American Association of Technologists GC/MS Workshop-data interpretation
- CDFA Pesticide Residue Workshop

### Memberships:

### Civic:

- SCA Inc. (Historical Society)
- Finnish American Home Association (FAHA)

Section No: 4
Page: 14 of 16
Revision No: 2.0
Date: January 15, 1994

# Laboratory Organization and Responsibilities

Key Personnel Qualification Summary - San Joaquin

# **Neil Jessup**

### **Current Responsibilities:**

Agronomist/Field service - Visalia

- Technical Representative San Joaquin Valley
- Coordinating sampling and sample pick up in the South San Joaquin Valley
- Consultation with clients on sampling and analysis requirements
- Proposal preparation for contracts on environmental and agricultural testing

### Work Experience:

- Ten years experience in areas of field service and sampling
- Considerable background in city, county, state and federal regulations for environmental testing requirements

#### Formal Education:

- B.S. (1977) in Agronomy, California Polytechnic State University, San Luis Obispo

#### **Continuing Education:**

- OSHA 40 hour trained for hazardous waste and emergency response, confined space entry and SCBA
- American Water Works Association, "Approved Water Sampling Procedures", March 1991.
- Halliburton NUS, "Solving the Mysteries, Collecting Environmental Samples", April 1992.

#### **Memberships:**

#### **Professional:**

- California Agriculture Production Consultants Association (CAPCA)


#### Civic

- Tulare County Hazardous Waste Advisory Committee

Section No: 4 Revision No: 2.0 Date: January 15, 1994 Page: 15 of 16

#### Laboratory Organization and Responsibilities


Figure 4-1 Organization Chart - Santa Paula Laboratory



Section No: 4 Revision No: 2.0 Date: January 15, 1994 Page: 16 of 16

# aboratory Organization and Responsibilities

igure 4-2 Organization Chart - Stockton Laboratory



• •

Section No: 5
Page: 1 of 30
Revision No: 2.0
Date: January 15, 1994

# **Quality Assurance Objectives**

The quality assurance objectives for accuracy, precision, and Detection Limits for Reporting (DLR) are listed in Tables 5-1 (Drinking Water Methods), 5-2 (Wastewater / Hazardous Waste Liquid Methods) and 5-3 (Solid Waste / Hazardous Waste Solids Methods).

Accuracy - is based on the recovery measurement of a target analyte after known addition to a given sample or representative sample matrix (see section 14.2). Accuracy values are expressed as the percent recovery of the known value, and serve as a reflection of the total measurement error (random and systematic). The acceptance ranges for recovery (%REC-AR) are used for data validation.

Precision - is based on the difference measurement of duplicate data points (see section 14.1). Precision values are expressed as relative percent difference (RPD) and serve as a reflection of the variability in measurement replication. Surrogates are not run in duplicate, so RPDs are not applicable. The Maximum Acceptance Value for the RPD's (RPD-MAV) are used for data validation.

Detection Limit for Reporting (DLR) - is the routine detection limit FGL uses for reporting purposes. Detection limit studies are performed continually (see section 11.1.2.2) to ensure that the objectives listed in this section are met or exceeded. Surrogates are required for quality assurance purposes only. Therefore, DLR information is not necessary.

Completeness - FGL is currently introducing controls to document incomplete reports. These are reports that are known to lack information at the time of delivery or reports where we are notified by the client that information is not complete. Future QA manuals will have the results for data completeness documented.

TABLE 5-1 Quality Assurance Objectives for Drinking Water Methods

CONSTITUENT	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR ug/L
EPA Method 501.2 Bromodichloromethane Bromoform	70-130 70-130	20	0.5
Chloroform Dibromochloromethane	70-130 70-130 70-130	20 20 20	0.5 0.5 0.5
EPA Method 502.2 Surrogates			
BFB	70-130	N/A	N/A
Fluorobenzene	70-130	N/A	N/A
Chlorofluorobenzene	70-130	N/A	N/A
Analytes			
Benzene	37-151	30	0.5
Bromobenzene	50-150	30	0.5
Bromochloromethane	50-150	30	0.5
Bromodichloromethane	35-155	30	0.5
Bromoform	45-169	30	0.5
Bromomethane	D-242	30	0.5
n-Butylbenzene	50-150	30	0.5
sec-Butylbenzene	50-150	30	0.5
tert-Butylbenzene	50-150	30	0.5

Section No: 5 Page: 2 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-1 Quality Assurance Objectives for Drinking Water Methods

	ACCURACY	PRECISION	DLR
CONSTITUENT	% REC-AR	RPD-MAV	ug/L
Method EPA 502.2 continued			
Carbon tetrachloride	70-140	30	0.5
Chlorobenzene	37-160	30	0.5
Chloroethane	14-320	30	0.5
Chloroform	51-128	30	0.5
Chloromethane	D-273	30	0.5
2-Chlorotoluene	50-150	30	0.5
4-Chlorotoluene	50-150	30	0.5
DBCP	50-150	30	0.5
Dibromochloromethane	53-149	30	0.5
1,2-Dibromoethane	50-150	30	0.5
Dibromomethane	50-150	30	0.5
1,2-Dichlorobenzene	50-150	30	0.5
	50-150	30	0.5
1,3-Dichlorobenzene		30	0.5
1,4-Dichlorobenzene	50-150		
Dichlorodifluoromethane	50-150	30	0.5
1,1-Dichloroethane	59-155 40-155	30	0.5
1,2-Dichloroethane	49-155	30	0.5
1,1-Dichloroethylene	D-234	30	0.5
cis-1,2-Dichloroethylene	50-150	30	0.5
trans-1,2-Dichloroethylene	54-156	30	0.5
1,2-Dichloropropane	D-210	30	0.5
1,3-Dichloropropane	50-150	30	0.5
2,2-Dichloropropane	50-150	30	0.5
1,1-Dichloropropene	50-150	30	0.5
cis-1,3-Dichloropropene	D-227	30	0.5
trans-1,3-Dichloropropene	17-183	30	0.5
Ethylbenzene	37-162	30	0.5
Hexachlorobutadiene	50-150	30	0.5
Isopropylbenzene	50-150	30	0.5
p-Isopropyltoluene	50-150	30	0.5
Methylene Chloride	D-221	30	0.5
Naphthalene	50-150	30	0.5
n-Propylbenzene	50-150	30	0.5
Styrene	50-150	30	0.5
1,1,1,2-Tetrachloroethane	50-150	30	0.5
1,1,2,2-Tetrachloroethane	<b>46-157</b>	30	0.5
Tetrachloroethylene	64-148	30	0.5
Toluene	47-163	30	0.5
1,2,3-Trichlorobenzene	50-150	30	0.5
1,2,4-Trichlorobenzene	50-150	30	0.5
1,1,1-Trichloroethane	52-150	30	0.5
1,1,2-Trichloroethane	71-157	30	0.5
Trichloroethylene	71-157	30	0.5
Trichlorofluoromethane	17-181	30	0.5
1,2,3-Trichloropropane	50-150	30	0.5
1,1,2-Trichlorotrifluoroeth	50-150	30	0.5
1,1,2 I LICITOL OCTILIA OL OCCII		- •	<del>-</del>

Section No: 5 Page: 3 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-1 Quality Assurance Objectives for Drinking Water Methods

Method EPA 502.2 continued         1,2,4-Trimethylbenzene         52-150         30         0.5           1,3,5-Trimethylbenzene         50-150         30         0.5           Vinyl Chloride         D-251         30         0.5           Xylenes m,p         50-150         30         0.5           Xylenes o         50-150         30         0.5           Method EPA 504         DBCP         70-130         30         0.02           EDB         70-130         30         0.01           Method EPA 505         Alachlor         50-150         30         0.2           Aldrin         42-122         30         0.01           Chlordane         45-119         30         0.1           Dieldrin         36-146         30         0.01           Heptachlor         34-111         30         0.01           Heptachlor Epoxide         37-142         30         0.01           Hexachlorobenzene         50-150         30         0.01           Heytachlor         50-150         30         0.01           Hexachlorobenzene         50-150         30         0.01           Hexachlorobenzene         50-150         30         0.01 <th></th> <th>ACCURACY</th> <th>PRECISION</th> <th>DLR</th>		ACCURACY	PRECISION	DLR
1,2,4-Trimethylbenzene   52-150   30   0.5     1,3,5-Trimethylbenzene   50-150   30   0.5     1,3,5-Trimethylbenzene   50-150   30   0.5     Xylenes m,p   50-150   30   0.5     Xylenes o   50-150   30   0.5     Method EPA 504     DBCP   70-130   30   0.01     Method EPA 505     Alachlor   50-150   30   0.01     Method EPA 505     Alachlor   42-122   30   0.01     Chlordane   45-119   30   0.1     Chlordane   45-119   30   0.1     Endrin   36-146   30   0.01     Heptachlor   34-111   30   0.01     Heptachlor Epoxide   37-142   30   0.01     Heptachlor Epoxide   37-142   30   0.01     Hexachlorobenzene   50-150   30   0.01     Lindane   32-127   30   0.05     Methoxychlor   50-150   30   0.1     Toxaphene   41-126   30   0.5     PCB 1016   50-114   30   0.3     PCB 1221   15-178   30   0.3     PCB 1232   10-215   30   0.3     PCB 1242   39-150   30   0.3     PCB 1242   39-150   30   0.3     PCB 1248   38-158   30   0.3     PCB 1254   29-131   30   0.3     PCB 1260   8-127   30   0.3     PCB 1260   8-127   30   0.3     PCB 127   30   0.3     PCB 128   39-150   30   0.3     PCB 129   30   30   30     Alachlor   70-130   30   1     Bromocil   70-130   30   1     Diazinon   70-130   30   2     Metribuzin   70-130   30   2     Dimethoate   70-130   30   2     Dimethoate   70-130   30   1     Metribuzin   70-130   30   0.1     Molinate   70-130   30   0.1     Molinate   70-130   30   0.1     Molinate   70-130   30   0.1     Molinate   70-130   30   0.1	CONSTITUENT	% REC-AR	RPD-MAV	ug/L
1,2,4-Trimethylbenzene   52-150   30   0.5     1,3,5-Trimethylbenzene   50-150   30   0.5     1,3,5-Trimethylbenzene   50-150   30   0.5     Xylenes m,p   50-150   30   0.5     Xylenes o   50-150   30   0.5     Xylenes o   50-150   30   0.5     Method EPA 504     DBCP   70-130   30   0.02     EDB   70-130   30   0.01     Method EPA 505     Alachlor   50-150   30   0.2     Aldrin   42-122   30   0.01     Chlordane   45-119   30   0.1     Chlordane   45-119   30   0.1     Dieldrin   36-146   30   0.01     Heptachlor   34-111   30   0.01     Heptachlor Epoxide   37-142   30   0.01     Heptachlor Epoxide   37-142   30   0.01     Heptachlor benzene   50-150   30   0.01     Lindane   32-127   30   0.05     Methoxychlor   50-150   30   0.1     Toxaphene   41-126   30   0.5     PCB 1016   50-114   30   0.3     PCB 1221   15-178   30   0.3     PCB 1232   10-215   30   0.3     PCB 1242   39-150   30   0.3     PCB 1242   39-150   30   0.3     PCB 1244   39-150   30   0.3     PCB 1254   29-131   30   0.3     PCB 1260   8-127   30   0.3     PCB 1260   8-127   30   0.3     Method EPA 507     Surrogates   1,3-Dimethyl-2-nitrobenzene   50-134   N/A   N/A     Analytes   Alachlor   70-130   30   1     Bromocil   70-130   30   1     Bromocil   70-130   30   2     Dimethoate   70-130   30   2     Dimethoate   70-130   30   2     Dimethoate   70-130   30   0.1     Metribuzin   70-130   30   0.1     Molinate   70-130   30   0.1     Molinate   70-130   30   0.1     Molinate   70-130   30   0.1	Method EPA 502.2 continued			
1.3.5-Trimethylenzene   50-150   30   0.5		52-150	30	0.5
Vinyl Chloride         D-251         30         0.5           Xylenes m,p         50-150         30         0.5           Xylenes o         50-150         30         0.5           Method EPA 504         DBCP         70-130         30         0.02           EDB         70-130         30         0.01           Method EPA 505         Alachlor           Alachlor         50-150         30         0.2           Aldrin         42-122         30         0.01           Chlordane         45-119         30         0.1           Chlordane         45-119         30         0.1           Endrin         30-147         30         0.01           Heptachlor Epoxide         37-142         30         0.01           Heptachlor Epoxide         37-142         30         0.01           Hexachlorobenzene         50-150         30         0.01           Hexachlorobenzene         50-150         30         0.1           Toxaphene         41-126         30         0.5           Methoxychlor         50-150         30         0.1           Toxaphene         41-126         30         0.3				
Xylenes m,p   S0-150   30   0.5				
Xylenes o         50-150         30         0.5           Method EPA 504         DBCP         70-130         30         0.02           EDB         70-130         30         0.01           Method EPA 505         Alachlor         50-150         30         0.2           Aldrin         42-122         30         0.01           Chlordane         45-119         30         0.1           Dieldrin         36-146         30         0.01           Endrin         30-147         30         0.01           Heptachlor         34-111         30         0.01           Heptachlor Epoxide         37-142         30         0.01           Hexachlorobenzene         50-150         30         0.01           Hexachlorobenzene         50-150         30         0.01           Kethoxychlor         50-150         30         0.01           Toxaphene         41-126         30         0.5           Methoxychlor         50-150         30         0.5           PCB 1016         50-114         30         0.3           PCB 1221         15-178         30         0.3           PCB 1232         10-215         3				
DBCP EDB         70-130         30         0.02 end           EDB         70-130         30         0.01           Method EPA 505         30         0.2           Aldchlor         50-150         30         0.2           Aldrin         42-122         30         0.01           Chlordane         45-119         30         0.1           Dieldrin         36-146         30         0.01           Endrin         30-147         30         0.01           Heptachlor Epoxide         37-142         30         0.01           Hexachlorobenzene         50-150         30         0.01           Lindane         32-127         30         0.05           Methoxychlor         50-150         30         0.1           Toxaphene         41-126         30         0.5           PCB 1016         50-114         30         0.3           PCB 1221         15-178         30         0.3           PCB 1232         10-215         30         0.3           PCB 1248         38-158         30         0.3           PCB 1254         29-131         30         0.3           PCB 1260         8-127 <td></td> <td></td> <td></td> <td></td>				
DBCP EDB         70-130         30         0.02 end           EDB         70-130         30         0.01           Method EPA 505         30         0.2           Aldchlor         50-150         30         0.2           Aldrin         42-122         30         0.01           Chlordane         45-119         30         0.1           Dieldrin         36-146         30         0.01           Endrin         30-147         30         0.01           Heptachlor Epoxide         37-142         30         0.01           Hexachlorobenzene         50-150         30         0.01           Lindane         32-127         30         0.05           Methoxychlor         50-150         30         0.1           Toxaphene         41-126         30         0.5           PCB 1016         50-114         30         0.3           PCB 1221         15-178         30         0.3           PCB 1232         10-215         30         0.3           PCB 1248         38-158         30         0.3           PCB 1254         29-131         30         0.3           PCB 1260         8-127 <td>Method EPA 504</td> <td></td> <td></td> <td></td>	Method EPA 504			
EDB         70-130         30         0.01           Method EPA 505         30         0.2           Alachlor         50-150         30         0.2           Aldrin         42-122         30         0.01           Chlordane         45-119         30         0.1           Dieldrin         36-146         30         0.01           Endrin         30-147         30         0.01           Heptachlor         34-111         30         0.01           Heptachlor Epoxide         37-142         30         0.01           Hexachlorobenzene         50-150         30         0.01           Hexachlorobenzene         50-150         30         0.05           Methoxychlor         50-150         30         0.05           Methoxychlor         50-150         30         0.1           Toxaphene         41-126         30         0.5           PCB 1016         50-114         30         0.3           PCB 1232         10-215         30         0.3           PCB 1242         39-150         30         0.3           PCB 1248         38-158         30         0.3           PCB 1254		70-130	30	0.02
Alachlor       50-150       30       0.2         Aldrin       42-122       30       0.01         Chlordane       45-119       30       0.1         Dieldrin       36-146       30       0.01         Endrin       30-147       30       0.01         Heptachlor       34-111       30       0.01         Heptachlor Epoxide       37-142       30       0.01         Hexachlorobenzene       50-150       30       0.01         Lindane       32-127       30       0.05         Methoxychlor       50-150       30       0.1         Toxaphene       41-126       30       0.5         PCB 1016       50-114       30       0.3         PCB 1221       15-178       30       0.3         PCB 12221       15-178       30       0.3         PCB 1242       39-150       30       0.3         PCB 1242       39-150       30       0.3         PCB 1254       29-131       30       0.3         PCB 1260       8-127       30       0.3         Method EPA 507       Surrogates       1       N/A       N/A         Norrogates				
Alachlor       50-150       30       0.2         Aldrin       42-122       30       0.01         Chlordane       45-119       30       0.1         Dieldrin       36-146       30       0.01         Endrin       30-147       30       0.01         Heptachlor       34-111       30       0.01         Heptachlor Epoxide       37-142       30       0.01         Hexachlorobenzene       50-150       30       0.01         Lindane       32-127       30       0.05         Methoxychlor       50-150       30       0.1         Toxaphene       41-126       30       0.5         PCB 1016       50-114       30       0.3         PCB 1221       15-178       30       0.3         PCB 12221       15-178       30       0.3         PCB 1242       39-150       30       0.3         PCB 1242       39-150       30       0.3         PCB 1254       29-131       30       0.3         PCB 1260       8-127       30       0.3         Method EPA 507       Surrogates       1       N/A       N/A         Norrogates	Method EPA 505			
Aldrin		50-150	30	0.2
Chlordane       45-119       30       0.1         Dieldrin       36-146       30       0.01         Endrin       30-147       30       0.01         Heptachlor       34-111       30       0.01         Heptachlor Epoxide       37-142       30       0.01         Hexachlorobenzene       50-150       30       0.01         Lindane       32-127       30       0.05         Methoxychlor       50-150       30       0.1         Toxaphene       41-126       30       0.5         PCB 1016       50-114       30       0.3         PCB 1221       15-178       30       0.3         PCB 1232       10-215       30       0.3         PCB 1242       39-150       30       0.3         PCB 1248       38-158       30       0.3         PCB 1254       29-131       30       0.3         PCB 1260       8-127       30       0.3         Method EPA 507       Surrogates       1,3-Dimethyl-2-nitrobenzene       53-105       N/A       N/A         Analytes       N/A       N/A       N/A       N/A         Alachlor       70-130       30				
Dieldrin         36-146         30         0.01           Endrin         30-147         30         0.01           Heptachlor         34-111         30         0.01           Heptachlor Epoxide         37-142         30         0.01           Hexachlorobenzene         50-150         30         0.01           Lindane         32-127         30         0.05           Methoxychlor         50-150         30         0.1           Toxaphene         41-126         30         0.5           PCB 1016         50-114         30         0.3           PCB 1221         15-178         30         0.3           PCB 1232         10-215         30         0.3           PCB 1242         39-150         30         0.3           PCB 1248         38-158         30         0.3           PCB 1254         29-131         30         0.3           PCB 1260         8-127         30         0.3           Method EPA 507         Surrogates         1,3-Dimethyl-2-nitrobenzene         53-105         N/A         N/A           Analytes         Alachlor         70-130         30         1           Alachlor				
Endrin 30-147 30 0.01 Heptachlor 34-111 30 0.01 Heptachlor Epoxide 37-142 30 0.01 Hexachlorobenzene 50-150 30 0.01 Lindane 32-127 30 0.05 Methoxychlor 50-150 30 0.1 Toxaphene 41-126 30 0.5 PCB 1016 50-114 30 0.3 PCB 1221 15-178 30 0.3 PCB 1232 10-215 30 0.3 PCB 1242 39-150 30 0.3 PCB 1248 38-158 30 0.3 PCB 1254 29-131 30 0.3 PCB 1260 8-127 30 0.3  Method EPA 507 Surrogates 1,3-Dimethyl-2-nitrobenzene 50-134 N/A N/A Analytes Alachlor 70-130 30 1 Bromocil 70-130 30 2 Dimethoate 70-130 30 2 Dimethoate 70-130 30 2 Metribuzin 70-130 30 2 Metribuzin 70-130 30 2 Metribuzin 70-130 30 2 PCB Metribuzin 70-130 30 2 PCB Metribuzin 70-130 30 1 Metribuzin 70-130 30 2 Prometryne 70-130 30 2 Prometryne 70-130 30 2 Prometryne				
Heptachlor   34-111   30   0.01     Heptachlor Epoxide   37-142   30   0.01     Hexachlorobenzene   50-150   30   0.01     Lindane   32-127   30   0.05     Methoxychlor   50-150   30   0.1     Toxaphene   41-126   30   0.5     PCB 1016   50-114   30   0.3     PCB 1221   15-178   30   0.3     PCB 1232   10-215   30   0.3     PCB 1242   39-150   30   0.3     PCB 1248   38-158   30   0.3     PCB 1254   29-131   30   0.3     PCB 1260   8-127   30   0.3     Method EPA 507   Surrogates     1,3-Dimethyl-2-nitrobenzene   50-134   N/A   N/A     Analytes   Alachlor   70-130   30   1     Atrazine   50-134   N/A   N/A     Analytes   Alachlor   70-130   30   1     Bromocil   70-130   30   1     Bromocil   70-130   30   2     Dimethoate   70-130   30   2     Metolachlor   70-130   30   2     Metolachlor   70-130   30   0.1     Diazinon   70-130   30   2     Metribuzin   70-130   30   0.1     Molinate   70-130   30   0.1     Prometryne   70-130   30   2				
Heptachlor Epoxide				
Hexachlorobenzene				
Lindane       32-127       30       0.05         Methoxychlor       50-150       30       0.1         Toxaphene       41-126       30       0.5         PCB 1016       50-114       30       0.3         PCB 1221       15-178       30       0.3         PCB 1232       10-215       30       0.3         PCB 1242       39-150       30       0.3         PCB 1248       38-158       30       0.3         PCB 1254       29-131       30       0.3         PCB 1260       8-127       30       0.3         Method EPA 507       Surrogates       1,3-Dimethyl-2-nitrobenzene       53-105       N/A       N/A         9-Nitroanthracene       50-134       N/A       N/A         Analytes       Alachlor       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       1         Bromocil       70-130       30       2         Butachlor       70-130       30       2         Dimethoate       70-130       30       1         Metolachlor       70-130       30       0.1 <td></td> <td></td> <td></td> <td></td>				
Methoxychlor         50-150         30         0.1           Toxaphene         41-126         30         0.5           PCB 1016         50-114         30         0.3           PCB 1221         15-178         30         0.3           PCB 1232         10-215         30         0.3           PCB 1242         39-150         30         0.3           PCB 1248         38-158         30         0.3           PCB 1254         29-131         30         0.3           PCB 1260         8-127         30         0.3           Method EPA 507         Surrogates         Surrogates         N/A         N/A           1,3-Dimethyl-2-nitrobenzene         53-105         N/A         N/A           9-Nitroanthracene         50-134         N/A         N/A           Analytes         N/A         N/A         N/A           Alachlor         70-130         30         1           Atrazine         70-130         30         1           Bromocil         70-130         30         1           Butachlor         70-130         30         2           Dimethoate         70-130         30         1				
Toxaphene         41-126         30         0.5           PCB 1016         50-114         30         0.3           PCB 1221         15-178         30         0.3           PCB 1232         10-215         30         0.3           PCB 1242         39-150         30         0.3           PCB 1248         38-158         30         0.3           PCB 1254         29-131         30         0.3           PCB 1260         8-127         30         0.3           Method EPA 507         Surrogates         S         S           1,3-Dimethyl-2-nitrobenzene         53-105         N/A         N/A           9-Nitroanthracene         50-134         N/A         N/A           Analytes         Alachlor         70-130         30         1           Atrazine         70-130         30         1           Bromocil         70-130         30         1           Bromocil         70-130         30         1           Butachlor         70-130         30         2           Dimethoate         70-130         30         2           Metolachlor         70-130         30         0				
PCB 1016       50-114       30       0.3         PCB 1221       15-178       30       0.3         PCB 1232       10-215       30       0.3         PCB 1242       39-150       30       0.3         PCB 1248       38-158       30       0.3         PCB 1254       29-131       30       0.3         PCB 1260       8-127       30       0.3         Method EPA 507       Surrogates       Surrogates       Surrogates       Surrogates       N/A       N/A         1,3-Dimethyl-2-nitrobenzene       50-134       N/A       N/A       N/A         9-Nitroanthracene       50-134       N/A       N/A       N/A         Analytes       Alachlor       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prome				
PCB 1221       15-178       30       0.3         PCB 1232       10-215       30       0.3         PCB 1242       39-150       30       0.3         PCB 1248       38-158       30       0.3         PCB 1254       29-131       30       0.3         PCB 1260       8-127       30       0.3         Method EPA 507         Surrogates         1,3-Dimethyl-2-nitrobenzene       53-105       N/A       N/A         9-Nitroanthracene       50-134       N/A       N/A         Analytes       Alachlor       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       1         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Metolachlor       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2	PCB 1016			
PCB 1232       10-215       30       0.3         PCB 1242       39-150       30       0.3         PCB 1248       38-158       30       0.3         PCB 1254       29-131       30       0.3         PCB 1260       8-127       30       0.3         Method EPA 507         Surrogates         1,3-Dimethyl-2-nitrobenzene       53-105       N/A       N/A         9-Nitroanthracene       50-134       N/A       N/A         Analytes       Alachlor       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2				
PCB 1242       39-150       30       0.3         PCB 1248       38-158       30       0.3         PCB 1254       29-131       30       0.3         PCB 1260       8-127       30       0.3         Method EPA 507         Surrogates         1,3-Dimethyl-2-nitrobenzene       53-105       N/A       N/A         9-Nitroanthracene       50-134       N/A       N/A         Analytes       Alachlor       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2				
PCB 1248       38-158       30       0.3         PCB 1254       29-131       30       0.3         PCB 1260       8-127       30       0.3         Method EPA 507         Surrogates         1,3-Dimethyl-2-nitrobenzene       53-105       N/A       N/A         9-Nitroanthracene       50-134       N/A       N/A         Analytes       N/A       N/A       N/A         Alachlor       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2				
PCB 1254       29-131       30       0.3         PCB 1260       8-127       30       0.3         Method EPA 507         Surrogates       Surrogates         1,3-Dimethyl-2-nitrobenzene       53-105       N/A       N/A         9-Nitroanthracene       50-134       N/A       N/A         Analytes       N/A       N/A       N/A         Alachlor       70-130       30       1         Atrazine       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2				
PCB 1260       8-127       30       0.3         Method EPA 507       Surrogates         1,3-Dimethyl-2-nitrobenzene       53-105       N/A       N/A         9-Nitroanthracene       50-134       N/A       N/A         Analytes       N/A       N/A       N/A         Alachlor       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       0         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2				
Surrogates       1,3-Dimethyl-2-nitrobenzene       53-105       N/A       N/A         9-Nitroanthracene       50-134       N/A       N/A         Analytes       N/A       N/A         Alachlor       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2				
1,3-Dimethyl-2-nitrobenzene       53-105       N/A       N/A         9-Nitroanthracene       50-134       N/A       N/A         Analytes       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2	Method EPA 507			
1,3-Dimethyl-2-nitrobenzene       53-105       N/A       N/A         9-Nitroanthracene       50-134       N/A       N/A         Analytes       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2	Surrogates			
9-Nitroanthracene       50-134       N/A       N/A         Analytes       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2	1,3-Dimethyl-2-nitrobenzene	53-105	N/A	N/A
Analytes       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2				
Alachlor       70-130       30       1         Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2	Analytes			
Atrazine       70-130       30       1         Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2		70-130	30	1
Bromocil       70-130       30       5         Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2	Atrazine			
Butachlor       70-130       30       1         Diazinon       70-130       30       2         Dimethoate       70-130       30       2         Metolachlor       70-130       30       1         Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2	Bromocil			
Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2	Butachlor			1
Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2	Diazinon			$\hat{\mathbf{z}}$
Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2				$\frac{\overline{2}}{2}$
Metribuzin       70-130       30       0.1         Molinate       70-130       30       2         Prometryne       70-130       30       2				ĩ
Molinate       70-130       30       2         Prometryne       70-130       30       2				
Prometryne 70-130 30 2				
				$\tilde{2}$
rropachior /0-150 50 1	Propachlor	70-130	30	ĩ

Section No: 5 Page: 4 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-1 Quality Assurance Objectives for Drinking Water Methods

CONSTITUENT	ACCURACY <u>% REC-AR</u>	PRECISION <u>RPD-MAV</u>	DLR ug/L
Method EPA 507 continued			
Simazine	70-130	30	1
Thiobencarb	70-130	30	ī
			_
Method EPA 508			
Surrogate		•	
Hexachlorobenzene	<b>70-130</b>	N/A	N/A
Analytes			
Chlorothalonil	<b>70-130</b>	30	0.2
PCB 1016	50-114	30	0.08
PCB 1221	15-178	30	0.2
PCB 1232	10-215	30	0.2
PCB 1242	39-150	30	0.2
PCB 1248	38-158	30	0.1
PCB 1254	29-131	30	0.1
PCB 1260	8-127	30	0.2
Method EPA 508A			
PCB's as Decachlorobiphenyl	70-130	30	0.2
Method EPA 510			
	70-130	20	0.5
Bromodichloromethane	70-130 70-130	30 30	$0.5 \\ 0.5$
Bromoform	70-130 70-130	30	0.5 0.5
Chloroform Dibromochloromethane	70-130 70-130	30	0.5
Dibromocmoromethane	/0-130	30	0.5
Method EPA 515.1			
Surrogate			
2,4-DCAA	30-150	N/A	N/A
Analytes			
Bentazon	30-150	30	2
Chloramben	30-150	30	2 1 2
2,4-D	30-150	30	2
2,4-DB	30-150	30	2
<b>D</b> alapon	30-150	30	2
Dicamba	30-150	30	5
Dichloroprop	30-150	30	2 2 5 2 1
Dinoseb	30-150	30	1
Pentachlorophenol	30-150	30	0.2
Picloram	30-150	30	1
2,4,5-T	30-150	30	ī
2,4,5-TP (Silvex)	30-150	30	ì
TO AL (MILTON)			-

Section No: 5 Page: 5 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-1 Quality Assurance Objectives for Drinking Water Methods

CONSTITUENT	ACCURACY % REC-AR	PRECISION RPD-MAV	DLR ug/L
CONSTITUENT	MADE III	AC D WALL	<u>u_/</u>
Method EPA 524.2			
Surrogates	***	<b></b>	
1,2-Dichloroethane-d4	76-114	N/A	N/A
Toluene-d8	88-110	N/A	N/A
BFB	86-115	N/A	N/A
Analytes	<b>5</b> 0.4.50	••	^ -
Acetone	50-150	30	0.5
Benzene	37-151	30	0.5
Bromobenzene	50-150	30	0.5
Bromochloromethane	50-150	30	0.5
Bromodichloromethane	35-155	30	0.5
Bromoform	45-169	30	0.5
Bromomethane	D-242	30	0.5
2-Butanone (MEK)	50-150	30	0.5
n-Butylbenzene	50-150	30	0.5
sec-Butylbenzene	50-150	30	0.5
tert-Butylbenzene	50-150	30	0.5
Carbon disulfide	50-150	30	0.5
Carbon tetrachloride	70-140	30	0.5
Chlorobenzene	37-160	30	0.5
Chloroethane	14-230	30	0.5
Chloroform	51-138	30	0.5
Chloromethane	D-273	30	0.5
2-Chlorotoluene	50-150	30	0.5
4-Chlorotoluene	50-150	30	0.5
Dibromochloromethane	53-149	30	0.5
1,2-Dibromoethane (EDB)	50-150	30	0.5
Dibromomethane	50-150	30	0.5
1,2-Dibromo-3-chloropropane	50-150	30	0.5
1,2-Dichlorobenzene	50-150	30	0.5
1,3-Dichlorobenzene	50-150	30	0.5
1,4-Dichlorobenzene	50-150	30	0.5
Dichlorodifluoromethane	50-150	30	0.5
1,1-Dichloroethane	59-155	30	0.5
1,2-Dichloroethane	49-155	30	0.5
1,1-Dichloroethylene	D-234	30	0.5
cis-1,2-Dichloroethylene	50-150	30	0.5
trans-1,2-Dichloroethylene	54-156	30	0.5
1,2-Dichloropropane	D-210	30	0.5
1,3-Dichloropropane	50-150	30	0.5
2,2-Dichloropropane	50-150	30	0.5
1,1-Dichloropropene	50-150	30	0.5
cis-1,3-Dichloropropene	D-227	30	0.5
trans-1,3-Dichloropropene	17-183	30	0.5
Ethylbenzene	37-162 50-150	30	0.5
Hexachlorobutadiene	50-150	30	0.5
2-Hexanone	50-150	30	0.5

Section No: 5 Page: 6 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-1 Quality Assurance Objectives for Drinking Water Methods

CONSTITUENT	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR ug/L
Method EPA 524.2 continued			
Isopropylbenzene	50-150	30	0.5
p-Isopropyltoluene	50-150	30	0.5
Methylene chloride	D-221	30	0.5
4-Methyl-2-pentanone (MIBK)	50-150	30	0.5
Naphthalene	50-150	30	0.5
	50-150	30	0.5
n-Propylbenzene	50-150	30	0.5
Styrene	50-150	30	0.5
1,1,1,2-Tetrachloroethane	46-157	30	0.5
1,1,2,2-Tetrachloroethane	64-148	30	0.5
Tetrachloroethylene			0.5
Toluene	47-163 50 150	30 30	0.5
1,2,3-Trichlorobenzene	50-150 50-150		
1,2,4-Trichlorobenzene	50-150	30	0.5
1,1,1-Trichloroethane	52-162 53-150	30	0.5
1,1,2-Trichloroethane	52-150	30	0.5
Trichloroethylene	71-157	30	0.5
Trichlorofluoromethane	17-181	30	0.5
1,2,3-Trichloropropane	50-150	30	0.5
1,1,2-Trichlorotrifluoroeth	50-150	30	0.5
1,2,4-Trimethylbenzene	50-150	30	0.5
Vinyl acetate	50-150	30	0.5
Vinyl chloride	D-251	30	0.5
Xylenes m,p	50-150	30	0.5
Xylenes o	50-150	30	0.5
Method EPA 525			
Surrogate			
Perylene-d12	50-150	N/A	N/A
Analytes			_
Acenaphthylene	50-150	30	1
Anthracene	50-150	30	1
Benzo(a)anthracene	50-150	30	1
Benzo(b)fluoranthene	50-150	30	1
Benzo(k)fluoranthene	50-150	30	1
Benzo(g,h,i)perylene	50-150	30	1
Benzo(a)pyrene	50-150	30	0.1
Butylbenzylphthalate	50-150	30	1
Chrysene	50-150	30	1
Dibenzo(a,h)anthracene	50-150	30	1
Dimethylphthalate	50-150	30	1
Diethylphthalate	50-150	30	1
Di-n-butylphthalate	50-150	30	1
bis(2-Ethylhexyl)adipate	50-150	30	1 3
bis(2-Ethylhexyl)phthalate	29-137	30	
Fluorene	50-150	30	1
Hexachlorobenzene	50-150	30	1

Section No: 5 Page: 7 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-1 Quality Assurance Objectives for Drinking Water Methods

	ACCURACY	PRECISION	DLR
CONSTITUENT	% REC-AR	RPD-MAV	ug/L
Method EPA 525 continued			
Hexachlorocyclopentadiene	50-150	30	1
	50-150	30	1
Indeno(1,2,3-c,d)pyrene		30	4
Pentachlorophenol	50-150	30	1
Phenanthrene	50-150		1
Pyrene	50-150	30	1
Method EPA 531.1			
Surrogate			
BDMC	70-130	N/A	N/A
Analytes	70-150	11/11	
Aldicarb	70-130	30	3
Aldicarb Sulfone	70-130	30	3
Aldicarb Sulfoxide	70-130	30	3
Carbofuran	70-130	30	3 3 5 5
Carbaryl	70-130	30	5
3-Hydroxycarbofuran	70-130	30	10
Methiocarb	70-130	30	10
	70-130 70-130	30	
Methomyl	70-130 70-130	30	5
1-Napthol	70-130 70-130	30	5
Oxymal	70-130 70-130	30	5 5 5 5
Propoxur	/0-130	30	3
Method EPA 547			
Glyphosate	70-130	20	20
Method EPA 548			
Endothail	70-130	20	40
Method EPA 549	<b>50</b> 100	••	_
Diquat	70-130	20	2
Paraquat	70-130	20	1
Method EPA 550.1			
Acenaphthene	70-130	20	3
Acenaphthylene	70-130	20	3 2
Anthracene	70-130	20	0.1
Benzo(a)anthracene	70-130	20	0.1
Benzo(a)pyrene	70-130	20	0.1
Benzo(b)fluoranthene	70-130	20	0.1
	70-130	20	0.2
Benzo(g,h,i)perylene Benzo(k)fluoranthene	70-130 70-130	20 20	0.1
	70-130 70-130		0.1
Chrysene	70-130 70-130	20 20	0.1
Dibenzo(a,h)anthracene Fluoranthene	70-130 70-130	20 20	
Fluorene	70-130 70-130	20 20	2 2
Indeno(1,2,3-c,d)pyrene	70-130 70-130	20 20	$\frac{2}{0.1}$
mueno(1,2,3-c,u)pyrene	/0-130	20	0.1

Section No: 5 Page: 8 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-1 Quality Assurance Objectives for Drinking Water Methods

CONSTITUENT	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR ug/L
Method EPA 550.1 continued 1-Methylnaphthalene	70-130	20	2
2-Methylnaphthalene Naphthalene	70-130 70-130	20 20	2 2 2
Phenanthrene	70-130	20	2
Pyrene	70-130	20	0.1
Method EPA 552			
Bromochloroacetic acid	70-130	20	1
Dibromoacetic acid	70-130	20	1
Dichloroacetic acid	70-130	20	1
2,4-Dichlorophenol	70-130	20	1
Monobromoacetic acid	70-130	20	1
Monochloroacetic acid	70-130	20	1
Trichloroacetic acid	70-130	20	1
2,4,6-Trichlorophenol	70-130	20	1

CONSTITUENT	Method	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR mg/L
Inorganic Chemicals				
Acidity	305.1	N/A	20	1
Alkalinity (as CaCO3)	310.0	N/A	20	1
Bicarbonate	310.1	N/A	20	1 2
BOD	405.1	80-120	20	2
Bromide	300.0	80-120	20	0.5
Carbon Dioxide	SM4500C	N/A	20	1
Carbonate	310.1	N/A	20	1
COD	410.2	75-125	20	4
Chloride	300.0	80-120	20	1
Chlorine Residual	330.2	N/A	20	0.1
Chlorine Residual	330.3 N/A	4	20	0.1
Color	110.3	N/A	20	3 units
Electrical Conductivity	120.1	80-120	20	1 umhos
Cyanide, Total	335.2	75-125	20	0.01
Fluoride by electrode	340.2	80-120	20	0.1
Hydroxide	310.0	N/A	20	1
MBAS	425.1	70-130	20	0.05
Nitrogen				
Ammonia	350.1	80-120	20	1
Nitrate	300.0	80-120	20	0.1
Nitrite	300.0	80-120	20	0.1
Nitrate	353.2	80-120	20	0.1
Nitrite	353.2	80-120	20	0.1
Total Kjeldahl	351.2	80-120	20	1
Odor	140.1	N/A	20	1 TON

Section No: 5 Page: 9 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-1 Quality Assurance Objectives for Drinking Water Methods

CONSTITUENT	<u>Method</u>	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR mg/L
Inorganic Chemical EPA Method	s continued			
Oil and Grease	413.1	N/A	20	3
Oxygen, dissolved	360.1	N/A	20	0.5
pH	150.1	N/A	20	N/A
Phenols	420.1	75-125	20.	0.1
Phosphorous	72011	70 120	-	V.1
Phosphate	300.0	80-120	20	0.1
Total	365.4	75-125	20	0.1
Solids/Residue	505.4	75 125	20	<b>0.1</b>
Filterable (TDS)	160.1	NA	20	40
Non-filterable (TSS)	160.1	NA NA	20	10
Total	160.2	NA NA	20	40
Volatile	160.3	NA NA	20	40
	160.4	NA	20	0.1 ml/L
Settleable Sulfate	300.0	80-120	20	
Sulfate	300.0	0U-12U	20	1
Sulfide	276.2	NT/A	20	0.1
Total	376.2	N/A	20	0.1
Dissolved	376.2	N/A	20	0.1
Sulfite	377.1	N/A	20	0.1
Tannin & Lignin	SM5500B	N/A	20	1
Titration - pH adjust.	N/A	N/A	20	1
Turbidity	180.1	N/A	20	0.2 NTU
		ACCURACY	PRECISION	DLR
CONSTITUENT	<u>Method</u>	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR mg/L
	Method			
Trace Metals		% REC-AR	RPD-MAV	mg/L
Trace Metals Aluminum	200.9	% REC-AR 75-125	<u>RPD-MAV</u> 20	mg/L 20
Trace Metals Aluminum Aluminum	200.9 200.8	% REC-AR 75-125 75-125	20 20	mg/L 20
Trace Metals Aluminum Aluminum Antimony	200.9 200.8 200.9	% REC-AR  75-125 75-125 75-125	20 20 20 20	mg/L 20 5 5
Trace Metals Aluminum Aluminum Antimony Antimony	200.9 200.8 200.9 200.8	% REC-AR  75-125 75-125 75-125 75-125	20 20 20 20 20	mg/L 20 5 0.5
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic	200.9 200.8 200.9 200.8 200.9	% REC-AR  75-125 75-125 75-125 75-125 75-125	20 20 20 20 20 20 20	mg/L 20 5 0.5 2
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic	200.9 200.8 200.9 200.8 200.9 200.8	% REC-AR  75-125 75-125 75-125 75-125 75-125 75-125 75-125	20 20 20 20 20 20 20 20	mg/L 20 5 5 0.5 2 2
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium	200.9 200.8 200.9 200.8 200.9 200.8 200.7	% REC-AR  75-125 75-125 75-125 75-125 75-125 75-125 80-120	RPD-MAV  20 20 20 20 20 20 20 20 20	mg/L 20 5 5 0.5 2 2 20
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8	% REC-AR  75-125 75-125 75-125 75-125 75-125 75-125 80-120 75-125	RPD-MAV  20 20 20 20 20 20 20 20 20 20	mg/L 20 5 5 0.5 2 20 0.5
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium Beryllium	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8 200.9	% REC-AR  75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125 75-125	RPD-MAV  20 20 20 20 20 20 20 20 20 20 20 20	mg/L  20 5 5 0.5 2 20 0.5 1
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium Beryllium Beryllium	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8 200.9 200.9	% REC-AR  75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125 75-125 75-125	RPD-MAV  20 20 20 20 20 20 20 20 20 20 20 20 20	mg/L  20 5 5 0.5 2 2 20 0.5 1 0.5
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium Beryllium Beryllium Boron	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8 200.9 200.8 200.7	% REC-AR  75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125 80-120	RPD-MAV  20 20 20 20 20 20 20 20 20 20 20 20 20	mg/L  20 5 5 0.5 2 2 20 0.5 1 0.5 0.1 mg/L
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium Beryllium Beryllium Boron Boron	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8 200.9 200.8 200.7 200.8	% REC-AR  75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125 80-120 75-125	RPD-MAV  20 20 20 20 20 20 20 20 20 20 20 20 20	mg/L  20 5 5 0.5 2 2 20 0.5 1 0.5 0.1 mg/L 0.01 mg/L
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium Beryllium Beryllium Boron Boron Cadmium	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8 200.9 200.8 200.7 200.8 200.7	% REC-AR  75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125 80-120 75-125 75-125 80-120 75-125	RPD-MAV  20 20 20 20 20 20 20 20 20 20 20 20 20	mg/L  20 5 5 0.5 2 2 20 0.5 1 0.5 0.1 mg/L 0.01 mg/L 1
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium Beryllium Beryllium Boron Boron Cadmium Cadmium	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8 200.9 200.8 200.7 200.8 200.9	% REC-AR  75-125 75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125 80-120 75-125 75-125 75-125 75-125	RPD-MAV  20 20 20 20 20 20 20 20 20 20 20 20 20	mg/L  20 5 5 0.5 2 2 20 0.5 1 0.5 0.1 mg/L 0.01 mg/L 1 0.5
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium Beryllium Beryllium Boron Cadmium Cadmium Calcium	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8 200.7 200.8 200.7 200.8 200.9 200.8	% REC-AR  75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125 80-120 75-125 75-125 80-120 75-125 75-125 80-120	RPD-MAV  20 20 20 20 20 20 20 20 20 20 20 20 20	mg/L  20 5 5 0.5 2 2 20 0.5 1 0.5 0.1 mg/L 0.01 mg/L 1 0.5 1 mg/L
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium Beryllium Beryllium Beryllium Cadmium Cadmium Calcium Chromium	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8 200.9 200.8 200.7 200.8 200.7 200.8 200.9	% REC-AR  75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125 80-120 75-125 75-125 80-120 75-125 75-125	RPD-MAV  20 20 20 20 20 20 20 20 20 20 20 20 20	mg/L  20 5 5 0.5 2 2 20 0.5 1 0.5 0.1 mg/L 0.01 mg/L 1 0.5 1 mg/L
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium Beryllium Beryllium Boron Cadmium Cadmium Calcium Chromium	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8 200.9 200.8 200.7 200.8 200.7 200.8 200.9 200.8	% REC-AR  75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125 80-120 75-125 75-125 75-125 75-125 75-125 75-125 75-125 75-125 75-125	RPD-MAV  20 20 20 20 20 20 20 20 20 20 20 20 20	mg/L  20 5 5 0.5 2 2 20 0.5 1 0.5 0.1 mg/L 0.01 mg/L 1 0.5 1 mg/L 5 2
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium Beryllium Beryllium Boron Cadmium Cadmium Calcium Chromium Chromium VI	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8 200.9 200.8 200.7 200.8 200.9 200.8 200.7 200.8 200.9	% REC-AR  75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125 80-120 75-125 75-125 75-125 75-125 75-125 75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125	RPD-MAV  20 20 20 20 20 20 20 20 20 20 20 20 20	mg/L  20 5 5 0.5 2 2 20 0.5 1 0.5 0.1 mg/L 0.01 mg/L 1 0.5 1 mg/L 5 2 10
Trace Metals Aluminum Aluminum Antimony Antimony Arsenic Arsenic Barium Barium Beryllium Beryllium Boron Cadmium Cadmium Calcium Chromium	200.9 200.8 200.9 200.8 200.9 200.8 200.7 200.8 200.9 200.8 200.7 200.8 200.7 200.8 200.9 200.8	% REC-AR  75-125 75-125 75-125 75-125 75-125 80-120 75-125 75-125 80-120 75-125 75-125 75-125 75-125 75-125 75-125 75-125 75-125 75-125	RPD-MAV  20 20 20 20 20 20 20 20 20 20 20 20 20	mg/L  20 5 5 0.5 2 2 20 0.5 1 0.5 0.1 mg/L 0.01 mg/L 1 0.5 1 mg/L 5 2

Section No: 5 Page: 10 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-1 Quality Assurance Objectives for Drinking Water Methods

CONSTITUENT	Method	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR ug/L
Trace Metals continued				
Copper	200.7	80-120	20	50
Copper	200.8	75-125	20	2
Iron	200.7	80-120	20	50
Lead	200.9	75-125	20	5
Lead	200.8	75-125 75-125	20-	0.5
Lithium	SM3500L	80-120	20	10
Magnesium	200.7	80-120	20	1 mg/L
Manganese	200.7	80-120	20	30
•	200.7	75-125	20	1
Manganese	245.1	75-125 75-125	20	0.2
Mercury	245.1 245.2	75-125 75-125	20	0.2
Mercury	243.2	80-120	20	50 50
Molybdenum		75-125	20	
Molybdenum	200.8			0.5
Nickel	200.7	80-120	20	50
Nickel	200.8	75-125	20	1
Potassium	200.7	80-120	20	1 mg/L 2
Selenium	200.9	75-125	20	2
Selenium	200.8	75-125	20	2
Silica	200.7	80-120	20	1 mg/L
Silver	200.9	75-125	20	0.5
Silver	200.8	75-125	20	0.5
Sodium	200.7	80-120	20	1 mg/L
Strontium	200.7	80-120	20	50
Thallium	200.9	75-125	20	2
Thallium	200.8	<b>75-125</b>	20	0.5
Tin	200.9	75-125	20	50
Uranium	200.7	80-120	20	100
Vanadium	200.7	80-120	20	20
Zinc	200.7	80-120	20	50
Zinc	200.8	75-125	20	5
		A CCITO A CM	DDECICION	DID
CONCERNITION	N.C. 43	ACCURACY	PRECISION	DLR
CONSTITUENT	<u>Method</u>	% REC-AR	RPD-MAV	<u>pCi/L</u>
Radiochemistry EPA Methods				
Gross Alpha	900.0	80-120	20	0.1
Gross Beta	900.0	80-120	20	0.1
Radon	913.0	80-120	20	10
Strontium 90	905.0	80-120	20	1
Total Radium	900.1	80-120	20	0.1
	906.0	80-120	20	200
Tritium		80-120 80-120	20 20	0.1
Uranium	908.0	0U-14U	<b>4</b> U	U. I

Section No: 5 Page: 11 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-2 Quality Assurance Objectives for Wastewater / Hazardous Waste Liquid Methods

CONSTITUENT	ACCURACY % REC-AR	PRECISION RPD-MAV	DLR ug/L
Method EPA 601/8010			
Surrogates			
BFB	50-150	N/A	N/A
Fluorobenzene	50-150	N/A	N/A
Chlorofluorobenzene	50-150	N/A	N/A
Analytes	20 100		
Bromodichloromethane	42-172	20	0.5
Bromoform	13-159	20	0.5
Bromomethane	D-144	20	0.5
Carbon tetrachloride	43-143	20	0.5
Chlorobenzene	38-150	20	0.5
Chloroethane	46-137	20	0.5
Chloroform	49-133	20	0.5
Chloromethane	D-193	20	0.5
Dibromochloromethane	24-191	20	0.5
1,2-Dichlorobenzene	D-208	20	0.5
1,3-Dichlorobenzene	7-18 <b>7</b>	20	0.5
1,4-Dichlorobenzene	42-143	20	0.5
Dichlorodifluoromethane	50-150	20	0.5
1,1-Dichloroethane	47-132	20	0.5
1,2-Dichloroethane	51-147	20	0.5
	28-167	20	0.5
1,1-Dichloroethylene		20	
trans-1,2-Dichloroethylene	38-155		0.5
1,2-Dichloropropane	44-156	20	0.5
cis-1,3-Dichloropropene	22-178	20	0.5
trans-1,3-Dichloropropene	22-178	20	0.5
Methylene chloride	25-162	20	0.5
1,1,2,2-Tetrachloroethane	50-150	20	0.5
Tetrachloroethylene	26-162	20 .	0.5
1,1,1-Trichloroethane	41-138	20	0.5
1,1,2-Trichloroethane	39-139	20	0.5
Trichloroethylene	81-119	20	0.5
Trichlorofluoromethane	21-156	20	0.5
Vinyl chloride	28-163	20	0.5
Made a CDA 0016M TDH (			
Method EPA 8015M TPH (purgeable)	50 1 50	40.0	<b>700</b>
Gas	50-150	40.0	500
Method EPA 8015M TPH (extractable)			
Crude oil	50-150	40.0	500
Diesel fuel	50-150	40.0	500
Hydraulic oil	50-150	40.0	500 500
Jet fuel	50-150	40.0	
Stoddard solvent	50-150 50-150	40.0	500 500
Waste oil	50-150 50-150	40.0 40.0	500
Traste UII	30-130	40.0	2000

Section No: 5
Page: 12 of 30
Revision No: 2.0

Date: January 15, 1994

TABLE 5-2 Quality Assurance Objectives for Wastewater / Hazardous Waste Liquid Methods

			•
CONSTITUENT	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR ug/L
Method EPA 602/8020			
Surrogates			
BFB	50-150	N/A	N/A
Analytes	20 120	11/12	11/14
Benzene	78-133	20	0.3
Chlorobenzene	73-132	20	0.3
1,2-Dichlorobenzene	64-143	20	0.3
1,3-Dichlorobenzene	61-150	20	0.3
1,4-Dichlorobenzene	61-151	20	0.3
Ethylbenzene	75-129	20	0.3
Toluene	61-164	20	0.3
Xylene, o	69-137	20	0.3
Xylene, p	71-135	20	0.3
Xylene, m	68-133	20	0.3
.23.20.10, 1.1	33 155	-•	***
Method EPA 604/8040 (analyzed by me	ethod 625/8270)		
2-Chlorophenol	23-134	30	10
2,4-Dichlorophenol	39-135	30	10
2,4-Dimethylphenol	42-109	30	10
4,6-Dinitro-o-cresol	D-181	30	50
2,4-Dinitrophenol	D-191	30	50
2-Methylphenol	50-150	30	10
4-Methylphenol	50-150	30	10
2-Nitrophenol	29-182	30	10
4-Nitrophenol	29-182	30	50
p-Chloro-m-cresol	22-147	30	20
Pentachlorophenol	14-176	30	50
Phenol	5-112	30	10
2,4,5-Trichlorophenol	37-144	30	10
2,4,6-Trichlorophenol	37-144	30	10
<b>2</b> , 1, 0			
Method EPA 608/8080			
Surrogates			
Hexachlorobenzene	26-116	N/A	N/A
Dibutylchlorendate	44-125	N/A	N/A
Analytes			
Aldrin	20-123	30	0.2
Alpha BHC	37-134	30	0.2
Beta BHC	17-147	30	0.2
Delta BHC	19-140	30	0.2
Chlordane	45-119	30	0.2
o,p - DDD	31-141	30	0.2
p,p - DDD	31-141	30	0.2
o,p - DDE	30-145	30	0.2
p,p - DDE	30-145	30	0.2
o,p - DDT	25-160	30	0.2
p,p - DDT	70-160	30	0.2
hih pp;	. 0 100	- •	

Section No: 5 Page: 13 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-2 Quality Assurance Objectives for Wastewater / Hazardous Waste Liquid Methods

			•
	ACCURACY	<b>PRECISION</b>	DLR
CONSTITUENT	% REC-AR	<u>RPD-MAV</u>	<u>ug/L</u>
Made of FDA (00/0000 and and			
Method EPA 608/8080 continued	47 126	20	0.2
Dieldrin	47-126	30	0.2
Endosulfan I	45-153 D. 202	30	0.2
Endosulfan II	D-202	30	0.2
Endosulfan sulfate	26-144	30	0.2
Endrin	30-147	30	0.2
Endrin aldehyde	50-150	30	0.2
Heptachlor	25-133	30	0.2
Heptachlor epoxide	37-142	30	0.2
Lindane	81-119	30	0.2
Methoxychlor	50-150	30	0.5
Toxaphene	41-126	30	5
PCB 1016	<b>50-114</b>	30	2
PCB 1221	15-178	30	2
PCB 1232	10-215	30	2
PCB 1242	39-150	30	2
PCB 1248	38-158	30	2
PCB 1254	29-131	30	2
PCB 1260	8-127	30	5 2 2 2 2 2 2 2
Method EPA 610/8310			
Acenaphthene	70-130	20	3
Acenaphthylene	70-130	20	3 2
Anthracene	70-130	20	$\overline{0}.1$
Benzo(a)anthracene	70-130	20	0.1
Benzo(b)fluoranthene	70-130	20	0.2
Benzo(k)fluoranthene	70-130	20	0.1
Benzo(g,h,i)perylene	70-130	20	0.1
Benzo(a)pyrene	70-130	20	0.2
Chrysene	70-130	20	0.1
Dibenzo(a,h)anthracene	70-130	20	0.3
Fluoranthene	70-130	20	2
Fluorene	70-130	20	2
Indeno(1,2,3-c,d)pyrene	70-130	20	$\tilde{0}.1$
Naphthalene	70-130	20	2
Phenanthrene	70-130	20	2 2
Pyrene	70-130	20	0.1
1 yrene	70-130	20	0.1
Method EPA 614/8140			
Surrogates			
1,3-Dimethyl-2-nitrobenzene	50-150	N/A	N/A
9-Nitroanthracene	50-150		
	30-130	N/A	N/A
Analytes	<b>5</b> 0.150	20	•
Azinphos methyl	50-150 50-150	30	2
Bolstar	50-150 50-150	30	2
Chlorpyrifos	50-150	30	2 2 2 2
Coumaphos	50-150	30	2

Section No: 5 Page: 14 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-2 Quality Assurance Objectives for Wastewater / Hazardous Waste Liquid Methods

CONSTITUENT	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR ug/L
Method EPA 614/8140 continued			
Demeton-o,s	50-150	30	2
Diazinon	50-150	30	2
Dichlorvos	50-150	30	$\overline{2}$
Disulfoton	50-150	30	2
Ethion	50-150	30	2
Ethoprop	50-150	30	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
Fensulfoton	50-150	30	2
Fenthion	50-150	30	2
Malathion	50-150	30	2
Merphos	50-150	30	2
Mevinphos	50-150	30	2
Naled	50-150	30	2
Parathion, ethyl	50-150	30	2
Parathion, methyl	50-150	30	2
Phorate	50-150	30	2
Ronnel	50-150	30	2
Stirophos	50-150	30	2
Tokuthion	50-150	30	2
Trichlornate	50-150	30	2
Method EPA 615/8150			
Surrogate			
2,4-DČAA	30-150	N/A	N/A
Analytes	30-130	11/42	11/12
Bentazon	30-150	30	20
Chloramben	30-150	30	10
2,4-D	30-150	30	100
Dalapon	30-150	30	10
2,4-DB	30-150	30	100
Dicamba	30-150	30	10
Dichlorprop	30-150	30	20
Dinoseb	30-150	30	10
Pentachlorophenol	30-150	30	10
Picloram	30-150	30	10
2,4,5-T	30-150	30	10
2,4,5-TP (Silvex)	30-150	30	10
Method EPA 624/8240			
Surrogates			
1,2-Dichloroethane-d4	76-114	30	N/A
Toluene-d8	88-110	30	N/A
BFB	86-115	30	N/A
Analytes	00-113	<b>50</b>	14/22
Acetone	50-150	30	10
Acrolein	50-150	30	100
Acrylonitrile	50-150	30	100
Act fromthe	20 120		100

Section No: 5 Page: 15 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-2 Quality Assurance Objectives for Wastewater / Hazardous Waste Liquid Methods

CONSTITUENT	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR ug/L
Method EPA 624/8240 continued			
Benzene	37-151	30	0.5
Bromodichloromethane	35-155	30	1
Bromoform	45-169	30	ī
Bromomethane	D-242	30	1
Carbon disulfide	50-150	30	<b>5</b>
Carbon tetrachloride	70-140	30	0.5
Chlorobenzene	37-160	30	0.5
Chloroethane	14-230	30	1
2-Chloroethylvinyl ether	50-150	30	10
Chloroform	51-138	30	0.5
Chloromethane	D-273	30	1
Dibromochloromethane	53-149	30	ī
1,2-Dichlorobenzene	50-150	30	1
1,3-Dichlorobenzene	50-150	30	ī
1,4-Dichlorobenzene	50-150	30	1
Dichlorodifuoromethane	50-150	30	0.5
1,1-Dichloroethane	59-155	30	1
1,2-Dichloroethane	49-155	30	1
1,1-Dichloroethylene	D-234	30	1
trans-1,2-Dichloroethylene	54-156	30	1
1,2-Dichloropropane	D-210	30	1
cis-1,3-Dichloropropene	D-227	30	2
trans-1,3-Dichloropropene	17-183	30	1
Ethanol	50-150	30	5000.
Ethylbenzene	37-162	30	0.5
2-Hexanone	50-150	30	5
Methylene chloride	D-221	30	0.5
2-Butanone (MEK)	50-150	30	10
4-Methyl-2-pentanone (MIBK)	50-150	30	5
Styrene	50-150	30	1
1,1,2,2-Tetrachloroethane	46-157	30	1
Tetrachloroethylene	64-148	30	1
Toluene	47-163	30	0.5
1,1,1-Trichloroethane	52-162	30	0.5
1,1,2-Trichloroethane	52-150	30	0.5
Trichloroethylene	71-157	30	1
Trichlorofluoromethane	17-181	30	1.5
Vinyl acetate	50-150	30	100
Vinyl chloride	D-251	30	0.5
Xylenes	50-150	30	1

Section No: 5 Page: 16 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-2 Quality Assurance Objectives for Wastewater / Hazardous Waste Liquid Methods

• •	•		4
	ACCURACY	PRECISION	DLR
CONSTITUENT	% REC-AR	RPD-MAV	ug/L
Method EPA 625/8270			
Surrogates			
2-Fluorobiphenyl	43-106	30	N/A
Nitrobenzene-d5	39-98	30	N/A
p-Terphenyl-d14	62-114	30	N/A
2-Fluorophenol	21-100	30	N/A
Phenol-d6	10-94	30	N/A
2,4,6-Tribromophenol	11-100	30	N/A
Analytes	11-100	30	11/74
Acenaphthene	36-130	30	10
	33-145	30	10
Acenaphthylene Aniline	50-150	30	50
Anthracene	27-133	30	10
Benzo(a)anthracene	33-143	30	10
Benzo(a)pyrene	17-163	30	10
Benzo(b)fluoranthene	24-159	30	10
Benzo(k)fluoranthene	11-162	30	10
Benzo(g,h,i)perylene	D-219	30	10
Benzylalcohol	50-150	30	20
bis(2-Chloroethoxy)methane	33-184	30	10
bis(2-Chloroethyl)ether	12-158	30	10
bis(2-Chloroisopropyl)ether	36-166	30	10
bis(2-Ethylhexly)phthalate	29-137	30	10
4-Bromophenylphenylether	65-114	30	10
Butylbenzylphthalate	D-152	30	10
Chloroaniline	50-150	30	10
Chloronaphthalene	60-180	30	10
Chlorophenylphenylether	25-158	30	10
Chrysene Chrysene	17-168	30	10
Dibenzo(a,h)anthracene	D-227	30	10
Dibenzofuran	50-150	30	10
1,2-Dichlorobenzene	32-129	30	10
1,3-Dichlorobenzene	D-172	30	10
1,4-Dichlorobenzene	33-114	30	10
3,3'-Dichlorbenzidine	8-213	30	20
Diethylphthalate	D-114	30	10
Dimethylphthalate	D-112	30	10
Di-n-butylphthalate	1-118	30	10
2,4-Dinitrotoluene	37-111	30	10
2,6-Dinitrotoluene	50-158	30	10
Di-n-octylphthalate	4-146	30	10
Fluoranthene	26-137	30	10
Fluorene	59-121	30	10
Hexachlorobenzene	50-150	30	10
Hexachlorobutadiene	24-116	30	10
Hexachlorocyclopentadiene	50-150	30	10
Hexachloroethane	40-113	30	10

Section No: 5 Page: 17 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-2 Quality Assurance Objectives for Wastewater / Hazardous Waste Liquid Methods

· · ·			•
	ACCURACY	<b>PRECISION</b>	DLR
CONSTITUENT	% REC-AR	RPD-MAV	$\underline{\mathbf{u}\mathbf{g}/\mathbf{L}}$
Method EPA 625/8270 continued	-00		
Indeno(1,2,3-c,d)pyrene	50-150	30	10
Isophorone	21-196	30	10
2-Methylnaphthalene	50-150	30	10
Naphthalene	21-133	30	10
Nitrobenzene	35-180	30	10
N-Nitrosodimethylamine	50-150	30	10
N-Nitrosodi-N-propylamine	D-112	30	10
N-Nitrosodiphenylamine	50-150	30	10
2-Nitroanaline	50-150	30	50
3-Nitroanaline	50-150	30	50
4-Nitroanaline	50-150	30	50
Phenanthrene	54-120	30	10
Pyrene	73-119	30	10
1,2,4-Trichlorbenzene	35-122	30	10
2-Chlorophenol	27-143	30	10
2,4-Dichlorophenol	39-135	30	10
2,4-Dimethylphenol	42-109	30	10
4,6-Dinitro-o-cresol	D-181	30	<b>50</b>
2,4-Dinitrophenol	D-191	30	<b>50</b>
2-Methylphenol	50-150	30	10
4-Methylphenol	50-150	30	10
2-Nitrophenol	29-182	30	10
4-Nitrophenol	D-53	50	50
p-Chloro-m-cresol	22-147	30	20
Pentachlorophenol	D-112	30	50
Phenol	D-82	30	10
2,4,5-Trichlorophenol	50-150	30	10
2,4,6-Trichlorophenol	37-144	30	10
Method EPA 632			
Barban	30-150	20	0.5
Carbaryl	30-150	30	0.5
Carbofuran	30-150	30 30	0.2
Chlorpropham	30-150	30	30
Diuron	30-150	30	0.3
Fluometuron	30-150	30	0.1
Linoron	30-150	30	100
Methiocarb	30-150	30	0.1
Methodalb	30-150	30	0.2
Monuron	30-150		100
Neburon	30-150	30	0.1
Oxamyl	30-150 30-150	30	0.1
Propham	30-150 30-150	30	100
Propoxur	30-150 30-150	30 30	0.7
Sidoron	30-150 30-150	30 30	1
Swep	30-150	30 30	1 2
O mcp	20-120	30	4

Section No: 5 Page: 18 of 30 Revision No: 2.0

Date: January 15, 1994

TABLE 5-2 Quality Assurance Objectives for Wastewater / Hazardous Waste Liquid Methods

CONSTITUENT			CURACY EC-AR		RECISION PD-MAV		DLR ug/L
Method EPA 415.1/9060 TOC	8	80-12	20	20	)		0.5 mg/L
Method EPA 9020 TOX	8	80-12	20	20			0.5
Method EPA 418.1 TRPH-By IR	4	50-150 20		20			0.5 mg/L
CONSTITUENT	Method	<u>l</u>	ACCURACY % REC-AR		PRECISION RPD-MAY		LR g/L
Inorganic Chemicals							
Acidity	305.1		N/A		20	1	
Alkalinity (as CaCO3)	310.0		N/A		20	1	
Bicarbonate	310.1		N/A		20	1	
BOD	405.1		80-120		20	2	
Bromide	300.0		80-120		20	0.	5
Carbon Dioxide	SM4500	)C	N/A		20	1	
Carbonate	310.1		N/A		20	1	
COD	410.2		75-125		20	4	
Chloride	300.0		80-120		20	1	_
Chlorine Residual	330.2		N/A		20	0.	
Chlorine Residual	330.3		N/A		20	0.	
Color	110.3		N/A		20		units
Electrical Conductivity	120.1		80-120		20		umhos
Cyanide, Total	335.2		75-125		20		01
Fluoride by electrode	340.2		80-120		20	0.	ı
Hydroxide	310.0 425.1		N/A 70-130		20 20	1	05
MBAS Nitrogen	425.1		/0-130		20	υ.	US
Nitrogen Ammonia	350.1		80-120		20	1	
Nitrate	300.0		80-120		20	Ô.	1
Nitrite	300.0		80-120		20	0.	
Nitrate	353.2		80-120		20	0.	
Nitrite	353.2 353.2		80-120		20	0.	
Total Kjeldahl	351.2		80-120		20	1	•
Odor	140.1		N/A		20	1	TON
Oil and Grease	413.1		N/A		20	3	10.1
Oxygen, dissolved	360.1		N/A		20	Õ.	5
pH	150.1		N/A		20		/ <b>A</b>
Phenols	420.1		75-125		20	0.	
Phosphorous			. 3 .=-		_ •	-•	=
phosphate	300.0		80-120		20	0.	1
Total	365.4		75-125		20	0.	

Section No: 5 Page: 19 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-2 Quality Assurance Objectives for Wastewater / Hazardous Waste Liquid Methods

TABLE 5-2 Quality Assurance C	objectives to	r wastewater / Ha	izardous waste	Liquid Metho
CONSTITUENT	Method	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR mg/L
Inorganic Chemicals continued				
Solids/Residue				
Filterable (TDS)	160.1	NA	20	40
Non-filterable (TSS)	169.2	NA	20	10
Total	160.3	NA	<b>20</b> .	40
Volatile	160.4	NA	20-	40
Settleable	160.5	NA	20	0.1  ml/L
Sulfate	300.0	80-120	20	1
Sulfide				
Total	376.2	N/A	20	0.1
Dissolved	376.2	N/A	20	0.1
Sulfite	377.1	N/A	20	0.1
Tannin & Lignin	SM5500B	N/A	20	1
Titration - pH adjust.	N/A	N/A	20	1
Turbidity	180.1	N/A	20	0.2 NTU
Trace Metals				
Aluminum	200.9	75-125	20	0.02
Aluminum	200.8	75-125	20	0.1
Antimony	200.9	75-125	20	0.02
Antimony	200.8	75-125	20	0.005
Arsenic	200.9	75-125	20	0.005
Arsenic	200.8	75-125	20	0.02
Barium	200.7	80-120	20	0.02
Barium	200.8	75-125	20	0.005
Beryllium	200.7	80-120	20	0.01
Beryllium	200.8	75-125	20	0.005
Boron	200.7	80-120	20	0.1
Boron	200.8	75-125	20	0.1
Cadmium	200.9	75-125	20	0.005
Cadmium	200.8	75-125	20	0.005
Calcium	200.7	80-120	20	1
Chromium	200.9	75-125	20	0.01
Chromium	200.8	75-125	20	0.02
Chromium VI	7196	D-120	20	0.01
Cobalt	200.7	80-120	20	0.05
Cobalt	200.8	75-125	20	0.005
Copper	200.7	80-120	20	0.05
Copper	200.8	75-125	20	0.02
Iron	200.7	80-120	20	0.05
Gold	231.1	75-125	20	0.05
Lead	200.9	75-125	20	0.01
Lead	200.8	75-125	20	0.005
Organic Lead	LUFT	50-150	20	0.05
Lithium	SM3500L	80-120	20	0.05
Magnesium	200.7	80-120	20	1
Manganese	200.7	80-120	20	0.03

Section No: 5 Page: 20 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-2 Quality Assurance Objectives for Wastewater / Hazardous Waste Liquid Methods

CONSTITUENT	<u>Method</u>	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR mg/L
Trace Metals continued				
Manganese	200.8	75-125	20	0.01
Mercury	245.1	75-125	20	0.0002
Mercury	245.2	75-125	20	0.0002
Molybdenum	200.7	80-120	<b>20</b> .	0.05
Molybdenum	200.8	75-125	20-	0.005
Nickel	200.7	80-120	20	0.05
Nickel	200.8	<b>75-125</b>	20	0.01
Potassium	200.7	80-120	20	1
Selenium	200.9	75-125	20	0.005
Selenium	200.8	75-125	20	0.02
Silica	200.7	80-120	20	1
Silver	200.9	75-125	20	0.01
Silver	200.8	75-125	20	0.005
Sodium	200.7	80-120	20	1
Strontium	200.7	80-120	20	0.05
Thallium	200.9	75-125	20	0.02
Thallium	200.8	75-125	20	0.005
Tin	200.9	75-125	20	0.05
Titanium	200.7	80-120	20	0.1
Uranium	200.7	80-120	20	0.1
Vanadium	200.7	80-120	20	0.02
Zinc	200.7	80-120	20	0.05
Zinc	200.8	75-125	20	0.05
		ACCURACY	PRECISION	DLR
CONSTITUENT	<u>Method</u>	% REC-AR	RPD-MAV	pCi/L
Radiochemistry				
Gross Alpha	900.0	80-120	20	0.1
Gross Beta	900.0	80-120	20	0.1
Radon	913.0	80-120	20	10
Strontium 90	905.0	80-120	20	1
Total Radium	900.1	80-120	20	0.1
Tritium	906.0	80-120	20	200
Uranium	908.0	80-120	20	0.1

Section No: 5 Page: 21 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-3 Quality Assurance Objectives for Solid Waste / Hazardous Waste Methods

TABLE 3-3 Quanty Assurance Obj	,0001.05 101 50114 4500		
	ACCURACY	<b>PRECISION</b>	DLR
CONSTITUENT	% REC-AR	RPD-MAV	mg/Kg
Method EPA 8010			
Surrogates			
BFB	50-150	N/A	N/A
Fluorobenzene	50-150	N/A	N/A
Chlorofluorobenzene	50-150	N/A	N/A
Analytes	-0.4-0		_
Azobenzene	50-150	30	55555555555555555555555555
Benzidine	50-150	30	5
Benzoic acid	50-150	30	5
Benzylchloride	50-150	20	5
bis(2-Chloroisopropyl)ether	50-150	20	5
Bromobenzene	50-150	20	5
Bromochloromethane	50-150	20	5
Bromodichloromethane	42-172	20	5
Bromoform	13-159	20	5
Bromomethane	D-144	20	5
Carbon tetrachloride	43-143	20	5
Chlorobenzene	38-150	20	5
Chloroethane	46-137	20	5
Chloroform	49-133	20	5
1-Chlorohexane	50-150	20	5
Chloromethane	D-193	20	5
2-Chlorotoluene	50-150	20	5
Chlorotoluene	50-150	20	5
DBCP	50-150	20	5
Dibromochloromethane	24-191	20	5
1,2-Dibromoethane	50-150	20	5
Dibromomethane	50-150	20	5
1,2-Dichlorobenzene	D-208	20	5
1,3-Dichlorobenzene	7-187	20	5
1,4-Dichlorobenzene	42-143	20	5
1,1-Dichloroethane	47-132	20	5
1,2-Dichloroethane	51-147	20	5
1,1-Dichloroethylene	28-167	20	5
cis-1,2-Dichloroethylene	<b>50-150</b>	20	5
trans-1,2-Dichloroethylene	38-155	20	5
1,2-Dichloropropane	44-156	20	5
1,3-Dichloropropane	50-150	20	5
2,2-Dichloropropane	50-150	20	5
1,1-Dichloropropene	50-150	20	5
cis-1,3-Dichloropropene	22-178	20	5
trans-1,3-Dichloropropene	22-178	20	5
Hexachlorobutadiene	50-150	20	5
Methylene chloride	25-162	20	5
1,1,1,2-Tetrachloroethane	50-150	20	5
1,1,2,2-Tetrachloroethane	50-150	20	55555555555555
Tetrachloroethylene	26-162	20	5

• •	
	ii.
	!
•	
	<b>\$1</b> 500
	<b>₩</b> .
	<b>(49</b> )
	# ·
	ø-
	**************************************
	21 1 1
	.gevi-
	ulig ™ .
	4.00 ×
	:
	Na - a

Section No: 5 Page: 22 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-3 Quality Assurance Objectives for Solid Waste / Hazardous Waste Methods

CONSTITUENT	ACCURACY % REC-AR	PRECISION RPD-MAV	DLR mg/Kg
Method EPA 8010 continued 1,2,3-Trichlorobenzene 1,2,4-Trichlorobenzene 1,1,1-Trichloroethane 1,1,2-Trichloroethane Trichloroethylene Trichlorofluoromethane Trichloropropane Vinyl chloride	50-150 50-150 41-138 39-136 35-146 21-156 50-150 28-163	20 20 20 20 20 20 20 20 20	5 5 5 5 5 5 5
Method EPA 8011 EDB DBCP	50-150 50-150	30 30	0.0005 0.0005
Method EPA 8015 Acrylamide Diethyl ether Ethanol Methyl ethyl ketone Methyl isobutyl ketone Paraldehyde	50-150 50-150 50-150 50-150 50-150	40 40 40 40 40 40	0.05 0.05 0.05 0.05 0.05 0.05
Method EPA 8015M TPH (purgeable) Gas	50-150	40	5
Method EPA 8015M TPH (extractable) Crude oil Diesel fuel Hydraulic oil Jet fuel Stoddard solvent Waste oil	50-150 50-150 50-150 50-150 50-150	40 40 40 40 40 40	10 10 10 10 10 50
Method EPA 8020 Benzene Chlorobenzene Ethylbenzene 1,2-Dichlorobenzene 1,3-Dichlorobenzene 1,4-Dichlorobenzene Toluene Xylene, o Xylene, p Xylene, m	39-159 55-135 32-160 37-154 50-141 42-143 46-148 50-150 50-150	20 20 20 20 20 20 20 20 20 20 20	0.003 0.003 0.003 0.003 0.003 0.003 0.003 0.003 0.003

Section No: 5 Page: 23 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-3 Quality Assurance Objectives for Solid Waste / Hazardous Waste Methods

CONSTITUENT	ACCURACY % REC-AR	PRECISION PRO MAY	DLR
CONSTITUENT	% REC-AR	RPD-MAV	mg/Kg
Method EPA 8040 (analyzed by method	d 8270)		
2-s-Butyl-4-6-dinitrophenol	50-150	30	0.1
2-Chlorophenol	23-134	30	0.1
4-Chloro-3-methylphenol	22-147	30	0.2
2,4-Dichlorophenol	39-135	30	0.1
2,4-Dimethylphenol	42-109	30	0.1
2,4-Dinitrophenol	D-191	30	0.5
2-Methyl-4,6-Dinitrophenol	D-181	30	0.5
2-Methylphenol	50-150	30	0.1
4-Methylphenol	50-150	30	0.1
2-Nitrophenol	29-182	30	0.1
4-Nitrophenol	29-182	30	0.5
Pentachlorophenol	14-176	30	0.5
Phenol	5-112	30	0.1
2,3,4,6-Tetrachlorophenol	50-150	30	0.1
2,3,5,6-Tetrachlorophenol	50-150 37 144	30	0.1
2,3,4-Trichlorophenol 2,3,5-Trichlorophenol	37-144 37-144	30 30	0.1 0.1
2,3,6-Trichlorophenol	37-144 37-144	30	0.1 0.1
2,4,5-Trichlorophenol	37-144 37-144	30 30	0.1 0.1
2,4,6-Trichlorophenol	37-144 37-144	30	0.1
•	37-144	30	0.1
Method EPA 8080			
Surrogates Hexachlorobenzene	50-150	30	N/A
Dibutylchlorendate	20-150	30 30	N/A N/A
Analytes	20-150	30	14/A
Aldrin	34-132	43	0.05
Alpha BHC	37-134	30	0.05
Beta BHC	17-147	30	0.05
Delta BHC	19-140	30	0.05
Chlordane	45-119	30	0.05
o,p - DDD	31-141	30	0.05
p,p - DDD	31-141	30	0.05
o,p - DDE	30-145	30	0.05
p,p - DDE	30-145	30	0.05
o,p - DDT	23-134	50	0.05
p,p - DDT	23-134	50	0.05
Dieldrin	31-134	38	0.05
Endosulfan I	45-153	30	0.05
Endosulfan II	D-202	30	0.05
Endosulfan sulfate	26-144	30	0.05
Endrin	42-139	45	0.05
Endrin aldehyde	50-150	30	0.05
Heptachlor	35-130	30	0.05
Heptachlor epoxide	37-142	30	0.05
Lindane	46-127	50	0.05

Section No: 5 Page: 24 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-3 Quality Assurance Objectives for Solid Waste / Hazardous Waste Methods

TABLE 5-3 Quanty Assurance Ob	jectives for Soud waste	e / mazardous waste	Methods
	ACCURACY	PRECISION	DLR
CONSTITUENT	% REC-AR	RPD-MAV	mg/Kg
Method EPA 8080 continued			
Methoxychlor	50-150	30	0.1
Toxaphene	41-126	30	0.1
PCB 1016	50-114	30	0.5
PCB 1221	15-178	30	0.5
PCB 1232	10-215	30	0.5
PCB 1242	39-150	30	0.5
PCB 1248	38-158	30	0.5
PCB 1254	29-131	30	0.5
PCB 1260	8-127	30	0.5
Method EPA 8140			
Surrogates			
1,3-Dimethyl-2-nitrobenzene	50-150	30	N/A
9-Nitroanthracene	50-150	30	N/A
Analytes			• … • •
Azinphos methyl	50-150	30	0.02
Bolstar	50-150	30	0.02
Chlorpyrifos	50-150	30	0.02
Coumaphos	50-150	30	0.02
Demeton-o,s	50-150	30	0.02
Diazinon	50-150	30	0.02
Dichlorvos	50-150	30	0.02
Disulfoton	50-150	30	0.02
Ethoprop	50-150	30	0.02
Fensulfoton	50-150	30	0.02
Fenthion	50-150	30	0.02
Merphos	50-150	30	0.02
Mevinphos	50-150	30	0.02
Naled	50-150	30	0.02
Parathion methyl	50-150	30	0.02
Phorate	50-150	30	0.02
Ronnel	50-150	30	0.02
Stirophos	50-150	30	0.02
Tokuthion	50-150	30	0.02
Trichlornate	50-150	30	0.02
Method EPA 8150			
Surrogate			
2,4-DČAA	30-150	N/A	N/A
Analytes			
Bentazon	30-150	30	0.2
Chloramben	30-150	30	0.1
2,4-D	30-150	30	1
Dalapon	30-150	30	$\bar{0.1}$
2,4-DB	30-150	30	1
Dicamba	30-150	30	0.1

Section No: 5 Page: 25 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-3 Quality Assurance Objectives for Solid Waste / Hazardous Waste Methods

			<b>~</b> -~
CONCENTRATE	ACCURACY	PRECISION	DLR
CONSTITUENT	% REC-AR	RPD-MAV	mg/Kg
Method EPA 8150 continued			
Dichlorprop	30-150	30	0.2
Dinoseb	30-150	30	0.1
Pentachlorophenol	30-150	30	0.1
Picloram	30-150	30	0.1
2,4,5-T	30-150	30	0.1
2,4,5-TP (Silvex)	30-150	30	0.2
2,4,5-11 (SHYCX)	30-130	30	<b>0.2</b>
Method EPA 8240			
Surrogates			
1,2-Dichloroethane-d4	61-164	N/A	N/A
Toluene-d8	81-117	N/A	N/A
BFB	67-124	N/A	N/A
Analytes	07-124	11/12	14/12
Acetone	50-150	30	0.01
Acrolein	50-150	30	0.1
	50-150	30	0.1
Acrylonitrile Benzene	66-142	21	0.005
	35-155	30	0.005
Bromodichloromethane			0.005
Bromoform	45-169 D 242	30	
Bromomethane	D-242	30	0.01
Carbon disulfide	50-150	30	0.005
Carbon tetrachloride	70-140	30	0.005
Chlorobenzene	60-133	21	0.005
Chloroethane	14-230	30	0.01
2-Chloroethylvinyl ether	50-150	30	0.01
Chloroform	51-138 D 272	30	0.005
Chloromethane	D-273	30	0.01
Dibromochloromethane	53-149	30	0.005
1,2-Dichlorobenzene	50-150	30	0.005
1,3-Dichlorobenzene	50-150	30	0.005
1,4-Dichlorobenzene	50-150	30	0.005
Dichlorodifluoromethane	50-150	30	0.0005
1,1-Dichloroethane	59-172	21	0.005
1,2-Dichloroethane	49-155	30	0.005
1,1-Dichloroethylene	D-234	30	0.005
trans-1,2-Dichloroethylene	54-156	30	0.005
1,2-Dichloropropane	D-210	30	0.005
cis-1,3-Dichloropropene	D-227	30	0.005
trans-1,3-Dichloropropene	17-183	30	0.005
Ethanol	50-150	30	10
Ethylbenzene	37-162	30	0.005
2-Hexanone	50-150	30	0.005
Methylene chloride	D-221	30	0.005
2-Butanone (MEK)	50-150	30	0.01
4-Methyl-2-pentanone (MIBK)	50-150	30	0.005
Styrene	50-150	30	0.005

Section No: 5 Page: 26 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-3 Quality Assurance Objectives for Solid Waste / Hazardous Waste Methods

CONSTITUENT	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAY	DLR mg/Kg
Method EPA 8240 continued			
1,1,2,2-Tetrachloroethane	46-157	30	0.005
Tetrachloroethylene	64-148	30	0.005
Toluene	59-139	21	0.005
1,1,1-Trichloroethane	52-162	30	0.005
1,1,2-Trichloroethane	52-150	30	0.005
Trichlorethylene	62-137	24	0.005
Trichlorofluoromethane	17-181	30	0.005
Vinyl acetate	50-150	30	0.1
Vinyl chloride	D-251	30	0.01
Xylenes	50-150	30	0.005
Method EPA 8270			
Surrogates			
2-Fluorobiphenyl	30-115	30	N/A
Nitrobenzene-d5	23-120	30	N/A
p-Terphenyl-d14	18-137	30	N/A
2-Fluorophenol	25-121	30	N/A
Phenol-d6	24-113	30	N/A
2,4,6-Tribromophenol	19-122	30	N/A
Analytes			
Acenaphthene	31-137	19	1
Acenaphthylene	33-145	30	1
Aniline	50-150	30	5
Anthracene	27-133	30	1
Benzo(a)anthracene	33-143	30	1
Benzo(a)pyrene	17-163	30	1
Benzo(b)fluoranthene	24-159	30	1
Benzo(k)fluoranthene	11-162	30	1
Benzo(g,h,i)perylene	D-219	30	1
Benzylalcohol	50-150	30	2
bis(2-Chloroethoxy)methane	33-184	30	1
bis(2-Chloroethyl)ether	12-158	30	1
bis(2-Chloroisopropyl)ether	36-166	30	1
bis(2-Ethylhexyl)phthalate	29-137	30	1
4-Bromophenylphenylether	65-114	30	1
Butylbenzylphthalate	D-152	30	1
Chloroaniline	50-150	30	2
Chloronaphthalene	60-180	30	1
Chlorophenylphenylether	25-158	30	1
Chrysene	17-168	30	1
Dibenzo(a,h)anthracene	D-227	30	1
Dibenzofuran	50-150	30	1
1,2-Dichlorobenzene	32-129	30	1
1,3-Dichlorobenzene	D-172	30	1
1,4-Dichlorobenzene	28-104	27	1
3,3'-Dichlorobenzidine	8-213	30	2

Section No: 5 Page: 27 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-3 Quality Assurance Objectives for Solid Waste / Hazardous Waste Methods

CONSTITUENT	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAY	DLR mg/Kg
Method EPA 8270 continued			
Diethylphthalate	D-114	30	1
Dimethylphthalate	D-112	30	1
Di-n-butylphthalate	1-118	30	ī
2,4-Dinitrotoluene	28-100	47	1
2,6-Dinitrotoluene	50-158	30	1
Di-n-octylphthalate	4-146	30	1
Fluoranthene	26-137	30	1
Fluorene	59-121	30	1
Hexachlorobenzene	50-150	30	1
Hexachlorobutadiene	24-116	30	1
Hexachlorocyclopentadiene	50-150	30	2
Hexachloroethane	40-113	30	2 1
Indeno(1,2,3-c,d)pyrene	50-150	30	1
Isophorone	21-196	30	1
2-Methylnaphthalene	50-150	30	1
Naphthalene	21-133	30	1
Nitrobenzene	35-180	30	1
N-Nitrosodimethylamine	50-150	30	1
N-Nitrosodi-N-propylamine	41-126	38	1
N-Nitrosodiphenylamine	50-150	30	
2-Nitroanaline	50-150	30	1 5 5 5
3-Nitroanaline	50-150	30	5
4-Nitroanaline	50-150	30	5
Phenanthrene	54-120	30	1
Pyrene	35-142	36	1
1,2,4-Trichlorbenzene	38-107	23	1
2-Chlorophenol	25-102	50	1
2,4-Dichlorophenol	39-135	30	1
2,4-Dimethylphenol	42-109	30	1
4,6-Dinitro-o-cresol	D-181	30	1 5 5
2,4-Dinitrophenol	<b>D-191</b>	30	
2-Methylphenol	50-150	30	1
4-Methylphenol	50-150	30	1
2-Nitrophenol	29-182	30	1
4-Nitrophenol	11-114	50	5 2 5
p-Chloro-m-cresol	26-103	33	2
Pentachlorophenol	1 <b>7-10</b> 9	47	5
Phenol	26-90	35	1
2,4,5-Trichlorophenol	50-150	30	1
2,4,6-Trichlorophenol	37-144	30	1
Azobenzene	50-150	30	5
Benzidine	50-150	30	1 5 5 5
Benzoic Acid	50-150	30	5

Section No: 5 Page: 28 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-3 Quality Assurance Objectives for Solid Waste / Hazardous Waste Methods

_	-	PRECISION RPD-MAV	DLR ug/Kg
70-1 70-1 70-1 70-1 70-1 70-1	130 130 130 130 130	20 20 20 20 20 20 20	3 2 0.1 0.1 0.2 0.1
70-1 70-1	130 130	20 20	0.2 0.1 0.3
70-1 70-1	130 130	20 20	2 2 0.1
<b>70-</b> 1	130	20 20 20	2 2 0.1
80-120		20	50
80-120		20	1
50-150		20	10
Method	% REC-AR	PRECISION RPD-MAV	DLR mg/Kg
9056 120.1 335.2 335.2 ASA/UL	70-130 80-120 65-135 65-135 N/A	30 20 30 30 20	10 10 umhos 1 50 N/A
350.1 9056 9056 Calc. 351.1 Calc. 413.1 150.1	70-130 70-130 70-130 N/A 65-135 N/A N/A N/A	30 30 30 30 30 30 30 20	4 4 3 100 100 100 200 N/A 5
	70-1 70-1 70-1 70-1 70-1 70-1 70-1 70-1	80-120  50-150  ACCURACY Method % REC-AR  9056 70-130 120.1 80-120 335.2 65-135 335.2 65-135 ASA/UL N/A  350.1 70-130 9056 70-130 9056 70-130 9056 70-130 Calc. N/A 351.1 65-135 Calc. N/A 413.1 N/A 150.1 N/A	% REC-AR         RPD-MAV           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           70-130         20           80-120         20           80-120         20           80-120         20           80-120         20           80-120         20           335.2         65-135         30           335.2         65-135         30           ASA/UL         N/A         20           350.1         70-130         30           9056         70-130         30           9056         70-130         30           9056         70-130         30           9056         70-130

Section No: 5 Page: 29 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-3 Quality Assurance Objectives for Solid Waste / Hazardous Waste Methods

TABLE 5-5 Quanty Assurance V	objectives to	of Solid Waste / I.	lazai dods Wasic	Wicthous
		DID	ACCURACY	PRECISION
CONSTITUENT	Method	DLR <u>% REC-AR</u>	RPD-MAV	mg/Kg
Inorganic Chemicals				
Phosphorous				
Phosphate	9056	70-130	30	3
Total (see Trace Metals)	7020	70-150	50	J
Sulfate	9056	70-130	30-	10
Sulfide	376.2	N/A	30	5
Suride	370.2	TV/A	30	3
Hazardous Waste Characterizati	on			
Corrosivity (pH)	9045	20.0	N/A	N/A
Ignitability	1020	N/A	N/A	N/A
Reactivity	SW-846	N/A	N/A	N/A
Generation	SW-846	N/A	N/A	N/A
Generation	511-040	14/12	14/12	11/12
Trace Metals				
Aluminum	6010	70-130	30	50
Aluminum	6020	70-130	30	20
Antimony	7041	65-135	30	3
Antimony	6020	65-135	30	1
Arsenic	7060	65-135	30	Ī
Arsenic	6020	65-135	30	4
Barium	6010	70-130	30	1
Barium	6020	70-130	30	Î.
Beryllium	6010	70-130	30	0.5
Beryllium	6020	70-130	30	1
Boron	6010	70-130	30	5
Boron	6020	70-130	30	5
Cadmium	6010	70-130	30	5 5 3 1
Cadmium	6020	70-130	30	1
Calcium	6010	70-130	30	50
Chromium	6010	70-130	30	3
Chromium	6020	70-130	30	4
Chromium VI	7196	D-130	30	0.2
Cobalt	6010	70-130	30	3
Cobalt	6020	70-130	30	4
Copper	6010	70-130	30	3
Copper	6020	70-130	30	3 4 3 3
Gold	231.1	70-130	30	3
Iron	6010	70-130	30	3
Lead	7420	70-130	30	4
Lead	6020	70-130	30	1
Organic Lead	LUFT	50-150	20	4
Lithium	7430	70-130	30	3
Magnesium	6010	70-130	30	50
Manganese	6010	70-130	30	2
Manganese	6020	70-130	30	$\overline{2}$
Mercury	7471	65-135	30	0.01

Section No: 5 Page: 30 of 30 Revision No: 2.0 Date: January 15, 1994

TABLE 5-3 Quality Assurance Objectives for Solid Waste / Hazardous Waste Methods

CONSTITUENT	Methods	ACCURACY <u>% REC-AR</u>	PRECISION RPD-MAV	DLR mg/Kg
Trace Metals continued				
Molybdenum	6010	70-130	30	3
Molybdenum	6020	70-130	30	1
Nickel	6010	70-130	30	3
Nickel	6020	70-130	30	3 2
Phosphorous, Total	6010	65-135	30-	50
Potassium	6010	70-130	30	50
Selenium	7740	65-135	30	3
Selenium	6020	65-135	30	4 3
Silver	6010	70-130	30	3
Silver	6020	70-130	30	1
Sodium	6010	70-130	30	50
Strontium	6010	65-135	30	3
Thallium	7841	65-135	30	3 3 1 3 5 5
Thallium	6020	65-135	30	1
Tin	6010	65-135	30	3
Titanium	6010	65-135	30	5
Uranium	6010	65-135	30	5
Vanadium	6010	70-130	30	1
Zinc	6010	70-130	30	3
Zinc	6020	70-130	30	10
		ACCURACY	PRECISION	DLR
CONSTITUENT	Method	% REC-AR	RPD-MAV	pCi/Kg
Radiochemistry				
Gross Alpha	900.0	80-120	20	1
Gross Beta	900.0	80-120	20	1
Radon	913.0	80-120	20	10
Strontium 90	905.0	80-120	20	1
Total Radium	900.1	80-120	20	1
Tritium	906.0	80-120	20	200
Uranium	908.0	80-120	20	1

•		
		:
	•	!
		:
	:	:
		$q \cdot k'$
		SAR-JA
		5.
		<b>₽</b> e:
		9.
	· · · · · · · · · · · · · · · · · · ·	
		A - 1
		A1.1
	;	
	,	

Section No: 6 Page: 1 of 16 Revision No: 2.0 Date: January 15, 1994

# Sampling Procedures

Sample collection and sample handling techniques are important aspects of the overall sample analysis process and have a major impact on the quality and validity of the results. Specific containers and preservatives are used to ensure that sample integrity is not lost through volatility or degration. In addition, contaminants that are likely to interfere or effect the quality of analytical data must be minimized or eliminated. If a client chooses to collect their own samples, experienced lab staff can brief clients by telephone on the proper methods of sample collection. Detailed procedures to ensure sampling consistency and compliance with method requirements are available. The correct container types, bottle sizes, preservatives, container closures, and holding times for sampling are shown in Table 6-1.

### 6.1 FGL Sampling Protocols

#### 6.1.1 General Precautions

The result of any analytical determination can be no better than the sample on which it is performed. The objective is to obtain a sample that meets the requirements of the sampling program and manage it in such a way that it does not deteriorate or become contaminated before reaching the laboratory. This objective implies that the relative proportions or concentrations of all pertinent components will be the same in the samples as in the material being sampled, and that the sample will be processed in such a way that no significant changes in composition occur before the tests are made.

A sample may be presented to the laboratory for specific determinations with the collector taking responsibility for its validity. Often the laboratory conducts or prescribes the sampling program which is determined in consultation with the user of the test results. Such consultation is essential to insure the selection of the appropriate sample and analytical methods that provide a true basis for answering the questions that prompted the sampling.

Before filling, rinse the sample bottle two or three times with the water being collected, unless the bottle contains a preservative. Depending on determinations to be performed, fill container full (most organics determinations) or leave space for aeration, mixing, etc. (microbiological analyses). For samples that will be shipped, preferably leave an air space of about one (1) percent of container capacity to allow for thermal expansion. Special precautions are necessary for samples containing organic compounds and trace metals. Because many constituents may be present at concentrations of micrograms per liter, they may be totally or partially lost if proper sampling and preservation procedures are not followed.

Representative samples of some sources can be obtained only by making composites of samples collected over a period of time or at many different sampling points. The details of collection vary so much with local conditions that no specific recommendations would be universally applicable. Sometimes it is more informative to analyze numerous separate samples instead of one composite so as not to obscure high and low results.

Sample carefully to insure that analytical results represent the actual sample composition. Important factors affecting results are; the presence of suspended matter or turbidity; the method chosen for its removal, and; the physical and chemical changes brought about by storage or aeration.

Section No: 6
Page: 2 of 16
Revision No: 2.0

Date: January 15, 1994

# Sampling Procedures

#### 6.1.1 General Precautions continued

Particular care is required when processing (grinding, blending, sieving, filtering) samples to be analyzed for trace constituents, especially metals and organic compounds. Some determinations, particularly of lead, can be invalidated by contamination from such processing.

Treat each sample individually with regard to the substances to be determined, the amount and nature of turbidity present, and other conditions that may influence the results.

It is impractical to give directions covering all conditions. The choice of technique for collecting a homogeneous sample must be left to the analyst's judgment. In general, separate any significant amount of suspended matter by decantation, centrifugation, or an appropriate filtration procedure. Often a slight turbidity can be tolerated if experience shows that it will cause no interference in gravimetric or volumetric tests. Its influence can be corrected in colorimetric tests, where it has potentially the greatest interfering effect. When relevant, state whether or not the sample has been filtered. To measure the total amount of a constituent, do not remove suspended solids, but treat them appropriately.

Make a record of every sample collected and identify every bottle, preferably by attaching an appropriately inscribed tag or label. Record sufficient information to provide positive sample identification at a later date. Include the name of the sample collector, the date, hour, and exact location, the water temperature, and any other data that may be needed for correlation, such as weather conditions, water level, stream flow, post-sampling handling, etc. Provide space on the label for the initials of those assuming sample custody and for the time and date of transfer. Identify sampling points by detailed description, by maps, or with the aid of stakes, buoys, or landmarks in a manner that will permit their identification by other persons without reliance on memory or personal guidance. When sample results are expected to be involved in litigation, it is recommended to use formal "chain-of-custody" procedures which trace sample history from collection to final reporting.

Hot samples collected under pressure should be cooled while still under pressure.

Before collecting samples from distribution systems, flush lines sufficiently to insure that the sample is representative of the supply, taking into account the diameter and length of the pipe to be flushed and the velocity of flow.

Collect samples from wells only after the well has been pumped sufficiently to insure that the sample represents the groundwater source. Sometimes it will be necessary to pump at a specified rate to achieve a characteristic drawdown, if this determines the zones from which the well is supplied. Record pumping rate and drawdown.

When samples are collected from a river or stream, observed results may vary with depth, stream flow, and distance from shore and from one shore to the other. If equipment is available, take an "integrated" sample from top to bottom in the middle of the stream or from side to side at mid-depth.

Section No: 6 Page: 3 of 16 Revision No: 2.0 Date: January 15, 1994

## Sampling Procedures

### 6.1.1 General Precautions continued

Lakes and reservoirs are subject to considerable variations from normal causes such as seasonal stratification, rainfall, runoff, and wind. Choose location, depth, and frequency of sampling to reflect local conditions and the purpose of the investigation. Avoid surface scum.

For certain constituents, sampling location is extremely important. Avoid areas of excessive turbulence because of potential loss of volatile constituents and of potential presence of toxic vapors. Avoid sampling at weirs because such locations tend to favor retrieval of lighter-than-water, immiscible compounds. Generally, collect samples beneath the surface in quiescent areas. If composite samples are required, take care that sample constituents are not lost during compositing because of improper handling of the sample being pooled. For example, casual dumping together of portions rather than addition to the composite through a submerged siphon can cause unnecessary volatilization.

Use only representative samples (or those conforming to a sampling program) for examination. The great variety of conditions under which collections must be made makes it impossible to prescribe a fixed procedure. In general, take into account the tests or analyses to be made and the purpose for which the results are needed.

#### 6.1.2 Field Notebook

The sampler or field investigator should keep a field notebook (preferably bound with pages numbered) to record sample collection procedures, dates, laboratory identification, sample collection location, and the name of the sampler. This is important for later recall or legal challenge.

#### 6.2 Water Samples

#### 6.2.1 Grab or Catch Samples

Strictly speaking, a sample collected at a particular time and place can represent only the composition of the source at that time and place. However, when a source is known to be fairly constant in composition over a considerable period of time or over substantial distances in all directions, then the sample may be said to represent a longer time period or a larger volume, or both, than the specific point at which it was collected. In such circumstances, some sources may be fairly represented by single grab samples. Examples are some water supplies, some surface waters, and rarely, some wastewater streams. When a source is known to vary with time, grab samples collected at suitable intervals and analyzed separately can document the extent, frequency, and duration of these variations. Choose sampling intervals on the basis of the frequency with which changes may be expected, which may vary from as little as five (5) minutes to as long as one (1) hour or more. Seasonal variations in natural systems may necessitate sampling over months. When the source composition varies in space rather than time, collect samples from appropriate locations.

Use great care in sampling wastewater, sludges, sludge banks, and muds. No definite procedure can be given, but take every possible precaution to obtain a representative sample or one conforming to a sampling program.

Section No: 6 Page: 4 of 16 Revision No: 2.0

Date: January 15, 1994

# **Sampling Procedures**

#### 6.2.2 Composite Samples

In most cases, the term "composite sample" refers to a mixture of grab samples collected at the same sampling point at different times. Sometimes the term "time-composite" is used to distinguish this type of sample from others. Time- composite samples are most useful for observing average concentrations that will be used, for example, in calculating the loading or the efficiency of a wastewater treatment plant. As an alternative to the separate analysis of a large number of samples and the computation of average and total results, composite samples represent a substantial saving in laboratory effort and expense. For these purposes, a composite sample representing a 24 hour period is considered standard for most determinations. Under certain circumstances, however, a composite sample representing one shift, or a shorter time period, or a complete cycle of a periodic operation, may be preferable. To evaluate the effects of special, variable, or irregular discharges and operations, collect composite samples representing the period during which such discharges occur.

For determining components or characteristics subject to significant and unavoidable changes on storage, do not use composite samples. Make such determinations on individual samples as soon as possible after collection and preferably at the sampling point. Analyses for all dissolved gases, residual chlorine, soluble sulfide, temperature, and pH are examples of this type of determination. Changes in such components as dissolved oxygen or carbon dioxide, pH, or temperature may produce secondary changes in certain inorganic constituents such as iron, manganese, alkalinity, or hardness. Use time-composite samples only for determining components that can be demonstrated to remain unchanged under the conditions of sample collection and preservation.

Take individual portions in a bottle having a diameter of at least 35 mm at the mouth and a capacity of at least 120 mL. Collect these portions every hour, in some cases every half hour or even every five (5) minutes, and mix at the end of the sampling period or combine in a single bottle as collected. If preservatives are used, add them to the sample bottle initially so that all portions of the composite are preserved as soon as collected. Analysis of individual samples sometimes may be necessary. It is desirable, and often essential, to combine individual samples in volumes proportional to flow. A final sample volume of 2 to 3 L is sufficient for sewage, effluents, and wastes.

Automatic sampling devices are available; however, do not use them unless the sample is preserved as described below. Clean sampling devices, including bottles, daily to eliminate biological growths and other deposits.

### 6.2.3 Integrated Samples

For certain purposes, the information needed is provided best by analyzing mixtures of grab samples collected from different points simultaneously, or as nearly so as possible. Such mixtures sometimes are called integrated samples. An example of the need for such sampling occurs in a river or stream that varies in composition across its width and depth. To evaluate average composition or total loading, use a mixture of samples representing various points in the cross-section, in proportion to their relative flows. The need for integrated samples also may exist if combined treatment is proposed for several separate wastewater streams, the interation of which may have a significant effect on treatability or even on composition. Mathematical prediction of the interactions may be inaccurate or impossible and testing a suitable integrated sample may provide more useful information.

Section No: 6 Page: 5 of 16 Revision No: 2.0 Date: January 15, 1994

## **Sampling Procedures**

### 6.2.3 Integrated Samples continued

Both natural and artificial lakes show variations of composition with both depth and horizontal location. However, under many conditions, neither total nor average results are especially significant; local variations are more important. In such cases, examine samples separately rather than integrate them.

Preparation of integrated samples usually requires special equipment to collect a sample from a known depth without contaminating it with overlying water. Knowledge of the volume, movement, and composition of the various parts of the water being sampled usually is required. Therefore, collecting integrated samples is a complicated and specialized process that cannot be described in detail.

### 6.3 Hazardous Waste Samples

### 6.3.1 Volatile Organics

Standard 40 mL glass screw-cap VOA vials with Teflon-faced silicone septum may be used for both liquid and solid matrices. The vials and septum should be soap and water washed and rinsed with distilled deionized water. After thoroughly cleaning the vials and septum, they should be placed in a muffle furnace and dried at 150 C for approximately one hour. (Note: Do not heat the septum for extended periods of time, i.e., more than one hour, because the silicone begins to slowly degrade at 105 C).

When collecting the samples, liquids and solids should be introduced into the vials gently to reduce agitation which might drive off volatile compounds. Liquid samples should be poured into the vial without introducing any air bubbles within the vial as it is being filled. Should bubbling occur as a result of violent pouring, the sample must be poured out and the vial refilled. Each VOA vial should be filled until there is a meniscus over the lip of the vial. The screw-top lid with the septum (Teflon side toward the sample) should then be tightened onto the vial. After tightening the lid, the vial should be inverted and tapped to check for air bubbles. If there are any air bubbles present the sample must be retaken. Two VOA vials should be filled per sample location.

VOA vials for samples with solid or semi-solid (sludges) matrices should be completely filled as best as possible. The vials should be tapped slightly as they are filled to eliminate as much free air space as possible. Two vials should also be filled per sample location.

VOA vials should be filled and labeled immediately at the point at which the sample is collected. They should NOT be filled near a running motor or any type of exhaust system because discharged fumes and vapors may contaminate the samples. The two vials from each sampling location should then be sealed in separate plastic bags to prevent crosscontamination between samples particularly if the sampled waste is suspected of containing high levels of volatile organics. (Activated carbon may also be included in the bags to prevent cross-contamination from highly contaminated samples). VOA samples may also be contaminated by diffusion of volatile organics through the septum during shipment and storage. To monitor possible contamination, a trip blank prepared from distilled deionized water should be carried throughout the sampling, storage, and shipping process.

Section No: 6 Page: 6 of 16 Revision No: 2.0 Date: January 15, 1994

# Sampling Procedures

## 6.3.2 Semivolatile Organics

(This includes Pesticides and Herbicides) Containers used to collect samples for the determination of semivolatile organic compounds should be soap and water washed followed by methanol (or isopropanol) rinsing. The sample containers should be of glass or Teflon and have screw-top covers with Teflon liners. In situations where Teflon is not available, samples may react with the aluminum foil, causing eventual contamination of the sample. Plastic containers or lids may NOT be used for the storage of samples due to the possibility of sample contaminat ion from the phthalate esters and other hydrocarbons within the plastic. Sample containers should be filled with care so as to prevent any portion of the collected sample coming in contact with the field persons gloves, thus causing contamination. Samples should not be collected or stored in the presence of exhaust fumes. If the sample comes in contact with the an automatic sampler run reagent water through the sampler and use as a field blank.

#### 6.3.3 Trace Metals

In the determination of trace metals, containers can introduce either positive or negative errors in the measurement of trace metals by (a) contributing contaminants through leaching or surface desorption, and (b) depleting concentrations through adsorption. Thus the collection and treatment of the sample prior to analysis require particular attention.

### 6.4 Underground Storage Tank Samples

### 6.4.2 Soil Samples

#### 6.4.2.1 Hydrocarbons

Soil samples collected from a backhoe, the ground or a soil coring device, should be collected in a thin-walled stainless steel or brass cylinder at least three inches long by one inch in diameter that has been prepared by the laboratory doing the analysis or the project consultant (cylinders can be made to fit inside the preferred split- barrel core sampler). About one inch of soil should be removed from the immediate surface area where the sample is to be taken and the cylinder then pounded in to the soil with a mallet or hammer. No headspace should be present in the cylinder once the sample is collected. When the sample is collected, each end of the cylinder should be covered with teflon tape and then capped with a polyethylene lid, taped and labeled. The sample should be immediately placed in an ice chest and kept cool at 4 C for delivery to the laboratory. Care should be taken throughout, to avoid contamination of both the inside and outside of the cylinder and its contents.

Samples should be kept cool at 4 C at the laboratory until they are analyzed. Holding times should not exceed 14 days from the time of collection. A portion of the sample should be removed and prepared for analysis according to approved EPA methods.

In situations where the above procedure is inappropriate (i.e. semi-solid samples), glass vials (properly prepared by contract laboratory consultant) with Teflon seal and screw cap should be used and maintained at 4 C until analysis.

#### 6.4.2.2 Organic Lead

Tetraethyl/tetramethyl-lead are volatile; therefore, soil samples should be collected in cylinders and frozen as described for volatile hydrocarbons above.

Section No: 6 Page: 7 of 16 Revision No: 2.0 Date: January 15, 1994

# Sampling Procedures

### 6.4.2.3 Product Samples

Free Floating Product (from a well): Sampling of free floating product on the surface of ground water should not be performed until the well has been allowed to stabilize for at least 24 hours after development or other withdrawal procedure. A sample should be collected that is indicative of the thickness of floating product within the monitoring well. This may be accomplished by the use of a clear, acrylic bailer designed to collect a liquid sample where free product and ground water meet. A graduated scale on the bailer is helpful for determining the thickness of free product. Samples should be field-inspected for the presence of odor and/or sheen in addition to the above evaluation.

Electronic measuring devices also are available for determining the thickness of the hydrocarbon layer floating on ground water.

### 6.4.2.4 Aqueous/Dissolved Product

If free product (from a well) is detected, analysis of water for dissolved product should be conducted after the free product has been substantially removed from the well. Before collecting a water sample, a well should be purged until temperature, conductivity and pH stabilize. Often, this will require removal of four or more well volumes by bailing or pumping. Once well volumes are removed and well water is stabilized, a sample can be taken after the water level approaches 80 percent of its initial level. Where water level recovery is slow, the sample can be collected after stabilization is achieved.

Ground water samples should be collected in a manner which reduces or eliminates the possibility of loss of volatile constituents from the sample. For collecting samples, a gas-actuated positive displacement pump or a submersible pump is preferred. A Teflon or stainless steel bailer is acceptable. Peristaltic pumps or airlift pumps should not be used.

Cross-contamination from transferring pumps (or bailers) from well to well can occur and should be avoided by thorough cleaning between sampling episodes. Dedicated (i.e., permanent installation) well pumps, while expensive, are often cost effective in the long term and ensure data reliability relative to cross-contamination. If transfer of equipment is necessary, sampling should proceed from the least contaminated to the most contaminated well, if the latter information is available before sample collection.

Water samples should be collected in vials or containers specifically designed to prevent loss of volatile constituents from the sample. These vials should be provided by an analytical laboratory, and preferably, the laboratory conducting the analysis. No headspace should be present in the sample container once the container has been capped. This can be checked by inverting the bottle, once the sample is collected, and looking for bubbles. Sometimes it is not possible to collect a sample without air bubbles, particularly if water is aerated. In these cases, the investigator should record the problem and account for probable error. Cooling samples may also produce headspace (bubbles), but these will disappear once the sample is warmed for analysis.

Samples should be placed in an ice chest maintained at 4 C with blue ice (care should be taken to prevent freezing of the water and bursting of the glass vial). A thermometer with a protected bulb should be carried in each ice chest.

Section No: 6 Page: 8 of 16 Revision No: 2.0

**Date: January 15, 1994** 

# **Sampling Procedures**

#### 6.4.2.5 Surface Water

Grab samples should be collected in appropriate glass containers supplied by the laboratory. The sample should be collected in such a manner that air bubbles are not entrapped. Semisolid samples should be collected the same way. The collected samples should be refrigerated (blue ice, 4 C) for transport and analyzed within seven (7) days of collection (14 days with preservatives).

## 6.5 Pesticide Residue Sampling Procedures

6.5.1 Concerning Re-entry and Worker Safety

All samples should be from the plant foliage (leaf tissue) when pesticides are applied to the foliage. Sometimes areas other than the plant foliage may be in question, such as the dripline area surface soil and/or the leaf duff (leaf litter) under the trees. The sample should be large enough to fill a normal "lunch bag" and be taken from several plantings.

6.5.2 Conerning Consumer Safety

The edible portion of the plant or fruit should be collected. The sample should contain approximately one (l) pound of material taken from several plants. Usually six to eight whole plants or fruit pieces will make up a good sample.

6.6 Sample Handling Policy

Proper sample containers, sample volumes, preservatives, and holding times are essential to providing reliable data. Table 6-1 provides information for each of these items. FGL references the following sources for compiling Table 6-1.

- (1) Federal Register, Volume 49, No. 209, October 26, 1984 and subsequent updates.
- (2) "Handbook for Sampling and Sample Preservation of Water and Wastewater", EPA Method Book, EPA-600/4-82-029, September 1982.
- (3) "Methods for Chemical Analysis in Waters and Waste" (MCAWW) EPA-600/4-79-020
- (4) "Methods for Evaluating Solid Waste", EPA Method Book, SW- 846, rev. 3, and Proposed Revisions.
- (5) "Standard Methods for the Analysis of Water and Wastewater", 17th Edition, 1990.
- (6) "Methods for the Determination of Organic Compounds in Drinking Water", EPA Method Book, EPA-600/4-88-039, December 1988.
- (7) "Methods for the Determination of Organic Compounds in Drinking Water-Supplement I", EPA Method Book, EPA-600/4- 90-020, July 1990.
- (8) "Methods for the Determination of Organic Compounds in Drinking Water-Supplement II", EPA Method Book, EPA-600/4- 90-020, July 1990.
- (9) "Methods for Organic Chemical Analysis of Municipal and Industrial Wastewater", EPA Method Book, EPA 600/4-82-057, July 1982.
- (10) "Prescribed Procedures for Measurement of Radioactivity in Drinking Water", EPA Method Book, EPA-600/4-80-032, August 1980.

6.6.1 Bottle Preparation

Sample bottles for most analyses, such as metals, and organics analyses, are purchased precleaned according to EPA Protocol specification from various vendors. In addition to manufacturer certified containers, FGL monitors sample containers for specific contaminants as each lot is received. Bottles are carefully wrapped to prevent breakage during shipment.

Section No: 6 Page: 9 of 16 Revision No: 2.0 Date: January 15, 1994

# **Sampling Procedures**

6.6.2 Shipping Samples

Prior to shipment of samples, all documentation must be ready for proper chain of custody. The information necessary for documenting chain of custody is outlined in the following section of the quality assurance manual (section 7). After filling out the proper sample documentation, the samples and documents should be placed in an ice chest with adequate protection. Normally "Blue Ice" is used for keeping samples cool. However, dry ice may be used if approved by Department of Transportation (DOT).

6.6.3 Sample Kits

FGL Environmental supplies the appropriate sample containers, preservatives, chain-of-custody forms, coolers with blue ice, and packing materials to client upon request. There is no charge for these services as long as FGL is the laboratory receiving the samples for analysis. Arrangements for sample kits may be made through the client services department.

Section No: 6 Page: 10 of 16 Revision No: 2.0 Date: January 15, 1994

# **Sampling Procedures**

TABLE 6-1 RECOMMENDED SAMPLE COLLECTION AND PRESERVATION

<u>Analysis</u>	Container	Volume (mL)	Preservation	Holding <u>Time</u>
General Inorganic Chemist	ry			
Acidity	P,G	250	Cool, 4 C	14 days
Alkalinity	P,G	250	Cool, 4 C	14 days
Asbestos	G	1000	Cool, 4 C	48 hr.
Bicarbonate Biochemical Oxygen Demand	P P,G	250 1000	Cool, 4 C Cool, 4 C	14 days 48 hr.
Boron Bromide Carbonate Carbon Dioxide Chemical Oxygen	P	250	Cool, 4 C	6 mo.
	P	250	Cool, 4 C	28 days
	P	250	Cool, 4 C	14 days
	P,G	250	Cool, 4 C	immed.
	P,G	250	H <sub>2</sub> SO <sub>4</sub> , pH < 2; Cool, 4 C	28 days
Demand Chloride Chlorine Residual Chlorine Demand Color	P,G	250	Cool, 4 C	28 days
	P,G	500	Cool, 4 C	2 hr.
	P,G	2000	Cool, 4 C	2 hr.
	P,G	250	Cool, 4 C	48 hr.
Cyanide, Total Electrical Conductivity Fluoride Hardness, Total	P,G	1000	NaOH, pH > 12; Cool, 4 C	14 days
	P	250	Cool, 4 C	28 days
	P,G	250	Cool, 4 C	28 days
	P,G	250	HNO <sub>3</sub> , pH < 2; Cool, 4 C	6 mo.
Hydroxide	P,G	250	Cool, 4 C	14 days
Iodide	P,G	250	Cool, 4 C	24 hr.
Langelier Index	P,G	500	Cool, 4 C	2 hr.
MBAS	P,G	500	Cool, 4 C	48 hr.
Nitrogen, Ammonia Nitrate+Nitrite Nitrate	P,G P,G P,G	250 250 250	H <sub>2</sub> SO <sub>4</sub> , pH < 2; Cool, 4 C H <sub>2</sub> SO <sub>4</sub> , pH < 2; Cool, 4 C Cool, 4 C	28 days 28 days 48 hr.
Nitrite	P,G	250	Cool, 4 C	48 hr.
Organic	P,G	400	H <sub>2</sub> SO <sub>4</sub> , pH < 2; Cool, 4 C	28 days
Total	P,G	250	H <sub>2</sub> SO <sub>4</sub> , pH < 2; Cool, 4 C	28 days
Total Kjeldahl Odor Oil and Grease Oxygen, Dissolved	P,G G G	250 500 1000 250	H <sub>2</sub> SO <sub>4</sub> , pH < 2; Cool, 4 C Cool, 4 C H <sub>2</sub> SO <sub>4</sub> , pH < 2; Cool, 4 C Cool, 4 C	28 days 24 hr. 28 days immed.
pH Phenolics	w/glass stop P,G G	250 500	Cool, 4 C H <sub>2</sub> SO <sub>4</sub> , pH <2; Cool, 4 C	2 hr. 28 days

P = plastic, G = glass Note: All solid samples should be collected in stainless steel sleeves, brass sleeves or in glass jars all with teflon-lined caps and 4-8 oz. capacity. All solid samples should be kept cool at 4

Section No: 6
Page: 11 of 16
Revision No: 2.0
Date: January 15, 1994

# **Sampling Procedures**

TABLE 6-1 RECOMMENDED SAMPLE COLLECTION AND PRESERVATION

<u>Analysis</u>	Container	Volume (mL)	Preservation	Holding <u>Time</u>
General Inorganic Chemistr	ry continued			
Phosphorus	<b>n</b> .C	250	0.1.40	40 1
Ortho/dissolved	P,G	250 250	Cool, 4 C	48 hr.
Total	P,G	250 250	H <sub>2</sub> SO <sub>4</sub> , pH < 2; Cool, 4 C	28 days
Resistivity	P P	250 250	Cool, 4 C	28 days
Silica	P P	250 250	Cool, 4 C	28 days 6 mo.
Sodium Absorption Ratio	r	250	HNO3, $pH < 2$	о що.
Solids,	D C	250	Cool 4C	7 days
Filterable Non-filterable	P,G	250 250	Cool, 4 C Cool, 4 C	7 days
	P,G P,G	250 250	Cool, 4 C	7 days
Total Volatile	P,G	250 250	Cool, 4 C	7 days
Settleable	P,G	1000	Cool, 4 C	48 hr.
Sulfate	P,G	250	Cool, 4 C	28 days
Sulfide	1,0	250	C001, 4 C	20 days
Total	P,G	500	2 ml ZnAcetate+NaOH, pH>9	7 days
Dissolved	P,G	500	NaOH, pH>9	24 hr.
Tannin & Lignin	G,G	250	(14011, pii > )	<b>2</b> -7 III •
Titration - pH adjustment	P,G	250	Cool, 4 C	14 days
Turbidity	P,G	250	Cool, 4 C	48 hr.
I di Didity	1,0	250	C001, 7 C	-10 III •
Trace Metals				
Chromium VI	P,G	500	Cool, 4 C	24 hr.
Mercury	P,G	500	HNO <sub>3</sub> , pH<2	28 days
All other metals	P,G	500	HNO <sub>3</sub> , pH < 2	6 mo.
All other metals	•	200	11103, pii 12	o mo.

P = plastic, G = glass

Note: All solid samples should be collected in stainless steel sleeves, brass sleeves or in glass jars all with teflon-lined caps and 4-8 oz. capacity. All solid samples should be kept cool at 4 C.

<sup>\*</sup> No headspace over sample

<sup>\*\*</sup> For non-preserved samples, the holding time is 5 days. For preserved samples, please provide either a non-preserved sample (100 mL) or the electrical conductivity prior to acidification.

Section No: 6 Page: 12 of 16 Revision No: 2.0

Date: January 15, 1994

# **Sampling Procedures**

TABLE 6-1 RECOMMENDED SAMPLE COLLECTION AND PRESERVATION

<u>Analysis</u>	Contai	<u>ner</u>	Volume (mL)	Preservation	Holding <u>Time</u>	
Radiochemistry Gross Alpha & Beta Total Radium Total Uranium Radon* Tritium Strontium 90	P P P G G		1000 1000 1000 2x250 2x250 1000	HNO <sub>3</sub> , pH < 2 HNO <sub>3</sub> , pH < 2 HCl, pH < 2 Cool, 4 C Cool, 4 C HCl, pH < 2	6 mo. 6 mo. 6 mo. 72 hr. 6 mo. 6 mo.	
All Bacteriological	gical P,G		100	0.008% Na <sub>2</sub> S <sub>2</sub> 0 <sub>3</sub> ; Cool, 4 C, Sterile	30 hr.	
<u>Analysis</u>	<u>Container</u>	Vo (m)	lume <u>L)</u>	Preservation	Holding <u>Time</u>	
Organic Chemicals						
<b>Drinking Water</b>						
EPA 501*	G, VOA TFE-septa cap	2 x	40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated HCl, pH <2; Cool, 4 C	14 days	
EPA 502.2*	G, VOA TFE-septa cap	2 x	40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated HCl pH <2; Cool, 4 C	14 days	
EPA 504*	G TFE-septa cap	2 x	40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	28 days	
EPA 505**	G TFE-septa cap	2 x	40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days	
EPA 507	G, amber TFE-lined cap	1 x	1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated or HCl pH <2; Cool, 4 C	14 days	
EPA 508**	G, amber TFE-lined cap	1 x	1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days	
EPA 510*	G, amber TFE-septa cap	1 x	250	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	14 days	

<sup>\*</sup> No head space over sample.

\*\* This is the maximum holding time prior to extraction. The extracted sample may be held up to 40 days before analysis.

Section No: 6 Page: 13 of 16 Revision No: 2.0 **Date: January 15, 1994** 

# **Sampling Procedures**

TABLE 6-1 RECOMMENDED SAMPLE COLLECTION AND PRESERVATION

<u>Analysis</u>	<u>Container</u>	Volume (mL)	Preservation	Holding <u>Time</u>
Organic Chemicals				
<b>Drinking Water</b>				
EPA 515.1**	G, amber TFE-lined cap	1 x 1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days
EPA 524.2*	G, VOA TFE-septa cap	2 x 40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated or HCl pH <2; Cool, 4 C	14 days
EPA 525**	G, amber TFE-lined cap	1 x 1000	Cool, 4 C	7 days
EPA 531	G, amber	1 x 250	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Monochloroacetic acid buffer	14 days
EPA 547	G, amber	1 x 125	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	6 mo.
EPA 548	G, amber	1 x 125	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days
EPA 549	G, amber silanized	1 x 1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days
EPA 550.1	G, amber	1 x 1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days
EPA 552	G, amber	1 x 1000	NH <sub>4</sub> Cl, if chlorinated Cool, 4 C	7 days
EPA 1613A	G, amber	1 x 1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days

<sup>\*</sup> No head space over sample.

\*\* This is the maximum holding time prior to extraction. The extracted sample may be held up to 40 days before analysis.

Section No: 6 Page: 14 of 16 Revision No: 2.0

Date: January 15, 1994

# **Sampling Procedures**

TABLE 6-1 RECOMMENDED SAMPLE COLLECTION AND PRESERVATION

<u>Analysis</u>	Container	Volume (mL)	<u>Preservation</u>	Holding <u>Time</u>
Organic Chemicals				
Wastewater and Ha	zardous Waste			
EPA 601/8010*	G, VOA TFE-septa cap	2 x 40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated HCl, pH <2; Cool, 4 C	14 days
EPA 8011	G, VOA TFE-septa cap	2 x 40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	28 days
EPA 602/8020*	G, VOA TFE-septa cap	2 x 40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated HCl, pH <2; Cool, 4 C	14 days
EPA 603/8030*	G, VOA TFE-septa cap	2 x 40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Adjust pH to 4-5; Cool, 4 C	14 days
EPA 604/8040**	G, amber TFE-lined cap	1 x 1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days
EPA 608/8080**	G, amber TFE-lined cap	1 x 1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days
EPA 610/8310	G, amber TFE-lined cap	1 x 1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	14 days
EPA 613**	G, amber TFE-lined cap	1 x 1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days
EPA 614/8140**	G, amber TFE-lined cap	1 x 1000	Cool, 4 C	7 days
EPA 615/8150**	G, amber TFE-lined cap	1 x 1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days
EPA 619	G, amber TFE-lined cap	1 x 1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	14 days

<sup>\*</sup> No head space over sample.

\*\*\* RCRA holding time is 7 days.

Note: All solid samples should be collected in stainless steel sleeves, brass sleeves or in glass jars all with teflon-lined caps and 4-8 oz. capacity. All solid samples should be kept cool at 4 C.

<sup>\*\*</sup> This is the maximum holding time prior to extraction. The extracted sample may be held up to 40 days before analysis.

Section No: 6 Page: 15 of 16 Revision No: 2.0 Date: January 15, 1994

# **Sampling Procedures**

TABLE 6-1 RECOMMENDED SAMPLE COLLECTION AND PRESERVATION

<u>Analysis</u>	<u>Container</u>	Volume (mL)	Preservation	Holding <u>Time</u>
Organic Chemicals	Organic Chemicals			
Wastewater and Ha	zardous Waste			
EPA 624/8240*	G, VOA TFE-septa cap	2 x 40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated HCl, pH <2; Cool, 4 C	14 days
EPA 625/8270**	G, amber TFE-lined cap	1 x 1000	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated Cool, 4 C	7 days
EPA 632**	G, amber TFE-lined cap	1 x 1000	Cool, 4 C	7 days
EPA 9020* (TOX)***	G, amber TFE-lined cap	1 x 250	H <sub>2</sub> SO <sub>4</sub> , pH < 2 Cool, 4 C	14 days 7 days
EPA 415.1 (TOC)	G, amber TFE-lined cap	1 x 250	HCl or H <sub>2</sub> SO <sub>4</sub> , pH <2 Cool, 4 C	28 days
EPA 9060	See note	250 g	Cool, 4 C	N/A
Underground Stora	ge Tank Analyse	S		
EPA 418.1	G, amber TFE-lined cap	1 x 1000	Cool, 4 C	28 days
EPA 8015,8015M*	G, VOA TFE-septa cap	2 x 40	HCl, pH <2 Cool, 4 C	14 days
EPA 601/8010*	G, VOA TFE-septa cap	2 x 40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated HCl, pH <2; Cool, 4 C	14 days
EPA 602/8020*	G, VOA TFE-septa cap	2 x 40	Na <sub>2</sub> S <sub>2</sub> O <sub>3</sub> , if chlorinated 14 days HCl, pH <2; Cool, 4 C	

Note: All solid samples should be collected in stainless steel sleeves, brass sleeves or in glass jars all with teflon-lined caps and 4-8 oz. capacity. All solid samples should be kept cool at 4 C.

Section No: 6 Page: 16 of 16 Revision No: 2.0

Date: January 15, 1994

# **Sampling Procedures**

TABLE 6-1 RECOMMENDED SAMPLE COLLECTION AND PRESERVATION

<u>Analysis</u>	<u>Container</u>	Volume (mL)	Preservation	Holding <u>Time</u>
Hazardous Waste C	Characterization			
Corrosivity	P,G	100	Cool, 4 C	7 days
Ignitability	G TFE-lined cap	100	Cool, 4 C	7 days
Reactivity/ Reactions	G TFE-lined cap	100	Cool, 4 C	7 days
Sulfide/Sulfide generation	G TFE-lined cap	100	Cool, 4 C	7 days
TTLC, STLC, TCL	P, and EP Toxicity			
Metals	G TFE-lined cap	500	Cool, 4 C	30 days
Pesticides	G, amber TFE-lined cap	1000	Cool, 4 C	7 days*
Herbicides	G, amber TFE-lined cap	1000	Cool, 4 C	7 days*
Bioassays			•	
Chronic	P,G	3x1000	Cool, 4 C	24 hr.
Acute	P,G	2x5 gal	Cool, 4 C	24 hr.

Note: All solid samples should be collected in stainless steel sleeves, brass sleeves or in glass jars all with teflon-lined caps and 4-8 oz. capacity. All solid samples should be kept cool at 4 C.

Section No: 7
Page: 1 of 6
Revision No: 2.0
Date: January 15, 1994

# Sample Custody

## 7.1 Sample Custody

It is essential to ensure sample integrity from the time of collection through analysis and final disposition. This includes the ability to trace possession and handling of the samples. This is referred to as chain-of-custody and is important in the event of litigation involving the results. Where litigation is not involved, chain-of-custody procedures are useful for routine control of sample flow.

A sample is considered to be under a person's custody if it is in the individual's physical possession, in the individual's sight, secured in a tamper-proof manner by that individual, or is secured in an area restricted to authorized personnel. The following procedures summarize the major aspects of chain-of-custody.

#### 7.1.1 Sample Labels

Use labels to prevent sample misidentification. Gummed paper labels or tags generally are adequate. Include at least the following information: sample number, name of collector, date and time of collection, and place of collection. Affix labels to sample containers before or at the time of sampling. Fill label out with waterproof ink at time of collection.

### 7.1.2 Custody Seals

Use sample seals to detect unauthorized tampering with samples up to the time of analysis. Plastic seals are normally used. Attach seal in such a way that it is necessary to break the seal to open the sample container. Affix seal to container before sample leaves custody of sampling personnel.

#### 7.1.3 Field Log Book

Record all information pertinent to a field survey or sampling in a bound log book. As a minimum, include the following in the log book; purpose of sampling; location of sampling point; name and address of field contact; producer of material being sampled and address, if different from location; and type of sample. Because sampling situations vary widely, no general rule can be given as to the information to be entered in the log book. It is desirable to record sufficient information between the logbook and chain-of-custody so that one could reconstruct the sampling without reliance on the collector's memory. Protect the log book and keep it in a safe place.

### 7.1.5 Shipping Samples or Sample Delivery to Laboratory

Prior to shipping samples all documentation must be ready for proper chain of custody. The information necessary for documenting chain of custody is outlined section 7.3. After filling out the proper sample documentation, the samples and documents should be placed in an ice chest with adequate protection. Normally "Blue Ice" is used for keeping samples cool. However, dry ice may be used if approved by Department of Transportation (DOT).

If client provides direct delivery of sample to laboratory, samples should be delivered as soon as practicable. Documentation must be ready for proper chain of custody. Again, all information necessary for documenting chain of custody is outlined section 7.3. Accompany sample with chain- of-custody record and a sample analysis request sheet. Deliver sample to sample custodian.

Section No: 7
Page: 2 of 6
Revision No: 2.0

Date: January 15, 1994

# Sample Custody

### 7.1.6 Receipt and Logging of Sample

In the laboratory, the sample custodian receives the sample and inspects its condition and seal, reconciles label information and seal against the chain-of-custody record, assigns a laboratory number, logs sample in the laboratory computer, and stores it in a secured storage room or cabinet until it is assigned to an analyst.

## 7.1.7 Assignment of Sample for Analysis

The laboratory supervisor usually assigns the sample for analysis. Once in the laboratory, the supervisor or analyst is responsible for the sample's care and custody.

## 7.1.8 Safety Considerations

Because sample constituents can be toxic, take adequate precautions during sampling and sample handling. Toxic substances can enter through the skin and, in the case of vapors, through the lungs. Inadvertent ingestion can occur via direct contact with foods or by adsorption of vapors onto foods. Precautions may be limited to wearing gloves or may include coveralls, aprons, or other protective apparel. Always wear eye protection. When toxic vapors might be present, sample only in well-ventilated areas or use a respirator or self-contained breathing apparatus. In a laboratory, open sample containers in a fume hood. Never have food near samples or sampling locations; always wash hands thoroughly before handling food.

If there is any possibility that flammable organic compounds may be present, take adequate precautions. Prohibit smoking near samples, sampling locations, and in the laboratory. Keep sparks, flames, and excessive heat sources away from samples, and sampling locations.

Radioactivity is screened at the time of sample receipt. Consult the radiation safety SOP and Radiation Safety Officer for proper handling of samples.

#### 7.2 Laboratory Sample Control and Tracking

FGL's sample control objectives are achieved through the use of a Laboratory Information Management System (LIMS). LIMS is a computer software system specifically designed by FGL for tracking and handling of the large amount of information required to efficiently manage an analytical chemistry laboratory. The system provides a versatile, easy-to-use vehicle for the laboratory managers and chemists to perform sample tracking and status checks.

### 7.3 Sample Receiving Policy

Obtain a chain-of-custody record accompanying each sample or group of samples. The chain-of-custody is usually prepared in the field.

Section No: 7 Page: 3 of 6
Revision No: 2.0
Date: January 15, 1994

# Sample Custody

7.3.1	Obtain the following client information and record on chain of custody: Reporting - Address Phone Number Fax Number Person to Contact
	Billing - Address Phone Number Fax Number P.O. or contract Number Person to Contact
7.3.2	Obtain the following project and sample information and record on chain of custody: Project description Sample descriptions Sample type Sampling date and time Sample containers, preservatives EPA Method Numbers or method descriptions Report form required: State FGL Determine turn-around-time requirement: Rush Number of Days
1	Inspect the sample for the following: Have holding times been observed and determine if it is possible for FGL to meet holding times? Has the correct preservative been used? Is the sample size adequate? Is the sample container satisfactory? Note sample condition: Broken/leaking container Temperature Ambient Chilled Record Actual Temperature Check for headspace when appropriate  Also note on the chain of custody any problems with sample condition, the person notified, time and date notified, and customers response, if any.  Screen all samples for radio chemical hazard using the Geiger counter kept in the sample receiving area. Consult the radiation safety SOP and Radiation Safety Officer for proper handling of samples.

7.3.4 Log the sample information into the LIMS under one of the following divisions:

Inorganic Organic Radioactivity Bacteriology Agriculture

Section No: 7 Page: 4 of 6 Revision No: 2.0

Date: January 15, 1994

# Sample Custody

7.3.5 Transfer samples and analyses worksheets to the proper refrigerator or lab work distribution area.

7.4 Sample Storage

All samples are retained for a minimum of 30 days except for microbiological samples which are held for a shorter time. A longer storage period can be arranged at the request of the client.

7.5 Sample Disposal

All samples which are considered to be potentially hazardous based upon analytical results or matrix, will be disposed of by lab packing. Extremely hazardous samples may be returned to the client for disposal. All disposal arrangements should be made with a project manager.

7.6 Subcontracted Lab Work

On occasion, laboratory work may need to be subcontracted to certified labs approved by FGL Environmental. Prior to subcontracting the client will be notified. Under no circumstances will work be subcontracted without client requirements being met. When work is subcontracted, it is done so under chain of custody, and the proper records are included with the data package.

Section No: 7 Page: 5 of 6 Revision No: 2.0 Date: January 15, 1994

Sample Custody

Figure 7-1 Chain of Custody

This page intentionally left blank for figure on next page.

•		
		•
		:
		•
	•	•
		#fac
		Ş*-
		<b>M</b> A
		es:
		je <sub>ro</sub> o
		Mic
		, tes
		, ter
		Janes
		Moreover,
		Janes
		Janes
		. 14.
		Moreover,
		West
		Processing of the control of the con
		Process  Annual Control of Contro
		West
		Process  Annual Control of Contro
		Process  Annual Control of Contro
		Process



# FRUIT UROWERS LABORATORY, Inc.

# CHAIN-OF-CUSTODY

Date:	Ī			T	T	Ī		<b></b>	1	1	T	1		1	T		$\Box$
Client:											1				1		
Address:							ted				l		1				
					ł J		c 2 Brit				ĺ						
Phone: ()			Ť,		l=		품흔	ł	1								
Fax: ()	Grab (G)		(P) Plastic		g We		16 c	1	ŀ								
Project name:			<u>a</u>		ונים פרים נפר	b) e	4, 4 203			1	1				İ		
Contact person:	(3)				onit rave sike	ota	4250 4825			1	1		1			t L	
Sampler(s):	ite		G]	Ö	E F W	a e	٠. ت			1	l	]	1			פרים הח	
Comp mampler metup:Date:/_/Time::	Composite(C)	<u>م</u>	9		(SW) Surface Water (MW) Monitoring Well (GW) Ground Water (TB) Travel Blank (WW) Wastewater (S) Spike (DW) Drinking Water	(NP) None Potable	reservative:NaHSO4, HCL, HZSO4, HNO3, pH <2 NaOH pH > 9 or pH > 12 ; Na2S2O3 if chlorinated Other		l							Sample Condition: Temperature (L) Leaking, (B) Broken (HS) VOA Headspace	Ê
Time: Mileage:		ne.	PTS:	ludg	er ster	Ž	A X	1								n: B) E	
Purchase order number:	e:	inta.	tain( ) V(	it.)s	Hat.		E CO									ttto adsp	Ξ.
QA/QC report required: Yes No	Type of Sample:	Number of Containers	Type of Containers: (B)Brass (V) VOA		(SW) Surface Water (GW) Ground Water (WW) Wastewater (OW) Drinking Water	(P) Potable	Frive Fy:									Cond King	Seal
Lab number:	5	L	of	Soil	Ser Sas	Pot	OH p						1			Lead VQ	ò
Sample Location/Description Date Time Sampled Sampled	ype	QE 3	Type (B)B	(S)	8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	<u>a</u>	Pres Ot				Ì		1			Samp (L) (HS)	Custody
		-=				-											
	_			↓_		_			ļ	ļ	ļ	<b> </b>	ļ	<del> </del> -	<u> </u>		
												Ì					
		-		-	<del></del>	_		<u> </u>	ļ	- <del> </del>	<del> </del>	<u> </u>	╁	<del> </del>			$\vdash$
									ļ	ļ	<u> </u>	ļ	<b>_</b>				
				l				1	1	1							
				1-	<del> </del>				<del> </del>	1	<del> </del>		1	1			П
				-	ļ	_		<b> </b>	<u></u>	<del> </del>			-		<b> </b> -	ļ ——	
										1							
				1						1							
	L D	115	au Le	L	by:	De	te: T	ime:		Rece	ived	by:	1	Date	<u> </u>	l Cime:	<b>'</b>
Misc. notes:	"	: 1 111	dara	meu	υy.	υū	1	_,,,,		,,,,,,,		-1.			-		
Rush results due by: Final sample disposition:	1-			<del></del>													_
Lab disposal: Return to Client:										<del></del>						· · · · · · · · · · · · · · · · · · ·	
Heth. of disp.: Date of ret.://	1																

prporpte\_Offices\_8\_Laboratory O\_Box 272 / 853 Corporation Street inta Paula: CA 93061-0272 Office & Laboratory 2500 Stagecoach Road Stockton, CA 95215 Field Office Visalla, California TEL: (209) 734-9473

•	
	7 19 2
	4
	E Transition
	:
	:
	' 687*
	<b>*</b>
	<b>*</b> ***********************************
	, <b>660</b> 00 2400-
	446
	¥6:-
	<b>Market</b>
	e po-
	1
	10.00 10.00
	<b>A</b> tro-
	i man
	-

Section No: 8
Page: 1 of 5
Revision No: 2.0
Date: January 15, 1994

## Calibration Procedures and Frequency

The production of analytical data of known, defensible and documented quality requires adherence to standardized procedures which cover all aspects of laboratory operation. The following sections provide details of the standardized procedures relating to instrumentation calibration.

#### 8.1 Instrument Calibration

Prior to use, every instrument must be calibrated according to the procedure found in the method specific Standard Operating Procedure (SOP). A list of all laboratory equipment may be found in section 17. Tables 8-1 and 8-2 list the organic mass spectrometer calibration ion abundance criteria which must be met.

The analytical balances are certified once a year by a certified specialist. All balances are labelled as certified. All balances are checked monthly using NIST traceable S weights.

All refrigerator, oven, and incubator temperatures are monitored daily, and all thermometers are checked for accuracy on a quarterly basis.

#### 8.2 Calibration Standards

All chemicals used by FGL Environmental are ACS reagent grade, or better. Wherever possible, standards are from sources that are traceable to the National Institude of Standards and Technology. A log book is maintained for all working standards. Each log contains the standard ID or code, date of working standard preparation, analyst initials who prepared the standard, the manufacturers lot number, stock solution expiration date, stock analyte concentration(s), analyte concentration(s), and initial and final volumes used in dilutions. The working standard container is also labeled with ID or code, date of standard preparation, analyst initials who prepared the standard, expiration date, analytes and analyte concentration.

### 8.3 Calibration Policy

### 8.3.1 Applicability

This policy is designed to be a guideline to ensure that all data are treated alike, and thus ensuring that data generated on any particular day of analysis are representative of the norm. However, the policies are not intended to be absolute criteria for the acceptance or rejection of any analytical data.

In cases where the acceptance criteria outlined in policy or SOPs cannot be achieved then the analyst uses a non-conformance report form to document the difficulty. More than one continuing difficulty will result in a Corrective Action Report (CAR, see section 15). These are on record and will be included in a project data package if that is required by the project plan. An example of a CAR form is shown in figure 15-1.

### 8.3.2 Linearity

All calibrations should be linear unless otherwise defined in the specific SOP. FGL's definition of linearity is a calibration curve that has a linear regression equal to or greater than 0.995. For organics, if a linear regression is used, a single average response factor may be used if acceptance criteria pass. Specific protocols outlined in a given SOP will take precedence over these generic policies.

Section No: 8
Page: 2 of 5
Revision No: 2.0
Date: January 15, 1994

# Calibration Procedures and Frequency

## 8.3.3 Selection of Quantitation Technique (Organics)

For organic analysis, a decision must be made during the validation process (and detailed in the SOP) as to whether an internal or external quantitation technique will be routinely employed.

The internal standard method of quantitation cannot be employed unless all of the following conditions are met:

- (1) The internal standard must be added post-extraction.
- (2) The internal standard must be added quantitatively.
- (3) Any analyte that is a target analyte in the method of interest may not be selected for use as an internal standard.
- (4) The concentration of the internal standard(s) must not exceed the calibration range of the method target analyte. In cases where the target analytes are associated with more than one calibration range (i.e. analytes "1-4" are calibrated from 1 to 10 ppb, while analyte "5" is calibrated from 10 to 100 ppb, all target analytes should be prepared at a level between the highest and lowest calibration standard (e.g. approximately 50 ppb in the example given).

The use of internal standard quantitation is of greatest benefit in those methods subject to injection variability, and thus, variability in the absolute mass injected onto the column(s) employed. The drawback to this technique, for GC methods, is that any compound which exhibits a similar retention time as the compound used for the internal standard will be identified as the internal standard, leading to erronous quantitation. For this reason, the internal standard technique is most useful for GC/MS where deuterated analytes not naturally occurring can be derected and quantified.

### 8.3.4 Selection of Calibration Method

As part of the validation process, the specific calibration range and calibration method must be determined and documented in the SOP. Once determined in this manner, the same protocols must be followed each time the method is employed. This will ensure that data reduction is not performed differently on separate data sets by different analysts. The calibration acceptance criteria are listed in section 8.3.8. A least squares (linear) regression is initially tried as a calibration method. For organics, if a linear regression is used, a single average response factor may be used. For inorganics, if the acceptance criteria cannot be met using a linear regression, then a second order polynomial can be used to fit the data, with the same acceptance criteria being applied. In the event that neither a simple linear regression nor a second order polynomial fit result in an equation which meets the calibration acceptance criteria, then the calibration range must be reduced.

#### 8.3.5 Minimum Number of Calibration Levels

Most calibrations include a minimum of three or five initial calibration standards plus a blank. Specific SOPs may have other requirements.

Section No: 8 Page: 3 of 5 Revision No: 2.0

Date: January 15, 1994

## Calibration Procedures and Frequency

#### 8.3.6 Selection of Calibration Levels

Two standards should be included per order of magnitude of concentration of the calibration curve. For example 0.1, 1.0, 10.0 has 2 standards per order magnitude (0.1 and 1.0; 1.0 and 10.0). In cases where instrumentation spans several orders of magnitude, the SOP for that method may not require this policy.

The lowest calibration level should be within a factor of 10 of the detection limit for reporting (DLR) for each target compound unless otherwise specified in the SOP.

#### 8.3.7 Calibration Analysis Sequence

The calibration must progress from the analysis of the lowest to highest standard unless the instrumentation does not permit it. A blank must be analyzed after the highest calibration standard.

If the analysis requires an initial high standard to set the gain, a blank must be run before starting with the low calibration standard unless the instrumentation does not permit it.

#### 8.3.8 Calibration Acceptance Criteria

In general, for inorganics, the calculated value for standards must be within 10% of the expected value. However, the value determined by the calibration curve for the lowest standard must be within +/-50% of the true value and if the calibration is linear through the origin (at less than +/-1/2 the detection limit). For organics, if a linear regression is used, a single average response factor may be used. The percent relative standard deviation for the individual standard response factors must be less than the maximum value listed for the method in the SOP.

8.3.9 Calibration Check Compounds (CCC) and Initial Calibration Verifications (ICV's) The CCC or ICV is used to check the validity of the initial calibration. This standard is composed of some or all of the same analytes used for calibration but from a different source than the calibration standard. The standard should be at a concentration near the midpoint of the curve. In many cases FGL uses a Laboratory Control Sample (LCS) as an ICV. In this case the LCS verifies both the calibration and sample preparation. FGL uses control charts for LCS's and acceptance ranges for many analytes have been statistically derived. Please see table 5-1 for acceptance limits. If calculated acceptance criteria are not listed, the general acceptance range is +/-25% of the true value for organics and +/-10% for inorganics.

#### 8.3.10 Continuing Calibration Verifications (CCV)

The CCV is used to verify continuing calibration validity without having to completely restandardize the instrument. Refer to specific EPA methods or SOPs to determine whether this is required. The continuing calibration standard should be near the mid-point of the calibration curve. If calculated acceptance criteria are not listed, the general acceptance range is +/-25% of the true value for organics and +/-10% for inorganics.

Section No: 8
Page: 4 of 5
Revision No: 2.0
Date: January 15, 1994

## **Calibration Procedures and Frequency**

#### 8.3.11 Organic Mass Spectrometry Tuning Criteria

In addition to the above calibration criteria, GC/MS methods require mass spectrometer tuning. The acceptance criteria for volatile organics using bromofluorobenzene (BFB) are listed in table 8-1. The acceptance criteria for semivolatile organics using decafluorotriphenylphosphene (DFTPP) are listed in table 8-2.

Table 8-1

## GC/MS Volatile Organic Key Ion Abundance Tuning Criteria, using BFB

<u>Mass</u>	Ion Abundance Criteria
50	15 to 40% of mass 95
<b>75</b>	30 to 60% of mass 95
95	base peak, 100% relative abundance
96	5 to 9% of mass 95
173	less than 2% of mass 174
174	greater than 50% of mass 95
175	5 to 9% of mass 174
176	greater than 95% but less than 101% of mass 174
177	5 to 9% of mass 176

#### **Table 8-2**

## GC/MS Semivolatile Organic Key Ion Abundance Tuning Criteria, using DFTPP

<u>Mass</u>	Ion Abundance Criteria
51	30 to 60% of mass 198
68	less than 2% of mass 69
70	less than 2% of mass 69
127	40 to 60% of mass 198
197	less than 1% of mass 198
198	base peak, 100% relative abundance
199	5 to 9% of mass 198
275	10 to 30% of mass 198
365	greater than 1% of mass 198
441	present but less than mass 443
442	greater than 40% of mass 198
443	17 to 23% of mass 442

Section No: 8
Page: 5 of 5
Revision No: 2.0
Date: January 15, 1994

## Calibration Procedures and Frequency

### 8.3.12 Calibration Frequency

#### **Inorganics**

For trace metals analyses calibrations are performed initially for each analytical run. Recalibration or continuing calibration checks are used every ten analyses. For wet chem analyses, a new curve is generated every six months. To verify daily calibration, continuing calibration verifications are used. Exceptions may exist for method specific SOPs.

#### **Organics**

GC and GC/MS methods are calibrated initially for all analytes. For each additional day of operation, a calibration check standard is analyzed and evaluated. If the calibration is deemed valid the analysis may be performed. Otherwise, the system is recalibrated. Exceptions may exist for method specific SOPs.

-		
		:
	-	
		42.7
		***
		P
		pro E t

Section No: 9
Page: 1 of 13
Revision No: 2.0
Date: January 15, 1994

## **Analytical Procedures**

#### 9.1 Method Sources

FGL uses EPA or standard methods for virtually all analyses. The following method manuals are used as references:

#### Drinking Water Methods -

- 1) "Methods for Chemical Analysis in Waters and Waste" (MCAWW) EPA-600/4-79-020
- 2) "Standard Methods for the Analysis of Water and Wastewater", 17th Edition, 1990.
- 3) "Methods for the Determination of Organic Compounds in Drinking Water", EPA Method Book, EPA-600/4-88-039, December 1988.
- 4) "Methods for the Determination of Organic Compounds in Drinking Water-Supplement I", EPA Method Book, EPA-600/4-90-020, July 1990.
- 5) "Methods for the Determination of Organic Compounds in Drinking Water-Supplement II", EPA Method Book, EPA-600/4- 90-020, July 1990.
- 6) "Eastern Environmental Radiation Facility Radiochemistry Procedures Manual", EPA Method Book, EPA 520/5-84-006, August 1984.
- 7) "Environmental Measurements Laboratory Procedures", HASL-300, 27th Edition, February 1992.

#### Wastewater Methods -

- 1) "Methods for Chemical Analysis in Waters and Waste" (MCAWW) EPA-600/4-79-020
- 2) "Standard Methods for the Analysis of Water and Wastewater", 17th Edition, 1990.
- 3) "Methods for Organic Chemical Analysis of Municipal and Industrial Wastewater", EPA Method Book, EPA 600/4-82-057, July 1982.
- 4) "Eastern Environmental Radiation Facility Radiochemistry Procedures Manual", EPA Method Book, EPA 520/5-84-006, August 1984.
- 5) "Environmental Measurements Laboratory Procedures", HASL-300, 27th Edition, February 1992.

#### Solid Waste / Hazardous Waste Methods -

- 1) "Methods for Evaluating Solid Waste", EPA Method Book, SW- 846, revision 3, and proposed revisions.
- 2) "Eastern Environmental Radiation Facility Radiochemistry Procedures Manual", EPA Method Book, EPA 520/5-84-006, August 1984.
- 3) "Environmental Measurements Laboratory Procedures", HASL-300, 27th Edition, February 1992.

Section No: 9
Page: 2 of 13
Revision No: 2.0
Date: January 15, 1994

## **Analytical Procedures**

## 9.2 Standard Operating Procedures (SOPs)

FGL has specific standard operating procedures (SOPs) for each analytical test we perform. These procedures contain the following major sections:

- 1) Title
- 2) Scope and Application
- 3) Summary of Method
- 4) Interferences
- 5) Safety
- 6) Sample Preparation
- 7) Reagent Preparation
- 8) Standard Preparation
- 9) Analytical Procedure
- 10) Calculations
- 11) Quality Control
- 12) Data Validation and Reporting
- 13) Record Keeping and Record Storage
- 14) Disposal of Waste
- 15) References

9.3 Specific Methods Used for Analysis

The analytical methods performed at FGL fall into three general categories: drinking waters, wastewaters, and solid waste / hazardous waste methods. These methods are listed in Table 9-1.

Section No: 9
Page: 3 of 13
Revision No: 2.0
Date: January 15, 1994

TABLE 9-1 Specific Analytical Drinking Water Methods

Parameter Organic Chemicals Trihalomethanes Volatile Organics EPA 501.2 EPA 502.2 GC/PID/Hall, purge & trap GC/ECD, micro extraction GC/ECD, mi	Parameter	Method	Description
Trihalomethanes Volatile Organics Dibromochloropropane (DBCP) and Ethylene dibromide (EDB) Chlorinated Pesticides Nitrogen/phosphorus Pesticides Chlorothalonil Chlorothalonil Chlorothalonil Chlorothalonil EPA 508 CC/ECD, liquid-liquid CC/ECD,	rarameter	Method	Description
Volatile Organics Dibromochloropropane (DBCP) and Ethylene dibromide (EDB) Chlorinated Pesticides Nitrogen/phosphorus Pesticides Chlorothalonii EPA 505 Chlorothalonii EPA 508 CC/ECD, micro extraction  RC/PD, liquid-liquid GC/ECD, liquid-liqui	Organic Chemicals		
Dibromochloropropane (DBCP) and Ethylene dibromide (EDB) Chlorinated Pesticides Nitrogen/phosphorus Pesticides Chlorothalonil EPA 507 CC/ECD, liquid-liquid Chlorothalonil EPA 508 CC/ECD, liquid-liquid CC/ECD, liquid-liqu			
And Ethylene dibromide (EDB) Chlorinated Pesticides Chlorinated Pesticides Chlorinated Pesticides Chlorothalonii Chlorothaloni	Volatile Organics	EPA 502.2	
Chlorinated Pesticides Nitrogen/phosphorus Pesticides Chlorothalonil PCB's as Decachlorobiphenyl Trihalomethane Form. Potential Herbicides Volatile Organics Diethylhexylphthalate Carbamates Carbamates Clyphosate (Roundup) EPA 547 EPA 548 EPA 551 EPA 552 GC/ECD, liquid-liquid GC/ECD, micro extraction GC/ECD, liquid-liquid Volatile Organics EPA 515.1 GC/ECD, liquid-liquid GC/ECD, liquid-liquid Volatile Organics EPA 525 GC/MS, SPE GC/MS, S	Dibromochloropropane (DBCP)	EPA 504	GC/ECD, micro extraction
Nitrogen/phosphorus Pesticides Chlorothalonii CPA 508 CC/ECD, liquid-liquid CC/ECD, ilquid-liquid CC/ECD, ilquid-liquid Trihalomethane Form. Potential Herbicides EPA 510 CC/ECD, micro extraction GC/ECD, liquid-liquid GC/ECD, micro extraction GC/ECD, liquid-liquid GC/ECD, micro extraction GC/ECD, liquid-liquid GC/ECD, liquid-liquid GC/ECD, liquid-liquid GC/ECD, liquid-liquid GC/ECD, micro extraction GC/ECD, liquid-liquid GC/ECD, liquid-liquid GC/ECD, liquid-liquid GC/ECD, liquid-liquid GC/ECD, liquid-liquid GC/ECD, micro extraction GC/ECD, liquid-liquid GC/ECD, micro extraction GC/ECD, liquid-liquid GC/ECD, liquid-liquid GC/ECD, liquid-liquid GC/ECD, micro extraction GC/ECD, liquid-liquid GC/ECD, micro extraction GC/ECD, liquid-liquid GC/ECD, micro extraction GC	and Ethylene dibromide (EDB)		
Chlorothalonii PCB's as Decachlorobiphenyl Trihalomethane Form. Potential Herbicides Volatile Organics Diethylhexylphthalate Carbamates Carbamate HPLC, post column derivatization MPLC, po	Chlorinated Pesticides		
PCB's as Decachlorobiphenyl Trihalomethane Form. Potential Herbicides Volatile Organics Diethylhexylphthalate Carbamates Glyphosate (Roundup) Endothall Paraquat and Diquat Polynuclear Aromatic Hydrocarbons Haloacetic Acids  General Inorganic Analyses Acidity Aggressive Index Alkalinity (CaCO3) Biochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbonate (CO3) Chlorine Residual (C12) Cyanide, Total (CN) EPA 300.1 EPA 300.1 EPA 300.2 EPA 300.2 EPA 300.4 Calculation Cyanide, Total (CN) EPA 300.4 EPA 300.4 Calculation Cyanide, Titration Cyanide, Total (CN) EPA 300.4 Carbon Dioxide (CO3) EPA 300.4 Colorimetric Chlorine Residual (C12) Chlorine Residual (C12) EPA 300.4 Cyanide, Total (CN) EPA 300.2 EPA 300.1 EPA 310.3 Calculation Cyanide, Total (CN) EPA 330.4 Chanical Coxygen Demand Color Cyanide, Total (CN) EPA 330.5 EPA 330.5 EPA 330.5 Colorimetric Chorimetric Chorime (F) EPA 330.5 Colorimetric Conductivity (EC) EPA 330.5 EPA 310.1 Titration Conductivity Bridge EPA 340.2 EPA 340.2 ISE Calculation Titration Calculation Calcu	Nitrogen/phosphorus Pesticides		
Trihalomethane Form. Potential Herbicides Volatile Organics Diethylhexylphthalate Carbamates Carbamates EPA 525 Carbamates Carbamates EPA 548 EPA 547 EPA 548 EPA 548 EPA 548 EPA 549 Polynuclear Aromatic Hydrocarbons Haloacetic Acids  General Inorganic Analyses Acidity Aggressive Index Alkalinity (CaCO3) Biochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbon Dioxide (CO3) Chlorine Residual (C12) Chlorine Residual (C12) Chlorine Residual (C12) Cyanide, Total (CN) EPA 300.1 EPA 330.2 EPA 330.2 EPA 330.2 EPA 330.3 EPA 330.4 Titration Calculation Calculation Colorine Cyanide, Total (CN) EPA 330.5 EPA 330.6 EPA 330.6 EPA 330.7 EPA 330.6 EPA 330.7 Carlon Demand Color Cyanide, Total (CN) EPA 330.7 EPA 330.7 EPA 330.7 EPA 330.7 EPA 330.7 EPA 330.7 Carlon Cyanide, Total (CN) EPA 330.7 EPA 330.7 EPA 330.7 EPA 330.7 EPA 330.7 Carlon Cyanide, Total (CN) EPA 330.7 EPA 330.7 EPA 330.7 EPA 330.7 Carlon Cyanide, Total (CN) EPA 330.7 EPA 330.7 EPA 330.7 EPA 330.7 EPA 330.7 Calculation Calculation Colorine Cyanide, Total (CN) EPA 330.7 EPA 330.7 EPA 330.7 EPA 330.7 EPA 330.7 Calculation Calcul			
Herbicides Volatile Organics Diethylhexylphthalate Carbamates Glyphosate (Roundup) EPA 547 EPA 531 EPA 548 EPA 549 FPILC, post column derivatization Folynuclear Aromatic Hydrocarbons Haloacetic Acids EPA 550.1 HPLC, post column derivatization EPA 549 FPA 550.1 HPLC, post column derivatization HPL			
Volatile Organics Diethylhexylphthalate EPA 525 GC/MS, purge & trap GC/MS, purge GC/MPLC, post column derivatization HPLC, post column derivatizat	Trihalomethane Form. Potential		
Diethylhexylphthalate Carbamates Carbamates Clyphosate (Roundup) EpA 547 EpA 548 EpA 548 EpA 549 Paraquat and Diquat Polynuclear Aromatic Hydrocarbons Haloacetic Acids EPA 550.1 EPA 550.1 EPA 552.1 EPA 552.1 EPA 552.1  General Inorganic Analyses Acidity Aggressive Index Alkalinity (CaCO3) Bicarbonate (HCO3) Biochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbonate (CO3) Chlorine Residual (Cl2) Chlorine Residual (Cl2) EPA 300.4 Chlorine Residual (Cl2) EPA 300.5 Cyanide, Total (CN) EPA 300.7 EPA 310.1 EPA 300.0 EPA 410.2 EPA 300.0 EPA 410.2 Colorimetric Chlorine Residual (Cl2) EPA 300.0 Chemical Oxygen Demand SM 409A Titration Cyanide, Total (CN) EPA 310.1 EPA 330.4 Titration Colorimetric Cyanide, Total (CN) EPA 330.5 EPA 330.5 EPA 330.4 Titration Colorimetric Cyanide, Total (CN) EPA 330.2 EPA 310.1 EPA 330.4 Titration Colorimetric Colorimetric Colorimetric Colorimetric Colorimetric Colorimetric Conductivity (EC) EPA 330.2 EPA 330.4 Titration Conductivity Bridge EPA 340.2 ISE Calculation Titration Coloructivity Bridge EPA 340.2 ISE Calculation Titration Calculation Titration Coloructivity Bridge EPA 340.2 ISE Calculation Titration Calculation Calculation Calculation	Herbicides		
Carbamates Glyphosate (Roundup) Endothall Endothall EPA 547 EPA 548 EPA 548 EPA 548 EPA 549 PPLC, post column derivatization Polynuclear Aromatic Hydrocarbons Haloacetic Acids EPA 550.1 EPA 550.1 EPA 552.1 EPA 552.1 General Inorganic Analyses Acidity Aggressive Index Alkalinity (CaCO3) Bicarbonate (HCO3) Bicarbonate (HCO3) EPA 310.1 EPA 310.1 Biration Biration Biration Biration Biration Biration Biration Carbon Dioxide (CO2) Carbonate (CO3) Carbonate (CO3) EPA 310.1 EPA 310.1 EPA 310.1 EPA 310.1 EPA 310.1 Carbon Dioxide (CO2) Carbonate (CO3) EPA 310.1 EPA 310.1 Carbonate (CO3) Carbonate (CO3) EPA 310.1 Chlorine Residual (C12) EPA 330.4 Chlorine Residual (C12) EPA 330.5 Colorimetric Chlorine Demand SM 409A Color Cyanide, Total (CN) EPA 335.2 Colorimetric Electrical Conductivity (EC) EPA 110.3 Cobservation Cyanide, Total (CN) EPA 330.2 EPA 340.2 EPA 340.2 EPA 340.2 EPA 340.2 EPA 340.1 Titration Conductivity Bridge Fluoride (F) EPA 340.2 EPA 340.1 Titration Calculation Titration Calculation Calculation Calculation Calculation Calculation			
Glyphosate (Roundup) Endothall EPA 548 EPA 548 EPA 549 HPLC, post column derivatization HPA 549 Paraquat and Diquat Polynuclear Aromatic Hydrocarbons Haloacetic Acids EPA 550.1 HPLC, post column derivatization HPLC, post column der			
Endothall Paraquat and Diquat Polynuclear Aromatic Hydrocarbons Haloacetic Acids  EPA 549 EPA 550.1 EPA 550.1 HPLC, post column derivatization HPLC, post column deri			
Paraquat and Diquat Polynuclear Aromatic Hydrocarbons Haloacetic Acids  General Inorganic Analyses Acidity Aggressive Index Alkalinity (CaCO3) Bicarbonate (HCO3) Biochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbonate (CO3) Chlorine Residual (CI2) Chlorine Residual (CI2) Chlorine Residual (CI2) Chlorine Demand Color Cyanide, Total (CN) EPA 310.1 EPA 310.1 EPA 300.0 EPA 310.1 EPA 300.0 EPA 310.1 Titration Color EPA 310.1 Titration Titration Color EPA 300.0 IC Colorimetric Colorimetric Chlorine Residual (CI2) Chlorine Residual (CI2) EPA 330.4 Titration Color EPA 310.5 Colorimetric Chlorine Demand Color EPA 310.1 Cyanide, Total (CN) EPA 335.2 Colorimetric Conductivity (EC) EPA 340.2 EPA 340.2 EPA 340.2 EPA 340.2 ISE Hardness, total (as CaCO3) Hydroxide (OH) EPA 310.1 Titration Calculation HPLC, post column derivatization FPA 310.1 Titration Calculation HPLC, post column derivatization HPLC, post column derivatization FPA 310.1 Titration Calculation HPLC, pos	• •		
Polynuclear Aromatic Hydrocarbons Haloacetic Acids  EPA 550.1 EPA 552.1  HPLC, post column derivatization HPLC, post column derivatization, SPE  General Inorganic Analyses Acidity			
Haloacetic Acids  EPA 552.1  HPLC, post column derivatization, SPE  General Inorganic Analyses Acidity Aggressive Index Alkalinity (CaCO3) Bicarbonate (HCO3) Bicochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbonate (CO3) Chemical Oxygen Demand (COD) Carbonate (CO3) Chloride (CI) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Demand Color Cyanide, Total (CN) EPA 300.2 EPA 300.4 EPA 300.0 IC Chloride (CI) EPA 300.0 IC Chlorine Residual (Cl2) EPA 300.0 IC Chlorine Residual (Cl2) EPA 300.0 Color EPA 300.0 Colorimetric Chlorine Demand Color EPA 110.3 Cobservation Cyanide, Total (CN) EPA 335.2 Colorimetric Electrical Conductivity (EC) EPA 120.1 Conductivity Bridge Fluoride (F) EPA 340.2 ISE Hardness, total (as CaCO3) Hydroxide (OH) EPA 310.1 Titration Calculation Titration Calculation Titration Calculation Titration Calculation Titration Calculation Titration Calculation Calculation			
General Inorganic Analyses Acidity EPA 305.1 Titration Aggressive Index N/A Calculation Alkalinity (CaCO3) EPA 310.1 Titration Bicarbonate (HCO3) EPA 310.1 Titration Biochemical Oxygen Demand (BOD5) EPA 405.1 ISE Bromide (Br) EPA 300.0 IC Carbon Dioxide (CO2) SM 4500CO2 Titration Carbonate (CO3) EPA 310.1 Titration Chemical Oxygen Demand (COD) EPA 410.2 Colorimetric Chloride (CI) EPA 300.0 IC Chlorine Residual (CI2) EPA 330.4 Titration Chlorine Residual (CI2) EPA 330.5 Colorimetric Chlorine Demand SM 409A Titration Color EPA 110.3 Observation Cyanide, Total (CN) EPA 335.2 Colorimetric Electrical Conductivity (EC) EPA 120.1 Conductivity Bridge Fluoride (F) EPA 340.2 ISE Hardness, total (as CaCO3) SM 2340B Calculation Hydroxide (OH) EPA 310.1 Titration Calculation Calculation Calculation			
General Inorganic Analyses Acidity Aggressive Index Alkalinity (CaCO3) Bicarbonate (HCO3) Biochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbon Dioxide (CO2) Carbonate (CO3) Chemical Oxygen Demand (COD) Chemical Oxygen Demand (COD) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Demand Color Cyanide, Total (CN) EPA 330.2 EPA 330.4 EPA 30.0 Cherical Conductivity (EC) EPA 330.5 Colorimetric Colorimetric Chloride (F) EPA 330.5 Colorimetric Cyanide, Total (CN) EPA 335.2 Colorimetric EPA 110.3 Conductivity Bridge Fluoride (F) EPA 340.2 EPA 310.1 Titration Calculation Hydroxide (OH) EPA 310.1 Titration Calculation Titration Calculation	Haloacetic Acids	EPA 552.1	
Acidity Aggressive Index Alkalinity (CaCO3) Bicarbonate (HCO3) Bicochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbon Dioxide (CO3) Chemical Oxygen Demand (COD) Chemical Oxygen Demand (COD) Chemical Oxygen Demand (COD) Chemical Oxygen Demand (COD) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Demand Color Cyanide, Total (CN) Electrical Conductivity (EC) Electrical Conductivity (EC) Flardness, total (as CaCO3) Hydroxide (OH) Langelier Index (corrosivity)  EPA 310.1 Titration Titration Color Color Conductivity Bridge Calculation Titration Calculation Titration Titration Calculation Titration Clarbon Titration Colorimetric Conductivity Bridge Calculation Titration Calculation Calculation			SPE
Acidity Aggressive Index Alkalinity (CaCO3) Bicarbonate (HCO3) Bicochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbon Dioxide (CO3) Chemical Oxygen Demand (COD) Chemical Oxygen Demand (COD) Chemical Oxygen Demand (COD) Chemical Oxygen Demand (COD) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Demand Color Cyanide, Total (CN) Electrical Conductivity (EC) Electrical Conductivity (EC) Flardness, total (as CaCO3) Hydroxide (OH) Langelier Index (corrosivity)  EPA 310.1 Titration Titration Color Color Conductivity Bridge Calculation Titration Calculation Titration Titration Calculation Titration Clar Titration Color Carbon Dioxide (CO2) EPA 310.1 Titration Colorimetric Conductivity Bridge Calculation Titration Calculation Titration Calculation Calculation Titration Calculation Titration Calculation Titration Calculation Titration Calculation Calculation Titration Calculation Titration Calculation Titration Calculation Titration Calculation Calculation Titration Calculation Calculation Calculation Calculation	General Inorganic Analyses		
Aggressive Index Alkalinity (CaCO3) Bicarbonate (HCO3) Biochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbon Dioxide (CO3) EPA 310.1 EPA 300.0 Carbon Dioxide (CO2) Carbonate (CO3) Chemical Oxygen Demand (COD) EPA 310.1 Chemical Oxygen Demand (COD) EPA 410.2 Chlorine (Cl) Chlorine Residual (Cl2) Chlorine Residual (Cl2) EPA 330.4 Chlorine Residual (Cl2) EPA 330.5 Chlorine Demand Color Chlorine Demand Color EPA 110.3 Cyanide, Total (CN) EPA 335.2 Colorimetric Electrical Conductivity (EC) EPA 340.2 EPA 340.2 EPA 340.2 EPA 310.1 Titration Conductivity Bridge Fluoride (F) EPA 340.2 EPA 310.1 Titration Calculation Titration Calculation Titration Calculation Titration Calculation Calculation Calculation Calculation Calculation Calculation		EPA 305.1	Titration
Alkalinity (CaCO3) Bicarbonate (HCO3) Biochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbonate (CO3) Chemical Oxygen Demand (COD) Chemical Oxygen Demand (COD) Chemical Oxygen Demand (COD) Chloride (Cl) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Demand Color Cyanide, Total (CN) Electrical Conductivity (EC) Fluoride (F) Hardness, total (as CaCO3) Hydroxide (OH) Langelier Index (corrosivity)  EPA 310.1 Titration Citration Citration Citration Color metric Colorimetric Colorimetric Colorimetric Conductivity Bridge Calculation Titration Calculation Calculation Calculation Calculation			
Bicarbonate (HCO3) Biochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbonate (CO3) Chemical Oxygen Demand (COD) Chemical Oxygen Demand (COD) Chloride (Cl) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Demand Color Cyanide, Total (CN) Electrical Conductivity (EC) Fluoride (F) Hardness, total (as CaCO3) Hydroxide (OH) Langelier Index (corrosivity)  EPA 300.0 EPA 310.1 Titration Citration Color EPA 330.4 Titration Colorimetric Colorimetric Colorimetric Conductivity Bridge EPA 340.2 SM 2340B Calculation Calculation Calculation Calculation Calculation		EPA 310.1	
Biochemical Oxygen Demand (BOD5) Bromide (Br) Carbon Dioxide (CO2) Carbonate (CO3) Chemical Oxygen Demand (COD) Chemical Oxygen Demand (COD) Chloride (Cl) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Demand Color Cyanide, Total (CN) EPA 300.0 EPA 310.1 EPA 300.0 EPA 410.2 Colorimetric EPA 300.0 IC Chlorine Residual (Cl2) EPA 330.4 Titration Color EPA 330.5 Colorimetric Chlorine Demand SM 409A Citration Cyanide, Total (CN) EPA 335.2 Colorimetric Electrical Conductivity (EC) EPA 335.2 Colorimetric EPA 120.1 EPA 340.2 EPA 340.2 EPA 340.2 EPA 340.2 EPA 310.1 Titration Calculation Hydroxide (OH) EPA 310.1 Titration Calculation Calculation Calculation			Titration
Bromide (Br) Carbon Dioxide (CO2) Carbonate (CO3) Chemical Oxygen Demand (COD) Chloride (Cl) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Demand Color Cyanide, Total (CN) EPA 310.1 EPA 310.1 EPA 300.0 EPA 410.2 Colorimetric EPA 300.0 IC Colorimetric EPA 330.4 Titration Color EPA 330.5 Colorimetric Chlorine Demand SM 409A Color EPA 110.3 Cobservation Cyanide, Total (CN) EPA 335.2 Colorimetric Electrical Conductivity (EC) EPA 335.2 Colorimetric EPA 120.1 EPA 340.2 ISE Hardness, total (as CaCO3) Hydroxide (OH) EPA 310.1 Titration Calculation Langelier Index (corrosivity) SM 2330B Calculation		EPA 405.1	ISE
Carbon Dioxide (CO2) Carbonate (CO3) Chemical Oxygen Demand (COD) Chloride (Cl) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Demand Color Cyanide, Total (CN) Electrical Conductivity (EC) Electrical Conductivity (EC) Fluoride (F) Hardness, total (as CaCO3) Hydroxide (OH) Langelier Index (corrosivity)  SM 4500CO2 EPA 310.1 Titration Color EPA 410.2 EPA 300.0 IC Colorimetric Colorimetric Colorimetric EPA 330.5 Colorimetric Conductivity Bridge ISE Calculation Titration Calculation Calculation Calculation Calculation Calculation Calculation Calculation Calculation		EPA 300.0	IC
Carbonate (CO3) Chemical Oxygen Demand (COD) EPA 410.2 Chloride (Cl) EPA 300.0 Chlorine Residual (Cl2) EPA 330.4 Chlorine Residual (Cl2) EPA 330.5 Chlorine Demand Color Cyanide, Total (CN) Electrical Conductivity (EC) EPA 335.2 Electrical Conductivity (EC) EPA 340.2 Fluoride (F) Hardness, total (as CaCO3) Hydroxide (OH) Langelier Index (corrosivity)  EPA 310.1 EPA 310.1 Titration Colorimetric Conductivity Bridge EPA 340.2 ISE Calculation Titration Calculation Calculation Calculation		SM 4500CO2	Titration
Chemical Oxygen Demand (COD) Chloride (Cl) EPA 300.0 EPA 300.0 Chlorine Residual (Cl2) EPA 330.4 Chlorine Residual (Cl2) EPA 330.5 Chlorine Demand Color Cyanide, Total (CN) EPA 335.2 Electrical Conductivity (EC) Fluoride (F) Hardness, total (as CaCO3) Hydroxide (OH) Langelier Index (corrosivity) EPA 300.0 IC Colorimetric EPA 330.5 Colorimetric Colorimetric Conductivity Bridge EPA 340.2 ISE Calculation Titration Calculation Calculation Calculation Calculation		EPA 310.1	Titration
Chloride (Cl) Chlorine Residual (Cl2) Chlorine Residual (Cl2) Chlorine Residual (Cl2) EPA 330.4 Chlorine Residual (Cl2) EPA 330.5 Chlorine Demand Color Cyanide, Total (CN) EPA 335.2 Electrical Conductivity (EC) EPA 120.1 EPA 340.2 Fluoride (F) Hardness, total (as CaCO3) Hydroxide (OH) Langelier Index (corrosivity) EPA 340.0 EPA 310.1 EPA 310.1 Titration Calculation Calculation Calculation Calculation Calculation Calculation Calculation Calculation	Chemical Oxygen Demand (COD)	EPA 410.2	Colorimetric
Chlorine Residual (Cl2)  Chlorine Demand  Color  Cyanide, Total (CN)  Electrical Conductivity (EC)  Fluoride (F)  Hardness, total (as CaCO3)  Hydroxide (OH)  Langelier Index (corrosivity)  EPA 330.5  EPA 330.5  EPA 310.1  EPA 310.1  EPA 330.5  Colorimetric  Conductivity Bridge  EPA 340.2  ISE  Calculation  Titration  Calculation  Calculation		EPA 300.0	
Chlorine Demand  Color  Cyanide, Total (CN)  Electrical Conductivity (EC)  Fluoride (F)  Hardness, total (as CaCO3)  Hydroxide (OH)  Langelier Index (corrosivity)  SM 409A  Titration  Observation  Colorimetric  EPA 335.2  Colorimetric  Conductivity Bridge  ISE  Calculation  Titration  Calculation  Calculation	Chlorine Residual (Cl2)	EPA 330.4	Titration
Color Cyanide, Total (CN) EPA 335.2 Colorimetric Electrical Conductivity (EC) Fluoride (F) EPA 340.2 Calculation Calculation EPA 310.1 Calculation			
Cyanide, Total (CN) EPA 335.2 Colorimetric Electrical Conductivity (EC) EPA 120.1 Conductivity Bridge Fluoride (F) EPA 340.2 ISE Hardness, total (as CaCO3) SM 2340B Calculation Hydroxide (OH) EPA 310.1 Titration Langelier Index (corrosivity) SM 2330B Calculation			
Electrical Conductivity (EC) Fluoride (F) Hardness, total (as CaCO3) Hydroxide (OH) Langelier Index (corrosivity)  EPA 120.1 EPA 340.2 SM 2340B EPA 310.1 Calculation Titration Calculation			
Fluoride (F) EPA 340.2 ISE Hardness, total (as CaCO3) SM 2340B Calculation Hydroxide (OH) EPA 310.1 Titration Langelier Index (corrosivity) SM 2330B Calculation			
Hardness, total (as CaCO3) SM 2340B Calculation Hydroxide (OH) EPA 310.1 Titration Langelier Index (corrosivity) SM 2330B Calculation			
Hydroxide (OH) EPA 310.1 Titration Langelier Index (corrosivity) SM 2330B Calculation			
Langelier Index (corrosivity) SM 2330B Calculation			
MBAS EPA 425.1 Colorimetric			
	MBAS	EPA 425.1	Colorimetric

Section No: 9
Page: 4 of 13
Revision No: 2.0
Date: January 15, 1994

TABLE 9-1 Specific Analytical Drinking Water Methods

••••••••••••••••••••••••••••••••••••••		
Parameter	Method	Description
		-
General Inorganic Analyses continued		
Nitrogen		
Ammonia (NH3-N)	EPA 350.1	Colorimetric
Nitrate (NO3-N)	EPA 300.0	IC
Nitrite (NO2-N)	EPA 300.0	IC
Nitrate (NO3-N)	EPA 353.2	Colorimetric
Nitrite (NO2-N)	EPA 353.2	Colorimetric
Organic (TKN-NH3-N)	N/A	Calculation
Total (TKN+NO3-N+NO2-N)	N/A	Calculation
Total Kjeldahl	EPA 351.2	Colorimetric
Odor	EPA 140.1	Observation
Oil and Grease	EPA 413.1	Gravimetric
Oxygen, Dissolved (DO)	EPA 360.1	ISE
pH	EPA 150.1	ISE
Phenois	EPA 420.1	Colorimetric
	LI A 420.1	Color mietric
Phosphorous	EDA 200 0	IC
Phosphate (PO4-P)	EPA 300.0 EPA 300.0	IC IC
Phosphate-dissolved (PO4-P)		
Total (P)	EPA 365.4	Colorimetric
Total-dissolved (P)	EPA 365.4	Colorimetric
Resistivity	N/A	Calculation
Sodium Percent	N/A	Calculation
Sodium Absorption Ratio (SAR)	EPA 200.7	ICP
Solids/Residue		
Filterable (TDS)	EPA 160.1	Gravimetric
Non-filterable (TSS)	EPA 160.2	Gravimetric
Total	EPA 160.3	Gravimetric
Volatile	EPA 160.4	Gravimetric
Settleable	EPA 160.5	Gravimetric
Sulfate (SO4)	EPA 300.0	IC
Sulfide (H2S)		
Total	EPA 376.2	Methylene Blue
Dissolved	EPA 376.2	Methylene Blue
Sulfite (SO2)	EPA 377.1	Titrimetric
Tannin & Lignin	SM 5500B	Colorimetric
Titration - pH adjustment	N/A	Titration
Turbidity	EPA 180.1	Nephelometric
luibluity	EI A 100.1	replicionetric
Trace Metals Analyses		
Aluminum (Al)	EPA 200.9	Furnace Atomic Absorption
Aluminum (Al)	EPA 200.8	ICP/MS
	EPA 200.9	
Antimony (Sb)		Furnace Atomic Absorption ICP/MS
Antimony (Sb)	EPA 200.8	
Arsenic (As)	EPA 200.9	Furnace Atomic Absorption
Arsenic (As)	EPA 200.8	ICP/MS
Barium (Ba)	EPA 200.7	ICP
Barium (Ba)	EPA 200.8	ICP/MS
Beryllium (Be)	EPA 200.7	ICP

Section No: 9
Page: 5 of 13
Revision No: 2.0
Date: January 15, 1994

TABLE 9-1 Specific Analytical Drinking Water Methods

Parameter	Method	Description
Trace Metals Analyses continued		
Beryllium (Be)	EPA 200.8	ICP/MS
Boron (B)	EPA 200.7	ICP
Boron (B)	EPA 200.8	ICP/MS
Cadmium (Cd)	EPA 200.9	Furnace Atomic Absorption
Cadmium (Cd)	EPA 200.8	ICP/MS
Calcium (Ca)	EPA 200.7	ICP
Chromium (Cr)	EPA 200.9	Furnace Atomic Absorption
Chromium (Cr)	EPA 200.8	ICP/MS
Chromium VI (Cr+6)	EPA 7196	Colorimetric
Cobalt (Co)	EPA 200.7	ICP
Cobalt (Co)	EPA 200.8	ICP/MS
Copper (Cu)	EPA 200.7	ICP
Copper (Cu)	EPA 200.8	ICP/MS
Iron (Fe)	EPA 200.7	ICP
Lead (Pb)	EPA 200.9	
Lead (Pb)	EPA 200.8	Furnace Atomic Absorption ICP/MS
Lithium (Li)	SM 3500LiB	
Magnesium (Mg)	EPA 200.7	Flame Atomic Absorption ICP
Manganese (Mn)	EPA 200.7	ICP
Manganese (Mn)	EPA 200.7	ICP/MS
Mercury (Hg)	EPA 245.1	· · ·
Mercury (Hg)	EPA 245.2	Cold Vapor Atomic Absorption
Molybdenum (Mo)	EPA 200.7	Cold Vapor Atomic Absorption ICP
Molybdenum (Mo)	EPA 200.7	ICP/MS
Nickel (Ni)	EPA 200.7	ICP
Nickel (Ni)	EPA 200.7 EPA 200.8	ICP/MS
Potassium (K)	EPA 200.7	ICP/MS
Selenium (Se)	EPA 200.7 EPA 200.9	
Selenium (Se)	EPA 200.9 EPA 200.8	Furnace Atomic Absorption ICP/MS
Silica (SiO2)	EPA 200.7	ICP/MS
Silver (Ag)	EPA 200.7 EPA 200.9	
Silver (Ag)	EPA 200.9 EPA 200.8	Furnace Atomic Absorption
Sodium (Na)	EPA 200.5 EPA 200.7	ICP/MS
Thallium (Tl)	EPA 200.7 EPA 200.9	ICP
Thallium (TI)	EPA 200.9 EPA 200.8	Furnace Atomic Absorption
Tin (Sn)	EPA 200.8 EPA 200.9	ICP/MS
Vanadium (V)		Furnace Atomic Absorption
Vanadium (V)	EPA 200.7	ICP ICP/MS
Zinc (Zn)	EPA 200.8	ICP/MS
	EPA 200.7	ICP
Zinc (Zn)	EPA 200.7	ICP/MS

Section No: 9
Page: 6 of 13
Revision No: 2.0
Date: January 15, 1994

TABLE 9-1 Specific Analytical Drinking Water Methods

Parameter	Method	Description
Radiochemical Analyses		
Gross Alpha	EPA 900.0	Proportional Counter
Gross Beta	EPA 900.0	Proportional Counter
Gross Alpha & Beta	EPA 900.0	Proportional Counter
Total Radium*	EPA 900.1	Isolation, Proportional Counter
Uranium	EPA 908.0	Isolation, Proportional Counter
Tritium	EPA 906.0	Distillation, Liquid Scintillation
Radon	EPA 913.0	Liquid Scintillation
Bacteriological Analyses		
Total & Fecal Coliform	SM9221E	Fermentation, MPN, 10 tube
Total Coliform-Colilert	SM9221D	Presence-Absence
Standard Plate Count	SM9215B	Incubation, visual count

<sup>\*</sup> Can be reported as Radium 226 if less than 3 pCi/liter.

Section No: 9
Page: 7 of 13
Revision No: 2.0
Date: January 15, 1994

TABLE 9-2 Specific Analytical Wastewater / Hazardous Waste Liquid Methods

Parameter	Method	Description
Organic Chemical Analyses		
Sample Preparation	EPA 3510	Liquid-Liquid extraction
Sample Preparation	EPA 3520	Continous Liquid- Liquid
Extraction		<u> </u>
Sample Preparation	EPA 3580	Solvent Dilution
Purgeable Halocarbons	EPA 601/8010	GC/PID/Hall, purge & trap
EDB and DBCP	EPA 8011	GC/ECD, micro extraction
Non-Halogenated Volatile Organics	EPA 8015	GC/FID, purge & trap
	EPA 8015M	GC/FID, purge & trap
Total Petroleum Hydrocarbons	EI A OUISM	GC/FID, purge & trap
Purgeable Non-Hologopated Volatile Organies	EPA 8015M	GC/FID, micro extraction
Non-Halogenated Volatile Organics Extractable	EFA OUISM	GC/FID, micro extraction
	EPA 602/8020	CC/FID purge & trep
Aromatic Volatile Organics	EPA 604/8040	GC/FCD liquid liquid
Phenols Chlorinated Pesticides & PCB's		GC/ECD, liquid-liquid
<del>-</del>	EPA 608/8080	GC/ECD, liquid-liquid
Polynuclear Aromatic Hydrocarbons	EPA 610/8310	HPLC/UV, liquid- liquid
Organophosphorus Pesticides	EPA 614/8140	GC/FPD, liquid-liquid
Chlorinated Herbicides	EPA 615/8150	GC/ECD, liquid-liquid
Volatile Organics	EPA 624/8240	GC/MS, purge & trap
Semi-volatile Organics	EPA 625/8270	GC/MS, liquid-liquid
Carbamates	EPA 632	HPLC/UV, liquid-liquid
Total Organic Carbon	(TOC)	EPA415.1/9060 IR, combustion
Total Organic Halogens (TOX)	EPA 9020	Coulometric, Pyrolysis
Total Recov. Pet. Hydrocarbons	EPA 418.1	IR, liquid-liquid
General Inorganic Analyses		
Acidity	EPA 305.1	Titration
Aggressive Index	N/A	Calculation
Alkalinity (CaCO3)	EPA 310.1	Titration
Bicarbonate (HCO3)	EPA 310.1	Colorimetric
Biochemical Oxygen Demand (BOD5)	EPA 405.1	ISE
Bromide (Br)	EPA 300.0	IC
Carbonate (CO3)	EPA 310.1	Titration
Carbon Dioxide (CO2)	SM 4500CO2	Titration
Chemical Oxygen Demand (COD)	EPA 410.2	Colorimetric
Chloride (Cl)	EPA 300.0	IC
Chlorine Residual (Cl2)	EPA 330.2	Titration
Chlorine Residual (Cl2)	EPA 330.5	Colorimetric
Chlorine Demand	SM 409A	Titration
Color	EPA 110.3	Visual
Cyanide, Total (CN)	EPA 335.2	Colorimetric
Electrical Conductivity (EC)	EPA 120.1	Conductivity Bridge
Fluoride (F)	EPA 340.2	ISE
Hardness, total (as CaCO3)	EPA 130.2	Titration
Hydroxide (OH)	EPA 310.1	Titration
Langelier Index (corrosivity)	SM 2330B	Calculation
MBAS	EPA 425.1	Colorimetric
ITE AND LESS	LILI THU.I	COLOI MILELI IC

Section No: 9 Page: 8 of 13 Revision No: 2.0 Date: January 15, 1994

TABLE 9-2 Specific Analytical Wastewater / Hazardous Waste Liquid Methods

Nitrogen  Ammonia (NH3-N)  Nitrate (NO3-N)  Nitrite (NO2-N)  Organic (TKN-NH3-N)  Total (TKN+NO3-N+NO2-N)  Oil and Grease  Oxygen, Dissolved (DO)  Phenols  Phosphate (PO4-P)  Phosphate (PO4-P)  Phosphate (PO4-P)  Total (P)  Total (P)  Total (P)  Total (P)  Total (P)  Solids/Residue  Filterable (TDS)  Non-filterable (TSS)  EPA 350.1  EPA 350.0  EPA 350.0  EPA 351.2  Colorimetric	Parameter	Method	Description
Ammonia (NH3-N) EPA 350.1 Colorimetric Nitrate (NO3-N) EPA 300.0 IC Nitrite (NO2-N) EPA 300.0 IC Organic (TKN-NH3-N) Calculation Total (TKN+NO3-N+NO2-N) Calculation Total Kjeldahl EPA 351.2 Colorimetric Odor EPA 140.1 Observation Oil and Grease EPA 413.1 Gravimetric Oxygen, Dissolved (DO) EPA 360.1 ISE PH EPA 150.1 ISE Phenols EPA 420.1 Colorimetric Phosphorous Phosphate (PO4-P) EPA 300.0 IC Total (P) EPA 365.4 Colorimetric Total-dissolved (P) EPA 365.4 Colorimetric Resistivity N/A Calculation Sodium Percent N/A Calculation Sodium Absorption Ratio (SAR) EPA 200.7 ICP Solids/Residue Filterable (TDS) EPA 160.1 Gravimetric Non-filterable (TSS) EPA 160.2 Gravimetric			
Nitrate (NO3-N) Nitrite (NO2-N) Nitrite (NO2-N) Organic (TKN-NH3-N) Total (TKN+NO3-N+NO2-N) Total Kjeldahl Odor Oil and Grease Oxygen, Dissolved (DO) Phosphate (PO4-P) Phosphate -dissolved (PO4-P) Total (P) Total (P) Total (P) Total (P) Solids/Residue Filterable (TDS) Non-filterable (TDS) EPA 300.0 EPA 300.0 EPA 300.0 EPA 360.1 EPA 360.1 EPA 360.1 EPA 300.0 IC Colorimetric		FD 4 250 1	
Nitrite (NO2-N) Organic (TKN-NH3-N) Total (TKN+NO3-N+NO2-N) Total Kjeldahl Odor Oil and Grease Oxygen, Dissolved (DO) Phenols Phosphorous Phosphate (PO4-P) Phosphate-dissolved (PO4-P) Total (P) Total (P) Total-dissolved (P) Solids/Residue Filterable (TDS) Non-filterable (TSS)  EPA 300.0  EPA 300.0  EPA 360.1  EPA 360.1  EPA 360.1  EPA 420.1  Colorimetric			
Organic (TKN-NH3-N) Total (TKN+NO3-N+NO2-N) Total Kjeldahl  Odor  Oil and Grease  Oxygen, Dissolved (DO)  Phenols  Phenols  Phosphate (PO4-P)  Phosphate-dissolved (PO4-P)  Total (P)  Total (P)  Total-dissolved (P)  Resistivity  Sodium Percent  Solids/Residue  Filterable (TDS)  Non-filterable (TSS)  Calculation  Calculation  Calculation  Calculation  Colorimetric			
Total (TKN+NO3-N+NO2-N) Total Kjeldahl  Odor Oil and Grease Oxygen, Dissolved (DO) EPA 360.1 EPA 413.1 Gravimetric Oxygen, Dissolved (DO) EPA 360.1 EPA 150.1 EPA 420.1 Colorimetric Phosphorous Phosphate (PO4-P) Phosphate-dissolved (PO4-P) EPA 300.0 EPA 300.0 IC Total (P) EPA 365.4 Colorimetric Total-dissolved (P) EPA 365.4 Colorimetric Resistivity N/A Calculation Sodium Percent N/A Calculation Sodium Absorption Ratio (SAR) Solids/Residue Filterable (TDS) Non-filterable (TSS) EPA 160.1 Gravimetric Gravimetric Gravimetric Gravimetric Gravimetric Gravimetric Gravimetric Gravimetric			ic
Total Kjeldahl Odor EPA 140.1 Observation Oil and Grease EPA 413.1 Gravimetric Oxygen, Dissolved (DO) EPA 360.1 ISE  PH EPA 150.1 ISE Phenols Phosphorous Phosphate (PO4-P) Phosphate-dissolved (PO4-P) Total (P) Total-dissolved (P) EPA 365.4 Total-dissolved (P) EPA 365.4 Colorimetric Total-dissolved (P) EPA 365.4 Colorimetric Total-dissolved (P) EPA 365.4 Colorimetric Colorimetric Total-dissolved (P) EPA 365.4 Colorimetric Colorimetric EPA 365.4 Colorimetric Colorimetric EPA 365.4 Colorimetric EPA 365.4 Colorimetric Colorimetric EPA 365.4 Colorimetric Colorimetric EPA 365.4 Colorimetric EPA 365.4 Colorimetric EPA 365.4 Colorimetric Colorimetric EPA 365.4 Colorimetric EPA 366.2 EPA 366			*_
Odor Oil and Grease Oxygen, Dissolved (DO) EPA 360.1 EPA 360.1 EPA 150.1 EPA 150.1 EPA 420.1 Phenols Phosphorous Phosphate (PO4-P) Phosphate-dissolved (PO4-P) EPA 300.0 EPA 365.4 Colorimetric Total (P) EPA 365.4 Colorimetric EPA 365.4 Colorimetric Total-dissolved (P) EPA 365.4 Colorimetric Colorimetric Colorimetric Colorimetric Colorimetric EPA 365.4 Colorimetric EPA 365.4 Colorimetric Colorimetric EPA 365.4 Colorimetric Colorimetric EPA 365.4 Colorimetric EPA 365.4 Colorimetric Colorimetric EPA 365.4 Colorimetric EPA 365.4 Colorimetric Colorimetric EPA 365.4 Colorimetric EPA 366.1 EPA 366.2 Colorimetric EPA 366.2 EPA 366.2 Colorimetric EPA 366.2			Calanianatri
Oil and Grease Oxygen, Dissolved (DO) EPA 360.1 ISE  PH EPA 150.1 EPA 420.1 Colorimetric  Phosphorous Phosphate (PO4-P) Phosphate-dissolved (PO4-P) Total (P) Total-dissolved (P) EPA 365.4 EPA 365.4 Colorimetric  EPA 365.4 Colorimetric  Colorimetric  EPA 365.4 Colorimetric  Colorimetric  Colorimetric  Colorimetric  Colorimetric  Colorimetric  Colorimetric  Colorimetric  Colorimetric  EPA 365.4 Colorimetric  Colorimetric  Colorimetric  Colorimetric  EPA 365.4 Colorimetric  Colorimetric  Colorimetric  Colorimetric  Colorimetric  EPA 365.4 Colorimetric  Colorimetric  Colorimetric  Colorimetric  Colorimetric  EPA 365.4 Colorimetric	•		
Oxygen, Dissolved (DO)  PH  EPA 360.1  EPA 360.1  EPA 150.1  ISE  Phenols  Phosphorous  Phosphate (PO4-P)  Phosphate-dissolved (PO4-P)  Total (P)  Total-dissolved (P)  EPA 300.0  EPA 300.0  IC  Total-dissolved (P)  EPA 365.4  Colorimetric  Colorimetric  EPA 365.4  Colorimetric  Resistivity  N/A  Calculation  Sodium Percent  N/A  Sodium Percent  Sodium Absorption Ratio (SAR)  EPA 200.7  Solids/Residue  Filterable (TDS)  Non-filterable (TSS)  EPA 160.1  Gravimetric  Gravimetric  Gravimetric			
Phenols Phosphorous Phosphate (PO4-P) Phosphate-dissolved (PO4-P) Total (P) Total-dissolved (P) Resistivity Resistivity Sodium Percent Sodium Absorption Ratio (SAR) Filterable (TDS) Non-filterable (TSS)  EPA 150.1 EPA 300.0 IC EPA 300.0 IC EPA 365.4 Colorimetric Co			
Phenols Phosphorous Phosphate (PO4-P) Phosphate-dissolved (PO4-P) Total (P) Total-dissolved (P) EPA 365.4 EPA 365.4 Colorimetric EPA 365.4 Colorimetric EPA 365.4 Colorimetric EPA 365.4 Colorimetric Colorimetric EPA 365.4 EPA 200.7 EPA 365.4 Colorimetric EPA 365.4 EPA 365.4 EPA 365.4 Colorimetric EPA 365.4			
Phosphorous Phosphate (PO4-P) Phosphate-dissolved (PO4-P) Fotal (P) Fotal-dissolved (P) Ferror Solium Percent Sodium Absorption Ratio (SAR) Filterable (TDS) Non-filterable (TSS)  EPA 300.0 Ferror Solium Colorimetric Ferror Solium Colorimetric Ferror Solium Absorption Ratio (SAR) Ferror Solium Colorimetric Ferror Soli			
Phosphate (PO4-P) EPA 300.0 IC Phosphate-dissolved (PO4-P) EPA 300.0 IC Total (P) EPA 365.4 Colorimetric Total-dissolved (P) EPA 365.4 Colorimetric Resistivity N/A Calculation Sodium Percent N/A Calculation Sodium Absorption Ratio (SAR) EPA 200.7 ICP Solids/Residue Filterable (TDS) EPA 160.1 Gravimetric Non-filterable (TSS) EPA 160.2 Gravimetric		EFA 420.1	Color affett ic
Phosphate-dissolved (PO4-P) EPA 300.0 IC Total (P) EPA 365.4 Colorimetric Total-dissolved (P) EPA 365.4 Colorimetric Resistivity N/A Calculation Sodium Percent N/A Calculation Sodium Absorption Ratio (SAR) EPA 200.7 ICP Solids/Residue Filterable (TDS) EPA 160.1 Gravimetric Non-filterable (TSS) EPA 160.2 Gravimetric		FPA 300 0	IC
Total (P) EPA 365.4 Colorimetric Total-dissolved (P) EPA 365.4 Colorimetric Resistivity N/A Calculation Sodium Percent N/A Calculation Sodium Absorption Ratio (SAR) EPA 200.7 ICP Solids/Residue Filterable (TDS) EPA 160.1 Gravimetric Non-filterable (TSS) EPA 160.2 Gravimetric			
Total-dissolved (P)  Resistivity  Sodium Percent  Sodium Absorption Ratio (SAR)  Solids/Residue  Filterable (TDS)  Non-filterable (TSS)  EPA 365.4  N/A  Calculation  Calculat			
Resistivity Sodium Percent N/A Calculation			
Sodium Percent Sodium Absorption Ratio (SAR) Solids/Residue Filterable (TDS) Non-filterable (TSS)  N/A EPA 200.7 ICP  Solids/Residue EPA 160.1 Gravimetric Gravimetric Gravimetric	, <i>,</i>		
Sodium Absorption Ratio (SAR) EPA 200.7 ICP Solids/Residue Filterable (TDS) EPA 160.1 Gravimetric Non-filterable (TSS) EPA 160.2 Gravimetric			
Solids/Residue Filterable (TDS) Non-filterable (TSS)  EPA 160.1  Gravimetric  Gravimetric			
Filterable (TDS) EPA 160.1 Gravimetric Non-filterable (TSS) EPA 160.2 Gravimetric		2111 20017	101
Non-filterable (TSS) EPA 160.2 Gravimetric		EPA 160.1	Gravimetric
	, ,		
10tal EPA 100.3 Gravimetric	Total	EPA 160.3	Gravimetric
Volatile EPA 160.4 Gravimetric			
Settleable EPA 160.5 Gravimetric	Settleable		Gravimetric
Sulfate (SO4) EPA 300.0 IC	Sulfate (SO4)		IC
Sulfide (H2S)	Sulfide (H2S)		
Total EPA 376.2 Methylene Blue	Total		
Dissolved EPA 376.2 Methylene Blue	Dissolved		Methylene Blue
Sulfite (SO2) EPA 377.1 Titrimetric			
Tannin & Lignin SM 513 Colorimetric			
Titration - pH adjustment N/A Titration			
Turbidity EPA 180.1 Nephelometric	Turbidity	EPA 180.1	Nephelometric
Trace Metals Analyses	Trace Metals Analyses		
Sample Preparation EPA 3015 Digestion		EPA 3015	Digestion
Aluminum (Al) EPA 200.9 Furnace Atomic Absorption			
Aluminum (Al) EPA 200.8 ICP/MS			
Antimony (Sb) EPA 200.9 Furnace Atomic Absorption	Antimony (Sb)	EPA 200.9	Furnace Atomic Absorption
Antimony (Sb) EPA 200.8 ICP/MS		EPA 200.8	
Arsenic (As) EPA 200.9 Furnace Atomic Absorption		EPA 200.9	Furnace Atomic Absorption
Arsenic (As) EPA 200.8 ICP/MS	Arsenic (As)	EPA 200.8	ICP/MS
Barium (Ba) EPA 200.7 ICP	Barium (Ba)		
Barium (Ba) EPA 200.8 ICP/MS			
Beryllium (Be) EPA 200.7 ICP			
Beryllium (Be) EPA 200.8 ICP/MS	Beryllium (Be)	EPA 200.8	ICP/MS

Section No: 9 Page: 9 of 13 Revision No: 2.0 Date: January 15, 1994

TABLE 9-2 Specific Analytical Wastewater / Hazardous Waste Liquid Methods

Parameter	Method	Description
Trace Metals Analyses continued		
Boron (B)	EPA 200.7	ICP
Boron (B)	EPA 200.8	ICP/MS
Cadmium (Cd)	EPA 200.9	Furnace Atomic Absorption
Cadmium (Cd)	EPA 200.8	ICP/MS
Calcium (Ca)	EPA 200.7	ICP
Chromium (Cr)	EPA 200.9	Furnace Atomic Absorption
Chromium (Cr)	EPA 200.8	ICP/MS
Chromium VI (Cr+6)	EPA 7196	Colorimetric
Cobalt (Co)	EPA 200.7	ICP
Cobalt (Co)	EPA 200.8	ICP/MS
Copper (Cu)	EPA 200.7	ICP
Copper (Cu)	EPA 200.8	ICP/MS
Gold (Au)	EPA 231.1	Flame Atomic Absorption
	EPA 200.7	ICP
Iron (Fe) Lead (Pb)	EPA 200.7 EPA 200.9	
Lead (Pb)	EPA 200.9	Furnace Atomic Absorption ICP/MS
	SM 3500LiB	Flame Atomic Absorption
Lithium (Li)	EPA 200.7	ICP
Magnesium (Mg)	EPA 200.7 EPA 200.7	ICP
Manganese (Mn)	EPA 200.7 EPA 200.8	ICP ICP/MS
Manganese (Mn)		
Mercury (Hg)	EPA 245.1 EPA 245.2	Cold Vapor Atomic Absorption
Mercury (Hg)		Cold Vapor Atomic Absorption
Molybdenum (Mo)	EPA 200.7	ICP ICP AIS
Molybdenum (Mo)	EPA 200.8	ICP/MS
Nickel (Ni)	EPA 200.7	ICP ICP/MS
Nickel (Ni)	EPA 200.8	ICP/MS
Potassium (K)	EPA 200.7	ICP
Selenium (Se)	EPA 200.9	Furnace Atomic Absorption
Selenium (Se)	EPA 200.8	ICP/MS
Silica (SiO2)	EPA 200.7	ICP
Silver (Ag)	EPA 200.9	Furnace Atomic Absorption
Silver (Ag)	EPA 200.8	ICP/MS
Sodium (Na)	EPA 200.7	ICP
Strontium (Sr)	EPA 200.7	ICP
Thallium (TI)	EPA 200.9	Furnace Atomic Absorption
Thallium (Tl)	EPA 200.8	ICP/MS
Tin (Sn)	EPA 200.9	Furn ace Atomic Absorption
Titanium (Ti)	EPA 200.7	ICP
Uranium (U)	EPA 200.7	I CP
Vanadium (V)	EPA 200.7	ICP
Zinc (Zn)	EPA 200.7	ICP
Zinc (Zn)	EPA 200.7	ICP/MS

Section No: 9
Page: 10 of 13
Revision No: 2.0
Date: January 15, 1994

TABLE 9-2 Specific Analytical Wastewater / Hazardous Waste Liquid Methods

Parameter	Method	Description
Radio Chemical Analyses		
Gross Alpha	EPA 900.0	Proportional counter
Gross Beta	EPA 900.0	Proportional counter
Gross Alpha & Beta	EPA 900.0	Proportional counter
Total Radium*	EPA 900.1	Isolation, proportional counter
Uranium	EPA 908.0	Isolation, proportional counter
Tritium	EPA 906.0	Disti llation, liquid scintillation
Radon	EPA 913.0	Liquid scintillation
Bacteriological Analyses		
Total Coliform	SM9221E	Fermentation, MPN, 15 tube
Total & Fecal Coliform	SM9221E	Fermentation, MPN, 15 tube
Standard Plate Count	SM9215B	Incubation, visual count

<sup>\*</sup> Can be reported as Radium 226 if less than 3 pCi/liter.

Section No: 9
Page: 11 of 13
Revision No: 2.0
Date: January 15, 1994

TABLE 9-3 Specific Analytical Solid Waste / Hazardous Waste Methods

•		
Parameter	Method	Description
Organic Chemical Analyses		
	Title 22	Extraction
Sample Preparation - STLC		Extraction
Sample Preparation - EP TOX	EPA 1310	— •- • · · · · · · · · · · · · · · · · ·
Sample Preparation - TCLP	EPA 1311	Extraction
Sample Preparation	EPA 3510	Liquid-Liquid extraction
Sample Preparation	EPA 3520	Continous Liquid- Liquid
Extraction		•
Sample Preparation	EPA 3540	Soxhlet Extraction
Sample Preparation	EPA 3550	Sonication Extraction
Sample Preparation	EPA 3580	Solvent Dilution
Purgeable Halocarbons	EPA 8010	GC/PID/Hall, purge & trap
EDB and DBCP	EPA 8011	GC/ECD, micro extraction
Non-Halogenated Volatile Organics	EPA 8015	GC/FID, purge & trap
Total Petroleum Hydrocarbons	EPA 8015M	GC/FID, purge & trap
	EI A OUISM	Gen in, purge a trup
Purgeable	EPA 8015M	GC/FID, micro extraction
Total Petroleum Hydrocarbons	EFA OUISM	GC/FID, micro extraction
Extractable	ED 4 0000	CC/ETD
Aromatic Volatile Organics	EPA 8020	GC/FID, purge & trap
Phenois	EPA 8040	GC/CED, soxhlet or sonication
Chlorinated Pesticides & PCB's	EPA 8080	GC/ECD, soxhlet or sonication
Polynuclear Aromatic Hydrocarbons	EPA 8100	GC/PID, soxhlet or sonication
Organophosphorus Pesticides	EPA 8141	GC/FPD, soxhlet or sonication
Chlorinated Phenoxy Herbicides	EPA 8150	GC/ECD, soxhlet or sonication
Volatile Organics	EPA 8240	GC/MS, purge & trap
Semi-volatile Organics	EPA 8270	GC/MS, soxhlet or sonication
Polynuclear Aromatic Hydrocarbons	EPA 8310	HPLC/ÚV, liquid- liquid
Carbamates	EPA 632	HPLC/UV, liquid- liquid
Total Organic Carbon (TOC)	EPA 9060	IR, combustion
Total Organic Carbon (10C)  Total Organic Halogens (TOX)	EPA 9020	Coulometric, Pyrolysis
Total Recov. Pet. Hydrocarbons	EPA 418.1	IR, liquid-liquid
Total Recov. Fet. Hydrocarbons	EFA 410.1	ix, ilquid-ilquid
General Inorganic Analyses		
	EPA 9056	IC
Chloride (Cl)		Conductivity bridge
Electrical Conductivity	EPA 120.1	
Cyanide, total (CN)	EPA 335.2	Distillation- Colorimetric
Fluoride (F)	EPA 340.1	Distillation-ISE
Moisture	ASA/UL	Gravimetric
Nitrogen	77	
Ammonia (NH3-N)	EPA 350.1	Colorimetric
Nitrate (NO3-N)	EPA 9056	IC
Nitrite (NO2-N)	EPA 9056	IC
Organic (TKN-NH3-N)	N/A	Calcul ation
Total (TKN+NO3-N+NO2-N)	N/A	Calcul ation
Total Kjeldahl	EPA 351.1	Colorimetric
Oil and grease		
Soxhlet	EPA 413.1M	Gravimetric
COMMICE	~ 11 -110+11/1	O. H. HILLOUIC

Section No: 9
Page: 12 of 13
Revision No: 2.0
Date: January 15, 1994

TABLE 9-3 Specific Analytical Solid Waste / Hazardous Waste Methods

Parameter	Method	Description
General Inorganic Analyses continued pH	EPA 9045	ISE
Phosphorous Phosphate (PO4)	EPA 9056 See Trace Metals	IC
Total (P) Sulfate (SO4)	EPA 9056	IC
Sulfide (H2S)	EPA 376.2	Colorimetric
Hazardous Waste Characterization Ana Corrosivity (pH)	lyses	
Aqueous sample	EPA 9040	ISE
Nonaqueous sample Ignitability	EPA 9045	ISE
Aqueous (Flashpoint)	EPA 1010	Flashpoint
Nonaqueous (Flammability)	EPA 1020	Flashpoint
Reactivity Reaction with water	SW-846 Ch 8	Observations
Reaction with dilute acid		
Reaction with dilute base		
Reaction with oxidizing agent Reaction with reducing agent		
Generation	SW-846 Ch 7	Screens
Sulfide		33.33.2
Cyanide		
Trace Metals		
Sample Preparation - TTLC	EPA 3050	Digestion
Sample Preparation - STLC Sample Preparation - EP TOX	Title 22 EPA 1310	Extraction Extraction
Sample Preparation - TCLP	EPA 1311	Extraction
Aluminum (Al)	EPA 6010	ICP
Aluminum (Al)	EPA 6020	ICP/MS
Antimony (Sb)	EPA 7041	Furnace Atomic Absorption
Antimony (Sb)	EPA 6020	ICP/MS
Arsenic (As) Arsenic (As)	EPA 7060 EPA 6020	Furnace Atomic Absorption ICP/MS
Barium (Ba)	EPA 6010	ICP
Barium (Ba)	EPA 6020	ICP/MS
Beryllium (Be)	EPA 6010	ICP
Beryllium (Be)	EPA 6020	ICP/MS
Boron (B)	EPA 6010 EPA 6020	ICP ICP/MS
Boron (B) Cadmium (Cd)	EPA 6010	ICP/MS
Cadmium (Cd)	EPA 6020	ICP/MS
Calcium (Ca)	EPA 6010	ICP
Chromium (Cr)	EPA 6010	ICP
Chromium (Cr)	EPA 6010	ICP/MS
Chromium VI (Cr+6)	EPA 7196	Colorimetric

Section No: 9
Page: 13 of 13
Revision No: 2.0
Date: January 15, 1994

TABLE 9-3 Specific Analytical Solid Waste / Hazardous Waste Methods

Parameter	Method	Description
Trace Metals Analyses continued		
Cobalt (Co)	EPA 6010	ICP
Cobalt (Co)	EPA 6020	ICP/MS
Copper (Cu)	EPA 6010	ICP
Copper (Cu)	EPA 6020	ICP/MS
Gold (Au)	EPA 231.1	Flame Atomic Absorption
Iron (Fe)	EPA 6010	ICP
Lead (Pb)	EPA 7420	Flame Atomic Absorption
Lead (Pb)	EPA 6020	ICP/MS
Lithium (Li)	EPA 7430	Flame Atomic Absorption
Magnesium (Mg)	EPA 6010	ICP
Manganese (Mn)	EPA 6010	ICP
Manganese (Mn)	EPA 6020	ICP/MS
Mercury (Hg)	EPA 7470	Cold Vapor Atomic Absorption
Molybdenum (Mo)	EPA 6010	ICP
Molybdenum (Mo)	EPA 6020	ICP/MS
Nickel (Ni)	EPA 6010	ICP
Nickel (Ni)	EPA 6020	ICP/MS
Phosphorous (P)	EPA 6010	ICP
Potassium (K)	EPA 6010	ICP
Selenium (Se)	EPA 7741	Furnace Atomic Absorption
Selenium (Se)	EPA 6020	ICP/MS
Silver (Ag)	EPA 6010	ICP
Silver (Ag)	EPA 6020	ICP/MS
Sodium (Na)	EPA 6010	ICP
Strontium (Sr)	EPA 6010	ICP
Thallium (Tl)	EPA 7841	Furnace Atomic Absorption
Thallium (Tl)	EPA 6020	ICP/MS
Tin (Sn)	EPA 6010	ICP
Titanium (Ti)	EPA 6010	ICP
Uranium (U)	EPA 6010	ICP
Vanadium (V)	EPA 6010	ICP
Zinc (Zn)	EPA 6010	ICP
Zinc (Zn)	EPA 6020	ICP/MS
Radio Chemical Analyses		
Gross Alpha	EPA 900.0	Proportional counter
Gross Beta	EPA 900.0	Proportional counter
Gross Alpha & Beta	EPA 900.0	Proportional counter
Total Radium*	EPA 900.1	Isolation, proportional counter
Uranium	EPA 908.0	Isolation, proportional counter
Tritium	EPA 906.0	Distillation, liquid scintillation
Radon	EPA 913.0	Liquid scintillation

<sup>\*</sup> Can be reported as Radium 226 if less than 3 pCi/liter.

- -	
	f
	; ;
	4.
	•
	<b>1</b>
	<b>k</b> is
	<b>p</b> *
	; No
	大
	<b>#</b>
	, 4 1
	,
	N ·
	) 
	( see
	; . ;
	÷.

Section No: 10 Page: 1 of 2 Revision No: 2.0 Date: January 15, 1994

## Data Reduction, Validation, and Reporting

The process of transforming raw analytical data into a finished report involves steps which are generally grouped into the categories of data reduction, data validation, and reporting. It involves mathematical modeling of the standard calibration curves, statistical analysis of the acquired data, calculations to account for preparation steps and dilutions, verification of adherence to quality assurance procedures, and the generation of hardcopy output.

#### 10.1 Data Reduction

At FGL Environmental the analyst has the primary responsibility for reducing raw data. This process consists primarily of converting raw data into final reportable values by comparing individual sample results against those obtained for calibration purposes then accounting for any dilutions or concentration.

For each method, all raw data results are recorded on method specific forms or in a standardized output from each of the various instruments. Details on procedures for data reduction may be found in the laboratory SOP for each method.

#### 10.2 Data Validation

Upon completion of each analytical run, the analyst enters or transfers the data to LIMS. The analytical raw data and LIMS generated QC summary sheets are validated by the laboratory supervisor or a backup peer analyst. They verify that all quality control parameters fall within acceptance limits and also review the analytical data for calculation errors and inconsistencies.

#### 10.3 Data Review Policy

The raw data review includes all documentation associated with the samples, including chromatograms, instrument run logs, digestion logs, and other instrument printouts. Upon approval by the analyst or supervisor, the analytical results for the run are transferred to a results database for compiling with other data for that sample. When all results for a sample have been entered, an on screen report is generated for review and validation by the supervisor. Upon approval by the supervisor sample reports are then released for final hardcopy reporting, which is forwarded to the client.

#### Data review includes the following:

- 1) All data packages are reviewed by a second analyst or the supervisor. The QC batch report and analytical run sheets (if applicable) must be signed by the reviewer.
- 2) All supervisors must review the data released for reporting.
- 3) Analysis reports are printed and again reviewed by the supervisor and lab director and signed by each upon approval.
- 4) Quality Control reports are printed and are reviewed and signed by the quality assurance director or officer.

Section No: 10
Page: 2 of 2
Revision No: 2.0
Date: January 15, 1994

## Data Reduction, Validation and Reporting

10.4 Data Reporting

Having received approval, the hardcopy report is then generated. Quality assurance reports are also generated at this step. Again, the final reports are reviewed before signing by both the department supervisor and laboratory director. Invoices are also reviewed and initialed by the department supervisor.

10.5 Data Storage

FGL Environmental maintains report files and the supporting raw data for the current and previous year on the premises. Reports and raw data are maintained for a total of ten years in the secured data storage facility.

Section No: 11 Revision No: 2.0 Date: January 15, 1994

Page: 1 of 18

## **Internal Quality Control**

An internal quality control program requires a set of routine internal procedures for assuring that the data generated from a measurement system meets prescribed criteria for data quality. An effective internal QC program must be capable of measuring and controlling the quality of the data, in terms of precision, accuracy, and completeness (see sections 5 and 14 for these details).

This section identifies QC protocols associated with analytical procedures. Table 11-1 is a general outline of quality control parameters monitored for each procedure. Included are general quality control measures as well as specific quality control checks which provide continual control and assessment of data quality. Figures 11-1 through 11-3 are examples of FGL Control Charts.

FGL uses continuing calibration verifications (CCV) and initial calibration verification (ICV) for instrument quality control. The laboratory control sample (LCS) is used for sample preparation quality control. The CCV standard only verifies continuing calibration. The ICV standard is used to independently verify the calibration and may take the place of CCV when used on a continuing basis during analysis. The LCS may take the place of both ICV and CCV when prepared independently and used on a continuing basis during analysis.

#### 11.1 Quality Control Parameters

#### 11.1.1 Initial Demonstration of Capability

Before analyzing samples, the laboratory must prove proficiency in the method by preparing a data package for certification. The laboratory normally provides the following information:

- 1) calibration data
- 2) calibration verification from an independent source
- 3) method detection limit data
- 4) detection limit verification data
- 5) accuracy and precision data

These must all be acceptable under the method QC criteria or, when requirements are not specified, reasonably meet good laboratory practices and Department of Health Services requirements.

#### 11.1.2 Analysis Quality Controls

#### 11.1.2.1 Instrument Blank

The instrument or calibration blank is used to calibrate the instrument. This blank contains the same reagents used in the standards and samples. However, the blank is prepared under controlled conditions and is not processed like all samples.

#### 11.1.2.2 Detection Limit Standard (DLS)

Normally, method detection limits (MDLs) are performed on an annual basis. However, this doesn't adequately reflect the day-to-day variations in the analysis. FGL has taken a different approach. We perform what we call detection limit standards on a daily basis. This gives more "representative" method detection limits. Tracking the DLS using our LIMS allows us to monitor instrument and method performance. Historically, we can also prove what our MDL was at a particular time.

Section No: 11 Revision No: 2.0 Date: January 15, 1994

Page: 2 of 18

## **Internal Quality Control**

#### 11.1.2.3 Initial Calibration Verification (ICV)

ICV is used as an independent verification of the calibration. EPA protocol recommends analysis of ICV for each analytical calibration. ICV samples are manufacturer or laboratory prepared from independent suitable reference standards. The ICV usually contains the analytes of interest at a concentration in the mid-calibration range. Method specific acceptance criteria are used when possible. When method specific criteria are unavailable, the recoveries are control charted to obtain acceptance limits.

### 11.1.2.4 Continuing Calibration Verification (CCV)

CCV is used to verify continuing calibration. Many EPA methods require analysis of CCV's on a per batch or per day basis. CCV samples are manufacturer or laboratory prepared from suitable reference standards. This standard may or may not be independent of the calibration stock standards. The CCV usually contains the analytes of interest at a concentration in the mid-calibration range. Method specific acceptance criteria are used when possible. When method specific criteria are unavailable the recoveries are control charted to obtain acceptance limits.

#### 11.1.2.5 Internal Standards (IS)

An IS is a synthetic compound not occurring in an environmental sample but has chemical behavior similar to that of the target analytes. EPA protocol requires IS for specific methods on a per sample basis (including QC samples). The IS serves as a check on the analysis and corrects for instrumental drift or matrix effects. Method specific acceptance criteria are used when possible. When method specific criteria are unavailable the recoveries are control charted to obtain acceptance limits.

#### 11.1.3 Method Quality Controls

#### 11.1.3.1 Method Blank

The method blank is used to ensure that any positive results were not because of reagent or labware contamination. Before analyzing any samples, the analyst must demonstrate through the analysis of a method blank, that all glassware and reagents are free of contaminants. Each time a set of samples is extracted, a method blank must be processed to check for laboratory contamination. The blank samples should be carried through all stages of the sample preparation and analysis. Lack of contamination is demonstrated if all target analytes with the exception of common laboratory reagents are below their DLRs.

#### 11.1.3.2 Laboratory Control Sample (LCS)

The LCS is used to verify overall accuracy of the method. EPA protocol requires analysis of an LCS for each analytical batch when appropriate. The LCS consists of either a control matrix spiked with analytes representative of the target analytes or a certified reference material. Whenever possible, the LCS contains the analyte of interest at a concentration in the mid-calibration range. This standard may or may not be independent of the calibration stock standards. Initially method specific acceptance criteria are used. Eventually, or when method specific criteria are unavailable, the recoveries are control charted to obtain acceptance limits.

Section No: 11 Revision No: 2.0 Date: January 15, 1994

Page: 3 of 18

## **Internal Quality Control**

#### 11.1.3.3 Surrogate Spikes

Surrogate spikes serve as a check on the extraction process where extraction is a necessary part of the analytical procedure. When surrogate recovery is within limits it indicates that the extraction was complete. A surrogate is a compound not expected to occur in an environmental sample but has chemical behavior similar to that of the target analytes. EPA protocol requires surrogate spikes for specific methods on a per sample basis (including QC samples). Initially method specific acceptance criteria are used. Eventually, or when method specific criteria are unavailable, the recoveries are control charted to obtain acceptance limits.

#### 11.1.3.4 Matrix Spike/Matrix Spike Duplicates (MS/MSD)

The MS/MSD is used to verify matrix specific precision and accuracy. EPA protocol normally requires analysis of MS/MSD samples for each analytical batch or matrix type. The MS/MSD spikes are manufacturer or laboratory prepared from suitable reference standards. This standard may or may not be independent of the calibration stock standards. The matrix spike recovery and relative percent difference (RPD) acceptance criteria are shown in Section 5. When matrix spike results fall outside limits published in the respective methods, The LCS is used to verify method control. If spike recoveries are outside normal limits due to matrix problems, the data should be reported noting matrix interference. The spike recovery and RPD acceptance limits are test specific and are control charted.

## 11.1.3.5 Duplicates

Duplicates are used to verify matrix specific precision. EPA protocol normally requires analysis of duplicate samples for each analytical batch or matrix type. The relative percent difference (RPD) calculated from duplicate analyses provide an assessment of precision. The RPD acceptance limits are test specific and are control charted.

#### 11.1.4 Radiochemical Specific Quality Controls

#### 11.1.4.1 Efficiency vs. Dissolved Solids Chart

Dissolved solids mask or decrease the radiation picked up by the counting wire. For each instrument an efficiency vs. solids chart must be generated as part of the initial demonstration of capability. In addition, whenever an instrument is maintained or repaired (i.e. a counting wire replaced) a new efficiency vs. solids charge must be generated. Samples containing solids such that the efficiency of counting drops below ten percent must be reset using a smaller aliquot so that the solids give acceptable counting efficiency. Prior to setting up a sample, an electrical conductivity measurement must be made for estimation of total dissolved solids.

#### 11.1.4.2 Background

Background samples are run daily, prior to sample analysis. However, a weekly average may be used for calculation purposes.

Section No: 11 Page No: 1 of 18 Revision No: 2.0

Date: January 15, 1994

## **Internal Quality Control Checks**

An internal quality control program requires a set of routine internal procedures for assuring that the data generated from a measurement system meets prescribed criteria for data quality. An effective internal QC program must be capable of measuring and controlling the quality of the data, in terms of precision, accuracy, and completeness (see sections 5 and 14 for these details).

This section identifies QC protocols associated with analytical procedures. Table 11-1 is a general outline of quality control parameters monitored for each procedure. Included are general quality control measures as well as specific quality control checks which provide continual control and assessment of data quality. Figures 11-1 through 11-3 are examples of FGL Control Charts.

FGL uses continuing calibration verifications (CCV) and initial calibration verification (ICV) for instrument quality control. The laboratory control sample (LCS) is used for sample preparation quality control. The CCV standard only verifies continuing calibration. The ICV standard is used to independently verify the calibration and may take the place of CCV when used on a continuing basis during analysis. The LCS may take the place of both ICV and CCV when prepared independently and used on a continuing basis during analysis.

#### 11.1 Quality Control Parameters

#### 11.1.1 Initial Demonstration of Capability

Before analyzing samples, the laboratory must prove proficiency in the method by preparing a data package for certification. The laboratory normally provides the following information:

- 1) calibration data
- 2) calibration verification from an independent source
- 3) method detection limit data
- 4) detection limit verification data
- 5) accuracy and precision data

These must all be acceptable under the method QC criteria or, when requirements are not specified, reasonably meet good laboratory practices and Department of Health Services requirements.

#### 11.1.2 Analysis Quality Controls

#### 11.1.2.1 Instrument Blank

The instrument or calibration blank is used to calibrate the instrument. This blank contains the same reagents used in the standards and samples. However, the blank is prepared under controlled conditions and is not processed like all samples.

#### 11.1.2.2 Detection Limit Standard (DLS)

Normally, method detection limits (MDLs) are performed on an annual basis. However, this doesn't adequately reflect the day-to-day variations in the analysis. FGL has taken a different approach. We perform what we call detection limit standards on a daily basis. This gives more "representative" method detection limits. Tracking the DLS using our LIMS allows us to monitor instrument and method performance. Historically, we can also prove what our MDL was at a particular time. The standard should be 3-10 times the MDL and may or may not be prepared independently of the calibration standards.

Section No: 11
Page No: 2 of 18
Revision No: 2.0
Date: January 15, 1994

## **Internal Quality Control Checks**

#### 11.1.2.3 Initial Calibration Verification (ICV)

ICV is used as an independent verification of the calibration. EPA protocol recommends analysis of ICV for each analytical calibration. ICV samples are manufacturer or laboratory prepared from independent suitable reference standards. The ICV usually contains the analytes of interest at a concentration in the mid-calibration range. Method specific acceptance criteria are used when possible. When method specific criteria are unavailable, the recoveries are control charted to obtain acceptance limits.

#### 11.1.2.4 Continuing Calibration Verification (CCV)

CCV is used to verify continuing calibration. Many EPA methods require analysis of CCV's on a per batch or per day basis. CCV samples are manufacturer or laboratory prepared from suitable reference standards. This standard may or may not be independent of the calibration stock standards. The CCV usually contains the analytes of interest at a concentration in the mid-calibration range. Method specific acceptance criteria are used when possible. When method specific criteria are unavailable the recoveries are control charted to obtain acceptance limits.

#### 11.1.2.5 Internal Standards (IS)

An IS is a synthetic compound not occuring in an environmental sample but has chemical behavior similar to that of the target analytes. EPA protocol requires IS for specific methods on a per sample basis (including QC samples). The IS serves as a check on the analysis and corrects for instrumental drift or matrix effects. Method specific acceptance criteria are used when possible. When method specific criteria are unavailable the recoveries are control charted to obtain acceptance limits.

#### 11.1.3 Method Quality Controls

#### 11.1.3.1 Method Blank

The method blank is used to ensure that any positive results were not because of reagent or labware contamination. Before analyzing any samples, the analyst must demonstrate through the analysis of a method blank, that all glassware and reagents are free of contaminants. Each time a set of samples is extracted, a method blank must be processed to check for laboratory contamination. The blank samples should be carried through all stages of the sample preparation and analysis. Lack of contamination is demonstrated if all target analytes with the exception of common laboratory reagents are below their DLRs.

#### 11.1.3.2 Field Blank

The field blank is used to ensure that any positive results were not because of contamination occurring during sampling. The field blank samples should be carried through all stages of the sample preparation and analysis. Lack of contamination is demonstrated if all target analytes with the exception of common laboratory reagents are below their DLRs.

Section No: 11 Page No: 3 of 18 Revision No: 2.0 Date: January 15, 1994

## **Internal Quality Control Checks**

#### 11.1.3.3 Travel Blank

The travel blank is used to ensure that any positive results were not because of contamination occurring during shipping and handling of the samples. The travel blank samples should be carried through all stages of the sample preparation and analysis. Lack of contamination is demonstrated if all target analytes with the exception of common laboratory reagents are below their DLRs.

### 11.1.3.4 Laboratory Control Sample (LCS)

The LCS is used to verify overall accuracy of the method. EPA protocol requires analysis of an LCS for each analytical batch when appropriate. The LCS consists of either a control matrix spiked with analytes representative of the target analytes or a certified reference material. Whenever possible, the LCS contains the analyte of interest at a concentration in the mid-calibration range. This standard may or may not be independent of the calibration stock standards. Initially method specific acceptance criteria are used. Eventually, or when method specific criteria are unavailable, the recoveries are control charted to obtain acceptance limits.

## 11.1.3.5 Surrogate Spikes

Surrogate spikes serve as a check on the extraction process where extraction is a necessary part of the analytical procedure. When surrogate recovery is within limits it indicates that the extraction was complete. A surrogate is a compound not expected to occur in an environmental sample but has chemical behavior similar to that of the target analytes. EPA protocol requires surrogate spikes for specific methods on a per sample basis (including QC samples). Initially method specific acceptance criteria are used. Eventually, or when method specific criteria are unavailable, the recoveries are control charted to obtain acceptance limits.

## 11.1.3.6 Matrix Spike/Matrix Spike Duplicates (MS/MSD)

The MS/MSD is used to verify matrix specific precision and accuracy. EPA protocol normally requires analysis of MS/MSD samples for each analytical batch or matrix type. The MS/MSD spikes are manufacturer or laboratory prepared from suitable reference standards. This standard may or may not be independent of the calibration stock standards. The matrix spike recovery and relative percent difference (RPD) acceptance criteria are shown in Section 5. When matrix spike results fall outside limits published in the respective methods, The LCS is used to verify method control. If spike recoveries are outside normal limits due to matrix problems, the data should be reported noting matrix interference. The spike recovery and RPD acceptance limits are test specific and are control charted.

#### 11.1.3.7 Duplicates

Duplicates are used to verify matrix specific precision. EPA protocol normally requires analysis of duplicate samples for each analytical batch or matrix type. The relative percent difference (RPD) calculated from duplicate analyses provide an assessment of precision. The RPD acceptance limits are test specific and are control charted.

Section No: 11
Page No: 4 of 18
Revision No: 2.0
Date: January 15, 1994

## **Internal Quality Control Checks**

#### 11.1.4 Radiochemical Specific Quality Controls

#### 11.1.4.1 Efficiency vs. Dissolved Solids Chart

Dissolved solids (TDS) mask or decrease the radiation picked up by the counting wire. For each instrument an efficiency vs. solids chart must be generated as part of the initial demonstration of capability. In addition, whenever an instrument is maintained or repaired (i.e. a counting wire replaced) a new efficiency vs. TDS chart must be generated. Samples containing solids such that the efficiency of counting drops below ten percent must be reset using a smaller aliquot so that the solids give acceptable counting efficiency. Whenever possible an electrical conductivity measurement is used to estimate TDS and sample aliquots.

#### 11.1.4.2 Background

Background samples are run daily, prior to sample analysis. However, a weekly average may be used for calculation purposes.

Section No: 11 Page: 5 of 19 Revision No: 2.0 Date: January 15, 1994

Fable 11-1 Quality Controls for Drinking Water Methods

		INST	метног								
<u>rest</u>	DLS	<u>BLANK</u>	<u>BLANK</u>	<u>CCY</u>	<u>ICV</u>	<u>LCS</u>	BS/BSD	MS/MSD	<u>DUP</u>	<u>SURR</u>	<u>I.S.</u>
Semivolatile Organics											
EPA 501.2	Daily	Batch	Batch			Batch		Batch			• •
EPA 504	Daily	Batch	Batch			Batch		Batch			
EPA 505	Daily	Batch	Batch			Batch		Batch			
EPA 507	Daily	Batch	Batch			Batch		Batch		Sample	
EPA 508	Daily	Batch	Batch			Batch		Batch		Sample	
EPA 508A	Daily	Batch	Batch			Batch		Batch			
EPA 510	Daily	Batch	Batch			Batch		Batch			
EPA 515.1	Daily	Batch	Batch			Batch		Batch		Sample	
EPA 525	Daily	Batch	Batch			Batch		Batch		Sample	Sample
EPA 531	Daily	Batch	Batch			Batch		Batch		Sample	
EPA 547	Daily	Batch	Batch			Batch		Batch			
EPA 548	Daily	Batch	Batch			Batch		Batch		Sample	
EPA 549	Daily	Batch	Batch			Batch		Batch			
EPA 550.1	Daily	Batch	Batch			Batch		Batch		Sample	
EPA 552	Daily	Batch	Batch			Batch		Batch		Sample	
TOC	Daily	Batch			Batch			Batch		-	
тох	Daily	Batch			Batch		. 1	Batch			
Volatile Organics							·				
EPA 502.2	Daily	Batch			Batch			Batch			Sample
EPA 524.2	Daily	Batch			Batch			Batch		Sample	Sample
Inorganic Chemicals											
Alkalinity	Daily				Batch				Batch		
Ammonia	Daily	Batch			Batch			Batch			
BOD	Daily	Batch				Batch			Batch		
Carbon Dioxide									Batch		
COD	Daily	Daily				Batch		Batch			
COD, % Transmittance	Daily	Daily				Batch		Batch			
Cl Res., colorimetric	Daily	Batch			Batch				Batch		
CI Res., titrimetric					Batch				Batch		

Section No: 11 Page: 6 of 19 Revision No: 2.0 Date: January 15, 1994

Table 11-1 Quality Controls for Drinking Water Methods

TEST	DLS	INST <u>BLANK</u>	METHOD BLANK	CCY	<u>ICY</u>	LCS	BS/BSD	MS/MSD	DUP	SURR	<u>I.S.</u>
Inorganic Chemical continued											
Cyanide, Free	Daily	Batch			Batch			Batch			
Cyanide, Total	Daily	Batch	Batch	Batch			Batch	Batch			
E.C.	Daily				Batch				Batch		
Fluoride (Distillation)		Batch	Batch			Batch		Batch			
Fluoride	Daily	Batch			Batch			Batch			
Gen. Physical									Batch		
Ignitability				Batch					Batch		
Ion Chromatography	Daily	Batch			Batch			Batch			
MBAS Extraction	Daily	Batch				Batch		Batch			
MBAS Screen										Batch	
Moisture, percent										Batch	
Oxygen, Dissolved										Batch	
Nitrate - Technicon	Daily	Batch			Batch			Batch			
Nitrite - Technicon	Daily	Batch			Batch			Batch			
Oil & Grease, Pet	Daily	Batch				Batch	Batch				
Oil & Grease, Sox	Daily	Batch				Batch	Batch				
Oil & Grease	Daily	Batch				Batch	Batch				
рН	•				Batch		•	1	Batch		
pH, Adjustment										Batch	
Phenols	Daily	Batch	Batch			Batch		Batch			
Phosphorous, Total	Daily	Batch	Batch			Batch		Batch			
Reactivity, Generation	•									Batch	
Reactivity									Batch		
Solids, Fixed	Daily	Batch				Batch			Batch		
Solids, Settleable	•										
Solids, Total	Daily	Batch				Batch			Batch		
Solids, T. Dissolved	Daily	Batch				Batch			Batch		
Solids, T. Suspended	Daily	Batch				Batch			Batch		
Solids, Volatile	Daily	Batch							Batch		
Solids, V. Suspended	Daily	Batch							Batch		
Sulfide, Diss	•								Batch		

nternal Quality Control

## Fable 11-1 Quality Controls for Drinking Water Methods

<u>rest</u>	DLS	INST <u>BLANK</u>	METHOD <u>BLANK</u>	<u>CCV</u>	<u>ICY</u>	<u>LCS</u>	BS/BSD	MS/MSD	<u>DUP</u>	<u>SURR</u>	<u>I.S.</u>
Inorganic Chemical continued Sulfide, Total									Batch		1.1
Sulfite									Batch		
ΓKN	Daily	Batch				Batch		Batch			
Fannin & Lignin	Daily	Batch				Batch		Batch			
Trace Metals											
Cr VI	Daily	Batch			Batch			Batch			Batch
FAA	Daily	Batch			, ,	Batch		Batch			
GFAA	Daily	Batch				Batch		Batch			
ICP	Daily	Batch				Batch		Batch			
ICP/MS	Daily	Batch				Batch		Batch			Sample
Hg - CVAA	Daily	Batch				Batch		Batch			
Radiochemistry											
Gross A & B		Batch					Batch				
Nuclide Screen		Batch					Batch				
Radium 226 & 228		Batch					Batch				
Radon		Batch					Batch	* *			
Strontium 90		Batch					Batch				
Tritium		Batch					Batch				
Uranium		Batch					Batch				

Table 11-2 Quality Controls for Wastewater / Hazardous Waste Liquid Methods

		INST	METHOD		****		DC/DCD	N 40 (N 40)	DID	CI III D	10
TEST	<u>DLS</u>	<u>BLANK</u>	<u>BLANK</u>	<u>CCY</u>	<u>ICY</u>	<u>LCS</u>	BS/BSD	MS/MSD	<u>DUP</u>	SURR	<u>I.S.</u>
Semivolatile Organics											
EPA 3510			Batch			Batch		Batch			•
EPA 3520			Batch			Batch		Batch			
EPA 3540			Batch			Batch		Batch			
EPA 3550			Batch			Batch		Batch			
EPA 3580			Batch			Batch			Batch		
TCLP			Batch						Batch		
EPA 8015	Daily	Batch			Batch						
EPA 8015M (Purgeable)	Daily	Batch			Batch						
EPA 8015M (Extract)	Daily	Batch			Batch						
EPA 604/8040	Daily	Batch			Batch						Sample
EPA 608/8080	Daily	Batch			Batch					Sample	
EPA 610/8310	Daily	Batch			Batch						
EPA 614/8140	Daily	Batch			Batch						Sample
EPA 615/8150	Daily	Batch			Batch						
EPA 625/8270	Daily	Batch			Batch						Sample
EPA 632	Daily	Batch			Batch						
TOC	Daily	Batch			Batch			Batch			
TOX	Daily	Batch			Batch			Batch			
TPH by IR	Daily	Batch	Batch			Batch		Batch			
Volatile Organics											
EPA 601/8010	Daily	Batch			Batch			Batch		Sample	Sample
EPA 602/8020	Daily	Batch			Batch			Batch		Sample	
EPA 624/8240	Daily	Batch			Batch			Batch		Sample	Sample
Inorganic Chemicals									<b>5</b>		
Alkalinity	Daily				Batch				Batch		
Ammonia	Daily	Batch			Batch			Batch	n		
BOD	Daily	Batch				Batch			Batch	D 4 1	
Carbon Dioxide										Batch	
COD	Daily	Daily				Batch		Batch			

, 1

Table 11-2 Quality Controls for Wastewater / Hazardous Waste Liquid Methods

<u>TEST</u>	DLS	INST <u>BLANK</u>	METHOD <u>BLANK</u>	<u>CCV</u>	<u>ICY</u>	<u>LCS</u>	BS/BSD	MS/MSD	<u>DUP</u>	SURR	<u>I.S.</u>
Inorganic Chemicals continued											
COD, % Transmittance	Daily	Daily				Batch		Batch			
Cl Res., colorimetric	Daily	Batch			Batch				Batch		
Cl Res., titrimetric		_			Batch				Batch		
Cyanide, Free	Daily	Batch			Batch			Batch			
Cyanide, Total	Daily	Batch	Batch	Batch			Batch	Batch			
E.C.	Daily				Batch				Batch		
Fluoride (Distillation)		Batch	Batch			Batch		Batch			
Fluoride	Daily	Batch			Batch			Batch			
Gen. Physical									Batch		
Ignitability				Batch					Batch		
Ion Chromatography	Daily	Batch			Batch			Batch			
MBAS Extraction	Daily	Batch				Batch		Batch			
MBAS Screen									Batch		
Moisture, percent										Batch	
Oxygen, Dissolved									Batch		
Nitrate - Technicon	Daily	Batch			Batch			Batch			
Nitrite - Technicon	Daily	Batch			Batch			Batch			
Oil & Grease, Pet	Daily	Batch				Batch	Batch	. 1			
Oil & Grease, Sox	Daily	Batch				Batch	Batch				
Oil & Grease	Daily	Batch				Batch	Batch				
р <b>Н</b>	_				Batch				Batch		
pH, Adjustment										Batch	
Phenols	Daily	Batch	Batch			Batch		Batch			
Phosphorus, Total	Daily	Batch	Batch			Batch		Batch			
Reactivity, Generation	•								Batch		
Reactivity									Batch		
Solids, Fixed	Daily	Batch				Batch			Batch		
Solids, Settleable	,										
Solids, Total	Daily	Batch				Batch			Batch		
Solids, T. Dissolved	Daily	Batch				Batch			Batch		
Solids, T. Suspended	Daily	Batch				Batch			Batch		
•	-										

Section No: 11 Page: 10 of 19 Revision No: 2.0 Date: January 15, 1994

Table 11-2 Quality Controls for Wastewater / Hazardous Waste Liquid Methods

<u>TEST</u>	DLS	INST <u>BLANK</u>	METHOI <u>BLANK</u>	<u>CCY</u>	<u>ICY</u>	<u>LCS</u>	BS/BSD	MS/MSD	DUP	SURR	<u>I.S.</u>
Inorganic Chemicals continued											
Solids, Volatile	Daily	Batch							Batch		• •
Solids, V. Suspended	Daily	Batch							Batch		
Sulfide, Diss									Batch		
Sulfide, Total									Batch		
Sulfite									Batch		
TKN	Daily	Batch				Batch		Batch			
Tannin & Lignin	Daily	Batch				Batch		Batch			
Trace Metals											
3015			Batch			Batch		Batch			
STLC			Batch						Batch		
TCLP			Batch			Batch		Batch			
Cr VI	Daily	Batch	Batch			Batch		Batch			
FAA	Daily	Batch			Batch						
GFAA	Daily	Batch			Batch						
ICP	Daily	Batch			Batch						
ICP/MS	Daily	Batch			Batch						Sample
Hg - CVAA	Daily	Batch			Batch			• '			
Radiochemistry											
Gross A & B		Batch					Batch				
Nuclide Screen		Batch					Batch				
Radium 226 & 228		Batch					Batch				
Radon									Batch		
Strontium 90		Batch					Batch				
Tritium		Batch					Batch				
Uranium		Batch					Batch				

 Fable 11-3
 Quality Controls for Solid Waste / Hazardous Waste Methods

<u>rest</u>	DLS	INST <u>BLANK</u>	METHOI <u>BLANK</u>	CCY	<u>ICY</u>	LCS	BS/BSD	MS/MSD	DUP	<u>SURR</u>	<u>1.S.</u>
Semivolatile Organics											
EPA 3510			Batch			Batch		Batch			• '
EPA 3520			Batch			Batch		Batch			
EPA 3540			Batch			Batch		Batch			
EPA 3550			Batch			Batch		Batch			
EPA 3580			Batch			Batch			Batch		
TCLP			Batch						Batch		
EPA 8015	Daily	Batch			Batch						
EPA 8015M (Diesel)	Daily	Batch			Batch						
EPA 8015M (Gas)	Daily	Batch			Batch						Sample
EPA 8040	Daily	Batch			Batch						Sample
EPA 8080	Daily	Batch			Batch						
EPA 8140	Daily	Batch			Batch						Sample
EPA 8150	Daily	Batch			Batch						
EPA 8310	Daily	Batch			Batch						
EPA 632	Daily	Batch			Batch						
EPA 8270	Daily	Batch			Batch						
TOC	Daily	Batch			Batch			Batch			
TOX	Daily	Batch			Batch			Batch			
TPH by IR	Daily	Batch	Batch		Batch			Batch			
Volatile Organics											
TCLP			Batch						Batch		
EPA 601/8010	Daily	Batch			Batch			Batch		Sample	Sample
EPA 602/8020	Daily	Batch			Batch			Batch		Sample	
EPA 624/8240	Daily	Batch			Batch			Batch		Sample	Sample
EPA 8260	Daily	Batch			Batch			Batch		Sample	Sample

Table 11-3 Quality Controls for Solid Waste / Hazardous Waste Methods

		INST	METHOL						D.1.00	ONDO	<b>.</b> C	
TEST	<u>DLS</u>	<u>BLANK</u>	<u>BLANK</u>	<u>CCY</u>	<u>ICY</u>	<u>LCS</u>	BS/BSD	MS/MSD	DUP	<u>SURR</u>	<u>I.S.</u>	
Solids Inorganic Chemicals												, ,
Ammonia	Daily	Batch				Batch		Batch	D		·	
Corrosivity (pH)					Batch				Batch			
Cyanide, Total	Daily	Batch	Batch	Batch			Batch		Batch			
E.C.	Daily				Batch			D . I	Batch			
Fluoride (Distillation)		Batch	Batch			Batch		Batch	m 1			
Ignitability				Batch					Batch			
Ion Chromatography	Daily	Batch				Batch		Batch		D. AL		
Moisture, percent										Batch		
Nitrate - Technicon	Daily	Batch				Batch		Batch				
Nitrite - Technicon	Daily	Batch				Batch		Batch				
Oil & Grease, Sox	Daily	Batch				Batch	Batch					
Oil & Grease	Daily	Batch				Batch	Batch					
pН				Batch				_	Batch			
Phenols	Daily	Batch	Batch			Batch		Batch				
Phosphorus (See Trace metals - 1	ICP)	ı										
Reactivity, Generation									Batch			
Reactivity									Batch			
Solids, Percent								• '	Batch			
Sulfide, Total									Batch			
TKN	Daily	Batch				Batch	Batch	Batch				
Trace Metals												
3050			Batch			Batch		Batch				
STLC			Batch						Batch			
TCŁP			Batch			Batch		Batch				
Cr VI	Daily	Batch	Batch			Batch		Batch				
FAA	Daily	Batch			Batch							
GFAA	Daily	Batch			Batch							
ICP	Daily	Batch			Batch						6 . 1	
ICP/MS	Daily	Batch			Batch						Sample	
Hg - CVAA	Daily	Batch			Batch							
-	-											

Section No: 11 Page: 13 of 19 Revision No: 2.0 Date: January 15, 1994

## nternal Quality Control

 Fable 11-3 Quality Controls for Solid Waste / Hazardous Waste Methods

INST

**METHOD** 

<u>rest</u>	<u>DLS</u>	<u>BLANK</u>	<u>BLANK</u>	<u>CCV</u>	<u>ICY</u>	<u>LCS</u>	<u>BS/BSD</u>	MS/MSD	<u>DUP</u>	<u>SURR</u>	<u>I.S.</u>	
Radiochemistry												
Gross A & B		Batch					Batch					4.4
Nuclide Screen		Batch					Batch					
Radium 226 & 228		Batch					Batch					
Radon									Batch			
Strontium 90		Batch					Batch					
Tritium		Batch					Batch					
Uranium		Batch					Batch					

Section No: 11 Page No: 14 of 19 Revision No: 2.0 Date: January 15, 1994

**Internal Quality Control Checks** 

Figure 11-1 FGL Control Chart for LCS

This page intentionally left blank for figures on next 2 pages.

# **QALCS-LBW**

# FGL ENVIRONMENTAL TREND CONTROL CHART

# 300.0 Anions for CL

09/23/93

BATCH	LOW	% RECOVERD (n= 30)  AVG  107	HIGH
ID	98		115
09/17/93:B 09/17/93:A 09/16/93:C 09/16/93:B 09/16/93:A 09/15/93:A 09/15/93:A 09/13/93:B 09/13/93:A 09/10/93:C 09/10/93:C 09/10/93:C 09/10/93:A 09/08/93:A 09/08/93:A 09/03/93:C 09/03/93:C 09/03/93:C 09/03/93:A 09/02/93:B 09/02/93:B 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C	Q	Q Q Q Q Q Q Q Q Q Q Q Q Q Q Q Q Q Q Q	Q

△/■ => Matrix Spike / Dup

Reporting Limits: 98 - 115 MAV % on 9/23/93 by: 98 - 115 MAV %

# QALCS-LBW

# FGL ENVIRONMENTAL TREND CONTROL CHART

# 300.0 Anions for CL

09/23/93

BATCH	DATE	Theo.	MS	MSD	AR	See
ID	COMPLETED	Conc.	%	%	%	Notes
99/17/93:B 09/17/93:A 09/16/93:C 09/16/93:B 09/16/93:A 09/15/93:B 09/15/93:A 09/13/93:B 09/13/93:C 09/10/93:C 09/10/93:C 09/10/93:C 09/10/93:A 09/08/93:B 09/08/93:B 09/08/93:A 09/08/93:A 09/03/93:A 09/02/93:B 09/02/93:A 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:C 09/01/93:A 08/27/93:C 08/27/93:C 08/27/93:C	09/17/93 09/17/93 09/16/93 09/16/93 09/16/93 09/15/93 09/15/93 09/13/93 09/13/93 09/10/93 09/10/93 09/10/93 09/10/93 09/10/93 09/08/93 09/08/93 09/08/93 09/03/93 09/03/93 09/02/93 09/02/93 09/01/93 09/01/93 09/01/93 08/27/93 08/27/93 08/27/93 08/27/93	213 213 213 213 213 213 213 213 213 213	105 101 110 109 105 108 105 104 106 110 108 107 106 108 105 105 105 105 107 107 95.2 112 109 121 109 108 106 108	75-125 75-125	1	

Section No: 11 Page No: 17 of 19 Revision No: 2.0 Date: January 15, 1994

**Internal Quality Control Checks** 

Figure 11-2 FGL Control Chart for MS/MSD and RPD

This page intentionally left blank for figures on next 2 pages.

# **QAMS-WW**

# FGL ENVIRONMENTAL TREND CONTROL CHART

# 300.0 Anions for CL

09/23/93

BATCH ID	LC 54		HIGH 150	1	FFERENCE (n= AVG 2.4	30) MAV 7.9
09/17/93:B		스틱				
09/16/93:C		△■ ∤		↔	ļ	
09/16/93:B			<b>=</b> △	<b>+</b>		
09/15/93:B			<b>A</b>	<b>↔</b>		
09/13/93:B		<b>△   ■</b>			]	-
09/10/93:D		△ ■	-		<del> </del>	
09/10/93:C		△  ■		-		
09/10/93:B		△■		•		
09/08/93:C		4 •	1		<del> -</del>	
09/08/93:B		•	Δ	H ++	1	
09/03/93:C		<b>a</b> -		<b>+</b>		
09/02/93:B		<b>△ </b> ‡			<b></b>	
09/02/93:A	•	۱			1	-
09/01/93:C		• 4			-	
09/01/93:B		△ ■			↔	
08/30/93:B		△ ⊨		•		
08/30/93:A		<b>■</b> Þ		-	!	
08/27/93:F	•			↔	1	
08/27/93:C		1 🐿		-	1	
08/26/93:E		■ △			↔	
08/26/93:C		<b>a</b>		-		
08/24/93:E		<b>△</b>		-		
08/24/93:D		■		-	1	
08/24/93:C		<b>A</b>		-		
08/24/93:B		. ■0		₩ ↔		
08/20/93:F		۵■		•		
08/18/93:E		Δ■		-		
08/18/93:D		<b>4</b>		<b>+</b>		
08/18/93:C		• 4			<b></b>	
08/18/93:B		Φ		-	]	

△/■ => Matrix Spike / Dup

↔ => % Difference

Reporting Limits:  $\frac{S4}{59} \cdot \frac{8}{150} = \frac{MAV}{7.9}$  on  $\frac{9}{123} \cdot \frac{93}{93}$  by:  $\frac{10}{129} \cdot \frac{10}{129} \cdot \frac{10}{1$ 

# QAMS-WW

# FGL ENVIRONMENTAL TREND CONTROL CHART

# 300.0 Anions for CL

09/23/93

BATCH ID	DATE COMPLETED	Theo. Conc.	MS %	AR %	DIFF.	MAV %	See Notes	
09/17/93:B 09/16/93:C	09/17/93 09/16/93	100 40.0	98.9 96.9	101 99.3	75-125 75-125	0.6 0.5	20.0	10
09/16/93:B	09/16/93	100	154	151	75-125	1.2	20.0	*
09/15/93:B 09/13/93:B	09/15/93 09/13/93	145 100	180 92.0	180 120	75-125 75 <b>-</b> 125	0.1 13.4	20.0 20.0	*
09/13/93:D	09/13/93	100	110	116	75-125	2.4	20.0	.,
09/10/93:C	09/10/93	200	98.9	103	75-125	1.6	20.0	
09/10/93:8	09/10/93	100	106	109	75-125	1.6	20.0	
09/08/93:C	09/08/93	100	110	118	75-125	2.4	20.0	10
09/08/93:B 09/03/93:C	09/08/93 09/03/93	200 100	124 95.7	113 95.8	75-125 75-125	2.1 0.1	20.0 20.0	
09/03/93:B	09/02/93	100	95.0	102	75-125	4.5	20.0	
09/02/93:A	09/02/93	100	68.6	46.0	75-125	14.1	20.0	10
09/01/93:C	09/01/93	200	85.7	82.0	75-125	3.3	20.0	13
09/01/93:B	09/01/93	200	84.5	89.7	75-125	2.8	20.0	
08/30/93:B 08/30/93:A	08/30/93 08/30/93	100 100	98.5 103	103 100	75-125 75-125	1.3 1.7	20.0 20.0	
08/27/93:F	08/27/93	4000	45.7	38.0	75-125	2.0	20.0	10
08/27/93:C	08/27/93	100	107	106	75-125	0.4	20.0	10
08/26/93:E	08/26/93	200	112	104	75-125	3.2	20.0	10
08/26/93:C	08/26/93	40.0	98.9	100	75 <b>-</b> 125	0.8	20.0	
08/24/93:E 08/24/93:D	08/24/93 08/24/93	50.0 625	109 97.2	111 95.3	75-125 75-125	1.3	20.0 20.0	
08/24/93:C	08/24/93	250	106	106	75-125	0.6	20.0	13
08/24/93:8	08/24/93	250	109	107	75-125	1.2	20.0	
08/20/93:F	08/20/93	50.0	77.9	80.3	75-125	1.0	20.0	
08/18/93:E	08/18/93	250	83.8 99.5	8 <b>6.</b> 4 99.7	75-125 75-125	1.5	20.0 20.0	13 10
08/18/93:D 08/18/93:C	08/18/93 08/18/93	100 100	101	99.7	75-125 75-125	0.1 3.0	20.0	10
08/18/93:8	08/18/93	40.0	102	103	75-125	0.5	20.0	13

-

Section No: 12 Page: 1 of 21 Revision No: 2.0 Date: January 15, 1994

# Performance and System Audits

The Quality Assurance Director or Officer is responsible for internal system audits, coordinating all external audits and performance evaluation (PE) samples. In addition, the QA Director or Officer is responsible for maintaining state and agency certification.

## 12.1 System Audits

System audits are performed both by external agencies, and by the laboratory Quality Assurance group. The focus of these audits is the overall analytical "system", from login to delivery of the finished reports. The purpose of the audit is to document compliance with the specified methodology contained in our Standard Operating Procedures (SOPs).

## 12.1.1 Internal System Audit Program

Internal system audits are conducted on a monthly basis. Several analytical methods are selected each month for a systems audit. Compliance with all the required QC is evaluated and indicated on the QA inspection summary report form (figure 16-1). This report contains all the new nonconformance items, previously uncompleted non-conformance items and finally all non-conformance items completed. Dates are recorded when the non-conformance was found and when it was completed. This report is given to all supervisors and managers. With these steps an ongoing quantitative assessment of the analytical system is provided.

## 12.1.2 External System Audits

System audits are performed by outside government agencies such as the California Department of Health Services, Lawrence Livermore National Laboratory and the Army Corp of Engineers. Audits are also performed by private agencies such as Chemical Waste Management, Inc.

# 12.2 Performance Evaluation Samples

Performance evaluation audits are used to provide a direct evaluation of the ability of the analytical systems to generate data that is consistent with the laboratory's stated objectives for accuracy and precision. External PE samples are analyzed as part of the certification and approval process for various state and federal agencies, as well as for other organizations.

# 12.2.1 External Performance Evaluation Samples

Performance evaluation samples are analyzed for a number of outside agencies including:

- (1) USEPA semi-annual drinking water check samples (WS series)
- (2) USEPA semi-annual wastewater check samples (WP series)
- (3) USEPA annual wastewater check samples (DMR studies)
- (4) EMSL, Las Vegas, radiochemistry check samples
- (5) Environmental Research Associates check samples

# 12.3 Certifications, Accreditations and Agency Approvals

FGL Environmental participates in laboratory certification programs with California, and other states. A copy of the California Environmental Laboratory Accredititation Program (ELAP) approved analyses list may be found in Figures 12-3 and 12-4. A copy of the Nevada Department of Human Resources approved analyses list may be found in Figure 12-5.

Section No: 12 Page: 2 of 21 Revision No: 2.0 Date: January 15, 1994

Performance and System Audits

Figure 12-1 FGL QA Inspection Form

This page intentionally left blank for figures on next 4 pages.

# FGL QC Inspection Report

Date:			
Inspector:			
<u>Item</u>	In Compliance?	Corrective Action	Due by
Overall - Oven Temps Ref. Temps Balance Checks Container Checks QC SOP's			
Comments:			
Front Office and Login - Sample #'s -			
Sample # 5			
LIMS Logbook File Tracking Chain of Custody Report Bill Training SOP's			
Comments:			
Bacteriology - D.W. Prep Log W.W. Prep Log P.C. Prep Log Client Notifications Media Prep Log Autoclave Temps Incubator Temps Water Suitability Corrective Action Log			
Bact Method Check			
Method: Analyst Training SOP	Sample #:	Date Comp:	
Comments:		7	
	The standard last short affects		


<u>Item</u>	In Compliance?	Corrective Action	Due by
Inorganics - Standard Prep Log Corrective Action Log Water Suitability Instrument Maint. Dionex DX-300 P.E. Lambda 3 Turner Nephelometer Fisher pH/ISE Orion E.C. Orion BOD P.E. 5000 P.E. 5100 Fisons PQ-II Leeman PS200			
Wet Chemistry Method Check			
Method: Data Package Batch QC Report Reviewed Report Batch Sheet Inst. Printout Control Charts Analyst Training SOP	Sample #:	Date Comp:	
Method: Data Package Batch QC Report Reviewed Report Batch Sheet Inst. Printout Control Charts Analyst Training SOP	Sample #:	Date Comp:	
Metals Method Check			
Method: Data Package Batch QC Report Reviewed Report Batch Sheet Inst. Printout Control Charts Analyst Training SOP	Sample #:	Date Comp:	
Comments:			
			<del></del>

<u>Item</u>	In Compliance?	Corrective Action	Due by
Organics - GC Lab: Standard prep Log GC Corrective Action Log Instrument Maint. GC 1 GC 2 GC 4 GC 5 GC 6 GC 7 GC 8 Hitachi HPLC IR			
GC Lab Method Check			
Method: Data Package Batch QC Report Reviewed Report Batch Sheet Inst. Printout Control Charts Analyst Training SOP  GC/MS Lab: Standard prep Log GC/MS Corrective Action Log Instrument Maint. GC/MS 1 GC/MS 2 GC/MS 3 GC/MS 4 MCI TOX Astro TOC	Sample #:	Date Comp:	
GC/MS Lab Method Check			
Method: Data Package Batch QC Report Reviewed Report Batch Sheet Inst. Printout Control Charts Analyst Training SOP	Sample #:	Date Comp:	
Comments:			

Radioactivity - Standard Prep. Log Corrective Action Log Instrument Maint.			
Alpha 1 Alpha 2 Alpha 5 Alpha 6 Alpha 7 Alpha/Beta 3 Alpha/Beta 4 Alpha/Beta 8 Liquid Scint.			
Radiochemistry Method Check			
Method: Data Package Batch QC Report Reviewed Report Batch Sheet Inst. Printout Control Charts Background Dump Efficiency Report Analyst Training SOP Comments:		Date Comp:	
Ag Lab - Standard Prep. Log Corrective Action Log Instrument Maint. Technicon - nitrate Technicon - TKN LECO pH meter E.C. meter ARL 3410			
Ag Method Check			
Method: Data Package Batch QC Report Reviewed Report Batch Sheet Inst. Printout Control Charts Analyst Training SOP Comments:	Sample #:	Date Comp:	

Section No: 12 Page: 7 of 21 Revision No: 2.0 Date: January 15, 1994

Performance and System Audits



This page intentionally left blank for figures on next 5 pages.

# ENVIRONMENTAL LABORATORY ACCREDITATION/REGISTRATION List of Approved Fields of Testing and Analytes

FGL Environmental Laboratory 853 Corporation Street Santa Paula, CA TELEPHONE No: (805) 659-0910 CALIFORNIA COUNTY: Ventura

CERTIFICATE NUMBER: 1573 EXPIRATION DATE: 7/31/95

1	Microbiology of Drinking Water and Wastewater (		=======================================				
	and a life of a fall of the second of the se	. L					
1.1	Total Coliforms in Drinking Water by Multiple To	ube rermen	tation				
1.2	Fecal Coliforms/E. Coli in Orinking Water by MTI Total Coliforms in Orinking Water by Membrane F	ilter Tech	nice				
1.3 1.4	Fecal Coliforms/E. Coli in Drinking Water by Me	mhrane Fil	ter Technics				
1.5	Total Coliforne and E. Coli in Orinking Water by		Y				
1.6	Total Coliforms in Orinking Water by Clark's Pr	esence/Ahs	ence				
1.7	Feral Coliforms/E Coli in Orinking Water by Cl.	arkic Pres	ence/Absence N				
1.8	Heterotrophic Plate Count						
1.9	Total Coliforms in Mastauerer by Multiple Tube Fermentation						
1.10	Seed Coliforns in Unstaugter by MTE		Y				
1.11	Total Coliforms in Unetqueter by Membrane Filte	r Tachnice					
1.12	Escal Coliforme in Unetquater by Membrane Filte	r Technics					
1.13	Facel Strentococci or Enterococci by Multiple T	uba Techni	PC				
1.14	Fecal Streptococci or Enterococci by Membrane F	ilter Tech	nics N				
2	Inorganic Chemistry and Physical Properties of	<u>Drinking W</u>	ater excluding Toxic Chemical Elements				
9	(07-15-91)						
2.1	Alkalinity Y	2.12	Sulfate Y				
2.2	CalciumY	2.13	Total Filterable Residue and Conductivity Y				
2.3	Chloride Y	2.4/	and Conductivity				
2.4	Corrosivity Y Fluoride Y	2.14	Iron (Colorimetric Methods Only) N				
2.5	Hardness ····· Y	2.15	Manganese (Colorimetric Methods Only) - N				
2.6	Hardness ····· Y	2.16	Phosphate, ortho Y Silica (Colorimetric Methods Only) N				
2.7	MBAS Y	2.17 2.18	Cyanide Y				
2.8	NitrateY	2.10	Cyanitae				
2.9 2.10	Nitrite Y						
2.11	SodiumY						
2.11	Social						
3	Analysis of Toxic Chemical Elements in Drinking	Water (07	'-15-91)				
•							
3.1	Arsenic Y	3.11	Silver Y				
3.2	Rapism Y	3.12	Zinc Y				
3.3	CadmiumY	3.13	Aluminum Y				
3.4	Chromium, total Y	3.14	Asbestos N				
3.5	Corner Y	3.15	EPA Method 200.7 ······ Y				
3.6	IronY	3.16	EPA Method 200.8 (Unregulated Elements				
3.7	Lead Y		and Lead Only)Y				
3.8	Manganese ····· Y Mercury ····· Y	3.17	Antimony Y				
3.9	Mercury Y Selenium Y	3.18 3.19	NickelY				
3.10	Selenium	3.19	ThalliumY				
		3.20	inactium				
,	Organic Chemistry of Drinking Water (measuremen	+ hu cr/ms	combination) (07-15-01)				
4							
4.1	EPA Method 501.3		N				
4.2	The Mashed 52/ 2						
4.3	and washing EDE		V				
4.4	EPA Method 513		N				
•••							
5	Organic Chemistry of Drinking Water (excluding	measuremen	nts by GC/MS combination) (07-15-91)				
5.1	EPA Method 501.1 N	5.15	EPA Method 547 Y				
5.2	EPA Method 501.2 Y	5.16	EPA Method 548 Y				
5.3	EPA Method 502.1 N	5.17	EPA Method 549Y				
5.4	EPA Method 502.2	5.18	EPA Method 550				
5.5	EPA Method 503.1N	5.19	EPA Method 550.1 N EPA Method 551 Y				
5.6	EPA Method 504Y	5.20	EPA Method 552 Y				
5.7	EPA Method 505	5.21	the metuod 307				
5.8	EPA Method 506 N EPA Method 507 Y						
5.9	EPA Method 507						
5.10	EPA Method 508AY						
5.11	EPA Method 510.1 N						
5.12	EPA Method 515.1 Y						
5.13	EPA Method 531.1						
5.14	ELM HERITON 33111						

CERTIFICATE NUMBER: 1573 EXPIRATION DATE: 7/31/95

6	Radiochemistry (07-15-91)			
6.1	Gross Alpha and Beta Radiation Y	6.11	Gross Alpha by Co-precipitation	Y
6.2	Total Padium Y	6.12	Padim 228	Y
6.3	Radium 226 Y	6.13	Radioactive Iodine	N
6.4	Ilranium Y	6.14	Gross Alpha & Beta in Hazardous Wastes	Y
6.5	Radon 222 Y	6.15	Alpha Emitting Radium Isotopes	
6.6	Radioactive Cesium N	0.15	in Haz. Wastes	Y
6.7	Iodine 131 N	6.16	Radium 228 in Hazardous Wastes	Ÿ
6.8	Padioactive Strontism	0.10	Radian Eco III Ilazar adas mastes	'
6.9	Taiting			
	Radioactive Strontium Y Tritium Y Gamma and Photon Emitters N			
6.10	Gasima and Photon Emitters			
7	Shellfish Sanitation ()			
7.1	Shellfish meat Microbiology			N
7.2	Paralytic Shellfish Poison			N
7.3	Domoic Acid			N
8	Aquatic Toxicity Bioassays ()			
8.1	Hazardous Waste Aquatic Toxicity Bioassay (Tit	le 22. CCR.	66261.24(a)(6))	N
8.2	Wastewater Testing According to Kopperdahl (19)	76) using Fr	reshwater Fish	N
8.3	Wastewater Testing According to EPA/600/4-85/01	13 usina fre	eshwater and/or Marine Organisms	N
8.4	Wastewater Testing by EPA Method 1000 0			N
8.5	Usetauster Testing by FPA Method 1002 0			N
8.6	Wastewater Testing by EPA Method 1003.0			N
8.7	Wastewater Testing by EPA Method 1006			N
8.8	Wastewater Testing by FPA Method 1007			N
8.9	Wastewater Testing by EPA Method 1009			N
8.10	Wastewater Testing According to Anderson, et. a	al. (1990) i	using Giant Kelp (Macrocystis pyrifera)	N
8.11	Wastewater Testing According to Anderson, et.	al. (1990) i	using Red Abalone (Haliotus rufescens) -	N
8.12	Wastewater Testing According to Dinnel and Stol	ber (1987) (	using Purple Sea Urchin	
0.12	Wastewater Testing According to Dinnel and Stol (Strongylocentrotus purpuratus)		************************************	N
8.13	Wastewater Testing According to Dinnel and Stol	ber (1987) i	using Red Sea Urchin	
	(Strongylocentrotus franciscapus)			N
8.14	Wastewater Testing According to Dinnel and Stol	ber (1987) (	using Sand Dollar	
•••	(Dendraster excentricus)		***************************************	N
8.15	Wastewater Testing According to procedure E 72	4-89 (ASTM.	1989) using Pacific Oyster	
	(Crassostrea gigas)			N
8.16	Wastewater Testing According to procedure E 72	4-89 (ASTM,	1989) using California Bay Mussel	
				N
8.17	Wastewater Testing According to Standard Method (Skeletonema costatum)	ds (APHA, 19	989) using an alga	
	(Skeletonema costatum)			N
8.18	Wastewater Testing According to EPA/600/4-90/0	27 using fr	eshwater and/or Marine Organisms	N
9	Physical Properties Testing of Hazardous Waste		•	
9.1	Ignitability by flashpoint determination (Title Corrosivity - pH determination (Title 22, CCR, Corrosivity - Corrosivity towards steel (Title 22, CCR, 66261 23)	e 22 CCP	66261 21)	١
9.2	Connectivity and determination (Title 22 CCR	44241 221	00201.21)	\
9.2	Correctivity - Correctivity towards steel (Title	22 CCB 6	.6261 221	\
	Reactivity (Title 22, CCR, 66261.23)		0001.227	`
9.4	REACTIVITY (11tte 22, 66K, 66201.23)			
10	Inorganic Chemistry and Toxic Chemical Element	s of Hazard	dous Vaste	
10.1	Antimony	10.7	Cobait	
	7040() N		7200()	N
	7041(06-06-86)Y			N
10.2	Arsenic	10.8	Copper	
	7060(06-06-86) Y		7210(06-06-86)	Y
	7061( N		7211()	N
10.3	Barium	10.9	Lead	
	7080( N		7420(06-06-86)	Y
	7081( N		7421(06-06-86)	Y
10.4	Beryllium	10.10	Mercury	
	7090( N		7470(06-06-86)	Y
	7091( ) N		7471(11-30-93)	Y
10.5	Cadmium	10.11	Mol viodenum	
	7130( N		7480()	N
	7131(06-06-86) Y		7481(11-30-93)	Y
10.6	Chromium, total	10.12	Nickel	
	7190( N		7520(06-06-86)	Y
	7191(11-30-93) Ÿ			

10.15 Thallium

Zinc

10.18 Chromium (VI)

Vanadium

10.16

10.17

10.19	Cyanide	
	9010(06-06-86)	Y
10.20	Fluoride	
	300.0(11-30-93)	Y
	340.1()	N
	340.2(06-06-86)	Y
	340.3()	N
10.21	Sulfide	
	9030(06-06-86)	٧
10.22		•
	()	u
10.23	•	
10.24		Ÿ
		•

#### 

7761(----- N

7840(-----) ------ N 7841(06-06-86) ------ Y

7910(----- ) ----- N 7911(----- ) ----- N

7950(06-06-86) ------ Y

7195(------) ------- N 7196(06-06-86) ------ Y 7197(-----) ------ N

11.1	California Waste Extraction Test (WET) (Title 22, CCR, 66261.100, Appendix II)	Y
11.2	Extraction Procedure Toxicity	Y
11.3	Toxicity Characteristic Leaching Procedure (TCLP) All Classes	Y
11.4	Toxicity Characteristic Leaching Procedure (TCLP) Inorganics Only	N
11.5	Toxicity Characteristic Leaching Procedure (TCLP) Extractables Only	N
11.6	Toxicity Characteristic Leaching Procedure (TCLP) Volatiles Only	N

### 12 Organic Chemistry of Hazardous Waste (measurement by GC/MS combination)

12.1	EDA Machael 82/0/02-05-875		v
12.1			
12.2	EPA Method 8250()	***************************************	N
12.3	EPA method 82/U(U2-U3-8/)		Y
12.4	EDA Method 8280()	***************************************	м
12.5	EPA Method 8290()		N
12.6	EPA Method 8260(11-30-93)		٧
12.0	Er A He thou 0200(11 30 )3)		

#### 13 Organic Chemistry of Hazardous Waste (excluding measurements by GC/MS combination)

13.1	EPA Method 8010( N	13.13 EPA Method 8310(05-27-92) Y
13.2	EPA Method 8015(01-09-90) Y	13.14 EPA Method 632 (07-15-91) Y
13.3	EPA Method 8020(06-06-86) Y	13.15 Total Petroleum Hydrocarbons
13.4	EPA Method 8030( N	(LUFT Manual) (06-06-86) Y
13.5	EPA Method 8040( N	13.16 EPA Method 8011(11-08-87) Y
13.6	EPA Method 8060( N	13.17 EPA Method 8021() N
13.7	EPA Method 8080(06-06-86) Y	13.18 EPA Method 8070() N
13.8	EPA Method 8090( ) N	13.19 EPA Method 8110() N
13.9	EPA Method 8100( N	13.20 EPA Method 8141(11-30-93) Y
13.10	EPA Method 8120( ) N	13.21 EPA Method 8330( N
13.11	EPA Method 8140(06-06-86) Y	

#### 14 Bulk Asbestos Analysis (-----)

13.12 EPA Method 8150(06-06-86) ----- Y

- 14.1 1% or Greater Asbestos Concentrations (Title 22, CCR, 66261.24(a)(2)(A)) ------N
- Substances Regulated Under the California Safe Drinking Water and Toxic Enforcement Act (Proposition 65) and Not Included in Other Listed Groups.

#### 16 Wastewater Inorganic Chemistry, Nutrients and Demand (07-15-91)

16.1	Acidity		Cyanide Y
16.2	Alkalinity		Cyanide amenable to Chlorination Y
16.3	Ammonia		Fluoride Y
16.4	Biochemical Oxygen Demand		Hardness Y
16.5	Boron	Y 16.16	Kjeldahl Nitrogen Y
16.6	Bromide		Magnesium Y
16.7	Calcium		Nitrate Y
16.8	c800		Nitrite Y
16.9	Chemical Oxygen Demand		Oil and Grease Y
16.10	Chloride		Organic Carbon Y
16.11	Chlorine Residual, total	Y 16.22	Oxygen, Dissolved Y

CERTIFICATE NUMBER: 1573 EXPIRATION DATE: 7/31/95 16.39 Surfactants (MBAS) ----- Y 16.23 16.40 Tannin and Lignin -----Y Phenois ----- Y 16.24 Phosphate, ortho- ----- Y 16.25 Phosphorus, total Iron (Colorimetric Only) ----- N 16.42 16.26 Manganese (Colorimetric Only) ----- N 16.43 16.27 Residue, Total 16.44 Total Recoverable 16.28 Residue, Filterable (TDS) ----- Y Petroleum Hydrocarbons ----- Y 16.29 Residue, Nonfilterable (TSS) ----- Y Residue, Settleable (SS) ----- Y 16.45 Total Organic Halides ----- Y 16.30 16.31 Residue, Volatile -----Y
Silica ------Y
Sodium -----Y 16.32 16.33 16.34 Specific Conductance ----- Y 16.35 Sulfate -----Y 16.36 Sulfide (includes total & soluble) - Y 16.37 16.38 Sulfite ----- Y Toxic Chemical Elements in Wastewater (07-15-91) 17 17.18 Nickel ----- Y Aluminum ----- Y 17.1 17.19 Osmium ----- N 17.20 Palladium ---- N Antimony ------ Y 17.2 Arsenic ----- Y 17.3 Platinum ----- N Barium -----Y 17.4 17.21 Rhodium ----- N Ruthenium ----- N Beryllium -----Y 17.22 17.5 Cadmium 17.6 17.23 Chromium (VI) Selenium ----- Y 17.24 17.7 Chromium, total -----Y Silver -----Y 17.8 17.25 17.9 17.26 Thatlium ..... Copper ----- Y 17.27 17.10 Tin ----- Y
Titanium ----- Y Gold -----Y Iridium -----N 17.28 17.11 17.29 17.12 Iron -----Y Vanadium ----- Y 17.30 17.13 Lead -----Y Manganese -----Y Zinc ------Y 17.31 17.14 EPA Method 200.7 ------ Y 17.32 17.15 EPA Method 200.8 Mercury -----Y 17.16 17.33 Molybdenum ------Y DCP ----- N 17.17 17.34 Asbestos ------ N 17.35 Organic Chemistry of Wastewater (measurements by GC/MS combination (07-15-91) 18 EPA Method 624 ------ Y 18.1 EPA Method 625 ------Y 18.2 EPA Method 1613 ------ N 18,3 EPA Method 1625 ----- N 18.4 18.5 19 Organic Chemistry of Wastewater (excluding measurements by GC/MS combination) (07-15-91) 19.8 EPA Method 608 ----- Y
19.9 EPA Method 609 ----- N EPA Method 601 ----- N 19.1 EPA Method 602 ----- Y EPA Method 609 ----- N 19.2 19.10 EPA Method 610 ----- N 19.11 EPA Method 611 ---- N 19.12 EPA Method 632 ---- Y EPA Method 603 ----- N 19.3 EPA Hethod 604 19.4 EPA Method 605 ----- N 19.5 19.13 EPA Method 619 ----- N 19.99 EPA Method 615 ---- Y EPA Method 606 ----- N 19.6 EPA Method 607 ----- N 19.7 Inorganic Chemistry and Toxic Chemical Elements of Pesticide Residues in Food (------) 20 20.1 Processed Foods by One of the Following Methods Atomic Absorption Spectrophotometry ------ N Inductively Coupled Plasma Atomic Emission Spectrophotometry Raw Commodities by One of the Following Methods 20.2 Atomic Absorption Spectrophotometry Inductively Coupled Plasma Atomic Emission Spectrophotometry 20.3 Dairy Products by One of the Following Methods

CERTIFICATE NUMBER: 1573 EXPIRATION DATE: 7/31/95

20.4	Feed Products by One of the Following Methods Atomic Absorption Spectrophotometry Inductively Coupled Plasma Atomic Emission Spectrophotometry Inductively Coupled Plasma/Mass Spectrometry	. N
21	Organic Chemistry of Pesticide Residues in Food (measurements by GC/MS) ()	
21.1	Gas Chromatographic/Mass Spectrometric Methods in Processed Foods	
21.3	Cae Chromatographic/Mage Spectrometric Mathode in Dairy Products	
21.4	Gas Chromatographic/Mass Spectrometric Methods in Feed Products	•
22	Organic Chemistry of Pesticide Residues in Food (Excluding Measurement by GC/MS Combination)  ()	
22.1	Halogenated Compounds in Processed Foods by One of the Following Methods	
	Gas Chromatography	N
	High Pressure Liquid Chromatography	N
	Liquid Chromatography/Mass Spectrometry	N
22.2	Organophosphorous Compounds in Processed Foods by One of the Following Methods	
	Cap Chromatography	N
	High Pressure Liquid Chromatography	M
	Liquid Chromatography/Mass Spectrometry	N
22.3	Carbanatas in Represent Foods by One of the Following Methods	
	Cae Chrometoppenhy	N
	High Pressure Liquid Chromatography	N
	Liquid Chromatography/Mass Spectrometry	N
22.4	Halogenerad Compounds in Pau Commodities by One of the Following Methods	
	Con Chromatography	N
	High Pressure Liquid Chromatography	N
	Liquid Chromatography/Mass Spectrometry	N
22.5	Occapophosphorous Compounds in Ray Commodities by One of the Following Methods	
	Cae Chrometagraphy	N
	High Pressure Liquid Chromatography	N
	Liquid Chromatography/Mass Spectrometry	N
22.6	Carbamates in Raw Commodities by One of the Following Methods	
	Gas Chromatography	N
	High Pressure Liquid Chromatography	N
	Liquid Chromatography/Mass Spectrometry	N
22.7	Halaganated Compands in Dairy Products by One of the Following Methods	
	Coe Chematoneany	N
	High Draceura Liquid Chromatography	N
	liquid Chromatography/Mass Spectrometry	N
22.8	Openhancehonous Companye in Dairy Products by One of the Following Methods	
	Coe Chrometodraphy	N
	High Pressure Liquid Chromatography	N
	Liquid Chromatography/Mass Spectrometry	N
22.9	Carbamates in Dairy Products by One of the Following Methods	
	Cae Chamatagagahy accessions and accession and accession and accession and accession accession and accession accession and accession acc	N
	High Pressure Liquid Chromatography	N
	Liquid Chromatography/Mass Spectrometry	N
22.10	Halogenated Compounds in Feed Products by One of the Following Methods	
	Gas Chromatography	N
	High Pressure Liquid Chromatography	N
	Liquid Chromatography/Mass Spectrometry	N
22.11	Organophosphorous Compounds in Feed Products by One of the Following Methods	
	Gas Chromatography	N
	High Pressure Liquid Chromatography	N
	Liquid Chromatography/Mass Spectrometry	N
22.12	archanges in Feed Deadusts by One of the Following Methods	
	A	N
	With Baseline Limit Champagapaphy assessment and a second	N
	Liquid Chromatography/Mass Spectrometry	N

Section No: 12 Page: 13 of 21 Revision No: 2.0 Date: January 15, 1994

# Performance and System Audits

Figure 12-3 FGL Stockton - CA DHS ELAP Certification

This page intentionally left blank for figures on next 5 pages.

# ENVIRONMENTAL LABORATORY ACCREDITATION/REGISTRATICN List of Approved fields of Testing and Analytes

FGL Environmental 2500 Stagecoach Road Stockton, CA TELEPHONE No: (209) 942-0181 CALIFORNIA COUNTY: San Joaquin CERTIFICATE NUMBER: 1563 EXPIRATION DATE: 07/31/95

200011					
1	Microbiology of Drinking Water and Wastewater (07-	03-91)			
1.1	Total Coliforms in Drinking Water by Multiple Tube	: fermen	tation Y		
1.2	fecal Coliforms/E. Coli in Drinking Water by MTF -		Y		
1.3	Total Coliforms in Drinking Water by Hembrane Filt	ter Tech	nics N		
1.4	Fecal Coliforms/E. Coli in Drinking Water by Membr	ane fil	ter Technics N		
1.5	Total Coliforns and E. Coli in Drinking Water by M	140-MUG	······································		
1.6	Total Coliforms in Orinking Water by Clark's Prese	ence/Abs	EUC6 A		
1.7	Fecal Coliforms/E. Coli in Drinking Water by Clark	('s Pres	ence/Absence Y		
1.8	Heterotrophic Plate Count		ү		
1.9	Total Coliforms in Wastewater by Multiple Tube Fer	mentati	ON Y		
1.10	Fecal Coliforms in Westewater by MTF		Y		
1.11	Total Coliforms in Wasteweter by Hembrane Filter T	rechnics			
1.12	Fecal Coliforns in Wastewater by Membrane Filter 1	lechnics			
1.13	Fecal Streptococci or Enterococci by Multiple Tube	t Techni	CB N		
1.14	Fecal Streptococci or Enterococci by Membrane Filt	ter Tech	nics X		
_	was a surface of the				
2	Inorganic Chemistry and Physical Properties of Dri	inking W	ater excluding Toxic Chemical Elements		
	(07-03-91)				
2 4	Alkalinity Y	2 42	Sulfate Y		
2.1	Calcium Y	2.12	Total Cilements Confdu		
2.3	Chloride Y	4.13	Total Filterable Residue and Conductivity Y		
2.4	Corrosivity Y	2.14	Iron (Colorimetric Methods Only) N		
2.5	Fluoride Y	2.15	Manganese (Colorimetric Methods Only) - N		
2.6	Hardness ······ Y	2.16	Phonoheta ortho assessment Y		
2.7	Magnesium Y	2.17	Silica (Colorimetric Methods Only) Y		
2.8	MBAS Y	2.18	Cyanide Y		
2.9	Nitrate	4.10	Cyamico		
2.10	NitriteY				
2.11	SodiumY				
4.11	3031411				
3	Analysis of Toxic Chemical Elements in Orinking Wa	ater (07	'-03- <del>9</del> 1)		
_					
3.1	Arsenic Y	3.11	Silver Y		
3.2	Barium Y	3.12	Zinc		
3.3	Cadmium Y	3.13	Aluminum Y		
3.4	Chromium, total	3.14	Asbestos N		
3.5	Copper Y	3.15	EPA Method 200.7		
3.6	Iron Y	3.16	EPA Method 200.8 (Unregulated Elements		
3.7	Lead Y		and Lead Only)N		
3.8	Manganese Y	3.17	Antimony Y		
3.9	Mercury Y	3.18	BerylliumY		
3.10	Setenium Y	3.19	Nickel		
		3.20	Thattium Y		
4	Organic Chemistry of Drinking Vater (measurement )				
4.1	EPA Method 501.3		Y		
4.2					
4.3	CDA Mathod 575		· Ý		
4.4	EPA Method 525 EPA Method 513				
	Era nethod 713				
5	Organic Chemistry of Drinking Water (excluding me	BSULT EMBE	nts by GC/MS combination) (07-03-91)		
5.1	EPA Method 501.1 Y	5.14	EPA Method 531.1 N		
5.2	EPA Hethod 501.2 Y	5.15	EPA Method 547		
5.3	FPA Method 502.1 ******* Y	5.16	EPA Method 548		
5.4	FPA Method 502.2 Y	5.17	EPA Nethod 549		
5.5	EPA Method 503.1 Y	5.18	EPA Method 550 N		
5.6	FDA Morhad 504 Y	5.19	EPA Nethod 550.1 N		
5.7	EPA Method 505 Y	5.20	EPA Method 551		
5.8	EPA Method 506 N	5.21	EPA Hethod 552		
5.9	EPA Method 507 N				
5.10	EPA Method 508		•		
5.11	EPA Method 508A N				
5.12	EPA Hethod 510.1				
5.13	EPA Method 515.1				

CERTIFICATE NUMBER: 1563 EXPIRATION DATE: 07-31-95

6	Radiochemistry ()			
6.1	Gross Alpha and Beta Radiation N	6.11	Gross Alpha by Co-precipitation	N
6.2	Total Radium N	6.12	Padium 228	M
6.3	hadin 326	6.13	Radium 228	ŭ
6.4	Uranium	6.14	Gross Alpha & Beta in Hazardous Wastes	7
	Radon 222 N		Gross Alpha & Beta in nazardous wastes **	N
6.5	Kagon 222	6.15	Alpha Emitting Radium Isotopes	
6.6	Radioactive Cesium N		in Haz. Wastes	N
6.7	lodine 131 N	6.16	Radium 228 in Hazardous Wastes	N
6.8	Radioactive Strontium N			
6.9	Tritium N			
6.10	Gamma and Photon Emitters N			
7	Shellfish Sanitation ()			
7.1	Shellfish meet Microbiology			H
7.2	Paralytic Shallfish Poison			M
7.3	Domoic Acid			N
8	Aquetic Toxicity Bioassays ()			
8.1	Hazardous Waste Aquatic Toxicity Bioassay (Title 2	22 000	66761 74/a)/6\\	и
8.2	Wastewater Testing According to Kopperdahl (1976)	us ne E	combustan Fich	,
	Mastewater resting According to Ropper Cant (1770)	using r	resingter rish.	
8.3	Wastewater Testing According to EPA/600/4-85/013	asing Fr	eshwater and/or marine organisms	N
8.4	Wastewater Testing by EPA Method 1000.0			N
8.5	Wastewater Testing by EPA Method 1000.0	•••••	***************************************	N
8.6	Uperpuerer Testing by EPA Mathod 1003 0			М
8.7	Unetquarer Testing by EDA Marked 1006			ш
8.8	Wastewater Testing by EPA Method 1007			M
8.9	Wastewater Testing by EPA Method 1009			N.
	Wastewater Testing by EPA Method Touy	44000	and an Adam Mala Managarant and Adams	N
8.10	Wastewater Testing According to Anderson, et. al.	(1990)	using Giant Kelp (Macrocystis pyrifera)	N
3.11	Wastewater Testing According to Anderson, et. al.	(1990)	using Red Abalone (Haliotus rufescens)	N
8.12	Wastewater Testing According to Dinnet and Stober (Strongylogentrotus purpuratus)	(1987)	using Purple Sea Urchin	
	(Strongylocentrotus purpuratus)		***************************************	N
8.13	Wastewater Testing According to Dinnet and Stober	(1987)	using Red See Urchin	
	(Strongylocentrotus franciscanus)	•		N
8.14	Wastewater Testing According to Dinnel and Stober	(1987)	using Sand Dollar	
	Wastewater Testing According to Dinnel and Stober (Strongylocentrotus franciscanus) Wastewater Testing According to Dinnel and Stober (Dendraster excentricus)			H
8.15	Wastewater Testing According to procedure E 724-8	9 (ASTM,	, 1989) using Pacific Oyster	
8.16	(Crassostree gigas)	O (ASTM.	10000 veine California Day Myses	
01.0	(Modfline arkillie)			N
8.17	Wastewater Testing According to Standard Methods (Skeletonema costatum)	(APHA, 1	1989) using en elga	
8.18	( <u>Skeletonema gostatum</u> ) Wastewater Testing According to EPA/600/4-90/027	usina fr	reshwater and/or Marine Organisms	N
9	Physical Properties Testing of Hazardous Waste (1			
	Ignitability by Flashpoint determination (Title 2 Corrosivity - pH determination (Title 22, CCR, 66	3 650	(/2/1 24)	
9.1	Ignitability by Flashpoint determination (little 2	Z, CCR,	00201.21)	N
9.2	Corrosivity - pH determination (Title 22, CCR, 66	261.22)	***************************************	۲
9.3	Corrosivity - Corrosivity towards steel (Title 22	CCR, 6	66261.22)	ì
9.4	Reactivity (Title 22, CCR, 66261.23)		***************************************	Y
10	Inorganic Chemistry and Toxic Chemical Elements o	f Hazer	dous Vaste	
10.1	Antimony	10.7	Cobalt	
	7040(07-03-91) Y	, • 11	7200(07-03-91)	٧
	7041(07-03-91)		7201(07-03-91)	٠
				ı
10.2	Arsenic	10.8	Copper	
	7060(07-03-91) Y		7210(07-03-91)	۲
	7061( N		7211(07-03-91)	Y
10.3	Barium	10.9	Lead	
	7080(07-03-91) Y		7420(07-03-91)	Y
	7081(07-03-91) Y		7421(07-03-91)	Y
10 /		10.10		•
10.4	Beryllium	10.10	7470(07-03-91)	
	7090(07-03-91) Y		/4/0(07-03-91)	7
	7091(07-03-91) Y		7471(07-03-91)	۲
10.5	Cadmium	10.11	Mot ybdenum	
	7130(07-03-91) Y		7480(07-03-91)	Y
	7131(07-03-91) Y		7481(07-03-91)	Ý
10.6	Chromium, total	10 13	? Nickel	•
10.0	7190(07-03-91) Y	19.12	7520(07-03-91)	u
	7194(07-03-71)		1360(V/103-Y1)	1
	7191(07-03-91) Y			

CERTIFICATE NUMBER: 1563 EXPIRATION DATE: 07-31-95 10.13 Selenium 7740(07-03-91) ----- Y 10.19 Cyanide 7741(-----) ------ N 9010(07-03-91) 10.20 Fluoride 10-14 Silver 7760(07-03-91) ----- Y 300.0(11-09-93) ------7761(07-03-91) ----- Y 340.1(-----) ------ N 340.2(07-03-91) ----- y Thallium 7840(07-03-91) ----- Y 340.3(------7841(07-03-91) ----- Y Sulfide Vanadium 9030(07-03-91) ------7910(07-03-91) ----- Y 10.22 Total Organic Lead 7911(07-03-91) ----- Y (07-03-91) ----- y 10.23 EPA Method 6010(11-09-93) ----- Y Zinc 7950(07-03-91) ----- y 10.24 EPA Method 6020(-----) 7951(07-03-91) ----- Y Chromium (YI) 7195(----- N 7196(07-03-91) ----- Y 7197(-----) ------ N 7198(-----11 Extraction Tests of Mazardous Waste (07-03-91) California Waste Extraction Test (WET) (Title 22, CCR, 66261.100, Appendix II) ------ Y 11.1 11.2 Extraction Procedure Toxicity -----11.3 11.4 11.5 11.6 12 Organic Chemistry of Nazardous Vaste (Reesurement by GC/MS combination) EPA method 8270(07-03-91) ------Y 12.2 12.3 12.4 12.5 12.6 13 Organic Chemistry of Hazardous Waste (excluding measurements by GC/MS combination) EPA Method 8010(07-03-91) ----- Y 13.13 EPA Method 8310(----- N 13.14 EPA Method 632 (-----) EPA Method 8015(07-03-91) ----- Y 13.2 13.15 Total Petroleum Hydrocarbons (LUFT Manual) (07-31-93)----13.3 EPA Method 8020(07-03-91) ----- Y EPA Method 8030(----- N 13.4 EPA Method 8040(07-03-91) ----- Y 13.16 EPA Method 8011(11-09-93) ----- Y 13.5 13.17 EPA Method 8021(----- N 13.18 EPA Method 8070(----- N 13.6 EPA Method 8060(----- N EPA Method 8080(07-03-91) ----- Y 13.7 EPA Hethod 8090(----- ) 13.19 EPA Method 8110(-----) 13.8 13.20 EPA Method 8141(----- ) EPA Method 8100(----- N 13.9 EPA Method 8120(----- ) 13.21 EPA Method 8330(----- N 13.10 EPA Method 8140(----- N 13.11 13.12 EPA Method 8150(07-03-91) ----- Y 14 Bulk Asbestos Analysis (-----) 1% or Greater Asbestos Concentrations (Title 22, CCR, 66261.24(a)(2)(A)) -----N 14.1 Substances Regulated Under the California Safe Drinking Water and Toxic Enforcement Act (Proposition 65) and Not Included in Other (isted Groups, Wastewater Inorganic Chemistry, Nutrients and Demand (07-03-91) 16 16.12 Cyanide ----- Y
16.13 Cyanide emenable to Chlorination ----- Y 16.1 Alkalinity -----Y 16.2 Ammonia ----- Y 16.3 Biochemical Oxygen Demand ------ Y 16.4 16.16 Kjeldahi Nitrogen Y
16.17 Magnesium Y
16.18 Nitrate Boron ----- Y 16.5 16.6 Calcium 16.7 16.19 Nitrite ----- Y C800 ----- Y 16.8 16.20 Oil and Grease

16.21 Organic Carbon -----Y

16.22 Oxygen, Dissalved ----- Y

Chemical Oxygen Demand ----- Y

16.10 Chloride ----- Y

16.11 Chlorine Residual, total ----- Y

16.9

Atomic Absorption Spectrophotometry Inductively Coupled Plasma Atomic Emission Spectrophotometry ------ N Inductively Coupled Plasma/Mass Spectrometry

Dairy Products by One of the Following Methods

20.3

# CERTIFICATE NUMBER: 1563 EXPIRATION DATE: 07-31-95

20.4	Feed Products by One of the Following Methods . Atomic Absorption Spectrophotometry	N
21	Organic Chemistry of Pesticide Residues in Food (measurements by GC/MS) ()	
21.1 21.2 21.3 21.4	Gas Chromatographic/Mass Spectrometric Methods in Processed Foods	N
22	Organic Chemistry of Pesticide Residues in Food (Excluding Measurement by GC/MS Combination)	
22.1	Halogenated Compounds in Processed Foods by One of the Following Methods Gas Chromatography High Pressure Liquid Chromatography Liquid Chromatography/Mass Spectrometry	i
22.2	Organophosphorous Compounds in Processed Foods by One of the Following Methods  Gas Chromatography  High Pressure Liquid Chromatography	N K
22.3	Liquid Chromatography/Mass Spectrometry  Carbamates in Processed Foods by One of the Following Methods  Gas Chromatography  High Pressure Liquid Chromatography	N
22.4	Liquid Chromatography/Mass Spectrometry	N
22.5	Liquid Chromatography/Mess Spectrometry  Organophosphorous Compounds in Raw Commodities by One of the Following Methods  Gas Chromatography  High Pressure Liquid Chromatography	N
22.6	Liquid Chromatography/Hess Spectrometry  Carbamates in Raw Commodities by One of the Following Methods  Gas Chromatography  High Pressure Liquid Chromatography	N
22.7	Liquid Chromatography/Mass Spectrometry Halogenated Compounds in Dairy Products by One of the Following Methods Gas Chromatography High Procure Liquid Chromatography	N
22.8	Liquid Chromatography/Mess Spectromatry  Organophosphorous Compounds in Dairy Products by One of the Following Methods Gas Chromatography  High Pressure Liquid Chromatography  Liquid Chromatography/Mess Spectromatry	N
22.9	Carbamates in Dairy Products by One of the Following Methods  Gas Chromatography	N
22.10	Halogenated Compounds in Feed Products by One of the Following Methods Gas Chromatography High Pressure Liquid Chromatography Liquid Chromatography/Hass Spectrometry	N
22.11	Organophosphorous Compounds in Feed Products by One of the Following Methods  Gas Chromatography	N
22.12	Carbamates in Feed Products by One of the Following Methods Gas Chromatography High Pressure Liquid Chromatography Liquid Chromatography/Mass Spectrometry	И

Section No: 12 Page: 19 of 21 Revision No: 2.0 Date: January 15, 1994

Performance and System Audits

Figure 12-4 FGL Santa Paula - NV DHR Certification

This page intentionally left blank for figures on next 2 pages.

BOB MILLER

Governor

PETER G. MORROS.

 Administration
 (702) 687-4670

 Air Quality
 687-5065

 Mining Regulation and Reclamation
 687-4675

 Water Quality Planning
 687-5883

 Water Pollution Control
 687-5870

 Fax
 687-5856



 Waste Management
 687-5872

 Chemical Hazards Management
 687-5872

 Federal Facilities
 687-5872\*

 Fax
 885-0868

#### DEPARTMENT OF CONSERVATION AND NATURAL RESOURCES

## DIVISION OF ENVIRONMENTAL PROTECTION

Capitol Complex

333 W. Nye Lane

Carson City, Nevada 89710

FGL ENVIRONMENTAL, INC. CA140 853 CORPORATION STREET SANTA PAULA, CA 93061 CONTACT

KURT WILKINSON

PHONE

(805) 659-0910

Pursuant to regulations adopted by the State Environmental Commission, the State of Nevada will accept data from this laboratory for the following contaminants under the Clean Water Act based performance evaluation sample results from the following studies:

WP030 WP031

THIS CERTIFICATE IS EFFECTIVE THRU SEPTEMBER, 1994, OR UNTIL WP032 IS EVALUATED.

MINERAL	NUTRIENTS	METALS	DEMANDS	ORGANICS	MISCELLANEOUS
pH SPEC. COND.	* AMMONIA-N NITRATE ORTHO-P	ALUMINUM ARSENIC BERYLLIUM	TOC 5-DAY BOD	PCBs IN OIL PESTICIDES	CYANIDE TSS (NFR) * OIL & GREASE
HARDNESS CALCIUM	KJELDAHL-N TOTAL-P	CAIMIUM COBALT	3 3.1. 505	VOLATILE HALOCARBONS VOLATILE AROMATICS	
MAGNESIUM SODIUM		CHROMIUM COPPER			
POTASSIUM		IRON MERCURY			
CHLORIDE FLUORIDE		MANGANESE NICKEL			
SULFATE		LEAD SELENIUM			
		VANADIUM ZINC ANTIMONY			
		SILVER THALLIUM			•
	,	* MOLYBDENUM STRONTIUM			

LAST ON-SITE

\* PROVISIONAL ACCEPTANCE

Recommended:

3-24-94

Approved:

3/25/94

Robert J. Vicks

Chemistry Certification Officer

Quality Assurance Officer

BOB MILLER Governor

SCOTT M. CRAIGIE Director



YVONNE SYLVA Administrator

DONALD S. KWALICK, MD, MPH State Health Officer

#### STATE OF NEVADA

# DEPARTMENT OF HUMAN RESOURCES

HEALTH DIVISION

BUREAU OF LABORATORY SERVICES

FGL ENVIRONMENTAL, INC. CA140

CONTACT

KURT WILKINSON

853 CORPORATION STREET SANTA PAULA, CA 93061

PHONE

(805) 659-0910

Pursuant to regulations adopted by the State Board of Health, the State of Nevada will accept data from this laboratory for the following contaminants under the Safe Drinking Water Act based performance evaluation sample results from EMSL-LV radiochemistry and the following studies:

WS032 WS033 WP030 WP031

THIS CERTIFICATE IS EFFECTIVE THRU OCTOBER, 1994, OR UNTIL WP032 AND WS034 ARE EVALUATED.

INORGANIC	S	ORGANICS		RADIOCHEMISTRY
PRIMARY	SECONDARY	ALACHLOR * ATRAZINE	TRIHALOMETHANES (THMs)	GROSS ALPHA GROSS BETA
ANTIMONY	Ha	CHLORODANE	VOLATILE ORGANIC	RADIUM-226
ARSENIC	SPEC. COND.	ENDRIN	COMPOUNDS (VOCs)	RADIUM-228
BARIUM		HEPTACHLOR	INCLUDING	
BERYLLIUM	HARDNESS	HEPTACHLOR EPOXIDE	VINYL CHLORIDE	URANTUM
CADMITUM	CALCIUM	<b>HEXACHLOROBENZENE</b>		
CHROMIUM	MAGNESTUM	HEXACHLOROCYCLOPENT	ADIENE	
COPPER	SODIUM	LINDANE		
LEAD	POTASSIUM	METHOXYCHLOR	ETHYLENE DIBROMIDE (EDB)	
MERCURY		SIMAZINE	DIBROMOCHLOROPROPANE (DB	
NICKEL	CHLORIDE	TOXAPHENE		
SELEVIUM	SULFATE		DECACHLOROBIPHENYL	
SILVER	IRON	2.4-D		
THALLIUM	MANGANESE	2,4,5-TP	BENZO (A) PYRENE	
NITRATE-N	ZINC	DALAPON	BIS (2-ETHYLHEXYL) ADIPATE	
NITRITE-N		DINOSEB	BIS (2-ETHYLHEXYL) PHTHALA	
FLUORIDE		PENTACHLOROPHENOL *		
DOS 677 AD DOS		PICLORAM	ENDOTHALL	
RES CHLORINE		* ALDICARB	GLYPHOSATE	
TURBIDITY TOTAL CYANIDE		ALDICARB SULFONE		
TOTAL CTANTOE		ALDICARB SULFOXIDE		
		CARBOFURAN		
LAST ON-SITE		OXAMYL (VYDATE)		
TADI ON SIII		CILLIA (TIDELLA)		

\* PROVISIONAL ACCEPTANCE

LABORATORY CERTIFICATION OFFICER

DATE

FY 1994

<b>-</b>	
	<u> </u>
	<del>-</del>
	<b>k</b> A. ,
	Mer -
	gec/s
	gks* -
	,
	• •
	<u>:</u>
	i,
	M. C.
	j
	1 25 2

Section No: 13
Page: 1 of 1
Revision No: 2.0

Date: January 15, 1994

## Preventative Maintenance

## 13.1 Maintenance and Repair of Instruments

Routine maintenance of equipment is performed by the analyst when appropriate. The department supervisor must be notified immediately if any sign of serious malfunction occurs in any instrument so that he can decide if a qualified serviceman should be consulted. If warranted, instrument repair and calibration is performed by qualified service technicians (usually service representatives of the instrument manufacturer). A record containing the date, the nature of the problem, description of the repair, and the name of the technician is also kept.

# 13.2 Good Laboratory Practices

Good laboratory practices are followed to prevent contamination of samples and standards. This includes the careful cleaning of glassware, and the use of disposable labware and containers when practical. Sample containers are monitored for contamination when received, according to lot number and proposed use.

The bacteriology water is monitored for suitability. Standard plate count, electrical conductivity and residual chlorine are checked monthly. Heavy metals (including lead, cadmium, chromium, copper, nickel and zinc) are checked annually.

-			
		, E-	
		:	
		· · · · · · · · · · · · · · · · · · ·	
	-	· save-set	
		† ;	
		`u	
		r.	
		: 60	w.
		- स्ट	
		: :	
		:	
		:	

Section No: 14 Page: 1 of 2 Revision No: 2.0 Date: January 15, 1994

Specific Routine Procedures used to assess Data Precision, Accuracy, and Completeness

Before analytical data can be used, it is necessary to determine the suitability of the data for a given purpose. The characteristics used to determine data suitability are precision, accuracy, and completeness. FGL Environmental deterimines these characteristics by using specific procedures, which are detailed in the following sections.

### 14.1 Precision

Precision is the measure of how closely replicate analyses agree. FGL Environmental uses Relative Percent Difference (RPD) to measure between duplicate analyses.

Precision is monitored for nearly all methods by RPD's plotted on control charts. The mean RPD +/- 2 standard deviations are the warning limits, and the mean RPD +/- 3 standard deviation are the control limits. To assess precision, FGL Environmental uses the following on a regular basis:

- (1) Duplicate samples
- (2) Duplicate Matrix Spikes
- (3) Control Charts

#### 14.1.1 Precision Calculation

The RPD of duplicate samples is an absolute value from the following calculation:

(First Sample Value - Second Sample Value) X 100

(First Sample Value + Second Sample Value) / 2

### 14.2 Accuracy

Accuracy measures the deviation of the analytical value from the "true" or known value. The true value for field samples are never known, so accuracy measurements are made on the analysis of QC samples analyzed with field samples.

Accuracy is monitored for nearly all methods by percent recoveries plotted on control charts. The mean recovery +/-2 standard deviation are the warning limits, and the mean recovery +/-3 standard deviation are the control limits. To assess accuracy, FGL Environmental uses the following on a regular basis:

- (1) Laboratory Control Samples
- (2) Matrix Spikes
- (3) Matrix Spike Duplicates
- (4) Surrogate Spikes
- (5) Control Charts

# 14.2.1 Accuracy Calculations

Percent recoveries are calculated as follows (identical units would be used through each calculation):

Laboratory control sample percent recoveries:

value found X 100

Section No: 14 Page: 2 of 2 Revision No: 2.0 Date: January 15, 1994

Specific Routine Procedures used to assess Data Precision, Accuracy, and Completeness

14.2.1 Accuracy Calculations continued Spike percent recoveries:

(spiked sample result - sample result) X 100

spike amount added

14.3 Completeness

Completeness is defined by QAMS-005/80 as - a measure of the amount of valid data obtained from a measurement system compared to the amount that was expected to be obtained under correct normal conditions.

By this definition the influence of the laboratory on completeness involves three areas: appropriate sample handling and storage, conformance to holding time requirements and data validity as measured by meeting acceptance criteria for the quality control parameters. At FGL we extend this one step further and also measure the complete final report package received by the client. By using non-conformance reports to the QA Director or Officer we record deficiencies in the final report being received by the client.

14.3.1 Completeness Calculations
Completeness is calculated as follows:

number of report deficiences for the year X 100

total number of reports for the year

Section No: 15 Page: 1 of 3 Revision No: 2.0 Date: January 15, 1994

# **Corrective Actions**

Corrective actions are necessary when trends of more than one out-of- control situations occur. Corrective action reports are used to document the corrections made. Corrective actions are not normally used in isolated out-of-control situations that have routine explanations as the data in these situations must be resolved before continuing and reporting analyses.

# 15.1 Corrective Action Reports

Each work area has a corrective action report logbook. When corrective actions are necessary, a corrective action report form (figure 15-1) is filled out identifying the analyst, date, method, client and lab number (if applicable), QA batch number (if applicable) problems encountered, investigation and proposed corrective actions. After implementing the actions another entry is required to verify that the problem was solved. This process may need to be repeated in some situations. The reports are on record and will be included in a project data package if that is required by the project plan. An example of a corrective action report form is shown in figure 15-1.

Section No: 15 Page: 2 of 3 Revision No: 2.0 Date: January 15, 1994

**Corrective Actions** 

Figure 15-1 Corrective Action Report Form

This page intentionally left blank for figure on next page.

Section No: 15 Page: 3 of 3 Revision No: 2.0 Date: January 15, 1994

# **Corrective Actions**

Corrective Action Report Form		
Method:		
Problem Assigned To:		
Problem encountered:	-1.2	
Cause of the problem:		
Corrective action:		
	10.0	
Closure of Investigation:		
_	Date	
Performed by:		
Verified by:	Date:	

<del>-</del>	
	• •
	î
	<u>:</u> ?
	Ť
	ř
	2003
	F <sup>1</sup>
	; (
	:
	 ¥ 6-
	(R)5
	;
$oldsymbol{\cdot}$	
	; f

Section No: 16
Page: 1 of 3
Revision No: 2.0
Date: January 15, 1994

### Quality Assurance Reports to Management

In order to insure that the Quality Assurance program at the lab maintains a high profile, there are several mechanisms in place which insure the QA information is routinely conveyed to laboratory management. This includes a formal monthly QA inspection summary report, reports on internal and external PE samples and summary reports for external system audits.

### 16.1 Monthly QA Inspection Summary Reports

The QA Director or Officer prepares a report to all managers on a monthly basis. This is a two section report containing the following details:

- (1) All uncompleted non-conformance items, the manager responsible for resolving the item, and date found.
- (2) All completed non-conformance items, the manager responsible and the date resolved.

This provides a historical record of progress in quality control and tracks non-conformance items that have not been resolved. This helps management prioritize on going non-conformance items.

### 16.2 Performance Evaluation Failure Reports

Evaluations of any failures on external PE samples are outlined by department supervisors and prepared by the QA Director or Officer for certifying agencies. Copies are given to the department supervisors and Lab Director.

### 16.3 External System Audit Summary Reports

After debriefing by the auditors a summary report is prepared by the QA Director or Officer for the supervisors and Lab Director. Rather than waiting for an audit report, this initiates corrective actions for any non-conformance items promptly.

Section No: 16 Page: 2 of 3
Revision No: 2.0
Date: January 15, 1994

Quality Assurance Reports to Management

Figure 16-1 FGL QA Inspection Summary Report Form

This page intentionally left blank for figure on next page.

Section No: 16 Page: 3 of 3 Revision No: 2.0 Date: January 15, 1994

# Quality Assurance Reports to Management

FGL QC Inspection Non-Comformance Summary Report							
Current Non-conformance Items							
Non-Comformance Item	Person Resp.	Date Found					
Corrected Non-comformance Items							
Non-Comformance Item	Person Resp.	Date Found	Date Comp.				

•	
	; ;
	<u>.</u>
	₩.
	Ma
	<b>16</b> 15
	4
	<b>‡</b>

Section No: Appendix A

Page: 1 of 2

Revision No: 2.0

Date: January 15, 1994

### **Equipment List**

FGL is dedicated to having state-of-the-art equipment throughout thelaboratory. The top quality equipment is essential to providing reliable data. Autosamplers are used when available and appropriate to increase throughput. The following is a list of equipment:

#### **Organics**

- 5 GCMS's -
  - 1 HP 5890II/5972 with 7673A autosampler
  - 1 HP 5890II/5972 with LSC3000/ALS2016 autosampler
  - 1 HP 5890II/5971A with 7673A autosampler
  - 1 HP 5890/5970 with 7673A autosampler
  - 1 Finnigan XL 50 with LSC2000/ALS2032 autosampler
- 9 GC's -
  - 2 HP 5890 with ECD + ECD detectors and 7673A autosampler
  - 1 HP 5890 with NPD + NPD detectors and 7673A autosampler
  - 1 HP 5890 with NPD + FPD detectors and 7673A autosampler
  - 1 HP 5890 with PID detector and LSC2000/ALS2016 autosampler
  - 1 HP 5890 with FID detector and LSC2000/ALS2016 autosampler
  - 1 HP 5890 with FID detector
  - 1 HP 5890 with ELCD + ELCD detectors
  - 1 Varian 3700 with ECD + ECD detectors
  - 1 Varian 3700 with ECD + FPD + FID detectors
- 2 HPLC's -
  - 1 HP 1090 with UV and fluorescence detectors and postcolumn derivatization
  - 1 Hitachi system with diode array and fluorescence detectors
- 2 IR's -
  - 1 Perkin-Elmer 700
  - 1 Foxboro Miran 1FF
- 1 TOX -

1 MCI TOX 10

- 1 TOC -
  - 1 ASTRO 2001

#### **Inorganics**

- 1 ICP/MS -
  - Fisons PlasmaQuad 2
- 2 ICP's -
  - 1 ARL 3410 with model 101 autosampler
  - 1 Thermo-Jarrell Ash Atomscan 25
- 2 Graphite Furnaces with Zeeman-AA -
  - 1 Perkin-Elmer 5100Z with AS-60 autosampler
  - 1 Hitachi **Z-8100**

Section No: Appendix A

Page: 2 of 2

Revision No: 2.0 Date: January 15, 1994

### **Equipment List**

### **Inorganics continued**

- 2 Flame AA's -
  - 2 Perkin-Elmer 5000
- 2 Microwave Digesters -
  - 2 CEM MDS 2100 Microwave Digester
- 2 IC's -
  - 2 Dionex 300 Ion Chromatograph and Spectraphysics AS3500 autosampler
- 3 Autoanalyzer's -
  - 3 Technicon AA2 autoanalyzer
- 3 UV/VIS Spectrophotometer's -
  - 1 Perkin-Elmer Lambda 3
  - 1 Beckman model 24
- 2 Nephelometers (turbidimeters) -
  - 2 Sequia-Turner model 690

### Radioactivity

- 1 Gamma ray spectroscope -
  - 1 Princeton Gamma Tech
- 1 Liquid scintillation autoanalyzer -
  - 1 Packard 2500TR
- 7 Proportional counter's -
  - 5 NMC PCC11T Alpha counters
  - 2 Tennelec LB 1000 Alpha/Beta counters
  - 1 Tennelec LB 5100 Alpha/Beta counter with autosampler

### **Microbiology**

- 3 Incubators
- 3 Autoclaves

#### **Field Services**

- 11 Field vehicles
- 8 Isco composite autosamplers

#### LIMS capabilities

- 3 Microvax with PCSA pathworks fileserver and Dbase IV
- 80 DOS/OS2/Windows based computers



# APPENDIX F BLANK, DUPLICATE, AND SPIKE SAMPLE ANALYTICAL REPORTS

July 20, 1994

LAB No: SP 403653-2

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus, CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW5/C/23 - 1A

Sampled : June 22, 1994

Sampled by : Tim Bricker

Received: June 22, 1994

Container : Amber Glass TFE-Cap

.Extracted : N/A

Preservatives: H2SO4 pH < 2

Analyzed: June 30, 1994 QA/QC ID# : SP 94063000A

### TOTAL ORGANIC HALOGENS

CONSTITUENT	EPA METHOD	UNITS	SAMPLE DLR	SAMPLE RESULTS	LAB DLR	BLANK RESULTS
TOX	9020	ug/L	5	ND	5	סא

DLR - Detection Limit for Reporting Purposes. MCL - Maximum Contaminant Level (--- indicates none determined.) NO = Not Detected at or above the DLR. ug/L = Micrograms Per Liter (ppb)

\* = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

kéllý A. Dunnahoo, B.S.

Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director

July 20, 1994

LAB No: SP 403653-2

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus , CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW5/0/23 - 1A

Sampled : June 22, 1994

Sampled by : Tim Bricker

Received: June 22, 1994

Container : Glass TFE-Cap

Extracted: N/A

Preservatives:

Analyzed: June 28, 1994 QA/QC ID# : SP 94062800K

### EPA METHOD 601

CONSTITUENT	SAMPLE	SAMPLE	LAB	BLANK
	DLR	RESULTS	DLR	RESULTS
	ug/L	ug/L	ug/L	ug/L
Trichloroethylene	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) Ug/L = Micrograms Per Liter (ppb) ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

UK€11∮ A. Dunnahoo, B.S.

Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director



July 15, 1994

LAB No: SP 403654-2

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus , CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW6/0/23 - 1A

Sampled by : Tim Bricker Container : Glass TFE-Cap

Preservatives:

Sampled : June 22, 1994 Received: June 22, 1994

Extracted: N/A

Analyzed: June 28, 1994 QA/QC ID# : SP 94062800K

### EPA METHOD 601

CONSTITUENT	SAMPLE	SAMPLE	LAB	BLANK
	DLR	RESULTS	DLR	RESULTS
	ug/L	ug/L	ug/L	ug/L
Trichloroethylene	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) ND = Not Detected at or above the DLR. ug/L = Micrograms Per Liter (ppb)

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

éll<sup>(</sup>y A. Dunnahoo, B.S*.* 

Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director

### APPENDIX G

ANALYTICAL REPORTS FOR BACKGROUND WATER QUALITY PARAMETERS AND GROUND WATER MONITORING PARAMETERS

July 11, 1994

LAB No: SP 403651-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road RE: Inorganic Analysis

Saugus, CA 91350

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Description: MW1/A,H,N,S/23 Sampled : June 22, 1994 Sampled by : Tim Bricker Received : June 22, 1994 Type of Sample: Monitoring Well Completed : June 29, 1994

QA/QC ID# : 40365101-

### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS
Chloride Conductivity Fluoride Nitrate pH Sulfate	300.0 120.1 340.2 353.2 150.1 300.0	mg/L umhos/cm2 mg/L mg/L units mg/L	2.0* 1 0.1 0.4  2.0*	150 740 0.2 3.6 7.5

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR.

ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram
• = DLR adjusted because of dilutions, concentrations, or limited sample.

Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S. Inorganic Lab Manager Darrell H. Nelson, B.S. Laboratory Director

KW/DHN:cl



July 15, 1994

LAB No: SP 403651-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus, CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW1/B/23

Sampled : June 22, 1994

Sampled by : Tim Bricker

Received: June 22, 1994

Container : Amber Glass TFE-Cap

Extracted: N/A

Preservatives: H2SO4 pH < 2

Analyzed: July 1, 1994 QA/QC ID# : SP 94063000A

### TOTAL ORGANIC CARBON

CONSTITUENT	EPA METHOD	UNITS	SAMPLE DLR	SAMPLE RESULTS	LAB DLR	BLANK RESULTS
TOC	415.1	mg/L	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) mg/L = Milligrams Per Liter (ppm) ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kéll√ A. Dunnahoo, B.S.

Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director



July 15, 1994

LAB No: SP 403651-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road RE: Organic Analysis Matrix: Monitoring Well

Saugus, CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW1/C/23

Sampled : June 22, 1994 Received : June 22, 1994

Sampled by : Tim Bricker

Extracted : N/A

Container : Amber Glass TFE-Cap

Analyzed: June 30, 1994

Preservatives: H2SO4 pH < 2

QA/QC ID# : SP 94063000A

### TOTAL ORGANIC HALOGENS

CONSTITUENT	EPA METHOD	UNITS	SAMPLE DLR	SAMPLE RESULTS	LAB DLR	BLANK RESULTS
TOX	9020	ug/L	5	ND	5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.)
ug/L = Micrograms Per Liter (ppb)

ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kélly (A. Dunnahoo, B.S. Organic Laboratory Manager

Darrell H. Nelson, B.S.

Laboratory Director

Analytical Chemists GENERAL MINERAL, PHYSICAL, INORGANIC, & RADIOLOGICAL CHEMICAL ANALYSES

Date of Report: July 12, 1994

Laboratory

Name: FGL Environmental

Name of Sampler: Tim Bricker

Date/time Sample

Date/Time

Sample

Date Analyses

Collected: 06/22/94-10:06 Rec. @ Lab: 06/22/94-13:26

Employed By: Bermite

Signature Lab

Director:

Completed: 06/27/94

System

Name: Bermite Division of Whittaker

System Number:

Sample ID No. 8P

Name or Number of Sample Source: MW1/E/23

User ID:

Station Number:

Date/Time of Sample:

9 4 0 6 2 2 1 0 0 6 Laboratory Code:

YYMMDDTTTT

Date Analyses Completed:

YYMMDD

Submitted by: FGL Environmental

Phone #: (805) 659-0910

#### RADIOACTIVITY ANALYSIS

MCL	UNITS	CONSTITUENT	ENTRY	RESULT	DLR
5-35 ‼ 50		Gross Alpha Gross Alpha Counting Error Gross Beta Gross Beta Counting Error	01501 01502 03501 03502	2 ± 2 4 ± 2	

MCL - Maximum Contaminate Level

DLR - Detection Limit for Reporting purposes

ND - Not Detected at or above DLR

+ Indicates Secondary Drinking Water Standards

 $\blacksquare$  >= 5 May require testing for  $U_{\alpha}$ ,  $^{226}Ra_{\alpha}$  >= 15 Unaccounted Alpha {Total  $\alpha$  -  $U_{\alpha}$ } >= 35 Total Gross Alpha limit.



July 15, 1994

LAB No: SP 403651-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus, CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW1/0/23

Sampled : June 22, 1994 Received : June 22, 1994

Sampled by : Tim Bricker Container : Glass TFE-Cap

Extracted: N/A

Preservatives:

Analyzed: June 28, 1994 QA/QC ID# : SP 94062800K

### EPA METHOD 601

CONSTITUENT	SAMPLE	SAMPLE	LAB	BLANK
	DLR	RESULTS	DLR	RESULTS
	ug/L	ug/L	ug/L	ug/L
Trichloroethylene	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) ND = Not Detected at or above the DLR. ug/L = Micrograms Per Liter (ppb)

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kelly A. Dunnahoo, B.S.

Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director

KAD/DHN:cl

Visatia, CA 209/734-9473

July 11, 1994

LAB No: SP 403651-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Inorganic Analysis

Saugus, CA 91350

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sampled : June 22, 1994 Description: MW1/R,U/23 Received: June 22, 1994 Sampled by : Tim Bricker Completed: June 23, 1994 Type of Sample: Monitoring Well

QA/QC ID# : 40365101-

### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS	MCL
Iron Lead Manganese Sodium	200.7 200.8 200.7 200.7	ug/L ug/L ug/L mg/L	50 0.2 30 1	150 ND ND 54	300 50 50

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR.

ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram

• = DLR adjusted because of dilutions, concentrations, or limited sample.

Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S.

Inorganic Lab Manager

KW/DHN:cl

Darrell H. Nelson, B.S. Laboratory Director



July 12, 1994

LAB No: SP 403651-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Inorganic Analysis

Saugus, CA 91350

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Description: MW1/T/23 Sampled by : Tim Bricker Sampled : June 22, 1994

Received: June 22, 1994 Completed: June 23, 1994

Type of Sample: Monitoring Well

QA/QC ID# : 40365101-

### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS	MCL
Turbidity	180.1	NTU	0.2	1.0	5

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR.

ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram • = DLR adjusted because of dilutions, concentrations, or limited sample.

Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S. Inorganic Lab Manager

Darrell H. Nelson, B.S. Laboratory Director

KW/DHN:cl

July 11, 1994

LAB No: SP 403652-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Inorganic Analysis

Saugus, CA 91350

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sampled : June 22, 1994 Description: MW3/A,H,N,S/23 Received : June 22, 1994 Sampled by : Tim Bricker Completed: June 29, 1994 Type of Sample: Monitoring Well

QA/QC ID# : 40365201-

### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS
Chloride	300.0	mg/L	2.0*	29
Conductivity	120.1	umhos/cm2		630
Fluoride	340.2	mg/L	0.1	0.2
Nitrate	353.2	mg/L	0.4	3.6
pH	150.1	units	2.0*	7.6
Sulfate	300.0	mg/L		71

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR.

ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram • = DLR adjusted because of dilutions, concentrations, or limited sample.

Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S.

Inorganic Lab Manager

KW/DHN:cl

Darrell H. Nelson, B.S.

Laboratory Director

July 15, 1994

LAB No: SP 403652-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus , CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW3/B/23

Sampled : June 22, 1994 Received: June 22, 1994

Sampled by : Tim Bricker

Extracted: N/A

Container : Amber Glass TFE-Cap

Analyzed: June 30, 1994

Preservatives: H2SO4 pH < 2

QA/QC ID# : SP 94063000A

### TOTAL ORGANIC CARBON

CONSTITUENT	EPA METHOD	UNITS	SAMPLE DLR	SAMPLE RESULTS	LAB DLR	BLANK RESULTS
TOC	415.1	mg/L	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) mg/L = Milligrams Per Liter (ppm) ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kelly<sup>(</sup>A. Dunnahoo, B.S.

Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director

KAD/DHN:cl

Santa Paula, CA 93061-0272

Visalia, CA PH:

July 15, 1994

LAB No: SP 403652-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus, CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW3/C/23

Sampled : June 22, 1994 Received : June 22, 1994

Sampled by : Tim Bricker

Container : Amber Glass TFE-Cap

Extracted: N/A

Analyzed: June 30, 1994

Preservatives: H2SO4 pH < 2

QA/QC ID# : SP 94063000A

### TOTAL ORGANIC HALOGENS

CONSTITUENT	EPA METHOD	UNITS	SAMPLE DLR	SAMPLE RESULTS	LAB DLR	BLANK RESULTS
TOX	9020	ug/L	5	8	5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) ug/L = Micrograms Per Liter (ppb) ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kerly A. Dunnahoo, B.S.

Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director

Analytical Chemists GENERAL MINERAL, PHYSICAL, INORGANIC, & RADIOLOGICAL CHEMICAL ANALYSES

Date of Report: July 12, 1994

Sample ID No. SP 403652-1

Laboratory

Signature Lab

Name:

FGL Environmental

Director:

Employed By: Bermite

Name of Sampler: Tim Bricker

Sample

Date Analyses

Date/time Sample

Date/Time

Collected: 06/22/94-10:26 Rec. @ Lab: 06/22/94-13:26 Completed: 06/27/94

System

Name: Bermite Division of Whittaker

System

Number:

Name or Number of Sample Source: MW3/E/23

User ID:

Station Number:

Date/Time of Sample:

9 4 0 6 2 2 1 0 2 6

Laboratory Code:

YYMMDDTTTT

Date Analyses Completed:

9 4 0 6 2 7 YYMMDD

Submitted by: FGL Environmental

Phone #: (805) 659-0910

#### RADIOACTIVITY ANALYSIS

MCL	UNITS	CONSTITUENT	ENTRY	RESULT	DLR
5-35 <b>!!</b> 50	pCi/L pCi/L pCi/L pCi/L	Gross Alpha Gross Alpha Counting Error Gross Beta Gross Beta Counting Error	01501 01502 03501 03502	1.0 ± 1 3 ± 2	

MCL - Maximum Contaminate Level

DLR - Detection Limit for Reporting purposes

ND - Not Detected at or above DLR

+ Indicates Secondary Drinking Water Standards

 $\blacksquare$  >= 5 May require testing for  $U_{lpha}$  ,  $^{226}$ Ra $_{lpha}$  >= 15 Unaccounted Alpha {Total lpha -  $U_{lpha}$  >= 35 Total Gross Alpha limit.

July 15, 1994

Preservatives:

LAB No: SP 403652-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus , CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW3/0/23 Sampled by : Tim Bricker Container : Glass TFE-Cap

Sampled : June 22, 1994 Received: June 22, 1994

Extracted: N/A

Analyzed: June 25, 1994 QA/QC ID# : SP 94062500K

### EPA METHOD 601

CONSTITUENT	SAMPLE	SAMPLE	LAB	BLANK
	DLR	RESULTS	DLR	RESULTS
	ug/L	ug/L	ug/L	ug/L
Trichloroethylene	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) ND = Not Detected at or above the DLR. ug/L = Micrograms Per Liter (ppb)

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kelly A. Dunnahoo, B.S.

Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director

July 11, 1994

LAB No: SP 403652-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Inorganic Analysis

Saugus, CA 91350

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sampled: June 22, 1994 Description: MW3/R,U/23 Sampled by : Tim Bricker Received: June 22, 1994 Completed: June 23, 1994 Type of Sample: Monitoring Well

QA/QC ID# : 40365201-

### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS	MCL
Iron Lead Manganese Sodium	200.7 200.8 200.7 200.7	ug/L ug/L ug/L mg/L	50 0.2 30 1	ND 4.9 ND 53	300 50 50

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR. ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram • = DLR adjusted because of dilutions, concentrations, or limited sample. Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S. Inorganic Lab Manager Darrell H. Nelson, B.S.

Laboratory Director

KW/DHN:cl

July 12, 1994

LAB No: SP 403652-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road RE: Inorganic Analysis

Saugus, CA 91350

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Description: MW3/T/23
Sampled by: Tim Bricker
Type of Sample: Monitoring Well

Sampled : June 22, 1994 Received : June 22, 1994 Completed : June 23, 1994

QA/QC ID# : 40365201-

### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS	MCL
Turbidity	180.1	NTU	0.2	0.3	5

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR.

ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram
• = DLR adjusted because of dilutions, concentrations, or limited sample.

Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S. Inorganic Lab Manager

KW/DHN:cl

Darrell H. Nelson, B.S. Laboratory Director

July 11, 1994

LAB No: SP 403653-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Inorganic Analysis

Saugus, CA 91350

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sampled : June 22, 1994 Description: MW5/A,H,N,S/23 Sampled by : Tim Bricker Received: June 22, 1994 Completed: June 29, 1994 Type of Sample: Monitoring Well

QA/QC ID# : 40365301-

### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS
Chloride	300.0	mg/L	2.0°	40
Conductivity	120.1	umhos/cm2	1	540
Fluoride	340.2	mg/L	0.1	0.2
Nitrate	353.2	mg/L	0.4	3.6
pH	150.1	units		7.7
Sulfate	300.0	mg/L	2.0°	35

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR. ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram • = DLR adjusted because of dilutions, concentrations, or limited sample. Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S. Inorganic Lab Manager Darrell H. Nelson, B.S. Laboratory Director

KW/DHN:cl



July 15, 1994

LAB No: SP 403653-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus , CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW5/B/23

Sampled : June 22, 1994 Received : June 22, 1994

Sampled by : Tim Bricker

Extracted : N/A

Container : Amber Glass TFE-Cap Preservatives: H2SO4 pH < 2

Analyzed: July 1, 1994

QA/QC ID# : SP 94063000A

### TOTAL ORGANIC CARBON

CONSTITUENT	EPA METHOD	UNITS	SAMPLE DLR	SAMPLE RESULTS	LAB DLR	BLANK RESULTS
TOC	415.1	mg/L	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.)
mg/L = Milligrams Per Liter (ppm)
ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kelly (A. Dunnahoo, B.S. Organic Laboratory Manager Darrell H. Nelson, B.S.

Organic Laboratory Manager Laboratory Director

KAD/DHN:c1

Visalia, CA PH: 209/734-9473



July 15, 1994

LAB No: SP 403653-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus , CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW5/C/23

Sampled : June 22, 1994 Received: June 22, 1994

Sampled by : Tim Bricker

Extracted: N/A

Container : Amber Glass TFE-Cap Preservatives: H2SO4 pH < 2

Analyzed: June 30, 1994

QA/QC ID# : SP 94063000A

### TOTAL ORGANIC HALOGENS

CONSTITUENT	EPA METHOD	UNITS	SAMPLE DLR	SAMPLE RESULTS	LAB DLR	BLANK RESULTS
TOX	9020	ug/L	5	ND	5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) ug/L = Micrograms Per Liter (ppb) ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

¢e11√ A. Dunnahoo, B.S.

Darrell H. Nelson, B.S. Laboratory Director

Organic Laboratory Manager

Analytical Chemists GENERAL MINERAL, PHYSICAL, INORGANIC, & RADIOLOGICAL CHEMICAL ANALYSES

Date of Report: July 12, 1994

Sample ID No. SP 403653-1

Laboratory

Signature Lab

Name:

FGL Environmental

Director:

Employed By: Bermite

Name of Sampler: Tim Bricker

Date/Time

Sample

Date Analyses

Date/time Sample

Date Analyses Completed:

Collected: 06/22/94-10:50 Rec. @ Lab: 06/22/94-13:26 Completed: 06/27/94

System

Name: Bermite Division of Whittaker

System Number:

Name or Number of Sample Source: MW5/E/23

User ID:

Station Number:

Date/Time of Sample:

9 4 0 6 2 2 1 0 5 0

Laboratory Code:

YYMMDDTTTT

9 4 0 6 2 7 YYMMDD

Submitted by: FGL Environmental

Phone #: (805) 659-0910

#### RADIOACTIVITY ANALYSIS

MCL	UNITS	CONSTITUENT	ENTRY	RESULT	DLR
5-35 ‼ 50	pCi/L	Gross Alpha Gross Alpha Counting Error Gross Beta Gross Beta Counting Error	01501 01502 03501 03502	1.0 ± 1 3 ± 2	

MCL - Maximum Contaminate Level

DLR - Detection Limit for Reporting purposes

ND - Not Detected at or above DLR

<sup>+</sup> Indicates Secondary Drinking Water Standards

 $<sup>\</sup>blacksquare$  >= 5 May require testing for  $U_{\alpha}$ ,  $^{226}Ra_{\alpha}$  >= 15 Unaccounted Alpha {Total  $\alpha$  -  $U_{\alpha}$ } >= 35 Total Gross Alpha limit.

July 15, 1994

LAB No: SP 403653-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

Saugus , CA 91350

RE: Organic Analysis Matrix: Monitoring Well

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW5/0/23 Sampled by : Tim Bricker Container : Glass TFE-Cap

Preservatives:

Sampled : June 22, 1994 Received : June 22, 1994

Extracted: N/A

Analyzed: June 28, 1994 QA/QC ID# : SP 94062800K

### EPA METHOD 601

CONSTITUENT	SAMPLE	SAMPLE	LAB	BLANK
	DLR	RESULTS	DLR	RESULTS
	ug/L	ug/L	ug/L	ug/L
Trichloroethylene	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) ug/L = Micrograms Per Liter (ppb) ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kelly A. Dunnahoo, B.S.

Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director



July 11, 1994

LAB No: SP 403653-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Inorganic Analysis

Saugus, CA 91350

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Description: MW5/R,U/23 Sampled : June 22, 1994
Sampled by : Tim Bricker Received : June 22, 1994
Type of Sample: Monitoring Well Completed : June 23, 1994

QA/QC ID# : 40365301-

### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS	MCL
Iron Lead Manganese Sodium	200.7 200.8 200.7 200.7	ug/L ug/L ug/L mg/L	50 0.2 30 1	70 ND ND 54	300 50 50

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR.

ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram

 $\phi$  = DLR adjusted because of dilutions, concentrations, or limited sample. Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S. Inorganic Lab Manager

KW/DHN:cl

Darrell H. Nelson, B.S. Laboratory Director

July 12, 1994

LAB No: SP 403653-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Inorganic Analysis

Saugus, CA 91350

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Description: MW5/T/23 Sampled by : Tim Bricker Type of Sample: Monitoring Well

Sampled : June 22, 1994 Received: June 22, 1994 Completed: June 23, 1994

QA/QC ID# : 40365301-

### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS	MCL
Turbidity	180.1	NTU	0.2	0.9	5

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR. ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram • = DLR adjusted because of dilutions, concentrations, or limited sample.

Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S. Inorganic Lab Manager

KW/DHN:cl

Darrell H. Nelson, B.S. Laboratory Director

July 11, 1994

LAB No: SP 403654-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

Saugus , CA 91350

RE: Inorganic Analysis

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Description: MW6/A,H,N,S/23 Sampled : June 22, 1994 Sampled by : Tim Bricker Received: June 22, 1994 Completed: June 29, 1994 Type of Sample: Monitoring Well

QA/QC ID# : 40365401-

### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS
Chloride Conductivity Fluoride Nitrate pH Sulfate	300.0 120.1 340.2 353.2 150.1 300.0	mg/L umhos/cm2 mg/L mg/L units mg/L	2.0° 1 0.1 0.4  2.0°	65 550 0.2 3.8 7.7

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR.

ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram • = DLR adjusted because of dilutions, concentrations, or limited sample.

Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S. Inorganic Lab Manager

KW/DHN:cl

Darrell H. Nelson, B.S. Laboratory Director

> Field Office Visalia, CA



July 15, 1994

LAB No: SP 403654-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road RE: Organic Analysis Matrix: Monitoring Well

Saugus, CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW6/B/23

Sampled : June 22, 1994 Received : June 22, 1994

Sampled by : Tim Bricker

Extracted : N/A

Container : Amber Glass TFE-Cap Preservatives: H2SO4 pH < 2

Analyzed : July 1, 1994

QA/QC ID# : SP 94063000A

### TOTAL ORGANIC CARBON

CONSTITUENT	EPA METHOD	UNITS	SAMPLE DLR	SAMPLE RESULTS	LAB DLR	BLANK RESULTS
TOC	415.1	mg/L	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.)
mg/L = Milligrams Per Liter (ppm)
ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kelly A. Dunnahoo, B.S. Organic Laboratory Manager Darrell H. Nelson, B.S. Laboratory Director

KAD/DHN:cl

Visalia, CA PH: 209/734-9473



## ENVIRONMENTAL

### **Analytical Chemists**

August 1, 1994

LAB No: SP 403654-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus, CA 91350

Sampling Site: Rermite 317 Area 23rd Qtr. Water Sampling 85 01.4

Sample Description: MW6/C/23

Sampled : June 22, 1994 Received: June 22, 1994

Sampled by : Tim Bricker

Extracted: N/A

Container : Amber Glass TFE-Cap

Analyzed: June 30, 1994

Preservatives: H2SO4 pH < 2

QA/QC ID# : SP 94063000A

### TOTAL ORGANIC HALOGENS

CONSTITUENT	EPA METHOD	UNITS	SAMPLE DLR	SAMPLE RESULTS	LAB DLR	BLANK RESULTS
TOX	9020	ug/L	5	ND	5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Meximum Contaminant Level (--- indicates none determined.) NO = Not Detected at or above the DLR. ug/L = Micrograms Per Liter (ppb)

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kelly A. Dunnahoo, B.S. Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director



Analytical Chemists GENERAL MINERAL, PHYSICAL, INORGANIC, & RADIOLOGICAL CHEMICAL ANALYSES

Date of Report: July 12, 1994

Laboratory

FGL Environmental Name:

Name of Sampler: Tim Bricker Date/time Sample

Collected: 06/22/94-11:16 Rec. @ Lab: 06/22/94-13:26

Date/Time Sample

Director:

Signature Lab

Employed By: Bermite Date Analyses

Completed: 06/27/94

System

Name: Bermite Division of Whittaker

System Number:

Sample ID No. SP

Name or Number of Sample Source: MW6/E/23

User ID:

Station Number:

Date/Time of Sample:

9 4 0 6 2 2 1 1 1 6

Laboratory Code:

YYMMDDTTTT

Date Analyses Completed:

9 4 0 6 2 7 YYMMDD

Submitted by: FGL Environmental

Phone #: (805) 659-0910

#### RADIOACTIVITY ANALYSIS

MCL	UNITS	CONSTITUENT	ENTRY	RESULT	DLR
5-35 ‼ 50	pCi/L pCi/L pCi/L pCi/L	Gross Alpha Gross Alpha Counting Error Gross Beta Gross Beta Counting Error	01501 01502 03501 03502	0.1 ± 1 2 ± 2	

MCL - Maximum Contaminate Level

DLR - Detection Limit for Reporting purposes

ND - Not Detected at or above DLR

+ Indicates Secondary Drinking Water Standards

 $\blacksquare$  >= 5 May require testing for  $U_{\alpha}$ ,  $^{226}Ra_{\alpha}$  >= 15 Unaccounted Alpha {Total  $\alpha$  -  $U_{\alpha}$ } >= 35 Total Gross Alpha limit.

July 15, 1994

LAB No: SP 403654-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus, CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW6/0/23 Sampled by : Tim Bricker

Sampled : June 22, 1994 Received: June 22, 1994

Container : Glass TFE-Cap

Extracted: N/A

Preservatives:

Analyzed: June 28, 1994 QA/QC ID# : SP 94062800K

#### EPA METHOD 601

CONSTITUENT	SAMPLE	SAMPLE	LAB	BLANK
	DLR	RESULTS	DLR	RESULTS
	ug/L	ug/L	ug/L	ug/L
Trichloroethylene	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) ug/L = Micrograms Per Liter (ppb) ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

'kéll& A. Dunnahoo, B.S.

Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director

KAD/DHN:cl

PH: 209/734-9473

July 11, 1994

LAB No: SP 403654-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

Saugus, CA 91350

RE: Inorganic Analysis

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Description: MW6/R,U/23 Sampled by : Tim Bricker Sampled : June 22, 1994

Type of Sample: Monitoring Well

Received: June 22, 1994 Completed: June 23, 1994

QA/QC ID# : 40365401-

#### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS	MCL
Iron Lead Manganese Sodium	200.7 200.8 200.7 200.7	ug/L ug/L ug/L mg/L	50 0.2 30 1	70 ND ND S8	300 50 50

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR. ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram

• = DLR adjusted because of dilutions, concentrations, or limited sample. Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S.

Inorganic Lab Manager

KW/DHN:cl

Darrell H. Nelson, B.S. Laboratory Director

July 12, 1994

LAB No: SP 403654-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road RE: Inorganic Analysis

Saugus , CA 91350

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Description: MW6/T/23 Sampled by : Tim Bricker Sampled : June 22, 1994

Type of Sample: Monitoring Well

Received: June 22, 1994 Completed: June 23, 1994

QA/QC ID# : 40365401-

#### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS	MCL
Turbidity	180.1	NTU	0.2	0.8	5

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR.

ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram

• = DLR adjusted because of dilutions, concentrations, or limited sample.

Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S. Inorganic Lab Manager

KW/DHN:cl

Darrell H. Nelson, B.S. Laboratory Director

July 11, 1994

LAB No: SP 403655-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Inorganic Analysis

Saugus , CA 91350

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sampled : June 22, 1994 Description: MW10/A,H,N,S/23 Received: June 22, 1994 Sampled by : Tim Bricker Completed: June 29, 1994 Type of Sample: Monitoring Well

QA/QC ID# : 40365501-

#### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS
Chloride	300.0	mg/L	2.0*	64
Conductivity	120.1	umhos/cm2	1	610
Fluoride	340.2	mg/L	0.1	0.2
Nitrate	353.2	mg/L	0.4	3.7
рН	150.1	units		7.8
Sulfate	300.0	mg/L	2.0*	39

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR.

ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram

• = DLR adjusted because of dilutions, concentrations, or limited sample. Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

Kurt Wilkinson, B.S.

Inorganic Lab Manager

KW/DHN:cl

FGL ENVIRONMENTAL

Darrell H. Nelson, B.S.

Laboratory Director



July 15, 1994

LAB No: SP 403655-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus , CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW10/B/23

Sampled : June 22, 1994 Received : June 22, 1994

Sampled by : Tim Bricker

Container : Amber Glass TFE-Cap

Extracted: N/A Analyzed : July 1, 1994

Preservatives: H2SO4 pH < 2

QA/QC ID# : SP 94063000A

#### TOTAL ORGANIC CARBON

CONSTITUENT	EPA METHOD	UNITS	SAMPLE DLR	SAMPLE RESULTS	LAB DLR	BLANK RESULTS
TOC	415.1	mg/L	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) ND = Not Detected at or above the DLR. mg/L = Milligrams Per Liter (ppm)

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kélly A. Dunnahoo, B.S.

Darrell H. Nelson, B.S.

Organic Laboratory Manager Laboratory Director

KAD/DHN:cl



July 15, 1994

LAB No: SP 403655-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

RE: Organic Analysis Matrix: Monitoring Well

Saugus , CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW10/C/23

Sampled : June 22, 1994 Received: June 22, 1994

Sampled by : Tim Bricker

Extracted: N/A

Container : Amber Glass TFE-Cap

Analyzed: June 30, 1994

Preservatives: H2SO4 pH < 2

QA/QC ID# : SP 94063000A

#### TOTAL ORGANIC HALOGENS

CONSTITUENT	EPA METHOD	UNITS	SAMPLE DLR	SAMPLE RESULTS	LAB DLR	BLANK RESULTS
TOX	9020	ug/L	5	20	5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.) ug/L = Micrograms Per Liter (ppb) ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kelly A. Dunnahoo, B.S.

Organic Laboratory Manager

Darrell H. Nelson, B.S. Laboratory Director

KAD/DHN:cl

209/734-9473 PH:

Analytical Chemists GENERAL MINERAL, PHYSICAL, INORGANIC, & RADIOLOGICAL CHEMICAL ANALYSES

Date of Report: July 12, 1994

403655-1 Sample ID No. SP

Laboratory

Signature Lab

Name:

FGL Environmental

Director:

Employed By: Bermite

Name of Sampler: Tim Bricker

Date/Time Sample

Date Analyses

Date/time Sample

Collected: 06/22/94-11:41 Rec. @ Lab: 06/22/94-13:26 Completed: 06/27/94

System

Name: Bermite Division of Whittaker

System Number:

Name or Number of Sample Source: MW10/E/23

User ID:

Station Number:

Date/Time of Sample: 9 4 0 6 2 2 1 1 4 1

Laboratory Code: 5867

YYMMDDTTTT

Date Analyses Completed:

9 4 0 6 2 7 YYMMDD

Submitted by: FGL Environmental

Phone #: (805) 659-0910

#### RADIOACTIVITY ANALYSIS

MCL	UNITS	CONSTITUENT	ENTRY	RESULT	DLR
5-35 ‼ 50	pCi/L	Gross Alpha Gross Alpha Counting Error Gross Beta Gross Beta Counting Error	01501 01502 03501 03502	0.4 ± 1 4 ± 2	

MCL - Maximum Contaminate Level

DLR - Detection Limit for Reporting purposes

ND - Not Detected at or above DLR

+ Indicates Secondary Drinking Water Standards

 $\blacksquare$  >= 5 May require testing for  $U_{\alpha}$ ,  $^{226}$ Ra $_{\alpha}$  >= 15 Unaccounted Alpha {Total  $\alpha$  -  $U_{\alpha}$ } >= 35 Total Gross Alpha limit.

July 15, 1994

LAB No: SP 403655-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road RE: Organic Analysis Matrix: Monitoring Well

Saugus , CA 91350

Sampling Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Sample Description: MW10/0/23

Sampled by : Tim Bricker

Container : Glass TFE-Cap

Preservatives:

Sampled : June 22, 1994 Received : June 22, 1994

Extracted: N/A

Analyzed : June 28, 1994

QA/QC ID# : SP 94062800K

#### EPA METHOD 601

CONSTITUENT	SAMPLE	SAMPLE	LAB	BLANK
	DLR	RESULTS	DLR	RESULTS
	ug/L	ug/L	ug/L	ug/L
Trichloroethylene	0.5	ND	0.5	ND

DLR = Detection Limit for Reporting Purposes. MCL = Maximum Contaminant Level (--- indicates none determined.)
ug/L = Micrograms Per Liter (ppb)

ND = Not Detected at or above the DLR.

• = DLR adjusted because of dilutions, concentrations, or limited sample.

If you have any questions, please call.

FGL ENVIRONMENTAL

Kelly A. Dunnahoo, B.S.

Organic Laboratory Manager

KAD/DHN:cl

Darrell H. Nelson, B.S. Laboratory Director

2007

July 11, 1994

LAB No: SP 403655-1

Bermite Division of Whittaker

22116 W. Soledad Canyon Road

Saugus, CA 91350

RE: Inorganic Analysis

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Description: MW10/R,U/23 Sampled by : Tim Bricker Type of Sample: Monitoring Well

Sampled : June 22, 1994 Received: June 22, 1994 Completed: June 23, 1994

QA/QC ID# : 40365501-

#### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS	MCL
Iron Lead Manganese Sodium	200.7 200.8 200.7 200.7	ug/L ug/L ug/L mg/L	50 0.2 30 1	ND ND ND 86	300 50 50

ND = Not Detected at or above the DLR. DLR = Detection Limit for Reporting Purposes. ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram → = DLR adjusted because of dilutions, concentrations, or limited sample.

Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S. Inorganic Lab Manager

KW/DHN:cl

Darrell H. Nelson, B.S. Laboratory Director



July 12, 1994

LAB No: SP 403655-1

Bermite Division of Whittaker 22116 W. Soledad Canyon Road

Saugus, CA 91350

RE: Inorganic Analysis

Sample Site: Bermite 317 Area 23rd Qtr. Water Sampling - 85-01.4

Description: MW10/T/23 Sampled by : Tim Bricker

Type of Sample: Monitoring Well

Sampled : June 22, 1994 Received: June 22, 1994 Completed: June 23, 1994

QA/QC ID# : 40365501-

#### Analytical Results

CONSTITUENT	EPA METHOD	UNITS	DLR	RESULTS	MCL
Turbidity	180.1	NTU	0.2	0.8	5

DLR = Detection Limit for Reporting Purposes. ND = Not Detected at or above the DLR. ug/L = Micrograms Per Liter (ppb) mg/L = Milligrams Per Liter (ppm) mg/kg = Milligrams Per Kilogram • = DLR adjusted because of dilutions, concentrations, or limited sample. Preservatives: (1) Cool 4°C Containers: (a) Plastic

If you have any questions, please call.

FGL ENVIRONMENTAL

Kurt Wilkinson, B.S.

Inorganic Lab Manager

KW/DHN:cl

Darrell H. Nelson, B.S. Laboratory Director

PH: 209/94

Field Office Visalia, CA PH:

209/734-9473 FAX: 209/734-8435

# APPENDIX H STATISTICAL ANALYSES

TABLE H-1
TWENTY-THIRD QUARTER SAMPLING EVENT

			Well No.				
Parameter	Units	Tolerance Limit	MW-5	MW-6	MW-10		
Chloride	mg/l	175	40	65	64		
pН		7.03/8.00	7.7	7.7	7.8		
Specific Conductance	μmhos/cm²	752	540	550	610		
Sulfate	mg/l	105	35	30	39		
Iron	μg/l	303	70	70	<50		
Manganese	μg/l	30ª	<30	30	<30		
Sodium	mg/l	60.5	54	58	86		
TCE	μg/l	0.5ª	< 0.5	< 0.5	< 0.5		
TOC	mg/l	3.59	< 0.5	< 0.5	< 0.5		
TOX	μg/l	65.4	<5	<5	20		

Note: All tolerance limits are upper limits except pH which has both upper and lower limits.

<sup>\*</sup>Tolerance limit set at detection limit.

TABLE H-2

CONCENTRATIONS OF GROUND WATER MONITORING PARAMETERS IN SAMPLES FROM BACKGROUND MONITORING WELL MW-1

Date	Quarter	pH°	Conductance <sup>a</sup> (µmhos/cm <sup>2</sup> )	TOC* (mg/l)	TOXª (μg/l)	SO <sub>4</sub> <sup>2</sup> (mg/l)	Cl (mg/l)	Fe (μg/l)	Mn (μg/l)	Na (mg/l)	TCE (μg/l)
10/04/88 <sup>b</sup>	1	7.5	598	<3	< 100	11					<5
01/25/89	2	7.48	572	2.4°	<100	22					
04/17/89	3	7.2		<3	<100	11					
07/27/89	4	7.48	500	2.4°	<100	13					
10/31/89	5	7.6	524	<3	<100	10	83				
01/25/90	6	7.4	570	<3	<100	16	85				
04/17/90	7	7.55	504	<4	<20	11	88				
07/17/90	8	8.28	530	<4	<20	10	82				
10/18/90	9	7.4	544	<1	75°	23	98				
01/29/91	10	7.5	573	1.4	<5	8	96				
04/23/91	11	7.68	559	1.8	<5	10	100				
07/19/91	12	7.33	575	1.2	<5	11	97				
10/08/91 <sup>d</sup>											
03/13/92	14	7.5	639	0.4°	<5	13	131				
04/21/92	15	7.5	643	< 0.5	<5	9	130				
07/29/92	16	7.55	660	< 0.5	6.9	11	133				
10/20/92	17	7.5	676	< 0.5	<5	10	138				
01/27/93	18	7.68	707	< 0.5	<5	6	137				
06/09/93°	19	7.5	715	<0.5	<5	9	134	250	<30	52	
07/14/93	20							220	<30	46	
08/11/93	20							60	<30	54	
09/22/93	20	7.5	720	< 0.5	9	13	161	100	<30	52	
12/08/93	21	7.4	726	< 0.5	<5	10	151	50	< 30	57	
03/10/94	22	7.5	730	>0.5	<5	10	150	200	<30	48	< 0.5
06/22/94	23	7.5	740	< 0.5	<5	15	150	150	<30	54	< 0.5

<sup>\*</sup>Each value is the average result from four replicate samples.

<sup>&</sup>lt;sup>b</sup>Samples from 01/27/88, 07/29/88, 08/15/88, and 10/04/88 reported TCE at <5  $\mu$ g/l.

The replicates included a portion with results below the detection limit. The average was calculated after assigning a value of one-half the detection limit for the samples below the detection limit.

<sup>&</sup>lt;sup>d</sup>Not sampled because water elevation dropped below elevation of sampling pump intake.

<sup>\*</sup>Single sample. Replicates no longer taken.

TABLE H-3

CONCENTRATIONS OF GROUND WATER MONITORING PARAMETERS IN SAMPLES FROM BACKGROUND MONITORING WELL MW-3

Date	Quarter	pH°	Conductance <sup>a</sup> (µmhos/cm <sup>2</sup> )	TOC* (mg/l)	ΤΟΧ <b>°</b> (μg/l)	SO <sub>4</sub> <sup>2</sup> · (mg/l)	Cl (mg/l)	Fe (μg/l)	Mn (μg/l)	Na (mg/l)	TCE (μg/l)
10/04/88 <sup>b</sup>	1	7.48	699	<3	361.25	73					<5
01/25/89	2	7.73	664	<3	<100	74					
04/17/89	3	7.3		<3	<100	9					
07/27/89	4	7.5	661	<3	<100	65					<u></u>
10/31/89	5	7.53	617	<3	<100	68	35				
01/25/90	6	7.18	641	7.1°	<100	74	36				
04/17/90	7	7.33	590	<4	<20	60	46				
07/17/90	8	8.23	589	<4	<20	67	39				
10/18/90	9	7.63	642	0.7°	<100	15	34				
01/29/91	10	7.28	656	2.2	<5	80	54				
04/23/91	11	7.55	629	2.0	<5	77	34				
07/19/91	12	7.23	633	1.3	<5	85	45				
10/09/91	13	7.65	642	< 0.5	<5	34	37				
03/13/92	14	7.45	648	0.6	3.3°	85	33				
04/21/92	15	7.5	644	< 0.5	<5	81	37				
07/29/92	16	7.55	643	0.34°	<5	74	33				
10/20/92	17	7.55	641	<0.5	<5	67	34				
01/27/93	18	7.6	640	< 0.5	<5	69	30				
06/09/93 <sup>d</sup>	19	7.6	627	< 0.5	<5	70	28	50	<30	48	
07/14/93	20							<50	<30	44	
08/11/93	20							< 50	<30	50	
09/22/93	20	7.4	630	<0.5	<5	87	37	< 50	<30	50	
12/08/93	21	7.4	627	< 0.5	<5	72	35	< 50	<30	54	
03/10/94	22	7.4	620	< 0.5	<5	74	31	< 50	<30	47	< 0.5
06/22/94	23	7.6	630	< 0.5	8°	71	29	<50	<30	53	< 0.5

<sup>\*</sup>Each value is the average result from four replicate samples.

<sup>&</sup>lt;sup>b</sup>Samples from 02/17/88, 05/27/88, 07/19/88, 08/15/88, and 10/04/88 reported TCE at <5  $\mu$ g/l.

The replicates included a portion with results below the detection limit. The average was calculated after assigning a value of one-half the detection limit for the samples below the detection limit.

<sup>&</sup>lt;sup>d</sup>Single sample. Replicates no longer taken.

<sup>°</sup>Duplicate sample analytical result also 8  $\mu$ g/l.

TABLE H-4
TOLERANCE LIMIT CALCULATIONS

	pН	Conductance	TOC	тох	Chloride	Sulfate	Iron	Manganese	Sodium
Σχ	338.2	27,018	50.34	799.7	2,831	1,793	1,230	210	709
n (number of samples)	45	43	45	44	37	45	14	14	14
x (mean)	7.51	628	1.12	18.2	76.5	39.8	87.9	15.0	50.7
s (sample standard deviation)	0.20	58.8	1.18	22.5	45.6	31.2	82.1	0	3.75
k (from tables)	2.408	2.105	2.092	2.099	2.150	2.092	2.614	2.614	2.614
Upper Tolerance Limit*	8.00	752	3.59	65.4	175	105	303	30°	60.5
Lower Tolerance Limit <sup>b</sup>	7.03								


<sup>\*</sup>Upper Tolerance Limit =  $\bar{x} + ks$ .

<sup>&</sup>lt;sup>b</sup>Lower Tolerance Limit =  $\bar{x} - ks$ .

<sup>&</sup>lt;sup>e</sup>Upper Tolerance Limit set at detection limit.


# **CHLORIDE**

## MONITORING WELLS MW-1 AND MW-3




# SPECIFIC CONDUCTANCE

## MONITORING WELLS MW-1 AND MW-3




IRON
MONITORING WELLS MW-1 AND MW-3




# **MANGANESE**

## MONITORING WELLS MW-1 AND MW-3




→ MW-1 → MW-3

pH
MONITORING WELLS MW-1 AND MW-3




→ MW-1 → MW-3

# SODIUM MONITORING WELLS MW-1 AND MW-3



# **SULFATE**


## MONITORING WELLS MW-1 AND MW-3



 $\rightarrow$  MW-1  $\rightarrow$  MW-3

# TOTAL ORGANIC CARBON

## MONITORING WELLS MW-1 AND MW-3



## TOTAL ORGANIC HALOGENS

## MONITORING WELLS MW-1 AND MW-3

