



Ocean University of China

Ocean Monitoring and Inspection Center

Monitoring (Inspection) Report

OUC (Testing) No. HDJC2013-001

Client: Qingdao Headway Technology Co., Ltd.

Project Name: Scaling Test of OceanGuardTM Ballast Water

Management System

Inspection Dept.: Marine Chemistry Analysis and Detection Laboratory

Approved by: _

Date of issue: 12/03/2013

Inspected by.: Ocean Monitoring and Inspection Center,

Ocean University of China

(Official Seal)

STATEMENT

1. The report is invalid without the official seal of Ocean Monitoring and Inspection Center, Ocean University of China (hereinafter referred to as the Center).

- 2. Copy of the report is invalid without the original seal of the Center.
- 3. The report is invalid without signature of test operator, verifier, and authorizer.
- 4. The report is invalid with any alteration.
- Should any dissidence arisen on the Test Report, please contact the Center within thirty days after receiving the report. An overdue submission of any complains will be disregarded.
- 6. If the samples were sent to the Center by the client, the Center is only responsible for the testing results, but not for the source of the samples,.
- 7. Test results are valid only for the same batch of samples.
- 8. Copy of test reports is not allowed without written permission of the Center.
- 9. This report is in decuplicate, with five for English version and five for Chinese version. For each version, two original copies and one duplicate will be sent to the Client, two duplicates will be kept at the Center and the inspection department (laboratory) respectively for documentation.

To improve our testing capability and service quality continuously and to better serve clients and the community, comments from all sectors of the community to the Center are warmly welcome.

Ocean Monitoring and Inspection Center

Ocean University of China

Add: 5 Yushan Road, Qingdao, China

Tel: 0532-82031800

Fax:0532-82032700

E-mail: hdjc@ouc.edu.cn

Zip Code: 266003

Ocean Monitoring and Inspection Center, Ocean University of China

No.HDJC2013-001

Page 1/15

Name of				1 age 1/13						
project	Scalir	ng Testing of OceanGua	ard TM Ballast Wa	ter Management System						
		: Qingdao Headway Te								
Client	1	Add: F4, #5 Building, Huite Industrial City, Zhuzhou Road, Qingdao, China Tel: (+86) -532-88702808 Entrusted by Qingdao Headway Technology Co., Ltd., the project comprises tests on								
	_	· · · · · · · · · · · · · · · · · · ·								
	10000 10000			s and gas concentration of ballast water						
				anagement System, in the test facility,						
	Qingdao Beihai Shipbuilding Heavy Industry Co., Ltd. There are three types of Balla									
D		Water Management Systems tested in this project (HMT-50, HMT-1200, HMT-3000).								
Project		Ocean Monitoring and Inspection Center, Ocean University of China acts as the implementation party of the project, and accredited staffs from the Center were								
Description	1	T 150	S (5)	TAS						
				eration of the whole process and to carry ed. Off-site testing samples were delivered						
			7.0							
		to specified laboratories of the Center and tested by accredited staffs within a specified period. The fourth cycle was completed from Feb 22 nd to Feb 27 th , 2013. The operation,								
				er supervision of CCS and DNV.						
	No.	Name	Model	Main Parameter						
		Ballast Pump	Outsourcing	Rated Capacity: 50 m ³ /h, 100 m ³ /h,						
	1			1000 m ³ /h and 2200 m ³ /h						
		ā	HMT-50F	Rated Capacity: 50 m ³ /h						
	2	Filter	HMT-1200F	Rated Capacity: 1200 m ³ /h						
			HMT-3000F	Rated Capacity: 3000 m³/h						
			HMT-50E	Rated Capacity: 50 m ³ /h						
Test	3	EUT Unit	HMT-1200E	Rated Capacity: 1200 m³/h						
Equipment			HMT-3000E	Rated Capacity: 3000 m ³ /h						
	4	Flow Meter	HMT-125FM	DN125						
		I low ivicted	HMT-600FM	DN600						
	5	Neutralization Unit	HMT-600N	Volume: 600L						
	6	Monitoring Unit	HMT-TRO							
	7	Power Distribution Unit	HMT-PDU							
	8	Control Unit	HMT-CL							
Test Process			_							
and			See report pa	age 10-15						
Equipment										

Test Operator: 李孝宗
Date: 11/03 / 2013

Ocean Monitoring and Inspection Center, Ocean University of China

No.HDJC2013-001

Page 2/15

	No.	Item	Sample Container	Collected Volume	Preservat ion	Expected Storage Time
	1	Temperature 1	Dissis Daula	1.7	Test on site	·
	2	Salinity	Plastic Bottle	1 L	Test on site	(America)
	3	TRO	Pretreated Plastic Bottle	1 L	Test on site	
	4	DOC	Pretreated Plastic Bottle	1 L	0-4 ℃	<u>≤</u> 7d
	5	POC	Pretreated Plastic Bottle	1 L	0-4 °C	<u>≤</u> 7d
Sampling and Storage	6	TSS	Pretreated Plastic Bottle	1 L	0-4 °C	≤24h
	7	Organisms≥50 μm	Sterile Plastic Bottle	1 m ³	Test on site	≤6h
El .	8	Organisms≥ (10-50)μm	Sterile Plastic Bottle	1 L	4 °C	≤24h
	9	Heterotrophic Bacteria				
	10	E. coli	Ctarila Diagtia			
	11	Vibrio Cholera	Sterile Plastic Bottle	1 L	4 °C	≤24h
,	12	Enterococcus Group Bacteria				
	13	H ₂	·		Test on site	
Remark						

Verifier: 7 1 2 Authorizer: 1/03/2013

Date: 11/03/2013

Test Operator: $\sqrt[3]{20}$

Ocean Monitoring and Inspection Center, Ocean University of China

No.HDJC2013-001

Page 3/15

	No.		Item	Method	Majo	r Instrument
4	1	Т	emperature	Sensor Detection	VIC	CTOR TP01
	2 Salinity		Salinity 3	Sensor Detection	ГОН	TEC SC-106
	3		TRO	DPD	HAC	CH DR/2800
	4		DOC	Catalytic Combustion	SHIMAI	OZU TOC-V _{cpn}
	5		POC	Catalytic Combustion	SHIMAI	OZU TOC-V _{cpn}
Testing Method and	6 TSS		TSS	Weighting	DDG-9203Electric Blast Drying Oven METTLER TOLEDO EL104 Balance	
Major Instrument	7	Org	anisms≥50µm	Microscope Determination	OPTEC SMJ-T2 Stereo Microscope	
	8	Orga	nisms≥(10-50) μm	CFDA	Leica OMLA Fluorescen Microscope	
	9	9 Heterotrophic Bacteria		Plate Counting	YUE FENG SPX-150 Low-temperature Incubator	
	10	10 E. coli		Counting after membrane filtration	YUE FENG SPX-150 Low-temperature Incubator	
	Enterococcus Group Bacteria		ococcus Group Bacteria	Counting after membrane filtration	YUE FENG SPX-150 Low-temperature Incubator	
	12	Vi	brio Cholera	Counting after membrane filtration	YUE FENG SPX-150 Low-temperature Incubator	
	13		H ₂	Sensor Detection	HAN WEI BX618 Gas Detector	
Testing Results		See report p		See report page 4-9		
Laboratory Environment	Temp			19.0 °C	Humidity	70 %
Remark					1	

Verifier: 74/2/2 Authorizer: 74/2 Authorizer: 74/2 Date: 11/03/2013

Ocean Monitoring and Inspection Center, Ocean University of China (Attachment)

No.HDJC2013-001

Page 4/15

1 Testing result of Cycle 4

1.1Operating Condition

Name of the system: OceanGuard Ballast Water Management System

Manufacturer: Qingdao Headway Technology Co., Ltd.

Location: No.8 Wharf, Qingdao Beihai Shipbuilding Heavy Industry Co., Ltd.

Cycle NO.: 4

Date: 02/22/2013-02/27/2013

Weather(Ballasting): Sunny

Longitude: 35°59.18'E

Latitude: 120°16.25'N

Water Depth: 10.2 m

Test Operator:

7

Verifier:

Authorizer: Akla

Ocean Monitoring and Inspection Center, Ocean University of China (Attachment)

No.HDJC2013-001

Page 5/15

1.2 Operating Data


Table 1.2.1 Operating time and flow

Date	Process Description	Start Time	Stop Time	Average Flow Rate (m ³ /h)
02/22/2013	Treated Water (HMT-50)	16:15	16:58	62.71
02/22/2013	Treated Water (HMT-1200)	14:57	15:19	1639
02/22/2013	Treated Water (HMT-3000)	14:32	14:51	3189
02/22/2013	Control Water	17:05	17:25	65.4

Table 1.2.2 Monitoring Report of different TRO Detectors

Item	Salinity (PSU)	TRO (mg/L) DPD Method	TRO (mg/L) Probe Method
Treated Water (HMT-50)	19.2±0.2	2.02	1.94
Treated Water (HMT-1200)	21.1±0.1	2.02	1.95
Treated Water (HMT-3000)	21.6±0.3	2.08	2.01

Test Operator: 科表 Verifier: 水片 Authorizer:



No.HDJC2013-001

Page 6/15

1.3 Test result of water and gas

Table 1.3.1 Test result of influent water

T4	Influent Water				
Item	HMT-50	HMT-1200	HMT-3000		
Temperature (°C)	4.1±0.1	4.9±0.3	5.0±0.2		
Salinity (PSU)	19.4±0.3	21.0±0.1	21.4±0.6		
TRO (mg/L)	0.01±0.01	0.01±0.01	0.00±0.00		
POC (mg/L)	0.40±0.02	0.43±0.05	0.42±0.08		
DOC (mg/L)	1.54±0.23	1.87±0.11	1.56±0.25		
TSS (mg/L)	6.59±0.85	7.25±1.50	7.36±0.79		
H ₂ (%LEL)	0.0	0.0	0.0		

Table 1.3.2 Test result of treated water

T	Treated Water				
Item	HMT-50	HMT-1200	HMT-3000		
Temperature (°C)	4.4±0.1	4.9±0.1	4.9±0.2		
Salinity (PSU)	19.2±0.2	21.1±0.1	21.6±0.3		
TRO (mg/L)	1.99±0.03	2.00±0.10	2.06±0.03		
POC (mg/L)	0.36±0.03	0.39±0.06	0.34±0.02		
DOC (mg/L)	1.56±0.04	1.74±0.12	1.49±0.14		
TSS (mg/L)	6.13±0.12	6.45±0.23	6.56±0.18		
H ₂ (%LEL)	0.0	0.0	0.0		

Test Operator:

Verifier: MB Le Authorizer: Alle

Ocean Monitoring and Inspection Center, Ocean University of China (Attachment)

No.HDJC2013-001

Page 7/15

Table 1.3.3 Test result of discharged water

Ti	Discharged Water				
Item	HMT-50	HMT-1200	HMT-3000		
Temperature (°C)	4.2±0.1	4.8±0.1	4.8±0.5		
Salinity (PSU)	19.4±0.1	21.0±0.1	21.5±0.2		
TRO (mg/L)	0.01±0.01	0.02±0.01	0.01±0.01		

Table 1.3.4 Test Result of control water

Item	Control Water
Temperature (°C)	4.3±0.2
Salinity (PSU)	20.2±0.1
TRO (mg/L)	0.01±0.01
POC (mg/L)	0.47±0.02
DOC (mg/L)	1.93±0.08
TSS (mg/L)	6.94±0.15
Organisms≥50μm (/m³)	496.13±15.01
Organisms≥10-50 μm (/mL)	(1.70±0.62)×10 ²
Heterotrophic bacteria (cfu/100mL)	(4.87±4.76)×10 ⁵
E. coli (cfu/100mL)	0.67±0.58
Enterococcus group bacteria (cfu/100mL)	0.67±0.15
Vibrio cholera (cfu/100mL)	0.00±0.00
H ₂ (%LEL)	0.0

Test Operator: 草茅

Verifier: Just 1

Authorizer: This

Ocean Monitoring and Inspection Center, Ocean University of China (Attachment)

No.HDJC2013-001

Page 8/15

Table 1.3.5 Test result of storage tank (T1)

Item	Ti (Water Treated by HMT-50)						
Tom	Day 1	Day 2	Day 3	Day 4	Day 5		
Temperature (°C)	5.0	5.1	5.0	5.9	5.7		
Salinity (PSU)	19.2	19.3	19.2	19.3	19.4		
TRO (mg/L)	0.08±0.01	0.02±0.02	0.01±0.01	0.01±0.01	0.01±0.01		
H_2 (%LEL)	0.0	0.0	0.0	0.0	0.0		

Table 1.3.6 Test result of storage tank (T2)

Item	T2 (Water Treated by HMT-1200)						
	Day 1	Day 2	Day 3	Day 4	Day 5		
Temperature (°C)	4.8	5.5	5.3	5.7	5.8		
Salinity(PSU)	21.3	21.1	21.2	21.1	21.2		
TRO (mg/L)	0.09±0.01	0.04±0.01	0.01±0.01	0.01±0.01	0.01±0.01		
H ₂ (%LEL)	0.0	0.0	0.0	0.0	0.0		

Table 1.3.7 Test result of storage tank (T3)

Item	T3 (Water Treated by HMT-3000)						
	Day 1	Day 2	Day 3	Day 4	Day 5		
Temperature (°C)	4.4	5.6	5.2	5.9	6.0		
Salinity (PSU)	21.6	21.5	21.6	21.6	21.5		
TRO (mg/L)	0.06±0.01	0.01±0.01	0.01±0.01	0.01±0.01	0.00±0.00		
H_2 (%LEL)	0.0	0.0	0.0	0.0	0.0		

Test Operator: 本意 Verifier: 不時 Authorizer: 表起

Ocean Monitoring and Inspection Center, Ocean University of China (Attachment)

No.HDJC2013-001

Page 9/15

Table 1.3.8 Test result of storage tank (T4)

Item	T4 (Control Water)					
Tem	Day 1	Day 2	Day 3	Day 4	Day 5	
Temperature (°C)	4.6	5.5	5.2	5.9	5.8	
Salinity (PSU)	20.3	20.2	20.2	20.1	20.3	
TRO (mg/L)	0.01±0.01	0.00±0.00	0.01±0.01	0.02±0.01	0.00±0.00	
H ₂ (%LEL)	0.0	0.0	0.0	0.0	0.0	

Table 1.3.9 TRO Concentration at Different Salinity (Test on site)

Item	Salinity (PSU)	TRO (mg/L)
Treated Water (HMT-50)	3.2	2.02
Treated Water (HMT-50)	2.0	2.05
Treated Water (HMT-50)	1.1	1.95

Test Operator:

Verifier: 34 34 Authorizer:

Ocean Monitoring and Inspection Center, Ocean University of China (Attachment)

No.HDJC2013-001

Page 10/15

2 Test Introduction

It is the scaling testing of brackish water, and a barge is loaded with fresh water at the wharf in advance. While operating, fresh water pumped from the barge by fresh water ballast pump mixes with the sea water pumped by the sea water ballast pump in the pipe, then both run through OceanGuard TM Ballast Water Management System. The treated water goes into the sea after neutralization process of the Neutralization Unit.

A full scaling testing cycle includes ballasting and storage. Three types of OceanGuardTM Ballast Water Management System in this project (with the rated capacity of 50 m³/h, 1200 m³/h and 3000 m³/h).

According to QAPP, the salinity was controlled between 18 PSU to23 PSU and TRO concentration testing in lower salinity was added.



Picture 2.1 Barge loaded with fresh water

Test Operator: 本意

Verifier:/

Authorizer:


Ocean Monitoring and Inspection Center, Ocean University of China (Attachment)

No.HDJC2013-001

Page 11/15

An example of running HMT-3000 system was given. Firstly, after starting the P3 and P4 Pump, water go through the Filter (HMT-3000F), as well as the EUT Unit (HMT-3000E) for treatment. Treated water goes into the sea after neutralization process of the Neutralization Unit (HMT-600N). During the treatment process, 1m3 of treated water goes into the storage tank T3. Operating process of HMT-50 and HMT-1200 is exactly the same as that of HMT-3000. The last step is simulating ballasting process of control water, i.e., water is pumped through the pump by the bypass pipe and then goes into the sea directly. During the process, 1m3 of control water goes into storage tank T4. After ballasting, all the storage tanks will be covered with opaque cover to avoid sunlight. There are 3 sampling points in the pipes of each system, for the sampling of influent water, treated water and discharged water.

Water in storage tanks T1, T2, T3, T4 should by stored for 5 days. TRO concentration, temperature, salinity and concentration of hydrogen gas in the top of the tank should be measured every day during the 5 days' period.



Test Operator: 葬孝菜

Verifier: Authorizer:

Ocean Monitoring and Inspection Center, Ocean University of China (Attachment)

No.HDJC2013-001

Page 12/15

Table 2.1 Notation for the system layout of scaling test

No.	Name	Main Parameters	Model
P1	Ballast Pump	Rated Capacity: 100 m ³ /h	
P2	Ballast Pump	Rated Capacity: 2200 m ³ /h	
Р3	Ballast Pump	Rated Capacity: 2200 m ³ /h	
P4	Ballast Pump	Rated Capacity: 1000 m ³ /h	
P5	Ballast Pump	Rated Capacity: 50 m ³ /h	
F1	Filter	Rated Capacity: 50 m ³ /h	HMT-50F
F2	Filter	Rated Capacity: 1200 m ³ /h	HMT-1200F
F3	Filter	Rated Capacity: 3000 m ³ /h	HMT-3000F
E1	EUT Unit	Rated Capacity: 50 m ³ /h	HMT-50E
E2	EUT Unit	Rated Capacity: 1200 m ³ /h	HMT-1200E
E3	EUT Unit	Rated Capacity: 3000 m ³ /h	НМТ-3000Е
FM1	Flow Meter	DN125	HMT-125FM
FM2	Flow Meter	DN600	HMT-600FM
N1	Neutralization Unit	Volume: 600L	HMT-600N
H1	Static Mixers	DN600	
T1-T4	Tank	Volume:1m ³	
V01-V48	Valve		

Test Operator:


Verifier: Authorizer:

Ocean Monitoring and Inspection Center, Ocean University of China (Attachment)


No.HDJC2013-001

Page 13/15

3 Pictures of system tested



Picture 3.1 Filter



Picture 3.2 EUT Unit

Test Operator: 郭芳某


Verifier: 30 35 13

Authorizer:


Ocean Monitoring and Inspection Center, Ocean University of China (Attachment)

No.HDJC2013-001

Page 14/15



Picture 3.3 Equipment layout of scaling test



Picture 3.4 TRO Meter with DPD Method

Test Operator:

Verifier: 水財皇 Authorizer: 東知記

Ocean Monitoring and Inspection Center, Ocean University of China (Attachment)

No.HDJC2013-001

Page 15/15



Picture 3.5 Operation of the system

Test Operator: 2

Verifier: Authorizer: Authorizer:

Checklist of Scaling Test of OceanGuardTM Ballast Water Management System

Checklist number: HMT-BWMS-ST-CN-04

Manufacturer: Qingdao Headway Technology Co., Ltd.

Place: 8 Wharf, Qingdao Beihai Shipbuilding Heavy Industry Co., Ltd.

Date: Feb., 22nd, 2013, Friday

No.	To be checked	Yes/No	Mark
1	Installation of equipment		
1.1	OceanGuard [™] BWMS of 50 m³/h		
1.1.1	Components of the System: Filter, EUT Unit, Control Unit, Power Distribution Unit, EUT Power Unit, Neutralization Unit, Monitoring Unit, Flow Meter	Yes	
1.1.2	System piping arrangement is consistent with QAPP (please refer to P4 in QAPP for details)	Yes	
1.1.3	Sampling point of influent water is before the Filter	Yes	
1.1.4	Sampling point of treated water is after the EUT Unit.	Yes	
1.1.5	Sampling point of discharging water is after the Neutralization Unit.	Yes .	
1.1.6	A simulated ballast tank of 1m ³ is near the system for storage of treated water.	Yes	
1.2	OceanGuard [™] BWMS of 1200 m³/h		
1.2.1	Components of the System: Filter, EUT Unit, Control Unit, Power Distribution Unit, EUT Power Unit, Neutralization Unit, Monitoring Unit, Flow Meter	Yes	
1.2.2	System piping arrangement is consistent with QAPP (please refer to P4 in QAPP for details)	Yes	
1.2.3	Sampling point of influent water is before the Filter	Yes	
1.2.4	Sampling point of treated water is after the EUT Unit.	Yes	
1.2.5	Sampling point of discharging water is after the Neutralization Unit.	Yes	
1.2.6	A simulated ballast tank of 1m ³ is near the system for storage of treated water.	Yes	
1.3	OceanGuard [™] BWMS of 3000 m ³ /h		
1.3.1	Components of the System: Filter, EUT Unit, Control Unit, Power Distribution Unit, EUT Power Unit, Neutralization Unit, Monitoring Unit, Flow Meter	Yes	
1.3.2	System piping arrangement is consistent with QAPP (please refer to P4 in QAPP for details)	Yes	
1.3.3	Sampling point of influent water is before the Filter	Yes	
1.3.4	Sampling point of treated water is after the EUT Unit	Yes	
1.3.5	Sampling point of discharging water is after the Neutralization Unit	TPS	

		T	1
1.3.6	A simulated ballast tank of 1m ³ is near the system for storage of treated water	Yes	
1.4	Bypass		
1.4.1	Open and close state of the bypass pipe is controlled by		
88 88 8	automatic valve	Yes	
1.4.2	There is a sampling point in the bypass	Yes	
1.4.3	A simulated ballast tank of 1m³ is near the system for storage	167	
1.1.0	of treated water	Yes	
2	Operation of equipment	17	
2.1	OceanGuard TM BWMS of 50 m ³ /h		
2.1.1	Press the key "Ballast on", automatic valves are open or		
۷. ۱. ۱	closed in normal state	Yes	
2.1.2	There is normal display in the panel of control unit		
2.1.3	Flow rate is around 50 m ³ /h	Yes	6/43/
2.1.4		Yes	56 M3/1
2.1.4	There is display of TRO concentration after the EUT unit, and	Yes	3 PSU
2.1.5	the value is equal to 2 mg/L	103	2000
2.1.0	When the Neutralization Unit starts work, neutralizer is added	Yes	0.7
0.4.0	into the pipe	19	
2.1.6	TRO concentration after the neutralization unit is lower than	Yes	IN PORMS
0.47	0.2 mg/L	163	a Dong,
2.1.7	Press the key "Ballast off", the automatic valve works in normal	Yes	
0.4.0	state	163	
2.1.8	There is record in the Log of Control Unit, and the time	Yes	
0.4.0	recorded as well as contents are correct	165	
2.1.9	During operation, 1 m ³ of water goes into simulated ballast	Yes	
	tank	10	
2.2	OceanGuard [™] BWMS of 1200 m³/h		
2.2.1	Press the key "Ballast on", automatic valves are open or	V	
	closed in normal state	Yes	
2.2.2	There is normal display in the panel of control unit	Yes	ļ., ,
2.2.3	Flow rate is around 1200 m ³ /h	Yes	1637 m3/
2.2.4	There is display of TRO concentration after the EUT unit, and	Vas	1 00
	the value is equal to 2 mg/L	Yes	hij rg
2.2.5	When the Neutralization Unit starts work, neutralizer is added	./	,
	into the pipe	Yes	
2.2.6	TRO concentration after the neutralization unit is lower than	J.	
	0.2 mg/L	Yes	Ow my
2.2.7	Press the key "Ballast off", the automatic valve works in normal	V	
	state	Yes	
2.2.8	There is record in the Log of Control Unit, and the time	~/-	
	recorded as well as contents are correct	Yes	9
2.2.9	During operation, 1 m ³ of water goes into simulated ballast	V	
	tank	Yes	1

20/ my/L 202 my/L 205 my/L 1,95 mg/L



2.3.1 Press the key "Ballast on", automatic valves are open or closed in normal state 2.3.2 There is normal display in the panel of control unit 2.3.3 Flow rate is around 3000 m³h 2.3.4 There is display of TRO concentration after the EUT unit, and the value is equal to 2 mg/L 2.3.5 When the Neutralization Unit starts work, neutralizer is added into the pipe 2.3.6 TRO concentration after the neutralization unit is lower than 0.2 mg/L 2.3.7 Press the key "Ballast off", the automatic valve works in normal state 2.3.8 There is record in the Log of Control Unit, and the time recorded as well as contents are correct 2.3.9 During operation, 1 m³ of water goes into simulated ballast tank 2.4 Operation of bypass 2.4.1 Press the key of "Emergency On" in control unit, valve of the bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/n 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of ireated water sampling is included: TRO 3.1.6 Sampling that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling 3.1.6 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.3	OceanGuard [™] BWMS of 3000 m ³ /h		
closed in normal state There is normal display in the panel of control unit 2.3.3 Flow rate is around 3000 m³/n There is display of TRO concentration after the EUT unit, and the value is equal to 2 mg/L 2.3.5 When the Neutralization Unit starts work, neutralizer is added into the pipe TRO concentration after the neutralization unit is lower than 0.2 mg/L 2.3.6 TRO concentration after the neutralization unit is lower than 0.2 mg/L 2.3.7 Press the key "Ballast off", the automatic valve works in normal state 2.3.8 There is record in the Log of Control Unit, and the time recorded as well as contents are correct 2.3.9 During operation, 1 m³ of water goes into simulated ballast tank 2.4 Operation of bypass 2.4.1 Press the key of "Emergency On" in control unit, valve of the bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/n 3.1.1 Sampling obtiles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of ireated water sampling is included: TRO 3.1.6 Sampling that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling 3.1.6 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.3.1		Ι,	1
2.3.2 There is normal display in the panel of control unit 2.3.3 Flow rate is around 3000 m³/h 2.3.4 There is display of TRO concentration after the EUT unit, and the value is equal to 2 mg/L 2.3.5 When the Neutralization Unit starts work, neutralizer is added into the pipe 2.3.6 TRO concentration after the neutralization unit is lower than 0.2 mg/L 2.3.7 Press the key "Ballast off", the automatic valve works in normal state 2.3.8 There is record in the Log of Control Unit, and the time recorded as well as contents are correct 2.3.9 During operation, 1 m³ of water goes into simulated ballast tank 2.4.1 Press the key of "Emergency On" in control unit, valve of the bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of ireated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water: sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling			Yes	
2.3.3 Flow rate is around 3000 m³/h 2.3.4 There is display of TRO concentration after the EUT unit, and the value is equal to 2 mg/L 2.3.5 When the Neutralization Unit starts work, neutralizer is added into the pipe 2.3.6 TRO concentration after the neutralization unit is lower than 0.2 mg/L 2.3.7 Press the key "Ballast off", the automatic valve works in normal state 2.3.8 There is record in the Log of Control Unit, and the time recorded as well as contents are correct 2.3.9 During operation, 1 m³ of water goes into simulated ballast tank 2.4 Operation of bypass 2.4.1 Press the key of "Emergency On" in control unit, valve of the bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and sallnity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of discharging water sampling is included: TRO 3.1.6 Sampling of discharging water: sampling is included: TRO 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.3.2	3 (1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	10 0000	
There is display of TRO concentration after the EUT unit, and the value is equal to 2 mg/L 2.3.5 When the Neutralization Unit starts work, neutralizer is added into the pipe 2.3.6 TRO concentration after the neutralization unit is lower than 0.2 mg/L 2.3.7 Press the key "Ballast off", the automatic valve works in normal state 2.3.8 There is record in the Log of Control Unit, and the time recorded as well as contents are correct 2.3.9 During operation, 1 m³ of water goes into simulated ballast tank 2.4 Operation of bypass 2.4.1 Press the key of "Emergency On" in control unit, valve of the bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and sallnity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of discharging water sampling is included: TRO 3.1.6 Sampling of discharging water sampling is included: TRO 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.3.3	part Mills 50 St.	1 .	21Px 203
2.3.6 When the Neutralization Unit starts work, neutralizer is added into the pipe 7.3.6 TRO concentration after the neutralization unit is lower than 0.2 mg/L. 7.3.7 Press the key "Ballast off", the automatic valve works in normal state 7.3.8 There is record in the Log of Control Unit, and the time recorded as well as contents are correct 7.3.9 During operation, 1 m³ of water goes into simulated ballast tank 7.4 Operation of bypass 2.4.1 Press the key of "Emergency On" in control unit, valve of the bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically and the sound alarm is canceled 2.4.1 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically and the sound alarm is canceled 2.4.2 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of ireated water sampling is included: TRO 3.1.6 Sampling of discharging water sampling is included: TRO 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4℃ immediately after sampling	2.3.4	Annual to the state of the stat		
2.3.6 TRO concentration after the neutralization unit is lower than 0.2 mg/L Press the key "Ballast off", the automatic valve works in normal state 2.3.8 There is record in the Log of Control Unit, and the time recorded as well as contents are correct 2.3.9 During operation, 1 m³ of water goes into simulated ballast tank 2.4 Operation of bypass 2.4.1 Press the key of "Emergency On" in control unit, valve of the bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.3.5	The first the fi	.50	
2.3.7 Press the key "Ballast off", the automatic valve works in normal state 2.3.8 There is record in the Log of Control Unit, and the time recorded as well as contents are correct 2.3.9 During operation, 1 m³ of water goes into simulated ballast tank 2.4 Operation of bypass 2.4.1 Press the key of "Emergency On" in control unit, valve of the bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.3.6			aoomy/
recorded as well as contents are correct 2.3.9 During operation, 1 m³ of water goes into simulated ballast tank 2.4 Operation of bypass 2.4.1 Press the key of "Emergency On" in control unit, valve of the bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of ireated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.3.7	The second of th		0'
tank 2.4 Operation of bypass 2.4.1 Press the key of "Emergency On" in control unit, valve of the bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of ireated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.3.8	The same of the sa	Yes	
2.4.1 Press the key of "Emergency On" in control unit, valve of the bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.3.9		Yes	
bypass is opened automatically, and other valves are closed 2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of ireated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.4	Operation of bypass		
2.4.2 Sound and light alarm is started 2.4.3 Press the key of "Mute", and the sound alarm is canceled 2.4.4 Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.4.1	The second of th	Yes	
Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.4.2	Ass the second with the second of the second		
Press the key of "Emergency Off" in control unit, valve of the bypass is closed automatically 2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.4.3	Press the key of "Mute", and the sound alarm is canceled	Yes	
2.4.5 During operation, 1 m³ of water goes into simulated ballast tank 3 Sampling, Storage and Transportation 3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.4.4	Press the key of "Emergency Off" in control unit, valve of the		
3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	2.4.5	During operation, 1 m ³ of water goes into simulated ballast		
3.1 OceanGuard™ BWMS of 50 m³/h 3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	3	S23 42 42 7 13	19	
3.1.1 Sampling bottles are numbered regularly, labels are waterproof and stuck firmly 3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4℃ immediately after sampling	3.1			
3.1.2 Sampling of influent water: three parallel samples for each parameter at three different time respectively 3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling			Yes	
3.1.3 Three parameters of influent water sampling are included: temperature and salinity, TSS, DOC and POC 3.1.4 Sampling of treated water: three parallel samples for each parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	3.1.2	1 N	24.0	
parameter at three different time respectively 3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	3.1.3			
3.1.5 One parameter of treated water sampling is included: TRO 3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	3.1.4	VOICE WE HAVE MAKE TO SEE THE SECOND	Tes.	
3.1.6 Sampling of discharging water: three parallel samples for each parameter at three different time respectively 3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	3.1.5	One parameter of treated water sampling is included: TRO		
3.1.7 One parameter of discharging water sampling is included: TRO 3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	3.1.6			
3.1.8 Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4°C immediately after sampling	3.1.7	One parameter of discharging water sampling is included: TRO		
	3.1.8	Samples that need to be tested in the lab, should be put into		
	3.1.9	Samples in the thermal insulation box should be delivered to	Yer	



	the lab within 6 hours	
3.1.10	Monitor concentration of hydrogen gas in simulated ballast	
	tanks	Yes
3.2	OceanGuard [™] BWMS of 1200 m³/h	
3.2.1	Sampling bottles are numbered regularly, labels are waterproof	
	and stuck firmly	Yes
3.2.2	Sampling of influent water: three parallel samples for each	
	parameter at three different time respectively	Yes Yes
3.2.3	Three parameters of influent water sampling are included:	
	temperature and salinity, TSS, DOC and POC	Yes
3.2.4	Sampling of treated water: three parallel samples for each	
	parameter at three different time respectively	Yes
3.2.5	One parameter of treated water sampling is included: TRO	Yes
3.2.6	Sampling of discharging water: three parallel samples for each	
	parameter at three different time respectively	Yes
3.2.7	One parameter of discharging water sampling is included: TRO	Yes
3.2.8	Samples that need to be tested in the lab, should be put into	
	the thermal insulation box of ≤4°C immediately after sampling	Yes
3.2.9	Samples in the thermal insulation box should be delivered to	
	the lab within 6 hours	Tes
3.2.10	Monitor concentration of hydrogen gas in simulated ballast	Tes Yes
	tanks	Yes
3.3	OceanGuard [™] BWMS of 3000 m ³ /h	
3.3.1	Sampling bottles are numbered regularly, labels are waterproof	,
	and stuck firmly	Yes
3.3.2	Sampling of influent water: three parallel samples for each	
	parameter at three different time respectively	Yes
3.3.3	Three parameters of influent water sampling are included:	
	temperature and salinity, TSS, DOC and POC	res
3.3.4	Sampling of treated water: three parallel samples for each	
	parameter at three different time respectively	Yes
3.3.5	One parameter of treated water sampling is included: TRO	res
3.3.6	Sampling of discharging water: three parallel samples for each	<i>y</i> .
	parameter at three different time respectively	Yes
3.3.7	One parameter of discharging water sampling is included: TRO	Yes
3.3.8	Samples that need to be tested in the lab, should be put into	V _a a
0.0.0	the thermal insulation box of ≤4°C immediately after sampling	Pes
3.3.9	Samples in the thermal insulation box should be delivered to	Vaa
0.0.40	the lab within 6 hours	Yes
3.3.10	Monitor concentration of hydrogen gas in simulated ballast	Yes
0.4	tanks	167
3.4	Sampling of control water	V
3.4.1	Sampling bottles are numbered regularly, labels are waterproof	inessed D Raviswad



	and stuck firmly	
3.4.2		
0.4.2	Sampling of control water: three parallel samples for each parameter at three different time respectively	Yes
3.4.3	Three parameters of control water sampling are included: temperature and salinity, TSS, DOC and POC, organisms ≥ 50µm, organisms ≥ 10-50µm and bacteria	Yes
3.4.4	Samples that need to be tested in the lab, should be put into the thermal insulation box of ≤4℃ immediately after sampling.	Yes
3.4.5	Samples in the thermal insulation box should be delivered to the lab within 6 hours	
3.4.6	Monitor concentration of hydrogen gas in simulated ballast tanks	Yes Yes
3.5	Sampling from simulated ballast tank (during storage)	
3.5.1	Sampling bottles are numbered regularly, labels are waterproof and stuck firmly	Yes
3.5.2	One sample for one parameter from each simulated ballast tank is taken	Yes
3.5.3	One parameter of sampling is included: TRO, temperature and salinity	Yes
3.5.4	Monitor concentration of hydrogen gas in simulated ballast tanks	Yes
4	On-site check	
4.1	All testing equipments have been calibrated with calibration label	Yes
4.2	Three parameters are tested on-site: temperature, salinity, TRO	Yes
4.3	Sensor thermometer is used to measure temperature	Pes
4.4	Salinity meter of sensor type is used to measure temperature	Yes
4.5	2800 spectrophotometer is used to monitor concentration of TRO	Yes
4.6	Gas detector of sensor type is used to monitor concentration of hydrogen gas	Yes
5	Check the data	
EA		. 1
5.1	Concentration of hydrogen gas in all test cycles is below 4%	Yec
5.2	Concentration of hydrogen gas in all test cycles is below 4% TRO concentration of treated water is equal to 2 mg/L	Yes Yes

