

June 18, 1991

Mr. Dennis Gagne
Regional Sample Control Custodian
U.S. Environmental Protection Agency
90 Canal Street
Boston, MA 02114

Re: 68-W9-0003

Work Assignment R01005 Case 16259, SDG AZ328

Gulf South Environmental Laboratory

Ciba-Geigy

Volatiles: 7/Water; AZ328-AZ334 Semivolatiles: 6/Water; AZ328-AZ333 Pesticide/PCBs: 6/Water; AZ328-AZ333

Dear Mr. Gagne:

The following is a Data Validation Report for Case 16259, which was generated by QuantaLex, Alliance's Data Validation Sub-Contractor. The analytical data for this case contained water samples which were collected by Alliance at the Ciba-Geigy Site and analyzed by Gulf South Environmental Laboratories.

If you have any questions, please feel free to contact me at (508) 970-5600 X 4201.

Sincerely,

Cynthia S. Fortin

Data Validation Coordinator

encl.

CSF/er

CC: Deborah Szaro/Moira Lataille, Region I TPO

Inthus S. Forton

Joanna Hall - Alliance Project Manager

SEMS DocID 666771

INCORPORATED

12600 West Colfax Avenue Suite A-300 Lakewood, Colorado 80215 TEL 303 237 · 7879 FAX 303 234 · 5858

June 17, 1991

Ms. Joanna Hall Alliance Technologies Corp. Boott Mills South, Foot of John Street Lowell, MA 01852

RE:

Case 16259, SDG AZ328

Gulf South Environmental Laboratory Volatiles: 7/Water; AZ328-AZ334 Semivolatiles: 6/Water; AZ328-AZ333 Pesticide/PCBs: 6/Water; AZ328-AZ333

Dear Ms. Hall:

Validation was performed on the analytical data from water samples which were collected by TRC Companies and submitted to Gulf South Environmental Laboratory for volatile, semivolatile, and pesticide analyses. The data were evaluated based on the following parameters:

- Data completeness
- \* Holding times
- \* GC/MS tuning
  - Calibration
  - Blanks
  - Surrogate recoveries
  - Matrix spike/matrix spike duplicate
- Field duplicates
- \* Internal standard performance
  - Compound identification
- \* **Compound quantitation** 
  - \* All criteria were met for this parameter

Table 1 summarizes the validation recommendations which were based on the following information:

### **Data Completeness**

#### Volatiles:

The Form 1 for sample AX328 did not report the positive result for Tetrachloroethene, although mass spectra were included as well as a value reported on the quantitation report. The result of 97 ug/L is reported on the data tables.

#### Pesticides:

The concentrations for the Evaluation Standard Mixes are missing from this case. On a previous case, the laboratory had submitted these concentrations. These standard concentrations were used to verify the reported calibration factors for this case and were found to be correct. The form containing the concentrations is inserted in this case as page 60A.

#### **Calibrations**

#### Volatiles:

The following compounds exceeded the percent difference (%D) or relative response criteria in the 4/29/91 continuing calibration. The non-detected results for 2-Butanone are rejected (R) and the positive results for Acetone and Tetrachloroethene are estimated (J) in the associated samples.

Compound	<u>CC</u> 04/29/91	<u>CC</u> 04/29/91	<u>CC</u> 04/29/91
2-Butanone	<b>+</b> .	-	
Acetone	•	X	
Tetrachloroethene			. <b>X</b>
Associated samples:	AZ328	AZ333	AZ328
•	AZ329	AZ334	- AZ329
	AZ330		AZ330
	AZ332	,	
	AZ333	•	
•	AZ334		
X = %D > 25% but $< 50%$		*	
+ = RF < 0.05			

#### Semivolatiles:

The following compounds exceeded the percent difference (%D) criteria in the 4/28/91 continuing calibration. The non-detected results for these compounds in all samples are estimated (UJ).

	<u>CC</u>
Compound	. 04/28/91
4-Chloroaniline	X
3-Nitroaniline	X
4-Nitroaniline	$\mathbf{X}$

Associated samples:

AZ328, AZ329 AZ330, AZ331 AZ332, AZ333

X = %D > 50%

#### Pesticides:

The percent difference (%D) for Aldrin exceeded criteria in the 4/29/91 continuing calibration on column DB608. The positive results for Aldrin in samples AZ330 and AZ331 are estimated (J).

Compound

<u>CC</u> 04/29/91

Aldrin

X

Associated samples:

AZ330, AZ331

X = %D > 15%

#### **Blanks**

#### Volatiles:

The blanks were contaminated with Acetone. The results for Acetone in samples AZ328, AZ329, AZ330, AZ331, and AZ332 are adjusted according to the following:

Compound

Maximum Concentration

**Action Level** 

Acetone

30 ug/L

300 ug/L

Action:

Value < CRQL: report CRQL followed by a U

Value > CRQL but < action level: report value followed by a U

Value > CRQL and > action level: report value unqualified

The additional blank contaminants 1,2-Dichloroethane and Methylene Chloride were not detected in the samples and no action is necessary.

#### Semivolatiles:

The blank was contaminated with bis(2-Ethylhexyl)phthalate. The result for bis(2-Ethylhexyl)phthalate in sample AZ328 is adjusted according to the following:

Compound

Maximum Concentration

Action Level

bis(2-Ethylhexyl)phthalate

2 ug/L

20 ug/L

#### Action:

Value < CRQL: report CRQL followed by a U

Value > CRQL but < action level: report value followed by a U Value > CRQL and > action level: report value unqualified

#### Surrogates

	Percent Recoveries	•
	Base/Neutral	Pest
<u>TR #</u>	<u>NBZ</u>	<u>DBC</u>
AZ328	132%	999%
AZ328DL	132%	0%
AZ329	125%	
AZ329DL	136%	
AZ331	121%	
AZ332	119%	166%

#### Semivolatiles:

The percent recovery of the surrogate Nitrobenzene-d5 exceeded the QC limits in samples AZ328, AZ329 (and their dilutions), AZ331, and AZ332; however, no action is necessary because only one surrogate in the base/neutral fraction was outside QC limits.

#### Pesticides:

The percent recovery of the surrogate Dibutylchlorendate exceeded the QC limits in sample AZ332; however, no action is necessary because there were no positive results in this sample.

The percent recovery of the surrogate Dibutylchlorendate was 0% in sample AZ328DL. The surrogate appears to have been diluted out of the sample; therefore, no action is taken.

The percent recovery of the surrogate Dibutylchlorendate was 999% in sample AZ328. However, this appeared to be a matrix effect and the results from this sample were not reported due to matrix interference; therefore no action is necessary. (Diluted analysis was reported.)

#### Matrix Spike/Matrix Spike Duplicate

#### Semivolatiles:

The spiking compounds failing percent recovery criteria in the MS/MSD analyses were undetected in the associated unspiked sample AZ332. No action is necessary.

#### Pesticides:

Various spiking compounds failing percent recovery and RPD criteria in the MS/MSD analyses were undetected in the associated unspiked sample AZ332. No action is necessary.

#### Other QC

#### Volatiles:

All diluted analyses of samples AZ328, AZ329, and AZ330 were prepared from sample aliquots of less than 1 milliliter.

#### Compound ID

#### Pesticides:

The positive results for Aldrin, 4,4'-DDD, and Methoxychlor in sample AZ331 are estimated (J) due to lack of quantitative agreement between the quantitation column and confirmation column.

Sample AZ331 was analyzed as a dilution due to high interferences in the original sample. All results on the Data Table are from the original analysis with the exception of the non-detected results for Endosulfan I, Dieldrin, 4,4'-DDE, alpha-Chlordane, and gamma Chlordane. The Contract Required Quantitation Limits for these compounds are from the dilution.

#### **Instrument Performance**

#### Pesticides:

The percent breakdowns for Endrin and 4,4'-DDT were reported as total degradation on column DB1701. However, it was not indicated that Endrin Aldehyde and 4,4'-DDD coelute on this column. Separate calculations showed that the percent breakdown for Endrin and 4,4'-DDT were within criteria. Therefore, no action is taken.

For the run performed on 4/26/91 through 4/29/91 on column DB608, several percent differences for the Dibutylchlorendate retention time check appeared to be reported incorrectly. The percent differences were recalculated and were within criteria. Therefore, no action is necessay.

#### General Comments

Positive results reported below the Contract Required Quantitation Limits (CRQLs) are qualified as estimated (J).

Tentatively Identified Compounds (TICs) which were common laboratory artifacts/contaminants (aldol products, solvent preservatives, reagent contaminants, column breakdown products, etc.) or which were also found in any associated blank were not listed on Table II - Tentatively Identified Compound Summary. If it was determined

that the tentative identification of a TIC was not acceptable, the identification was changed to an unknown or appropriate class of compound.

Dimethylbenzene (xylene), a VOA target compound, was reported as a TIC in the semivolatile analyses of samples AZ328 and AZ329. This compound is not reported on Table II.

Sincerely, QuantaLex, Inc.

Jill Gaschler

Associate Consultant

Jue Hasehlu

anthony W. Noth

Anthony Toth Staff Consultant

**Enclosure** 

#### CIBA GEIGY CASE 16259 TABLE I - RECOMMENDATIONS SUMMARY

TR#	VOA	BNA	Pesticide/PCB
AZ328	A1,A2,A4	A7,A8	A
AZ329	A1,A2,A4	A7	Α
AZ330	A1,A2,A4	. <b>A</b> 7	<b>A</b> 5
AZ331	A1	<b>A</b> 7	A5,A6
AZ332	A1,A2	<b>A</b> 7	Α
AZ333	A <sup>2</sup> ,A <sup>3</sup>	<b>A</b> 7	A
AZ334	A2,A3		·

- A Accept all data.
- A1 Accept data but change positive values for Acetone to revised detection limits due to blank contamination.
- A<sup>2</sup> Accept data but reject (R) detection limits for 2-Butanone due to minimum RF being less than 0.05.
- A<sup>3</sup> Accept data but estimate (J) positive values for Acetone due to calibrations being out of range.
- A<sup>4</sup> Accept data but estimate (J) positive values for Tetrachloroethene due to calibrations being out of range.
- A<sup>5</sup> Accept data but estimate (J) positive values for Aldrin due to calibrations being out of range.
- A6 Accept data but estimate (J) positive values for Aldrin, 4,4'-DDD, and Methoxychlor due to lack of quantitative agreement between columns.
- A<sup>7</sup> Accept data but estimate (UJ) detection limits for 4-Chloroaniline, 3-Nitroaniline, and 4-Nitroaniline due to calibrations being out of range.
- As Accept data but change positive values for bis(2-Ethylhexyl)phthalate to revised detection limits due to blank contamination.

# CIBA GEIGY CASE 16259 TABLE II - TENTATIVELY IDENTIFIED COMPOUND SUMMARY

# Semivolatile Compounds

#### Volatile Compound

#### AZ328 (20 TICs)

Chloromethyl Benzene Isomer

N-(1,1-Dimethylethyl)-2-Propenamide

Alpha, Alpha-Dimethyl Benzene Methanol

Chlorophenol Isomer

1,1'-Oxybisbenzene

4-Hydroxy-3-Methoxy-Benzoic Acid

Sulfonybisphenol Isomer (2)

Benzenacetic Acid

Unknown Carboycilic Acid

Unknown PNA(MW=154)

Unknown Fatty Acid

Unknown Chlorinated Organic

Unknown (7)

#### AZ334 (1 TIC)

1-Bromo-2-Chloro Ethane

#### AZ328 (1 TIC)

Chlorotoluene Isomer

#### AZ329 (1 TIC)

Chlorotoluene Isomer

### AZ330 (1 TIC)

1-Chloro-4-Trifluorobenzene

# AZ331 (1 TIC)

Chlorotoluene Isomer

#### AZ329 (20 TICs)

Chloromethyl Benzene Isomer

1-Phenyl Ethanone

Alpha, Alpha-Dimethyl Benzene Methanol

Ethyl-phenol

Chlorophenol Isomer

2-Chloro Benzene Methanol

Benzenacetic Acid

1,1'-Oxybis Benzene

Sulfanylbis Phenol Isomer (3)

Unknown Fatty Acid (2)

Unknown Carboxylic Acid

Unknown Chlorinated Organic

Unknown (5)

#### **AZ330 (8 TICs)**

Trifluoromethyl Benzenamine Isomer

Chloro Trifluoromethyl Benzenamine Isomer (2)

2,6-Bis(1,1-Dimethylethyl)-2,5-Cyclohexadiene-1,4-Dione

Dimethyl Pyrazine

2-(2H-Benzotriazol-2-yl)-4-Methyl Phenol

Unknown (2)

#### CIBA GEIGY CASE 16259 TABLE II - TENTATIVELY IDENTIFIED COMPOUND SUMMARY (continued)

### **Semivolatile Compounds**

# **Volatile Compound**

## AZ331 (21 TICs)

Aniline (ACN)

Tetramethyl 4-Piperdinone

Tetramethyl 4-Piperdinol

Benzeneacetic Acid

Chloro Trifluoromethyl Benzenamine Isomer

Methyl Quinoxaline

2,6-Bis(1-Dimethyethyl)-2,5-Cydohexadiene-1,4-Dione

1H-Benzotriazole

6-Chloro-N,N'-Bis(1-methylethyl)-1,3,5-Triazine-2,4-Diamine

2-(2H-Benzotriazol-2-YL)-4-Methyl Phenol

Unknown (10)

Unknown Chlorinated Organic

AZ332 (1 TIC)

Unknown

<b>.</b>	-
Region	
***	

# ORGANIC REGIONAL DATA ASSESSMENT

CASE NO. 16259 LABORATORY Gulf South Environmental Laboratory  SDG # AZ328 SOW # 10/86 (Rev. 2/88) DPO: ACTION FYI_		SITE _Ciba Geigy NO. OF SAMPLES/ MATRIX _7/Water REVIEWER (IF NOT ESD) _QuantaLex, Inc. REVIEWER'S NAME _Anthony Toth COMPLETION DATE _June 17, 1991			
	<u>D</u> a	ata Assessment	Summary		
		VOA	BNA	Pest.	Other
1.	Holding Times	0	_ 0		<del></del>
2.	GC/MS Tune/Instr.Perf.	0	<u> </u>	0	
3.	Calibrations	M	0	0	
4.	Blanks	<u></u> 0	O		***
5.	Surrogates	O	_ 0	0	
6.	Matrix Spike/Dup.	0_	_0_	_ 0	<u></u>
7.	Other QC	0 '	0_		<u> </u>
8.	Internal Standards	0	_0_	N/A	·
9.	Compound Identification	0_	_0_	_0	<u> </u>
10.	System Performance	_ 0	_0_		·
11.	Overall Assessment	O	o	_ 0	
<b>A</b> C'	O = Data had no problems/or qualified due to M = Data qualified due to major problems. Z = Data unacceptable. X = Problems, but do not affect data. N/A = Not applicable.  FION ITEMS: Please refer to the memo an	• .	ining to cook dot		
—	11014 11 121415. Ficase teres to the memo and	u discussions perta	nung to each dat	a assessment catego	ory.
AR	EAS OF CONCERN: Most results for 2-	Butanone are reject	ed.		
NO	TABLE PERFORMANCE:				

Site Name	Ciba Geigy	 _
Reference 1	Number	

# REGION I REVIEW OF ORGANIC CONTRACT LABORATORY DATA PACKAGE

The hardcopied <u>Gulf South Environmental Laboratory</u> been reviewed and the quality assurance and performance included:	_ data package received at Region I has ce data summarized. The data reviewed
Case No.         16529         SAS No.           SDG No.         AZ328         Matrix         Water           No. of Samples         7	Sampling Date(s): 04/18/91 Shipping Date(s): 04/19/91 Date Rec'd by Lab: 04/22/91
Traffic Report Nos.: AZ328, AZ329, AZ330, AZ3	31, AZ332, AZ333, AZ334
Trip Blank No.: AZ334 Equipment Blank No.: AZ333 Rinsate Field Dup. Nos.: AZ328, AZ329	
SOW No. 10/88 (Rev. 2/88) requires that specific a associated reports be provided by the laboratory to the R general criteria used to determine the performance were	legions, EMSL-LV, and SMO. The
- Data Completeness Holding Times GC/MS Tuning Calibrations Blanks Surrogate Recoveries -	Matrix Spike/Matrix Spike Dup Field Duplicates Internal Standard Performance Pesticide Inst. Performance Compound Identification Compound Quantitation
Overall comments: In general, the data are valid. Most	results for 2-Butanone are rejected.
<del></del>	
Definitions of Qualifiers:	
<ul> <li>A - Acceptable data.</li> <li>J - Approximate data due to quality control criteria.</li> <li>R - Reject data due to quality control criteria.</li> <li>U - Compound not detected.</li> </ul>	
Reviewer: Anthony W. Joth	Date: 6-17-9/

# I. DATA COMPLETENESS

MISSING INFORMATION	<b>DATE LAB CONTACTED</b>	<b>DATE RECEIVED</b>
Pesticide:		
Evaluation Mixes standard	Not Requested	
Evaluation Mixes standard concentrations.	(See memo)	
YOA:		
The positive result for	Not Requested	
Tetrachloroethane (97 ppb)	(See memo)	
was not reported on Form 1 for sample AZ328.		<del></del>
sample AZ328.		<del></del>
		·
		:
<del></del>		
<del></del>		
· · · · · · · · · · · · · · · · · · ·		<del></del>
		<del></del>

#### II. HOLDING TIMES

Complete table for all samples and circle the fractions which are not within criteria.

		VOA	В	NA	PE	ST
SAMPLE ID	DATE SAMPLED	DATE ANAL	DATE EXTR	DATE ANAL	DATE EXTR	DATE ANAL
AZ328	04/18/91	04/29/91	04/22/91	04/28/91		
AZ328DL	04/18/91	04/30/91	04/22/91	04/29/91	04/22/91	05/01/91
AZ329	04/18/91	04/29/91	04/22/91	04/28/91		
AZ329DL	04/18/91	04/30/91	04/22/91	04/29/91	04/22/91	05/02/91
AZ330	04/18/91	04/29/91	04/22/91	04/28/91	04/22/91	04/28/91
AZ330DL	04/18/91	04/30/91				
AZ331	04/18/91	04/30/91	04/22/91	04/28/91	04/22/91	04/28/91
AZ331DL	04/18/91				04/22/91	05/02/91
AZ332	04/18/91	04/29/91	04/22/91	04/28/91	04/22/91	04/29/91
AZ333	04/18/91	04/29/91	04/22/91	04/28/91	04/22/91	04/30/91
AZ334	04/18/91	04/29/91				
		_				
		_				

VOA - Unpreserved: Aromatic within 7 days, non-aromatic within 14 days of sample

collection.

Preserved: Soils:

Both within 14 days of sample collection. Both within 14 days of sample collection.

BNA & PEST - Extracted within 7 days, analyzed within 40 days, soils and water.

#### **ACTION:**

- 1. If holding times are exceeded all positive results are estimated (J) and non-detects are estimated (UJ).
- 2. If holding times are grossly exceeded, the reviewer may determine that non-detects are unusable (R).

# REGION I Data Review Worksheets

**GC/MS TUNING** 

Ш.

<u>X</u>	The DFTPP performance results were reviewed and found to be within the specified criteria.
	If no, Samples affected:
<u>X</u>	The BFB performance results were reviewed and found to be within the specified criteria.
	If no, Samples affected:

If mass calibration is in error, refer to the Region guidelines for expanded criteria. If necessary, all associated data as unusable (R).

#### IV A. VOLATILE CALIBRATION VERIFICATION

Date of Initial Calibration

Dates of Continuing Calibrations

Instrument ID

Marin A coult

1.04/18/91

1.04/29-30/91

1.F

Matrix/Level :<u>Water</u>

DATE \_\_CRITERIA OUT \_\_COMPOUND (VALUE)

<u>DATE</u>	<u>CRITERIA OUT</u> RF, %RSD, RF, %D	COMPOUND (VALUE)
04/29/91	RF Samples Affected:	2-Butanone (0.042) AZ328, AZ329, AZ330, AZ332, AZ333, AZ334
04/29/91	%D Samples Affected:	Acetone (34.0) AZ333, AZ334
04/29/91	%D Samples Affected:	Dibromochloromethane (26.4) None
04/29/91	%D Samples Affected:	2-Butanone (39.1) None
04/29/91	%D Samples Affected:	Trans-1.3-Dichloropropene (26.4) None
04/29/91	%D Samples Affected:	Bromoform (27.2) None
04/29/91	%D Samples Affected:	4-Methyl-2-Pentanone (29.8) None
04/29/91	%D Samples Affected:	2-Hexanone (34,2) None
04/29/91	%D Samples Affected:	Tetrachloroethene (27.2) AZ328, AZ329, AZ330
04/29/91	%D Samples Affected:	1.2-Dichloroethane (25.3) None

- 1. All RF's, and RF's must be >0.05.
- 2. All %RSD's must be <30%.
- 3. All %D's must be <25%.

#### **ACTION:**

- 1. If any compound has an initial RF or a continuing RF of <0.05:
  - a. Flag positive results for that compound as estimated (J).
  - b. Flag non-detects for that compound as unusable (R).
- 2. If any compound has a %RSD >30% or a %D >25%:
  - a. Flag positive results for that compound as estimated (J).
  - b. Flag non-detects for that compound as estimated (UJ) if the %RSD or %D is >50%.

A separate worksheet should be filled out for each initial curve.

#### IV A. VOLATILE CALIBRATION VERIFICATION

Date of Initial Calibration

Dates of Continuing Calibrations

Instrument ID

Matrix/Level

: 04/18/91
: 04/29-30/91
: F
: Water

	_,		•
DATE	<u>CRITERIA OUT</u> RF, %RSD, RF, %D	COMPOUND (VALUE	D.
04/29/91	%D Samples Affected:	Carbon Tetrachloride (25.7) None	
04/29/91	%D Samples Affected:	Vinyl Acetate (25.5) None	
04/29/91	%D Samples Affected:	cis-1.3-Dichloropropene (25.1) None	· · · · · · · · · · · · · · · · · · ·
04/30/91	%D Samples Affected:	Acetone (45.1) None	
04/30/91	%D Samples Affected:	2-Butanone (26.1) None	_ <del>`</del>
04/30/91	%D Samples Affected:	Bromodichloromethane (27.9) None	
04/30/91	%D Samples Affected:	Dibromochloromethane (39.9) None	
04/30/91	%D Samples Affected:	Bromoform (48.4) None	·
04/30/91	%D Samples Affected:	2-Hexanone (35.2) None	
	Samples Affected:		

- 1. All RF's, and RF's must be >0.05.
- 2. All %RSD's must be <30%.
- 3. All %D's must be <25%.

#### **ACTION:**

- 1. If any compound has an initial RF or a continuing RF of <0.05:
  - a. Flag positive results for that compound as estimated (J).
  - b. Flag non-detects for that compound as unusable (R).
- 2. If any compound has a %RSD >30% or a %D >25%:
  - a. Flag positive results for that compound as estimated (J).
  - b. Flag non-detects for that compound as estimated (UJ) if the %RSD or %D is >50%.

A separate worksheet should be filled out for each initial curve.

#### IV B. SEMIVOLATILE CALIBRATION VERIFICATION Date of Initial Calibration : 02/26/91 Dates of Continuing Calibrations : 04/28-29/91 Instrument ID DATE CRITERIA OUT <u>COMPOUND</u> RF, %RSD, RF, %D 04/28/91 %D 4-Chloroaniline (-69.5) Samples Affected: AZ328, AZ329, AZ330, AZ331, AZ332, AZ333 04/28/91 3-Nitroaniline (108.9) AZ328, AZ329, AZ330, AZ331, AZ332, AZ333 Samples Affected: 04/28/91 4-Nitrophenol (-25.3) Samples Affected: None 04/28/91 4-Nitroaniline (-60.3) Samples Affected: AZ328, AZ329, AZ330, AZ331, AZ332, AZ333 04/29/91 %D 4-Chloraniline (-76.7) Samples Affected: None 04/29/91 3-Nitroaniline (104.4) Samples Affected: None 4-Nitrophenol (-39.1) 04/29/91 Samples Affected: None 04/29/91 4-Nitroaniline (-72.1) Samples Affected: None Samples Affected: Samples Affected: Samples Affected:

See worksheet IV-A for criteria and actions.

Samples Affected:

Samples Affected:

A new worksheet should be filled out for each initial curve.

# V A. BLANK ANALYSIS RESULTS (Sections 1 & 2)

List the contamination in the blanks below.

1. Labora	tory Blanks		•	Level: Soil
DATE	LAB ID	FRACTION/ MATRIX	COMPOUND	CONCENTRATION/ UNITS
04/29/91	VBLKW1	VOA/Water	Methylene Chloride	_5 ug/L
04/29/91	SBLKW1	BNA/Water	bis(2-Ethylhexyl)phthalate	2 ug/L
	<del>.</del>	<u> </u>		
		-		
2. Equipm	nent and Trip Bl	anks		
DATE	TR#	FRACTION/ MATRIX	COMPOUND	CONCENTRATION/ UNITS
04/29/91_	AZ333	VOA/Water	Acetone	25 ug/L
04/29/91	AZ334	VOA/Water	Acetone	30 ug/L
04/29/91	AZ334	VOA/Water	1.2-Dichloroethane	13 ug/L
	<del></del> ,			

A separate worksheet should be used for low and medium level blanks.

## V B. BLANK ANALYSIS RESULTS (Section 3)

#### 3. Blank Actions

Action levels should be based upon the highest concentration of contaminant determined in any blank. The action level for samples which have been concentrated or diluted should be multiplied by the concentration/dilution factor. No positive sample result should be reported unless the concentration of the compound in the sample exceeds the action level of 10 x's the amount in the blank for the common contaminants, or 5 x's the amount for any other compound. Specific actions are as follows:

- 1. The concentration is less than the CRQL, report the CRQL.
- 2. The concentration is greater than the CROL, but less than the action level, report the concentration found U.
- 3. The concentration is greater than the action level, report the concentration unqualified.

For examples, refer to the Regional Guidelines.

Common contaminants = methylene chloride, acetone, 2-butanone, toluene, and phthalates.

LEVEL: Low			
COMPOUND	MAX. CONC./ UNITS	ACTION LEVEL/ UNITS	CROL
Acetone	30 ug/L	300 ug/L	10 ug/L
Methylene Chloride	5 ug/L	50 ug/L	5 ug/L
1,2-Dichloroethane	13 ug/L	65 ug/L	5 ug/L
bis(2-Ethylhexyl)phthalate	2 ug/L	20 ug/L	10 ug/L
			-

A separate worksheet should be used for low and medium level blanks.

# VI. SURROGATE SPIKE RECOVERIES

List the percent recoveries which do not meet the criteria for surrogate recovery.

							Matri	x: _	Water	
TR #'s	TOL	VOA BFB	DCE	NBZ	B/N FBP	TPH	PHL	A 2FP	ТВР	Pest* DBC
AZ328				132%					_	999%
AZ328DL			,	132%					_	0%
AZ329				125%						<del> </del>
AX329DL			,	136%					<u></u>	
AX331				121%	_					
AZ332		· - · · · -		119%						166%
·				•						
					-					<u> </u>
QC Limits				35%						24%
	to	to	to	to	to	to	to	to	to	to
				114%						154%
Surrogate Ac	tions:			<u>&lt;10</u>	Percen	t Recove	ery R >CRI		visory on	ly
Positi Non-c	ve sample letected r	e results esults		J F		J UJ	J A			
~~~			_							

CRR = Contract Required Recovery Range

Surrogate Action should be applied:

- 1. If at least two surrogates in a B/N or A fraction or one surrogate in the VOA fraction are out of specification, but have recoveries of >10%.
- 2. If any one surrogate in a fraction shows <10% recovery.

#### VII A. MATRIX SPIKE/MATRIX SPIKE DUPLICATE

1.	Matrix Spike/Matrix	Spike Duplicate	Recoveries and Precision
----	---------------------	-----------------	--------------------------

TR Nos. AZ332N	AS , <u>AX332MSD</u>	Level: Low	Matrix: Water
List the percent rec Form 3.	overies and RPD's of compour	nds which do not meet the	criteria stated on
FRACTION/ MS OR MSD	COMPOUND	%REC/ RPD	<u>OC LIMITS</u>
Pest/MS	Endrin	123%	56-121%
Pest/MS/MSD	Heptachlor	27	20
Pest/MS/MSD	Aldrin	30	22
BNA/MS	4-Nitrophenol	113%	10-80%
BNA/MSD	4-Nitrophenol	109%	10-80%
BNA/MS	2.4-Dinitrotoluene	109%	24-96%
BNA/MSD	2.4-Dinitrotoluene	103%	24-96%
·			
			·
		<del></del>	
•			

#### QUALIFICATION IS LIMITED TO THE UNSPIKED SAMPLE ONLY.

1. If any compound does not meet the Contract Required Recovery range (CRR), follow the actions stated below:

	Percent Recovery			
	<10 <b>%</b>	10%-CRR	<u>&gt;CRR</u>	
Positive sample results	J	J	J	
Non-detected results	R	Α	Α	

2. If any compound does not meet the RPD criteria, flag positive results for that compound as estimated (J).

A separate worksheet should be used for each MS/MSD pair.

# VII B. MATRIX SPIKE/MATRIX SPIKE DUPLICATE (Section 2)

2. Matrix Spike l	Duplicate - Unspiked Con	pounds				
TR Nos. AZ33	32MS	D				
unspiked sample,	tions of the unspiked com matrix spike, and matrix s the unspiked compounds	pike dupli	id determine t icate. No lim	he percent RSI its have been de	o's of the evelop	he ed for
<u>FRACTION</u>	COMPOUND	<u>SA</u>	MPLE, MS,	MSD CONC.		%RSD
None				· 		
				·	,	
, 						
			,			
					,	
					,	
<del></del>			<u></u>		,	
		<del>.</del> .			,	

The reviewer must use professional judgement to determine if there is a need to qualify any of the unspiked compounds in the sample.

TR Nos. AZ328 ,

#### VIII. FIELD DUPLICATE PRECISION

1. An R	tions of the compounds PD of <30% for water du PD of <50% for soil dup	iplicates.	ne following RPD criteria:	
<u>FRACTION</u>	COMPOUND	SAMPLE CONC.	DUP SAMPLE CONC.	RPD
None	·			
·		· · · · · · · · · · · · · · · · · · ·	·	
· :			·	
<del></del>				
	·	-	-	
<del></del>		· · · · · · · · · · · · · · · · · · ·		
<u> </u>				

#### **ACTIONS:**

- 1. If the results for any compounds do not meet the RPD criteria, flag the positive results for that compound as estimated.
- 2. If one value is non-detected, and one is above the CRQL:
  - a. Flag the positive result as estimated (J).
  - b. Flag the non-detected result as estimated (UJ).

NOTE: Professional judgement may be utilized to apply duplicate actions to all samples of a similar matrix.

A separate worksheet should be filled out for each field duplicate pair.

Matrix: Water

#### IX. INTERNAL STANDARD PERFORMANCE

List the internal standard areas of samples which do not meet the criteria of +100% or -50% of the internal standard area in the associated continuing calibration standard.

SAMPLE ID	DATE	IS OUT	IS AREA/	ACCEPTABLE RANGE	<u>ACTION</u>
None	· · ·		-	· · · · · · · · · · · · · · · · · · ·	
		<u></u>		· · · · · · · · · · · · · · · · · · ·	·
	·	<del>-;</del>			
<del></del>					

#### **ACTION:**

- 1. If an IS area count is outside the criteria -50% or +100% of the associated standard:
  - a. Positive results for compounds quantitated using that IS are flagged as estimated (J) for that sample fraction.
  - b. Non-detects for compounds quantitated using that IS are flagged as estimated (UJ) for that sample fraction.
  - c. If extremely low area counts are reported, or if performance exhibits a major drop-off, then a severe loss of sensitivity is indicated. Non-detects should then be flagged as unusable (R).
- 2. If an IS retention time varies more than 30 seconds, the chromatographic profile for that sample must be examined to determine if any false positives or negatives exist. For shifts of a large magnitude, the reviewer may consider partial or total rejection of the data for that sample fraction.

# X A. PESTICIDE INSTRUMENT PERFORMANCE (Section 1)

#### 1. DDT Retention Time

List the DDT standards which have a retention time (RT) of less than 12 minutes on the packed column (except OV-1 or OV-101).

STANDARD ID	DATE/ TIME	RT	SAMPLES AFFECTED	<u>ACTIONS</u>
None		·	· · · · · · · · · · · · · · · · · · ·	
		<del></del>		
· .				
			·	
			<del></del>	
· · · · · · · · · · · · · · · · · · ·				
		·		
•			<u>.</u>	

#### **ACTION:**

If the RT is less than 12 minutes, examine the chromatography to evaluate the separation. If adequate separation is not achieved, flag all affected compound data as unusable (R).

2. Retention Time Windows

# X B. PESTICIDE INSTRUMENT PERFORMANCE (Section 2)

List the compounds	which are not	within the	established	windows.

COMPOUND	DATE (TIME)	RT	RT WINDOW	SAMPLES AFFECTED
None			· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·
· · · · · · · · · · · · · · · · · · ·				
				· · · · · · · · · · · · · · · · · · ·
		-;-		
Check the sample chromato	grams of the	e samples	analyzed after the la	est in control standard for
peaks within an expanded w Refer to Regional guideline present, discuss actions belo	indow. If r s for inform ow:	o peaks a ation on o	are present, there is u qualifying data if pea	est in control standard for sually no effect on the data. ks are present. If peaks are
				·
				· · · · · · · · · · · · · · · · · · ·

# X C. PESTICIDE INSTRUMENT PERFORMANCE (Section 3)

J. DD . MIG DIGHT DOELUGUON	3.	<b>DDT</b>	and	<b>Endrin</b>	Degradation
-----------------------------	----	------------	-----	---------------	-------------

List the standards which have a DDT or Endrin breakdown of greater than 20%.

STANDARD ID	DDT OR ENDRIN	PERCENT BREAKDOWN	SAMPLES AFFECTED	<u>DDD, DDE OR</u> <u>ENDRIN KETONE</u> <u>PRESENT</u>
None		-		
		· .		·

If the percent breakdown for DDT is greater than 20%:

- 1. Flag all positive results for DDT as estimated (J) for all samples following the last in control standard. If no DDT was present, but DDD and/or DDE are positive, then flag the quantitation limit for DDT as unusable (R).
- 2. Flag all positive results for DDD and/or DDE as estimated (J).

If the percent breakdown for Endrin is greater than 20%:

- 1. Flag all positive results for endrin as estimated (J) for all samples following the last in control standard. If no endrin was detected, but endrin aldehyde and/or endrin ketone are positive, flag the quantitation limit for endrin as unusable (R).
- 2. Flag all positive results for endrin ketone as estimated (J).

The percent breakdowns for Endrin and 4.4'-DDT were reported as total degradation on column
DB-1701. However, it was not indicated that Endrin Aldehyde and 4.4'-DDD coelute on this column.
Separate calculations showed that the percent breakdown for Endrin and 4.4'-DDT are within criteria.
Therefore, no action is taken.

# X D. PESTICIDE INSTRUMENT PERFORMANCE (Section 4)

## 4. DBC Retention Time Check

List the percent difference for the DBC shift greater than 2% for packed columns, greater than 1.5% for wide-bore capillary columns, or greater than 0.3% for narrow-bore capillary columns.

	<u>TR #'S</u>	DBC %DIFFERENCE	<u>ACTIONS</u>
	None	·	•
		<u> </u>	· · · · · · · · · · · · · · · · · · ·
	· ·	·	
		·	
	<del></del>		
the rev	iewer. Discuss	eet the retention time criteria, the analysises, but qualification of the data is left up to any qualification of the data below:  **DS appear to be incorrect. Recalculate*	
	•	vithin criteria. No action is necessary.	
	·		
		· · · · · · · · · · · · · · · · · · ·	
	<u> </u>	·····	

# XI A. PESTICIDE CALIBRATION (Sections 1 and 2)

1.	Initial Calibration	•	

List the compounds which did not meet the Relative Standard Deviation (RSD) criteria of less than 10% for the initial calibration on the quantitation column.

<u>DATE</u>	COMPOUND	%RSD	<u>COLUMN</u>	SAMPLES AFFECTED
None				
<ul><li>2. Analytica</li><li>Did the labor</li><li>If No,</li></ul>	ratory follow the correct 7	2 hour sequence ta reviewer mus	e described in th	ne SOW? Yes
			-	
		·		•
	·			·
·				•

# XI B. PESTICIDE CALIBRATION (Section 3)

# 3. Continuing Calibration

List the compounds which did not meet the percent difference (%D) criteria of <15% on the quantitation column or <20% on the confirmation for the continuing calibration.

DATE	COMPOUND	<u>%D</u>	COLUMN	SAMPLES AFFECTED
04/29/91	Aldrin	<u>-17.3</u>	DB608	AZ330, AZ331
<del></del>	·	<del></del>		
	<del></del>			· · · · · · · · · · · · · · · · · · ·
		<del></del>	-	
			<del></del>	
	-			

If the %D criteria is not met, flag all associated positive results as estimated (J).

#### REGION I Data Review Worksheets

# XII. SAMPLE QUANTITATION

In the space below, please show a minimum of one sample calculation per fraction:

#### VOA:

AZ328DL Toluene

#### BNA:

AZ328 1,2-Dichlorobenzene

$$\frac{37320}{11069}$$
 x  $\frac{40 \text{ ug/L}}{1.291}$  = 104.5 ug/L

#### PEST/PCB:

AZ330 Aldrin

Page

1 of 1

#### **CLP VOLATILE ORGANIC ANALYSIS** AZ328

**CASE NO. 16259** 

SDG NO.

**ANALYTICAL RESULTS** 

Sample Location	Ciba	Ciba	Ciba	Ciba	Ciba	Ciba	Ciba	
	Geigy	Gelgy	Gelgy	Gelgy	Geigy	Geigy	Gelgy	
Sample Number	MW14S	MW14S	MW11S	MW15S	MW18S		. =	
	•							
Traffic Report Number	AZ328	AZ329	AZ330	AZ331	AZ332	AZ333	AZ334	
Remarks	50X Dil.	Dup. AZ328				Rinsate	Trip Blank	
		50X DII.						
Sampling Date	04/18/91	04/18/91	04/18/91	04/18/91	04/18/91	04/18/91	04/18/91	
Analysis Date	04/29/91	04/29/91	04/29/91	04/30/91	04/29/91	04/29/91	04/29/91	
VOLATILE ORGANIC	,			-	1			<del>                                     </del>
COMPOUND	ug/L	ug/L	ug/L	ug/L	ug/L	ug/L	ug/L	
Chloromethane								
Bromomethane								
Vinyl Chloride								
Chloroethane								
Methylene Chloride								
Acetone						25 J	30 J	
Carbon Disulfide								
1,1-Dichloroethene	· · · · · · · · · · · · · · · · · · ·				_	ļ <u>.</u> .		
1,1-Dichloroethane								
1,2-Dichloroethene (Total)	<u> </u>							
Chloroform						<u> </u>		
1,2-Dichloroethane				ļ			13	
2-Butanone				ļ			<u> </u>	
1,1,1-Trichioroethane	260	240		<u></u>				
Carbon Tetrachloride			ļ	<u> </u>				
Vinyl Acetate				<u> </u>				
Bromodichloromethane			ļ	<u> </u>		ļ		
1,2-Dichloropropane		<del></del>	<u> </u>		<del></del>	ļ	<del> </del>	
cls-1,3-Dichloropropene Trichloroethene		<u> </u>		<del> </del>		- <del>-</del> -	-	
Dibromochloromethane	<del></del>	<del> </del>	<del> </del>	1		<u> </u>	<del> </del>	
1,1,2-Trichloroethane		<del> </del>		<del> </del>	<del> </del>			
Benzene	<del></del>	<del>                                     </del>	14	<del> </del>	-	<del> </del>	<del> </del>	
trans-1,3-Dichloropropene	<del></del>	+		<del>                                     </del>	+	<del> </del>	<del> </del>	<del>                                     </del>
Bromoform	<del></del>	<del>                                     </del>		<del>                                     </del>	<del>- </del>	<del> </del>	<del> </del>	<del>                                     </del>
4-Methyl-2-pentanone		<del> </del>	,	+	+	<del> </del>	<del>  </del>	<del>                                     </del>
2-Hexanone	<del></del>	<del> </del>		-	-	<del> </del> .	+	<del>                                     </del>
Tetrachloroethene	97 J	90 J	4 J	<del> </del>	<del> </del>	<del> </del>		<del>                                     </del>
1,1,2,2-Tetrachioroethane	<del></del>			+	<del> </del>	<del>                                     </del>	+	<del>                                     </del>
Toluene	230000 *	240000 *	7	10	+	+	+	-
Chlorobenzene	150 J	140 J	830 *	12	+	+	+-	-
Ethylbenzene	1200	1200		4 J	<del> </del>	+	+	
Styrene	1.23	1	<del>                                     </del>	+	<del>                                     </del>	<del> </del>	<del></del>	<del> </del>
Xylene (Total)	4000	3800	<del>                                     </del>	20	<del>                                     </del>	<del>                                     </del>	+	<del>                                      </del>
	1-000	15000		20				I

A blank space indicates the compound was not detected.

Quantitation is approximate due to limitations identified during the quality control review.

R Value is rejected.

Value reported from diluted analysis.

2

Page

1 of 1

AZ328

## CLP VOLATILE ORGANIC ANALYSIS

CASE NO. 16259

SDG NO.

SAMPLE QUANTITATION LIMITS

Sample Number   MW14S   MW14S MW14S   MW14S   MW14S   MW14S   MW14S   MW14S   MW14S   MW14S	Sample Location	Ciba	Clba	Ciba	Ciba	Clba	Clba	Ciba	
Sample Number	•		1	1					
Traffic Report Number	Sample Number		<del></del>	<del></del>		<del></del>	Goigy	Congy	
Remarks	·			}					
Remarks	Traffic Donart Number	A7000	47000	47000	47004	47000	17000	1700	
COMPOUND		<del></del>		<del>                                      </del>	AZ331	AZ332		+	
VOLATILE ORGANIC COMPOUND         ug/L	nemarks	SUX DII.					Rinsate	Trip Blank	
Chloromethane	VOLATILE ORGANIC							<del>                                     </del>	
Bromomethane	COMPOUND	ug/L	ug/L	ug/L	ug/L	ug/L	ug/L	ug/L	
Vinyl Chloride         500         500         10         10         10         10         10           Chloroethane         500         500         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10 <t< td=""><td>Chloromethane</td><td>500</td><td>500</td><td>10</td><td>10</td><td>10</td><td>10</td><td>10</td><td></td></t<>	Chloromethane	500	500	10	10	10	10	10	
Chloroethane         500         500         10         10         10         10         10           Methylene Chloride         250         250         5         5         5         5         5           Acetone         1000 U         970 U         23 U         60 U         16 U         10         10           Carbon Dleufilde         250         250         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5 <td< td=""><td>Bromomethane</td><td>500</td><td>500</td><td>10</td><td>10</td><td>10</td><td>10</td><td>10</td><td></td></td<>	Bromomethane	500	500	10	10	10	10	10	
Methylene Chloride         250         250         5         5         5         5           Acetone         1000 U         970 U         23 U         60 U         16 U         10         10           Carbon Disutifide         250         250         5         5         5         5         5           1,1-Dichloroethene         250         250         5         5         5         5         5           1,2-Dichloroethene (Total)         250         250         5         5         5         5         5           1,2-Dichloroethene (Total)         250         250         5         5         5         5         5         5           1,2-Dichloroethene (Total)         250         250         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5 <td>Vinyl Chloride</td> <td>500</td> <td>500</td> <td>10</td> <td>10</td> <td>10</td> <td>10</td> <td>10</td> <td></td>	Vinyl Chloride	500	500	10	10	10	10	10	
Acetone         1000 U         970 U         23 U         60 U         16 U         10         10           Carbon Disulfide         250         250         5         5         5         5         5         5         5         1         1         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10 <td< td=""><td>Chloroethane</td><td>500</td><td>500</td><td>10</td><td>10</td><td>10</td><td>10</td><td>10</td><td></td></td<>	Chloroethane	500	500	10	10	10	10	10	
Carbon Disulfide         250         250         5         5         5         5           1,1-Dichloroethene         250         250         5         5         5         5         5           1,1-Dichloroethane         250         250         5         5         5         5         5           1,2-Dichloroethane         250         250         5         5         5         5         5           2-Butanone         250         250         5         5         5         5         5           2-Butanone         500 R         500 R         10 R         10 R         10 R         10 R           1,1,1-Trichloroethane         250         250         5         5         5         5         5           2-Butanone         500 R         500 R         10 R	Methylene Chloride	250	250	5	5	5	5	5	
Carbon Disulfide         250         250         5         5         5         5         5           1,1-Dichloroethene         250         250         5         5         5         5         5           1,1-Dichloroethane         250         250         5         5         5         5         5           1,2-Dichloroethane         250         250         5         5         5         5         5           1,2-Dichloroethane         250         250         5         5         5         5         5           2-Butanone         500 R         500 R         10 R         10 R         10 R         10 R         10 R           1,1,1-Trichloroethane         250         250         5         5         5         5         5           2-Butanone         500 R         500 R         10 R <td< td=""><td>Acetone</td><td>1000 U</td><td>970 U</td><td>23 U</td><td>60 U</td><td>16 U</td><td>10</td><td>10</td><td></td></td<>	Acetone	1000 U	970 U	23 U	60 U	16 U	10	10	
1,1-Dichloroethene         250         250         5         5         5         5         5         1,1-Dichloroethane         250         250         250         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5 </td <td>Carbon Disulfide</td> <td>250</td> <td>250</td> <td>5</td> <td>5</td> <td>5</td> <td>5</td> <td>+</td> <td></td>	Carbon Disulfide	250	250	5	5	5	5	+	
1,1-Dichloroethane         250         250         5         5         5         5         5         1,2-Dichloroethane (Total)         250         250         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         <	1,1-Dichloroethene	250	250	5				+	
1,2-Dichloroethene (Total)         250         250         5         5         5         5         5         5         1         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5 <td< td=""><td>1,1-Dichloroethane</td><td>250</td><td>250</td><td>5</td><td>5</td><td>5</td><td></td><td><del>                                     </del></td><td></td></td<>	1,1-Dichloroethane	250	250	5	5	5		<del>                                     </del>	
Chloroform         250         250         5         5         5         5           1,2-Dichloroethane         250         250         5         5         5         5           2-Butanone         500 R         500 R         10 R         10 R         10 R         10 R           1,1,1-Trichloroethane         250         250         5         5         5         5           Carbon Tetrachloride         250         250         5         5         5         5           Vinyl Acetate         500         500         10         10         10         10         10           Bromodichloromethane         250         250         5         5         5         5         5           1,2-Dichloropropane         250         250         5         5         5         5         5           1,2-Dichloropropane         250         250         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5	1,2-Dichloroethene (Total)	250	250	5	5	5		<del></del>	
1,2-Dichloroethane         250         250         5         5         5         5         5           2-Butanone         500 R         500 R         10 R         <	Chloroform	250	250	5	<del></del>		<del>                                     </del>	+	
2-Butanone         500 R         500 R         10 R         11 R         10 R	1,2-Dichloroethane	250	250	<del></del>	<del></del>			<del> </del>	
1,1,1-Trichloroethane         250         250         5         5         5         5         5           Carbon Tetrachloride         250         250         5         5         5         5         5           Vinyl Acetate         500         500         10         10         10         10         10           Bromodichloromethane         250         250         5         5         5         5         5           1,2-Dichloropropane         250         250         5         5         5         5         5           cls-1,3-Dichloropropane         250         250         5         5         5         5         5           cls-1,3-Dichloropropene         250         250         5         5         5         5         5           Dibromochloromethane         250         250 <td< td=""><td>2-Butanone</td><td>500 R</td><td></td><td>10 R</td><td></td><td></td><td>+</td><td><del>-</del></td><td></td></td<>	2-Butanone	500 R		10 R			+	<del>-</del>	
Carbon Tetrachloride         250         250         5         5         5         5           Vinyl Acetate         500         500         10         10         10         10         10           Bromodichloromethane         250         250         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5 <td< td=""><td>1,1,1-Trichloroethane</td><td>250</td><td><del></del></td><td><del>                                     </del></td><td></td><td><del></del></td><td></td><td><del></del></td><td></td></td<>	1,1,1-Trichloroethane	250	<del></del>	<del>                                     </del>		<del></del>		<del></del>	
Vinyl Acetate         500         500         10         10         10         10         10           Bromodichloromethane         250         250         5         5         5         5         5           1,2-Dichloropropane         250         250         5         5         5         5         5           cls-1,3-Dichloropropene         250         250         5         5         5         5         5           Trichloroethene         250         250         5         5         5         5         5           Dibromochloromethane         250         250         5         5         5         5         5           1,1,2-Trichloroethane         250         250         5         5         5         5         5           Benzene         250         250         5         5         5         5         5         5           Benzene         250         250         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5 </td <td>Carbon Tetrachloride</td> <td>250</td> <td></td> <td>5</td> <td></td> <td>5</td> <td></td> <td><del>                                     </del></td> <td></td>	Carbon Tetrachloride	250		5		5		<del>                                     </del>	
Bromodichloromethane	Vinyl Acetate	500		<del></del>			<del></del>		
1,2-Dichloropropane       250       250       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5       5 <td>Bromodichloromethane</td> <td>250</td> <td>250</td> <td></td> <td></td> <td></td> <td><del></del></td> <td><del></del></td> <td></td>	Bromodichloromethane	250	250				<del></del>	<del></del>	
cls-1,3-Dichloropropene         250         250         5         5         5         5         5           Trichloroethene         250         250         5         5         5         5         5           Dibromochloromethane         250         250         5         5         5         5         5         5           1,1,2-Trichloroethane         250         250         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5	1,2-Dichloropropane	250	<del></del>			5		<del>                                     </del>	
Trichloroethene         250         250         5         5         5         5         5           Dibromochloromethane         250         250         5         5         5         5         5           1,1,2-Trichloroethane         250         250         5         5         5         5         5           Benzene         250         250         5         5         5         5         5         5           trans-1,3-Dichloropropene         250         250         5         5         5         5         5         5         5           Bromoform         250         250         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5	cls-1,3-Dichloropropene	250	250	5					
Dibromochloromethane         250         250         5         5         5         5         5           1,1,2-Trichloroethane         250         250         5         5         5         5         5           Benzene         250         250         5         5         5         5         5         5           trans-1,3-Dichloropropene         250         250         5         5         5         5         5         5         5           Bromoform         250         250         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5         5	Trichloroethene	250	250	5	5			<del></del>	
1,1,2-Trichloroethane       250       250       5       5       5       5       5         Benzene       250       250       5       5       5       5       5       5         trans-1,3-Dichloropropene       250       250       5       5       5       5       5       5         Bromoform       250       250       5       5       5       5       5       5         4-Methyl-2-pentanone       500       500       10       10       10       10       10       10         2-Hexanone       500       500       10       10       10       10       10       10         Tetrachloroethene       250       250       5       5       5       5       5       5         Toluene       10000 °       10000 °       5       5       5       5       5       5         Chlorobenzene       250       250       50 °       5       5       5       5       5	Dibromochloromethane	250	250	5	5	5	5	· · · · · · · · · · · · · · · · · · ·	
Benzene       250       250       5       5       5       5       5         trans-1,3-Dichloropropene       250       250       5       5       5       5       5         Bromoform       250       250       5       5       5       5       5         4-Methyl-2-pentanone       500       500       10       10       10       10       10         2-Hexanone       500       500       10       10       10       10       10       10         Tetrachloroethene       250       250       5       5       5       5       5         1,1,2,2-Tetrachloroethane       250       250       5       5       5       5       5         Toluene       10000 *       10000 *       5       5       5       5       5         Chlorobenzene       250       250       50 *       5       5       5       5	1,1,2-Trichloroethane	250	250	5	5	5 .	<del></del>		-
trans-1,3-Dichloropropene         250         250         5         5         5         5         5           Bromoform         250         250         5         5         5         5         5         5           4-Methyl-2-pentanone         500         500         10         10         10         10         10         10           2-Hexanone         500         500         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10	Benzene	250	250	5	5	5	5	5	
Bromoform         250         250         5         5         5         5         5           4-Methyl-2-pentanone         500         500         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10         10	trans-1,3-Dichloropropene	250	250	5	5	5			
2-Hexanone       500       500       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10	Bromoform	250	250	5	5	5	5	5	
2-Hexanone       500       500       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10       10	4-Methyl-2-pentanone	500	500	10	10	10	10		
Tetrachloroethene         250         250         5         5         5         5         5           1,1,2,2-Tetrachloroethane         250         250         5         5         5         5         5           Toluene         10000 *         10000 *         5         5         5         5         5           Chlorobenzene         250         250         50 *         5         5         5         5	2-Hexanone	500	500	10			<del></del>	<del></del>	-
1,1,2,2-Tetrachloroethane       250       250       5       5       5       5         Toluene       10000 *       10000 *       5       5       5       5       5         Chlorobenzene       250       250       50 *       5       5       5       5	Tetrachioroethene	250	250		<del></del>			<del></del>	
Toluene         10000 *         10000 *         5         5         5         5         5           Chlorobenzene         250         250         50 *         5         5         5         5	1,1,2,2-Tetrachloroethane	250	250		<del></del>			<del></del>	-
Chlorobenzene         250         250         50 *         5         5         5	Toluene	10000 *	10000 *	5		5		+	
	Chlorobenzene	250	250	50 *		<del>                                     </del>		<del></del>	
Ethylbenzene   250   250   5   5   5   5	Ethylbenzene	250	250		<del></del>			<del></del>	
Styrene 250 250 5 5 5 5	Styrene	250		5	<del></del>	<del>                                     </del>	<del></del>		
Xylene (Total) 250 250 5 5 5 5	_ <del>`</del>	<del></del>	<del>                                     </del>		<del></del>			<del>                                     </del>	

UJ Quantitation limit is approximate due to limitations identified during the quality control review.

R Value is rejected.

<sup>\*</sup> Elevated due to diluted value used.

3

Page

1 of 2

# CLP EXTRACTABLE ORGANIC ANALYSIS

CASE NO. 16259

SDG NO. AZ328

ANALYTICAL RESULTS

	<del></del> _	7110712111			1		T	
Sample Location	Ciba	Ciba	Ciba	Ciba	Clba	Ciba		
	Geigy	Geigy	Geigy	Geigy	Gelgy	Gelgy		
Sample Number	MW14S	MW14S	MW11S	MW15S	MW18S			
		<u> </u>		<u> </u>				
Traffic Report Number	AZ328	AZ329	AZ330	AZ331	AZ332	AZ333		
Remarks		Dup. AZ328				Rinsate		
Sampling Date	04/18/91	04/18/91	04/18/91	04/18/91	04/18/91	04/18/91		
Extraction Date	04/22/91	04/22/91	04/22/91	04/22/91	04/22/91	04/22/91		
Analysis Date	04/28/91	04/28/91	04/28/91	04/28/91	04/28/91	04/28/91		
SEMI-VOLATILE	_							
COMPOUND	ug/L_	ug/L_	ug/L	ug/L	ug/L	ug/L	ļ	ļ
Phenol	410 *	410 *		52			ļ <u></u> .	
bis (2-Chloroethyl) ether				<u> </u>		ļ ·		,
2-Chiorophenol				ļ	ļ			·
1,3-Dichlorobenzene	-:			<del> </del>				<u> </u>
1,4-Dichlorobenzene				ļ			ļ	
Benzyl Alcohol	170 *	160 *		ļ	ļ	<del>-</del>	<u> </u>	
1,2-Dichiorobenzene	100	97		<u>  </u>			ļ	
2-Methylphenol	480 *	470 *		<del>                                     </del>		ļ		
bis (2-Chloroisopropyl)ether					<u> </u>	1		
4-Methylphenol	200 *	200 *		54				
N-Nitroso-di-n-propylamine							<u> </u>	
Hexachloroethane						<u> </u>	<u> </u>	
Nitrobenzene			ļ					
Isophorone						<u> </u>		
2-Nitrophenol				<u> </u>		<u> </u>		
2,4-Dimethylphenol	40	38		ļ	<u> </u>			
Benzoic acid	1000 *	970 *						
bis (2-Chloroethoxy) methane	<u> </u>							
2,4-Dichlorophenol	1400 *	1300 *		26				
1,2,4-Trichlorobenzene								
Naphthalene	13	12						
4-Chloroaniline								
Hexachlorobutadiene								
4-Chloro-3-methylphenol	26	27						
2-Methylnaphthalene			_				1	
Hexachlorocyclopentadiene								
2,4,6-Trichlorophenol								
2,4,5-Trichlorophenol						-	1	
2-Chloronaphthalene						T .		_
2-Nitroaniline							1	
Dimethylphthalate								
Acenaphthylene								
2,6-Dinitrotoluene								

Page

2 of 2

## **CLP EXTRACTABLE ORGANIC ANALYSIS**

AZ328

CASE NO. 16259 SDG NO. **ANALYTICAL RESULTS** 

Sample Location	Ciba	Clba	Ciba	Ciba	Clba	Ciba		
	Gelgy	Geigy	Gelgy	Geigy	Gelgy	Geigy		
Sample Number	MW14S	MW14S	MW11S	MW15S	MW18S			
			İ					
Traffic Report Number	AZ328	AZ329	AZ330	AZ331	AZ332	AZ333		
Remarks		Dup. AZ328				Rinsate		
				<u> </u>				
SEMI-VOLATILE COMPOUND	4							
3-Nitroaniline	ug/L	ug/L	ug/L	ug/L	ug/L	ug/L		
Acenaphthene		<del> </del>		<del> </del>	<del>                                     </del>	· ·		
<del></del>	<del>                                     </del>	<del> </del>				<del> </del>	-	
2,4-Dinitrophenol	· · · ·	<del>                                     </del>	i -	+	-		<u> </u>	
4-Nitrophenol Dibenzofuran		-	1	<del> </del>		<del> </del>		
	-	<del> </del>		<u> </u>	-	<u> </u>		<del></del>
2,4-Dinitrotoluene		<del>                                     </del>	* .	_	ļ	<del> </del>		
Diethylphthalate	<del></del>			<u> </u>		<del>                                      </del>	ļ <u></u>	
4-Chlorophenyl-phenylether				<del>-</del>	<del></del>	<u> </u>		
Fluorene		-			<u> </u>	<del></del>	ļ	
4-Nitroaniline		1.		<del> </del>	<del></del>	<del> </del>		
4,6-Dinitro-2-methylphenol				<u> </u>	<del> </del>	<del> </del>		
N-Nitrosodiphenylamine		ļ	 	<del> </del>				
4-Bromophenyl-phenylether	<del>  , -</del>	<del> </del>		<del>  :</del>				
Hexachlorobenzene	<del> </del>	-		<del> </del>				
Pentachlorophenol	<del> </del>	ļ						
Phenanthrene	<del>  .                                     </del>			<del> </del>				
Anthracene		<del> </del>		-			ļ	
Di-n-butylphthalate		<del> </del>	;	<del> </del>	ļ			
Fluoranthene	<del></del>	-		<del> </del>			<b>}</b>	
Pyrene				<del> </del>	<del> </del>		ļ	<del></del> -
Butylbenzylphthalate				<del> </del>	<del> </del>	<u> </u>	-	
3,3'-Dichlorobenzidine		<del> </del>		<u> </u>			<u> </u>	
Benzo(a)anthracene					<del> </del>			
Chrysene		<u> </u>		<u> </u>	<del> </del>		ļ	
bis(2-Ethylhexyl)phthalate		<del>                                     </del>		<del>                                       </del>	<del>                                      </del>	<u> </u>		_
Di-n-octyl phthalate	-	ļ		<del>                                     </del>	<del> </del>	· -		
Benzo(b)fluoranthene	<u> </u>	<del>                                     </del>		<del> </del>	<u> </u>	<u> </u>		
Benzo(k)fluoranthene		<del> </del>	·	<u> </u>	-	<del>                                     </del>		
Benzo(a)pyrene		<u> </u>			<del> </del>			
Indeno (1,2,3-cd)pyrene	-							
Dibenz(a,h)anthracene	<del></del>	<u> </u>		<del> </del>	<del> </del>		ļ <u>.</u>	
Benzo(g,h,i)perylene		<u> </u>		<u></u>		<u> </u>		

A blank space indicates the compound was not detected.

Quantitation is approximate due to limitations identified during the quality control review.

Value is rejected.

Result obtained through dilution.

TABLE 4 Page 1 of 2

CLP EXTRACTABLE ORGANIC ANALYSIS
CASE NO. 16259 SDG NO. AZ328
SAMPLE QUANTITATION LIMITS

Sample Location	Ciba	Ciba	Ciba	Ciba	Ciba	Ciba		Ī
	Geigy	Geigy	Geigy	Geigy	Gelgy	Gelgy		
Sample Number	MW14S	MW14S	MW11S	MW15S	MW18S			
Traffic Report Number	AZ328	AZ329	AZ330	AZ331	AZ332	AZ333		
Remarks		Dup. AZ328				Rinsate		
SEMI-VOLATILE COMPOUND	ug/L	ug/L	ug/L	ug/L	ug/L	ug/L		
Phenol	100 *	100 *	10	10	10	10		
bis (2-Chloroethyl) ether	10	10	10	10	10	10		
2-Chlorophenol	10	10	10	10	10	10		
1,3-Dichlorobenzene	10	10	10	10	10	10		
1,4-Dichlorobenzene	10	10	10	10	10	10		
Benzyl Alcohol	100 *	100 °	10	10	10	10		
1,2-Dichlorobenzene	10	10	10	10	10	10		
2-Methylphenol	100 *	100 *	10	10	10	10		<del> </del>
bis (2-Chlorolsopropyl)ether	10	10	10	10	10	10	<u> </u>	
4-Methylphenol	100 *	100 *	10	10	10	10	<u> </u>	
N-Nitroso-di-n-propylamine	10	10	10	10	10	10		-
Hexachloroethane	10	10	10	10	10	10		<del>  -</del>
Nitrobenzene	10	10	10	10	10	10		
Isophorone	10	10	10	10	10	10	†	
2-Nitrophenol	10	10	10	10	10	10		
2,4-Dimethylphenol	10	10	10	10	10	10		
Benzoic acid	500 *	500 *	50	50	50	50	†	
bis (2-Chloroethoxy) methane	10	10	10	10	10	10	<del> </del>	
2,4-Dichlorophenol	100 *	100 *	10	10	10	10	· · · · · · · · · · · · · · · · · · ·	
1,2,4-Trichlorobenzene	10	10	10	10	10	10		
Naphthalene	10	10	10	10	10	10		~
4-Chloroaniline	10 UJ	10 UJ	10 UJ	10 UJ	10 UJ	10 UJ	Ì	
Hexachlorobutadiene	10	10	10	10	10	10		
4-Chloro-3-methylphenol	10	10	10	10	10	10		
2-Methylnaphthalene	10	10	10	10	10	10	· · · · · · · · · · · · · · · · · · ·	
Hexachlorocyclopentadiene	10	10	10	10	10	10		<u> </u>
2,4,6-Trichlorophenol	10	10	10	10	10	10		
2,4,5-Trichlorophenol	50	50	50	50	50	50		T
2-Chioronaphthalene	10	10	10	10	10	10		
2-Nitroaniline	50	50	50	50	50	50		1
Dimethylphthalate	10	10	10	10	10	10		<del>                                     </del>
Acenaphthylene	10	10	10	10	10	10	<del> </del>	<del>                                     </del>
2,6-Dinitrotoluene	10	10	10	10	10	10		<del>                                     </del>

UJ Quantitation limit is approximate due to limitations identified during the quality control review.

R Value is rejected.

TABLE 4 Page 2 of 2

CLP EXTRACTABLE ORGANIC ANALYSIS
CASE NO. 16259 SDG NO. AZ328
SAMPLE QUANTITATION LIMITS

Sample Location	Ciba	Ciba	Ciba	Ciba	Clba	Ciba		
	Gelgy	Gelgy	Gelgy	Gelgy	Gelgy	Gelgy	1	
Sample Number	MW14S	MW14S	MW11S	MW15S	MW18S	, <u> </u>		
Traffic Report Number	AZ328	AZ329	AZ330	AZ331	AZ332	AZ333	<u> </u>	
Remarks		Dup. AZ328	+			Rinsate		
SEMI-VOLATILE		<del> </del>			<del> </del>	<del>                                     </del>	<del> </del>	<del>                                     </del>
COMPOUND	ug/L	ug/L	ug/L	ug/L	ug/L	ug/L		
3-Nitroaniline	50 UJ	50 W	50 UJ	50 UJ	50 UJ	50 UJ		<del>                                     </del>
Acenaphthene	10	10	10	10	10	10		· ·
2,4-Dinitrophenol	50	50	50	50	50	50	1	<u> </u>
4-Nitrophenol	50	50	50	50	50	50		1
Dibenzofuran	10	10	10	10	10	10		
2,4-Dinitrotoluene	10	10	10	10	10	10	1	
Diethylphthalate	10	10	10	10	10	10		
4-Chlorophenyl-phenylether	10	10	10	10	10	10		† · · · · ·
Fluorene	10	10	10	10	10	10		
4-Nitroaniline	50 UJ	50 UJ	50 UJ	50 UJ	50 UJ	50 UJ		
4,6-Dinitro-2-methylphenol	50	50	50	50	50	50		<del> </del>
N-Nitrosodiphenylamine	10	10	10	10	10	10		
4-Bromophenyl-phenylether	10	10	10	10	10	10		
Hexachlorobenzene	10	10	10	10	10	10		<del>                                     </del>
Pentachlorophenol	50	50	50	50	50	50		<del> </del>
Phenanthrene	10	10	10	10	10	10		
Anthracene	10	10	10	10	10	10		
Di-n-butyiphthalate	10	10	10	10	10	10		-
Fluoranthene	10	10	10	10	10	10	<del> </del>	
Pyrene	10	10	10	10	10	10		
Butylbenzylphthalate	10	10	10	10	10	10		-
3,3'-Dichlorobenzidine	20	20	20	20	20	20		
Benzo(a)anthracene	10	10	10	10	10	10	. "	<del> </del>
Chrysene	10	10	10	10	10	10		-
bis(2-Ethylhexyl)phthalate	10 U	10	10	10	10	10	<del>                                     </del>	_
Di-n-octyl phthalate	10	10	10	10	10	10	-	-
Benzo(b)fluoranthene	10	10	10	10	10	10		<del> </del>
Benzo(k)fluoranthene	10	10	10	10	10	10		<del> </del>
Benzo(a)pyrene	10	10	10	10	10	10	· · · ·	_
Indeno (1,2,3-cd)pyrene	10	10	10	10	10	10	<del> </del>	<del>                                     </del>
Dibenz(a,h)anthracene	10	10	10	10	10	10	-	<del> </del>
Benzo(g,h,i)perylene	10	10	10	10	10	10		<del>  -</del>
Pourio/Airithat Alous	) 10	110	יין	, עון	יון	יון	Ī	I

UJ Quantitation limit is approximate due to limitations identified during the quality control review.

R Value is rejected.

Elevated due to diluted value used.

5

Page

of 1

# CLP EXTRACTABLE ORGANIC ANALYSIS

CASE NO. 16259

SDG NO.

AZ328

# ANALYTICAL RESULTS

Sample Location	Ciba	Ciba	Ciba	Ciba	Ciba	Clba		
	Gelgy	Gelgy	Gelgy	Geigy	Gelgy	Gelgy		
Sample Number	MW14S	MW14S	MW11S	MW15S	MW18S			
Traffic Report Number	AZ328DL	AZ329DL	AZ330	AZ331	AZ332	AZ333		
Remarks	100X DII.	Dup. AZ328			†	Rinsate		
		100X Dil.	ł				į	
Sampling Date	04/18/91	04/18/91	04/18/91	04/18/91	04/18/91	04/18/91		
Extraction Date	04/22/91	04/22/91	04/22/91	04/22/91	04/22/91	04/22/91		
Analysis Date	05/01/91	05/02/91	04/28/91	04/28/91	04/29/91	04/30/91	<u> </u>	
PESTICIDE/PCB								
COMPOUND	ug/L_	ug/L	ug/L	ug/L	ug/L	ug/L	ļ <u></u>	
alpha-BHC							<u></u>	
beta-BHC						<u> </u>		
delta-BHC								
gamma-BHC (Lindane)			<u>.</u>					
Heptachior								
Aldrin			0.071 J	0.28 J				
Heptachlor epoxide			0.053	1.4				
Endosulfan I				I				
Dieldrin								
4,4'-DDE								1
Endrin								
Endosulfan II								
4,4'-DDD				0.32 J				
Endosulfan sulfate								
4,4'-DDT					Ī			
Methoxychlor			6.3	0.73 J				
Endrin ketone			0.14					
alpha-Chlordane						-		
gamma-Chlordane								
Toxaphene					T	1		
Aroclor-1016								
Aroclor-1221						1.		
Aroclor-1232							Ì	· .
Aroclor-1242								· · · ·
Aroclor-1248								
Aroclor-1254								
Aroclor-1260			-	1	<del>                                      </del>	<del></del>		<del></del>

A blank space indicates the compound was not detected.

Quantitation is approximate due to limitations identified during the quality control review.

R Value is rejected.

6

Page

1 of 1

# CLP EXTRACTABLE ORGANIC ANALYSIS CASE NO. 16259 SDG NO. AZ328 SAMPLE QUANTITATION LIMITS

Sample Location	Ciba	Ciba	Ciba	Ciba	Ciba	Ciba		
	Geigy	Geigy	Geigy	Geigy	Gelgy	Geigy		
Sample Number	MW14S	MW14S	MW11S	MW15S	MW18S			
Traffic Report Number	AZ328DL	AZ329DL	AZ330	AZ331	AZ332	AZ333		
Remarks	100X Dil.	Dup. AZ328 100X Dil.				Rinsate		
PESTICIDE/PCB COMPOUND	ug/L	ug/L	ug/L	ug/L	ug/L	ug/L		
alpha-BHC	5.0	5.0	0.050	0.050	0.050	0.050		
beta-BHC	5.0	5.0	0.050	0.050	0.050	0.050	<u> </u>	
delta-BHC	5.0	5.0	0.050	0.050	0.050	0.050	<u></u>	<del>                                     </del>
gamma-BHC (Lindane)	5.0	5.0	0.050	0.050	0.050	0.050	<del> </del> -	
Heptachlor	5.0	5.0	0.050	0.050	0.050	0.050		
Aldrin	5.0	5.0	0.050	0.050	0.050	0.050		
Heptachlor epoxide	5.0	5.0	0.050	0.050	0.050	0.050		
Endosulfan I	5.0	5.0	0.050	5.0 *	0.050	0.050		
Dieldrin	10	10	0.10	10 *	0.10	0.10		
4,4'-DDE	10	10	0.10	10 *	0.10	0.10		
Endrin	10	10	0.10	0.10	0.10	0.10		
Endosulfan II	10	10	0.10	0.10	0.10	0.10		
4,4'-DDD	10	10	0.10	0.10	0.10	0.10		
Endosulfan sulfate	- 10	10	0.10	0.10	0.10	0.10		
4,4'-DDT	10	10	0.10	0.10	0.10	0.10		
Methoxychlor	50	50	0.50	0.50	0.50	0.50		
Endrin ketone	10	10	0.10	0.10	0.10	0.10		
alpha-Chiordane	50	50	0.50	50 *	0.50	0.50		
gamma-Chlordane	50	50	0.50	50 *	0.50	0.50		
Toxaphene	100	100	1.0	1.0	1.0	1.0		
Aroclor-1016	50	50	0.50	0.50	0.50	0.50		
Aroclor-1221	50	50	0.50	0.50	0.50	0.50		
Aroclor-1232	50	50	0.50	0.50	0.50	0.50		
Aroclor-1242	50	50	0.50	0.50	0.50	0.50		
Aroclor-1248	50	50	0.50	0.50	0.50	0.50		
Aroclor-1254	100	100	1.0	1.0	1.0	1.0		
Aroclor-1260	100	100	1.0	1.0	1.0	1.0		

UJ Quantitation limit is approximate due to limitations identified during the quality control review.

R Value is rejected.

<sup>\*</sup> Results reported from the dilution.